

# intelbras

## **SNMP Objects and OIDs Scanning**

ITB TEAM - Special Projects

May, 13, 2024

ITB - Business Networks - Special Projects

# Summary

<b>1. Description .....</b>	<b>3</b>
<b>2. SNMP Objects and OIDs .....</b>	<b>3</b>

# 1. Description

This document presents the results of the SNMP Objects and OIDs scanning for the SC3570-48GP-6X switch. The OIDs and MiBs presented were collected using the following switch specifications:

```
1 INTELBRAS OS Software, Version 7.1.070, Release 1124
2 Copyright (C) 2023 Intelbras S.A. All rights reserved.
3 INTELBRAS SC 3570-48GP-6X uptime is 0 weeks, 0 days, 1 hour, 8 minutes
4 Last reboot reason : User reboot
5
6 Boot image: flash:/sc3570-ibos710-boot-r1124.bin
7 Boot image version: 7.1.070, Release 1124
8   Compiled Oct 25 2023 11:00:00
9 System image: flash:/sc3570-ibos710-system-r1124.bin
10 System image version: 7.1.070, Release 1124
11   Compiled Oct 25 2023 11:00:00
12
13
14 Slot 1:
15 Uptime is 0 weeks,0 days,1 hour,8 minutes
16 SC 3570-48GP-6X with 1 Processor
17 BOARD TYPE:          SC 3570-48GP-6X
18 DRAM:                1024M bytes
19 FLASH:               512M bytes
20 PCB 1 Version:       VER.A
21 Bootrom Version:     111
22 CPLD 1 Version:      002
23 Release Version:     INTELBRAS SC 3570-48GP-6X-1124
24 Patch Version :      None
25 Reboot Cause :       UserReboot
26 [SubSlot 0] 48GE+6SFP Plus
```

## 2. SNMP Objects and OIDs

Name	OID	Value Type	Value Example
sysDescr.0	.1.3.6.1.2.1.1.1.0	OctetString	INTELBRAS Platform Software, Software Version 7.1.070, Release 1124 INTELBRAS SC 3570-48GP-6X Copyright (C) 2023 Intelbras S.A. All rights reserved.
sysObjectID.0	.1.3.6.1.2.1.1.2.0	OID	ib-SC3570-48GP-6X
sysUpTime.0	.1.3.6.1.2.1.1.3.0	TimeTicks	26 minutes 7.54 seconds (156754)
sysContact.0	.1.3.6.1.2.1.1.4.0	OctetString	INTELBRAS S.A.
sysName.0	.1.3.6.1.2.1.1.5.0	OctetString	SC 3570-48GP-6X
sysLocation.0	.1.3.6.1.2.1.1.6.0	OctetString	Brazil
sysServices.0	.1.3.6.1.2.1.1.7.0	Integer	78
ifNumber.0	.1.3.6.1.2.1.2.1.0	Integer	58
ifIndex.1	.1.3.6.1.2.1.2.2.1.1.1	Integer	1

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ifIndex.2	.1.3.6.1.2.1.2.2.1.1.2	Integer	2
ifIndex.3	.1.3.6.1.2.1.2.2.1.1.3	Integer	3
ifIndex.4	.1.3.6.1.2.1.2.2.1.1.4	Integer	4
ifIndex.5	.1.3.6.1.2.1.2.2.1.1.5	Integer	5
ifIndex.6	.1.3.6.1.2.1.2.2.1.1.6	Integer	6
ifIndex.7	.1.3.6.1.2.1.2.2.1.1.7	Integer	7
ifIndex.8	.1.3.6.1.2.1.2.2.1.1.8	Integer	8
ifIndex.9	.1.3.6.1.2.1.2.2.1.1.9	Integer	9
ifIndex.10	.1.3.6.1.2.1.2.2.1.1.10	Integer	10
ifIndex.11	.1.3.6.1.2.1.2.2.1.1.11	Integer	11
ifIndex.12	.1.3.6.1.2.1.2.2.1.1.12	Integer	12
ifIndex.13	.1.3.6.1.2.1.2.2.1.1.13	Integer	13
ifIndex.14	.1.3.6.1.2.1.2.2.1.1.14	Integer	14
ifIndex.15	.1.3.6.1.2.1.2.2.1.1.15	Integer	15
ifIndex.16	.1.3.6.1.2.1.2.2.1.1.16	Integer	16
ifIndex.17	.1.3.6.1.2.1.2.2.1.1.17	Integer	17
ifIndex.18	.1.3.6.1.2.1.2.2.1.1.18	Integer	18
ifIndex.19	.1.3.6.1.2.1.2.2.1.1.19	Integer	19
ifIndex.20	.1.3.6.1.2.1.2.2.1.1.20	Integer	20
ifIndex.21	.1.3.6.1.2.1.2.2.1.1.21	Integer	21
ifIndex.22	.1.3.6.1.2.1.2.2.1.1.22	Integer	22
ifIndex.23	.1.3.6.1.2.1.2.2.1.1.23	Integer	23
ifIndex.24	.1.3.6.1.2.1.2.2.1.1.24	Integer	24
ifIndex.25	.1.3.6.1.2.1.2.2.1.1.25	Integer	25
ifIndex.26	.1.3.6.1.2.1.2.2.1.1.26	Integer	26
ifIndex.27	.1.3.6.1.2.1.2.2.1.1.27	Integer	27
ifIndex.28	.1.3.6.1.2.1.2.2.1.1.28	Integer	28
ifIndex.29	.1.3.6.1.2.1.2.2.1.1.29	Integer	29
ifIndex.30	.1.3.6.1.2.1.2.2.1.1.30	Integer	30
ifIndex.31	.1.3.6.1.2.1.2.2.1.1.31	Integer	31
ifIndex.32	.1.3.6.1.2.1.2.2.1.1.32	Integer	32
ifIndex.33	.1.3.6.1.2.1.2.2.1.1.33	Integer	33
ifIndex.34	.1.3.6.1.2.1.2.2.1.1.34	Integer	34
ifIndex.35	.1.3.6.1.2.1.2.2.1.1.35	Integer	35
ifIndex.36	.1.3.6.1.2.1.2.2.1.1.36	Integer	36
ifIndex.37	.1.3.6.1.2.1.2.2.1.1.37	Integer	37
ifIndex.38	.1.3.6.1.2.1.2.2.1.1.38	Integer	38
ifIndex.39	.1.3.6.1.2.1.2.2.1.1.39	Integer	39
ifIndex.40	.1.3.6.1.2.1.2.2.1.1.40	Integer	40
ifIndex.41	.1.3.6.1.2.1.2.2.1.1.41	Integer	41
ifIndex.42	.1.3.6.1.2.1.2.2.1.1.42	Integer	42
ifIndex.43	.1.3.6.1.2.1.2.2.1.1.43	Integer	43
ifIndex.44	.1.3.6.1.2.1.2.2.1.1.44	Integer	44

Name	OID	Value Type	Value Example
ifIndex.45	.1.3.6.1.2.1.2.2.1.1.45	Integer	45
ifIndex.46	.1.3.6.1.2.1.2.2.1.1.46	Integer	46
ifIndex.47	.1.3.6.1.2.1.2.2.1.1.47	Integer	47
ifIndex.48	.1.3.6.1.2.1.2.2.1.1.48	Integer	48
ifIndex.49	.1.3.6.1.2.1.2.2.1.1.49	Integer	49
ifIndex.50	.1.3.6.1.2.1.2.2.1.1.50	Integer	50
ifIndex.51	.1.3.6.1.2.1.2.2.1.1.51	Integer	51
ifIndex.52	.1.3.6.1.2.1.2.2.1.1.52	Integer	52
ifIndex.53	.1.3.6.1.2.1.2.2.1.1.53	Integer	53
ifIndex.54	.1.3.6.1.2.1.2.2.1.1.54	Integer	54
ifIndex.631	.1.3.6.1.2.1.2.2.1.1.631	Integer	631
ifIndex.632	.1.3.6.1.2.1.2.2.1.1.632	Integer	632
ifIndex.633	.1.3.6.1.2.1.2.2.1.1.633	Integer	633
ifIndex.634	.1.3.6.1.2.1.2.2.1.1.634	Integer	634
ifDescr.1	.1.3.6.1.2.1.2.2.1.2.1	OctetString	GigabitEthernet1/0/1
ifDescr.2	.1.3.6.1.2.1.2.2.1.2.2	OctetString	GigabitEthernet1/0/2
ifDescr.3	.1.3.6.1.2.1.2.2.1.2.3	OctetString	GigabitEthernet1/0/3
ifDescr.4	.1.3.6.1.2.1.2.2.1.2.4	OctetString	GigabitEthernet1/0/4
ifDescr.5	.1.3.6.1.2.1.2.2.1.2.5	OctetString	GigabitEthernet1/0/5
ifDescr.6	.1.3.6.1.2.1.2.2.1.2.6	OctetString	GigabitEthernet1/0/6
ifDescr.7	.1.3.6.1.2.1.2.2.1.2.7	OctetString	GigabitEthernet1/0/7
ifDescr.8	.1.3.6.1.2.1.2.2.1.2.8	OctetString	GigabitEthernet1/0/8
ifDescr.9	.1.3.6.1.2.1.2.2.1.2.9	OctetString	GigabitEthernet1/0/9
ifDescr.10	.1.3.6.1.2.1.2.2.1.2.10	OctetString	GigabitEthernet1/0/10
ifDescr.11	.1.3.6.1.2.1.2.2.1.2.11	OctetString	GigabitEthernet1/0/11
ifDescr.12	.1.3.6.1.2.1.2.2.1.2.12	OctetString	GigabitEthernet1/0/12
ifDescr.13	.1.3.6.1.2.1.2.2.1.2.13	OctetString	GigabitEthernet1/0/13
ifDescr.14	.1.3.6.1.2.1.2.2.1.2.14	OctetString	GigabitEthernet1/0/14
ifDescr.15	.1.3.6.1.2.1.2.2.1.2.15	OctetString	GigabitEthernet1/0/15
ifDescr.16	.1.3.6.1.2.1.2.2.1.2.16	OctetString	GigabitEthernet1/0/16
ifDescr.17	.1.3.6.1.2.1.2.2.1.2.17	OctetString	GigabitEthernet1/0/17
ifDescr.18	.1.3.6.1.2.1.2.2.1.2.18	OctetString	GigabitEthernet1/0/18
ifDescr.19	.1.3.6.1.2.1.2.2.1.2.19	OctetString	GigabitEthernet1/0/19
ifDescr.20	.1.3.6.1.2.1.2.2.1.2.20	OctetString	GigabitEthernet1/0/20
ifDescr.21	.1.3.6.1.2.1.2.2.1.2.21	OctetString	GigabitEthernet1/0/21
ifDescr.22	.1.3.6.1.2.1.2.2.1.2.22	OctetString	GigabitEthernet1/0/22
ifDescr.23	.1.3.6.1.2.1.2.2.1.2.23	OctetString	GigabitEthernet1/0/23
ifDescr.24	.1.3.6.1.2.1.2.2.1.2.24	OctetString	GigabitEthernet1/0/24
ifDescr.25	.1.3.6.1.2.1.2.2.1.2.25	OctetString	GigabitEthernet1/0/25
ifDescr.26	.1.3.6.1.2.1.2.2.1.2.26	OctetString	GigabitEthernet1/0/26
ifDescr.27	.1.3.6.1.2.1.2.2.1.2.27	OctetString	GigabitEthernet1/0/27
ifDescr.28	.1.3.6.1.2.1.2.2.1.2.28	OctetString	GigabitEthernet1/0/28
ifDescr.29	.1.3.6.1.2.1.2.2.1.2.29	OctetString	GigabitEthernet1/0/29

Name	OID	Value Type	Value Example
ifDescr.30	.1.3.6.1.2.1.2.2.1.2.30	OctetString	GigabitEthernet1/0/30
ifDescr.31	.1.3.6.1.2.1.2.2.1.2.31	OctetString	GigabitEthernet1/0/31
ifDescr.32	.1.3.6.1.2.1.2.2.1.2.32	OctetString	GigabitEthernet1/0/32
ifDescr.33	.1.3.6.1.2.1.2.2.1.2.33	OctetString	GigabitEthernet1/0/33
ifDescr.34	.1.3.6.1.2.1.2.2.1.2.34	OctetString	GigabitEthernet1/0/34
ifDescr.35	.1.3.6.1.2.1.2.2.1.2.35	OctetString	GigabitEthernet1/0/35
ifDescr.36	.1.3.6.1.2.1.2.2.1.2.36	OctetString	GigabitEthernet1/0/36
ifDescr.37	.1.3.6.1.2.1.2.2.1.2.37	OctetString	GigabitEthernet1/0/37
ifDescr.38	.1.3.6.1.2.1.2.2.1.2.38	OctetString	GigabitEthernet1/0/38
ifDescr.39	.1.3.6.1.2.1.2.2.1.2.39	OctetString	GigabitEthernet1/0/39
ifDescr.40	.1.3.6.1.2.1.2.2.1.2.40	OctetString	GigabitEthernet1/0/40
ifDescr.41	.1.3.6.1.2.1.2.2.1.2.41	OctetString	GigabitEthernet1/0/41
ifDescr.42	.1.3.6.1.2.1.2.2.1.2.42	OctetString	GigabitEthernet1/0/42
ifDescr.43	.1.3.6.1.2.1.2.2.1.2.43	OctetString	GigabitEthernet1/0/43
ifDescr.44	.1.3.6.1.2.1.2.2.1.2.44	OctetString	GigabitEthernet1/0/44
ifDescr.45	.1.3.6.1.2.1.2.2.1.2.45	OctetString	GigabitEthernet1/0/45
ifDescr.46	.1.3.6.1.2.1.2.2.1.2.46	OctetString	GigabitEthernet1/0/46
ifDescr.47	.1.3.6.1.2.1.2.2.1.2.47	OctetString	GigabitEthernet1/0/47
ifDescr.48	.1.3.6.1.2.1.2.2.1.2.48	OctetString	GigabitEthernet1/0/48
ifDescr.49	.1.3.6.1.2.1.2.2.1.2.49	OctetString	Ten-GigabitEthernet1/0/49
ifDescr.50	.1.3.6.1.2.1.2.2.1.2.50	OctetString	Ten-GigabitEthernet1/0/50
ifDescr.51	.1.3.6.1.2.1.2.2.1.2.51	OctetString	Ten-GigabitEthernet1/0/51
ifDescr.52	.1.3.6.1.2.1.2.2.1.2.52	OctetString	Ten-GigabitEthernet1/0/52
ifDescr.53	.1.3.6.1.2.1.2.2.1.2.53	OctetString	Ten-GigabitEthernet1/0/53
ifDescr.54	.1.3.6.1.2.1.2.2.1.2.54	OctetString	Ten-GigabitEthernet1/0/54
ifDescr.631	.1.3.6.1.2.1.2.2.1.2.631	OctetString	NULL0
ifDescr.632	.1.3.6.1.2.1.2.2.1.2.632	OctetString	InLoopBack0
ifDescr.633	.1.3.6.1.2.1.2.2.1.2.633	OctetString	Register-Tunnel0
ifDescr.634	.1.3.6.1.2.1.2.2.1.2.634	OctetString	Vlan-interface1
ifType.1	.1.3.6.1.2.1.2.2.1.3.1	Integer	ethernet-csmacd (6)
ifType.2	.1.3.6.1.2.1.2.2.1.3.2	Integer	ethernet-csmacd (6)
ifType.3	.1.3.6.1.2.1.2.2.1.3.3	Integer	ethernet-csmacd (6)
ifType.4	.1.3.6.1.2.1.2.2.1.3.4	Integer	ethernet-csmacd (6)
ifType.5	.1.3.6.1.2.1.2.2.1.3.5	Integer	ethernet-csmacd (6)
ifType.6	.1.3.6.1.2.1.2.2.1.3.6	Integer	ethernet-csmacd (6)
ifType.7	.1.3.6.1.2.1.2.2.1.3.7	Integer	ethernet-csmacd (6)
ifType.8	.1.3.6.1.2.1.2.2.1.3.8	Integer	ethernet-csmacd (6)
ifType.9	.1.3.6.1.2.1.2.2.1.3.9	Integer	ethernet-csmacd (6)
ifType.10	.1.3.6.1.2.1.2.2.1.3.10	Integer	ethernet-csmacd (6)
ifType.11	.1.3.6.1.2.1.2.2.1.3.11	Integer	ethernet-csmacd (6)
ifType.12	.1.3.6.1.2.1.2.2.1.3.12	Integer	ethernet-csmacd (6)
ifType.13	.1.3.6.1.2.1.2.2.1.3.13	Integer	ethernet-csmacd (6)
ifType.14	.1.3.6.1.2.1.2.2.1.3.14	Integer	ethernet-csmacd (6)

Name	OID	Value Type	Value Example
ifType.15	.1.3.6.1.2.1.2.2.1.3.15	Integer	ethernet-csmacd (6)
ifType.16	.1.3.6.1.2.1.2.2.1.3.16	Integer	ethernet-csmacd (6)
ifType.17	.1.3.6.1.2.1.2.2.1.3.17	Integer	ethernet-csmacd (6)
ifType.18	.1.3.6.1.2.1.2.2.1.3.18	Integer	ethernet-csmacd (6)
ifType.19	.1.3.6.1.2.1.2.2.1.3.19	Integer	ethernet-csmacd (6)
ifType.20	.1.3.6.1.2.1.2.2.1.3.20	Integer	ethernet-csmacd (6)
ifType.21	.1.3.6.1.2.1.2.2.1.3.21	Integer	ethernet-csmacd (6)
ifType.22	.1.3.6.1.2.1.2.2.1.3.22	Integer	ethernet-csmacd (6)
ifType.23	.1.3.6.1.2.1.2.2.1.3.23	Integer	ethernet-csmacd (6)
ifType.24	.1.3.6.1.2.1.2.2.1.3.24	Integer	ethernet-csmacd (6)
ifType.25	.1.3.6.1.2.1.2.2.1.3.25	Integer	ethernet-csmacd (6)
ifType.26	.1.3.6.1.2.1.2.2.1.3.26	Integer	ethernet-csmacd (6)
ifType.27	.1.3.6.1.2.1.2.2.1.3.27	Integer	ethernet-csmacd (6)
ifType.28	.1.3.6.1.2.1.2.2.1.3.28	Integer	ethernet-csmacd (6)
ifType.29	.1.3.6.1.2.1.2.2.1.3.29	Integer	ethernet-csmacd (6)
ifType.30	.1.3.6.1.2.1.2.2.1.3.30	Integer	ethernet-csmacd (6)
ifType.31	.1.3.6.1.2.1.2.2.1.3.31	Integer	ethernet-csmacd (6)
ifType.32	.1.3.6.1.2.1.2.2.1.3.32	Integer	ethernet-csmacd (6)
ifType.33	.1.3.6.1.2.1.2.2.1.3.33	Integer	ethernet-csmacd (6)
ifType.34	.1.3.6.1.2.1.2.2.1.3.34	Integer	ethernet-csmacd (6)
ifType.35	.1.3.6.1.2.1.2.2.1.3.35	Integer	ethernet-csmacd (6)
ifType.36	.1.3.6.1.2.1.2.2.1.3.36	Integer	ethernet-csmacd (6)
ifType.37	.1.3.6.1.2.1.2.2.1.3.37	Integer	ethernet-csmacd (6)
ifType.38	.1.3.6.1.2.1.2.2.1.3.38	Integer	ethernet-csmacd (6)
ifType.39	.1.3.6.1.2.1.2.2.1.3.39	Integer	ethernet-csmacd (6)
ifType.40	.1.3.6.1.2.1.2.2.1.3.40	Integer	ethernet-csmacd (6)
ifType.41	.1.3.6.1.2.1.2.2.1.3.41	Integer	ethernet-csmacd (6)
ifType.42	.1.3.6.1.2.1.2.2.1.3.42	Integer	ethernet-csmacd (6)
ifType.43	.1.3.6.1.2.1.2.2.1.3.43	Integer	ethernet-csmacd (6)
ifType.44	.1.3.6.1.2.1.2.2.1.3.44	Integer	ethernet-csmacd (6)
ifType.45	.1.3.6.1.2.1.2.2.1.3.45	Integer	ethernet-csmacd (6)
ifType.46	.1.3.6.1.2.1.2.2.1.3.46	Integer	ethernet-csmacd (6)
ifType.47	.1.3.6.1.2.1.2.2.1.3.47	Integer	ethernet-csmacd (6)
ifType.48	.1.3.6.1.2.1.2.2.1.3.48	Integer	ethernet-csmacd (6)
ifType.49	.1.3.6.1.2.1.2.2.1.3.49	Integer	ethernet-csmacd (6)
ifType.50	.1.3.6.1.2.1.2.2.1.3.50	Integer	ethernet-csmacd (6)
ifType.51	.1.3.6.1.2.1.2.2.1.3.51	Integer	ethernet-csmacd (6)
ifType.52	.1.3.6.1.2.1.2.2.1.3.52	Integer	ethernet-csmacd (6)
ifType.53	.1.3.6.1.2.1.2.2.1.3.53	Integer	ethernet-csmacd (6)
ifType.54	.1.3.6.1.2.1.2.2.1.3.54	Integer	ethernet-csmacd (6)
ifType.631	.1.3.6.1.2.1.2.2.1.3.631	Integer	other (1)
ifType.632	.1.3.6.1.2.1.2.2.1.3.632	Integer	softwareLoopback (24)
ifType.633	.1.3.6.1.2.1.2.2.1.3.633	Integer	other (1)

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ifType.634	.1.3.6.1.2.1.2.2.1.3.634	Integer	136
ifMtu.1	.1.3.6.1.2.1.2.2.1.4.1	Integer	12288
ifMtu.2	.1.3.6.1.2.1.2.2.1.4.2	Integer	12288
ifMtu.3	.1.3.6.1.2.1.2.2.1.4.3	Integer	12288
ifMtu.4	.1.3.6.1.2.1.2.2.1.4.4	Integer	12288
ifMtu.5	.1.3.6.1.2.1.2.2.1.4.5	Integer	12288
ifMtu.6	.1.3.6.1.2.1.2.2.1.4.6	Integer	12288
ifMtu.7	.1.3.6.1.2.1.2.2.1.4.7	Integer	12288
ifMtu.8	.1.3.6.1.2.1.2.2.1.4.8	Integer	12288
ifMtu.9	.1.3.6.1.2.1.2.2.1.4.9	Integer	12288
ifMtu.10	.1.3.6.1.2.1.2.2.1.4.10	Integer	12288
ifMtu.11	.1.3.6.1.2.1.2.2.1.4.11	Integer	12288
ifMtu.12	.1.3.6.1.2.1.2.2.1.4.12	Integer	12288
ifMtu.13	.1.3.6.1.2.1.2.2.1.4.13	Integer	12288
ifMtu.14	.1.3.6.1.2.1.2.2.1.4.14	Integer	12288
ifMtu.15	.1.3.6.1.2.1.2.2.1.4.15	Integer	12288
ifMtu.16	.1.3.6.1.2.1.2.2.1.4.16	Integer	12288
ifMtu.17	.1.3.6.1.2.1.2.2.1.4.17	Integer	12288
ifMtu.18	.1.3.6.1.2.1.2.2.1.4.18	Integer	12288
ifMtu.19	.1.3.6.1.2.1.2.2.1.4.19	Integer	12288
ifMtu.20	.1.3.6.1.2.1.2.2.1.4.20	Integer	12288
ifMtu.21	.1.3.6.1.2.1.2.2.1.4.21	Integer	12288
ifMtu.22	.1.3.6.1.2.1.2.2.1.4.22	Integer	12288
ifMtu.23	.1.3.6.1.2.1.2.2.1.4.23	Integer	12288
ifMtu.24	.1.3.6.1.2.1.2.2.1.4.24	Integer	12288
ifMtu.25	.1.3.6.1.2.1.2.2.1.4.25	Integer	12288
ifMtu.26	.1.3.6.1.2.1.2.2.1.4.26	Integer	12288
ifMtu.27	.1.3.6.1.2.1.2.2.1.4.27	Integer	12288
ifMtu.28	.1.3.6.1.2.1.2.2.1.4.28	Integer	12288
ifMtu.29	.1.3.6.1.2.1.2.2.1.4.29	Integer	12288
ifMtu.30	.1.3.6.1.2.1.2.2.1.4.30	Integer	12288
ifMtu.31	.1.3.6.1.2.1.2.2.1.4.31	Integer	12288
ifMtu.32	.1.3.6.1.2.1.2.2.1.4.32	Integer	12288
ifMtu.33	.1.3.6.1.2.1.2.2.1.4.33	Integer	12288
ifMtu.34	.1.3.6.1.2.1.2.2.1.4.34	Integer	12288
ifMtu.35	.1.3.6.1.2.1.2.2.1.4.35	Integer	12288
ifMtu.36	.1.3.6.1.2.1.2.2.1.4.36	Integer	12288
ifMtu.37	.1.3.6.1.2.1.2.2.1.4.37	Integer	12288
ifMtu.38	.1.3.6.1.2.1.2.2.1.4.38	Integer	12288
ifMtu.39	.1.3.6.1.2.1.2.2.1.4.39	Integer	12288
ifMtu.40	.1.3.6.1.2.1.2.2.1.4.40	Integer	12288
ifMtu.41	.1.3.6.1.2.1.2.2.1.4.41	Integer	12288
ifMtu.42	.1.3.6.1.2.1.2.2.1.4.42	Integer	12288



Name	OID	Value Type	Value Example
ifMtu.43	.1.3.6.1.2.1.2.2.1.4.43	Integer	12288
ifMtu.44	.1.3.6.1.2.1.2.2.1.4.44	Integer	12288
ifMtu.45	.1.3.6.1.2.1.2.2.1.4.45	Integer	12288
ifMtu.46	.1.3.6.1.2.1.2.2.1.4.46	Integer	12288
ifMtu.47	.1.3.6.1.2.1.2.2.1.4.47	Integer	12288
ifMtu.48	.1.3.6.1.2.1.2.2.1.4.48	Integer	12288
ifMtu.49	.1.3.6.1.2.1.2.2.1.4.49	Integer	12288
ifMtu.50	.1.3.6.1.2.1.2.2.1.4.50	Integer	12288
ifMtu.51	.1.3.6.1.2.1.2.2.1.4.51	Integer	12288
ifMtu.52	.1.3.6.1.2.1.2.2.1.4.52	Integer	12288
ifMtu.53	.1.3.6.1.2.1.2.2.1.4.53	Integer	12288
ifMtu.54	.1.3.6.1.2.1.2.2.1.4.54	Integer	12288
ifMtu.631	.1.3.6.1.2.1.2.2.1.4.631	Integer	1500
ifMtu.632	.1.3.6.1.2.1.2.2.1.4.632	Integer	1536
ifMtu.633	.1.3.6.1.2.1.2.2.1.4.633	Integer	1536
ifMtu.634	.1.3.6.1.2.1.2.2.1.4.634	Integer	1500
ifSpeed.1	.1.3.6.1.2.1.2.2.1.5.1	Gauge	1000000000
ifSpeed.2	.1.3.6.1.2.1.2.2.1.5.2	Gauge	1000000000
ifSpeed.3	.1.3.6.1.2.1.2.2.1.5.3	Gauge	1000000000
ifSpeed.4	.1.3.6.1.2.1.2.2.1.5.4	Gauge	1000000000
ifSpeed.5	.1.3.6.1.2.1.2.2.1.5.5	Gauge	1000000000
ifSpeed.6	.1.3.6.1.2.1.2.2.1.5.6	Gauge	1000000000
ifSpeed.7	.1.3.6.1.2.1.2.2.1.5.7	Gauge	1000000000
ifSpeed.8	.1.3.6.1.2.1.2.2.1.5.8	Gauge	1000000000
ifSpeed.9	.1.3.6.1.2.1.2.2.1.5.9	Gauge	1000000000
ifSpeed.10	.1.3.6.1.2.1.2.2.1.5.10	Gauge	1000000000
ifSpeed.11	.1.3.6.1.2.1.2.2.1.5.11	Gauge	1000000000
ifSpeed.12	.1.3.6.1.2.1.2.2.1.5.12	Gauge	1000000000
ifSpeed.13	.1.3.6.1.2.1.2.2.1.5.13	Gauge	1000000000
ifSpeed.14	.1.3.6.1.2.1.2.2.1.5.14	Gauge	1000000000
ifSpeed.15	.1.3.6.1.2.1.2.2.1.5.15	Gauge	1000000000
ifSpeed.16	.1.3.6.1.2.1.2.2.1.5.16	Gauge	1000000000
ifSpeed.17	.1.3.6.1.2.1.2.2.1.5.17	Gauge	1000000000
ifSpeed.18	.1.3.6.1.2.1.2.2.1.5.18	Gauge	1000000000
ifSpeed.19	.1.3.6.1.2.1.2.2.1.5.19	Gauge	1000000000
ifSpeed.20	.1.3.6.1.2.1.2.2.1.5.20	Gauge	1000000000
ifSpeed.21	.1.3.6.1.2.1.2.2.1.5.21	Gauge	1000000000
ifSpeed.22	.1.3.6.1.2.1.2.2.1.5.22	Gauge	1000000000
ifSpeed.23	.1.3.6.1.2.1.2.2.1.5.23	Gauge	1000000000
ifSpeed.24	.1.3.6.1.2.1.2.2.1.5.24	Gauge	1000000000
ifSpeed.25	.1.3.6.1.2.1.2.2.1.5.25	Gauge	1000000000
ifSpeed.26	.1.3.6.1.2.1.2.2.1.5.26	Gauge	1000000000
ifSpeed.27	.1.3.6.1.2.1.2.2.1.5.27	Gauge	1000000000

Name	OID	Value Type	Value Example
ifSpeed.28	.1.3.6.1.2.1.2.2.1.5.28	Gauge	1000000000
ifSpeed.29	.1.3.6.1.2.1.2.2.1.5.29	Gauge	1000000000
ifSpeed.30	.1.3.6.1.2.1.2.2.1.5.30	Gauge	1000000000
ifSpeed.31	.1.3.6.1.2.1.2.2.1.5.31	Gauge	1000000000
ifSpeed.32	.1.3.6.1.2.1.2.2.1.5.32	Gauge	1000000000
ifSpeed.33	.1.3.6.1.2.1.2.2.1.5.33	Gauge	1000000000
ifSpeed.34	.1.3.6.1.2.1.2.2.1.5.34	Gauge	1000000000
ifSpeed.35	.1.3.6.1.2.1.2.2.1.5.35	Gauge	1000000000
ifSpeed.36	.1.3.6.1.2.1.2.2.1.5.36	Gauge	1000000000
ifSpeed.37	.1.3.6.1.2.1.2.2.1.5.37	Gauge	1000000000
ifSpeed.38	.1.3.6.1.2.1.2.2.1.5.38	Gauge	1000000000
ifSpeed.39	.1.3.6.1.2.1.2.2.1.5.39	Gauge	1000000000
ifSpeed.40	.1.3.6.1.2.1.2.2.1.5.40	Gauge	1000000000
ifSpeed.41	.1.3.6.1.2.1.2.2.1.5.41	Gauge	1000000000
ifSpeed.42	.1.3.6.1.2.1.2.2.1.5.42	Gauge	1000000000
ifSpeed.43	.1.3.6.1.2.1.2.2.1.5.43	Gauge	1000000000
ifSpeed.44	.1.3.6.1.2.1.2.2.1.5.44	Gauge	1000000000
ifSpeed.45	.1.3.6.1.2.1.2.2.1.5.45	Gauge	1000000000
ifSpeed.46	.1.3.6.1.2.1.2.2.1.5.46	Gauge	1000000000
ifSpeed.47	.1.3.6.1.2.1.2.2.1.5.47	Gauge	1000000000
ifSpeed.48	.1.3.6.1.2.1.2.2.1.5.48	Gauge	1000000000
ifSpeed.49	.1.3.6.1.2.1.2.2.1.5.49	Gauge	4294967295
ifSpeed.50	.1.3.6.1.2.1.2.2.1.5.50	Gauge	4294967295
ifSpeed.51	.1.3.6.1.2.1.2.2.1.5.51	Gauge	4294967295
ifSpeed.52	.1.3.6.1.2.1.2.2.1.5.52	Gauge	4294967295
ifSpeed.53	.1.3.6.1.2.1.2.2.1.5.53	Gauge	4294967295
ifSpeed.54	.1.3.6.1.2.1.2.2.1.5.54	Gauge	4294967295
ifSpeed.631	.1.3.6.1.2.1.2.2.1.5.631	Gauge	1000000000
ifSpeed.632	.1.3.6.1.2.1.2.2.1.5.632	Gauge	0
ifSpeed.633	.1.3.6.1.2.1.2.2.1.5.633	Gauge	0
ifSpeed.634	.1.3.6.1.2.1.2.2.1.5.634	Gauge	4294967295
ifPhysAddress.1	.1.3.6.1.2.1.2.2.1.6.1	OctetString	14-84-77-95-1D-DA
ifPhysAddress.2	.1.3.6.1.2.1.2.2.1.6.2	OctetString	14-84-77-95-1D-DB
ifPhysAddress.3	.1.3.6.1.2.1.2.2.1.6.3	OctetString	14-84-77-95-1D-DC
ifPhysAddress.4	.1.3.6.1.2.1.2.2.1.6.4	OctetString	14-84-77-95-1D-DD
ifPhysAddress.5	.1.3.6.1.2.1.2.2.1.6.5	OctetString	14-84-77-95-1D-DE
ifPhysAddress.6	.1.3.6.1.2.1.2.2.1.6.6	OctetString	14-84-77-95-1D-DF
ifPhysAddress.7	.1.3.6.1.2.1.2.2.1.6.7	OctetString	14-84-77-95-1D-E0
ifPhysAddress.8	.1.3.6.1.2.1.2.2.1.6.8	OctetString	14-84-77-95-1D-E1
ifPhysAddress.9	.1.3.6.1.2.1.2.2.1.6.9	OctetString	14-84-77-95-1D-E2
ifPhysAddress.10	.1.3.6.1.2.1.2.2.1.6.10	OctetString	14-84-77-95-1D-E3
ifPhysAddress.11	.1.3.6.1.2.1.2.2.1.6.11	OctetString	14-84-77-95-1D-E4
ifPhysAddress.12	.1.3.6.1.2.1.2.2.1.6.12	OctetString	14-84-77-95-1D-E5

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ifPhysAddress.13	.1.3.6.1.2.1.2.2.1.6.13	OctetString	14-84-77-95-1D-E6
ifPhysAddress.14	.1.3.6.1.2.1.2.2.1.6.14	OctetString	14-84-77-95-1D-E7
ifPhysAddress.15	.1.3.6.1.2.1.2.2.1.6.15	OctetString	14-84-77-95-1D-E8
ifPhysAddress.16	.1.3.6.1.2.1.2.2.1.6.16	OctetString	14-84-77-95-1D-E9
ifPhysAddress.17	.1.3.6.1.2.1.2.2.1.6.17	OctetString	14-84-77-95-1D-EA
ifPhysAddress.18	.1.3.6.1.2.1.2.2.1.6.18	OctetString	14-84-77-95-1D-EB
ifPhysAddress.19	.1.3.6.1.2.1.2.2.1.6.19	OctetString	14-84-77-95-1D-EC
ifPhysAddress.20	.1.3.6.1.2.1.2.2.1.6.20	OctetString	14-84-77-95-1D-ED
ifPhysAddress.21	.1.3.6.1.2.1.2.2.1.6.21	OctetString	14-84-77-95-1D-EE
ifPhysAddress.22	.1.3.6.1.2.1.2.2.1.6.22	OctetString	14-84-77-95-1D-EF
ifPhysAddress.23	.1.3.6.1.2.1.2.2.1.6.23	OctetString	14-84-77-95-1D-F0
ifPhysAddress.24	.1.3.6.1.2.1.2.2.1.6.24	OctetString	14-84-77-95-1D-F1
ifPhysAddress.25	.1.3.6.1.2.1.2.2.1.6.25	OctetString	14-84-77-95-1D-F2
ifPhysAddress.26	.1.3.6.1.2.1.2.2.1.6.26	OctetString	14-84-77-95-1D-F3
ifPhysAddress.27	.1.3.6.1.2.1.2.2.1.6.27	OctetString	14-84-77-95-1D-F4
ifPhysAddress.28	.1.3.6.1.2.1.2.2.1.6.28	OctetString	14-84-77-95-1D-F5
ifPhysAddress.29	.1.3.6.1.2.1.2.2.1.6.29	OctetString	14-84-77-95-1D-F6
ifPhysAddress.30	.1.3.6.1.2.1.2.2.1.6.30	OctetString	14-84-77-95-1D-F7
ifPhysAddress.31	.1.3.6.1.2.1.2.2.1.6.31	OctetString	14-84-77-95-1D-F8
ifPhysAddress.32	.1.3.6.1.2.1.2.2.1.6.32	OctetString	14-84-77-95-1D-F9
ifPhysAddress.33	.1.3.6.1.2.1.2.2.1.6.33	OctetString	14-84-77-95-1D-FA
ifPhysAddress.34	.1.3.6.1.2.1.2.2.1.6.34	OctetString	14-84-77-95-1D-FB
ifPhysAddress.35	.1.3.6.1.2.1.2.2.1.6.35	OctetString	14-84-77-95-1D-FC
ifPhysAddress.36	.1.3.6.1.2.1.2.2.1.6.36	OctetString	14-84-77-95-1D-FD
ifPhysAddress.37	.1.3.6.1.2.1.2.2.1.6.37	OctetString	14-84-77-95-1D-FE
ifPhysAddress.38	.1.3.6.1.2.1.2.2.1.6.38	OctetString	14-84-77-95-1D-FF
ifPhysAddress.39	.1.3.6.1.2.1.2.2.1.6.39	OctetString	14-84-77-95-1E-00
ifPhysAddress.40	.1.3.6.1.2.1.2.2.1.6.40	OctetString	14-84-77-95-1E-01
ifPhysAddress.41	.1.3.6.1.2.1.2.2.1.6.41	OctetString	14-84-77-95-1E-02
ifPhysAddress.42	.1.3.6.1.2.1.2.2.1.6.42	OctetString	14-84-77-95-1E-03
ifPhysAddress.43	.1.3.6.1.2.1.2.2.1.6.43	OctetString	14-84-77-95-1E-04
ifPhysAddress.44	.1.3.6.1.2.1.2.2.1.6.44	OctetString	14-84-77-95-1E-05
ifPhysAddress.45	.1.3.6.1.2.1.2.2.1.6.45	OctetString	14-84-77-95-1E-06
ifPhysAddress.46	.1.3.6.1.2.1.2.2.1.6.46	OctetString	14-84-77-95-1E-07
ifPhysAddress.47	.1.3.6.1.2.1.2.2.1.6.47	OctetString	14-84-77-95-1E-08
ifPhysAddress.48	.1.3.6.1.2.1.2.2.1.6.48	OctetString	14-84-77-95-1E-09
ifPhysAddress.49	.1.3.6.1.2.1.2.2.1.6.49	OctetString	14-84-77-95-1E-0A
ifPhysAddress.50	.1.3.6.1.2.1.2.2.1.6.50	OctetString	14-84-77-95-1E-0B
ifPhysAddress.51	.1.3.6.1.2.1.2.2.1.6.51	OctetString	14-84-77-95-1E-0C
ifPhysAddress.52	.1.3.6.1.2.1.2.2.1.6.52	OctetString	14-84-77-95-1E-0D
ifPhysAddress.53	.1.3.6.1.2.1.2.2.1.6.53	OctetString	14-84-77-95-1E-0E
ifPhysAddress.54	.1.3.6.1.2.1.2.2.1.6.54	OctetString	14-84-77-95-1E-0F
ifPhysAddress.631	.1.3.6.1.2.1.2.2.1.6.631	OctetString	00-00-00-00-00-00

Name	OID	Value Type	Value Example
ifPhysAddress.632	.1.3.6.1.2.1.2.2.1.6.632	OctetString	00-00-00-00-00-00
ifPhysAddress.633	.1.3.6.1.2.1.2.2.1.6.633	OctetString	00-00-00-00-00-00
ifPhysAddress.634	.1.3.6.1.2.1.2.2.1.6.634	OctetString	14-84-77-95-1D-BB
ifAdminStatus.1	.1.3.6.1.2.1.2.2.1.7.1	Integer	up (1)
ifAdminStatus.2	.1.3.6.1.2.1.2.2.1.7.2	Integer	up (1)
ifAdminStatus.3	.1.3.6.1.2.1.2.2.1.7.3	Integer	up (1)
ifAdminStatus.4	.1.3.6.1.2.1.2.2.1.7.4	Integer	up (1)
ifAdminStatus.5	.1.3.6.1.2.1.2.2.1.7.5	Integer	up (1)
ifAdminStatus.6	.1.3.6.1.2.1.2.2.1.7.6	Integer	up (1)
ifAdminStatus.7	.1.3.6.1.2.1.2.2.1.7.7	Integer	up (1)
ifAdminStatus.8	.1.3.6.1.2.1.2.2.1.7.8	Integer	up (1)
ifAdminStatus.9	.1.3.6.1.2.1.2.2.1.7.9	Integer	up (1)
ifAdminStatus.10	.1.3.6.1.2.1.2.2.1.7.10	Integer	up (1)
ifAdminStatus.11	.1.3.6.1.2.1.2.2.1.7.11	Integer	up (1)
ifAdminStatus.12	.1.3.6.1.2.1.2.2.1.7.12	Integer	up (1)
ifAdminStatus.13	.1.3.6.1.2.1.2.2.1.7.13	Integer	up (1)
ifAdminStatus.14	.1.3.6.1.2.1.2.2.1.7.14	Integer	up (1)
ifAdminStatus.15	.1.3.6.1.2.1.2.2.1.7.15	Integer	up (1)
ifAdminStatus.16	.1.3.6.1.2.1.2.2.1.7.16	Integer	up (1)
ifAdminStatus.17	.1.3.6.1.2.1.2.2.1.7.17	Integer	up (1)
ifAdminStatus.18	.1.3.6.1.2.1.2.2.1.7.18	Integer	up (1)
ifAdminStatus.19	.1.3.6.1.2.1.2.2.1.7.19	Integer	up (1)
ifAdminStatus.20	.1.3.6.1.2.1.2.2.1.7.20	Integer	up (1)
ifAdminStatus.21	.1.3.6.1.2.1.2.2.1.7.21	Integer	up (1)
ifAdminStatus.22	.1.3.6.1.2.1.2.2.1.7.22	Integer	up (1)
ifAdminStatus.23	.1.3.6.1.2.1.2.2.1.7.23	Integer	up (1)
ifAdminStatus.24	.1.3.6.1.2.1.2.2.1.7.24	Integer	up (1)
ifAdminStatus.25	.1.3.6.1.2.1.2.2.1.7.25	Integer	up (1)
ifAdminStatus.26	.1.3.6.1.2.1.2.2.1.7.26	Integer	up (1)
ifAdminStatus.27	.1.3.6.1.2.1.2.2.1.7.27	Integer	up (1)
ifAdminStatus.28	.1.3.6.1.2.1.2.2.1.7.28	Integer	up (1)
ifAdminStatus.29	.1.3.6.1.2.1.2.2.1.7.29	Integer	up (1)
ifAdminStatus.30	.1.3.6.1.2.1.2.2.1.7.30	Integer	up (1)
ifAdminStatus.31	.1.3.6.1.2.1.2.2.1.7.31	Integer	up (1)
ifAdminStatus.32	.1.3.6.1.2.1.2.2.1.7.32	Integer	up (1)
ifAdminStatus.33	.1.3.6.1.2.1.2.2.1.7.33	Integer	up (1)
ifAdminStatus.34	.1.3.6.1.2.1.2.2.1.7.34	Integer	up (1)
ifAdminStatus.35	.1.3.6.1.2.1.2.2.1.7.35	Integer	up (1)
ifAdminStatus.36	.1.3.6.1.2.1.2.2.1.7.36	Integer	up (1)
ifAdminStatus.37	.1.3.6.1.2.1.2.2.1.7.37	Integer	up (1)
ifAdminStatus.38	.1.3.6.1.2.1.2.2.1.7.38	Integer	up (1)
ifAdminStatus.39	.1.3.6.1.2.1.2.2.1.7.39	Integer	up (1)
ifAdminStatus.40	.1.3.6.1.2.1.2.2.1.7.40	Integer	up (1)

Name	OID	Value Type	Value Example
ifAdminStatus.41	.1.3.6.1.2.1.2.2.1.7.41	Integer	up (1)
ifAdminStatus.42	.1.3.6.1.2.1.2.2.1.7.42	Integer	up (1)
ifAdminStatus.43	.1.3.6.1.2.1.2.2.1.7.43	Integer	up (1)
ifAdminStatus.44	.1.3.6.1.2.1.2.2.1.7.44	Integer	up (1)
ifAdminStatus.45	.1.3.6.1.2.1.2.2.1.7.45	Integer	up (1)
ifAdminStatus.46	.1.3.6.1.2.1.2.2.1.7.46	Integer	up (1)
ifAdminStatus.47	.1.3.6.1.2.1.2.2.1.7.47	Integer	up (1)
ifAdminStatus.48	.1.3.6.1.2.1.2.2.1.7.48	Integer	up (1)
ifAdminStatus.49	.1.3.6.1.2.1.2.2.1.7.49	Integer	up (1)
ifAdminStatus.50	.1.3.6.1.2.1.2.2.1.7.50	Integer	up (1)
ifAdminStatus.51	.1.3.6.1.2.1.2.2.1.7.51	Integer	up (1)
ifAdminStatus.52	.1.3.6.1.2.1.2.2.1.7.52	Integer	up (1)
ifAdminStatus.53	.1.3.6.1.2.1.2.2.1.7.53	Integer	up (1)
ifAdminStatus.54	.1.3.6.1.2.1.2.2.1.7.54	Integer	up (1)
ifAdminStatus.631	.1.3.6.1.2.1.2.2.1.7.631	Integer	up (1)
ifAdminStatus.632	.1.3.6.1.2.1.2.2.1.7.632	Integer	up (1)
ifAdminStatus.633	.1.3.6.1.2.1.2.2.1.7.633	Integer	up (1)
ifAdminStatus.634	.1.3.6.1.2.1.2.2.1.7.634	Integer	up (1)
ifOperStatus.1	.1.3.6.1.2.1.2.2.1.8.1	Integer	up (1)
ifOperStatus.2	.1.3.6.1.2.1.2.2.1.8.2	Integer	down (2)
ifOperStatus.3	.1.3.6.1.2.1.2.2.1.8.3	Integer	down (2)
ifOperStatus.4	.1.3.6.1.2.1.2.2.1.8.4	Integer	down (2)
ifOperStatus.5	.1.3.6.1.2.1.2.2.1.8.5	Integer	down (2)
ifOperStatus.6	.1.3.6.1.2.1.2.2.1.8.6	Integer	down (2)
ifOperStatus.7	.1.3.6.1.2.1.2.2.1.8.7	Integer	down (2)
ifOperStatus.8	.1.3.6.1.2.1.2.2.1.8.8	Integer	down (2)
ifOperStatus.9	.1.3.6.1.2.1.2.2.1.8.9	Integer	down (2)
ifOperStatus.10	.1.3.6.1.2.1.2.2.1.8.10	Integer	down (2)
ifOperStatus.11	.1.3.6.1.2.1.2.2.1.8.11	Integer	down (2)
ifOperStatus.12	.1.3.6.1.2.1.2.2.1.8.12	Integer	down (2)
ifOperStatus.13	.1.3.6.1.2.1.2.2.1.8.13	Integer	down (2)
ifOperStatus.14	.1.3.6.1.2.1.2.2.1.8.14	Integer	down (2)
ifOperStatus.15	.1.3.6.1.2.1.2.2.1.8.15	Integer	down (2)
ifOperStatus.16	.1.3.6.1.2.1.2.2.1.8.16	Integer	down (2)
ifOperStatus.17	.1.3.6.1.2.1.2.2.1.8.17	Integer	down (2)
ifOperStatus.18	.1.3.6.1.2.1.2.2.1.8.18	Integer	down (2)
ifOperStatus.19	.1.3.6.1.2.1.2.2.1.8.19	Integer	down (2)
ifOperStatus.20	.1.3.6.1.2.1.2.2.1.8.20	Integer	down (2)
ifOperStatus.21	.1.3.6.1.2.1.2.2.1.8.21	Integer	down (2)
ifOperStatus.22	.1.3.6.1.2.1.2.2.1.8.22	Integer	down (2)
ifOperStatus.23	.1.3.6.1.2.1.2.2.1.8.23	Integer	down (2)
ifOperStatus.24	.1.3.6.1.2.1.2.2.1.8.24	Integer	down (2)
ifOperStatus.25	.1.3.6.1.2.1.2.2.1.8.25	Integer	down (2)

Name	OID	Value Type	Value Example
ifOperStatus.26	.1.3.6.1.2.1.2.2.1.8.26	Integer	down (2)
ifOperStatus.27	.1.3.6.1.2.1.2.2.1.8.27	Integer	down (2)
ifOperStatus.28	.1.3.6.1.2.1.2.2.1.8.28	Integer	down (2)
ifOperStatus.29	.1.3.6.1.2.1.2.2.1.8.29	Integer	down (2)
ifOperStatus.30	.1.3.6.1.2.1.2.2.1.8.30	Integer	down (2)
ifOperStatus.31	.1.3.6.1.2.1.2.2.1.8.31	Integer	down (2)
ifOperStatus.32	.1.3.6.1.2.1.2.2.1.8.32	Integer	down (2)
ifOperStatus.33	.1.3.6.1.2.1.2.2.1.8.33	Integer	down (2)
ifOperStatus.34	.1.3.6.1.2.1.2.2.1.8.34	Integer	down (2)
ifOperStatus.35	.1.3.6.1.2.1.2.2.1.8.35	Integer	down (2)
ifOperStatus.36	.1.3.6.1.2.1.2.2.1.8.36	Integer	down (2)
ifOperStatus.37	.1.3.6.1.2.1.2.2.1.8.37	Integer	down (2)
ifOperStatus.38	.1.3.6.1.2.1.2.2.1.8.38	Integer	down (2)
ifOperStatus.39	.1.3.6.1.2.1.2.2.1.8.39	Integer	down (2)
ifOperStatus.40	.1.3.6.1.2.1.2.2.1.8.40	Integer	down (2)
ifOperStatus.41	.1.3.6.1.2.1.2.2.1.8.41	Integer	down (2)
ifOperStatus.42	.1.3.6.1.2.1.2.2.1.8.42	Integer	down (2)
ifOperStatus.43	.1.3.6.1.2.1.2.2.1.8.43	Integer	down (2)
ifOperStatus.44	.1.3.6.1.2.1.2.2.1.8.44	Integer	down (2)
ifOperStatus.45	.1.3.6.1.2.1.2.2.1.8.45	Integer	down (2)
ifOperStatus.46	.1.3.6.1.2.1.2.2.1.8.46	Integer	down (2)
ifOperStatus.47	.1.3.6.1.2.1.2.2.1.8.47	Integer	down (2)
ifOperStatus.48	.1.3.6.1.2.1.2.2.1.8.48	Integer	down (2)
ifOperStatus.49	.1.3.6.1.2.1.2.2.1.8.49	Integer	down (2)
ifOperStatus.50	.1.3.6.1.2.1.2.2.1.8.50	Integer	down (2)
ifOperStatus.51	.1.3.6.1.2.1.2.2.1.8.51	Integer	down (2)
ifOperStatus.52	.1.3.6.1.2.1.2.2.1.8.52	Integer	down (2)
ifOperStatus.53	.1.3.6.1.2.1.2.2.1.8.53	Integer	down (2)
ifOperStatus.54	.1.3.6.1.2.1.2.2.1.8.54	Integer	down (2)
ifOperStatus.631	.1.3.6.1.2.1.2.2.1.8.631	Integer	up (1)
ifOperStatus.632	.1.3.6.1.2.1.2.2.1.8.632	Integer	up (1)
ifOperStatus.633	.1.3.6.1.2.1.2.2.1.8.633	Integer	up (1)
ifOperStatus.634	.1.3.6.1.2.1.2.2.1.8.634	Integer	up (1)
ifLastChange.1	.1.3.6.1.2.1.2.2.1.9.1	TimeTicks	23 minutes 15.27 seconds (139527)
ifLastChange.2	.1.3.6.1.2.1.2.2.1.9.2	TimeTicks	1 minute 58.19 seconds (11819)
ifLastChange.3	.1.3.6.1.2.1.2.2.1.9.3	TimeTicks	1 minute 58.19 seconds (11819)
ifLastChange.4	.1.3.6.1.2.1.2.2.1.9.4	TimeTicks	1 minute 58.19 seconds (11819)
ifLastChange.5	.1.3.6.1.2.1.2.2.1.9.5	TimeTicks	1 minute 58.19 seconds (11819)
ifLastChange.6	.1.3.6.1.2.1.2.2.1.9.6	TimeTicks	1 minute 58.2 seconds (11820)
ifLastChange.7	.1.3.6.1.2.1.2.2.1.9.7	TimeTicks	1 minute 58.2 seconds (11820)
ifLastChange.8	.1.3.6.1.2.1.2.2.1.9.8	TimeTicks	1 minute 58.2 seconds (11820)
ifLastChange.9	.1.3.6.1.2.1.2.2.1.9.9	TimeTicks	1 minute 58.2 seconds (11820)



Name	OID	Value Type	Value Example
ifLastChange.53	.1.3.6.1.2.1.2.2.1.9.53	TimeTicks	1 minute 58.2 seconds (11820)
ifLastChange.54	.1.3.6.1.2.1.2.2.1.9.54	TimeTicks	1 minute 58.22 seconds (11822)
ifLastChange.631	.1.3.6.1.2.1.2.2.1.9.631	TimeTicks	1 minute 58.2 seconds (11820)
ifLastChange.632	.1.3.6.1.2.1.2.2.1.9.632	TimeTicks	3 minutes 42.03 seconds (22203)
ifLastChange.633	.1.3.6.1.2.1.2.2.1.9.633	TimeTicks	1 minute 58.13 seconds (11813)
ifLastChange.634	.1.3.6.1.2.1.2.2.1.9.634	TimeTicks	23 minutes 15.3 seconds (139530)
ifInOctets.1	.1.3.6.1.2.1.2.2.1.10.1	Counter32	3424228
ifInOctets.2	.1.3.6.1.2.1.2.2.1.10.2	Counter32	0
ifInOctets.3	.1.3.6.1.2.1.2.2.1.10.3	Counter32	0
ifInOctets.4	.1.3.6.1.2.1.2.2.1.10.4	Counter32	0
ifInOctets.5	.1.3.6.1.2.1.2.2.1.10.5	Counter32	0
ifInOctets.6	.1.3.6.1.2.1.2.2.1.10.6	Counter32	0
ifInOctets.7	.1.3.6.1.2.1.2.2.1.10.7	Counter32	0
ifInOctets.8	.1.3.6.1.2.1.2.2.1.10.8	Counter32	0
ifInOctets.9	.1.3.6.1.2.1.2.2.1.10.9	Counter32	0
ifInOctets.10	.1.3.6.1.2.1.2.2.1.10.10	Counter32	0
ifInOctets.11	.1.3.6.1.2.1.2.2.1.10.11	Counter32	0
ifInOctets.12	.1.3.6.1.2.1.2.2.1.10.12	Counter32	0
ifInOctets.13	.1.3.6.1.2.1.2.2.1.10.13	Counter32	0
ifInOctets.14	.1.3.6.1.2.1.2.2.1.10.14	Counter32	0
ifInOctets.15	.1.3.6.1.2.1.2.2.1.10.15	Counter32	0
ifInOctets.16	.1.3.6.1.2.1.2.2.1.10.16	Counter32	0
ifInOctets.17	.1.3.6.1.2.1.2.2.1.10.17	Counter32	0
ifInOctets.18	.1.3.6.1.2.1.2.2.1.10.18	Counter32	0
ifInOctets.19	.1.3.6.1.2.1.2.2.1.10.19	Counter32	0
ifInOctets.20	.1.3.6.1.2.1.2.2.1.10.20	Counter32	0
ifInOctets.21	.1.3.6.1.2.1.2.2.1.10.21	Counter32	0
ifInOctets.22	.1.3.6.1.2.1.2.2.1.10.22	Counter32	0
ifInOctets.23	.1.3.6.1.2.1.2.2.1.10.23	Counter32	0
ifInOctets.24	.1.3.6.1.2.1.2.2.1.10.24	Counter32	0
ifInOctets.25	.1.3.6.1.2.1.2.2.1.10.25	Counter32	0
ifInOctets.26	.1.3.6.1.2.1.2.2.1.10.26	Counter32	0
ifInOctets.27	.1.3.6.1.2.1.2.2.1.10.27	Counter32	0
ifInOctets.28	.1.3.6.1.2.1.2.2.1.10.28	Counter32	0
ifInOctets.29	.1.3.6.1.2.1.2.2.1.10.29	Counter32	0
ifInOctets.30	.1.3.6.1.2.1.2.2.1.10.30	Counter32	0
ifInOctets.31	.1.3.6.1.2.1.2.2.1.10.31	Counter32	0
ifInOctets.32	.1.3.6.1.2.1.2.2.1.10.32	Counter32	0
ifInOctets.33	.1.3.6.1.2.1.2.2.1.10.33	Counter32	0
ifInOctets.34	.1.3.6.1.2.1.2.2.1.10.34	Counter32	0
ifInOctets.35	.1.3.6.1.2.1.2.2.1.10.35	Counter32	0



<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
iflInOctets.36	.1.3.6.1.2.1.2.2.1.10.36	Counter32	0
iflInOctets.37	.1.3.6.1.2.1.2.2.1.10.37	Counter32	0
iflInOctets.38	.1.3.6.1.2.1.2.2.1.10.38	Counter32	0
iflInOctets.39	.1.3.6.1.2.1.2.2.1.10.39	Counter32	0
iflInOctets.40	.1.3.6.1.2.1.2.2.1.10.40	Counter32	0
iflInOctets.41	.1.3.6.1.2.1.2.2.1.10.41	Counter32	0
iflInOctets.42	.1.3.6.1.2.1.2.2.1.10.42	Counter32	0
iflInOctets.43	.1.3.6.1.2.1.2.2.1.10.43	Counter32	0
iflInOctets.44	.1.3.6.1.2.1.2.2.1.10.44	Counter32	0
iflInOctets.45	.1.3.6.1.2.1.2.2.1.10.45	Counter32	0
iflInOctets.46	.1.3.6.1.2.1.2.2.1.10.46	Counter32	0
iflInOctets.47	.1.3.6.1.2.1.2.2.1.10.47	Counter32	0
iflInOctets.48	.1.3.6.1.2.1.2.2.1.10.48	Counter32	0
iflInOctets.49	.1.3.6.1.2.1.2.2.1.10.49	Counter32	0
iflInOctets.50	.1.3.6.1.2.1.2.2.1.10.50	Counter32	0
iflInOctets.51	.1.3.6.1.2.1.2.2.1.10.51	Counter32	0
iflInOctets.52	.1.3.6.1.2.1.2.2.1.10.52	Counter32	0
iflInOctets.53	.1.3.6.1.2.1.2.2.1.10.53	Counter32	0
iflInOctets.54	.1.3.6.1.2.1.2.2.1.10.54	Counter32	0
iflInOctets.631	.1.3.6.1.2.1.2.2.1.10.631	Counter32	0
iflInOctets.632	.1.3.6.1.2.1.2.2.1.10.632	Counter32	0
iflInOctets.633	.1.3.6.1.2.1.2.2.1.10.633	Counter32	0
iflInOctets.634	.1.3.6.1.2.1.2.2.1.10.634	Counter32	0
iflInUcastPkts.1	.1.3.6.1.2.1.2.2.1.11.1	Counter32	5588
iflInUcastPkts.2	.1.3.6.1.2.1.2.2.1.11.2	Counter32	0
iflInUcastPkts.3	.1.3.6.1.2.1.2.2.1.11.3	Counter32	0
iflInUcastPkts.4	.1.3.6.1.2.1.2.2.1.11.4	Counter32	0
iflInUcastPkts.5	.1.3.6.1.2.1.2.2.1.11.5	Counter32	0
iflInUcastPkts.6	.1.3.6.1.2.1.2.2.1.11.6	Counter32	0
iflInUcastPkts.7	.1.3.6.1.2.1.2.2.1.11.7	Counter32	0
iflInUcastPkts.8	.1.3.6.1.2.1.2.2.1.11.8	Counter32	0
iflInUcastPkts.9	.1.3.6.1.2.1.2.2.1.11.9	Counter32	0
iflInUcastPkts.10	.1.3.6.1.2.1.2.2.1.11.10	Counter32	0
iflInUcastPkts.11	.1.3.6.1.2.1.2.2.1.11.11	Counter32	0
iflInUcastPkts.12	.1.3.6.1.2.1.2.2.1.11.12	Counter32	0
iflInUcastPkts.13	.1.3.6.1.2.1.2.2.1.11.13	Counter32	0
iflInUcastPkts.14	.1.3.6.1.2.1.2.2.1.11.14	Counter32	0
iflInUcastPkts.15	.1.3.6.1.2.1.2.2.1.11.15	Counter32	0
iflInUcastPkts.16	.1.3.6.1.2.1.2.2.1.11.16	Counter32	0
iflInUcastPkts.17	.1.3.6.1.2.1.2.2.1.11.17	Counter32	0
iflInUcastPkts.18	.1.3.6.1.2.1.2.2.1.11.18	Counter32	0
iflInUcastPkts.19	.1.3.6.1.2.1.2.2.1.11.19	Counter32	0
iflInUcastPkts.20	.1.3.6.1.2.1.2.2.1.11.20	Counter32	0

Name	OID	Value Type	Value Example
ifInUcastPkts.21	.1.3.6.1.2.1.2.2.1.11.21	Counter32	0
ifInUcastPkts.22	.1.3.6.1.2.1.2.2.1.11.22	Counter32	0
ifInUcastPkts.23	.1.3.6.1.2.1.2.2.1.11.23	Counter32	0
ifInUcastPkts.24	.1.3.6.1.2.1.2.2.1.11.24	Counter32	0
ifInUcastPkts.25	.1.3.6.1.2.1.2.2.1.11.25	Counter32	0
ifInUcastPkts.26	.1.3.6.1.2.1.2.2.1.11.26	Counter32	0
ifInUcastPkts.27	.1.3.6.1.2.1.2.2.1.11.27	Counter32	0
ifInUcastPkts.28	.1.3.6.1.2.1.2.2.1.11.28	Counter32	0
ifInUcastPkts.29	.1.3.6.1.2.1.2.2.1.11.29	Counter32	0
ifInUcastPkts.30	.1.3.6.1.2.1.2.2.1.11.30	Counter32	0
ifInUcastPkts.31	.1.3.6.1.2.1.2.2.1.11.31	Counter32	0
ifInUcastPkts.32	.1.3.6.1.2.1.2.2.1.11.32	Counter32	0
ifInUcastPkts.33	.1.3.6.1.2.1.2.2.1.11.33	Counter32	0
ifInUcastPkts.34	.1.3.6.1.2.1.2.2.1.11.34	Counter32	0
ifInUcastPkts.35	.1.3.6.1.2.1.2.2.1.11.35	Counter32	0
ifInUcastPkts.36	.1.3.6.1.2.1.2.2.1.11.36	Counter32	0
ifInUcastPkts.37	.1.3.6.1.2.1.2.2.1.11.37	Counter32	0
ifInUcastPkts.38	.1.3.6.1.2.1.2.2.1.11.38	Counter32	0
ifInUcastPkts.39	.1.3.6.1.2.1.2.2.1.11.39	Counter32	0
ifInUcastPkts.40	.1.3.6.1.2.1.2.2.1.11.40	Counter32	0
ifInUcastPkts.41	.1.3.6.1.2.1.2.2.1.11.41	Counter32	0
ifInUcastPkts.42	.1.3.6.1.2.1.2.2.1.11.42	Counter32	0
ifInUcastPkts.43	.1.3.6.1.2.1.2.2.1.11.43	Counter32	0
ifInUcastPkts.44	.1.3.6.1.2.1.2.2.1.11.44	Counter32	0
ifInUcastPkts.45	.1.3.6.1.2.1.2.2.1.11.45	Counter32	0
ifInUcastPkts.46	.1.3.6.1.2.1.2.2.1.11.46	Counter32	0
ifInUcastPkts.47	.1.3.6.1.2.1.2.2.1.11.47	Counter32	0
ifInUcastPkts.48	.1.3.6.1.2.1.2.2.1.11.48	Counter32	0
ifInUcastPkts.49	.1.3.6.1.2.1.2.2.1.11.49	Counter32	0
ifInUcastPkts.50	.1.3.6.1.2.1.2.2.1.11.50	Counter32	0
ifInUcastPkts.51	.1.3.6.1.2.1.2.2.1.11.51	Counter32	0
ifInUcastPkts.52	.1.3.6.1.2.1.2.2.1.11.52	Counter32	0
ifInUcastPkts.53	.1.3.6.1.2.1.2.2.1.11.53	Counter32	0
ifInUcastPkts.54	.1.3.6.1.2.1.2.2.1.11.54	Counter32	0
ifInUcastPkts.634	.1.3.6.1.2.1.2.2.1.11.634	Counter32	0
ifInNUcastPkts.1	.1.3.6.1.2.1.2.2.1.12.1	Counter32	38898
ifInNUcastPkts.2	.1.3.6.1.2.1.2.2.1.12.2	Counter32	0
ifInNUcastPkts.3	.1.3.6.1.2.1.2.2.1.12.3	Counter32	0
ifInNUcastPkts.4	.1.3.6.1.2.1.2.2.1.12.4	Counter32	0
ifInNUcastPkts.5	.1.3.6.1.2.1.2.2.1.12.5	Counter32	0
ifInNUcastPkts.6	.1.3.6.1.2.1.2.2.1.12.6	Counter32	0
ifInNUcastPkts.7	.1.3.6.1.2.1.2.2.1.12.7	Counter32	0
ifInNUcastPkts.8	.1.3.6.1.2.1.2.2.1.12.8	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ifInNUcastPkts.9	.1.3.6.1.2.1.2.2.1.12.9	Counter32	0
ifInNUcastPkts.10	.1.3.6.1.2.1.2.2.1.12.10	Counter32	0
ifInNUcastPkts.11	.1.3.6.1.2.1.2.2.1.12.11	Counter32	0
ifInNUcastPkts.12	.1.3.6.1.2.1.2.2.1.12.12	Counter32	0
ifInNUcastPkts.13	.1.3.6.1.2.1.2.2.1.12.13	Counter32	0
ifInNUcastPkts.14	.1.3.6.1.2.1.2.2.1.12.14	Counter32	0
ifInNUcastPkts.15	.1.3.6.1.2.1.2.2.1.12.15	Counter32	0
ifInNUcastPkts.16	.1.3.6.1.2.1.2.2.1.12.16	Counter32	0
ifInNUcastPkts.17	.1.3.6.1.2.1.2.2.1.12.17	Counter32	0
ifInNUcastPkts.18	.1.3.6.1.2.1.2.2.1.12.18	Counter32	0
ifInNUcastPkts.19	.1.3.6.1.2.1.2.2.1.12.19	Counter32	0
ifInNUcastPkts.20	.1.3.6.1.2.1.2.2.1.12.20	Counter32	0
ifInNUcastPkts.21	.1.3.6.1.2.1.2.2.1.12.21	Counter32	0
ifInNUcastPkts.22	.1.3.6.1.2.1.2.2.1.12.22	Counter32	0
ifInNUcastPkts.23	.1.3.6.1.2.1.2.2.1.12.23	Counter32	0
ifInNUcastPkts.24	.1.3.6.1.2.1.2.2.1.12.24	Counter32	0
ifInNUcastPkts.25	.1.3.6.1.2.1.2.2.1.12.25	Counter32	0
ifInNUcastPkts.26	.1.3.6.1.2.1.2.2.1.12.26	Counter32	0
ifInNUcastPkts.27	.1.3.6.1.2.1.2.2.1.12.27	Counter32	0
ifInNUcastPkts.28	.1.3.6.1.2.1.2.2.1.12.28	Counter32	0
ifInNUcastPkts.29	.1.3.6.1.2.1.2.2.1.12.29	Counter32	0
ifInNUcastPkts.30	.1.3.6.1.2.1.2.2.1.12.30	Counter32	0
ifInNUcastPkts.31	.1.3.6.1.2.1.2.2.1.12.31	Counter32	0
ifInNUcastPkts.32	.1.3.6.1.2.1.2.2.1.12.32	Counter32	0
ifInNUcastPkts.33	.1.3.6.1.2.1.2.2.1.12.33	Counter32	0
ifInNUcastPkts.34	.1.3.6.1.2.1.2.2.1.12.34	Counter32	0
ifInNUcastPkts.35	.1.3.6.1.2.1.2.2.1.12.35	Counter32	0
ifInNUcastPkts.36	.1.3.6.1.2.1.2.2.1.12.36	Counter32	0
ifInNUcastPkts.37	.1.3.6.1.2.1.2.2.1.12.37	Counter32	0
ifInNUcastPkts.38	.1.3.6.1.2.1.2.2.1.12.38	Counter32	0
ifInNUcastPkts.39	.1.3.6.1.2.1.2.2.1.12.39	Counter32	0
ifInNUcastPkts.40	.1.3.6.1.2.1.2.2.1.12.40	Counter32	0
ifInNUcastPkts.41	.1.3.6.1.2.1.2.2.1.12.41	Counter32	0
ifInNUcastPkts.42	.1.3.6.1.2.1.2.2.1.12.42	Counter32	0
ifInNUcastPkts.43	.1.3.6.1.2.1.2.2.1.12.43	Counter32	0
ifInNUcastPkts.44	.1.3.6.1.2.1.2.2.1.12.44	Counter32	0
ifInNUcastPkts.45	.1.3.6.1.2.1.2.2.1.12.45	Counter32	0
ifInNUcastPkts.46	.1.3.6.1.2.1.2.2.1.12.46	Counter32	0
ifInNUcastPkts.47	.1.3.6.1.2.1.2.2.1.12.47	Counter32	0
ifInNUcastPkts.48	.1.3.6.1.2.1.2.2.1.12.48	Counter32	0
ifInNUcastPkts.49	.1.3.6.1.2.1.2.2.1.12.49	Counter32	0
ifInNUcastPkts.50	.1.3.6.1.2.1.2.2.1.12.50	Counter32	0
ifInNUcastPkts.51	.1.3.6.1.2.1.2.2.1.12.51	Counter32	0

Name	OID	Value Type	Value Example
ifInNUcastPkts.52	.1.3.6.1.2.1.2.2.1.12.52	Counter32	0
ifInNUcastPkts.53	.1.3.6.1.2.1.2.2.1.12.53	Counter32	0
ifInNUcastPkts.54	.1.3.6.1.2.1.2.2.1.12.54	Counter32	0
ifInNUcastPkts.634	.1.3.6.1.2.1.2.2.1.12.634	Counter32	0
ifInDiscards.1	.1.3.6.1.2.1.2.2.1.13.1	Counter32	8371
ifInDiscards.2	.1.3.6.1.2.1.2.2.1.13.2	Counter32	0
ifInDiscards.3	.1.3.6.1.2.1.2.2.1.13.3	Counter32	0
ifInDiscards.4	.1.3.6.1.2.1.2.2.1.13.4	Counter32	0
ifInDiscards.5	.1.3.6.1.2.1.2.2.1.13.5	Counter32	0
ifInDiscards.6	.1.3.6.1.2.1.2.2.1.13.6	Counter32	0
ifInDiscards.7	.1.3.6.1.2.1.2.2.1.13.7	Counter32	0
ifInDiscards.8	.1.3.6.1.2.1.2.2.1.13.8	Counter32	0
ifInDiscards.9	.1.3.6.1.2.1.2.2.1.13.9	Counter32	0
ifInDiscards.10	.1.3.6.1.2.1.2.2.1.13.10	Counter32	0
ifInDiscards.11	.1.3.6.1.2.1.2.2.1.13.11	Counter32	0
ifInDiscards.12	.1.3.6.1.2.1.2.2.1.13.12	Counter32	0
ifInDiscards.13	.1.3.6.1.2.1.2.2.1.13.13	Counter32	0
ifInDiscards.14	.1.3.6.1.2.1.2.2.1.13.14	Counter32	0
ifInDiscards.15	.1.3.6.1.2.1.2.2.1.13.15	Counter32	0
ifInDiscards.16	.1.3.6.1.2.1.2.2.1.13.16	Counter32	0
ifInDiscards.17	.1.3.6.1.2.1.2.2.1.13.17	Counter32	0
ifInDiscards.18	.1.3.6.1.2.1.2.2.1.13.18	Counter32	0
ifInDiscards.19	.1.3.6.1.2.1.2.2.1.13.19	Counter32	0
ifInDiscards.20	.1.3.6.1.2.1.2.2.1.13.20	Counter32	0
ifInDiscards.21	.1.3.6.1.2.1.2.2.1.13.21	Counter32	0
ifInDiscards.22	.1.3.6.1.2.1.2.2.1.13.22	Counter32	0
ifInDiscards.23	.1.3.6.1.2.1.2.2.1.13.23	Counter32	0
ifInDiscards.24	.1.3.6.1.2.1.2.2.1.13.24	Counter32	0
ifInDiscards.25	.1.3.6.1.2.1.2.2.1.13.25	Counter32	0
ifInDiscards.26	.1.3.6.1.2.1.2.2.1.13.26	Counter32	0
ifInDiscards.27	.1.3.6.1.2.1.2.2.1.13.27	Counter32	0
ifInDiscards.28	.1.3.6.1.2.1.2.2.1.13.28	Counter32	0
ifInDiscards.29	.1.3.6.1.2.1.2.2.1.13.29	Counter32	0
ifInDiscards.30	.1.3.6.1.2.1.2.2.1.13.30	Counter32	0
ifInDiscards.31	.1.3.6.1.2.1.2.2.1.13.31	Counter32	0
ifInDiscards.32	.1.3.6.1.2.1.2.2.1.13.32	Counter32	0
ifInDiscards.33	.1.3.6.1.2.1.2.2.1.13.33	Counter32	0
ifInDiscards.34	.1.3.6.1.2.1.2.2.1.13.34	Counter32	0
ifInDiscards.35	.1.3.6.1.2.1.2.2.1.13.35	Counter32	0
ifInDiscards.36	.1.3.6.1.2.1.2.2.1.13.36	Counter32	0
ifInDiscards.37	.1.3.6.1.2.1.2.2.1.13.37	Counter32	0
ifInDiscards.38	.1.3.6.1.2.1.2.2.1.13.38	Counter32	0
ifInDiscards.39	.1.3.6.1.2.1.2.2.1.13.39	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ifInDiscards.40	.1.3.6.1.2.1.2.2.1.13.40	Counter32	0
ifInDiscards.41	.1.3.6.1.2.1.2.2.1.13.41	Counter32	0
ifInDiscards.42	.1.3.6.1.2.1.2.2.1.13.42	Counter32	0
ifInDiscards.43	.1.3.6.1.2.1.2.2.1.13.43	Counter32	0
ifInDiscards.44	.1.3.6.1.2.1.2.2.1.13.44	Counter32	0
ifInDiscards.45	.1.3.6.1.2.1.2.2.1.13.45	Counter32	0
ifInDiscards.46	.1.3.6.1.2.1.2.2.1.13.46	Counter32	0
ifInDiscards.47	.1.3.6.1.2.1.2.2.1.13.47	Counter32	0
ifInDiscards.48	.1.3.6.1.2.1.2.2.1.13.48	Counter32	0
ifInDiscards.49	.1.3.6.1.2.1.2.2.1.13.49	Counter32	0
ifInDiscards.50	.1.3.6.1.2.1.2.2.1.13.50	Counter32	0
ifInDiscards.51	.1.3.6.1.2.1.2.2.1.13.51	Counter32	0
ifInDiscards.52	.1.3.6.1.2.1.2.2.1.13.52	Counter32	0
ifInDiscards.53	.1.3.6.1.2.1.2.2.1.13.53	Counter32	0
ifInDiscards.54	.1.3.6.1.2.1.2.2.1.13.54	Counter32	0
ifInDiscards.631	.1.3.6.1.2.1.2.2.1.13.631	Counter32	0
ifInDiscards.632	.1.3.6.1.2.1.2.2.1.13.632	Counter32	0
ifInDiscards.633	.1.3.6.1.2.1.2.2.1.13.633	Counter32	0
ifInDiscards.634	.1.3.6.1.2.1.2.2.1.13.634	Counter32	0
ifInErrors.1	.1.3.6.1.2.1.2.2.1.14.1	Counter32	0
ifInErrors.2	.1.3.6.1.2.1.2.2.1.14.2	Counter32	0
ifInErrors.3	.1.3.6.1.2.1.2.2.1.14.3	Counter32	0
ifInErrors.4	.1.3.6.1.2.1.2.2.1.14.4	Counter32	0
ifInErrors.5	.1.3.6.1.2.1.2.2.1.14.5	Counter32	0
ifInErrors.6	.1.3.6.1.2.1.2.2.1.14.6	Counter32	0
ifInErrors.7	.1.3.6.1.2.1.2.2.1.14.7	Counter32	0
ifInErrors.8	.1.3.6.1.2.1.2.2.1.14.8	Counter32	0
ifInErrors.9	.1.3.6.1.2.1.2.2.1.14.9	Counter32	0
ifInErrors.10	.1.3.6.1.2.1.2.2.1.14.10	Counter32	0
ifInErrors.11	.1.3.6.1.2.1.2.2.1.14.11	Counter32	0
ifInErrors.12	.1.3.6.1.2.1.2.2.1.14.12	Counter32	0
ifInErrors.13	.1.3.6.1.2.1.2.2.1.14.13	Counter32	0
ifInErrors.14	.1.3.6.1.2.1.2.2.1.14.14	Counter32	0
ifInErrors.15	.1.3.6.1.2.1.2.2.1.14.15	Counter32	0
ifInErrors.16	.1.3.6.1.2.1.2.2.1.14.16	Counter32	0
ifInErrors.17	.1.3.6.1.2.1.2.2.1.14.17	Counter32	0
ifInErrors.18	.1.3.6.1.2.1.2.2.1.14.18	Counter32	0
ifInErrors.19	.1.3.6.1.2.1.2.2.1.14.19	Counter32	0
ifInErrors.20	.1.3.6.1.2.1.2.2.1.14.20	Counter32	0
ifInErrors.21	.1.3.6.1.2.1.2.2.1.14.21	Counter32	0
ifInErrors.22	.1.3.6.1.2.1.2.2.1.14.22	Counter32	0
ifInErrors.23	.1.3.6.1.2.1.2.2.1.14.23	Counter32	0
ifInErrors.24	.1.3.6.1.2.1.2.2.1.14.24	Counter32	0

Name	OID	Value Type	Value Example
ifInErrors.25	.1.3.6.1.2.1.2.2.1.14.25	Counter32	0
ifInErrors.26	.1.3.6.1.2.1.2.2.1.14.26	Counter32	0
ifInErrors.27	.1.3.6.1.2.1.2.2.1.14.27	Counter32	0
ifInErrors.28	.1.3.6.1.2.1.2.2.1.14.28	Counter32	0
ifInErrors.29	.1.3.6.1.2.1.2.2.1.14.29	Counter32	0
ifInErrors.30	.1.3.6.1.2.1.2.2.1.14.30	Counter32	0
ifInErrors.31	.1.3.6.1.2.1.2.2.1.14.31	Counter32	0
ifInErrors.32	.1.3.6.1.2.1.2.2.1.14.32	Counter32	0
ifInErrors.33	.1.3.6.1.2.1.2.2.1.14.33	Counter32	0
ifInErrors.34	.1.3.6.1.2.1.2.2.1.14.34	Counter32	0
ifInErrors.35	.1.3.6.1.2.1.2.2.1.14.35	Counter32	0
ifInErrors.36	.1.3.6.1.2.1.2.2.1.14.36	Counter32	0
ifInErrors.37	.1.3.6.1.2.1.2.2.1.14.37	Counter32	0
ifInErrors.38	.1.3.6.1.2.1.2.2.1.14.38	Counter32	0
ifInErrors.39	.1.3.6.1.2.1.2.2.1.14.39	Counter32	0
ifInErrors.40	.1.3.6.1.2.1.2.2.1.14.40	Counter32	0
ifInErrors.41	.1.3.6.1.2.1.2.2.1.14.41	Counter32	0
ifInErrors.42	.1.3.6.1.2.1.2.2.1.14.42	Counter32	0
ifInErrors.43	.1.3.6.1.2.1.2.2.1.14.43	Counter32	0
ifInErrors.44	.1.3.6.1.2.1.2.2.1.14.44	Counter32	0
ifInErrors.45	.1.3.6.1.2.1.2.2.1.14.45	Counter32	0
ifInErrors.46	.1.3.6.1.2.1.2.2.1.14.46	Counter32	0
ifInErrors.47	.1.3.6.1.2.1.2.2.1.14.47	Counter32	0
ifInErrors.48	.1.3.6.1.2.1.2.2.1.14.48	Counter32	0
ifInErrors.49	.1.3.6.1.2.1.2.2.1.14.49	Counter32	0
ifInErrors.50	.1.3.6.1.2.1.2.2.1.14.50	Counter32	0
ifInErrors.51	.1.3.6.1.2.1.2.2.1.14.51	Counter32	0
ifInErrors.52	.1.3.6.1.2.1.2.2.1.14.52	Counter32	0
ifInErrors.53	.1.3.6.1.2.1.2.2.1.14.53	Counter32	0
ifInErrors.54	.1.3.6.1.2.1.2.2.1.14.54	Counter32	0
ifInErrors.634	.1.3.6.1.2.1.2.2.1.14.634	Counter32	0
ifInUnknownProtos.1	.1.3.6.1.2.1.2.2.1.15.1	Counter32	116
ifInUnknownProtos.2	.1.3.6.1.2.1.2.2.1.15.2	Counter32	0
ifInUnknownProtos.3	.1.3.6.1.2.1.2.2.1.15.3	Counter32	0
ifInUnknownProtos.4	.1.3.6.1.2.1.2.2.1.15.4	Counter32	0
ifInUnknownProtos.5	.1.3.6.1.2.1.2.2.1.15.5	Counter32	0
ifInUnknownProtos.6	.1.3.6.1.2.1.2.2.1.15.6	Counter32	0
ifInUnknownProtos.7	.1.3.6.1.2.1.2.2.1.15.7	Counter32	0
ifInUnknownProtos.8	.1.3.6.1.2.1.2.2.1.15.8	Counter32	0
ifInUnknownProtos.9	.1.3.6.1.2.1.2.2.1.15.9	Counter32	0
ifInUnknownProtos.10	.1.3.6.1.2.1.2.2.1.15.10	Counter32	0
ifInUnknownProtos.11	.1.3.6.1.2.1.2.2.1.15.11	Counter32	0
ifInUnknownProtos.12	.1.3.6.1.2.1.2.2.1.15.12	Counter32	0

Name	OID	Value Type	Value Example
ifInUnknownProtos.13	.1.3.6.1.2.1.2.2.1.15.13	Counter32	0
ifInUnknownProtos.14	.1.3.6.1.2.1.2.2.1.15.14	Counter32	0
ifInUnknownProtos.15	.1.3.6.1.2.1.2.2.1.15.15	Counter32	0
ifInUnknownProtos.16	.1.3.6.1.2.1.2.2.1.15.16	Counter32	0
ifInUnknownProtos.17	.1.3.6.1.2.1.2.2.1.15.17	Counter32	0
ifInUnknownProtos.18	.1.3.6.1.2.1.2.2.1.15.18	Counter32	0
ifInUnknownProtos.19	.1.3.6.1.2.1.2.2.1.15.19	Counter32	0
ifInUnknownProtos.20	.1.3.6.1.2.1.2.2.1.15.20	Counter32	0
ifInUnknownProtos.21	.1.3.6.1.2.1.2.2.1.15.21	Counter32	0
ifInUnknownProtos.22	.1.3.6.1.2.1.2.2.1.15.22	Counter32	0
ifInUnknownProtos.23	.1.3.6.1.2.1.2.2.1.15.23	Counter32	0
ifInUnknownProtos.24	.1.3.6.1.2.1.2.2.1.15.24	Counter32	0
ifInUnknownProtos.25	.1.3.6.1.2.1.2.2.1.15.25	Counter32	0
ifInUnknownProtos.26	.1.3.6.1.2.1.2.2.1.15.26	Counter32	0
ifInUnknownProtos.27	.1.3.6.1.2.1.2.2.1.15.27	Counter32	0
ifInUnknownProtos.28	.1.3.6.1.2.1.2.2.1.15.28	Counter32	0
ifInUnknownProtos.29	.1.3.6.1.2.1.2.2.1.15.29	Counter32	0
ifInUnknownProtos.30	.1.3.6.1.2.1.2.2.1.15.30	Counter32	0
ifInUnknownProtos.31	.1.3.6.1.2.1.2.2.1.15.31	Counter32	0
ifInUnknownProtos.32	.1.3.6.1.2.1.2.2.1.15.32	Counter32	0
ifInUnknownProtos.33	.1.3.6.1.2.1.2.2.1.15.33	Counter32	0
ifInUnknownProtos.34	.1.3.6.1.2.1.2.2.1.15.34	Counter32	0
ifInUnknownProtos.35	.1.3.6.1.2.1.2.2.1.15.35	Counter32	0
ifInUnknownProtos.36	.1.3.6.1.2.1.2.2.1.15.36	Counter32	0
ifInUnknownProtos.37	.1.3.6.1.2.1.2.2.1.15.37	Counter32	0
ifInUnknownProtos.38	.1.3.6.1.2.1.2.2.1.15.38	Counter32	0
ifInUnknownProtos.39	.1.3.6.1.2.1.2.2.1.15.39	Counter32	0
ifInUnknownProtos.40	.1.3.6.1.2.1.2.2.1.15.40	Counter32	0
ifInUnknownProtos.41	.1.3.6.1.2.1.2.2.1.15.41	Counter32	0
ifInUnknownProtos.42	.1.3.6.1.2.1.2.2.1.15.42	Counter32	0
ifInUnknownProtos.43	.1.3.6.1.2.1.2.2.1.15.43	Counter32	0
ifInUnknownProtos.44	.1.3.6.1.2.1.2.2.1.15.44	Counter32	0
ifInUnknownProtos.45	.1.3.6.1.2.1.2.2.1.15.45	Counter32	0
ifInUnknownProtos.46	.1.3.6.1.2.1.2.2.1.15.46	Counter32	0
ifInUnknownProtos.47	.1.3.6.1.2.1.2.2.1.15.47	Counter32	0
ifInUnknownProtos.48	.1.3.6.1.2.1.2.2.1.15.48	Counter32	0
ifInUnknownProtos.49	.1.3.6.1.2.1.2.2.1.15.49	Counter32	0
ifInUnknownProtos.50	.1.3.6.1.2.1.2.2.1.15.50	Counter32	0
ifInUnknownProtos.51	.1.3.6.1.2.1.2.2.1.15.51	Counter32	0
ifInUnknownProtos.52	.1.3.6.1.2.1.2.2.1.15.52	Counter32	0
ifInUnknownProtos.53	.1.3.6.1.2.1.2.2.1.15.53	Counter32	0
ifInUnknownProtos.54	.1.3.6.1.2.1.2.2.1.15.54	Counter32	0
ifInUnknownProtos.631	.1.3.6.1.2.1.2.2.1.15.631	Counter32	0

Name	OID	Value Type	Value Example
ifInUnknownProtos.632	.1.3.6.1.2.1.2.2.1.15.632	Counter32	0
ifInUnknownProtos.633	.1.3.6.1.2.1.2.2.1.15.633	Counter32	0
ifInUnknownProtos.634	.1.3.6.1.2.1.2.2.1.15.634	Counter32	116
ifOutOctets.1	.1.3.6.1.2.1.2.2.1.16.1	Counter32	1020266
ifOutOctets.2	.1.3.6.1.2.1.2.2.1.16.2	Counter32	0
ifOutOctets.3	.1.3.6.1.2.1.2.2.1.16.3	Counter32	0
ifOutOctets.4	.1.3.6.1.2.1.2.2.1.16.4	Counter32	0
ifOutOctets.5	.1.3.6.1.2.1.2.2.1.16.5	Counter32	0
ifOutOctets.6	.1.3.6.1.2.1.2.2.1.16.6	Counter32	0
ifOutOctets.7	.1.3.6.1.2.1.2.2.1.16.7	Counter32	0
ifOutOctets.8	.1.3.6.1.2.1.2.2.1.16.8	Counter32	0
ifOutOctets.9	.1.3.6.1.2.1.2.2.1.16.9	Counter32	0
ifOutOctets.10	.1.3.6.1.2.1.2.2.1.16.10	Counter32	0
ifOutOctets.11	.1.3.6.1.2.1.2.2.1.16.11	Counter32	0
ifOutOctets.12	.1.3.6.1.2.1.2.2.1.16.12	Counter32	0
ifOutOctets.13	.1.3.6.1.2.1.2.2.1.16.13	Counter32	0
ifOutOctets.14	.1.3.6.1.2.1.2.2.1.16.14	Counter32	0
ifOutOctets.15	.1.3.6.1.2.1.2.2.1.16.15	Counter32	0
ifOutOctets.16	.1.3.6.1.2.1.2.2.1.16.16	Counter32	0
ifOutOctets.17	.1.3.6.1.2.1.2.2.1.16.17	Counter32	0
ifOutOctets.18	.1.3.6.1.2.1.2.2.1.16.18	Counter32	0
ifOutOctets.19	.1.3.6.1.2.1.2.2.1.16.19	Counter32	0
ifOutOctets.20	.1.3.6.1.2.1.2.2.1.16.20	Counter32	0
ifOutOctets.21	.1.3.6.1.2.1.2.2.1.16.21	Counter32	0
ifOutOctets.22	.1.3.6.1.2.1.2.2.1.16.22	Counter32	0
ifOutOctets.23	.1.3.6.1.2.1.2.2.1.16.23	Counter32	0
ifOutOctets.24	.1.3.6.1.2.1.2.2.1.16.24	Counter32	0
ifOutOctets.25	.1.3.6.1.2.1.2.2.1.16.25	Counter32	0
ifOutOctets.26	.1.3.6.1.2.1.2.2.1.16.26	Counter32	0
ifOutOctets.27	.1.3.6.1.2.1.2.2.1.16.27	Counter32	0
ifOutOctets.28	.1.3.6.1.2.1.2.2.1.16.28	Counter32	0
ifOutOctets.29	.1.3.6.1.2.1.2.2.1.16.29	Counter32	0
ifOutOctets.30	.1.3.6.1.2.1.2.2.1.16.30	Counter32	0
ifOutOctets.31	.1.3.6.1.2.1.2.2.1.16.31	Counter32	0
ifOutOctets.32	.1.3.6.1.2.1.2.2.1.16.32	Counter32	0
ifOutOctets.33	.1.3.6.1.2.1.2.2.1.16.33	Counter32	0
ifOutOctets.34	.1.3.6.1.2.1.2.2.1.16.34	Counter32	0
ifOutOctets.35	.1.3.6.1.2.1.2.2.1.16.35	Counter32	0
ifOutOctets.36	.1.3.6.1.2.1.2.2.1.16.36	Counter32	0
ifOutOctets.37	.1.3.6.1.2.1.2.2.1.16.37	Counter32	0
ifOutOctets.38	.1.3.6.1.2.1.2.2.1.16.38	Counter32	0
ifOutOctets.39	.1.3.6.1.2.1.2.2.1.16.39	Counter32	0
ifOutOctets.40	.1.3.6.1.2.1.2.2.1.16.40	Counter32	0



<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ifOutOctets.41	.1.3.6.1.2.1.2.2.1.16.41	Counter32	0
ifOutOctets.42	.1.3.6.1.2.1.2.2.1.16.42	Counter32	0
ifOutOctets.43	.1.3.6.1.2.1.2.2.1.16.43	Counter32	0
ifOutOctets.44	.1.3.6.1.2.1.2.2.1.16.44	Counter32	0
ifOutOctets.45	.1.3.6.1.2.1.2.2.1.16.45	Counter32	0
ifOutOctets.46	.1.3.6.1.2.1.2.2.1.16.46	Counter32	0
ifOutOctets.47	.1.3.6.1.2.1.2.2.1.16.47	Counter32	0
ifOutOctets.48	.1.3.6.1.2.1.2.2.1.16.48	Counter32	0
ifOutOctets.49	.1.3.6.1.2.1.2.2.1.16.49	Counter32	0
ifOutOctets.50	.1.3.6.1.2.1.2.2.1.16.50	Counter32	0
ifOutOctets.51	.1.3.6.1.2.1.2.2.1.16.51	Counter32	0
ifOutOctets.52	.1.3.6.1.2.1.2.2.1.16.52	Counter32	0
ifOutOctets.53	.1.3.6.1.2.1.2.2.1.16.53	Counter32	0
ifOutOctets.54	.1.3.6.1.2.1.2.2.1.16.54	Counter32	0
ifOutOctets.631	.1.3.6.1.2.1.2.2.1.16.631	Counter32	0
ifOutOctets.632	.1.3.6.1.2.1.2.2.1.16.632	Counter32	0
ifOutOctets.633	.1.3.6.1.2.1.2.2.1.16.633	Counter32	0
ifOutOctets.634	.1.3.6.1.2.1.2.2.1.16.634	Counter32	0
ifOutUcastPkts.1	.1.3.6.1.2.1.2.2.1.17.1	Counter32	5459
ifOutUcastPkts.2	.1.3.6.1.2.1.2.2.1.17.2	Counter32	0
ifOutUcastPkts.3	.1.3.6.1.2.1.2.2.1.17.3	Counter32	0
ifOutUcastPkts.4	.1.3.6.1.2.1.2.2.1.17.4	Counter32	0
ifOutUcastPkts.5	.1.3.6.1.2.1.2.2.1.17.5	Counter32	0
ifOutUcastPkts.6	.1.3.6.1.2.1.2.2.1.17.6	Counter32	0
ifOutUcastPkts.7	.1.3.6.1.2.1.2.2.1.17.7	Counter32	0
ifOutUcastPkts.8	.1.3.6.1.2.1.2.2.1.17.8	Counter32	0
ifOutUcastPkts.9	.1.3.6.1.2.1.2.2.1.17.9	Counter32	0
ifOutUcastPkts.10	.1.3.6.1.2.1.2.2.1.17.10	Counter32	0
ifOutUcastPkts.11	.1.3.6.1.2.1.2.2.1.17.11	Counter32	0
ifOutUcastPkts.12	.1.3.6.1.2.1.2.2.1.17.12	Counter32	0
ifOutUcastPkts.13	.1.3.6.1.2.1.2.2.1.17.13	Counter32	0
ifOutUcastPkts.14	.1.3.6.1.2.1.2.2.1.17.14	Counter32	0
ifOutUcastPkts.15	.1.3.6.1.2.1.2.2.1.17.15	Counter32	0
ifOutUcastPkts.16	.1.3.6.1.2.1.2.2.1.17.16	Counter32	0
ifOutUcastPkts.17	.1.3.6.1.2.1.2.2.1.17.17	Counter32	0
ifOutUcastPkts.18	.1.3.6.1.2.1.2.2.1.17.18	Counter32	0
ifOutUcastPkts.19	.1.3.6.1.2.1.2.2.1.17.19	Counter32	0
ifOutUcastPkts.20	.1.3.6.1.2.1.2.2.1.17.20	Counter32	0
ifOutUcastPkts.21	.1.3.6.1.2.1.2.2.1.17.21	Counter32	0
ifOutUcastPkts.22	.1.3.6.1.2.1.2.2.1.17.22	Counter32	0
ifOutUcastPkts.23	.1.3.6.1.2.1.2.2.1.17.23	Counter32	0
ifOutUcastPkts.24	.1.3.6.1.2.1.2.2.1.17.24	Counter32	0
ifOutUcastPkts.25	.1.3.6.1.2.1.2.2.1.17.25	Counter32	0

Name	OID	Value Type	Value Example
ifOutUcastPkts.26	.1.3.6.1.2.1.2.2.1.17.26	Counter32	0
ifOutUcastPkts.27	.1.3.6.1.2.1.2.2.1.17.27	Counter32	0
ifOutUcastPkts.28	.1.3.6.1.2.1.2.2.1.17.28	Counter32	0
ifOutUcastPkts.29	.1.3.6.1.2.1.2.2.1.17.29	Counter32	0
ifOutUcastPkts.30	.1.3.6.1.2.1.2.2.1.17.30	Counter32	0
ifOutUcastPkts.31	.1.3.6.1.2.1.2.2.1.17.31	Counter32	0
ifOutUcastPkts.32	.1.3.6.1.2.1.2.2.1.17.32	Counter32	0
ifOutUcastPkts.33	.1.3.6.1.2.1.2.2.1.17.33	Counter32	0
ifOutUcastPkts.34	.1.3.6.1.2.1.2.2.1.17.34	Counter32	0
ifOutUcastPkts.35	.1.3.6.1.2.1.2.2.1.17.35	Counter32	0
ifOutUcastPkts.36	.1.3.6.1.2.1.2.2.1.17.36	Counter32	0
ifOutUcastPkts.37	.1.3.6.1.2.1.2.2.1.17.37	Counter32	0
ifOutUcastPkts.38	.1.3.6.1.2.1.2.2.1.17.38	Counter32	0
ifOutUcastPkts.39	.1.3.6.1.2.1.2.2.1.17.39	Counter32	0
ifOutUcastPkts.40	.1.3.6.1.2.1.2.2.1.17.40	Counter32	0
ifOutUcastPkts.41	.1.3.6.1.2.1.2.2.1.17.41	Counter32	0
ifOutUcastPkts.42	.1.3.6.1.2.1.2.2.1.17.42	Counter32	0
ifOutUcastPkts.43	.1.3.6.1.2.1.2.2.1.17.43	Counter32	0
ifOutUcastPkts.44	.1.3.6.1.2.1.2.2.1.17.44	Counter32	0
ifOutUcastPkts.45	.1.3.6.1.2.1.2.2.1.17.45	Counter32	0
ifOutUcastPkts.46	.1.3.6.1.2.1.2.2.1.17.46	Counter32	0
ifOutUcastPkts.47	.1.3.6.1.2.1.2.2.1.17.47	Counter32	0
ifOutUcastPkts.48	.1.3.6.1.2.1.2.2.1.17.48	Counter32	0
ifOutUcastPkts.49	.1.3.6.1.2.1.2.2.1.17.49	Counter32	0
ifOutUcastPkts.50	.1.3.6.1.2.1.2.2.1.17.50	Counter32	0
ifOutUcastPkts.51	.1.3.6.1.2.1.2.2.1.17.51	Counter32	0
ifOutUcastPkts.52	.1.3.6.1.2.1.2.2.1.17.52	Counter32	0
ifOutUcastPkts.53	.1.3.6.1.2.1.2.2.1.17.53	Counter32	0
ifOutUcastPkts.54	.1.3.6.1.2.1.2.2.1.17.54	Counter32	0
ifOutUcastPkts.634	.1.3.6.1.2.1.2.2.1.17.634	Counter32	0
ifOutNUcastPkts.1	.1.3.6.1.2.1.2.2.1.18.1	Counter32	1938
ifOutNUcastPkts.2	.1.3.6.1.2.1.2.2.1.18.2	Counter32	0
ifOutNUcastPkts.3	.1.3.6.1.2.1.2.2.1.18.3	Counter32	0
ifOutNUcastPkts.4	.1.3.6.1.2.1.2.2.1.18.4	Counter32	0
ifOutNUcastPkts.5	.1.3.6.1.2.1.2.2.1.18.5	Counter32	0
ifOutNUcastPkts.6	.1.3.6.1.2.1.2.2.1.18.6	Counter32	0
ifOutNUcastPkts.7	.1.3.6.1.2.1.2.2.1.18.7	Counter32	0
ifOutNUcastPkts.8	.1.3.6.1.2.1.2.2.1.18.8	Counter32	0
ifOutNUcastPkts.9	.1.3.6.1.2.1.2.2.1.18.9	Counter32	0
ifOutNUcastPkts.10	.1.3.6.1.2.1.2.2.1.18.10	Counter32	0
ifOutNUcastPkts.11	.1.3.6.1.2.1.2.2.1.18.11	Counter32	0
ifOutNUcastPkts.12	.1.3.6.1.2.1.2.2.1.18.12	Counter32	0
ifOutNUcastPkts.13	.1.3.6.1.2.1.2.2.1.18.13	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ifOutNUcastPkts.14	.1.3.6.1.2.1.2.2.1.18.14	Counter32	0
ifOutNUcastPkts.15	.1.3.6.1.2.1.2.2.1.18.15	Counter32	0
ifOutNUcastPkts.16	.1.3.6.1.2.1.2.2.1.18.16	Counter32	0
ifOutNUcastPkts.17	.1.3.6.1.2.1.2.2.1.18.17	Counter32	0
ifOutNUcastPkts.18	.1.3.6.1.2.1.2.2.1.18.18	Counter32	0
ifOutNUcastPkts.19	.1.3.6.1.2.1.2.2.1.18.19	Counter32	0
ifOutNUcastPkts.20	.1.3.6.1.2.1.2.2.1.18.20	Counter32	0
ifOutNUcastPkts.21	.1.3.6.1.2.1.2.2.1.18.21	Counter32	0
ifOutNUcastPkts.22	.1.3.6.1.2.1.2.2.1.18.22	Counter32	0
ifOutNUcastPkts.23	.1.3.6.1.2.1.2.2.1.18.23	Counter32	0
ifOutNUcastPkts.24	.1.3.6.1.2.1.2.2.1.18.24	Counter32	0
ifOutNUcastPkts.25	.1.3.6.1.2.1.2.2.1.18.25	Counter32	0
ifOutNUcastPkts.26	.1.3.6.1.2.1.2.2.1.18.26	Counter32	0
ifOutNUcastPkts.27	.1.3.6.1.2.1.2.2.1.18.27	Counter32	0
ifOutNUcastPkts.28	.1.3.6.1.2.1.2.2.1.18.28	Counter32	0
ifOutNUcastPkts.29	.1.3.6.1.2.1.2.2.1.18.29	Counter32	0
ifOutNUcastPkts.30	.1.3.6.1.2.1.2.2.1.18.30	Counter32	0
ifOutNUcastPkts.31	.1.3.6.1.2.1.2.2.1.18.31	Counter32	0
ifOutNUcastPkts.32	.1.3.6.1.2.1.2.2.1.18.32	Counter32	0
ifOutNUcastPkts.33	.1.3.6.1.2.1.2.2.1.18.33	Counter32	0
ifOutNUcastPkts.34	.1.3.6.1.2.1.2.2.1.18.34	Counter32	0
ifOutNUcastPkts.35	.1.3.6.1.2.1.2.2.1.18.35	Counter32	0
ifOutNUcastPkts.36	.1.3.6.1.2.1.2.2.1.18.36	Counter32	0
ifOutNUcastPkts.37	.1.3.6.1.2.1.2.2.1.18.37	Counter32	0
ifOutNUcastPkts.38	.1.3.6.1.2.1.2.2.1.18.38	Counter32	0
ifOutNUcastPkts.39	.1.3.6.1.2.1.2.2.1.18.39	Counter32	0
ifOutNUcastPkts.40	.1.3.6.1.2.1.2.2.1.18.40	Counter32	0
ifOutNUcastPkts.41	.1.3.6.1.2.1.2.2.1.18.41	Counter32	0
ifOutNUcastPkts.42	.1.3.6.1.2.1.2.2.1.18.42	Counter32	0
ifOutNUcastPkts.43	.1.3.6.1.2.1.2.2.1.18.43	Counter32	0
ifOutNUcastPkts.44	.1.3.6.1.2.1.2.2.1.18.44	Counter32	0
ifOutNUcastPkts.45	.1.3.6.1.2.1.2.2.1.18.45	Counter32	0
ifOutNUcastPkts.46	.1.3.6.1.2.1.2.2.1.18.46	Counter32	0
ifOutNUcastPkts.47	.1.3.6.1.2.1.2.2.1.18.47	Counter32	0
ifOutNUcastPkts.48	.1.3.6.1.2.1.2.2.1.18.48	Counter32	0
ifOutNUcastPkts.49	.1.3.6.1.2.1.2.2.1.18.49	Counter32	0
ifOutNUcastPkts.50	.1.3.6.1.2.1.2.2.1.18.50	Counter32	0
ifOutNUcastPkts.51	.1.3.6.1.2.1.2.2.1.18.51	Counter32	0
ifOutNUcastPkts.52	.1.3.6.1.2.1.2.2.1.18.52	Counter32	0
ifOutNUcastPkts.53	.1.3.6.1.2.1.2.2.1.18.53	Counter32	0
ifOutNUcastPkts.54	.1.3.6.1.2.1.2.2.1.18.54	Counter32	0
ifOutNUcastPkts.634	.1.3.6.1.2.1.2.2.1.18.634	Counter32	0
ifOutDiscards.1	.1.3.6.1.2.1.2.2.1.19.1	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ifOutDiscards.2	.1.3.6.1.2.1.2.2.1.19.2	Counter32	0
ifOutDiscards.3	.1.3.6.1.2.1.2.2.1.19.3	Counter32	0
ifOutDiscards.4	.1.3.6.1.2.1.2.2.1.19.4	Counter32	0
ifOutDiscards.5	.1.3.6.1.2.1.2.2.1.19.5	Counter32	0
ifOutDiscards.6	.1.3.6.1.2.1.2.2.1.19.6	Counter32	0
ifOutDiscards.7	.1.3.6.1.2.1.2.2.1.19.7	Counter32	0
ifOutDiscards.8	.1.3.6.1.2.1.2.2.1.19.8	Counter32	0
ifOutDiscards.9	.1.3.6.1.2.1.2.2.1.19.9	Counter32	0
ifOutDiscards.10	.1.3.6.1.2.1.2.2.1.19.10	Counter32	0
ifOutDiscards.11	.1.3.6.1.2.1.2.2.1.19.11	Counter32	0
ifOutDiscards.12	.1.3.6.1.2.1.2.2.1.19.12	Counter32	0
ifOutDiscards.13	.1.3.6.1.2.1.2.2.1.19.13	Counter32	0
ifOutDiscards.14	.1.3.6.1.2.1.2.2.1.19.14	Counter32	0
ifOutDiscards.15	.1.3.6.1.2.1.2.2.1.19.15	Counter32	0
ifOutDiscards.16	.1.3.6.1.2.1.2.2.1.19.16	Counter32	0
ifOutDiscards.17	.1.3.6.1.2.1.2.2.1.19.17	Counter32	0
ifOutDiscards.18	.1.3.6.1.2.1.2.2.1.19.18	Counter32	0
ifOutDiscards.19	.1.3.6.1.2.1.2.2.1.19.19	Counter32	0
ifOutDiscards.20	.1.3.6.1.2.1.2.2.1.19.20	Counter32	0
ifOutDiscards.21	.1.3.6.1.2.1.2.2.1.19.21	Counter32	0
ifOutDiscards.22	.1.3.6.1.2.1.2.2.1.19.22	Counter32	0
ifOutDiscards.23	.1.3.6.1.2.1.2.2.1.19.23	Counter32	0
ifOutDiscards.24	.1.3.6.1.2.1.2.2.1.19.24	Counter32	0
ifOutDiscards.25	.1.3.6.1.2.1.2.2.1.19.25	Counter32	0
ifOutDiscards.26	.1.3.6.1.2.1.2.2.1.19.26	Counter32	0
ifOutDiscards.27	.1.3.6.1.2.1.2.2.1.19.27	Counter32	0
ifOutDiscards.28	.1.3.6.1.2.1.2.2.1.19.28	Counter32	0
ifOutDiscards.29	.1.3.6.1.2.1.2.2.1.19.29	Counter32	0
ifOutDiscards.30	.1.3.6.1.2.1.2.2.1.19.30	Counter32	0
ifOutDiscards.31	.1.3.6.1.2.1.2.2.1.19.31	Counter32	0
ifOutDiscards.32	.1.3.6.1.2.1.2.2.1.19.32	Counter32	0
ifOutDiscards.33	.1.3.6.1.2.1.2.2.1.19.33	Counter32	0
ifOutDiscards.34	.1.3.6.1.2.1.2.2.1.19.34	Counter32	0
ifOutDiscards.35	.1.3.6.1.2.1.2.2.1.19.35	Counter32	0
ifOutDiscards.36	.1.3.6.1.2.1.2.2.1.19.36	Counter32	0
ifOutDiscards.37	.1.3.6.1.2.1.2.2.1.19.37	Counter32	0
ifOutDiscards.38	.1.3.6.1.2.1.2.2.1.19.38	Counter32	0
ifOutDiscards.39	.1.3.6.1.2.1.2.2.1.19.39	Counter32	0
ifOutDiscards.40	.1.3.6.1.2.1.2.2.1.19.40	Counter32	0
ifOutDiscards.41	.1.3.6.1.2.1.2.2.1.19.41	Counter32	0
ifOutDiscards.42	.1.3.6.1.2.1.2.2.1.19.42	Counter32	0
ifOutDiscards.43	.1.3.6.1.2.1.2.2.1.19.43	Counter32	0
ifOutDiscards.44	.1.3.6.1.2.1.2.2.1.19.44	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ifOutDiscards.45	.1.3.6.1.2.1.2.2.1.19.45	Counter32	0
ifOutDiscards.46	.1.3.6.1.2.1.2.2.1.19.46	Counter32	0
ifOutDiscards.47	.1.3.6.1.2.1.2.2.1.19.47	Counter32	0
ifOutDiscards.48	.1.3.6.1.2.1.2.2.1.19.48	Counter32	0
ifOutDiscards.49	.1.3.6.1.2.1.2.2.1.19.49	Counter32	0
ifOutDiscards.50	.1.3.6.1.2.1.2.2.1.19.50	Counter32	0
ifOutDiscards.51	.1.3.6.1.2.1.2.2.1.19.51	Counter32	0
ifOutDiscards.52	.1.3.6.1.2.1.2.2.1.19.52	Counter32	0
ifOutDiscards.53	.1.3.6.1.2.1.2.2.1.19.53	Counter32	0
ifOutDiscards.54	.1.3.6.1.2.1.2.2.1.19.54	Counter32	0
ifOutDiscards.631	.1.3.6.1.2.1.2.2.1.19.631	Counter32	0
ifOutDiscards.632	.1.3.6.1.2.1.2.2.1.19.632	Counter32	0
ifOutDiscards.633	.1.3.6.1.2.1.2.2.1.19.633	Counter32	0
ifOutDiscards.634	.1.3.6.1.2.1.2.2.1.19.634	Counter32	0
ifOutErrors.1	.1.3.6.1.2.1.2.2.1.20.1	Counter32	0
ifOutErrors.2	.1.3.6.1.2.1.2.2.1.20.2	Counter32	0
ifOutErrors.3	.1.3.6.1.2.1.2.2.1.20.3	Counter32	0
ifOutErrors.4	.1.3.6.1.2.1.2.2.1.20.4	Counter32	0
ifOutErrors.5	.1.3.6.1.2.1.2.2.1.20.5	Counter32	0
ifOutErrors.6	.1.3.6.1.2.1.2.2.1.20.6	Counter32	0
ifOutErrors.7	.1.3.6.1.2.1.2.2.1.20.7	Counter32	0
ifOutErrors.8	.1.3.6.1.2.1.2.2.1.20.8	Counter32	0
ifOutErrors.9	.1.3.6.1.2.1.2.2.1.20.9	Counter32	0
ifOutErrors.10	.1.3.6.1.2.1.2.2.1.20.10	Counter32	0
ifOutErrors.11	.1.3.6.1.2.1.2.2.1.20.11	Counter32	0
ifOutErrors.12	.1.3.6.1.2.1.2.2.1.20.12	Counter32	0
ifOutErrors.13	.1.3.6.1.2.1.2.2.1.20.13	Counter32	0
ifOutErrors.14	.1.3.6.1.2.1.2.2.1.20.14	Counter32	0
ifOutErrors.15	.1.3.6.1.2.1.2.2.1.20.15	Counter32	0
ifOutErrors.16	.1.3.6.1.2.1.2.2.1.20.16	Counter32	0
ifOutErrors.17	.1.3.6.1.2.1.2.2.1.20.17	Counter32	0
ifOutErrors.18	.1.3.6.1.2.1.2.2.1.20.18	Counter32	0
ifOutErrors.19	.1.3.6.1.2.1.2.2.1.20.19	Counter32	0
ifOutErrors.20	.1.3.6.1.2.1.2.2.1.20.20	Counter32	0
ifOutErrors.21	.1.3.6.1.2.1.2.2.1.20.21	Counter32	0
ifOutErrors.22	.1.3.6.1.2.1.2.2.1.20.22	Counter32	0
ifOutErrors.23	.1.3.6.1.2.1.2.2.1.20.23	Counter32	0
ifOutErrors.24	.1.3.6.1.2.1.2.2.1.20.24	Counter32	0
ifOutErrors.25	.1.3.6.1.2.1.2.2.1.20.25	Counter32	0
ifOutErrors.26	.1.3.6.1.2.1.2.2.1.20.26	Counter32	0
ifOutErrors.27	.1.3.6.1.2.1.2.2.1.20.27	Counter32	0
ifOutErrors.28	.1.3.6.1.2.1.2.2.1.20.28	Counter32	0
ifOutErrors.29	.1.3.6.1.2.1.2.2.1.20.29	Counter32	0

Name	OID	Value Type	Value Example
ifOutErrors.30	.1.3.6.1.2.1.2.2.1.20.30	Counter32	0
ifOutErrors.31	.1.3.6.1.2.1.2.2.1.20.31	Counter32	0
ifOutErrors.32	.1.3.6.1.2.1.2.2.1.20.32	Counter32	0
ifOutErrors.33	.1.3.6.1.2.1.2.2.1.20.33	Counter32	0
ifOutErrors.34	.1.3.6.1.2.1.2.2.1.20.34	Counter32	0
ifOutErrors.35	.1.3.6.1.2.1.2.2.1.20.35	Counter32	0
ifOutErrors.36	.1.3.6.1.2.1.2.2.1.20.36	Counter32	0
ifOutErrors.37	.1.3.6.1.2.1.2.2.1.20.37	Counter32	0
ifOutErrors.38	.1.3.6.1.2.1.2.2.1.20.38	Counter32	0
ifOutErrors.39	.1.3.6.1.2.1.2.2.1.20.39	Counter32	0
ifOutErrors.40	.1.3.6.1.2.1.2.2.1.20.40	Counter32	0
ifOutErrors.41	.1.3.6.1.2.1.2.2.1.20.41	Counter32	0
ifOutErrors.42	.1.3.6.1.2.1.2.2.1.20.42	Counter32	0
ifOutErrors.43	.1.3.6.1.2.1.2.2.1.20.43	Counter32	0
ifOutErrors.44	.1.3.6.1.2.1.2.2.1.20.44	Counter32	0
ifOutErrors.45	.1.3.6.1.2.1.2.2.1.20.45	Counter32	0
ifOutErrors.46	.1.3.6.1.2.1.2.2.1.20.46	Counter32	0
ifOutErrors.47	.1.3.6.1.2.1.2.2.1.20.47	Counter32	0
ifOutErrors.48	.1.3.6.1.2.1.2.2.1.20.48	Counter32	0
ifOutErrors.49	.1.3.6.1.2.1.2.2.1.20.49	Counter32	0
ifOutErrors.50	.1.3.6.1.2.1.2.2.1.20.50	Counter32	0
ifOutErrors.51	.1.3.6.1.2.1.2.2.1.20.51	Counter32	0
ifOutErrors.52	.1.3.6.1.2.1.2.2.1.20.52	Counter32	0
ifOutErrors.53	.1.3.6.1.2.1.2.2.1.20.53	Counter32	0
ifOutErrors.54	.1.3.6.1.2.1.2.2.1.20.54	Counter32	0
ifOutErrors.634	.1.3.6.1.2.1.2.2.1.20.634	Counter32	0
ifOutQLen.1	.1.3.6.1.2.1.2.2.1.21.1	Gauge	0
ifOutQLen.2	.1.3.6.1.2.1.2.2.1.21.2	Gauge	0
ifOutQLen.3	.1.3.6.1.2.1.2.2.1.21.3	Gauge	0
ifOutQLen.4	.1.3.6.1.2.1.2.2.1.21.4	Gauge	0
ifOutQLen.5	.1.3.6.1.2.1.2.2.1.21.5	Gauge	0
ifOutQLen.6	.1.3.6.1.2.1.2.2.1.21.6	Gauge	0
ifOutQLen.7	.1.3.6.1.2.1.2.2.1.21.7	Gauge	0
ifOutQLen.8	.1.3.6.1.2.1.2.2.1.21.8	Gauge	0
ifOutQLen.9	.1.3.6.1.2.1.2.2.1.21.9	Gauge	0
ifOutQLen.10	.1.3.6.1.2.1.2.2.1.21.10	Gauge	0
ifOutQLen.11	.1.3.6.1.2.1.2.2.1.21.11	Gauge	0
ifOutQLen.12	.1.3.6.1.2.1.2.2.1.21.12	Gauge	0
ifOutQLen.13	.1.3.6.1.2.1.2.2.1.21.13	Gauge	0
ifOutQLen.14	.1.3.6.1.2.1.2.2.1.21.14	Gauge	0
ifOutQLen.15	.1.3.6.1.2.1.2.2.1.21.15	Gauge	0
ifOutQLen.16	.1.3.6.1.2.1.2.2.1.21.16	Gauge	0
ifOutQLen.17	.1.3.6.1.2.1.2.2.1.21.17	Gauge	0

Name	OID	Value Type	Value Example
ifOutQLen.18	.1.3.6.1.2.1.2.2.1.21.18	Gauge	0
ifOutQLen.19	.1.3.6.1.2.1.2.2.1.21.19	Gauge	0
ifOutQLen.20	.1.3.6.1.2.1.2.2.1.21.20	Gauge	0
ifOutQLen.21	.1.3.6.1.2.1.2.2.1.21.21	Gauge	0
ifOutQLen.22	.1.3.6.1.2.1.2.2.1.21.22	Gauge	0
ifOutQLen.23	.1.3.6.1.2.1.2.2.1.21.23	Gauge	0
ifOutQLen.24	.1.3.6.1.2.1.2.2.1.21.24	Gauge	0
ifOutQLen.25	.1.3.6.1.2.1.2.2.1.21.25	Gauge	0
ifOutQLen.26	.1.3.6.1.2.1.2.2.1.21.26	Gauge	0
ifOutQLen.27	.1.3.6.1.2.1.2.2.1.21.27	Gauge	0
ifOutQLen.28	.1.3.6.1.2.1.2.2.1.21.28	Gauge	0
ifOutQLen.29	.1.3.6.1.2.1.2.2.1.21.29	Gauge	0
ifOutQLen.30	.1.3.6.1.2.1.2.2.1.21.30	Gauge	0
ifOutQLen.31	.1.3.6.1.2.1.2.2.1.21.31	Gauge	0
ifOutQLen.32	.1.3.6.1.2.1.2.2.1.21.32	Gauge	0
ifOutQLen.33	.1.3.6.1.2.1.2.2.1.21.33	Gauge	0
ifOutQLen.34	.1.3.6.1.2.1.2.2.1.21.34	Gauge	0
ifOutQLen.35	.1.3.6.1.2.1.2.2.1.21.35	Gauge	0
ifOutQLen.36	.1.3.6.1.2.1.2.2.1.21.36	Gauge	0
ifOutQLen.37	.1.3.6.1.2.1.2.2.1.21.37	Gauge	0
ifOutQLen.38	.1.3.6.1.2.1.2.2.1.21.38	Gauge	0
ifOutQLen.39	.1.3.6.1.2.1.2.2.1.21.39	Gauge	0
ifOutQLen.40	.1.3.6.1.2.1.2.2.1.21.40	Gauge	0
ifOutQLen.41	.1.3.6.1.2.1.2.2.1.21.41	Gauge	0
ifOutQLen.42	.1.3.6.1.2.1.2.2.1.21.42	Gauge	0
ifOutQLen.43	.1.3.6.1.2.1.2.2.1.21.43	Gauge	0
ifOutQLen.44	.1.3.6.1.2.1.2.2.1.21.44	Gauge	0
ifOutQLen.45	.1.3.6.1.2.1.2.2.1.21.45	Gauge	0
ifOutQLen.46	.1.3.6.1.2.1.2.2.1.21.46	Gauge	0
ifOutQLen.47	.1.3.6.1.2.1.2.2.1.21.47	Gauge	0
ifOutQLen.48	.1.3.6.1.2.1.2.2.1.21.48	Gauge	0
ifOutQLen.49	.1.3.6.1.2.1.2.2.1.21.49	Gauge	0
ifOutQLen.50	.1.3.6.1.2.1.2.2.1.21.50	Gauge	0
ifOutQLen.51	.1.3.6.1.2.1.2.2.1.21.51	Gauge	0
ifOutQLen.52	.1.3.6.1.2.1.2.2.1.21.52	Gauge	0
ifOutQLen.53	.1.3.6.1.2.1.2.2.1.21.53	Gauge	0
ifOutQLen.54	.1.3.6.1.2.1.2.2.1.21.54	Gauge	0
ifOutQLen.631	.1.3.6.1.2.1.2.2.1.21.631	Gauge	0
ifOutQLen.632	.1.3.6.1.2.1.2.2.1.21.632	Gauge	0
ifOutQLen.633	.1.3.6.1.2.1.2.2.1.21.633	Gauge	0
ifOutQLen.634	.1.3.6.1.2.1.2.2.1.21.634	Gauge	0
ifSpecific.1	.1.3.6.1.2.1.2.2.1.22.1	OID	.0.0
ifSpecific.2	.1.3.6.1.2.1.2.2.1.22.2	OID	.0.0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ifSpecific.3	.1.3.6.1.2.1.2.2.1.22.3	OID	.0.0
ifSpecific.4	.1.3.6.1.2.1.2.2.1.22.4	OID	.0.0
ifSpecific.5	.1.3.6.1.2.1.2.2.1.22.5	OID	.0.0
ifSpecific.6	.1.3.6.1.2.1.2.2.1.22.6	OID	.0.0
ifSpecific.7	.1.3.6.1.2.1.2.2.1.22.7	OID	.0.0
ifSpecific.8	.1.3.6.1.2.1.2.2.1.22.8	OID	.0.0
ifSpecific.9	.1.3.6.1.2.1.2.2.1.22.9	OID	.0.0
ifSpecific.10	.1.3.6.1.2.1.2.2.1.22.10	OID	.0.0
ifSpecific.11	.1.3.6.1.2.1.2.2.1.22.11	OID	.0.0
ifSpecific.12	.1.3.6.1.2.1.2.2.1.22.12	OID	.0.0
ifSpecific.13	.1.3.6.1.2.1.2.2.1.22.13	OID	.0.0
ifSpecific.14	.1.3.6.1.2.1.2.2.1.22.14	OID	.0.0
ifSpecific.15	.1.3.6.1.2.1.2.2.1.22.15	OID	.0.0
ifSpecific.16	.1.3.6.1.2.1.2.2.1.22.16	OID	.0.0
ifSpecific.17	.1.3.6.1.2.1.2.2.1.22.17	OID	.0.0
ifSpecific.18	.1.3.6.1.2.1.2.2.1.22.18	OID	.0.0
ifSpecific.19	.1.3.6.1.2.1.2.2.1.22.19	OID	.0.0
ifSpecific.20	.1.3.6.1.2.1.2.2.1.22.20	OID	.0.0
ifSpecific.21	.1.3.6.1.2.1.2.2.1.22.21	OID	.0.0
ifSpecific.22	.1.3.6.1.2.1.2.2.1.22.22	OID	.0.0
ifSpecific.23	.1.3.6.1.2.1.2.2.1.22.23	OID	.0.0
ifSpecific.24	.1.3.6.1.2.1.2.2.1.22.24	OID	.0.0
ifSpecific.25	.1.3.6.1.2.1.2.2.1.22.25	OID	.0.0
ifSpecific.26	.1.3.6.1.2.1.2.2.1.22.26	OID	.0.0
ifSpecific.27	.1.3.6.1.2.1.2.2.1.22.27	OID	.0.0
ifSpecific.28	.1.3.6.1.2.1.2.2.1.22.28	OID	.0.0
ifSpecific.29	.1.3.6.1.2.1.2.2.1.22.29	OID	.0.0
ifSpecific.30	.1.3.6.1.2.1.2.2.1.22.30	OID	.0.0
ifSpecific.31	.1.3.6.1.2.1.2.2.1.22.31	OID	.0.0
ifSpecific.32	.1.3.6.1.2.1.2.2.1.22.32	OID	.0.0
ifSpecific.33	.1.3.6.1.2.1.2.2.1.22.33	OID	.0.0
ifSpecific.34	.1.3.6.1.2.1.2.2.1.22.34	OID	.0.0
ifSpecific.35	.1.3.6.1.2.1.2.2.1.22.35	OID	.0.0
ifSpecific.36	.1.3.6.1.2.1.2.2.1.22.36	OID	.0.0
ifSpecific.37	.1.3.6.1.2.1.2.2.1.22.37	OID	.0.0
ifSpecific.38	.1.3.6.1.2.1.2.2.1.22.38	OID	.0.0
ifSpecific.39	.1.3.6.1.2.1.2.2.1.22.39	OID	.0.0
ifSpecific.40	.1.3.6.1.2.1.2.2.1.22.40	OID	.0.0
ifSpecific.41	.1.3.6.1.2.1.2.2.1.22.41	OID	.0.0
ifSpecific.42	.1.3.6.1.2.1.2.2.1.22.42	OID	.0.0
ifSpecific.43	.1.3.6.1.2.1.2.2.1.22.43	OID	.0.0
ifSpecific.44	.1.3.6.1.2.1.2.2.1.22.44	OID	.0.0
ifSpecific.45	.1.3.6.1.2.1.2.2.1.22.45	OID	.0.0



Name	OID	Value Type	Value Example
ifSpecific.46	.1.3.6.1.2.1.2.2.1.22.46	OID	.0.0
ifSpecific.47	.1.3.6.1.2.1.2.2.1.22.47	OID	.0.0
ifSpecific.48	.1.3.6.1.2.1.2.2.1.22.48	OID	.0.0
ifSpecific.49	.1.3.6.1.2.1.2.2.1.22.49	OID	.0.0
ifSpecific.50	.1.3.6.1.2.1.2.2.1.22.50	OID	.0.0
ifSpecific.51	.1.3.6.1.2.1.2.2.1.22.51	OID	.0.0
ifSpecific.52	.1.3.6.1.2.1.2.2.1.22.52	OID	.0.0
ifSpecific.53	.1.3.6.1.2.1.2.2.1.22.53	OID	.0.0
ifSpecific.54	.1.3.6.1.2.1.2.2.1.22.54	OID	.0.0
ifSpecific.631	.1.3.6.1.2.1.2.2.1.22.631	OID	.0.0
ifSpecific.632	.1.3.6.1.2.1.2.2.1.22.632	OID	.0.0
ifSpecific.633	.1.3.6.1.2.1.2.2.1.22.633	OID	.0.0
ifSpecific.634	.1.3.6.1.2.1.2.2.1.22.634	OID	.0.0
atfIndex.634.1.10.100.65.1	.1.3.6.1.2.1.3.1.1.1.634.1.10.100.65.1	Integer	634
atfIndex.634.1.10.100.65.11	.1.3.6.1.2.1.3.1.1.1.634.1.10.100.65.11	Integer	634
atfIndex.634.1.10.100.65.12	.1.3.6.1.2.1.3.1.1.1.634.1.10.100.65.12	Integer	634
atfIndex.634.1.10.100.65.29	.1.3.6.1.2.1.3.1.1.1.634.1.10.100.65.29	Integer	634
atfIndex.634.1.10.100.65.31	.1.3.6.1.2.1.3.1.1.1.634.1.10.100.65.31	Integer	634
atfIndex.634.1.10.100.65.33	.1.3.6.1.2.1.3.1.1.1.634.1.10.100.65.33	Integer	634
atfIndex.634.1.10.100.65.34	.1.3.6.1.2.1.3.1.1.1.634.1.10.100.65.34	Integer	634
atfIndex.634.1.10.100.65.35	.1.3.6.1.2.1.3.1.1.1.634.1.10.100.65.35	Integer	634
atfIndex.634.1.10.100.65.39	.1.3.6.1.2.1.3.1.1.1.634.1.10.100.65.39	Integer	634
atfIndex.634.1.10.100.65.43	.1.3.6.1.2.1.3.1.1.1.634.1.10.100.65.43	Integer	634
atfIndex.634.1.10.100.65.67	.1.3.6.1.2.1.3.1.1.1.634.1.10.100.65.67	Integer	634
atfIndex.634.1.10.100.65.153	.1.3.6.1.2.1.3.1.1.1.634.1.10.100.65.153	Integer	634
atfIndex.634.1.10.100.65.158	.1.3.6.1.2.1.3.1.1.1.634.1.10.100.65.158	Integer	634
atfIndex.634.1.10.100.65.164	.1.3.6.1.2.1.3.1.1.1.634.1.10.100.65.164	Integer	634
atfIndex.634.1.10.100.65.170	.1.3.6.1.2.1.3.1.1.1.634.1.10.100.65.170	Integer	634
atfIndex.634.1.10.100.65.254	.1.3.6.1.2.1.3.1.1.1.634.1.10.100.65.254	Integer	634
atPhysAd- dress.634.1.10.100.65.1	.1.3.6.1.2.1.3.1.1.2.634.1.10.100.65.1	OctetString	00-09-0F-09-1E-0A
atPhysAd- dress.634.1.10.100.65.11	.1.3.6.1.2.1.3.1.1.2.634.1.10.100.65.11	OctetString	14-84-77-ED-A7-07
atPhysAd- dress.634.1.10.100.65.12	.1.3.6.1.2.1.3.1.1.2.634.1.10.100.65.12	OctetString	BC-D0-EB-FD-5E-3B
atPhysAd- dress.634.1.10.100.65.29	.1.3.6.1.2.1.3.1.1.2.634.1.10.100.65.29	OctetString	90-F7-B2-DD-73-E7
atPhysAd- dress.634.1.10.100.65.31	.1.3.6.1.2.1.3.1.1.2.634.1.10.100.65.31	OctetString	14-84-77-CF-9A-6D
atPhysAd- dress.634.1.10.100.65.33	.1.3.6.1.2.1.3.1.1.2.634.1.10.100.65.33	OctetString	14-84-77-85-A2-07
atPhysAd- dress.634.1.10.100.65.34	.1.3.6.1.2.1.3.1.1.2.634.1.10.100.65.34	OctetString	14-84-77-8C-C7-7D
atPhysAd- dress.634.1.10.100.65.35	.1.3.6.1.2.1.3.1.1.2.634.1.10.100.65.35	OctetString	7C-7A-3C-15-0E-1F

Name	OID	Value Type	Value Example
atPhysAd- dress.634.1.10.100.65.39	.1.3.6.1.2.1.3.1.1.2.634.1.10.100.65.39	OctetString	54-C6-FF-E9-AC-66
atPhysAd- dress.634.1.10.100.65.43	.1.3.6.1.2.1.3.1.1.2.634.1.10.100.65.43	OctetString	14-84-77-E3-41-49
atPhysAd- dress.634.1.10.100.65.67	.1.3.6.1.2.1.3.1.1.2.634.1.10.100.65.67	OctetString	14-84-77-83-B1-2B
atPhysAd- dress.634.1.10.100.65.153	.1.3.6.1.2.1.3.1.1.2.634.1.10.100.65.153	OctetString	00-00-FC-00-E2-CD
atPhysAd- dress.634.1.10.100.65.158	.1.3.6.1.2.1.3.1.1.2.634.1.10.100.65.158	OctetString	E8-78-EE-E5-D3-07
atPhysAd- dress.634.1.10.100.65.164	.1.3.6.1.2.1.3.1.1.2.634.1.10.100.65.164	OctetString	E4-60-17-EC-7A-A7
atPhysAd- dress.634.1.10.100.65.170	.1.3.6.1.2.1.3.1.1.2.634.1.10.100.65.170	OctetString	14-84-77-94-F3-3D
atPhysAd- dress.634.1.10.100.65.254	.1.3.6.1.2.1.3.1.1.2.634.1.10.100.65.254	OctetString	00-00-FC-00-9A-E2
atNetAd- dress.634.1.10.100.65.1	.1.3.6.1.2.1.3.1.1.3.634.1.10.100.65.1	IpAddress	10.100.65.1
atNetAd- dress.634.1.10.100.65.11	.1.3.6.1.2.1.3.1.1.3.634.1.10.100.65.11	IpAddress	10.100.65.11
atNetAd- dress.634.1.10.100.65.12	.1.3.6.1.2.1.3.1.1.3.634.1.10.100.65.12	IpAddress	10.100.65.12
atNetAd- dress.634.1.10.100.65.29	.1.3.6.1.2.1.3.1.1.3.634.1.10.100.65.29	IpAddress	10.100.65.29
atNetAd- dress.634.1.10.100.65.31	.1.3.6.1.2.1.3.1.1.3.634.1.10.100.65.31	IpAddress	10.100.65.31
atNetAd- dress.634.1.10.100.65.33	.1.3.6.1.2.1.3.1.1.3.634.1.10.100.65.33	IpAddress	10.100.65.33
atNetAd- dress.634.1.10.100.65.34	.1.3.6.1.2.1.3.1.1.3.634.1.10.100.65.34	IpAddress	10.100.65.34
atNetAd- dress.634.1.10.100.65.35	.1.3.6.1.2.1.3.1.1.3.634.1.10.100.65.35	IpAddress	10.100.65.35
atNetAd- dress.634.1.10.100.65.39	.1.3.6.1.2.1.3.1.1.3.634.1.10.100.65.39	IpAddress	10.100.65.39
atNetAd- dress.634.1.10.100.65.43	.1.3.6.1.2.1.3.1.1.3.634.1.10.100.65.43	IpAddress	10.100.65.43
atNetAd- dress.634.1.10.100.65.67	.1.3.6.1.2.1.3.1.1.3.634.1.10.100.65.67	IpAddress	10.100.65.67
atNetAd- dress.634.1.10.100.65.153	.1.3.6.1.2.1.3.1.1.3.634.1.10.100.65.153	IpAddress	10.100.65.153
atNetAd- dress.634.1.10.100.65.158	.1.3.6.1.2.1.3.1.1.3.634.1.10.100.65.158	IpAddress	10.100.65.158
atNetAd- dress.634.1.10.100.65.164	.1.3.6.1.2.1.3.1.1.3.634.1.10.100.65.164	IpAddress	10.100.65.164
atNetAd- dress.634.1.10.100.65.170	.1.3.6.1.2.1.3.1.1.3.634.1.10.100.65.170	IpAddress	10.100.65.170
atNetAd- dress.634.1.10.100.65.254	.1.3.6.1.2.1.3.1.1.3.634.1.10.100.65.254	IpAddress	10.100.65.254
ipForwarding.0	.1.3.6.1.2.1.4.1.0	Integer	gateway (1)
ipDefaultTTL.0	.1.3.6.1.2.1.4.2.0	Integer	255

Name	OID	Value Type	Value Example
ipInReceives.0	.1.3.6.1.2.1.4.3.0	Counter32	0
ipInHdrErrors.0	.1.3.6.1.2.1.4.4.0	Counter32	0
ipInAddrErrors.0	.1.3.6.1.2.1.4.5.0	Counter32	0
ipForwDatagrams.0	.1.3.6.1.2.1.4.6.0	Counter32	0
ipInUnknownProtos.0	.1.3.6.1.2.1.4.7.0	Counter32	0
ipInDiscards.0	.1.3.6.1.2.1.4.8.0	Counter32	0
ipInDelivers.0	.1.3.6.1.2.1.4.9.0	Counter32	0
ipOutRequests.0	.1.3.6.1.2.1.4.10.0	Counter32	0
ipOutDiscards.0	.1.3.6.1.2.1.4.11.0	Counter32	0
ipOutNoRoutes.0	.1.3.6.1.2.1.4.12.0	Counter32	0
ipReasmTimeout.0	.1.3.6.1.2.1.4.13.0	Integer	30
ipReasmReqds.0	.1.3.6.1.2.1.4.14.0	Counter32	0
ipReasmOKs.0	.1.3.6.1.2.1.4.15.0	Counter32	0
ipReasmFails.0	.1.3.6.1.2.1.4.16.0	Counter32	0
ipFragOKs.0	.1.3.6.1.2.1.4.17.0	Counter32	0
ipFragFails.0	.1.3.6.1.2.1.4.18.0	Counter32	0
ipFragCreates.0	.1.3.6.1.2.1.4.19.0	Counter32	0
ipAdEntAddr.10.100.65.116	.1.3.6.1.2.1.4.20.1.1.10.100.65.116	IpAddress	10.100.65.116
ipAdEntIfIndex.10.100.65.116	.1.3.6.1.2.1.4.20.1.2.10.100.65.116	Integer	634
ipAdEntNet-Mask.10.100.65.116	.1.3.6.1.2.1.4.20.1.3.10.100.65.116	IpAddress	255.255.255.0
ipAdEntBcastAddr.10.100.65.116	.1.3.6.1.2.1.4.20.1.4.10.100.65.116	Integer	1
ipAdEntReasmMax-Size.10.100.65.116	.1.3.6.1.2.1.4.20.1.5.10.100.65.116	Integer	65535
ipRouteDest.0.0.0.0	.1.3.6.1.2.1.4.21.1.1.0.0.0.0	IpAddress	0.0.0.0
ipRouteDest.10.100.65.0	.1.3.6.1.2.1.4.21.1.1.10.100.65.0	IpAddress	10.100.65.0
ipRouteDest.10.100.65.116	.1.3.6.1.2.1.4.21.1.1.10.100.65.116	IpAddress	10.100.65.116
ipRouteDest.10.100.65.255	.1.3.6.1.2.1.4.21.1.1.10.100.65.255	IpAddress	10.100.65.255
ipRouteDest.127.0.0.0	.1.3.6.1.2.1.4.21.1.1.127.0.0.0	IpAddress	127.0.0.0
ipRouteDest.127.0.0.1	.1.3.6.1.2.1.4.21.1.1.127.0.0.1	IpAddress	127.0.0.1
ipRouteDest.127.255.255.255	.1.3.6.1.2.1.4.21.1.1.127.255.255.255	IpAddress	127.255.255.255
ipRouteDest.224.0.0.0	.1.3.6.1.2.1.4.21.1.1.224.0.0.0	IpAddress	224.0.0.0
ipRouteDest.255.255.255.255	.1.3.6.1.2.1.4.21.1.1.255.255.255.255	IpAddress	255.255.255.255
ipRoutelfIndex.0.0.0.0	.1.3.6.1.2.1.4.21.1.2.0.0.0.0	Integer	634
ipRoutelfIndex.10.100.65.0	.1.3.6.1.2.1.4.21.1.2.10.100.65.0	Integer	634
ipRoutelfIndex.10.100.65.116	.1.3.6.1.2.1.4.21.1.2.10.100.65.116	Integer	632
ipRoutelfIndex.10.100.65.255	.1.3.6.1.2.1.4.21.1.2.10.100.65.255	Integer	634
ipRoutelfIndex.127.0.0.0	.1.3.6.1.2.1.4.21.1.2.127.0.0.0	Integer	632
ipRoutelfIndex.127.0.0.1	.1.3.6.1.2.1.4.21.1.2.127.0.0.1	Integer	632
ipRoutelfIndex.127.255.255.255	.1.3.6.1.2.1.4.21.1.2.127.255.255.255	Integer	632
ipRoutelfIndex.224.0.0.0	.1.3.6.1.2.1.4.21.1.2.224.0.0.0	Integer	631

Name	OID	Value Type	Value Example
ipRouteIn- dex.255.255.255.255	.1.3.6.1.2.1.4.21.1.2.255.255.255.255	Integer	632
ipRouteMetric1.0.0.0.0	.1.3.6.1.2.1.4.21.1.3.0.0.0.0	Integer	0
ipRouteMetric1.10.100.65.0	.1.3.6.1.2.1.4.21.1.3.10.100.65.0	Integer	0
ipRouteMetric1.10.100.65.116	.1.3.6.1.2.1.4.21.1.3.10.100.65.116	Integer	0
ipRouteMetric1.10.100.65.255	.1.3.6.1.2.1.4.21.1.3.10.100.65.255	Integer	0
ipRouteMetric1.127.0.0.0	.1.3.6.1.2.1.4.21.1.3.127.0.0.0	Integer	0
ipRouteMetric1.127.0.0.1	.1.3.6.1.2.1.4.21.1.3.127.0.0.1	Integer	0
ipRouteMe- tric1.127.255.255.255	.1.3.6.1.2.1.4.21.1.3.127.255.255.255	Integer	0
ipRouteMetric1.224.0.0.0	.1.3.6.1.2.1.4.21.1.3.224.0.0.0	Integer	0
ipRouteMe- tric1.255.255.255.255	.1.3.6.1.2.1.4.21.1.3.255.255.255.255	Integer	0
ipRouteMetric2.0.0.0.0	.1.3.6.1.2.1.4.21.1.4.0.0.0.0	Integer	-1
ipRouteMetric2.10.100.65.0	.1.3.6.1.2.1.4.21.1.4.10.100.65.0	Integer	-1
ipRouteMetric2.10.100.65.116	.1.3.6.1.2.1.4.21.1.4.10.100.65.116	Integer	-1
ipRouteMetric2.10.100.65.255	.1.3.6.1.2.1.4.21.1.4.10.100.65.255	Integer	-1
ipRouteMetric2.127.0.0.0	.1.3.6.1.2.1.4.21.1.4.127.0.0.0	Integer	-1
ipRouteMetric2.127.0.0.1	.1.3.6.1.2.1.4.21.1.4.127.0.0.1	Integer	-1
ipRouteMe- tric2.127.255.255.255	.1.3.6.1.2.1.4.21.1.4.127.255.255.255	Integer	-1
ipRouteMetric2.224.0.0.0	.1.3.6.1.2.1.4.21.1.4.224.0.0.0	Integer	-1
ipRouteMe- tric2.255.255.255.255	.1.3.6.1.2.1.4.21.1.4.255.255.255.255	Integer	-1
ipRouteMetric3.0.0.0.0	.1.3.6.1.2.1.4.21.1.5.0.0.0.0	Integer	-1
ipRouteMetric3.10.100.65.0	.1.3.6.1.2.1.4.21.1.5.10.100.65.0	Integer	-1
ipRouteMetric3.10.100.65.116	.1.3.6.1.2.1.4.21.1.5.10.100.65.116	Integer	-1
ipRouteMetric3.10.100.65.255	.1.3.6.1.2.1.4.21.1.5.10.100.65.255	Integer	-1
ipRouteMetric3.127.0.0.0	.1.3.6.1.2.1.4.21.1.5.127.0.0.0	Integer	-1
ipRouteMetric3.127.0.0.1	.1.3.6.1.2.1.4.21.1.5.127.0.0.1	Integer	-1
ipRouteMe- tric3.127.255.255.255	.1.3.6.1.2.1.4.21.1.5.127.255.255.255	Integer	-1
ipRouteMetric3.224.0.0.0	.1.3.6.1.2.1.4.21.1.5.224.0.0.0	Integer	-1
ipRouteMe- tric3.255.255.255.255	.1.3.6.1.2.1.4.21.1.5.255.255.255.255	Integer	-1
ipRouteMetric4.0.0.0.0	.1.3.6.1.2.1.4.21.1.6.0.0.0.0	Integer	-1
ipRouteMetric4.10.100.65.0	.1.3.6.1.2.1.4.21.1.6.10.100.65.0	Integer	-1
ipRouteMetric4.10.100.65.116	.1.3.6.1.2.1.4.21.1.6.10.100.65.116	Integer	-1
ipRouteMetric4.10.100.65.255	.1.3.6.1.2.1.4.21.1.6.10.100.65.255	Integer	-1
ipRouteMetric4.127.0.0.0	.1.3.6.1.2.1.4.21.1.6.127.0.0.0	Integer	-1
ipRouteMetric4.127.0.0.1	.1.3.6.1.2.1.4.21.1.6.127.0.0.1	Integer	-1
ipRouteMe- tric4.127.255.255.255	.1.3.6.1.2.1.4.21.1.6.127.255.255.255	Integer	-1
ipRouteMetric4.224.0.0.0	.1.3.6.1.2.1.4.21.1.6.224.0.0.0	Integer	-1
ipRouteMe- tric4.255.255.255.255	.1.3.6.1.2.1.4.21.1.6.255.255.255.255	Integer	-1

Name	OID	Value Type	Value Example
ipRouteNextHop.0.0.0.0	.1.3.6.1.2.1.4.21.1.7.0.0.0.0	IpAddress	10.100.65.1
ipRouteNextHop.10.100.65.0	.1.3.6.1.2.1.4.21.1.7.10.100.65.0	IpAddress	10.100.65.116
ipRoute-NextHop.10.100.65.116	.1.3.6.1.2.1.4.21.1.7.10.100.65.116	IpAddress	127.0.0.1
ipRoute-NextHop.10.100.65.255	.1.3.6.1.2.1.4.21.1.7.10.100.65.255	IpAddress	10.100.65.116
ipRouteNextHop.127.0.0.0	.1.3.6.1.2.1.4.21.1.7.127.0.0.0	IpAddress	127.0.0.1
ipRouteNextHop.127.0.0.1	.1.3.6.1.2.1.4.21.1.7.127.0.0.1	IpAddress	127.0.0.1
ipRoute-NextHop.127.255.255.255	.1.3.6.1.2.1.4.21.1.7.127.255.255.255	IpAddress	127.0.0.1
ipRouteNextHop.224.0.0.0	.1.3.6.1.2.1.4.21.1.7.224.0.0.0	IpAddress	0.0.0.0
ipRoute-NextHop.255.255.255.255	.1.3.6.1.2.1.4.21.1.7.255.255.255.255	IpAddress	127.0.0.1
ipRouteType.0.0.0.0	.1.3.6.1.2.1.4.21.1.8.0.0.0.0	Integer	remote (4)
ipRouteType.10.100.65.0	.1.3.6.1.2.1.4.21.1.8.10.100.65.0	Integer	direct (3)
ipRouteType.10.100.65.116	.1.3.6.1.2.1.4.21.1.8.10.100.65.116	Integer	direct (3)
ipRouteType.10.100.65.255	.1.3.6.1.2.1.4.21.1.8.10.100.65.255	Integer	direct (3)
ipRouteType.127.0.0.0	.1.3.6.1.2.1.4.21.1.8.127.0.0.0	Integer	direct (3)
ipRouteType.127.0.0.1	.1.3.6.1.2.1.4.21.1.8.127.0.0.1	Integer	direct (3)
ipRouteType.127.255.255.255	.1.3.6.1.2.1.4.21.1.8.127.255.255.255	Integer	direct (3)
ipRouteType.224.0.0.0	.1.3.6.1.2.1.4.21.1.8.224.0.0.0	Integer	invalid (2)
ipRouteType.255.255.255.255	.1.3.6.1.2.1.4.21.1.8.255.255.255.255	Integer	direct (3)
ipRouteProto.0.0.0.0	.1.3.6.1.2.1.4.21.1.9.0.0.0.0	Integer	netmgmt (3)
ipRouteProto.10.100.65.0	.1.3.6.1.2.1.4.21.1.9.10.100.65.0	Integer	local (2)
ipRouteProto.10.100.65.116	.1.3.6.1.2.1.4.21.1.9.10.100.65.116	Integer	local (2)
ipRouteProto.10.100.65.255	.1.3.6.1.2.1.4.21.1.9.10.100.65.255	Integer	local (2)
ipRouteProto.127.0.0.0	.1.3.6.1.2.1.4.21.1.9.127.0.0.0	Integer	local (2)
ipRouteProto.127.0.0.1	.1.3.6.1.2.1.4.21.1.9.127.0.0.1	Integer	local (2)
ipRouteProto.127.255.255.255	.1.3.6.1.2.1.4.21.1.9.127.255.255.255	Integer	local (2)
ipRouteProto.224.0.0.0	.1.3.6.1.2.1.4.21.1.9.224.0.0.0	Integer	local (2)
ipRouteProto.255.255.255.255	.1.3.6.1.2.1.4.21.1.9.255.255.255.255	Integer	local (2)
ipRouteAge.0.0.0.0	.1.3.6.1.2.1.4.21.1.10.0.0.0.0	Integer	182
ipRouteAge.10.100.65.0	.1.3.6.1.2.1.4.21.1.10.10.100.65.0	Integer	182
ipRouteAge.10.100.65.116	.1.3.6.1.2.1.4.21.1.10.10.100.65.116	Integer	182
ipRouteAge.10.100.65.255	.1.3.6.1.2.1.4.21.1.10.10.100.65.255	Integer	182
ipRouteAge.127.0.0.0	.1.3.6.1.2.1.4.21.1.10.127.0.0.0	Integer	1366
ipRouteAge.127.0.0.1	.1.3.6.1.2.1.4.21.1.10.127.0.0.1	Integer	1366
ipRouteAge.127.255.255.255	.1.3.6.1.2.1.4.21.1.10.127.255.255.255	Integer	1366
ipRouteAge.224.0.0.0	.1.3.6.1.2.1.4.21.1.10.224.0.0.0	Integer	1366
ipRouteAge.255.255.255.255	.1.3.6.1.2.1.4.21.1.10.255.255.255.255	Integer	1366
ipRouteMask.0.0.0.0	.1.3.6.1.2.1.4.21.1.11.0.0.0.0	IpAddress	0.0.0.0
ipRouteMask.10.100.65.0	.1.3.6.1.2.1.4.21.1.11.10.100.65.0	IpAddress	255.255.255.0
ipRouteMask.10.100.65.116	.1.3.6.1.2.1.4.21.1.11.10.100.65.116	IpAddress	255.255.255.255
ipRouteMask.10.100.65.255	.1.3.6.1.2.1.4.21.1.11.10.100.65.255	IpAddress	255.255.255.255

Name	OID	Value Type	Value Example
ipRouteMask.127.0.0.0	.1.3.6.1.2.1.4.21.1.11.127.0.0.0	IpAddress	255.0.0.0
ipRouteMask.127.0.0.1	.1.3.6.1.2.1.4.21.1.11.127.0.0.1	IpAddress	255.255.255.255
ipRouteMask.127.255.255.255	.1.3.6.1.2.1.4.21.1.11.127.255.255.255	IpAddress	255.255.255.255
ipRouteMask.224.0.0.0	.1.3.6.1.2.1.4.21.1.11.224.0.0.0	IpAddress	240.0.0.0
ipRouteMask.255.255.255.255	.1.3.6.1.2.1.4.21.1.11.255.255.255.255	IpAddress	255.255.255.255
.1.3.6.1.2.1.4.21.1.12.0.0.0.0	.1.3.6.1.2.1.4.21.1.12.0.0.0.0	Integer	-1
.1.3.6.1.2.1.4.21.1.12.10.100.65.0	.1.3.6.1.2.1.4.21.1.12.10.100.65.0	Integer	-1
.1.3.6.1.2.1.4.21.1.12.10.100.65.116	.1.3.6.1.2.1.4.21.1.12.10.100.65.116	Integer	-1
.1.3.6.1.2.1.4.21.1.12.10.100.65.255	.1.3.6.1.2.1.4.21.1.12.10.100.65.255	Integer	-1
.1.3.6.1.2.1.4.21.1.12.127.0.0.0	.1.3.6.1.2.1.4.21.1.12.127.0.0.0	Integer	-1
.1.3.6.1.2.1.4.21.1.12.127.0.0.1	.1.3.6.1.2.1.4.21.1.12.127.0.0.1	Integer	-1
.1.3.6.1.2.1.4.21.1.12.127.255.255	.1.3.6.1.2.1.4.21.1.12.127.255.255	Integer	-1
.1.3.6.1.2.1.4.21.1.12.224.0.0.0	.1.3.6.1.2.1.4.21.1.12.224.0.0.0	Integer	-1
.1.3.6.1.2.1.4.21.1.12.255.255.255	.1.3.6.1.2.1.4.21.1.12.255.255.255	Integer	-1
.1.3.6.1.2.1.4.21.1.13.0.0.0.0	.1.3.6.1.2.1.4.21.1.13.0.0.0.0	OID	.0.0
.1.3.6.1.2.1.4.21.1.13.10.100.65.0	.1.3.6.1.2.1.4.21.1.13.10.100.65.0	OID	.0.0
.1.3.6.1.2.1.4.21.1.13.10.100.65.116	.1.3.6.1.2.1.4.21.1.13.10.100.65.116	OID	.0.0
.1.3.6.1.2.1.4.21.1.13.10.100.65.255	.1.3.6.1.2.1.4.21.1.13.10.100.65.255	OID	.0.0
.1.3.6.1.2.1.4.21.1.13.127.0.0.0	.1.3.6.1.2.1.4.21.1.13.127.0.0.0	OID	.0.0
.1.3.6.1.2.1.4.21.1.13.127.0.0.1	.1.3.6.1.2.1.4.21.1.13.127.0.0.1	OID	.0.0
.1.3.6.1.2.1.4.21.1.13.127.255.255	.1.3.6.1.2.1.4.21.1.13.127.255.255	OID	.0.0
.1.3.6.1.2.1.4.21.1.13.224.0.0.0	.1.3.6.1.2.1.4.21.1.13.224.0.0.0	OID	.0.0
.1.3.6.1.2.1.4.21.1.13.255.255.255	.1.3.6.1.2.1.4.21.1.13.255.255.255	OID	.0.0
ipNetToMediaIindex.634.10.100.65.1	.1.3.6.1.2.1.4.22.1.1.634.10.100.65.1	Integer	634
ipNetToMediaIindex.634.10.100.65.11	.1.3.6.1.2.1.4.22.1.1.634.10.100.65.11	Integer	634
ipNetToMediaIindex.634.10.100.65.12	.1.3.6.1.2.1.4.22.1.1.634.10.100.65.12	Integer	634
ipNetToMediaIindex.634.10.100.65.29	.1.3.6.1.2.1.4.22.1.1.634.10.100.65.29	Integer	634
ipNetToMediaIindex.634.10.100.65.31	.1.3.6.1.2.1.4.22.1.1.634.10.100.65.31	Integer	634
ipNetToMediaIindex.634.10.100.65.33	.1.3.6.1.2.1.4.22.1.1.634.10.100.65.33	Integer	634
ipNetToMediaIindex.634.10.100.65.34	.1.3.6.1.2.1.4.22.1.1.634.10.100.65.34	Integer	634
ipNetToMediaIindex.634.10.100.65.35	.1.3.6.1.2.1.4.22.1.1.634.10.100.65.35	Integer	634
ipNetToMediaIindex.634.10.100.65.39	.1.3.6.1.2.1.4.22.1.1.634.10.100.65.39	Integer	634
ipNetToMediaIindex.634.10.100.65.43	.1.3.6.1.2.1.4.22.1.1.634.10.100.65.43	Integer	634
ipNetToMediaIindex.634.10.100.65.67	.1.3.6.1.2.1.4.22.1.1.634.10.100.65.67	Integer	634
ipNetToMediaIindex.634.10.100.65.153	.1.3.6.1.2.1.4.22.1.1.634.10.100.65.153	Integer	634

Name	OID	Value Type	Value Example
ipNetToMediaIndex.634.10.100.65.158	.1.3.6.1.2.1.4.22.1.1.634.10.100.65.158	Integer	634
ipNetToMediaIndex.634.10.100.65.164	.1.3.6.1.2.1.4.22.1.1.634.10.100.65.164	Integer	634
ipNetToMediaIndex.634.10.100.65.170	.1.3.6.1.2.1.4.22.1.1.634.10.100.65.170	Integer	634
ipNetToMediaIndex.634.10.100.65.254	.1.3.6.1.2.1.4.22.1.1.634.10.100.65.254	Integer	634
ipNetToMediaPhysAddress.634.10.100.65.1	.1.3.6.1.2.1.4.22.1.2.634.10.100.65.1	OctetString	00-09-0F-09-1E-0A
ipNetToMediaPhysAddress.634.10.100.65.11	.1.3.6.1.2.1.4.22.1.2.634.10.100.65.11	OctetString	14-84-77-ED-A7-07
ipNetToMediaPhysAddress.634.10.100.65.12	.1.3.6.1.2.1.4.22.1.2.634.10.100.65.12	OctetString	BC-D0-EB-FD-5E-3B
ipNetToMediaPhysAddress.634.10.100.65.29	.1.3.6.1.2.1.4.22.1.2.634.10.100.65.29	OctetString	90-F7-B2-DD-73-E7
ipNetToMediaPhysAddress.634.10.100.65.31	.1.3.6.1.2.1.4.22.1.2.634.10.100.65.31	OctetString	14-84-77-CF-9A-6D
ipNetToMediaPhysAddress.634.10.100.65.33	.1.3.6.1.2.1.4.22.1.2.634.10.100.65.33	OctetString	14-84-77-85-A2-07
ipNetToMediaPhysAddress.634.10.100.65.34	.1.3.6.1.2.1.4.22.1.2.634.10.100.65.34	OctetString	14-84-77-8C-C7-7D
ipNetToMediaPhysAddress.634.10.100.65.35	.1.3.6.1.2.1.4.22.1.2.634.10.100.65.35	OctetString	7C-7A-3C-15-0E-1F
ipNetToMediaPhysAddress.634.10.100.65.39	.1.3.6.1.2.1.4.22.1.2.634.10.100.65.39	OctetString	54-C6-FF-E9-AC-66
ipNetToMediaPhysAddress.634.10.100.65.43	.1.3.6.1.2.1.4.22.1.2.634.10.100.65.43	OctetString	14-84-77-E3-41-49
ipNetToMediaPhysAddress.634.10.100.65.67	.1.3.6.1.2.1.4.22.1.2.634.10.100.65.67	OctetString	14-84-77-83-B1-2B
ipNetToMediaPhysAddress.634.10.100.65.153	.1.3.6.1.2.1.4.22.1.2.634.10.100.65.153	OctetString	00-00-FC-00-E2-CD
ipNetToMediaPhysAddress.634.10.100.65.158	.1.3.6.1.2.1.4.22.1.2.634.10.100.65.158	OctetString	E8-78-EE-E5-D3-07
ipNetToMediaPhysAddress.634.10.100.65.164	.1.3.6.1.2.1.4.22.1.2.634.10.100.65.164	OctetString	E4-60-17-EC-7A-A7
ipNetToMediaPhysAddress.634.10.100.65.170	.1.3.6.1.2.1.4.22.1.2.634.10.100.65.170	OctetString	14-84-77-94-F3-3D
ipNetToMediaPhysAddress.634.10.100.65.254	.1.3.6.1.2.1.4.22.1.2.634.10.100.65.254	OctetString	00-00-FC-00-9A-E2
ipNetToMediaNetAddress.634.10.100.65.1	.1.3.6.1.2.1.4.22.1.3.634.10.100.65.1	IpAddress	10.100.65.1
ipNetToMediaNetAddress.634.10.100.65.11	.1.3.6.1.2.1.4.22.1.3.634.10.100.65.11	IpAddress	10.100.65.11
ipNetToMediaNetAddress.634.10.100.65.12	.1.3.6.1.2.1.4.22.1.3.634.10.100.65.12	IpAddress	10.100.65.12
ipNetToMediaNetAddress.634.10.100.65.29	.1.3.6.1.2.1.4.22.1.3.634.10.100.65.29	IpAddress	10.100.65.29
ipNetToMediaNetAddress.634.10.100.65.31	.1.3.6.1.2.1.4.22.1.3.634.10.100.65.31	IpAddress	10.100.65.31

Name	OID	Value Type	Value Example
ipNetToMediaNetAddress.634.10.100.65.33	.1.3.6.1.2.1.4.22.1.3.634.10.100.65.33	IpAddress	10.100.65.33
ipNetToMediaNetAddress.634.10.100.65.34	.1.3.6.1.2.1.4.22.1.3.634.10.100.65.34	IpAddress	10.100.65.34
ipNetToMediaNetAddress.634.10.100.65.35	.1.3.6.1.2.1.4.22.1.3.634.10.100.65.35	IpAddress	10.100.65.35
ipNetToMediaNetAddress.634.10.100.65.39	.1.3.6.1.2.1.4.22.1.3.634.10.100.65.39	IpAddress	10.100.65.39
ipNetToMediaNetAddress.634.10.100.65.43	.1.3.6.1.2.1.4.22.1.3.634.10.100.65.43	IpAddress	10.100.65.43
ipNetToMediaNetAddress.634.10.100.65.67	.1.3.6.1.2.1.4.22.1.3.634.10.100.65.67	IpAddress	10.100.65.67
ipNetToMediaNetAddress.634.10.100.65.153	.1.3.6.1.2.1.4.22.1.3.634.10.100.65.153	IpAddress	10.100.65.153
ipNetToMediaNetAddress.634.10.100.65.158	.1.3.6.1.2.1.4.22.1.3.634.10.100.65.158	IpAddress	10.100.65.158
ipNetToMediaNetAddress.634.10.100.65.164	.1.3.6.1.2.1.4.22.1.3.634.10.100.65.164	IpAddress	10.100.65.164
ipNetToMediaNetAddress.634.10.100.65.170	.1.3.6.1.2.1.4.22.1.3.634.10.100.65.170	IpAddress	10.100.65.170
ipNetToMediaNetAddress.634.10.100.65.254	.1.3.6.1.2.1.4.22.1.3.634.10.100.65.254	IpAddress	10.100.65.254
ipNetToMediaType.634.10.100.65.1	.1.3.6.1.2.1.4.22.1.4.634.10.100.65.1	Integer	dynamic (3)
ipNetToMediaType.634.10.100.65.11	.1.3.6.1.2.1.4.22.1.4.634.10.100.65.11	Integer	dynamic (3)
ipNetToMediaType.634.10.100.65.12	.1.3.6.1.2.1.4.22.1.4.634.10.100.65.12	Integer	dynamic (3)
ipNetToMediaType.634.10.100.65.29	.1.3.6.1.2.1.4.22.1.4.634.10.100.65.29	Integer	dynamic (3)
ipNetToMediaType.634.10.100.65.31	.1.3.6.1.2.1.4.22.1.4.634.10.100.65.31	Integer	dynamic (3)
ipNetToMediaType.634.10.100.65.33	.1.3.6.1.2.1.4.22.1.4.634.10.100.65.33	Integer	dynamic (3)
ipNetToMediaType.634.10.100.65.34	.1.3.6.1.2.1.4.22.1.4.634.10.100.65.34	Integer	dynamic (3)
ipNetToMediaType.634.10.100.65.35	.1.3.6.1.2.1.4.22.1.4.634.10.100.65.35	Integer	dynamic (3)
ipNetToMediaType.634.10.100.65.39	.1.3.6.1.2.1.4.22.1.4.634.10.100.65.39	Integer	dynamic (3)
ipNetToMediaType.634.10.100.65.43	.1.3.6.1.2.1.4.22.1.4.634.10.100.65.43	Integer	dynamic (3)
ipNetToMediaType.634.10.100.65.67	.1.3.6.1.2.1.4.22.1.4.634.10.100.65.67	Integer	dynamic (3)
ipNetToMediaType.634.10.100.65.153	.1.3.6.1.2.1.4.22.1.4.634.10.100.65.153	Integer	dynamic (3)
ipNetToMediaType.634.10.100.65.158	.1.3.6.1.2.1.4.22.1.4.634.10.100.65.158	Integer	dynamic (3)
ipNetToMediaType.634.10.100.65.164	.1.3.6.1.2.1.4.22.1.4.634.10.100.65.164	Integer	dynamic (3)









Name	OID	Value Type	Value Example
ipCidrRouteNextHopAS.1.276102125.240.0.0.001277000010.255.0.0.0.0	127.0.0.1	Integer	0
ipCidrRouteNextHopAS.1.2720104255.255.255.255.001257256.255.255.00270.0.1	127.0.0.1	Integer	0
ipCidrRouteNextHopAS.1.2720104255.255.255.255.001257256.255.255.00270.0.1	127.0.0.1	Integer	0
ipCidrRouteNextHopAS.1.272254255.0522552552552550.227.0551256027.0.0.1	127.0.0.1	Integer	0
ipCidrRouteNextHopAS.224.0.0.0.0240.01010.0240.0.0.0.0	127.0.0.1	Integer	0
ipCidrRouteNextHopAS.224.0.0.0.0240.01010.0240.0.0.0.0	127.0.0.1	Integer	0
ipCidrRouteNextHopAS.254255.255.0522552552552550.227.0551256027.0.0.1	127.0.0.1	Integer	0
ipCidrRouteMetric1.0.0.0.030.0.0.0.00165.0.0.0.0.0.0.0.10.1	Integer	0	
ipCidrRouteMetric1.0.0.0.030.0.0.0.00165.0.0.0.0.0.0.0.10.1	Integer	0	
ipCidrRouteMetric1316.100165.244.255125600.65.0.255.255.265.0.0	Integer	0.65.116	
ipCidrRouteMetric13.6.0.200.624.25512560255.0.25512562551255.0	Integer	0.65.116	
ipCidrRouteMetric1316.100165.244.2551256.055.255.0612550255.255.255	Integer	27.0.0.1	
ipCidrRouteMetric3.6.102100.03.255.2550255.255.055.2551255125512551255	Integer	00.65.116	
ipCidrRouteMetric1.127.03001225.0400.0.127.0.0710.0.0.255.0.0.0.0	Integer	0	
ipCidrRouteMetric1.1276102125.2451255.255.0.027255.255.255.255	Integer	0.0.1	
ipCidrRouteMetric1.1276102125.2451255.255.0.027255.255.255.255	Integer	0.0.1	
ipCidrRouteMetric1.3.6.272259.295255.255.2952952952950.257.255.2551256027.0.0.1	Integer	0	
ipCidrRouteMetric1.224.0.006240.0.0.040.0101024.0.0.0.240.0.0.0.0	Integer	0	
ipCidrRouteMetric1.224.0.0.0.255225.29510.02400000.255.255.255	Integer	0.0	
ipCidrRouteMetric1.3.052259.295255.2952952952950.257.255.2551256027.0.0.1	Integer	0	
ipCidrRouteMetric2.0.0.0.030.0.0.0.00165.0.0.0.0.0.0.0.10.1	Integer	-1	
ipCidrRouteMetric2.0.0.0.030.0.0.0.00165.0.0.0.0.0.0.0.10.1	Integer	-1	
ipCidrRouteMetric2316.100165.244.255125600.65.0.255.255.265.0.0	Integer	0.65.116	
ipCidrRouteMetric13.6.0.200.624.25512560255.0.25512562551255.0	Integer	0.65.116	
ipCidrRouteMetric2316.100165.244.2551256.055.255.0612550255.255.255	Integer	27.0.0.1	
ipCidrRouteMetric3.6.102100.03.255.2550255.255.055.2551255125512551255	Integer	00.65.116	
ipCidrRouteMetric2.127.03001225.0400.0.127.0.0710.0.0.255.0.0.0.0	Integer	-1	
ipCidrRouteMetric2.1276102125.2451255.255.0.027255.255.255.255	Integer	-1	
ipCidrRouteMetric2.1276102125.2451255.255.0.027255.255.255.255	Integer	-1	
ipCidrRouteMetric1.3.6.272259.295255.255.2952952952950.257.255.2551256027.0.0.1	Integer	-1	
ipCidrRouteMetric2.224.0.006240.0.0.040.0101024.0.0.0.240.0.0.0.0	Integer	-1	
ipCidrRouteMetric2.224.0.0.0.255225.29510.02400000.255.255.255	Integer	-1	
ipCidrRouteMetric1.3.052259.295255.2952952952950.257.255.2551256027.0.0.1	Integer	-1	
ipCidrRouteMetric3.0.0.0.030.0.0.0.00165.0.0.0.0.0.0.0.10.1	Integer	-1	
ipCidrRouteMetric3.0.0.0.030.0.0.0.00165.0.0.0.0.0.0.0.10.1	Integer	-1	
ipCidrRouteMetric3316.100165.244.255125600.65.0.255.255.265.0.0	Integer	0.65.116	
ipCidrRouteMetric13.6.0.200.624.25512560255.0.25512562551255.0	Integer	-1	
ipCidrRouteMetric3316.100165.244.2551256.055.255.0612550255.255.255	Integer	-1	
ipCidrRouteMetric3.6.102100.03.255.2550255.255.055.2551255125512551255	Integer	00.65.116	
ipCidrRouteMetric3.127.03001225.0400.0.127.0.0710.0.0.255.0.0.0.0	Integer	-1	
ipCidrRouteMetric3.1276102125.2451255.255.0.027255.255.255.255	Integer	-1	
ipCidrRouteMetric3.1276102125.2451255.255.0.027255.255.255.255	Integer	-1	
ipCidrRouteMetric1.3.6.272259.295255.255.2952952952950.257.255.2551256027.0.0.1	Integer	-1	





Name	OID	Value Type	Value Example
inetCidrRouteIndex.1.4.24.0.0.0	1.3.6.1.2.1.4.24.0.0.0.3214701268435459.268435459	Integer	100.65.1
inetCidrRouteIndex.1.4.24.0.0.0	1.3.6.1.2.1.4.24.0.0.0.3214701268435459.268435459	Integer	632
inetCidrRouteIndex.1.4.24.0.0.0	1.3.6.1.2.1.4.24.0.0.0.3214701268435459.268435459	Integer	634
inetCidrRouteIndex.1.4.24.0.0.0	1.3.6.1.2.1.4.24.0.0.0.3214701268435459.268435459	Integer	634
inetCidrRouteIndex.1.4.24.0.0.0	1.3.6.1.2.1.4.24.0.0.0.3214701268435459.268435459	Integer	634
inetCidrRouteIndex.1.4.24.0.0.0	1.3.6.1.2.1.4.24.0.0.0.3214701268435459.268435459	Integer	632
inetCidrRouteIndex.1.4.24.0.0.0	1.3.6.1.2.1.4.24.0.0.0.3214701268435459.268435459	Integer	634
inetCidrRouteIndex.1.4.24.0.0.0	1.3.6.1.2.1.4.24.0.0.0.3214701268435459.268435459	Integer	632
inetCidrRouteIndex.1.4.24.0.0.0	1.3.6.1.2.1.4.24.0.0.0.3214701268435459.268435459	Integer	632
inetCidrRouteIndex.1.4.24.0.0.0	1.3.6.1.2.1.4.24.0.0.0.3214701268435459.268435459	Integer	632
inetCidrRouteIndex.1.4.24.0.0.0	1.3.6.1.2.1.4.24.0.0.0.3214701268435459.268435459	Integer	632
inetCidrRouteIndex.1.4.24.0.0.0	1.3.6.1.2.1.4.24.0.0.0.3214701268435459.268435459	Integer	631
inetCidrRouteIndex.1.4.24.0.0.0	1.3.6.1.2.1.4.24.0.0.0.3214701268435459.268435459	Integer	631
inetCidrRouteIndex.1.4.24.0.0.0	1.3.6.1.2.1.4.24.0.0.0.3214701268435459.268435459	Integer	632
inetCidrRouteDiscards.0	.1.3.6.1.2.1.4.24.8.0	Counter32	0
ipv6IpForwarding.0	.1.3.6.1.2.1.4.25.0	Integer	forwarding (1)
ipv6IpDefaultHopLimit.0	.1.3.6.1.2.1.4.26.0	Integer	64
ipIfStatsInReceives.1.634	.1.3.6.1.2.1.4.31.3.1.3.1.634	Counter32	0
ipIfStatsInOctets.1.634	.1.3.6.1.2.1.4.31.3.1.5.1.634	Counter32	0
ipIfStatsInHdrErrors.1.634	.1.3.6.1.2.1.4.31.3.1.7.1.634	Counter32	0
ipIfStatsInNoRoutes.1.634	.1.3.6.1.2.1.4.31.3.1.8.1.634	Counter32	0
ipIfStatsInAddrErrors.1.634	.1.3.6.1.2.1.4.31.3.1.9.1.634	Counter32	0
ipIfStatsInUnknownPro- tos.1.634	.1.3.6.1.2.1.4.31.3.1.10.1.634	Counter32	0
ipIfStatsInTruncatedPkts.1.634	.1.3.6.1.2.1.4.31.3.1.11.1.634	Counter32	0
ipIfStatsInForwData- grams.1.634	.1.3.6.1.2.1.4.31.3.1.12.1.634	Counter32	0
ipIfStatsReasmReqds.1.634	.1.3.6.1.2.1.4.31.3.1.14.1.634	Counter32	0
ipIfStatsReasmOKs.1.634	.1.3.6.1.2.1.4.31.3.1.15.1.634	Counter32	0
ipIfStatsReasmFails.1.634	.1.3.6.1.2.1.4.31.3.1.16.1.634	Counter32	0
ipIfStatsInDiscards.1.634	.1.3.6.1.2.1.4.31.3.1.17.1.634	Counter32	4294967295
ipIfStatsInDelivers.1.634	.1.3.6.1.2.1.4.31.3.1.18.1.634	Counter32	0
ipIfStatsOutRequests.1.634	.1.3.6.1.2.1.4.31.3.1.20.1.634	Counter32	0
ipIfStatsOutForwData- grams.1.634	.1.3.6.1.2.1.4.31.3.1.23.1.634	Counter32	0
ipIfStatsOutDiscards.1.634	.1.3.6.1.2.1.4.31.3.1.25.1.634	Counter32	4294967295
ipIfStatsOutFragReqds.1.634	.1.3.6.1.2.1.4.31.3.1.26.1.634	Counter32	0
ipIfStatsOutFragOKs.1.634	.1.3.6.1.2.1.4.31.3.1.27.1.634	Counter32	0
ipIfStatsOutFragFails.1.634	.1.3.6.1.2.1.4.31.3.1.28.1.634	Counter32	0
ipIfStatsOutFragCreates.1.634	.1.3.6.1.2.1.4.31.3.1.29.1.634	Counter32	0
ipIfStatsOutTransmits.1.634	.1.3.6.1.2.1.4.31.3.1.30.1.634	Counter32	0
ipIfStatsOutOctets.1.634	.1.3.6.1.2.1.4.31.3.1.32.1.634	Counter32	0
ipIfStatsInMcastPkts.1.634	.1.3.6.1.2.1.4.31.3.1.34.1.634	Counter32	0
ipIfStatsOutMcastPkts.1.634	.1.3.6.1.2.1.4.31.3.1.38.1.634	Counter32	0
icmplnMsgs.0	.1.3.6.1.2.1.5.1.0	Counter32	135

Name	OID	Value Type	Value Example
icmpInErrors.0	.1.3.6.1.2.1.5.2.0	Counter32	0
icmpInDestUnreachs.0	.1.3.6.1.2.1.5.3.0	Counter32	123
icmpInTimeExcds.0	.1.3.6.1.2.1.5.4.0	Counter32	0
icmpInParmProbs.0	.1.3.6.1.2.1.5.5.0	Counter32	0
icmpInSrcQuenchs.0	.1.3.6.1.2.1.5.6.0	Counter32	0
icmpInRedirects.0	.1.3.6.1.2.1.5.7.0	Counter32	0
icmpInEchos.0	.1.3.6.1.2.1.5.8.0	Counter32	7
icmpInEchoReps.0	.1.3.6.1.2.1.5.9.0	Counter32	5
icmpInTimestamps.0	.1.3.6.1.2.1.5.10.0	Counter32	0
icmpInTimestampReps.0	.1.3.6.1.2.1.5.11.0	Counter32	0
icmpInAddrMasks.0	.1.3.6.1.2.1.5.12.0	Counter32	0
icmpInAddrMaskReps.0	.1.3.6.1.2.1.5.13.0	Counter32	0
icmpOutMsgs.0	.1.3.6.1.2.1.5.14.0	Counter32	19
icmpOutErrors.0	.1.3.6.1.2.1.5.15.0	Counter32	4
icmpOutDestUnreachs.0	.1.3.6.1.2.1.5.16.0	Counter32	0
icmpOutTimeExcds.0	.1.3.6.1.2.1.5.17.0	Counter32	0
icmpOutParmProbs.0	.1.3.6.1.2.1.5.18.0	Counter32	0
icmpOutSrcQuenchs.0	.1.3.6.1.2.1.5.19.0	Counter32	0
icmpOutRedirects.0	.1.3.6.1.2.1.5.20.0	Counter32	0
icmpOutEchos.0	.1.3.6.1.2.1.5.21.0	Counter32	8
icmpOutEchoReps.0	.1.3.6.1.2.1.5.22.0	Counter32	7
icmpOutTimestamps.0	.1.3.6.1.2.1.5.23.0	Counter32	0
icmpOutTimestampReps.0	.1.3.6.1.2.1.5.24.0	Counter32	0
icmpOutAddrMasks.0	.1.3.6.1.2.1.5.25.0	Counter32	0
icmpOutAddrMaskReps.0	.1.3.6.1.2.1.5.26.0	Counter32	0
icmpStatsInMsgs.2	.1.3.6.1.2.1.5.29.1.2.2	Counter32	0
icmpMsgStatsInPkts.2.1	.1.3.6.1.2.1.5.30.1.3.2.1	Counter32	0
tcpRtoAlgorithm.0	.1.3.6.1.2.1.6.1.0	Integer	vanj (4)
tcpRtoMin.0	.1.3.6.1.2.1.6.2.0	Integer	1000
tcpRtoMax.0	.1.3.6.1.2.1.6.3.0	Integer	64000
tcpMaxConn.0	.1.3.6.1.2.1.6.4.0	Integer	-1
tcpActiveOpens.0	.1.3.6.1.2.1.6.5.0	Counter32	212
tcpPassiveOpens.0	.1.3.6.1.2.1.6.6.0	Counter32	0
tcpAttemptFails.0	.1.3.6.1.2.1.6.7.0	Counter32	0
tcpEstabResets.0	.1.3.6.1.2.1.6.8.0	Counter32	4
tcpCurrEstab.0	.1.3.6.1.2.1.6.9.0	Gauge	4
tcpInSegs.0	.1.3.6.1.2.1.6.10.0	Counter32	388
tcpOutSegs.0	.1.3.6.1.2.1.6.11.0	Counter32	587
tcpRetransSegs.0	.1.3.6.1.2.1.6.12.0	Counter32	48
tcpConnS- tate.0.0.0.0.22.0.0.0.0	.1.3.6.1.2.1.6.13.1.1.0.0.0.0.22.0.0.0.0	Integer	listen (2)
tcpConnS- tate.0.0.0.0.80.0.0.0.0	.1.3.6.1.2.1.6.13.1.1.0.0.0.0.80.0.0.0.0	Integer	listen (2)

Name	OID	Value Type	Value Example
tcpConnState.0.0.0.0.443.0.0.0.0.0	.1.3.6.1.2.1.6.13.1.1.0.0.0.0.443.0.0.0.0	Integer	listen (2)
tcpConnState.10.100.65.616.21504.20.33.0.82617443	.1.3.6.1.2.1.6.13.1.1.0.0.0.0.443.0.0.0.0	Integer	established (5)
tcpConnState.10.100.65.616.21505.20.33.0.82617443	.1.3.6.1.2.1.6.13.1.1.0.0.0.0.443.0.0.0.0	Integer	established (5)
tcpConnState.10.100.65.616.21506.20.33.0.82617443	.1.3.6.1.2.1.6.13.1.1.0.0.0.0.443.0.0.0.0	Integer	established (5)
tcpConnState.10.100.65.616.21507.20.33.0.82617443	.1.3.6.1.2.1.6.13.1.1.0.0.0.0.443.0.0.0.0	Integer	established (5)
tcpConnLocalAddress.0.0.0.0.22.0.0.0.0.0	.1.3.6.1.2.1.6.13.1.2.0.0.0.0.22.0.0.0.0	IpAddress	0.0.0.0
tcpConnLocalAddress.0.0.0.0.80.0.0.0.0.0	.1.3.6.1.2.1.6.13.1.2.0.0.0.0.80.0.0.0.0	IpAddress	0.0.0.0
tcpConnLocalAddress.0.0.0.0.443.0.0.0.0.0	.1.3.6.1.2.1.6.13.1.2.0.0.0.0.443.0.0.0.0	IpAddress	0.0.0.0
tcpConnLocalAddress.10.100.65.616.11504.20.33.0.82617443	.1.3.6.1.2.1.6.13.1.2.0.0.0.0.443.0.0.0.0	IpAddress	10.100.65.116
tcpConnLocalAddress.10.100.65.616.11505.20.33.0.82617443	.1.3.6.1.2.1.6.13.1.2.0.0.0.0.443.0.0.0.0	IpAddress	10.100.65.116
tcpConnLocalAddress.10.100.65.616.11506.20.33.0.82617443	.1.3.6.1.2.1.6.13.1.2.0.0.0.0.443.0.0.0.0	IpAddress	10.100.65.116
tcpConnLocalAddress.10.100.65.616.11507.20.33.0.82617443	.1.3.6.1.2.1.6.13.1.2.0.0.0.0.443.0.0.0.0	IpAddress	10.100.65.116
tcpConnLocalPort.0.0.0.0.22.0.0.0.0.0	.1.3.6.1.2.1.6.13.1.3.0.0.0.0.22.0.0.0.0	Integer	22
tcpConnLocalPort.0.0.0.0.80.0.0.0.0.0	.1.3.6.1.2.1.6.13.1.3.0.0.0.0.80.0.0.0.0	Integer	80
tcpConnLocalPort.0.0.0.0.443.0.0.0.0.0	.1.3.6.1.2.1.6.13.1.3.0.0.0.0.443.0.0.0.0	Integer	443
tcpConnLocalPort.10.100.65.216.15504.20.33.0.82617443	.1.3.6.1.2.1.6.13.1.3.0.0.0.0.443.0.0.0.0	Integer	15504
tcpConnLocalPort.10.100.65.216.15505.20.33.0.82617443	.1.3.6.1.2.1.6.13.1.3.0.0.0.0.443.0.0.0.0	Integer	15505
tcpConnLocalPort.10.100.65.216.15506.20.33.0.82617443	.1.3.6.1.2.1.6.13.1.3.0.0.0.0.443.0.0.0.0	Integer	15506
tcpConnLocalPort.10.100.65.216.15507.20.33.0.82617443	.1.3.6.1.2.1.6.13.1.3.0.0.0.0.443.0.0.0.0	Integer	15507
tcpConnRemAddress.0.0.0.0.22.0.0.0.0.0	.1.3.6.1.2.1.6.13.1.4.0.0.0.0.22.0.0.0.0	IpAddress	0.0.0.0
tcpConnRemAddress.0.0.0.0.80.0.0.0.0.0	.1.3.6.1.2.1.6.13.1.4.0.0.0.0.80.0.0.0.0	IpAddress	0.0.0.0
tcpConnRemAddress.0.0.0.0.443.0.0.0.0.0	.1.3.6.1.2.1.6.13.1.4.0.0.0.0.443.0.0.0.0	IpAddress	0.0.0.0
tcpConnRemAddress.10.100.65.216.15504.20.33.0.82617443	.1.3.6.1.2.1.6.13.1.4.0.0.0.0.443.0.0.0.0	IpAddress	20.33.5.82
tcpConnRemAddress.10.100.65.216.15505.20.33.0.82617443	.1.3.6.1.2.1.6.13.1.4.0.0.0.0.443.0.0.0.0	IpAddress	20.33.5.82
tcpConnRemAddress.10.100.65.216.15506.20.33.0.82617443	.1.3.6.1.2.1.6.13.1.4.0.0.0.0.443.0.0.0.0	IpAddress	20.33.5.82
tcpConnRemAddress.10.100.65.216.15507.20.33.0.82617443	.1.3.6.1.2.1.6.13.1.4.0.0.0.0.443.0.0.0.0	IpAddress	20.33.5.82
tcpConnRemPort.0.0.0.0.22.0.0.0.0.0	.1.3.6.1.2.1.6.13.1.5.0.0.0.0.22.0.0.0.0	Integer	0
tcpConnRemPort.0.0.0.0.80.0.0.0.0.0	.1.3.6.1.2.1.6.13.1.5.0.0.0.0.80.0.0.0.0	Integer	0
tcpConnRemPort.0.0.0.0.443.0.0.0.0.0	.1.3.6.1.2.1.6.13.1.5.0.0.0.0.443.0.0.0.0	Integer	0
tcpConnRemPort.10.100.65.216.15504.20.33.0.82617443	.1.3.6.1.2.1.6.13.1.5.0.0.0.0.443.0.0.0.0	Integer	17443
tcpConnRemPort.10.100.65.216.15505.20.33.0.82617443	.1.3.6.1.2.1.6.13.1.5.0.0.0.0.443.0.0.0.0	Integer	17443
tcpConnRemPort.10.100.65.216.15506.20.33.0.82617443	.1.3.6.1.2.1.6.13.1.5.0.0.0.0.443.0.0.0.0	Integer	17443
tcpConnRemPort.10.100.65.216.15507.20.33.0.82617443	.1.3.6.1.2.1.6.13.1.5.0.0.0.0.443.0.0.0.0	Integer	17443
tcpInErrs.0	.1.3.6.1.2.1.6.14.0	Counter32	0





Name	OID	Value Type	Value Example
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.1	Integer	9345
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.2	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.3	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.4	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.5	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.6	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.7	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.8	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.9	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.10	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.11	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.12	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.13	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.14	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.15	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.16	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.17	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.18	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.19	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.20	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.21	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.22	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.23	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.24	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.25	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.26	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.27	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.28	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.29	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.30	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.31	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.32	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.33	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.34	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.35	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.36	Integer	11748
udpEndpointProcess	.3.6.1.2.1.10.7.2.1.1.37	Integer	11748

Name	OID	Value Type	Value Example
dot3StatsIndex.38	.1.3.6.1.2.1.10.7.2.1.1.38	Integer	38
dot3StatsIndex.39	.1.3.6.1.2.1.10.7.2.1.1.39	Integer	39
dot3StatsIndex.40	.1.3.6.1.2.1.10.7.2.1.1.40	Integer	40
dot3StatsIndex.41	.1.3.6.1.2.1.10.7.2.1.1.41	Integer	41
dot3StatsIndex.42	.1.3.6.1.2.1.10.7.2.1.1.42	Integer	42
dot3StatsIndex.43	.1.3.6.1.2.1.10.7.2.1.1.43	Integer	43
dot3StatsIndex.44	.1.3.6.1.2.1.10.7.2.1.1.44	Integer	44
dot3StatsIndex.45	.1.3.6.1.2.1.10.7.2.1.1.45	Integer	45
dot3StatsIndex.46	.1.3.6.1.2.1.10.7.2.1.1.46	Integer	46
dot3StatsIndex.47	.1.3.6.1.2.1.10.7.2.1.1.47	Integer	47
dot3StatsIndex.48	.1.3.6.1.2.1.10.7.2.1.1.48	Integer	48
dot3StatsIndex.49	.1.3.6.1.2.1.10.7.2.1.1.49	Integer	49
dot3StatsIndex.50	.1.3.6.1.2.1.10.7.2.1.1.50	Integer	50
dot3StatsIndex.51	.1.3.6.1.2.1.10.7.2.1.1.51	Integer	51
dot3StatsIndex.52	.1.3.6.1.2.1.10.7.2.1.1.52	Integer	52
dot3StatsIndex.53	.1.3.6.1.2.1.10.7.2.1.1.53	Integer	53
dot3StatsIndex.54	.1.3.6.1.2.1.10.7.2.1.1.54	Integer	54
dot3StatsAlignmentErrors.1	.1.3.6.1.2.1.10.7.2.1.2.1	Counter32	0
dot3StatsAlignmentErrors.2	.1.3.6.1.2.1.10.7.2.1.2.2	Counter32	0
dot3StatsAlignmentErrors.3	.1.3.6.1.2.1.10.7.2.1.2.3	Counter32	0
dot3StatsAlignmentErrors.4	.1.3.6.1.2.1.10.7.2.1.2.4	Counter32	0
dot3StatsAlignmentErrors.5	.1.3.6.1.2.1.10.7.2.1.2.5	Counter32	0
dot3StatsAlignmentErrors.6	.1.3.6.1.2.1.10.7.2.1.2.6	Counter32	0
dot3StatsAlignmentErrors.7	.1.3.6.1.2.1.10.7.2.1.2.7	Counter32	0
dot3StatsAlignmentErrors.8	.1.3.6.1.2.1.10.7.2.1.2.8	Counter32	0
dot3StatsAlignmentErrors.9	.1.3.6.1.2.1.10.7.2.1.2.9	Counter32	0
dot3StatsAlignmentErrors.10	.1.3.6.1.2.1.10.7.2.1.2.10	Counter32	0
dot3StatsAlignmentErrors.11	.1.3.6.1.2.1.10.7.2.1.2.11	Counter32	0
dot3StatsAlignmentErrors.12	.1.3.6.1.2.1.10.7.2.1.2.12	Counter32	0
dot3StatsAlignmentErrors.13	.1.3.6.1.2.1.10.7.2.1.2.13	Counter32	0
dot3StatsAlignmentErrors.14	.1.3.6.1.2.1.10.7.2.1.2.14	Counter32	0
dot3StatsAlignmentErrors.15	.1.3.6.1.2.1.10.7.2.1.2.15	Counter32	0
dot3StatsAlignmentErrors.16	.1.3.6.1.2.1.10.7.2.1.2.16	Counter32	0
dot3StatsAlignmentErrors.17	.1.3.6.1.2.1.10.7.2.1.2.17	Counter32	0
dot3StatsAlignmentErrors.18	.1.3.6.1.2.1.10.7.2.1.2.18	Counter32	0
dot3StatsAlignmentErrors.19	.1.3.6.1.2.1.10.7.2.1.2.19	Counter32	0
dot3StatsAlignmentErrors.20	.1.3.6.1.2.1.10.7.2.1.2.20	Counter32	0
dot3StatsAlignmentErrors.21	.1.3.6.1.2.1.10.7.2.1.2.21	Counter32	0
dot3StatsAlignmentErrors.22	.1.3.6.1.2.1.10.7.2.1.2.22	Counter32	0
dot3StatsAlignmentErrors.23	.1.3.6.1.2.1.10.7.2.1.2.23	Counter32	0
dot3StatsAlignmentErrors.24	.1.3.6.1.2.1.10.7.2.1.2.24	Counter32	0
dot3StatsAlignmentErrors.25	.1.3.6.1.2.1.10.7.2.1.2.25	Counter32	0
dot3StatsAlignmentErrors.26	.1.3.6.1.2.1.10.7.2.1.2.26	Counter32	0

Name	OID	Value Type	Value Example
dot3StatsAlignmentErrors.27	.1.3.6.1.2.1.10.7.2.1.2.27	Counter32	0
dot3StatsAlignmentErrors.28	.1.3.6.1.2.1.10.7.2.1.2.28	Counter32	0
dot3StatsAlignmentErrors.29	.1.3.6.1.2.1.10.7.2.1.2.29	Counter32	0
dot3StatsAlignmentErrors.30	.1.3.6.1.2.1.10.7.2.1.2.30	Counter32	0
dot3StatsAlignmentErrors.31	.1.3.6.1.2.1.10.7.2.1.2.31	Counter32	0
dot3StatsAlignmentErrors.32	.1.3.6.1.2.1.10.7.2.1.2.32	Counter32	0
dot3StatsAlignmentErrors.33	.1.3.6.1.2.1.10.7.2.1.2.33	Counter32	0
dot3StatsAlignmentErrors.34	.1.3.6.1.2.1.10.7.2.1.2.34	Counter32	0
dot3StatsAlignmentErrors.35	.1.3.6.1.2.1.10.7.2.1.2.35	Counter32	0
dot3StatsAlignmentErrors.36	.1.3.6.1.2.1.10.7.2.1.2.36	Counter32	0
dot3StatsAlignmentErrors.37	.1.3.6.1.2.1.10.7.2.1.2.37	Counter32	0
dot3StatsAlignmentErrors.38	.1.3.6.1.2.1.10.7.2.1.2.38	Counter32	0
dot3StatsAlignmentErrors.39	.1.3.6.1.2.1.10.7.2.1.2.39	Counter32	0
dot3StatsAlignmentErrors.40	.1.3.6.1.2.1.10.7.2.1.2.40	Counter32	0
dot3StatsAlignmentErrors.41	.1.3.6.1.2.1.10.7.2.1.2.41	Counter32	0
dot3StatsAlignmentErrors.42	.1.3.6.1.2.1.10.7.2.1.2.42	Counter32	0
dot3StatsAlignmentErrors.43	.1.3.6.1.2.1.10.7.2.1.2.43	Counter32	0
dot3StatsAlignmentErrors.44	.1.3.6.1.2.1.10.7.2.1.2.44	Counter32	0
dot3StatsAlignmentErrors.45	.1.3.6.1.2.1.10.7.2.1.2.45	Counter32	0
dot3StatsAlignmentErrors.46	.1.3.6.1.2.1.10.7.2.1.2.46	Counter32	0
dot3StatsAlignmentErrors.47	.1.3.6.1.2.1.10.7.2.1.2.47	Counter32	0
dot3StatsAlignmentErrors.48	.1.3.6.1.2.1.10.7.2.1.2.48	Counter32	0
dot3StatsAlignmentErrors.49	.1.3.6.1.2.1.10.7.2.1.2.49	Counter32	0
dot3StatsAlignmentErrors.50	.1.3.6.1.2.1.10.7.2.1.2.50	Counter32	0
dot3StatsAlignmentErrors.51	.1.3.6.1.2.1.10.7.2.1.2.51	Counter32	0
dot3StatsAlignmentErrors.52	.1.3.6.1.2.1.10.7.2.1.2.52	Counter32	0
dot3StatsAlignmentErrors.53	.1.3.6.1.2.1.10.7.2.1.2.53	Counter32	0
dot3StatsAlignmentErrors.54	.1.3.6.1.2.1.10.7.2.1.2.54	Counter32	0
dot3StatsFCSErrors.1	.1.3.6.1.2.1.10.7.2.1.3.1	Counter32	0
dot3StatsFCSErrors.2	.1.3.6.1.2.1.10.7.2.1.3.2	Counter32	0
dot3StatsFCSErrors.3	.1.3.6.1.2.1.10.7.2.1.3.3	Counter32	0
dot3StatsFCSErrors.4	.1.3.6.1.2.1.10.7.2.1.3.4	Counter32	0
dot3StatsFCSErrors.5	.1.3.6.1.2.1.10.7.2.1.3.5	Counter32	0
dot3StatsFCSErrors.6	.1.3.6.1.2.1.10.7.2.1.3.6	Counter32	0
dot3StatsFCSErrors.7	.1.3.6.1.2.1.10.7.2.1.3.7	Counter32	0
dot3StatsFCSErrors.8	.1.3.6.1.2.1.10.7.2.1.3.8	Counter32	0
dot3StatsFCSErrors.9	.1.3.6.1.2.1.10.7.2.1.3.9	Counter32	0
dot3StatsFCSErrors.10	.1.3.6.1.2.1.10.7.2.1.3.10	Counter32	0
dot3StatsFCSErrors.11	.1.3.6.1.2.1.10.7.2.1.3.11	Counter32	0
dot3StatsFCSErrors.12	.1.3.6.1.2.1.10.7.2.1.3.12	Counter32	0
dot3StatsFCSErrors.13	.1.3.6.1.2.1.10.7.2.1.3.13	Counter32	0
dot3StatsFCSErrors.14	.1.3.6.1.2.1.10.7.2.1.3.14	Counter32	0
dot3StatsFCSErrors.15	.1.3.6.1.2.1.10.7.2.1.3.15	Counter32	0

Name	OID	Value Type	Value Example
dot3StatsFCSErrors.16	.1.3.6.1.2.1.10.7.2.1.3.16	Counter32	0
dot3StatsFCSErrors.17	.1.3.6.1.2.1.10.7.2.1.3.17	Counter32	0
dot3StatsFCSErrors.18	.1.3.6.1.2.1.10.7.2.1.3.18	Counter32	0
dot3StatsFCSErrors.19	.1.3.6.1.2.1.10.7.2.1.3.19	Counter32	0
dot3StatsFCSErrors.20	.1.3.6.1.2.1.10.7.2.1.3.20	Counter32	0
dot3StatsFCSErrors.21	.1.3.6.1.2.1.10.7.2.1.3.21	Counter32	0
dot3StatsFCSErrors.22	.1.3.6.1.2.1.10.7.2.1.3.22	Counter32	0
dot3StatsFCSErrors.23	.1.3.6.1.2.1.10.7.2.1.3.23	Counter32	0
dot3StatsFCSErrors.24	.1.3.6.1.2.1.10.7.2.1.3.24	Counter32	0
dot3StatsFCSErrors.25	.1.3.6.1.2.1.10.7.2.1.3.25	Counter32	0
dot3StatsFCSErrors.26	.1.3.6.1.2.1.10.7.2.1.3.26	Counter32	0
dot3StatsFCSErrors.27	.1.3.6.1.2.1.10.7.2.1.3.27	Counter32	0
dot3StatsFCSErrors.28	.1.3.6.1.2.1.10.7.2.1.3.28	Counter32	0
dot3StatsFCSErrors.29	.1.3.6.1.2.1.10.7.2.1.3.29	Counter32	0
dot3StatsFCSErrors.30	.1.3.6.1.2.1.10.7.2.1.3.30	Counter32	0
dot3StatsFCSErrors.31	.1.3.6.1.2.1.10.7.2.1.3.31	Counter32	0
dot3StatsFCSErrors.32	.1.3.6.1.2.1.10.7.2.1.3.32	Counter32	0
dot3StatsFCSErrors.33	.1.3.6.1.2.1.10.7.2.1.3.33	Counter32	0
dot3StatsFCSErrors.34	.1.3.6.1.2.1.10.7.2.1.3.34	Counter32	0
dot3StatsFCSErrors.35	.1.3.6.1.2.1.10.7.2.1.3.35	Counter32	0
dot3StatsFCSErrors.36	.1.3.6.1.2.1.10.7.2.1.3.36	Counter32	0
dot3StatsFCSErrors.37	.1.3.6.1.2.1.10.7.2.1.3.37	Counter32	0
dot3StatsFCSErrors.38	.1.3.6.1.2.1.10.7.2.1.3.38	Counter32	0
dot3StatsFCSErrors.39	.1.3.6.1.2.1.10.7.2.1.3.39	Counter32	0
dot3StatsFCSErrors.40	.1.3.6.1.2.1.10.7.2.1.3.40	Counter32	0
dot3StatsFCSErrors.41	.1.3.6.1.2.1.10.7.2.1.3.41	Counter32	0
dot3StatsFCSErrors.42	.1.3.6.1.2.1.10.7.2.1.3.42	Counter32	0
dot3StatsFCSErrors.43	.1.3.6.1.2.1.10.7.2.1.3.43	Counter32	0
dot3StatsFCSErrors.44	.1.3.6.1.2.1.10.7.2.1.3.44	Counter32	0
dot3StatsFCSErrors.45	.1.3.6.1.2.1.10.7.2.1.3.45	Counter32	0
dot3StatsFCSErrors.46	.1.3.6.1.2.1.10.7.2.1.3.46	Counter32	0
dot3StatsFCSErrors.47	.1.3.6.1.2.1.10.7.2.1.3.47	Counter32	0
dot3StatsFCSErrors.48	.1.3.6.1.2.1.10.7.2.1.3.48	Counter32	0
dot3StatsFCSErrors.49	.1.3.6.1.2.1.10.7.2.1.3.49	Counter32	0
dot3StatsFCSErrors.50	.1.3.6.1.2.1.10.7.2.1.3.50	Counter32	0
dot3StatsFCSErrors.51	.1.3.6.1.2.1.10.7.2.1.3.51	Counter32	0
dot3StatsFCSErrors.52	.1.3.6.1.2.1.10.7.2.1.3.52	Counter32	0
dot3StatsFCSErrors.53	.1.3.6.1.2.1.10.7.2.1.3.53	Counter32	0
dot3StatsFCSErrors.54	.1.3.6.1.2.1.10.7.2.1.3.54	Counter32	0
dot3StatsSingleCollisionFrames.1	.1.3.6.1.2.1.10.7.2.1.4.1	Counter32	0
dot3StatsSingleCollisionFrames.2	.1.3.6.1.2.1.10.7.2.1.4.2	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot3StatsSingleCollisionFrames.3	.1.3.6.1.2.1.10.7.2.1.4.3	Counter32	0
dot3StatsSingleCollisionFrames.4	.1.3.6.1.2.1.10.7.2.1.4.4	Counter32	0
dot3StatsSingleCollisionFrames.5	.1.3.6.1.2.1.10.7.2.1.4.5	Counter32	0
dot3StatsSingleCollisionFrames.6	.1.3.6.1.2.1.10.7.2.1.4.6	Counter32	0
dot3StatsSingleCollisionFrames.7	.1.3.6.1.2.1.10.7.2.1.4.7	Counter32	0
dot3StatsSingleCollisionFrames.8	.1.3.6.1.2.1.10.7.2.1.4.8	Counter32	0
dot3StatsSingleCollisionFrames.9	.1.3.6.1.2.1.10.7.2.1.4.9	Counter32	0
dot3StatsSingleCollisionFrames.10	.1.3.6.1.2.1.10.7.2.1.4.10	Counter32	0
dot3StatsSingleCollisionFrames.11	.1.3.6.1.2.1.10.7.2.1.4.11	Counter32	0
dot3StatsSingleCollisionFrames.12	.1.3.6.1.2.1.10.7.2.1.4.12	Counter32	0
dot3StatsSingleCollisionFrames.13	.1.3.6.1.2.1.10.7.2.1.4.13	Counter32	0
dot3StatsSingleCollisionFrames.14	.1.3.6.1.2.1.10.7.2.1.4.14	Counter32	0
dot3StatsSingleCollisionFrames.15	.1.3.6.1.2.1.10.7.2.1.4.15	Counter32	0
dot3StatsSingleCollisionFrames.16	.1.3.6.1.2.1.10.7.2.1.4.16	Counter32	0
dot3StatsSingleCollisionFrames.17	.1.3.6.1.2.1.10.7.2.1.4.17	Counter32	0
dot3StatsSingleCollisionFrames.18	.1.3.6.1.2.1.10.7.2.1.4.18	Counter32	0
dot3StatsSingleCollisionFrames.19	.1.3.6.1.2.1.10.7.2.1.4.19	Counter32	0
dot3StatsSingleCollisionFrames.20	.1.3.6.1.2.1.10.7.2.1.4.20	Counter32	0
dot3StatsSingleCollisionFrames.21	.1.3.6.1.2.1.10.7.2.1.4.21	Counter32	0
dot3StatsSingleCollisionFrames.22	.1.3.6.1.2.1.10.7.2.1.4.22	Counter32	0
dot3StatsSingleCollisionFrames.23	.1.3.6.1.2.1.10.7.2.1.4.23	Counter32	0
dot3StatsSingleCollisionFrames.24	.1.3.6.1.2.1.10.7.2.1.4.24	Counter32	0
dot3StatsSingleCollisionFrames.25	.1.3.6.1.2.1.10.7.2.1.4.25	Counter32	0
dot3StatsSingleCollisionFrames.26	.1.3.6.1.2.1.10.7.2.1.4.26	Counter32	0
dot3StatsSingleCollisionFrames.27	.1.3.6.1.2.1.10.7.2.1.4.27	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot3StatsSingleCollisionFrames.28	.1.3.6.1.2.1.10.7.2.1.4.28	Counter32	0
dot3StatsSingleCollisionFrames.29	.1.3.6.1.2.1.10.7.2.1.4.29	Counter32	0
dot3StatsSingleCollisionFrames.30	.1.3.6.1.2.1.10.7.2.1.4.30	Counter32	0
dot3StatsSingleCollisionFrames.31	.1.3.6.1.2.1.10.7.2.1.4.31	Counter32	0
dot3StatsSingleCollisionFrames.32	.1.3.6.1.2.1.10.7.2.1.4.32	Counter32	0
dot3StatsSingleCollisionFrames.33	.1.3.6.1.2.1.10.7.2.1.4.33	Counter32	0
dot3StatsSingleCollisionFrames.34	.1.3.6.1.2.1.10.7.2.1.4.34	Counter32	0
dot3StatsSingleCollisionFrames.35	.1.3.6.1.2.1.10.7.2.1.4.35	Counter32	0
dot3StatsSingleCollisionFrames.36	.1.3.6.1.2.1.10.7.2.1.4.36	Counter32	0
dot3StatsSingleCollisionFrames.37	.1.3.6.1.2.1.10.7.2.1.4.37	Counter32	0
dot3StatsSingleCollisionFrames.38	.1.3.6.1.2.1.10.7.2.1.4.38	Counter32	0
dot3StatsSingleCollisionFrames.39	.1.3.6.1.2.1.10.7.2.1.4.39	Counter32	0
dot3StatsSingleCollisionFrames.40	.1.3.6.1.2.1.10.7.2.1.4.40	Counter32	0
dot3StatsSingleCollisionFrames.41	.1.3.6.1.2.1.10.7.2.1.4.41	Counter32	0
dot3StatsSingleCollisionFrames.42	.1.3.6.1.2.1.10.7.2.1.4.42	Counter32	0
dot3StatsSingleCollisionFrames.43	.1.3.6.1.2.1.10.7.2.1.4.43	Counter32	0
dot3StatsSingleCollisionFrames.44	.1.3.6.1.2.1.10.7.2.1.4.44	Counter32	0
dot3StatsSingleCollisionFrames.45	.1.3.6.1.2.1.10.7.2.1.4.45	Counter32	0
dot3StatsSingleCollisionFrames.46	.1.3.6.1.2.1.10.7.2.1.4.46	Counter32	0
dot3StatsSingleCollisionFrames.47	.1.3.6.1.2.1.10.7.2.1.4.47	Counter32	0
dot3StatsSingleCollisionFrames.48	.1.3.6.1.2.1.10.7.2.1.4.48	Counter32	0
dot3StatsSingleCollisionFrames.49	.1.3.6.1.2.1.10.7.2.1.4.49	Counter32	0
dot3StatsSingleCollisionFrames.50	.1.3.6.1.2.1.10.7.2.1.4.50	Counter32	0
dot3StatsSingleCollisionFrames.51	.1.3.6.1.2.1.10.7.2.1.4.51	Counter32	0
dot3StatsSingleCollisionFrames.52	.1.3.6.1.2.1.10.7.2.1.4.52	Counter32	0

Name	OID	Value Type	Value Example
dot3StatsSingleCollisionFrames.53	.1.3.6.1.2.1.10.7.2.1.4.53	Counter32	0
dot3StatsSingleCollisionFrames.54	.1.3.6.1.2.1.10.7.2.1.4.54	Counter32	0
dot3StatsMultipleCollisionFrames.1	.1.3.6.1.2.1.10.7.2.1.5.1	Counter32	0
dot3StatsMultipleCollisionFrames.2	.1.3.6.1.2.1.10.7.2.1.5.2	Counter32	0
dot3StatsMultipleCollisionFrames.3	.1.3.6.1.2.1.10.7.2.1.5.3	Counter32	0
dot3StatsMultipleCollisionFrames.4	.1.3.6.1.2.1.10.7.2.1.5.4	Counter32	0
dot3StatsMultipleCollisionFrames.5	.1.3.6.1.2.1.10.7.2.1.5.5	Counter32	0
dot3StatsMultipleCollisionFrames.6	.1.3.6.1.2.1.10.7.2.1.5.6	Counter32	0
dot3StatsMultipleCollisionFrames.7	.1.3.6.1.2.1.10.7.2.1.5.7	Counter32	0
dot3StatsMultipleCollisionFrames.8	.1.3.6.1.2.1.10.7.2.1.5.8	Counter32	0
dot3StatsMultipleCollisionFrames.9	.1.3.6.1.2.1.10.7.2.1.5.9	Counter32	0
dot3StatsMultipleCollisionFrames.10	.1.3.6.1.2.1.10.7.2.1.5.10	Counter32	0
dot3StatsMultipleCollisionFrames.11	.1.3.6.1.2.1.10.7.2.1.5.11	Counter32	0
dot3StatsMultipleCollisionFrames.12	.1.3.6.1.2.1.10.7.2.1.5.12	Counter32	0
dot3StatsMultipleCollisionFrames.13	.1.3.6.1.2.1.10.7.2.1.5.13	Counter32	0
dot3StatsMultipleCollisionFrames.14	.1.3.6.1.2.1.10.7.2.1.5.14	Counter32	0
dot3StatsMultipleCollisionFrames.15	.1.3.6.1.2.1.10.7.2.1.5.15	Counter32	0
dot3StatsMultipleCollisionFrames.16	.1.3.6.1.2.1.10.7.2.1.5.16	Counter32	0
dot3StatsMultipleCollisionFrames.17	.1.3.6.1.2.1.10.7.2.1.5.17	Counter32	0
dot3StatsMultipleCollisionFrames.18	.1.3.6.1.2.1.10.7.2.1.5.18	Counter32	0
dot3StatsMultipleCollisionFrames.19	.1.3.6.1.2.1.10.7.2.1.5.19	Counter32	0
dot3StatsMultipleCollisionFrames.20	.1.3.6.1.2.1.10.7.2.1.5.20	Counter32	0
dot3StatsMultipleCollisionFrames.21	.1.3.6.1.2.1.10.7.2.1.5.21	Counter32	0
dot3StatsMultipleCollisionFrames.22	.1.3.6.1.2.1.10.7.2.1.5.22	Counter32	0
dot3StatsMultipleCollisionFrames.23	.1.3.6.1.2.1.10.7.2.1.5.23	Counter32	0



<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot3StatsMultipleCollisionFrames.24	.1.3.6.1.2.1.10.7.2.1.5.24	Counter32	0
dot3StatsMultipleCollisionFrames.25	.1.3.6.1.2.1.10.7.2.1.5.25	Counter32	0
dot3StatsMultipleCollisionFrames.26	.1.3.6.1.2.1.10.7.2.1.5.26	Counter32	0
dot3StatsMultipleCollisionFrames.27	.1.3.6.1.2.1.10.7.2.1.5.27	Counter32	0
dot3StatsMultipleCollisionFrames.28	.1.3.6.1.2.1.10.7.2.1.5.28	Counter32	0
dot3StatsMultipleCollisionFrames.29	.1.3.6.1.2.1.10.7.2.1.5.29	Counter32	0
dot3StatsMultipleCollisionFrames.30	.1.3.6.1.2.1.10.7.2.1.5.30	Counter32	0
dot3StatsMultipleCollisionFrames.31	.1.3.6.1.2.1.10.7.2.1.5.31	Counter32	0
dot3StatsMultipleCollisionFrames.32	.1.3.6.1.2.1.10.7.2.1.5.32	Counter32	0
dot3StatsMultipleCollisionFrames.33	.1.3.6.1.2.1.10.7.2.1.5.33	Counter32	0
dot3StatsMultipleCollisionFrames.34	.1.3.6.1.2.1.10.7.2.1.5.34	Counter32	0
dot3StatsMultipleCollisionFrames.35	.1.3.6.1.2.1.10.7.2.1.5.35	Counter32	0
dot3StatsMultipleCollisionFrames.36	.1.3.6.1.2.1.10.7.2.1.5.36	Counter32	0
dot3StatsMultipleCollisionFrames.37	.1.3.6.1.2.1.10.7.2.1.5.37	Counter32	0
dot3StatsMultipleCollisionFrames.38	.1.3.6.1.2.1.10.7.2.1.5.38	Counter32	0
dot3StatsMultipleCollisionFrames.39	.1.3.6.1.2.1.10.7.2.1.5.39	Counter32	0
dot3StatsMultipleCollisionFrames.40	.1.3.6.1.2.1.10.7.2.1.5.40	Counter32	0
dot3StatsMultipleCollisionFrames.41	.1.3.6.1.2.1.10.7.2.1.5.41	Counter32	0
dot3StatsMultipleCollisionFrames.42	.1.3.6.1.2.1.10.7.2.1.5.42	Counter32	0
dot3StatsMultipleCollisionFrames.43	.1.3.6.1.2.1.10.7.2.1.5.43	Counter32	0
dot3StatsMultipleCollisionFrames.44	.1.3.6.1.2.1.10.7.2.1.5.44	Counter32	0
dot3StatsMultipleCollisionFrames.45	.1.3.6.1.2.1.10.7.2.1.5.45	Counter32	0
dot3StatsMultipleCollisionFrames.46	.1.3.6.1.2.1.10.7.2.1.5.46	Counter32	0
dot3StatsMultipleCollisionFrames.47	.1.3.6.1.2.1.10.7.2.1.5.47	Counter32	0
dot3StatsMultipleCollisionFrames.48	.1.3.6.1.2.1.10.7.2.1.5.48	Counter32	0

Name	OID	Value Type	Value Example
dot3StatsMultipleCollisionFrames.49	.1.3.6.1.2.1.10.7.2.1.5.49	Counter32	0
dot3StatsMultipleCollisionFrames.50	.1.3.6.1.2.1.10.7.2.1.5.50	Counter32	0
dot3StatsMultipleCollisionFrames.51	.1.3.6.1.2.1.10.7.2.1.5.51	Counter32	0
dot3StatsMultipleCollisionFrames.52	.1.3.6.1.2.1.10.7.2.1.5.52	Counter32	0
dot3StatsMultipleCollisionFrames.53	.1.3.6.1.2.1.10.7.2.1.5.53	Counter32	0
dot3StatsMultipleCollisionFrames.54	.1.3.6.1.2.1.10.7.2.1.5.54	Counter32	0
dot3StatsSQETestErrors.1	.1.3.6.1.2.1.10.7.2.1.6.1	Counter32	0
dot3StatsSQETestErrors.2	.1.3.6.1.2.1.10.7.2.1.6.2	Counter32	0
dot3StatsSQETestErrors.3	.1.3.6.1.2.1.10.7.2.1.6.3	Counter32	0
dot3StatsSQETestErrors.4	.1.3.6.1.2.1.10.7.2.1.6.4	Counter32	0
dot3StatsSQETestErrors.5	.1.3.6.1.2.1.10.7.2.1.6.5	Counter32	0
dot3StatsSQETestErrors.6	.1.3.6.1.2.1.10.7.2.1.6.6	Counter32	0
dot3StatsSQETestErrors.7	.1.3.6.1.2.1.10.7.2.1.6.7	Counter32	0
dot3StatsSQETestErrors.8	.1.3.6.1.2.1.10.7.2.1.6.8	Counter32	0
dot3StatsSQETestErrors.9	.1.3.6.1.2.1.10.7.2.1.6.9	Counter32	0
dot3StatsSQETestErrors.10	.1.3.6.1.2.1.10.7.2.1.6.10	Counter32	0
dot3StatsSQETestErrors.11	.1.3.6.1.2.1.10.7.2.1.6.11	Counter32	0
dot3StatsSQETestErrors.12	.1.3.6.1.2.1.10.7.2.1.6.12	Counter32	0
dot3StatsSQETestErrors.13	.1.3.6.1.2.1.10.7.2.1.6.13	Counter32	0
dot3StatsSQETestErrors.14	.1.3.6.1.2.1.10.7.2.1.6.14	Counter32	0
dot3StatsSQETestErrors.15	.1.3.6.1.2.1.10.7.2.1.6.15	Counter32	0
dot3StatsSQETestErrors.16	.1.3.6.1.2.1.10.7.2.1.6.16	Counter32	0
dot3StatsSQETestErrors.17	.1.3.6.1.2.1.10.7.2.1.6.17	Counter32	0
dot3StatsSQETestErrors.18	.1.3.6.1.2.1.10.7.2.1.6.18	Counter32	0
dot3StatsSQETestErrors.19	.1.3.6.1.2.1.10.7.2.1.6.19	Counter32	0
dot3StatsSQETestErrors.20	.1.3.6.1.2.1.10.7.2.1.6.20	Counter32	0
dot3StatsSQETestErrors.21	.1.3.6.1.2.1.10.7.2.1.6.21	Counter32	0
dot3StatsSQETestErrors.22	.1.3.6.1.2.1.10.7.2.1.6.22	Counter32	0
dot3StatsSQETestErrors.23	.1.3.6.1.2.1.10.7.2.1.6.23	Counter32	0
dot3StatsSQETestErrors.24	.1.3.6.1.2.1.10.7.2.1.6.24	Counter32	0
dot3StatsSQETestErrors.25	.1.3.6.1.2.1.10.7.2.1.6.25	Counter32	0
dot3StatsSQETestErrors.26	.1.3.6.1.2.1.10.7.2.1.6.26	Counter32	0
dot3StatsSQETestErrors.27	.1.3.6.1.2.1.10.7.2.1.6.27	Counter32	0
dot3StatsSQETestErrors.28	.1.3.6.1.2.1.10.7.2.1.6.28	Counter32	0
dot3StatsSQETestErrors.29	.1.3.6.1.2.1.10.7.2.1.6.29	Counter32	0
dot3StatsSQETestErrors.30	.1.3.6.1.2.1.10.7.2.1.6.30	Counter32	0
dot3StatsSQETestErrors.31	.1.3.6.1.2.1.10.7.2.1.6.31	Counter32	0
dot3StatsSQETestErrors.32	.1.3.6.1.2.1.10.7.2.1.6.32	Counter32	0
dot3StatsSQETestErrors.33	.1.3.6.1.2.1.10.7.2.1.6.33	Counter32	0

Name	OID	Value Type	Value Example
dot3StatsSQETestErrors.34	.1.3.6.1.2.1.10.7.2.1.6.34	Counter32	0
dot3StatsSQETestErrors.35	.1.3.6.1.2.1.10.7.2.1.6.35	Counter32	0
dot3StatsSQETestErrors.36	.1.3.6.1.2.1.10.7.2.1.6.36	Counter32	0
dot3StatsSQETestErrors.37	.1.3.6.1.2.1.10.7.2.1.6.37	Counter32	0
dot3StatsSQETestErrors.38	.1.3.6.1.2.1.10.7.2.1.6.38	Counter32	0
dot3StatsSQETestErrors.39	.1.3.6.1.2.1.10.7.2.1.6.39	Counter32	0
dot3StatsSQETestErrors.40	.1.3.6.1.2.1.10.7.2.1.6.40	Counter32	0
dot3StatsSQETestErrors.41	.1.3.6.1.2.1.10.7.2.1.6.41	Counter32	0
dot3StatsSQETestErrors.42	.1.3.6.1.2.1.10.7.2.1.6.42	Counter32	0
dot3StatsSQETestErrors.43	.1.3.6.1.2.1.10.7.2.1.6.43	Counter32	0
dot3StatsSQETestErrors.44	.1.3.6.1.2.1.10.7.2.1.6.44	Counter32	0
dot3StatsSQETestErrors.45	.1.3.6.1.2.1.10.7.2.1.6.45	Counter32	0
dot3StatsSQETestErrors.46	.1.3.6.1.2.1.10.7.2.1.6.46	Counter32	0
dot3StatsSQETestErrors.47	.1.3.6.1.2.1.10.7.2.1.6.47	Counter32	0
dot3StatsSQETestErrors.48	.1.3.6.1.2.1.10.7.2.1.6.48	Counter32	0
dot3StatsSQETestErrors.49	.1.3.6.1.2.1.10.7.2.1.6.49	Counter32	0
dot3StatsSQETestErrors.50	.1.3.6.1.2.1.10.7.2.1.6.50	Counter32	0
dot3StatsSQETestErrors.51	.1.3.6.1.2.1.10.7.2.1.6.51	Counter32	0
dot3StatsSQETestErrors.52	.1.3.6.1.2.1.10.7.2.1.6.52	Counter32	0
dot3StatsSQETestErrors.53	.1.3.6.1.2.1.10.7.2.1.6.53	Counter32	0
dot3StatsSQETestErrors.54	.1.3.6.1.2.1.10.7.2.1.6.54	Counter32	0
dot3StatsDeferredTransmissions.1	.1.3.6.1.2.1.10.7.2.1.7.1	Counter32	0
dot3StatsDeferredTransmissions.2	.1.3.6.1.2.1.10.7.2.1.7.2	Counter32	0
dot3StatsDeferredTransmissions.3	.1.3.6.1.2.1.10.7.2.1.7.3	Counter32	0
dot3StatsDeferredTransmissions.4	.1.3.6.1.2.1.10.7.2.1.7.4	Counter32	0
dot3StatsDeferredTransmissions.5	.1.3.6.1.2.1.10.7.2.1.7.5	Counter32	0
dot3StatsDeferredTransmissions.6	.1.3.6.1.2.1.10.7.2.1.7.6	Counter32	0
dot3StatsDeferredTransmissions.7	.1.3.6.1.2.1.10.7.2.1.7.7	Counter32	0
dot3StatsDeferredTransmissions.8	.1.3.6.1.2.1.10.7.2.1.7.8	Counter32	0
dot3StatsDeferredTransmissions.9	.1.3.6.1.2.1.10.7.2.1.7.9	Counter32	0
dot3StatsDeferredTransmissions.10	.1.3.6.1.2.1.10.7.2.1.7.10	Counter32	0
dot3StatsDeferredTransmissions.11	.1.3.6.1.2.1.10.7.2.1.7.11	Counter32	0
dot3StatsDeferredTransmissions.12	.1.3.6.1.2.1.10.7.2.1.7.12	Counter32	0
dot3StatsDeferredTransmissions.13	.1.3.6.1.2.1.10.7.2.1.7.13	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot3StatsDeferredTransmissions.14	.1.3.6.1.2.1.10.7.2.1.7.14	Counter32	0
dot3StatsDeferredTransmissions.15	.1.3.6.1.2.1.10.7.2.1.7.15	Counter32	0
dot3StatsDeferredTransmissions.16	.1.3.6.1.2.1.10.7.2.1.7.16	Counter32	0
dot3StatsDeferredTransmissions.17	.1.3.6.1.2.1.10.7.2.1.7.17	Counter32	0
dot3StatsDeferredTransmissions.18	.1.3.6.1.2.1.10.7.2.1.7.18	Counter32	0
dot3StatsDeferredTransmissions.19	.1.3.6.1.2.1.10.7.2.1.7.19	Counter32	0
dot3StatsDeferredTransmissions.20	.1.3.6.1.2.1.10.7.2.1.7.20	Counter32	0
dot3StatsDeferredTransmissions.21	.1.3.6.1.2.1.10.7.2.1.7.21	Counter32	0
dot3StatsDeferredTransmissions.22	.1.3.6.1.2.1.10.7.2.1.7.22	Counter32	0
dot3StatsDeferredTransmissions.23	.1.3.6.1.2.1.10.7.2.1.7.23	Counter32	0
dot3StatsDeferredTransmissions.24	.1.3.6.1.2.1.10.7.2.1.7.24	Counter32	0
dot3StatsDeferredTransmissions.25	.1.3.6.1.2.1.10.7.2.1.7.25	Counter32	0
dot3StatsDeferredTransmissions.26	.1.3.6.1.2.1.10.7.2.1.7.26	Counter32	0
dot3StatsDeferredTransmissions.27	.1.3.6.1.2.1.10.7.2.1.7.27	Counter32	0
dot3StatsDeferredTransmissions.28	.1.3.6.1.2.1.10.7.2.1.7.28	Counter32	0
dot3StatsDeferredTransmissions.29	.1.3.6.1.2.1.10.7.2.1.7.29	Counter32	0
dot3StatsDeferredTransmissions.30	.1.3.6.1.2.1.10.7.2.1.7.30	Counter32	0
dot3StatsDeferredTransmissions.31	.1.3.6.1.2.1.10.7.2.1.7.31	Counter32	0
dot3StatsDeferredTransmissions.32	.1.3.6.1.2.1.10.7.2.1.7.32	Counter32	0
dot3StatsDeferredTransmissions.33	.1.3.6.1.2.1.10.7.2.1.7.33	Counter32	0
dot3StatsDeferredTransmissions.34	.1.3.6.1.2.1.10.7.2.1.7.34	Counter32	0
dot3StatsDeferredTransmissions.35	.1.3.6.1.2.1.10.7.2.1.7.35	Counter32	0
dot3StatsDeferredTransmissions.36	.1.3.6.1.2.1.10.7.2.1.7.36	Counter32	0
dot3StatsDeferredTransmissions.37	.1.3.6.1.2.1.10.7.2.1.7.37	Counter32	0
dot3StatsDeferredTransmissions.38	.1.3.6.1.2.1.10.7.2.1.7.38	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot3StatsDeferredTransmissions.39	.1.3.6.1.2.1.10.7.2.1.7.39	Counter32	0
dot3StatsDeferredTransmissions.40	.1.3.6.1.2.1.10.7.2.1.7.40	Counter32	0
dot3StatsDeferredTransmissions.41	.1.3.6.1.2.1.10.7.2.1.7.41	Counter32	0
dot3StatsDeferredTransmissions.42	.1.3.6.1.2.1.10.7.2.1.7.42	Counter32	0
dot3StatsDeferredTransmissions.43	.1.3.6.1.2.1.10.7.2.1.7.43	Counter32	0
dot3StatsDeferredTransmissions.44	.1.3.6.1.2.1.10.7.2.1.7.44	Counter32	0
dot3StatsDeferredTransmissions.45	.1.3.6.1.2.1.10.7.2.1.7.45	Counter32	0
dot3StatsDeferredTransmissions.46	.1.3.6.1.2.1.10.7.2.1.7.46	Counter32	0
dot3StatsDeferredTransmissions.47	.1.3.6.1.2.1.10.7.2.1.7.47	Counter32	0
dot3StatsDeferredTransmissions.48	.1.3.6.1.2.1.10.7.2.1.7.48	Counter32	0
dot3StatsDeferredTransmissions.49	.1.3.6.1.2.1.10.7.2.1.7.49	Counter32	0
dot3StatsDeferredTransmissions.50	.1.3.6.1.2.1.10.7.2.1.7.50	Counter32	0
dot3StatsDeferredTransmissions.51	.1.3.6.1.2.1.10.7.2.1.7.51	Counter32	0
dot3StatsDeferredTransmissions.52	.1.3.6.1.2.1.10.7.2.1.7.52	Counter32	0
dot3StatsDeferredTransmissions.53	.1.3.6.1.2.1.10.7.2.1.7.53	Counter32	0
dot3StatsDeferredTransmissions.54	.1.3.6.1.2.1.10.7.2.1.7.54	Counter32	0
dot3StatsLateCollisions.1	.1.3.6.1.2.1.10.7.2.1.8.1	Counter32	0
dot3StatsLateCollisions.2	.1.3.6.1.2.1.10.7.2.1.8.2	Counter32	0
dot3StatsLateCollisions.3	.1.3.6.1.2.1.10.7.2.1.8.3	Counter32	0
dot3StatsLateCollisions.4	.1.3.6.1.2.1.10.7.2.1.8.4	Counter32	0
dot3StatsLateCollisions.5	.1.3.6.1.2.1.10.7.2.1.8.5	Counter32	0
dot3StatsLateCollisions.6	.1.3.6.1.2.1.10.7.2.1.8.6	Counter32	0
dot3StatsLateCollisions.7	.1.3.6.1.2.1.10.7.2.1.8.7	Counter32	0
dot3StatsLateCollisions.8	.1.3.6.1.2.1.10.7.2.1.8.8	Counter32	0
dot3StatsLateCollisions.9	.1.3.6.1.2.1.10.7.2.1.8.9	Counter32	0
dot3StatsLateCollisions.10	.1.3.6.1.2.1.10.7.2.1.8.10	Counter32	0
dot3StatsLateCollisions.11	.1.3.6.1.2.1.10.7.2.1.8.11	Counter32	0
dot3StatsLateCollisions.12	.1.3.6.1.2.1.10.7.2.1.8.12	Counter32	0
dot3StatsLateCollisions.13	.1.3.6.1.2.1.10.7.2.1.8.13	Counter32	0
dot3StatsLateCollisions.14	.1.3.6.1.2.1.10.7.2.1.8.14	Counter32	0
dot3StatsLateCollisions.15	.1.3.6.1.2.1.10.7.2.1.8.15	Counter32	0
dot3StatsLateCollisions.16	.1.3.6.1.2.1.10.7.2.1.8.16	Counter32	0

Name	OID	Value Type	Value Example
dot3StatsLateCollisions.17	.1.3.6.1.2.1.10.7.2.1.8.17	Counter32	0
dot3StatsLateCollisions.18	.1.3.6.1.2.1.10.7.2.1.8.18	Counter32	0
dot3StatsLateCollisions.19	.1.3.6.1.2.1.10.7.2.1.8.19	Counter32	0
dot3StatsLateCollisions.20	.1.3.6.1.2.1.10.7.2.1.8.20	Counter32	0
dot3StatsLateCollisions.21	.1.3.6.1.2.1.10.7.2.1.8.21	Counter32	0
dot3StatsLateCollisions.22	.1.3.6.1.2.1.10.7.2.1.8.22	Counter32	0
dot3StatsLateCollisions.23	.1.3.6.1.2.1.10.7.2.1.8.23	Counter32	0
dot3StatsLateCollisions.24	.1.3.6.1.2.1.10.7.2.1.8.24	Counter32	0
dot3StatsLateCollisions.25	.1.3.6.1.2.1.10.7.2.1.8.25	Counter32	0
dot3StatsLateCollisions.26	.1.3.6.1.2.1.10.7.2.1.8.26	Counter32	0
dot3StatsLateCollisions.27	.1.3.6.1.2.1.10.7.2.1.8.27	Counter32	0
dot3StatsLateCollisions.28	.1.3.6.1.2.1.10.7.2.1.8.28	Counter32	0
dot3StatsLateCollisions.29	.1.3.6.1.2.1.10.7.2.1.8.29	Counter32	0
dot3StatsLateCollisions.30	.1.3.6.1.2.1.10.7.2.1.8.30	Counter32	0
dot3StatsLateCollisions.31	.1.3.6.1.2.1.10.7.2.1.8.31	Counter32	0
dot3StatsLateCollisions.32	.1.3.6.1.2.1.10.7.2.1.8.32	Counter32	0
dot3StatsLateCollisions.33	.1.3.6.1.2.1.10.7.2.1.8.33	Counter32	0
dot3StatsLateCollisions.34	.1.3.6.1.2.1.10.7.2.1.8.34	Counter32	0
dot3StatsLateCollisions.35	.1.3.6.1.2.1.10.7.2.1.8.35	Counter32	0
dot3StatsLateCollisions.36	.1.3.6.1.2.1.10.7.2.1.8.36	Counter32	0
dot3StatsLateCollisions.37	.1.3.6.1.2.1.10.7.2.1.8.37	Counter32	0
dot3StatsLateCollisions.38	.1.3.6.1.2.1.10.7.2.1.8.38	Counter32	0
dot3StatsLateCollisions.39	.1.3.6.1.2.1.10.7.2.1.8.39	Counter32	0
dot3StatsLateCollisions.40	.1.3.6.1.2.1.10.7.2.1.8.40	Counter32	0
dot3StatsLateCollisions.41	.1.3.6.1.2.1.10.7.2.1.8.41	Counter32	0
dot3StatsLateCollisions.42	.1.3.6.1.2.1.10.7.2.1.8.42	Counter32	0
dot3StatsLateCollisions.43	.1.3.6.1.2.1.10.7.2.1.8.43	Counter32	0
dot3StatsLateCollisions.44	.1.3.6.1.2.1.10.7.2.1.8.44	Counter32	0
dot3StatsLateCollisions.45	.1.3.6.1.2.1.10.7.2.1.8.45	Counter32	0
dot3StatsLateCollisions.46	.1.3.6.1.2.1.10.7.2.1.8.46	Counter32	0
dot3StatsLateCollisions.47	.1.3.6.1.2.1.10.7.2.1.8.47	Counter32	0
dot3StatsLateCollisions.48	.1.3.6.1.2.1.10.7.2.1.8.48	Counter32	0
dot3StatsLateCollisions.49	.1.3.6.1.2.1.10.7.2.1.8.49	Counter32	0
dot3StatsLateCollisions.50	.1.3.6.1.2.1.10.7.2.1.8.50	Counter32	0
dot3StatsLateCollisions.51	.1.3.6.1.2.1.10.7.2.1.8.51	Counter32	0
dot3StatsLateCollisions.52	.1.3.6.1.2.1.10.7.2.1.8.52	Counter32	0
dot3StatsLateCollisions.53	.1.3.6.1.2.1.10.7.2.1.8.53	Counter32	0
dot3StatsLateCollisions.54	.1.3.6.1.2.1.10.7.2.1.8.54	Counter32	0
dot3StatsExcessiveCollisions.1	.1.3.6.1.2.1.10.7.2.1.9.1	Counter32	0
dot3StatsExcessiveCollisions.2	.1.3.6.1.2.1.10.7.2.1.9.2	Counter32	0
dot3StatsExcessiveCollisions.3	.1.3.6.1.2.1.10.7.2.1.9.3	Counter32	0
dot3StatsExcessiveCollisions.4	.1.3.6.1.2.1.10.7.2.1.9.4	Counter32	0
dot3StatsExcessiveCollisions.5	.1.3.6.1.2.1.10.7.2.1.9.5	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot3StatsExcessiveCollisions.6	.1.3.6.1.2.1.10.7.2.1.9.6	Counter32	0
dot3StatsExcessiveCollisions.7	.1.3.6.1.2.1.10.7.2.1.9.7	Counter32	0
dot3StatsExcessiveCollisions.8	.1.3.6.1.2.1.10.7.2.1.9.8	Counter32	0
dot3StatsExcessiveCollisions.9	.1.3.6.1.2.1.10.7.2.1.9.9	Counter32	0
dot3StatsExcessiveCollisions.10	.1.3.6.1.2.1.10.7.2.1.9.10	Counter32	0
dot3StatsExcessiveCollisions.11	.1.3.6.1.2.1.10.7.2.1.9.11	Counter32	0
dot3StatsExcessiveCollisions.12	.1.3.6.1.2.1.10.7.2.1.9.12	Counter32	0
dot3StatsExcessiveCollisions.13	.1.3.6.1.2.1.10.7.2.1.9.13	Counter32	0
dot3StatsExcessiveCollisions.14	.1.3.6.1.2.1.10.7.2.1.9.14	Counter32	0
dot3StatsExcessiveCollisions.15	.1.3.6.1.2.1.10.7.2.1.9.15	Counter32	0
dot3StatsExcessiveCollisions.16	.1.3.6.1.2.1.10.7.2.1.9.16	Counter32	0
dot3StatsExcessiveCollisions.17	.1.3.6.1.2.1.10.7.2.1.9.17	Counter32	0
dot3StatsExcessiveCollisions.18	.1.3.6.1.2.1.10.7.2.1.9.18	Counter32	0
dot3StatsExcessiveCollisions.19	.1.3.6.1.2.1.10.7.2.1.9.19	Counter32	0
dot3StatsExcessiveCollisions.20	.1.3.6.1.2.1.10.7.2.1.9.20	Counter32	0
dot3StatsExcessiveCollisions.21	.1.3.6.1.2.1.10.7.2.1.9.21	Counter32	0
dot3StatsExcessiveCollisions.22	.1.3.6.1.2.1.10.7.2.1.9.22	Counter32	0
dot3StatsExcessiveCollisions.23	.1.3.6.1.2.1.10.7.2.1.9.23	Counter32	0
dot3StatsExcessiveCollisions.24	.1.3.6.1.2.1.10.7.2.1.9.24	Counter32	0
dot3StatsExcessiveCollisions.25	.1.3.6.1.2.1.10.7.2.1.9.25	Counter32	0
dot3StatsExcessiveCollisions.26	.1.3.6.1.2.1.10.7.2.1.9.26	Counter32	0
dot3StatsExcessiveCollisions.27	.1.3.6.1.2.1.10.7.2.1.9.27	Counter32	0
dot3StatsExcessiveCollisions.28	.1.3.6.1.2.1.10.7.2.1.9.28	Counter32	0
dot3StatsExcessiveCollisions.29	.1.3.6.1.2.1.10.7.2.1.9.29	Counter32	0
dot3StatsExcessiveCollisions.30	.1.3.6.1.2.1.10.7.2.1.9.30	Counter32	0
dot3StatsExcessiveCollisions.31	.1.3.6.1.2.1.10.7.2.1.9.31	Counter32	0
dot3StatsExcessiveCollisions.32	.1.3.6.1.2.1.10.7.2.1.9.32	Counter32	0

Name	OID	Value Type	Value Example
dot3StatsExcessiveCollisions.33	.1.3.6.1.2.1.10.7.2.1.9.33	Counter32	0
dot3StatsExcessiveCollisions.34	.1.3.6.1.2.1.10.7.2.1.9.34	Counter32	0
dot3StatsExcessiveCollisions.35	.1.3.6.1.2.1.10.7.2.1.9.35	Counter32	0
dot3StatsExcessiveCollisions.36	.1.3.6.1.2.1.10.7.2.1.9.36	Counter32	0
dot3StatsExcessiveCollisions.37	.1.3.6.1.2.1.10.7.2.1.9.37	Counter32	0
dot3StatsExcessiveCollisions.38	.1.3.6.1.2.1.10.7.2.1.9.38	Counter32	0
dot3StatsExcessiveCollisions.39	.1.3.6.1.2.1.10.7.2.1.9.39	Counter32	0
dot3StatsExcessiveCollisions.40	.1.3.6.1.2.1.10.7.2.1.9.40	Counter32	0
dot3StatsExcessiveCollisions.41	.1.3.6.1.2.1.10.7.2.1.9.41	Counter32	0
dot3StatsExcessiveCollisions.42	.1.3.6.1.2.1.10.7.2.1.9.42	Counter32	0
dot3StatsExcessiveCollisions.43	.1.3.6.1.2.1.10.7.2.1.9.43	Counter32	0
dot3StatsExcessiveCollisions.44	.1.3.6.1.2.1.10.7.2.1.9.44	Counter32	0
dot3StatsExcessiveCollisions.45	.1.3.6.1.2.1.10.7.2.1.9.45	Counter32	0
dot3StatsExcessiveCollisions.46	.1.3.6.1.2.1.10.7.2.1.9.46	Counter32	0
dot3StatsExcessiveCollisions.47	.1.3.6.1.2.1.10.7.2.1.9.47	Counter32	0
dot3StatsExcessiveCollisions.48	.1.3.6.1.2.1.10.7.2.1.9.48	Counter32	0
dot3StatsExcessiveCollisions.49	.1.3.6.1.2.1.10.7.2.1.9.49	Counter32	0
dot3StatsExcessiveCollisions.50	.1.3.6.1.2.1.10.7.2.1.9.50	Counter32	0
dot3StatsExcessiveCollisions.51	.1.3.6.1.2.1.10.7.2.1.9.51	Counter32	0
dot3StatsExcessiveCollisions.52	.1.3.6.1.2.1.10.7.2.1.9.52	Counter32	0
dot3StatsExcessiveCollisions.53	.1.3.6.1.2.1.10.7.2.1.9.53	Counter32	0
dot3StatsExcessiveCollisions.54	.1.3.6.1.2.1.10.7.2.1.9.54	Counter32	0
dot3StatsInternalMacTransmitErrors.1	.1.3.6.1.2.1.10.7.2.1.10.1	Counter32	0
dot3StatsInternalMacTransmitErrors.2	.1.3.6.1.2.1.10.7.2.1.10.2	Counter32	0
dot3StatsInternalMacTransmitErrors.3	.1.3.6.1.2.1.10.7.2.1.10.3	Counter32	0



Name	OID	Value Type	Value Example
dot3StatsInternalMacTransmitErrors.4	.1.3.6.1.2.1.10.7.2.1.10.4	Counter32	0
dot3StatsInternalMacTransmitErrors.5	.1.3.6.1.2.1.10.7.2.1.10.5	Counter32	0
dot3StatsInternalMacTransmitErrors.6	.1.3.6.1.2.1.10.7.2.1.10.6	Counter32	0
dot3StatsInternalMacTransmitErrors.7	.1.3.6.1.2.1.10.7.2.1.10.7	Counter32	0
dot3StatsInternalMacTransmitErrors.8	.1.3.6.1.2.1.10.7.2.1.10.8	Counter32	0
dot3StatsInternalMacTransmitErrors.9	.1.3.6.1.2.1.10.7.2.1.10.9	Counter32	0
dot3StatsInternalMacTransmitErrors.10	.1.3.6.1.2.1.10.7.2.1.10.10	Counter32	0
dot3StatsInternalMacTransmitErrors.11	.1.3.6.1.2.1.10.7.2.1.10.11	Counter32	0
dot3StatsInternalMacTransmitErrors.12	.1.3.6.1.2.1.10.7.2.1.10.12	Counter32	0
dot3StatsInternalMacTransmitErrors.13	.1.3.6.1.2.1.10.7.2.1.10.13	Counter32	0
dot3StatsInternalMacTransmitErrors.14	.1.3.6.1.2.1.10.7.2.1.10.14	Counter32	0
dot3StatsInternalMacTransmitErrors.15	.1.3.6.1.2.1.10.7.2.1.10.15	Counter32	0
dot3StatsInternalMacTransmitErrors.16	.1.3.6.1.2.1.10.7.2.1.10.16	Counter32	0
dot3StatsInternalMacTransmitErrors.17	.1.3.6.1.2.1.10.7.2.1.10.17	Counter32	0
dot3StatsInternalMacTransmitErrors.18	.1.3.6.1.2.1.10.7.2.1.10.18	Counter32	0
dot3StatsInternalMacTransmitErrors.19	.1.3.6.1.2.1.10.7.2.1.10.19	Counter32	0
dot3StatsInternalMacTransmitErrors.20	.1.3.6.1.2.1.10.7.2.1.10.20	Counter32	0
dot3StatsInternalMacTransmitErrors.21	.1.3.6.1.2.1.10.7.2.1.10.21	Counter32	0
dot3StatsInternalMacTransmitErrors.22	.1.3.6.1.2.1.10.7.2.1.10.22	Counter32	0
dot3StatsInternalMacTransmitErrors.23	.1.3.6.1.2.1.10.7.2.1.10.23	Counter32	0
dot3StatsInternalMacTransmitErrors.24	.1.3.6.1.2.1.10.7.2.1.10.24	Counter32	0
dot3StatsInternalMacTransmitErrors.25	.1.3.6.1.2.1.10.7.2.1.10.25	Counter32	0
dot3StatsInternalMacTransmitErrors.26	.1.3.6.1.2.1.10.7.2.1.10.26	Counter32	0
dot3StatsInternalMacTransmitErrors.27	.1.3.6.1.2.1.10.7.2.1.10.27	Counter32	0
dot3StatsInternalMacTransmitErrors.28	.1.3.6.1.2.1.10.7.2.1.10.28	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot3StatsInternalMacTransmitErrors.29	.1.3.6.1.2.1.10.7.2.1.10.29	Counter32	0
dot3StatsInternalMacTransmitErrors.30	.1.3.6.1.2.1.10.7.2.1.10.30	Counter32	0
dot3StatsInternalMacTransmitErrors.31	.1.3.6.1.2.1.10.7.2.1.10.31	Counter32	0
dot3StatsInternalMacTransmitErrors.32	.1.3.6.1.2.1.10.7.2.1.10.32	Counter32	0
dot3StatsInternalMacTransmitErrors.33	.1.3.6.1.2.1.10.7.2.1.10.33	Counter32	0
dot3StatsInternalMacTransmitErrors.34	.1.3.6.1.2.1.10.7.2.1.10.34	Counter32	0
dot3StatsInternalMacTransmitErrors.35	.1.3.6.1.2.1.10.7.2.1.10.35	Counter32	0
dot3StatsInternalMacTransmitErrors.36	.1.3.6.1.2.1.10.7.2.1.10.36	Counter32	0
dot3StatsInternalMacTransmitErrors.37	.1.3.6.1.2.1.10.7.2.1.10.37	Counter32	0
dot3StatsInternalMacTransmitErrors.38	.1.3.6.1.2.1.10.7.2.1.10.38	Counter32	0
dot3StatsInternalMacTransmitErrors.39	.1.3.6.1.2.1.10.7.2.1.10.39	Counter32	0
dot3StatsInternalMacTransmitErrors.40	.1.3.6.1.2.1.10.7.2.1.10.40	Counter32	0
dot3StatsInternalMacTransmitErrors.41	.1.3.6.1.2.1.10.7.2.1.10.41	Counter32	0
dot3StatsInternalMacTransmitErrors.42	.1.3.6.1.2.1.10.7.2.1.10.42	Counter32	0
dot3StatsInternalMacTransmitErrors.43	.1.3.6.1.2.1.10.7.2.1.10.43	Counter32	0
dot3StatsInternalMacTransmitErrors.44	.1.3.6.1.2.1.10.7.2.1.10.44	Counter32	0
dot3StatsInternalMacTransmitErrors.45	.1.3.6.1.2.1.10.7.2.1.10.45	Counter32	0
dot3StatsInternalMacTransmitErrors.46	.1.3.6.1.2.1.10.7.2.1.10.46	Counter32	0
dot3StatsInternalMacTransmitErrors.47	.1.3.6.1.2.1.10.7.2.1.10.47	Counter32	0
dot3StatsInternalMacTransmitErrors.48	.1.3.6.1.2.1.10.7.2.1.10.48	Counter32	0
dot3StatsInternalMacTransmitErrors.49	.1.3.6.1.2.1.10.7.2.1.10.49	Counter32	0
dot3StatsInternalMacTransmitErrors.50	.1.3.6.1.2.1.10.7.2.1.10.50	Counter32	0
dot3StatsInternalMacTransmitErrors.51	.1.3.6.1.2.1.10.7.2.1.10.51	Counter32	0
dot3StatsInternalMacTransmitErrors.52	.1.3.6.1.2.1.10.7.2.1.10.52	Counter32	0
dot3StatsInternalMacTransmitErrors.53	.1.3.6.1.2.1.10.7.2.1.10.53	Counter32	0

Name	OID	Value Type	Value Example
dot3StatsInternalMacTransmitErrors.54	.1.3.6.1.2.1.10.7.2.1.10.54	Counter32	0
dot3StatsCarrierSenseErrors.1	.1.3.6.1.2.1.10.7.2.1.11.1	Counter32	0
dot3StatsCarrierSenseErrors.2	.1.3.6.1.2.1.10.7.2.1.11.2	Counter32	0
dot3StatsCarrierSenseErrors.3	.1.3.6.1.2.1.10.7.2.1.11.3	Counter32	0
dot3StatsCarrierSenseErrors.4	.1.3.6.1.2.1.10.7.2.1.11.4	Counter32	0
dot3StatsCarrierSenseErrors.5	.1.3.6.1.2.1.10.7.2.1.11.5	Counter32	0
dot3StatsCarrierSenseErrors.6	.1.3.6.1.2.1.10.7.2.1.11.6	Counter32	0
dot3StatsCarrierSenseErrors.7	.1.3.6.1.2.1.10.7.2.1.11.7	Counter32	0
dot3StatsCarrierSenseErrors.8	.1.3.6.1.2.1.10.7.2.1.11.8	Counter32	0
dot3StatsCarrierSenseErrors.9	.1.3.6.1.2.1.10.7.2.1.11.9	Counter32	0
dot3StatsCarrierSenseErrors.10	.1.3.6.1.2.1.10.7.2.1.11.10	Counter32	0
dot3StatsCarrierSenseErrors.11	.1.3.6.1.2.1.10.7.2.1.11.11	Counter32	0
dot3StatsCarrierSenseErrors.12	.1.3.6.1.2.1.10.7.2.1.11.12	Counter32	0
dot3StatsCarrierSenseErrors.13	.1.3.6.1.2.1.10.7.2.1.11.13	Counter32	0
dot3StatsCarrierSenseErrors.14	.1.3.6.1.2.1.10.7.2.1.11.14	Counter32	0
dot3StatsCarrierSenseErrors.15	.1.3.6.1.2.1.10.7.2.1.11.15	Counter32	0
dot3StatsCarrierSenseErrors.16	.1.3.6.1.2.1.10.7.2.1.11.16	Counter32	0
dot3StatsCarrierSenseErrors.17	.1.3.6.1.2.1.10.7.2.1.11.17	Counter32	0
dot3StatsCarrierSenseErrors.18	.1.3.6.1.2.1.10.7.2.1.11.18	Counter32	0
dot3StatsCarrierSenseErrors.19	.1.3.6.1.2.1.10.7.2.1.11.19	Counter32	0
dot3StatsCarrierSenseErrors.20	.1.3.6.1.2.1.10.7.2.1.11.20	Counter32	0
dot3StatsCarrierSenseErrors.21	.1.3.6.1.2.1.10.7.2.1.11.21	Counter32	0
dot3StatsCarrierSenseErrors.22	.1.3.6.1.2.1.10.7.2.1.11.22	Counter32	0
dot3StatsCarrierSenseErrors.23	.1.3.6.1.2.1.10.7.2.1.11.23	Counter32	0
dot3StatsCarrierSenseErrors.24	.1.3.6.1.2.1.10.7.2.1.11.24	Counter32	0
dot3StatsCarrierSenseErrors.25	.1.3.6.1.2.1.10.7.2.1.11.25	Counter32	0
dot3StatsCarrierSenseErrors.26	.1.3.6.1.2.1.10.7.2.1.11.26	Counter32	0
dot3StatsCarrierSenseErrors.27	.1.3.6.1.2.1.10.7.2.1.11.27	Counter32	0
dot3StatsCarrierSenseErrors.28	.1.3.6.1.2.1.10.7.2.1.11.28	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot3StatsCarrierSenseErrors.29	.1.3.6.1.2.1.10.7.2.1.11.29	Counter32	0
dot3StatsCarrierSenseErrors.30	.1.3.6.1.2.1.10.7.2.1.11.30	Counter32	0
dot3StatsCarrierSenseErrors.31	.1.3.6.1.2.1.10.7.2.1.11.31	Counter32	0
dot3StatsCarrierSenseErrors.32	.1.3.6.1.2.1.10.7.2.1.11.32	Counter32	0
dot3StatsCarrierSenseErrors.33	.1.3.6.1.2.1.10.7.2.1.11.33	Counter32	0
dot3StatsCarrierSenseErrors.34	.1.3.6.1.2.1.10.7.2.1.11.34	Counter32	0
dot3StatsCarrierSenseErrors.35	.1.3.6.1.2.1.10.7.2.1.11.35	Counter32	0
dot3StatsCarrierSenseErrors.36	.1.3.6.1.2.1.10.7.2.1.11.36	Counter32	0
dot3StatsCarrierSenseErrors.37	.1.3.6.1.2.1.10.7.2.1.11.37	Counter32	0
dot3StatsCarrierSenseErrors.38	.1.3.6.1.2.1.10.7.2.1.11.38	Counter32	0
dot3StatsCarrierSenseErrors.39	.1.3.6.1.2.1.10.7.2.1.11.39	Counter32	0
dot3StatsCarrierSenseErrors.40	.1.3.6.1.2.1.10.7.2.1.11.40	Counter32	0
dot3StatsCarrierSenseErrors.41	.1.3.6.1.2.1.10.7.2.1.11.41	Counter32	0
dot3StatsCarrierSenseErrors.42	.1.3.6.1.2.1.10.7.2.1.11.42	Counter32	0
dot3StatsCarrierSenseErrors.43	.1.3.6.1.2.1.10.7.2.1.11.43	Counter32	0
dot3StatsCarrierSenseErrors.44	.1.3.6.1.2.1.10.7.2.1.11.44	Counter32	0
dot3StatsCarrierSenseErrors.45	.1.3.6.1.2.1.10.7.2.1.11.45	Counter32	0
dot3StatsCarrierSenseErrors.46	.1.3.6.1.2.1.10.7.2.1.11.46	Counter32	0
dot3StatsCarrierSenseErrors.47	.1.3.6.1.2.1.10.7.2.1.11.47	Counter32	0
dot3StatsCarrierSenseErrors.48	.1.3.6.1.2.1.10.7.2.1.11.48	Counter32	0
dot3StatsCarrierSenseErrors.49	.1.3.6.1.2.1.10.7.2.1.11.49	Counter32	0
dot3StatsCarrierSenseErrors.50	.1.3.6.1.2.1.10.7.2.1.11.50	Counter32	0
dot3StatsCarrierSenseErrors.51	.1.3.6.1.2.1.10.7.2.1.11.51	Counter32	0
dot3StatsCarrierSenseErrors.52	.1.3.6.1.2.1.10.7.2.1.11.52	Counter32	0
dot3StatsCarrierSenseErrors.53	.1.3.6.1.2.1.10.7.2.1.11.53	Counter32	0

Name	OID	Value Type	Value Example
dot3StatsCarrierSenseErrors.54	.1.3.6.1.2.1.10.7.2.1.11.54	Counter32	0
dot3StatsFrameTooLongs.1	.1.3.6.1.2.1.10.7.2.1.13.1	Counter32	0
dot3StatsFrameTooLongs.2	.1.3.6.1.2.1.10.7.2.1.13.2	Counter32	0
dot3StatsFrameTooLongs.3	.1.3.6.1.2.1.10.7.2.1.13.3	Counter32	0
dot3StatsFrameTooLongs.4	.1.3.6.1.2.1.10.7.2.1.13.4	Counter32	0
dot3StatsFrameTooLongs.5	.1.3.6.1.2.1.10.7.2.1.13.5	Counter32	0
dot3StatsFrameTooLongs.6	.1.3.6.1.2.1.10.7.2.1.13.6	Counter32	0
dot3StatsFrameTooLongs.7	.1.3.6.1.2.1.10.7.2.1.13.7	Counter32	0
dot3StatsFrameTooLongs.8	.1.3.6.1.2.1.10.7.2.1.13.8	Counter32	0
dot3StatsFrameTooLongs.9	.1.3.6.1.2.1.10.7.2.1.13.9	Counter32	0
dot3StatsFrameTooLongs.10	.1.3.6.1.2.1.10.7.2.1.13.10	Counter32	0
dot3StatsFrameTooLongs.11	.1.3.6.1.2.1.10.7.2.1.13.11	Counter32	0
dot3StatsFrameTooLongs.12	.1.3.6.1.2.1.10.7.2.1.13.12	Counter32	0
dot3StatsFrameTooLongs.13	.1.3.6.1.2.1.10.7.2.1.13.13	Counter32	0
dot3StatsFrameTooLongs.14	.1.3.6.1.2.1.10.7.2.1.13.14	Counter32	0
dot3StatsFrameTooLongs.15	.1.3.6.1.2.1.10.7.2.1.13.15	Counter32	0
dot3StatsFrameTooLongs.16	.1.3.6.1.2.1.10.7.2.1.13.16	Counter32	0
dot3StatsFrameTooLongs.17	.1.3.6.1.2.1.10.7.2.1.13.17	Counter32	0
dot3StatsFrameTooLongs.18	.1.3.6.1.2.1.10.7.2.1.13.18	Counter32	0
dot3StatsFrameTooLongs.19	.1.3.6.1.2.1.10.7.2.1.13.19	Counter32	0
dot3StatsFrameTooLongs.20	.1.3.6.1.2.1.10.7.2.1.13.20	Counter32	0
dot3StatsFrameTooLongs.21	.1.3.6.1.2.1.10.7.2.1.13.21	Counter32	0
dot3StatsFrameTooLongs.22	.1.3.6.1.2.1.10.7.2.1.13.22	Counter32	0
dot3StatsFrameTooLongs.23	.1.3.6.1.2.1.10.7.2.1.13.23	Counter32	0
dot3StatsFrameTooLongs.24	.1.3.6.1.2.1.10.7.2.1.13.24	Counter32	0
dot3StatsFrameTooLongs.25	.1.3.6.1.2.1.10.7.2.1.13.25	Counter32	0
dot3StatsFrameTooLongs.26	.1.3.6.1.2.1.10.7.2.1.13.26	Counter32	0
dot3StatsFrameTooLongs.27	.1.3.6.1.2.1.10.7.2.1.13.27	Counter32	0
dot3StatsFrameTooLongs.28	.1.3.6.1.2.1.10.7.2.1.13.28	Counter32	0
dot3StatsFrameTooLongs.29	.1.3.6.1.2.1.10.7.2.1.13.29	Counter32	0
dot3StatsFrameTooLongs.30	.1.3.6.1.2.1.10.7.2.1.13.30	Counter32	0
dot3StatsFrameTooLongs.31	.1.3.6.1.2.1.10.7.2.1.13.31	Counter32	0
dot3StatsFrameTooLongs.32	.1.3.6.1.2.1.10.7.2.1.13.32	Counter32	0
dot3StatsFrameTooLongs.33	.1.3.6.1.2.1.10.7.2.1.13.33	Counter32	0
dot3StatsFrameTooLongs.34	.1.3.6.1.2.1.10.7.2.1.13.34	Counter32	0
dot3StatsFrameTooLongs.35	.1.3.6.1.2.1.10.7.2.1.13.35	Counter32	0
dot3StatsFrameTooLongs.36	.1.3.6.1.2.1.10.7.2.1.13.36	Counter32	0
dot3StatsFrameTooLongs.37	.1.3.6.1.2.1.10.7.2.1.13.37	Counter32	0
dot3StatsFrameTooLongs.38	.1.3.6.1.2.1.10.7.2.1.13.38	Counter32	0
dot3StatsFrameTooLongs.39	.1.3.6.1.2.1.10.7.2.1.13.39	Counter32	0
dot3StatsFrameTooLongs.40	.1.3.6.1.2.1.10.7.2.1.13.40	Counter32	0
dot3StatsFrameTooLongs.41	.1.3.6.1.2.1.10.7.2.1.13.41	Counter32	0

Name	OID	Value Type	Value Example
dot3StatsFrameTooLongs.42	.1.3.6.1.2.1.10.7.2.1.13.42	Counter32	0
dot3StatsFrameTooLongs.43	.1.3.6.1.2.1.10.7.2.1.13.43	Counter32	0
dot3StatsFrameTooLongs.44	.1.3.6.1.2.1.10.7.2.1.13.44	Counter32	0
dot3StatsFrameTooLongs.45	.1.3.6.1.2.1.10.7.2.1.13.45	Counter32	0
dot3StatsFrameTooLongs.46	.1.3.6.1.2.1.10.7.2.1.13.46	Counter32	0
dot3StatsFrameTooLongs.47	.1.3.6.1.2.1.10.7.2.1.13.47	Counter32	0
dot3StatsFrameTooLongs.48	.1.3.6.1.2.1.10.7.2.1.13.48	Counter32	0
dot3StatsFrameTooLongs.49	.1.3.6.1.2.1.10.7.2.1.13.49	Counter32	0
dot3StatsFrameTooLongs.50	.1.3.6.1.2.1.10.7.2.1.13.50	Counter32	0
dot3StatsFrameTooLongs.51	.1.3.6.1.2.1.10.7.2.1.13.51	Counter32	0
dot3StatsFrameTooLongs.52	.1.3.6.1.2.1.10.7.2.1.13.52	Counter32	0
dot3StatsFrameTooLongs.53	.1.3.6.1.2.1.10.7.2.1.13.53	Counter32	0
dot3StatsFrameTooLongs.54	.1.3.6.1.2.1.10.7.2.1.13.54	Counter32	0
dot3StatsInternalMacReceive-Errors.1	.1.3.6.1.2.1.10.7.2.1.16.1	Counter32	0
dot3StatsInternalMacReceive-Errors.2	.1.3.6.1.2.1.10.7.2.1.16.2	Counter32	0
dot3StatsInternalMacReceive-Errors.3	.1.3.6.1.2.1.10.7.2.1.16.3	Counter32	0
dot3StatsInternalMacReceive-Errors.4	.1.3.6.1.2.1.10.7.2.1.16.4	Counter32	0
dot3StatsInternalMacReceive-Errors.5	.1.3.6.1.2.1.10.7.2.1.16.5	Counter32	0
dot3StatsInternalMacReceive-Errors.6	.1.3.6.1.2.1.10.7.2.1.16.6	Counter32	0
dot3StatsInternalMacReceive-Errors.7	.1.3.6.1.2.1.10.7.2.1.16.7	Counter32	0
dot3StatsInternalMacReceive-Errors.8	.1.3.6.1.2.1.10.7.2.1.16.8	Counter32	0
dot3StatsInternalMacReceive-Errors.9	.1.3.6.1.2.1.10.7.2.1.16.9	Counter32	0
dot3StatsInternalMacReceive-Errors.10	.1.3.6.1.2.1.10.7.2.1.16.10	Counter32	0
dot3StatsInternalMacReceive-Errors.11	.1.3.6.1.2.1.10.7.2.1.16.11	Counter32	0
dot3StatsInternalMacReceive-Errors.12	.1.3.6.1.2.1.10.7.2.1.16.12	Counter32	0
dot3StatsInternalMacReceive-Errors.13	.1.3.6.1.2.1.10.7.2.1.16.13	Counter32	0
dot3StatsInternalMacReceive-Errors.14	.1.3.6.1.2.1.10.7.2.1.16.14	Counter32	0
dot3StatsInternalMacReceive-Errors.15	.1.3.6.1.2.1.10.7.2.1.16.15	Counter32	0
dot3StatsInternalMacReceive-Errors.16	.1.3.6.1.2.1.10.7.2.1.16.16	Counter32	0
dot3StatsInternalMacReceive-Errors.17	.1.3.6.1.2.1.10.7.2.1.16.17	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot3StatsInternalMacReceive-Errors.18	.1.3.6.1.2.1.10.7.2.1.16.18	Counter32	0
dot3StatsInternalMacReceive-Errors.19	.1.3.6.1.2.1.10.7.2.1.16.19	Counter32	0
dot3StatsInternalMacReceive-Errors.20	.1.3.6.1.2.1.10.7.2.1.16.20	Counter32	0
dot3StatsInternalMacReceive-Errors.21	.1.3.6.1.2.1.10.7.2.1.16.21	Counter32	0
dot3StatsInternalMacReceive-Errors.22	.1.3.6.1.2.1.10.7.2.1.16.22	Counter32	0
dot3StatsInternalMacReceive-Errors.23	.1.3.6.1.2.1.10.7.2.1.16.23	Counter32	0
dot3StatsInternalMacReceive-Errors.24	.1.3.6.1.2.1.10.7.2.1.16.24	Counter32	0
dot3StatsInternalMacReceive-Errors.25	.1.3.6.1.2.1.10.7.2.1.16.25	Counter32	0
dot3StatsInternalMacReceive-Errors.26	.1.3.6.1.2.1.10.7.2.1.16.26	Counter32	0
dot3StatsInternalMacReceive-Errors.27	.1.3.6.1.2.1.10.7.2.1.16.27	Counter32	0
dot3StatsInternalMacReceive-Errors.28	.1.3.6.1.2.1.10.7.2.1.16.28	Counter32	0
dot3StatsInternalMacReceive-Errors.29	.1.3.6.1.2.1.10.7.2.1.16.29	Counter32	0
dot3StatsInternalMacReceive-Errors.30	.1.3.6.1.2.1.10.7.2.1.16.30	Counter32	0
dot3StatsInternalMacReceive-Errors.31	.1.3.6.1.2.1.10.7.2.1.16.31	Counter32	0
dot3StatsInternalMacReceive-Errors.32	.1.3.6.1.2.1.10.7.2.1.16.32	Counter32	0
dot3StatsInternalMacReceive-Errors.33	.1.3.6.1.2.1.10.7.2.1.16.33	Counter32	0
dot3StatsInternalMacReceive-Errors.34	.1.3.6.1.2.1.10.7.2.1.16.34	Counter32	0
dot3StatsInternalMacReceive-Errors.35	.1.3.6.1.2.1.10.7.2.1.16.35	Counter32	0
dot3StatsInternalMacReceive-Errors.36	.1.3.6.1.2.1.10.7.2.1.16.36	Counter32	0
dot3StatsInternalMacReceive-Errors.37	.1.3.6.1.2.1.10.7.2.1.16.37	Counter32	0
dot3StatsInternalMacReceive-Errors.38	.1.3.6.1.2.1.10.7.2.1.16.38	Counter32	0
dot3StatsInternalMacReceive-Errors.39	.1.3.6.1.2.1.10.7.2.1.16.39	Counter32	0
dot3StatsInternalMacReceive-Errors.40	.1.3.6.1.2.1.10.7.2.1.16.40	Counter32	0
dot3StatsInternalMacReceive-Errors.41	.1.3.6.1.2.1.10.7.2.1.16.41	Counter32	0
dot3StatsInternalMacReceive-Errors.42	.1.3.6.1.2.1.10.7.2.1.16.42	Counter32	0

Name	OID	Value Type	Value Example
dot3StatsInternalMacReceive-Errors.43	.1.3.6.1.2.1.10.7.2.1.16.43	Counter32	0
dot3StatsInternalMacReceive-Errors.44	.1.3.6.1.2.1.10.7.2.1.16.44	Counter32	0
dot3StatsInternalMacReceive-Errors.45	.1.3.6.1.2.1.10.7.2.1.16.45	Counter32	0
dot3StatsInternalMacReceive-Errors.46	.1.3.6.1.2.1.10.7.2.1.16.46	Counter32	0
dot3StatsInternalMacReceive-Errors.47	.1.3.6.1.2.1.10.7.2.1.16.47	Counter32	0
dot3StatsInternalMacReceive-Errors.48	.1.3.6.1.2.1.10.7.2.1.16.48	Counter32	0
dot3StatsInternalMacReceive-Errors.49	.1.3.6.1.2.1.10.7.2.1.16.49	Counter32	0
dot3StatsInternalMacReceive-Errors.50	.1.3.6.1.2.1.10.7.2.1.16.50	Counter32	0
dot3StatsInternalMacReceive-Errors.51	.1.3.6.1.2.1.10.7.2.1.16.51	Counter32	0
dot3StatsInternalMacReceive-Errors.52	.1.3.6.1.2.1.10.7.2.1.16.52	Counter32	0
dot3StatsInternalMacReceive-Errors.53	.1.3.6.1.2.1.10.7.2.1.16.53	Counter32	0
dot3StatsInternalMacReceive-Errors.54	.1.3.6.1.2.1.10.7.2.1.16.54	Counter32	0
.1.3.6.1.2.1.10.7.2.1.17.1	.1.3.6.1.2.1.10.7.2.1.17.1	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.2	.1.3.6.1.2.1.10.7.2.1.17.2	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.3	.1.3.6.1.2.1.10.7.2.1.17.3	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.4	.1.3.6.1.2.1.10.7.2.1.17.4	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.5	.1.3.6.1.2.1.10.7.2.1.17.5	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.6	.1.3.6.1.2.1.10.7.2.1.17.6	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.7	.1.3.6.1.2.1.10.7.2.1.17.7	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.8	.1.3.6.1.2.1.10.7.2.1.17.8	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.9	.1.3.6.1.2.1.10.7.2.1.17.9	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.10	.1.3.6.1.2.1.10.7.2.1.17.10	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.11	.1.3.6.1.2.1.10.7.2.1.17.11	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.12	.1.3.6.1.2.1.10.7.2.1.17.12	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.13	.1.3.6.1.2.1.10.7.2.1.17.13	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.14	.1.3.6.1.2.1.10.7.2.1.17.14	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.15	.1.3.6.1.2.1.10.7.2.1.17.15	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.16	.1.3.6.1.2.1.10.7.2.1.17.16	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.17	.1.3.6.1.2.1.10.7.2.1.17.17	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.18	.1.3.6.1.2.1.10.7.2.1.17.18	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.19	.1.3.6.1.2.1.10.7.2.1.17.19	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.20	.1.3.6.1.2.1.10.7.2.1.17.20	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.21	.1.3.6.1.2.1.10.7.2.1.17.21	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.22	.1.3.6.1.2.1.10.7.2.1.17.22	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.23	.1.3.6.1.2.1.10.7.2.1.17.23	OID	.0.0



Name	OID	Value Type	Value Example
.1.3.6.1.2.1.10.7.2.1.17.24	.1.3.6.1.2.1.10.7.2.1.17.24	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.25	.1.3.6.1.2.1.10.7.2.1.17.25	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.26	.1.3.6.1.2.1.10.7.2.1.17.26	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.27	.1.3.6.1.2.1.10.7.2.1.17.27	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.28	.1.3.6.1.2.1.10.7.2.1.17.28	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.29	.1.3.6.1.2.1.10.7.2.1.17.29	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.30	.1.3.6.1.2.1.10.7.2.1.17.30	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.31	.1.3.6.1.2.1.10.7.2.1.17.31	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.32	.1.3.6.1.2.1.10.7.2.1.17.32	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.33	.1.3.6.1.2.1.10.7.2.1.17.33	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.34	.1.3.6.1.2.1.10.7.2.1.17.34	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.35	.1.3.6.1.2.1.10.7.2.1.17.35	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.36	.1.3.6.1.2.1.10.7.2.1.17.36	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.37	.1.3.6.1.2.1.10.7.2.1.17.37	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.38	.1.3.6.1.2.1.10.7.2.1.17.38	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.39	.1.3.6.1.2.1.10.7.2.1.17.39	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.40	.1.3.6.1.2.1.10.7.2.1.17.40	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.41	.1.3.6.1.2.1.10.7.2.1.17.41	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.42	.1.3.6.1.2.1.10.7.2.1.17.42	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.43	.1.3.6.1.2.1.10.7.2.1.17.43	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.44	.1.3.6.1.2.1.10.7.2.1.17.44	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.45	.1.3.6.1.2.1.10.7.2.1.17.45	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.46	.1.3.6.1.2.1.10.7.2.1.17.46	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.47	.1.3.6.1.2.1.10.7.2.1.17.47	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.48	.1.3.6.1.2.1.10.7.2.1.17.48	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.49	.1.3.6.1.2.1.10.7.2.1.17.49	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.50	.1.3.6.1.2.1.10.7.2.1.17.50	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.51	.1.3.6.1.2.1.10.7.2.1.17.51	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.52	.1.3.6.1.2.1.10.7.2.1.17.52	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.53	.1.3.6.1.2.1.10.7.2.1.17.53	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.17.54	.1.3.6.1.2.1.10.7.2.1.17.54	OID	.0.0
.1.3.6.1.2.1.10.7.2.1.18.1	.1.3.6.1.2.1.10.7.2.1.18.1	Counter32	0
.1.3.6.1.2.1.10.7.2.1.18.2	.1.3.6.1.2.1.10.7.2.1.18.2	Counter32	0
.1.3.6.1.2.1.10.7.2.1.18.3	.1.3.6.1.2.1.10.7.2.1.18.3	Counter32	0
.1.3.6.1.2.1.10.7.2.1.18.4	.1.3.6.1.2.1.10.7.2.1.18.4	Counter32	0
.1.3.6.1.2.1.10.7.2.1.18.5	.1.3.6.1.2.1.10.7.2.1.18.5	Counter32	0
.1.3.6.1.2.1.10.7.2.1.18.6	.1.3.6.1.2.1.10.7.2.1.18.6	Counter32	0
.1.3.6.1.2.1.10.7.2.1.18.7	.1.3.6.1.2.1.10.7.2.1.18.7	Counter32	0
.1.3.6.1.2.1.10.7.2.1.18.8	.1.3.6.1.2.1.10.7.2.1.18.8	Counter32	0
.1.3.6.1.2.1.10.7.2.1.18.9	.1.3.6.1.2.1.10.7.2.1.18.9	Counter32	0
.1.3.6.1.2.1.10.7.2.1.18.10	.1.3.6.1.2.1.10.7.2.1.18.10	Counter32	0
.1.3.6.1.2.1.10.7.2.1.18.11	.1.3.6.1.2.1.10.7.2.1.18.11	Counter32	0
.1.3.6.1.2.1.10.7.2.1.18.12	.1.3.6.1.2.1.10.7.2.1.18.12	Counter32	0



Name	OID	Value Type	Value Example
.1.3.6.1.2.1.10.7.2.1.19.2	.1.3.6.1.2.1.10.7.2.1.19.2	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.3	.1.3.6.1.2.1.10.7.2.1.19.3	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.4	.1.3.6.1.2.1.10.7.2.1.19.4	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.5	.1.3.6.1.2.1.10.7.2.1.19.5	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.6	.1.3.6.1.2.1.10.7.2.1.19.6	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.7	.1.3.6.1.2.1.10.7.2.1.19.7	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.8	.1.3.6.1.2.1.10.7.2.1.19.8	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.9	.1.3.6.1.2.1.10.7.2.1.19.9	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.10	.1.3.6.1.2.1.10.7.2.1.19.10	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.11	.1.3.6.1.2.1.10.7.2.1.19.11	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.12	.1.3.6.1.2.1.10.7.2.1.19.12	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.13	.1.3.6.1.2.1.10.7.2.1.19.13	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.14	.1.3.6.1.2.1.10.7.2.1.19.14	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.15	.1.3.6.1.2.1.10.7.2.1.19.15	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.16	.1.3.6.1.2.1.10.7.2.1.19.16	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.17	.1.3.6.1.2.1.10.7.2.1.19.17	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.18	.1.3.6.1.2.1.10.7.2.1.19.18	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.19	.1.3.6.1.2.1.10.7.2.1.19.19	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.20	.1.3.6.1.2.1.10.7.2.1.19.20	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.21	.1.3.6.1.2.1.10.7.2.1.19.21	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.22	.1.3.6.1.2.1.10.7.2.1.19.22	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.23	.1.3.6.1.2.1.10.7.2.1.19.23	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.24	.1.3.6.1.2.1.10.7.2.1.19.24	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.25	.1.3.6.1.2.1.10.7.2.1.19.25	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.26	.1.3.6.1.2.1.10.7.2.1.19.26	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.27	.1.3.6.1.2.1.10.7.2.1.19.27	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.28	.1.3.6.1.2.1.10.7.2.1.19.28	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.29	.1.3.6.1.2.1.10.7.2.1.19.29	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.30	.1.3.6.1.2.1.10.7.2.1.19.30	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.31	.1.3.6.1.2.1.10.7.2.1.19.31	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.32	.1.3.6.1.2.1.10.7.2.1.19.32	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.33	.1.3.6.1.2.1.10.7.2.1.19.33	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.34	.1.3.6.1.2.1.10.7.2.1.19.34	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.35	.1.3.6.1.2.1.10.7.2.1.19.35	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.36	.1.3.6.1.2.1.10.7.2.1.19.36	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.37	.1.3.6.1.2.1.10.7.2.1.19.37	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.38	.1.3.6.1.2.1.10.7.2.1.19.38	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.39	.1.3.6.1.2.1.10.7.2.1.19.39	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.40	.1.3.6.1.2.1.10.7.2.1.19.40	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.41	.1.3.6.1.2.1.10.7.2.1.19.41	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.42	.1.3.6.1.2.1.10.7.2.1.19.42	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.43	.1.3.6.1.2.1.10.7.2.1.19.43	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.44	.1.3.6.1.2.1.10.7.2.1.19.44	Integer	1

Name	OID	Value Type	Value Example
.1.3.6.1.2.1.10.7.2.1.19.45	.1.3.6.1.2.1.10.7.2.1.19.45	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.46	.1.3.6.1.2.1.10.7.2.1.19.46	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.47	.1.3.6.1.2.1.10.7.2.1.19.47	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.48	.1.3.6.1.2.1.10.7.2.1.19.48	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.49	.1.3.6.1.2.1.10.7.2.1.19.49	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.50	.1.3.6.1.2.1.10.7.2.1.19.50	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.51	.1.3.6.1.2.1.10.7.2.1.19.51	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.52	.1.3.6.1.2.1.10.7.2.1.19.52	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.53	.1.3.6.1.2.1.10.7.2.1.19.53	Integer	1
.1.3.6.1.2.1.10.7.2.1.19.54	.1.3.6.1.2.1.10.7.2.1.19.54	Integer	1
.1.3.6.1.2.1.10.7.2.1.20.1	.1.3.6.1.2.1.10.7.2.1.20.1	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.2	.1.3.6.1.2.1.10.7.2.1.20.2	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.3	.1.3.6.1.2.1.10.7.2.1.20.3	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.4	.1.3.6.1.2.1.10.7.2.1.20.4	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.5	.1.3.6.1.2.1.10.7.2.1.20.5	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.6	.1.3.6.1.2.1.10.7.2.1.20.6	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.7	.1.3.6.1.2.1.10.7.2.1.20.7	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.8	.1.3.6.1.2.1.10.7.2.1.20.8	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.9	.1.3.6.1.2.1.10.7.2.1.20.9	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.10	.1.3.6.1.2.1.10.7.2.1.20.10	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.11	.1.3.6.1.2.1.10.7.2.1.20.11	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.12	.1.3.6.1.2.1.10.7.2.1.20.12	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.13	.1.3.6.1.2.1.10.7.2.1.20.13	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.14	.1.3.6.1.2.1.10.7.2.1.20.14	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.15	.1.3.6.1.2.1.10.7.2.1.20.15	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.16	.1.3.6.1.2.1.10.7.2.1.20.16	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.17	.1.3.6.1.2.1.10.7.2.1.20.17	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.18	.1.3.6.1.2.1.10.7.2.1.20.18	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.19	.1.3.6.1.2.1.10.7.2.1.20.19	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.20	.1.3.6.1.2.1.10.7.2.1.20.20	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.21	.1.3.6.1.2.1.10.7.2.1.20.21	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.22	.1.3.6.1.2.1.10.7.2.1.20.22	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.23	.1.3.6.1.2.1.10.7.2.1.20.23	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.24	.1.3.6.1.2.1.10.7.2.1.20.24	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.25	.1.3.6.1.2.1.10.7.2.1.20.25	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.26	.1.3.6.1.2.1.10.7.2.1.20.26	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.27	.1.3.6.1.2.1.10.7.2.1.20.27	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.28	.1.3.6.1.2.1.10.7.2.1.20.28	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.29	.1.3.6.1.2.1.10.7.2.1.20.29	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.30	.1.3.6.1.2.1.10.7.2.1.20.30	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.31	.1.3.6.1.2.1.10.7.2.1.20.31	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.32	.1.3.6.1.2.1.10.7.2.1.20.32	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.33	.1.3.6.1.2.1.10.7.2.1.20.33	Integer	2

Name	OID	Value Type	Value Example
.1.3.6.1.2.1.10.7.2.1.20.34	.1.3.6.1.2.1.10.7.2.1.20.34	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.35	.1.3.6.1.2.1.10.7.2.1.20.35	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.36	.1.3.6.1.2.1.10.7.2.1.20.36	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.37	.1.3.6.1.2.1.10.7.2.1.20.37	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.38	.1.3.6.1.2.1.10.7.2.1.20.38	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.39	.1.3.6.1.2.1.10.7.2.1.20.39	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.40	.1.3.6.1.2.1.10.7.2.1.20.40	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.41	.1.3.6.1.2.1.10.7.2.1.20.41	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.42	.1.3.6.1.2.1.10.7.2.1.20.42	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.43	.1.3.6.1.2.1.10.7.2.1.20.43	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.44	.1.3.6.1.2.1.10.7.2.1.20.44	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.45	.1.3.6.1.2.1.10.7.2.1.20.45	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.46	.1.3.6.1.2.1.10.7.2.1.20.46	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.47	.1.3.6.1.2.1.10.7.2.1.20.47	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.48	.1.3.6.1.2.1.10.7.2.1.20.48	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.49	.1.3.6.1.2.1.10.7.2.1.20.49	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.50	.1.3.6.1.2.1.10.7.2.1.20.50	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.51	.1.3.6.1.2.1.10.7.2.1.20.51	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.52	.1.3.6.1.2.1.10.7.2.1.20.52	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.53	.1.3.6.1.2.1.10.7.2.1.20.53	Integer	2
.1.3.6.1.2.1.10.7.2.1.20.54	.1.3.6.1.2.1.10.7.2.1.20.54	Integer	2
.1.3.6.1.2.1.10.7.2.1.21.1	.1.3.6.1.2.1.10.7.2.1.21.1	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.2	.1.3.6.1.2.1.10.7.2.1.21.2	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.3	.1.3.6.1.2.1.10.7.2.1.21.3	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.4	.1.3.6.1.2.1.10.7.2.1.21.4	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.5	.1.3.6.1.2.1.10.7.2.1.21.5	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.6	.1.3.6.1.2.1.10.7.2.1.21.6	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.7	.1.3.6.1.2.1.10.7.2.1.21.7	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.8	.1.3.6.1.2.1.10.7.2.1.21.8	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.9	.1.3.6.1.2.1.10.7.2.1.21.9	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.10	.1.3.6.1.2.1.10.7.2.1.21.10	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.11	.1.3.6.1.2.1.10.7.2.1.21.11	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.12	.1.3.6.1.2.1.10.7.2.1.21.12	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.13	.1.3.6.1.2.1.10.7.2.1.21.13	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.14	.1.3.6.1.2.1.10.7.2.1.21.14	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.15	.1.3.6.1.2.1.10.7.2.1.21.15	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.16	.1.3.6.1.2.1.10.7.2.1.21.16	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.17	.1.3.6.1.2.1.10.7.2.1.21.17	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.18	.1.3.6.1.2.1.10.7.2.1.21.18	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.19	.1.3.6.1.2.1.10.7.2.1.21.19	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.20	.1.3.6.1.2.1.10.7.2.1.21.20	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.21	.1.3.6.1.2.1.10.7.2.1.21.21	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.22	.1.3.6.1.2.1.10.7.2.1.21.22	Integer	3

Name	OID	Value Type	Value Example
.1.3.6.1.2.1.10.7.2.1.21.23	.1.3.6.1.2.1.10.7.2.1.21.23	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.24	.1.3.6.1.2.1.10.7.2.1.21.24	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.25	.1.3.6.1.2.1.10.7.2.1.21.25	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.26	.1.3.6.1.2.1.10.7.2.1.21.26	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.27	.1.3.6.1.2.1.10.7.2.1.21.27	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.28	.1.3.6.1.2.1.10.7.2.1.21.28	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.29	.1.3.6.1.2.1.10.7.2.1.21.29	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.30	.1.3.6.1.2.1.10.7.2.1.21.30	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.31	.1.3.6.1.2.1.10.7.2.1.21.31	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.32	.1.3.6.1.2.1.10.7.2.1.21.32	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.33	.1.3.6.1.2.1.10.7.2.1.21.33	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.34	.1.3.6.1.2.1.10.7.2.1.21.34	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.35	.1.3.6.1.2.1.10.7.2.1.21.35	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.36	.1.3.6.1.2.1.10.7.2.1.21.36	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.37	.1.3.6.1.2.1.10.7.2.1.21.37	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.38	.1.3.6.1.2.1.10.7.2.1.21.38	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.39	.1.3.6.1.2.1.10.7.2.1.21.39	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.40	.1.3.6.1.2.1.10.7.2.1.21.40	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.41	.1.3.6.1.2.1.10.7.2.1.21.41	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.42	.1.3.6.1.2.1.10.7.2.1.21.42	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.43	.1.3.6.1.2.1.10.7.2.1.21.43	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.44	.1.3.6.1.2.1.10.7.2.1.21.44	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.45	.1.3.6.1.2.1.10.7.2.1.21.45	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.46	.1.3.6.1.2.1.10.7.2.1.21.46	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.47	.1.3.6.1.2.1.10.7.2.1.21.47	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.48	.1.3.6.1.2.1.10.7.2.1.21.48	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.49	.1.3.6.1.2.1.10.7.2.1.21.49	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.50	.1.3.6.1.2.1.10.7.2.1.21.50	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.51	.1.3.6.1.2.1.10.7.2.1.21.51	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.52	.1.3.6.1.2.1.10.7.2.1.21.52	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.53	.1.3.6.1.2.1.10.7.2.1.21.53	Integer	3
.1.3.6.1.2.1.10.7.2.1.21.54	.1.3.6.1.2.1.10.7.2.1.21.54	Integer	3
dot3CollFrequencies.1.1	.1.3.6.1.2.1.10.7.5.1.3.1.1	Counter32	0
dot3CollFrequencies.1.2	.1.3.6.1.2.1.10.7.5.1.3.1.2	Counter32	0
dot3CollFrequencies.1.3	.1.3.6.1.2.1.10.7.5.1.3.1.3	Counter32	0
dot3CollFrequencies.1.4	.1.3.6.1.2.1.10.7.5.1.3.1.4	Counter32	0
dot3CollFrequencies.1.5	.1.3.6.1.2.1.10.7.5.1.3.1.5	Counter32	0
dot3CollFrequencies.1.6	.1.3.6.1.2.1.10.7.5.1.3.1.6	Counter32	0
dot3CollFrequencies.1.7	.1.3.6.1.2.1.10.7.5.1.3.1.7	Counter32	0
dot3CollFrequencies.1.8	.1.3.6.1.2.1.10.7.5.1.3.1.8	Counter32	0
dot3CollFrequencies.1.9	.1.3.6.1.2.1.10.7.5.1.3.1.9	Counter32	0
dot3CollFrequencies.1.10	.1.3.6.1.2.1.10.7.5.1.3.1.10	Counter32	0
dot3CollFrequencies.1.11	.1.3.6.1.2.1.10.7.5.1.3.1.11	Counter32	0

Name	OID	Value Type	Value Example
dot3CollFrequencies.1.12	.1.3.6.1.2.1.10.7.5.1.3.1.12	Counter32	0
dot3CollFrequencies.1.13	.1.3.6.1.2.1.10.7.5.1.3.1.13	Counter32	0
dot3CollFrequencies.1.14	.1.3.6.1.2.1.10.7.5.1.3.1.14	Counter32	0
dot3CollFrequencies.1.15	.1.3.6.1.2.1.10.7.5.1.3.1.15	Counter32	0
dot3CollFrequencies.1.16	.1.3.6.1.2.1.10.7.5.1.3.1.16	Counter32	0
dot3CollFrequencies.2.1	.1.3.6.1.2.1.10.7.5.1.3.2.1	Counter32	0
dot3CollFrequencies.2.2	.1.3.6.1.2.1.10.7.5.1.3.2.2	Counter32	0
dot3CollFrequencies.2.3	.1.3.6.1.2.1.10.7.5.1.3.2.3	Counter32	0
dot3CollFrequencies.2.4	.1.3.6.1.2.1.10.7.5.1.3.2.4	Counter32	0
dot3CollFrequencies.2.5	.1.3.6.1.2.1.10.7.5.1.3.2.5	Counter32	0
dot3CollFrequencies.2.6	.1.3.6.1.2.1.10.7.5.1.3.2.6	Counter32	0
dot3CollFrequencies.2.7	.1.3.6.1.2.1.10.7.5.1.3.2.7	Counter32	0
dot3CollFrequencies.2.8	.1.3.6.1.2.1.10.7.5.1.3.2.8	Counter32	0
dot3CollFrequencies.2.9	.1.3.6.1.2.1.10.7.5.1.3.2.9	Counter32	0
dot3CollFrequencies.2.10	.1.3.6.1.2.1.10.7.5.1.3.2.10	Counter32	0
dot3CollFrequencies.2.11	.1.3.6.1.2.1.10.7.5.1.3.2.11	Counter32	0
dot3CollFrequencies.2.12	.1.3.6.1.2.1.10.7.5.1.3.2.12	Counter32	0
dot3CollFrequencies.2.13	.1.3.6.1.2.1.10.7.5.1.3.2.13	Counter32	0
dot3CollFrequencies.2.14	.1.3.6.1.2.1.10.7.5.1.3.2.14	Counter32	0
dot3CollFrequencies.2.15	.1.3.6.1.2.1.10.7.5.1.3.2.15	Counter32	0
dot3CollFrequencies.2.16	.1.3.6.1.2.1.10.7.5.1.3.2.16	Counter32	0
dot3CollFrequencies.3.1	.1.3.6.1.2.1.10.7.5.1.3.3.1	Counter32	0
dot3CollFrequencies.3.2	.1.3.6.1.2.1.10.7.5.1.3.3.2	Counter32	0
dot3CollFrequencies.3.3	.1.3.6.1.2.1.10.7.5.1.3.3.3	Counter32	0
dot3CollFrequencies.3.4	.1.3.6.1.2.1.10.7.5.1.3.3.4	Counter32	0
dot3CollFrequencies.3.5	.1.3.6.1.2.1.10.7.5.1.3.3.5	Counter32	0
dot3CollFrequencies.3.6	.1.3.6.1.2.1.10.7.5.1.3.3.6	Counter32	0
dot3CollFrequencies.3.7	.1.3.6.1.2.1.10.7.5.1.3.3.7	Counter32	0
dot3CollFrequencies.3.8	.1.3.6.1.2.1.10.7.5.1.3.3.8	Counter32	0
dot3CollFrequencies.3.9	.1.3.6.1.2.1.10.7.5.1.3.3.9	Counter32	0
dot3CollFrequencies.3.10	.1.3.6.1.2.1.10.7.5.1.3.3.10	Counter32	0
dot3CollFrequencies.3.11	.1.3.6.1.2.1.10.7.5.1.3.3.11	Counter32	0
dot3CollFrequencies.3.12	.1.3.6.1.2.1.10.7.5.1.3.3.12	Counter32	0
dot3CollFrequencies.3.13	.1.3.6.1.2.1.10.7.5.1.3.3.13	Counter32	0
dot3CollFrequencies.3.14	.1.3.6.1.2.1.10.7.5.1.3.3.14	Counter32	0
dot3CollFrequencies.3.15	.1.3.6.1.2.1.10.7.5.1.3.3.15	Counter32	0
dot3CollFrequencies.3.16	.1.3.6.1.2.1.10.7.5.1.3.3.16	Counter32	0
dot3CollFrequencies.4.1	.1.3.6.1.2.1.10.7.5.1.3.4.1	Counter32	0
dot3CollFrequencies.4.2	.1.3.6.1.2.1.10.7.5.1.3.4.2	Counter32	0
dot3CollFrequencies.4.3	.1.3.6.1.2.1.10.7.5.1.3.4.3	Counter32	0
dot3CollFrequencies.4.4	.1.3.6.1.2.1.10.7.5.1.3.4.4	Counter32	0
dot3CollFrequencies.4.5	.1.3.6.1.2.1.10.7.5.1.3.4.5	Counter32	0
dot3CollFrequencies.4.6	.1.3.6.1.2.1.10.7.5.1.3.4.6	Counter32	0

Name	OID	Value Type	Value Example
dot3CollFrequencies.4.7	.1.3.6.1.2.1.10.7.5.1.3.4.7	Counter32	0
dot3CollFrequencies.4.8	.1.3.6.1.2.1.10.7.5.1.3.4.8	Counter32	0
dot3CollFrequencies.4.9	.1.3.6.1.2.1.10.7.5.1.3.4.9	Counter32	0
dot3CollFrequencies.4.10	.1.3.6.1.2.1.10.7.5.1.3.4.10	Counter32	0
dot3CollFrequencies.4.11	.1.3.6.1.2.1.10.7.5.1.3.4.11	Counter32	0
dot3CollFrequencies.4.12	.1.3.6.1.2.1.10.7.5.1.3.4.12	Counter32	0
dot3CollFrequencies.4.13	.1.3.6.1.2.1.10.7.5.1.3.4.13	Counter32	0
dot3CollFrequencies.4.14	.1.3.6.1.2.1.10.7.5.1.3.4.14	Counter32	0
dot3CollFrequencies.4.15	.1.3.6.1.2.1.10.7.5.1.3.4.15	Counter32	0
dot3CollFrequencies.4.16	.1.3.6.1.2.1.10.7.5.1.3.4.16	Counter32	0
dot3CollFrequencies.5.1	.1.3.6.1.2.1.10.7.5.1.3.5.1	Counter32	0
dot3CollFrequencies.5.2	.1.3.6.1.2.1.10.7.5.1.3.5.2	Counter32	0
dot3CollFrequencies.5.3	.1.3.6.1.2.1.10.7.5.1.3.5.3	Counter32	0
dot3CollFrequencies.5.4	.1.3.6.1.2.1.10.7.5.1.3.5.4	Counter32	0
dot3CollFrequencies.5.5	.1.3.6.1.2.1.10.7.5.1.3.5.5	Counter32	0
dot3CollFrequencies.5.6	.1.3.6.1.2.1.10.7.5.1.3.5.6	Counter32	0
dot3CollFrequencies.5.7	.1.3.6.1.2.1.10.7.5.1.3.5.7	Counter32	0
dot3CollFrequencies.5.8	.1.3.6.1.2.1.10.7.5.1.3.5.8	Counter32	0
dot3CollFrequencies.5.9	.1.3.6.1.2.1.10.7.5.1.3.5.9	Counter32	0
dot3CollFrequencies.5.10	.1.3.6.1.2.1.10.7.5.1.3.5.10	Counter32	0
dot3CollFrequencies.5.11	.1.3.6.1.2.1.10.7.5.1.3.5.11	Counter32	0
dot3CollFrequencies.5.12	.1.3.6.1.2.1.10.7.5.1.3.5.12	Counter32	0
dot3CollFrequencies.5.13	.1.3.6.1.2.1.10.7.5.1.3.5.13	Counter32	0
dot3CollFrequencies.5.14	.1.3.6.1.2.1.10.7.5.1.3.5.14	Counter32	0
dot3CollFrequencies.5.15	.1.3.6.1.2.1.10.7.5.1.3.5.15	Counter32	0
dot3CollFrequencies.5.16	.1.3.6.1.2.1.10.7.5.1.3.5.16	Counter32	0
dot3CollFrequencies.6.1	.1.3.6.1.2.1.10.7.5.1.3.6.1	Counter32	0
dot3CollFrequencies.6.2	.1.3.6.1.2.1.10.7.5.1.3.6.2	Counter32	0
dot3CollFrequencies.6.3	.1.3.6.1.2.1.10.7.5.1.3.6.3	Counter32	0
dot3CollFrequencies.6.4	.1.3.6.1.2.1.10.7.5.1.3.6.4	Counter32	0
dot3CollFrequencies.6.5	.1.3.6.1.2.1.10.7.5.1.3.6.5	Counter32	0
dot3CollFrequencies.6.6	.1.3.6.1.2.1.10.7.5.1.3.6.6	Counter32	0
dot3CollFrequencies.6.7	.1.3.6.1.2.1.10.7.5.1.3.6.7	Counter32	0
dot3CollFrequencies.6.8	.1.3.6.1.2.1.10.7.5.1.3.6.8	Counter32	0
dot3CollFrequencies.6.9	.1.3.6.1.2.1.10.7.5.1.3.6.9	Counter32	0
dot3CollFrequencies.6.10	.1.3.6.1.2.1.10.7.5.1.3.6.10	Counter32	0
dot3CollFrequencies.6.11	.1.3.6.1.2.1.10.7.5.1.3.6.11	Counter32	0
dot3CollFrequencies.6.12	.1.3.6.1.2.1.10.7.5.1.3.6.12	Counter32	0
dot3CollFrequencies.6.13	.1.3.6.1.2.1.10.7.5.1.3.6.13	Counter32	0
dot3CollFrequencies.6.14	.1.3.6.1.2.1.10.7.5.1.3.6.14	Counter32	0
dot3CollFrequencies.6.15	.1.3.6.1.2.1.10.7.5.1.3.6.15	Counter32	0
dot3CollFrequencies.6.16	.1.3.6.1.2.1.10.7.5.1.3.6.16	Counter32	0
dot3CollFrequencies.7.1	.1.3.6.1.2.1.10.7.5.1.3.7.1	Counter32	0



Name	OID	Value Type	Value Example
dot3CollFrequencies.7.2	.1.3.6.1.2.1.10.7.5.1.3.7.2	Counter32	0
dot3CollFrequencies.7.3	.1.3.6.1.2.1.10.7.5.1.3.7.3	Counter32	0
dot3CollFrequencies.7.4	.1.3.6.1.2.1.10.7.5.1.3.7.4	Counter32	0
dot3CollFrequencies.7.5	.1.3.6.1.2.1.10.7.5.1.3.7.5	Counter32	0
dot3CollFrequencies.7.6	.1.3.6.1.2.1.10.7.5.1.3.7.6	Counter32	0
dot3CollFrequencies.7.7	.1.3.6.1.2.1.10.7.5.1.3.7.7	Counter32	0
dot3CollFrequencies.7.8	.1.3.6.1.2.1.10.7.5.1.3.7.8	Counter32	0
dot3CollFrequencies.7.9	.1.3.6.1.2.1.10.7.5.1.3.7.9	Counter32	0
dot3CollFrequencies.7.10	.1.3.6.1.2.1.10.7.5.1.3.7.10	Counter32	0
dot3CollFrequencies.7.11	.1.3.6.1.2.1.10.7.5.1.3.7.11	Counter32	0
dot3CollFrequencies.7.12	.1.3.6.1.2.1.10.7.5.1.3.7.12	Counter32	0
dot3CollFrequencies.7.13	.1.3.6.1.2.1.10.7.5.1.3.7.13	Counter32	0
dot3CollFrequencies.7.14	.1.3.6.1.2.1.10.7.5.1.3.7.14	Counter32	0
dot3CollFrequencies.7.15	.1.3.6.1.2.1.10.7.5.1.3.7.15	Counter32	0
dot3CollFrequencies.7.16	.1.3.6.1.2.1.10.7.5.1.3.7.16	Counter32	0
dot3CollFrequencies.8.1	.1.3.6.1.2.1.10.7.5.1.3.8.1	Counter32	0
dot3CollFrequencies.8.2	.1.3.6.1.2.1.10.7.5.1.3.8.2	Counter32	0
dot3CollFrequencies.8.3	.1.3.6.1.2.1.10.7.5.1.3.8.3	Counter32	0
dot3CollFrequencies.8.4	.1.3.6.1.2.1.10.7.5.1.3.8.4	Counter32	0
dot3CollFrequencies.8.5	.1.3.6.1.2.1.10.7.5.1.3.8.5	Counter32	0
dot3CollFrequencies.8.6	.1.3.6.1.2.1.10.7.5.1.3.8.6	Counter32	0
dot3CollFrequencies.8.7	.1.3.6.1.2.1.10.7.5.1.3.8.7	Counter32	0
dot3CollFrequencies.8.8	.1.3.6.1.2.1.10.7.5.1.3.8.8	Counter32	0
dot3CollFrequencies.8.9	.1.3.6.1.2.1.10.7.5.1.3.8.9	Counter32	0
dot3CollFrequencies.8.10	.1.3.6.1.2.1.10.7.5.1.3.8.10	Counter32	0
dot3CollFrequencies.8.11	.1.3.6.1.2.1.10.7.5.1.3.8.11	Counter32	0
dot3CollFrequencies.8.12	.1.3.6.1.2.1.10.7.5.1.3.8.12	Counter32	0
dot3CollFrequencies.8.13	.1.3.6.1.2.1.10.7.5.1.3.8.13	Counter32	0
dot3CollFrequencies.8.14	.1.3.6.1.2.1.10.7.5.1.3.8.14	Counter32	0
dot3CollFrequencies.8.15	.1.3.6.1.2.1.10.7.5.1.3.8.15	Counter32	0
dot3CollFrequencies.8.16	.1.3.6.1.2.1.10.7.5.1.3.8.16	Counter32	0
dot3CollFrequencies.9.1	.1.3.6.1.2.1.10.7.5.1.3.9.1	Counter32	0
dot3CollFrequencies.9.2	.1.3.6.1.2.1.10.7.5.1.3.9.2	Counter32	0
dot3CollFrequencies.9.3	.1.3.6.1.2.1.10.7.5.1.3.9.3	Counter32	0
dot3CollFrequencies.9.4	.1.3.6.1.2.1.10.7.5.1.3.9.4	Counter32	0
dot3CollFrequencies.9.5	.1.3.6.1.2.1.10.7.5.1.3.9.5	Counter32	0
dot3CollFrequencies.9.6	.1.3.6.1.2.1.10.7.5.1.3.9.6	Counter32	0
dot3CollFrequencies.9.7	.1.3.6.1.2.1.10.7.5.1.3.9.7	Counter32	0
dot3CollFrequencies.9.8	.1.3.6.1.2.1.10.7.5.1.3.9.8	Counter32	0
dot3CollFrequencies.9.9	.1.3.6.1.2.1.10.7.5.1.3.9.9	Counter32	0
dot3CollFrequencies.9.10	.1.3.6.1.2.1.10.7.5.1.3.9.10	Counter32	0
dot3CollFrequencies.9.11	.1.3.6.1.2.1.10.7.5.1.3.9.11	Counter32	0
dot3CollFrequencies.9.12	.1.3.6.1.2.1.10.7.5.1.3.9.12	Counter32	0

Name	OID	Value Type	Value Example
dot3CollFrequencies.9.13	.1.3.6.1.2.1.10.7.5.1.3.9.13	Counter32	0
dot3CollFrequencies.9.14	.1.3.6.1.2.1.10.7.5.1.3.9.14	Counter32	0
dot3CollFrequencies.9.15	.1.3.6.1.2.1.10.7.5.1.3.9.15	Counter32	0
dot3CollFrequencies.9.16	.1.3.6.1.2.1.10.7.5.1.3.9.16	Counter32	0
dot3CollFrequencies.10.1	.1.3.6.1.2.1.10.7.5.1.3.10.1	Counter32	0
dot3CollFrequencies.10.2	.1.3.6.1.2.1.10.7.5.1.3.10.2	Counter32	0
dot3CollFrequencies.10.3	.1.3.6.1.2.1.10.7.5.1.3.10.3	Counter32	0
dot3CollFrequencies.10.4	.1.3.6.1.2.1.10.7.5.1.3.10.4	Counter32	0
dot3CollFrequencies.10.5	.1.3.6.1.2.1.10.7.5.1.3.10.5	Counter32	0
dot3CollFrequencies.10.6	.1.3.6.1.2.1.10.7.5.1.3.10.6	Counter32	0
dot3CollFrequencies.10.7	.1.3.6.1.2.1.10.7.5.1.3.10.7	Counter32	0
dot3CollFrequencies.10.8	.1.3.6.1.2.1.10.7.5.1.3.10.8	Counter32	0
dot3CollFrequencies.10.9	.1.3.6.1.2.1.10.7.5.1.3.10.9	Counter32	0
dot3CollFrequencies.10.10	.1.3.6.1.2.1.10.7.5.1.3.10.10	Counter32	0
dot3CollFrequencies.10.11	.1.3.6.1.2.1.10.7.5.1.3.10.11	Counter32	0
dot3CollFrequencies.10.12	.1.3.6.1.2.1.10.7.5.1.3.10.12	Counter32	0
dot3CollFrequencies.10.13	.1.3.6.1.2.1.10.7.5.1.3.10.13	Counter32	0
dot3CollFrequencies.10.14	.1.3.6.1.2.1.10.7.5.1.3.10.14	Counter32	0
dot3CollFrequencies.10.15	.1.3.6.1.2.1.10.7.5.1.3.10.15	Counter32	0
dot3CollFrequencies.10.16	.1.3.6.1.2.1.10.7.5.1.3.10.16	Counter32	0
dot3CollFrequencies.11.1	.1.3.6.1.2.1.10.7.5.1.3.11.1	Counter32	0
dot3CollFrequencies.11.2	.1.3.6.1.2.1.10.7.5.1.3.11.2	Counter32	0
dot3CollFrequencies.11.3	.1.3.6.1.2.1.10.7.5.1.3.11.3	Counter32	0
dot3CollFrequencies.11.4	.1.3.6.1.2.1.10.7.5.1.3.11.4	Counter32	0
dot3CollFrequencies.11.5	.1.3.6.1.2.1.10.7.5.1.3.11.5	Counter32	0
dot3CollFrequencies.11.6	.1.3.6.1.2.1.10.7.5.1.3.11.6	Counter32	0
dot3CollFrequencies.11.7	.1.3.6.1.2.1.10.7.5.1.3.11.7	Counter32	0
dot3CollFrequencies.11.8	.1.3.6.1.2.1.10.7.5.1.3.11.8	Counter32	0
dot3CollFrequencies.11.9	.1.3.6.1.2.1.10.7.5.1.3.11.9	Counter32	0
dot3CollFrequencies.11.10	.1.3.6.1.2.1.10.7.5.1.3.11.10	Counter32	0
dot3CollFrequencies.11.11	.1.3.6.1.2.1.10.7.5.1.3.11.11	Counter32	0
dot3CollFrequencies.11.12	.1.3.6.1.2.1.10.7.5.1.3.11.12	Counter32	0
dot3CollFrequencies.11.13	.1.3.6.1.2.1.10.7.5.1.3.11.13	Counter32	0
dot3CollFrequencies.11.14	.1.3.6.1.2.1.10.7.5.1.3.11.14	Counter32	0
dot3CollFrequencies.11.15	.1.3.6.1.2.1.10.7.5.1.3.11.15	Counter32	0
dot3CollFrequencies.11.16	.1.3.6.1.2.1.10.7.5.1.3.11.16	Counter32	0
dot3CollFrequencies.12.1	.1.3.6.1.2.1.10.7.5.1.3.12.1	Counter32	0
dot3CollFrequencies.12.2	.1.3.6.1.2.1.10.7.5.1.3.12.2	Counter32	0
dot3CollFrequencies.12.3	.1.3.6.1.2.1.10.7.5.1.3.12.3	Counter32	0
dot3CollFrequencies.12.4	.1.3.6.1.2.1.10.7.5.1.3.12.4	Counter32	0
dot3CollFrequencies.12.5	.1.3.6.1.2.1.10.7.5.1.3.12.5	Counter32	0
dot3CollFrequencies.12.6	.1.3.6.1.2.1.10.7.5.1.3.12.6	Counter32	0
dot3CollFrequencies.12.7	.1.3.6.1.2.1.10.7.5.1.3.12.7	Counter32	0

Name	OID	Value Type	Value Example
dot3CollFrequencies.12.8	.1.3.6.1.2.1.10.7.5.1.3.12.8	Counter32	0
dot3CollFrequencies.12.9	.1.3.6.1.2.1.10.7.5.1.3.12.9	Counter32	0
dot3CollFrequencies.12.10	.1.3.6.1.2.1.10.7.5.1.3.12.10	Counter32	0
dot3CollFrequencies.12.11	.1.3.6.1.2.1.10.7.5.1.3.12.11	Counter32	0
dot3CollFrequencies.12.12	.1.3.6.1.2.1.10.7.5.1.3.12.12	Counter32	0
dot3CollFrequencies.12.13	.1.3.6.1.2.1.10.7.5.1.3.12.13	Counter32	0
dot3CollFrequencies.12.14	.1.3.6.1.2.1.10.7.5.1.3.12.14	Counter32	0
dot3CollFrequencies.12.15	.1.3.6.1.2.1.10.7.5.1.3.12.15	Counter32	0
dot3CollFrequencies.12.16	.1.3.6.1.2.1.10.7.5.1.3.12.16	Counter32	0
dot3CollFrequencies.13.1	.1.3.6.1.2.1.10.7.5.1.3.13.1	Counter32	0
dot3CollFrequencies.13.2	.1.3.6.1.2.1.10.7.5.1.3.13.2	Counter32	0
dot3CollFrequencies.13.3	.1.3.6.1.2.1.10.7.5.1.3.13.3	Counter32	0
dot3CollFrequencies.13.4	.1.3.6.1.2.1.10.7.5.1.3.13.4	Counter32	0
dot3CollFrequencies.13.5	.1.3.6.1.2.1.10.7.5.1.3.13.5	Counter32	0
dot3CollFrequencies.13.6	.1.3.6.1.2.1.10.7.5.1.3.13.6	Counter32	0
dot3CollFrequencies.13.7	.1.3.6.1.2.1.10.7.5.1.3.13.7	Counter32	0
dot3CollFrequencies.13.8	.1.3.6.1.2.1.10.7.5.1.3.13.8	Counter32	0
dot3CollFrequencies.13.9	.1.3.6.1.2.1.10.7.5.1.3.13.9	Counter32	0
dot3CollFrequencies.13.10	.1.3.6.1.2.1.10.7.5.1.3.13.10	Counter32	0
dot3CollFrequencies.13.11	.1.3.6.1.2.1.10.7.5.1.3.13.11	Counter32	0
dot3CollFrequencies.13.12	.1.3.6.1.2.1.10.7.5.1.3.13.12	Counter32	0
dot3CollFrequencies.13.13	.1.3.6.1.2.1.10.7.5.1.3.13.13	Counter32	0
dot3CollFrequencies.13.14	.1.3.6.1.2.1.10.7.5.1.3.13.14	Counter32	0
dot3CollFrequencies.13.15	.1.3.6.1.2.1.10.7.5.1.3.13.15	Counter32	0
dot3CollFrequencies.13.16	.1.3.6.1.2.1.10.7.5.1.3.13.16	Counter32	0
dot3CollFrequencies.14.1	.1.3.6.1.2.1.10.7.5.1.3.14.1	Counter32	0
dot3CollFrequencies.14.2	.1.3.6.1.2.1.10.7.5.1.3.14.2	Counter32	0
dot3CollFrequencies.14.3	.1.3.6.1.2.1.10.7.5.1.3.14.3	Counter32	0
dot3CollFrequencies.14.4	.1.3.6.1.2.1.10.7.5.1.3.14.4	Counter32	0
dot3CollFrequencies.14.5	.1.3.6.1.2.1.10.7.5.1.3.14.5	Counter32	0
dot3CollFrequencies.14.6	.1.3.6.1.2.1.10.7.5.1.3.14.6	Counter32	0
dot3CollFrequencies.14.7	.1.3.6.1.2.1.10.7.5.1.3.14.7	Counter32	0
dot3CollFrequencies.14.8	.1.3.6.1.2.1.10.7.5.1.3.14.8	Counter32	0
dot3CollFrequencies.14.9	.1.3.6.1.2.1.10.7.5.1.3.14.9	Counter32	0
dot3CollFrequencies.14.10	.1.3.6.1.2.1.10.7.5.1.3.14.10	Counter32	0
dot3CollFrequencies.14.11	.1.3.6.1.2.1.10.7.5.1.3.14.11	Counter32	0
dot3CollFrequencies.14.12	.1.3.6.1.2.1.10.7.5.1.3.14.12	Counter32	0
dot3CollFrequencies.14.13	.1.3.6.1.2.1.10.7.5.1.3.14.13	Counter32	0
dot3CollFrequencies.14.14	.1.3.6.1.2.1.10.7.5.1.3.14.14	Counter32	0
dot3CollFrequencies.14.15	.1.3.6.1.2.1.10.7.5.1.3.14.15	Counter32	0
dot3CollFrequencies.14.16	.1.3.6.1.2.1.10.7.5.1.3.14.16	Counter32	0
dot3CollFrequencies.15.1	.1.3.6.1.2.1.10.7.5.1.3.15.1	Counter32	0
dot3CollFrequencies.15.2	.1.3.6.1.2.1.10.7.5.1.3.15.2	Counter32	0

Name	OID	Value Type	Value Example
dot3CollFrequencies.15.3	.1.3.6.1.2.1.10.7.5.1.3.15.3	Counter32	0
dot3CollFrequencies.15.4	.1.3.6.1.2.1.10.7.5.1.3.15.4	Counter32	0
dot3CollFrequencies.15.5	.1.3.6.1.2.1.10.7.5.1.3.15.5	Counter32	0
dot3CollFrequencies.15.6	.1.3.6.1.2.1.10.7.5.1.3.15.6	Counter32	0
dot3CollFrequencies.15.7	.1.3.6.1.2.1.10.7.5.1.3.15.7	Counter32	0
dot3CollFrequencies.15.8	.1.3.6.1.2.1.10.7.5.1.3.15.8	Counter32	0
dot3CollFrequencies.15.9	.1.3.6.1.2.1.10.7.5.1.3.15.9	Counter32	0
dot3CollFrequencies.15.10	.1.3.6.1.2.1.10.7.5.1.3.15.10	Counter32	0
dot3CollFrequencies.15.11	.1.3.6.1.2.1.10.7.5.1.3.15.11	Counter32	0
dot3CollFrequencies.15.12	.1.3.6.1.2.1.10.7.5.1.3.15.12	Counter32	0
dot3CollFrequencies.15.13	.1.3.6.1.2.1.10.7.5.1.3.15.13	Counter32	0
dot3CollFrequencies.15.14	.1.3.6.1.2.1.10.7.5.1.3.15.14	Counter32	0
dot3CollFrequencies.15.15	.1.3.6.1.2.1.10.7.5.1.3.15.15	Counter32	0
dot3CollFrequencies.15.16	.1.3.6.1.2.1.10.7.5.1.3.15.16	Counter32	0
dot3CollFrequencies.16.1	.1.3.6.1.2.1.10.7.5.1.3.16.1	Counter32	0
dot3CollFrequencies.16.2	.1.3.6.1.2.1.10.7.5.1.3.16.2	Counter32	0
dot3CollFrequencies.16.3	.1.3.6.1.2.1.10.7.5.1.3.16.3	Counter32	0
dot3CollFrequencies.16.4	.1.3.6.1.2.1.10.7.5.1.3.16.4	Counter32	0
dot3CollFrequencies.16.5	.1.3.6.1.2.1.10.7.5.1.3.16.5	Counter32	0
dot3CollFrequencies.16.6	.1.3.6.1.2.1.10.7.5.1.3.16.6	Counter32	0
dot3CollFrequencies.16.7	.1.3.6.1.2.1.10.7.5.1.3.16.7	Counter32	0
dot3CollFrequencies.16.8	.1.3.6.1.2.1.10.7.5.1.3.16.8	Counter32	0
dot3CollFrequencies.16.9	.1.3.6.1.2.1.10.7.5.1.3.16.9	Counter32	0
dot3CollFrequencies.16.10	.1.3.6.1.2.1.10.7.5.1.3.16.10	Counter32	0
dot3CollFrequencies.16.11	.1.3.6.1.2.1.10.7.5.1.3.16.11	Counter32	0
dot3CollFrequencies.16.12	.1.3.6.1.2.1.10.7.5.1.3.16.12	Counter32	0
dot3CollFrequencies.16.13	.1.3.6.1.2.1.10.7.5.1.3.16.13	Counter32	0
dot3CollFrequencies.16.14	.1.3.6.1.2.1.10.7.5.1.3.16.14	Counter32	0
dot3CollFrequencies.16.15	.1.3.6.1.2.1.10.7.5.1.3.16.15	Counter32	0
dot3CollFrequencies.16.16	.1.3.6.1.2.1.10.7.5.1.3.16.16	Counter32	0
dot3CollFrequencies.17.1	.1.3.6.1.2.1.10.7.5.1.3.17.1	Counter32	0
dot3CollFrequencies.17.2	.1.3.6.1.2.1.10.7.5.1.3.17.2	Counter32	0
dot3CollFrequencies.17.3	.1.3.6.1.2.1.10.7.5.1.3.17.3	Counter32	0
dot3CollFrequencies.17.4	.1.3.6.1.2.1.10.7.5.1.3.17.4	Counter32	0
dot3CollFrequencies.17.5	.1.3.6.1.2.1.10.7.5.1.3.17.5	Counter32	0
dot3CollFrequencies.17.6	.1.3.6.1.2.1.10.7.5.1.3.17.6	Counter32	0
dot3CollFrequencies.17.7	.1.3.6.1.2.1.10.7.5.1.3.17.7	Counter32	0
dot3CollFrequencies.17.8	.1.3.6.1.2.1.10.7.5.1.3.17.8	Counter32	0
dot3CollFrequencies.17.9	.1.3.6.1.2.1.10.7.5.1.3.17.9	Counter32	0
dot3CollFrequencies.17.10	.1.3.6.1.2.1.10.7.5.1.3.17.10	Counter32	0
dot3CollFrequencies.17.11	.1.3.6.1.2.1.10.7.5.1.3.17.11	Counter32	0
dot3CollFrequencies.17.12	.1.3.6.1.2.1.10.7.5.1.3.17.12	Counter32	0
dot3CollFrequencies.17.13	.1.3.6.1.2.1.10.7.5.1.3.17.13	Counter32	0

Name	OID	Value Type	Value Example
dot3CollFrequencies.17.14	.1.3.6.1.2.1.10.7.5.1.3.17.14	Counter32	0
dot3CollFrequencies.17.15	.1.3.6.1.2.1.10.7.5.1.3.17.15	Counter32	0
dot3CollFrequencies.17.16	.1.3.6.1.2.1.10.7.5.1.3.17.16	Counter32	0
dot3CollFrequencies.18.1	.1.3.6.1.2.1.10.7.5.1.3.18.1	Counter32	0
dot3CollFrequencies.18.2	.1.3.6.1.2.1.10.7.5.1.3.18.2	Counter32	0
dot3CollFrequencies.18.3	.1.3.6.1.2.1.10.7.5.1.3.18.3	Counter32	0
dot3CollFrequencies.18.4	.1.3.6.1.2.1.10.7.5.1.3.18.4	Counter32	0
dot3CollFrequencies.18.5	.1.3.6.1.2.1.10.7.5.1.3.18.5	Counter32	0
dot3CollFrequencies.18.6	.1.3.6.1.2.1.10.7.5.1.3.18.6	Counter32	0
dot3CollFrequencies.18.7	.1.3.6.1.2.1.10.7.5.1.3.18.7	Counter32	0
dot3CollFrequencies.18.8	.1.3.6.1.2.1.10.7.5.1.3.18.8	Counter32	0
dot3CollFrequencies.18.9	.1.3.6.1.2.1.10.7.5.1.3.18.9	Counter32	0
dot3CollFrequencies.18.10	.1.3.6.1.2.1.10.7.5.1.3.18.10	Counter32	0
dot3CollFrequencies.18.11	.1.3.6.1.2.1.10.7.5.1.3.18.11	Counter32	0
dot3CollFrequencies.18.12	.1.3.6.1.2.1.10.7.5.1.3.18.12	Counter32	0
dot3CollFrequencies.18.13	.1.3.6.1.2.1.10.7.5.1.3.18.13	Counter32	0
dot3CollFrequencies.18.14	.1.3.6.1.2.1.10.7.5.1.3.18.14	Counter32	0
dot3CollFrequencies.18.15	.1.3.6.1.2.1.10.7.5.1.3.18.15	Counter32	0
dot3CollFrequencies.18.16	.1.3.6.1.2.1.10.7.5.1.3.18.16	Counter32	0
dot3CollFrequencies.19.1	.1.3.6.1.2.1.10.7.5.1.3.19.1	Counter32	0
dot3CollFrequencies.19.2	.1.3.6.1.2.1.10.7.5.1.3.19.2	Counter32	0
dot3CollFrequencies.19.3	.1.3.6.1.2.1.10.7.5.1.3.19.3	Counter32	0
dot3CollFrequencies.19.4	.1.3.6.1.2.1.10.7.5.1.3.19.4	Counter32	0
dot3CollFrequencies.19.5	.1.3.6.1.2.1.10.7.5.1.3.19.5	Counter32	0
dot3CollFrequencies.19.6	.1.3.6.1.2.1.10.7.5.1.3.19.6	Counter32	0
dot3CollFrequencies.19.7	.1.3.6.1.2.1.10.7.5.1.3.19.7	Counter32	0
dot3CollFrequencies.19.8	.1.3.6.1.2.1.10.7.5.1.3.19.8	Counter32	0
dot3CollFrequencies.19.9	.1.3.6.1.2.1.10.7.5.1.3.19.9	Counter32	0
dot3CollFrequencies.19.10	.1.3.6.1.2.1.10.7.5.1.3.19.10	Counter32	0
dot3CollFrequencies.19.11	.1.3.6.1.2.1.10.7.5.1.3.19.11	Counter32	0
dot3CollFrequencies.19.12	.1.3.6.1.2.1.10.7.5.1.3.19.12	Counter32	0
dot3CollFrequencies.19.13	.1.3.6.1.2.1.10.7.5.1.3.19.13	Counter32	0
dot3CollFrequencies.19.14	.1.3.6.1.2.1.10.7.5.1.3.19.14	Counter32	0
dot3CollFrequencies.19.15	.1.3.6.1.2.1.10.7.5.1.3.19.15	Counter32	0
dot3CollFrequencies.19.16	.1.3.6.1.2.1.10.7.5.1.3.19.16	Counter32	0
dot3CollFrequencies.20.1	.1.3.6.1.2.1.10.7.5.1.3.20.1	Counter32	0
dot3CollFrequencies.20.2	.1.3.6.1.2.1.10.7.5.1.3.20.2	Counter32	0
dot3CollFrequencies.20.3	.1.3.6.1.2.1.10.7.5.1.3.20.3	Counter32	0
dot3CollFrequencies.20.4	.1.3.6.1.2.1.10.7.5.1.3.20.4	Counter32	0
dot3CollFrequencies.20.5	.1.3.6.1.2.1.10.7.5.1.3.20.5	Counter32	0
dot3CollFrequencies.20.6	.1.3.6.1.2.1.10.7.5.1.3.20.6	Counter32	0
dot3CollFrequencies.20.7	.1.3.6.1.2.1.10.7.5.1.3.20.7	Counter32	0
dot3CollFrequencies.20.8	.1.3.6.1.2.1.10.7.5.1.3.20.8	Counter32	0

Name	OID	Value Type	Value Example
dot3CollFrequencies.20.9	.1.3.6.1.2.1.10.7.5.1.3.20.9	Counter32	0
dot3CollFrequencies.20.10	.1.3.6.1.2.1.10.7.5.1.3.20.10	Counter32	0
dot3CollFrequencies.20.11	.1.3.6.1.2.1.10.7.5.1.3.20.11	Counter32	0
dot3CollFrequencies.20.12	.1.3.6.1.2.1.10.7.5.1.3.20.12	Counter32	0
dot3CollFrequencies.20.13	.1.3.6.1.2.1.10.7.5.1.3.20.13	Counter32	0
dot3CollFrequencies.20.14	.1.3.6.1.2.1.10.7.5.1.3.20.14	Counter32	0
dot3CollFrequencies.20.15	.1.3.6.1.2.1.10.7.5.1.3.20.15	Counter32	0
dot3CollFrequencies.20.16	.1.3.6.1.2.1.10.7.5.1.3.20.16	Counter32	0
dot3CollFrequencies.21.1	.1.3.6.1.2.1.10.7.5.1.3.21.1	Counter32	0
dot3CollFrequencies.21.2	.1.3.6.1.2.1.10.7.5.1.3.21.2	Counter32	0
dot3CollFrequencies.21.3	.1.3.6.1.2.1.10.7.5.1.3.21.3	Counter32	0
dot3CollFrequencies.21.4	.1.3.6.1.2.1.10.7.5.1.3.21.4	Counter32	0
dot3CollFrequencies.21.5	.1.3.6.1.2.1.10.7.5.1.3.21.5	Counter32	0
dot3CollFrequencies.21.6	.1.3.6.1.2.1.10.7.5.1.3.21.6	Counter32	0
dot3CollFrequencies.21.7	.1.3.6.1.2.1.10.7.5.1.3.21.7	Counter32	0
dot3CollFrequencies.21.8	.1.3.6.1.2.1.10.7.5.1.3.21.8	Counter32	0
dot3CollFrequencies.21.9	.1.3.6.1.2.1.10.7.5.1.3.21.9	Counter32	0
dot3CollFrequencies.21.10	.1.3.6.1.2.1.10.7.5.1.3.21.10	Counter32	0
dot3CollFrequencies.21.11	.1.3.6.1.2.1.10.7.5.1.3.21.11	Counter32	0
dot3CollFrequencies.21.12	.1.3.6.1.2.1.10.7.5.1.3.21.12	Counter32	0
dot3CollFrequencies.21.13	.1.3.6.1.2.1.10.7.5.1.3.21.13	Counter32	0
dot3CollFrequencies.21.14	.1.3.6.1.2.1.10.7.5.1.3.21.14	Counter32	0
dot3CollFrequencies.21.15	.1.3.6.1.2.1.10.7.5.1.3.21.15	Counter32	0
dot3CollFrequencies.21.16	.1.3.6.1.2.1.10.7.5.1.3.21.16	Counter32	0
dot3CollFrequencies.22.1	.1.3.6.1.2.1.10.7.5.1.3.22.1	Counter32	0
dot3CollFrequencies.22.2	.1.3.6.1.2.1.10.7.5.1.3.22.2	Counter32	0
dot3CollFrequencies.22.3	.1.3.6.1.2.1.10.7.5.1.3.22.3	Counter32	0
dot3CollFrequencies.22.4	.1.3.6.1.2.1.10.7.5.1.3.22.4	Counter32	0
dot3CollFrequencies.22.5	.1.3.6.1.2.1.10.7.5.1.3.22.5	Counter32	0
dot3CollFrequencies.22.6	.1.3.6.1.2.1.10.7.5.1.3.22.6	Counter32	0
dot3CollFrequencies.22.7	.1.3.6.1.2.1.10.7.5.1.3.22.7	Counter32	0
dot3CollFrequencies.22.8	.1.3.6.1.2.1.10.7.5.1.3.22.8	Counter32	0
dot3CollFrequencies.22.9	.1.3.6.1.2.1.10.7.5.1.3.22.9	Counter32	0
dot3CollFrequencies.22.10	.1.3.6.1.2.1.10.7.5.1.3.22.10	Counter32	0
dot3CollFrequencies.22.11	.1.3.6.1.2.1.10.7.5.1.3.22.11	Counter32	0
dot3CollFrequencies.22.12	.1.3.6.1.2.1.10.7.5.1.3.22.12	Counter32	0
dot3CollFrequencies.22.13	.1.3.6.1.2.1.10.7.5.1.3.22.13	Counter32	0
dot3CollFrequencies.22.14	.1.3.6.1.2.1.10.7.5.1.3.22.14	Counter32	0
dot3CollFrequencies.22.15	.1.3.6.1.2.1.10.7.5.1.3.22.15	Counter32	0
dot3CollFrequencies.22.16	.1.3.6.1.2.1.10.7.5.1.3.22.16	Counter32	0
dot3CollFrequencies.23.1	.1.3.6.1.2.1.10.7.5.1.3.23.1	Counter32	0
dot3CollFrequencies.23.2	.1.3.6.1.2.1.10.7.5.1.3.23.2	Counter32	0
dot3CollFrequencies.23.3	.1.3.6.1.2.1.10.7.5.1.3.23.3	Counter32	0

Name	OID	Value Type	Value Example
dot3CollFrequencies.23.4	.1.3.6.1.2.1.10.7.5.1.3.23.4	Counter32	0
dot3CollFrequencies.23.5	.1.3.6.1.2.1.10.7.5.1.3.23.5	Counter32	0
dot3CollFrequencies.23.6	.1.3.6.1.2.1.10.7.5.1.3.23.6	Counter32	0
dot3CollFrequencies.23.7	.1.3.6.1.2.1.10.7.5.1.3.23.7	Counter32	0
dot3CollFrequencies.23.8	.1.3.6.1.2.1.10.7.5.1.3.23.8	Counter32	0
dot3CollFrequencies.23.9	.1.3.6.1.2.1.10.7.5.1.3.23.9	Counter32	0
dot3CollFrequencies.23.10	.1.3.6.1.2.1.10.7.5.1.3.23.10	Counter32	0
dot3CollFrequencies.23.11	.1.3.6.1.2.1.10.7.5.1.3.23.11	Counter32	0
dot3CollFrequencies.23.12	.1.3.6.1.2.1.10.7.5.1.3.23.12	Counter32	0
dot3CollFrequencies.23.13	.1.3.6.1.2.1.10.7.5.1.3.23.13	Counter32	0
dot3CollFrequencies.23.14	.1.3.6.1.2.1.10.7.5.1.3.23.14	Counter32	0
dot3CollFrequencies.23.15	.1.3.6.1.2.1.10.7.5.1.3.23.15	Counter32	0
dot3CollFrequencies.23.16	.1.3.6.1.2.1.10.7.5.1.3.23.16	Counter32	0
dot3CollFrequencies.24.1	.1.3.6.1.2.1.10.7.5.1.3.24.1	Counter32	0
dot3CollFrequencies.24.2	.1.3.6.1.2.1.10.7.5.1.3.24.2	Counter32	0
dot3CollFrequencies.24.3	.1.3.6.1.2.1.10.7.5.1.3.24.3	Counter32	0
dot3CollFrequencies.24.4	.1.3.6.1.2.1.10.7.5.1.3.24.4	Counter32	0
dot3CollFrequencies.24.5	.1.3.6.1.2.1.10.7.5.1.3.24.5	Counter32	0
dot3CollFrequencies.24.6	.1.3.6.1.2.1.10.7.5.1.3.24.6	Counter32	0
dot3CollFrequencies.24.7	.1.3.6.1.2.1.10.7.5.1.3.24.7	Counter32	0
dot3CollFrequencies.24.8	.1.3.6.1.2.1.10.7.5.1.3.24.8	Counter32	0
dot3CollFrequencies.24.9	.1.3.6.1.2.1.10.7.5.1.3.24.9	Counter32	0
dot3CollFrequencies.24.10	.1.3.6.1.2.1.10.7.5.1.3.24.10	Counter32	0
dot3CollFrequencies.24.11	.1.3.6.1.2.1.10.7.5.1.3.24.11	Counter32	0
dot3CollFrequencies.24.12	.1.3.6.1.2.1.10.7.5.1.3.24.12	Counter32	0
dot3CollFrequencies.24.13	.1.3.6.1.2.1.10.7.5.1.3.24.13	Counter32	0
dot3CollFrequencies.24.14	.1.3.6.1.2.1.10.7.5.1.3.24.14	Counter32	0
dot3CollFrequencies.24.15	.1.3.6.1.2.1.10.7.5.1.3.24.15	Counter32	0
dot3CollFrequencies.24.16	.1.3.6.1.2.1.10.7.5.1.3.24.16	Counter32	0
dot3CollFrequencies.25.1	.1.3.6.1.2.1.10.7.5.1.3.25.1	Counter32	0
dot3CollFrequencies.25.2	.1.3.6.1.2.1.10.7.5.1.3.25.2	Counter32	0
dot3CollFrequencies.25.3	.1.3.6.1.2.1.10.7.5.1.3.25.3	Counter32	0
dot3CollFrequencies.25.4	.1.3.6.1.2.1.10.7.5.1.3.25.4	Counter32	0
dot3CollFrequencies.25.5	.1.3.6.1.2.1.10.7.5.1.3.25.5	Counter32	0
dot3CollFrequencies.25.6	.1.3.6.1.2.1.10.7.5.1.3.25.6	Counter32	0
dot3CollFrequencies.25.7	.1.3.6.1.2.1.10.7.5.1.3.25.7	Counter32	0
dot3CollFrequencies.25.8	.1.3.6.1.2.1.10.7.5.1.3.25.8	Counter32	0
dot3CollFrequencies.25.9	.1.3.6.1.2.1.10.7.5.1.3.25.9	Counter32	0
dot3CollFrequencies.25.10	.1.3.6.1.2.1.10.7.5.1.3.25.10	Counter32	0
dot3CollFrequencies.25.11	.1.3.6.1.2.1.10.7.5.1.3.25.11	Counter32	0
dot3CollFrequencies.25.12	.1.3.6.1.2.1.10.7.5.1.3.25.12	Counter32	0
dot3CollFrequencies.25.13	.1.3.6.1.2.1.10.7.5.1.3.25.13	Counter32	0
dot3CollFrequencies.25.14	.1.3.6.1.2.1.10.7.5.1.3.25.14	Counter32	0

Name	OID	Value Type	Value Example
dot3CollFrequencies.25.15	.1.3.6.1.2.1.10.7.5.1.3.25.15	Counter32	0
dot3CollFrequencies.25.16	.1.3.6.1.2.1.10.7.5.1.3.25.16	Counter32	0
dot3CollFrequencies.26.1	.1.3.6.1.2.1.10.7.5.1.3.26.1	Counter32	0
dot3CollFrequencies.26.2	.1.3.6.1.2.1.10.7.5.1.3.26.2	Counter32	0
dot3CollFrequencies.26.3	.1.3.6.1.2.1.10.7.5.1.3.26.3	Counter32	0
dot3CollFrequencies.26.4	.1.3.6.1.2.1.10.7.5.1.3.26.4	Counter32	0
dot3CollFrequencies.26.5	.1.3.6.1.2.1.10.7.5.1.3.26.5	Counter32	0
dot3CollFrequencies.26.6	.1.3.6.1.2.1.10.7.5.1.3.26.6	Counter32	0
dot3CollFrequencies.26.7	.1.3.6.1.2.1.10.7.5.1.3.26.7	Counter32	0
dot3CollFrequencies.26.8	.1.3.6.1.2.1.10.7.5.1.3.26.8	Counter32	0
dot3CollFrequencies.26.9	.1.3.6.1.2.1.10.7.5.1.3.26.9	Counter32	0
dot3CollFrequencies.26.10	.1.3.6.1.2.1.10.7.5.1.3.26.10	Counter32	0
dot3CollFrequencies.26.11	.1.3.6.1.2.1.10.7.5.1.3.26.11	Counter32	0
dot3CollFrequencies.26.12	.1.3.6.1.2.1.10.7.5.1.3.26.12	Counter32	0
dot3CollFrequencies.26.13	.1.3.6.1.2.1.10.7.5.1.3.26.13	Counter32	0
dot3CollFrequencies.26.14	.1.3.6.1.2.1.10.7.5.1.3.26.14	Counter32	0
dot3CollFrequencies.26.15	.1.3.6.1.2.1.10.7.5.1.3.26.15	Counter32	0
dot3CollFrequencies.26.16	.1.3.6.1.2.1.10.7.5.1.3.26.16	Counter32	0
dot3CollFrequencies.27.1	.1.3.6.1.2.1.10.7.5.1.3.27.1	Counter32	0
dot3CollFrequencies.27.2	.1.3.6.1.2.1.10.7.5.1.3.27.2	Counter32	0
dot3CollFrequencies.27.3	.1.3.6.1.2.1.10.7.5.1.3.27.3	Counter32	0
dot3CollFrequencies.27.4	.1.3.6.1.2.1.10.7.5.1.3.27.4	Counter32	0
dot3CollFrequencies.27.5	.1.3.6.1.2.1.10.7.5.1.3.27.5	Counter32	0
dot3CollFrequencies.27.6	.1.3.6.1.2.1.10.7.5.1.3.27.6	Counter32	0
dot3CollFrequencies.27.7	.1.3.6.1.2.1.10.7.5.1.3.27.7	Counter32	0
dot3CollFrequencies.27.8	.1.3.6.1.2.1.10.7.5.1.3.27.8	Counter32	0
dot3CollFrequencies.27.9	.1.3.6.1.2.1.10.7.5.1.3.27.9	Counter32	0
dot3CollFrequencies.27.10	.1.3.6.1.2.1.10.7.5.1.3.27.10	Counter32	0
dot3CollFrequencies.27.11	.1.3.6.1.2.1.10.7.5.1.3.27.11	Counter32	0
dot3CollFrequencies.27.12	.1.3.6.1.2.1.10.7.5.1.3.27.12	Counter32	0
dot3CollFrequencies.27.13	.1.3.6.1.2.1.10.7.5.1.3.27.13	Counter32	0
dot3CollFrequencies.27.14	.1.3.6.1.2.1.10.7.5.1.3.27.14	Counter32	0
dot3CollFrequencies.27.15	.1.3.6.1.2.1.10.7.5.1.3.27.15	Counter32	0
dot3CollFrequencies.27.16	.1.3.6.1.2.1.10.7.5.1.3.27.16	Counter32	0
dot3CollFrequencies.28.1	.1.3.6.1.2.1.10.7.5.1.3.28.1	Counter32	0
dot3CollFrequencies.28.2	.1.3.6.1.2.1.10.7.5.1.3.28.2	Counter32	0
dot3CollFrequencies.28.3	.1.3.6.1.2.1.10.7.5.1.3.28.3	Counter32	0
dot3CollFrequencies.28.4	.1.3.6.1.2.1.10.7.5.1.3.28.4	Counter32	0
dot3CollFrequencies.28.5	.1.3.6.1.2.1.10.7.5.1.3.28.5	Counter32	0
dot3CollFrequencies.28.6	.1.3.6.1.2.1.10.7.5.1.3.28.6	Counter32	0
dot3CollFrequencies.28.7	.1.3.6.1.2.1.10.7.5.1.3.28.7	Counter32	0
dot3CollFrequencies.28.8	.1.3.6.1.2.1.10.7.5.1.3.28.8	Counter32	0
dot3CollFrequencies.28.9	.1.3.6.1.2.1.10.7.5.1.3.28.9	Counter32	0



Name	OID	Value Type	Value Example
dot3CollFrequencies.28.10	.1.3.6.1.2.1.10.7.5.1.3.28.10	Counter32	0
dot3CollFrequencies.28.11	.1.3.6.1.2.1.10.7.5.1.3.28.11	Counter32	0
dot3CollFrequencies.28.12	.1.3.6.1.2.1.10.7.5.1.3.28.12	Counter32	0
dot3CollFrequencies.28.13	.1.3.6.1.2.1.10.7.5.1.3.28.13	Counter32	0
dot3CollFrequencies.28.14	.1.3.6.1.2.1.10.7.5.1.3.28.14	Counter32	0
dot3CollFrequencies.28.15	.1.3.6.1.2.1.10.7.5.1.3.28.15	Counter32	0
dot3CollFrequencies.28.16	.1.3.6.1.2.1.10.7.5.1.3.28.16	Counter32	0
dot3CollFrequencies.29.1	.1.3.6.1.2.1.10.7.5.1.3.29.1	Counter32	0
dot3CollFrequencies.29.2	.1.3.6.1.2.1.10.7.5.1.3.29.2	Counter32	0
dot3CollFrequencies.29.3	.1.3.6.1.2.1.10.7.5.1.3.29.3	Counter32	0
dot3CollFrequencies.29.4	.1.3.6.1.2.1.10.7.5.1.3.29.4	Counter32	0
dot3CollFrequencies.29.5	.1.3.6.1.2.1.10.7.5.1.3.29.5	Counter32	0
dot3CollFrequencies.29.6	.1.3.6.1.2.1.10.7.5.1.3.29.6	Counter32	0
dot3CollFrequencies.29.7	.1.3.6.1.2.1.10.7.5.1.3.29.7	Counter32	0
dot3CollFrequencies.29.8	.1.3.6.1.2.1.10.7.5.1.3.29.8	Counter32	0
dot3CollFrequencies.29.9	.1.3.6.1.2.1.10.7.5.1.3.29.9	Counter32	0
dot3CollFrequencies.29.10	.1.3.6.1.2.1.10.7.5.1.3.29.10	Counter32	0
dot3CollFrequencies.29.11	.1.3.6.1.2.1.10.7.5.1.3.29.11	Counter32	0
dot3CollFrequencies.29.12	.1.3.6.1.2.1.10.7.5.1.3.29.12	Counter32	0
dot3CollFrequencies.29.13	.1.3.6.1.2.1.10.7.5.1.3.29.13	Counter32	0
dot3CollFrequencies.29.14	.1.3.6.1.2.1.10.7.5.1.3.29.14	Counter32	0
dot3CollFrequencies.29.15	.1.3.6.1.2.1.10.7.5.1.3.29.15	Counter32	0
dot3CollFrequencies.29.16	.1.3.6.1.2.1.10.7.5.1.3.29.16	Counter32	0
dot3CollFrequencies.30.1	.1.3.6.1.2.1.10.7.5.1.3.30.1	Counter32	0
dot3CollFrequencies.30.2	.1.3.6.1.2.1.10.7.5.1.3.30.2	Counter32	0
dot3CollFrequencies.30.3	.1.3.6.1.2.1.10.7.5.1.3.30.3	Counter32	0
dot3CollFrequencies.30.4	.1.3.6.1.2.1.10.7.5.1.3.30.4	Counter32	0
dot3CollFrequencies.30.5	.1.3.6.1.2.1.10.7.5.1.3.30.5	Counter32	0
dot3CollFrequencies.30.6	.1.3.6.1.2.1.10.7.5.1.3.30.6	Counter32	0
dot3CollFrequencies.30.7	.1.3.6.1.2.1.10.7.5.1.3.30.7	Counter32	0
dot3CollFrequencies.30.8	.1.3.6.1.2.1.10.7.5.1.3.30.8	Counter32	0
dot3CollFrequencies.30.9	.1.3.6.1.2.1.10.7.5.1.3.30.9	Counter32	0
dot3CollFrequencies.30.10	.1.3.6.1.2.1.10.7.5.1.3.30.10	Counter32	0
dot3CollFrequencies.30.11	.1.3.6.1.2.1.10.7.5.1.3.30.11	Counter32	0
dot3CollFrequencies.30.12	.1.3.6.1.2.1.10.7.5.1.3.30.12	Counter32	0
dot3CollFrequencies.30.13	.1.3.6.1.2.1.10.7.5.1.3.30.13	Counter32	0
dot3CollFrequencies.30.14	.1.3.6.1.2.1.10.7.5.1.3.30.14	Counter32	0
dot3CollFrequencies.30.15	.1.3.6.1.2.1.10.7.5.1.3.30.15	Counter32	0
dot3CollFrequencies.30.16	.1.3.6.1.2.1.10.7.5.1.3.30.16	Counter32	0
dot3CollFrequencies.31.1	.1.3.6.1.2.1.10.7.5.1.3.31.1	Counter32	0
dot3CollFrequencies.31.2	.1.3.6.1.2.1.10.7.5.1.3.31.2	Counter32	0
dot3CollFrequencies.31.3	.1.3.6.1.2.1.10.7.5.1.3.31.3	Counter32	0
dot3CollFrequencies.31.4	.1.3.6.1.2.1.10.7.5.1.3.31.4	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot3CollFrequencies.31.5	.1.3.6.1.2.1.10.7.5.1.3.31.5	Counter32	0
dot3CollFrequencies.31.6	.1.3.6.1.2.1.10.7.5.1.3.31.6	Counter32	0
dot3CollFrequencies.31.7	.1.3.6.1.2.1.10.7.5.1.3.31.7	Counter32	0
dot3CollFrequencies.31.8	.1.3.6.1.2.1.10.7.5.1.3.31.8	Counter32	0
dot3CollFrequencies.31.9	.1.3.6.1.2.1.10.7.5.1.3.31.9	Counter32	0
dot3CollFrequencies.31.10	.1.3.6.1.2.1.10.7.5.1.3.31.10	Counter32	0
dot3CollFrequencies.31.11	.1.3.6.1.2.1.10.7.5.1.3.31.11	Counter32	0
dot3CollFrequencies.31.12	.1.3.6.1.2.1.10.7.5.1.3.31.12	Counter32	0
dot3CollFrequencies.31.13	.1.3.6.1.2.1.10.7.5.1.3.31.13	Counter32	0
dot3CollFrequencies.31.14	.1.3.6.1.2.1.10.7.5.1.3.31.14	Counter32	0
dot3CollFrequencies.31.15	.1.3.6.1.2.1.10.7.5.1.3.31.15	Counter32	0
dot3CollFrequencies.31.16	.1.3.6.1.2.1.10.7.5.1.3.31.16	Counter32	0
dot3CollFrequencies.32.1	.1.3.6.1.2.1.10.7.5.1.3.32.1	Counter32	0
dot3CollFrequencies.32.2	.1.3.6.1.2.1.10.7.5.1.3.32.2	Counter32	0
dot3CollFrequencies.32.3	.1.3.6.1.2.1.10.7.5.1.3.32.3	Counter32	0
dot3CollFrequencies.32.4	.1.3.6.1.2.1.10.7.5.1.3.32.4	Counter32	0
dot3CollFrequencies.32.5	.1.3.6.1.2.1.10.7.5.1.3.32.5	Counter32	0
dot3CollFrequencies.32.6	.1.3.6.1.2.1.10.7.5.1.3.32.6	Counter32	0
dot3CollFrequencies.32.7	.1.3.6.1.2.1.10.7.5.1.3.32.7	Counter32	0
dot3CollFrequencies.32.8	.1.3.6.1.2.1.10.7.5.1.3.32.8	Counter32	0
dot3CollFrequencies.32.9	.1.3.6.1.2.1.10.7.5.1.3.32.9	Counter32	0
dot3CollFrequencies.32.10	.1.3.6.1.2.1.10.7.5.1.3.32.10	Counter32	0
dot3CollFrequencies.32.11	.1.3.6.1.2.1.10.7.5.1.3.32.11	Counter32	0
dot3CollFrequencies.32.12	.1.3.6.1.2.1.10.7.5.1.3.32.12	Counter32	0
dot3CollFrequencies.32.13	.1.3.6.1.2.1.10.7.5.1.3.32.13	Counter32	0
dot3CollFrequencies.32.14	.1.3.6.1.2.1.10.7.5.1.3.32.14	Counter32	0
dot3CollFrequencies.32.15	.1.3.6.1.2.1.10.7.5.1.3.32.15	Counter32	0
dot3CollFrequencies.32.16	.1.3.6.1.2.1.10.7.5.1.3.32.16	Counter32	0
dot3CollFrequencies.33.1	.1.3.6.1.2.1.10.7.5.1.3.33.1	Counter32	0
dot3CollFrequencies.33.2	.1.3.6.1.2.1.10.7.5.1.3.33.2	Counter32	0
dot3CollFrequencies.33.3	.1.3.6.1.2.1.10.7.5.1.3.33.3	Counter32	0
dot3CollFrequencies.33.4	.1.3.6.1.2.1.10.7.5.1.3.33.4	Counter32	0
dot3CollFrequencies.33.5	.1.3.6.1.2.1.10.7.5.1.3.33.5	Counter32	0
dot3CollFrequencies.33.6	.1.3.6.1.2.1.10.7.5.1.3.33.6	Counter32	0
dot3CollFrequencies.33.7	.1.3.6.1.2.1.10.7.5.1.3.33.7	Counter32	0
dot3CollFrequencies.33.8	.1.3.6.1.2.1.10.7.5.1.3.33.8	Counter32	0
dot3CollFrequencies.33.9	.1.3.6.1.2.1.10.7.5.1.3.33.9	Counter32	0
dot3CollFrequencies.33.10	.1.3.6.1.2.1.10.7.5.1.3.33.10	Counter32	0
dot3CollFrequencies.33.11	.1.3.6.1.2.1.10.7.5.1.3.33.11	Counter32	0
dot3CollFrequencies.33.12	.1.3.6.1.2.1.10.7.5.1.3.33.12	Counter32	0
dot3CollFrequencies.33.13	.1.3.6.1.2.1.10.7.5.1.3.33.13	Counter32	0
dot3CollFrequencies.33.14	.1.3.6.1.2.1.10.7.5.1.3.33.14	Counter32	0
dot3CollFrequencies.33.15	.1.3.6.1.2.1.10.7.5.1.3.33.15	Counter32	0

Name	OID	Value Type	Value Example
dot3CollFrequencies.33.16	.1.3.6.1.2.1.10.7.5.1.3.33.16	Counter32	0
dot3CollFrequencies.34.1	.1.3.6.1.2.1.10.7.5.1.3.34.1	Counter32	0
dot3CollFrequencies.34.2	.1.3.6.1.2.1.10.7.5.1.3.34.2	Counter32	0
dot3CollFrequencies.34.3	.1.3.6.1.2.1.10.7.5.1.3.34.3	Counter32	0
dot3CollFrequencies.34.4	.1.3.6.1.2.1.10.7.5.1.3.34.4	Counter32	0
dot3CollFrequencies.34.5	.1.3.6.1.2.1.10.7.5.1.3.34.5	Counter32	0
dot3CollFrequencies.34.6	.1.3.6.1.2.1.10.7.5.1.3.34.6	Counter32	0
dot3CollFrequencies.34.7	.1.3.6.1.2.1.10.7.5.1.3.34.7	Counter32	0
dot3CollFrequencies.34.8	.1.3.6.1.2.1.10.7.5.1.3.34.8	Counter32	0
dot3CollFrequencies.34.9	.1.3.6.1.2.1.10.7.5.1.3.34.9	Counter32	0
dot3CollFrequencies.34.10	.1.3.6.1.2.1.10.7.5.1.3.34.10	Counter32	0
dot3CollFrequencies.34.11	.1.3.6.1.2.1.10.7.5.1.3.34.11	Counter32	0
dot3CollFrequencies.34.12	.1.3.6.1.2.1.10.7.5.1.3.34.12	Counter32	0
dot3CollFrequencies.34.13	.1.3.6.1.2.1.10.7.5.1.3.34.13	Counter32	0
dot3CollFrequencies.34.14	.1.3.6.1.2.1.10.7.5.1.3.34.14	Counter32	0
dot3CollFrequencies.34.15	.1.3.6.1.2.1.10.7.5.1.3.34.15	Counter32	0
dot3CollFrequencies.34.16	.1.3.6.1.2.1.10.7.5.1.3.34.16	Counter32	0
dot3CollFrequencies.35.1	.1.3.6.1.2.1.10.7.5.1.3.35.1	Counter32	0
dot3CollFrequencies.35.2	.1.3.6.1.2.1.10.7.5.1.3.35.2	Counter32	0
dot3CollFrequencies.35.3	.1.3.6.1.2.1.10.7.5.1.3.35.3	Counter32	0
dot3CollFrequencies.35.4	.1.3.6.1.2.1.10.7.5.1.3.35.4	Counter32	0
dot3CollFrequencies.35.5	.1.3.6.1.2.1.10.7.5.1.3.35.5	Counter32	0
dot3CollFrequencies.35.6	.1.3.6.1.2.1.10.7.5.1.3.35.6	Counter32	0
dot3CollFrequencies.35.7	.1.3.6.1.2.1.10.7.5.1.3.35.7	Counter32	0
dot3CollFrequencies.35.8	.1.3.6.1.2.1.10.7.5.1.3.35.8	Counter32	0
dot3CollFrequencies.35.9	.1.3.6.1.2.1.10.7.5.1.3.35.9	Counter32	0
dot3CollFrequencies.35.10	.1.3.6.1.2.1.10.7.5.1.3.35.10	Counter32	0
dot3CollFrequencies.35.11	.1.3.6.1.2.1.10.7.5.1.3.35.11	Counter32	0
dot3CollFrequencies.35.12	.1.3.6.1.2.1.10.7.5.1.3.35.12	Counter32	0
dot3CollFrequencies.35.13	.1.3.6.1.2.1.10.7.5.1.3.35.13	Counter32	0
dot3CollFrequencies.35.14	.1.3.6.1.2.1.10.7.5.1.3.35.14	Counter32	0
dot3CollFrequencies.35.15	.1.3.6.1.2.1.10.7.5.1.3.35.15	Counter32	0
dot3CollFrequencies.35.16	.1.3.6.1.2.1.10.7.5.1.3.35.16	Counter32	0
dot3CollFrequencies.36.1	.1.3.6.1.2.1.10.7.5.1.3.36.1	Counter32	0
dot3CollFrequencies.36.2	.1.3.6.1.2.1.10.7.5.1.3.36.2	Counter32	0
dot3CollFrequencies.36.3	.1.3.6.1.2.1.10.7.5.1.3.36.3	Counter32	0
dot3CollFrequencies.36.4	.1.3.6.1.2.1.10.7.5.1.3.36.4	Counter32	0
dot3CollFrequencies.36.5	.1.3.6.1.2.1.10.7.5.1.3.36.5	Counter32	0
dot3CollFrequencies.36.6	.1.3.6.1.2.1.10.7.5.1.3.36.6	Counter32	0
dot3CollFrequencies.36.7	.1.3.6.1.2.1.10.7.5.1.3.36.7	Counter32	0
dot3CollFrequencies.36.8	.1.3.6.1.2.1.10.7.5.1.3.36.8	Counter32	0
dot3CollFrequencies.36.9	.1.3.6.1.2.1.10.7.5.1.3.36.9	Counter32	0
dot3CollFrequencies.36.10	.1.3.6.1.2.1.10.7.5.1.3.36.10	Counter32	0

Name	OID	Value Type	Value Example
dot3CollFrequencies.36.11	.1.3.6.1.2.1.10.7.5.1.3.36.11	Counter32	0
dot3CollFrequencies.36.12	.1.3.6.1.2.1.10.7.5.1.3.36.12	Counter32	0
dot3CollFrequencies.36.13	.1.3.6.1.2.1.10.7.5.1.3.36.13	Counter32	0
dot3CollFrequencies.36.14	.1.3.6.1.2.1.10.7.5.1.3.36.14	Counter32	0
dot3CollFrequencies.36.15	.1.3.6.1.2.1.10.7.5.1.3.36.15	Counter32	0
dot3CollFrequencies.36.16	.1.3.6.1.2.1.10.7.5.1.3.36.16	Counter32	0
dot3CollFrequencies.37.1	.1.3.6.1.2.1.10.7.5.1.3.37.1	Counter32	0
dot3CollFrequencies.37.2	.1.3.6.1.2.1.10.7.5.1.3.37.2	Counter32	0
dot3CollFrequencies.37.3	.1.3.6.1.2.1.10.7.5.1.3.37.3	Counter32	0
dot3CollFrequencies.37.4	.1.3.6.1.2.1.10.7.5.1.3.37.4	Counter32	0
dot3CollFrequencies.37.5	.1.3.6.1.2.1.10.7.5.1.3.37.5	Counter32	0
dot3CollFrequencies.37.6	.1.3.6.1.2.1.10.7.5.1.3.37.6	Counter32	0
dot3CollFrequencies.37.7	.1.3.6.1.2.1.10.7.5.1.3.37.7	Counter32	0
dot3CollFrequencies.37.8	.1.3.6.1.2.1.10.7.5.1.3.37.8	Counter32	0
dot3CollFrequencies.37.9	.1.3.6.1.2.1.10.7.5.1.3.37.9	Counter32	0
dot3CollFrequencies.37.10	.1.3.6.1.2.1.10.7.5.1.3.37.10	Counter32	0
dot3CollFrequencies.37.11	.1.3.6.1.2.1.10.7.5.1.3.37.11	Counter32	0
dot3CollFrequencies.37.12	.1.3.6.1.2.1.10.7.5.1.3.37.12	Counter32	0
dot3CollFrequencies.37.13	.1.3.6.1.2.1.10.7.5.1.3.37.13	Counter32	0
dot3CollFrequencies.37.14	.1.3.6.1.2.1.10.7.5.1.3.37.14	Counter32	0
dot3CollFrequencies.37.15	.1.3.6.1.2.1.10.7.5.1.3.37.15	Counter32	0
dot3CollFrequencies.37.16	.1.3.6.1.2.1.10.7.5.1.3.37.16	Counter32	0
dot3CollFrequencies.38.1	.1.3.6.1.2.1.10.7.5.1.3.38.1	Counter32	0
dot3CollFrequencies.38.2	.1.3.6.1.2.1.10.7.5.1.3.38.2	Counter32	0
dot3CollFrequencies.38.3	.1.3.6.1.2.1.10.7.5.1.3.38.3	Counter32	0
dot3CollFrequencies.38.4	.1.3.6.1.2.1.10.7.5.1.3.38.4	Counter32	0
dot3CollFrequencies.38.5	.1.3.6.1.2.1.10.7.5.1.3.38.5	Counter32	0
dot3CollFrequencies.38.6	.1.3.6.1.2.1.10.7.5.1.3.38.6	Counter32	0
dot3CollFrequencies.38.7	.1.3.6.1.2.1.10.7.5.1.3.38.7	Counter32	0
dot3CollFrequencies.38.8	.1.3.6.1.2.1.10.7.5.1.3.38.8	Counter32	0
dot3CollFrequencies.38.9	.1.3.6.1.2.1.10.7.5.1.3.38.9	Counter32	0
dot3CollFrequencies.38.10	.1.3.6.1.2.1.10.7.5.1.3.38.10	Counter32	0
dot3CollFrequencies.38.11	.1.3.6.1.2.1.10.7.5.1.3.38.11	Counter32	0
dot3CollFrequencies.38.12	.1.3.6.1.2.1.10.7.5.1.3.38.12	Counter32	0
dot3CollFrequencies.38.13	.1.3.6.1.2.1.10.7.5.1.3.38.13	Counter32	0
dot3CollFrequencies.38.14	.1.3.6.1.2.1.10.7.5.1.3.38.14	Counter32	0
dot3CollFrequencies.38.15	.1.3.6.1.2.1.10.7.5.1.3.38.15	Counter32	0
dot3CollFrequencies.38.16	.1.3.6.1.2.1.10.7.5.1.3.38.16	Counter32	0
dot3CollFrequencies.39.1	.1.3.6.1.2.1.10.7.5.1.3.39.1	Counter32	0
dot3CollFrequencies.39.2	.1.3.6.1.2.1.10.7.5.1.3.39.2	Counter32	0
dot3CollFrequencies.39.3	.1.3.6.1.2.1.10.7.5.1.3.39.3	Counter32	0
dot3CollFrequencies.39.4	.1.3.6.1.2.1.10.7.5.1.3.39.4	Counter32	0
dot3CollFrequencies.39.5	.1.3.6.1.2.1.10.7.5.1.3.39.5	Counter32	0

Name	OID	Value Type	Value Example
dot3CollFrequencies.39.6	.1.3.6.1.2.1.10.7.5.1.3.39.6	Counter32	0
dot3CollFrequencies.39.7	.1.3.6.1.2.1.10.7.5.1.3.39.7	Counter32	0
dot3CollFrequencies.39.8	.1.3.6.1.2.1.10.7.5.1.3.39.8	Counter32	0
dot3CollFrequencies.39.9	.1.3.6.1.2.1.10.7.5.1.3.39.9	Counter32	0
dot3CollFrequencies.39.10	.1.3.6.1.2.1.10.7.5.1.3.39.10	Counter32	0
dot3CollFrequencies.39.11	.1.3.6.1.2.1.10.7.5.1.3.39.11	Counter32	0
dot3CollFrequencies.39.12	.1.3.6.1.2.1.10.7.5.1.3.39.12	Counter32	0
dot3CollFrequencies.39.13	.1.3.6.1.2.1.10.7.5.1.3.39.13	Counter32	0
dot3CollFrequencies.39.14	.1.3.6.1.2.1.10.7.5.1.3.39.14	Counter32	0
dot3CollFrequencies.39.15	.1.3.6.1.2.1.10.7.5.1.3.39.15	Counter32	0
dot3CollFrequencies.39.16	.1.3.6.1.2.1.10.7.5.1.3.39.16	Counter32	0
dot3CollFrequencies.40.1	.1.3.6.1.2.1.10.7.5.1.3.40.1	Counter32	0
dot3CollFrequencies.40.2	.1.3.6.1.2.1.10.7.5.1.3.40.2	Counter32	0
dot3CollFrequencies.40.3	.1.3.6.1.2.1.10.7.5.1.3.40.3	Counter32	0
dot3CollFrequencies.40.4	.1.3.6.1.2.1.10.7.5.1.3.40.4	Counter32	0
dot3CollFrequencies.40.5	.1.3.6.1.2.1.10.7.5.1.3.40.5	Counter32	0
dot3CollFrequencies.40.6	.1.3.6.1.2.1.10.7.5.1.3.40.6	Counter32	0
dot3CollFrequencies.40.7	.1.3.6.1.2.1.10.7.5.1.3.40.7	Counter32	0
dot3CollFrequencies.40.8	.1.3.6.1.2.1.10.7.5.1.3.40.8	Counter32	0
dot3CollFrequencies.40.9	.1.3.6.1.2.1.10.7.5.1.3.40.9	Counter32	0
dot3CollFrequencies.40.10	.1.3.6.1.2.1.10.7.5.1.3.40.10	Counter32	0
dot3CollFrequencies.40.11	.1.3.6.1.2.1.10.7.5.1.3.40.11	Counter32	0
dot3CollFrequencies.40.12	.1.3.6.1.2.1.10.7.5.1.3.40.12	Counter32	0
dot3CollFrequencies.40.13	.1.3.6.1.2.1.10.7.5.1.3.40.13	Counter32	0
dot3CollFrequencies.40.14	.1.3.6.1.2.1.10.7.5.1.3.40.14	Counter32	0
dot3CollFrequencies.40.15	.1.3.6.1.2.1.10.7.5.1.3.40.15	Counter32	0
dot3CollFrequencies.40.16	.1.3.6.1.2.1.10.7.5.1.3.40.16	Counter32	0
dot3CollFrequencies.41.1	.1.3.6.1.2.1.10.7.5.1.3.41.1	Counter32	0
dot3CollFrequencies.41.2	.1.3.6.1.2.1.10.7.5.1.3.41.2	Counter32	0
dot3CollFrequencies.41.3	.1.3.6.1.2.1.10.7.5.1.3.41.3	Counter32	0
dot3CollFrequencies.41.4	.1.3.6.1.2.1.10.7.5.1.3.41.4	Counter32	0
dot3CollFrequencies.41.5	.1.3.6.1.2.1.10.7.5.1.3.41.5	Counter32	0
dot3CollFrequencies.41.6	.1.3.6.1.2.1.10.7.5.1.3.41.6	Counter32	0
dot3CollFrequencies.41.7	.1.3.6.1.2.1.10.7.5.1.3.41.7	Counter32	0
dot3CollFrequencies.41.8	.1.3.6.1.2.1.10.7.5.1.3.41.8	Counter32	0
dot3CollFrequencies.41.9	.1.3.6.1.2.1.10.7.5.1.3.41.9	Counter32	0
dot3CollFrequencies.41.10	.1.3.6.1.2.1.10.7.5.1.3.41.10	Counter32	0
dot3CollFrequencies.41.11	.1.3.6.1.2.1.10.7.5.1.3.41.11	Counter32	0
dot3CollFrequencies.41.12	.1.3.6.1.2.1.10.7.5.1.3.41.12	Counter32	0
dot3CollFrequencies.41.13	.1.3.6.1.2.1.10.7.5.1.3.41.13	Counter32	0
dot3CollFrequencies.41.14	.1.3.6.1.2.1.10.7.5.1.3.41.14	Counter32	0
dot3CollFrequencies.41.15	.1.3.6.1.2.1.10.7.5.1.3.41.15	Counter32	0
dot3CollFrequencies.41.16	.1.3.6.1.2.1.10.7.5.1.3.41.16	Counter32	0

Name	OID	Value Type	Value Example
dot3CollFrequencies.42.1	.1.3.6.1.2.1.10.7.5.1.3.42.1	Counter32	0
dot3CollFrequencies.42.2	.1.3.6.1.2.1.10.7.5.1.3.42.2	Counter32	0
dot3CollFrequencies.42.3	.1.3.6.1.2.1.10.7.5.1.3.42.3	Counter32	0
dot3CollFrequencies.42.4	.1.3.6.1.2.1.10.7.5.1.3.42.4	Counter32	0
dot3CollFrequencies.42.5	.1.3.6.1.2.1.10.7.5.1.3.42.5	Counter32	0
dot3CollFrequencies.42.6	.1.3.6.1.2.1.10.7.5.1.3.42.6	Counter32	0
dot3CollFrequencies.42.7	.1.3.6.1.2.1.10.7.5.1.3.42.7	Counter32	0
dot3CollFrequencies.42.8	.1.3.6.1.2.1.10.7.5.1.3.42.8	Counter32	0
dot3CollFrequencies.42.9	.1.3.6.1.2.1.10.7.5.1.3.42.9	Counter32	0
dot3CollFrequencies.42.10	.1.3.6.1.2.1.10.7.5.1.3.42.10	Counter32	0
dot3CollFrequencies.42.11	.1.3.6.1.2.1.10.7.5.1.3.42.11	Counter32	0
dot3CollFrequencies.42.12	.1.3.6.1.2.1.10.7.5.1.3.42.12	Counter32	0
dot3CollFrequencies.42.13	.1.3.6.1.2.1.10.7.5.1.3.42.13	Counter32	0
dot3CollFrequencies.42.14	.1.3.6.1.2.1.10.7.5.1.3.42.14	Counter32	0
dot3CollFrequencies.42.15	.1.3.6.1.2.1.10.7.5.1.3.42.15	Counter32	0
dot3CollFrequencies.42.16	.1.3.6.1.2.1.10.7.5.1.3.42.16	Counter32	0
dot3CollFrequencies.43.1	.1.3.6.1.2.1.10.7.5.1.3.43.1	Counter32	0
dot3CollFrequencies.43.2	.1.3.6.1.2.1.10.7.5.1.3.43.2	Counter32	0
dot3CollFrequencies.43.3	.1.3.6.1.2.1.10.7.5.1.3.43.3	Counter32	0
dot3CollFrequencies.43.4	.1.3.6.1.2.1.10.7.5.1.3.43.4	Counter32	0
dot3CollFrequencies.43.5	.1.3.6.1.2.1.10.7.5.1.3.43.5	Counter32	0
dot3CollFrequencies.43.6	.1.3.6.1.2.1.10.7.5.1.3.43.6	Counter32	0
dot3CollFrequencies.43.7	.1.3.6.1.2.1.10.7.5.1.3.43.7	Counter32	0
dot3CollFrequencies.43.8	.1.3.6.1.2.1.10.7.5.1.3.43.8	Counter32	0
dot3CollFrequencies.43.9	.1.3.6.1.2.1.10.7.5.1.3.43.9	Counter32	0
dot3CollFrequencies.43.10	.1.3.6.1.2.1.10.7.5.1.3.43.10	Counter32	0
dot3CollFrequencies.43.11	.1.3.6.1.2.1.10.7.5.1.3.43.11	Counter32	0
dot3CollFrequencies.43.12	.1.3.6.1.2.1.10.7.5.1.3.43.12	Counter32	0
dot3CollFrequencies.43.13	.1.3.6.1.2.1.10.7.5.1.3.43.13	Counter32	0
dot3CollFrequencies.43.14	.1.3.6.1.2.1.10.7.5.1.3.43.14	Counter32	0
dot3CollFrequencies.43.15	.1.3.6.1.2.1.10.7.5.1.3.43.15	Counter32	0
dot3CollFrequencies.43.16	.1.3.6.1.2.1.10.7.5.1.3.43.16	Counter32	0
dot3CollFrequencies.44.1	.1.3.6.1.2.1.10.7.5.1.3.44.1	Counter32	0
dot3CollFrequencies.44.2	.1.3.6.1.2.1.10.7.5.1.3.44.2	Counter32	0
dot3CollFrequencies.44.3	.1.3.6.1.2.1.10.7.5.1.3.44.3	Counter32	0
dot3CollFrequencies.44.4	.1.3.6.1.2.1.10.7.5.1.3.44.4	Counter32	0
dot3CollFrequencies.44.5	.1.3.6.1.2.1.10.7.5.1.3.44.5	Counter32	0
dot3CollFrequencies.44.6	.1.3.6.1.2.1.10.7.5.1.3.44.6	Counter32	0
dot3CollFrequencies.44.7	.1.3.6.1.2.1.10.7.5.1.3.44.7	Counter32	0
dot3CollFrequencies.44.8	.1.3.6.1.2.1.10.7.5.1.3.44.8	Counter32	0
dot3CollFrequencies.44.9	.1.3.6.1.2.1.10.7.5.1.3.44.9	Counter32	0
dot3CollFrequencies.44.10	.1.3.6.1.2.1.10.7.5.1.3.44.10	Counter32	0
dot3CollFrequencies.44.11	.1.3.6.1.2.1.10.7.5.1.3.44.11	Counter32	0

Name	OID	Value Type	Value Example
dot3CollFrequencies.44.12	.1.3.6.1.2.1.10.7.5.1.3.44.12	Counter32	0
dot3CollFrequencies.44.13	.1.3.6.1.2.1.10.7.5.1.3.44.13	Counter32	0
dot3CollFrequencies.44.14	.1.3.6.1.2.1.10.7.5.1.3.44.14	Counter32	0
dot3CollFrequencies.44.15	.1.3.6.1.2.1.10.7.5.1.3.44.15	Counter32	0
dot3CollFrequencies.44.16	.1.3.6.1.2.1.10.7.5.1.3.44.16	Counter32	0
dot3CollFrequencies.45.1	.1.3.6.1.2.1.10.7.5.1.3.45.1	Counter32	0
dot3CollFrequencies.45.2	.1.3.6.1.2.1.10.7.5.1.3.45.2	Counter32	0
dot3CollFrequencies.45.3	.1.3.6.1.2.1.10.7.5.1.3.45.3	Counter32	0
dot3CollFrequencies.45.4	.1.3.6.1.2.1.10.7.5.1.3.45.4	Counter32	0
dot3CollFrequencies.45.5	.1.3.6.1.2.1.10.7.5.1.3.45.5	Counter32	0
dot3CollFrequencies.45.6	.1.3.6.1.2.1.10.7.5.1.3.45.6	Counter32	0
dot3CollFrequencies.45.7	.1.3.6.1.2.1.10.7.5.1.3.45.7	Counter32	0
dot3CollFrequencies.45.8	.1.3.6.1.2.1.10.7.5.1.3.45.8	Counter32	0
dot3CollFrequencies.45.9	.1.3.6.1.2.1.10.7.5.1.3.45.9	Counter32	0
dot3CollFrequencies.45.10	.1.3.6.1.2.1.10.7.5.1.3.45.10	Counter32	0
dot3CollFrequencies.45.11	.1.3.6.1.2.1.10.7.5.1.3.45.11	Counter32	0
dot3CollFrequencies.45.12	.1.3.6.1.2.1.10.7.5.1.3.45.12	Counter32	0
dot3CollFrequencies.45.13	.1.3.6.1.2.1.10.7.5.1.3.45.13	Counter32	0
dot3CollFrequencies.45.14	.1.3.6.1.2.1.10.7.5.1.3.45.14	Counter32	0
dot3CollFrequencies.45.15	.1.3.6.1.2.1.10.7.5.1.3.45.15	Counter32	0
dot3CollFrequencies.45.16	.1.3.6.1.2.1.10.7.5.1.3.45.16	Counter32	0
dot3CollFrequencies.46.1	.1.3.6.1.2.1.10.7.5.1.3.46.1	Counter32	0
dot3CollFrequencies.46.2	.1.3.6.1.2.1.10.7.5.1.3.46.2	Counter32	0
dot3CollFrequencies.46.3	.1.3.6.1.2.1.10.7.5.1.3.46.3	Counter32	0
dot3CollFrequencies.46.4	.1.3.6.1.2.1.10.7.5.1.3.46.4	Counter32	0
dot3CollFrequencies.46.5	.1.3.6.1.2.1.10.7.5.1.3.46.5	Counter32	0
dot3CollFrequencies.46.6	.1.3.6.1.2.1.10.7.5.1.3.46.6	Counter32	0
dot3CollFrequencies.46.7	.1.3.6.1.2.1.10.7.5.1.3.46.7	Counter32	0
dot3CollFrequencies.46.8	.1.3.6.1.2.1.10.7.5.1.3.46.8	Counter32	0
dot3CollFrequencies.46.9	.1.3.6.1.2.1.10.7.5.1.3.46.9	Counter32	0
dot3CollFrequencies.46.10	.1.3.6.1.2.1.10.7.5.1.3.46.10	Counter32	0
dot3CollFrequencies.46.11	.1.3.6.1.2.1.10.7.5.1.3.46.11	Counter32	0
dot3CollFrequencies.46.12	.1.3.6.1.2.1.10.7.5.1.3.46.12	Counter32	0
dot3CollFrequencies.46.13	.1.3.6.1.2.1.10.7.5.1.3.46.13	Counter32	0
dot3CollFrequencies.46.14	.1.3.6.1.2.1.10.7.5.1.3.46.14	Counter32	0
dot3CollFrequencies.46.15	.1.3.6.1.2.1.10.7.5.1.3.46.15	Counter32	0
dot3CollFrequencies.46.16	.1.3.6.1.2.1.10.7.5.1.3.46.16	Counter32	0
dot3CollFrequencies.47.1	.1.3.6.1.2.1.10.7.5.1.3.47.1	Counter32	0
dot3CollFrequencies.47.2	.1.3.6.1.2.1.10.7.5.1.3.47.2	Counter32	0
dot3CollFrequencies.47.3	.1.3.6.1.2.1.10.7.5.1.3.47.3	Counter32	0
dot3CollFrequencies.47.4	.1.3.6.1.2.1.10.7.5.1.3.47.4	Counter32	0
dot3CollFrequencies.47.5	.1.3.6.1.2.1.10.7.5.1.3.47.5	Counter32	0
dot3CollFrequencies.47.6	.1.3.6.1.2.1.10.7.5.1.3.47.6	Counter32	0



<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot3CollFrequencies.47.7	.1.3.6.1.2.1.10.7.5.1.3.47.7	Counter32	0
dot3CollFrequencies.47.8	.1.3.6.1.2.1.10.7.5.1.3.47.8	Counter32	0
dot3CollFrequencies.47.9	.1.3.6.1.2.1.10.7.5.1.3.47.9	Counter32	0
dot3CollFrequencies.47.10	.1.3.6.1.2.1.10.7.5.1.3.47.10	Counter32	0
dot3CollFrequencies.47.11	.1.3.6.1.2.1.10.7.5.1.3.47.11	Counter32	0
dot3CollFrequencies.47.12	.1.3.6.1.2.1.10.7.5.1.3.47.12	Counter32	0
dot3CollFrequencies.47.13	.1.3.6.1.2.1.10.7.5.1.3.47.13	Counter32	0
dot3CollFrequencies.47.14	.1.3.6.1.2.1.10.7.5.1.3.47.14	Counter32	0
dot3CollFrequencies.47.15	.1.3.6.1.2.1.10.7.5.1.3.47.15	Counter32	0
dot3CollFrequencies.47.16	.1.3.6.1.2.1.10.7.5.1.3.47.16	Counter32	0
dot3CollFrequencies.48.1	.1.3.6.1.2.1.10.7.5.1.3.48.1	Counter32	0
dot3CollFrequencies.48.2	.1.3.6.1.2.1.10.7.5.1.3.48.2	Counter32	0
dot3CollFrequencies.48.3	.1.3.6.1.2.1.10.7.5.1.3.48.3	Counter32	0
dot3CollFrequencies.48.4	.1.3.6.1.2.1.10.7.5.1.3.48.4	Counter32	0
dot3CollFrequencies.48.5	.1.3.6.1.2.1.10.7.5.1.3.48.5	Counter32	0
dot3CollFrequencies.48.6	.1.3.6.1.2.1.10.7.5.1.3.48.6	Counter32	0
dot3CollFrequencies.48.7	.1.3.6.1.2.1.10.7.5.1.3.48.7	Counter32	0
dot3CollFrequencies.48.8	.1.3.6.1.2.1.10.7.5.1.3.48.8	Counter32	0
dot3CollFrequencies.48.9	.1.3.6.1.2.1.10.7.5.1.3.48.9	Counter32	0
dot3CollFrequencies.48.10	.1.3.6.1.2.1.10.7.5.1.3.48.10	Counter32	0
dot3CollFrequencies.48.11	.1.3.6.1.2.1.10.7.5.1.3.48.11	Counter32	0
dot3CollFrequencies.48.12	.1.3.6.1.2.1.10.7.5.1.3.48.12	Counter32	0
dot3CollFrequencies.48.13	.1.3.6.1.2.1.10.7.5.1.3.48.13	Counter32	0
dot3CollFrequencies.48.14	.1.3.6.1.2.1.10.7.5.1.3.48.14	Counter32	0
dot3CollFrequencies.48.15	.1.3.6.1.2.1.10.7.5.1.3.48.15	Counter32	0
dot3CollFrequencies.48.16	.1.3.6.1.2.1.10.7.5.1.3.48.16	Counter32	0
dot3CollFrequencies.49.1	.1.3.6.1.2.1.10.7.5.1.3.49.1	Counter32	0
dot3CollFrequencies.49.2	.1.3.6.1.2.1.10.7.5.1.3.49.2	Counter32	0
dot3CollFrequencies.49.3	.1.3.6.1.2.1.10.7.5.1.3.49.3	Counter32	0
dot3CollFrequencies.49.4	.1.3.6.1.2.1.10.7.5.1.3.49.4	Counter32	0
dot3CollFrequencies.49.5	.1.3.6.1.2.1.10.7.5.1.3.49.5	Counter32	0
dot3CollFrequencies.49.6	.1.3.6.1.2.1.10.7.5.1.3.49.6	Counter32	0
dot3CollFrequencies.49.7	.1.3.6.1.2.1.10.7.5.1.3.49.7	Counter32	0
dot3CollFrequencies.49.8	.1.3.6.1.2.1.10.7.5.1.3.49.8	Counter32	0
dot3CollFrequencies.49.9	.1.3.6.1.2.1.10.7.5.1.3.49.9	Counter32	0
dot3CollFrequencies.49.10	.1.3.6.1.2.1.10.7.5.1.3.49.10	Counter32	0
dot3CollFrequencies.49.11	.1.3.6.1.2.1.10.7.5.1.3.49.11	Counter32	0
dot3CollFrequencies.49.12	.1.3.6.1.2.1.10.7.5.1.3.49.12	Counter32	0
dot3CollFrequencies.49.13	.1.3.6.1.2.1.10.7.5.1.3.49.13	Counter32	0
dot3CollFrequencies.49.14	.1.3.6.1.2.1.10.7.5.1.3.49.14	Counter32	0
dot3CollFrequencies.49.15	.1.3.6.1.2.1.10.7.5.1.3.49.15	Counter32	0
dot3CollFrequencies.49.16	.1.3.6.1.2.1.10.7.5.1.3.49.16	Counter32	0
dot3CollFrequencies.50.1	.1.3.6.1.2.1.10.7.5.1.3.50.1	Counter32	0



Name	OID	Value Type	Value Example
dot3CollFrequencies.50.2	.1.3.6.1.2.1.10.7.5.1.3.50.2	Counter32	0
dot3CollFrequencies.50.3	.1.3.6.1.2.1.10.7.5.1.3.50.3	Counter32	0
dot3CollFrequencies.50.4	.1.3.6.1.2.1.10.7.5.1.3.50.4	Counter32	0
dot3CollFrequencies.50.5	.1.3.6.1.2.1.10.7.5.1.3.50.5	Counter32	0
dot3CollFrequencies.50.6	.1.3.6.1.2.1.10.7.5.1.3.50.6	Counter32	0
dot3CollFrequencies.50.7	.1.3.6.1.2.1.10.7.5.1.3.50.7	Counter32	0
dot3CollFrequencies.50.8	.1.3.6.1.2.1.10.7.5.1.3.50.8	Counter32	0
dot3CollFrequencies.50.9	.1.3.6.1.2.1.10.7.5.1.3.50.9	Counter32	0
dot3CollFrequencies.50.10	.1.3.6.1.2.1.10.7.5.1.3.50.10	Counter32	0
dot3CollFrequencies.50.11	.1.3.6.1.2.1.10.7.5.1.3.50.11	Counter32	0
dot3CollFrequencies.50.12	.1.3.6.1.2.1.10.7.5.1.3.50.12	Counter32	0
dot3CollFrequencies.50.13	.1.3.6.1.2.1.10.7.5.1.3.50.13	Counter32	0
dot3CollFrequencies.50.14	.1.3.6.1.2.1.10.7.5.1.3.50.14	Counter32	0
dot3CollFrequencies.50.15	.1.3.6.1.2.1.10.7.5.1.3.50.15	Counter32	0
dot3CollFrequencies.50.16	.1.3.6.1.2.1.10.7.5.1.3.50.16	Counter32	0
dot3CollFrequencies.51.1	.1.3.6.1.2.1.10.7.5.1.3.51.1	Counter32	0
dot3CollFrequencies.51.2	.1.3.6.1.2.1.10.7.5.1.3.51.2	Counter32	0
dot3CollFrequencies.51.3	.1.3.6.1.2.1.10.7.5.1.3.51.3	Counter32	0
dot3CollFrequencies.51.4	.1.3.6.1.2.1.10.7.5.1.3.51.4	Counter32	0
dot3CollFrequencies.51.5	.1.3.6.1.2.1.10.7.5.1.3.51.5	Counter32	0
dot3CollFrequencies.51.6	.1.3.6.1.2.1.10.7.5.1.3.51.6	Counter32	0
dot3CollFrequencies.51.7	.1.3.6.1.2.1.10.7.5.1.3.51.7	Counter32	0
dot3CollFrequencies.51.8	.1.3.6.1.2.1.10.7.5.1.3.51.8	Counter32	0
dot3CollFrequencies.51.9	.1.3.6.1.2.1.10.7.5.1.3.51.9	Counter32	0
dot3CollFrequencies.51.10	.1.3.6.1.2.1.10.7.5.1.3.51.10	Counter32	0
dot3CollFrequencies.51.11	.1.3.6.1.2.1.10.7.5.1.3.51.11	Counter32	0
dot3CollFrequencies.51.12	.1.3.6.1.2.1.10.7.5.1.3.51.12	Counter32	0
dot3CollFrequencies.51.13	.1.3.6.1.2.1.10.7.5.1.3.51.13	Counter32	0
dot3CollFrequencies.51.14	.1.3.6.1.2.1.10.7.5.1.3.51.14	Counter32	0
dot3CollFrequencies.51.15	.1.3.6.1.2.1.10.7.5.1.3.51.15	Counter32	0
dot3CollFrequencies.51.16	.1.3.6.1.2.1.10.7.5.1.3.51.16	Counter32	0
dot3CollFrequencies.52.1	.1.3.6.1.2.1.10.7.5.1.3.52.1	Counter32	0
dot3CollFrequencies.52.2	.1.3.6.1.2.1.10.7.5.1.3.52.2	Counter32	0
dot3CollFrequencies.52.3	.1.3.6.1.2.1.10.7.5.1.3.52.3	Counter32	0
dot3CollFrequencies.52.4	.1.3.6.1.2.1.10.7.5.1.3.52.4	Counter32	0
dot3CollFrequencies.52.5	.1.3.6.1.2.1.10.7.5.1.3.52.5	Counter32	0
dot3CollFrequencies.52.6	.1.3.6.1.2.1.10.7.5.1.3.52.6	Counter32	0
dot3CollFrequencies.52.7	.1.3.6.1.2.1.10.7.5.1.3.52.7	Counter32	0
dot3CollFrequencies.52.8	.1.3.6.1.2.1.10.7.5.1.3.52.8	Counter32	0
dot3CollFrequencies.52.9	.1.3.6.1.2.1.10.7.5.1.3.52.9	Counter32	0
dot3CollFrequencies.52.10	.1.3.6.1.2.1.10.7.5.1.3.52.10	Counter32	0
dot3CollFrequencies.52.11	.1.3.6.1.2.1.10.7.5.1.3.52.11	Counter32	0
dot3CollFrequencies.52.12	.1.3.6.1.2.1.10.7.5.1.3.52.12	Counter32	0

Name	OID	Value Type	Value Example
dot3CollFrequencies.52.13	.1.3.6.1.2.1.10.7.5.1.3.52.13	Counter32	0
dot3CollFrequencies.52.14	.1.3.6.1.2.1.10.7.5.1.3.52.14	Counter32	0
dot3CollFrequencies.52.15	.1.3.6.1.2.1.10.7.5.1.3.52.15	Counter32	0
dot3CollFrequencies.52.16	.1.3.6.1.2.1.10.7.5.1.3.52.16	Counter32	0
dot3CollFrequencies.53.1	.1.3.6.1.2.1.10.7.5.1.3.53.1	Counter32	0
dot3CollFrequencies.53.2	.1.3.6.1.2.1.10.7.5.1.3.53.2	Counter32	0
dot3CollFrequencies.53.3	.1.3.6.1.2.1.10.7.5.1.3.53.3	Counter32	0
dot3CollFrequencies.53.4	.1.3.6.1.2.1.10.7.5.1.3.53.4	Counter32	0
dot3CollFrequencies.53.5	.1.3.6.1.2.1.10.7.5.1.3.53.5	Counter32	0
dot3CollFrequencies.53.6	.1.3.6.1.2.1.10.7.5.1.3.53.6	Counter32	0
dot3CollFrequencies.53.7	.1.3.6.1.2.1.10.7.5.1.3.53.7	Counter32	0
dot3CollFrequencies.53.8	.1.3.6.1.2.1.10.7.5.1.3.53.8	Counter32	0
dot3CollFrequencies.53.9	.1.3.6.1.2.1.10.7.5.1.3.53.9	Counter32	0
dot3CollFrequencies.53.10	.1.3.6.1.2.1.10.7.5.1.3.53.10	Counter32	0
dot3CollFrequencies.53.11	.1.3.6.1.2.1.10.7.5.1.3.53.11	Counter32	0
dot3CollFrequencies.53.12	.1.3.6.1.2.1.10.7.5.1.3.53.12	Counter32	0
dot3CollFrequencies.53.13	.1.3.6.1.2.1.10.7.5.1.3.53.13	Counter32	0
dot3CollFrequencies.53.14	.1.3.6.1.2.1.10.7.5.1.3.53.14	Counter32	0
dot3CollFrequencies.53.15	.1.3.6.1.2.1.10.7.5.1.3.53.15	Counter32	0
dot3CollFrequencies.53.16	.1.3.6.1.2.1.10.7.5.1.3.53.16	Counter32	0
dot3CollFrequencies.54.1	.1.3.6.1.2.1.10.7.5.1.3.54.1	Counter32	0
dot3CollFrequencies.54.2	.1.3.6.1.2.1.10.7.5.1.3.54.2	Counter32	0
dot3CollFrequencies.54.3	.1.3.6.1.2.1.10.7.5.1.3.54.3	Counter32	0
dot3CollFrequencies.54.4	.1.3.6.1.2.1.10.7.5.1.3.54.4	Counter32	0
dot3CollFrequencies.54.5	.1.3.6.1.2.1.10.7.5.1.3.54.5	Counter32	0
dot3CollFrequencies.54.6	.1.3.6.1.2.1.10.7.5.1.3.54.6	Counter32	0
dot3CollFrequencies.54.7	.1.3.6.1.2.1.10.7.5.1.3.54.7	Counter32	0
dot3CollFrequencies.54.8	.1.3.6.1.2.1.10.7.5.1.3.54.8	Counter32	0
dot3CollFrequencies.54.9	.1.3.6.1.2.1.10.7.5.1.3.54.9	Counter32	0
dot3CollFrequencies.54.10	.1.3.6.1.2.1.10.7.5.1.3.54.10	Counter32	0
dot3CollFrequencies.54.11	.1.3.6.1.2.1.10.7.5.1.3.54.11	Counter32	0
dot3CollFrequencies.54.12	.1.3.6.1.2.1.10.7.5.1.3.54.12	Counter32	0
dot3CollFrequencies.54.13	.1.3.6.1.2.1.10.7.5.1.3.54.13	Counter32	0
dot3CollFrequencies.54.14	.1.3.6.1.2.1.10.7.5.1.3.54.14	Counter32	0
dot3CollFrequencies.54.15	.1.3.6.1.2.1.10.7.5.1.3.54.15	Counter32	0
dot3CollFrequencies.54.16	.1.3.6.1.2.1.10.7.5.1.3.54.16	Counter32	0
dot3ControlFunctionsSupported.1	.1.3.6.1.2.1.10.7.9.1.1.1	OctetString	{pause}
dot3ControlFunctionsSupported.2	.1.3.6.1.2.1.10.7.9.1.1.2	OctetString	{pause}
dot3ControlFunctionsSupported.3	.1.3.6.1.2.1.10.7.9.1.1.3	OctetString	{pause}
dot3ControlFunctionsSupported.4	.1.3.6.1.2.1.10.7.9.1.1.4	OctetString	{pause}

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot3ControlFunctionsSupported.5	.1.3.6.1.2.1.10.7.9.1.1.5	OctetString	{pause}
dot3ControlFunctionsSupported.6	.1.3.6.1.2.1.10.7.9.1.1.6	OctetString	{pause}
dot3ControlFunctionsSupported.7	.1.3.6.1.2.1.10.7.9.1.1.7	OctetString	{pause}
dot3ControlFunctionsSupported.8	.1.3.6.1.2.1.10.7.9.1.1.8	OctetString	{pause}
dot3ControlFunctionsSupported.9	.1.3.6.1.2.1.10.7.9.1.1.9	OctetString	{pause}
dot3ControlFunctionsSupported.10	.1.3.6.1.2.1.10.7.9.1.1.10	OctetString	{pause}
dot3ControlFunctionsSupported.11	.1.3.6.1.2.1.10.7.9.1.1.11	OctetString	{pause}
dot3ControlFunctionsSupported.12	.1.3.6.1.2.1.10.7.9.1.1.12	OctetString	{pause}
dot3ControlFunctionsSupported.13	.1.3.6.1.2.1.10.7.9.1.1.13	OctetString	{pause}
dot3ControlFunctionsSupported.14	.1.3.6.1.2.1.10.7.9.1.1.14	OctetString	{pause}
dot3ControlFunctionsSupported.15	.1.3.6.1.2.1.10.7.9.1.1.15	OctetString	{pause}
dot3ControlFunctionsSupported.16	.1.3.6.1.2.1.10.7.9.1.1.16	OctetString	{pause}
dot3ControlFunctionsSupported.17	.1.3.6.1.2.1.10.7.9.1.1.17	OctetString	{pause}
dot3ControlFunctionsSupported.18	.1.3.6.1.2.1.10.7.9.1.1.18	OctetString	{pause}
dot3ControlFunctionsSupported.19	.1.3.6.1.2.1.10.7.9.1.1.19	OctetString	{pause}
dot3ControlFunctionsSupported.20	.1.3.6.1.2.1.10.7.9.1.1.20	OctetString	{pause}
dot3ControlFunctionsSupported.21	.1.3.6.1.2.1.10.7.9.1.1.21	OctetString	{pause}
dot3ControlFunctionsSupported.22	.1.3.6.1.2.1.10.7.9.1.1.22	OctetString	{pause}
dot3ControlFunctionsSupported.23	.1.3.6.1.2.1.10.7.9.1.1.23	OctetString	{pause}
dot3ControlFunctionsSupported.24	.1.3.6.1.2.1.10.7.9.1.1.24	OctetString	{pause}
dot3ControlFunctionsSupported.25	.1.3.6.1.2.1.10.7.9.1.1.25	OctetString	{pause}
dot3ControlFunctionsSupported.26	.1.3.6.1.2.1.10.7.9.1.1.26	OctetString	{pause}
dot3ControlFunctionsSupported.27	.1.3.6.1.2.1.10.7.9.1.1.27	OctetString	{pause}
dot3ControlFunctionsSupported.28	.1.3.6.1.2.1.10.7.9.1.1.28	OctetString	{pause}
dot3ControlFunctionsSupported.29	.1.3.6.1.2.1.10.7.9.1.1.29	OctetString	{pause}

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot3ControlFunctionsSupported.30	.1.3.6.1.2.1.10.7.9.1.1.30	OctetString	{pause}
dot3ControlFunctionsSupported.31	.1.3.6.1.2.1.10.7.9.1.1.31	OctetString	{pause}
dot3ControlFunctionsSupported.32	.1.3.6.1.2.1.10.7.9.1.1.32	OctetString	{pause}
dot3ControlFunctionsSupported.33	.1.3.6.1.2.1.10.7.9.1.1.33	OctetString	{pause}
dot3ControlFunctionsSupported.34	.1.3.6.1.2.1.10.7.9.1.1.34	OctetString	{pause}
dot3ControlFunctionsSupported.35	.1.3.6.1.2.1.10.7.9.1.1.35	OctetString	{pause}
dot3ControlFunctionsSupported.36	.1.3.6.1.2.1.10.7.9.1.1.36	OctetString	{pause}
dot3ControlFunctionsSupported.37	.1.3.6.1.2.1.10.7.9.1.1.37	OctetString	{pause}
dot3ControlFunctionsSupported.38	.1.3.6.1.2.1.10.7.9.1.1.38	OctetString	{pause}
dot3ControlFunctionsSupported.39	.1.3.6.1.2.1.10.7.9.1.1.39	OctetString	{pause}
dot3ControlFunctionsSupported.40	.1.3.6.1.2.1.10.7.9.1.1.40	OctetString	{pause}
dot3ControlFunctionsSupported.41	.1.3.6.1.2.1.10.7.9.1.1.41	OctetString	{pause}
dot3ControlFunctionsSupported.42	.1.3.6.1.2.1.10.7.9.1.1.42	OctetString	{pause}
dot3ControlFunctionsSupported.43	.1.3.6.1.2.1.10.7.9.1.1.43	OctetString	{pause}
dot3ControlFunctionsSupported.44	.1.3.6.1.2.1.10.7.9.1.1.44	OctetString	{pause}
dot3ControlFunctionsSupported.45	.1.3.6.1.2.1.10.7.9.1.1.45	OctetString	{pause}
dot3ControlFunctionsSupported.46	.1.3.6.1.2.1.10.7.9.1.1.46	OctetString	{pause}
dot3ControlFunctionsSupported.47	.1.3.6.1.2.1.10.7.9.1.1.47	OctetString	{pause}
dot3ControlFunctionsSupported.48	.1.3.6.1.2.1.10.7.9.1.1.48	OctetString	{pause}
dot3ControlFunctionsSupported.49	.1.3.6.1.2.1.10.7.9.1.1.49	OctetString	{pause}
dot3ControlFunctionsSupported.50	.1.3.6.1.2.1.10.7.9.1.1.50	OctetString	{pause}
dot3ControlFunctionsSupported.51	.1.3.6.1.2.1.10.7.9.1.1.51	OctetString	{pause}
dot3ControlFunctionsSupported.52	.1.3.6.1.2.1.10.7.9.1.1.52	OctetString	{pause}
dot3ControlFunctionsSupported.53	.1.3.6.1.2.1.10.7.9.1.1.53	OctetString	{pause}
dot3ControlFunctionsSupported.54	.1.3.6.1.2.1.10.7.9.1.1.54	OctetString	{pause}

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot3ControlInUnknownOpcodes.1	.1.3.6.1.2.1.10.7.9.1.2.1	Counter32	0
dot3ControlInUnknownOpcodes.2	.1.3.6.1.2.1.10.7.9.1.2.2	Counter32	0
dot3ControlInUnknownOpcodes.3	.1.3.6.1.2.1.10.7.9.1.2.3	Counter32	0
dot3ControlInUnknownOpcodes.4	.1.3.6.1.2.1.10.7.9.1.2.4	Counter32	0
dot3ControlInUnknownOpcodes.5	.1.3.6.1.2.1.10.7.9.1.2.5	Counter32	0
dot3ControlInUnknownOpcodes.6	.1.3.6.1.2.1.10.7.9.1.2.6	Counter32	0
dot3ControlInUnknownOpcodes.7	.1.3.6.1.2.1.10.7.9.1.2.7	Counter32	0
dot3ControlInUnknownOpcodes.8	.1.3.6.1.2.1.10.7.9.1.2.8	Counter32	0
dot3ControlInUnknownOpcodes.9	.1.3.6.1.2.1.10.7.9.1.2.9	Counter32	0
dot3ControlInUnknownOpcodes.10	.1.3.6.1.2.1.10.7.9.1.2.10	Counter32	0
dot3ControlInUnknownOpcodes.11	.1.3.6.1.2.1.10.7.9.1.2.11	Counter32	0
dot3ControlInUnknownOpcodes.12	.1.3.6.1.2.1.10.7.9.1.2.12	Counter32	0
dot3ControlInUnknownOpcodes.13	.1.3.6.1.2.1.10.7.9.1.2.13	Counter32	0
dot3ControlInUnknownOpcodes.14	.1.3.6.1.2.1.10.7.9.1.2.14	Counter32	0
dot3ControlInUnknownOpcodes.15	.1.3.6.1.2.1.10.7.9.1.2.15	Counter32	0
dot3ControlInUnknownOpcodes.16	.1.3.6.1.2.1.10.7.9.1.2.16	Counter32	0
dot3ControlInUnknownOpcodes.17	.1.3.6.1.2.1.10.7.9.1.2.17	Counter32	0
dot3ControlInUnknownOpcodes.18	.1.3.6.1.2.1.10.7.9.1.2.18	Counter32	0
dot3ControlInUnknownOpcodes.19	.1.3.6.1.2.1.10.7.9.1.2.19	Counter32	0
dot3ControlInUnknownOpcodes.20	.1.3.6.1.2.1.10.7.9.1.2.20	Counter32	0
dot3ControlInUnknownOpcodes.21	.1.3.6.1.2.1.10.7.9.1.2.21	Counter32	0
dot3ControlInUnknownOpcodes.22	.1.3.6.1.2.1.10.7.9.1.2.22	Counter32	0
dot3ControlInUnknownOpcodes.23	.1.3.6.1.2.1.10.7.9.1.2.23	Counter32	0
dot3ControlInUnknownOpcodes.24	.1.3.6.1.2.1.10.7.9.1.2.24	Counter32	0
dot3ControlInUnknownOpcodes.25	.1.3.6.1.2.1.10.7.9.1.2.25	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot3ControlInUnknownOpco-des.26	.1.3.6.1.2.1.10.7.9.1.2.26	Counter32	0
dot3ControlInUnknownOpco-des.27	.1.3.6.1.2.1.10.7.9.1.2.27	Counter32	0
dot3ControlInUnknownOpco-des.28	.1.3.6.1.2.1.10.7.9.1.2.28	Counter32	0
dot3ControlInUnknownOpco-des.29	.1.3.6.1.2.1.10.7.9.1.2.29	Counter32	0
dot3ControlInUnknownOpco-des.30	.1.3.6.1.2.1.10.7.9.1.2.30	Counter32	0
dot3ControlInUnknownOpco-des.31	.1.3.6.1.2.1.10.7.9.1.2.31	Counter32	0
dot3ControlInUnknownOpco-des.32	.1.3.6.1.2.1.10.7.9.1.2.32	Counter32	0
dot3ControlInUnknownOpco-des.33	.1.3.6.1.2.1.10.7.9.1.2.33	Counter32	0
dot3ControlInUnknownOpco-des.34	.1.3.6.1.2.1.10.7.9.1.2.34	Counter32	0
dot3ControlInUnknownOpco-des.35	.1.3.6.1.2.1.10.7.9.1.2.35	Counter32	0
dot3ControlInUnknownOpco-des.36	.1.3.6.1.2.1.10.7.9.1.2.36	Counter32	0
dot3ControlInUnknownOpco-des.37	.1.3.6.1.2.1.10.7.9.1.2.37	Counter32	0
dot3ControlInUnknownOpco-des.38	.1.3.6.1.2.1.10.7.9.1.2.38	Counter32	0
dot3ControlInUnknownOpco-des.39	.1.3.6.1.2.1.10.7.9.1.2.39	Counter32	0
dot3ControlInUnknownOpco-des.40	.1.3.6.1.2.1.10.7.9.1.2.40	Counter32	0
dot3ControlInUnknownOpco-des.41	.1.3.6.1.2.1.10.7.9.1.2.41	Counter32	0
dot3ControlInUnknownOpco-des.42	.1.3.6.1.2.1.10.7.9.1.2.42	Counter32	0
dot3ControlInUnknownOpco-des.43	.1.3.6.1.2.1.10.7.9.1.2.43	Counter32	0
dot3ControlInUnknownOpco-des.44	.1.3.6.1.2.1.10.7.9.1.2.44	Counter32	0
dot3ControlInUnknownOpco-des.45	.1.3.6.1.2.1.10.7.9.1.2.45	Counter32	0
dot3ControlInUnknownOpco-des.46	.1.3.6.1.2.1.10.7.9.1.2.46	Counter32	0
dot3ControlInUnknownOpco-des.47	.1.3.6.1.2.1.10.7.9.1.2.47	Counter32	0
dot3ControlInUnknownOpco-des.48	.1.3.6.1.2.1.10.7.9.1.2.48	Counter32	0
dot3ControlInUnknownOpco-des.49	.1.3.6.1.2.1.10.7.9.1.2.49	Counter32	0
dot3ControlInUnknownOpco-des.50	.1.3.6.1.2.1.10.7.9.1.2.50	Counter32	0

Name	OID	Value Type	Value Example
dot3ControlInUnknownOpco-des.51	.1.3.6.1.2.1.10.7.9.1.2.51	Counter32	0
dot3ControlInUnknownOpco-des.52	.1.3.6.1.2.1.10.7.9.1.2.52	Counter32	0
dot3ControlInUnknownOpco-des.53	.1.3.6.1.2.1.10.7.9.1.2.53	Counter32	0
dot3ControlInUnknownOpco-des.54	.1.3.6.1.2.1.10.7.9.1.2.54	Counter32	0
dot3PauseAdminMode.1	.1.3.6.1.2.1.10.7.10.1.1.1	Integer	disabled (1)
dot3PauseAdminMode.2	.1.3.6.1.2.1.10.7.10.1.1.2	Integer	disabled (1)
dot3PauseAdminMode.3	.1.3.6.1.2.1.10.7.10.1.1.3	Integer	disabled (1)
dot3PauseAdminMode.4	.1.3.6.1.2.1.10.7.10.1.1.4	Integer	disabled (1)
dot3PauseAdminMode.5	.1.3.6.1.2.1.10.7.10.1.1.5	Integer	disabled (1)
dot3PauseAdminMode.6	.1.3.6.1.2.1.10.7.10.1.1.6	Integer	disabled (1)
dot3PauseAdminMode.7	.1.3.6.1.2.1.10.7.10.1.1.7	Integer	disabled (1)
dot3PauseAdminMode.8	.1.3.6.1.2.1.10.7.10.1.1.8	Integer	disabled (1)
dot3PauseAdminMode.9	.1.3.6.1.2.1.10.7.10.1.1.9	Integer	disabled (1)
dot3PauseAdminMode.10	.1.3.6.1.2.1.10.7.10.1.1.10	Integer	disabled (1)
dot3PauseAdminMode.11	.1.3.6.1.2.1.10.7.10.1.1.11	Integer	disabled (1)
dot3PauseAdminMode.12	.1.3.6.1.2.1.10.7.10.1.1.12	Integer	disabled (1)
dot3PauseAdminMode.13	.1.3.6.1.2.1.10.7.10.1.1.13	Integer	disabled (1)
dot3PauseAdminMode.14	.1.3.6.1.2.1.10.7.10.1.1.14	Integer	disabled (1)
dot3PauseAdminMode.15	.1.3.6.1.2.1.10.7.10.1.1.15	Integer	disabled (1)
dot3PauseAdminMode.16	.1.3.6.1.2.1.10.7.10.1.1.16	Integer	disabled (1)
dot3PauseAdminMode.17	.1.3.6.1.2.1.10.7.10.1.1.17	Integer	disabled (1)
dot3PauseAdminMode.18	.1.3.6.1.2.1.10.7.10.1.1.18	Integer	disabled (1)
dot3PauseAdminMode.19	.1.3.6.1.2.1.10.7.10.1.1.19	Integer	disabled (1)
dot3PauseAdminMode.20	.1.3.6.1.2.1.10.7.10.1.1.20	Integer	disabled (1)
dot3PauseAdminMode.21	.1.3.6.1.2.1.10.7.10.1.1.21	Integer	disabled (1)
dot3PauseAdminMode.22	.1.3.6.1.2.1.10.7.10.1.1.22	Integer	disabled (1)
dot3PauseAdminMode.23	.1.3.6.1.2.1.10.7.10.1.1.23	Integer	disabled (1)
dot3PauseAdminMode.24	.1.3.6.1.2.1.10.7.10.1.1.24	Integer	disabled (1)
dot3PauseAdminMode.25	.1.3.6.1.2.1.10.7.10.1.1.25	Integer	disabled (1)
dot3PauseAdminMode.26	.1.3.6.1.2.1.10.7.10.1.1.26	Integer	disabled (1)
dot3PauseAdminMode.27	.1.3.6.1.2.1.10.7.10.1.1.27	Integer	disabled (1)
dot3PauseAdminMode.28	.1.3.6.1.2.1.10.7.10.1.1.28	Integer	disabled (1)
dot3PauseAdminMode.29	.1.3.6.1.2.1.10.7.10.1.1.29	Integer	disabled (1)
dot3PauseAdminMode.30	.1.3.6.1.2.1.10.7.10.1.1.30	Integer	disabled (1)
dot3PauseAdminMode.31	.1.3.6.1.2.1.10.7.10.1.1.31	Integer	disabled (1)
dot3PauseAdminMode.32	.1.3.6.1.2.1.10.7.10.1.1.32	Integer	disabled (1)
dot3PauseAdminMode.33	.1.3.6.1.2.1.10.7.10.1.1.33	Integer	disabled (1)
dot3PauseAdminMode.34	.1.3.6.1.2.1.10.7.10.1.1.34	Integer	disabled (1)
dot3PauseAdminMode.35	.1.3.6.1.2.1.10.7.10.1.1.35	Integer	disabled (1)
dot3PauseAdminMode.36	.1.3.6.1.2.1.10.7.10.1.1.36	Integer	disabled (1)

Name	OID	Value Type	Value Example
dot3PauseAdminMode.37	.1.3.6.1.2.1.10.7.10.1.1.37	Integer	disabled (1)
dot3PauseAdminMode.38	.1.3.6.1.2.1.10.7.10.1.1.38	Integer	disabled (1)
dot3PauseAdminMode.39	.1.3.6.1.2.1.10.7.10.1.1.39	Integer	disabled (1)
dot3PauseAdminMode.40	.1.3.6.1.2.1.10.7.10.1.1.40	Integer	disabled (1)
dot3PauseAdminMode.41	.1.3.6.1.2.1.10.7.10.1.1.41	Integer	disabled (1)
dot3PauseAdminMode.42	.1.3.6.1.2.1.10.7.10.1.1.42	Integer	disabled (1)
dot3PauseAdminMode.43	.1.3.6.1.2.1.10.7.10.1.1.43	Integer	disabled (1)
dot3PauseAdminMode.44	.1.3.6.1.2.1.10.7.10.1.1.44	Integer	disabled (1)
dot3PauseAdminMode.45	.1.3.6.1.2.1.10.7.10.1.1.45	Integer	disabled (1)
dot3PauseAdminMode.46	.1.3.6.1.2.1.10.7.10.1.1.46	Integer	disabled (1)
dot3PauseAdminMode.47	.1.3.6.1.2.1.10.7.10.1.1.47	Integer	disabled (1)
dot3PauseAdminMode.48	.1.3.6.1.2.1.10.7.10.1.1.48	Integer	disabled (1)
dot3PauseAdminMode.49	.1.3.6.1.2.1.10.7.10.1.1.49	Integer	disabled (1)
dot3PauseAdminMode.50	.1.3.6.1.2.1.10.7.10.1.1.50	Integer	disabled (1)
dot3PauseAdminMode.51	.1.3.6.1.2.1.10.7.10.1.1.51	Integer	disabled (1)
dot3PauseAdminMode.52	.1.3.6.1.2.1.10.7.10.1.1.52	Integer	disabled (1)
dot3PauseAdminMode.53	.1.3.6.1.2.1.10.7.10.1.1.53	Integer	disabled (1)
dot3PauseAdminMode.54	.1.3.6.1.2.1.10.7.10.1.1.54	Integer	disabled (1)
dot3PauseOperMode.1	.1.3.6.1.2.1.10.7.10.1.2.1	Integer	disabled (1)
dot3PauseOperMode.2	.1.3.6.1.2.1.10.7.10.1.2.2	Integer	disabled (1)
dot3PauseOperMode.3	.1.3.6.1.2.1.10.7.10.1.2.3	Integer	disabled (1)
dot3PauseOperMode.4	.1.3.6.1.2.1.10.7.10.1.2.4	Integer	disabled (1)
dot3PauseOperMode.5	.1.3.6.1.2.1.10.7.10.1.2.5	Integer	disabled (1)
dot3PauseOperMode.6	.1.3.6.1.2.1.10.7.10.1.2.6	Integer	disabled (1)
dot3PauseOperMode.7	.1.3.6.1.2.1.10.7.10.1.2.7	Integer	disabled (1)
dot3PauseOperMode.8	.1.3.6.1.2.1.10.7.10.1.2.8	Integer	disabled (1)
dot3PauseOperMode.9	.1.3.6.1.2.1.10.7.10.1.2.9	Integer	disabled (1)
dot3PauseOperMode.10	.1.3.6.1.2.1.10.7.10.1.2.10	Integer	disabled (1)
dot3PauseOperMode.11	.1.3.6.1.2.1.10.7.10.1.2.11	Integer	disabled (1)
dot3PauseOperMode.12	.1.3.6.1.2.1.10.7.10.1.2.12	Integer	disabled (1)
dot3PauseOperMode.13	.1.3.6.1.2.1.10.7.10.1.2.13	Integer	disabled (1)
dot3PauseOperMode.14	.1.3.6.1.2.1.10.7.10.1.2.14	Integer	disabled (1)
dot3PauseOperMode.15	.1.3.6.1.2.1.10.7.10.1.2.15	Integer	disabled (1)
dot3PauseOperMode.16	.1.3.6.1.2.1.10.7.10.1.2.16	Integer	disabled (1)
dot3PauseOperMode.17	.1.3.6.1.2.1.10.7.10.1.2.17	Integer	disabled (1)
dot3PauseOperMode.18	.1.3.6.1.2.1.10.7.10.1.2.18	Integer	disabled (1)
dot3PauseOperMode.19	.1.3.6.1.2.1.10.7.10.1.2.19	Integer	disabled (1)
dot3PauseOperMode.20	.1.3.6.1.2.1.10.7.10.1.2.20	Integer	disabled (1)
dot3PauseOperMode.21	.1.3.6.1.2.1.10.7.10.1.2.21	Integer	disabled (1)
dot3PauseOperMode.22	.1.3.6.1.2.1.10.7.10.1.2.22	Integer	disabled (1)
dot3PauseOperMode.23	.1.3.6.1.2.1.10.7.10.1.2.23	Integer	disabled (1)
dot3PauseOperMode.24	.1.3.6.1.2.1.10.7.10.1.2.24	Integer	disabled (1)
dot3PauseOperMode.25	.1.3.6.1.2.1.10.7.10.1.2.25	Integer	disabled (1)



Name	OID	Value Type	Value Example
dot3PauseOperMode.26	.1.3.6.1.2.1.10.7.10.1.2.26	Integer	disabled (1)
dot3PauseOperMode.27	.1.3.6.1.2.1.10.7.10.1.2.27	Integer	disabled (1)
dot3PauseOperMode.28	.1.3.6.1.2.1.10.7.10.1.2.28	Integer	disabled (1)
dot3PauseOperMode.29	.1.3.6.1.2.1.10.7.10.1.2.29	Integer	disabled (1)
dot3PauseOperMode.30	.1.3.6.1.2.1.10.7.10.1.2.30	Integer	disabled (1)
dot3PauseOperMode.31	.1.3.6.1.2.1.10.7.10.1.2.31	Integer	disabled (1)
dot3PauseOperMode.32	.1.3.6.1.2.1.10.7.10.1.2.32	Integer	disabled (1)
dot3PauseOperMode.33	.1.3.6.1.2.1.10.7.10.1.2.33	Integer	disabled (1)
dot3PauseOperMode.34	.1.3.6.1.2.1.10.7.10.1.2.34	Integer	disabled (1)
dot3PauseOperMode.35	.1.3.6.1.2.1.10.7.10.1.2.35	Integer	disabled (1)
dot3PauseOperMode.36	.1.3.6.1.2.1.10.7.10.1.2.36	Integer	disabled (1)
dot3PauseOperMode.37	.1.3.6.1.2.1.10.7.10.1.2.37	Integer	disabled (1)
dot3PauseOperMode.38	.1.3.6.1.2.1.10.7.10.1.2.38	Integer	disabled (1)
dot3PauseOperMode.39	.1.3.6.1.2.1.10.7.10.1.2.39	Integer	disabled (1)
dot3PauseOperMode.40	.1.3.6.1.2.1.10.7.10.1.2.40	Integer	disabled (1)
dot3PauseOperMode.41	.1.3.6.1.2.1.10.7.10.1.2.41	Integer	disabled (1)
dot3PauseOperMode.42	.1.3.6.1.2.1.10.7.10.1.2.42	Integer	disabled (1)
dot3PauseOperMode.43	.1.3.6.1.2.1.10.7.10.1.2.43	Integer	disabled (1)
dot3PauseOperMode.44	.1.3.6.1.2.1.10.7.10.1.2.44	Integer	disabled (1)
dot3PauseOperMode.45	.1.3.6.1.2.1.10.7.10.1.2.45	Integer	disabled (1)
dot3PauseOperMode.46	.1.3.6.1.2.1.10.7.10.1.2.46	Integer	disabled (1)
dot3PauseOperMode.47	.1.3.6.1.2.1.10.7.10.1.2.47	Integer	disabled (1)
dot3PauseOperMode.48	.1.3.6.1.2.1.10.7.10.1.2.48	Integer	disabled (1)
dot3PauseOperMode.49	.1.3.6.1.2.1.10.7.10.1.2.49	Integer	disabled (1)
dot3PauseOperMode.50	.1.3.6.1.2.1.10.7.10.1.2.50	Integer	disabled (1)
dot3PauseOperMode.51	.1.3.6.1.2.1.10.7.10.1.2.51	Integer	disabled (1)
dot3PauseOperMode.52	.1.3.6.1.2.1.10.7.10.1.2.52	Integer	disabled (1)
dot3PauseOperMode.53	.1.3.6.1.2.1.10.7.10.1.2.53	Integer	disabled (1)
dot3PauseOperMode.54	.1.3.6.1.2.1.10.7.10.1.2.54	Integer	disabled (1)
dot3InPauseFrames.1	.1.3.6.1.2.1.10.7.10.1.3.1	Counter32	0
dot3InPauseFrames.2	.1.3.6.1.2.1.10.7.10.1.3.2	Counter32	0
dot3InPauseFrames.3	.1.3.6.1.2.1.10.7.10.1.3.3	Counter32	0
dot3InPauseFrames.4	.1.3.6.1.2.1.10.7.10.1.3.4	Counter32	0
dot3InPauseFrames.5	.1.3.6.1.2.1.10.7.10.1.3.5	Counter32	0
dot3InPauseFrames.6	.1.3.6.1.2.1.10.7.10.1.3.6	Counter32	0
dot3InPauseFrames.7	.1.3.6.1.2.1.10.7.10.1.3.7	Counter32	0
dot3InPauseFrames.8	.1.3.6.1.2.1.10.7.10.1.3.8	Counter32	0
dot3InPauseFrames.9	.1.3.6.1.2.1.10.7.10.1.3.9	Counter32	0
dot3InPauseFrames.10	.1.3.6.1.2.1.10.7.10.1.3.10	Counter32	0
dot3InPauseFrames.11	.1.3.6.1.2.1.10.7.10.1.3.11	Counter32	0
dot3InPauseFrames.12	.1.3.6.1.2.1.10.7.10.1.3.12	Counter32	0
dot3InPauseFrames.13	.1.3.6.1.2.1.10.7.10.1.3.13	Counter32	0
dot3InPauseFrames.14	.1.3.6.1.2.1.10.7.10.1.3.14	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot3InPauseFrames.15	.1.3.6.1.2.1.10.7.10.1.3.15	Counter32	0
dot3InPauseFrames.16	.1.3.6.1.2.1.10.7.10.1.3.16	Counter32	0
dot3InPauseFrames.17	.1.3.6.1.2.1.10.7.10.1.3.17	Counter32	0
dot3InPauseFrames.18	.1.3.6.1.2.1.10.7.10.1.3.18	Counter32	0
dot3InPauseFrames.19	.1.3.6.1.2.1.10.7.10.1.3.19	Counter32	0
dot3InPauseFrames.20	.1.3.6.1.2.1.10.7.10.1.3.20	Counter32	0
dot3InPauseFrames.21	.1.3.6.1.2.1.10.7.10.1.3.21	Counter32	0
dot3InPauseFrames.22	.1.3.6.1.2.1.10.7.10.1.3.22	Counter32	0
dot3InPauseFrames.23	.1.3.6.1.2.1.10.7.10.1.3.23	Counter32	0
dot3InPauseFrames.24	.1.3.6.1.2.1.10.7.10.1.3.24	Counter32	0
dot3InPauseFrames.25	.1.3.6.1.2.1.10.7.10.1.3.25	Counter32	0
dot3InPauseFrames.26	.1.3.6.1.2.1.10.7.10.1.3.26	Counter32	0
dot3InPauseFrames.27	.1.3.6.1.2.1.10.7.10.1.3.27	Counter32	0
dot3InPauseFrames.28	.1.3.6.1.2.1.10.7.10.1.3.28	Counter32	0
dot3InPauseFrames.29	.1.3.6.1.2.1.10.7.10.1.3.29	Counter32	0
dot3InPauseFrames.30	.1.3.6.1.2.1.10.7.10.1.3.30	Counter32	0
dot3InPauseFrames.31	.1.3.6.1.2.1.10.7.10.1.3.31	Counter32	0
dot3InPauseFrames.32	.1.3.6.1.2.1.10.7.10.1.3.32	Counter32	0
dot3InPauseFrames.33	.1.3.6.1.2.1.10.7.10.1.3.33	Counter32	0
dot3InPauseFrames.34	.1.3.6.1.2.1.10.7.10.1.3.34	Counter32	0
dot3InPauseFrames.35	.1.3.6.1.2.1.10.7.10.1.3.35	Counter32	0
dot3InPauseFrames.36	.1.3.6.1.2.1.10.7.10.1.3.36	Counter32	0
dot3InPauseFrames.37	.1.3.6.1.2.1.10.7.10.1.3.37	Counter32	0
dot3InPauseFrames.38	.1.3.6.1.2.1.10.7.10.1.3.38	Counter32	0
dot3InPauseFrames.39	.1.3.6.1.2.1.10.7.10.1.3.39	Counter32	0
dot3InPauseFrames.40	.1.3.6.1.2.1.10.7.10.1.3.40	Counter32	0
dot3InPauseFrames.41	.1.3.6.1.2.1.10.7.10.1.3.41	Counter32	0
dot3InPauseFrames.42	.1.3.6.1.2.1.10.7.10.1.3.42	Counter32	0
dot3InPauseFrames.43	.1.3.6.1.2.1.10.7.10.1.3.43	Counter32	0
dot3InPauseFrames.44	.1.3.6.1.2.1.10.7.10.1.3.44	Counter32	0
dot3InPauseFrames.45	.1.3.6.1.2.1.10.7.10.1.3.45	Counter32	0
dot3InPauseFrames.46	.1.3.6.1.2.1.10.7.10.1.3.46	Counter32	0
dot3InPauseFrames.47	.1.3.6.1.2.1.10.7.10.1.3.47	Counter32	0
dot3InPauseFrames.48	.1.3.6.1.2.1.10.7.10.1.3.48	Counter32	0
dot3InPauseFrames.49	.1.3.6.1.2.1.10.7.10.1.3.49	Counter32	0
dot3InPauseFrames.50	.1.3.6.1.2.1.10.7.10.1.3.50	Counter32	0
dot3InPauseFrames.51	.1.3.6.1.2.1.10.7.10.1.3.51	Counter32	0
dot3InPauseFrames.52	.1.3.6.1.2.1.10.7.10.1.3.52	Counter32	0
dot3InPauseFrames.53	.1.3.6.1.2.1.10.7.10.1.3.53	Counter32	0
dot3InPauseFrames.54	.1.3.6.1.2.1.10.7.10.1.3.54	Counter32	0
dot3OutPauseFrames.1	.1.3.6.1.2.1.10.7.10.1.4.1	Counter32	0
dot3OutPauseFrames.2	.1.3.6.1.2.1.10.7.10.1.4.2	Counter32	0
dot3OutPauseFrames.3	.1.3.6.1.2.1.10.7.10.1.4.3	Counter32	0

Name	OID	Value Type	Value Example
dot3OutPauseFrames.4	.1.3.6.1.2.1.10.7.10.1.4.4	Counter32	0
dot3OutPauseFrames.5	.1.3.6.1.2.1.10.7.10.1.4.5	Counter32	0
dot3OutPauseFrames.6	.1.3.6.1.2.1.10.7.10.1.4.6	Counter32	0
dot3OutPauseFrames.7	.1.3.6.1.2.1.10.7.10.1.4.7	Counter32	0
dot3OutPauseFrames.8	.1.3.6.1.2.1.10.7.10.1.4.8	Counter32	0
dot3OutPauseFrames.9	.1.3.6.1.2.1.10.7.10.1.4.9	Counter32	0
dot3OutPauseFrames.10	.1.3.6.1.2.1.10.7.10.1.4.10	Counter32	0
dot3OutPauseFrames.11	.1.3.6.1.2.1.10.7.10.1.4.11	Counter32	0
dot3OutPauseFrames.12	.1.3.6.1.2.1.10.7.10.1.4.12	Counter32	0
dot3OutPauseFrames.13	.1.3.6.1.2.1.10.7.10.1.4.13	Counter32	0
dot3OutPauseFrames.14	.1.3.6.1.2.1.10.7.10.1.4.14	Counter32	0
dot3OutPauseFrames.15	.1.3.6.1.2.1.10.7.10.1.4.15	Counter32	0
dot3OutPauseFrames.16	.1.3.6.1.2.1.10.7.10.1.4.16	Counter32	0
dot3OutPauseFrames.17	.1.3.6.1.2.1.10.7.10.1.4.17	Counter32	0
dot3OutPauseFrames.18	.1.3.6.1.2.1.10.7.10.1.4.18	Counter32	0
dot3OutPauseFrames.19	.1.3.6.1.2.1.10.7.10.1.4.19	Counter32	0
dot3OutPauseFrames.20	.1.3.6.1.2.1.10.7.10.1.4.20	Counter32	0
dot3OutPauseFrames.21	.1.3.6.1.2.1.10.7.10.1.4.21	Counter32	0
dot3OutPauseFrames.22	.1.3.6.1.2.1.10.7.10.1.4.22	Counter32	0
dot3OutPauseFrames.23	.1.3.6.1.2.1.10.7.10.1.4.23	Counter32	0
dot3OutPauseFrames.24	.1.3.6.1.2.1.10.7.10.1.4.24	Counter32	0
dot3OutPauseFrames.25	.1.3.6.1.2.1.10.7.10.1.4.25	Counter32	0
dot3OutPauseFrames.26	.1.3.6.1.2.1.10.7.10.1.4.26	Counter32	0
dot3OutPauseFrames.27	.1.3.6.1.2.1.10.7.10.1.4.27	Counter32	0
dot3OutPauseFrames.28	.1.3.6.1.2.1.10.7.10.1.4.28	Counter32	0
dot3OutPauseFrames.29	.1.3.6.1.2.1.10.7.10.1.4.29	Counter32	0
dot3OutPauseFrames.30	.1.3.6.1.2.1.10.7.10.1.4.30	Counter32	0
dot3OutPauseFrames.31	.1.3.6.1.2.1.10.7.10.1.4.31	Counter32	0
dot3OutPauseFrames.32	.1.3.6.1.2.1.10.7.10.1.4.32	Counter32	0
dot3OutPauseFrames.33	.1.3.6.1.2.1.10.7.10.1.4.33	Counter32	0
dot3OutPauseFrames.34	.1.3.6.1.2.1.10.7.10.1.4.34	Counter32	0
dot3OutPauseFrames.35	.1.3.6.1.2.1.10.7.10.1.4.35	Counter32	0
dot3OutPauseFrames.36	.1.3.6.1.2.1.10.7.10.1.4.36	Counter32	0
dot3OutPauseFrames.37	.1.3.6.1.2.1.10.7.10.1.4.37	Counter32	0
dot3OutPauseFrames.38	.1.3.6.1.2.1.10.7.10.1.4.38	Counter32	0
dot3OutPauseFrames.39	.1.3.6.1.2.1.10.7.10.1.4.39	Counter32	0
dot3OutPauseFrames.40	.1.3.6.1.2.1.10.7.10.1.4.40	Counter32	0
dot3OutPauseFrames.41	.1.3.6.1.2.1.10.7.10.1.4.41	Counter32	0
dot3OutPauseFrames.42	.1.3.6.1.2.1.10.7.10.1.4.42	Counter32	0
dot3OutPauseFrames.43	.1.3.6.1.2.1.10.7.10.1.4.43	Counter32	0
dot3OutPauseFrames.44	.1.3.6.1.2.1.10.7.10.1.4.44	Counter32	0
dot3OutPauseFrames.45	.1.3.6.1.2.1.10.7.10.1.4.45	Counter32	0
dot3OutPauseFrames.46	.1.3.6.1.2.1.10.7.10.1.4.46	Counter32	0

Name	OID	Value Type	Value Example
dot3OutPauseFrames.47	.1.3.6.1.2.1.10.7.10.1.4.47	Counter32	0
dot3OutPauseFrames.48	.1.3.6.1.2.1.10.7.10.1.4.48	Counter32	0
dot3OutPauseFrames.49	.1.3.6.1.2.1.10.7.10.1.4.49	Counter32	0
dot3OutPauseFrames.50	.1.3.6.1.2.1.10.7.10.1.4.50	Counter32	0
dot3OutPauseFrames.51	.1.3.6.1.2.1.10.7.10.1.4.51	Counter32	0
dot3OutPauseFrames.52	.1.3.6.1.2.1.10.7.10.1.4.52	Counter32	0
dot3OutPauseFrames.53	.1.3.6.1.2.1.10.7.10.1.4.53	Counter32	0
dot3OutPauseFrames.54	.1.3.6.1.2.1.10.7.10.1.4.54	Counter32	0
snmpInPkts.0	.1.3.6.1.2.1.11.1.0	Counter32	7250
snmpOutPkts.0	.1.3.6.1.2.1.11.2.0	Counter32	7356
snmpInBadVersions.0	.1.3.6.1.2.1.11.3.0	Counter32	0
snmpInBadCommunityNames.0	.1.3.6.1.2.1.11.4.0	Counter32	0
snmpInBadCommunityUses.0	.1.3.6.1.2.1.11.5.0	Counter32	0
snmpInASNParseErrs.0	.1.3.6.1.2.1.11.6.0	Counter32	0
snmpInTooBigs.0	.1.3.6.1.2.1.11.8.0	Counter32	0
snmpInNoSuchNames.0	.1.3.6.1.2.1.11.9.0	Counter32	0
snmpInBadValues.0	.1.3.6.1.2.1.11.10.0	Counter32	0
snmpInReadOnlys.0	.1.3.6.1.2.1.11.11.0	Counter32	0
snmpInGenErrs.0	.1.3.6.1.2.1.11.12.0	Counter32	0
snmpInTotalReqVars.0	.1.3.6.1.2.1.11.13.0	Counter32	9520
snmpInTotalSetVars.0	.1.3.6.1.2.1.11.14.0	Counter32	0
snmpInGetRequests.0	.1.3.6.1.2.1.11.15.0	Counter32	16
snmpInGetNexts.0	.1.3.6.1.2.1.11.16.0	Counter32	7221
snmpInSetRequests.0	.1.3.6.1.2.1.11.17.0	Counter32	0
snmpInGetResponses.0	.1.3.6.1.2.1.11.18.0	Counter32	0
snmpInTraps.0	.1.3.6.1.2.1.11.19.0	Counter32	0
snmpOutTooBigs.0	.1.3.6.1.2.1.11.20.0	Counter32	0
snmpOutNoSuchNames.0	.1.3.6.1.2.1.11.21.0	Counter32	0
snmpOutBadValues.0	.1.3.6.1.2.1.11.22.0	Counter32	0
snmpOutGenErrs.0	.1.3.6.1.2.1.11.24.0	Counter32	0
snmpOutGetRequests.0	.1.3.6.1.2.1.11.25.0	Counter32	0
snmpOutGetNexts.0	.1.3.6.1.2.1.11.26.0	Counter32	0
snmpOutSetRequests.0	.1.3.6.1.2.1.11.27.0	Counter32	0
snmpOutGetResponses.0	.1.3.6.1.2.1.11.28.0	Counter32	7274
snmpOutTraps.0	.1.3.6.1.2.1.11.29.0	Counter32	106
snmpEnableAuthenTraps.0	.1.3.6.1.2.1.11.30.0	Integer	enabled (1)
snmpSilentDrops.0	.1.3.6.1.2.1.11.31.0	Counter32	0
snmpProxyDrops.0	.1.3.6.1.2.1.11.32.0	Counter32	0
dot1dBaseBridgeAddress.0	.1.3.6.1.2.1.17.1.1.0	OctetString	14-84-77-95-1D-B0
dot1dBaseNumPorts.0	.1.3.6.1.2.1.17.1.2.0	Integer	54
dot1dBaseType.0	.1.3.6.1.2.1.17.1.3.0	Integer	transparent-only (2)
dot1dBasePort.1	.1.3.6.1.2.1.17.1.4.1.1	Integer	1

Name	OID	Value Type	Value Example
dot1dBasePort.2	.1.3.6.1.2.1.17.1.4.1.1.2	Integer	2
dot1dBasePort.3	.1.3.6.1.2.1.17.1.4.1.1.3	Integer	3
dot1dBasePort.4	.1.3.6.1.2.1.17.1.4.1.1.4	Integer	4
dot1dBasePort.5	.1.3.6.1.2.1.17.1.4.1.1.5	Integer	5
dot1dBasePort.6	.1.3.6.1.2.1.17.1.4.1.1.6	Integer	6
dot1dBasePort.7	.1.3.6.1.2.1.17.1.4.1.1.7	Integer	7
dot1dBasePort.8	.1.3.6.1.2.1.17.1.4.1.1.8	Integer	8
dot1dBasePort.9	.1.3.6.1.2.1.17.1.4.1.1.9	Integer	9
dot1dBasePort.10	.1.3.6.1.2.1.17.1.4.1.1.10	Integer	10
dot1dBasePort.11	.1.3.6.1.2.1.17.1.4.1.1.11	Integer	11
dot1dBasePort.12	.1.3.6.1.2.1.17.1.4.1.1.12	Integer	12
dot1dBasePort.13	.1.3.6.1.2.1.17.1.4.1.1.13	Integer	13
dot1dBasePort.14	.1.3.6.1.2.1.17.1.4.1.1.14	Integer	14
dot1dBasePort.15	.1.3.6.1.2.1.17.1.4.1.1.15	Integer	15
dot1dBasePort.16	.1.3.6.1.2.1.17.1.4.1.1.16	Integer	16
dot1dBasePort.17	.1.3.6.1.2.1.17.1.4.1.1.17	Integer	17
dot1dBasePort.18	.1.3.6.1.2.1.17.1.4.1.1.18	Integer	18
dot1dBasePort.19	.1.3.6.1.2.1.17.1.4.1.1.19	Integer	19
dot1dBasePort.20	.1.3.6.1.2.1.17.1.4.1.1.20	Integer	20
dot1dBasePort.21	.1.3.6.1.2.1.17.1.4.1.1.21	Integer	21
dot1dBasePort.22	.1.3.6.1.2.1.17.1.4.1.1.22	Integer	22
dot1dBasePort.23	.1.3.6.1.2.1.17.1.4.1.1.23	Integer	23
dot1dBasePort.24	.1.3.6.1.2.1.17.1.4.1.1.24	Integer	24
dot1dBasePort.25	.1.3.6.1.2.1.17.1.4.1.1.25	Integer	25
dot1dBasePort.26	.1.3.6.1.2.1.17.1.4.1.1.26	Integer	26
dot1dBasePort.27	.1.3.6.1.2.1.17.1.4.1.1.27	Integer	27
dot1dBasePort.28	.1.3.6.1.2.1.17.1.4.1.1.28	Integer	28
dot1dBasePort.29	.1.3.6.1.2.1.17.1.4.1.1.29	Integer	29
dot1dBasePort.30	.1.3.6.1.2.1.17.1.4.1.1.30	Integer	30
dot1dBasePort.31	.1.3.6.1.2.1.17.1.4.1.1.31	Integer	31
dot1dBasePort.32	.1.3.6.1.2.1.17.1.4.1.1.32	Integer	32
dot1dBasePort.33	.1.3.6.1.2.1.17.1.4.1.1.33	Integer	33
dot1dBasePort.34	.1.3.6.1.2.1.17.1.4.1.1.34	Integer	34
dot1dBasePort.35	.1.3.6.1.2.1.17.1.4.1.1.35	Integer	35
dot1dBasePort.36	.1.3.6.1.2.1.17.1.4.1.1.36	Integer	36
dot1dBasePort.37	.1.3.6.1.2.1.17.1.4.1.1.37	Integer	37
dot1dBasePort.38	.1.3.6.1.2.1.17.1.4.1.1.38	Integer	38
dot1dBasePort.39	.1.3.6.1.2.1.17.1.4.1.1.39	Integer	39
dot1dBasePort.40	.1.3.6.1.2.1.17.1.4.1.1.40	Integer	40
dot1dBasePort.41	.1.3.6.1.2.1.17.1.4.1.1.41	Integer	41
dot1dBasePort.42	.1.3.6.1.2.1.17.1.4.1.1.42	Integer	42
dot1dBasePort.43	.1.3.6.1.2.1.17.1.4.1.1.43	Integer	43
dot1dBasePort.44	.1.3.6.1.2.1.17.1.4.1.1.44	Integer	44

Name	OID	Value Type	Value Example
dot1dBasePort.45	.1.3.6.1.2.1.17.1.4.1.1.45	Integer	45
dot1dBasePort.46	.1.3.6.1.2.1.17.1.4.1.1.46	Integer	46
dot1dBasePort.47	.1.3.6.1.2.1.17.1.4.1.1.47	Integer	47
dot1dBasePort.48	.1.3.6.1.2.1.17.1.4.1.1.48	Integer	48
dot1dBasePort.49	.1.3.6.1.2.1.17.1.4.1.1.49	Integer	49
dot1dBasePort.50	.1.3.6.1.2.1.17.1.4.1.1.50	Integer	50
dot1dBasePort.51	.1.3.6.1.2.1.17.1.4.1.1.51	Integer	51
dot1dBasePort.52	.1.3.6.1.2.1.17.1.4.1.1.52	Integer	52
dot1dBasePort.53	.1.3.6.1.2.1.17.1.4.1.1.53	Integer	53
dot1dBasePort.54	.1.3.6.1.2.1.17.1.4.1.1.54	Integer	54
dot1dBasePortIfIndex.1	.1.3.6.1.2.1.17.1.4.1.2.1	Integer	1
dot1dBasePortIfIndex.2	.1.3.6.1.2.1.17.1.4.1.2.2	Integer	2
dot1dBasePortIfIndex.3	.1.3.6.1.2.1.17.1.4.1.2.3	Integer	3
dot1dBasePortIfIndex.4	.1.3.6.1.2.1.17.1.4.1.2.4	Integer	4
dot1dBasePortIfIndex.5	.1.3.6.1.2.1.17.1.4.1.2.5	Integer	5
dot1dBasePortIfIndex.6	.1.3.6.1.2.1.17.1.4.1.2.6	Integer	6
dot1dBasePortIfIndex.7	.1.3.6.1.2.1.17.1.4.1.2.7	Integer	7
dot1dBasePortIfIndex.8	.1.3.6.1.2.1.17.1.4.1.2.8	Integer	8
dot1dBasePortIfIndex.9	.1.3.6.1.2.1.17.1.4.1.2.9	Integer	9
dot1dBasePortIfIndex.10	.1.3.6.1.2.1.17.1.4.1.2.10	Integer	10
dot1dBasePortIfIndex.11	.1.3.6.1.2.1.17.1.4.1.2.11	Integer	11
dot1dBasePortIfIndex.12	.1.3.6.1.2.1.17.1.4.1.2.12	Integer	12
dot1dBasePortIfIndex.13	.1.3.6.1.2.1.17.1.4.1.2.13	Integer	13
dot1dBasePortIfIndex.14	.1.3.6.1.2.1.17.1.4.1.2.14	Integer	14
dot1dBasePortIfIndex.15	.1.3.6.1.2.1.17.1.4.1.2.15	Integer	15
dot1dBasePortIfIndex.16	.1.3.6.1.2.1.17.1.4.1.2.16	Integer	16
dot1dBasePortIfIndex.17	.1.3.6.1.2.1.17.1.4.1.2.17	Integer	17
dot1dBasePortIfIndex.18	.1.3.6.1.2.1.17.1.4.1.2.18	Integer	18
dot1dBasePortIfIndex.19	.1.3.6.1.2.1.17.1.4.1.2.19	Integer	19
dot1dBasePortIfIndex.20	.1.3.6.1.2.1.17.1.4.1.2.20	Integer	20
dot1dBasePortIfIndex.21	.1.3.6.1.2.1.17.1.4.1.2.21	Integer	21
dot1dBasePortIfIndex.22	.1.3.6.1.2.1.17.1.4.1.2.22	Integer	22
dot1dBasePortIfIndex.23	.1.3.6.1.2.1.17.1.4.1.2.23	Integer	23
dot1dBasePortIfIndex.24	.1.3.6.1.2.1.17.1.4.1.2.24	Integer	24
dot1dBasePortIfIndex.25	.1.3.6.1.2.1.17.1.4.1.2.25	Integer	25
dot1dBasePortIfIndex.26	.1.3.6.1.2.1.17.1.4.1.2.26	Integer	26
dot1dBasePortIfIndex.27	.1.3.6.1.2.1.17.1.4.1.2.27	Integer	27
dot1dBasePortIfIndex.28	.1.3.6.1.2.1.17.1.4.1.2.28	Integer	28
dot1dBasePortIfIndex.29	.1.3.6.1.2.1.17.1.4.1.2.29	Integer	29
dot1dBasePortIfIndex.30	.1.3.6.1.2.1.17.1.4.1.2.30	Integer	30
dot1dBasePortIfIndex.31	.1.3.6.1.2.1.17.1.4.1.2.31	Integer	31
dot1dBasePortIfIndex.32	.1.3.6.1.2.1.17.1.4.1.2.32	Integer	32
dot1dBasePortIfIndex.33	.1.3.6.1.2.1.17.1.4.1.2.33	Integer	33

Name	OID	Value Type	Value Example
dot1dBasePortIfIndex.34	.1.3.6.1.2.1.17.1.4.1.2.34	Integer	34
dot1dBasePortIfIndex.35	.1.3.6.1.2.1.17.1.4.1.2.35	Integer	35
dot1dBasePortIfIndex.36	.1.3.6.1.2.1.17.1.4.1.2.36	Integer	36
dot1dBasePortIfIndex.37	.1.3.6.1.2.1.17.1.4.1.2.37	Integer	37
dot1dBasePortIfIndex.38	.1.3.6.1.2.1.17.1.4.1.2.38	Integer	38
dot1dBasePortIfIndex.39	.1.3.6.1.2.1.17.1.4.1.2.39	Integer	39
dot1dBasePortIfIndex.40	.1.3.6.1.2.1.17.1.4.1.2.40	Integer	40
dot1dBasePortIfIndex.41	.1.3.6.1.2.1.17.1.4.1.2.41	Integer	41
dot1dBasePortIfIndex.42	.1.3.6.1.2.1.17.1.4.1.2.42	Integer	42
dot1dBasePortIfIndex.43	.1.3.6.1.2.1.17.1.4.1.2.43	Integer	43
dot1dBasePortIfIndex.44	.1.3.6.1.2.1.17.1.4.1.2.44	Integer	44
dot1dBasePortIfIndex.45	.1.3.6.1.2.1.17.1.4.1.2.45	Integer	45
dot1dBasePortIfIndex.46	.1.3.6.1.2.1.17.1.4.1.2.46	Integer	46
dot1dBasePortIfIndex.47	.1.3.6.1.2.1.17.1.4.1.2.47	Integer	47
dot1dBasePortIfIndex.48	.1.3.6.1.2.1.17.1.4.1.2.48	Integer	48
dot1dBasePortIfIndex.49	.1.3.6.1.2.1.17.1.4.1.2.49	Integer	49
dot1dBasePortIfIndex.50	.1.3.6.1.2.1.17.1.4.1.2.50	Integer	50
dot1dBasePortIfIndex.51	.1.3.6.1.2.1.17.1.4.1.2.51	Integer	51
dot1dBasePortIfIndex.52	.1.3.6.1.2.1.17.1.4.1.2.52	Integer	52
dot1dBasePortIfIndex.53	.1.3.6.1.2.1.17.1.4.1.2.53	Integer	53
dot1dBasePortIfIndex.54	.1.3.6.1.2.1.17.1.4.1.2.54	Integer	54
dot1dBasePortCircuit.1	.1.3.6.1.2.1.17.1.4.1.3.1	OID	.0.0
dot1dBasePortCircuit.2	.1.3.6.1.2.1.17.1.4.1.3.2	OID	.0.0
dot1dBasePortCircuit.3	.1.3.6.1.2.1.17.1.4.1.3.3	OID	.0.0
dot1dBasePortCircuit.4	.1.3.6.1.2.1.17.1.4.1.3.4	OID	.0.0
dot1dBasePortCircuit.5	.1.3.6.1.2.1.17.1.4.1.3.5	OID	.0.0
dot1dBasePortCircuit.6	.1.3.6.1.2.1.17.1.4.1.3.6	OID	.0.0
dot1dBasePortCircuit.7	.1.3.6.1.2.1.17.1.4.1.3.7	OID	.0.0
dot1dBasePortCircuit.8	.1.3.6.1.2.1.17.1.4.1.3.8	OID	.0.0
dot1dBasePortCircuit.9	.1.3.6.1.2.1.17.1.4.1.3.9	OID	.0.0
dot1dBasePortCircuit.10	.1.3.6.1.2.1.17.1.4.1.3.10	OID	.0.0
dot1dBasePortCircuit.11	.1.3.6.1.2.1.17.1.4.1.3.11	OID	.0.0
dot1dBasePortCircuit.12	.1.3.6.1.2.1.17.1.4.1.3.12	OID	.0.0
dot1dBasePortCircuit.13	.1.3.6.1.2.1.17.1.4.1.3.13	OID	.0.0
dot1dBasePortCircuit.14	.1.3.6.1.2.1.17.1.4.1.3.14	OID	.0.0
dot1dBasePortCircuit.15	.1.3.6.1.2.1.17.1.4.1.3.15	OID	.0.0
dot1dBasePortCircuit.16	.1.3.6.1.2.1.17.1.4.1.3.16	OID	.0.0
dot1dBasePortCircuit.17	.1.3.6.1.2.1.17.1.4.1.3.17	OID	.0.0
dot1dBasePortCircuit.18	.1.3.6.1.2.1.17.1.4.1.3.18	OID	.0.0
dot1dBasePortCircuit.19	.1.3.6.1.2.1.17.1.4.1.3.19	OID	.0.0
dot1dBasePortCircuit.20	.1.3.6.1.2.1.17.1.4.1.3.20	OID	.0.0
dot1dBasePortCircuit.21	.1.3.6.1.2.1.17.1.4.1.3.21	OID	.0.0
dot1dBasePortCircuit.22	.1.3.6.1.2.1.17.1.4.1.3.22	OID	.0.0

Name	OID	Value Type	Value Example
dot1dBasePortCircuit.23	.1.3.6.1.2.1.17.1.4.1.3.23	OID	.0.0
dot1dBasePortCircuit.24	.1.3.6.1.2.1.17.1.4.1.3.24	OID	.0.0
dot1dBasePortCircuit.25	.1.3.6.1.2.1.17.1.4.1.3.25	OID	.0.0
dot1dBasePortCircuit.26	.1.3.6.1.2.1.17.1.4.1.3.26	OID	.0.0
dot1dBasePortCircuit.27	.1.3.6.1.2.1.17.1.4.1.3.27	OID	.0.0
dot1dBasePortCircuit.28	.1.3.6.1.2.1.17.1.4.1.3.28	OID	.0.0
dot1dBasePortCircuit.29	.1.3.6.1.2.1.17.1.4.1.3.29	OID	.0.0
dot1dBasePortCircuit.30	.1.3.6.1.2.1.17.1.4.1.3.30	OID	.0.0
dot1dBasePortCircuit.31	.1.3.6.1.2.1.17.1.4.1.3.31	OID	.0.0
dot1dBasePortCircuit.32	.1.3.6.1.2.1.17.1.4.1.3.32	OID	.0.0
dot1dBasePortCircuit.33	.1.3.6.1.2.1.17.1.4.1.3.33	OID	.0.0
dot1dBasePortCircuit.34	.1.3.6.1.2.1.17.1.4.1.3.34	OID	.0.0
dot1dBasePortCircuit.35	.1.3.6.1.2.1.17.1.4.1.3.35	OID	.0.0
dot1dBasePortCircuit.36	.1.3.6.1.2.1.17.1.4.1.3.36	OID	.0.0
dot1dBasePortCircuit.37	.1.3.6.1.2.1.17.1.4.1.3.37	OID	.0.0
dot1dBasePortCircuit.38	.1.3.6.1.2.1.17.1.4.1.3.38	OID	.0.0
dot1dBasePortCircuit.39	.1.3.6.1.2.1.17.1.4.1.3.39	OID	.0.0
dot1dBasePortCircuit.40	.1.3.6.1.2.1.17.1.4.1.3.40	OID	.0.0
dot1dBasePortCircuit.41	.1.3.6.1.2.1.17.1.4.1.3.41	OID	.0.0
dot1dBasePortCircuit.42	.1.3.6.1.2.1.17.1.4.1.3.42	OID	.0.0
dot1dBasePortCircuit.43	.1.3.6.1.2.1.17.1.4.1.3.43	OID	.0.0
dot1dBasePortCircuit.44	.1.3.6.1.2.1.17.1.4.1.3.44	OID	.0.0
dot1dBasePortCircuit.45	.1.3.6.1.2.1.17.1.4.1.3.45	OID	.0.0
dot1dBasePortCircuit.46	.1.3.6.1.2.1.17.1.4.1.3.46	OID	.0.0
dot1dBasePortCircuit.47	.1.3.6.1.2.1.17.1.4.1.3.47	OID	.0.0
dot1dBasePortCircuit.48	.1.3.6.1.2.1.17.1.4.1.3.48	OID	.0.0
dot1dBasePortCircuit.49	.1.3.6.1.2.1.17.1.4.1.3.49	OID	.0.0
dot1dBasePortCircuit.50	.1.3.6.1.2.1.17.1.4.1.3.50	OID	.0.0
dot1dBasePortCircuit.51	.1.3.6.1.2.1.17.1.4.1.3.51	OID	.0.0
dot1dBasePortCircuit.52	.1.3.6.1.2.1.17.1.4.1.3.52	OID	.0.0
dot1dBasePortCircuit.53	.1.3.6.1.2.1.17.1.4.1.3.53	OID	.0.0
dot1dBasePortCircuit.54	.1.3.6.1.2.1.17.1.4.1.3.54	OID	.0.0
dot1dBasePortDelayExceeded-Discards.1	.1.3.6.1.2.1.17.1.4.1.4.1	Counter32	0
dot1dBasePortDelayExceeded-Discards.2	.1.3.6.1.2.1.17.1.4.1.4.2	Counter32	0
dot1dBasePortDelayExceeded-Discards.3	.1.3.6.1.2.1.17.1.4.1.4.3	Counter32	0
dot1dBasePortDelayExceeded-Discards.4	.1.3.6.1.2.1.17.1.4.1.4.4	Counter32	0
dot1dBasePortDelayExceeded-Discards.5	.1.3.6.1.2.1.17.1.4.1.4.5	Counter32	0
dot1dBasePortDelayExceeded-Discards.6	.1.3.6.1.2.1.17.1.4.1.4.6	Counter32	0



Name	OID	Value Type	Value Example
dot1dBasePortDelayExceeded-Discards.7	.1.3.6.1.2.1.17.1.4.1.4.7	Counter32	0
dot1dBasePortDelayExceeded-Discards.8	.1.3.6.1.2.1.17.1.4.1.4.8	Counter32	0
dot1dBasePortDelayExceeded-Discards.9	.1.3.6.1.2.1.17.1.4.1.4.9	Counter32	0
dot1dBasePortDelayExceeded-Discards.10	.1.3.6.1.2.1.17.1.4.1.4.10	Counter32	0
dot1dBasePortDelayExceeded-Discards.11	.1.3.6.1.2.1.17.1.4.1.4.11	Counter32	0
dot1dBasePortDelayExceeded-Discards.12	.1.3.6.1.2.1.17.1.4.1.4.12	Counter32	0
dot1dBasePortDelayExceeded-Discards.13	.1.3.6.1.2.1.17.1.4.1.4.13	Counter32	0
dot1dBasePortDelayExceeded-Discards.14	.1.3.6.1.2.1.17.1.4.1.4.14	Counter32	0
dot1dBasePortDelayExceeded-Discards.15	.1.3.6.1.2.1.17.1.4.1.4.15	Counter32	0
dot1dBasePortDelayExceeded-Discards.16	.1.3.6.1.2.1.17.1.4.1.4.16	Counter32	0
dot1dBasePortDelayExceeded-Discards.17	.1.3.6.1.2.1.17.1.4.1.4.17	Counter32	0
dot1dBasePortDelayExceeded-Discards.18	.1.3.6.1.2.1.17.1.4.1.4.18	Counter32	0
dot1dBasePortDelayExceeded-Discards.19	.1.3.6.1.2.1.17.1.4.1.4.19	Counter32	0
dot1dBasePortDelayExceeded-Discards.20	.1.3.6.1.2.1.17.1.4.1.4.20	Counter32	0
dot1dBasePortDelayExceeded-Discards.21	.1.3.6.1.2.1.17.1.4.1.4.21	Counter32	0
dot1dBasePortDelayExceeded-Discards.22	.1.3.6.1.2.1.17.1.4.1.4.22	Counter32	0
dot1dBasePortDelayExceeded-Discards.23	.1.3.6.1.2.1.17.1.4.1.4.23	Counter32	0
dot1dBasePortDelayExceeded-Discards.24	.1.3.6.1.2.1.17.1.4.1.4.24	Counter32	0
dot1dBasePortDelayExceeded-Discards.25	.1.3.6.1.2.1.17.1.4.1.4.25	Counter32	0
dot1dBasePortDelayExceeded-Discards.26	.1.3.6.1.2.1.17.1.4.1.4.26	Counter32	0
dot1dBasePortDelayExceeded-Discards.27	.1.3.6.1.2.1.17.1.4.1.4.27	Counter32	0
dot1dBasePortDelayExceeded-Discards.28	.1.3.6.1.2.1.17.1.4.1.4.28	Counter32	0
dot1dBasePortDelayExceeded-Discards.29	.1.3.6.1.2.1.17.1.4.1.4.29	Counter32	0
dot1dBasePortDelayExceeded-Discards.30	.1.3.6.1.2.1.17.1.4.1.4.30	Counter32	0
dot1dBasePortDelayExceeded-Discards.31	.1.3.6.1.2.1.17.1.4.1.4.31	Counter32	0

Name	OID	Value Type	Value Example
dot1dBasePortDelayExceeded-Discards.32	.1.3.6.1.2.1.17.1.4.1.4.32	Counter32	0
dot1dBasePortDelayExceeded-Discards.33	.1.3.6.1.2.1.17.1.4.1.4.33	Counter32	0
dot1dBasePortDelayExceeded-Discards.34	.1.3.6.1.2.1.17.1.4.1.4.34	Counter32	0
dot1dBasePortDelayExceeded-Discards.35	.1.3.6.1.2.1.17.1.4.1.4.35	Counter32	0
dot1dBasePortDelayExceeded-Discards.36	.1.3.6.1.2.1.17.1.4.1.4.36	Counter32	0
dot1dBasePortDelayExceeded-Discards.37	.1.3.6.1.2.1.17.1.4.1.4.37	Counter32	0
dot1dBasePortDelayExceeded-Discards.38	.1.3.6.1.2.1.17.1.4.1.4.38	Counter32	0
dot1dBasePortDelayExceeded-Discards.39	.1.3.6.1.2.1.17.1.4.1.4.39	Counter32	0
dot1dBasePortDelayExceeded-Discards.40	.1.3.6.1.2.1.17.1.4.1.4.40	Counter32	0
dot1dBasePortDelayExceeded-Discards.41	.1.3.6.1.2.1.17.1.4.1.4.41	Counter32	0
dot1dBasePortDelayExceeded-Discards.42	.1.3.6.1.2.1.17.1.4.1.4.42	Counter32	0
dot1dBasePortDelayExceeded-Discards.43	.1.3.6.1.2.1.17.1.4.1.4.43	Counter32	0
dot1dBasePortDelayExceeded-Discards.44	.1.3.6.1.2.1.17.1.4.1.4.44	Counter32	0
dot1dBasePortDelayExceeded-Discards.45	.1.3.6.1.2.1.17.1.4.1.4.45	Counter32	0
dot1dBasePortDelayExceeded-Discards.46	.1.3.6.1.2.1.17.1.4.1.4.46	Counter32	0
dot1dBasePortDelayExceeded-Discards.47	.1.3.6.1.2.1.17.1.4.1.4.47	Counter32	0
dot1dBasePortDelayExceeded-Discards.48	.1.3.6.1.2.1.17.1.4.1.4.48	Counter32	0
dot1dBasePortDelayExceeded-Discards.49	.1.3.6.1.2.1.17.1.4.1.4.49	Counter32	0
dot1dBasePortDelayExceeded-Discards.50	.1.3.6.1.2.1.17.1.4.1.4.50	Counter32	0
dot1dBasePortDelayExceeded-Discards.51	.1.3.6.1.2.1.17.1.4.1.4.51	Counter32	0
dot1dBasePortDelayExceeded-Discards.52	.1.3.6.1.2.1.17.1.4.1.4.52	Counter32	0
dot1dBasePortDelayExceeded-Discards.53	.1.3.6.1.2.1.17.1.4.1.4.53	Counter32	0
dot1dBasePortDelayExceeded-Discards.54	.1.3.6.1.2.1.17.1.4.1.4.54	Counter32	0
dot1dBasePortMtuExceeded-Discards.1	.1.3.6.1.2.1.17.1.4.1.5.1	Counter32	0
dot1dBasePortMtuExceeded-Discards.2	.1.3.6.1.2.1.17.1.4.1.5.2	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot1dBasePortMtuExceeded-Discards.3	.1.3.6.1.2.1.17.1.4.1.5.3	Counter32	0
dot1dBasePortMtuExceeded-Discards.4	.1.3.6.1.2.1.17.1.4.1.5.4	Counter32	0
dot1dBasePortMtuExceeded-Discards.5	.1.3.6.1.2.1.17.1.4.1.5.5	Counter32	0
dot1dBasePortMtuExceeded-Discards.6	.1.3.6.1.2.1.17.1.4.1.5.6	Counter32	0
dot1dBasePortMtuExceeded-Discards.7	.1.3.6.1.2.1.17.1.4.1.5.7	Counter32	0
dot1dBasePortMtuExceeded-Discards.8	.1.3.6.1.2.1.17.1.4.1.5.8	Counter32	0
dot1dBasePortMtuExceeded-Discards.9	.1.3.6.1.2.1.17.1.4.1.5.9	Counter32	0
dot1dBasePortMtuExceeded-Discards.10	.1.3.6.1.2.1.17.1.4.1.5.10	Counter32	0
dot1dBasePortMtuExceeded-Discards.11	.1.3.6.1.2.1.17.1.4.1.5.11	Counter32	0
dot1dBasePortMtuExceeded-Discards.12	.1.3.6.1.2.1.17.1.4.1.5.12	Counter32	0
dot1dBasePortMtuExceeded-Discards.13	.1.3.6.1.2.1.17.1.4.1.5.13	Counter32	0
dot1dBasePortMtuExceeded-Discards.14	.1.3.6.1.2.1.17.1.4.1.5.14	Counter32	0
dot1dBasePortMtuExceeded-Discards.15	.1.3.6.1.2.1.17.1.4.1.5.15	Counter32	0
dot1dBasePortMtuExceeded-Discards.16	.1.3.6.1.2.1.17.1.4.1.5.16	Counter32	0
dot1dBasePortMtuExceeded-Discards.17	.1.3.6.1.2.1.17.1.4.1.5.17	Counter32	0
dot1dBasePortMtuExceeded-Discards.18	.1.3.6.1.2.1.17.1.4.1.5.18	Counter32	0
dot1dBasePortMtuExceeded-Discards.19	.1.3.6.1.2.1.17.1.4.1.5.19	Counter32	0
dot1dBasePortMtuExceeded-Discards.20	.1.3.6.1.2.1.17.1.4.1.5.20	Counter32	0
dot1dBasePortMtuExceeded-Discards.21	.1.3.6.1.2.1.17.1.4.1.5.21	Counter32	0
dot1dBasePortMtuExceeded-Discards.22	.1.3.6.1.2.1.17.1.4.1.5.22	Counter32	0
dot1dBasePortMtuExceeded-Discards.23	.1.3.6.1.2.1.17.1.4.1.5.23	Counter32	0
dot1dBasePortMtuExceeded-Discards.24	.1.3.6.1.2.1.17.1.4.1.5.24	Counter32	0
dot1dBasePortMtuExceeded-Discards.25	.1.3.6.1.2.1.17.1.4.1.5.25	Counter32	0
dot1dBasePortMtuExceeded-Discards.26	.1.3.6.1.2.1.17.1.4.1.5.26	Counter32	0
dot1dBasePortMtuExceeded-Discards.27	.1.3.6.1.2.1.17.1.4.1.5.27	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot1dBasePortMtuExceeded-Discards.28	.1.3.6.1.2.1.17.1.4.1.5.28	Counter32	0
dot1dBasePortMtuExceeded-Discards.29	.1.3.6.1.2.1.17.1.4.1.5.29	Counter32	0
dot1dBasePortMtuExceeded-Discards.30	.1.3.6.1.2.1.17.1.4.1.5.30	Counter32	0
dot1dBasePortMtuExceeded-Discards.31	.1.3.6.1.2.1.17.1.4.1.5.31	Counter32	0
dot1dBasePortMtuExceeded-Discards.32	.1.3.6.1.2.1.17.1.4.1.5.32	Counter32	0
dot1dBasePortMtuExceeded-Discards.33	.1.3.6.1.2.1.17.1.4.1.5.33	Counter32	0
dot1dBasePortMtuExceeded-Discards.34	.1.3.6.1.2.1.17.1.4.1.5.34	Counter32	0
dot1dBasePortMtuExceeded-Discards.35	.1.3.6.1.2.1.17.1.4.1.5.35	Counter32	0
dot1dBasePortMtuExceeded-Discards.36	.1.3.6.1.2.1.17.1.4.1.5.36	Counter32	0
dot1dBasePortMtuExceeded-Discards.37	.1.3.6.1.2.1.17.1.4.1.5.37	Counter32	0
dot1dBasePortMtuExceeded-Discards.38	.1.3.6.1.2.1.17.1.4.1.5.38	Counter32	0
dot1dBasePortMtuExceeded-Discards.39	.1.3.6.1.2.1.17.1.4.1.5.39	Counter32	0
dot1dBasePortMtuExceeded-Discards.40	.1.3.6.1.2.1.17.1.4.1.5.40	Counter32	0
dot1dBasePortMtuExceeded-Discards.41	.1.3.6.1.2.1.17.1.4.1.5.41	Counter32	0
dot1dBasePortMtuExceeded-Discards.42	.1.3.6.1.2.1.17.1.4.1.5.42	Counter32	0
dot1dBasePortMtuExceeded-Discards.43	.1.3.6.1.2.1.17.1.4.1.5.43	Counter32	0
dot1dBasePortMtuExceeded-Discards.44	.1.3.6.1.2.1.17.1.4.1.5.44	Counter32	0
dot1dBasePortMtuExceeded-Discards.45	.1.3.6.1.2.1.17.1.4.1.5.45	Counter32	0
dot1dBasePortMtuExceeded-Discards.46	.1.3.6.1.2.1.17.1.4.1.5.46	Counter32	0
dot1dBasePortMtuExceeded-Discards.47	.1.3.6.1.2.1.17.1.4.1.5.47	Counter32	0
dot1dBasePortMtuExceeded-Discards.48	.1.3.6.1.2.1.17.1.4.1.5.48	Counter32	0
dot1dBasePortMtuExceeded-Discards.49	.1.3.6.1.2.1.17.1.4.1.5.49	Counter32	0
dot1dBasePortMtuExceeded-Discards.50	.1.3.6.1.2.1.17.1.4.1.5.50	Counter32	0
dot1dBasePortMtuExceeded-Discards.51	.1.3.6.1.2.1.17.1.4.1.5.51	Counter32	0
dot1dBasePortMtuExceeded-Discards.52	.1.3.6.1.2.1.17.1.4.1.5.52	Counter32	0

Name	OID	Value Type	Value Example
dot1dBasePortMtuExceeded-Discards.53	.1.3.6.1.2.1.17.1.4.1.5.53	Counter32	0
dot1dBasePortMtuExceeded-Discards.54	.1.3.6.1.2.1.17.1.4.1.5.54	Counter32	0
dot1dStpProtocolSpecification.0	.1.3.6.1.2.1.17.2.1.0	Integer	unknown (1)
dot1dStpPriority.0	.1.3.6.1.2.1.17.2.2.0	Integer	32768
dot1dStpTimeSinceTopology-Change.0	.1.3.6.1.2.1.17.2.3.0	TimeTicks	2.83 seconds (283)
dot1dStpTopChanges.0	.1.3.6.1.2.1.17.2.4.0	Counter32	226
dot1dStpDesignatedRoot.0	.1.3.6.1.2.1.17.2.5.0	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpRootCost.0	.1.3.6.1.2.1.17.2.6.0	Integer	20080
dot1dStpRootPort.0	.1.3.6.1.2.1.17.2.7.0	Integer	1
dot1dStpMaxAge.0	.1.3.6.1.2.1.17.2.8.0	Integer	2000
dot1dStpHelloTime.0	.1.3.6.1.2.1.17.2.9.0	Integer	200
dot1dStpHoldTime.0	.1.3.6.1.2.1.17.2.10.0	Integer	0
dot1dStpForwardDelay.0	.1.3.6.1.2.1.17.2.11.0	Integer	1500
dot1dStpBridgeMaxAge.0	.1.3.6.1.2.1.17.2.12.0	Integer	2000
dot1dStpBridgeHelloTime.0	.1.3.6.1.2.1.17.2.13.0	Integer	200
dot1dStpBridgeForwardDe- lay.0	.1.3.6.1.2.1.17.2.14.0	Integer	1500
dot1dStpPort.1	.1.3.6.1.2.1.17.2.15.1.1.1	Integer	1
dot1dStpPort.2	.1.3.6.1.2.1.17.2.15.1.1.2	Integer	2
dot1dStpPort.3	.1.3.6.1.2.1.17.2.15.1.1.3	Integer	3
dot1dStpPort.4	.1.3.6.1.2.1.17.2.15.1.1.4	Integer	4
dot1dStpPort.5	.1.3.6.1.2.1.17.2.15.1.1.5	Integer	5
dot1dStpPort.6	.1.3.6.1.2.1.17.2.15.1.1.6	Integer	6
dot1dStpPort.7	.1.3.6.1.2.1.17.2.15.1.1.7	Integer	7
dot1dStpPort.8	.1.3.6.1.2.1.17.2.15.1.1.8	Integer	8
dot1dStpPort.9	.1.3.6.1.2.1.17.2.15.1.1.9	Integer	9
dot1dStpPort.10	.1.3.6.1.2.1.17.2.15.1.1.10	Integer	10
dot1dStpPort.11	.1.3.6.1.2.1.17.2.15.1.1.11	Integer	11
dot1dStpPort.12	.1.3.6.1.2.1.17.2.15.1.1.12	Integer	12
dot1dStpPort.13	.1.3.6.1.2.1.17.2.15.1.1.13	Integer	13
dot1dStpPort.14	.1.3.6.1.2.1.17.2.15.1.1.14	Integer	14
dot1dStpPort.15	.1.3.6.1.2.1.17.2.15.1.1.15	Integer	15
dot1dStpPort.16	.1.3.6.1.2.1.17.2.15.1.1.16	Integer	16
dot1dStpPort.17	.1.3.6.1.2.1.17.2.15.1.1.17	Integer	17
dot1dStpPort.18	.1.3.6.1.2.1.17.2.15.1.1.18	Integer	18
dot1dStpPort.19	.1.3.6.1.2.1.17.2.15.1.1.19	Integer	19
dot1dStpPort.20	.1.3.6.1.2.1.17.2.15.1.1.20	Integer	20
dot1dStpPort.21	.1.3.6.1.2.1.17.2.15.1.1.21	Integer	21
dot1dStpPort.22	.1.3.6.1.2.1.17.2.15.1.1.22	Integer	22
dot1dStpPort.23	.1.3.6.1.2.1.17.2.15.1.1.23	Integer	23

Name	OID	Value Type	Value Example
dot1dStpPort.24	.1.3.6.1.2.1.17.2.15.1.1.24	Integer	24
dot1dStpPort.25	.1.3.6.1.2.1.17.2.15.1.1.25	Integer	25
dot1dStpPort.26	.1.3.6.1.2.1.17.2.15.1.1.26	Integer	26
dot1dStpPort.27	.1.3.6.1.2.1.17.2.15.1.1.27	Integer	27
dot1dStpPort.28	.1.3.6.1.2.1.17.2.15.1.1.28	Integer	28
dot1dStpPort.29	.1.3.6.1.2.1.17.2.15.1.1.29	Integer	29
dot1dStpPort.30	.1.3.6.1.2.1.17.2.15.1.1.30	Integer	30
dot1dStpPort.31	.1.3.6.1.2.1.17.2.15.1.1.31	Integer	31
dot1dStpPort.32	.1.3.6.1.2.1.17.2.15.1.1.32	Integer	32
dot1dStpPort.33	.1.3.6.1.2.1.17.2.15.1.1.33	Integer	33
dot1dStpPort.34	.1.3.6.1.2.1.17.2.15.1.1.34	Integer	34
dot1dStpPort.35	.1.3.6.1.2.1.17.2.15.1.1.35	Integer	35
dot1dStpPort.36	.1.3.6.1.2.1.17.2.15.1.1.36	Integer	36
dot1dStpPort.37	.1.3.6.1.2.1.17.2.15.1.1.37	Integer	37
dot1dStpPort.38	.1.3.6.1.2.1.17.2.15.1.1.38	Integer	38
dot1dStpPort.39	.1.3.6.1.2.1.17.2.15.1.1.39	Integer	39
dot1dStpPort.40	.1.3.6.1.2.1.17.2.15.1.1.40	Integer	40
dot1dStpPort.41	.1.3.6.1.2.1.17.2.15.1.1.41	Integer	41
dot1dStpPort.42	.1.3.6.1.2.1.17.2.15.1.1.42	Integer	42
dot1dStpPort.43	.1.3.6.1.2.1.17.2.15.1.1.43	Integer	43
dot1dStpPort.44	.1.3.6.1.2.1.17.2.15.1.1.44	Integer	44
dot1dStpPort.45	.1.3.6.1.2.1.17.2.15.1.1.45	Integer	45
dot1dStpPort.46	.1.3.6.1.2.1.17.2.15.1.1.46	Integer	46
dot1dStpPort.47	.1.3.6.1.2.1.17.2.15.1.1.47	Integer	47
dot1dStpPort.48	.1.3.6.1.2.1.17.2.15.1.1.48	Integer	48
dot1dStpPort.49	.1.3.6.1.2.1.17.2.15.1.1.49	Integer	49
dot1dStpPort.50	.1.3.6.1.2.1.17.2.15.1.1.50	Integer	50
dot1dStpPort.51	.1.3.6.1.2.1.17.2.15.1.1.51	Integer	51
dot1dStpPort.52	.1.3.6.1.2.1.17.2.15.1.1.52	Integer	52
dot1dStpPort.53	.1.3.6.1.2.1.17.2.15.1.1.53	Integer	53
dot1dStpPort.54	.1.3.6.1.2.1.17.2.15.1.1.54	Integer	54
dot1dStpPortPriority.1	.1.3.6.1.2.1.17.2.15.1.2.1	Integer	128
dot1dStpPortPriority.2	.1.3.6.1.2.1.17.2.15.1.2.2	Integer	128
dot1dStpPortPriority.3	.1.3.6.1.2.1.17.2.15.1.2.3	Integer	128
dot1dStpPortPriority.4	.1.3.6.1.2.1.17.2.15.1.2.4	Integer	128
dot1dStpPortPriority.5	.1.3.6.1.2.1.17.2.15.1.2.5	Integer	128
dot1dStpPortPriority.6	.1.3.6.1.2.1.17.2.15.1.2.6	Integer	128
dot1dStpPortPriority.7	.1.3.6.1.2.1.17.2.15.1.2.7	Integer	128
dot1dStpPortPriority.8	.1.3.6.1.2.1.17.2.15.1.2.8	Integer	128
dot1dStpPortPriority.9	.1.3.6.1.2.1.17.2.15.1.2.9	Integer	128
dot1dStpPortPriority.10	.1.3.6.1.2.1.17.2.15.1.2.10	Integer	128
dot1dStpPortPriority.11	.1.3.6.1.2.1.17.2.15.1.2.11	Integer	128
dot1dStpPortPriority.12	.1.3.6.1.2.1.17.2.15.1.2.12	Integer	128

Name	OID	Value Type	Value Example
dot1dStpPortPriority.13	.1.3.6.1.2.1.17.2.15.1.2.13	Integer	128
dot1dStpPortPriority.14	.1.3.6.1.2.1.17.2.15.1.2.14	Integer	128
dot1dStpPortPriority.15	.1.3.6.1.2.1.17.2.15.1.2.15	Integer	128
dot1dStpPortPriority.16	.1.3.6.1.2.1.17.2.15.1.2.16	Integer	128
dot1dStpPortPriority.17	.1.3.6.1.2.1.17.2.15.1.2.17	Integer	128
dot1dStpPortPriority.18	.1.3.6.1.2.1.17.2.15.1.2.18	Integer	128
dot1dStpPortPriority.19	.1.3.6.1.2.1.17.2.15.1.2.19	Integer	128
dot1dStpPortPriority.20	.1.3.6.1.2.1.17.2.15.1.2.20	Integer	128
dot1dStpPortPriority.21	.1.3.6.1.2.1.17.2.15.1.2.21	Integer	128
dot1dStpPortPriority.22	.1.3.6.1.2.1.17.2.15.1.2.22	Integer	128
dot1dStpPortPriority.23	.1.3.6.1.2.1.17.2.15.1.2.23	Integer	128
dot1dStpPortPriority.24	.1.3.6.1.2.1.17.2.15.1.2.24	Integer	128
dot1dStpPortPriority.25	.1.3.6.1.2.1.17.2.15.1.2.25	Integer	128
dot1dStpPortPriority.26	.1.3.6.1.2.1.17.2.15.1.2.26	Integer	128
dot1dStpPortPriority.27	.1.3.6.1.2.1.17.2.15.1.2.27	Integer	128
dot1dStpPortPriority.28	.1.3.6.1.2.1.17.2.15.1.2.28	Integer	128
dot1dStpPortPriority.29	.1.3.6.1.2.1.17.2.15.1.2.29	Integer	128
dot1dStpPortPriority.30	.1.3.6.1.2.1.17.2.15.1.2.30	Integer	128
dot1dStpPortPriority.31	.1.3.6.1.2.1.17.2.15.1.2.31	Integer	128
dot1dStpPortPriority.32	.1.3.6.1.2.1.17.2.15.1.2.32	Integer	128
dot1dStpPortPriority.33	.1.3.6.1.2.1.17.2.15.1.2.33	Integer	128
dot1dStpPortPriority.34	.1.3.6.1.2.1.17.2.15.1.2.34	Integer	128
dot1dStpPortPriority.35	.1.3.6.1.2.1.17.2.15.1.2.35	Integer	128
dot1dStpPortPriority.36	.1.3.6.1.2.1.17.2.15.1.2.36	Integer	128
dot1dStpPortPriority.37	.1.3.6.1.2.1.17.2.15.1.2.37	Integer	128
dot1dStpPortPriority.38	.1.3.6.1.2.1.17.2.15.1.2.38	Integer	128
dot1dStpPortPriority.39	.1.3.6.1.2.1.17.2.15.1.2.39	Integer	128
dot1dStpPortPriority.40	.1.3.6.1.2.1.17.2.15.1.2.40	Integer	128
dot1dStpPortPriority.41	.1.3.6.1.2.1.17.2.15.1.2.41	Integer	128
dot1dStpPortPriority.42	.1.3.6.1.2.1.17.2.15.1.2.42	Integer	128
dot1dStpPortPriority.43	.1.3.6.1.2.1.17.2.15.1.2.43	Integer	128
dot1dStpPortPriority.44	.1.3.6.1.2.1.17.2.15.1.2.44	Integer	128
dot1dStpPortPriority.45	.1.3.6.1.2.1.17.2.15.1.2.45	Integer	128
dot1dStpPortPriority.46	.1.3.6.1.2.1.17.2.15.1.2.46	Integer	128
dot1dStpPortPriority.47	.1.3.6.1.2.1.17.2.15.1.2.47	Integer	128
dot1dStpPortPriority.48	.1.3.6.1.2.1.17.2.15.1.2.48	Integer	128
dot1dStpPortPriority.49	.1.3.6.1.2.1.17.2.15.1.2.49	Integer	128
dot1dStpPortPriority.50	.1.3.6.1.2.1.17.2.15.1.2.50	Integer	128
dot1dStpPortPriority.51	.1.3.6.1.2.1.17.2.15.1.2.51	Integer	128
dot1dStpPortPriority.52	.1.3.6.1.2.1.17.2.15.1.2.52	Integer	128
dot1dStpPortPriority.53	.1.3.6.1.2.1.17.2.15.1.2.53	Integer	128
dot1dStpPortPriority.54	.1.3.6.1.2.1.17.2.15.1.2.54	Integer	128
dot1dStpPortState.1	.1.3.6.1.2.1.17.2.15.1.3.1	Integer	forwarding (5)

Name	OID	Value Type	Value Example
dot1dStpPortState.2	.1.3.6.1.2.1.17.2.15.1.3.2	Integer	blocking (2)
dot1dStpPortState.3	.1.3.6.1.2.1.17.2.15.1.3.3	Integer	blocking (2)
dot1dStpPortState.4	.1.3.6.1.2.1.17.2.15.1.3.4	Integer	blocking (2)
dot1dStpPortState.5	.1.3.6.1.2.1.17.2.15.1.3.5	Integer	blocking (2)
dot1dStpPortState.6	.1.3.6.1.2.1.17.2.15.1.3.6	Integer	blocking (2)
dot1dStpPortState.7	.1.3.6.1.2.1.17.2.15.1.3.7	Integer	blocking (2)
dot1dStpPortState.8	.1.3.6.1.2.1.17.2.15.1.3.8	Integer	blocking (2)
dot1dStpPortState.9	.1.3.6.1.2.1.17.2.15.1.3.9	Integer	blocking (2)
dot1dStpPortState.10	.1.3.6.1.2.1.17.2.15.1.3.10	Integer	blocking (2)
dot1dStpPortState.11	.1.3.6.1.2.1.17.2.15.1.3.11	Integer	blocking (2)
dot1dStpPortState.12	.1.3.6.1.2.1.17.2.15.1.3.12	Integer	blocking (2)
dot1dStpPortState.13	.1.3.6.1.2.1.17.2.15.1.3.13	Integer	blocking (2)
dot1dStpPortState.14	.1.3.6.1.2.1.17.2.15.1.3.14	Integer	blocking (2)
dot1dStpPortState.15	.1.3.6.1.2.1.17.2.15.1.3.15	Integer	blocking (2)
dot1dStpPortState.16	.1.3.6.1.2.1.17.2.15.1.3.16	Integer	blocking (2)
dot1dStpPortState.17	.1.3.6.1.2.1.17.2.15.1.3.17	Integer	blocking (2)
dot1dStpPortState.18	.1.3.6.1.2.1.17.2.15.1.3.18	Integer	blocking (2)
dot1dStpPortState.19	.1.3.6.1.2.1.17.2.15.1.3.19	Integer	blocking (2)
dot1dStpPortState.20	.1.3.6.1.2.1.17.2.15.1.3.20	Integer	blocking (2)
dot1dStpPortState.21	.1.3.6.1.2.1.17.2.15.1.3.21	Integer	blocking (2)
dot1dStpPortState.22	.1.3.6.1.2.1.17.2.15.1.3.22	Integer	blocking (2)
dot1dStpPortState.23	.1.3.6.1.2.1.17.2.15.1.3.23	Integer	blocking (2)
dot1dStpPortState.24	.1.3.6.1.2.1.17.2.15.1.3.24	Integer	blocking (2)
dot1dStpPortState.25	.1.3.6.1.2.1.17.2.15.1.3.25	Integer	blocking (2)
dot1dStpPortState.26	.1.3.6.1.2.1.17.2.15.1.3.26	Integer	blocking (2)
dot1dStpPortState.27	.1.3.6.1.2.1.17.2.15.1.3.27	Integer	blocking (2)
dot1dStpPortState.28	.1.3.6.1.2.1.17.2.15.1.3.28	Integer	blocking (2)
dot1dStpPortState.29	.1.3.6.1.2.1.17.2.15.1.3.29	Integer	blocking (2)
dot1dStpPortState.30	.1.3.6.1.2.1.17.2.15.1.3.30	Integer	blocking (2)
dot1dStpPortState.31	.1.3.6.1.2.1.17.2.15.1.3.31	Integer	blocking (2)
dot1dStpPortState.32	.1.3.6.1.2.1.17.2.15.1.3.32	Integer	blocking (2)
dot1dStpPortState.33	.1.3.6.1.2.1.17.2.15.1.3.33	Integer	blocking (2)
dot1dStpPortState.34	.1.3.6.1.2.1.17.2.15.1.3.34	Integer	blocking (2)
dot1dStpPortState.35	.1.3.6.1.2.1.17.2.15.1.3.35	Integer	blocking (2)
dot1dStpPortState.36	.1.3.6.1.2.1.17.2.15.1.3.36	Integer	blocking (2)
dot1dStpPortState.37	.1.3.6.1.2.1.17.2.15.1.3.37	Integer	blocking (2)
dot1dStpPortState.38	.1.3.6.1.2.1.17.2.15.1.3.38	Integer	blocking (2)
dot1dStpPortState.39	.1.3.6.1.2.1.17.2.15.1.3.39	Integer	blocking (2)
dot1dStpPortState.40	.1.3.6.1.2.1.17.2.15.1.3.40	Integer	blocking (2)
dot1dStpPortState.41	.1.3.6.1.2.1.17.2.15.1.3.41	Integer	blocking (2)
dot1dStpPortState.42	.1.3.6.1.2.1.17.2.15.1.3.42	Integer	blocking (2)
dot1dStpPortState.43	.1.3.6.1.2.1.17.2.15.1.3.43	Integer	blocking (2)
dot1dStpPortState.44	.1.3.6.1.2.1.17.2.15.1.3.44	Integer	blocking (2)



Name	OID	Value Type	Value Example
dot1dStpPortState.45	.1.3.6.1.2.1.17.2.15.1.3.45	Integer	blocking (2)
dot1dStpPortState.46	.1.3.6.1.2.1.17.2.15.1.3.46	Integer	blocking (2)
dot1dStpPortState.47	.1.3.6.1.2.1.17.2.15.1.3.47	Integer	blocking (2)
dot1dStpPortState.48	.1.3.6.1.2.1.17.2.15.1.3.48	Integer	blocking (2)
dot1dStpPortState.49	.1.3.6.1.2.1.17.2.15.1.3.49	Integer	blocking (2)
dot1dStpPortState.50	.1.3.6.1.2.1.17.2.15.1.3.50	Integer	blocking (2)
dot1dStpPortState.51	.1.3.6.1.2.1.17.2.15.1.3.51	Integer	blocking (2)
dot1dStpPortState.52	.1.3.6.1.2.1.17.2.15.1.3.52	Integer	blocking (2)
dot1dStpPortState.53	.1.3.6.1.2.1.17.2.15.1.3.53	Integer	blocking (2)
dot1dStpPortState.54	.1.3.6.1.2.1.17.2.15.1.3.54	Integer	blocking (2)
dot1dStpPortEnable.1	.1.3.6.1.2.1.17.2.15.1.4.1	Integer	enabled (1)
dot1dStpPortEnable.2	.1.3.6.1.2.1.17.2.15.1.4.2	Integer	enabled (1)
dot1dStpPortEnable.3	.1.3.6.1.2.1.17.2.15.1.4.3	Integer	enabled (1)
dot1dStpPortEnable.4	.1.3.6.1.2.1.17.2.15.1.4.4	Integer	enabled (1)
dot1dStpPortEnable.5	.1.3.6.1.2.1.17.2.15.1.4.5	Integer	enabled (1)
dot1dStpPortEnable.6	.1.3.6.1.2.1.17.2.15.1.4.6	Integer	enabled (1)
dot1dStpPortEnable.7	.1.3.6.1.2.1.17.2.15.1.4.7	Integer	enabled (1)
dot1dStpPortEnable.8	.1.3.6.1.2.1.17.2.15.1.4.8	Integer	enabled (1)
dot1dStpPortEnable.9	.1.3.6.1.2.1.17.2.15.1.4.9	Integer	enabled (1)
dot1dStpPortEnable.10	.1.3.6.1.2.1.17.2.15.1.4.10	Integer	enabled (1)
dot1dStpPortEnable.11	.1.3.6.1.2.1.17.2.15.1.4.11	Integer	enabled (1)
dot1dStpPortEnable.12	.1.3.6.1.2.1.17.2.15.1.4.12	Integer	enabled (1)
dot1dStpPortEnable.13	.1.3.6.1.2.1.17.2.15.1.4.13	Integer	enabled (1)
dot1dStpPortEnable.14	.1.3.6.1.2.1.17.2.15.1.4.14	Integer	enabled (1)
dot1dStpPortEnable.15	.1.3.6.1.2.1.17.2.15.1.4.15	Integer	enabled (1)
dot1dStpPortEnable.16	.1.3.6.1.2.1.17.2.15.1.4.16	Integer	enabled (1)
dot1dStpPortEnable.17	.1.3.6.1.2.1.17.2.15.1.4.17	Integer	enabled (1)
dot1dStpPortEnable.18	.1.3.6.1.2.1.17.2.15.1.4.18	Integer	enabled (1)
dot1dStpPortEnable.19	.1.3.6.1.2.1.17.2.15.1.4.19	Integer	enabled (1)
dot1dStpPortEnable.20	.1.3.6.1.2.1.17.2.15.1.4.20	Integer	enabled (1)
dot1dStpPortEnable.21	.1.3.6.1.2.1.17.2.15.1.4.21	Integer	enabled (1)
dot1dStpPortEnable.22	.1.3.6.1.2.1.17.2.15.1.4.22	Integer	enabled (1)
dot1dStpPortEnable.23	.1.3.6.1.2.1.17.2.15.1.4.23	Integer	enabled (1)
dot1dStpPortEnable.24	.1.3.6.1.2.1.17.2.15.1.4.24	Integer	enabled (1)
dot1dStpPortEnable.25	.1.3.6.1.2.1.17.2.15.1.4.25	Integer	enabled (1)
dot1dStpPortEnable.26	.1.3.6.1.2.1.17.2.15.1.4.26	Integer	enabled (1)
dot1dStpPortEnable.27	.1.3.6.1.2.1.17.2.15.1.4.27	Integer	enabled (1)
dot1dStpPortEnable.28	.1.3.6.1.2.1.17.2.15.1.4.28	Integer	enabled (1)
dot1dStpPortEnable.29	.1.3.6.1.2.1.17.2.15.1.4.29	Integer	enabled (1)
dot1dStpPortEnable.30	.1.3.6.1.2.1.17.2.15.1.4.30	Integer	enabled (1)
dot1dStpPortEnable.31	.1.3.6.1.2.1.17.2.15.1.4.31	Integer	enabled (1)
dot1dStpPortEnable.32	.1.3.6.1.2.1.17.2.15.1.4.32	Integer	enabled (1)
dot1dStpPortEnable.33	.1.3.6.1.2.1.17.2.15.1.4.33	Integer	enabled (1)

Name	OID	Value Type	Value Example
dot1dStpPortEnable.34	.1.3.6.1.2.1.17.2.15.1.4.34	Integer	enabled (1)
dot1dStpPortEnable.35	.1.3.6.1.2.1.17.2.15.1.4.35	Integer	enabled (1)
dot1dStpPortEnable.36	.1.3.6.1.2.1.17.2.15.1.4.36	Integer	enabled (1)
dot1dStpPortEnable.37	.1.3.6.1.2.1.17.2.15.1.4.37	Integer	enabled (1)
dot1dStpPortEnable.38	.1.3.6.1.2.1.17.2.15.1.4.38	Integer	enabled (1)
dot1dStpPortEnable.39	.1.3.6.1.2.1.17.2.15.1.4.39	Integer	enabled (1)
dot1dStpPortEnable.40	.1.3.6.1.2.1.17.2.15.1.4.40	Integer	enabled (1)
dot1dStpPortEnable.41	.1.3.6.1.2.1.17.2.15.1.4.41	Integer	enabled (1)
dot1dStpPortEnable.42	.1.3.6.1.2.1.17.2.15.1.4.42	Integer	enabled (1)
dot1dStpPortEnable.43	.1.3.6.1.2.1.17.2.15.1.4.43	Integer	enabled (1)
dot1dStpPortEnable.44	.1.3.6.1.2.1.17.2.15.1.4.44	Integer	enabled (1)
dot1dStpPortEnable.45	.1.3.6.1.2.1.17.2.15.1.4.45	Integer	enabled (1)
dot1dStpPortEnable.46	.1.3.6.1.2.1.17.2.15.1.4.46	Integer	enabled (1)
dot1dStpPortEnable.47	.1.3.6.1.2.1.17.2.15.1.4.47	Integer	enabled (1)
dot1dStpPortEnable.48	.1.3.6.1.2.1.17.2.15.1.4.48	Integer	enabled (1)
dot1dStpPortEnable.49	.1.3.6.1.2.1.17.2.15.1.4.49	Integer	enabled (1)
dot1dStpPortEnable.50	.1.3.6.1.2.1.17.2.15.1.4.50	Integer	enabled (1)
dot1dStpPortEnable.51	.1.3.6.1.2.1.17.2.15.1.4.51	Integer	enabled (1)
dot1dStpPortEnable.52	.1.3.6.1.2.1.17.2.15.1.4.52	Integer	enabled (1)
dot1dStpPortEnable.53	.1.3.6.1.2.1.17.2.15.1.4.53	Integer	enabled (1)
dot1dStpPortEnable.54	.1.3.6.1.2.1.17.2.15.1.4.54	Integer	enabled (1)
dot1dStpPortPathCost.1	.1.3.6.1.2.1.17.2.15.1.5.1	Integer	20
dot1dStpPortPathCost.2	.1.3.6.1.2.1.17.2.15.1.5.2	Integer	65535
dot1dStpPortPathCost.3	.1.3.6.1.2.1.17.2.15.1.5.3	Integer	65535
dot1dStpPortPathCost.4	.1.3.6.1.2.1.17.2.15.1.5.4	Integer	65535
dot1dStpPortPathCost.5	.1.3.6.1.2.1.17.2.15.1.5.5	Integer	65535
dot1dStpPortPathCost.6	.1.3.6.1.2.1.17.2.15.1.5.6	Integer	65535
dot1dStpPortPathCost.7	.1.3.6.1.2.1.17.2.15.1.5.7	Integer	65535
dot1dStpPortPathCost.8	.1.3.6.1.2.1.17.2.15.1.5.8	Integer	65535
dot1dStpPortPathCost.9	.1.3.6.1.2.1.17.2.15.1.5.9	Integer	65535
dot1dStpPortPathCost.10	.1.3.6.1.2.1.17.2.15.1.5.10	Integer	65535
dot1dStpPortPathCost.11	.1.3.6.1.2.1.17.2.15.1.5.11	Integer	65535
dot1dStpPortPathCost.12	.1.3.6.1.2.1.17.2.15.1.5.12	Integer	65535
dot1dStpPortPathCost.13	.1.3.6.1.2.1.17.2.15.1.5.13	Integer	65535
dot1dStpPortPathCost.14	.1.3.6.1.2.1.17.2.15.1.5.14	Integer	65535
dot1dStpPortPathCost.15	.1.3.6.1.2.1.17.2.15.1.5.15	Integer	65535
dot1dStpPortPathCost.16	.1.3.6.1.2.1.17.2.15.1.5.16	Integer	65535
dot1dStpPortPathCost.17	.1.3.6.1.2.1.17.2.15.1.5.17	Integer	65535
dot1dStpPortPathCost.18	.1.3.6.1.2.1.17.2.15.1.5.18	Integer	65535
dot1dStpPortPathCost.19	.1.3.6.1.2.1.17.2.15.1.5.19	Integer	65535
dot1dStpPortPathCost.20	.1.3.6.1.2.1.17.2.15.1.5.20	Integer	65535
dot1dStpPortPathCost.21	.1.3.6.1.2.1.17.2.15.1.5.21	Integer	65535
dot1dStpPortPathCost.22	.1.3.6.1.2.1.17.2.15.1.5.22	Integer	65535

Name	OID	Value Type	Value Example
dot1dStpPortPathCost.23	.1.3.6.1.2.1.17.2.15.1.5.23	Integer	65535
dot1dStpPortPathCost.24	.1.3.6.1.2.1.17.2.15.1.5.24	Integer	65535
dot1dStpPortPathCost.25	.1.3.6.1.2.1.17.2.15.1.5.25	Integer	65535
dot1dStpPortPathCost.26	.1.3.6.1.2.1.17.2.15.1.5.26	Integer	65535
dot1dStpPortPathCost.27	.1.3.6.1.2.1.17.2.15.1.5.27	Integer	65535
dot1dStpPortPathCost.28	.1.3.6.1.2.1.17.2.15.1.5.28	Integer	65535
dot1dStpPortPathCost.29	.1.3.6.1.2.1.17.2.15.1.5.29	Integer	65535
dot1dStpPortPathCost.30	.1.3.6.1.2.1.17.2.15.1.5.30	Integer	65535
dot1dStpPortPathCost.31	.1.3.6.1.2.1.17.2.15.1.5.31	Integer	65535
dot1dStpPortPathCost.32	.1.3.6.1.2.1.17.2.15.1.5.32	Integer	65535
dot1dStpPortPathCost.33	.1.3.6.1.2.1.17.2.15.1.5.33	Integer	65535
dot1dStpPortPathCost.34	.1.3.6.1.2.1.17.2.15.1.5.34	Integer	65535
dot1dStpPortPathCost.35	.1.3.6.1.2.1.17.2.15.1.5.35	Integer	65535
dot1dStpPortPathCost.36	.1.3.6.1.2.1.17.2.15.1.5.36	Integer	65535
dot1dStpPortPathCost.37	.1.3.6.1.2.1.17.2.15.1.5.37	Integer	65535
dot1dStpPortPathCost.38	.1.3.6.1.2.1.17.2.15.1.5.38	Integer	65535
dot1dStpPortPathCost.39	.1.3.6.1.2.1.17.2.15.1.5.39	Integer	65535
dot1dStpPortPathCost.40	.1.3.6.1.2.1.17.2.15.1.5.40	Integer	65535
dot1dStpPortPathCost.41	.1.3.6.1.2.1.17.2.15.1.5.41	Integer	65535
dot1dStpPortPathCost.42	.1.3.6.1.2.1.17.2.15.1.5.42	Integer	65535
dot1dStpPortPathCost.43	.1.3.6.1.2.1.17.2.15.1.5.43	Integer	65535
dot1dStpPortPathCost.44	.1.3.6.1.2.1.17.2.15.1.5.44	Integer	65535
dot1dStpPortPathCost.45	.1.3.6.1.2.1.17.2.15.1.5.45	Integer	65535
dot1dStpPortPathCost.46	.1.3.6.1.2.1.17.2.15.1.5.46	Integer	65535
dot1dStpPortPathCost.47	.1.3.6.1.2.1.17.2.15.1.5.47	Integer	65535
dot1dStpPortPathCost.48	.1.3.6.1.2.1.17.2.15.1.5.48	Integer	65535
dot1dStpPortPathCost.49	.1.3.6.1.2.1.17.2.15.1.5.49	Integer	65535
dot1dStpPortPathCost.50	.1.3.6.1.2.1.17.2.15.1.5.50	Integer	65535
dot1dStpPortPathCost.51	.1.3.6.1.2.1.17.2.15.1.5.51	Integer	65535
dot1dStpPortPathCost.52	.1.3.6.1.2.1.17.2.15.1.5.52	Integer	65535
dot1dStpPortPathCost.53	.1.3.6.1.2.1.17.2.15.1.5.53	Integer	65535
dot1dStpPortPathCost.54	.1.3.6.1.2.1.17.2.15.1.5.54	Integer	65535
dot1dStpPortDesignatedRoot.1	.1.3.6.1.2.1.17.2.15.1.6.1	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.2	.1.3.6.1.2.1.17.2.15.1.6.2	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.3	.1.3.6.1.2.1.17.2.15.1.6.3	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.4	.1.3.6.1.2.1.17.2.15.1.6.4	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.5	.1.3.6.1.2.1.17.2.15.1.6.5	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.6	.1.3.6.1.2.1.17.2.15.1.6.6	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.7	.1.3.6.1.2.1.17.2.15.1.6.7	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.8	.1.3.6.1.2.1.17.2.15.1.6.8	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.9	.1.3.6.1.2.1.17.2.15.1.6.9	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.10	.1.3.6.1.2.1.17.2.15.1.6.10	OctetString	40-00-E4-F0-04-73-89-88

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot1dStpPortDesignatedRoot.11	.1.3.6.1.2.1.17.2.15.1.6.11	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.12	.1.3.6.1.2.1.17.2.15.1.6.12	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.13	.1.3.6.1.2.1.17.2.15.1.6.13	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.14	.1.3.6.1.2.1.17.2.15.1.6.14	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.15	.1.3.6.1.2.1.17.2.15.1.6.15	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.16	.1.3.6.1.2.1.17.2.15.1.6.16	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.17	.1.3.6.1.2.1.17.2.15.1.6.17	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.18	.1.3.6.1.2.1.17.2.15.1.6.18	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.19	.1.3.6.1.2.1.17.2.15.1.6.19	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.20	.1.3.6.1.2.1.17.2.15.1.6.20	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.21	.1.3.6.1.2.1.17.2.15.1.6.21	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.22	.1.3.6.1.2.1.17.2.15.1.6.22	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.23	.1.3.6.1.2.1.17.2.15.1.6.23	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.24	.1.3.6.1.2.1.17.2.15.1.6.24	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.25	.1.3.6.1.2.1.17.2.15.1.6.25	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.26	.1.3.6.1.2.1.17.2.15.1.6.26	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.27	.1.3.6.1.2.1.17.2.15.1.6.27	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.28	.1.3.6.1.2.1.17.2.15.1.6.28	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.29	.1.3.6.1.2.1.17.2.15.1.6.29	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.30	.1.3.6.1.2.1.17.2.15.1.6.30	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.31	.1.3.6.1.2.1.17.2.15.1.6.31	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.32	.1.3.6.1.2.1.17.2.15.1.6.32	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.33	.1.3.6.1.2.1.17.2.15.1.6.33	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.34	.1.3.6.1.2.1.17.2.15.1.6.34	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.35	.1.3.6.1.2.1.17.2.15.1.6.35	OctetString	40-00-E4-F0-04-73-89-88

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot1dStpPortDesignatedRoot.36	.1.3.6.1.2.1.17.2.15.1.6.36	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.37	.1.3.6.1.2.1.17.2.15.1.6.37	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.38	.1.3.6.1.2.1.17.2.15.1.6.38	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.39	.1.3.6.1.2.1.17.2.15.1.6.39	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.40	.1.3.6.1.2.1.17.2.15.1.6.40	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.41	.1.3.6.1.2.1.17.2.15.1.6.41	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.42	.1.3.6.1.2.1.17.2.15.1.6.42	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.43	.1.3.6.1.2.1.17.2.15.1.6.43	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.44	.1.3.6.1.2.1.17.2.15.1.6.44	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.45	.1.3.6.1.2.1.17.2.15.1.6.45	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.46	.1.3.6.1.2.1.17.2.15.1.6.46	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.47	.1.3.6.1.2.1.17.2.15.1.6.47	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.48	.1.3.6.1.2.1.17.2.15.1.6.48	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.49	.1.3.6.1.2.1.17.2.15.1.6.49	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.50	.1.3.6.1.2.1.17.2.15.1.6.50	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.51	.1.3.6.1.2.1.17.2.15.1.6.51	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.52	.1.3.6.1.2.1.17.2.15.1.6.52	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.53	.1.3.6.1.2.1.17.2.15.1.6.53	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedRoot.54	.1.3.6.1.2.1.17.2.15.1.6.54	OctetString	40-00-E4-F0-04-73-89-88
dot1dStpPortDesignatedCost.1	.1.3.6.1.2.1.17.2.15.1.7.1	Integer	20060
dot1dStpPortDesignatedCost.2	.1.3.6.1.2.1.17.2.15.1.7.2	Integer	20080
dot1dStpPortDesignatedCost.3	.1.3.6.1.2.1.17.2.15.1.7.3	Integer	20080
dot1dStpPortDesignatedCost.4	.1.3.6.1.2.1.17.2.15.1.7.4	Integer	20080
dot1dStpPortDesignatedCost.5	.1.3.6.1.2.1.17.2.15.1.7.5	Integer	20080
dot1dStpPortDesignatedCost.6	.1.3.6.1.2.1.17.2.15.1.7.6	Integer	20080
dot1dStpPortDesignatedCost.7	.1.3.6.1.2.1.17.2.15.1.7.7	Integer	20080
dot1dStpPortDesignatedCost.8	.1.3.6.1.2.1.17.2.15.1.7.8	Integer	20080
dot1dStpPortDesignatedCost.9	.1.3.6.1.2.1.17.2.15.1.7.9	Integer	20080
dot1dStpPortDesignatedCost.10	.1.3.6.1.2.1.17.2.15.1.7.10	Integer	20080

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot1dStpPortDesignated-Cost.11	.1.3.6.1.2.1.17.2.15.1.7.11	Integer	20080
dot1dStpPortDesignated-Cost.12	.1.3.6.1.2.1.17.2.15.1.7.12	Integer	20080
dot1dStpPortDesignated-Cost.13	.1.3.6.1.2.1.17.2.15.1.7.13	Integer	20080
dot1dStpPortDesignated-Cost.14	.1.3.6.1.2.1.17.2.15.1.7.14	Integer	20080
dot1dStpPortDesignated-Cost.15	.1.3.6.1.2.1.17.2.15.1.7.15	Integer	20080
dot1dStpPortDesignated-Cost.16	.1.3.6.1.2.1.17.2.15.1.7.16	Integer	20080
dot1dStpPortDesignated-Cost.17	.1.3.6.1.2.1.17.2.15.1.7.17	Integer	20080
dot1dStpPortDesignated-Cost.18	.1.3.6.1.2.1.17.2.15.1.7.18	Integer	20080
dot1dStpPortDesignated-Cost.19	.1.3.6.1.2.1.17.2.15.1.7.19	Integer	20080
dot1dStpPortDesignated-Cost.20	.1.3.6.1.2.1.17.2.15.1.7.20	Integer	20080
dot1dStpPortDesignated-Cost.21	.1.3.6.1.2.1.17.2.15.1.7.21	Integer	20080
dot1dStpPortDesignated-Cost.22	.1.3.6.1.2.1.17.2.15.1.7.22	Integer	20080
dot1dStpPortDesignated-Cost.23	.1.3.6.1.2.1.17.2.15.1.7.23	Integer	20080
dot1dStpPortDesignated-Cost.24	.1.3.6.1.2.1.17.2.15.1.7.24	Integer	20080
dot1dStpPortDesignated-Cost.25	.1.3.6.1.2.1.17.2.15.1.7.25	Integer	20080
dot1dStpPortDesignated-Cost.26	.1.3.6.1.2.1.17.2.15.1.7.26	Integer	20080
dot1dStpPortDesignated-Cost.27	.1.3.6.1.2.1.17.2.15.1.7.27	Integer	20080
dot1dStpPortDesignated-Cost.28	.1.3.6.1.2.1.17.2.15.1.7.28	Integer	20080
dot1dStpPortDesignated-Cost.29	.1.3.6.1.2.1.17.2.15.1.7.29	Integer	20080
dot1dStpPortDesignated-Cost.30	.1.3.6.1.2.1.17.2.15.1.7.30	Integer	20080
dot1dStpPortDesignated-Cost.31	.1.3.6.1.2.1.17.2.15.1.7.31	Integer	20080
dot1dStpPortDesignated-Cost.32	.1.3.6.1.2.1.17.2.15.1.7.32	Integer	20080
dot1dStpPortDesignated-Cost.33	.1.3.6.1.2.1.17.2.15.1.7.33	Integer	20080
dot1dStpPortDesignated-Cost.34	.1.3.6.1.2.1.17.2.15.1.7.34	Integer	20080
dot1dStpPortDesignated-Cost.35	.1.3.6.1.2.1.17.2.15.1.7.35	Integer	20080

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot1dStpPortDesignated-Cost.36	.1.3.6.1.2.1.17.2.15.1.7.36	Integer	20080
dot1dStpPortDesignated-Cost.37	.1.3.6.1.2.1.17.2.15.1.7.37	Integer	20080
dot1dStpPortDesignated-Cost.38	.1.3.6.1.2.1.17.2.15.1.7.38	Integer	20080
dot1dStpPortDesignated-Cost.39	.1.3.6.1.2.1.17.2.15.1.7.39	Integer	20080
dot1dStpPortDesignated-Cost.40	.1.3.6.1.2.1.17.2.15.1.7.40	Integer	20080
dot1dStpPortDesignated-Cost.41	.1.3.6.1.2.1.17.2.15.1.7.41	Integer	20080
dot1dStpPortDesignated-Cost.42	.1.3.6.1.2.1.17.2.15.1.7.42	Integer	20080
dot1dStpPortDesignated-Cost.43	.1.3.6.1.2.1.17.2.15.1.7.43	Integer	20080
dot1dStpPortDesignated-Cost.44	.1.3.6.1.2.1.17.2.15.1.7.44	Integer	20080
dot1dStpPortDesignated-Cost.45	.1.3.6.1.2.1.17.2.15.1.7.45	Integer	20080
dot1dStpPortDesignated-Cost.46	.1.3.6.1.2.1.17.2.15.1.7.46	Integer	20080
dot1dStpPortDesignated-Cost.47	.1.3.6.1.2.1.17.2.15.1.7.47	Integer	20080
dot1dStpPortDesignated-Cost.48	.1.3.6.1.2.1.17.2.15.1.7.48	Integer	20080
dot1dStpPortDesignated-Cost.49	.1.3.6.1.2.1.17.2.15.1.7.49	Integer	20080
dot1dStpPortDesignated-Cost.50	.1.3.6.1.2.1.17.2.15.1.7.50	Integer	20080
dot1dStpPortDesignated-Cost.51	.1.3.6.1.2.1.17.2.15.1.7.51	Integer	20080
dot1dStpPortDesignated-Cost.52	.1.3.6.1.2.1.17.2.15.1.7.52	Integer	20080
dot1dStpPortDesignated-Cost.53	.1.3.6.1.2.1.17.2.15.1.7.53	Integer	20080
dot1dStpPortDesignated-Cost.54	.1.3.6.1.2.1.17.2.15.1.7.54	Integer	20080
dot1dStpPortDesignated-Bridge.1	.1.3.6.1.2.1.17.2.15.1.8.1	OctetString	80-00-14-84-77-83-B1-20
dot1dStpPortDesignated-Bridge.2	.1.3.6.1.2.1.17.2.15.1.8.2	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.3	.1.3.6.1.2.1.17.2.15.1.8.3	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.4	.1.3.6.1.2.1.17.2.15.1.8.4	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.5	.1.3.6.1.2.1.17.2.15.1.8.5	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.6	.1.3.6.1.2.1.17.2.15.1.8.6	OctetString	80-00-14-84-77-95-1D-B0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot1dStpPortDesignated-Bridge.7	.1.3.6.1.2.1.17.2.15.1.8.7	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.8	.1.3.6.1.2.1.17.2.15.1.8.8	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.9	.1.3.6.1.2.1.17.2.15.1.8.9	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.10	.1.3.6.1.2.1.17.2.15.1.8.10	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.11	.1.3.6.1.2.1.17.2.15.1.8.11	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.12	.1.3.6.1.2.1.17.2.15.1.8.12	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.13	.1.3.6.1.2.1.17.2.15.1.8.13	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.14	.1.3.6.1.2.1.17.2.15.1.8.14	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.15	.1.3.6.1.2.1.17.2.15.1.8.15	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.16	.1.3.6.1.2.1.17.2.15.1.8.16	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.17	.1.3.6.1.2.1.17.2.15.1.8.17	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.18	.1.3.6.1.2.1.17.2.15.1.8.18	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.19	.1.3.6.1.2.1.17.2.15.1.8.19	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.20	.1.3.6.1.2.1.17.2.15.1.8.20	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.21	.1.3.6.1.2.1.17.2.15.1.8.21	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.22	.1.3.6.1.2.1.17.2.15.1.8.22	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.23	.1.3.6.1.2.1.17.2.15.1.8.23	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.24	.1.3.6.1.2.1.17.2.15.1.8.24	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.25	.1.3.6.1.2.1.17.2.15.1.8.25	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.26	.1.3.6.1.2.1.17.2.15.1.8.26	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.27	.1.3.6.1.2.1.17.2.15.1.8.27	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.28	.1.3.6.1.2.1.17.2.15.1.8.28	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.29	.1.3.6.1.2.1.17.2.15.1.8.29	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.30	.1.3.6.1.2.1.17.2.15.1.8.30	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.31	.1.3.6.1.2.1.17.2.15.1.8.31	OctetString	80-00-14-84-77-95-1D-B0



<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot1dStpPortDesignated-Bridge.32	.1.3.6.1.2.1.17.2.15.1.8.32	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.33	.1.3.6.1.2.1.17.2.15.1.8.33	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.34	.1.3.6.1.2.1.17.2.15.1.8.34	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.35	.1.3.6.1.2.1.17.2.15.1.8.35	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.36	.1.3.6.1.2.1.17.2.15.1.8.36	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.37	.1.3.6.1.2.1.17.2.15.1.8.37	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.38	.1.3.6.1.2.1.17.2.15.1.8.38	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.39	.1.3.6.1.2.1.17.2.15.1.8.39	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.40	.1.3.6.1.2.1.17.2.15.1.8.40	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.41	.1.3.6.1.2.1.17.2.15.1.8.41	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.42	.1.3.6.1.2.1.17.2.15.1.8.42	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.43	.1.3.6.1.2.1.17.2.15.1.8.43	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.44	.1.3.6.1.2.1.17.2.15.1.8.44	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.45	.1.3.6.1.2.1.17.2.15.1.8.45	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.46	.1.3.6.1.2.1.17.2.15.1.8.46	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.47	.1.3.6.1.2.1.17.2.15.1.8.47	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.48	.1.3.6.1.2.1.17.2.15.1.8.48	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.49	.1.3.6.1.2.1.17.2.15.1.8.49	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.50	.1.3.6.1.2.1.17.2.15.1.8.50	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.51	.1.3.6.1.2.1.17.2.15.1.8.51	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.52	.1.3.6.1.2.1.17.2.15.1.8.52	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.53	.1.3.6.1.2.1.17.2.15.1.8.53	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignated-Bridge.54	.1.3.6.1.2.1.17.2.15.1.8.54	OctetString	80-00-14-84-77-95-1D-B0
dot1dStpPortDesignatedPort.1	.1.3.6.1.2.1.17.2.15.1.9.1	OctetString	0x80 02
dot1dStpPortDesignatedPort.2	.1.3.6.1.2.1.17.2.15.1.9.2	OctetString	0x80 02
dot1dStpPortDesignatedPort.3	.1.3.6.1.2.1.17.2.15.1.9.3	OctetString	0x80 03
dot1dStpPortDesignatedPort.4	.1.3.6.1.2.1.17.2.15.1.9.4	OctetString	0x80 04

Name	OID	Value Type	Value Example
dot1dStpPortDesignatedPort.5	.1.3.6.1.2.1.17.2.15.1.9.5	OctetString	0x80 05
dot1dStpPortDesignatedPort.6	.1.3.6.1.2.1.17.2.15.1.9.6	OctetString	0x80 06
dot1dStpPortDesignatedPort.7	.1.3.6.1.2.1.17.2.15.1.9.7	OctetString	0x80 07
dot1dStpPortDesignatedPort.8	.1.3.6.1.2.1.17.2.15.1.9.8	OctetString	0x80 08
dot1dStpPortDesignatedPort.9	.1.3.6.1.2.1.17.2.15.1.9.9	OctetString	0x80 09
dot1dStpPortDesignated-Port.10	.1.3.6.1.2.1.17.2.15.1.9.10	OctetString	0x80 0A
dot1dStpPortDesignated-Port.11	.1.3.6.1.2.1.17.2.15.1.9.11	OctetString	0x80 0B
dot1dStpPortDesignated-Port.12	.1.3.6.1.2.1.17.2.15.1.9.12	OctetString	0x80 0C
dot1dStpPortDesignated-Port.13	.1.3.6.1.2.1.17.2.15.1.9.13	OctetString	0x80 0D
dot1dStpPortDesignated-Port.14	.1.3.6.1.2.1.17.2.15.1.9.14	OctetString	0x80 0E
dot1dStpPortDesignated-Port.15	.1.3.6.1.2.1.17.2.15.1.9.15	OctetString	0x80 0F
dot1dStpPortDesignated-Port.16	.1.3.6.1.2.1.17.2.15.1.9.16	OctetString	0x80 10
dot1dStpPortDesignated-Port.17	.1.3.6.1.2.1.17.2.15.1.9.17	OctetString	0x80 11
dot1dStpPortDesignated-Port.18	.1.3.6.1.2.1.17.2.15.1.9.18	OctetString	0x80 12
dot1dStpPortDesignated-Port.19	.1.3.6.1.2.1.17.2.15.1.9.19	OctetString	0x80 13
dot1dStpPortDesignated-Port.20	.1.3.6.1.2.1.17.2.15.1.9.20	OctetString	0x80 14
dot1dStpPortDesignated-Port.21	.1.3.6.1.2.1.17.2.15.1.9.21	OctetString	0x80 15
dot1dStpPortDesignated-Port.22	.1.3.6.1.2.1.17.2.15.1.9.22	OctetString	0x80 16
dot1dStpPortDesignated-Port.23	.1.3.6.1.2.1.17.2.15.1.9.23	OctetString	0x80 17
dot1dStpPortDesignated-Port.24	.1.3.6.1.2.1.17.2.15.1.9.24	OctetString	0x80 18
dot1dStpPortDesignated-Port.25	.1.3.6.1.2.1.17.2.15.1.9.25	OctetString	0x80 19
dot1dStpPortDesignated-Port.26	.1.3.6.1.2.1.17.2.15.1.9.26	OctetString	0x80 1A
dot1dStpPortDesignated-Port.27	.1.3.6.1.2.1.17.2.15.1.9.27	OctetString	0x80 1B
dot1dStpPortDesignated-Port.28	.1.3.6.1.2.1.17.2.15.1.9.28	OctetString	0x80 1C
dot1dStpPortDesignated-Port.29	.1.3.6.1.2.1.17.2.15.1.9.29	OctetString	0x80 1D
dot1dStpPortDesignated-Port.30	.1.3.6.1.2.1.17.2.15.1.9.30	OctetString	0x80 1E
dot1dStpPortDesignated-Port.31	.1.3.6.1.2.1.17.2.15.1.9.31	OctetString	0x80 1F

Name	OID	Value Type	Value Example
dot1dStpPortDesignated-Port.32	.1.3.6.1.2.1.17.2.15.1.9.32	OctetString	0x80 20
dot1dStpPortDesignated-Port.33	.1.3.6.1.2.1.17.2.15.1.9.33	OctetString	0x80 21
dot1dStpPortDesignated-Port.34	.1.3.6.1.2.1.17.2.15.1.9.34	OctetString	0x80 22
dot1dStpPortDesignated-Port.35	.1.3.6.1.2.1.17.2.15.1.9.35	OctetString	0x80 23
dot1dStpPortDesignated-Port.36	.1.3.6.1.2.1.17.2.15.1.9.36	OctetString	0x80 24
dot1dStpPortDesignated-Port.37	.1.3.6.1.2.1.17.2.15.1.9.37	OctetString	0x80 25
dot1dStpPortDesignated-Port.38	.1.3.6.1.2.1.17.2.15.1.9.38	OctetString	0x80 26
dot1dStpPortDesignated-Port.39	.1.3.6.1.2.1.17.2.15.1.9.39	OctetString	0x80 27
dot1dStpPortDesignated-Port.40	.1.3.6.1.2.1.17.2.15.1.9.40	OctetString	0x80 28
dot1dStpPortDesignated-Port.41	.1.3.6.1.2.1.17.2.15.1.9.41	OctetString	0x80 29
dot1dStpPortDesignated-Port.42	.1.3.6.1.2.1.17.2.15.1.9.42	OctetString	0x80 2A
dot1dStpPortDesignated-Port.43	.1.3.6.1.2.1.17.2.15.1.9.43	OctetString	0x80 2B
dot1dStpPortDesignated-Port.44	.1.3.6.1.2.1.17.2.15.1.9.44	OctetString	0x80 2C
dot1dStpPortDesignated-Port.45	.1.3.6.1.2.1.17.2.15.1.9.45	OctetString	0x80 2D
dot1dStpPortDesignated-Port.46	.1.3.6.1.2.1.17.2.15.1.9.46	OctetString	0x80 2E
dot1dStpPortDesignated-Port.47	.1.3.6.1.2.1.17.2.15.1.9.47	OctetString	0x80 2F
dot1dStpPortDesignated-Port.48	.1.3.6.1.2.1.17.2.15.1.9.48	OctetString	0x80 30
dot1dStpPortDesignated-Port.49	.1.3.6.1.2.1.17.2.15.1.9.49	OctetString	0x80 31
dot1dStpPortDesignated-Port.50	.1.3.6.1.2.1.17.2.15.1.9.50	OctetString	0x80 32
dot1dStpPortDesignated-Port.51	.1.3.6.1.2.1.17.2.15.1.9.51	OctetString	0x80 33
dot1dStpPortDesignated-Port.52	.1.3.6.1.2.1.17.2.15.1.9.52	OctetString	0x80 34
dot1dStpPortDesignated-Port.53	.1.3.6.1.2.1.17.2.15.1.9.53	OctetString	0x80 35
dot1dStpPortDesignated-Port.54	.1.3.6.1.2.1.17.2.15.1.9.54	OctetString	0x80 36
dot1dStpPortForwardTransitions.1	.1.3.6.1.2.1.17.2.15.1.10.1	Counter32	1
dot1dStpPortForwardTransitions.2	.1.3.6.1.2.1.17.2.15.1.10.2	Counter32	0

Name	OID	Value Type	Value Example
dot1dStpPortForwardTransitions.3	.1.3.6.1.2.1.17.2.15.1.10.3	Counter32	0
dot1dStpPortForwardTransitions.4	.1.3.6.1.2.1.17.2.15.1.10.4	Counter32	0
dot1dStpPortForwardTransitions.5	.1.3.6.1.2.1.17.2.15.1.10.5	Counter32	0
dot1dStpPortForwardTransitions.6	.1.3.6.1.2.1.17.2.15.1.10.6	Counter32	0
dot1dStpPortForwardTransitions.7	.1.3.6.1.2.1.17.2.15.1.10.7	Counter32	0
dot1dStpPortForwardTransitions.8	.1.3.6.1.2.1.17.2.15.1.10.8	Counter32	0
dot1dStpPortForwardTransitions.9	.1.3.6.1.2.1.17.2.15.1.10.9	Counter32	0
dot1dStpPortForwardTransitions.10	.1.3.6.1.2.1.17.2.15.1.10.10	Counter32	0
dot1dStpPortForwardTransitions.11	.1.3.6.1.2.1.17.2.15.1.10.11	Counter32	0
dot1dStpPortForwardTransitions.12	.1.3.6.1.2.1.17.2.15.1.10.12	Counter32	0
dot1dStpPortForwardTransitions.13	.1.3.6.1.2.1.17.2.15.1.10.13	Counter32	0
dot1dStpPortForwardTransitions.14	.1.3.6.1.2.1.17.2.15.1.10.14	Counter32	0
dot1dStpPortForwardTransitions.15	.1.3.6.1.2.1.17.2.15.1.10.15	Counter32	0
dot1dStpPortForwardTransitions.16	.1.3.6.1.2.1.17.2.15.1.10.16	Counter32	0
dot1dStpPortForwardTransitions.17	.1.3.6.1.2.1.17.2.15.1.10.17	Counter32	0
dot1dStpPortForwardTransitions.18	.1.3.6.1.2.1.17.2.15.1.10.18	Counter32	0
dot1dStpPortForwardTransitions.19	.1.3.6.1.2.1.17.2.15.1.10.19	Counter32	0
dot1dStpPortForwardTransitions.20	.1.3.6.1.2.1.17.2.15.1.10.20	Counter32	0
dot1dStpPortForwardTransitions.21	.1.3.6.1.2.1.17.2.15.1.10.21	Counter32	0
dot1dStpPortForwardTransitions.22	.1.3.6.1.2.1.17.2.15.1.10.22	Counter32	0
dot1dStpPortForwardTransitions.23	.1.3.6.1.2.1.17.2.15.1.10.23	Counter32	0
dot1dStpPortForwardTransitions.24	.1.3.6.1.2.1.17.2.15.1.10.24	Counter32	0
dot1dStpPortForwardTransitions.25	.1.3.6.1.2.1.17.2.15.1.10.25	Counter32	0
dot1dStpPortForwardTransitions.26	.1.3.6.1.2.1.17.2.15.1.10.26	Counter32	0
dot1dStpPortForwardTransitions.27	.1.3.6.1.2.1.17.2.15.1.10.27	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
dot1dStpPortForwardTransitions.28	.1.3.6.1.2.1.17.2.15.1.10.28	Counter32	0
dot1dStpPortForwardTransitions.29	.1.3.6.1.2.1.17.2.15.1.10.29	Counter32	0
dot1dStpPortForwardTransitions.30	.1.3.6.1.2.1.17.2.15.1.10.30	Counter32	0
dot1dStpPortForwardTransitions.31	.1.3.6.1.2.1.17.2.15.1.10.31	Counter32	0
dot1dStpPortForwardTransitions.32	.1.3.6.1.2.1.17.2.15.1.10.32	Counter32	0
dot1dStpPortForwardTransitions.33	.1.3.6.1.2.1.17.2.15.1.10.33	Counter32	0
dot1dStpPortForwardTransitions.34	.1.3.6.1.2.1.17.2.15.1.10.34	Counter32	0
dot1dStpPortForwardTransitions.35	.1.3.6.1.2.1.17.2.15.1.10.35	Counter32	0
dot1dStpPortForwardTransitions.36	.1.3.6.1.2.1.17.2.15.1.10.36	Counter32	0
dot1dStpPortForwardTransitions.37	.1.3.6.1.2.1.17.2.15.1.10.37	Counter32	0
dot1dStpPortForwardTransitions.38	.1.3.6.1.2.1.17.2.15.1.10.38	Counter32	0
dot1dStpPortForwardTransitions.39	.1.3.6.1.2.1.17.2.15.1.10.39	Counter32	0
dot1dStpPortForwardTransitions.40	.1.3.6.1.2.1.17.2.15.1.10.40	Counter32	0
dot1dStpPortForwardTransitions.41	.1.3.6.1.2.1.17.2.15.1.10.41	Counter32	0
dot1dStpPortForwardTransitions.42	.1.3.6.1.2.1.17.2.15.1.10.42	Counter32	0
dot1dStpPortForwardTransitions.43	.1.3.6.1.2.1.17.2.15.1.10.43	Counter32	0
dot1dStpPortForwardTransitions.44	.1.3.6.1.2.1.17.2.15.1.10.44	Counter32	0
dot1dStpPortForwardTransitions.45	.1.3.6.1.2.1.17.2.15.1.10.45	Counter32	0
dot1dStpPortForwardTransitions.46	.1.3.6.1.2.1.17.2.15.1.10.46	Counter32	0
dot1dStpPortForwardTransitions.47	.1.3.6.1.2.1.17.2.15.1.10.47	Counter32	0
dot1dStpPortForwardTransitions.48	.1.3.6.1.2.1.17.2.15.1.10.48	Counter32	0
dot1dStpPortForwardTransitions.49	.1.3.6.1.2.1.17.2.15.1.10.49	Counter32	0
dot1dStpPortForwardTransitions.50	.1.3.6.1.2.1.17.2.15.1.10.50	Counter32	0
dot1dStpPortForwardTransitions.51	.1.3.6.1.2.1.17.2.15.1.10.51	Counter32	0
dot1dStpPortForwardTransitions.52	.1.3.6.1.2.1.17.2.15.1.10.52	Counter32	0

Name	OID	Value Type	Value Example
dot1dStpPortForwardTransitions.53	.1.3.6.1.2.1.17.2.15.1.10.53	Counter32	0
dot1dStpPortForwardTransitions.54	.1.3.6.1.2.1.17.2.15.1.10.54	Counter32	0
dot1dTpAgingTime.0	.1.3.6.1.2.1.17.4.2.0	Integer	300
dot1dDeviceCapabilities.0	.1.3.6.1.2.1.17.6.1.1.1.0	OctetString	{dot1dTrafficClasses, dot1qStaticEntryIndividualPort, dot1qVLCapable, dot1qConfigurablePvidTagging}
dot1dTrafficClassesEnabled.0	.1.3.6.1.2.1.17.6.1.1.2.0	Integer	true (1)
dot1dPortCapabilities.1	.1.3.6.1.2.1.17.6.1.1.4.1.1.1	OctetString	{}
dot1dPortCapabilities.2	.1.3.6.1.2.1.17.6.1.1.4.1.1.2	OctetString	{}
dot1dPortCapabilities.3	.1.3.6.1.2.1.17.6.1.1.4.1.1.3	OctetString	{}
dot1dPortCapabilities.4	.1.3.6.1.2.1.17.6.1.1.4.1.1.4	OctetString	{}
dot1dPortCapabilities.5	.1.3.6.1.2.1.17.6.1.1.4.1.1.5	OctetString	{}
dot1dPortCapabilities.6	.1.3.6.1.2.1.17.6.1.1.4.1.1.6	OctetString	{}
dot1dPortCapabilities.7	.1.3.6.1.2.1.17.6.1.1.4.1.1.7	OctetString	{}
dot1dPortCapabilities.8	.1.3.6.1.2.1.17.6.1.1.4.1.1.8	OctetString	{}
dot1dPortCapabilities.9	.1.3.6.1.2.1.17.6.1.1.4.1.1.9	OctetString	{}
dot1dPortCapabilities.10	.1.3.6.1.2.1.17.6.1.1.4.1.1.10	OctetString	{}
dot1dPortCapabilities.11	.1.3.6.1.2.1.17.6.1.1.4.1.1.11	OctetString	{}
dot1dPortCapabilities.12	.1.3.6.1.2.1.17.6.1.1.4.1.1.12	OctetString	{}
dot1dPortCapabilities.13	.1.3.6.1.2.1.17.6.1.1.4.1.1.13	OctetString	{}
dot1dPortCapabilities.14	.1.3.6.1.2.1.17.6.1.1.4.1.1.14	OctetString	{}
dot1dPortCapabilities.15	.1.3.6.1.2.1.17.6.1.1.4.1.1.15	OctetString	{}
dot1dPortCapabilities.16	.1.3.6.1.2.1.17.6.1.1.4.1.1.16	OctetString	{}
dot1dPortCapabilities.17	.1.3.6.1.2.1.17.6.1.1.4.1.1.17	OctetString	{}
dot1dPortCapabilities.18	.1.3.6.1.2.1.17.6.1.1.4.1.1.18	OctetString	{}
dot1dPortCapabilities.19	.1.3.6.1.2.1.17.6.1.1.4.1.1.19	OctetString	{}
dot1dPortCapabilities.20	.1.3.6.1.2.1.17.6.1.1.4.1.1.20	OctetString	{}
dot1dPortCapabilities.21	.1.3.6.1.2.1.17.6.1.1.4.1.1.21	OctetString	{}
dot1dPortCapabilities.22	.1.3.6.1.2.1.17.6.1.1.4.1.1.22	OctetString	{}
dot1dPortCapabilities.23	.1.3.6.1.2.1.17.6.1.1.4.1.1.23	OctetString	{}
dot1dPortCapabilities.24	.1.3.6.1.2.1.17.6.1.1.4.1.1.24	OctetString	{}
dot1dPortCapabilities.25	.1.3.6.1.2.1.17.6.1.1.4.1.1.25	OctetString	{}
dot1dPortCapabilities.26	.1.3.6.1.2.1.17.6.1.1.4.1.1.26	OctetString	{}
dot1dPortCapabilities.27	.1.3.6.1.2.1.17.6.1.1.4.1.1.27	OctetString	{}
dot1dPortCapabilities.28	.1.3.6.1.2.1.17.6.1.1.4.1.1.28	OctetString	{}
dot1dPortCapabilities.29	.1.3.6.1.2.1.17.6.1.1.4.1.1.29	OctetString	{}
dot1dPortCapabilities.30	.1.3.6.1.2.1.17.6.1.1.4.1.1.30	OctetString	{}
dot1dPortCapabilities.31	.1.3.6.1.2.1.17.6.1.1.4.1.1.31	OctetString	{}
dot1dPortCapabilities.32	.1.3.6.1.2.1.17.6.1.1.4.1.1.32	OctetString	{}
dot1dPortCapabilities.33	.1.3.6.1.2.1.17.6.1.1.4.1.1.33	OctetString	{}
dot1dPortCapabilities.34	.1.3.6.1.2.1.17.6.1.1.4.1.1.34	OctetString	{}

Name	OID	Value Type	Value Example
dot1dPortCapabilities.35	.1.3.6.1.2.1.17.6.1.1.4.1.1.35	OctetString	{}
dot1dPortCapabilities.36	.1.3.6.1.2.1.17.6.1.1.4.1.1.36	OctetString	{}
dot1dPortCapabilities.37	.1.3.6.1.2.1.17.6.1.1.4.1.1.37	OctetString	{}
dot1dPortCapabilities.38	.1.3.6.1.2.1.17.6.1.1.4.1.1.38	OctetString	{}
dot1dPortCapabilities.39	.1.3.6.1.2.1.17.6.1.1.4.1.1.39	OctetString	{}
dot1dPortCapabilities.40	.1.3.6.1.2.1.17.6.1.1.4.1.1.40	OctetString	{}
dot1dPortCapabilities.41	.1.3.6.1.2.1.17.6.1.1.4.1.1.41	OctetString	{}
dot1dPortCapabilities.42	.1.3.6.1.2.1.17.6.1.1.4.1.1.42	OctetString	{}
dot1dPortCapabilities.43	.1.3.6.1.2.1.17.6.1.1.4.1.1.43	OctetString	{}
dot1dPortCapabilities.44	.1.3.6.1.2.1.17.6.1.1.4.1.1.44	OctetString	{}
dot1dPortCapabilities.45	.1.3.6.1.2.1.17.6.1.1.4.1.1.45	OctetString	{}
dot1dPortCapabilities.46	.1.3.6.1.2.1.17.6.1.1.4.1.1.46	OctetString	{}
dot1dPortCapabilities.47	.1.3.6.1.2.1.17.6.1.1.4.1.1.47	OctetString	{}
dot1dPortCapabilities.48	.1.3.6.1.2.1.17.6.1.1.4.1.1.48	OctetString	{}
dot1dPortCapabilities.49	.1.3.6.1.2.1.17.6.1.1.4.1.1.49	OctetString	{}
dot1dPortCapabilities.50	.1.3.6.1.2.1.17.6.1.1.4.1.1.50	OctetString	{}
dot1dPortCapabilities.51	.1.3.6.1.2.1.17.6.1.1.4.1.1.51	OctetString	{}
dot1dPortCapabilities.52	.1.3.6.1.2.1.17.6.1.1.4.1.1.52	OctetString	{}
dot1dPortCapabilities.53	.1.3.6.1.2.1.17.6.1.1.4.1.1.53	OctetString	{}
dot1dPortCapabilities.54	.1.3.6.1.2.1.17.6.1.1.4.1.1.54	OctetString	{}
ifMauIfIndex.1.1	.1.3.6.1.2.1.26.2.1.1.1.1.1	Integer	1
ifMauIfIndex.2.1	.1.3.6.1.2.1.26.2.1.1.1.2.1	Integer	2
ifMauIfIndex.3.1	.1.3.6.1.2.1.26.2.1.1.1.3.1	Integer	3
ifMauIfIndex.4.1	.1.3.6.1.2.1.26.2.1.1.1.4.1	Integer	4
ifMauIfIndex.5.1	.1.3.6.1.2.1.26.2.1.1.1.5.1	Integer	5
ifMauIfIndex.6.1	.1.3.6.1.2.1.26.2.1.1.1.6.1	Integer	6
ifMauIfIndex.7.1	.1.3.6.1.2.1.26.2.1.1.1.7.1	Integer	7
ifMauIfIndex.8.1	.1.3.6.1.2.1.26.2.1.1.1.8.1	Integer	8
ifMauIfIndex.9.1	.1.3.6.1.2.1.26.2.1.1.1.9.1	Integer	9
ifMauIfIndex.10.1	.1.3.6.1.2.1.26.2.1.1.1.10.1	Integer	10
ifMauIfIndex.11.1	.1.3.6.1.2.1.26.2.1.1.1.11.1	Integer	11
ifMauIfIndex.12.1	.1.3.6.1.2.1.26.2.1.1.1.12.1	Integer	12
ifMauIfIndex.13.1	.1.3.6.1.2.1.26.2.1.1.1.13.1	Integer	13
ifMauIfIndex.14.1	.1.3.6.1.2.1.26.2.1.1.1.14.1	Integer	14
ifMauIfIndex.15.1	.1.3.6.1.2.1.26.2.1.1.1.15.1	Integer	15
ifMauIfIndex.16.1	.1.3.6.1.2.1.26.2.1.1.1.16.1	Integer	16
ifMauIfIndex.17.1	.1.3.6.1.2.1.26.2.1.1.1.17.1	Integer	17
ifMauIfIndex.18.1	.1.3.6.1.2.1.26.2.1.1.1.18.1	Integer	18
ifMauIfIndex.19.1	.1.3.6.1.2.1.26.2.1.1.1.19.1	Integer	19
ifMauIfIndex.20.1	.1.3.6.1.2.1.26.2.1.1.1.20.1	Integer	20
ifMauIfIndex.21.1	.1.3.6.1.2.1.26.2.1.1.1.21.1	Integer	21
ifMauIfIndex.22.1	.1.3.6.1.2.1.26.2.1.1.1.22.1	Integer	22
ifMauIfIndex.23.1	.1.3.6.1.2.1.26.2.1.1.1.23.1	Integer	23

Name	OID	Value Type	Value Example
ifMaulfIndex.24.1	.1.3.6.1.2.1.26.2.1.1.1.24.1	Integer	24
ifMaulfIndex.25.1	.1.3.6.1.2.1.26.2.1.1.1.25.1	Integer	25
ifMaulfIndex.26.1	.1.3.6.1.2.1.26.2.1.1.1.26.1	Integer	26
ifMaulfIndex.27.1	.1.3.6.1.2.1.26.2.1.1.1.27.1	Integer	27
ifMaulfIndex.28.1	.1.3.6.1.2.1.26.2.1.1.1.28.1	Integer	28
ifMaulfIndex.29.1	.1.3.6.1.2.1.26.2.1.1.1.29.1	Integer	29
ifMaulfIndex.30.1	.1.3.6.1.2.1.26.2.1.1.1.30.1	Integer	30
ifMaulfIndex.31.1	.1.3.6.1.2.1.26.2.1.1.1.31.1	Integer	31
ifMaulfIndex.32.1	.1.3.6.1.2.1.26.2.1.1.1.32.1	Integer	32
ifMaulfIndex.33.1	.1.3.6.1.2.1.26.2.1.1.1.33.1	Integer	33
ifMaulfIndex.34.1	.1.3.6.1.2.1.26.2.1.1.1.34.1	Integer	34
ifMaulfIndex.35.1	.1.3.6.1.2.1.26.2.1.1.1.35.1	Integer	35
ifMaulfIndex.36.1	.1.3.6.1.2.1.26.2.1.1.1.36.1	Integer	36
ifMaulfIndex.37.1	.1.3.6.1.2.1.26.2.1.1.1.37.1	Integer	37
ifMaulfIndex.38.1	.1.3.6.1.2.1.26.2.1.1.1.38.1	Integer	38
ifMaulfIndex.39.1	.1.3.6.1.2.1.26.2.1.1.1.39.1	Integer	39
ifMaulfIndex.40.1	.1.3.6.1.2.1.26.2.1.1.1.40.1	Integer	40
ifMaulfIndex.41.1	.1.3.6.1.2.1.26.2.1.1.1.41.1	Integer	41
ifMaulfIndex.42.1	.1.3.6.1.2.1.26.2.1.1.1.42.1	Integer	42
ifMaulfIndex.43.1	.1.3.6.1.2.1.26.2.1.1.1.43.1	Integer	43
ifMaulfIndex.44.1	.1.3.6.1.2.1.26.2.1.1.1.44.1	Integer	44
ifMaulfIndex.45.1	.1.3.6.1.2.1.26.2.1.1.1.45.1	Integer	45
ifMaulfIndex.46.1	.1.3.6.1.2.1.26.2.1.1.1.46.1	Integer	46
ifMaulfIndex.47.1	.1.3.6.1.2.1.26.2.1.1.1.47.1	Integer	47
ifMaulfIndex.48.1	.1.3.6.1.2.1.26.2.1.1.1.48.1	Integer	48
ifMaulfIndex.49.1	.1.3.6.1.2.1.26.2.1.1.1.49.1	Integer	49
ifMaulfIndex.50.1	.1.3.6.1.2.1.26.2.1.1.1.50.1	Integer	50
ifMaulfIndex.51.1	.1.3.6.1.2.1.26.2.1.1.1.51.1	Integer	51
ifMaulfIndex.52.1	.1.3.6.1.2.1.26.2.1.1.1.52.1	Integer	52
ifMaulfIndex.53.1	.1.3.6.1.2.1.26.2.1.1.1.53.1	Integer	53
ifMaulfIndex.54.1	.1.3.6.1.2.1.26.2.1.1.1.54.1	Integer	54
ifMaulIndex.1.1	.1.3.6.1.2.1.26.2.1.1.2.1.1	Integer	1
ifMaulIndex.2.1	.1.3.6.1.2.1.26.2.1.1.2.2.1	Integer	1
ifMaulIndex.3.1	.1.3.6.1.2.1.26.2.1.1.2.3.1	Integer	1
ifMaulIndex.4.1	.1.3.6.1.2.1.26.2.1.1.2.4.1	Integer	1
ifMaulIndex.5.1	.1.3.6.1.2.1.26.2.1.1.2.5.1	Integer	1
ifMaulIndex.6.1	.1.3.6.1.2.1.26.2.1.1.2.6.1	Integer	1
ifMaulIndex.7.1	.1.3.6.1.2.1.26.2.1.1.2.7.1	Integer	1
ifMaulIndex.8.1	.1.3.6.1.2.1.26.2.1.1.2.8.1	Integer	1
ifMaulIndex.9.1	.1.3.6.1.2.1.26.2.1.1.2.9.1	Integer	1
ifMaulIndex.10.1	.1.3.6.1.2.1.26.2.1.1.2.10.1	Integer	1
ifMaulIndex.11.1	.1.3.6.1.2.1.26.2.1.1.2.11.1	Integer	1
ifMaulIndex.12.1	.1.3.6.1.2.1.26.2.1.1.2.12.1	Integer	1



Name	OID	Value Type	Value Example
ifMauIndex.13.1	.1.3.6.1.2.1.26.2.1.1.2.13.1	Integer	1
ifMauIndex.14.1	.1.3.6.1.2.1.26.2.1.1.2.14.1	Integer	1
ifMauIndex.15.1	.1.3.6.1.2.1.26.2.1.1.2.15.1	Integer	1
ifMauIndex.16.1	.1.3.6.1.2.1.26.2.1.1.2.16.1	Integer	1
ifMauIndex.17.1	.1.3.6.1.2.1.26.2.1.1.2.17.1	Integer	1
ifMauIndex.18.1	.1.3.6.1.2.1.26.2.1.1.2.18.1	Integer	1
ifMauIndex.19.1	.1.3.6.1.2.1.26.2.1.1.2.19.1	Integer	1
ifMauIndex.20.1	.1.3.6.1.2.1.26.2.1.1.2.20.1	Integer	1
ifMauIndex.21.1	.1.3.6.1.2.1.26.2.1.1.2.21.1	Integer	1
ifMauIndex.22.1	.1.3.6.1.2.1.26.2.1.1.2.22.1	Integer	1
ifMauIndex.23.1	.1.3.6.1.2.1.26.2.1.1.2.23.1	Integer	1
ifMauIndex.24.1	.1.3.6.1.2.1.26.2.1.1.2.24.1	Integer	1
ifMauIndex.25.1	.1.3.6.1.2.1.26.2.1.1.2.25.1	Integer	1
ifMauIndex.26.1	.1.3.6.1.2.1.26.2.1.1.2.26.1	Integer	1
ifMauIndex.27.1	.1.3.6.1.2.1.26.2.1.1.2.27.1	Integer	1
ifMauIndex.28.1	.1.3.6.1.2.1.26.2.1.1.2.28.1	Integer	1
ifMauIndex.29.1	.1.3.6.1.2.1.26.2.1.1.2.29.1	Integer	1
ifMauIndex.30.1	.1.3.6.1.2.1.26.2.1.1.2.30.1	Integer	1
ifMauIndex.31.1	.1.3.6.1.2.1.26.2.1.1.2.31.1	Integer	1
ifMauIndex.32.1	.1.3.6.1.2.1.26.2.1.1.2.32.1	Integer	1
ifMauIndex.33.1	.1.3.6.1.2.1.26.2.1.1.2.33.1	Integer	1
ifMauIndex.34.1	.1.3.6.1.2.1.26.2.1.1.2.34.1	Integer	1
ifMauIndex.35.1	.1.3.6.1.2.1.26.2.1.1.2.35.1	Integer	1
ifMauIndex.36.1	.1.3.6.1.2.1.26.2.1.1.2.36.1	Integer	1
ifMauIndex.37.1	.1.3.6.1.2.1.26.2.1.1.2.37.1	Integer	1
ifMauIndex.38.1	.1.3.6.1.2.1.26.2.1.1.2.38.1	Integer	1
ifMauIndex.39.1	.1.3.6.1.2.1.26.2.1.1.2.39.1	Integer	1
ifMauIndex.40.1	.1.3.6.1.2.1.26.2.1.1.2.40.1	Integer	1
ifMauIndex.41.1	.1.3.6.1.2.1.26.2.1.1.2.41.1	Integer	1
ifMauIndex.42.1	.1.3.6.1.2.1.26.2.1.1.2.42.1	Integer	1
ifMauIndex.43.1	.1.3.6.1.2.1.26.2.1.1.2.43.1	Integer	1
ifMauIndex.44.1	.1.3.6.1.2.1.26.2.1.1.2.44.1	Integer	1
ifMauIndex.45.1	.1.3.6.1.2.1.26.2.1.1.2.45.1	Integer	1
ifMauIndex.46.1	.1.3.6.1.2.1.26.2.1.1.2.46.1	Integer	1
ifMauIndex.47.1	.1.3.6.1.2.1.26.2.1.1.2.47.1	Integer	1
ifMauIndex.48.1	.1.3.6.1.2.1.26.2.1.1.2.48.1	Integer	1
ifMauIndex.49.1	.1.3.6.1.2.1.26.2.1.1.2.49.1	Integer	1
ifMauIndex.50.1	.1.3.6.1.2.1.26.2.1.1.2.50.1	Integer	1
ifMauIndex.51.1	.1.3.6.1.2.1.26.2.1.1.2.51.1	Integer	1
ifMauIndex.52.1	.1.3.6.1.2.1.26.2.1.1.2.52.1	Integer	1
ifMauIndex.53.1	.1.3.6.1.2.1.26.2.1.1.2.53.1	Integer	1
ifMauIndex.54.1	.1.3.6.1.2.1.26.2.1.1.2.54.1	Integer	1
ifMauType.1.1	.1.3.6.1.2.1.26.2.1.1.3.1.1	OID	dot3MauType1000BaseTFD

Name	OID	Value Type	Value Example
ifMauType.2.1	.1.3.6.1.2.1.26.2.1.1.3.2.1	OID	.0.0
ifMauType.3.1	.1.3.6.1.2.1.26.2.1.1.3.3.1	OID	.0.0
ifMauType.4.1	.1.3.6.1.2.1.26.2.1.1.3.4.1	OID	.0.0
ifMauType.5.1	.1.3.6.1.2.1.26.2.1.1.3.5.1	OID	.0.0
ifMauType.6.1	.1.3.6.1.2.1.26.2.1.1.3.6.1	OID	.0.0
ifMauType.7.1	.1.3.6.1.2.1.26.2.1.1.3.7.1	OID	.0.0
ifMauType.8.1	.1.3.6.1.2.1.26.2.1.1.3.8.1	OID	.0.0
ifMauType.9.1	.1.3.6.1.2.1.26.2.1.1.3.9.1	OID	.0.0
ifMauType.10.1	.1.3.6.1.2.1.26.2.1.1.3.10.1	OID	.0.0
ifMauType.11.1	.1.3.6.1.2.1.26.2.1.1.3.11.1	OID	.0.0
ifMauType.12.1	.1.3.6.1.2.1.26.2.1.1.3.12.1	OID	.0.0
ifMauType.13.1	.1.3.6.1.2.1.26.2.1.1.3.13.1	OID	.0.0
ifMauType.14.1	.1.3.6.1.2.1.26.2.1.1.3.14.1	OID	.0.0
ifMauType.15.1	.1.3.6.1.2.1.26.2.1.1.3.15.1	OID	.0.0
ifMauType.16.1	.1.3.6.1.2.1.26.2.1.1.3.16.1	OID	.0.0
ifMauType.17.1	.1.3.6.1.2.1.26.2.1.1.3.17.1	OID	.0.0
ifMauType.18.1	.1.3.6.1.2.1.26.2.1.1.3.18.1	OID	.0.0
ifMauType.19.1	.1.3.6.1.2.1.26.2.1.1.3.19.1	OID	.0.0
ifMauType.20.1	.1.3.6.1.2.1.26.2.1.1.3.20.1	OID	.0.0
ifMauType.21.1	.1.3.6.1.2.1.26.2.1.1.3.21.1	OID	.0.0
ifMauType.22.1	.1.3.6.1.2.1.26.2.1.1.3.22.1	OID	.0.0
ifMauType.23.1	.1.3.6.1.2.1.26.2.1.1.3.23.1	OID	.0.0
ifMauType.24.1	.1.3.6.1.2.1.26.2.1.1.3.24.1	OID	.0.0
ifMauType.25.1	.1.3.6.1.2.1.26.2.1.1.3.25.1	OID	.0.0
ifMauType.26.1	.1.3.6.1.2.1.26.2.1.1.3.26.1	OID	.0.0
ifMauType.27.1	.1.3.6.1.2.1.26.2.1.1.3.27.1	OID	.0.0
ifMauType.28.1	.1.3.6.1.2.1.26.2.1.1.3.28.1	OID	.0.0
ifMauType.29.1	.1.3.6.1.2.1.26.2.1.1.3.29.1	OID	.0.0
ifMauType.30.1	.1.3.6.1.2.1.26.2.1.1.3.30.1	OID	.0.0
ifMauType.31.1	.1.3.6.1.2.1.26.2.1.1.3.31.1	OID	.0.0
ifMauType.32.1	.1.3.6.1.2.1.26.2.1.1.3.32.1	OID	.0.0
ifMauType.33.1	.1.3.6.1.2.1.26.2.1.1.3.33.1	OID	.0.0
ifMauType.34.1	.1.3.6.1.2.1.26.2.1.1.3.34.1	OID	.0.0
ifMauType.35.1	.1.3.6.1.2.1.26.2.1.1.3.35.1	OID	.0.0
ifMauType.36.1	.1.3.6.1.2.1.26.2.1.1.3.36.1	OID	.0.0
ifMauType.37.1	.1.3.6.1.2.1.26.2.1.1.3.37.1	OID	.0.0
ifMauType.38.1	.1.3.6.1.2.1.26.2.1.1.3.38.1	OID	.0.0
ifMauType.39.1	.1.3.6.1.2.1.26.2.1.1.3.39.1	OID	.0.0
ifMauType.40.1	.1.3.6.1.2.1.26.2.1.1.3.40.1	OID	.0.0
ifMauType.41.1	.1.3.6.1.2.1.26.2.1.1.3.41.1	OID	.0.0
ifMauType.42.1	.1.3.6.1.2.1.26.2.1.1.3.42.1	OID	.0.0
ifMauType.43.1	.1.3.6.1.2.1.26.2.1.1.3.43.1	OID	.0.0
ifMauType.44.1	.1.3.6.1.2.1.26.2.1.1.3.44.1	OID	.0.0

Name	OID	Value Type	Value Example
ifMauType.45.1	.1.3.6.1.2.1.26.2.1.1.3.45.1	OID	.0.0
ifMauType.46.1	.1.3.6.1.2.1.26.2.1.1.3.46.1	OID	.0.0
ifMauType.47.1	.1.3.6.1.2.1.26.2.1.1.3.47.1	OID	.0.0
ifMauType.48.1	.1.3.6.1.2.1.26.2.1.1.3.48.1	OID	.0.0
ifMauType.49.1	.1.3.6.1.2.1.26.2.1.1.3.49.1	OID	.0.0
ifMauType.50.1	.1.3.6.1.2.1.26.2.1.1.3.50.1	OID	.0.0
ifMauType.51.1	.1.3.6.1.2.1.26.2.1.1.3.51.1	OID	.0.0
ifMauType.52.1	.1.3.6.1.2.1.26.2.1.1.3.52.1	OID	.0.0
ifMauType.53.1	.1.3.6.1.2.1.26.2.1.1.3.53.1	OID	.0.0
ifMauType.54.1	.1.3.6.1.2.1.26.2.1.1.3.54.1	OID	.0.0
ifMauStatus.1.1	.1.3.6.1.2.1.26.2.1.1.4.1.1	Integer	operational (3)
ifMauStatus.2.1	.1.3.6.1.2.1.26.2.1.1.4.2.1	Integer	shutdown (5)
ifMauStatus.3.1	.1.3.6.1.2.1.26.2.1.1.4.3.1	Integer	shutdown (5)
ifMauStatus.4.1	.1.3.6.1.2.1.26.2.1.1.4.4.1	Integer	shutdown (5)
ifMauStatus.5.1	.1.3.6.1.2.1.26.2.1.1.4.5.1	Integer	shutdown (5)
ifMauStatus.6.1	.1.3.6.1.2.1.26.2.1.1.4.6.1	Integer	shutdown (5)
ifMauStatus.7.1	.1.3.6.1.2.1.26.2.1.1.4.7.1	Integer	shutdown (5)
ifMauStatus.8.1	.1.3.6.1.2.1.26.2.1.1.4.8.1	Integer	shutdown (5)
ifMauStatus.9.1	.1.3.6.1.2.1.26.2.1.1.4.9.1	Integer	shutdown (5)
ifMauStatus.10.1	.1.3.6.1.2.1.26.2.1.1.4.10.1	Integer	shutdown (5)
ifMauStatus.11.1	.1.3.6.1.2.1.26.2.1.1.4.11.1	Integer	shutdown (5)
ifMauStatus.12.1	.1.3.6.1.2.1.26.2.1.1.4.12.1	Integer	shutdown (5)
ifMauStatus.13.1	.1.3.6.1.2.1.26.2.1.1.4.13.1	Integer	shutdown (5)
ifMauStatus.14.1	.1.3.6.1.2.1.26.2.1.1.4.14.1	Integer	shutdown (5)
ifMauStatus.15.1	.1.3.6.1.2.1.26.2.1.1.4.15.1	Integer	shutdown (5)
ifMauStatus.16.1	.1.3.6.1.2.1.26.2.1.1.4.16.1	Integer	shutdown (5)
ifMauStatus.17.1	.1.3.6.1.2.1.26.2.1.1.4.17.1	Integer	shutdown (5)
ifMauStatus.18.1	.1.3.6.1.2.1.26.2.1.1.4.18.1	Integer	shutdown (5)
ifMauStatus.19.1	.1.3.6.1.2.1.26.2.1.1.4.19.1	Integer	shutdown (5)
ifMauStatus.20.1	.1.3.6.1.2.1.26.2.1.1.4.20.1	Integer	shutdown (5)
ifMauStatus.21.1	.1.3.6.1.2.1.26.2.1.1.4.21.1	Integer	shutdown (5)
ifMauStatus.22.1	.1.3.6.1.2.1.26.2.1.1.4.22.1	Integer	shutdown (5)
ifMauStatus.23.1	.1.3.6.1.2.1.26.2.1.1.4.23.1	Integer	shutdown (5)
ifMauStatus.24.1	.1.3.6.1.2.1.26.2.1.1.4.24.1	Integer	shutdown (5)
ifMauStatus.25.1	.1.3.6.1.2.1.26.2.1.1.4.25.1	Integer	shutdown (5)
ifMauStatus.26.1	.1.3.6.1.2.1.26.2.1.1.4.26.1	Integer	shutdown (5)
ifMauStatus.27.1	.1.3.6.1.2.1.26.2.1.1.4.27.1	Integer	shutdown (5)
ifMauStatus.28.1	.1.3.6.1.2.1.26.2.1.1.4.28.1	Integer	shutdown (5)
ifMauStatus.29.1	.1.3.6.1.2.1.26.2.1.1.4.29.1	Integer	shutdown (5)
ifMauStatus.30.1	.1.3.6.1.2.1.26.2.1.1.4.30.1	Integer	shutdown (5)
ifMauStatus.31.1	.1.3.6.1.2.1.26.2.1.1.4.31.1	Integer	shutdown (5)
ifMauStatus.32.1	.1.3.6.1.2.1.26.2.1.1.4.32.1	Integer	shutdown (5)
ifMauStatus.33.1	.1.3.6.1.2.1.26.2.1.1.4.33.1	Integer	shutdown (5)

Name	OID	Value Type	Value Example
ifMauStatus.34.1	.1.3.6.1.2.1.26.2.1.1.4.34.1	Integer	shutdown (5)
ifMauStatus.35.1	.1.3.6.1.2.1.26.2.1.1.4.35.1	Integer	shutdown (5)
ifMauStatus.36.1	.1.3.6.1.2.1.26.2.1.1.4.36.1	Integer	shutdown (5)
ifMauStatus.37.1	.1.3.6.1.2.1.26.2.1.1.4.37.1	Integer	shutdown (5)
ifMauStatus.38.1	.1.3.6.1.2.1.26.2.1.1.4.38.1	Integer	shutdown (5)
ifMauStatus.39.1	.1.3.6.1.2.1.26.2.1.1.4.39.1	Integer	shutdown (5)
ifMauStatus.40.1	.1.3.6.1.2.1.26.2.1.1.4.40.1	Integer	shutdown (5)
ifMauStatus.41.1	.1.3.6.1.2.1.26.2.1.1.4.41.1	Integer	shutdown (5)
ifMauStatus.42.1	.1.3.6.1.2.1.26.2.1.1.4.42.1	Integer	shutdown (5)
ifMauStatus.43.1	.1.3.6.1.2.1.26.2.1.1.4.43.1	Integer	shutdown (5)
ifMauStatus.44.1	.1.3.6.1.2.1.26.2.1.1.4.44.1	Integer	shutdown (5)
ifMauStatus.45.1	.1.3.6.1.2.1.26.2.1.1.4.45.1	Integer	shutdown (5)
ifMauStatus.46.1	.1.3.6.1.2.1.26.2.1.1.4.46.1	Integer	shutdown (5)
ifMauStatus.47.1	.1.3.6.1.2.1.26.2.1.1.4.47.1	Integer	shutdown (5)
ifMauStatus.48.1	.1.3.6.1.2.1.26.2.1.1.4.48.1	Integer	shutdown (5)
ifMauStatus.49.1	.1.3.6.1.2.1.26.2.1.1.4.49.1	Integer	shutdown (5)
ifMauStatus.50.1	.1.3.6.1.2.1.26.2.1.1.4.50.1	Integer	shutdown (5)
ifMauStatus.51.1	.1.3.6.1.2.1.26.2.1.1.4.51.1	Integer	shutdown (5)
ifMauStatus.52.1	.1.3.6.1.2.1.26.2.1.1.4.52.1	Integer	shutdown (5)
ifMauStatus.53.1	.1.3.6.1.2.1.26.2.1.1.4.53.1	Integer	shutdown (5)
ifMauStatus.54.1	.1.3.6.1.2.1.26.2.1.1.4.54.1	Integer	shutdown (5)
ifMauMediaAvailable.1.1	.1.3.6.1.2.1.26.2.1.1.5.1.1	Integer	available (3)
ifMauMediaAvailable.2.1	.1.3.6.1.2.1.26.2.1.1.5.2.1	Integer	notAvailable (4)
ifMauMediaAvailable.3.1	.1.3.6.1.2.1.26.2.1.1.5.3.1	Integer	notAvailable (4)
ifMauMediaAvailable.4.1	.1.3.6.1.2.1.26.2.1.1.5.4.1	Integer	notAvailable (4)
ifMauMediaAvailable.5.1	.1.3.6.1.2.1.26.2.1.1.5.5.1	Integer	notAvailable (4)
ifMauMediaAvailable.6.1	.1.3.6.1.2.1.26.2.1.1.5.6.1	Integer	notAvailable (4)
ifMauMediaAvailable.7.1	.1.3.6.1.2.1.26.2.1.1.5.7.1	Integer	notAvailable (4)
ifMauMediaAvailable.8.1	.1.3.6.1.2.1.26.2.1.1.5.8.1	Integer	notAvailable (4)
ifMauMediaAvailable.9.1	.1.3.6.1.2.1.26.2.1.1.5.9.1	Integer	notAvailable (4)
ifMauMediaAvailable.10.1	.1.3.6.1.2.1.26.2.1.1.5.10.1	Integer	notAvailable (4)
ifMauMediaAvailable.11.1	.1.3.6.1.2.1.26.2.1.1.5.11.1	Integer	notAvailable (4)
ifMauMediaAvailable.12.1	.1.3.6.1.2.1.26.2.1.1.5.12.1	Integer	notAvailable (4)
ifMauMediaAvailable.13.1	.1.3.6.1.2.1.26.2.1.1.5.13.1	Integer	notAvailable (4)
ifMauMediaAvailable.14.1	.1.3.6.1.2.1.26.2.1.1.5.14.1	Integer	notAvailable (4)
ifMauMediaAvailable.15.1	.1.3.6.1.2.1.26.2.1.1.5.15.1	Integer	notAvailable (4)
ifMauMediaAvailable.16.1	.1.3.6.1.2.1.26.2.1.1.5.16.1	Integer	notAvailable (4)
ifMauMediaAvailable.17.1	.1.3.6.1.2.1.26.2.1.1.5.17.1	Integer	notAvailable (4)
ifMauMediaAvailable.18.1	.1.3.6.1.2.1.26.2.1.1.5.18.1	Integer	notAvailable (4)
ifMauMediaAvailable.19.1	.1.3.6.1.2.1.26.2.1.1.5.19.1	Integer	notAvailable (4)
ifMauMediaAvailable.20.1	.1.3.6.1.2.1.26.2.1.1.5.20.1	Integer	notAvailable (4)
ifMauMediaAvailable.21.1	.1.3.6.1.2.1.26.2.1.1.5.21.1	Integer	notAvailable (4)
ifMauMediaAvailable.22.1	.1.3.6.1.2.1.26.2.1.1.5.22.1	Integer	notAvailable (4)

Name	OID	Value Type	Value Example
ifMauMediaAvailable.23.1	.1.3.6.1.2.1.26.2.1.1.5.23.1	Integer	notAvailable (4)
ifMauMediaAvailable.24.1	.1.3.6.1.2.1.26.2.1.1.5.24.1	Integer	notAvailable (4)
ifMauMediaAvailable.25.1	.1.3.6.1.2.1.26.2.1.1.5.25.1	Integer	notAvailable (4)
ifMauMediaAvailable.26.1	.1.3.6.1.2.1.26.2.1.1.5.26.1	Integer	notAvailable (4)
ifMauMediaAvailable.27.1	.1.3.6.1.2.1.26.2.1.1.5.27.1	Integer	notAvailable (4)
ifMauMediaAvailable.28.1	.1.3.6.1.2.1.26.2.1.1.5.28.1	Integer	notAvailable (4)
ifMauMediaAvailable.29.1	.1.3.6.1.2.1.26.2.1.1.5.29.1	Integer	notAvailable (4)
ifMauMediaAvailable.30.1	.1.3.6.1.2.1.26.2.1.1.5.30.1	Integer	notAvailable (4)
ifMauMediaAvailable.31.1	.1.3.6.1.2.1.26.2.1.1.5.31.1	Integer	notAvailable (4)
ifMauMediaAvailable.32.1	.1.3.6.1.2.1.26.2.1.1.5.32.1	Integer	notAvailable (4)
ifMauMediaAvailable.33.1	.1.3.6.1.2.1.26.2.1.1.5.33.1	Integer	notAvailable (4)
ifMauMediaAvailable.34.1	.1.3.6.1.2.1.26.2.1.1.5.34.1	Integer	notAvailable (4)
ifMauMediaAvailable.35.1	.1.3.6.1.2.1.26.2.1.1.5.35.1	Integer	notAvailable (4)
ifMauMediaAvailable.36.1	.1.3.6.1.2.1.26.2.1.1.5.36.1	Integer	notAvailable (4)
ifMauMediaAvailable.37.1	.1.3.6.1.2.1.26.2.1.1.5.37.1	Integer	notAvailable (4)
ifMauMediaAvailable.38.1	.1.3.6.1.2.1.26.2.1.1.5.38.1	Integer	notAvailable (4)
ifMauMediaAvailable.39.1	.1.3.6.1.2.1.26.2.1.1.5.39.1	Integer	notAvailable (4)
ifMauMediaAvailable.40.1	.1.3.6.1.2.1.26.2.1.1.5.40.1	Integer	notAvailable (4)
ifMauMediaAvailable.41.1	.1.3.6.1.2.1.26.2.1.1.5.41.1	Integer	notAvailable (4)
ifMauMediaAvailable.42.1	.1.3.6.1.2.1.26.2.1.1.5.42.1	Integer	notAvailable (4)
ifMauMediaAvailable.43.1	.1.3.6.1.2.1.26.2.1.1.5.43.1	Integer	notAvailable (4)
ifMauMediaAvailable.44.1	.1.3.6.1.2.1.26.2.1.1.5.44.1	Integer	notAvailable (4)
ifMauMediaAvailable.45.1	.1.3.6.1.2.1.26.2.1.1.5.45.1	Integer	notAvailable (4)
ifMauMediaAvailable.46.1	.1.3.6.1.2.1.26.2.1.1.5.46.1	Integer	notAvailable (4)
ifMauMediaAvailable.47.1	.1.3.6.1.2.1.26.2.1.1.5.47.1	Integer	notAvailable (4)
ifMauMediaAvailable.48.1	.1.3.6.1.2.1.26.2.1.1.5.48.1	Integer	notAvailable (4)
ifMauMediaAvailable.49.1	.1.3.6.1.2.1.26.2.1.1.5.49.1	Integer	notAvailable (4)
ifMauMediaAvailable.50.1	.1.3.6.1.2.1.26.2.1.1.5.50.1	Integer	notAvailable (4)
ifMauMediaAvailable.51.1	.1.3.6.1.2.1.26.2.1.1.5.51.1	Integer	notAvailable (4)
ifMauMediaAvailable.52.1	.1.3.6.1.2.1.26.2.1.1.5.52.1	Integer	notAvailable (4)
ifMauMediaAvailable.53.1	.1.3.6.1.2.1.26.2.1.1.5.53.1	Integer	notAvailable (4)
ifMauMediaAvailable.54.1	.1.3.6.1.2.1.26.2.1.1.5.54.1	Integer	notAvailable (4)
ifMauMediaAvailableStateExits.1.1	.1.3.6.1.2.1.26.2.1.1.6.1.1	Counter32	0
ifMauMediaAvailableStateExits.2.1	.1.3.6.1.2.1.26.2.1.1.6.2.1	Counter32	0
ifMauMediaAvailableStateExits.3.1	.1.3.6.1.2.1.26.2.1.1.6.3.1	Counter32	0
ifMauMediaAvailableStateExits.4.1	.1.3.6.1.2.1.26.2.1.1.6.4.1	Counter32	0
ifMauMediaAvailableStateExits.5.1	.1.3.6.1.2.1.26.2.1.1.6.5.1	Counter32	0
ifMauMediaAvailableStateExits.6.1	.1.3.6.1.2.1.26.2.1.1.6.6.1	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ifMauMediaAvailableStateExits.7.1	.1.3.6.1.2.1.26.2.1.1.6.7.1	Counter32	0
ifMauMediaAvailableStateExits.8.1	.1.3.6.1.2.1.26.2.1.1.6.8.1	Counter32	0
ifMauMediaAvailableStateExits.9.1	.1.3.6.1.2.1.26.2.1.1.6.9.1	Counter32	0
ifMauMediaAvailableStateExits.10.1	.1.3.6.1.2.1.26.2.1.1.6.10.1	Counter32	0
ifMauMediaAvailableStateExits.11.1	.1.3.6.1.2.1.26.2.1.1.6.11.1	Counter32	0
ifMauMediaAvailableStateExits.12.1	.1.3.6.1.2.1.26.2.1.1.6.12.1	Counter32	0
ifMauMediaAvailableStateExits.13.1	.1.3.6.1.2.1.26.2.1.1.6.13.1	Counter32	0
ifMauMediaAvailableStateExits.14.1	.1.3.6.1.2.1.26.2.1.1.6.14.1	Counter32	0
ifMauMediaAvailableStateExits.15.1	.1.3.6.1.2.1.26.2.1.1.6.15.1	Counter32	0
ifMauMediaAvailableStateExits.16.1	.1.3.6.1.2.1.26.2.1.1.6.16.1	Counter32	0
ifMauMediaAvailableStateExits.17.1	.1.3.6.1.2.1.26.2.1.1.6.17.1	Counter32	0
ifMauMediaAvailableStateExits.18.1	.1.3.6.1.2.1.26.2.1.1.6.18.1	Counter32	0
ifMauMediaAvailableStateExits.19.1	.1.3.6.1.2.1.26.2.1.1.6.19.1	Counter32	0
ifMauMediaAvailableStateExits.20.1	.1.3.6.1.2.1.26.2.1.1.6.20.1	Counter32	0
ifMauMediaAvailableStateExits.21.1	.1.3.6.1.2.1.26.2.1.1.6.21.1	Counter32	0
ifMauMediaAvailableStateExits.22.1	.1.3.6.1.2.1.26.2.1.1.6.22.1	Counter32	0
ifMauMediaAvailableStateExits.23.1	.1.3.6.1.2.1.26.2.1.1.6.23.1	Counter32	0
ifMauMediaAvailableStateExits.24.1	.1.3.6.1.2.1.26.2.1.1.6.24.1	Counter32	0
ifMauMediaAvailableStateExits.25.1	.1.3.6.1.2.1.26.2.1.1.6.25.1	Counter32	0
ifMauMediaAvailableStateExits.26.1	.1.3.6.1.2.1.26.2.1.1.6.26.1	Counter32	0
ifMauMediaAvailableStateExits.27.1	.1.3.6.1.2.1.26.2.1.1.6.27.1	Counter32	0
ifMauMediaAvailableStateExits.28.1	.1.3.6.1.2.1.26.2.1.1.6.28.1	Counter32	0
ifMauMediaAvailableStateExits.29.1	.1.3.6.1.2.1.26.2.1.1.6.29.1	Counter32	0
ifMauMediaAvailableStateExits.30.1	.1.3.6.1.2.1.26.2.1.1.6.30.1	Counter32	0
ifMauMediaAvailableStateExits.31.1	.1.3.6.1.2.1.26.2.1.1.6.31.1	Counter32	0

Name	OID	Value Type	Value Example
ifMauMediaAvailableStateExits.32.1	.1.3.6.1.2.1.26.2.1.1.6.32.1	Counter32	0
ifMauMediaAvailableStateExits.33.1	.1.3.6.1.2.1.26.2.1.1.6.33.1	Counter32	0
ifMauMediaAvailableStateExits.34.1	.1.3.6.1.2.1.26.2.1.1.6.34.1	Counter32	0
ifMauMediaAvailableStateExits.35.1	.1.3.6.1.2.1.26.2.1.1.6.35.1	Counter32	0
ifMauMediaAvailableStateExits.36.1	.1.3.6.1.2.1.26.2.1.1.6.36.1	Counter32	0
ifMauMediaAvailableStateExits.37.1	.1.3.6.1.2.1.26.2.1.1.6.37.1	Counter32	0
ifMauMediaAvailableStateExits.38.1	.1.3.6.1.2.1.26.2.1.1.6.38.1	Counter32	0
ifMauMediaAvailableStateExits.39.1	.1.3.6.1.2.1.26.2.1.1.6.39.1	Counter32	0
ifMauMediaAvailableStateExits.40.1	.1.3.6.1.2.1.26.2.1.1.6.40.1	Counter32	0
ifMauMediaAvailableStateExits.41.1	.1.3.6.1.2.1.26.2.1.1.6.41.1	Counter32	0
ifMauMediaAvailableStateExits.42.1	.1.3.6.1.2.1.26.2.1.1.6.42.1	Counter32	0
ifMauMediaAvailableStateExits.43.1	.1.3.6.1.2.1.26.2.1.1.6.43.1	Counter32	0
ifMauMediaAvailableStateExits.44.1	.1.3.6.1.2.1.26.2.1.1.6.44.1	Counter32	0
ifMauMediaAvailableStateExits.45.1	.1.3.6.1.2.1.26.2.1.1.6.45.1	Counter32	0
ifMauMediaAvailableStateExits.46.1	.1.3.6.1.2.1.26.2.1.1.6.46.1	Counter32	0
ifMauMediaAvailableStateExits.47.1	.1.3.6.1.2.1.26.2.1.1.6.47.1	Counter32	0
ifMauMediaAvailableStateExits.48.1	.1.3.6.1.2.1.26.2.1.1.6.48.1	Counter32	0
ifMauMediaAvailableStateExits.49.1	.1.3.6.1.2.1.26.2.1.1.6.49.1	Counter32	0
ifMauMediaAvailableStateExits.50.1	.1.3.6.1.2.1.26.2.1.1.6.50.1	Counter32	0
ifMauMediaAvailableStateExits.51.1	.1.3.6.1.2.1.26.2.1.1.6.51.1	Counter32	0
ifMauMediaAvailableStateExits.52.1	.1.3.6.1.2.1.26.2.1.1.6.52.1	Counter32	0
ifMauMediaAvailableStateExits.53.1	.1.3.6.1.2.1.26.2.1.1.6.53.1	Counter32	0
ifMauMediaAvailableStateExits.54.1	.1.3.6.1.2.1.26.2.1.1.6.54.1	Counter32	0
ifMauJabberState.1.1	.1.3.6.1.2.1.26.2.1.1.7.1.1	Integer	other (1)
ifMauJabberState.2.1	.1.3.6.1.2.1.26.2.1.1.7.2.1	Integer	other (1)
ifMauJabberState.3.1	.1.3.6.1.2.1.26.2.1.1.7.3.1	Integer	other (1)
ifMauJabberState.4.1	.1.3.6.1.2.1.26.2.1.1.7.4.1	Integer	other (1)

Name	OID	Value Type	Value Example
ifMauJabberState.5.1	.1.3.6.1.2.1.26.2.1.1.7.5.1	Integer	other (1)
ifMauJabberState.6.1	.1.3.6.1.2.1.26.2.1.1.7.6.1	Integer	other (1)
ifMauJabberState.7.1	.1.3.6.1.2.1.26.2.1.1.7.7.1	Integer	other (1)
ifMauJabberState.8.1	.1.3.6.1.2.1.26.2.1.1.7.8.1	Integer	other (1)
ifMauJabberState.9.1	.1.3.6.1.2.1.26.2.1.1.7.9.1	Integer	other (1)
ifMauJabberState.10.1	.1.3.6.1.2.1.26.2.1.1.7.10.1	Integer	other (1)
ifMauJabberState.11.1	.1.3.6.1.2.1.26.2.1.1.7.11.1	Integer	other (1)
ifMauJabberState.12.1	.1.3.6.1.2.1.26.2.1.1.7.12.1	Integer	other (1)
ifMauJabberState.13.1	.1.3.6.1.2.1.26.2.1.1.7.13.1	Integer	other (1)
ifMauJabberState.14.1	.1.3.6.1.2.1.26.2.1.1.7.14.1	Integer	other (1)
ifMauJabberState.15.1	.1.3.6.1.2.1.26.2.1.1.7.15.1	Integer	other (1)
ifMauJabberState.16.1	.1.3.6.1.2.1.26.2.1.1.7.16.1	Integer	other (1)
ifMauJabberState.17.1	.1.3.6.1.2.1.26.2.1.1.7.17.1	Integer	other (1)
ifMauJabberState.18.1	.1.3.6.1.2.1.26.2.1.1.7.18.1	Integer	other (1)
ifMauJabberState.19.1	.1.3.6.1.2.1.26.2.1.1.7.19.1	Integer	other (1)
ifMauJabberState.20.1	.1.3.6.1.2.1.26.2.1.1.7.20.1	Integer	other (1)
ifMauJabberState.21.1	.1.3.6.1.2.1.26.2.1.1.7.21.1	Integer	other (1)
ifMauJabberState.22.1	.1.3.6.1.2.1.26.2.1.1.7.22.1	Integer	other (1)
ifMauJabberState.23.1	.1.3.6.1.2.1.26.2.1.1.7.23.1	Integer	other (1)
ifMauJabberState.24.1	.1.3.6.1.2.1.26.2.1.1.7.24.1	Integer	other (1)
ifMauJabberState.25.1	.1.3.6.1.2.1.26.2.1.1.7.25.1	Integer	other (1)
ifMauJabberState.26.1	.1.3.6.1.2.1.26.2.1.1.7.26.1	Integer	other (1)
ifMauJabberState.27.1	.1.3.6.1.2.1.26.2.1.1.7.27.1	Integer	other (1)
ifMauJabberState.28.1	.1.3.6.1.2.1.26.2.1.1.7.28.1	Integer	other (1)
ifMauJabberState.29.1	.1.3.6.1.2.1.26.2.1.1.7.29.1	Integer	other (1)
ifMauJabberState.30.1	.1.3.6.1.2.1.26.2.1.1.7.30.1	Integer	other (1)
ifMauJabberState.31.1	.1.3.6.1.2.1.26.2.1.1.7.31.1	Integer	other (1)
ifMauJabberState.32.1	.1.3.6.1.2.1.26.2.1.1.7.32.1	Integer	other (1)
ifMauJabberState.33.1	.1.3.6.1.2.1.26.2.1.1.7.33.1	Integer	other (1)
ifMauJabberState.34.1	.1.3.6.1.2.1.26.2.1.1.7.34.1	Integer	other (1)
ifMauJabberState.35.1	.1.3.6.1.2.1.26.2.1.1.7.35.1	Integer	other (1)
ifMauJabberState.36.1	.1.3.6.1.2.1.26.2.1.1.7.36.1	Integer	other (1)
ifMauJabberState.37.1	.1.3.6.1.2.1.26.2.1.1.7.37.1	Integer	other (1)
ifMauJabberState.38.1	.1.3.6.1.2.1.26.2.1.1.7.38.1	Integer	other (1)
ifMauJabberState.39.1	.1.3.6.1.2.1.26.2.1.1.7.39.1	Integer	other (1)
ifMauJabberState.40.1	.1.3.6.1.2.1.26.2.1.1.7.40.1	Integer	other (1)
ifMauJabberState.41.1	.1.3.6.1.2.1.26.2.1.1.7.41.1	Integer	other (1)
ifMauJabberState.42.1	.1.3.6.1.2.1.26.2.1.1.7.42.1	Integer	other (1)
ifMauJabberState.43.1	.1.3.6.1.2.1.26.2.1.1.7.43.1	Integer	other (1)
ifMauJabberState.44.1	.1.3.6.1.2.1.26.2.1.1.7.44.1	Integer	other (1)
ifMauJabberState.45.1	.1.3.6.1.2.1.26.2.1.1.7.45.1	Integer	other (1)
ifMauJabberState.46.1	.1.3.6.1.2.1.26.2.1.1.7.46.1	Integer	other (1)
ifMauJabberState.47.1	.1.3.6.1.2.1.26.2.1.1.7.47.1	Integer	other (1)



Name	OID	Value Type	Value Example
ifMauJabberState.48.1	.1.3.6.1.2.1.26.2.1.1.7.48.1	Integer	other (1)
ifMauJabberState.49.1	.1.3.6.1.2.1.26.2.1.1.7.49.1	Integer	other (1)
ifMauJabberState.50.1	.1.3.6.1.2.1.26.2.1.1.7.50.1	Integer	other (1)
ifMauJabberState.51.1	.1.3.6.1.2.1.26.2.1.1.7.51.1	Integer	other (1)
ifMauJabberState.52.1	.1.3.6.1.2.1.26.2.1.1.7.52.1	Integer	other (1)
ifMauJabberState.53.1	.1.3.6.1.2.1.26.2.1.1.7.53.1	Integer	other (1)
ifMauJabberState.54.1	.1.3.6.1.2.1.26.2.1.1.7.54.1	Integer	other (1)
ifMauJabberingStateEnters.1.1	.1.3.6.1.2.1.26.2.1.1.8.1.1	Counter32	0
ifMauJabberingStateEnters.2.1	.1.3.6.1.2.1.26.2.1.1.8.2.1	Counter32	0
ifMauJabberingStateEnters.3.1	.1.3.6.1.2.1.26.2.1.1.8.3.1	Counter32	0
ifMauJabberingStateEnters.4.1	.1.3.6.1.2.1.26.2.1.1.8.4.1	Counter32	0
ifMauJabberingStateEnters.5.1	.1.3.6.1.2.1.26.2.1.1.8.5.1	Counter32	0
ifMauJabberingStateEnters.6.1	.1.3.6.1.2.1.26.2.1.1.8.6.1	Counter32	0
ifMauJabberingStateEnters.7.1	.1.3.6.1.2.1.26.2.1.1.8.7.1	Counter32	0
ifMauJabberingStateEnters.8.1	.1.3.6.1.2.1.26.2.1.1.8.8.1	Counter32	0
ifMauJabberingStateEnters.9.1	.1.3.6.1.2.1.26.2.1.1.8.9.1	Counter32	0
ifMauJabberingStateEnters.10.1	.1.3.6.1.2.1.26.2.1.1.8.10.1	Counter32	0
ifMauJabberingStateEnters.11.1	.1.3.6.1.2.1.26.2.1.1.8.11.1	Counter32	0
ifMauJabberingStateEnters.12.1	.1.3.6.1.2.1.26.2.1.1.8.12.1	Counter32	0
ifMauJabberingStateEnters.13.1	.1.3.6.1.2.1.26.2.1.1.8.13.1	Counter32	0
ifMauJabberingStateEnters.14.1	.1.3.6.1.2.1.26.2.1.1.8.14.1	Counter32	0
ifMauJabberingStateEnters.15.1	.1.3.6.1.2.1.26.2.1.1.8.15.1	Counter32	0
ifMauJabberingStateEnters.16.1	.1.3.6.1.2.1.26.2.1.1.8.16.1	Counter32	0
ifMauJabberingStateEnters.17.1	.1.3.6.1.2.1.26.2.1.1.8.17.1	Counter32	0
ifMauJabberingStateEnters.18.1	.1.3.6.1.2.1.26.2.1.1.8.18.1	Counter32	0
ifMauJabberingStateEnters.19.1	.1.3.6.1.2.1.26.2.1.1.8.19.1	Counter32	0
ifMauJabberingStateEnters.20.1	.1.3.6.1.2.1.26.2.1.1.8.20.1	Counter32	0
ifMauJabberingStateEnters.21.1	.1.3.6.1.2.1.26.2.1.1.8.21.1	Counter32	0
ifMauJabberingStateEnters.22.1	.1.3.6.1.2.1.26.2.1.1.8.22.1	Counter32	0
ifMauJabberingStateEnters.23.1	.1.3.6.1.2.1.26.2.1.1.8.23.1	Counter32	0
ifMauJabberingStateEnters.24.1	.1.3.6.1.2.1.26.2.1.1.8.24.1	Counter32	0
ifMauJabberingStateEnters.25.1	.1.3.6.1.2.1.26.2.1.1.8.25.1	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ifMauJabberingStateEnters.26.1	.1.3.6.1.2.1.26.2.1.1.8.26.1	Counter32	0
ifMauJabberingStateEnters.27.1	.1.3.6.1.2.1.26.2.1.1.8.27.1	Counter32	0
ifMauJabberingStateEnters.28.1	.1.3.6.1.2.1.26.2.1.1.8.28.1	Counter32	0
ifMauJabberingStateEnters.29.1	.1.3.6.1.2.1.26.2.1.1.8.29.1	Counter32	0
ifMauJabberingStateEnters.30.1	.1.3.6.1.2.1.26.2.1.1.8.30.1	Counter32	0
ifMauJabberingStateEnters.31.1	.1.3.6.1.2.1.26.2.1.1.8.31.1	Counter32	0
ifMauJabberingStateEnters.32.1	.1.3.6.1.2.1.26.2.1.1.8.32.1	Counter32	0
ifMauJabberingStateEnters.33.1	.1.3.6.1.2.1.26.2.1.1.8.33.1	Counter32	0
ifMauJabberingStateEnters.34.1	.1.3.6.1.2.1.26.2.1.1.8.34.1	Counter32	0
ifMauJabberingStateEnters.35.1	.1.3.6.1.2.1.26.2.1.1.8.35.1	Counter32	0
ifMauJabberingStateEnters.36.1	.1.3.6.1.2.1.26.2.1.1.8.36.1	Counter32	0
ifMauJabberingStateEnters.37.1	.1.3.6.1.2.1.26.2.1.1.8.37.1	Counter32	0
ifMauJabberingStateEnters.38.1	.1.3.6.1.2.1.26.2.1.1.8.38.1	Counter32	0
ifMauJabberingStateEnters.39.1	.1.3.6.1.2.1.26.2.1.1.8.39.1	Counter32	0
ifMauJabberingStateEnters.40.1	.1.3.6.1.2.1.26.2.1.1.8.40.1	Counter32	0
ifMauJabberingStateEnters.41.1	.1.3.6.1.2.1.26.2.1.1.8.41.1	Counter32	0
ifMauJabberingStateEnters.42.1	.1.3.6.1.2.1.26.2.1.1.8.42.1	Counter32	0
ifMauJabberingStateEnters.43.1	.1.3.6.1.2.1.26.2.1.1.8.43.1	Counter32	0
ifMauJabberingStateEnters.44.1	.1.3.6.1.2.1.26.2.1.1.8.44.1	Counter32	0
ifMauJabberingStateEnters.45.1	.1.3.6.1.2.1.26.2.1.1.8.45.1	Counter32	0
ifMauJabberingStateEnters.46.1	.1.3.6.1.2.1.26.2.1.1.8.46.1	Counter32	0
ifMauJabberingStateEnters.47.1	.1.3.6.1.2.1.26.2.1.1.8.47.1	Counter32	0
ifMauJabberingStateEnters.48.1	.1.3.6.1.2.1.26.2.1.1.8.48.1	Counter32	0
ifMauJabberingStateEnters.49.1	.1.3.6.1.2.1.26.2.1.1.8.49.1	Counter32	0
ifMauJabberingStateEnters.50.1	.1.3.6.1.2.1.26.2.1.1.8.50.1	Counter32	0

Name	OID	Value Type	Value Example
ifMauJabberingStateEnters.51.1	.1.3.6.1.2.1.26.2.1.1.8.51.1	Counter32	0
ifMauJabberingStateEnters.52.1	.1.3.6.1.2.1.26.2.1.1.8.52.1	Counter32	0
ifMauJabberingStateEnters.53.1	.1.3.6.1.2.1.26.2.1.1.8.53.1	Counter32	0
ifMauJabberingStateEnters.54.1	.1.3.6.1.2.1.26.2.1.1.8.54.1	Counter32	0
ifMauFalseCarriers.1.1	.1.3.6.1.2.1.26.2.1.1.9.1.1	Counter32	0
ifMauFalseCarriers.2.1	.1.3.6.1.2.1.26.2.1.1.9.2.1	Counter32	0
ifMauFalseCarriers.3.1	.1.3.6.1.2.1.26.2.1.1.9.3.1	Counter32	0
ifMauFalseCarriers.4.1	.1.3.6.1.2.1.26.2.1.1.9.4.1	Counter32	0
ifMauFalseCarriers.5.1	.1.3.6.1.2.1.26.2.1.1.9.5.1	Counter32	0
ifMauFalseCarriers.6.1	.1.3.6.1.2.1.26.2.1.1.9.6.1	Counter32	0
ifMauFalseCarriers.7.1	.1.3.6.1.2.1.26.2.1.1.9.7.1	Counter32	0
ifMauFalseCarriers.8.1	.1.3.6.1.2.1.26.2.1.1.9.8.1	Counter32	0
ifMauFalseCarriers.9.1	.1.3.6.1.2.1.26.2.1.1.9.9.1	Counter32	0
ifMauFalseCarriers.10.1	.1.3.6.1.2.1.26.2.1.1.9.10.1	Counter32	0
ifMauFalseCarriers.11.1	.1.3.6.1.2.1.26.2.1.1.9.11.1	Counter32	0
ifMauFalseCarriers.12.1	.1.3.6.1.2.1.26.2.1.1.9.12.1	Counter32	0
ifMauFalseCarriers.13.1	.1.3.6.1.2.1.26.2.1.1.9.13.1	Counter32	0
ifMauFalseCarriers.14.1	.1.3.6.1.2.1.26.2.1.1.9.14.1	Counter32	0
ifMauFalseCarriers.15.1	.1.3.6.1.2.1.26.2.1.1.9.15.1	Counter32	0
ifMauFalseCarriers.16.1	.1.3.6.1.2.1.26.2.1.1.9.16.1	Counter32	0
ifMauFalseCarriers.17.1	.1.3.6.1.2.1.26.2.1.1.9.17.1	Counter32	0
ifMauFalseCarriers.18.1	.1.3.6.1.2.1.26.2.1.1.9.18.1	Counter32	0
ifMauFalseCarriers.19.1	.1.3.6.1.2.1.26.2.1.1.9.19.1	Counter32	0
ifMauFalseCarriers.20.1	.1.3.6.1.2.1.26.2.1.1.9.20.1	Counter32	0
ifMauFalseCarriers.21.1	.1.3.6.1.2.1.26.2.1.1.9.21.1	Counter32	0
ifMauFalseCarriers.22.1	.1.3.6.1.2.1.26.2.1.1.9.22.1	Counter32	0
ifMauFalseCarriers.23.1	.1.3.6.1.2.1.26.2.1.1.9.23.1	Counter32	0
ifMauFalseCarriers.24.1	.1.3.6.1.2.1.26.2.1.1.9.24.1	Counter32	0
ifMauFalseCarriers.25.1	.1.3.6.1.2.1.26.2.1.1.9.25.1	Counter32	0
ifMauFalseCarriers.26.1	.1.3.6.1.2.1.26.2.1.1.9.26.1	Counter32	0
ifMauFalseCarriers.27.1	.1.3.6.1.2.1.26.2.1.1.9.27.1	Counter32	0
ifMauFalseCarriers.28.1	.1.3.6.1.2.1.26.2.1.1.9.28.1	Counter32	0
ifMauFalseCarriers.29.1	.1.3.6.1.2.1.26.2.1.1.9.29.1	Counter32	0
ifMauFalseCarriers.30.1	.1.3.6.1.2.1.26.2.1.1.9.30.1	Counter32	0
ifMauFalseCarriers.31.1	.1.3.6.1.2.1.26.2.1.1.9.31.1	Counter32	0
ifMauFalseCarriers.32.1	.1.3.6.1.2.1.26.2.1.1.9.32.1	Counter32	0
ifMauFalseCarriers.33.1	.1.3.6.1.2.1.26.2.1.1.9.33.1	Counter32	0
ifMauFalseCarriers.34.1	.1.3.6.1.2.1.26.2.1.1.9.34.1	Counter32	0
ifMauFalseCarriers.35.1	.1.3.6.1.2.1.26.2.1.1.9.35.1	Counter32	0
ifMauFalseCarriers.36.1	.1.3.6.1.2.1.26.2.1.1.9.36.1	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ifMauFalseCarriers.37.1	.1.3.6.1.2.1.26.2.1.1.9.37.1	Counter32	0
ifMauFalseCarriers.38.1	.1.3.6.1.2.1.26.2.1.1.9.38.1	Counter32	0
ifMauFalseCarriers.39.1	.1.3.6.1.2.1.26.2.1.1.9.39.1	Counter32	0
ifMauFalseCarriers.40.1	.1.3.6.1.2.1.26.2.1.1.9.40.1	Counter32	0
ifMauFalseCarriers.41.1	.1.3.6.1.2.1.26.2.1.1.9.41.1	Counter32	0
ifMauFalseCarriers.42.1	.1.3.6.1.2.1.26.2.1.1.9.42.1	Counter32	0
ifMauFalseCarriers.43.1	.1.3.6.1.2.1.26.2.1.1.9.43.1	Counter32	0
ifMauFalseCarriers.44.1	.1.3.6.1.2.1.26.2.1.1.9.44.1	Counter32	0
ifMauFalseCarriers.45.1	.1.3.6.1.2.1.26.2.1.1.9.45.1	Counter32	0
ifMauFalseCarriers.46.1	.1.3.6.1.2.1.26.2.1.1.9.46.1	Counter32	0
ifMauFalseCarriers.47.1	.1.3.6.1.2.1.26.2.1.1.9.47.1	Counter32	0
ifMauFalseCarriers.48.1	.1.3.6.1.2.1.26.2.1.1.9.48.1	Counter32	0
ifMauFalseCarriers.49.1	.1.3.6.1.2.1.26.2.1.1.9.49.1	Counter32	0
ifMauFalseCarriers.50.1	.1.3.6.1.2.1.26.2.1.1.9.50.1	Counter32	0
ifMauFalseCarriers.51.1	.1.3.6.1.2.1.26.2.1.1.9.51.1	Counter32	0
ifMauFalseCarriers.52.1	.1.3.6.1.2.1.26.2.1.1.9.52.1	Counter32	0
ifMauFalseCarriers.53.1	.1.3.6.1.2.1.26.2.1.1.9.53.1	Counter32	0
ifMauFalseCarriers.54.1	.1.3.6.1.2.1.26.2.1.1.9.54.1	Counter32	0
ifMauTypeList.1.1	.1.3.6.1.2.1.26.2.1.1.10.1.1	Integer	1
ifMauTypeList.2.1	.1.3.6.1.2.1.26.2.1.1.10.2.1	Integer	1
ifMauTypeList.3.1	.1.3.6.1.2.1.26.2.1.1.10.3.1	Integer	1
ifMauTypeList.4.1	.1.3.6.1.2.1.26.2.1.1.10.4.1	Integer	1
ifMauTypeList.5.1	.1.3.6.1.2.1.26.2.1.1.10.5.1	Integer	1
ifMauTypeList.6.1	.1.3.6.1.2.1.26.2.1.1.10.6.1	Integer	1
ifMauTypeList.7.1	.1.3.6.1.2.1.26.2.1.1.10.7.1	Integer	1
ifMauTypeList.8.1	.1.3.6.1.2.1.26.2.1.1.10.8.1	Integer	1
ifMauTypeList.9.1	.1.3.6.1.2.1.26.2.1.1.10.9.1	Integer	1
ifMauTypeList.10.1	.1.3.6.1.2.1.26.2.1.1.10.10.1	Integer	1
ifMauTypeList.11.1	.1.3.6.1.2.1.26.2.1.1.10.11.1	Integer	1
ifMauTypeList.12.1	.1.3.6.1.2.1.26.2.1.1.10.12.1	Integer	1
ifMauTypeList.13.1	.1.3.6.1.2.1.26.2.1.1.10.13.1	Integer	1
ifMauTypeList.14.1	.1.3.6.1.2.1.26.2.1.1.10.14.1	Integer	1
ifMauTypeList.15.1	.1.3.6.1.2.1.26.2.1.1.10.15.1	Integer	1
ifMauTypeList.16.1	.1.3.6.1.2.1.26.2.1.1.10.16.1	Integer	1
ifMauTypeList.17.1	.1.3.6.1.2.1.26.2.1.1.10.17.1	Integer	1
ifMauTypeList.18.1	.1.3.6.1.2.1.26.2.1.1.10.18.1	Integer	1
ifMauTypeList.19.1	.1.3.6.1.2.1.26.2.1.1.10.19.1	Integer	1
ifMauTypeList.20.1	.1.3.6.1.2.1.26.2.1.1.10.20.1	Integer	1
ifMauTypeList.21.1	.1.3.6.1.2.1.26.2.1.1.10.21.1	Integer	1
ifMauTypeList.22.1	.1.3.6.1.2.1.26.2.1.1.10.22.1	Integer	1
ifMauTypeList.23.1	.1.3.6.1.2.1.26.2.1.1.10.23.1	Integer	1
ifMauTypeList.24.1	.1.3.6.1.2.1.26.2.1.1.10.24.1	Integer	1
ifMauTypeList.25.1	.1.3.6.1.2.1.26.2.1.1.10.25.1	Integer	1

Name	OID	Value Type	Value Example
ifMauTypeList.26.1	.1.3.6.1.2.1.26.2.1.1.10.26.1	Integer	1
ifMauTypeList.27.1	.1.3.6.1.2.1.26.2.1.1.10.27.1	Integer	1
ifMauTypeList.28.1	.1.3.6.1.2.1.26.2.1.1.10.28.1	Integer	1
ifMauTypeList.29.1	.1.3.6.1.2.1.26.2.1.1.10.29.1	Integer	1
ifMauTypeList.30.1	.1.3.6.1.2.1.26.2.1.1.10.30.1	Integer	1
ifMauTypeList.31.1	.1.3.6.1.2.1.26.2.1.1.10.31.1	Integer	1
ifMauTypeList.32.1	.1.3.6.1.2.1.26.2.1.1.10.32.1	Integer	1
ifMauTypeList.33.1	.1.3.6.1.2.1.26.2.1.1.10.33.1	Integer	1
ifMauTypeList.34.1	.1.3.6.1.2.1.26.2.1.1.10.34.1	Integer	1
ifMauTypeList.35.1	.1.3.6.1.2.1.26.2.1.1.10.35.1	Integer	1
ifMauTypeList.36.1	.1.3.6.1.2.1.26.2.1.1.10.36.1	Integer	1
ifMauTypeList.37.1	.1.3.6.1.2.1.26.2.1.1.10.37.1	Integer	1
ifMauTypeList.38.1	.1.3.6.1.2.1.26.2.1.1.10.38.1	Integer	1
ifMauTypeList.39.1	.1.3.6.1.2.1.26.2.1.1.10.39.1	Integer	1
ifMauTypeList.40.1	.1.3.6.1.2.1.26.2.1.1.10.40.1	Integer	1
ifMauTypeList.41.1	.1.3.6.1.2.1.26.2.1.1.10.41.1	Integer	1
ifMauTypeList.42.1	.1.3.6.1.2.1.26.2.1.1.10.42.1	Integer	1
ifMauTypeList.43.1	.1.3.6.1.2.1.26.2.1.1.10.43.1	Integer	1
ifMauTypeList.44.1	.1.3.6.1.2.1.26.2.1.1.10.44.1	Integer	1
ifMauTypeList.45.1	.1.3.6.1.2.1.26.2.1.1.10.45.1	Integer	1
ifMauTypeList.46.1	.1.3.6.1.2.1.26.2.1.1.10.46.1	Integer	1
ifMauTypeList.47.1	.1.3.6.1.2.1.26.2.1.1.10.47.1	Integer	1
ifMauTypeList.48.1	.1.3.6.1.2.1.26.2.1.1.10.48.1	Integer	1
ifMauTypeList.49.1	.1.3.6.1.2.1.26.2.1.1.10.49.1	Integer	1
ifMauTypeList.50.1	.1.3.6.1.2.1.26.2.1.1.10.50.1	Integer	1
ifMauTypeList.51.1	.1.3.6.1.2.1.26.2.1.1.10.51.1	Integer	1
ifMauTypeList.52.1	.1.3.6.1.2.1.26.2.1.1.10.52.1	Integer	1
ifMauTypeList.53.1	.1.3.6.1.2.1.26.2.1.1.10.53.1	Integer	1
ifMauTypeList.54.1	.1.3.6.1.2.1.26.2.1.1.10.54.1	Integer	1
ifMauDefaultType.1.1	.1.3.6.1.2.1.26.2.1.1.11.1.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.2.1	.1.3.6.1.2.1.26.2.1.1.11.2.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.3.1	.1.3.6.1.2.1.26.2.1.1.11.3.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.4.1	.1.3.6.1.2.1.26.2.1.1.11.4.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.5.1	.1.3.6.1.2.1.26.2.1.1.11.5.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.6.1	.1.3.6.1.2.1.26.2.1.1.11.6.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.7.1	.1.3.6.1.2.1.26.2.1.1.11.7.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.8.1	.1.3.6.1.2.1.26.2.1.1.11.8.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.9.1	.1.3.6.1.2.1.26.2.1.1.11.9.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.10.1	.1.3.6.1.2.1.26.2.1.1.11.10.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.11.1	.1.3.6.1.2.1.26.2.1.1.11.11.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.12.1	.1.3.6.1.2.1.26.2.1.1.11.12.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.13.1	.1.3.6.1.2.1.26.2.1.1.11.13.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.14.1	.1.3.6.1.2.1.26.2.1.1.11.14.1	OID	dot3MauType1000BaseTFD

Name	OID	Value Type	Value Example
ifMauDefaultType.15.1	.1.3.6.1.2.1.26.2.1.1.11.15.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.16.1	.1.3.6.1.2.1.26.2.1.1.11.16.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.17.1	.1.3.6.1.2.1.26.2.1.1.11.17.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.18.1	.1.3.6.1.2.1.26.2.1.1.11.18.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.19.1	.1.3.6.1.2.1.26.2.1.1.11.19.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.20.1	.1.3.6.1.2.1.26.2.1.1.11.20.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.21.1	.1.3.6.1.2.1.26.2.1.1.11.21.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.22.1	.1.3.6.1.2.1.26.2.1.1.11.22.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.23.1	.1.3.6.1.2.1.26.2.1.1.11.23.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.24.1	.1.3.6.1.2.1.26.2.1.1.11.24.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.25.1	.1.3.6.1.2.1.26.2.1.1.11.25.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.26.1	.1.3.6.1.2.1.26.2.1.1.11.26.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.27.1	.1.3.6.1.2.1.26.2.1.1.11.27.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.28.1	.1.3.6.1.2.1.26.2.1.1.11.28.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.29.1	.1.3.6.1.2.1.26.2.1.1.11.29.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.30.1	.1.3.6.1.2.1.26.2.1.1.11.30.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.31.1	.1.3.6.1.2.1.26.2.1.1.11.31.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.32.1	.1.3.6.1.2.1.26.2.1.1.11.32.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.33.1	.1.3.6.1.2.1.26.2.1.1.11.33.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.34.1	.1.3.6.1.2.1.26.2.1.1.11.34.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.35.1	.1.3.6.1.2.1.26.2.1.1.11.35.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.36.1	.1.3.6.1.2.1.26.2.1.1.11.36.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.37.1	.1.3.6.1.2.1.26.2.1.1.11.37.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.38.1	.1.3.6.1.2.1.26.2.1.1.11.38.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.39.1	.1.3.6.1.2.1.26.2.1.1.11.39.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.40.1	.1.3.6.1.2.1.26.2.1.1.11.40.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.41.1	.1.3.6.1.2.1.26.2.1.1.11.41.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.42.1	.1.3.6.1.2.1.26.2.1.1.11.42.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.43.1	.1.3.6.1.2.1.26.2.1.1.11.43.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.44.1	.1.3.6.1.2.1.26.2.1.1.11.44.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.45.1	.1.3.6.1.2.1.26.2.1.1.11.45.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.46.1	.1.3.6.1.2.1.26.2.1.1.11.46.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.47.1	.1.3.6.1.2.1.26.2.1.1.11.47.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.48.1	.1.3.6.1.2.1.26.2.1.1.11.48.1	OID	dot3MauType1000BaseTFD
ifMauDefaultType.49.1	.1.3.6.1.2.1.26.2.1.1.11.49.1	OID	.0.0
ifMauDefaultType.50.1	.1.3.6.1.2.1.26.2.1.1.11.50.1	OID	.0.0
ifMauDefaultType.51.1	.1.3.6.1.2.1.26.2.1.1.11.51.1	OID	.0.0
ifMauDefaultType.52.1	.1.3.6.1.2.1.26.2.1.1.11.52.1	OID	.0.0
ifMauDefaultType.53.1	.1.3.6.1.2.1.26.2.1.1.11.53.1	OID	.0.0
ifMauDefaultType.54.1	.1.3.6.1.2.1.26.2.1.1.11.54.1	OID	.0.0
ifMauAutoNegSupported.1.1	.1.3.6.1.2.1.26.2.1.1.12.1.1	Integer	true (1)
ifMauAutoNegSupported.2.1	.1.3.6.1.2.1.26.2.1.1.12.2.1	Integer	true (1)
ifMauAutoNegSupported.3.1	.1.3.6.1.2.1.26.2.1.1.12.3.1	Integer	true (1)

Name	OID	Value Type	Value Example
ifMauAutoNegSupported.4.1	.1.3.6.1.2.1.26.2.1.1.12.4.1	Integer	true (1)
ifMauAutoNegSupported.5.1	.1.3.6.1.2.1.26.2.1.1.12.5.1	Integer	true (1)
ifMauAutoNegSupported.6.1	.1.3.6.1.2.1.26.2.1.1.12.6.1	Integer	true (1)
ifMauAutoNegSupported.7.1	.1.3.6.1.2.1.26.2.1.1.12.7.1	Integer	true (1)
ifMauAutoNegSupported.8.1	.1.3.6.1.2.1.26.2.1.1.12.8.1	Integer	true (1)
ifMauAutoNegSupported.9.1	.1.3.6.1.2.1.26.2.1.1.12.9.1	Integer	true (1)
ifMauAutoNegSupported.10.1	.1.3.6.1.2.1.26.2.1.1.12.10.1	Integer	true (1)
ifMauAutoNegSupported.11.1	.1.3.6.1.2.1.26.2.1.1.12.11.1	Integer	true (1)
ifMauAutoNegSupported.12.1	.1.3.6.1.2.1.26.2.1.1.12.12.1	Integer	true (1)
ifMauAutoNegSupported.13.1	.1.3.6.1.2.1.26.2.1.1.12.13.1	Integer	true (1)
ifMauAutoNegSupported.14.1	.1.3.6.1.2.1.26.2.1.1.12.14.1	Integer	true (1)
ifMauAutoNegSupported.15.1	.1.3.6.1.2.1.26.2.1.1.12.15.1	Integer	true (1)
ifMauAutoNegSupported.16.1	.1.3.6.1.2.1.26.2.1.1.12.16.1	Integer	true (1)
ifMauAutoNegSupported.17.1	.1.3.6.1.2.1.26.2.1.1.12.17.1	Integer	true (1)
ifMauAutoNegSupported.18.1	.1.3.6.1.2.1.26.2.1.1.12.18.1	Integer	true (1)
ifMauAutoNegSupported.19.1	.1.3.6.1.2.1.26.2.1.1.12.19.1	Integer	true (1)
ifMauAutoNegSupported.20.1	.1.3.6.1.2.1.26.2.1.1.12.20.1	Integer	true (1)
ifMauAutoNegSupported.21.1	.1.3.6.1.2.1.26.2.1.1.12.21.1	Integer	true (1)
ifMauAutoNegSupported.22.1	.1.3.6.1.2.1.26.2.1.1.12.22.1	Integer	true (1)
ifMauAutoNegSupported.23.1	.1.3.6.1.2.1.26.2.1.1.12.23.1	Integer	true (1)
ifMauAutoNegSupported.24.1	.1.3.6.1.2.1.26.2.1.1.12.24.1	Integer	true (1)
ifMauAutoNegSupported.25.1	.1.3.6.1.2.1.26.2.1.1.12.25.1	Integer	true (1)
ifMauAutoNegSupported.26.1	.1.3.6.1.2.1.26.2.1.1.12.26.1	Integer	true (1)
ifMauAutoNegSupported.27.1	.1.3.6.1.2.1.26.2.1.1.12.27.1	Integer	true (1)
ifMauAutoNegSupported.28.1	.1.3.6.1.2.1.26.2.1.1.12.28.1	Integer	true (1)
ifMauAutoNegSupported.29.1	.1.3.6.1.2.1.26.2.1.1.12.29.1	Integer	true (1)
ifMauAutoNegSupported.30.1	.1.3.6.1.2.1.26.2.1.1.12.30.1	Integer	true (1)
ifMauAutoNegSupported.31.1	.1.3.6.1.2.1.26.2.1.1.12.31.1	Integer	true (1)
ifMauAutoNegSupported.32.1	.1.3.6.1.2.1.26.2.1.1.12.32.1	Integer	true (1)
ifMauAutoNegSupported.33.1	.1.3.6.1.2.1.26.2.1.1.12.33.1	Integer	true (1)
ifMauAutoNegSupported.34.1	.1.3.6.1.2.1.26.2.1.1.12.34.1	Integer	true (1)
ifMauAutoNegSupported.35.1	.1.3.6.1.2.1.26.2.1.1.12.35.1	Integer	true (1)
ifMauAutoNegSupported.36.1	.1.3.6.1.2.1.26.2.1.1.12.36.1	Integer	true (1)
ifMauAutoNegSupported.37.1	.1.3.6.1.2.1.26.2.1.1.12.37.1	Integer	true (1)
ifMauAutoNegSupported.38.1	.1.3.6.1.2.1.26.2.1.1.12.38.1	Integer	true (1)
ifMauAutoNegSupported.39.1	.1.3.6.1.2.1.26.2.1.1.12.39.1	Integer	true (1)
ifMauAutoNegSupported.40.1	.1.3.6.1.2.1.26.2.1.1.12.40.1	Integer	true (1)
ifMauAutoNegSupported.41.1	.1.3.6.1.2.1.26.2.1.1.12.41.1	Integer	true (1)
ifMauAutoNegSupported.42.1	.1.3.6.1.2.1.26.2.1.1.12.42.1	Integer	true (1)
ifMauAutoNegSupported.43.1	.1.3.6.1.2.1.26.2.1.1.12.43.1	Integer	true (1)
ifMauAutoNegSupported.44.1	.1.3.6.1.2.1.26.2.1.1.12.44.1	Integer	true (1)
ifMauAutoNegSupported.45.1	.1.3.6.1.2.1.26.2.1.1.12.45.1	Integer	true (1)
ifMauAutoNegSupported.46.1	.1.3.6.1.2.1.26.2.1.1.12.46.1	Integer	true (1)

Name	OID	Value Type	Value Example
ifMauAutoNegSupported.47.1	.1.3.6.1.2.1.26.2.1.1.12.47.1	Integer	true (1)
ifMauAutoNegSupported.48.1	.1.3.6.1.2.1.26.2.1.1.12.48.1	Integer	true (1)
ifMauAutoNegSupported.49.1	.1.3.6.1.2.1.26.2.1.1.12.49.1	Integer	true (1)
ifMauAutoNegSupported.50.1	.1.3.6.1.2.1.26.2.1.1.12.50.1	Integer	true (1)
ifMauAutoNegSupported.51.1	.1.3.6.1.2.1.26.2.1.1.12.51.1	Integer	true (1)
ifMauAutoNegSupported.52.1	.1.3.6.1.2.1.26.2.1.1.12.52.1	Integer	true (1)
ifMauAutoNegSupported.53.1	.1.3.6.1.2.1.26.2.1.1.12.53.1	Integer	true (1)
ifMauAutoNegSupported.54.1	.1.3.6.1.2.1.26.2.1.1.12.54.1	Integer	true (1)
ifMauTypeListBits.1.1	.1.3.6.1.2.1.26.2.1.1.13.1.1	OctetString	{b1000baseTFD}
ifMauTypeListBits.2.1	.1.3.6.1.2.1.26.2.1.1.13.2.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.3.1	.1.3.6.1.2.1.26.2.1.1.13.3.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.4.1	.1.3.6.1.2.1.26.2.1.1.13.4.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.5.1	.1.3.6.1.2.1.26.2.1.1.13.5.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.6.1	.1.3.6.1.2.1.26.2.1.1.13.6.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.7.1	.1.3.6.1.2.1.26.2.1.1.13.7.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.8.1	.1.3.6.1.2.1.26.2.1.1.13.8.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.9.1	.1.3.6.1.2.1.26.2.1.1.13.9.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.10.1	.1.3.6.1.2.1.26.2.1.1.13.10.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.11.1	.1.3.6.1.2.1.26.2.1.1.13.11.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.12.1	.1.3.6.1.2.1.26.2.1.1.13.12.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.13.1	.1.3.6.1.2.1.26.2.1.1.13.13.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.14.1	.1.3.6.1.2.1.26.2.1.1.13.14.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.15.1	.1.3.6.1.2.1.26.2.1.1.13.15.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}



<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ifMauTypeListBits.16.1	.1.3.6.1.2.1.26.2.1.1.13.16.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.17.1	.1.3.6.1.2.1.26.2.1.1.13.17.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.18.1	.1.3.6.1.2.1.26.2.1.1.13.18.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.19.1	.1.3.6.1.2.1.26.2.1.1.13.19.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.20.1	.1.3.6.1.2.1.26.2.1.1.13.20.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.21.1	.1.3.6.1.2.1.26.2.1.1.13.21.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.22.1	.1.3.6.1.2.1.26.2.1.1.13.22.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.23.1	.1.3.6.1.2.1.26.2.1.1.13.23.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.24.1	.1.3.6.1.2.1.26.2.1.1.13.24.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.25.1	.1.3.6.1.2.1.26.2.1.1.13.25.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.26.1	.1.3.6.1.2.1.26.2.1.1.13.26.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.27.1	.1.3.6.1.2.1.26.2.1.1.13.27.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.28.1	.1.3.6.1.2.1.26.2.1.1.13.28.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.29.1	.1.3.6.1.2.1.26.2.1.1.13.29.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.30.1	.1.3.6.1.2.1.26.2.1.1.13.30.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.31.1	.1.3.6.1.2.1.26.2.1.1.13.31.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.32.1	.1.3.6.1.2.1.26.2.1.1.13.32.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.33.1	.1.3.6.1.2.1.26.2.1.1.13.33.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}

Name	OID	Value Type	Value Example
ifMauTypeListBits.34.1	.1.3.6.1.2.1.26.2.1.1.13.34.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.35.1	.1.3.6.1.2.1.26.2.1.1.13.35.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.36.1	.1.3.6.1.2.1.26.2.1.1.13.36.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.37.1	.1.3.6.1.2.1.26.2.1.1.13.37.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.38.1	.1.3.6.1.2.1.26.2.1.1.13.38.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.39.1	.1.3.6.1.2.1.26.2.1.1.13.39.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.40.1	.1.3.6.1.2.1.26.2.1.1.13.40.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.41.1	.1.3.6.1.2.1.26.2.1.1.13.41.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.42.1	.1.3.6.1.2.1.26.2.1.1.13.42.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.43.1	.1.3.6.1.2.1.26.2.1.1.13.43.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.44.1	.1.3.6.1.2.1.26.2.1.1.13.44.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.45.1	.1.3.6.1.2.1.26.2.1.1.13.45.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.46.1	.1.3.6.1.2.1.26.2.1.1.13.46.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.47.1	.1.3.6.1.2.1.26.2.1.1.13.47.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.48.1	.1.3.6.1.2.1.26.2.1.1.13.48.1	OctetString	{b10baseTHD, b10baseTFD, b100baseTXHD, b100baseTXFD, b1000baseTFD}
ifMauTypeListBits.49.1	.1.3.6.1.2.1.26.2.1.1.13.49.1	OctetString	{bOther}
ifMauTypeListBits.50.1	.1.3.6.1.2.1.26.2.1.1.13.50.1	OctetString	{bOther}
ifMauTypeListBits.51.1	.1.3.6.1.2.1.26.2.1.1.13.51.1	OctetString	{bOther}
ifMauTypeListBits.52.1	.1.3.6.1.2.1.26.2.1.1.13.52.1	OctetString	{bOther}
ifMauTypeListBits.53.1	.1.3.6.1.2.1.26.2.1.1.13.53.1	OctetString	{bOther}
ifMauTypeListBits.54.1	.1.3.6.1.2.1.26.2.1.1.13.54.1	OctetString	{bOther}
ifJackType.1.1.1	.1.3.6.1.2.1.26.2.2.1.2.1.1.1	Integer	rx45 (2)

Name	OID	Value Type	Value Example
ifJackType.2.1.1	.1.3.6.1.2.1.26.2.2.1.2.2.1.1	Integer	rj45 (2)
ifJackType.3.1.1	.1.3.6.1.2.1.26.2.2.1.2.3.1.1	Integer	rj45 (2)
ifJackType.4.1.1	.1.3.6.1.2.1.26.2.2.1.2.4.1.1	Integer	rj45 (2)
ifJackType.5.1.1	.1.3.6.1.2.1.26.2.2.1.2.5.1.1	Integer	rj45 (2)
ifJackType.6.1.1	.1.3.6.1.2.1.26.2.2.1.2.6.1.1	Integer	rj45 (2)
ifJackType.7.1.1	.1.3.6.1.2.1.26.2.2.1.2.7.1.1	Integer	rj45 (2)
ifJackType.8.1.1	.1.3.6.1.2.1.26.2.2.1.2.8.1.1	Integer	rj45 (2)
ifJackType.9.1.1	.1.3.6.1.2.1.26.2.2.1.2.9.1.1	Integer	rj45 (2)
ifJackType.10.1.1	.1.3.6.1.2.1.26.2.2.1.2.10.1.1	Integer	rj45 (2)
ifJackType.11.1.1	.1.3.6.1.2.1.26.2.2.1.2.11.1.1	Integer	rj45 (2)
ifJackType.12.1.1	.1.3.6.1.2.1.26.2.2.1.2.12.1.1	Integer	rj45 (2)
ifJackType.13.1.1	.1.3.6.1.2.1.26.2.2.1.2.13.1.1	Integer	rj45 (2)
ifJackType.14.1.1	.1.3.6.1.2.1.26.2.2.1.2.14.1.1	Integer	rj45 (2)
ifJackType.15.1.1	.1.3.6.1.2.1.26.2.2.1.2.15.1.1	Integer	rj45 (2)
ifJackType.16.1.1	.1.3.6.1.2.1.26.2.2.1.2.16.1.1	Integer	rj45 (2)
ifJackType.17.1.1	.1.3.6.1.2.1.26.2.2.1.2.17.1.1	Integer	rj45 (2)
ifJackType.18.1.1	.1.3.6.1.2.1.26.2.2.1.2.18.1.1	Integer	rj45 (2)
ifJackType.19.1.1	.1.3.6.1.2.1.26.2.2.1.2.19.1.1	Integer	rj45 (2)
ifJackType.20.1.1	.1.3.6.1.2.1.26.2.2.1.2.20.1.1	Integer	rj45 (2)
ifJackType.21.1.1	.1.3.6.1.2.1.26.2.2.1.2.21.1.1	Integer	rj45 (2)
ifJackType.22.1.1	.1.3.6.1.2.1.26.2.2.1.2.22.1.1	Integer	rj45 (2)
ifJackType.23.1.1	.1.3.6.1.2.1.26.2.2.1.2.23.1.1	Integer	rj45 (2)
ifJackType.24.1.1	.1.3.6.1.2.1.26.2.2.1.2.24.1.1	Integer	rj45 (2)
ifJackType.25.1.1	.1.3.6.1.2.1.26.2.2.1.2.25.1.1	Integer	rj45 (2)
ifJackType.26.1.1	.1.3.6.1.2.1.26.2.2.1.2.26.1.1	Integer	rj45 (2)
ifJackType.27.1.1	.1.3.6.1.2.1.26.2.2.1.2.27.1.1	Integer	rj45 (2)
ifJackType.28.1.1	.1.3.6.1.2.1.26.2.2.1.2.28.1.1	Integer	rj45 (2)
ifJackType.29.1.1	.1.3.6.1.2.1.26.2.2.1.2.29.1.1	Integer	rj45 (2)
ifJackType.30.1.1	.1.3.6.1.2.1.26.2.2.1.2.30.1.1	Integer	rj45 (2)
ifJackType.31.1.1	.1.3.6.1.2.1.26.2.2.1.2.31.1.1	Integer	rj45 (2)
ifJackType.32.1.1	.1.3.6.1.2.1.26.2.2.1.2.32.1.1	Integer	rj45 (2)
ifJackType.33.1.1	.1.3.6.1.2.1.26.2.2.1.2.33.1.1	Integer	rj45 (2)
ifJackType.34.1.1	.1.3.6.1.2.1.26.2.2.1.2.34.1.1	Integer	rj45 (2)
ifJackType.35.1.1	.1.3.6.1.2.1.26.2.2.1.2.35.1.1	Integer	rj45 (2)
ifJackType.36.1.1	.1.3.6.1.2.1.26.2.2.1.2.36.1.1	Integer	rj45 (2)
ifJackType.37.1.1	.1.3.6.1.2.1.26.2.2.1.2.37.1.1	Integer	rj45 (2)
ifJackType.38.1.1	.1.3.6.1.2.1.26.2.2.1.2.38.1.1	Integer	rj45 (2)
ifJackType.39.1.1	.1.3.6.1.2.1.26.2.2.1.2.39.1.1	Integer	rj45 (2)
ifJackType.40.1.1	.1.3.6.1.2.1.26.2.2.1.2.40.1.1	Integer	rj45 (2)
ifJackType.41.1.1	.1.3.6.1.2.1.26.2.2.1.2.41.1.1	Integer	rj45 (2)
ifJackType.42.1.1	.1.3.6.1.2.1.26.2.2.1.2.42.1.1	Integer	rj45 (2)
ifJackType.43.1.1	.1.3.6.1.2.1.26.2.2.1.2.43.1.1	Integer	rj45 (2)
ifJackType.44.1.1	.1.3.6.1.2.1.26.2.2.1.2.44.1.1	Integer	rj45 (2)

Name	OID	Value Type	Value Example
ifJackType.45.1.1	.1.3.6.1.2.1.26.2.2.1.2.45.1.1	Integer	rj45 (2)
ifJackType.46.1.1	.1.3.6.1.2.1.26.2.2.1.2.46.1.1	Integer	rj45 (2)
ifJackType.47.1.1	.1.3.6.1.2.1.26.2.2.1.2.47.1.1	Integer	rj45 (2)
ifJackType.48.1.1	.1.3.6.1.2.1.26.2.2.1.2.48.1.1	Integer	rj45 (2)
ifJackType.49.1.1	.1.3.6.1.2.1.26.2.2.1.2.49.1.1	Integer	other (1)
ifJackType.50.1.1	.1.3.6.1.2.1.26.2.2.1.2.50.1.1	Integer	other (1)
ifJackType.51.1.1	.1.3.6.1.2.1.26.2.2.1.2.51.1.1	Integer	other (1)
ifJackType.52.1.1	.1.3.6.1.2.1.26.2.2.1.2.52.1.1	Integer	other (1)
ifJackType.53.1.1	.1.3.6.1.2.1.26.2.2.1.2.53.1.1	Integer	other (1)
ifJackType.54.1.1	.1.3.6.1.2.1.26.2.2.1.2.54.1.1	Integer	other (1)
ifMauAutoNegAdminStatus.1.1	.1.3.6.1.2.1.26.5.1.1.1.1.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.2.1	.1.3.6.1.2.1.26.5.1.1.1.2.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.3.1	.1.3.6.1.2.1.26.5.1.1.1.3.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.4.1	.1.3.6.1.2.1.26.5.1.1.1.4.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.5.1	.1.3.6.1.2.1.26.5.1.1.1.5.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.6.1	.1.3.6.1.2.1.26.5.1.1.1.6.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.7.1	.1.3.6.1.2.1.26.5.1.1.1.7.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.8.1	.1.3.6.1.2.1.26.5.1.1.1.8.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.9.1	.1.3.6.1.2.1.26.5.1.1.1.9.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.10.1	.1.3.6.1.2.1.26.5.1.1.1.10.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.11.1	.1.3.6.1.2.1.26.5.1.1.1.11.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.12.1	.1.3.6.1.2.1.26.5.1.1.1.12.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.13.1	.1.3.6.1.2.1.26.5.1.1.1.13.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.14.1	.1.3.6.1.2.1.26.5.1.1.1.14.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.15.1	.1.3.6.1.2.1.26.5.1.1.1.15.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.16.1	.1.3.6.1.2.1.26.5.1.1.1.16.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.17.1	.1.3.6.1.2.1.26.5.1.1.1.17.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.18.1	.1.3.6.1.2.1.26.5.1.1.1.18.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.19.1	.1.3.6.1.2.1.26.5.1.1.1.19.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.20.1	.1.3.6.1.2.1.26.5.1.1.1.20.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.21.1	.1.3.6.1.2.1.26.5.1.1.1.21.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.22.1	.1.3.6.1.2.1.26.5.1.1.1.22.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.23.1	.1.3.6.1.2.1.26.5.1.1.1.23.1	Integer	enabled (1)

Name	OID	Value Type	Value Example
ifMauAutoNegAdminStatus.24.1	.1.3.6.1.2.1.26.5.1.1.1.24.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.25.1	.1.3.6.1.2.1.26.5.1.1.1.25.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.26.1	.1.3.6.1.2.1.26.5.1.1.1.26.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.27.1	.1.3.6.1.2.1.26.5.1.1.1.27.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.28.1	.1.3.6.1.2.1.26.5.1.1.1.28.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.29.1	.1.3.6.1.2.1.26.5.1.1.1.29.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.30.1	.1.3.6.1.2.1.26.5.1.1.1.30.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.31.1	.1.3.6.1.2.1.26.5.1.1.1.31.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.32.1	.1.3.6.1.2.1.26.5.1.1.1.32.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.33.1	.1.3.6.1.2.1.26.5.1.1.1.33.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.34.1	.1.3.6.1.2.1.26.5.1.1.1.34.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.35.1	.1.3.6.1.2.1.26.5.1.1.1.35.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.36.1	.1.3.6.1.2.1.26.5.1.1.1.36.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.37.1	.1.3.6.1.2.1.26.5.1.1.1.37.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.38.1	.1.3.6.1.2.1.26.5.1.1.1.38.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.39.1	.1.3.6.1.2.1.26.5.1.1.1.39.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.40.1	.1.3.6.1.2.1.26.5.1.1.1.40.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.41.1	.1.3.6.1.2.1.26.5.1.1.1.41.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.42.1	.1.3.6.1.2.1.26.5.1.1.1.42.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.43.1	.1.3.6.1.2.1.26.5.1.1.1.43.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.44.1	.1.3.6.1.2.1.26.5.1.1.1.44.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.45.1	.1.3.6.1.2.1.26.5.1.1.1.45.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.46.1	.1.3.6.1.2.1.26.5.1.1.1.46.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.47.1	.1.3.6.1.2.1.26.5.1.1.1.47.1	Integer	enabled (1)
ifMauAutoNegAdminStatus.48.1	.1.3.6.1.2.1.26.5.1.1.1.48.1	Integer	enabled (1)

Name	OID	Value Type	Value Example
ifMauAutoNegAdminStatus.49.1	.1.3.6.1.2.1.26.5.1.1.1.49.1	Integer	disabled (2)
ifMauAutoNegAdminStatus.50.1	.1.3.6.1.2.1.26.5.1.1.1.50.1	Integer	disabled (2)
ifMauAutoNegAdminStatus.51.1	.1.3.6.1.2.1.26.5.1.1.1.51.1	Integer	disabled (2)
ifMauAutoNegAdminStatus.52.1	.1.3.6.1.2.1.26.5.1.1.1.52.1	Integer	disabled (2)
ifMauAutoNegAdminStatus.53.1	.1.3.6.1.2.1.26.5.1.1.1.53.1	Integer	disabled (2)
ifMauAutoNegAdminStatus.54.1	.1.3.6.1.2.1.26.5.1.1.1.54.1	Integer	disabled (2)
ifMauAutoNegRemoteSignaling.1.1	.1.3.6.1.2.1.26.5.1.1.2.1.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.2.1	.1.3.6.1.2.1.26.5.1.1.2.2.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.3.1	.1.3.6.1.2.1.26.5.1.1.2.3.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.4.1	.1.3.6.1.2.1.26.5.1.1.2.4.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.5.1	.1.3.6.1.2.1.26.5.1.1.2.5.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.6.1	.1.3.6.1.2.1.26.5.1.1.2.6.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.7.1	.1.3.6.1.2.1.26.5.1.1.2.7.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.8.1	.1.3.6.1.2.1.26.5.1.1.2.8.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.9.1	.1.3.6.1.2.1.26.5.1.1.2.9.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.10.1	.1.3.6.1.2.1.26.5.1.1.2.10.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.11.1	.1.3.6.1.2.1.26.5.1.1.2.11.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.12.1	.1.3.6.1.2.1.26.5.1.1.2.12.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.13.1	.1.3.6.1.2.1.26.5.1.1.2.13.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.14.1	.1.3.6.1.2.1.26.5.1.1.2.14.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.15.1	.1.3.6.1.2.1.26.5.1.1.2.15.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.16.1	.1.3.6.1.2.1.26.5.1.1.2.16.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.17.1	.1.3.6.1.2.1.26.5.1.1.2.17.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.18.1	.1.3.6.1.2.1.26.5.1.1.2.18.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.19.1	.1.3.6.1.2.1.26.5.1.1.2.19.1	Integer	notdetected (2)

Name	OID	Value Type	Value Example
ifMauAutoNegRemoteSignaling.20.1	.1.3.6.1.2.1.26.5.1.1.2.20.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.21.1	.1.3.6.1.2.1.26.5.1.1.2.21.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.22.1	.1.3.6.1.2.1.26.5.1.1.2.22.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.23.1	.1.3.6.1.2.1.26.5.1.1.2.23.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.24.1	.1.3.6.1.2.1.26.5.1.1.2.24.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.25.1	.1.3.6.1.2.1.26.5.1.1.2.25.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.26.1	.1.3.6.1.2.1.26.5.1.1.2.26.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.27.1	.1.3.6.1.2.1.26.5.1.1.2.27.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.28.1	.1.3.6.1.2.1.26.5.1.1.2.28.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.29.1	.1.3.6.1.2.1.26.5.1.1.2.29.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.30.1	.1.3.6.1.2.1.26.5.1.1.2.30.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.31.1	.1.3.6.1.2.1.26.5.1.1.2.31.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.32.1	.1.3.6.1.2.1.26.5.1.1.2.32.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.33.1	.1.3.6.1.2.1.26.5.1.1.2.33.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.34.1	.1.3.6.1.2.1.26.5.1.1.2.34.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.35.1	.1.3.6.1.2.1.26.5.1.1.2.35.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.36.1	.1.3.6.1.2.1.26.5.1.1.2.36.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.37.1	.1.3.6.1.2.1.26.5.1.1.2.37.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.38.1	.1.3.6.1.2.1.26.5.1.1.2.38.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.39.1	.1.3.6.1.2.1.26.5.1.1.2.39.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.40.1	.1.3.6.1.2.1.26.5.1.1.2.40.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.41.1	.1.3.6.1.2.1.26.5.1.1.2.41.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.42.1	.1.3.6.1.2.1.26.5.1.1.2.42.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.43.1	.1.3.6.1.2.1.26.5.1.1.2.43.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.44.1	.1.3.6.1.2.1.26.5.1.1.2.44.1	Integer	notdetected (2)

Name	OID	Value Type	Value Example
ifMauAutoNegRemoteSignaling.45.1	.1.3.6.1.2.1.26.5.1.1.2.45.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.46.1	.1.3.6.1.2.1.26.5.1.1.2.46.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.47.1	.1.3.6.1.2.1.26.5.1.1.2.47.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.48.1	.1.3.6.1.2.1.26.5.1.1.2.48.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.49.1	.1.3.6.1.2.1.26.5.1.1.2.49.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.50.1	.1.3.6.1.2.1.26.5.1.1.2.50.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.51.1	.1.3.6.1.2.1.26.5.1.1.2.51.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.52.1	.1.3.6.1.2.1.26.5.1.1.2.52.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.53.1	.1.3.6.1.2.1.26.5.1.1.2.53.1	Integer	notdetected (2)
ifMauAutoNegRemoteSignaling.54.1	.1.3.6.1.2.1.26.5.1.1.2.54.1	Integer	notdetected (2)
ifMauAutoNegConfig.1.1	.1.3.6.1.2.1.26.5.1.1.4.1.1	Integer	complete (3)
ifMauAutoNegConfig.2.1	.1.3.6.1.2.1.26.5.1.1.4.2.1	Integer	other (1)
ifMauAutoNegConfig.3.1	.1.3.6.1.2.1.26.5.1.1.4.3.1	Integer	other (1)
ifMauAutoNegConfig.4.1	.1.3.6.1.2.1.26.5.1.1.4.4.1	Integer	other (1)
ifMauAutoNegConfig.5.1	.1.3.6.1.2.1.26.5.1.1.4.5.1	Integer	other (1)
ifMauAutoNegConfig.6.1	.1.3.6.1.2.1.26.5.1.1.4.6.1	Integer	other (1)
ifMauAutoNegConfig.7.1	.1.3.6.1.2.1.26.5.1.1.4.7.1	Integer	other (1)
ifMauAutoNegConfig.8.1	.1.3.6.1.2.1.26.5.1.1.4.8.1	Integer	other (1)
ifMauAutoNegConfig.9.1	.1.3.6.1.2.1.26.5.1.1.4.9.1	Integer	other (1)
ifMauAutoNegConfig.10.1	.1.3.6.1.2.1.26.5.1.1.4.10.1	Integer	other (1)
ifMauAutoNegConfig.11.1	.1.3.6.1.2.1.26.5.1.1.4.11.1	Integer	other (1)
ifMauAutoNegConfig.12.1	.1.3.6.1.2.1.26.5.1.1.4.12.1	Integer	other (1)
ifMauAutoNegConfig.13.1	.1.3.6.1.2.1.26.5.1.1.4.13.1	Integer	other (1)
ifMauAutoNegConfig.14.1	.1.3.6.1.2.1.26.5.1.1.4.14.1	Integer	other (1)
ifMauAutoNegConfig.15.1	.1.3.6.1.2.1.26.5.1.1.4.15.1	Integer	other (1)
ifMauAutoNegConfig.16.1	.1.3.6.1.2.1.26.5.1.1.4.16.1	Integer	other (1)
ifMauAutoNegConfig.17.1	.1.3.6.1.2.1.26.5.1.1.4.17.1	Integer	other (1)
ifMauAutoNegConfig.18.1	.1.3.6.1.2.1.26.5.1.1.4.18.1	Integer	other (1)
ifMauAutoNegConfig.19.1	.1.3.6.1.2.1.26.5.1.1.4.19.1	Integer	other (1)
ifMauAutoNegConfig.20.1	.1.3.6.1.2.1.26.5.1.1.4.20.1	Integer	other (1)
ifMauAutoNegConfig.21.1	.1.3.6.1.2.1.26.5.1.1.4.21.1	Integer	other (1)
ifMauAutoNegConfig.22.1	.1.3.6.1.2.1.26.5.1.1.4.22.1	Integer	other (1)
ifMauAutoNegConfig.23.1	.1.3.6.1.2.1.26.5.1.1.4.23.1	Integer	other (1)
ifMauAutoNegConfig.24.1	.1.3.6.1.2.1.26.5.1.1.4.24.1	Integer	other (1)
ifMauAutoNegConfig.25.1	.1.3.6.1.2.1.26.5.1.1.4.25.1	Integer	other (1)
ifMauAutoNegConfig.26.1	.1.3.6.1.2.1.26.5.1.1.4.26.1	Integer	other (1)



Name	OID	Value Type	Value Example
ifMauAutoNegConfig.27.1	.1.3.6.1.2.1.26.5.1.1.4.27.1	Integer	other (1)
ifMauAutoNegConfig.28.1	.1.3.6.1.2.1.26.5.1.1.4.28.1	Integer	other (1)
ifMauAutoNegConfig.29.1	.1.3.6.1.2.1.26.5.1.1.4.29.1	Integer	other (1)
ifMauAutoNegConfig.30.1	.1.3.6.1.2.1.26.5.1.1.4.30.1	Integer	other (1)
ifMauAutoNegConfig.31.1	.1.3.6.1.2.1.26.5.1.1.4.31.1	Integer	other (1)
ifMauAutoNegConfig.32.1	.1.3.6.1.2.1.26.5.1.1.4.32.1	Integer	other (1)
ifMauAutoNegConfig.33.1	.1.3.6.1.2.1.26.5.1.1.4.33.1	Integer	other (1)
ifMauAutoNegConfig.34.1	.1.3.6.1.2.1.26.5.1.1.4.34.1	Integer	other (1)
ifMauAutoNegConfig.35.1	.1.3.6.1.2.1.26.5.1.1.4.35.1	Integer	other (1)
ifMauAutoNegConfig.36.1	.1.3.6.1.2.1.26.5.1.1.4.36.1	Integer	other (1)
ifMauAutoNegConfig.37.1	.1.3.6.1.2.1.26.5.1.1.4.37.1	Integer	other (1)
ifMauAutoNegConfig.38.1	.1.3.6.1.2.1.26.5.1.1.4.38.1	Integer	other (1)
ifMauAutoNegConfig.39.1	.1.3.6.1.2.1.26.5.1.1.4.39.1	Integer	other (1)
ifMauAutoNegConfig.40.1	.1.3.6.1.2.1.26.5.1.1.4.40.1	Integer	other (1)
ifMauAutoNegConfig.41.1	.1.3.6.1.2.1.26.5.1.1.4.41.1	Integer	other (1)
ifMauAutoNegConfig.42.1	.1.3.6.1.2.1.26.5.1.1.4.42.1	Integer	other (1)
ifMauAutoNegConfig.43.1	.1.3.6.1.2.1.26.5.1.1.4.43.1	Integer	other (1)
ifMauAutoNegConfig.44.1	.1.3.6.1.2.1.26.5.1.1.4.44.1	Integer	other (1)
ifMauAutoNegConfig.45.1	.1.3.6.1.2.1.26.5.1.1.4.45.1	Integer	other (1)
ifMauAutoNegConfig.46.1	.1.3.6.1.2.1.26.5.1.1.4.46.1	Integer	other (1)
ifMauAutoNegConfig.47.1	.1.3.6.1.2.1.26.5.1.1.4.47.1	Integer	other (1)
ifMauAutoNegConfig.48.1	.1.3.6.1.2.1.26.5.1.1.4.48.1	Integer	other (1)
ifMauAutoNegConfig.49.1	.1.3.6.1.2.1.26.5.1.1.4.49.1	Integer	disabled (4)
ifMauAutoNegConfig.50.1	.1.3.6.1.2.1.26.5.1.1.4.50.1	Integer	disabled (4)
ifMauAutoNegConfig.51.1	.1.3.6.1.2.1.26.5.1.1.4.51.1	Integer	disabled (4)
ifMauAutoNegConfig.52.1	.1.3.6.1.2.1.26.5.1.1.4.52.1	Integer	disabled (4)
ifMauAutoNegConfig.53.1	.1.3.6.1.2.1.26.5.1.1.4.53.1	Integer	disabled (4)
ifMauAutoNegConfig.54.1	.1.3.6.1.2.1.26.5.1.1.4.54.1	Integer	disabled (4)
ifMauAutoNegCapability.1.1	.1.3.6.1.2.1.26.5.1.1.5.1.1	Integer	0
ifMauAutoNegCapability.2.1	.1.3.6.1.2.1.26.5.1.1.5.2.1	Integer	0
ifMauAutoNegCapability.3.1	.1.3.6.1.2.1.26.5.1.1.5.3.1	Integer	0
ifMauAutoNegCapability.4.1	.1.3.6.1.2.1.26.5.1.1.5.4.1	Integer	0
ifMauAutoNegCapability.5.1	.1.3.6.1.2.1.26.5.1.1.5.5.1	Integer	0
ifMauAutoNegCapability.6.1	.1.3.6.1.2.1.26.5.1.1.5.6.1	Integer	0
ifMauAutoNegCapability.7.1	.1.3.6.1.2.1.26.5.1.1.5.7.1	Integer	0
ifMauAutoNegCapability.8.1	.1.3.6.1.2.1.26.5.1.1.5.8.1	Integer	0
ifMauAutoNegCapability.9.1	.1.3.6.1.2.1.26.5.1.1.5.9.1	Integer	0
ifMauAutoNegCapability.10.1	.1.3.6.1.2.1.26.5.1.1.5.10.1	Integer	0
ifMauAutoNegCapability.11.1	.1.3.6.1.2.1.26.5.1.1.5.11.1	Integer	0
ifMauAutoNegCapability.12.1	.1.3.6.1.2.1.26.5.1.1.5.12.1	Integer	0
ifMauAutoNegCapability.13.1	.1.3.6.1.2.1.26.5.1.1.5.13.1	Integer	0
ifMauAutoNegCapability.14.1	.1.3.6.1.2.1.26.5.1.1.5.14.1	Integer	0
ifMauAutoNegCapability.15.1	.1.3.6.1.2.1.26.5.1.1.5.15.1	Integer	0

Name	OID	Value Type	Value Example
ifMauAutoNegCapability.16.1	.1.3.6.1.2.1.26.5.1.1.5.16.1	Integer	0
ifMauAutoNegCapability.17.1	.1.3.6.1.2.1.26.5.1.1.5.17.1	Integer	0
ifMauAutoNegCapability.18.1	.1.3.6.1.2.1.26.5.1.1.5.18.1	Integer	0
ifMauAutoNegCapability.19.1	.1.3.6.1.2.1.26.5.1.1.5.19.1	Integer	0
ifMauAutoNegCapability.20.1	.1.3.6.1.2.1.26.5.1.1.5.20.1	Integer	0
ifMauAutoNegCapability.21.1	.1.3.6.1.2.1.26.5.1.1.5.21.1	Integer	0
ifMauAutoNegCapability.22.1	.1.3.6.1.2.1.26.5.1.1.5.22.1	Integer	0
ifMauAutoNegCapability.23.1	.1.3.6.1.2.1.26.5.1.1.5.23.1	Integer	0
ifMauAutoNegCapability.24.1	.1.3.6.1.2.1.26.5.1.1.5.24.1	Integer	0
ifMauAutoNegCapability.25.1	.1.3.6.1.2.1.26.5.1.1.5.25.1	Integer	0
ifMauAutoNegCapability.26.1	.1.3.6.1.2.1.26.5.1.1.5.26.1	Integer	0
ifMauAutoNegCapability.27.1	.1.3.6.1.2.1.26.5.1.1.5.27.1	Integer	0
ifMauAutoNegCapability.28.1	.1.3.6.1.2.1.26.5.1.1.5.28.1	Integer	0
ifMauAutoNegCapability.29.1	.1.3.6.1.2.1.26.5.1.1.5.29.1	Integer	0
ifMauAutoNegCapability.30.1	.1.3.6.1.2.1.26.5.1.1.5.30.1	Integer	0
ifMauAutoNegCapability.31.1	.1.3.6.1.2.1.26.5.1.1.5.31.1	Integer	0
ifMauAutoNegCapability.32.1	.1.3.6.1.2.1.26.5.1.1.5.32.1	Integer	0
ifMauAutoNegCapability.33.1	.1.3.6.1.2.1.26.5.1.1.5.33.1	Integer	0
ifMauAutoNegCapability.34.1	.1.3.6.1.2.1.26.5.1.1.5.34.1	Integer	0
ifMauAutoNegCapability.35.1	.1.3.6.1.2.1.26.5.1.1.5.35.1	Integer	0
ifMauAutoNegCapability.36.1	.1.3.6.1.2.1.26.5.1.1.5.36.1	Integer	0
ifMauAutoNegCapability.37.1	.1.3.6.1.2.1.26.5.1.1.5.37.1	Integer	0
ifMauAutoNegCapability.38.1	.1.3.6.1.2.1.26.5.1.1.5.38.1	Integer	0
ifMauAutoNegCapability.39.1	.1.3.6.1.2.1.26.5.1.1.5.39.1	Integer	0
ifMauAutoNegCapability.40.1	.1.3.6.1.2.1.26.5.1.1.5.40.1	Integer	0
ifMauAutoNegCapability.41.1	.1.3.6.1.2.1.26.5.1.1.5.41.1	Integer	0
ifMauAutoNegCapability.42.1	.1.3.6.1.2.1.26.5.1.1.5.42.1	Integer	0
ifMauAutoNegCapability.43.1	.1.3.6.1.2.1.26.5.1.1.5.43.1	Integer	0
ifMauAutoNegCapability.44.1	.1.3.6.1.2.1.26.5.1.1.5.44.1	Integer	0
ifMauAutoNegCapability.45.1	.1.3.6.1.2.1.26.5.1.1.5.45.1	Integer	0
ifMauAutoNegCapability.46.1	.1.3.6.1.2.1.26.5.1.1.5.46.1	Integer	0
ifMauAutoNegCapability.47.1	.1.3.6.1.2.1.26.5.1.1.5.47.1	Integer	0
ifMauAutoNegCapability.48.1	.1.3.6.1.2.1.26.5.1.1.5.48.1	Integer	0
ifMauAutoNegCapability.49.1	.1.3.6.1.2.1.26.5.1.1.5.49.1	Integer	0
ifMauAutoNegCapability.50.1	.1.3.6.1.2.1.26.5.1.1.5.50.1	Integer	0
ifMauAutoNegCapability.51.1	.1.3.6.1.2.1.26.5.1.1.5.51.1	Integer	0
ifMauAutoNegCapability.52.1	.1.3.6.1.2.1.26.5.1.1.5.52.1	Integer	0
ifMauAutoNegCapability.53.1	.1.3.6.1.2.1.26.5.1.1.5.53.1	Integer	0
ifMauAutoNegCapability.54.1	.1.3.6.1.2.1.26.5.1.1.5.54.1	Integer	0
ifMauAutoNegCapAdvertised.1.1	.1.3.6.1.2.1.26.5.1.1.6.1.1	Integer	0
ifMauAutoNegCapAdvertised.2.1	.1.3.6.1.2.1.26.5.1.1.6.2.1	Integer	0

Name	OID	Value Type	Value Example
ifMauAutoNegCapAdvertised.3.1	.1.3.6.1.2.1.26.5.1.1.6.3.1	Integer	0
ifMauAutoNegCapAdvertised.4.1	.1.3.6.1.2.1.26.5.1.1.6.4.1	Integer	0
ifMauAutoNegCapAdvertised.5.1	.1.3.6.1.2.1.26.5.1.1.6.5.1	Integer	0
ifMauAutoNegCapAdvertised.6.1	.1.3.6.1.2.1.26.5.1.1.6.6.1	Integer	0
ifMauAutoNegCapAdvertised.7.1	.1.3.6.1.2.1.26.5.1.1.6.7.1	Integer	0
ifMauAutoNegCapAdvertised.8.1	.1.3.6.1.2.1.26.5.1.1.6.8.1	Integer	0
ifMauAutoNegCapAdvertised.9.1	.1.3.6.1.2.1.26.5.1.1.6.9.1	Integer	0
ifMauAutoNegCapAdvertised.10.1	.1.3.6.1.2.1.26.5.1.1.6.10.1	Integer	0
ifMauAutoNegCapAdvertised.11.1	.1.3.6.1.2.1.26.5.1.1.6.11.1	Integer	0
ifMauAutoNegCapAdvertised.12.1	.1.3.6.1.2.1.26.5.1.1.6.12.1	Integer	0
ifMauAutoNegCapAdvertised.13.1	.1.3.6.1.2.1.26.5.1.1.6.13.1	Integer	0
ifMauAutoNegCapAdvertised.14.1	.1.3.6.1.2.1.26.5.1.1.6.14.1	Integer	0
ifMauAutoNegCapAdvertised.15.1	.1.3.6.1.2.1.26.5.1.1.6.15.1	Integer	0
ifMauAutoNegCapAdvertised.16.1	.1.3.6.1.2.1.26.5.1.1.6.16.1	Integer	0
ifMauAutoNegCapAdvertised.17.1	.1.3.6.1.2.1.26.5.1.1.6.17.1	Integer	0
ifMauAutoNegCapAdvertised.18.1	.1.3.6.1.2.1.26.5.1.1.6.18.1	Integer	0
ifMauAutoNegCapAdvertised.19.1	.1.3.6.1.2.1.26.5.1.1.6.19.1	Integer	0
ifMauAutoNegCapAdvertised.20.1	.1.3.6.1.2.1.26.5.1.1.6.20.1	Integer	0
ifMauAutoNegCapAdvertised.21.1	.1.3.6.1.2.1.26.5.1.1.6.21.1	Integer	0
ifMauAutoNegCapAdvertised.22.1	.1.3.6.1.2.1.26.5.1.1.6.22.1	Integer	0
ifMauAutoNegCapAdvertised.23.1	.1.3.6.1.2.1.26.5.1.1.6.23.1	Integer	0
ifMauAutoNegCapAdvertised.24.1	.1.3.6.1.2.1.26.5.1.1.6.24.1	Integer	0
ifMauAutoNegCapAdvertised.25.1	.1.3.6.1.2.1.26.5.1.1.6.25.1	Integer	0
ifMauAutoNegCapAdvertised.26.1	.1.3.6.1.2.1.26.5.1.1.6.26.1	Integer	0
ifMauAutoNegCapAdvertised.27.1	.1.3.6.1.2.1.26.5.1.1.6.27.1	Integer	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ifMauAutoNegCapAdvertised.28.1	.1.3.6.1.2.1.26.5.1.1.6.28.1	Integer	0
ifMauAutoNegCapAdvertised.29.1	.1.3.6.1.2.1.26.5.1.1.6.29.1	Integer	0
ifMauAutoNegCapAdvertised.30.1	.1.3.6.1.2.1.26.5.1.1.6.30.1	Integer	0
ifMauAutoNegCapAdvertised.31.1	.1.3.6.1.2.1.26.5.1.1.6.31.1	Integer	0
ifMauAutoNegCapAdvertised.32.1	.1.3.6.1.2.1.26.5.1.1.6.32.1	Integer	0
ifMauAutoNegCapAdvertised.33.1	.1.3.6.1.2.1.26.5.1.1.6.33.1	Integer	0
ifMauAutoNegCapAdvertised.34.1	.1.3.6.1.2.1.26.5.1.1.6.34.1	Integer	0
ifMauAutoNegCapAdvertised.35.1	.1.3.6.1.2.1.26.5.1.1.6.35.1	Integer	0
ifMauAutoNegCapAdvertised.36.1	.1.3.6.1.2.1.26.5.1.1.6.36.1	Integer	0
ifMauAutoNegCapAdvertised.37.1	.1.3.6.1.2.1.26.5.1.1.6.37.1	Integer	0
ifMauAutoNegCapAdvertised.38.1	.1.3.6.1.2.1.26.5.1.1.6.38.1	Integer	0
ifMauAutoNegCapAdvertised.39.1	.1.3.6.1.2.1.26.5.1.1.6.39.1	Integer	0
ifMauAutoNegCapAdvertised.40.1	.1.3.6.1.2.1.26.5.1.1.6.40.1	Integer	0
ifMauAutoNegCapAdvertised.41.1	.1.3.6.1.2.1.26.5.1.1.6.41.1	Integer	0
ifMauAutoNegCapAdvertised.42.1	.1.3.6.1.2.1.26.5.1.1.6.42.1	Integer	0
ifMauAutoNegCapAdvertised.43.1	.1.3.6.1.2.1.26.5.1.1.6.43.1	Integer	0
ifMauAutoNegCapAdvertised.44.1	.1.3.6.1.2.1.26.5.1.1.6.44.1	Integer	0
ifMauAutoNegCapAdvertised.45.1	.1.3.6.1.2.1.26.5.1.1.6.45.1	Integer	0
ifMauAutoNegCapAdvertised.46.1	.1.3.6.1.2.1.26.5.1.1.6.46.1	Integer	0
ifMauAutoNegCapAdvertised.47.1	.1.3.6.1.2.1.26.5.1.1.6.47.1	Integer	0
ifMauAutoNegCapAdvertised.48.1	.1.3.6.1.2.1.26.5.1.1.6.48.1	Integer	0
ifMauAutoNegCapAdvertised.49.1	.1.3.6.1.2.1.26.5.1.1.6.49.1	Integer	0
ifMauAutoNegCapAdvertised.50.1	.1.3.6.1.2.1.26.5.1.1.6.50.1	Integer	0
ifMauAutoNegCapAdvertised.51.1	.1.3.6.1.2.1.26.5.1.1.6.51.1	Integer	0
ifMauAutoNegCapAdvertised.52.1	.1.3.6.1.2.1.26.5.1.1.6.52.1	Integer	0

Name	OID	Value Type	Value Example
ifMauAutoNegCapAdvertised.53.1	.1.3.6.1.2.1.26.5.1.1.6.53.1	Integer	0
ifMauAutoNegCapAdvertised.54.1	.1.3.6.1.2.1.26.5.1.1.6.54.1	Integer	0
ifMauAutoNegCapReceived.1.1	.1.3.6.1.2.1.26.5.1.1.7.1.1	Integer	0
ifMauAutoNegCapReceived.2.1	.1.3.6.1.2.1.26.5.1.1.7.2.1	Integer	0
ifMauAutoNegCapReceived.3.1	.1.3.6.1.2.1.26.5.1.1.7.3.1	Integer	0
ifMauAutoNegCapReceived.4.1	.1.3.6.1.2.1.26.5.1.1.7.4.1	Integer	0
ifMauAutoNegCapReceived.5.1	.1.3.6.1.2.1.26.5.1.1.7.5.1	Integer	0
ifMauAutoNegCapReceived.6.1	.1.3.6.1.2.1.26.5.1.1.7.6.1	Integer	0
ifMauAutoNegCapReceived.7.1	.1.3.6.1.2.1.26.5.1.1.7.7.1	Integer	0
ifMauAutoNegCapReceived.8.1	.1.3.6.1.2.1.26.5.1.1.7.8.1	Integer	0
ifMauAutoNegCapReceived.9.1	.1.3.6.1.2.1.26.5.1.1.7.9.1	Integer	0
ifMauAutoNegCapReceived.10.1	.1.3.6.1.2.1.26.5.1.1.7.10.1	Integer	0
ifMauAutoNegCapReceived.11.1	.1.3.6.1.2.1.26.5.1.1.7.11.1	Integer	0
ifMauAutoNegCapReceived.12.1	.1.3.6.1.2.1.26.5.1.1.7.12.1	Integer	0
ifMauAutoNegCapReceived.13.1	.1.3.6.1.2.1.26.5.1.1.7.13.1	Integer	0
ifMauAutoNegCapReceived.14.1	.1.3.6.1.2.1.26.5.1.1.7.14.1	Integer	0
ifMauAutoNegCapReceived.15.1	.1.3.6.1.2.1.26.5.1.1.7.15.1	Integer	0
ifMauAutoNegCapReceived.16.1	.1.3.6.1.2.1.26.5.1.1.7.16.1	Integer	0
ifMauAutoNegCapReceived.17.1	.1.3.6.1.2.1.26.5.1.1.7.17.1	Integer	0
ifMauAutoNegCapReceived.18.1	.1.3.6.1.2.1.26.5.1.1.7.18.1	Integer	0
ifMauAutoNegCapReceived.19.1	.1.3.6.1.2.1.26.5.1.1.7.19.1	Integer	0
ifMauAutoNegCapReceived.20.1	.1.3.6.1.2.1.26.5.1.1.7.20.1	Integer	0
ifMauAutoNegCapReceived.21.1	.1.3.6.1.2.1.26.5.1.1.7.21.1	Integer	0
ifMauAutoNegCapReceived.22.1	.1.3.6.1.2.1.26.5.1.1.7.22.1	Integer	0
ifMauAutoNegCapReceived.23.1	.1.3.6.1.2.1.26.5.1.1.7.23.1	Integer	0
ifMauAutoNegCapReceived.24.1	.1.3.6.1.2.1.26.5.1.1.7.24.1	Integer	0
ifMauAutoNegCapReceived.25.1	.1.3.6.1.2.1.26.5.1.1.7.25.1	Integer	0
ifMauAutoNegCapReceived.26.1	.1.3.6.1.2.1.26.5.1.1.7.26.1	Integer	0
ifMauAutoNegCapReceived.27.1	.1.3.6.1.2.1.26.5.1.1.7.27.1	Integer	0

Name	OID	Value Type	Value Example
ifMauAutoNegCapReceived.28.1	.1.3.6.1.2.1.26.5.1.1.7.28.1	Integer	0
ifMauAutoNegCapReceived.29.1	.1.3.6.1.2.1.26.5.1.1.7.29.1	Integer	0
ifMauAutoNegCapReceived.30.1	.1.3.6.1.2.1.26.5.1.1.7.30.1	Integer	0
ifMauAutoNegCapReceived.31.1	.1.3.6.1.2.1.26.5.1.1.7.31.1	Integer	0
ifMauAutoNegCapReceived.32.1	.1.3.6.1.2.1.26.5.1.1.7.32.1	Integer	0
ifMauAutoNegCapReceived.33.1	.1.3.6.1.2.1.26.5.1.1.7.33.1	Integer	0
ifMauAutoNegCapReceived.34.1	.1.3.6.1.2.1.26.5.1.1.7.34.1	Integer	0
ifMauAutoNegCapReceived.35.1	.1.3.6.1.2.1.26.5.1.1.7.35.1	Integer	0
ifMauAutoNegCapReceived.36.1	.1.3.6.1.2.1.26.5.1.1.7.36.1	Integer	0
ifMauAutoNegCapReceived.37.1	.1.3.6.1.2.1.26.5.1.1.7.37.1	Integer	0
ifMauAutoNegCapReceived.38.1	.1.3.6.1.2.1.26.5.1.1.7.38.1	Integer	0
ifMauAutoNegCapReceived.39.1	.1.3.6.1.2.1.26.5.1.1.7.39.1	Integer	0
ifMauAutoNegCapReceived.40.1	.1.3.6.1.2.1.26.5.1.1.7.40.1	Integer	0
ifMauAutoNegCapReceived.41.1	.1.3.6.1.2.1.26.5.1.1.7.41.1	Integer	0
ifMauAutoNegCapReceived.42.1	.1.3.6.1.2.1.26.5.1.1.7.42.1	Integer	0
ifMauAutoNegCapReceived.43.1	.1.3.6.1.2.1.26.5.1.1.7.43.1	Integer	0
ifMauAutoNegCapReceived.44.1	.1.3.6.1.2.1.26.5.1.1.7.44.1	Integer	0
ifMauAutoNegCapReceived.45.1	.1.3.6.1.2.1.26.5.1.1.7.45.1	Integer	0
ifMauAutoNegCapReceived.46.1	.1.3.6.1.2.1.26.5.1.1.7.46.1	Integer	0
ifMauAutoNegCapReceived.47.1	.1.3.6.1.2.1.26.5.1.1.7.47.1	Integer	0
ifMauAutoNegCapReceived.48.1	.1.3.6.1.2.1.26.5.1.1.7.48.1	Integer	0
ifMauAutoNegCapReceived.49.1	.1.3.6.1.2.1.26.5.1.1.7.49.1	Integer	0
ifMauAutoNegCapReceived.50.1	.1.3.6.1.2.1.26.5.1.1.7.50.1	Integer	0
ifMauAutoNegCapReceived.51.1	.1.3.6.1.2.1.26.5.1.1.7.51.1	Integer	0
ifMauAutoNegCapReceived.52.1	.1.3.6.1.2.1.26.5.1.1.7.52.1	Integer	0

Name	OID	Value Type	Value Example
ifMauAutoNegCapReceived.53.1	.1.3.6.1.2.1.26.5.1.1.7.53.1	Integer	0
ifMauAutoNegCapReceived.54.1	.1.3.6.1.2.1.26.5.1.1.7.54.1	Integer	0
ifMauAutoNegRestart.1.1	.1.3.6.1.2.1.26.5.1.1.8.1.1	Integer	norestart (2)
ifMauAutoNegRestart.2.1	.1.3.6.1.2.1.26.5.1.1.8.2.1	Integer	norestart (2)
ifMauAutoNegRestart.3.1	.1.3.6.1.2.1.26.5.1.1.8.3.1	Integer	norestart (2)
ifMauAutoNegRestart.4.1	.1.3.6.1.2.1.26.5.1.1.8.4.1	Integer	norestart (2)
ifMauAutoNegRestart.5.1	.1.3.6.1.2.1.26.5.1.1.8.5.1	Integer	norestart (2)
ifMauAutoNegRestart.6.1	.1.3.6.1.2.1.26.5.1.1.8.6.1	Integer	norestart (2)
ifMauAutoNegRestart.7.1	.1.3.6.1.2.1.26.5.1.1.8.7.1	Integer	norestart (2)
ifMauAutoNegRestart.8.1	.1.3.6.1.2.1.26.5.1.1.8.8.1	Integer	norestart (2)
ifMauAutoNegRestart.9.1	.1.3.6.1.2.1.26.5.1.1.8.9.1	Integer	norestart (2)
ifMauAutoNegRestart.10.1	.1.3.6.1.2.1.26.5.1.1.8.10.1	Integer	norestart (2)
ifMauAutoNegRestart.11.1	.1.3.6.1.2.1.26.5.1.1.8.11.1	Integer	norestart (2)
ifMauAutoNegRestart.12.1	.1.3.6.1.2.1.26.5.1.1.8.12.1	Integer	norestart (2)
ifMauAutoNegRestart.13.1	.1.3.6.1.2.1.26.5.1.1.8.13.1	Integer	norestart (2)
ifMauAutoNegRestart.14.1	.1.3.6.1.2.1.26.5.1.1.8.14.1	Integer	norestart (2)
ifMauAutoNegRestart.15.1	.1.3.6.1.2.1.26.5.1.1.8.15.1	Integer	norestart (2)
ifMauAutoNegRestart.16.1	.1.3.6.1.2.1.26.5.1.1.8.16.1	Integer	norestart (2)
ifMauAutoNegRestart.17.1	.1.3.6.1.2.1.26.5.1.1.8.17.1	Integer	norestart (2)
ifMauAutoNegRestart.18.1	.1.3.6.1.2.1.26.5.1.1.8.18.1	Integer	norestart (2)
ifMauAutoNegRestart.19.1	.1.3.6.1.2.1.26.5.1.1.8.19.1	Integer	norestart (2)
ifMauAutoNegRestart.20.1	.1.3.6.1.2.1.26.5.1.1.8.20.1	Integer	norestart (2)
ifMauAutoNegRestart.21.1	.1.3.6.1.2.1.26.5.1.1.8.21.1	Integer	norestart (2)
ifMauAutoNegRestart.22.1	.1.3.6.1.2.1.26.5.1.1.8.22.1	Integer	norestart (2)
ifMauAutoNegRestart.23.1	.1.3.6.1.2.1.26.5.1.1.8.23.1	Integer	norestart (2)
ifMauAutoNegRestart.24.1	.1.3.6.1.2.1.26.5.1.1.8.24.1	Integer	norestart (2)
ifMauAutoNegRestart.25.1	.1.3.6.1.2.1.26.5.1.1.8.25.1	Integer	norestart (2)
ifMauAutoNegRestart.26.1	.1.3.6.1.2.1.26.5.1.1.8.26.1	Integer	norestart (2)
ifMauAutoNegRestart.27.1	.1.3.6.1.2.1.26.5.1.1.8.27.1	Integer	norestart (2)
ifMauAutoNegRestart.28.1	.1.3.6.1.2.1.26.5.1.1.8.28.1	Integer	norestart (2)
ifMauAutoNegRestart.29.1	.1.3.6.1.2.1.26.5.1.1.8.29.1	Integer	norestart (2)
ifMauAutoNegRestart.30.1	.1.3.6.1.2.1.26.5.1.1.8.30.1	Integer	norestart (2)
ifMauAutoNegRestart.31.1	.1.3.6.1.2.1.26.5.1.1.8.31.1	Integer	norestart (2)
ifMauAutoNegRestart.32.1	.1.3.6.1.2.1.26.5.1.1.8.32.1	Integer	norestart (2)
ifMauAutoNegRestart.33.1	.1.3.6.1.2.1.26.5.1.1.8.33.1	Integer	norestart (2)
ifMauAutoNegRestart.34.1	.1.3.6.1.2.1.26.5.1.1.8.34.1	Integer	norestart (2)
ifMauAutoNegRestart.35.1	.1.3.6.1.2.1.26.5.1.1.8.35.1	Integer	norestart (2)
ifMauAutoNegRestart.36.1	.1.3.6.1.2.1.26.5.1.1.8.36.1	Integer	norestart (2)
ifMauAutoNegRestart.37.1	.1.3.6.1.2.1.26.5.1.1.8.37.1	Integer	norestart (2)
ifMauAutoNegRestart.38.1	.1.3.6.1.2.1.26.5.1.1.8.38.1	Integer	norestart (2)
ifMauAutoNegRestart.39.1	.1.3.6.1.2.1.26.5.1.1.8.39.1	Integer	norestart (2)

Name	OID	Value Type	Value Example
ifMauAutoNegRestart.40.1	.1.3.6.1.2.1.26.5.1.1.8.40.1	Integer	norestart (2)
ifMauAutoNegRestart.41.1	.1.3.6.1.2.1.26.5.1.1.8.41.1	Integer	norestart (2)
ifMauAutoNegRestart.42.1	.1.3.6.1.2.1.26.5.1.1.8.42.1	Integer	norestart (2)
ifMauAutoNegRestart.43.1	.1.3.6.1.2.1.26.5.1.1.8.43.1	Integer	norestart (2)
ifMauAutoNegRestart.44.1	.1.3.6.1.2.1.26.5.1.1.8.44.1	Integer	norestart (2)
ifMauAutoNegRestart.45.1	.1.3.6.1.2.1.26.5.1.1.8.45.1	Integer	norestart (2)
ifMauAutoNegRestart.46.1	.1.3.6.1.2.1.26.5.1.1.8.46.1	Integer	norestart (2)
ifMauAutoNegRestart.47.1	.1.3.6.1.2.1.26.5.1.1.8.47.1	Integer	norestart (2)
ifMauAutoNegRestart.48.1	.1.3.6.1.2.1.26.5.1.1.8.48.1	Integer	norestart (2)
ifMauAutoNegRestart.49.1	.1.3.6.1.2.1.26.5.1.1.8.49.1	Integer	norestart (2)
ifMauAutoNegRestart.50.1	.1.3.6.1.2.1.26.5.1.1.8.50.1	Integer	norestart (2)
ifMauAutoNegRestart.51.1	.1.3.6.1.2.1.26.5.1.1.8.51.1	Integer	norestart (2)
ifMauAutoNegRestart.52.1	.1.3.6.1.2.1.26.5.1.1.8.52.1	Integer	norestart (2)
ifMauAutoNegRestart.53.1	.1.3.6.1.2.1.26.5.1.1.8.53.1	Integer	norestart (2)
ifMauAutoNegRestart.54.1	.1.3.6.1.2.1.26.5.1.1.8.54.1	Integer	norestart (2)
ifMauAutoNegCapability-Bits.1.1	.1.3.6.1.2.1.26.5.1.1.9.1.1	OctetString	{}
ifMauAutoNegCapability-Bits.2.1	.1.3.6.1.2.1.26.5.1.1.9.2.1	OctetString	{}
ifMauAutoNegCapability-Bits.3.1	.1.3.6.1.2.1.26.5.1.1.9.3.1	OctetString	{}
ifMauAutoNegCapability-Bits.4.1	.1.3.6.1.2.1.26.5.1.1.9.4.1	OctetString	{}
ifMauAutoNegCapability-Bits.5.1	.1.3.6.1.2.1.26.5.1.1.9.5.1	OctetString	{}
ifMauAutoNegCapability-Bits.6.1	.1.3.6.1.2.1.26.5.1.1.9.6.1	OctetString	{}
ifMauAutoNegCapability-Bits.7.1	.1.3.6.1.2.1.26.5.1.1.9.7.1	OctetString	{}
ifMauAutoNegCapability-Bits.8.1	.1.3.6.1.2.1.26.5.1.1.9.8.1	OctetString	{}
ifMauAutoNegCapability-Bits.9.1	.1.3.6.1.2.1.26.5.1.1.9.9.1	OctetString	{}
ifMauAutoNegCapability-Bits.10.1	.1.3.6.1.2.1.26.5.1.1.9.10.1	OctetString	{}
ifMauAutoNegCapability-Bits.11.1	.1.3.6.1.2.1.26.5.1.1.9.11.1	OctetString	{}
ifMauAutoNegCapability-Bits.12.1	.1.3.6.1.2.1.26.5.1.1.9.12.1	OctetString	{}
ifMauAutoNegCapability-Bits.13.1	.1.3.6.1.2.1.26.5.1.1.9.13.1	OctetString	{}
ifMauAutoNegCapability-Bits.14.1	.1.3.6.1.2.1.26.5.1.1.9.14.1	OctetString	{}
ifMauAutoNegCapability-Bits.15.1	.1.3.6.1.2.1.26.5.1.1.9.15.1	OctetString	{}
ifMauAutoNegCapability-Bits.16.1	.1.3.6.1.2.1.26.5.1.1.9.16.1	OctetString	{}



Name	OID	Value Type	Value Example
ifMauAutoNegCapability-Bits.17.1	.1.3.6.1.2.1.26.5.1.1.9.17.1	OctetString	{}
ifMauAutoNegCapability-Bits.18.1	.1.3.6.1.2.1.26.5.1.1.9.18.1	OctetString	{}
ifMauAutoNegCapability-Bits.19.1	.1.3.6.1.2.1.26.5.1.1.9.19.1	OctetString	{}
ifMauAutoNegCapability-Bits.20.1	.1.3.6.1.2.1.26.5.1.1.9.20.1	OctetString	{}
ifMauAutoNegCapability-Bits.21.1	.1.3.6.1.2.1.26.5.1.1.9.21.1	OctetString	{}
ifMauAutoNegCapability-Bits.22.1	.1.3.6.1.2.1.26.5.1.1.9.22.1	OctetString	{}
ifMauAutoNegCapability-Bits.23.1	.1.3.6.1.2.1.26.5.1.1.9.23.1	OctetString	{}
ifMauAutoNegCapability-Bits.24.1	.1.3.6.1.2.1.26.5.1.1.9.24.1	OctetString	{}
ifMauAutoNegCapability-Bits.25.1	.1.3.6.1.2.1.26.5.1.1.9.25.1	OctetString	{}
ifMauAutoNegCapability-Bits.26.1	.1.3.6.1.2.1.26.5.1.1.9.26.1	OctetString	{}
ifMauAutoNegCapability-Bits.27.1	.1.3.6.1.2.1.26.5.1.1.9.27.1	OctetString	{}
ifMauAutoNegCapability-Bits.28.1	.1.3.6.1.2.1.26.5.1.1.9.28.1	OctetString	{}
ifMauAutoNegCapability-Bits.29.1	.1.3.6.1.2.1.26.5.1.1.9.29.1	OctetString	{}
ifMauAutoNegCapability-Bits.30.1	.1.3.6.1.2.1.26.5.1.1.9.30.1	OctetString	{}
ifMauAutoNegCapability-Bits.31.1	.1.3.6.1.2.1.26.5.1.1.9.31.1	OctetString	{}
ifMauAutoNegCapability-Bits.32.1	.1.3.6.1.2.1.26.5.1.1.9.32.1	OctetString	{}
ifMauAutoNegCapability-Bits.33.1	.1.3.6.1.2.1.26.5.1.1.9.33.1	OctetString	{}
ifMauAutoNegCapability-Bits.34.1	.1.3.6.1.2.1.26.5.1.1.9.34.1	OctetString	{}
ifMauAutoNegCapability-Bits.35.1	.1.3.6.1.2.1.26.5.1.1.9.35.1	OctetString	{}
ifMauAutoNegCapability-Bits.36.1	.1.3.6.1.2.1.26.5.1.1.9.36.1	OctetString	{}
ifMauAutoNegCapability-Bits.37.1	.1.3.6.1.2.1.26.5.1.1.9.37.1	OctetString	{}
ifMauAutoNegCapability-Bits.38.1	.1.3.6.1.2.1.26.5.1.1.9.38.1	OctetString	{}
ifMauAutoNegCapability-Bits.39.1	.1.3.6.1.2.1.26.5.1.1.9.39.1	OctetString	{}
ifMauAutoNegCapability-Bits.40.1	.1.3.6.1.2.1.26.5.1.1.9.40.1	OctetString	{}
ifMauAutoNegCapability-Bits.41.1	.1.3.6.1.2.1.26.5.1.1.9.41.1	OctetString	{}

Name	OID	Value Type	Value Example
ifMauAutoNegCapability-Bits.42.1	.1.3.6.1.2.1.26.5.1.1.9.42.1	OctetString	{}
ifMauAutoNegCapability-Bits.43.1	.1.3.6.1.2.1.26.5.1.1.9.43.1	OctetString	{}
ifMauAutoNegCapability-Bits.44.1	.1.3.6.1.2.1.26.5.1.1.9.44.1	OctetString	{}
ifMauAutoNegCapability-Bits.45.1	.1.3.6.1.2.1.26.5.1.1.9.45.1	OctetString	{}
ifMauAutoNegCapability-Bits.46.1	.1.3.6.1.2.1.26.5.1.1.9.46.1	OctetString	{}
ifMauAutoNegCapability-Bits.47.1	.1.3.6.1.2.1.26.5.1.1.9.47.1	OctetString	{}
ifMauAutoNegCapability-Bits.48.1	.1.3.6.1.2.1.26.5.1.1.9.48.1	OctetString	{}
ifMauAutoNegCapability-Bits.49.1	.1.3.6.1.2.1.26.5.1.1.9.49.1	OctetString	{}
ifMauAutoNegCapability-Bits.50.1	.1.3.6.1.2.1.26.5.1.1.9.50.1	OctetString	{}
ifMauAutoNegCapability-Bits.51.1	.1.3.6.1.2.1.26.5.1.1.9.51.1	OctetString	{}
ifMauAutoNegCapability-Bits.52.1	.1.3.6.1.2.1.26.5.1.1.9.52.1	OctetString	{}
ifMauAutoNegCapability-Bits.53.1	.1.3.6.1.2.1.26.5.1.1.9.53.1	OctetString	{}
ifMauAutoNegCapability-Bits.54.1	.1.3.6.1.2.1.26.5.1.1.9.54.1	OctetString	{}
ifMauAutoNegCapAdvertised-Bits.1.1	.1.3.6.1.2.1.26.5.1.1.10.1.1	OctetString	{b10baseT, b10baseTFD, b100baseTX, b100baseTXFD, b1000baseTFD}
ifMauAutoNegCapAdvertised-Bits.2.1	.1.3.6.1.2.1.26.5.1.1.10.2.1	OctetString	{b10baseT, b10baseTFD, b100baseTX, b100baseTXFD, b1000baseTFD}
ifMauAutoNegCapAdvertised-Bits.3.1	.1.3.6.1.2.1.26.5.1.1.10.3.1	OctetString	{b10baseT, b10baseTFD, b100baseTX, b100baseTXFD, b1000baseTFD}
ifMauAutoNegCapAdvertised-Bits.4.1	.1.3.6.1.2.1.26.5.1.1.10.4.1	OctetString	{b10baseT, b10baseTFD, b100baseTX, b100baseTXFD, b1000baseTFD}
ifMauAutoNegCapAdvertised-Bits.5.1	.1.3.6.1.2.1.26.5.1.1.10.5.1	OctetString	{b10baseT, b10baseTFD, b100baseTX, b100baseTXFD, b1000baseTFD}
ifMauAutoNegCapAdvertised-Bits.6.1	.1.3.6.1.2.1.26.5.1.1.10.6.1	OctetString	{b10baseT, b10baseTFD, b100baseTX, b100baseTXFD, b1000baseTFD}
ifMauAutoNegCapAdvertised-Bits.7.1	.1.3.6.1.2.1.26.5.1.1.10.7.1	OctetString	{b10baseT, b10baseTFD, b100baseTX, b100baseTXFD, b1000baseTFD}
ifMauAutoNegCapAdvertised-Bits.8.1	.1.3.6.1.2.1.26.5.1.1.10.8.1	OctetString	{b10baseT, b10baseTFD, b100baseTX, b100baseTXFD, b1000baseTFD}

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ifMauAutoNegCapAdvertised-Bits.9.1	.1.3.6.1.2.1.26.5.1.1.10.9.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.10.1	.1.3.6.1.2.1.26.5.1.1.10.10.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.11.1	.1.3.6.1.2.1.26.5.1.1.10.11.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.12.1	.1.3.6.1.2.1.26.5.1.1.10.12.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.13.1	.1.3.6.1.2.1.26.5.1.1.10.13.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.14.1	.1.3.6.1.2.1.26.5.1.1.10.14.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.15.1	.1.3.6.1.2.1.26.5.1.1.10.15.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.16.1	.1.3.6.1.2.1.26.5.1.1.10.16.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.17.1	.1.3.6.1.2.1.26.5.1.1.10.17.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.18.1	.1.3.6.1.2.1.26.5.1.1.10.18.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.19.1	.1.3.6.1.2.1.26.5.1.1.10.19.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.20.1	.1.3.6.1.2.1.26.5.1.1.10.20.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.21.1	.1.3.6.1.2.1.26.5.1.1.10.21.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.22.1	.1.3.6.1.2.1.26.5.1.1.10.22.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.23.1	.1.3.6.1.2.1.26.5.1.1.10.23.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.24.1	.1.3.6.1.2.1.26.5.1.1.10.24.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.25.1	.1.3.6.1.2.1.26.5.1.1.10.25.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.26.1	.1.3.6.1.2.1.26.5.1.1.10.26.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ifMauAutoNegCapAdvertised-Bits.27.1	.1.3.6.1.2.1.26.5.1.1.10.27.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.28.1	.1.3.6.1.2.1.26.5.1.1.10.28.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.29.1	.1.3.6.1.2.1.26.5.1.1.10.29.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.30.1	.1.3.6.1.2.1.26.5.1.1.10.30.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.31.1	.1.3.6.1.2.1.26.5.1.1.10.31.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.32.1	.1.3.6.1.2.1.26.5.1.1.10.32.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.33.1	.1.3.6.1.2.1.26.5.1.1.10.33.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.34.1	.1.3.6.1.2.1.26.5.1.1.10.34.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.35.1	.1.3.6.1.2.1.26.5.1.1.10.35.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.36.1	.1.3.6.1.2.1.26.5.1.1.10.36.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.37.1	.1.3.6.1.2.1.26.5.1.1.10.37.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.38.1	.1.3.6.1.2.1.26.5.1.1.10.38.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.39.1	.1.3.6.1.2.1.26.5.1.1.10.39.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.40.1	.1.3.6.1.2.1.26.5.1.1.10.40.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.41.1	.1.3.6.1.2.1.26.5.1.1.10.41.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.42.1	.1.3.6.1.2.1.26.5.1.1.10.42.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.43.1	.1.3.6.1.2.1.26.5.1.1.10.43.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.44.1	.1.3.6.1.2.1.26.5.1.1.10.44.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}

Name	OID	Value Type	Value Example
ifMauAutoNegCapAdvertised-Bits.45.1	.1.3.6.1.2.1.26.5.1.1.10.45.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.46.1	.1.3.6.1.2.1.26.5.1.1.10.46.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.47.1	.1.3.6.1.2.1.26.5.1.1.10.47.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.48.1	.1.3.6.1.2.1.26.5.1.1.10.48.1	OctetString	{b10baseT, b10baseTFD, b100-baseTX, b100baseTXFD, b1000-baseTFD}
ifMauAutoNegCapAdvertised-Bits.49.1	.1.3.6.1.2.1.26.5.1.1.10.49.1	OctetString	{}
ifMauAutoNegCapAdvertised-Bits.50.1	.1.3.6.1.2.1.26.5.1.1.10.50.1	OctetString	{}
ifMauAutoNegCapAdvertised-Bits.51.1	.1.3.6.1.2.1.26.5.1.1.10.51.1	OctetString	{}
ifMauAutoNegCapAdvertised-Bits.52.1	.1.3.6.1.2.1.26.5.1.1.10.52.1	OctetString	{}
ifMauAutoNegCapAdvertised-Bits.53.1	.1.3.6.1.2.1.26.5.1.1.10.53.1	OctetString	{}
ifMauAutoNegCapAdvertised-Bits.54.1	.1.3.6.1.2.1.26.5.1.1.10.54.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.1.1	.1.3.6.1.2.1.26.5.1.1.11.1.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.2.1	.1.3.6.1.2.1.26.5.1.1.11.2.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.3.1	.1.3.6.1.2.1.26.5.1.1.11.3.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.4.1	.1.3.6.1.2.1.26.5.1.1.11.4.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.5.1	.1.3.6.1.2.1.26.5.1.1.11.5.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.6.1	.1.3.6.1.2.1.26.5.1.1.11.6.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.7.1	.1.3.6.1.2.1.26.5.1.1.11.7.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.8.1	.1.3.6.1.2.1.26.5.1.1.11.8.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.9.1	.1.3.6.1.2.1.26.5.1.1.11.9.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.10.1	.1.3.6.1.2.1.26.5.1.1.11.10.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.11.1	.1.3.6.1.2.1.26.5.1.1.11.11.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.12.1	.1.3.6.1.2.1.26.5.1.1.11.12.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.13.1	.1.3.6.1.2.1.26.5.1.1.11.13.1	OctetString	{}

Name	OID	Value Type	Value Example
ifMauAutoNegCapReceived-Bits.14.1	.1.3.6.1.2.1.26.5.1.1.11.14.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.15.1	.1.3.6.1.2.1.26.5.1.1.11.15.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.16.1	.1.3.6.1.2.1.26.5.1.1.11.16.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.17.1	.1.3.6.1.2.1.26.5.1.1.11.17.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.18.1	.1.3.6.1.2.1.26.5.1.1.11.18.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.19.1	.1.3.6.1.2.1.26.5.1.1.11.19.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.20.1	.1.3.6.1.2.1.26.5.1.1.11.20.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.21.1	.1.3.6.1.2.1.26.5.1.1.11.21.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.22.1	.1.3.6.1.2.1.26.5.1.1.11.22.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.23.1	.1.3.6.1.2.1.26.5.1.1.11.23.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.24.1	.1.3.6.1.2.1.26.5.1.1.11.24.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.25.1	.1.3.6.1.2.1.26.5.1.1.11.25.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.26.1	.1.3.6.1.2.1.26.5.1.1.11.26.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.27.1	.1.3.6.1.2.1.26.5.1.1.11.27.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.28.1	.1.3.6.1.2.1.26.5.1.1.11.28.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.29.1	.1.3.6.1.2.1.26.5.1.1.11.29.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.30.1	.1.3.6.1.2.1.26.5.1.1.11.30.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.31.1	.1.3.6.1.2.1.26.5.1.1.11.31.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.32.1	.1.3.6.1.2.1.26.5.1.1.11.32.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.33.1	.1.3.6.1.2.1.26.5.1.1.11.33.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.34.1	.1.3.6.1.2.1.26.5.1.1.11.34.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.35.1	.1.3.6.1.2.1.26.5.1.1.11.35.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.36.1	.1.3.6.1.2.1.26.5.1.1.11.36.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.37.1	.1.3.6.1.2.1.26.5.1.1.11.37.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.38.1	.1.3.6.1.2.1.26.5.1.1.11.38.1	OctetString	{}

Name	OID	Value Type	Value Example
ifMauAutoNegCapReceived-Bits.39.1	.1.3.6.1.2.1.26.5.1.1.11.39.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.40.1	.1.3.6.1.2.1.26.5.1.1.11.40.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.41.1	.1.3.6.1.2.1.26.5.1.1.11.41.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.42.1	.1.3.6.1.2.1.26.5.1.1.11.42.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.43.1	.1.3.6.1.2.1.26.5.1.1.11.43.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.44.1	.1.3.6.1.2.1.26.5.1.1.11.44.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.45.1	.1.3.6.1.2.1.26.5.1.1.11.45.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.46.1	.1.3.6.1.2.1.26.5.1.1.11.46.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.47.1	.1.3.6.1.2.1.26.5.1.1.11.47.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.48.1	.1.3.6.1.2.1.26.5.1.1.11.48.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.49.1	.1.3.6.1.2.1.26.5.1.1.11.49.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.50.1	.1.3.6.1.2.1.26.5.1.1.11.50.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.51.1	.1.3.6.1.2.1.26.5.1.1.11.51.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.52.1	.1.3.6.1.2.1.26.5.1.1.11.52.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.53.1	.1.3.6.1.2.1.26.5.1.1.11.53.1	OctetString	{}
ifMauAutoNegCapReceived-Bits.54.1	.1.3.6.1.2.1.26.5.1.1.11.54.1	OctetString	{}
ifMauAutoNegRemoteFaultAdvertised.1.1	.1.3.6.1.2.1.26.5.1.1.12.1.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAdvertised.2.1	.1.3.6.1.2.1.26.5.1.1.12.2.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAdvertised.3.1	.1.3.6.1.2.1.26.5.1.1.12.3.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAdvertised.4.1	.1.3.6.1.2.1.26.5.1.1.12.4.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAdvertised.5.1	.1.3.6.1.2.1.26.5.1.1.12.5.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAdvertised.6.1	.1.3.6.1.2.1.26.5.1.1.12.6.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAdvertised.7.1	.1.3.6.1.2.1.26.5.1.1.12.7.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAdvertised.8.1	.1.3.6.1.2.1.26.5.1.1.12.8.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAdvertised.9.1	.1.3.6.1.2.1.26.5.1.1.12.9.1	Integer	noError (1)

Name	OID	Value Type	Value Example
ifMauAutoNegRemoteFaultAd- vertised.10.1	.1.3.6.1.2.1.26.5.1.1.12.10.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.11.1	.1.3.6.1.2.1.26.5.1.1.12.11.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.12.1	.1.3.6.1.2.1.26.5.1.1.12.12.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.13.1	.1.3.6.1.2.1.26.5.1.1.12.13.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.14.1	.1.3.6.1.2.1.26.5.1.1.12.14.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.15.1	.1.3.6.1.2.1.26.5.1.1.12.15.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.16.1	.1.3.6.1.2.1.26.5.1.1.12.16.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.17.1	.1.3.6.1.2.1.26.5.1.1.12.17.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.18.1	.1.3.6.1.2.1.26.5.1.1.12.18.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.19.1	.1.3.6.1.2.1.26.5.1.1.12.19.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.20.1	.1.3.6.1.2.1.26.5.1.1.12.20.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.21.1	.1.3.6.1.2.1.26.5.1.1.12.21.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.22.1	.1.3.6.1.2.1.26.5.1.1.12.22.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.23.1	.1.3.6.1.2.1.26.5.1.1.12.23.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.24.1	.1.3.6.1.2.1.26.5.1.1.12.24.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.25.1	.1.3.6.1.2.1.26.5.1.1.12.25.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.26.1	.1.3.6.1.2.1.26.5.1.1.12.26.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.27.1	.1.3.6.1.2.1.26.5.1.1.12.27.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.28.1	.1.3.6.1.2.1.26.5.1.1.12.28.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.29.1	.1.3.6.1.2.1.26.5.1.1.12.29.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.30.1	.1.3.6.1.2.1.26.5.1.1.12.30.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.31.1	.1.3.6.1.2.1.26.5.1.1.12.31.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.32.1	.1.3.6.1.2.1.26.5.1.1.12.32.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.33.1	.1.3.6.1.2.1.26.5.1.1.12.33.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.34.1	.1.3.6.1.2.1.26.5.1.1.12.34.1	Integer	noError (1)



Name	OID	Value Type	Value Example
ifMauAutoNegRemoteFaultAd- vertised.35.1	.1.3.6.1.2.1.26.5.1.1.12.35.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.36.1	.1.3.6.1.2.1.26.5.1.1.12.36.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.37.1	.1.3.6.1.2.1.26.5.1.1.12.37.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.38.1	.1.3.6.1.2.1.26.5.1.1.12.38.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.39.1	.1.3.6.1.2.1.26.5.1.1.12.39.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.40.1	.1.3.6.1.2.1.26.5.1.1.12.40.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.41.1	.1.3.6.1.2.1.26.5.1.1.12.41.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.42.1	.1.3.6.1.2.1.26.5.1.1.12.42.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.43.1	.1.3.6.1.2.1.26.5.1.1.12.43.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.44.1	.1.3.6.1.2.1.26.5.1.1.12.44.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.45.1	.1.3.6.1.2.1.26.5.1.1.12.45.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.46.1	.1.3.6.1.2.1.26.5.1.1.12.46.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.47.1	.1.3.6.1.2.1.26.5.1.1.12.47.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.48.1	.1.3.6.1.2.1.26.5.1.1.12.48.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.49.1	.1.3.6.1.2.1.26.5.1.1.12.49.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.50.1	.1.3.6.1.2.1.26.5.1.1.12.50.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.51.1	.1.3.6.1.2.1.26.5.1.1.12.51.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.52.1	.1.3.6.1.2.1.26.5.1.1.12.52.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.53.1	.1.3.6.1.2.1.26.5.1.1.12.53.1	Integer	noError (1)
ifMauAutoNegRemoteFaultAd- vertised.54.1	.1.3.6.1.2.1.26.5.1.1.12.54.1	Integer	noError (1)
ifMauAutoNegRemoteFaultRe- ceived.1.1	.1.3.6.1.2.1.26.5.1.1.13.1.1	Integer	noError (1)
ifMauAutoNegRemoteFaultRe- ceived.2.1	.1.3.6.1.2.1.26.5.1.1.13.2.1	Integer	noError (1)
ifMauAutoNegRemoteFaultRe- ceived.3.1	.1.3.6.1.2.1.26.5.1.1.13.3.1	Integer	noError (1)
ifMauAutoNegRemoteFaultRe- ceived.4.1	.1.3.6.1.2.1.26.5.1.1.13.4.1	Integer	noError (1)
ifMauAutoNegRemoteFaultRe- ceived.5.1	.1.3.6.1.2.1.26.5.1.1.13.5.1	Integer	noError (1)

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ifMauAutoNegRemoteFaultReceived.6.1	.1.3.6.1.2.1.26.5.1.1.13.6.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.7.1	.1.3.6.1.2.1.26.5.1.1.13.7.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.8.1	.1.3.6.1.2.1.26.5.1.1.13.8.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.9.1	.1.3.6.1.2.1.26.5.1.1.13.9.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.10.1	.1.3.6.1.2.1.26.5.1.1.13.10.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.11.1	.1.3.6.1.2.1.26.5.1.1.13.11.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.12.1	.1.3.6.1.2.1.26.5.1.1.13.12.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.13.1	.1.3.6.1.2.1.26.5.1.1.13.13.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.14.1	.1.3.6.1.2.1.26.5.1.1.13.14.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.15.1	.1.3.6.1.2.1.26.5.1.1.13.15.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.16.1	.1.3.6.1.2.1.26.5.1.1.13.16.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.17.1	.1.3.6.1.2.1.26.5.1.1.13.17.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.18.1	.1.3.6.1.2.1.26.5.1.1.13.18.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.19.1	.1.3.6.1.2.1.26.5.1.1.13.19.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.20.1	.1.3.6.1.2.1.26.5.1.1.13.20.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.21.1	.1.3.6.1.2.1.26.5.1.1.13.21.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.22.1	.1.3.6.1.2.1.26.5.1.1.13.22.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.23.1	.1.3.6.1.2.1.26.5.1.1.13.23.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.24.1	.1.3.6.1.2.1.26.5.1.1.13.24.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.25.1	.1.3.6.1.2.1.26.5.1.1.13.25.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.26.1	.1.3.6.1.2.1.26.5.1.1.13.26.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.27.1	.1.3.6.1.2.1.26.5.1.1.13.27.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.28.1	.1.3.6.1.2.1.26.5.1.1.13.28.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.29.1	.1.3.6.1.2.1.26.5.1.1.13.29.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.30.1	.1.3.6.1.2.1.26.5.1.1.13.30.1	Integer	noError (1)

Name	OID	Value Type	Value Example
ifMauAutoNegRemoteFaultReceived.31.1	.1.3.6.1.2.1.26.5.1.1.13.31.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.32.1	.1.3.6.1.2.1.26.5.1.1.13.32.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.33.1	.1.3.6.1.2.1.26.5.1.1.13.33.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.34.1	.1.3.6.1.2.1.26.5.1.1.13.34.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.35.1	.1.3.6.1.2.1.26.5.1.1.13.35.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.36.1	.1.3.6.1.2.1.26.5.1.1.13.36.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.37.1	.1.3.6.1.2.1.26.5.1.1.13.37.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.38.1	.1.3.6.1.2.1.26.5.1.1.13.38.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.39.1	.1.3.6.1.2.1.26.5.1.1.13.39.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.40.1	.1.3.6.1.2.1.26.5.1.1.13.40.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.41.1	.1.3.6.1.2.1.26.5.1.1.13.41.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.42.1	.1.3.6.1.2.1.26.5.1.1.13.42.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.43.1	.1.3.6.1.2.1.26.5.1.1.13.43.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.44.1	.1.3.6.1.2.1.26.5.1.1.13.44.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.45.1	.1.3.6.1.2.1.26.5.1.1.13.45.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.46.1	.1.3.6.1.2.1.26.5.1.1.13.46.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.47.1	.1.3.6.1.2.1.26.5.1.1.13.47.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.48.1	.1.3.6.1.2.1.26.5.1.1.13.48.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.49.1	.1.3.6.1.2.1.26.5.1.1.13.49.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.50.1	.1.3.6.1.2.1.26.5.1.1.13.50.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.51.1	.1.3.6.1.2.1.26.5.1.1.13.51.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.52.1	.1.3.6.1.2.1.26.5.1.1.13.52.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.53.1	.1.3.6.1.2.1.26.5.1.1.13.53.1	Integer	noError (1)
ifMauAutoNegRemoteFaultReceived.54.1	.1.3.6.1.2.1.26.5.1.1.13.54.1	Integer	noError (1)
ifName.1	.1.3.6.1.2.1.31.1.1.1.1.1	OctetString	GigabitEthernet1/0/1
ifName.2	.1.3.6.1.2.1.31.1.1.1.1.2	OctetString	GigabitEthernet1/0/2

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ifName.3	.1.3.6.1.2.1.31.1.1.1.1.3	OctetString	GigabitEthernet1/0/3
ifName.4	.1.3.6.1.2.1.31.1.1.1.1.4	OctetString	GigabitEthernet1/0/4
ifName.5	.1.3.6.1.2.1.31.1.1.1.1.5	OctetString	GigabitEthernet1/0/5
ifName.6	.1.3.6.1.2.1.31.1.1.1.1.6	OctetString	GigabitEthernet1/0/6
ifName.7	.1.3.6.1.2.1.31.1.1.1.1.7	OctetString	GigabitEthernet1/0/7
ifName.8	.1.3.6.1.2.1.31.1.1.1.1.8	OctetString	GigabitEthernet1/0/8
ifName.9	.1.3.6.1.2.1.31.1.1.1.1.9	OctetString	GigabitEthernet1/0/9
ifName.10	.1.3.6.1.2.1.31.1.1.1.1.10	OctetString	GigabitEthernet1/0/10
ifName.11	.1.3.6.1.2.1.31.1.1.1.1.11	OctetString	GigabitEthernet1/0/11
ifName.12	.1.3.6.1.2.1.31.1.1.1.1.12	OctetString	GigabitEthernet1/0/12
ifName.13	.1.3.6.1.2.1.31.1.1.1.1.13	OctetString	GigabitEthernet1/0/13
ifName.14	.1.3.6.1.2.1.31.1.1.1.1.14	OctetString	GigabitEthernet1/0/14
ifName.15	.1.3.6.1.2.1.31.1.1.1.1.15	OctetString	GigabitEthernet1/0/15
ifName.16	.1.3.6.1.2.1.31.1.1.1.1.16	OctetString	GigabitEthernet1/0/16
ifName.17	.1.3.6.1.2.1.31.1.1.1.1.17	OctetString	GigabitEthernet1/0/17
ifName.18	.1.3.6.1.2.1.31.1.1.1.1.18	OctetString	GigabitEthernet1/0/18
ifName.19	.1.3.6.1.2.1.31.1.1.1.1.19	OctetString	GigabitEthernet1/0/19
ifName.20	.1.3.6.1.2.1.31.1.1.1.1.20	OctetString	GigabitEthernet1/0/20
ifName.21	.1.3.6.1.2.1.31.1.1.1.1.21	OctetString	GigabitEthernet1/0/21
ifName.22	.1.3.6.1.2.1.31.1.1.1.1.22	OctetString	GigabitEthernet1/0/22
ifName.23	.1.3.6.1.2.1.31.1.1.1.1.23	OctetString	GigabitEthernet1/0/23
ifName.24	.1.3.6.1.2.1.31.1.1.1.1.24	OctetString	GigabitEthernet1/0/24
ifName.25	.1.3.6.1.2.1.31.1.1.1.1.25	OctetString	GigabitEthernet1/0/25
ifName.26	.1.3.6.1.2.1.31.1.1.1.1.26	OctetString	GigabitEthernet1/0/26
ifName.27	.1.3.6.1.2.1.31.1.1.1.1.27	OctetString	GigabitEthernet1/0/27
ifName.28	.1.3.6.1.2.1.31.1.1.1.1.28	OctetString	GigabitEthernet1/0/28
ifName.29	.1.3.6.1.2.1.31.1.1.1.1.29	OctetString	GigabitEthernet1/0/29
ifName.30	.1.3.6.1.2.1.31.1.1.1.1.30	OctetString	GigabitEthernet1/0/30
ifName.31	.1.3.6.1.2.1.31.1.1.1.1.31	OctetString	GigabitEthernet1/0/31
ifName.32	.1.3.6.1.2.1.31.1.1.1.1.32	OctetString	GigabitEthernet1/0/32
ifName.33	.1.3.6.1.2.1.31.1.1.1.1.33	OctetString	GigabitEthernet1/0/33
ifName.34	.1.3.6.1.2.1.31.1.1.1.1.34	OctetString	GigabitEthernet1/0/34
ifName.35	.1.3.6.1.2.1.31.1.1.1.1.35	OctetString	GigabitEthernet1/0/35
ifName.36	.1.3.6.1.2.1.31.1.1.1.1.36	OctetString	GigabitEthernet1/0/36
ifName.37	.1.3.6.1.2.1.31.1.1.1.1.37	OctetString	GigabitEthernet1/0/37
ifName.38	.1.3.6.1.2.1.31.1.1.1.1.38	OctetString	GigabitEthernet1/0/38
ifName.39	.1.3.6.1.2.1.31.1.1.1.1.39	OctetString	GigabitEthernet1/0/39
ifName.40	.1.3.6.1.2.1.31.1.1.1.1.40	OctetString	GigabitEthernet1/0/40
ifName.41	.1.3.6.1.2.1.31.1.1.1.1.41	OctetString	GigabitEthernet1/0/41
ifName.42	.1.3.6.1.2.1.31.1.1.1.1.42	OctetString	GigabitEthernet1/0/42
ifName.43	.1.3.6.1.2.1.31.1.1.1.1.43	OctetString	GigabitEthernet1/0/43
ifName.44	.1.3.6.1.2.1.31.1.1.1.1.44	OctetString	GigabitEthernet1/0/44
ifName.45	.1.3.6.1.2.1.31.1.1.1.1.45	OctetString	GigabitEthernet1/0/45

Name	OID	Value Type	Value Example
ifName.46	.1.3.6.1.2.1.31.1.1.1.1.46	OctetString	GigabitEthernet1/0/46
ifName.47	.1.3.6.1.2.1.31.1.1.1.1.47	OctetString	GigabitEthernet1/0/47
ifName.48	.1.3.6.1.2.1.31.1.1.1.1.48	OctetString	GigabitEthernet1/0/48
ifName.49	.1.3.6.1.2.1.31.1.1.1.1.49	OctetString	Ten-GigabitEthernet1/0/49
ifName.50	.1.3.6.1.2.1.31.1.1.1.1.50	OctetString	Ten-GigabitEthernet1/0/50
ifName.51	.1.3.6.1.2.1.31.1.1.1.1.51	OctetString	Ten-GigabitEthernet1/0/51
ifName.52	.1.3.6.1.2.1.31.1.1.1.1.52	OctetString	Ten-GigabitEthernet1/0/52
ifName.53	.1.3.6.1.2.1.31.1.1.1.1.53	OctetString	Ten-GigabitEthernet1/0/53
ifName.54	.1.3.6.1.2.1.31.1.1.1.1.54	OctetString	Ten-GigabitEthernet1/0/54
ifName.631	.1.3.6.1.2.1.31.1.1.1.1.631	OctetString	NULL0
ifName.632	.1.3.6.1.2.1.31.1.1.1.1.632	OctetString	InLoopBack0
ifName.633	.1.3.6.1.2.1.31.1.1.1.1.633	OctetString	Register-Tunnel0
ifName.634	.1.3.6.1.2.1.31.1.1.1.1.634	OctetString	Vlan-interface1
ifInMulticastPkts.1	.1.3.6.1.2.1.31.1.1.1.2.1	Counter32	14865
ifInMulticastPkts.2	.1.3.6.1.2.1.31.1.1.1.2.2	Counter32	0
ifInMulticastPkts.3	.1.3.6.1.2.1.31.1.1.1.2.3	Counter32	0
ifInMulticastPkts.4	.1.3.6.1.2.1.31.1.1.1.2.4	Counter32	0
ifInMulticastPkts.5	.1.3.6.1.2.1.31.1.1.1.2.5	Counter32	0
ifInMulticastPkts.6	.1.3.6.1.2.1.31.1.1.1.2.6	Counter32	0
ifInMulticastPkts.7	.1.3.6.1.2.1.31.1.1.1.2.7	Counter32	0
ifInMulticastPkts.8	.1.3.6.1.2.1.31.1.1.1.2.8	Counter32	0
ifInMulticastPkts.9	.1.3.6.1.2.1.31.1.1.1.2.9	Counter32	0
ifInMulticastPkts.10	.1.3.6.1.2.1.31.1.1.1.2.10	Counter32	0
ifInMulticastPkts.11	.1.3.6.1.2.1.31.1.1.1.2.11	Counter32	0
ifInMulticastPkts.12	.1.3.6.1.2.1.31.1.1.1.2.12	Counter32	0
ifInMulticastPkts.13	.1.3.6.1.2.1.31.1.1.1.2.13	Counter32	0
ifInMulticastPkts.14	.1.3.6.1.2.1.31.1.1.1.2.14	Counter32	0
ifInMulticastPkts.15	.1.3.6.1.2.1.31.1.1.1.2.15	Counter32	0
ifInMulticastPkts.16	.1.3.6.1.2.1.31.1.1.1.2.16	Counter32	0
ifInMulticastPkts.17	.1.3.6.1.2.1.31.1.1.1.2.17	Counter32	0
ifInMulticastPkts.18	.1.3.6.1.2.1.31.1.1.1.2.18	Counter32	0
ifInMulticastPkts.19	.1.3.6.1.2.1.31.1.1.1.2.19	Counter32	0
ifInMulticastPkts.20	.1.3.6.1.2.1.31.1.1.1.2.20	Counter32	0
ifInMulticastPkts.21	.1.3.6.1.2.1.31.1.1.1.2.21	Counter32	0
ifInMulticastPkts.22	.1.3.6.1.2.1.31.1.1.1.2.22	Counter32	0
ifInMulticastPkts.23	.1.3.6.1.2.1.31.1.1.1.2.23	Counter32	0
ifInMulticastPkts.24	.1.3.6.1.2.1.31.1.1.1.2.24	Counter32	0
ifInMulticastPkts.25	.1.3.6.1.2.1.31.1.1.1.2.25	Counter32	0
ifInMulticastPkts.26	.1.3.6.1.2.1.31.1.1.1.2.26	Counter32	0
ifInMulticastPkts.27	.1.3.6.1.2.1.31.1.1.1.2.27	Counter32	0
ifInMulticastPkts.28	.1.3.6.1.2.1.31.1.1.1.2.28	Counter32	0
ifInMulticastPkts.29	.1.3.6.1.2.1.31.1.1.1.2.29	Counter32	0
ifInMulticastPkts.30	.1.3.6.1.2.1.31.1.1.1.2.30	Counter32	0

Name	OID	Value Type	Value Example
ifInMulticastPkts.31	.1.3.6.1.2.1.31.1.1.1.2.31	Counter32	0
ifInMulticastPkts.32	.1.3.6.1.2.1.31.1.1.1.2.32	Counter32	0
ifInMulticastPkts.33	.1.3.6.1.2.1.31.1.1.1.2.33	Counter32	0
ifInMulticastPkts.34	.1.3.6.1.2.1.31.1.1.1.2.34	Counter32	0
ifInMulticastPkts.35	.1.3.6.1.2.1.31.1.1.1.2.35	Counter32	0
ifInMulticastPkts.36	.1.3.6.1.2.1.31.1.1.1.2.36	Counter32	0
ifInMulticastPkts.37	.1.3.6.1.2.1.31.1.1.1.2.37	Counter32	0
ifInMulticastPkts.38	.1.3.6.1.2.1.31.1.1.1.2.38	Counter32	0
ifInMulticastPkts.39	.1.3.6.1.2.1.31.1.1.1.2.39	Counter32	0
ifInMulticastPkts.40	.1.3.6.1.2.1.31.1.1.1.2.40	Counter32	0
ifInMulticastPkts.41	.1.3.6.1.2.1.31.1.1.1.2.41	Counter32	0
ifInMulticastPkts.42	.1.3.6.1.2.1.31.1.1.1.2.42	Counter32	0
ifInMulticastPkts.43	.1.3.6.1.2.1.31.1.1.1.2.43	Counter32	0
ifInMulticastPkts.44	.1.3.6.1.2.1.31.1.1.1.2.44	Counter32	0
ifInMulticastPkts.45	.1.3.6.1.2.1.31.1.1.1.2.45	Counter32	0
ifInMulticastPkts.46	.1.3.6.1.2.1.31.1.1.1.2.46	Counter32	0
ifInMulticastPkts.47	.1.3.6.1.2.1.31.1.1.1.2.47	Counter32	0
ifInMulticastPkts.48	.1.3.6.1.2.1.31.1.1.1.2.48	Counter32	0
ifInMulticastPkts.49	.1.3.6.1.2.1.31.1.1.1.2.49	Counter32	0
ifInMulticastPkts.50	.1.3.6.1.2.1.31.1.1.1.2.50	Counter32	0
ifInMulticastPkts.51	.1.3.6.1.2.1.31.1.1.1.2.51	Counter32	0
ifInMulticastPkts.52	.1.3.6.1.2.1.31.1.1.1.2.52	Counter32	0
ifInMulticastPkts.53	.1.3.6.1.2.1.31.1.1.1.2.53	Counter32	0
ifInMulticastPkts.54	.1.3.6.1.2.1.31.1.1.1.2.54	Counter32	0
ifInMulticastPkts.634	.1.3.6.1.2.1.31.1.1.1.2.634	Counter32	0
ifInBroadcastPkts.1	.1.3.6.1.2.1.31.1.1.1.3.1	Counter32	80782
ifInBroadcastPkts.2	.1.3.6.1.2.1.31.1.1.1.3.2	Counter32	0
ifInBroadcastPkts.3	.1.3.6.1.2.1.31.1.1.1.3.3	Counter32	0
ifInBroadcastPkts.4	.1.3.6.1.2.1.31.1.1.1.3.4	Counter32	0
ifInBroadcastPkts.5	.1.3.6.1.2.1.31.1.1.1.3.5	Counter32	0
ifInBroadcastPkts.6	.1.3.6.1.2.1.31.1.1.1.3.6	Counter32	0
ifInBroadcastPkts.7	.1.3.6.1.2.1.31.1.1.1.3.7	Counter32	0
ifInBroadcastPkts.8	.1.3.6.1.2.1.31.1.1.1.3.8	Counter32	0
ifInBroadcastPkts.9	.1.3.6.1.2.1.31.1.1.1.3.9	Counter32	0
ifInBroadcastPkts.10	.1.3.6.1.2.1.31.1.1.1.3.10	Counter32	0
ifInBroadcastPkts.11	.1.3.6.1.2.1.31.1.1.1.3.11	Counter32	0
ifInBroadcastPkts.12	.1.3.6.1.2.1.31.1.1.1.3.12	Counter32	0
ifInBroadcastPkts.13	.1.3.6.1.2.1.31.1.1.1.3.13	Counter32	0
ifInBroadcastPkts.14	.1.3.6.1.2.1.31.1.1.1.3.14	Counter32	0
ifInBroadcastPkts.15	.1.3.6.1.2.1.31.1.1.1.3.15	Counter32	0
ifInBroadcastPkts.16	.1.3.6.1.2.1.31.1.1.1.3.16	Counter32	0
ifInBroadcastPkts.17	.1.3.6.1.2.1.31.1.1.1.3.17	Counter32	0
ifInBroadcastPkts.18	.1.3.6.1.2.1.31.1.1.1.3.18	Counter32	0

Name	OID	Value Type	Value Example
ifInBroadcastPkts.19	.1.3.6.1.2.1.31.1.1.1.3.19	Counter32	0
ifInBroadcastPkts.20	.1.3.6.1.2.1.31.1.1.1.3.20	Counter32	0
ifInBroadcastPkts.21	.1.3.6.1.2.1.31.1.1.1.3.21	Counter32	0
ifInBroadcastPkts.22	.1.3.6.1.2.1.31.1.1.1.3.22	Counter32	0
ifInBroadcastPkts.23	.1.3.6.1.2.1.31.1.1.1.3.23	Counter32	0
ifInBroadcastPkts.24	.1.3.6.1.2.1.31.1.1.1.3.24	Counter32	0
ifInBroadcastPkts.25	.1.3.6.1.2.1.31.1.1.1.3.25	Counter32	0
ifInBroadcastPkts.26	.1.3.6.1.2.1.31.1.1.1.3.26	Counter32	0
ifInBroadcastPkts.27	.1.3.6.1.2.1.31.1.1.1.3.27	Counter32	0
ifInBroadcastPkts.28	.1.3.6.1.2.1.31.1.1.1.3.28	Counter32	0
ifInBroadcastPkts.29	.1.3.6.1.2.1.31.1.1.1.3.29	Counter32	0
ifInBroadcastPkts.30	.1.3.6.1.2.1.31.1.1.1.3.30	Counter32	0
ifInBroadcastPkts.31	.1.3.6.1.2.1.31.1.1.1.3.31	Counter32	0
ifInBroadcastPkts.32	.1.3.6.1.2.1.31.1.1.1.3.32	Counter32	0
ifInBroadcastPkts.33	.1.3.6.1.2.1.31.1.1.1.3.33	Counter32	0
ifInBroadcastPkts.34	.1.3.6.1.2.1.31.1.1.1.3.34	Counter32	0
ifInBroadcastPkts.35	.1.3.6.1.2.1.31.1.1.1.3.35	Counter32	0
ifInBroadcastPkts.36	.1.3.6.1.2.1.31.1.1.1.3.36	Counter32	0
ifInBroadcastPkts.37	.1.3.6.1.2.1.31.1.1.1.3.37	Counter32	0
ifInBroadcastPkts.38	.1.3.6.1.2.1.31.1.1.1.3.38	Counter32	0
ifInBroadcastPkts.39	.1.3.6.1.2.1.31.1.1.1.3.39	Counter32	0
ifInBroadcastPkts.40	.1.3.6.1.2.1.31.1.1.1.3.40	Counter32	0
ifInBroadcastPkts.41	.1.3.6.1.2.1.31.1.1.1.3.41	Counter32	0
ifInBroadcastPkts.42	.1.3.6.1.2.1.31.1.1.1.3.42	Counter32	0
ifInBroadcastPkts.43	.1.3.6.1.2.1.31.1.1.1.3.43	Counter32	0
ifInBroadcastPkts.44	.1.3.6.1.2.1.31.1.1.1.3.44	Counter32	0
ifInBroadcastPkts.45	.1.3.6.1.2.1.31.1.1.1.3.45	Counter32	0
ifInBroadcastPkts.46	.1.3.6.1.2.1.31.1.1.1.3.46	Counter32	0
ifInBroadcastPkts.47	.1.3.6.1.2.1.31.1.1.1.3.47	Counter32	0
ifInBroadcastPkts.48	.1.3.6.1.2.1.31.1.1.1.3.48	Counter32	0
ifInBroadcastPkts.49	.1.3.6.1.2.1.31.1.1.1.3.49	Counter32	0
ifInBroadcastPkts.50	.1.3.6.1.2.1.31.1.1.1.3.50	Counter32	0
ifInBroadcastPkts.51	.1.3.6.1.2.1.31.1.1.1.3.51	Counter32	0
ifInBroadcastPkts.52	.1.3.6.1.2.1.31.1.1.1.3.52	Counter32	0
ifInBroadcastPkts.53	.1.3.6.1.2.1.31.1.1.1.3.53	Counter32	0
ifInBroadcastPkts.54	.1.3.6.1.2.1.31.1.1.1.3.54	Counter32	0
ifInBroadcastPkts.634	.1.3.6.1.2.1.31.1.1.1.3.634	Counter32	0
ifOutMulticastPkts.1	.1.3.6.1.2.1.31.1.1.1.4.1	Counter32	223
ifOutMulticastPkts.2	.1.3.6.1.2.1.31.1.1.1.4.2	Counter32	0
ifOutMulticastPkts.3	.1.3.6.1.2.1.31.1.1.1.4.3	Counter32	0
ifOutMulticastPkts.4	.1.3.6.1.2.1.31.1.1.1.4.4	Counter32	0
ifOutMulticastPkts.5	.1.3.6.1.2.1.31.1.1.1.4.5	Counter32	0
ifOutMulticastPkts.6	.1.3.6.1.2.1.31.1.1.1.4.6	Counter32	0

Name	OID	Value Type	Value Example
ifOutMulticastPkts.7	.1.3.6.1.2.1.31.1.1.1.4.7	Counter32	0
ifOutMulticastPkts.8	.1.3.6.1.2.1.31.1.1.1.4.8	Counter32	0
ifOutMulticastPkts.9	.1.3.6.1.2.1.31.1.1.1.4.9	Counter32	0
ifOutMulticastPkts.10	.1.3.6.1.2.1.31.1.1.1.4.10	Counter32	0
ifOutMulticastPkts.11	.1.3.6.1.2.1.31.1.1.1.4.11	Counter32	0
ifOutMulticastPkts.12	.1.3.6.1.2.1.31.1.1.1.4.12	Counter32	0
ifOutMulticastPkts.13	.1.3.6.1.2.1.31.1.1.1.4.13	Counter32	0
ifOutMulticastPkts.14	.1.3.6.1.2.1.31.1.1.1.4.14	Counter32	0
ifOutMulticastPkts.15	.1.3.6.1.2.1.31.1.1.1.4.15	Counter32	0
ifOutMulticastPkts.16	.1.3.6.1.2.1.31.1.1.1.4.16	Counter32	0
ifOutMulticastPkts.17	.1.3.6.1.2.1.31.1.1.1.4.17	Counter32	0
ifOutMulticastPkts.18	.1.3.6.1.2.1.31.1.1.1.4.18	Counter32	0
ifOutMulticastPkts.19	.1.3.6.1.2.1.31.1.1.1.4.19	Counter32	0
ifOutMulticastPkts.20	.1.3.6.1.2.1.31.1.1.1.4.20	Counter32	0
ifOutMulticastPkts.21	.1.3.6.1.2.1.31.1.1.1.4.21	Counter32	0
ifOutMulticastPkts.22	.1.3.6.1.2.1.31.1.1.1.4.22	Counter32	0
ifOutMulticastPkts.23	.1.3.6.1.2.1.31.1.1.1.4.23	Counter32	0
ifOutMulticastPkts.24	.1.3.6.1.2.1.31.1.1.1.4.24	Counter32	0
ifOutMulticastPkts.25	.1.3.6.1.2.1.31.1.1.1.4.25	Counter32	0
ifOutMulticastPkts.26	.1.3.6.1.2.1.31.1.1.1.4.26	Counter32	0
ifOutMulticastPkts.27	.1.3.6.1.2.1.31.1.1.1.4.27	Counter32	0
ifOutMulticastPkts.28	.1.3.6.1.2.1.31.1.1.1.4.28	Counter32	0
ifOutMulticastPkts.29	.1.3.6.1.2.1.31.1.1.1.4.29	Counter32	0
ifOutMulticastPkts.30	.1.3.6.1.2.1.31.1.1.1.4.30	Counter32	0
ifOutMulticastPkts.31	.1.3.6.1.2.1.31.1.1.1.4.31	Counter32	0
ifOutMulticastPkts.32	.1.3.6.1.2.1.31.1.1.1.4.32	Counter32	0
ifOutMulticastPkts.33	.1.3.6.1.2.1.31.1.1.1.4.33	Counter32	0
ifOutMulticastPkts.34	.1.3.6.1.2.1.31.1.1.1.4.34	Counter32	0
ifOutMulticastPkts.35	.1.3.6.1.2.1.31.1.1.1.4.35	Counter32	0
ifOutMulticastPkts.36	.1.3.6.1.2.1.31.1.1.1.4.36	Counter32	0
ifOutMulticastPkts.37	.1.3.6.1.2.1.31.1.1.1.4.37	Counter32	0
ifOutMulticastPkts.38	.1.3.6.1.2.1.31.1.1.1.4.38	Counter32	0
ifOutMulticastPkts.39	.1.3.6.1.2.1.31.1.1.1.4.39	Counter32	0
ifOutMulticastPkts.40	.1.3.6.1.2.1.31.1.1.1.4.40	Counter32	0
ifOutMulticastPkts.41	.1.3.6.1.2.1.31.1.1.1.4.41	Counter32	0
ifOutMulticastPkts.42	.1.3.6.1.2.1.31.1.1.1.4.42	Counter32	0
ifOutMulticastPkts.43	.1.3.6.1.2.1.31.1.1.1.4.43	Counter32	0
ifOutMulticastPkts.44	.1.3.6.1.2.1.31.1.1.1.4.44	Counter32	0
ifOutMulticastPkts.45	.1.3.6.1.2.1.31.1.1.1.4.45	Counter32	0
ifOutMulticastPkts.46	.1.3.6.1.2.1.31.1.1.1.4.46	Counter32	0
ifOutMulticastPkts.47	.1.3.6.1.2.1.31.1.1.1.4.47	Counter32	0
ifOutMulticastPkts.48	.1.3.6.1.2.1.31.1.1.1.4.48	Counter32	0
ifOutMulticastPkts.49	.1.3.6.1.2.1.31.1.1.1.4.49	Counter32	0



Name	OID	Value Type	Value Example
ifOutMulticastPkts.50	.1.3.6.1.2.1.31.1.1.1.4.50	Counter32	0
ifOutMulticastPkts.51	.1.3.6.1.2.1.31.1.1.1.4.51	Counter32	0
ifOutMulticastPkts.52	.1.3.6.1.2.1.31.1.1.1.4.52	Counter32	0
ifOutMulticastPkts.53	.1.3.6.1.2.1.31.1.1.1.4.53	Counter32	0
ifOutMulticastPkts.54	.1.3.6.1.2.1.31.1.1.1.4.54	Counter32	0
ifOutMulticastPkts.634	.1.3.6.1.2.1.31.1.1.1.4.634	Counter32	0
ifOutBroadcastPkts.1	.1.3.6.1.2.1.31.1.1.1.5.1	Counter32	3981
ifOutBroadcastPkts.2	.1.3.6.1.2.1.31.1.1.1.5.2	Counter32	0
ifOutBroadcastPkts.3	.1.3.6.1.2.1.31.1.1.1.5.3	Counter32	0
ifOutBroadcastPkts.4	.1.3.6.1.2.1.31.1.1.1.5.4	Counter32	0
ifOutBroadcastPkts.5	.1.3.6.1.2.1.31.1.1.1.5.5	Counter32	0
ifOutBroadcastPkts.6	.1.3.6.1.2.1.31.1.1.1.5.6	Counter32	0
ifOutBroadcastPkts.7	.1.3.6.1.2.1.31.1.1.1.5.7	Counter32	0
ifOutBroadcastPkts.8	.1.3.6.1.2.1.31.1.1.1.5.8	Counter32	0
ifOutBroadcastPkts.9	.1.3.6.1.2.1.31.1.1.1.5.9	Counter32	0
ifOutBroadcastPkts.10	.1.3.6.1.2.1.31.1.1.1.5.10	Counter32	0
ifOutBroadcastPkts.11	.1.3.6.1.2.1.31.1.1.1.5.11	Counter32	0
ifOutBroadcastPkts.12	.1.3.6.1.2.1.31.1.1.1.5.12	Counter32	0
ifOutBroadcastPkts.13	.1.3.6.1.2.1.31.1.1.1.5.13	Counter32	0
ifOutBroadcastPkts.14	.1.3.6.1.2.1.31.1.1.1.5.14	Counter32	0
ifOutBroadcastPkts.15	.1.3.6.1.2.1.31.1.1.1.5.15	Counter32	0
ifOutBroadcastPkts.16	.1.3.6.1.2.1.31.1.1.1.5.16	Counter32	0
ifOutBroadcastPkts.17	.1.3.6.1.2.1.31.1.1.1.5.17	Counter32	0
ifOutBroadcastPkts.18	.1.3.6.1.2.1.31.1.1.1.5.18	Counter32	0
ifOutBroadcastPkts.19	.1.3.6.1.2.1.31.1.1.1.5.19	Counter32	0
ifOutBroadcastPkts.20	.1.3.6.1.2.1.31.1.1.1.5.20	Counter32	0
ifOutBroadcastPkts.21	.1.3.6.1.2.1.31.1.1.1.5.21	Counter32	0
ifOutBroadcastPkts.22	.1.3.6.1.2.1.31.1.1.1.5.22	Counter32	0
ifOutBroadcastPkts.23	.1.3.6.1.2.1.31.1.1.1.5.23	Counter32	0
ifOutBroadcastPkts.24	.1.3.6.1.2.1.31.1.1.1.5.24	Counter32	0
ifOutBroadcastPkts.25	.1.3.6.1.2.1.31.1.1.1.5.25	Counter32	0
ifOutBroadcastPkts.26	.1.3.6.1.2.1.31.1.1.1.5.26	Counter32	0
ifOutBroadcastPkts.27	.1.3.6.1.2.1.31.1.1.1.5.27	Counter32	0
ifOutBroadcastPkts.28	.1.3.6.1.2.1.31.1.1.1.5.28	Counter32	0
ifOutBroadcastPkts.29	.1.3.6.1.2.1.31.1.1.1.5.29	Counter32	0
ifOutBroadcastPkts.30	.1.3.6.1.2.1.31.1.1.1.5.30	Counter32	0
ifOutBroadcastPkts.31	.1.3.6.1.2.1.31.1.1.1.5.31	Counter32	0
ifOutBroadcastPkts.32	.1.3.6.1.2.1.31.1.1.1.5.32	Counter32	0
ifOutBroadcastPkts.33	.1.3.6.1.2.1.31.1.1.1.5.33	Counter32	0
ifOutBroadcastPkts.34	.1.3.6.1.2.1.31.1.1.1.5.34	Counter32	0
ifOutBroadcastPkts.35	.1.3.6.1.2.1.31.1.1.1.5.35	Counter32	0
ifOutBroadcastPkts.36	.1.3.6.1.2.1.31.1.1.1.5.36	Counter32	0
ifOutBroadcastPkts.37	.1.3.6.1.2.1.31.1.1.1.5.37	Counter32	0

Name	OID	Value Type	Value Example
ifOutBroadcastPkts.38	.1.3.6.1.2.1.31.1.1.1.5.38	Counter32	0
ifOutBroadcastPkts.39	.1.3.6.1.2.1.31.1.1.1.5.39	Counter32	0
ifOutBroadcastPkts.40	.1.3.6.1.2.1.31.1.1.1.5.40	Counter32	0
ifOutBroadcastPkts.41	.1.3.6.1.2.1.31.1.1.1.5.41	Counter32	0
ifOutBroadcastPkts.42	.1.3.6.1.2.1.31.1.1.1.5.42	Counter32	0
ifOutBroadcastPkts.43	.1.3.6.1.2.1.31.1.1.1.5.43	Counter32	0
ifOutBroadcastPkts.44	.1.3.6.1.2.1.31.1.1.1.5.44	Counter32	0
ifOutBroadcastPkts.45	.1.3.6.1.2.1.31.1.1.1.5.45	Counter32	0
ifOutBroadcastPkts.46	.1.3.6.1.2.1.31.1.1.1.5.46	Counter32	0
ifOutBroadcastPkts.47	.1.3.6.1.2.1.31.1.1.1.5.47	Counter32	0
ifOutBroadcastPkts.48	.1.3.6.1.2.1.31.1.1.1.5.48	Counter32	0
ifOutBroadcastPkts.49	.1.3.6.1.2.1.31.1.1.1.5.49	Counter32	0
ifOutBroadcastPkts.50	.1.3.6.1.2.1.31.1.1.1.5.50	Counter32	0
ifOutBroadcastPkts.51	.1.3.6.1.2.1.31.1.1.1.5.51	Counter32	0
ifOutBroadcastPkts.52	.1.3.6.1.2.1.31.1.1.1.5.52	Counter32	0
ifOutBroadcastPkts.53	.1.3.6.1.2.1.31.1.1.1.5.53	Counter32	0
ifOutBroadcastPkts.54	.1.3.6.1.2.1.31.1.1.1.5.54	Counter32	0
ifOutBroadcastPkts.634	.1.3.6.1.2.1.31.1.1.1.5.634	Counter32	0
ifLinkUpDownTrapEnable.1	.1.3.6.1.2.1.31.1.1.1.14.1	Integer	enabled (1)
ifLinkUpDownTrapEnable.2	.1.3.6.1.2.1.31.1.1.1.14.2	Integer	enabled (1)
ifLinkUpDownTrapEnable.3	.1.3.6.1.2.1.31.1.1.1.14.3	Integer	enabled (1)
ifLinkUpDownTrapEnable.4	.1.3.6.1.2.1.31.1.1.1.14.4	Integer	enabled (1)
ifLinkUpDownTrapEnable.5	.1.3.6.1.2.1.31.1.1.1.14.5	Integer	enabled (1)
ifLinkUpDownTrapEnable.6	.1.3.6.1.2.1.31.1.1.1.14.6	Integer	enabled (1)
ifLinkUpDownTrapEnable.7	.1.3.6.1.2.1.31.1.1.1.14.7	Integer	enabled (1)
ifLinkUpDownTrapEnable.8	.1.3.6.1.2.1.31.1.1.1.14.8	Integer	enabled (1)
ifLinkUpDownTrapEnable.9	.1.3.6.1.2.1.31.1.1.1.14.9	Integer	enabled (1)
ifLinkUpDownTrapEnable.10	.1.3.6.1.2.1.31.1.1.1.14.10	Integer	enabled (1)
ifLinkUpDownTrapEnable.11	.1.3.6.1.2.1.31.1.1.1.14.11	Integer	enabled (1)
ifLinkUpDownTrapEnable.12	.1.3.6.1.2.1.31.1.1.1.14.12	Integer	enabled (1)
ifLinkUpDownTrapEnable.13	.1.3.6.1.2.1.31.1.1.1.14.13	Integer	enabled (1)
ifLinkUpDownTrapEnable.14	.1.3.6.1.2.1.31.1.1.1.14.14	Integer	enabled (1)
ifLinkUpDownTrapEnable.15	.1.3.6.1.2.1.31.1.1.1.14.15	Integer	enabled (1)
ifLinkUpDownTrapEnable.16	.1.3.6.1.2.1.31.1.1.1.14.16	Integer	enabled (1)
ifLinkUpDownTrapEnable.17	.1.3.6.1.2.1.31.1.1.1.14.17	Integer	enabled (1)
ifLinkUpDownTrapEnable.18	.1.3.6.1.2.1.31.1.1.1.14.18	Integer	enabled (1)
ifLinkUpDownTrapEnable.19	.1.3.6.1.2.1.31.1.1.1.14.19	Integer	enabled (1)
ifLinkUpDownTrapEnable.20	.1.3.6.1.2.1.31.1.1.1.14.20	Integer	enabled (1)
ifLinkUpDownTrapEnable.21	.1.3.6.1.2.1.31.1.1.1.14.21	Integer	enabled (1)
ifLinkUpDownTrapEnable.22	.1.3.6.1.2.1.31.1.1.1.14.22	Integer	enabled (1)
ifLinkUpDownTrapEnable.23	.1.3.6.1.2.1.31.1.1.1.14.23	Integer	enabled (1)
ifLinkUpDownTrapEnable.24	.1.3.6.1.2.1.31.1.1.1.14.24	Integer	enabled (1)
ifLinkUpDownTrapEnable.25	.1.3.6.1.2.1.31.1.1.1.14.25	Integer	enabled (1)

Name	OID	Value Type	Value Example
ifLinkUpDownTrapEnable.26	.1.3.6.1.2.1.31.1.1.1.14.26	Integer	enabled (1)
ifLinkUpDownTrapEnable.27	.1.3.6.1.2.1.31.1.1.1.14.27	Integer	enabled (1)
ifLinkUpDownTrapEnable.28	.1.3.6.1.2.1.31.1.1.1.14.28	Integer	enabled (1)
ifLinkUpDownTrapEnable.29	.1.3.6.1.2.1.31.1.1.1.14.29	Integer	enabled (1)
ifLinkUpDownTrapEnable.30	.1.3.6.1.2.1.31.1.1.1.14.30	Integer	enabled (1)
ifLinkUpDownTrapEnable.31	.1.3.6.1.2.1.31.1.1.1.14.31	Integer	enabled (1)
ifLinkUpDownTrapEnable.32	.1.3.6.1.2.1.31.1.1.1.14.32	Integer	enabled (1)
ifLinkUpDownTrapEnable.33	.1.3.6.1.2.1.31.1.1.1.14.33	Integer	enabled (1)
ifLinkUpDownTrapEnable.34	.1.3.6.1.2.1.31.1.1.1.14.34	Integer	enabled (1)
ifLinkUpDownTrapEnable.35	.1.3.6.1.2.1.31.1.1.1.14.35	Integer	enabled (1)
ifLinkUpDownTrapEnable.36	.1.3.6.1.2.1.31.1.1.1.14.36	Integer	enabled (1)
ifLinkUpDownTrapEnable.37	.1.3.6.1.2.1.31.1.1.1.14.37	Integer	enabled (1)
ifLinkUpDownTrapEnable.38	.1.3.6.1.2.1.31.1.1.1.14.38	Integer	enabled (1)
ifLinkUpDownTrapEnable.39	.1.3.6.1.2.1.31.1.1.1.14.39	Integer	enabled (1)
ifLinkUpDownTrapEnable.40	.1.3.6.1.2.1.31.1.1.1.14.40	Integer	enabled (1)
ifLinkUpDownTrapEnable.41	.1.3.6.1.2.1.31.1.1.1.14.41	Integer	enabled (1)
ifLinkUpDownTrapEnable.42	.1.3.6.1.2.1.31.1.1.1.14.42	Integer	enabled (1)
ifLinkUpDownTrapEnable.43	.1.3.6.1.2.1.31.1.1.1.14.43	Integer	enabled (1)
ifLinkUpDownTrapEnable.44	.1.3.6.1.2.1.31.1.1.1.14.44	Integer	enabled (1)
ifLinkUpDownTrapEnable.45	.1.3.6.1.2.1.31.1.1.1.14.45	Integer	enabled (1)
ifLinkUpDownTrapEnable.46	.1.3.6.1.2.1.31.1.1.1.14.46	Integer	enabled (1)
ifLinkUpDownTrapEnable.47	.1.3.6.1.2.1.31.1.1.1.14.47	Integer	enabled (1)
ifLinkUpDownTrapEnable.48	.1.3.6.1.2.1.31.1.1.1.14.48	Integer	enabled (1)
ifLinkUpDownTrapEnable.49	.1.3.6.1.2.1.31.1.1.1.14.49	Integer	enabled (1)
ifLinkUpDownTrapEnable.50	.1.3.6.1.2.1.31.1.1.1.14.50	Integer	enabled (1)
ifLinkUpDownTrapEnable.51	.1.3.6.1.2.1.31.1.1.1.14.51	Integer	enabled (1)
ifLinkUpDownTrapEnable.52	.1.3.6.1.2.1.31.1.1.1.14.52	Integer	enabled (1)
ifLinkUpDownTrapEnable.53	.1.3.6.1.2.1.31.1.1.1.14.53	Integer	enabled (1)
ifLinkUpDownTrapEnable.54	.1.3.6.1.2.1.31.1.1.1.14.54	Integer	enabled (1)
ifLinkUpDownTrapEnable.631	.1.3.6.1.2.1.31.1.1.1.14.631	Integer	disabled (2)
ifLinkUpDownTrapEnable.632	.1.3.6.1.2.1.31.1.1.1.14.632	Integer	disabled (2)
ifLinkUpDownTrapEnable.633	.1.3.6.1.2.1.31.1.1.1.14.633	Integer	disabled (2)
ifLinkUpDownTrapEnable.634	.1.3.6.1.2.1.31.1.1.1.14.634	Integer	enabled (1)
ifHighSpeed.1	.1.3.6.1.2.1.31.1.1.1.15.1	Gauge	1000
ifHighSpeed.2	.1.3.6.1.2.1.31.1.1.1.15.2	Gauge	1000
ifHighSpeed.3	.1.3.6.1.2.1.31.1.1.1.15.3	Gauge	1000
ifHighSpeed.4	.1.3.6.1.2.1.31.1.1.1.15.4	Gauge	1000
ifHighSpeed.5	.1.3.6.1.2.1.31.1.1.1.15.5	Gauge	1000
ifHighSpeed.6	.1.3.6.1.2.1.31.1.1.1.15.6	Gauge	1000
ifHighSpeed.7	.1.3.6.1.2.1.31.1.1.1.15.7	Gauge	1000
ifHighSpeed.8	.1.3.6.1.2.1.31.1.1.1.15.8	Gauge	1000
ifHighSpeed.9	.1.3.6.1.2.1.31.1.1.1.15.9	Gauge	1000
ifHighSpeed.10	.1.3.6.1.2.1.31.1.1.1.15.10	Gauge	1000

Name	OID	Value Type	Value Example
ifHighSpeed.11	.1.3.6.1.2.1.31.1.1.1.15.11	Gauge	1000
ifHighSpeed.12	.1.3.6.1.2.1.31.1.1.1.15.12	Gauge	1000
ifHighSpeed.13	.1.3.6.1.2.1.31.1.1.1.15.13	Gauge	1000
ifHighSpeed.14	.1.3.6.1.2.1.31.1.1.1.15.14	Gauge	1000
ifHighSpeed.15	.1.3.6.1.2.1.31.1.1.1.15.15	Gauge	1000
ifHighSpeed.16	.1.3.6.1.2.1.31.1.1.1.15.16	Gauge	1000
ifHighSpeed.17	.1.3.6.1.2.1.31.1.1.1.15.17	Gauge	1000
ifHighSpeed.18	.1.3.6.1.2.1.31.1.1.1.15.18	Gauge	1000
ifHighSpeed.19	.1.3.6.1.2.1.31.1.1.1.15.19	Gauge	1000
ifHighSpeed.20	.1.3.6.1.2.1.31.1.1.1.15.20	Gauge	1000
ifHighSpeed.21	.1.3.6.1.2.1.31.1.1.1.15.21	Gauge	1000
ifHighSpeed.22	.1.3.6.1.2.1.31.1.1.1.15.22	Gauge	1000
ifHighSpeed.23	.1.3.6.1.2.1.31.1.1.1.15.23	Gauge	1000
ifHighSpeed.24	.1.3.6.1.2.1.31.1.1.1.15.24	Gauge	1000
ifHighSpeed.25	.1.3.6.1.2.1.31.1.1.1.15.25	Gauge	1000
ifHighSpeed.26	.1.3.6.1.2.1.31.1.1.1.15.26	Gauge	1000
ifHighSpeed.27	.1.3.6.1.2.1.31.1.1.1.15.27	Gauge	1000
ifHighSpeed.28	.1.3.6.1.2.1.31.1.1.1.15.28	Gauge	1000
ifHighSpeed.29	.1.3.6.1.2.1.31.1.1.1.15.29	Gauge	1000
ifHighSpeed.30	.1.3.6.1.2.1.31.1.1.1.15.30	Gauge	1000
ifHighSpeed.31	.1.3.6.1.2.1.31.1.1.1.15.31	Gauge	1000
ifHighSpeed.32	.1.3.6.1.2.1.31.1.1.1.15.32	Gauge	1000
ifHighSpeed.33	.1.3.6.1.2.1.31.1.1.1.15.33	Gauge	1000
ifHighSpeed.34	.1.3.6.1.2.1.31.1.1.1.15.34	Gauge	1000
ifHighSpeed.35	.1.3.6.1.2.1.31.1.1.1.15.35	Gauge	1000
ifHighSpeed.36	.1.3.6.1.2.1.31.1.1.1.15.36	Gauge	1000
ifHighSpeed.37	.1.3.6.1.2.1.31.1.1.1.15.37	Gauge	1000
ifHighSpeed.38	.1.3.6.1.2.1.31.1.1.1.15.38	Gauge	1000
ifHighSpeed.39	.1.3.6.1.2.1.31.1.1.1.15.39	Gauge	1000
ifHighSpeed.40	.1.3.6.1.2.1.31.1.1.1.15.40	Gauge	1000
ifHighSpeed.41	.1.3.6.1.2.1.31.1.1.1.15.41	Gauge	1000
ifHighSpeed.42	.1.3.6.1.2.1.31.1.1.1.15.42	Gauge	1000
ifHighSpeed.43	.1.3.6.1.2.1.31.1.1.1.15.43	Gauge	1000
ifHighSpeed.44	.1.3.6.1.2.1.31.1.1.1.15.44	Gauge	1000
ifHighSpeed.45	.1.3.6.1.2.1.31.1.1.1.15.45	Gauge	1000
ifHighSpeed.46	.1.3.6.1.2.1.31.1.1.1.15.46	Gauge	1000
ifHighSpeed.47	.1.3.6.1.2.1.31.1.1.1.15.47	Gauge	1000
ifHighSpeed.48	.1.3.6.1.2.1.31.1.1.1.15.48	Gauge	1000
ifHighSpeed.49	.1.3.6.1.2.1.31.1.1.1.15.49	Gauge	10000
ifHighSpeed.50	.1.3.6.1.2.1.31.1.1.1.15.50	Gauge	10000
ifHighSpeed.51	.1.3.6.1.2.1.31.1.1.1.15.51	Gauge	10000
ifHighSpeed.52	.1.3.6.1.2.1.31.1.1.1.15.52	Gauge	10000
ifHighSpeed.53	.1.3.6.1.2.1.31.1.1.1.15.53	Gauge	10000

Name	OID	Value Type	Value Example
ifHighSpeed.54	.1.3.6.1.2.1.31.1.1.1.15.54	Gauge	10000
ifHighSpeed.631	.1.3.6.1.2.1.31.1.1.1.15.631	Gauge	1000
ifHighSpeed.632	.1.3.6.1.2.1.31.1.1.1.15.632	Gauge	0
ifHighSpeed.633	.1.3.6.1.2.1.31.1.1.1.15.633	Gauge	0
ifHighSpeed.634	.1.3.6.1.2.1.31.1.1.1.15.634	Gauge	10000
ifPromiscuousMode.1	.1.3.6.1.2.1.31.1.1.1.16.1	Integer	false (2)
ifPromiscuousMode.2	.1.3.6.1.2.1.31.1.1.1.16.2	Integer	false (2)
ifPromiscuousMode.3	.1.3.6.1.2.1.31.1.1.1.16.3	Integer	false (2)
ifPromiscuousMode.4	.1.3.6.1.2.1.31.1.1.1.16.4	Integer	false (2)
ifPromiscuousMode.5	.1.3.6.1.2.1.31.1.1.1.16.5	Integer	false (2)
ifPromiscuousMode.6	.1.3.6.1.2.1.31.1.1.1.16.6	Integer	false (2)
ifPromiscuousMode.7	.1.3.6.1.2.1.31.1.1.1.16.7	Integer	false (2)
ifPromiscuousMode.8	.1.3.6.1.2.1.31.1.1.1.16.8	Integer	false (2)
ifPromiscuousMode.9	.1.3.6.1.2.1.31.1.1.1.16.9	Integer	false (2)
ifPromiscuousMode.10	.1.3.6.1.2.1.31.1.1.1.16.10	Integer	false (2)
ifPromiscuousMode.11	.1.3.6.1.2.1.31.1.1.1.16.11	Integer	false (2)
ifPromiscuousMode.12	.1.3.6.1.2.1.31.1.1.1.16.12	Integer	false (2)
ifPromiscuousMode.13	.1.3.6.1.2.1.31.1.1.1.16.13	Integer	false (2)
ifPromiscuousMode.14	.1.3.6.1.2.1.31.1.1.1.16.14	Integer	false (2)
ifPromiscuousMode.15	.1.3.6.1.2.1.31.1.1.1.16.15	Integer	false (2)
ifPromiscuousMode.16	.1.3.6.1.2.1.31.1.1.1.16.16	Integer	false (2)
ifPromiscuousMode.17	.1.3.6.1.2.1.31.1.1.1.16.17	Integer	false (2)
ifPromiscuousMode.18	.1.3.6.1.2.1.31.1.1.1.16.18	Integer	false (2)
ifPromiscuousMode.19	.1.3.6.1.2.1.31.1.1.1.16.19	Integer	false (2)
ifPromiscuousMode.20	.1.3.6.1.2.1.31.1.1.1.16.20	Integer	false (2)
ifPromiscuousMode.21	.1.3.6.1.2.1.31.1.1.1.16.21	Integer	false (2)
ifPromiscuousMode.22	.1.3.6.1.2.1.31.1.1.1.16.22	Integer	false (2)
ifPromiscuousMode.23	.1.3.6.1.2.1.31.1.1.1.16.23	Integer	false (2)
ifPromiscuousMode.24	.1.3.6.1.2.1.31.1.1.1.16.24	Integer	false (2)
ifPromiscuousMode.25	.1.3.6.1.2.1.31.1.1.1.16.25	Integer	false (2)
ifPromiscuousMode.26	.1.3.6.1.2.1.31.1.1.1.16.26	Integer	false (2)
ifPromiscuousMode.27	.1.3.6.1.2.1.31.1.1.1.16.27	Integer	false (2)
ifPromiscuousMode.28	.1.3.6.1.2.1.31.1.1.1.16.28	Integer	false (2)
ifPromiscuousMode.29	.1.3.6.1.2.1.31.1.1.1.16.29	Integer	false (2)
ifPromiscuousMode.30	.1.3.6.1.2.1.31.1.1.1.16.30	Integer	false (2)
ifPromiscuousMode.31	.1.3.6.1.2.1.31.1.1.1.16.31	Integer	false (2)
ifPromiscuousMode.32	.1.3.6.1.2.1.31.1.1.1.16.32	Integer	false (2)
ifPromiscuousMode.33	.1.3.6.1.2.1.31.1.1.1.16.33	Integer	false (2)
ifPromiscuousMode.34	.1.3.6.1.2.1.31.1.1.1.16.34	Integer	false (2)
ifPromiscuousMode.35	.1.3.6.1.2.1.31.1.1.1.16.35	Integer	false (2)
ifPromiscuousMode.36	.1.3.6.1.2.1.31.1.1.1.16.36	Integer	false (2)
ifPromiscuousMode.37	.1.3.6.1.2.1.31.1.1.1.16.37	Integer	false (2)
ifPromiscuousMode.38	.1.3.6.1.2.1.31.1.1.1.16.38	Integer	false (2)

Name	OID	Value Type	Value Example
ifPromiscuousMode.39	.1.3.6.1.2.1.31.1.1.1.16.39	Integer	false (2)
ifPromiscuousMode.40	.1.3.6.1.2.1.31.1.1.1.16.40	Integer	false (2)
ifPromiscuousMode.41	.1.3.6.1.2.1.31.1.1.1.16.41	Integer	false (2)
ifPromiscuousMode.42	.1.3.6.1.2.1.31.1.1.1.16.42	Integer	false (2)
ifPromiscuousMode.43	.1.3.6.1.2.1.31.1.1.1.16.43	Integer	false (2)
ifPromiscuousMode.44	.1.3.6.1.2.1.31.1.1.1.16.44	Integer	false (2)
ifPromiscuousMode.45	.1.3.6.1.2.1.31.1.1.1.16.45	Integer	false (2)
ifPromiscuousMode.46	.1.3.6.1.2.1.31.1.1.1.16.46	Integer	false (2)
ifPromiscuousMode.47	.1.3.6.1.2.1.31.1.1.1.16.47	Integer	false (2)
ifPromiscuousMode.48	.1.3.6.1.2.1.31.1.1.1.16.48	Integer	false (2)
ifPromiscuousMode.49	.1.3.6.1.2.1.31.1.1.1.16.49	Integer	false (2)
ifPromiscuousMode.50	.1.3.6.1.2.1.31.1.1.1.16.50	Integer	false (2)
ifPromiscuousMode.51	.1.3.6.1.2.1.31.1.1.1.16.51	Integer	false (2)
ifPromiscuousMode.52	.1.3.6.1.2.1.31.1.1.1.16.52	Integer	false (2)
ifPromiscuousMode.53	.1.3.6.1.2.1.31.1.1.1.16.53	Integer	false (2)
ifPromiscuousMode.54	.1.3.6.1.2.1.31.1.1.1.16.54	Integer	false (2)
ifPromiscuousMode.631	.1.3.6.1.2.1.31.1.1.1.16.631	Integer	false (2)
ifPromiscuousMode.632	.1.3.6.1.2.1.31.1.1.1.16.632	Integer	false (2)
ifPromiscuousMode.633	.1.3.6.1.2.1.31.1.1.1.16.633	Integer	false (2)
ifPromiscuousMode.634	.1.3.6.1.2.1.31.1.1.1.16.634	Integer	false (2)
ifConnectorPresent.1	.1.3.6.1.2.1.31.1.1.1.17.1	Integer	true (1)
ifConnectorPresent.2	.1.3.6.1.2.1.31.1.1.1.17.2	Integer	true (1)
ifConnectorPresent.3	.1.3.6.1.2.1.31.1.1.1.17.3	Integer	true (1)
ifConnectorPresent.4	.1.3.6.1.2.1.31.1.1.1.17.4	Integer	true (1)
ifConnectorPresent.5	.1.3.6.1.2.1.31.1.1.1.17.5	Integer	true (1)
ifConnectorPresent.6	.1.3.6.1.2.1.31.1.1.1.17.6	Integer	true (1)
ifConnectorPresent.7	.1.3.6.1.2.1.31.1.1.1.17.7	Integer	true (1)
ifConnectorPresent.8	.1.3.6.1.2.1.31.1.1.1.17.8	Integer	true (1)
ifConnectorPresent.9	.1.3.6.1.2.1.31.1.1.1.17.9	Integer	true (1)
ifConnectorPresent.10	.1.3.6.1.2.1.31.1.1.1.17.10	Integer	true (1)
ifConnectorPresent.11	.1.3.6.1.2.1.31.1.1.1.17.11	Integer	true (1)
ifConnectorPresent.12	.1.3.6.1.2.1.31.1.1.1.17.12	Integer	true (1)
ifConnectorPresent.13	.1.3.6.1.2.1.31.1.1.1.17.13	Integer	true (1)
ifConnectorPresent.14	.1.3.6.1.2.1.31.1.1.1.17.14	Integer	true (1)
ifConnectorPresent.15	.1.3.6.1.2.1.31.1.1.1.17.15	Integer	true (1)
ifConnectorPresent.16	.1.3.6.1.2.1.31.1.1.1.17.16	Integer	true (1)
ifConnectorPresent.17	.1.3.6.1.2.1.31.1.1.1.17.17	Integer	true (1)
ifConnectorPresent.18	.1.3.6.1.2.1.31.1.1.1.17.18	Integer	true (1)
ifConnectorPresent.19	.1.3.6.1.2.1.31.1.1.1.17.19	Integer	true (1)
ifConnectorPresent.20	.1.3.6.1.2.1.31.1.1.1.17.20	Integer	true (1)
ifConnectorPresent.21	.1.3.6.1.2.1.31.1.1.1.17.21	Integer	true (1)
ifConnectorPresent.22	.1.3.6.1.2.1.31.1.1.1.17.22	Integer	true (1)
ifConnectorPresent.23	.1.3.6.1.2.1.31.1.1.1.17.23	Integer	true (1)

Name	OID	Value Type	Value Example
ifConnectorPresent.24	.1.3.6.1.2.1.31.1.1.1.17.24	Integer	true (1)
ifConnectorPresent.25	.1.3.6.1.2.1.31.1.1.1.17.25	Integer	true (1)
ifConnectorPresent.26	.1.3.6.1.2.1.31.1.1.1.17.26	Integer	true (1)
ifConnectorPresent.27	.1.3.6.1.2.1.31.1.1.1.17.27	Integer	true (1)
ifConnectorPresent.28	.1.3.6.1.2.1.31.1.1.1.17.28	Integer	true (1)
ifConnectorPresent.29	.1.3.6.1.2.1.31.1.1.1.17.29	Integer	true (1)
ifConnectorPresent.30	.1.3.6.1.2.1.31.1.1.1.17.30	Integer	true (1)
ifConnectorPresent.31	.1.3.6.1.2.1.31.1.1.1.17.31	Integer	true (1)
ifConnectorPresent.32	.1.3.6.1.2.1.31.1.1.1.17.32	Integer	true (1)
ifConnectorPresent.33	.1.3.6.1.2.1.31.1.1.1.17.33	Integer	true (1)
ifConnectorPresent.34	.1.3.6.1.2.1.31.1.1.1.17.34	Integer	true (1)
ifConnectorPresent.35	.1.3.6.1.2.1.31.1.1.1.17.35	Integer	true (1)
ifConnectorPresent.36	.1.3.6.1.2.1.31.1.1.1.17.36	Integer	true (1)
ifConnectorPresent.37	.1.3.6.1.2.1.31.1.1.1.17.37	Integer	true (1)
ifConnectorPresent.38	.1.3.6.1.2.1.31.1.1.1.17.38	Integer	true (1)
ifConnectorPresent.39	.1.3.6.1.2.1.31.1.1.1.17.39	Integer	true (1)
ifConnectorPresent.40	.1.3.6.1.2.1.31.1.1.1.17.40	Integer	true (1)
ifConnectorPresent.41	.1.3.6.1.2.1.31.1.1.1.17.41	Integer	true (1)
ifConnectorPresent.42	.1.3.6.1.2.1.31.1.1.1.17.42	Integer	true (1)
ifConnectorPresent.43	.1.3.6.1.2.1.31.1.1.1.17.43	Integer	true (1)
ifConnectorPresent.44	.1.3.6.1.2.1.31.1.1.1.17.44	Integer	true (1)
ifConnectorPresent.45	.1.3.6.1.2.1.31.1.1.1.17.45	Integer	true (1)
ifConnectorPresent.46	.1.3.6.1.2.1.31.1.1.1.17.46	Integer	true (1)
ifConnectorPresent.47	.1.3.6.1.2.1.31.1.1.1.17.47	Integer	true (1)
ifConnectorPresent.48	.1.3.6.1.2.1.31.1.1.1.17.48	Integer	true (1)
ifConnectorPresent.49	.1.3.6.1.2.1.31.1.1.1.17.49	Integer	true (1)
ifConnectorPresent.50	.1.3.6.1.2.1.31.1.1.1.17.50	Integer	true (1)
ifConnectorPresent.51	.1.3.6.1.2.1.31.1.1.1.17.51	Integer	true (1)
ifConnectorPresent.52	.1.3.6.1.2.1.31.1.1.1.17.52	Integer	true (1)
ifConnectorPresent.53	.1.3.6.1.2.1.31.1.1.1.17.53	Integer	true (1)
ifConnectorPresent.54	.1.3.6.1.2.1.31.1.1.1.17.54	Integer	true (1)
ifConnectorPresent.631	.1.3.6.1.2.1.31.1.1.1.17.631	Integer	false (2)
ifConnectorPresent.632	.1.3.6.1.2.1.31.1.1.1.17.632	Integer	false (2)
ifConnectorPresent.633	.1.3.6.1.2.1.31.1.1.1.17.633	Integer	false (2)
ifConnectorPresent.634	.1.3.6.1.2.1.31.1.1.1.17.634	Integer	false (2)
ifAlias.1	.1.3.6.1.2.1.31.1.1.1.18.1	OctetString	UPLINK
ifAlias.2	.1.3.6.1.2.1.31.1.1.1.18.2	OctetString	GigabitEthernet1/0/2 Interface
ifAlias.3	.1.3.6.1.2.1.31.1.1.1.18.3	OctetString	GigabitEthernet1/0/3 Interface
ifAlias.4	.1.3.6.1.2.1.31.1.1.1.18.4	OctetString	GigabitEthernet1/0/4 Interface
ifAlias.5	.1.3.6.1.2.1.31.1.1.1.18.5	OctetString	GigabitEthernet1/0/5 Interface
ifAlias.6	.1.3.6.1.2.1.31.1.1.1.18.6	OctetString	GigabitEthernet1/0/6 Interface
ifAlias.7	.1.3.6.1.2.1.31.1.1.1.18.7	OctetString	GigabitEthernet1/0/7 Interface
ifAlias.8	.1.3.6.1.2.1.31.1.1.1.18.8	OctetString	GigabitEthernet1/0/8 Interface

Name	OID	Value Type	Value Example
ifAlias.9	.1.3.6.1.2.1.31.1.1.1.18.9	OctetString	GigabitEthernet1/0/9 Interface
ifAlias.10	.1.3.6.1.2.1.31.1.1.1.18.10	OctetString	GigabitEthernet1/0/10 Interface
ifAlias.11	.1.3.6.1.2.1.31.1.1.1.18.11	OctetString	GigabitEthernet1/0/11 Interface
ifAlias.12	.1.3.6.1.2.1.31.1.1.1.18.12	OctetString	GigabitEthernet1/0/12 Interface
ifAlias.13	.1.3.6.1.2.1.31.1.1.1.18.13	OctetString	GigabitEthernet1/0/13 Interface
ifAlias.14	.1.3.6.1.2.1.31.1.1.1.18.14	OctetString	GigabitEthernet1/0/14 Interface
ifAlias.15	.1.3.6.1.2.1.31.1.1.1.18.15	OctetString	GigabitEthernet1/0/15 Interface
ifAlias.16	.1.3.6.1.2.1.31.1.1.1.18.16	OctetString	GigabitEthernet1/0/16 Interface
ifAlias.17	.1.3.6.1.2.1.31.1.1.1.18.17	OctetString	GigabitEthernet1/0/17 Interface
ifAlias.18	.1.3.6.1.2.1.31.1.1.1.18.18	OctetString	GigabitEthernet1/0/18 Interface
ifAlias.19	.1.3.6.1.2.1.31.1.1.1.18.19	OctetString	GigabitEthernet1/0/19 Interface
ifAlias.20	.1.3.6.1.2.1.31.1.1.1.18.20	OctetString	GigabitEthernet1/0/20 Interface
ifAlias.21	.1.3.6.1.2.1.31.1.1.1.18.21	OctetString	GigabitEthernet1/0/21 Interface
ifAlias.22	.1.3.6.1.2.1.31.1.1.1.18.22	OctetString	GigabitEthernet1/0/22 Interface
ifAlias.23	.1.3.6.1.2.1.31.1.1.1.18.23	OctetString	GigabitEthernet1/0/23 Interface
ifAlias.24	.1.3.6.1.2.1.31.1.1.1.18.24	OctetString	GigabitEthernet1/0/24 Interface
ifAlias.25	.1.3.6.1.2.1.31.1.1.1.18.25	OctetString	GigabitEthernet1/0/25 Interface
ifAlias.26	.1.3.6.1.2.1.31.1.1.1.18.26	OctetString	GigabitEthernet1/0/26 Interface
ifAlias.27	.1.3.6.1.2.1.31.1.1.1.18.27	OctetString	GigabitEthernet1/0/27 Interface
ifAlias.28	.1.3.6.1.2.1.31.1.1.1.18.28	OctetString	GigabitEthernet1/0/28 Interface
ifAlias.29	.1.3.6.1.2.1.31.1.1.1.18.29	OctetString	GigabitEthernet1/0/29 Interface
ifAlias.30	.1.3.6.1.2.1.31.1.1.1.18.30	OctetString	GigabitEthernet1/0/30 Interface
ifAlias.31	.1.3.6.1.2.1.31.1.1.1.18.31	OctetString	GigabitEthernet1/0/31 Interface
ifAlias.32	.1.3.6.1.2.1.31.1.1.1.18.32	OctetString	GigabitEthernet1/0/32 Interface
ifAlias.33	.1.3.6.1.2.1.31.1.1.1.18.33	OctetString	GigabitEthernet1/0/33 Interface
ifAlias.34	.1.3.6.1.2.1.31.1.1.1.18.34	OctetString	GigabitEthernet1/0/34 Interface



Name	OID	Value Type	Value Example
ifAlias.35	.1.3.6.1.2.1.31.1.1.1.18.35	OctetString	GigabitEthernet1/0/35 Interface
ifAlias.36	.1.3.6.1.2.1.31.1.1.1.18.36	OctetString	GigabitEthernet1/0/36 Interface
ifAlias.37	.1.3.6.1.2.1.31.1.1.1.18.37	OctetString	GigabitEthernet1/0/37 Interface
ifAlias.38	.1.3.6.1.2.1.31.1.1.1.18.38	OctetString	GigabitEthernet1/0/38 Interface
ifAlias.39	.1.3.6.1.2.1.31.1.1.1.18.39	OctetString	GigabitEthernet1/0/39 Interface
ifAlias.40	.1.3.6.1.2.1.31.1.1.1.18.40	OctetString	GigabitEthernet1/0/40 Interface
ifAlias.41	.1.3.6.1.2.1.31.1.1.1.18.41	OctetString	GigabitEthernet1/0/41 Interface
ifAlias.42	.1.3.6.1.2.1.31.1.1.1.18.42	OctetString	GigabitEthernet1/0/42 Interface
ifAlias.43	.1.3.6.1.2.1.31.1.1.1.18.43	OctetString	GigabitEthernet1/0/43 Interface
ifAlias.44	.1.3.6.1.2.1.31.1.1.1.18.44	OctetString	GigabitEthernet1/0/44 Interface
ifAlias.45	.1.3.6.1.2.1.31.1.1.1.18.45	OctetString	RODRIGO-PC
ifAlias.46	.1.3.6.1.2.1.31.1.1.1.18.46	OctetString	GigabitEthernet1/0/46 Interface
ifAlias.47	.1.3.6.1.2.1.31.1.1.1.18.47	OctetString	ANA-PC
ifAlias.48	.1.3.6.1.2.1.31.1.1.1.18.48	OctetString	GigabitEthernet1/0/48 Interface
ifAlias.49	.1.3.6.1.2.1.31.1.1.1.18.49	OctetString	Ten-GigabitEthernet1/0/49 Interface
ifAlias.50	.1.3.6.1.2.1.31.1.1.1.18.50	OctetString	Ten-GigabitEthernet1/0/50 Interface
ifAlias.51	.1.3.6.1.2.1.31.1.1.1.18.51	OctetString	Ten-GigabitEthernet1/0/51 Interface
ifAlias.52	.1.3.6.1.2.1.31.1.1.1.18.52	OctetString	Ten-GigabitEthernet1/0/52 Interface
ifAlias.53	.1.3.6.1.2.1.31.1.1.1.18.53	OctetString	Ten-GigabitEthernet1/0/53 Interface
ifAlias.54	.1.3.6.1.2.1.31.1.1.1.18.54	OctetString	Ten-GigabitEthernet1/0/54 Interface
ifAlias.631	.1.3.6.1.2.1.31.1.1.1.18.631	OctetString	NULL0 Interface
ifAlias.632	.1.3.6.1.2.1.31.1.1.1.18.632	OctetString	InLoopBack0 Interface
ifAlias.633	.1.3.6.1.2.1.31.1.1.1.18.633	OctetString	Register-Tunnel0 Interface
ifAlias.634	.1.3.6.1.2.1.31.1.1.1.18.634	OctetString	Vlan-interface1 Interface
ifCounterDiscontinuityTime.1	.1.3.6.1.2.1.31.1.1.1.19.1	TimeTicks	0 millisecond (0)
ifCounterDiscontinuityTime.2	.1.3.6.1.2.1.31.1.1.1.19.2	TimeTicks	0 millisecond (0)
ifCounterDiscontinuityTime.3	.1.3.6.1.2.1.31.1.1.1.19.3	TimeTicks	0 millisecond (0)
ifCounterDiscontinuityTime.4	.1.3.6.1.2.1.31.1.1.1.19.4	TimeTicks	0 millisecond (0)
ifCounterDiscontinuityTime.5	.1.3.6.1.2.1.31.1.1.1.19.5	TimeTicks	0 millisecond (0)
ifCounterDiscontinuityTime.6	.1.3.6.1.2.1.31.1.1.1.19.6	TimeTicks	0 millisecond (0)



Name	OID	Value Type	Value Example
ifCounterDiscontinuityTime.50	.1.3.6.1.2.1.31.1.1.1.19.50	TimeTicks	0 millisecond (0)
ifCounterDiscontinuityTime.51	.1.3.6.1.2.1.31.1.1.1.19.51	TimeTicks	0 millisecond (0)
ifCounterDiscontinuityTime.52	.1.3.6.1.2.1.31.1.1.1.19.52	TimeTicks	0 millisecond (0)
ifCounterDiscontinuityTime.53	.1.3.6.1.2.1.31.1.1.1.19.53	TimeTicks	0 millisecond (0)
ifCounterDiscontinuityTime.54	.1.3.6.1.2.1.31.1.1.1.19.54	TimeTicks	0 millisecond (0)
ifCounterDiscontinuity-Time.631	.1.3.6.1.2.1.31.1.1.1.19.631	TimeTicks	0 millisecond (0)
ifCounterDiscontinuity-Time.632	.1.3.6.1.2.1.31.1.1.1.19.632	TimeTicks	0 millisecond (0)
ifCounterDiscontinuity-Time.633	.1.3.6.1.2.1.31.1.1.1.19.633	TimeTicks	0 millisecond (0)
ifCounterDiscontinuity-Time.634	.1.3.6.1.2.1.31.1.1.1.19.634	TimeTicks	0 millisecond (0)
ifRcvAddressStatus.1.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.1.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.2.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.2.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.3.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.3.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.4.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.4.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.5.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.5.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.6.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.6.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.7.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.7.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.8.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.8.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.9.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.9.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.10.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.10.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.11.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.11.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.12.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.12.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.13.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.13.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.14.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.14.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.15.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.15.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.16.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.16.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.17.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.17.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.18.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.18.6.20.132.119.149.29.176	Integer	active (1)

Name	OID	Value Type	Value Example
ifRcvAddressStatus.19.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.19.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.20.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.20.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.21.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.21.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.22.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.22.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.23.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.23.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.24.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.24.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.25.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.25.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.26.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.26.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.27.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.27.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.28.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.28.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.29.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.29.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.30.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.30.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.31.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.31.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.32.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.32.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.33.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.33.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.34.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.34.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.35.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.35.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.36.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.36.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.37.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.37.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.38.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.38.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.39.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.39.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.40.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.40.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.41.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.41.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.42.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.42.6.20.132.119.149.29.176	Integer	active (1)
ifRcvAddressStatus.43.6.20.132.119.149.29.176	.1.3.6.1.2.1.31.1.4.1.2.43.6.20.132.119.149.29.176	Integer	active (1)



Name	OID	Value Type	Value Example
ifRcvAddressType.25.6.20.1.32611	2.1.491.294.176.25.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.26.6.20.1.32611	2.1.491.294.176.26.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.27.6.20.1.32611	2.1.491.294.176.27.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.28.6.20.1.32611	2.1.491.294.176.28.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.29.6.20.1.32611	2.1.491.294.176.29.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.30.6.20.1.32611	2.1.491.294.176.30.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.31.6.20.1.32611	2.1.491.294.176.31.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.32.6.20.1.32611	2.1.491.294.176.32.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.33.6.20.1.32611	2.1.491.294.176.33.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.34.6.20.1.32611	2.1.491.294.176.34.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.35.6.20.1.32611	2.1.491.294.176.35.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.36.6.20.1.32611	2.1.491.294.176.36.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.37.6.20.1.32611	2.1.491.294.176.37.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.38.6.20.1.32611	2.1.491.294.176.38.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.39.6.20.1.32611	2.1.491.294.176.39.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.40.6.20.1.32611	2.1.491.294.176.40.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.41.6.20.1.32611	2.1.491.294.176.41.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.42.6.20.1.32611	2.1.491.294.176.42.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.43.6.20.1.32611	2.1.491.294.176.43.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.44.6.20.1.32611	2.1.491.294.176.44.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.45.6.20.1.32611	2.1.491.294.176.45.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.46.6.20.1.32611	2.1.491.294.176.46.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.47.6.20.1.32611	2.1.491.294.176.47.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.48.6.20.1.32611	2.1.491.294.176.48.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.49.6.20.1.32611	2.1.491.294.176.49.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.50.6.20.1.32611	2.1.491.294.176.50.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.51.6.20.1.32611	2.1.491.294.176.51.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.52.6.20.1.32611	2.1.491.294.176.52.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.53.6.20.1.32611	2.1.491.294.176.53.6.20.132.119.149.20	Integer	nonVolatile (3)
ifRcvAddressType.54.6.20.1.32611	2.1.491.294.176.54.6.20.132.119.149.20	Integer	nonVolatile (3)
ifTableLastChange.0	.1.3.6.1.2.1.31.1.5.0	TimeTicks	3 minutes 37.94 seconds (21794)
entPhysicalDescr.1	.1.3.6.1.2.1.47.1.1.1.2.1	OctetString	INTELBRAS
entPhysicalDescr.2	.1.3.6.1.2.1.47.1.1.1.2.2	OctetString	INTELBRAS SC 3570-48GP-6X Software Version 7.1.070
entPhysicalDescr.12	.1.3.6.1.2.1.47.1.1.1.2.12	OctetString	CONTAINER LEVEL1
entPhysicalDescr.13	.1.3.6.1.2.1.47.1.1.1.2.13	OctetString	CONTAINER LEVEL1
entPhysicalDescr.14	.1.3.6.1.2.1.47.1.1.1.2.14	OctetString	CONTAINER LEVEL1
entPhysicalDescr.15	.1.3.6.1.2.1.47.1.1.1.2.15	OctetString	CONTAINER LEVEL1
entPhysicalDescr.16	.1.3.6.1.2.1.47.1.1.1.2.16	OctetString	CONTAINER LEVEL1
entPhysicalDescr.17	.1.3.6.1.2.1.47.1.1.1.2.17	OctetString	CONTAINER LEVEL1
entPhysicalDescr.18	.1.3.6.1.2.1.47.1.1.1.2.18	OctetString	CONTAINER LEVEL1
entPhysicalDescr.19	.1.3.6.1.2.1.47.1.1.1.2.19	OctetString	CONTAINER LEVEL1

Name	OID	Value Type	Value Example
entPhysicalDescr.20	.1.3.6.1.2.1.47.1.1.1.1.2.20	OctetString	CONTAINER LEVEL1
entPhysicalDescr.21	.1.3.6.1.2.1.47.1.1.1.1.2.21	OctetString	CONTAINER LEVEL1
entPhysicalDescr.22	.1.3.6.1.2.1.47.1.1.1.1.2.22	OctetString	CONTAINER LEVEL1
entPhysicalDescr.23	.1.3.6.1.2.1.47.1.1.1.1.2.23	OctetString	CONTAINER LEVEL1
entPhysicalDescr.24	.1.3.6.1.2.1.47.1.1.1.1.2.24	OctetString	CONTAINER LEVEL1
entPhysicalDescr.25	.1.3.6.1.2.1.47.1.1.1.1.2.25	OctetString	CONTAINER LEVEL1
entPhysicalDescr.26	.1.3.6.1.2.1.47.1.1.1.1.2.26	OctetString	CONTAINER LEVEL1
entPhysicalDescr.27	.1.3.6.1.2.1.47.1.1.1.1.2.27	OctetString	CONTAINER LEVEL1
entPhysicalDescr.28	.1.3.6.1.2.1.47.1.1.1.1.2.28	OctetString	CONTAINER LEVEL1
entPhysicalDescr.29	.1.3.6.1.2.1.47.1.1.1.1.2.29	OctetString	CONTAINER LEVEL1
entPhysicalDescr.30	.1.3.6.1.2.1.47.1.1.1.1.2.30	OctetString	CONTAINER LEVEL1
entPhysicalDescr.31	.1.3.6.1.2.1.47.1.1.1.1.2.31	OctetString	CONTAINER LEVEL1
entPhysicalDescr.212	.1.3.6.1.2.1.47.1.1.1.1.2.212	OctetString	MODULE LEVEL1
entPhysicalDescr.213	.1.3.6.1.2.1.47.1.1.1.1.2.213	OctetString	PSU
entPhysicalDescr.216	.1.3.6.1.2.1.47.1.1.1.1.2.216	OctetString	FAN UNIT
entPhysicalDescr.220	.1.3.6.1.2.1.47.1.1.1.1.2.220	OctetString	SENSOR
entPhysicalDescr.221	.1.3.6.1.2.1.47.1.1.1.1.2.221	OctetString	SENSOR
entPhysicalDescr.412	.1.3.6.1.2.1.47.1.1.1.1.2.412	OctetString	CONTAINER LEVEL2
entPhysicalDescr.413	.1.3.6.1.2.1.47.1.1.1.1.2.413	OctetString	CONTAINER LEVEL2
entPhysicalDescr.414	.1.3.6.1.2.1.47.1.1.1.1.2.414	OctetString	CONTAINER LEVEL2
entPhysicalDescr.442	.1.3.6.1.2.1.47.1.1.1.1.2.442	OctetString	MODULE LEVEL2
entPhysicalDescr.472	.1.3.6.1.2.1.47.1.1.1.1.2.472	OctetString	GigabitEthernet1/0/1
entPhysicalDescr.473	.1.3.6.1.2.1.47.1.1.1.1.2.473	OctetString	GigabitEthernet1/0/2
entPhysicalDescr.474	.1.3.6.1.2.1.47.1.1.1.1.2.474	OctetString	GigabitEthernet1/0/3
entPhysicalDescr.475	.1.3.6.1.2.1.47.1.1.1.1.2.475	OctetString	GigabitEthernet1/0/4
entPhysicalDescr.476	.1.3.6.1.2.1.47.1.1.1.1.2.476	OctetString	GigabitEthernet1/0/5
entPhysicalDescr.477	.1.3.6.1.2.1.47.1.1.1.1.2.477	OctetString	GigabitEthernet1/0/6
entPhysicalDescr.478	.1.3.6.1.2.1.47.1.1.1.1.2.478	OctetString	GigabitEthernet1/0/7
entPhysicalDescr.479	.1.3.6.1.2.1.47.1.1.1.1.2.479	OctetString	GigabitEthernet1/0/8
entPhysicalDescr.480	.1.3.6.1.2.1.47.1.1.1.1.2.480	OctetString	GigabitEthernet1/0/9
entPhysicalDescr.481	.1.3.6.1.2.1.47.1.1.1.1.2.481	OctetString	GigabitEthernet1/0/10
entPhysicalDescr.482	.1.3.6.1.2.1.47.1.1.1.1.2.482	OctetString	GigabitEthernet1/0/11
entPhysicalDescr.483	.1.3.6.1.2.1.47.1.1.1.1.2.483	OctetString	GigabitEthernet1/0/12
entPhysicalDescr.484	.1.3.6.1.2.1.47.1.1.1.1.2.484	OctetString	GigabitEthernet1/0/13
entPhysicalDescr.485	.1.3.6.1.2.1.47.1.1.1.1.2.485	OctetString	GigabitEthernet1/0/14
entPhysicalDescr.486	.1.3.6.1.2.1.47.1.1.1.1.2.486	OctetString	GigabitEthernet1/0/15
entPhysicalDescr.487	.1.3.6.1.2.1.47.1.1.1.1.2.487	OctetString	GigabitEthernet1/0/16
entPhysicalDescr.488	.1.3.6.1.2.1.47.1.1.1.1.2.488	OctetString	GigabitEthernet1/0/17
entPhysicalDescr.489	.1.3.6.1.2.1.47.1.1.1.1.2.489	OctetString	GigabitEthernet1/0/18
entPhysicalDescr.490	.1.3.6.1.2.1.47.1.1.1.1.2.490	OctetString	GigabitEthernet1/0/19
entPhysicalDescr.491	.1.3.6.1.2.1.47.1.1.1.1.2.491	OctetString	GigabitEthernet1/0/20
entPhysicalDescr.492	.1.3.6.1.2.1.47.1.1.1.1.2.492	OctetString	GigabitEthernet1/0/21
entPhysicalDescr.493	.1.3.6.1.2.1.47.1.1.1.1.2.493	OctetString	GigabitEthernet1/0/22



Name	OID	Value Type	Value Example
entPhysicalDescr.494	.1.3.6.1.2.1.47.1.1.1.1.2.494	OctetString	GigabitEthernet1/0/23
entPhysicalDescr.495	.1.3.6.1.2.1.47.1.1.1.1.2.495	OctetString	GigabitEthernet1/0/24
entPhysicalDescr.496	.1.3.6.1.2.1.47.1.1.1.1.2.496	OctetString	GigabitEthernet1/0/25
entPhysicalDescr.497	.1.3.6.1.2.1.47.1.1.1.1.2.497	OctetString	GigabitEthernet1/0/26
entPhysicalDescr.498	.1.3.6.1.2.1.47.1.1.1.1.2.498	OctetString	GigabitEthernet1/0/27
entPhysicalDescr.499	.1.3.6.1.2.1.47.1.1.1.1.2.499	OctetString	GigabitEthernet1/0/28
entPhysicalDescr.500	.1.3.6.1.2.1.47.1.1.1.1.2.500	OctetString	GigabitEthernet1/0/29
entPhysicalDescr.501	.1.3.6.1.2.1.47.1.1.1.1.2.501	OctetString	GigabitEthernet1/0/30
entPhysicalDescr.502	.1.3.6.1.2.1.47.1.1.1.1.2.502	OctetString	GigabitEthernet1/0/31
entPhysicalDescr.503	.1.3.6.1.2.1.47.1.1.1.1.2.503	OctetString	GigabitEthernet1/0/32
entPhysicalDescr.504	.1.3.6.1.2.1.47.1.1.1.1.2.504	OctetString	GigabitEthernet1/0/33
entPhysicalDescr.505	.1.3.6.1.2.1.47.1.1.1.1.2.505	OctetString	GigabitEthernet1/0/34
entPhysicalDescr.506	.1.3.6.1.2.1.47.1.1.1.1.2.506	OctetString	GigabitEthernet1/0/35
entPhysicalDescr.507	.1.3.6.1.2.1.47.1.1.1.1.2.507	OctetString	GigabitEthernet1/0/36
entPhysicalDescr.508	.1.3.6.1.2.1.47.1.1.1.1.2.508	OctetString	GigabitEthernet1/0/37
entPhysicalDescr.509	.1.3.6.1.2.1.47.1.1.1.1.2.509	OctetString	GigabitEthernet1/0/38
entPhysicalDescr.510	.1.3.6.1.2.1.47.1.1.1.1.2.510	OctetString	GigabitEthernet1/0/39
entPhysicalDescr.511	.1.3.6.1.2.1.47.1.1.1.1.2.511	OctetString	GigabitEthernet1/0/40
entPhysicalDescr.512	.1.3.6.1.2.1.47.1.1.1.1.2.512	OctetString	GigabitEthernet1/0/41
entPhysicalDescr.513	.1.3.6.1.2.1.47.1.1.1.1.2.513	OctetString	GigabitEthernet1/0/42
entPhysicalDescr.514	.1.3.6.1.2.1.47.1.1.1.1.2.514	OctetString	GigabitEthernet1/0/43
entPhysicalDescr.515	.1.3.6.1.2.1.47.1.1.1.1.2.515	OctetString	GigabitEthernet1/0/44
entPhysicalDescr.516	.1.3.6.1.2.1.47.1.1.1.1.2.516	OctetString	GigabitEthernet1/0/45
entPhysicalDescr.517	.1.3.6.1.2.1.47.1.1.1.1.2.517	OctetString	GigabitEthernet1/0/46
entPhysicalDescr.518	.1.3.6.1.2.1.47.1.1.1.1.2.518	OctetString	GigabitEthernet1/0/47
entPhysicalDescr.519	.1.3.6.1.2.1.47.1.1.1.1.2.519	OctetString	GigabitEthernet1/0/48
entPhysicalDescr.520	.1.3.6.1.2.1.47.1.1.1.1.2.520	OctetString	Ten-GigabitEthernet1/0/49
entPhysicalDescr.521	.1.3.6.1.2.1.47.1.1.1.1.2.521	OctetString	Ten-GigabitEthernet1/0/50
entPhysicalDescr.522	.1.3.6.1.2.1.47.1.1.1.1.2.522	OctetString	Ten-GigabitEthernet1/0/51
entPhysicalDescr.523	.1.3.6.1.2.1.47.1.1.1.1.2.523	OctetString	Ten-GigabitEthernet1/0/52
entPhysicalDescr.524	.1.3.6.1.2.1.47.1.1.1.1.2.524	OctetString	Ten-GigabitEthernet1/0/53
entPhysicalDescr.525	.1.3.6.1.2.1.47.1.1.1.1.2.525	OctetString	Ten-GigabitEthernet1/0/54
entPhysicalVendorType.1	.1.3.6.1.2.1.47.1.1.1.1.3.1	OID	.0.0
entPhysicalVendorType.2	.1.3.6.1.2.1.47.1.1.1.1.3.2	OID	ib-SC3570-48GP-6X
entPhysicalVendorType.12	.1.3.6.1.2.1.47.1.1.1.1.3.12	OID	.0.0
entPhysicalVendorType.13	.1.3.6.1.2.1.47.1.1.1.1.3.13	OID	.0.0
entPhysicalVendorType.14	.1.3.6.1.2.1.47.1.1.1.1.3.14	OID	.0.0
entPhysicalVendorType.15	.1.3.6.1.2.1.47.1.1.1.1.3.15	OID	.0.0
entPhysicalVendorType.16	.1.3.6.1.2.1.47.1.1.1.1.3.16	OID	.0.0
entPhysicalVendorType.17	.1.3.6.1.2.1.47.1.1.1.1.3.17	OID	.0.0
entPhysicalVendorType.18	.1.3.6.1.2.1.47.1.1.1.1.3.18	OID	.0.0
entPhysicalVendorType.19	.1.3.6.1.2.1.47.1.1.1.1.3.19	OID	.0.0
entPhysicalVendorType.20	.1.3.6.1.2.1.47.1.1.1.1.3.20	OID	.0.0



Name	OID	Value Type	Value Example
entPhysicalVendorType.21	.1.3.6.1.2.1.47.1.1.1.1.3.21	OID	.0.0
entPhysicalVendorType.22	.1.3.6.1.2.1.47.1.1.1.1.3.22	OID	.0.0
entPhysicalVendorType.23	.1.3.6.1.2.1.47.1.1.1.1.3.23	OID	.0.0
entPhysicalVendorType.24	.1.3.6.1.2.1.47.1.1.1.1.3.24	OID	.0.0
entPhysicalVendorType.25	.1.3.6.1.2.1.47.1.1.1.1.3.25	OID	.0.0
entPhysicalVendorType.26	.1.3.6.1.2.1.47.1.1.1.1.3.26	OID	.0.0
entPhysicalVendorType.27	.1.3.6.1.2.1.47.1.1.1.1.3.27	OID	.0.0
entPhysicalVendorType.28	.1.3.6.1.2.1.47.1.1.1.1.3.28	OID	.0.0
entPhysicalVendorType.29	.1.3.6.1.2.1.47.1.1.1.1.3.29	OID	.0.0
entPhysicalVendorType.30	.1.3.6.1.2.1.47.1.1.1.1.3.30	OID	.0.0
entPhysicalVendorType.31	.1.3.6.1.2.1.47.1.1.1.1.3.31	OID	.0.0
entPhysicalVendorType.212	.1.3.6.1.2.1.47.1.1.1.1.3.212	OID	.0.0
entPhysicalVendorType.213	.1.3.6.1.2.1.47.1.1.1.1.3.213	OID	.1.3.6.1.4.1.26138.2.3.126.10.3.1.6.2
entPhysicalVendorType.216	.1.3.6.1.2.1.47.1.1.1.1.3.216	OID	.0.0
entPhysicalVendorType.220	.1.3.6.1.2.1.47.1.1.1.1.3.220	OID	.0.0
entPhysicalVendorType.221	.1.3.6.1.2.1.47.1.1.1.1.3.221	OID	.0.0
entPhysicalVendorType.412	.1.3.6.1.2.1.47.1.1.1.1.3.412	OID	.0.0
entPhysicalVendorType.413	.1.3.6.1.2.1.47.1.1.1.1.3.413	OID	.0.0
entPhysicalVendorType.414	.1.3.6.1.2.1.47.1.1.1.1.3.414	OID	.0.0
entPhysicalVendorType.442	.1.3.6.1.2.1.47.1.1.1.1.3.442	OID	.0.0
entPhysicalVendorType.472	.1.3.6.1.2.1.47.1.1.1.1.3.472	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.473	.1.3.6.1.2.1.47.1.1.1.1.3.473	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.474	.1.3.6.1.2.1.47.1.1.1.1.3.474	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.475	.1.3.6.1.2.1.47.1.1.1.1.3.475	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.476	.1.3.6.1.2.1.47.1.1.1.1.3.476	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.477	.1.3.6.1.2.1.47.1.1.1.1.3.477	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.478	.1.3.6.1.2.1.47.1.1.1.1.3.478	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.479	.1.3.6.1.2.1.47.1.1.1.1.3.479	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.480	.1.3.6.1.2.1.47.1.1.1.1.3.480	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.481	.1.3.6.1.2.1.47.1.1.1.1.3.481	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.482	.1.3.6.1.2.1.47.1.1.1.1.3.482	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.483	.1.3.6.1.2.1.47.1.1.1.1.3.483	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.484	.1.3.6.1.2.1.47.1.1.1.1.3.484	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.485	.1.3.6.1.2.1.47.1.1.1.1.3.485	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.486	.1.3.6.1.2.1.47.1.1.1.1.3.486	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.487	.1.3.6.1.2.1.47.1.1.1.1.3.487	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.488	.1.3.6.1.2.1.47.1.1.1.1.3.488	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.489	.1.3.6.1.2.1.47.1.1.1.1.3.489	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.490	.1.3.6.1.2.1.47.1.1.1.1.3.490	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.491	.1.3.6.1.2.1.47.1.1.1.1.3.491	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.492	.1.3.6.1.2.1.47.1.1.1.1.3.492	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.493	.1.3.6.1.2.1.47.1.1.1.1.3.493	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.494	.1.3.6.1.2.1.47.1.1.1.1.3.494	OID	ibevtPortSw-1000BASE-T

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
entPhysicalVendorType.495	.1.3.6.1.2.1.47.1.1.1.1.3.495	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.496	.1.3.6.1.2.1.47.1.1.1.1.3.496	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.497	.1.3.6.1.2.1.47.1.1.1.1.3.497	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.498	.1.3.6.1.2.1.47.1.1.1.1.3.498	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.499	.1.3.6.1.2.1.47.1.1.1.1.3.499	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.500	.1.3.6.1.2.1.47.1.1.1.1.3.500	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.501	.1.3.6.1.2.1.47.1.1.1.1.3.501	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.502	.1.3.6.1.2.1.47.1.1.1.1.3.502	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.503	.1.3.6.1.2.1.47.1.1.1.1.3.503	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.504	.1.3.6.1.2.1.47.1.1.1.1.3.504	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.505	.1.3.6.1.2.1.47.1.1.1.1.3.505	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.506	.1.3.6.1.2.1.47.1.1.1.1.3.506	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.507	.1.3.6.1.2.1.47.1.1.1.1.3.507	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.508	.1.3.6.1.2.1.47.1.1.1.1.3.508	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.509	.1.3.6.1.2.1.47.1.1.1.1.3.509	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.510	.1.3.6.1.2.1.47.1.1.1.1.3.510	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.511	.1.3.6.1.2.1.47.1.1.1.1.3.511	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.512	.1.3.6.1.2.1.47.1.1.1.1.3.512	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.513	.1.3.6.1.2.1.47.1.1.1.1.3.513	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.514	.1.3.6.1.2.1.47.1.1.1.1.3.514	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.515	.1.3.6.1.2.1.47.1.1.1.1.3.515	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.516	.1.3.6.1.2.1.47.1.1.1.1.3.516	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.517	.1.3.6.1.2.1.47.1.1.1.1.3.517	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.518	.1.3.6.1.2.1.47.1.1.1.1.3.518	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.519	.1.3.6.1.2.1.47.1.1.1.1.3.519	OID	ibevtPortSw-1000BASE-T
entPhysicalVendorType.520	.1.3.6.1.2.1.47.1.1.1.1.3.520	OID	ibevtPortSw-SFP-PLUS-NO-CONNECTOR
entPhysicalVendorType.521	.1.3.6.1.2.1.47.1.1.1.1.3.521	OID	ibevtPortSw-SFP-PLUS-NO-CONNECTOR
entPhysicalVendorType.522	.1.3.6.1.2.1.47.1.1.1.1.3.522	OID	ibevtPortSw-SFP-PLUS-NO-CONNECTOR
entPhysicalVendorType.523	.1.3.6.1.2.1.47.1.1.1.1.3.523	OID	ibevtPortSw-SFP-PLUS-NO-CONNECTOR
entPhysicalVendorType.524	.1.3.6.1.2.1.47.1.1.1.1.3.524	OID	ibevtPortSw-SFP-PLUS-NO-CONNECTOR
entPhysicalVendorType.525	.1.3.6.1.2.1.47.1.1.1.1.3.525	OID	ibevtPortSw-SFP-PLUS-NO-CONNECTOR
entPhysicalContainedIn.1	.1.3.6.1.2.1.47.1.1.1.1.4.1	Integer	0
entPhysicalContainedIn.2	.1.3.6.1.2.1.47.1.1.1.1.4.2	Integer	1
entPhysicalContainedIn.12	.1.3.6.1.2.1.47.1.1.1.1.4.12	Integer	2
entPhysicalContainedIn.13	.1.3.6.1.2.1.47.1.1.1.1.4.13	Integer	2
entPhysicalContainedIn.14	.1.3.6.1.2.1.47.1.1.1.1.4.14	Integer	2
entPhysicalContainedIn.15	.1.3.6.1.2.1.47.1.1.1.1.4.15	Integer	2
entPhysicalContainedIn.16	.1.3.6.1.2.1.47.1.1.1.1.4.16	Integer	2
entPhysicalContainedIn.17	.1.3.6.1.2.1.47.1.1.1.1.4.17	Integer	2

Name	OID	Value Type	Value Example
entPhysicalContainedIn.18	.1.3.6.1.2.1.47.1.1.1.1.4.18	Integer	2
entPhysicalContainedIn.19	.1.3.6.1.2.1.47.1.1.1.1.4.19	Integer	2
entPhysicalContainedIn.20	.1.3.6.1.2.1.47.1.1.1.1.4.20	Integer	2
entPhysicalContainedIn.21	.1.3.6.1.2.1.47.1.1.1.1.4.21	Integer	2
entPhysicalContainedIn.22	.1.3.6.1.2.1.47.1.1.1.1.4.22	Integer	2
entPhysicalContainedIn.23	.1.3.6.1.2.1.47.1.1.1.1.4.23	Integer	2
entPhysicalContainedIn.24	.1.3.6.1.2.1.47.1.1.1.1.4.24	Integer	2
entPhysicalContainedIn.25	.1.3.6.1.2.1.47.1.1.1.1.4.25	Integer	2
entPhysicalContainedIn.26	.1.3.6.1.2.1.47.1.1.1.1.4.26	Integer	2
entPhysicalContainedIn.27	.1.3.6.1.2.1.47.1.1.1.1.4.27	Integer	2
entPhysicalContainedIn.28	.1.3.6.1.2.1.47.1.1.1.1.4.28	Integer	2
entPhysicalContainedIn.29	.1.3.6.1.2.1.47.1.1.1.1.4.29	Integer	2
entPhysicalContainedIn.30	.1.3.6.1.2.1.47.1.1.1.1.4.30	Integer	2
entPhysicalContainedIn.31	.1.3.6.1.2.1.47.1.1.1.1.4.31	Integer	2
entPhysicalContainedIn.212	.1.3.6.1.2.1.47.1.1.1.1.4.212	Integer	12
entPhysicalContainedIn.213	.1.3.6.1.2.1.47.1.1.1.1.4.213	Integer	13
entPhysicalContainedIn.216	.1.3.6.1.2.1.47.1.1.1.1.4.216	Integer	16
entPhysicalContainedIn.220	.1.3.6.1.2.1.47.1.1.1.1.4.220	Integer	20
entPhysicalContainedIn.221	.1.3.6.1.2.1.47.1.1.1.1.4.221	Integer	21
entPhysicalContainedIn.412	.1.3.6.1.2.1.47.1.1.1.1.4.412	Integer	212
entPhysicalContainedIn.413	.1.3.6.1.2.1.47.1.1.1.1.4.413	Integer	212
entPhysicalContainedIn.414	.1.3.6.1.2.1.47.1.1.1.1.4.414	Integer	212
entPhysicalContainedIn.442	.1.3.6.1.2.1.47.1.1.1.1.4.442	Integer	412
entPhysicalContainedIn.472	.1.3.6.1.2.1.47.1.1.1.1.4.472	Integer	442
entPhysicalContainedIn.473	.1.3.6.1.2.1.47.1.1.1.1.4.473	Integer	442
entPhysicalContainedIn.474	.1.3.6.1.2.1.47.1.1.1.1.4.474	Integer	442
entPhysicalContainedIn.475	.1.3.6.1.2.1.47.1.1.1.1.4.475	Integer	442
entPhysicalContainedIn.476	.1.3.6.1.2.1.47.1.1.1.1.4.476	Integer	442
entPhysicalContainedIn.477	.1.3.6.1.2.1.47.1.1.1.1.4.477	Integer	442
entPhysicalContainedIn.478	.1.3.6.1.2.1.47.1.1.1.1.4.478	Integer	442
entPhysicalContainedIn.479	.1.3.6.1.2.1.47.1.1.1.1.4.479	Integer	442
entPhysicalContainedIn.480	.1.3.6.1.2.1.47.1.1.1.1.4.480	Integer	442
entPhysicalContainedIn.481	.1.3.6.1.2.1.47.1.1.1.1.4.481	Integer	442
entPhysicalContainedIn.482	.1.3.6.1.2.1.47.1.1.1.1.4.482	Integer	442
entPhysicalContainedIn.483	.1.3.6.1.2.1.47.1.1.1.1.4.483	Integer	442
entPhysicalContainedIn.484	.1.3.6.1.2.1.47.1.1.1.1.4.484	Integer	442
entPhysicalContainedIn.485	.1.3.6.1.2.1.47.1.1.1.1.4.485	Integer	442
entPhysicalContainedIn.486	.1.3.6.1.2.1.47.1.1.1.1.4.486	Integer	442
entPhysicalContainedIn.487	.1.3.6.1.2.1.47.1.1.1.1.4.487	Integer	442
entPhysicalContainedIn.488	.1.3.6.1.2.1.47.1.1.1.1.4.488	Integer	442
entPhysicalContainedIn.489	.1.3.6.1.2.1.47.1.1.1.1.4.489	Integer	442
entPhysicalContainedIn.490	.1.3.6.1.2.1.47.1.1.1.1.4.490	Integer	442
entPhysicalContainedIn.491	.1.3.6.1.2.1.47.1.1.1.1.4.491	Integer	442

Name	OID	Value Type	Value Example
entPhysicalContainedIn.492	.1.3.6.1.2.1.47.1.1.1.1.4.492	Integer	442
entPhysicalContainedIn.493	.1.3.6.1.2.1.47.1.1.1.1.4.493	Integer	442
entPhysicalContainedIn.494	.1.3.6.1.2.1.47.1.1.1.1.4.494	Integer	442
entPhysicalContainedIn.495	.1.3.6.1.2.1.47.1.1.1.1.4.495	Integer	442
entPhysicalContainedIn.496	.1.3.6.1.2.1.47.1.1.1.1.4.496	Integer	442
entPhysicalContainedIn.497	.1.3.6.1.2.1.47.1.1.1.1.4.497	Integer	442
entPhysicalContainedIn.498	.1.3.6.1.2.1.47.1.1.1.1.4.498	Integer	442
entPhysicalContainedIn.499	.1.3.6.1.2.1.47.1.1.1.1.4.499	Integer	442
entPhysicalContainedIn.500	.1.3.6.1.2.1.47.1.1.1.1.4.500	Integer	442
entPhysicalContainedIn.501	.1.3.6.1.2.1.47.1.1.1.1.4.501	Integer	442
entPhysicalContainedIn.502	.1.3.6.1.2.1.47.1.1.1.1.4.502	Integer	442
entPhysicalContainedIn.503	.1.3.6.1.2.1.47.1.1.1.1.4.503	Integer	442
entPhysicalContainedIn.504	.1.3.6.1.2.1.47.1.1.1.1.4.504	Integer	442
entPhysicalContainedIn.505	.1.3.6.1.2.1.47.1.1.1.1.4.505	Integer	442
entPhysicalContainedIn.506	.1.3.6.1.2.1.47.1.1.1.1.4.506	Integer	442
entPhysicalContainedIn.507	.1.3.6.1.2.1.47.1.1.1.1.4.507	Integer	442
entPhysicalContainedIn.508	.1.3.6.1.2.1.47.1.1.1.1.4.508	Integer	442
entPhysicalContainedIn.509	.1.3.6.1.2.1.47.1.1.1.1.4.509	Integer	442
entPhysicalContainedIn.510	.1.3.6.1.2.1.47.1.1.1.1.4.510	Integer	442
entPhysicalContainedIn.511	.1.3.6.1.2.1.47.1.1.1.1.4.511	Integer	442
entPhysicalContainedIn.512	.1.3.6.1.2.1.47.1.1.1.1.4.512	Integer	442
entPhysicalContainedIn.513	.1.3.6.1.2.1.47.1.1.1.1.4.513	Integer	442
entPhysicalContainedIn.514	.1.3.6.1.2.1.47.1.1.1.1.4.514	Integer	442
entPhysicalContainedIn.515	.1.3.6.1.2.1.47.1.1.1.1.4.515	Integer	442
entPhysicalContainedIn.516	.1.3.6.1.2.1.47.1.1.1.1.4.516	Integer	442
entPhysicalContainedIn.517	.1.3.6.1.2.1.47.1.1.1.1.4.517	Integer	442
entPhysicalContainedIn.518	.1.3.6.1.2.1.47.1.1.1.1.4.518	Integer	442
entPhysicalContainedIn.519	.1.3.6.1.2.1.47.1.1.1.1.4.519	Integer	442
entPhysicalContainedIn.520	.1.3.6.1.2.1.47.1.1.1.1.4.520	Integer	442
entPhysicalContainedIn.521	.1.3.6.1.2.1.47.1.1.1.1.4.521	Integer	442
entPhysicalContainedIn.522	.1.3.6.1.2.1.47.1.1.1.1.4.522	Integer	442
entPhysicalContainedIn.523	.1.3.6.1.2.1.47.1.1.1.1.4.523	Integer	442
entPhysicalContainedIn.524	.1.3.6.1.2.1.47.1.1.1.1.4.524	Integer	442
entPhysicalContainedIn.525	.1.3.6.1.2.1.47.1.1.1.1.4.525	Integer	442
entPhysicalClass.1	.1.3.6.1.2.1.47.1.1.1.1.5.1	Integer	stack (11)
entPhysicalClass.2	.1.3.6.1.2.1.47.1.1.1.1.5.2	Integer	chassis (3)
entPhysicalClass.12	.1.3.6.1.2.1.47.1.1.1.1.5.12	Integer	container (5)
entPhysicalClass.13	.1.3.6.1.2.1.47.1.1.1.1.5.13	Integer	container (5)
entPhysicalClass.14	.1.3.6.1.2.1.47.1.1.1.1.5.14	Integer	container (5)
entPhysicalClass.15	.1.3.6.1.2.1.47.1.1.1.1.5.15	Integer	container (5)
entPhysicalClass.16	.1.3.6.1.2.1.47.1.1.1.1.5.16	Integer	container (5)
entPhysicalClass.17	.1.3.6.1.2.1.47.1.1.1.1.5.17	Integer	container (5)
entPhysicalClass.18	.1.3.6.1.2.1.47.1.1.1.1.5.18	Integer	container (5)

Name	OID	Value Type	Value Example
entPhysicalClass.19	.1.3.6.1.2.1.47.1.1.1.1.5.19	Integer	container (5)
entPhysicalClass.20	.1.3.6.1.2.1.47.1.1.1.1.5.20	Integer	container (5)
entPhysicalClass.21	.1.3.6.1.2.1.47.1.1.1.1.5.21	Integer	container (5)
entPhysicalClass.22	.1.3.6.1.2.1.47.1.1.1.1.5.22	Integer	container (5)
entPhysicalClass.23	.1.3.6.1.2.1.47.1.1.1.1.5.23	Integer	container (5)
entPhysicalClass.24	.1.3.6.1.2.1.47.1.1.1.1.5.24	Integer	container (5)
entPhysicalClass.25	.1.3.6.1.2.1.47.1.1.1.1.5.25	Integer	container (5)
entPhysicalClass.26	.1.3.6.1.2.1.47.1.1.1.1.5.26	Integer	container (5)
entPhysicalClass.27	.1.3.6.1.2.1.47.1.1.1.1.5.27	Integer	container (5)
entPhysicalClass.28	.1.3.6.1.2.1.47.1.1.1.1.5.28	Integer	container (5)
entPhysicalClass.29	.1.3.6.1.2.1.47.1.1.1.1.5.29	Integer	container (5)
entPhysicalClass.30	.1.3.6.1.2.1.47.1.1.1.1.5.30	Integer	container (5)
entPhysicalClass.31	.1.3.6.1.2.1.47.1.1.1.1.5.31	Integer	container (5)
entPhysicalClass.212	.1.3.6.1.2.1.47.1.1.1.1.5.212	Integer	module (9)
entPhysicalClass.213	.1.3.6.1.2.1.47.1.1.1.1.5.213	Integer	powerSupply (6)
entPhysicalClass.216	.1.3.6.1.2.1.47.1.1.1.1.5.216	Integer	fan (7)
entPhysicalClass.220	.1.3.6.1.2.1.47.1.1.1.1.5.220	Integer	sensor (8)
entPhysicalClass.221	.1.3.6.1.2.1.47.1.1.1.1.5.221	Integer	sensor (8)
entPhysicalClass.412	.1.3.6.1.2.1.47.1.1.1.1.5.412	Integer	container (5)
entPhysicalClass.413	.1.3.6.1.2.1.47.1.1.1.1.5.413	Integer	container (5)
entPhysicalClass.414	.1.3.6.1.2.1.47.1.1.1.1.5.414	Integer	container (5)
entPhysicalClass.442	.1.3.6.1.2.1.47.1.1.1.1.5.442	Integer	module (9)
entPhysicalClass.472	.1.3.6.1.2.1.47.1.1.1.1.5.472	Integer	port (10)
entPhysicalClass.473	.1.3.6.1.2.1.47.1.1.1.1.5.473	Integer	port (10)
entPhysicalClass.474	.1.3.6.1.2.1.47.1.1.1.1.5.474	Integer	port (10)
entPhysicalClass.475	.1.3.6.1.2.1.47.1.1.1.1.5.475	Integer	port (10)
entPhysicalClass.476	.1.3.6.1.2.1.47.1.1.1.1.5.476	Integer	port (10)
entPhysicalClass.477	.1.3.6.1.2.1.47.1.1.1.1.5.477	Integer	port (10)
entPhysicalClass.478	.1.3.6.1.2.1.47.1.1.1.1.5.478	Integer	port (10)
entPhysicalClass.479	.1.3.6.1.2.1.47.1.1.1.1.5.479	Integer	port (10)
entPhysicalClass.480	.1.3.6.1.2.1.47.1.1.1.1.5.480	Integer	port (10)
entPhysicalClass.481	.1.3.6.1.2.1.47.1.1.1.1.5.481	Integer	port (10)
entPhysicalClass.482	.1.3.6.1.2.1.47.1.1.1.1.5.482	Integer	port (10)
entPhysicalClass.483	.1.3.6.1.2.1.47.1.1.1.1.5.483	Integer	port (10)
entPhysicalClass.484	.1.3.6.1.2.1.47.1.1.1.1.5.484	Integer	port (10)
entPhysicalClass.485	.1.3.6.1.2.1.47.1.1.1.1.5.485	Integer	port (10)
entPhysicalClass.486	.1.3.6.1.2.1.47.1.1.1.1.5.486	Integer	port (10)
entPhysicalClass.487	.1.3.6.1.2.1.47.1.1.1.1.5.487	Integer	port (10)
entPhysicalClass.488	.1.3.6.1.2.1.47.1.1.1.1.5.488	Integer	port (10)
entPhysicalClass.489	.1.3.6.1.2.1.47.1.1.1.1.5.489	Integer	port (10)
entPhysicalClass.490	.1.3.6.1.2.1.47.1.1.1.1.5.490	Integer	port (10)
entPhysicalClass.491	.1.3.6.1.2.1.47.1.1.1.1.5.491	Integer	port (10)
entPhysicalClass.492	.1.3.6.1.2.1.47.1.1.1.1.5.492	Integer	port (10)

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
entPhysicalClass.493	.1.3.6.1.2.1.47.1.1.1.1.5.493	Integer	port (10)
entPhysicalClass.494	.1.3.6.1.2.1.47.1.1.1.1.5.494	Integer	port (10)
entPhysicalClass.495	.1.3.6.1.2.1.47.1.1.1.1.5.495	Integer	port (10)
entPhysicalClass.496	.1.3.6.1.2.1.47.1.1.1.1.5.496	Integer	port (10)
entPhysicalClass.497	.1.3.6.1.2.1.47.1.1.1.1.5.497	Integer	port (10)
entPhysicalClass.498	.1.3.6.1.2.1.47.1.1.1.1.5.498	Integer	port (10)
entPhysicalClass.499	.1.3.6.1.2.1.47.1.1.1.1.5.499	Integer	port (10)
entPhysicalClass.500	.1.3.6.1.2.1.47.1.1.1.1.5.500	Integer	port (10)
entPhysicalClass.501	.1.3.6.1.2.1.47.1.1.1.1.5.501	Integer	port (10)
entPhysicalClass.502	.1.3.6.1.2.1.47.1.1.1.1.5.502	Integer	port (10)
entPhysicalClass.503	.1.3.6.1.2.1.47.1.1.1.1.5.503	Integer	port (10)
entPhysicalClass.504	.1.3.6.1.2.1.47.1.1.1.1.5.504	Integer	port (10)
entPhysicalClass.505	.1.3.6.1.2.1.47.1.1.1.1.5.505	Integer	port (10)
entPhysicalClass.506	.1.3.6.1.2.1.47.1.1.1.1.5.506	Integer	port (10)
entPhysicalClass.507	.1.3.6.1.2.1.47.1.1.1.1.5.507	Integer	port (10)
entPhysicalClass.508	.1.3.6.1.2.1.47.1.1.1.1.5.508	Integer	port (10)
entPhysicalClass.509	.1.3.6.1.2.1.47.1.1.1.1.5.509	Integer	port (10)
entPhysicalClass.510	.1.3.6.1.2.1.47.1.1.1.1.5.510	Integer	port (10)
entPhysicalClass.511	.1.3.6.1.2.1.47.1.1.1.1.5.511	Integer	port (10)
entPhysicalClass.512	.1.3.6.1.2.1.47.1.1.1.1.5.512	Integer	port (10)
entPhysicalClass.513	.1.3.6.1.2.1.47.1.1.1.1.5.513	Integer	port (10)
entPhysicalClass.514	.1.3.6.1.2.1.47.1.1.1.1.5.514	Integer	port (10)
entPhysicalClass.515	.1.3.6.1.2.1.47.1.1.1.1.5.515	Integer	port (10)
entPhysicalClass.516	.1.3.6.1.2.1.47.1.1.1.1.5.516	Integer	port (10)
entPhysicalClass.517	.1.3.6.1.2.1.47.1.1.1.1.5.517	Integer	port (10)
entPhysicalClass.518	.1.3.6.1.2.1.47.1.1.1.1.5.518	Integer	port (10)
entPhysicalClass.519	.1.3.6.1.2.1.47.1.1.1.1.5.519	Integer	port (10)
entPhysicalClass.520	.1.3.6.1.2.1.47.1.1.1.1.5.520	Integer	port (10)
entPhysicalClass.521	.1.3.6.1.2.1.47.1.1.1.1.5.521	Integer	port (10)
entPhysicalClass.522	.1.3.6.1.2.1.47.1.1.1.1.5.522	Integer	port (10)
entPhysicalClass.523	.1.3.6.1.2.1.47.1.1.1.1.5.523	Integer	port (10)
entPhysicalClass.524	.1.3.6.1.2.1.47.1.1.1.1.5.524	Integer	port (10)
entPhysicalClass.525	.1.3.6.1.2.1.47.1.1.1.1.5.525	Integer	port (10)
entPhysicalParentRelPos.1	.1.3.6.1.2.1.47.1.1.1.1.6.1	Integer	-1
entPhysicalParentRelPos.2	.1.3.6.1.2.1.47.1.1.1.1.6.2	Integer	1
entPhysicalParentRelPos.12	.1.3.6.1.2.1.47.1.1.1.1.6.12	Integer	1
entPhysicalParentRelPos.13	.1.3.6.1.2.1.47.1.1.1.1.6.13	Integer	2
entPhysicalParentRelPos.14	.1.3.6.1.2.1.47.1.1.1.1.6.14	Integer	3
entPhysicalParentRelPos.15	.1.3.6.1.2.1.47.1.1.1.1.6.15	Integer	4
entPhysicalParentRelPos.16	.1.3.6.1.2.1.47.1.1.1.1.6.16	Integer	5
entPhysicalParentRelPos.17	.1.3.6.1.2.1.47.1.1.1.1.6.17	Integer	6
entPhysicalParentRelPos.18	.1.3.6.1.2.1.47.1.1.1.1.6.18	Integer	7
entPhysicalParentRelPos.19	.1.3.6.1.2.1.47.1.1.1.1.6.19	Integer	8

Name	OID	Value Type	Value Example
entPhysicalParentRelPos.20	.1.3.6.1.2.1.47.1.1.1.1.6.20	Integer	9
entPhysicalParentRelPos.21	.1.3.6.1.2.1.47.1.1.1.1.6.21	Integer	10
entPhysicalParentRelPos.22	.1.3.6.1.2.1.47.1.1.1.1.6.22	Integer	11
entPhysicalParentRelPos.23	.1.3.6.1.2.1.47.1.1.1.1.6.23	Integer	12
entPhysicalParentRelPos.24	.1.3.6.1.2.1.47.1.1.1.1.6.24	Integer	13
entPhysicalParentRelPos.25	.1.3.6.1.2.1.47.1.1.1.1.6.25	Integer	14
entPhysicalParentRelPos.26	.1.3.6.1.2.1.47.1.1.1.1.6.26	Integer	15
entPhysicalParentRelPos.27	.1.3.6.1.2.1.47.1.1.1.1.6.27	Integer	16
entPhysicalParentRelPos.28	.1.3.6.1.2.1.47.1.1.1.1.6.28	Integer	17
entPhysicalParentRelPos.29	.1.3.6.1.2.1.47.1.1.1.1.6.29	Integer	18
entPhysicalParentRelPos.30	.1.3.6.1.2.1.47.1.1.1.1.6.30	Integer	19
entPhysicalParentRelPos.31	.1.3.6.1.2.1.47.1.1.1.1.6.31	Integer	20
entPhysicalParentRelPos.212	.1.3.6.1.2.1.47.1.1.1.1.6.212	Integer	1
entPhysicalParentRelPos.213	.1.3.6.1.2.1.47.1.1.1.1.6.213	Integer	1
entPhysicalParentRelPos.216	.1.3.6.1.2.1.47.1.1.1.1.6.216	Integer	1
entPhysicalParentRelPos.220	.1.3.6.1.2.1.47.1.1.1.1.6.220	Integer	1
entPhysicalParentRelPos.221	.1.3.6.1.2.1.47.1.1.1.1.6.221	Integer	1
entPhysicalParentRelPos.412	.1.3.6.1.2.1.47.1.1.1.1.6.412	Integer	1
entPhysicalParentRelPos.413	.1.3.6.1.2.1.47.1.1.1.1.6.413	Integer	2
entPhysicalParentRelPos.414	.1.3.6.1.2.1.47.1.1.1.1.6.414	Integer	3
entPhysicalParentRelPos.442	.1.3.6.1.2.1.47.1.1.1.1.6.442	Integer	1
entPhysicalParentRelPos.472	.1.3.6.1.2.1.47.1.1.1.1.6.472	Integer	1
entPhysicalParentRelPos.473	.1.3.6.1.2.1.47.1.1.1.1.6.473	Integer	2
entPhysicalParentRelPos.474	.1.3.6.1.2.1.47.1.1.1.1.6.474	Integer	3
entPhysicalParentRelPos.475	.1.3.6.1.2.1.47.1.1.1.1.6.475	Integer	4
entPhysicalParentRelPos.476	.1.3.6.1.2.1.47.1.1.1.1.6.476	Integer	5
entPhysicalParentRelPos.477	.1.3.6.1.2.1.47.1.1.1.1.6.477	Integer	6
entPhysicalParentRelPos.478	.1.3.6.1.2.1.47.1.1.1.1.6.478	Integer	7
entPhysicalParentRelPos.479	.1.3.6.1.2.1.47.1.1.1.1.6.479	Integer	8
entPhysicalParentRelPos.480	.1.3.6.1.2.1.47.1.1.1.1.6.480	Integer	9
entPhysicalParentRelPos.481	.1.3.6.1.2.1.47.1.1.1.1.6.481	Integer	10
entPhysicalParentRelPos.482	.1.3.6.1.2.1.47.1.1.1.1.6.482	Integer	11
entPhysicalParentRelPos.483	.1.3.6.1.2.1.47.1.1.1.1.6.483	Integer	12
entPhysicalParentRelPos.484	.1.3.6.1.2.1.47.1.1.1.1.6.484	Integer	13
entPhysicalParentRelPos.485	.1.3.6.1.2.1.47.1.1.1.1.6.485	Integer	14
entPhysicalParentRelPos.486	.1.3.6.1.2.1.47.1.1.1.1.6.486	Integer	15
entPhysicalParentRelPos.487	.1.3.6.1.2.1.47.1.1.1.1.6.487	Integer	16
entPhysicalParentRelPos.488	.1.3.6.1.2.1.47.1.1.1.1.6.488	Integer	17
entPhysicalParentRelPos.489	.1.3.6.1.2.1.47.1.1.1.1.6.489	Integer	18
entPhysicalParentRelPos.490	.1.3.6.1.2.1.47.1.1.1.1.6.490	Integer	19
entPhysicalParentRelPos.491	.1.3.6.1.2.1.47.1.1.1.1.6.491	Integer	20
entPhysicalParentRelPos.492	.1.3.6.1.2.1.47.1.1.1.1.6.492	Integer	21
entPhysicalParentRelPos.493	.1.3.6.1.2.1.47.1.1.1.1.6.493	Integer	22



Name	OID	Value Type	Value Example
entPhysicalParentRelPos.494	.1.3.6.1.2.1.47.1.1.1.1.6.494	Integer	23
entPhysicalParentRelPos.495	.1.3.6.1.2.1.47.1.1.1.1.6.495	Integer	24
entPhysicalParentRelPos.496	.1.3.6.1.2.1.47.1.1.1.1.6.496	Integer	25
entPhysicalParentRelPos.497	.1.3.6.1.2.1.47.1.1.1.1.6.497	Integer	26
entPhysicalParentRelPos.498	.1.3.6.1.2.1.47.1.1.1.1.6.498	Integer	27
entPhysicalParentRelPos.499	.1.3.6.1.2.1.47.1.1.1.1.6.499	Integer	28
entPhysicalParentRelPos.500	.1.3.6.1.2.1.47.1.1.1.1.6.500	Integer	29
entPhysicalParentRelPos.501	.1.3.6.1.2.1.47.1.1.1.1.6.501	Integer	30
entPhysicalParentRelPos.502	.1.3.6.1.2.1.47.1.1.1.1.6.502	Integer	31
entPhysicalParentRelPos.503	.1.3.6.1.2.1.47.1.1.1.1.6.503	Integer	32
entPhysicalParentRelPos.504	.1.3.6.1.2.1.47.1.1.1.1.6.504	Integer	33
entPhysicalParentRelPos.505	.1.3.6.1.2.1.47.1.1.1.1.6.505	Integer	34
entPhysicalParentRelPos.506	.1.3.6.1.2.1.47.1.1.1.1.6.506	Integer	35
entPhysicalParentRelPos.507	.1.3.6.1.2.1.47.1.1.1.1.6.507	Integer	36
entPhysicalParentRelPos.508	.1.3.6.1.2.1.47.1.1.1.1.6.508	Integer	37
entPhysicalParentRelPos.509	.1.3.6.1.2.1.47.1.1.1.1.6.509	Integer	38
entPhysicalParentRelPos.510	.1.3.6.1.2.1.47.1.1.1.1.6.510	Integer	39
entPhysicalParentRelPos.511	.1.3.6.1.2.1.47.1.1.1.1.6.511	Integer	40
entPhysicalParentRelPos.512	.1.3.6.1.2.1.47.1.1.1.1.6.512	Integer	41
entPhysicalParentRelPos.513	.1.3.6.1.2.1.47.1.1.1.1.6.513	Integer	42
entPhysicalParentRelPos.514	.1.3.6.1.2.1.47.1.1.1.1.6.514	Integer	43
entPhysicalParentRelPos.515	.1.3.6.1.2.1.47.1.1.1.1.6.515	Integer	44
entPhysicalParentRelPos.516	.1.3.6.1.2.1.47.1.1.1.1.6.516	Integer	45
entPhysicalParentRelPos.517	.1.3.6.1.2.1.47.1.1.1.1.6.517	Integer	46
entPhysicalParentRelPos.518	.1.3.6.1.2.1.47.1.1.1.1.6.518	Integer	47
entPhysicalParentRelPos.519	.1.3.6.1.2.1.47.1.1.1.1.6.519	Integer	48
entPhysicalParentRelPos.520	.1.3.6.1.2.1.47.1.1.1.1.6.520	Integer	49
entPhysicalParentRelPos.521	.1.3.6.1.2.1.47.1.1.1.1.6.521	Integer	50
entPhysicalParentRelPos.522	.1.3.6.1.2.1.47.1.1.1.1.6.522	Integer	51
entPhysicalParentRelPos.523	.1.3.6.1.2.1.47.1.1.1.1.6.523	Integer	52
entPhysicalParentRelPos.524	.1.3.6.1.2.1.47.1.1.1.1.6.524	Integer	53
entPhysicalParentRelPos.525	.1.3.6.1.2.1.47.1.1.1.1.6.525	Integer	54
entPhysicalName.1	.1.3.6.1.2.1.47.1.1.1.1.7.1	OctetString	
entPhysicalName.2	.1.3.6.1.2.1.47.1.1.1.1.7.2	OctetString	SC 3570
entPhysicalName.12	.1.3.6.1.2.1.47.1.1.1.1.7.12	OctetString	Level 1 Container #1
entPhysicalName.13	.1.3.6.1.2.1.47.1.1.1.1.7.13	OctetString	Level 1 Container #2
entPhysicalName.14	.1.3.6.1.2.1.47.1.1.1.1.7.14	OctetString	Level 1 Container #3
entPhysicalName.15	.1.3.6.1.2.1.47.1.1.1.1.7.15	OctetString	Level 1 Container #4
entPhysicalName.16	.1.3.6.1.2.1.47.1.1.1.1.7.16	OctetString	Level 1 Container #5
entPhysicalName.17	.1.3.6.1.2.1.47.1.1.1.1.7.17	OctetString	Level 1 Container #6
entPhysicalName.18	.1.3.6.1.2.1.47.1.1.1.1.7.18	OctetString	Level 1 Container #7
entPhysicalName.19	.1.3.6.1.2.1.47.1.1.1.1.7.19	OctetString	Level 1 Container #8
entPhysicalName.20	.1.3.6.1.2.1.47.1.1.1.1.7.20	OctetString	Level 1 Container #9



Name	OID	Value Type	Value Example
entPhysicalName.21	.1.3.6.1.2.1.47.1.1.1.1.7.21	OctetString	Level 1 Container #10
entPhysicalName.22	.1.3.6.1.2.1.47.1.1.1.1.7.22	OctetString	Level 1 Container #11
entPhysicalName.23	.1.3.6.1.2.1.47.1.1.1.1.7.23	OctetString	Level 1 Container #12
entPhysicalName.24	.1.3.6.1.2.1.47.1.1.1.1.7.24	OctetString	Level 1 Container #13
entPhysicalName.25	.1.3.6.1.2.1.47.1.1.1.1.7.25	OctetString	Level 1 Container #14
entPhysicalName.26	.1.3.6.1.2.1.47.1.1.1.1.7.26	OctetString	Level 1 Container #15
entPhysicalName.27	.1.3.6.1.2.1.47.1.1.1.1.7.27	OctetString	Level 1 Container #16
entPhysicalName.28	.1.3.6.1.2.1.47.1.1.1.1.7.28	OctetString	Level 1 Container #17
entPhysicalName.29	.1.3.6.1.2.1.47.1.1.1.1.7.29	OctetString	Level 1 Container #18
entPhysicalName.30	.1.3.6.1.2.1.47.1.1.1.1.7.30	OctetString	Level 1 Container #19
entPhysicalName.31	.1.3.6.1.2.1.47.1.1.1.1.7.31	OctetString	Level 1 Container #20
entPhysicalName.212	.1.3.6.1.2.1.47.1.1.1.1.7.212	OctetString	Board
entPhysicalName.213	.1.3.6.1.2.1.47.1.1.1.1.7.213	OctetString	PSU 1
entPhysicalName.216	.1.3.6.1.2.1.47.1.1.1.1.7.216	OctetString	FAN 1
entPhysicalName.220	.1.3.6.1.2.1.47.1.1.1.1.7.220	OctetString	SENSOR 1
entPhysicalName.221	.1.3.6.1.2.1.47.1.1.1.1.7.221	OctetString	SENSOR 2
entPhysicalName.412	.1.3.6.1.2.1.47.1.1.1.1.7.412	OctetString	Level 2 Virtual Container #0
entPhysicalName.413	.1.3.6.1.2.1.47.1.1.1.1.7.413	OctetString	Level 2 Virtual Container #1
entPhysicalName.414	.1.3.6.1.2.1.47.1.1.1.1.7.414	OctetString	Level 2 Virtual Container #2
entPhysicalName.442	.1.3.6.1.2.1.47.1.1.1.1.7.442	OctetString	SubCard0
entPhysicalName.472	.1.3.6.1.2.1.47.1.1.1.1.7.472	OctetString	GigabitEthernet1/0/1
entPhysicalName.473	.1.3.6.1.2.1.47.1.1.1.1.7.473	OctetString	GigabitEthernet1/0/2
entPhysicalName.474	.1.3.6.1.2.1.47.1.1.1.1.7.474	OctetString	GigabitEthernet1/0/3
entPhysicalName.475	.1.3.6.1.2.1.47.1.1.1.1.7.475	OctetString	GigabitEthernet1/0/4
entPhysicalName.476	.1.3.6.1.2.1.47.1.1.1.1.7.476	OctetString	GigabitEthernet1/0/5
entPhysicalName.477	.1.3.6.1.2.1.47.1.1.1.1.7.477	OctetString	GigabitEthernet1/0/6
entPhysicalName.478	.1.3.6.1.2.1.47.1.1.1.1.7.478	OctetString	GigabitEthernet1/0/7
entPhysicalName.479	.1.3.6.1.2.1.47.1.1.1.1.7.479	OctetString	GigabitEthernet1/0/8
entPhysicalName.480	.1.3.6.1.2.1.47.1.1.1.1.7.480	OctetString	GigabitEthernet1/0/9
entPhysicalName.481	.1.3.6.1.2.1.47.1.1.1.1.7.481	OctetString	GigabitEthernet1/0/10
entPhysicalName.482	.1.3.6.1.2.1.47.1.1.1.1.7.482	OctetString	GigabitEthernet1/0/11
entPhysicalName.483	.1.3.6.1.2.1.47.1.1.1.1.7.483	OctetString	GigabitEthernet1/0/12
entPhysicalName.484	.1.3.6.1.2.1.47.1.1.1.1.7.484	OctetString	GigabitEthernet1/0/13
entPhysicalName.485	.1.3.6.1.2.1.47.1.1.1.1.7.485	OctetString	GigabitEthernet1/0/14
entPhysicalName.486	.1.3.6.1.2.1.47.1.1.1.1.7.486	OctetString	GigabitEthernet1/0/15
entPhysicalName.487	.1.3.6.1.2.1.47.1.1.1.1.7.487	OctetString	GigabitEthernet1/0/16
entPhysicalName.488	.1.3.6.1.2.1.47.1.1.1.1.7.488	OctetString	GigabitEthernet1/0/17
entPhysicalName.489	.1.3.6.1.2.1.47.1.1.1.1.7.489	OctetString	GigabitEthernet1/0/18
entPhysicalName.490	.1.3.6.1.2.1.47.1.1.1.1.7.490	OctetString	GigabitEthernet1/0/19
entPhysicalName.491	.1.3.6.1.2.1.47.1.1.1.1.7.491	OctetString	GigabitEthernet1/0/20
entPhysicalName.492	.1.3.6.1.2.1.47.1.1.1.1.7.492	OctetString	GigabitEthernet1/0/21
entPhysicalName.493	.1.3.6.1.2.1.47.1.1.1.1.7.493	OctetString	GigabitEthernet1/0/22
entPhysicalName.494	.1.3.6.1.2.1.47.1.1.1.1.7.494	OctetString	GigabitEthernet1/0/23

Name	OID	Value Type	Value Example
entPhysicalName.495	.1.3.6.1.2.1.47.1.1.1.1.7.495	OctetString	GigabitEthernet1/0/24
entPhysicalName.496	.1.3.6.1.2.1.47.1.1.1.1.7.496	OctetString	GigabitEthernet1/0/25
entPhysicalName.497	.1.3.6.1.2.1.47.1.1.1.1.7.497	OctetString	GigabitEthernet1/0/26
entPhysicalName.498	.1.3.6.1.2.1.47.1.1.1.1.7.498	OctetString	GigabitEthernet1/0/27
entPhysicalName.499	.1.3.6.1.2.1.47.1.1.1.1.7.499	OctetString	GigabitEthernet1/0/28
entPhysicalName.500	.1.3.6.1.2.1.47.1.1.1.1.7.500	OctetString	GigabitEthernet1/0/29
entPhysicalName.501	.1.3.6.1.2.1.47.1.1.1.1.7.501	OctetString	GigabitEthernet1/0/30
entPhysicalName.502	.1.3.6.1.2.1.47.1.1.1.1.7.502	OctetString	GigabitEthernet1/0/31
entPhysicalName.503	.1.3.6.1.2.1.47.1.1.1.1.7.503	OctetString	GigabitEthernet1/0/32
entPhysicalName.504	.1.3.6.1.2.1.47.1.1.1.1.7.504	OctetString	GigabitEthernet1/0/33
entPhysicalName.505	.1.3.6.1.2.1.47.1.1.1.1.7.505	OctetString	GigabitEthernet1/0/34
entPhysicalName.506	.1.3.6.1.2.1.47.1.1.1.1.7.506	OctetString	GigabitEthernet1/0/35
entPhysicalName.507	.1.3.6.1.2.1.47.1.1.1.1.7.507	OctetString	GigabitEthernet1/0/36
entPhysicalName.508	.1.3.6.1.2.1.47.1.1.1.1.7.508	OctetString	GigabitEthernet1/0/37
entPhysicalName.509	.1.3.6.1.2.1.47.1.1.1.1.7.509	OctetString	GigabitEthernet1/0/38
entPhysicalName.510	.1.3.6.1.2.1.47.1.1.1.1.7.510	OctetString	GigabitEthernet1/0/39
entPhysicalName.511	.1.3.6.1.2.1.47.1.1.1.1.7.511	OctetString	GigabitEthernet1/0/40
entPhysicalName.512	.1.3.6.1.2.1.47.1.1.1.1.7.512	OctetString	GigabitEthernet1/0/41
entPhysicalName.513	.1.3.6.1.2.1.47.1.1.1.1.7.513	OctetString	GigabitEthernet1/0/42
entPhysicalName.514	.1.3.6.1.2.1.47.1.1.1.1.7.514	OctetString	GigabitEthernet1/0/43
entPhysicalName.515	.1.3.6.1.2.1.47.1.1.1.1.7.515	OctetString	GigabitEthernet1/0/44
entPhysicalName.516	.1.3.6.1.2.1.47.1.1.1.1.7.516	OctetString	GigabitEthernet1/0/45
entPhysicalName.517	.1.3.6.1.2.1.47.1.1.1.1.7.517	OctetString	GigabitEthernet1/0/46
entPhysicalName.518	.1.3.6.1.2.1.47.1.1.1.1.7.518	OctetString	GigabitEthernet1/0/47
entPhysicalName.519	.1.3.6.1.2.1.47.1.1.1.1.7.519	OctetString	GigabitEthernet1/0/48
entPhysicalName.520	.1.3.6.1.2.1.47.1.1.1.1.7.520	OctetString	Ten-GigabitEthernet1/0/49
entPhysicalName.521	.1.3.6.1.2.1.47.1.1.1.1.7.521	OctetString	Ten-GigabitEthernet1/0/50
entPhysicalName.522	.1.3.6.1.2.1.47.1.1.1.1.7.522	OctetString	Ten-GigabitEthernet1/0/51
entPhysicalName.523	.1.3.6.1.2.1.47.1.1.1.1.7.523	OctetString	Ten-GigabitEthernet1/0/52
entPhysicalName.524	.1.3.6.1.2.1.47.1.1.1.1.7.524	OctetString	Ten-GigabitEthernet1/0/53
entPhysicalName.525	.1.3.6.1.2.1.47.1.1.1.1.7.525	OctetString	Ten-GigabitEthernet1/0/54
entPhysicalHardwareRev.1	.1.3.6.1.2.1.47.1.1.1.1.8.1	OctetString	
entPhysicalHardwareRev.2	.1.3.6.1.2.1.47.1.1.1.1.8.2	OctetString	Ver.A
entPhysicalHardwareRev.12	.1.3.6.1.2.1.47.1.1.1.1.8.12	OctetString	
entPhysicalHardwareRev.13	.1.3.6.1.2.1.47.1.1.1.1.8.13	OctetString	
entPhysicalHardwareRev.14	.1.3.6.1.2.1.47.1.1.1.1.8.14	OctetString	
entPhysicalHardwareRev.15	.1.3.6.1.2.1.47.1.1.1.1.8.15	OctetString	
entPhysicalHardwareRev.16	.1.3.6.1.2.1.47.1.1.1.1.8.16	OctetString	
entPhysicalHardwareRev.17	.1.3.6.1.2.1.47.1.1.1.1.8.17	OctetString	
entPhysicalHardwareRev.18	.1.3.6.1.2.1.47.1.1.1.1.8.18	OctetString	
entPhysicalHardwareRev.19	.1.3.6.1.2.1.47.1.1.1.1.8.19	OctetString	
entPhysicalHardwareRev.20	.1.3.6.1.2.1.47.1.1.1.1.8.20	OctetString	
entPhysicalHardwareRev.21	.1.3.6.1.2.1.47.1.1.1.1.8.21	OctetString	

Name	OID	Value Type	Value Example
entPhysicalHardwareRev.22	.1.3.6.1.2.1.47.1.1.1.1.8.22	OctetString	
entPhysicalHardwareRev.23	.1.3.6.1.2.1.47.1.1.1.1.8.23	OctetString	
entPhysicalHardwareRev.24	.1.3.6.1.2.1.47.1.1.1.1.8.24	OctetString	
entPhysicalHardwareRev.25	.1.3.6.1.2.1.47.1.1.1.1.8.25	OctetString	
entPhysicalHardwareRev.26	.1.3.6.1.2.1.47.1.1.1.1.8.26	OctetString	
entPhysicalHardwareRev.27	.1.3.6.1.2.1.47.1.1.1.1.8.27	OctetString	
entPhysicalHardwareRev.28	.1.3.6.1.2.1.47.1.1.1.1.8.28	OctetString	
entPhysicalHardwareRev.29	.1.3.6.1.2.1.47.1.1.1.1.8.29	OctetString	
entPhysicalHardwareRev.30	.1.3.6.1.2.1.47.1.1.1.1.8.30	OctetString	
entPhysicalHardwareRev.31	.1.3.6.1.2.1.47.1.1.1.1.8.31	OctetString	
entPhysicalHardwareRev.212	.1.3.6.1.2.1.47.1.1.1.1.8.212	OctetString	Ver.A
entPhysicalHardwareRev.213	.1.3.6.1.2.1.47.1.1.1.1.8.213	OctetString	
entPhysicalHardwareRev.216	.1.3.6.1.2.1.47.1.1.1.1.8.216	OctetString	
entPhysicalHardwareRev.220	.1.3.6.1.2.1.47.1.1.1.1.8.220	OctetString	
entPhysicalHardwareRev.221	.1.3.6.1.2.1.47.1.1.1.1.8.221	OctetString	
entPhysicalHardwareRev.412	.1.3.6.1.2.1.47.1.1.1.1.8.412	OctetString	
entPhysicalHardwareRev.413	.1.3.6.1.2.1.47.1.1.1.1.8.413	OctetString	
entPhysicalHardwareRev.414	.1.3.6.1.2.1.47.1.1.1.1.8.414	OctetString	
entPhysicalHardwareRev.442	.1.3.6.1.2.1.47.1.1.1.1.8.442	OctetString	Ver.A
entPhysicalHardwareRev.472	.1.3.6.1.2.1.47.1.1.1.1.8.472	OctetString	
entPhysicalHardwareRev.473	.1.3.6.1.2.1.47.1.1.1.1.8.473	OctetString	
entPhysicalHardwareRev.474	.1.3.6.1.2.1.47.1.1.1.1.8.474	OctetString	
entPhysicalHardwareRev.475	.1.3.6.1.2.1.47.1.1.1.1.8.475	OctetString	
entPhysicalHardwareRev.476	.1.3.6.1.2.1.47.1.1.1.1.8.476	OctetString	
entPhysicalHardwareRev.477	.1.3.6.1.2.1.47.1.1.1.1.8.477	OctetString	
entPhysicalHardwareRev.478	.1.3.6.1.2.1.47.1.1.1.1.8.478	OctetString	
entPhysicalHardwareRev.479	.1.3.6.1.2.1.47.1.1.1.1.8.479	OctetString	
entPhysicalHardwareRev.480	.1.3.6.1.2.1.47.1.1.1.1.8.480	OctetString	
entPhysicalHardwareRev.481	.1.3.6.1.2.1.47.1.1.1.1.8.481	OctetString	
entPhysicalHardwareRev.482	.1.3.6.1.2.1.47.1.1.1.1.8.482	OctetString	
entPhysicalHardwareRev.483	.1.3.6.1.2.1.47.1.1.1.1.8.483	OctetString	
entPhysicalHardwareRev.484	.1.3.6.1.2.1.47.1.1.1.1.8.484	OctetString	
entPhysicalHardwareRev.485	.1.3.6.1.2.1.47.1.1.1.1.8.485	OctetString	
entPhysicalHardwareRev.486	.1.3.6.1.2.1.47.1.1.1.1.8.486	OctetString	
entPhysicalHardwareRev.487	.1.3.6.1.2.1.47.1.1.1.1.8.487	OctetString	
entPhysicalHardwareRev.488	.1.3.6.1.2.1.47.1.1.1.1.8.488	OctetString	
entPhysicalHardwareRev.489	.1.3.6.1.2.1.47.1.1.1.1.8.489	OctetString	
entPhysicalHardwareRev.490	.1.3.6.1.2.1.47.1.1.1.1.8.490	OctetString	
entPhysicalHardwareRev.491	.1.3.6.1.2.1.47.1.1.1.1.8.491	OctetString	
entPhysicalHardwareRev.492	.1.3.6.1.2.1.47.1.1.1.1.8.492	OctetString	
entPhysicalHardwareRev.493	.1.3.6.1.2.1.47.1.1.1.1.8.493	OctetString	
entPhysicalHardwareRev.494	.1.3.6.1.2.1.47.1.1.1.1.8.494	OctetString	
entPhysicalHardwareRev.495	.1.3.6.1.2.1.47.1.1.1.1.8.495	OctetString	

Name	OID	Value Type	Value Example
entPhysicalHardwareRev.496	.1.3.6.1.2.1.47.1.1.1.1.8.496	OctetString	
entPhysicalHardwareRev.497	.1.3.6.1.2.1.47.1.1.1.1.8.497	OctetString	
entPhysicalHardwareRev.498	.1.3.6.1.2.1.47.1.1.1.1.8.498	OctetString	
entPhysicalHardwareRev.499	.1.3.6.1.2.1.47.1.1.1.1.8.499	OctetString	
entPhysicalHardwareRev.500	.1.3.6.1.2.1.47.1.1.1.1.8.500	OctetString	
entPhysicalHardwareRev.501	.1.3.6.1.2.1.47.1.1.1.1.8.501	OctetString	
entPhysicalHardwareRev.502	.1.3.6.1.2.1.47.1.1.1.1.8.502	OctetString	
entPhysicalHardwareRev.503	.1.3.6.1.2.1.47.1.1.1.1.8.503	OctetString	
entPhysicalHardwareRev.504	.1.3.6.1.2.1.47.1.1.1.1.8.504	OctetString	
entPhysicalHardwareRev.505	.1.3.6.1.2.1.47.1.1.1.1.8.505	OctetString	
entPhysicalHardwareRev.506	.1.3.6.1.2.1.47.1.1.1.1.8.506	OctetString	
entPhysicalHardwareRev.507	.1.3.6.1.2.1.47.1.1.1.1.8.507	OctetString	
entPhysicalHardwareRev.508	.1.3.6.1.2.1.47.1.1.1.1.8.508	OctetString	
entPhysicalHardwareRev.509	.1.3.6.1.2.1.47.1.1.1.1.8.509	OctetString	
entPhysicalHardwareRev.510	.1.3.6.1.2.1.47.1.1.1.1.8.510	OctetString	
entPhysicalHardwareRev.511	.1.3.6.1.2.1.47.1.1.1.1.8.511	OctetString	
entPhysicalHardwareRev.512	.1.3.6.1.2.1.47.1.1.1.1.8.512	OctetString	
entPhysicalHardwareRev.513	.1.3.6.1.2.1.47.1.1.1.1.8.513	OctetString	
entPhysicalHardwareRev.514	.1.3.6.1.2.1.47.1.1.1.1.8.514	OctetString	
entPhysicalHardwareRev.515	.1.3.6.1.2.1.47.1.1.1.1.8.515	OctetString	
entPhysicalHardwareRev.516	.1.3.6.1.2.1.47.1.1.1.1.8.516	OctetString	
entPhysicalHardwareRev.517	.1.3.6.1.2.1.47.1.1.1.1.8.517	OctetString	
entPhysicalHardwareRev.518	.1.3.6.1.2.1.47.1.1.1.1.8.518	OctetString	
entPhysicalHardwareRev.519	.1.3.6.1.2.1.47.1.1.1.1.8.519	OctetString	
entPhysicalHardwareRev.520	.1.3.6.1.2.1.47.1.1.1.1.8.520	OctetString	
entPhysicalHardwareRev.521	.1.3.6.1.2.1.47.1.1.1.1.8.521	OctetString	
entPhysicalHardwareRev.522	.1.3.6.1.2.1.47.1.1.1.1.8.522	OctetString	
entPhysicalHardwareRev.523	.1.3.6.1.2.1.47.1.1.1.1.8.523	OctetString	
entPhysicalHardwareRev.524	.1.3.6.1.2.1.47.1.1.1.1.8.524	OctetString	
entPhysicalHardwareRev.525	.1.3.6.1.2.1.47.1.1.1.1.8.525	OctetString	
entPhysicalFirmwareRev.1	.1.3.6.1.2.1.47.1.1.1.1.9.1	OctetString	
entPhysicalFirmwareRev.2	.1.3.6.1.2.1.47.1.1.1.1.9.2	OctetString	111
entPhysicalFirmwareRev.12	.1.3.6.1.2.1.47.1.1.1.1.9.12	OctetString	
entPhysicalFirmwareRev.13	.1.3.6.1.2.1.47.1.1.1.1.9.13	OctetString	
entPhysicalFirmwareRev.14	.1.3.6.1.2.1.47.1.1.1.1.9.14	OctetString	
entPhysicalFirmwareRev.15	.1.3.6.1.2.1.47.1.1.1.1.9.15	OctetString	
entPhysicalFirmwareRev.16	.1.3.6.1.2.1.47.1.1.1.1.9.16	OctetString	
entPhysicalFirmwareRev.17	.1.3.6.1.2.1.47.1.1.1.1.9.17	OctetString	
entPhysicalFirmwareRev.18	.1.3.6.1.2.1.47.1.1.1.1.9.18	OctetString	
entPhysicalFirmwareRev.19	.1.3.6.1.2.1.47.1.1.1.1.9.19	OctetString	
entPhysicalFirmwareRev.20	.1.3.6.1.2.1.47.1.1.1.1.9.20	OctetString	
entPhysicalFirmwareRev.21	.1.3.6.1.2.1.47.1.1.1.1.9.21	OctetString	
entPhysicalFirmwareRev.22	.1.3.6.1.2.1.47.1.1.1.1.9.22	OctetString	

Name	OID	Value Type	Value Example
entPhysicalFirmwareRev.23	.1.3.6.1.2.1.47.1.1.1.1.9.23	OctetString	
entPhysicalFirmwareRev.24	.1.3.6.1.2.1.47.1.1.1.1.9.24	OctetString	
entPhysicalFirmwareRev.25	.1.3.6.1.2.1.47.1.1.1.1.9.25	OctetString	
entPhysicalFirmwareRev.26	.1.3.6.1.2.1.47.1.1.1.1.9.26	OctetString	
entPhysicalFirmwareRev.27	.1.3.6.1.2.1.47.1.1.1.1.9.27	OctetString	
entPhysicalFirmwareRev.28	.1.3.6.1.2.1.47.1.1.1.1.9.28	OctetString	
entPhysicalFirmwareRev.29	.1.3.6.1.2.1.47.1.1.1.1.9.29	OctetString	
entPhysicalFirmwareRev.30	.1.3.6.1.2.1.47.1.1.1.1.9.30	OctetString	
entPhysicalFirmwareRev.31	.1.3.6.1.2.1.47.1.1.1.1.9.31	OctetString	
entPhysicalFirmwareRev.212	.1.3.6.1.2.1.47.1.1.1.1.9.212	OctetString	111
entPhysicalFirmwareRev.213	.1.3.6.1.2.1.47.1.1.1.1.9.213	OctetString	
entPhysicalFirmwareRev.216	.1.3.6.1.2.1.47.1.1.1.1.9.216	OctetString	
entPhysicalFirmwareRev.220	.1.3.6.1.2.1.47.1.1.1.1.9.220	OctetString	
entPhysicalFirmwareRev.221	.1.3.6.1.2.1.47.1.1.1.1.9.221	OctetString	
entPhysicalFirmwareRev.412	.1.3.6.1.2.1.47.1.1.1.1.9.412	OctetString	
entPhysicalFirmwareRev.413	.1.3.6.1.2.1.47.1.1.1.1.9.413	OctetString	
entPhysicalFirmwareRev.414	.1.3.6.1.2.1.47.1.1.1.1.9.414	OctetString	
entPhysicalFirmwareRev.442	.1.3.6.1.2.1.47.1.1.1.1.9.442	OctetString	
entPhysicalFirmwareRev.472	.1.3.6.1.2.1.47.1.1.1.1.9.472	OctetString	
entPhysicalFirmwareRev.473	.1.3.6.1.2.1.47.1.1.1.1.9.473	OctetString	
entPhysicalFirmwareRev.474	.1.3.6.1.2.1.47.1.1.1.1.9.474	OctetString	
entPhysicalFirmwareRev.475	.1.3.6.1.2.1.47.1.1.1.1.9.475	OctetString	
entPhysicalFirmwareRev.476	.1.3.6.1.2.1.47.1.1.1.1.9.476	OctetString	
entPhysicalFirmwareRev.477	.1.3.6.1.2.1.47.1.1.1.1.9.477	OctetString	
entPhysicalFirmwareRev.478	.1.3.6.1.2.1.47.1.1.1.1.9.478	OctetString	
entPhysicalFirmwareRev.479	.1.3.6.1.2.1.47.1.1.1.1.9.479	OctetString	
entPhysicalFirmwareRev.480	.1.3.6.1.2.1.47.1.1.1.1.9.480	OctetString	
entPhysicalFirmwareRev.481	.1.3.6.1.2.1.47.1.1.1.1.9.481	OctetString	
entPhysicalFirmwareRev.482	.1.3.6.1.2.1.47.1.1.1.1.9.482	OctetString	
entPhysicalFirmwareRev.483	.1.3.6.1.2.1.47.1.1.1.1.9.483	OctetString	
entPhysicalFirmwareRev.484	.1.3.6.1.2.1.47.1.1.1.1.9.484	OctetString	
entPhysicalFirmwareRev.485	.1.3.6.1.2.1.47.1.1.1.1.9.485	OctetString	
entPhysicalFirmwareRev.486	.1.3.6.1.2.1.47.1.1.1.1.9.486	OctetString	
entPhysicalFirmwareRev.487	.1.3.6.1.2.1.47.1.1.1.1.9.487	OctetString	
entPhysicalFirmwareRev.488	.1.3.6.1.2.1.47.1.1.1.1.9.488	OctetString	
entPhysicalFirmwareRev.489	.1.3.6.1.2.1.47.1.1.1.1.9.489	OctetString	
entPhysicalFirmwareRev.490	.1.3.6.1.2.1.47.1.1.1.1.9.490	OctetString	
entPhysicalFirmwareRev.491	.1.3.6.1.2.1.47.1.1.1.1.9.491	OctetString	
entPhysicalFirmwareRev.492	.1.3.6.1.2.1.47.1.1.1.1.9.492	OctetString	
entPhysicalFirmwareRev.493	.1.3.6.1.2.1.47.1.1.1.1.9.493	OctetString	
entPhysicalFirmwareRev.494	.1.3.6.1.2.1.47.1.1.1.1.9.494	OctetString	
entPhysicalFirmwareRev.495	.1.3.6.1.2.1.47.1.1.1.1.9.495	OctetString	
entPhysicalFirmwareRev.496	.1.3.6.1.2.1.47.1.1.1.1.9.496	OctetString	

Name	OID	Value Type	Value Example
entPhysicalFirmwareRev.497	.1.3.6.1.2.1.47.1.1.1.1.9.497	OctetString	
entPhysicalFirmwareRev.498	.1.3.6.1.2.1.47.1.1.1.1.9.498	OctetString	
entPhysicalFirmwareRev.499	.1.3.6.1.2.1.47.1.1.1.1.9.499	OctetString	
entPhysicalFirmwareRev.500	.1.3.6.1.2.1.47.1.1.1.1.9.500	OctetString	
entPhysicalFirmwareRev.501	.1.3.6.1.2.1.47.1.1.1.1.9.501	OctetString	
entPhysicalFirmwareRev.502	.1.3.6.1.2.1.47.1.1.1.1.9.502	OctetString	
entPhysicalFirmwareRev.503	.1.3.6.1.2.1.47.1.1.1.1.9.503	OctetString	
entPhysicalFirmwareRev.504	.1.3.6.1.2.1.47.1.1.1.1.9.504	OctetString	
entPhysicalFirmwareRev.505	.1.3.6.1.2.1.47.1.1.1.1.9.505	OctetString	
entPhysicalFirmwareRev.506	.1.3.6.1.2.1.47.1.1.1.1.9.506	OctetString	
entPhysicalFirmwareRev.507	.1.3.6.1.2.1.47.1.1.1.1.9.507	OctetString	
entPhysicalFirmwareRev.508	.1.3.6.1.2.1.47.1.1.1.1.9.508	OctetString	
entPhysicalFirmwareRev.509	.1.3.6.1.2.1.47.1.1.1.1.9.509	OctetString	
entPhysicalFirmwareRev.510	.1.3.6.1.2.1.47.1.1.1.1.9.510	OctetString	
entPhysicalFirmwareRev.511	.1.3.6.1.2.1.47.1.1.1.1.9.511	OctetString	
entPhysicalFirmwareRev.512	.1.3.6.1.2.1.47.1.1.1.1.9.512	OctetString	
entPhysicalFirmwareRev.513	.1.3.6.1.2.1.47.1.1.1.1.9.513	OctetString	
entPhysicalFirmwareRev.514	.1.3.6.1.2.1.47.1.1.1.1.9.514	OctetString	
entPhysicalFirmwareRev.515	.1.3.6.1.2.1.47.1.1.1.1.9.515	OctetString	
entPhysicalFirmwareRev.516	.1.3.6.1.2.1.47.1.1.1.1.9.516	OctetString	
entPhysicalFirmwareRev.517	.1.3.6.1.2.1.47.1.1.1.1.9.517	OctetString	
entPhysicalFirmwareRev.518	.1.3.6.1.2.1.47.1.1.1.1.9.518	OctetString	
entPhysicalFirmwareRev.519	.1.3.6.1.2.1.47.1.1.1.1.9.519	OctetString	
entPhysicalFirmwareRev.520	.1.3.6.1.2.1.47.1.1.1.1.9.520	OctetString	
entPhysicalFirmwareRev.521	.1.3.6.1.2.1.47.1.1.1.1.9.521	OctetString	
entPhysicalFirmwareRev.522	.1.3.6.1.2.1.47.1.1.1.1.9.522	OctetString	
entPhysicalFirmwareRev.523	.1.3.6.1.2.1.47.1.1.1.1.9.523	OctetString	
entPhysicalFirmwareRev.524	.1.3.6.1.2.1.47.1.1.1.1.9.524	OctetString	
entPhysicalFirmwareRev.525	.1.3.6.1.2.1.47.1.1.1.1.9.525	OctetString	
entPhysicalSoftwareRev.1	.1.3.6.1.2.1.47.1.1.1.1.10.1	OctetString	
entPhysicalSoftwareRev.2	.1.3.6.1.2.1.47.1.1.1.1.10.2	OctetString	7.1.070 Release 1124
entPhysicalSoftwareRev.12	.1.3.6.1.2.1.47.1.1.1.1.10.12	OctetString	
entPhysicalSoftwareRev.13	.1.3.6.1.2.1.47.1.1.1.1.10.13	OctetString	
entPhysicalSoftwareRev.14	.1.3.6.1.2.1.47.1.1.1.1.10.14	OctetString	
entPhysicalSoftwareRev.15	.1.3.6.1.2.1.47.1.1.1.1.10.15	OctetString	
entPhysicalSoftwareRev.16	.1.3.6.1.2.1.47.1.1.1.1.10.16	OctetString	
entPhysicalSoftwareRev.17	.1.3.6.1.2.1.47.1.1.1.1.10.17	OctetString	
entPhysicalSoftwareRev.18	.1.3.6.1.2.1.47.1.1.1.1.10.18	OctetString	
entPhysicalSoftwareRev.19	.1.3.6.1.2.1.47.1.1.1.1.10.19	OctetString	
entPhysicalSoftwareRev.20	.1.3.6.1.2.1.47.1.1.1.1.10.20	OctetString	
entPhysicalSoftwareRev.21	.1.3.6.1.2.1.47.1.1.1.1.10.21	OctetString	
entPhysicalSoftwareRev.22	.1.3.6.1.2.1.47.1.1.1.1.10.22	OctetString	
entPhysicalSoftwareRev.23	.1.3.6.1.2.1.47.1.1.1.1.10.23	OctetString	

Name	OID	Value Type	Value Example
entPhysicalSoftwareRev.24	.1.3.6.1.2.1.47.1.1.1.1.10.24	OctetString	
entPhysicalSoftwareRev.25	.1.3.6.1.2.1.47.1.1.1.1.10.25	OctetString	
entPhysicalSoftwareRev.26	.1.3.6.1.2.1.47.1.1.1.1.10.26	OctetString	
entPhysicalSoftwareRev.27	.1.3.6.1.2.1.47.1.1.1.1.10.27	OctetString	
entPhysicalSoftwareRev.28	.1.3.6.1.2.1.47.1.1.1.1.10.28	OctetString	
entPhysicalSoftwareRev.29	.1.3.6.1.2.1.47.1.1.1.1.10.29	OctetString	
entPhysicalSoftwareRev.30	.1.3.6.1.2.1.47.1.1.1.1.10.30	OctetString	
entPhysicalSoftwareRev.31	.1.3.6.1.2.1.47.1.1.1.1.10.31	OctetString	
entPhysicalSoftwareRev.212	.1.3.6.1.2.1.47.1.1.1.1.10.212	OctetString	V900R001B01D094
entPhysicalSoftwareRev.213	.1.3.6.1.2.1.47.1.1.1.1.10.213	OctetString	
entPhysicalSoftwareRev.216	.1.3.6.1.2.1.47.1.1.1.1.10.216	OctetString	
entPhysicalSoftwareRev.220	.1.3.6.1.2.1.47.1.1.1.1.10.220	OctetString	
entPhysicalSoftwareRev.221	.1.3.6.1.2.1.47.1.1.1.1.10.221	OctetString	
entPhysicalSoftwareRev.412	.1.3.6.1.2.1.47.1.1.1.1.10.412	OctetString	
entPhysicalSoftwareRev.413	.1.3.6.1.2.1.47.1.1.1.1.10.413	OctetString	
entPhysicalSoftwareRev.414	.1.3.6.1.2.1.47.1.1.1.1.10.414	OctetString	
entPhysicalSoftwareRev.442	.1.3.6.1.2.1.47.1.1.1.1.10.442	OctetString	
entPhysicalSoftwareRev.472	.1.3.6.1.2.1.47.1.1.1.1.10.472	OctetString	
entPhysicalSoftwareRev.473	.1.3.6.1.2.1.47.1.1.1.1.10.473	OctetString	
entPhysicalSoftwareRev.474	.1.3.6.1.2.1.47.1.1.1.1.10.474	OctetString	
entPhysicalSoftwareRev.475	.1.3.6.1.2.1.47.1.1.1.1.10.475	OctetString	
entPhysicalSoftwareRev.476	.1.3.6.1.2.1.47.1.1.1.1.10.476	OctetString	
entPhysicalSoftwareRev.477	.1.3.6.1.2.1.47.1.1.1.1.10.477	OctetString	
entPhysicalSoftwareRev.478	.1.3.6.1.2.1.47.1.1.1.1.10.478	OctetString	
entPhysicalSoftwareRev.479	.1.3.6.1.2.1.47.1.1.1.1.10.479	OctetString	
entPhysicalSoftwareRev.480	.1.3.6.1.2.1.47.1.1.1.1.10.480	OctetString	
entPhysicalSoftwareRev.481	.1.3.6.1.2.1.47.1.1.1.1.10.481	OctetString	
entPhysicalSoftwareRev.482	.1.3.6.1.2.1.47.1.1.1.1.10.482	OctetString	
entPhysicalSoftwareRev.483	.1.3.6.1.2.1.47.1.1.1.1.10.483	OctetString	
entPhysicalSoftwareRev.484	.1.3.6.1.2.1.47.1.1.1.1.10.484	OctetString	
entPhysicalSoftwareRev.485	.1.3.6.1.2.1.47.1.1.1.1.10.485	OctetString	
entPhysicalSoftwareRev.486	.1.3.6.1.2.1.47.1.1.1.1.10.486	OctetString	
entPhysicalSoftwareRev.487	.1.3.6.1.2.1.47.1.1.1.1.10.487	OctetString	
entPhysicalSoftwareRev.488	.1.3.6.1.2.1.47.1.1.1.1.10.488	OctetString	
entPhysicalSoftwareRev.489	.1.3.6.1.2.1.47.1.1.1.1.10.489	OctetString	
entPhysicalSoftwareRev.490	.1.3.6.1.2.1.47.1.1.1.1.10.490	OctetString	
entPhysicalSoftwareRev.491	.1.3.6.1.2.1.47.1.1.1.1.10.491	OctetString	
entPhysicalSoftwareRev.492	.1.3.6.1.2.1.47.1.1.1.1.10.492	OctetString	
entPhysicalSoftwareRev.493	.1.3.6.1.2.1.47.1.1.1.1.10.493	OctetString	
entPhysicalSoftwareRev.494	.1.3.6.1.2.1.47.1.1.1.1.10.494	OctetString	
entPhysicalSoftwareRev.495	.1.3.6.1.2.1.47.1.1.1.1.10.495	OctetString	
entPhysicalSoftwareRev.496	.1.3.6.1.2.1.47.1.1.1.1.10.496	OctetString	
entPhysicalSoftwareRev.497	.1.3.6.1.2.1.47.1.1.1.1.10.497	OctetString	



Name	OID	Value Type	Value Example
entPhysicalSoftwareRev.498	.1.3.6.1.2.1.47.1.1.1.1.10.498	OctetString	
entPhysicalSoftwareRev.499	.1.3.6.1.2.1.47.1.1.1.1.10.499	OctetString	
entPhysicalSoftwareRev.500	.1.3.6.1.2.1.47.1.1.1.1.10.500	OctetString	
entPhysicalSoftwareRev.501	.1.3.6.1.2.1.47.1.1.1.1.10.501	OctetString	
entPhysicalSoftwareRev.502	.1.3.6.1.2.1.47.1.1.1.1.10.502	OctetString	
entPhysicalSoftwareRev.503	.1.3.6.1.2.1.47.1.1.1.1.10.503	OctetString	
entPhysicalSoftwareRev.504	.1.3.6.1.2.1.47.1.1.1.1.10.504	OctetString	
entPhysicalSoftwareRev.505	.1.3.6.1.2.1.47.1.1.1.1.10.505	OctetString	
entPhysicalSoftwareRev.506	.1.3.6.1.2.1.47.1.1.1.1.10.506	OctetString	
entPhysicalSoftwareRev.507	.1.3.6.1.2.1.47.1.1.1.1.10.507	OctetString	
entPhysicalSoftwareRev.508	.1.3.6.1.2.1.47.1.1.1.1.10.508	OctetString	
entPhysicalSoftwareRev.509	.1.3.6.1.2.1.47.1.1.1.1.10.509	OctetString	
entPhysicalSoftwareRev.510	.1.3.6.1.2.1.47.1.1.1.1.10.510	OctetString	
entPhysicalSoftwareRev.511	.1.3.6.1.2.1.47.1.1.1.1.10.511	OctetString	
entPhysicalSoftwareRev.512	.1.3.6.1.2.1.47.1.1.1.1.10.512	OctetString	
entPhysicalSoftwareRev.513	.1.3.6.1.2.1.47.1.1.1.1.10.513	OctetString	
entPhysicalSoftwareRev.514	.1.3.6.1.2.1.47.1.1.1.1.10.514	OctetString	
entPhysicalSoftwareRev.515	.1.3.6.1.2.1.47.1.1.1.1.10.515	OctetString	
entPhysicalSoftwareRev.516	.1.3.6.1.2.1.47.1.1.1.1.10.516	OctetString	
entPhysicalSoftwareRev.517	.1.3.6.1.2.1.47.1.1.1.1.10.517	OctetString	
entPhysicalSoftwareRev.518	.1.3.6.1.2.1.47.1.1.1.1.10.518	OctetString	
entPhysicalSoftwareRev.519	.1.3.6.1.2.1.47.1.1.1.1.10.519	OctetString	
entPhysicalSoftwareRev.520	.1.3.6.1.2.1.47.1.1.1.1.10.520	OctetString	
entPhysicalSoftwareRev.521	.1.3.6.1.2.1.47.1.1.1.1.10.521	OctetString	
entPhysicalSoftwareRev.522	.1.3.6.1.2.1.47.1.1.1.1.10.522	OctetString	
entPhysicalSoftwareRev.523	.1.3.6.1.2.1.47.1.1.1.1.10.523	OctetString	
entPhysicalSoftwareRev.524	.1.3.6.1.2.1.47.1.1.1.1.10.524	OctetString	
entPhysicalSoftwareRev.525	.1.3.6.1.2.1.47.1.1.1.1.10.525	OctetString	
entPhysicalSerialNum.1	.1.3.6.1.2.1.47.1.1.1.1.11.1	OctetString	
entPhysicalSerialNum.2	.1.3.6.1.2.1.47.1.1.1.1.11.2	OctetString	219801A3PQP23400006H
entPhysicalSerialNum.12	.1.3.6.1.2.1.47.1.1.1.1.11.12	OctetString	
entPhysicalSerialNum.13	.1.3.6.1.2.1.47.1.1.1.1.11.13	OctetString	
entPhysicalSerialNum.14	.1.3.6.1.2.1.47.1.1.1.1.11.14	OctetString	
entPhysicalSerialNum.15	.1.3.6.1.2.1.47.1.1.1.1.11.15	OctetString	
entPhysicalSerialNum.16	.1.3.6.1.2.1.47.1.1.1.1.11.16	OctetString	
entPhysicalSerialNum.17	.1.3.6.1.2.1.47.1.1.1.1.11.17	OctetString	
entPhysicalSerialNum.18	.1.3.6.1.2.1.47.1.1.1.1.11.18	OctetString	
entPhysicalSerialNum.19	.1.3.6.1.2.1.47.1.1.1.1.11.19	OctetString	
entPhysicalSerialNum.20	.1.3.6.1.2.1.47.1.1.1.1.11.20	OctetString	
entPhysicalSerialNum.21	.1.3.6.1.2.1.47.1.1.1.1.11.21	OctetString	
entPhysicalSerialNum.22	.1.3.6.1.2.1.47.1.1.1.1.11.22	OctetString	
entPhysicalSerialNum.23	.1.3.6.1.2.1.47.1.1.1.1.11.23	OctetString	
entPhysicalSerialNum.24	.1.3.6.1.2.1.47.1.1.1.1.11.24	OctetString	



Name	OID	Value Type	Value Example
entPhysicalSerialNum.25	.1.3.6.1.2.1.47.1.1.1.1.11.25	OctetString	
entPhysicalSerialNum.26	.1.3.6.1.2.1.47.1.1.1.1.11.26	OctetString	
entPhysicalSerialNum.27	.1.3.6.1.2.1.47.1.1.1.1.11.27	OctetString	
entPhysicalSerialNum.28	.1.3.6.1.2.1.47.1.1.1.1.11.28	OctetString	
entPhysicalSerialNum.29	.1.3.6.1.2.1.47.1.1.1.1.11.29	OctetString	
entPhysicalSerialNum.30	.1.3.6.1.2.1.47.1.1.1.1.11.30	OctetString	
entPhysicalSerialNum.31	.1.3.6.1.2.1.47.1.1.1.1.11.31	OctetString	
entPhysicalSerialNum.212	.1.3.6.1.2.1.47.1.1.1.1.11.212	OctetString	219801A3PQP23400006H
entPhysicalSerialNum.213	.1.3.6.1.2.1.47.1.1.1.1.11.213	OctetString	219803A05N6233V001F2
entPhysicalSerialNum.216	.1.3.6.1.2.1.47.1.1.1.1.11.216	OctetString	
entPhysicalSerialNum.220	.1.3.6.1.2.1.47.1.1.1.1.11.220	OctetString	
entPhysicalSerialNum.221	.1.3.6.1.2.1.47.1.1.1.1.11.221	OctetString	
entPhysicalSerialNum.412	.1.3.6.1.2.1.47.1.1.1.1.11.412	OctetString	
entPhysicalSerialNum.413	.1.3.6.1.2.1.47.1.1.1.1.11.413	OctetString	
entPhysicalSerialNum.414	.1.3.6.1.2.1.47.1.1.1.1.11.414	OctetString	
entPhysicalSerialNum.442	.1.3.6.1.2.1.47.1.1.1.1.11.442	OctetString	
entPhysicalSerialNum.472	.1.3.6.1.2.1.47.1.1.1.1.11.472	OctetString	
entPhysicalSerialNum.473	.1.3.6.1.2.1.47.1.1.1.1.11.473	OctetString	
entPhysicalSerialNum.474	.1.3.6.1.2.1.47.1.1.1.1.11.474	OctetString	
entPhysicalSerialNum.475	.1.3.6.1.2.1.47.1.1.1.1.11.475	OctetString	
entPhysicalSerialNum.476	.1.3.6.1.2.1.47.1.1.1.1.11.476	OctetString	
entPhysicalSerialNum.477	.1.3.6.1.2.1.47.1.1.1.1.11.477	OctetString	
entPhysicalSerialNum.478	.1.3.6.1.2.1.47.1.1.1.1.11.478	OctetString	
entPhysicalSerialNum.479	.1.3.6.1.2.1.47.1.1.1.1.11.479	OctetString	
entPhysicalSerialNum.480	.1.3.6.1.2.1.47.1.1.1.1.11.480	OctetString	
entPhysicalSerialNum.481	.1.3.6.1.2.1.47.1.1.1.1.11.481	OctetString	
entPhysicalSerialNum.482	.1.3.6.1.2.1.47.1.1.1.1.11.482	OctetString	
entPhysicalSerialNum.483	.1.3.6.1.2.1.47.1.1.1.1.11.483	OctetString	
entPhysicalSerialNum.484	.1.3.6.1.2.1.47.1.1.1.1.11.484	OctetString	
entPhysicalSerialNum.485	.1.3.6.1.2.1.47.1.1.1.1.11.485	OctetString	
entPhysicalSerialNum.486	.1.3.6.1.2.1.47.1.1.1.1.11.486	OctetString	
entPhysicalSerialNum.487	.1.3.6.1.2.1.47.1.1.1.1.11.487	OctetString	
entPhysicalSerialNum.488	.1.3.6.1.2.1.47.1.1.1.1.11.488	OctetString	
entPhysicalSerialNum.489	.1.3.6.1.2.1.47.1.1.1.1.11.489	OctetString	
entPhysicalSerialNum.490	.1.3.6.1.2.1.47.1.1.1.1.11.490	OctetString	
entPhysicalSerialNum.491	.1.3.6.1.2.1.47.1.1.1.1.11.491	OctetString	
entPhysicalSerialNum.492	.1.3.6.1.2.1.47.1.1.1.1.11.492	OctetString	
entPhysicalSerialNum.493	.1.3.6.1.2.1.47.1.1.1.1.11.493	OctetString	
entPhysicalSerialNum.494	.1.3.6.1.2.1.47.1.1.1.1.11.494	OctetString	
entPhysicalSerialNum.495	.1.3.6.1.2.1.47.1.1.1.1.11.495	OctetString	
entPhysicalSerialNum.496	.1.3.6.1.2.1.47.1.1.1.1.11.496	OctetString	
entPhysicalSerialNum.497	.1.3.6.1.2.1.47.1.1.1.1.11.497	OctetString	
entPhysicalSerialNum.498	.1.3.6.1.2.1.47.1.1.1.1.11.498	OctetString	

Name	OID	Value Type	Value Example
entPhysicalSerialNum.499	.1.3.6.1.2.1.47.1.1.1.1.11.499	OctetString	
entPhysicalSerialNum.500	.1.3.6.1.2.1.47.1.1.1.1.11.500	OctetString	
entPhysicalSerialNum.501	.1.3.6.1.2.1.47.1.1.1.1.11.501	OctetString	
entPhysicalSerialNum.502	.1.3.6.1.2.1.47.1.1.1.1.11.502	OctetString	
entPhysicalSerialNum.503	.1.3.6.1.2.1.47.1.1.1.1.11.503	OctetString	
entPhysicalSerialNum.504	.1.3.6.1.2.1.47.1.1.1.1.11.504	OctetString	
entPhysicalSerialNum.505	.1.3.6.1.2.1.47.1.1.1.1.11.505	OctetString	
entPhysicalSerialNum.506	.1.3.6.1.2.1.47.1.1.1.1.11.506	OctetString	
entPhysicalSerialNum.507	.1.3.6.1.2.1.47.1.1.1.1.11.507	OctetString	
entPhysicalSerialNum.508	.1.3.6.1.2.1.47.1.1.1.1.11.508	OctetString	
entPhysicalSerialNum.509	.1.3.6.1.2.1.47.1.1.1.1.11.509	OctetString	
entPhysicalSerialNum.510	.1.3.6.1.2.1.47.1.1.1.1.11.510	OctetString	
entPhysicalSerialNum.511	.1.3.6.1.2.1.47.1.1.1.1.11.511	OctetString	
entPhysicalSerialNum.512	.1.3.6.1.2.1.47.1.1.1.1.11.512	OctetString	
entPhysicalSerialNum.513	.1.3.6.1.2.1.47.1.1.1.1.11.513	OctetString	
entPhysicalSerialNum.514	.1.3.6.1.2.1.47.1.1.1.1.11.514	OctetString	
entPhysicalSerialNum.515	.1.3.6.1.2.1.47.1.1.1.1.11.515	OctetString	
entPhysicalSerialNum.516	.1.3.6.1.2.1.47.1.1.1.1.11.516	OctetString	
entPhysicalSerialNum.517	.1.3.6.1.2.1.47.1.1.1.1.11.517	OctetString	
entPhysicalSerialNum.518	.1.3.6.1.2.1.47.1.1.1.1.11.518	OctetString	
entPhysicalSerialNum.519	.1.3.6.1.2.1.47.1.1.1.1.11.519	OctetString	
entPhysicalSerialNum.520	.1.3.6.1.2.1.47.1.1.1.1.11.520	OctetString	
entPhysicalSerialNum.521	.1.3.6.1.2.1.47.1.1.1.1.11.521	OctetString	
entPhysicalSerialNum.522	.1.3.6.1.2.1.47.1.1.1.1.11.522	OctetString	
entPhysicalSerialNum.523	.1.3.6.1.2.1.47.1.1.1.1.11.523	OctetString	
entPhysicalSerialNum.524	.1.3.6.1.2.1.47.1.1.1.1.11.524	OctetString	
entPhysicalSerialNum.525	.1.3.6.1.2.1.47.1.1.1.1.11.525	OctetString	
entPhysicalMfgName.1	.1.3.6.1.2.1.47.1.1.1.1.12.1	OctetString	INTELBRAS
entPhysicalMfgName.2	.1.3.6.1.2.1.47.1.1.1.1.12.2	OctetString	INTELBRAS
entPhysicalMfgName.12	.1.3.6.1.2.1.47.1.1.1.1.12.12	OctetString	
entPhysicalMfgName.13	.1.3.6.1.2.1.47.1.1.1.1.12.13	OctetString	
entPhysicalMfgName.14	.1.3.6.1.2.1.47.1.1.1.1.12.14	OctetString	
entPhysicalMfgName.15	.1.3.6.1.2.1.47.1.1.1.1.12.15	OctetString	
entPhysicalMfgName.16	.1.3.6.1.2.1.47.1.1.1.1.12.16	OctetString	
entPhysicalMfgName.17	.1.3.6.1.2.1.47.1.1.1.1.12.17	OctetString	
entPhysicalMfgName.18	.1.3.6.1.2.1.47.1.1.1.1.12.18	OctetString	
entPhysicalMfgName.19	.1.3.6.1.2.1.47.1.1.1.1.12.19	OctetString	
entPhysicalMfgName.20	.1.3.6.1.2.1.47.1.1.1.1.12.20	OctetString	
entPhysicalMfgName.21	.1.3.6.1.2.1.47.1.1.1.1.12.21	OctetString	
entPhysicalMfgName.22	.1.3.6.1.2.1.47.1.1.1.1.12.22	OctetString	
entPhysicalMfgName.23	.1.3.6.1.2.1.47.1.1.1.1.12.23	OctetString	
entPhysicalMfgName.24	.1.3.6.1.2.1.47.1.1.1.1.12.24	OctetString	
entPhysicalMfgName.25	.1.3.6.1.2.1.47.1.1.1.1.12.25	OctetString	

Name	OID	Value Type	Value Example
entPhysicalMfgName.26	.1.3.6.1.2.1.47.1.1.1.1.12.26	OctetString	
entPhysicalMfgName.27	.1.3.6.1.2.1.47.1.1.1.1.12.27	OctetString	
entPhysicalMfgName.28	.1.3.6.1.2.1.47.1.1.1.1.12.28	OctetString	
entPhysicalMfgName.29	.1.3.6.1.2.1.47.1.1.1.1.12.29	OctetString	
entPhysicalMfgName.30	.1.3.6.1.2.1.47.1.1.1.1.12.30	OctetString	
entPhysicalMfgName.31	.1.3.6.1.2.1.47.1.1.1.1.12.31	OctetString	
entPhysicalMfgName.212	.1.3.6.1.2.1.47.1.1.1.1.12.212	OctetString	INTELBRAS
entPhysicalMfgName.213	.1.3.6.1.2.1.47.1.1.1.1.12.213	OctetString	
entPhysicalMfgName.216	.1.3.6.1.2.1.47.1.1.1.1.12.216	OctetString	
entPhysicalMfgName.220	.1.3.6.1.2.1.47.1.1.1.1.12.220	OctetString	
entPhysicalMfgName.221	.1.3.6.1.2.1.47.1.1.1.1.12.221	OctetString	
entPhysicalMfgName.412	.1.3.6.1.2.1.47.1.1.1.1.12.412	OctetString	
entPhysicalMfgName.413	.1.3.6.1.2.1.47.1.1.1.1.12.413	OctetString	
entPhysicalMfgName.414	.1.3.6.1.2.1.47.1.1.1.1.12.414	OctetString	
entPhysicalMfgName.442	.1.3.6.1.2.1.47.1.1.1.1.12.442	OctetString	INTELBRAS
entPhysicalMfgName.472	.1.3.6.1.2.1.47.1.1.1.1.12.472	OctetString	
entPhysicalMfgName.473	.1.3.6.1.2.1.47.1.1.1.1.12.473	OctetString	
entPhysicalMfgName.474	.1.3.6.1.2.1.47.1.1.1.1.12.474	OctetString	
entPhysicalMfgName.475	.1.3.6.1.2.1.47.1.1.1.1.12.475	OctetString	
entPhysicalMfgName.476	.1.3.6.1.2.1.47.1.1.1.1.12.476	OctetString	
entPhysicalMfgName.477	.1.3.6.1.2.1.47.1.1.1.1.12.477	OctetString	
entPhysicalMfgName.478	.1.3.6.1.2.1.47.1.1.1.1.12.478	OctetString	
entPhysicalMfgName.479	.1.3.6.1.2.1.47.1.1.1.1.12.479	OctetString	
entPhysicalMfgName.480	.1.3.6.1.2.1.47.1.1.1.1.12.480	OctetString	
entPhysicalMfgName.481	.1.3.6.1.2.1.47.1.1.1.1.12.481	OctetString	
entPhysicalMfgName.482	.1.3.6.1.2.1.47.1.1.1.1.12.482	OctetString	
entPhysicalMfgName.483	.1.3.6.1.2.1.47.1.1.1.1.12.483	OctetString	
entPhysicalMfgName.484	.1.3.6.1.2.1.47.1.1.1.1.12.484	OctetString	
entPhysicalMfgName.485	.1.3.6.1.2.1.47.1.1.1.1.12.485	OctetString	
entPhysicalMfgName.486	.1.3.6.1.2.1.47.1.1.1.1.12.486	OctetString	
entPhysicalMfgName.487	.1.3.6.1.2.1.47.1.1.1.1.12.487	OctetString	
entPhysicalMfgName.488	.1.3.6.1.2.1.47.1.1.1.1.12.488	OctetString	
entPhysicalMfgName.489	.1.3.6.1.2.1.47.1.1.1.1.12.489	OctetString	
entPhysicalMfgName.490	.1.3.6.1.2.1.47.1.1.1.1.12.490	OctetString	
entPhysicalMfgName.491	.1.3.6.1.2.1.47.1.1.1.1.12.491	OctetString	
entPhysicalMfgName.492	.1.3.6.1.2.1.47.1.1.1.1.12.492	OctetString	
entPhysicalMfgName.493	.1.3.6.1.2.1.47.1.1.1.1.12.493	OctetString	
entPhysicalMfgName.494	.1.3.6.1.2.1.47.1.1.1.1.12.494	OctetString	
entPhysicalMfgName.495	.1.3.6.1.2.1.47.1.1.1.1.12.495	OctetString	
entPhysicalMfgName.496	.1.3.6.1.2.1.47.1.1.1.1.12.496	OctetString	
entPhysicalMfgName.497	.1.3.6.1.2.1.47.1.1.1.1.12.497	OctetString	
entPhysicalMfgName.498	.1.3.6.1.2.1.47.1.1.1.1.12.498	OctetString	
entPhysicalMfgName.499	.1.3.6.1.2.1.47.1.1.1.1.12.499	OctetString	

Name	OID	Value Type	Value Example
entPhysicalMfgName.500	.1.3.6.1.2.1.47.1.1.1.1.12.500	OctetString	
entPhysicalMfgName.501	.1.3.6.1.2.1.47.1.1.1.1.12.501	OctetString	
entPhysicalMfgName.502	.1.3.6.1.2.1.47.1.1.1.1.12.502	OctetString	
entPhysicalMfgName.503	.1.3.6.1.2.1.47.1.1.1.1.12.503	OctetString	
entPhysicalMfgName.504	.1.3.6.1.2.1.47.1.1.1.1.12.504	OctetString	
entPhysicalMfgName.505	.1.3.6.1.2.1.47.1.1.1.1.12.505	OctetString	
entPhysicalMfgName.506	.1.3.6.1.2.1.47.1.1.1.1.12.506	OctetString	
entPhysicalMfgName.507	.1.3.6.1.2.1.47.1.1.1.1.12.507	OctetString	
entPhysicalMfgName.508	.1.3.6.1.2.1.47.1.1.1.1.12.508	OctetString	
entPhysicalMfgName.509	.1.3.6.1.2.1.47.1.1.1.1.12.509	OctetString	
entPhysicalMfgName.510	.1.3.6.1.2.1.47.1.1.1.1.12.510	OctetString	
entPhysicalMfgName.511	.1.3.6.1.2.1.47.1.1.1.1.12.511	OctetString	
entPhysicalMfgName.512	.1.3.6.1.2.1.47.1.1.1.1.12.512	OctetString	
entPhysicalMfgName.513	.1.3.6.1.2.1.47.1.1.1.1.12.513	OctetString	
entPhysicalMfgName.514	.1.3.6.1.2.1.47.1.1.1.1.12.514	OctetString	
entPhysicalMfgName.515	.1.3.6.1.2.1.47.1.1.1.1.12.515	OctetString	
entPhysicalMfgName.516	.1.3.6.1.2.1.47.1.1.1.1.12.516	OctetString	
entPhysicalMfgName.517	.1.3.6.1.2.1.47.1.1.1.1.12.517	OctetString	
entPhysicalMfgName.518	.1.3.6.1.2.1.47.1.1.1.1.12.518	OctetString	
entPhysicalMfgName.519	.1.3.6.1.2.1.47.1.1.1.1.12.519	OctetString	
entPhysicalMfgName.520	.1.3.6.1.2.1.47.1.1.1.1.12.520	OctetString	
entPhysicalMfgName.521	.1.3.6.1.2.1.47.1.1.1.1.12.521	OctetString	
entPhysicalMfgName.522	.1.3.6.1.2.1.47.1.1.1.1.12.522	OctetString	
entPhysicalMfgName.523	.1.3.6.1.2.1.47.1.1.1.1.12.523	OctetString	
entPhysicalMfgName.524	.1.3.6.1.2.1.47.1.1.1.1.12.524	OctetString	
entPhysicalMfgName.525	.1.3.6.1.2.1.47.1.1.1.1.12.525	OctetString	
entPhysicalModelName.1	.1.3.6.1.2.1.47.1.1.1.1.13.1	OctetString	
entPhysicalModelName.2	.1.3.6.1.2.1.47.1.1.1.1.13.2	OctetString	INTELBRAS SC 3570-48GP-6X
entPhysicalModelName.12	.1.3.6.1.2.1.47.1.1.1.1.13.12	OctetString	
entPhysicalModelName.13	.1.3.6.1.2.1.47.1.1.1.1.13.13	OctetString	
entPhysicalModelName.14	.1.3.6.1.2.1.47.1.1.1.1.13.14	OctetString	
entPhysicalModelName.15	.1.3.6.1.2.1.47.1.1.1.1.13.15	OctetString	
entPhysicalModelName.16	.1.3.6.1.2.1.47.1.1.1.1.13.16	OctetString	
entPhysicalModelName.17	.1.3.6.1.2.1.47.1.1.1.1.13.17	OctetString	
entPhysicalModelName.18	.1.3.6.1.2.1.47.1.1.1.1.13.18	OctetString	
entPhysicalModelName.19	.1.3.6.1.2.1.47.1.1.1.1.13.19	OctetString	
entPhysicalModelName.20	.1.3.6.1.2.1.47.1.1.1.1.13.20	OctetString	
entPhysicalModelName.21	.1.3.6.1.2.1.47.1.1.1.1.13.21	OctetString	
entPhysicalModelName.22	.1.3.6.1.2.1.47.1.1.1.1.13.22	OctetString	
entPhysicalModelName.23	.1.3.6.1.2.1.47.1.1.1.1.13.23	OctetString	
entPhysicalModelName.24	.1.3.6.1.2.1.47.1.1.1.1.13.24	OctetString	
entPhysicalModelName.25	.1.3.6.1.2.1.47.1.1.1.1.13.25	OctetString	
entPhysicalModelName.26	.1.3.6.1.2.1.47.1.1.1.1.13.26	OctetString	

Name	OID	Value Type	Value Example
entPhysicalModelName.27	.1.3.6.1.2.1.47.1.1.1.1.13.27	OctetString	
entPhysicalModelName.28	.1.3.6.1.2.1.47.1.1.1.1.13.28	OctetString	
entPhysicalModelName.29	.1.3.6.1.2.1.47.1.1.1.1.13.29	OctetString	
entPhysicalModelName.30	.1.3.6.1.2.1.47.1.1.1.1.13.30	OctetString	
entPhysicalModelName.31	.1.3.6.1.2.1.47.1.1.1.1.13.31	OctetString	
entPhysicalModelName.212	.1.3.6.1.2.1.47.1.1.1.1.13.212	OctetString	INTELBRAS SC 3570-48GP-6X
entPhysicalModelName.213	.1.3.6.1.2.1.47.1.1.1.1.13.213	OctetString	
entPhysicalModelName.216	.1.3.6.1.2.1.47.1.1.1.1.13.216	OctetString	
entPhysicalModelName.220	.1.3.6.1.2.1.47.1.1.1.1.13.220	OctetString	
entPhysicalModelName.221	.1.3.6.1.2.1.47.1.1.1.1.13.221	OctetString	
entPhysicalModelName.412	.1.3.6.1.2.1.47.1.1.1.1.13.412	OctetString	
entPhysicalModelName.413	.1.3.6.1.2.1.47.1.1.1.1.13.413	OctetString	
entPhysicalModelName.414	.1.3.6.1.2.1.47.1.1.1.1.13.414	OctetString	
entPhysicalModelName.442	.1.3.6.1.2.1.47.1.1.1.1.13.442	OctetString	
entPhysicalModelName.472	.1.3.6.1.2.1.47.1.1.1.1.13.472	OctetString	
entPhysicalModelName.473	.1.3.6.1.2.1.47.1.1.1.1.13.473	OctetString	
entPhysicalModelName.474	.1.3.6.1.2.1.47.1.1.1.1.13.474	OctetString	
entPhysicalModelName.475	.1.3.6.1.2.1.47.1.1.1.1.13.475	OctetString	
entPhysicalModelName.476	.1.3.6.1.2.1.47.1.1.1.1.13.476	OctetString	
entPhysicalModelName.477	.1.3.6.1.2.1.47.1.1.1.1.13.477	OctetString	
entPhysicalModelName.478	.1.3.6.1.2.1.47.1.1.1.1.13.478	OctetString	
entPhysicalModelName.479	.1.3.6.1.2.1.47.1.1.1.1.13.479	OctetString	
entPhysicalModelName.480	.1.3.6.1.2.1.47.1.1.1.1.13.480	OctetString	
entPhysicalModelName.481	.1.3.6.1.2.1.47.1.1.1.1.13.481	OctetString	
entPhysicalModelName.482	.1.3.6.1.2.1.47.1.1.1.1.13.482	OctetString	
entPhysicalModelName.483	.1.3.6.1.2.1.47.1.1.1.1.13.483	OctetString	
entPhysicalModelName.484	.1.3.6.1.2.1.47.1.1.1.1.13.484	OctetString	
entPhysicalModelName.485	.1.3.6.1.2.1.47.1.1.1.1.13.485	OctetString	
entPhysicalModelName.486	.1.3.6.1.2.1.47.1.1.1.1.13.486	OctetString	
entPhysicalModelName.487	.1.3.6.1.2.1.47.1.1.1.1.13.487	OctetString	
entPhysicalModelName.488	.1.3.6.1.2.1.47.1.1.1.1.13.488	OctetString	
entPhysicalModelName.489	.1.3.6.1.2.1.47.1.1.1.1.13.489	OctetString	
entPhysicalModelName.490	.1.3.6.1.2.1.47.1.1.1.1.13.490	OctetString	
entPhysicalModelName.491	.1.3.6.1.2.1.47.1.1.1.1.13.491	OctetString	
entPhysicalModelName.492	.1.3.6.1.2.1.47.1.1.1.1.13.492	OctetString	
entPhysicalModelName.493	.1.3.6.1.2.1.47.1.1.1.1.13.493	OctetString	
entPhysicalModelName.494	.1.3.6.1.2.1.47.1.1.1.1.13.494	OctetString	
entPhysicalModelName.495	.1.3.6.1.2.1.47.1.1.1.1.13.495	OctetString	
entPhysicalModelName.496	.1.3.6.1.2.1.47.1.1.1.1.13.496	OctetString	
entPhysicalModelName.497	.1.3.6.1.2.1.47.1.1.1.1.13.497	OctetString	
entPhysicalModelName.498	.1.3.6.1.2.1.47.1.1.1.1.13.498	OctetString	
entPhysicalModelName.499	.1.3.6.1.2.1.47.1.1.1.1.13.499	OctetString	
entPhysicalModelName.500	.1.3.6.1.2.1.47.1.1.1.1.13.500	OctetString	

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
entPhysicalModelName.501	.1.3.6.1.2.1.47.1.1.1.1.13.501	OctetString	
entPhysicalModelName.502	.1.3.6.1.2.1.47.1.1.1.1.13.502	OctetString	
entPhysicalModelName.503	.1.3.6.1.2.1.47.1.1.1.1.13.503	OctetString	
entPhysicalModelName.504	.1.3.6.1.2.1.47.1.1.1.1.13.504	OctetString	
entPhysicalModelName.505	.1.3.6.1.2.1.47.1.1.1.1.13.505	OctetString	
entPhysicalModelName.506	.1.3.6.1.2.1.47.1.1.1.1.13.506	OctetString	
entPhysicalModelName.507	.1.3.6.1.2.1.47.1.1.1.1.13.507	OctetString	
entPhysicalModelName.508	.1.3.6.1.2.1.47.1.1.1.1.13.508	OctetString	
entPhysicalModelName.509	.1.3.6.1.2.1.47.1.1.1.1.13.509	OctetString	
entPhysicalModelName.510	.1.3.6.1.2.1.47.1.1.1.1.13.510	OctetString	
entPhysicalModelName.511	.1.3.6.1.2.1.47.1.1.1.1.13.511	OctetString	
entPhysicalModelName.512	.1.3.6.1.2.1.47.1.1.1.1.13.512	OctetString	
entPhysicalModelName.513	.1.3.6.1.2.1.47.1.1.1.1.13.513	OctetString	
entPhysicalModelName.514	.1.3.6.1.2.1.47.1.1.1.1.13.514	OctetString	
entPhysicalModelName.515	.1.3.6.1.2.1.47.1.1.1.1.13.515	OctetString	
entPhysicalModelName.516	.1.3.6.1.2.1.47.1.1.1.1.13.516	OctetString	
entPhysicalModelName.517	.1.3.6.1.2.1.47.1.1.1.1.13.517	OctetString	
entPhysicalModelName.518	.1.3.6.1.2.1.47.1.1.1.1.13.518	OctetString	
entPhysicalModelName.519	.1.3.6.1.2.1.47.1.1.1.1.13.519	OctetString	
entPhysicalModelName.520	.1.3.6.1.2.1.47.1.1.1.1.13.520	OctetString	
entPhysicalModelName.521	.1.3.6.1.2.1.47.1.1.1.1.13.521	OctetString	
entPhysicalModelName.522	.1.3.6.1.2.1.47.1.1.1.1.13.522	OctetString	
entPhysicalModelName.523	.1.3.6.1.2.1.47.1.1.1.1.13.523	OctetString	
entPhysicalModelName.524	.1.3.6.1.2.1.47.1.1.1.1.13.524	OctetString	
entPhysicalModelName.525	.1.3.6.1.2.1.47.1.1.1.1.13.525	OctetString	
entPhysicalAlias.1	.1.3.6.1.2.1.47.1.1.1.1.14.1	OctetString	
entPhysicalAlias.2	.1.3.6.1.2.1.47.1.1.1.1.14.2	OctetString	LS-SC 3570-48GP-6X
entPhysicalAlias.12	.1.3.6.1.2.1.47.1.1.1.1.14.12	OctetString	
entPhysicalAlias.13	.1.3.6.1.2.1.47.1.1.1.1.14.13	OctetString	
entPhysicalAlias.14	.1.3.6.1.2.1.47.1.1.1.1.14.14	OctetString	
entPhysicalAlias.15	.1.3.6.1.2.1.47.1.1.1.1.14.15	OctetString	
entPhysicalAlias.16	.1.3.6.1.2.1.47.1.1.1.1.14.16	OctetString	
entPhysicalAlias.17	.1.3.6.1.2.1.47.1.1.1.1.14.17	OctetString	
entPhysicalAlias.18	.1.3.6.1.2.1.47.1.1.1.1.14.18	OctetString	
entPhysicalAlias.19	.1.3.6.1.2.1.47.1.1.1.1.14.19	OctetString	
entPhysicalAlias.20	.1.3.6.1.2.1.47.1.1.1.1.14.20	OctetString	
entPhysicalAlias.21	.1.3.6.1.2.1.47.1.1.1.1.14.21	OctetString	
entPhysicalAlias.22	.1.3.6.1.2.1.47.1.1.1.1.14.22	OctetString	
entPhysicalAlias.23	.1.3.6.1.2.1.47.1.1.1.1.14.23	OctetString	
entPhysicalAlias.24	.1.3.6.1.2.1.47.1.1.1.1.14.24	OctetString	
entPhysicalAlias.25	.1.3.6.1.2.1.47.1.1.1.1.14.25	OctetString	
entPhysicalAlias.26	.1.3.6.1.2.1.47.1.1.1.1.14.26	OctetString	
entPhysicalAlias.27	.1.3.6.1.2.1.47.1.1.1.1.14.27	OctetString	

Name	OID	Value Type	Value Example
entPhysicalAlias.28	.1.3.6.1.2.1.47.1.1.1.1.14.28	OctetString	
entPhysicalAlias.29	.1.3.6.1.2.1.47.1.1.1.1.14.29	OctetString	
entPhysicalAlias.30	.1.3.6.1.2.1.47.1.1.1.1.14.30	OctetString	
entPhysicalAlias.31	.1.3.6.1.2.1.47.1.1.1.1.14.31	OctetString	
entPhysicalAlias.212	.1.3.6.1.2.1.47.1.1.1.1.14.212	OctetString	LS-SC 3570-48GP-6X
entPhysicalAlias.213	.1.3.6.1.2.1.47.1.1.1.1.14.213	OctetString	
entPhysicalAlias.216	.1.3.6.1.2.1.47.1.1.1.1.14.216	OctetString	
entPhysicalAlias.220	.1.3.6.1.2.1.47.1.1.1.1.14.220	OctetString	
entPhysicalAlias.221	.1.3.6.1.2.1.47.1.1.1.1.14.221	OctetString	
entPhysicalAlias.412	.1.3.6.1.2.1.47.1.1.1.1.14.412	OctetString	
entPhysicalAlias.413	.1.3.6.1.2.1.47.1.1.1.1.14.413	OctetString	
entPhysicalAlias.414	.1.3.6.1.2.1.47.1.1.1.1.14.414	OctetString	
entPhysicalAlias.442	.1.3.6.1.2.1.47.1.1.1.1.14.442	OctetString	
entPhysicalAlias.472	.1.3.6.1.2.1.47.1.1.1.1.14.472	OctetString	
entPhysicalAlias.473	.1.3.6.1.2.1.47.1.1.1.1.14.473	OctetString	
entPhysicalAlias.474	.1.3.6.1.2.1.47.1.1.1.1.14.474	OctetString	
entPhysicalAlias.475	.1.3.6.1.2.1.47.1.1.1.1.14.475	OctetString	
entPhysicalAlias.476	.1.3.6.1.2.1.47.1.1.1.1.14.476	OctetString	
entPhysicalAlias.477	.1.3.6.1.2.1.47.1.1.1.1.14.477	OctetString	
entPhysicalAlias.478	.1.3.6.1.2.1.47.1.1.1.1.14.478	OctetString	
entPhysicalAlias.479	.1.3.6.1.2.1.47.1.1.1.1.14.479	OctetString	
entPhysicalAlias.480	.1.3.6.1.2.1.47.1.1.1.1.14.480	OctetString	
entPhysicalAlias.481	.1.3.6.1.2.1.47.1.1.1.1.14.481	OctetString	
entPhysicalAlias.482	.1.3.6.1.2.1.47.1.1.1.1.14.482	OctetString	
entPhysicalAlias.483	.1.3.6.1.2.1.47.1.1.1.1.14.483	OctetString	
entPhysicalAlias.484	.1.3.6.1.2.1.47.1.1.1.1.14.484	OctetString	
entPhysicalAlias.485	.1.3.6.1.2.1.47.1.1.1.1.14.485	OctetString	
entPhysicalAlias.486	.1.3.6.1.2.1.47.1.1.1.1.14.486	OctetString	
entPhysicalAlias.487	.1.3.6.1.2.1.47.1.1.1.1.14.487	OctetString	
entPhysicalAlias.488	.1.3.6.1.2.1.47.1.1.1.1.14.488	OctetString	
entPhysicalAlias.489	.1.3.6.1.2.1.47.1.1.1.1.14.489	OctetString	
entPhysicalAlias.490	.1.3.6.1.2.1.47.1.1.1.1.14.490	OctetString	
entPhysicalAlias.491	.1.3.6.1.2.1.47.1.1.1.1.14.491	OctetString	
entPhysicalAlias.492	.1.3.6.1.2.1.47.1.1.1.1.14.492	OctetString	
entPhysicalAlias.493	.1.3.6.1.2.1.47.1.1.1.1.14.493	OctetString	
entPhysicalAlias.494	.1.3.6.1.2.1.47.1.1.1.1.14.494	OctetString	
entPhysicalAlias.495	.1.3.6.1.2.1.47.1.1.1.1.14.495	OctetString	
entPhysicalAlias.496	.1.3.6.1.2.1.47.1.1.1.1.14.496	OctetString	
entPhysicalAlias.497	.1.3.6.1.2.1.47.1.1.1.1.14.497	OctetString	
entPhysicalAlias.498	.1.3.6.1.2.1.47.1.1.1.1.14.498	OctetString	
entPhysicalAlias.499	.1.3.6.1.2.1.47.1.1.1.1.14.499	OctetString	
entPhysicalAlias.500	.1.3.6.1.2.1.47.1.1.1.1.14.500	OctetString	
entPhysicalAlias.501	.1.3.6.1.2.1.47.1.1.1.1.14.501	OctetString	



Name	OID	Value Type	Value Example
entPhysicalAlias.502	.1.3.6.1.2.1.47.1.1.1.1.14.502	OctetString	
entPhysicalAlias.503	.1.3.6.1.2.1.47.1.1.1.1.14.503	OctetString	
entPhysicalAlias.504	.1.3.6.1.2.1.47.1.1.1.1.14.504	OctetString	
entPhysicalAlias.505	.1.3.6.1.2.1.47.1.1.1.1.14.505	OctetString	
entPhysicalAlias.506	.1.3.6.1.2.1.47.1.1.1.1.14.506	OctetString	
entPhysicalAlias.507	.1.3.6.1.2.1.47.1.1.1.1.14.507	OctetString	
entPhysicalAlias.508	.1.3.6.1.2.1.47.1.1.1.1.14.508	OctetString	
entPhysicalAlias.509	.1.3.6.1.2.1.47.1.1.1.1.14.509	OctetString	
entPhysicalAlias.510	.1.3.6.1.2.1.47.1.1.1.1.14.510	OctetString	
entPhysicalAlias.511	.1.3.6.1.2.1.47.1.1.1.1.14.511	OctetString	
entPhysicalAlias.512	.1.3.6.1.2.1.47.1.1.1.1.14.512	OctetString	
entPhysicalAlias.513	.1.3.6.1.2.1.47.1.1.1.1.14.513	OctetString	
entPhysicalAlias.514	.1.3.6.1.2.1.47.1.1.1.1.14.514	OctetString	
entPhysicalAlias.515	.1.3.6.1.2.1.47.1.1.1.1.14.515	OctetString	
entPhysicalAlias.516	.1.3.6.1.2.1.47.1.1.1.1.14.516	OctetString	
entPhysicalAlias.517	.1.3.6.1.2.1.47.1.1.1.1.14.517	OctetString	
entPhysicalAlias.518	.1.3.6.1.2.1.47.1.1.1.1.14.518	OctetString	
entPhysicalAlias.519	.1.3.6.1.2.1.47.1.1.1.1.14.519	OctetString	
entPhysicalAlias.520	.1.3.6.1.2.1.47.1.1.1.1.14.520	OctetString	
entPhysicalAlias.521	.1.3.6.1.2.1.47.1.1.1.1.14.521	OctetString	
entPhysicalAlias.522	.1.3.6.1.2.1.47.1.1.1.1.14.522	OctetString	
entPhysicalAlias.523	.1.3.6.1.2.1.47.1.1.1.1.14.523	OctetString	
entPhysicalAlias.524	.1.3.6.1.2.1.47.1.1.1.1.14.524	OctetString	
entPhysicalAlias.525	.1.3.6.1.2.1.47.1.1.1.1.14.525	OctetString	
entPhysicalAssetID.1	.1.3.6.1.2.1.47.1.1.1.1.15.1	OctetString	
entPhysicalAssetID.2	.1.3.6.1.2.1.47.1.1.1.1.15.2	OctetString	
entPhysicalAssetID.12	.1.3.6.1.2.1.47.1.1.1.1.15.12	OctetString	
entPhysicalAssetID.13	.1.3.6.1.2.1.47.1.1.1.1.15.13	OctetString	
entPhysicalAssetID.14	.1.3.6.1.2.1.47.1.1.1.1.15.14	OctetString	
entPhysicalAssetID.15	.1.3.6.1.2.1.47.1.1.1.1.15.15	OctetString	
entPhysicalAssetID.16	.1.3.6.1.2.1.47.1.1.1.1.15.16	OctetString	
entPhysicalAssetID.17	.1.3.6.1.2.1.47.1.1.1.1.15.17	OctetString	
entPhysicalAssetID.18	.1.3.6.1.2.1.47.1.1.1.1.15.18	OctetString	
entPhysicalAssetID.19	.1.3.6.1.2.1.47.1.1.1.1.15.19	OctetString	
entPhysicalAssetID.20	.1.3.6.1.2.1.47.1.1.1.1.15.20	OctetString	
entPhysicalAssetID.21	.1.3.6.1.2.1.47.1.1.1.1.15.21	OctetString	
entPhysicalAssetID.22	.1.3.6.1.2.1.47.1.1.1.1.15.22	OctetString	
entPhysicalAssetID.23	.1.3.6.1.2.1.47.1.1.1.1.15.23	OctetString	
entPhysicalAssetID.24	.1.3.6.1.2.1.47.1.1.1.1.15.24	OctetString	
entPhysicalAssetID.25	.1.3.6.1.2.1.47.1.1.1.1.15.25	OctetString	
entPhysicalAssetID.26	.1.3.6.1.2.1.47.1.1.1.1.15.26	OctetString	
entPhysicalAssetID.27	.1.3.6.1.2.1.47.1.1.1.1.15.27	OctetString	
entPhysicalAssetID.28	.1.3.6.1.2.1.47.1.1.1.1.15.28	OctetString	



Name	OID	Value Type	Value Example
entPhysicalAssetID.29	.1.3.6.1.2.1.47.1.1.1.1.15.29	OctetString	
entPhysicalAssetID.30	.1.3.6.1.2.1.47.1.1.1.1.15.30	OctetString	
entPhysicalAssetID.31	.1.3.6.1.2.1.47.1.1.1.1.15.31	OctetString	
entPhysicalAssetID.212	.1.3.6.1.2.1.47.1.1.1.1.15.212	OctetString	
entPhysicalAssetID.213	.1.3.6.1.2.1.47.1.1.1.1.15.213	OctetString	
entPhysicalAssetID.216	.1.3.6.1.2.1.47.1.1.1.1.15.216	OctetString	
entPhysicalAssetID.220	.1.3.6.1.2.1.47.1.1.1.1.15.220	OctetString	
entPhysicalAssetID.221	.1.3.6.1.2.1.47.1.1.1.1.15.221	OctetString	
entPhysicalAssetID.412	.1.3.6.1.2.1.47.1.1.1.1.15.412	OctetString	
entPhysicalAssetID.413	.1.3.6.1.2.1.47.1.1.1.1.15.413	OctetString	
entPhysicalAssetID.414	.1.3.6.1.2.1.47.1.1.1.1.15.414	OctetString	
entPhysicalAssetID.442	.1.3.6.1.2.1.47.1.1.1.1.15.442	OctetString	
entPhysicalAssetID.472	.1.3.6.1.2.1.47.1.1.1.1.15.472	OctetString	
entPhysicalAssetID.473	.1.3.6.1.2.1.47.1.1.1.1.15.473	OctetString	
entPhysicalAssetID.474	.1.3.6.1.2.1.47.1.1.1.1.15.474	OctetString	
entPhysicalAssetID.475	.1.3.6.1.2.1.47.1.1.1.1.15.475	OctetString	
entPhysicalAssetID.476	.1.3.6.1.2.1.47.1.1.1.1.15.476	OctetString	
entPhysicalAssetID.477	.1.3.6.1.2.1.47.1.1.1.1.15.477	OctetString	
entPhysicalAssetID.478	.1.3.6.1.2.1.47.1.1.1.1.15.478	OctetString	
entPhysicalAssetID.479	.1.3.6.1.2.1.47.1.1.1.1.15.479	OctetString	
entPhysicalAssetID.480	.1.3.6.1.2.1.47.1.1.1.1.15.480	OctetString	
entPhysicalAssetID.481	.1.3.6.1.2.1.47.1.1.1.1.15.481	OctetString	
entPhysicalAssetID.482	.1.3.6.1.2.1.47.1.1.1.1.15.482	OctetString	
entPhysicalAssetID.483	.1.3.6.1.2.1.47.1.1.1.1.15.483	OctetString	
entPhysicalAssetID.484	.1.3.6.1.2.1.47.1.1.1.1.15.484	OctetString	
entPhysicalAssetID.485	.1.3.6.1.2.1.47.1.1.1.1.15.485	OctetString	
entPhysicalAssetID.486	.1.3.6.1.2.1.47.1.1.1.1.15.486	OctetString	
entPhysicalAssetID.487	.1.3.6.1.2.1.47.1.1.1.1.15.487	OctetString	
entPhysicalAssetID.488	.1.3.6.1.2.1.47.1.1.1.1.15.488	OctetString	
entPhysicalAssetID.489	.1.3.6.1.2.1.47.1.1.1.1.15.489	OctetString	
entPhysicalAssetID.490	.1.3.6.1.2.1.47.1.1.1.1.15.490	OctetString	
entPhysicalAssetID.491	.1.3.6.1.2.1.47.1.1.1.1.15.491	OctetString	
entPhysicalAssetID.492	.1.3.6.1.2.1.47.1.1.1.1.15.492	OctetString	
entPhysicalAssetID.493	.1.3.6.1.2.1.47.1.1.1.1.15.493	OctetString	
entPhysicalAssetID.494	.1.3.6.1.2.1.47.1.1.1.1.15.494	OctetString	
entPhysicalAssetID.495	.1.3.6.1.2.1.47.1.1.1.1.15.495	OctetString	
entPhysicalAssetID.496	.1.3.6.1.2.1.47.1.1.1.1.15.496	OctetString	
entPhysicalAssetID.497	.1.3.6.1.2.1.47.1.1.1.1.15.497	OctetString	
entPhysicalAssetID.498	.1.3.6.1.2.1.47.1.1.1.1.15.498	OctetString	
entPhysicalAssetID.499	.1.3.6.1.2.1.47.1.1.1.1.15.499	OctetString	
entPhysicalAssetID.500	.1.3.6.1.2.1.47.1.1.1.1.15.500	OctetString	
entPhysicalAssetID.501	.1.3.6.1.2.1.47.1.1.1.1.15.501	OctetString	
entPhysicalAssetID.502	.1.3.6.1.2.1.47.1.1.1.1.15.502	OctetString	

Name	OID	Value Type	Value Example
entPhysicalAssetID.503	.1.3.6.1.2.1.47.1.1.1.1.15.503	OctetString	
entPhysicalAssetID.504	.1.3.6.1.2.1.47.1.1.1.1.15.504	OctetString	
entPhysicalAssetID.505	.1.3.6.1.2.1.47.1.1.1.1.15.505	OctetString	
entPhysicalAssetID.506	.1.3.6.1.2.1.47.1.1.1.1.15.506	OctetString	
entPhysicalAssetID.507	.1.3.6.1.2.1.47.1.1.1.1.15.507	OctetString	
entPhysicalAssetID.508	.1.3.6.1.2.1.47.1.1.1.1.15.508	OctetString	
entPhysicalAssetID.509	.1.3.6.1.2.1.47.1.1.1.1.15.509	OctetString	
entPhysicalAssetID.510	.1.3.6.1.2.1.47.1.1.1.1.15.510	OctetString	
entPhysicalAssetID.511	.1.3.6.1.2.1.47.1.1.1.1.15.511	OctetString	
entPhysicalAssetID.512	.1.3.6.1.2.1.47.1.1.1.1.15.512	OctetString	
entPhysicalAssetID.513	.1.3.6.1.2.1.47.1.1.1.1.15.513	OctetString	
entPhysicalAssetID.514	.1.3.6.1.2.1.47.1.1.1.1.15.514	OctetString	
entPhysicalAssetID.515	.1.3.6.1.2.1.47.1.1.1.1.15.515	OctetString	
entPhysicalAssetID.516	.1.3.6.1.2.1.47.1.1.1.1.15.516	OctetString	
entPhysicalAssetID.517	.1.3.6.1.2.1.47.1.1.1.1.15.517	OctetString	
entPhysicalAssetID.518	.1.3.6.1.2.1.47.1.1.1.1.15.518	OctetString	
entPhysicalAssetID.519	.1.3.6.1.2.1.47.1.1.1.1.15.519	OctetString	
entPhysicalAssetID.520	.1.3.6.1.2.1.47.1.1.1.1.15.520	OctetString	
entPhysicalAssetID.521	.1.3.6.1.2.1.47.1.1.1.1.15.521	OctetString	
entPhysicalAssetID.522	.1.3.6.1.2.1.47.1.1.1.1.15.522	OctetString	
entPhysicalAssetID.523	.1.3.6.1.2.1.47.1.1.1.1.15.523	OctetString	
entPhysicalAssetID.524	.1.3.6.1.2.1.47.1.1.1.1.15.524	OctetString	
entPhysicalAssetID.525	.1.3.6.1.2.1.47.1.1.1.1.15.525	OctetString	
entPhysicalIsFRU.1	.1.3.6.1.2.1.47.1.1.1.1.16.1	Integer	false (2)
entPhysicalIsFRU.2	.1.3.6.1.2.1.47.1.1.1.1.16.2	Integer	true (1)
entPhysicalIsFRU.12	.1.3.6.1.2.1.47.1.1.1.1.16.12	Integer	false (2)
entPhysicalIsFRU.13	.1.3.6.1.2.1.47.1.1.1.1.16.13	Integer	false (2)
entPhysicalIsFRU.14	.1.3.6.1.2.1.47.1.1.1.1.16.14	Integer	false (2)
entPhysicalIsFRU.15	.1.3.6.1.2.1.47.1.1.1.1.16.15	Integer	false (2)
entPhysicalIsFRU.16	.1.3.6.1.2.1.47.1.1.1.1.16.16	Integer	false (2)
entPhysicalIsFRU.17	.1.3.6.1.2.1.47.1.1.1.1.16.17	Integer	false (2)
entPhysicalIsFRU.18	.1.3.6.1.2.1.47.1.1.1.1.16.18	Integer	false (2)
entPhysicalIsFRU.19	.1.3.6.1.2.1.47.1.1.1.1.16.19	Integer	false (2)
entPhysicalIsFRU.20	.1.3.6.1.2.1.47.1.1.1.1.16.20	Integer	false (2)
entPhysicalIsFRU.21	.1.3.6.1.2.1.47.1.1.1.1.16.21	Integer	false (2)
entPhysicalIsFRU.22	.1.3.6.1.2.1.47.1.1.1.1.16.22	Integer	false (2)
entPhysicalIsFRU.23	.1.3.6.1.2.1.47.1.1.1.1.16.23	Integer	false (2)
entPhysicalIsFRU.24	.1.3.6.1.2.1.47.1.1.1.1.16.24	Integer	false (2)
entPhysicalIsFRU.25	.1.3.6.1.2.1.47.1.1.1.1.16.25	Integer	false (2)
entPhysicalIsFRU.26	.1.3.6.1.2.1.47.1.1.1.1.16.26	Integer	false (2)
entPhysicalIsFRU.27	.1.3.6.1.2.1.47.1.1.1.1.16.27	Integer	false (2)
entPhysicalIsFRU.28	.1.3.6.1.2.1.47.1.1.1.1.16.28	Integer	false (2)
entPhysicalIsFRU.29	.1.3.6.1.2.1.47.1.1.1.1.16.29	Integer	false (2)

Name	OID	Value Type	Value Example
entPhysicalsFRU.30	.1.3.6.1.2.1.47.1.1.1.1.16.30	Integer	false (2)
entPhysicalsFRU.31	.1.3.6.1.2.1.47.1.1.1.1.16.31	Integer	false (2)
entPhysicalsFRU.212	.1.3.6.1.2.1.47.1.1.1.1.16.212	Integer	false (2)
entPhysicalsFRU.213	.1.3.6.1.2.1.47.1.1.1.1.16.213	Integer	true (1)
entPhysicalsFRU.216	.1.3.6.1.2.1.47.1.1.1.1.16.216	Integer	false (2)
entPhysicalsFRU.220	.1.3.6.1.2.1.47.1.1.1.1.16.220	Integer	false (2)
entPhysicalsFRU.221	.1.3.6.1.2.1.47.1.1.1.1.16.221	Integer	false (2)
entPhysicalsFRU.412	.1.3.6.1.2.1.47.1.1.1.1.16.412	Integer	false (2)
entPhysicalsFRU.413	.1.3.6.1.2.1.47.1.1.1.1.16.413	Integer	false (2)
entPhysicalsFRU.414	.1.3.6.1.2.1.47.1.1.1.1.16.414	Integer	false (2)
entPhysicalsFRU.442	.1.3.6.1.2.1.47.1.1.1.1.16.442	Integer	true (1)
entPhysicalsFRU.472	.1.3.6.1.2.1.47.1.1.1.1.16.472	Integer	false (2)
entPhysicalsFRU.473	.1.3.6.1.2.1.47.1.1.1.1.16.473	Integer	false (2)
entPhysicalsFRU.474	.1.3.6.1.2.1.47.1.1.1.1.16.474	Integer	false (2)
entPhysicalsFRU.475	.1.3.6.1.2.1.47.1.1.1.1.16.475	Integer	false (2)
entPhysicalsFRU.476	.1.3.6.1.2.1.47.1.1.1.1.16.476	Integer	false (2)
entPhysicalsFRU.477	.1.3.6.1.2.1.47.1.1.1.1.16.477	Integer	false (2)
entPhysicalsFRU.478	.1.3.6.1.2.1.47.1.1.1.1.16.478	Integer	false (2)
entPhysicalsFRU.479	.1.3.6.1.2.1.47.1.1.1.1.16.479	Integer	false (2)
entPhysicalsFRU.480	.1.3.6.1.2.1.47.1.1.1.1.16.480	Integer	false (2)
entPhysicalsFRU.481	.1.3.6.1.2.1.47.1.1.1.1.16.481	Integer	false (2)
entPhysicalsFRU.482	.1.3.6.1.2.1.47.1.1.1.1.16.482	Integer	false (2)
entPhysicalsFRU.483	.1.3.6.1.2.1.47.1.1.1.1.16.483	Integer	false (2)
entPhysicalsFRU.484	.1.3.6.1.2.1.47.1.1.1.1.16.484	Integer	false (2)
entPhysicalsFRU.485	.1.3.6.1.2.1.47.1.1.1.1.16.485	Integer	false (2)
entPhysicalsFRU.486	.1.3.6.1.2.1.47.1.1.1.1.16.486	Integer	false (2)
entPhysicalsFRU.487	.1.3.6.1.2.1.47.1.1.1.1.16.487	Integer	false (2)
entPhysicalsFRU.488	.1.3.6.1.2.1.47.1.1.1.1.16.488	Integer	false (2)
entPhysicalsFRU.489	.1.3.6.1.2.1.47.1.1.1.1.16.489	Integer	false (2)
entPhysicalsFRU.490	.1.3.6.1.2.1.47.1.1.1.1.16.490	Integer	false (2)
entPhysicalsFRU.491	.1.3.6.1.2.1.47.1.1.1.1.16.491	Integer	false (2)
entPhysicalsFRU.492	.1.3.6.1.2.1.47.1.1.1.1.16.492	Integer	false (2)
entPhysicalsFRU.493	.1.3.6.1.2.1.47.1.1.1.1.16.493	Integer	false (2)
entPhysicalsFRU.494	.1.3.6.1.2.1.47.1.1.1.1.16.494	Integer	false (2)
entPhysicalsFRU.495	.1.3.6.1.2.1.47.1.1.1.1.16.495	Integer	false (2)
entPhysicalsFRU.496	.1.3.6.1.2.1.47.1.1.1.1.16.496	Integer	false (2)
entPhysicalsFRU.497	.1.3.6.1.2.1.47.1.1.1.1.16.497	Integer	false (2)
entPhysicalsFRU.498	.1.3.6.1.2.1.47.1.1.1.1.16.498	Integer	false (2)
entPhysicalsFRU.499	.1.3.6.1.2.1.47.1.1.1.1.16.499	Integer	false (2)
entPhysicalsFRU.500	.1.3.6.1.2.1.47.1.1.1.1.16.500	Integer	false (2)
entPhysicalsFRU.501	.1.3.6.1.2.1.47.1.1.1.1.16.501	Integer	false (2)
entPhysicalsFRU.502	.1.3.6.1.2.1.47.1.1.1.1.16.502	Integer	false (2)
entPhysicalsFRU.503	.1.3.6.1.2.1.47.1.1.1.1.16.503	Integer	false (2)

Name	OID	Value Type	Value Example
entPhysicalIsFRU.504	.1.3.6.1.2.1.47.1.1.1.1.16.504	Integer	false (2)
entPhysicalIsFRU.505	.1.3.6.1.2.1.47.1.1.1.1.16.505	Integer	false (2)
entPhysicalIsFRU.506	.1.3.6.1.2.1.47.1.1.1.1.16.506	Integer	false (2)
entPhysicalIsFRU.507	.1.3.6.1.2.1.47.1.1.1.1.16.507	Integer	false (2)
entPhysicalIsFRU.508	.1.3.6.1.2.1.47.1.1.1.1.16.508	Integer	false (2)
entPhysicalIsFRU.509	.1.3.6.1.2.1.47.1.1.1.1.16.509	Integer	false (2)
entPhysicalIsFRU.510	.1.3.6.1.2.1.47.1.1.1.1.16.510	Integer	false (2)
entPhysicalIsFRU.511	.1.3.6.1.2.1.47.1.1.1.1.16.511	Integer	false (2)
entPhysicalIsFRU.512	.1.3.6.1.2.1.47.1.1.1.1.16.512	Integer	false (2)
entPhysicalIsFRU.513	.1.3.6.1.2.1.47.1.1.1.1.16.513	Integer	false (2)
entPhysicalIsFRU.514	.1.3.6.1.2.1.47.1.1.1.1.16.514	Integer	false (2)
entPhysicalIsFRU.515	.1.3.6.1.2.1.47.1.1.1.1.16.515	Integer	false (2)
entPhysicalIsFRU.516	.1.3.6.1.2.1.47.1.1.1.1.16.516	Integer	false (2)
entPhysicalIsFRU.517	.1.3.6.1.2.1.47.1.1.1.1.16.517	Integer	false (2)
entPhysicalIsFRU.518	.1.3.6.1.2.1.47.1.1.1.1.16.518	Integer	false (2)
entPhysicalIsFRU.519	.1.3.6.1.2.1.47.1.1.1.1.16.519	Integer	false (2)
entPhysicalIsFRU.520	.1.3.6.1.2.1.47.1.1.1.1.16.520	Integer	true (1)
entPhysicalIsFRU.521	.1.3.6.1.2.1.47.1.1.1.1.16.521	Integer	true (1)
entPhysicalIsFRU.522	.1.3.6.1.2.1.47.1.1.1.1.16.522	Integer	true (1)
entPhysicalIsFRU.523	.1.3.6.1.2.1.47.1.1.1.1.16.523	Integer	true (1)
entPhysicalIsFRU.524	.1.3.6.1.2.1.47.1.1.1.1.16.524	Integer	true (1)
entPhysicalIsFRU.525	.1.3.6.1.2.1.47.1.1.1.1.16.525	Integer	true (1)
entPhysicalMfgDate.1	.1.3.6.1.2.1.47.1.1.1.1.17.1	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.2	.1.3.6.1.2.1.47.1.1.1.1.17.2	OctetString	2023-4-28,0:0:0.0
entPhysicalMfgDate.12	.1.3.6.1.2.1.47.1.1.1.1.17.12	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.13	.1.3.6.1.2.1.47.1.1.1.1.17.13	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.14	.1.3.6.1.2.1.47.1.1.1.1.17.14	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.15	.1.3.6.1.2.1.47.1.1.1.1.17.15	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.16	.1.3.6.1.2.1.47.1.1.1.1.17.16	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.17	.1.3.6.1.2.1.47.1.1.1.1.17.17	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.18	.1.3.6.1.2.1.47.1.1.1.1.17.18	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.19	.1.3.6.1.2.1.47.1.1.1.1.17.19	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.20	.1.3.6.1.2.1.47.1.1.1.1.17.20	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.21	.1.3.6.1.2.1.47.1.1.1.1.17.21	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.22	.1.3.6.1.2.1.47.1.1.1.1.17.22	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.23	.1.3.6.1.2.1.47.1.1.1.1.17.23	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.24	.1.3.6.1.2.1.47.1.1.1.1.17.24	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.25	.1.3.6.1.2.1.47.1.1.1.1.17.25	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.26	.1.3.6.1.2.1.47.1.1.1.1.17.26	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.27	.1.3.6.1.2.1.47.1.1.1.1.17.27	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.28	.1.3.6.1.2.1.47.1.1.1.1.17.28	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.29	.1.3.6.1.2.1.47.1.1.1.1.17.29	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.30	.1.3.6.1.2.1.47.1.1.1.1.17.30	OctetString	0-0-0,0:0:0.0



Name	OID	Value Type	Value Example
entPhysicalMfgDate.505	.1.3.6.1.2.1.47.1.1.1.1.17.505	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.506	.1.3.6.1.2.1.47.1.1.1.1.17.506	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.507	.1.3.6.1.2.1.47.1.1.1.1.17.507	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.508	.1.3.6.1.2.1.47.1.1.1.1.17.508	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.509	.1.3.6.1.2.1.47.1.1.1.1.17.509	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.510	.1.3.6.1.2.1.47.1.1.1.1.17.510	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.511	.1.3.6.1.2.1.47.1.1.1.1.17.511	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.512	.1.3.6.1.2.1.47.1.1.1.1.17.512	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.513	.1.3.6.1.2.1.47.1.1.1.1.17.513	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.514	.1.3.6.1.2.1.47.1.1.1.1.17.514	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.515	.1.3.6.1.2.1.47.1.1.1.1.17.515	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.516	.1.3.6.1.2.1.47.1.1.1.1.17.516	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.517	.1.3.6.1.2.1.47.1.1.1.1.17.517	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.518	.1.3.6.1.2.1.47.1.1.1.1.17.518	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.519	.1.3.6.1.2.1.47.1.1.1.1.17.519	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.520	.1.3.6.1.2.1.47.1.1.1.1.17.520	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.521	.1.3.6.1.2.1.47.1.1.1.1.17.521	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.522	.1.3.6.1.2.1.47.1.1.1.1.17.522	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.523	.1.3.6.1.2.1.47.1.1.1.1.17.523	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.524	.1.3.6.1.2.1.47.1.1.1.1.17.524	OctetString	0-0-0,0:0:0.0
entPhysicalMfgDate.525	.1.3.6.1.2.1.47.1.1.1.1.17.525	OctetString	0-0-0,0:0:0.0
entPhysicalUris.1	.1.3.6.1.2.1.47.1.1.1.1.18.1	OctetString	
entPhysicalUris.2	.1.3.6.1.2.1.47.1.1.1.1.18.2	OctetString	NONE
entPhysicalUris.12	.1.3.6.1.2.1.47.1.1.1.1.18.12	OctetString	
entPhysicalUris.13	.1.3.6.1.2.1.47.1.1.1.1.18.13	OctetString	
entPhysicalUris.14	.1.3.6.1.2.1.47.1.1.1.1.18.14	OctetString	
entPhysicalUris.15	.1.3.6.1.2.1.47.1.1.1.1.18.15	OctetString	
entPhysicalUris.16	.1.3.6.1.2.1.47.1.1.1.1.18.16	OctetString	
entPhysicalUris.17	.1.3.6.1.2.1.47.1.1.1.1.18.17	OctetString	
entPhysicalUris.18	.1.3.6.1.2.1.47.1.1.1.1.18.18	OctetString	
entPhysicalUris.19	.1.3.6.1.2.1.47.1.1.1.1.18.19	OctetString	
entPhysicalUris.20	.1.3.6.1.2.1.47.1.1.1.1.18.20	OctetString	
entPhysicalUris.21	.1.3.6.1.2.1.47.1.1.1.1.18.21	OctetString	
entPhysicalUris.22	.1.3.6.1.2.1.47.1.1.1.1.18.22	OctetString	
entPhysicalUris.23	.1.3.6.1.2.1.47.1.1.1.1.18.23	OctetString	
entPhysicalUris.24	.1.3.6.1.2.1.47.1.1.1.1.18.24	OctetString	
entPhysicalUris.25	.1.3.6.1.2.1.47.1.1.1.1.18.25	OctetString	
entPhysicalUris.26	.1.3.6.1.2.1.47.1.1.1.1.18.26	OctetString	
entPhysicalUris.27	.1.3.6.1.2.1.47.1.1.1.1.18.27	OctetString	
entPhysicalUris.28	.1.3.6.1.2.1.47.1.1.1.1.18.28	OctetString	
entPhysicalUris.29	.1.3.6.1.2.1.47.1.1.1.1.18.29	OctetString	
entPhysicalUris.30	.1.3.6.1.2.1.47.1.1.1.1.18.30	OctetString	
entPhysicalUris.31	.1.3.6.1.2.1.47.1.1.1.1.18.31	OctetString	

Name	OID	Value Type	Value Example
entPhysicalUris.212	.1.3.6.1.2.1.47.1.1.1.1.18.212	OctetString	
entPhysicalUris.213	.1.3.6.1.2.1.47.1.1.1.1.18.213	OctetString	
entPhysicalUris.216	.1.3.6.1.2.1.47.1.1.1.1.18.216	OctetString	
entPhysicalUris.220	.1.3.6.1.2.1.47.1.1.1.1.18.220	OctetString	
entPhysicalUris.221	.1.3.6.1.2.1.47.1.1.1.1.18.221	OctetString	
entPhysicalUris.412	.1.3.6.1.2.1.47.1.1.1.1.18.412	OctetString	
entPhysicalUris.413	.1.3.6.1.2.1.47.1.1.1.1.18.413	OctetString	
entPhysicalUris.414	.1.3.6.1.2.1.47.1.1.1.1.18.414	OctetString	
entPhysicalUris.442	.1.3.6.1.2.1.47.1.1.1.1.18.442	OctetString	
entPhysicalUris.472	.1.3.6.1.2.1.47.1.1.1.1.18.472	OctetString	
entPhysicalUris.473	.1.3.6.1.2.1.47.1.1.1.1.18.473	OctetString	
entPhysicalUris.474	.1.3.6.1.2.1.47.1.1.1.1.18.474	OctetString	
entPhysicalUris.475	.1.3.6.1.2.1.47.1.1.1.1.18.475	OctetString	
entPhysicalUris.476	.1.3.6.1.2.1.47.1.1.1.1.18.476	OctetString	
entPhysicalUris.477	.1.3.6.1.2.1.47.1.1.1.1.18.477	OctetString	
entPhysicalUris.478	.1.3.6.1.2.1.47.1.1.1.1.18.478	OctetString	
entPhysicalUris.479	.1.3.6.1.2.1.47.1.1.1.1.18.479	OctetString	
entPhysicalUris.480	.1.3.6.1.2.1.47.1.1.1.1.18.480	OctetString	
entPhysicalUris.481	.1.3.6.1.2.1.47.1.1.1.1.18.481	OctetString	
entPhysicalUris.482	.1.3.6.1.2.1.47.1.1.1.1.18.482	OctetString	
entPhysicalUris.483	.1.3.6.1.2.1.47.1.1.1.1.18.483	OctetString	
entPhysicalUris.484	.1.3.6.1.2.1.47.1.1.1.1.18.484	OctetString	
entPhysicalUris.485	.1.3.6.1.2.1.47.1.1.1.1.18.485	OctetString	
entPhysicalUris.486	.1.3.6.1.2.1.47.1.1.1.1.18.486	OctetString	
entPhysicalUris.487	.1.3.6.1.2.1.47.1.1.1.1.18.487	OctetString	
entPhysicalUris.488	.1.3.6.1.2.1.47.1.1.1.1.18.488	OctetString	
entPhysicalUris.489	.1.3.6.1.2.1.47.1.1.1.1.18.489	OctetString	
entPhysicalUris.490	.1.3.6.1.2.1.47.1.1.1.1.18.490	OctetString	
entPhysicalUris.491	.1.3.6.1.2.1.47.1.1.1.1.18.491	OctetString	
entPhysicalUris.492	.1.3.6.1.2.1.47.1.1.1.1.18.492	OctetString	
entPhysicalUris.493	.1.3.6.1.2.1.47.1.1.1.1.18.493	OctetString	
entPhysicalUris.494	.1.3.6.1.2.1.47.1.1.1.1.18.494	OctetString	
entPhysicalUris.495	.1.3.6.1.2.1.47.1.1.1.1.18.495	OctetString	
entPhysicalUris.496	.1.3.6.1.2.1.47.1.1.1.1.18.496	OctetString	
entPhysicalUris.497	.1.3.6.1.2.1.47.1.1.1.1.18.497	OctetString	
entPhysicalUris.498	.1.3.6.1.2.1.47.1.1.1.1.18.498	OctetString	
entPhysicalUris.499	.1.3.6.1.2.1.47.1.1.1.1.18.499	OctetString	
entPhysicalUris.500	.1.3.6.1.2.1.47.1.1.1.1.18.500	OctetString	
entPhysicalUris.501	.1.3.6.1.2.1.47.1.1.1.1.18.501	OctetString	
entPhysicalUris.502	.1.3.6.1.2.1.47.1.1.1.1.18.502	OctetString	
entPhysicalUris.503	.1.3.6.1.2.1.47.1.1.1.1.18.503	OctetString	
entPhysicalUris.504	.1.3.6.1.2.1.47.1.1.1.1.18.504	OctetString	
entPhysicalUris.505	.1.3.6.1.2.1.47.1.1.1.1.18.505	OctetString	



Name	OID	Value Type	Value Example
entPhysicalUris.506	.1.3.6.1.2.1.47.1.1.1.1.18.506	OctetString	
entPhysicalUris.507	.1.3.6.1.2.1.47.1.1.1.1.18.507	OctetString	
entPhysicalUris.508	.1.3.6.1.2.1.47.1.1.1.1.18.508	OctetString	
entPhysicalUris.509	.1.3.6.1.2.1.47.1.1.1.1.18.509	OctetString	
entPhysicalUris.510	.1.3.6.1.2.1.47.1.1.1.1.18.510	OctetString	
entPhysicalUris.511	.1.3.6.1.2.1.47.1.1.1.1.18.511	OctetString	
entPhysicalUris.512	.1.3.6.1.2.1.47.1.1.1.1.18.512	OctetString	
entPhysicalUris.513	.1.3.6.1.2.1.47.1.1.1.1.18.513	OctetString	
entPhysicalUris.514	.1.3.6.1.2.1.47.1.1.1.1.18.514	OctetString	
entPhysicalUris.515	.1.3.6.1.2.1.47.1.1.1.1.18.515	OctetString	
entPhysicalUris.516	.1.3.6.1.2.1.47.1.1.1.1.18.516	OctetString	
entPhysicalUris.517	.1.3.6.1.2.1.47.1.1.1.1.18.517	OctetString	
entPhysicalUris.518	.1.3.6.1.2.1.47.1.1.1.1.18.518	OctetString	
entPhysicalUris.519	.1.3.6.1.2.1.47.1.1.1.1.18.519	OctetString	
entPhysicalUris.520	.1.3.6.1.2.1.47.1.1.1.1.18.520	OctetString	
entPhysicalUris.521	.1.3.6.1.2.1.47.1.1.1.1.18.521	OctetString	
entPhysicalUris.522	.1.3.6.1.2.1.47.1.1.1.1.18.522	OctetString	
entPhysicalUris.523	.1.3.6.1.2.1.47.1.1.1.1.18.523	OctetString	
entPhysicalUris.524	.1.3.6.1.2.1.47.1.1.1.1.18.524	OctetString	
entPhysicalUris.525	.1.3.6.1.2.1.47.1.1.1.1.18.525	OctetString	
entAliasMappingIdentifier.472.0	.1.3.6.1.2.1.47.1.3.2.1.2.472.0	OID	ifIndex.1
entAliasMappingIdentifier.473.0	.1.3.6.1.2.1.47.1.3.2.1.2.473.0	OID	ifIndex.2
entAliasMappingIdentifier.474.0	.1.3.6.1.2.1.47.1.3.2.1.2.474.0	OID	ifIndex.3
entAliasMappingIdentifier.475.0	.1.3.6.1.2.1.47.1.3.2.1.2.475.0	OID	ifIndex.4
entAliasMappingIdentifier.476.0	.1.3.6.1.2.1.47.1.3.2.1.2.476.0	OID	ifIndex.5
entAliasMappingIdentifier.477.0	.1.3.6.1.2.1.47.1.3.2.1.2.477.0	OID	ifIndex.6
entAliasMappingIdentifier.478.0	.1.3.6.1.2.1.47.1.3.2.1.2.478.0	OID	ifIndex.7
entAliasMappingIdentifier.479.0	.1.3.6.1.2.1.47.1.3.2.1.2.479.0	OID	ifIndex.8
entAliasMappingIdentifier.480.0	.1.3.6.1.2.1.47.1.3.2.1.2.480.0	OID	ifIndex.9
entAliasMappingIdentifier.481.0	.1.3.6.1.2.1.47.1.3.2.1.2.481.0	OID	ifIndex.10
entAliasMappingIdentifier.482.0	.1.3.6.1.2.1.47.1.3.2.1.2.482.0	OID	ifIndex.11
entAliasMappingIdentifier.483.0	.1.3.6.1.2.1.47.1.3.2.1.2.483.0	OID	ifIndex.12
entAliasMappingIdentifier.484.0	.1.3.6.1.2.1.47.1.3.2.1.2.484.0	OID	ifIndex.13



<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
entAliasMappingIdentifier.485.0	.1.3.6.1.2.1.47.1.3.2.1.2.485.0	OID	ifIndex.14
entAliasMappingIdentifier.486.0	.1.3.6.1.2.1.47.1.3.2.1.2.486.0	OID	ifIndex.15
entAliasMappingIdentifier.487.0	.1.3.6.1.2.1.47.1.3.2.1.2.487.0	OID	ifIndex.16
entAliasMappingIdentifier.488.0	.1.3.6.1.2.1.47.1.3.2.1.2.488.0	OID	ifIndex.17
entAliasMappingIdentifier.489.0	.1.3.6.1.2.1.47.1.3.2.1.2.489.0	OID	ifIndex.18
entAliasMappingIdentifier.490.0	.1.3.6.1.2.1.47.1.3.2.1.2.490.0	OID	ifIndex.19
entAliasMappingIdentifier.491.0	.1.3.6.1.2.1.47.1.3.2.1.2.491.0	OID	ifIndex.20
entAliasMappingIdentifier.492.0	.1.3.6.1.2.1.47.1.3.2.1.2.492.0	OID	ifIndex.21
entAliasMappingIdentifier.493.0	.1.3.6.1.2.1.47.1.3.2.1.2.493.0	OID	ifIndex.22
entAliasMappingIdentifier.494.0	.1.3.6.1.2.1.47.1.3.2.1.2.494.0	OID	ifIndex.23
entAliasMappingIdentifier.495.0	.1.3.6.1.2.1.47.1.3.2.1.2.495.0	OID	ifIndex.24
entAliasMappingIdentifier.496.0	.1.3.6.1.2.1.47.1.3.2.1.2.496.0	OID	ifIndex.25
entAliasMappingIdentifier.497.0	.1.3.6.1.2.1.47.1.3.2.1.2.497.0	OID	ifIndex.26
entAliasMappingIdentifier.498.0	.1.3.6.1.2.1.47.1.3.2.1.2.498.0	OID	ifIndex.27
entAliasMappingIdentifier.499.0	.1.3.6.1.2.1.47.1.3.2.1.2.499.0	OID	ifIndex.28
entAliasMappingIdentifier.500.0	.1.3.6.1.2.1.47.1.3.2.1.2.500.0	OID	ifIndex.29
entAliasMappingIdentifier.501.0	.1.3.6.1.2.1.47.1.3.2.1.2.501.0	OID	ifIndex.30
entAliasMappingIdentifier.502.0	.1.3.6.1.2.1.47.1.3.2.1.2.502.0	OID	ifIndex.31
entAliasMappingIdentifier.503.0	.1.3.6.1.2.1.47.1.3.2.1.2.503.0	OID	ifIndex.32
entAliasMappingIdentifier.504.0	.1.3.6.1.2.1.47.1.3.2.1.2.504.0	OID	ifIndex.33
entAliasMappingIdentifier.505.0	.1.3.6.1.2.1.47.1.3.2.1.2.505.0	OID	ifIndex.34
entAliasMappingIdentifier.506.0	.1.3.6.1.2.1.47.1.3.2.1.2.506.0	OID	ifIndex.35
entAliasMappingIdentifier.507.0	.1.3.6.1.2.1.47.1.3.2.1.2.507.0	OID	ifIndex.36
entAliasMappingIdentifier.508.0	.1.3.6.1.2.1.47.1.3.2.1.2.508.0	OID	ifIndex.37
entAliasMappingIdentifier.509.0	.1.3.6.1.2.1.47.1.3.2.1.2.509.0	OID	ifIndex.38

Name	OID	Value Type	Value Example
entAliasMappingIdentifier.510.0	.1.3.6.1.2.1.47.1.3.2.1.2.510.0	OID	ifIndex.39
entAliasMappingIdentifier.511.0	.1.3.6.1.2.1.47.1.3.2.1.2.511.0	OID	ifIndex.40
entAliasMappingIdentifier.512.0	.1.3.6.1.2.1.47.1.3.2.1.2.512.0	OID	ifIndex.41
entAliasMappingIdentifier.513.0	.1.3.6.1.2.1.47.1.3.2.1.2.513.0	OID	ifIndex.42
entAliasMappingIdentifier.514.0	.1.3.6.1.2.1.47.1.3.2.1.2.514.0	OID	ifIndex.43
entAliasMappingIdentifier.515.0	.1.3.6.1.2.1.47.1.3.2.1.2.515.0	OID	ifIndex.44
entAliasMappingIdentifier.516.0	.1.3.6.1.2.1.47.1.3.2.1.2.516.0	OID	ifIndex.45
entAliasMappingIdentifier.517.0	.1.3.6.1.2.1.47.1.3.2.1.2.517.0	OID	ifIndex.46
entAliasMappingIdentifier.518.0	.1.3.6.1.2.1.47.1.3.2.1.2.518.0	OID	ifIndex.47
entAliasMappingIdentifier.519.0	.1.3.6.1.2.1.47.1.3.2.1.2.519.0	OID	ifIndex.48
entAliasMappingIdentifier.520.0	.1.3.6.1.2.1.47.1.3.2.1.2.520.0	OID	ifIndex.49
entAliasMappingIdentifier.521.0	.1.3.6.1.2.1.47.1.3.2.1.2.521.0	OID	ifIndex.50
entAliasMappingIdentifier.522.0	.1.3.6.1.2.1.47.1.3.2.1.2.522.0	OID	ifIndex.51
entAliasMappingIdentifier.523.0	.1.3.6.1.2.1.47.1.3.2.1.2.523.0	OID	ifIndex.52
entAliasMappingIdentifier.524.0	.1.3.6.1.2.1.47.1.3.2.1.2.524.0	OID	ifIndex.53
entAliasMappingIdentifier.525.0	.1.3.6.1.2.1.47.1.3.2.1.2.525.0	OID	ifIndex.54
entPhysicalChildIndex.1.2	.1.3.6.1.2.1.47.1.3.3.1.1.1.2	Integer	2
entPhysicalChildIndex.2.12	.1.3.6.1.2.1.47.1.3.3.1.1.2.12	Integer	12
entPhysicalChildIndex.2.13	.1.3.6.1.2.1.47.1.3.3.1.1.2.13	Integer	13
entPhysicalChildIndex.2.14	.1.3.6.1.2.1.47.1.3.3.1.1.2.14	Integer	14
entPhysicalChildIndex.2.15	.1.3.6.1.2.1.47.1.3.3.1.1.2.15	Integer	15
entPhysicalChildIndex.2.16	.1.3.6.1.2.1.47.1.3.3.1.1.2.16	Integer	16
entPhysicalChildIndex.2.17	.1.3.6.1.2.1.47.1.3.3.1.1.2.17	Integer	17
entPhysicalChildIndex.2.18	.1.3.6.1.2.1.47.1.3.3.1.1.2.18	Integer	18
entPhysicalChildIndex.2.19	.1.3.6.1.2.1.47.1.3.3.1.1.2.19	Integer	19
entPhysicalChildIndex.2.20	.1.3.6.1.2.1.47.1.3.3.1.1.2.20	Integer	20
entPhysicalChildIndex.2.21	.1.3.6.1.2.1.47.1.3.3.1.1.2.21	Integer	21
entPhysicalChildIndex.2.22	.1.3.6.1.2.1.47.1.3.3.1.1.2.22	Integer	22
entPhysicalChildIndex.2.23	.1.3.6.1.2.1.47.1.3.3.1.1.2.23	Integer	23
entPhysicalChildIndex.2.24	.1.3.6.1.2.1.47.1.3.3.1.1.2.24	Integer	24
entPhysicalChildIndex.2.25	.1.3.6.1.2.1.47.1.3.3.1.1.2.25	Integer	25
entPhysicalChildIndex.2.26	.1.3.6.1.2.1.47.1.3.3.1.1.2.26	Integer	26

Name	OID	Value Type	Value Example
entPhysicalChildIndex.2.27	.1.3.6.1.2.1.47.1.3.3.1.1.2.27	Integer	27
entPhysicalChildIndex.2.28	.1.3.6.1.2.1.47.1.3.3.1.1.2.28	Integer	28
entPhysicalChildIndex.2.29	.1.3.6.1.2.1.47.1.3.3.1.1.2.29	Integer	29
entPhysicalChildIndex.2.30	.1.3.6.1.2.1.47.1.3.3.1.1.2.30	Integer	30
entPhysicalChildIndex.2.31	.1.3.6.1.2.1.47.1.3.3.1.1.2.31	Integer	31
entPhysicalChildIndex.12.212	.1.3.6.1.2.1.47.1.3.3.1.1.12.212	Integer	212
entPhysicalChildIndex.13.213	.1.3.6.1.2.1.47.1.3.3.1.1.13.213	Integer	213
entPhysicalChildIndex.16.216	.1.3.6.1.2.1.47.1.3.3.1.1.16.216	Integer	216
entPhysicalChildIndex.20.220	.1.3.6.1.2.1.47.1.3.3.1.1.20.220	Integer	220
entPhysicalChildIndex.21.221	.1.3.6.1.2.1.47.1.3.3.1.1.21.221	Integer	221
entPhysicalChildIndex.212.412	.1.3.6.1.2.1.47.1.3.3.1.1.212.412	Integer	412
entPhysicalChildIndex.212.413	.1.3.6.1.2.1.47.1.3.3.1.1.212.413	Integer	413
entPhysicalChildIndex.212.414	.1.3.6.1.2.1.47.1.3.3.1.1.212.414	Integer	414
entPhysicalChildIndex.412.442	.1.3.6.1.2.1.47.1.3.3.1.1.412.442	Integer	442
entPhysicalChildIndex.442.472	.1.3.6.1.2.1.47.1.3.3.1.1.442.472	Integer	472
entPhysicalChildIndex.442.473	.1.3.6.1.2.1.47.1.3.3.1.1.442.473	Integer	473
entPhysicalChildIndex.442.474	.1.3.6.1.2.1.47.1.3.3.1.1.442.474	Integer	474
entPhysicalChildIndex.442.475	.1.3.6.1.2.1.47.1.3.3.1.1.442.475	Integer	475
entPhysicalChildIndex.442.476	.1.3.6.1.2.1.47.1.3.3.1.1.442.476	Integer	476
entPhysicalChildIndex.442.477	.1.3.6.1.2.1.47.1.3.3.1.1.442.477	Integer	477
entPhysicalChildIndex.442.478	.1.3.6.1.2.1.47.1.3.3.1.1.442.478	Integer	478
entPhysicalChildIndex.442.479	.1.3.6.1.2.1.47.1.3.3.1.1.442.479	Integer	479
entPhysicalChildIndex.442.480	.1.3.6.1.2.1.47.1.3.3.1.1.442.480	Integer	480
entPhysicalChildIndex.442.481	.1.3.6.1.2.1.47.1.3.3.1.1.442.481	Integer	481
entPhysicalChildIndex.442.482	.1.3.6.1.2.1.47.1.3.3.1.1.442.482	Integer	482
entPhysicalChildIndex.442.483	.1.3.6.1.2.1.47.1.3.3.1.1.442.483	Integer	483
entPhysicalChildIndex.442.484	.1.3.6.1.2.1.47.1.3.3.1.1.442.484	Integer	484
entPhysicalChildIndex.442.485	.1.3.6.1.2.1.47.1.3.3.1.1.442.485	Integer	485
entPhysicalChildIndex.442.486	.1.3.6.1.2.1.47.1.3.3.1.1.442.486	Integer	486
entPhysicalChildIndex.442.487	.1.3.6.1.2.1.47.1.3.3.1.1.442.487	Integer	487
entPhysicalChildIndex.442.488	.1.3.6.1.2.1.47.1.3.3.1.1.442.488	Integer	488
entPhysicalChildIndex.442.489	.1.3.6.1.2.1.47.1.3.3.1.1.442.489	Integer	489
entPhysicalChildIndex.442.490	.1.3.6.1.2.1.47.1.3.3.1.1.442.490	Integer	490
entPhysicalChildIndex.442.491	.1.3.6.1.2.1.47.1.3.3.1.1.442.491	Integer	491
entPhysicalChildIndex.442.492	.1.3.6.1.2.1.47.1.3.3.1.1.442.492	Integer	492
entPhysicalChildIndex.442.493	.1.3.6.1.2.1.47.1.3.3.1.1.442.493	Integer	493
entPhysicalChildIndex.442.494	.1.3.6.1.2.1.47.1.3.3.1.1.442.494	Integer	494
entPhysicalChildIndex.442.495	.1.3.6.1.2.1.47.1.3.3.1.1.442.495	Integer	495
entPhysicalChildIndex.442.496	.1.3.6.1.2.1.47.1.3.3.1.1.442.496	Integer	496
entPhysicalChildIndex.442.497	.1.3.6.1.2.1.47.1.3.3.1.1.442.497	Integer	497
entPhysicalChildIndex.442.498	.1.3.6.1.2.1.47.1.3.3.1.1.442.498	Integer	498
entPhysicalChildIndex.442.499	.1.3.6.1.2.1.47.1.3.3.1.1.442.499	Integer	499
entPhysicalChildIndex.442.500	.1.3.6.1.2.1.47.1.3.3.1.1.442.500	Integer	500

Name	OID	Value Type	Value Example
entPhysicalChildIndex.442.501	.1.3.6.1.2.1.47.1.3.3.1.1.442.501	Integer	501
entPhysicalChildIndex.442.502	.1.3.6.1.2.1.47.1.3.3.1.1.442.502	Integer	502
entPhysicalChildIndex.442.503	.1.3.6.1.2.1.47.1.3.3.1.1.442.503	Integer	503
entPhysicalChildIndex.442.504	.1.3.6.1.2.1.47.1.3.3.1.1.442.504	Integer	504
entPhysicalChildIndex.442.505	.1.3.6.1.2.1.47.1.3.3.1.1.442.505	Integer	505
entPhysicalChildIndex.442.506	.1.3.6.1.2.1.47.1.3.3.1.1.442.506	Integer	506
entPhysicalChildIndex.442.507	.1.3.6.1.2.1.47.1.3.3.1.1.442.507	Integer	507
entPhysicalChildIndex.442.508	.1.3.6.1.2.1.47.1.3.3.1.1.442.508	Integer	508
entPhysicalChildIndex.442.509	.1.3.6.1.2.1.47.1.3.3.1.1.442.509	Integer	509
entPhysicalChildIndex.442.510	.1.3.6.1.2.1.47.1.3.3.1.1.442.510	Integer	510
entPhysicalChildIndex.442.511	.1.3.6.1.2.1.47.1.3.3.1.1.442.511	Integer	511
entPhysicalChildIndex.442.512	.1.3.6.1.2.1.47.1.3.3.1.1.442.512	Integer	512
entPhysicalChildIndex.442.513	.1.3.6.1.2.1.47.1.3.3.1.1.442.513	Integer	513
entPhysicalChildIndex.442.514	.1.3.6.1.2.1.47.1.3.3.1.1.442.514	Integer	514
entPhysicalChildIndex.442.515	.1.3.6.1.2.1.47.1.3.3.1.1.442.515	Integer	515
entPhysicalChildIndex.442.516	.1.3.6.1.2.1.47.1.3.3.1.1.442.516	Integer	516
entPhysicalChildIndex.442.517	.1.3.6.1.2.1.47.1.3.3.1.1.442.517	Integer	517
entPhysicalChildIndex.442.518	.1.3.6.1.2.1.47.1.3.3.1.1.442.518	Integer	518
entPhysicalChildIndex.442.519	.1.3.6.1.2.1.47.1.3.3.1.1.442.519	Integer	519
entPhysicalChildIndex.442.520	.1.3.6.1.2.1.47.1.3.3.1.1.442.520	Integer	520
entPhysicalChildIndex.442.521	.1.3.6.1.2.1.47.1.3.3.1.1.442.521	Integer	521
entPhysicalChildIndex.442.522	.1.3.6.1.2.1.47.1.3.3.1.1.442.522	Integer	522
entPhysicalChildIndex.442.523	.1.3.6.1.2.1.47.1.3.3.1.1.442.523	Integer	523
entPhysicalChildIndex.442.524	.1.3.6.1.2.1.47.1.3.3.1.1.442.524	Integer	524
entPhysicalChildIndex.442.525	.1.3.6.1.2.1.47.1.3.3.1.1.442.525	Integer	525
entLastChangeTime.0	.1.3.6.1.2.1.47.1.4.1.0	TimeTicks	0 millisecond (0)
ipv6Forwarding.0	.1.3.6.1.2.1.55.1.1.0	Integer	forwarding (1)
ipv6DefaultHopLimit.0	.1.3.6.1.2.1.55.1.2.0	Integer	64
ipv6Interfaces.0	.1.3.6.1.2.1.55.1.3.0	Gauge	1
ipv6IfTableLastChange.0	.1.3.6.1.2.1.55.1.4.0	TimeTicks	0 millisecond (0)
radiusAuthClientInvalidServerAddresses.0	.1.3.6.1.2.1.67.1.2.1.1.1.0	Counter32	0
radiusAuthClientIdentifier.0	.1.3.6.1.2.1.67.1.2.1.1.2.0	OctetString	INTELBRAS
radiusAccClientInvalidServerAddresses.0	.1.3.6.1.2.1.67.2.2.1.1.1.0	Counter32	0
radiusAccClientIdentifier.0	.1.3.6.1.2.1.67.2.2.1.1.2.0	OctetString	INTELBRAS
pethPsePortAdminEnable.4.1	.1.3.6.1.2.1.105.1.1.1.3.4.1	Integer	true (1)
pethPsePortAdminEnable.4.2	.1.3.6.1.2.1.105.1.1.1.3.4.2	Integer	true (1)
pethPsePortAdminEnable.4.3	.1.3.6.1.2.1.105.1.1.1.3.4.3	Integer	true (1)
pethPsePortAdminEnable.4.4	.1.3.6.1.2.1.105.1.1.1.3.4.4	Integer	true (1)
pethPsePortAdminEnable.4.5	.1.3.6.1.2.1.105.1.1.1.3.4.5	Integer	true (1)
pethPsePortAdminEnable.4.6	.1.3.6.1.2.1.105.1.1.1.3.4.6	Integer	true (1)
pethPsePortAdminEnable.4.7	.1.3.6.1.2.1.105.1.1.1.3.4.7	Integer	true (1)

Name	OID	Value Type	Value Example
pethPsePortAdminEnable.4.8	.1.3.6.1.2.1.105.1.1.1.3.4.8	Integer	true (1)
pethPsePortAdminEnable.4.9	.1.3.6.1.2.1.105.1.1.1.3.4.9	Integer	true (1)
pethPsePortAdminEnable.4.10	.1.3.6.1.2.1.105.1.1.1.3.4.10	Integer	true (1)
pethPsePortAdminEnable.4.11	.1.3.6.1.2.1.105.1.1.1.3.4.11	Integer	true (1)
pethPsePortAdminEnable.4.12	.1.3.6.1.2.1.105.1.1.1.3.4.12	Integer	true (1)
pethPsePortAdminEnable.4.13	.1.3.6.1.2.1.105.1.1.1.3.4.13	Integer	true (1)
pethPsePortAdminEnable.4.14	.1.3.6.1.2.1.105.1.1.1.3.4.14	Integer	true (1)
pethPsePortAdminEnable.4.15	.1.3.6.1.2.1.105.1.1.1.3.4.15	Integer	true (1)
pethPsePortAdminEnable.4.16	.1.3.6.1.2.1.105.1.1.1.3.4.16	Integer	true (1)
pethPsePortAdminEnable.4.17	.1.3.6.1.2.1.105.1.1.1.3.4.17	Integer	true (1)
pethPsePortAdminEnable.4.18	.1.3.6.1.2.1.105.1.1.1.3.4.18	Integer	true (1)
pethPsePortAdminEnable.4.19	.1.3.6.1.2.1.105.1.1.1.3.4.19	Integer	true (1)
pethPsePortAdminEnable.4.20	.1.3.6.1.2.1.105.1.1.1.3.4.20	Integer	true (1)
pethPsePortAdminEnable.4.21	.1.3.6.1.2.1.105.1.1.1.3.4.21	Integer	true (1)
pethPsePortAdminEnable.4.22	.1.3.6.1.2.1.105.1.1.1.3.4.22	Integer	true (1)
pethPsePortAdminEnable.4.23	.1.3.6.1.2.1.105.1.1.1.3.4.23	Integer	true (1)
pethPsePortAdminEnable.4.24	.1.3.6.1.2.1.105.1.1.1.3.4.24	Integer	true (1)
pethPsePortAdminEnable.4.25	.1.3.6.1.2.1.105.1.1.1.3.4.25	Integer	true (1)
pethPsePortAdminEnable.4.26	.1.3.6.1.2.1.105.1.1.1.3.4.26	Integer	true (1)
pethPsePortAdminEnable.4.27	.1.3.6.1.2.1.105.1.1.1.3.4.27	Integer	true (1)
pethPsePortAdminEnable.4.28	.1.3.6.1.2.1.105.1.1.1.3.4.28	Integer	true (1)
pethPsePortAdminEnable.4.29	.1.3.6.1.2.1.105.1.1.1.3.4.29	Integer	true (1)
pethPsePortAdminEnable.4.30	.1.3.6.1.2.1.105.1.1.1.3.4.30	Integer	true (1)
pethPsePortAdminEnable.4.31	.1.3.6.1.2.1.105.1.1.1.3.4.31	Integer	true (1)
pethPsePortAdminEnable.4.32	.1.3.6.1.2.1.105.1.1.1.3.4.32	Integer	true (1)
pethPsePortAdminEnable.4.33	.1.3.6.1.2.1.105.1.1.1.3.4.33	Integer	true (1)
pethPsePortAdminEnable.4.34	.1.3.6.1.2.1.105.1.1.1.3.4.34	Integer	true (1)
pethPsePortAdminEnable.4.35	.1.3.6.1.2.1.105.1.1.1.3.4.35	Integer	true (1)
pethPsePortAdminEnable.4.36	.1.3.6.1.2.1.105.1.1.1.3.4.36	Integer	true (1)
pethPsePortAdminEnable.4.37	.1.3.6.1.2.1.105.1.1.1.3.4.37	Integer	true (1)
pethPsePortAdminEnable.4.38	.1.3.6.1.2.1.105.1.1.1.3.4.38	Integer	true (1)
pethPsePortAdminEnable.4.39	.1.3.6.1.2.1.105.1.1.1.3.4.39	Integer	true (1)
pethPsePortAdminEnable.4.40	.1.3.6.1.2.1.105.1.1.1.3.4.40	Integer	true (1)
pethPsePortAdminEnable.4.41	.1.3.6.1.2.1.105.1.1.1.3.4.41	Integer	true (1)
pethPsePortAdminEnable.4.42	.1.3.6.1.2.1.105.1.1.1.3.4.42	Integer	true (1)
pethPsePortAdminEnable.4.43	.1.3.6.1.2.1.105.1.1.1.3.4.43	Integer	true (1)
pethPsePortAdminEnable.4.44	.1.3.6.1.2.1.105.1.1.1.3.4.44	Integer	true (1)
pethPsePortAdminEnable.4.45	.1.3.6.1.2.1.105.1.1.1.3.4.45	Integer	true (1)
pethPsePortAdminEnable.4.46	.1.3.6.1.2.1.105.1.1.1.3.4.46	Integer	true (1)
pethPsePortAdminEnable.4.47	.1.3.6.1.2.1.105.1.1.1.3.4.47	Integer	true (1)
pethPsePortAdminEnable.4.48	.1.3.6.1.2.1.105.1.1.1.3.4.48	Integer	true (1)
pethPsePortPowerPairsControlAbility.4.1	.1.3.6.1.2.1.105.1.1.1.4.4.1	Integer	false (2)

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
pethPsePortPowerPairsControlAbility.4.2	.1.3.6.1.2.1.105.1.1.1.4.4.2	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.3	.1.3.6.1.2.1.105.1.1.1.4.4.3	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.4	.1.3.6.1.2.1.105.1.1.1.4.4.4	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.5	.1.3.6.1.2.1.105.1.1.1.4.4.5	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.6	.1.3.6.1.2.1.105.1.1.1.4.4.6	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.7	.1.3.6.1.2.1.105.1.1.1.4.4.7	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.8	.1.3.6.1.2.1.105.1.1.1.4.4.8	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.9	.1.3.6.1.2.1.105.1.1.1.4.4.9	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.10	.1.3.6.1.2.1.105.1.1.1.4.4.10	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.11	.1.3.6.1.2.1.105.1.1.1.4.4.11	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.12	.1.3.6.1.2.1.105.1.1.1.4.4.12	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.13	.1.3.6.1.2.1.105.1.1.1.4.4.13	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.14	.1.3.6.1.2.1.105.1.1.1.4.4.14	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.15	.1.3.6.1.2.1.105.1.1.1.4.4.15	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.16	.1.3.6.1.2.1.105.1.1.1.4.4.16	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.17	.1.3.6.1.2.1.105.1.1.1.4.4.17	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.18	.1.3.6.1.2.1.105.1.1.1.4.4.18	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.19	.1.3.6.1.2.1.105.1.1.1.4.4.19	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.20	.1.3.6.1.2.1.105.1.1.1.4.4.20	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.21	.1.3.6.1.2.1.105.1.1.1.4.4.21	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.22	.1.3.6.1.2.1.105.1.1.1.4.4.22	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.23	.1.3.6.1.2.1.105.1.1.1.4.4.23	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.24	.1.3.6.1.2.1.105.1.1.1.4.4.24	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.25	.1.3.6.1.2.1.105.1.1.1.4.4.25	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.26	.1.3.6.1.2.1.105.1.1.1.4.4.26	Integer	false (2)

Name	OID	Value Type	Value Example
pethPsePortPowerPairsControlAbility.4.27	.1.3.6.1.2.1.105.1.1.1.4.4.27	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.28	.1.3.6.1.2.1.105.1.1.1.4.4.28	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.29	.1.3.6.1.2.1.105.1.1.1.4.4.29	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.30	.1.3.6.1.2.1.105.1.1.1.4.4.30	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.31	.1.3.6.1.2.1.105.1.1.1.4.4.31	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.32	.1.3.6.1.2.1.105.1.1.1.4.4.32	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.33	.1.3.6.1.2.1.105.1.1.1.4.4.33	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.34	.1.3.6.1.2.1.105.1.1.1.4.4.34	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.35	.1.3.6.1.2.1.105.1.1.1.4.4.35	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.36	.1.3.6.1.2.1.105.1.1.1.4.4.36	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.37	.1.3.6.1.2.1.105.1.1.1.4.4.37	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.38	.1.3.6.1.2.1.105.1.1.1.4.4.38	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.39	.1.3.6.1.2.1.105.1.1.1.4.4.39	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.40	.1.3.6.1.2.1.105.1.1.1.4.4.40	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.41	.1.3.6.1.2.1.105.1.1.1.4.4.41	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.42	.1.3.6.1.2.1.105.1.1.1.4.4.42	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.43	.1.3.6.1.2.1.105.1.1.1.4.4.43	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.44	.1.3.6.1.2.1.105.1.1.1.4.4.44	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.45	.1.3.6.1.2.1.105.1.1.1.4.4.45	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.46	.1.3.6.1.2.1.105.1.1.1.4.4.46	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.47	.1.3.6.1.2.1.105.1.1.1.4.4.47	Integer	false (2)
pethPsePortPowerPairsControlAbility.4.48	.1.3.6.1.2.1.105.1.1.1.4.4.48	Integer	false (2)
pethPsePortPowerPairs.4.1	.1.3.6.1.2.1.105.1.1.1.5.4.1	Integer	signal (1)
pethPsePortPowerPairs.4.2	.1.3.6.1.2.1.105.1.1.1.5.4.2	Integer	signal (1)
pethPsePortPowerPairs.4.3	.1.3.6.1.2.1.105.1.1.1.5.4.3	Integer	signal (1)
pethPsePortPowerPairs.4.4	.1.3.6.1.2.1.105.1.1.1.5.4.4	Integer	signal (1)
pethPsePortPowerPairs.4.5	.1.3.6.1.2.1.105.1.1.1.5.4.5	Integer	signal (1)
pethPsePortPowerPairs.4.6	.1.3.6.1.2.1.105.1.1.1.5.4.6	Integer	signal (1)

Name	OID	Value Type	Value Example
pethPsePortPowerPairs.4.7	.1.3.6.1.2.1.105.1.1.1.5.4.7	Integer	signal (1)
pethPsePortPowerPairs.4.8	.1.3.6.1.2.1.105.1.1.1.5.4.8	Integer	signal (1)
pethPsePortPowerPairs.4.9	.1.3.6.1.2.1.105.1.1.1.5.4.9	Integer	signal (1)
pethPsePortPowerPairs.4.10	.1.3.6.1.2.1.105.1.1.1.5.4.10	Integer	signal (1)
pethPsePortPowerPairs.4.11	.1.3.6.1.2.1.105.1.1.1.5.4.11	Integer	signal (1)
pethPsePortPowerPairs.4.12	.1.3.6.1.2.1.105.1.1.1.5.4.12	Integer	signal (1)
pethPsePortPowerPairs.4.13	.1.3.6.1.2.1.105.1.1.1.5.4.13	Integer	signal (1)
pethPsePortPowerPairs.4.14	.1.3.6.1.2.1.105.1.1.1.5.4.14	Integer	signal (1)
pethPsePortPowerPairs.4.15	.1.3.6.1.2.1.105.1.1.1.5.4.15	Integer	signal (1)
pethPsePortPowerPairs.4.16	.1.3.6.1.2.1.105.1.1.1.5.4.16	Integer	signal (1)
pethPsePortPowerPairs.4.17	.1.3.6.1.2.1.105.1.1.1.5.4.17	Integer	signal (1)
pethPsePortPowerPairs.4.18	.1.3.6.1.2.1.105.1.1.1.5.4.18	Integer	signal (1)
pethPsePortPowerPairs.4.19	.1.3.6.1.2.1.105.1.1.1.5.4.19	Integer	signal (1)
pethPsePortPowerPairs.4.20	.1.3.6.1.2.1.105.1.1.1.5.4.20	Integer	signal (1)
pethPsePortPowerPairs.4.21	.1.3.6.1.2.1.105.1.1.1.5.4.21	Integer	signal (1)
pethPsePortPowerPairs.4.22	.1.3.6.1.2.1.105.1.1.1.5.4.22	Integer	signal (1)
pethPsePortPowerPairs.4.23	.1.3.6.1.2.1.105.1.1.1.5.4.23	Integer	signal (1)
pethPsePortPowerPairs.4.24	.1.3.6.1.2.1.105.1.1.1.5.4.24	Integer	signal (1)
pethPsePortPowerPairs.4.25	.1.3.6.1.2.1.105.1.1.1.5.4.25	Integer	signal (1)
pethPsePortPowerPairs.4.26	.1.3.6.1.2.1.105.1.1.1.5.4.26	Integer	signal (1)
pethPsePortPowerPairs.4.27	.1.3.6.1.2.1.105.1.1.1.5.4.27	Integer	signal (1)
pethPsePortPowerPairs.4.28	.1.3.6.1.2.1.105.1.1.1.5.4.28	Integer	signal (1)
pethPsePortPowerPairs.4.29	.1.3.6.1.2.1.105.1.1.1.5.4.29	Integer	signal (1)
pethPsePortPowerPairs.4.30	.1.3.6.1.2.1.105.1.1.1.5.4.30	Integer	signal (1)
pethPsePortPowerPairs.4.31	.1.3.6.1.2.1.105.1.1.1.5.4.31	Integer	signal (1)
pethPsePortPowerPairs.4.32	.1.3.6.1.2.1.105.1.1.1.5.4.32	Integer	signal (1)
pethPsePortPowerPairs.4.33	.1.3.6.1.2.1.105.1.1.1.5.4.33	Integer	signal (1)
pethPsePortPowerPairs.4.34	.1.3.6.1.2.1.105.1.1.1.5.4.34	Integer	signal (1)
pethPsePortPowerPairs.4.35	.1.3.6.1.2.1.105.1.1.1.5.4.35	Integer	signal (1)
pethPsePortPowerPairs.4.36	.1.3.6.1.2.1.105.1.1.1.5.4.36	Integer	signal (1)
pethPsePortPowerPairs.4.37	.1.3.6.1.2.1.105.1.1.1.5.4.37	Integer	signal (1)
pethPsePortPowerPairs.4.38	.1.3.6.1.2.1.105.1.1.1.5.4.38	Integer	signal (1)
pethPsePortPowerPairs.4.39	.1.3.6.1.2.1.105.1.1.1.5.4.39	Integer	signal (1)
pethPsePortPowerPairs.4.40	.1.3.6.1.2.1.105.1.1.1.5.4.40	Integer	signal (1)
pethPsePortPowerPairs.4.41	.1.3.6.1.2.1.105.1.1.1.5.4.41	Integer	signal (1)
pethPsePortPowerPairs.4.42	.1.3.6.1.2.1.105.1.1.1.5.4.42	Integer	signal (1)
pethPsePortPowerPairs.4.43	.1.3.6.1.2.1.105.1.1.1.5.4.43	Integer	signal (1)
pethPsePortPowerPairs.4.44	.1.3.6.1.2.1.105.1.1.1.5.4.44	Integer	signal (1)
pethPsePortPowerPairs.4.45	.1.3.6.1.2.1.105.1.1.1.5.4.45	Integer	signal (1)
pethPsePortPowerPairs.4.46	.1.3.6.1.2.1.105.1.1.1.5.4.46	Integer	signal (1)
pethPsePortPowerPairs.4.47	.1.3.6.1.2.1.105.1.1.1.5.4.47	Integer	signal (1)
pethPsePortPowerPairs.4.48	.1.3.6.1.2.1.105.1.1.1.5.4.48	Integer	signal (1)



Name	OID	Value Type	Value Example
pethPsePortDetectionStatus.4.1	.1.3.6.1.2.1.105.1.1.1.6.4.1	Integer	searching (2)
pethPsePortDetectionStatus.4.2	.1.3.6.1.2.1.105.1.1.1.6.4.2	Integer	searching (2)
pethPsePortDetectionStatus.4.3	.1.3.6.1.2.1.105.1.1.1.6.4.3	Integer	searching (2)
pethPsePortDetectionStatus.4.4	.1.3.6.1.2.1.105.1.1.1.6.4.4	Integer	searching (2)
pethPsePortDetectionStatus.4.5	.1.3.6.1.2.1.105.1.1.1.6.4.5	Integer	searching (2)
pethPsePortDetectionStatus.4.6	.1.3.6.1.2.1.105.1.1.1.6.4.6	Integer	searching (2)
pethPsePortDetectionStatus.4.7	.1.3.6.1.2.1.105.1.1.1.6.4.7	Integer	searching (2)
pethPsePortDetectionStatus.4.8	.1.3.6.1.2.1.105.1.1.1.6.4.8	Integer	searching (2)
pethPsePortDetectionStatus.4.9	.1.3.6.1.2.1.105.1.1.1.6.4.9	Integer	searching (2)
pethPsePortDetectionStatus.4.10	.1.3.6.1.2.1.105.1.1.1.6.4.10	Integer	searching (2)
pethPsePortDetectionStatus.4.11	.1.3.6.1.2.1.105.1.1.1.6.4.11	Integer	searching (2)
pethPsePortDetectionStatus.4.12	.1.3.6.1.2.1.105.1.1.1.6.4.12	Integer	searching (2)
pethPsePortDetectionStatus.4.13	.1.3.6.1.2.1.105.1.1.1.6.4.13	Integer	searching (2)
pethPsePortDetectionStatus.4.14	.1.3.6.1.2.1.105.1.1.1.6.4.14	Integer	searching (2)
pethPsePortDetectionStatus.4.15	.1.3.6.1.2.1.105.1.1.1.6.4.15	Integer	searching (2)
pethPsePortDetectionStatus.4.16	.1.3.6.1.2.1.105.1.1.1.6.4.16	Integer	searching (2)
pethPsePortDetectionStatus.4.17	.1.3.6.1.2.1.105.1.1.1.6.4.17	Integer	searching (2)
pethPsePortDetectionStatus.4.18	.1.3.6.1.2.1.105.1.1.1.6.4.18	Integer	searching (2)
pethPsePortDetectionStatus.4.19	.1.3.6.1.2.1.105.1.1.1.6.4.19	Integer	searching (2)
pethPsePortDetectionStatus.4.20	.1.3.6.1.2.1.105.1.1.1.6.4.20	Integer	searching (2)
pethPsePortDetectionStatus.4.21	.1.3.6.1.2.1.105.1.1.1.6.4.21	Integer	searching (2)
pethPsePortDetectionStatus.4.22	.1.3.6.1.2.1.105.1.1.1.6.4.22	Integer	searching (2)
pethPsePortDetectionStatus.4.23	.1.3.6.1.2.1.105.1.1.1.6.4.23	Integer	searching (2)
pethPsePortDetectionStatus.4.24	.1.3.6.1.2.1.105.1.1.1.6.4.24	Integer	searching (2)
pethPsePortDetectionStatus.4.25	.1.3.6.1.2.1.105.1.1.1.6.4.25	Integer	searching (2)

Name	OID	Value Type	Value Example
pethPsePortDetectionStatus.4.26	.1.3.6.1.2.1.105.1.1.1.6.4.26	Integer	searching (2)
pethPsePortDetectionStatus.4.27	.1.3.6.1.2.1.105.1.1.1.6.4.27	Integer	searching (2)
pethPsePortDetectionStatus.4.28	.1.3.6.1.2.1.105.1.1.1.6.4.28	Integer	searching (2)
pethPsePortDetectionStatus.4.29	.1.3.6.1.2.1.105.1.1.1.6.4.29	Integer	searching (2)
pethPsePortDetectionStatus.4.30	.1.3.6.1.2.1.105.1.1.1.6.4.30	Integer	searching (2)
pethPsePortDetectionStatus.4.31	.1.3.6.1.2.1.105.1.1.1.6.4.31	Integer	searching (2)
pethPsePortDetectionStatus.4.32	.1.3.6.1.2.1.105.1.1.1.6.4.32	Integer	searching (2)
pethPsePortDetectionStatus.4.33	.1.3.6.1.2.1.105.1.1.1.6.4.33	Integer	searching (2)
pethPsePortDetectionStatus.4.34	.1.3.6.1.2.1.105.1.1.1.6.4.34	Integer	searching (2)
pethPsePortDetectionStatus.4.35	.1.3.6.1.2.1.105.1.1.1.6.4.35	Integer	searching (2)
pethPsePortDetectionStatus.4.36	.1.3.6.1.2.1.105.1.1.1.6.4.36	Integer	searching (2)
pethPsePortDetectionStatus.4.37	.1.3.6.1.2.1.105.1.1.1.6.4.37	Integer	searching (2)
pethPsePortDetectionStatus.4.38	.1.3.6.1.2.1.105.1.1.1.6.4.38	Integer	searching (2)
pethPsePortDetectionStatus.4.39	.1.3.6.1.2.1.105.1.1.1.6.4.39	Integer	searching (2)
pethPsePortDetectionStatus.4.40	.1.3.6.1.2.1.105.1.1.1.6.4.40	Integer	searching (2)
pethPsePortDetectionStatus.4.41	.1.3.6.1.2.1.105.1.1.1.6.4.41	Integer	searching (2)
pethPsePortDetectionStatus.4.42	.1.3.6.1.2.1.105.1.1.1.6.4.42	Integer	searching (2)
pethPsePortDetectionStatus.4.43	.1.3.6.1.2.1.105.1.1.1.6.4.43	Integer	searching (2)
pethPsePortDetectionStatus.4.44	.1.3.6.1.2.1.105.1.1.1.6.4.44	Integer	searching (2)
pethPsePortDetectionStatus.4.45	.1.3.6.1.2.1.105.1.1.1.6.4.45	Integer	searching (2)
pethPsePortDetectionStatus.4.46	.1.3.6.1.2.1.105.1.1.1.6.4.46	Integer	searching (2)
pethPsePortDetectionStatus.4.47	.1.3.6.1.2.1.105.1.1.1.6.4.47	Integer	searching (2)
pethPsePortDetectionStatus.4.48	.1.3.6.1.2.1.105.1.1.1.6.4.48	Integer	searching (2)
pethPsePortPowerPriority.4.1	.1.3.6.1.2.1.105.1.1.1.7.4.1	Integer	low (3)
pethPsePortPowerPriority.4.2	.1.3.6.1.2.1.105.1.1.1.7.4.2	Integer	low (3)
pethPsePortPowerPriority.4.3	.1.3.6.1.2.1.105.1.1.1.7.4.3	Integer	low (3)
pethPsePortPowerPriority.4.4	.1.3.6.1.2.1.105.1.1.1.7.4.4	Integer	low (3)

Name	OID	Value Type	Value Example
pethPsePortPowerPriority.4.5	.1.3.6.1.2.1.105.1.1.1.7.4.5	Integer	low (3)
pethPsePortPowerPriority.4.6	.1.3.6.1.2.1.105.1.1.1.7.4.6	Integer	low (3)
pethPsePortPowerPriority.4.7	.1.3.6.1.2.1.105.1.1.1.7.4.7	Integer	low (3)
pethPsePortPowerPriority.4.8	.1.3.6.1.2.1.105.1.1.1.7.4.8	Integer	low (3)
pethPsePortPowerPriority.4.9	.1.3.6.1.2.1.105.1.1.1.7.4.9	Integer	low (3)
pethPsePortPowerPriority.4.10	.1.3.6.1.2.1.105.1.1.1.7.4.10	Integer	low (3)
pethPsePortPowerPriority.4.11	.1.3.6.1.2.1.105.1.1.1.7.4.11	Integer	low (3)
pethPsePortPowerPriority.4.12	.1.3.6.1.2.1.105.1.1.1.7.4.12	Integer	low (3)
pethPsePortPowerPriority.4.13	.1.3.6.1.2.1.105.1.1.1.7.4.13	Integer	low (3)
pethPsePortPowerPriority.4.14	.1.3.6.1.2.1.105.1.1.1.7.4.14	Integer	low (3)
pethPsePortPowerPriority.4.15	.1.3.6.1.2.1.105.1.1.1.7.4.15	Integer	low (3)
pethPsePortPowerPriority.4.16	.1.3.6.1.2.1.105.1.1.1.7.4.16	Integer	low (3)
pethPsePortPowerPriority.4.17	.1.3.6.1.2.1.105.1.1.1.7.4.17	Integer	low (3)
pethPsePortPowerPriority.4.18	.1.3.6.1.2.1.105.1.1.1.7.4.18	Integer	low (3)
pethPsePortPowerPriority.4.19	.1.3.6.1.2.1.105.1.1.1.7.4.19	Integer	low (3)
pethPsePortPowerPriority.4.20	.1.3.6.1.2.1.105.1.1.1.7.4.20	Integer	low (3)
pethPsePortPowerPriority.4.21	.1.3.6.1.2.1.105.1.1.1.7.4.21	Integer	low (3)
pethPsePortPowerPriority.4.22	.1.3.6.1.2.1.105.1.1.1.7.4.22	Integer	low (3)
pethPsePortPowerPriority.4.23	.1.3.6.1.2.1.105.1.1.1.7.4.23	Integer	low (3)
pethPsePortPowerPriority.4.24	.1.3.6.1.2.1.105.1.1.1.7.4.24	Integer	low (3)
pethPsePortPowerPriority.4.25	.1.3.6.1.2.1.105.1.1.1.7.4.25	Integer	low (3)
pethPsePortPowerPriority.4.26	.1.3.6.1.2.1.105.1.1.1.7.4.26	Integer	low (3)
pethPsePortPowerPriority.4.27	.1.3.6.1.2.1.105.1.1.1.7.4.27	Integer	low (3)
pethPsePortPowerPriority.4.28	.1.3.6.1.2.1.105.1.1.1.7.4.28	Integer	low (3)
pethPsePortPowerPriority.4.29	.1.3.6.1.2.1.105.1.1.1.7.4.29	Integer	low (3)
pethPsePortPowerPriority.4.30	.1.3.6.1.2.1.105.1.1.1.7.4.30	Integer	low (3)
pethPsePortPowerPriority.4.31	.1.3.6.1.2.1.105.1.1.1.7.4.31	Integer	low (3)
pethPsePortPowerPriority.4.32	.1.3.6.1.2.1.105.1.1.1.7.4.32	Integer	low (3)
pethPsePortPowerPriority.4.33	.1.3.6.1.2.1.105.1.1.1.7.4.33	Integer	low (3)
pethPsePortPowerPriority.4.34	.1.3.6.1.2.1.105.1.1.1.7.4.34	Integer	low (3)
pethPsePortPowerPriority.4.35	.1.3.6.1.2.1.105.1.1.1.7.4.35	Integer	low (3)
pethPsePortPowerPriority.4.36	.1.3.6.1.2.1.105.1.1.1.7.4.36	Integer	low (3)
pethPsePortPowerPriority.4.37	.1.3.6.1.2.1.105.1.1.1.7.4.37	Integer	low (3)
pethPsePortPowerPriority.4.38	.1.3.6.1.2.1.105.1.1.1.7.4.38	Integer	low (3)
pethPsePortPowerPriority.4.39	.1.3.6.1.2.1.105.1.1.1.7.4.39	Integer	low (3)
pethPsePortPowerPriority.4.40	.1.3.6.1.2.1.105.1.1.1.7.4.40	Integer	low (3)
pethPsePortPowerPriority.4.41	.1.3.6.1.2.1.105.1.1.1.7.4.41	Integer	low (3)
pethPsePortPowerPriority.4.42	.1.3.6.1.2.1.105.1.1.1.7.4.42	Integer	low (3)
pethPsePortPowerPriority.4.43	.1.3.6.1.2.1.105.1.1.1.7.4.43	Integer	low (3)
pethPsePortPowerPriority.4.44	.1.3.6.1.2.1.105.1.1.1.7.4.44	Integer	low (3)
pethPsePortPowerPriority.4.45	.1.3.6.1.2.1.105.1.1.1.7.4.45	Integer	low (3)
pethPsePortPowerPriority.4.46	.1.3.6.1.2.1.105.1.1.1.7.4.46	Integer	low (3)
pethPsePortPowerPriority.4.47	.1.3.6.1.2.1.105.1.1.1.7.4.47	Integer	low (3)

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
pethPsePortPowerPriority.4.48	.1.3.6.1.2.1.105.1.1.1.7.4.48	Integer	low (3)
pethPsePortMPSAbsentCounter.4.1	.1.3.6.1.2.1.105.1.1.1.8.4.1	Counter32	0
pethPsePortMPSAbsentCounter.4.2	.1.3.6.1.2.1.105.1.1.1.8.4.2	Counter32	0
pethPsePortMPSAbsentCounter.4.3	.1.3.6.1.2.1.105.1.1.1.8.4.3	Counter32	0
pethPsePortMPSAbsentCounter.4.4	.1.3.6.1.2.1.105.1.1.1.8.4.4	Counter32	0
pethPsePortMPSAbsentCounter.4.5	.1.3.6.1.2.1.105.1.1.1.8.4.5	Counter32	0
pethPsePortMPSAbsentCounter.4.6	.1.3.6.1.2.1.105.1.1.1.8.4.6	Counter32	0
pethPsePortMPSAbsentCounter.4.7	.1.3.6.1.2.1.105.1.1.1.8.4.7	Counter32	0
pethPsePortMPSAbsentCounter.4.8	.1.3.6.1.2.1.105.1.1.1.8.4.8	Counter32	0
pethPsePortMPSAbsentCounter.4.9	.1.3.6.1.2.1.105.1.1.1.8.4.9	Counter32	0
pethPsePortMPSAbsentCounter.4.10	.1.3.6.1.2.1.105.1.1.1.8.4.10	Counter32	0
pethPsePortMPSAbsentCounter.4.11	.1.3.6.1.2.1.105.1.1.1.8.4.11	Counter32	0
pethPsePortMPSAbsentCounter.4.12	.1.3.6.1.2.1.105.1.1.1.8.4.12	Counter32	0
pethPsePortMPSAbsentCounter.4.13	.1.3.6.1.2.1.105.1.1.1.8.4.13	Counter32	0
pethPsePortMPSAbsentCounter.4.14	.1.3.6.1.2.1.105.1.1.1.8.4.14	Counter32	0
pethPsePortMPSAbsentCounter.4.15	.1.3.6.1.2.1.105.1.1.1.8.4.15	Counter32	0
pethPsePortMPSAbsentCounter.4.16	.1.3.6.1.2.1.105.1.1.1.8.4.16	Counter32	0
pethPsePortMPSAbsentCounter.4.17	.1.3.6.1.2.1.105.1.1.1.8.4.17	Counter32	0
pethPsePortMPSAbsentCounter.4.18	.1.3.6.1.2.1.105.1.1.1.8.4.18	Counter32	0
pethPsePortMPSAbsentCounter.4.19	.1.3.6.1.2.1.105.1.1.1.8.4.19	Counter32	0
pethPsePortMPSAbsentCounter.4.20	.1.3.6.1.2.1.105.1.1.1.8.4.20	Counter32	0
pethPsePortMPSAbsentCounter.4.21	.1.3.6.1.2.1.105.1.1.1.8.4.21	Counter32	0
pethPsePortMPSAbsentCounter.4.22	.1.3.6.1.2.1.105.1.1.1.8.4.22	Counter32	0
pethPsePortMPSAbsentCounter.4.23	.1.3.6.1.2.1.105.1.1.1.8.4.23	Counter32	0
pethPsePortMPSAbsentCounter.4.24	.1.3.6.1.2.1.105.1.1.1.8.4.24	Counter32	0
pethPsePortMPSAbsentCounter.4.25	.1.3.6.1.2.1.105.1.1.1.8.4.25	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
pethPsePortMPSAbsentCounter.4.26	.1.3.6.1.2.1.105.1.1.1.8.4.26	Counter32	0
pethPsePortMPSAbsentCounter.4.27	.1.3.6.1.2.1.105.1.1.1.8.4.27	Counter32	0
pethPsePortMPSAbsentCounter.4.28	.1.3.6.1.2.1.105.1.1.1.8.4.28	Counter32	0
pethPsePortMPSAbsentCounter.4.29	.1.3.6.1.2.1.105.1.1.1.8.4.29	Counter32	0
pethPsePortMPSAbsentCounter.4.30	.1.3.6.1.2.1.105.1.1.1.8.4.30	Counter32	0
pethPsePortMPSAbsentCounter.4.31	.1.3.6.1.2.1.105.1.1.1.8.4.31	Counter32	0
pethPsePortMPSAbsentCounter.4.32	.1.3.6.1.2.1.105.1.1.1.8.4.32	Counter32	0
pethPsePortMPSAbsentCounter.4.33	.1.3.6.1.2.1.105.1.1.1.8.4.33	Counter32	0
pethPsePortMPSAbsentCounter.4.34	.1.3.6.1.2.1.105.1.1.1.8.4.34	Counter32	0
pethPsePortMPSAbsentCounter.4.35	.1.3.6.1.2.1.105.1.1.1.8.4.35	Counter32	0
pethPsePortMPSAbsentCounter.4.36	.1.3.6.1.2.1.105.1.1.1.8.4.36	Counter32	0
pethPsePortMPSAbsentCounter.4.37	.1.3.6.1.2.1.105.1.1.1.8.4.37	Counter32	0
pethPsePortMPSAbsentCounter.4.38	.1.3.6.1.2.1.105.1.1.1.8.4.38	Counter32	0
pethPsePortMPSAbsentCounter.4.39	.1.3.6.1.2.1.105.1.1.1.8.4.39	Counter32	0
pethPsePortMPSAbsentCounter.4.40	.1.3.6.1.2.1.105.1.1.1.8.4.40	Counter32	0
pethPsePortMPSAbsentCounter.4.41	.1.3.6.1.2.1.105.1.1.1.8.4.41	Counter32	0
pethPsePortMPSAbsentCounter.4.42	.1.3.6.1.2.1.105.1.1.1.8.4.42	Counter32	0
pethPsePortMPSAbsentCounter.4.43	.1.3.6.1.2.1.105.1.1.1.8.4.43	Counter32	0
pethPsePortMPSAbsentCounter.4.44	.1.3.6.1.2.1.105.1.1.1.8.4.44	Counter32	0
pethPsePortMPSAbsentCounter.4.45	.1.3.6.1.2.1.105.1.1.1.8.4.45	Counter32	0
pethPsePortMPSAbsentCounter.4.46	.1.3.6.1.2.1.105.1.1.1.8.4.46	Counter32	0
pethPsePortMPSAbsentCounter.4.47	.1.3.6.1.2.1.105.1.1.1.8.4.47	Counter32	0
pethPsePortMPSAbsentCounter.4.48	.1.3.6.1.2.1.105.1.1.1.8.4.48	Counter32	0
pethPsePortType.4.1	.1.3.6.1.2.1.105.1.1.1.9.4.1	OctetString	
pethPsePortType.4.2	.1.3.6.1.2.1.105.1.1.1.9.4.2	OctetString	
pethPsePortType.4.3	.1.3.6.1.2.1.105.1.1.1.9.4.3	OctetString	
pethPsePortType.4.4	.1.3.6.1.2.1.105.1.1.1.9.4.4	OctetString	

Name	OID	Value Type	Value Example
pethPsePortType.4.5	.1.3.6.1.2.1.105.1.1.1.9.4.5	OctetString	
pethPsePortType.4.6	.1.3.6.1.2.1.105.1.1.1.9.4.6	OctetString	
pethPsePortType.4.7	.1.3.6.1.2.1.105.1.1.1.9.4.7	OctetString	
pethPsePortType.4.8	.1.3.6.1.2.1.105.1.1.1.9.4.8	OctetString	
pethPsePortType.4.9	.1.3.6.1.2.1.105.1.1.1.9.4.9	OctetString	
pethPsePortType.4.10	.1.3.6.1.2.1.105.1.1.1.9.4.10	OctetString	
pethPsePortType.4.11	.1.3.6.1.2.1.105.1.1.1.9.4.11	OctetString	
pethPsePortType.4.12	.1.3.6.1.2.1.105.1.1.1.9.4.12	OctetString	
pethPsePortType.4.13	.1.3.6.1.2.1.105.1.1.1.9.4.13	OctetString	
pethPsePortType.4.14	.1.3.6.1.2.1.105.1.1.1.9.4.14	OctetString	
pethPsePortType.4.15	.1.3.6.1.2.1.105.1.1.1.9.4.15	OctetString	
pethPsePortType.4.16	.1.3.6.1.2.1.105.1.1.1.9.4.16	OctetString	
pethPsePortType.4.17	.1.3.6.1.2.1.105.1.1.1.9.4.17	OctetString	
pethPsePortType.4.18	.1.3.6.1.2.1.105.1.1.1.9.4.18	OctetString	
pethPsePortType.4.19	.1.3.6.1.2.1.105.1.1.1.9.4.19	OctetString	
pethPsePortType.4.20	.1.3.6.1.2.1.105.1.1.1.9.4.20	OctetString	
pethPsePortType.4.21	.1.3.6.1.2.1.105.1.1.1.9.4.21	OctetString	
pethPsePortType.4.22	.1.3.6.1.2.1.105.1.1.1.9.4.22	OctetString	
pethPsePortType.4.23	.1.3.6.1.2.1.105.1.1.1.9.4.23	OctetString	
pethPsePortType.4.24	.1.3.6.1.2.1.105.1.1.1.9.4.24	OctetString	
pethPsePortType.4.25	.1.3.6.1.2.1.105.1.1.1.9.4.25	OctetString	
pethPsePortType.4.26	.1.3.6.1.2.1.105.1.1.1.9.4.26	OctetString	
pethPsePortType.4.27	.1.3.6.1.2.1.105.1.1.1.9.4.27	OctetString	
pethPsePortType.4.28	.1.3.6.1.2.1.105.1.1.1.9.4.28	OctetString	
pethPsePortType.4.29	.1.3.6.1.2.1.105.1.1.1.9.4.29	OctetString	
pethPsePortType.4.30	.1.3.6.1.2.1.105.1.1.1.9.4.30	OctetString	
pethPsePortType.4.31	.1.3.6.1.2.1.105.1.1.1.9.4.31	OctetString	
pethPsePortType.4.32	.1.3.6.1.2.1.105.1.1.1.9.4.32	OctetString	
pethPsePortType.4.33	.1.3.6.1.2.1.105.1.1.1.9.4.33	OctetString	
pethPsePortType.4.34	.1.3.6.1.2.1.105.1.1.1.9.4.34	OctetString	
pethPsePortType.4.35	.1.3.6.1.2.1.105.1.1.1.9.4.35	OctetString	
pethPsePortType.4.36	.1.3.6.1.2.1.105.1.1.1.9.4.36	OctetString	
pethPsePortType.4.37	.1.3.6.1.2.1.105.1.1.1.9.4.37	OctetString	
pethPsePortType.4.38	.1.3.6.1.2.1.105.1.1.1.9.4.38	OctetString	
pethPsePortType.4.39	.1.3.6.1.2.1.105.1.1.1.9.4.39	OctetString	
pethPsePortType.4.40	.1.3.6.1.2.1.105.1.1.1.9.4.40	OctetString	
pethPsePortType.4.41	.1.3.6.1.2.1.105.1.1.1.9.4.41	OctetString	
pethPsePortType.4.42	.1.3.6.1.2.1.105.1.1.1.9.4.42	OctetString	
pethPsePortType.4.43	.1.3.6.1.2.1.105.1.1.1.9.4.43	OctetString	
pethPsePortType.4.44	.1.3.6.1.2.1.105.1.1.1.9.4.44	OctetString	
pethPsePortType.4.45	.1.3.6.1.2.1.105.1.1.1.9.4.45	OctetString	
pethPsePortType.4.46	.1.3.6.1.2.1.105.1.1.1.9.4.46	OctetString	
pethPsePortType.4.47	.1.3.6.1.2.1.105.1.1.1.9.4.47	OctetString	

Name	OID	Value Type	Value Example
pethPsePortType.4.48	.1.3.6.1.2.1.105.1.1.1.9.4.48	OctetString	
pethPsePortPowerClassifications.4.1	.1.3.6.1.2.1.105.1.1.1.10.4.1	Integer	class0 (1)
pethPsePortPowerClassifications.4.2	.1.3.6.1.2.1.105.1.1.1.10.4.2	Integer	class0 (1)
pethPsePortPowerClassifications.4.3	.1.3.6.1.2.1.105.1.1.1.10.4.3	Integer	class0 (1)
pethPsePortPowerClassifications.4.4	.1.3.6.1.2.1.105.1.1.1.10.4.4	Integer	class0 (1)
pethPsePortPowerClassifications.4.5	.1.3.6.1.2.1.105.1.1.1.10.4.5	Integer	class0 (1)
pethPsePortPowerClassifications.4.6	.1.3.6.1.2.1.105.1.1.1.10.4.6	Integer	class0 (1)
pethPsePortPowerClassifications.4.7	.1.3.6.1.2.1.105.1.1.1.10.4.7	Integer	class0 (1)
pethPsePortPowerClassifications.4.8	.1.3.6.1.2.1.105.1.1.1.10.4.8	Integer	class0 (1)
pethPsePortPowerClassifications.4.9	.1.3.6.1.2.1.105.1.1.1.10.4.9	Integer	class0 (1)
pethPsePortPowerClassifications.4.10	.1.3.6.1.2.1.105.1.1.1.10.4.10	Integer	class0 (1)
pethPsePortPowerClassifications.4.11	.1.3.6.1.2.1.105.1.1.1.10.4.11	Integer	class0 (1)
pethPsePortPowerClassifications.4.12	.1.3.6.1.2.1.105.1.1.1.10.4.12	Integer	class0 (1)
pethPsePortPowerClassifications.4.13	.1.3.6.1.2.1.105.1.1.1.10.4.13	Integer	class0 (1)
pethPsePortPowerClassifications.4.14	.1.3.6.1.2.1.105.1.1.1.10.4.14	Integer	class0 (1)
pethPsePortPowerClassifications.4.15	.1.3.6.1.2.1.105.1.1.1.10.4.15	Integer	class0 (1)
pethPsePortPowerClassifications.4.16	.1.3.6.1.2.1.105.1.1.1.10.4.16	Integer	class0 (1)
pethPsePortPowerClassifications.4.17	.1.3.6.1.2.1.105.1.1.1.10.4.17	Integer	class0 (1)
pethPsePortPowerClassifications.4.18	.1.3.6.1.2.1.105.1.1.1.10.4.18	Integer	class0 (1)
pethPsePortPowerClassifications.4.19	.1.3.6.1.2.1.105.1.1.1.10.4.19	Integer	class0 (1)
pethPsePortPowerClassifications.4.20	.1.3.6.1.2.1.105.1.1.1.10.4.20	Integer	class0 (1)
pethPsePortPowerClassifications.4.21	.1.3.6.1.2.1.105.1.1.1.10.4.21	Integer	class0 (1)
pethPsePortPowerClassifications.4.22	.1.3.6.1.2.1.105.1.1.1.10.4.22	Integer	class0 (1)
pethPsePortPowerClassifications.4.23	.1.3.6.1.2.1.105.1.1.1.10.4.23	Integer	class0 (1)
pethPsePortPowerClassifications.4.24	.1.3.6.1.2.1.105.1.1.1.10.4.24	Integer	class0 (1)
pethPsePortPowerClassifications.4.25	.1.3.6.1.2.1.105.1.1.1.10.4.25	Integer	class0 (1)

Name	OID	Value Type	Value Example
pethPsePortPowerClassifications.4.26	.1.3.6.1.2.1.105.1.1.1.10.4.26	Integer	class0 (1)
pethPsePortPowerClassifications.4.27	.1.3.6.1.2.1.105.1.1.1.10.4.27	Integer	class0 (1)
pethPsePortPowerClassifications.4.28	.1.3.6.1.2.1.105.1.1.1.10.4.28	Integer	class0 (1)
pethPsePortPowerClassifications.4.29	.1.3.6.1.2.1.105.1.1.1.10.4.29	Integer	class0 (1)
pethPsePortPowerClassifications.4.30	.1.3.6.1.2.1.105.1.1.1.10.4.30	Integer	class0 (1)
pethPsePortPowerClassifications.4.31	.1.3.6.1.2.1.105.1.1.1.10.4.31	Integer	class0 (1)
pethPsePortPowerClassifications.4.32	.1.3.6.1.2.1.105.1.1.1.10.4.32	Integer	class0 (1)
pethPsePortPowerClassifications.4.33	.1.3.6.1.2.1.105.1.1.1.10.4.33	Integer	class0 (1)
pethPsePortPowerClassifications.4.34	.1.3.6.1.2.1.105.1.1.1.10.4.34	Integer	class0 (1)
pethPsePortPowerClassifications.4.35	.1.3.6.1.2.1.105.1.1.1.10.4.35	Integer	class0 (1)
pethPsePortPowerClassifications.4.36	.1.3.6.1.2.1.105.1.1.1.10.4.36	Integer	class0 (1)
pethPsePortPowerClassifications.4.37	.1.3.6.1.2.1.105.1.1.1.10.4.37	Integer	class0 (1)
pethPsePortPowerClassifications.4.38	.1.3.6.1.2.1.105.1.1.1.10.4.38	Integer	class0 (1)
pethPsePortPowerClassifications.4.39	.1.3.6.1.2.1.105.1.1.1.10.4.39	Integer	class0 (1)
pethPsePortPowerClassifications.4.40	.1.3.6.1.2.1.105.1.1.1.10.4.40	Integer	class0 (1)
pethPsePortPowerClassifications.4.41	.1.3.6.1.2.1.105.1.1.1.10.4.41	Integer	class0 (1)
pethPsePortPowerClassifications.4.42	.1.3.6.1.2.1.105.1.1.1.10.4.42	Integer	class0 (1)
pethPsePortPowerClassifications.4.43	.1.3.6.1.2.1.105.1.1.1.10.4.43	Integer	class0 (1)
pethPsePortPowerClassifications.4.44	.1.3.6.1.2.1.105.1.1.1.10.4.44	Integer	class0 (1)
pethPsePortPowerClassifications.4.45	.1.3.6.1.2.1.105.1.1.1.10.4.45	Integer	class0 (1)
pethPsePortPowerClassifications.4.46	.1.3.6.1.2.1.105.1.1.1.10.4.46	Integer	class0 (1)
pethPsePortPowerClassifications.4.47	.1.3.6.1.2.1.105.1.1.1.10.4.47	Integer	class0 (1)
pethPsePortPowerClassifications.4.48	.1.3.6.1.2.1.105.1.1.1.10.4.48	Integer	class0 (1)
pethPsePortInvalidSignatureCounter.4.1	.1.3.6.1.2.1.105.1.1.1.11.4.1	Counter32	1525
pethPsePortInvalidSignatureCounter.4.2	.1.3.6.1.2.1.105.1.1.1.11.4.2	Counter32	1681



<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
pethPsePortInvalidSignature-Counter.4.3	.1.3.6.1.2.1.105.1.1.1.11.4.3	Counter32	1681
pethPsePortInvalidSignature-Counter.4.4	.1.3.6.1.2.1.105.1.1.1.11.4.4	Counter32	1681
pethPsePortInvalidSignature-Counter.4.5	.1.3.6.1.2.1.105.1.1.1.11.4.5	Counter32	1703
pethPsePortInvalidSignature-Counter.4.6	.1.3.6.1.2.1.105.1.1.1.11.4.6	Counter32	1704
pethPsePortInvalidSignature-Counter.4.7	.1.3.6.1.2.1.105.1.1.1.11.4.7	Counter32	1703
pethPsePortInvalidSignature-Counter.4.8	.1.3.6.1.2.1.105.1.1.1.11.4.8	Counter32	1703
pethPsePortInvalidSignature-Counter.4.9	.1.3.6.1.2.1.105.1.1.1.11.4.9	Counter32	1696
pethPsePortInvalidSignature-Counter.4.10	.1.3.6.1.2.1.105.1.1.1.11.4.10	Counter32	1696
pethPsePortInvalidSignature-Counter.4.11	.1.3.6.1.2.1.105.1.1.1.11.4.11	Counter32	1696
pethPsePortInvalidSignature-Counter.4.12	.1.3.6.1.2.1.105.1.1.1.11.4.12	Counter32	1696
pethPsePortInvalidSignature-Counter.4.13	.1.3.6.1.2.1.105.1.1.1.11.4.13	Counter32	1695
pethPsePortInvalidSignature-Counter.4.14	.1.3.6.1.2.1.105.1.1.1.11.4.14	Counter32	1695
pethPsePortInvalidSignature-Counter.4.15	.1.3.6.1.2.1.105.1.1.1.11.4.15	Counter32	1696
pethPsePortInvalidSignature-Counter.4.16	.1.3.6.1.2.1.105.1.1.1.11.4.16	Counter32	1696
pethPsePortInvalidSignature-Counter.4.17	.1.3.6.1.2.1.105.1.1.1.11.4.17	Counter32	1688
pethPsePortInvalidSignature-Counter.4.18	.1.3.6.1.2.1.105.1.1.1.11.4.18	Counter32	1688
pethPsePortInvalidSignature-Counter.4.19	.1.3.6.1.2.1.105.1.1.1.11.4.19	Counter32	1688
pethPsePortInvalidSignature-Counter.4.20	.1.3.6.1.2.1.105.1.1.1.11.4.20	Counter32	1688
pethPsePortInvalidSignature-Counter.4.21	.1.3.6.1.2.1.105.1.1.1.11.4.21	Counter32	1688
pethPsePortInvalidSignature-Counter.4.22	.1.3.6.1.2.1.105.1.1.1.11.4.22	Counter32	1688
pethPsePortInvalidSignature-Counter.4.23	.1.3.6.1.2.1.105.1.1.1.11.4.23	Counter32	1688
pethPsePortInvalidSignature-Counter.4.24	.1.3.6.1.2.1.105.1.1.1.11.4.24	Counter32	1688
pethPsePortInvalidSignature-Counter.4.25	.1.3.6.1.2.1.105.1.1.1.11.4.25	Counter32	1701
pethPsePortInvalidSignature-Counter.4.26	.1.3.6.1.2.1.105.1.1.1.11.4.26	Counter32	1701
pethPsePortInvalidSignature-Counter.4.27	.1.3.6.1.2.1.105.1.1.1.11.4.27	Counter32	1702

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
pethPsePortInvalidSignature-Counter.4.28	.1.3.6.1.2.1.105.1.1.1.11.4.28	Counter32	1702
pethPsePortInvalidSignature-Counter.4.29	.1.3.6.1.2.1.105.1.1.1.11.4.29	Counter32	1703
pethPsePortInvalidSignature-Counter.4.30	.1.3.6.1.2.1.105.1.1.1.11.4.30	Counter32	1703
pethPsePortInvalidSignature-Counter.4.31	.1.3.6.1.2.1.105.1.1.1.11.4.31	Counter32	1703
pethPsePortInvalidSignature-Counter.4.32	.1.3.6.1.2.1.105.1.1.1.11.4.32	Counter32	1703
pethPsePortInvalidSignature-Counter.4.33	.1.3.6.1.2.1.105.1.1.1.11.4.33	Counter32	1688
pethPsePortInvalidSignature-Counter.4.34	.1.3.6.1.2.1.105.1.1.1.11.4.34	Counter32	1688
pethPsePortInvalidSignature-Counter.4.35	.1.3.6.1.2.1.105.1.1.1.11.4.35	Counter32	1688
pethPsePortInvalidSignature-Counter.4.36	.1.3.6.1.2.1.105.1.1.1.11.4.36	Counter32	1688
pethPsePortInvalidSignature-Counter.4.37	.1.3.6.1.2.1.105.1.1.1.11.4.37	Counter32	1688
pethPsePortInvalidSignature-Counter.4.38	.1.3.6.1.2.1.105.1.1.1.11.4.38	Counter32	1687
pethPsePortInvalidSignature-Counter.4.39	.1.3.6.1.2.1.105.1.1.1.11.4.39	Counter32	1688
pethPsePortInvalidSignature-Counter.4.40	.1.3.6.1.2.1.105.1.1.1.11.4.40	Counter32	1688
pethPsePortInvalidSignature-Counter.4.41	.1.3.6.1.2.1.105.1.1.1.11.4.41	Counter32	1704
pethPsePortInvalidSignature-Counter.4.42	.1.3.6.1.2.1.105.1.1.1.11.4.42	Counter32	1704
pethPsePortInvalidSignature-Counter.4.43	.1.3.6.1.2.1.105.1.1.1.11.4.43	Counter32	1705
pethPsePortInvalidSignature-Counter.4.44	.1.3.6.1.2.1.105.1.1.1.11.4.44	Counter32	1705
pethPsePortInvalidSignature-Counter.4.45	.1.3.6.1.2.1.105.1.1.1.11.4.45	Counter32	1704
pethPsePortInvalidSignature-Counter.4.46	.1.3.6.1.2.1.105.1.1.1.11.4.46	Counter32	1705
pethPsePortInvalidSignature-Counter.4.47	.1.3.6.1.2.1.105.1.1.1.11.4.47	Counter32	1704
pethPsePortInvalidSignature-Counter.4.48	.1.3.6.1.2.1.105.1.1.1.11.4.48	Counter32	1704
pethPsePortPowerDenied-Counter.4.1	.1.3.6.1.2.1.105.1.1.1.12.4.1	Counter32	0
pethPsePortPowerDenied-Counter.4.2	.1.3.6.1.2.1.105.1.1.1.12.4.2	Counter32	0
pethPsePortPowerDenied-Counter.4.3	.1.3.6.1.2.1.105.1.1.1.12.4.3	Counter32	0
pethPsePortPowerDenied-Counter.4.4	.1.3.6.1.2.1.105.1.1.1.12.4.4	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
pethPsePortPowerDenied-Counter.4.5	.1.3.6.1.2.1.105.1.1.1.12.4.5	Counter32	0
pethPsePortPowerDenied-Counter.4.6	.1.3.6.1.2.1.105.1.1.1.12.4.6	Counter32	0
pethPsePortPowerDenied-Counter.4.7	.1.3.6.1.2.1.105.1.1.1.12.4.7	Counter32	0
pethPsePortPowerDenied-Counter.4.8	.1.3.6.1.2.1.105.1.1.1.12.4.8	Counter32	0
pethPsePortPowerDenied-Counter.4.9	.1.3.6.1.2.1.105.1.1.1.12.4.9	Counter32	0
pethPsePortPowerDenied-Counter.4.10	.1.3.6.1.2.1.105.1.1.1.12.4.10	Counter32	0
pethPsePortPowerDenied-Counter.4.11	.1.3.6.1.2.1.105.1.1.1.12.4.11	Counter32	0
pethPsePortPowerDenied-Counter.4.12	.1.3.6.1.2.1.105.1.1.1.12.4.12	Counter32	0
pethPsePortPowerDenied-Counter.4.13	.1.3.6.1.2.1.105.1.1.1.12.4.13	Counter32	0
pethPsePortPowerDenied-Counter.4.14	.1.3.6.1.2.1.105.1.1.1.12.4.14	Counter32	0
pethPsePortPowerDenied-Counter.4.15	.1.3.6.1.2.1.105.1.1.1.12.4.15	Counter32	0
pethPsePortPowerDenied-Counter.4.16	.1.3.6.1.2.1.105.1.1.1.12.4.16	Counter32	0
pethPsePortPowerDenied-Counter.4.17	.1.3.6.1.2.1.105.1.1.1.12.4.17	Counter32	0
pethPsePortPowerDenied-Counter.4.18	.1.3.6.1.2.1.105.1.1.1.12.4.18	Counter32	0
pethPsePortPowerDenied-Counter.4.19	.1.3.6.1.2.1.105.1.1.1.12.4.19	Counter32	0
pethPsePortPowerDenied-Counter.4.20	.1.3.6.1.2.1.105.1.1.1.12.4.20	Counter32	0
pethPsePortPowerDenied-Counter.4.21	.1.3.6.1.2.1.105.1.1.1.12.4.21	Counter32	0
pethPsePortPowerDenied-Counter.4.22	.1.3.6.1.2.1.105.1.1.1.12.4.22	Counter32	0
pethPsePortPowerDenied-Counter.4.23	.1.3.6.1.2.1.105.1.1.1.12.4.23	Counter32	0
pethPsePortPowerDenied-Counter.4.24	.1.3.6.1.2.1.105.1.1.1.12.4.24	Counter32	0
pethPsePortPowerDenied-Counter.4.25	.1.3.6.1.2.1.105.1.1.1.12.4.25	Counter32	0
pethPsePortPowerDenied-Counter.4.26	.1.3.6.1.2.1.105.1.1.1.12.4.26	Counter32	0
pethPsePortPowerDenied-Counter.4.27	.1.3.6.1.2.1.105.1.1.1.12.4.27	Counter32	0
pethPsePortPowerDenied-Counter.4.28	.1.3.6.1.2.1.105.1.1.1.12.4.28	Counter32	0
pethPsePortPowerDenied-Counter.4.29	.1.3.6.1.2.1.105.1.1.1.12.4.29	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
pethPsePortPowerDenied-Counter.4.30	.1.3.6.1.2.1.105.1.1.1.12.4.30	Counter32	0
pethPsePortPowerDenied-Counter.4.31	.1.3.6.1.2.1.105.1.1.1.12.4.31	Counter32	0
pethPsePortPowerDenied-Counter.4.32	.1.3.6.1.2.1.105.1.1.1.12.4.32	Counter32	0
pethPsePortPowerDenied-Counter.4.33	.1.3.6.1.2.1.105.1.1.1.12.4.33	Counter32	0
pethPsePortPowerDenied-Counter.4.34	.1.3.6.1.2.1.105.1.1.1.12.4.34	Counter32	0
pethPsePortPowerDenied-Counter.4.35	.1.3.6.1.2.1.105.1.1.1.12.4.35	Counter32	0
pethPsePortPowerDenied-Counter.4.36	.1.3.6.1.2.1.105.1.1.1.12.4.36	Counter32	0
pethPsePortPowerDenied-Counter.4.37	.1.3.6.1.2.1.105.1.1.1.12.4.37	Counter32	0
pethPsePortPowerDenied-Counter.4.38	.1.3.6.1.2.1.105.1.1.1.12.4.38	Counter32	0
pethPsePortPowerDenied-Counter.4.39	.1.3.6.1.2.1.105.1.1.1.12.4.39	Counter32	0
pethPsePortPowerDenied-Counter.4.40	.1.3.6.1.2.1.105.1.1.1.12.4.40	Counter32	0
pethPsePortPowerDenied-Counter.4.41	.1.3.6.1.2.1.105.1.1.1.12.4.41	Counter32	0
pethPsePortPowerDenied-Counter.4.42	.1.3.6.1.2.1.105.1.1.1.12.4.42	Counter32	0
pethPsePortPowerDenied-Counter.4.43	.1.3.6.1.2.1.105.1.1.1.12.4.43	Counter32	0
pethPsePortPowerDenied-Counter.4.44	.1.3.6.1.2.1.105.1.1.1.12.4.44	Counter32	0
pethPsePortPowerDenied-Counter.4.45	.1.3.6.1.2.1.105.1.1.1.12.4.45	Counter32	0
pethPsePortPowerDenied-Counter.4.46	.1.3.6.1.2.1.105.1.1.1.12.4.46	Counter32	0
pethPsePortPowerDenied-Counter.4.47	.1.3.6.1.2.1.105.1.1.1.12.4.47	Counter32	0
pethPsePortPowerDenied-Counter.4.48	.1.3.6.1.2.1.105.1.1.1.12.4.48	Counter32	0
pethPsePortOverLoadCounter.4.1	.1.3.6.1.2.1.105.1.1.1.13.4.1	Counter32	0
pethPsePortOverLoadCounter.4.2	.1.3.6.1.2.1.105.1.1.1.13.4.2	Counter32	0
pethPsePortOverLoadCounter.4.3	.1.3.6.1.2.1.105.1.1.1.13.4.3	Counter32	0
pethPsePortOverLoadCounter.4.4	.1.3.6.1.2.1.105.1.1.1.13.4.4	Counter32	0
pethPsePortOverLoadCounter.4.5	.1.3.6.1.2.1.105.1.1.1.13.4.5	Counter32	0
pethPsePortOverLoadCounter.4.6	.1.3.6.1.2.1.105.1.1.1.13.4.6	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
pethPsePortOverLoadCounter.4.7	.1.3.6.1.2.1.105.1.1.1.13.4.7	Counter32	0
pethPsePortOverLoadCounter.4.8	.1.3.6.1.2.1.105.1.1.1.13.4.8	Counter32	0
pethPsePortOverLoadCounter.4.9	.1.3.6.1.2.1.105.1.1.1.13.4.9	Counter32	0
pethPsePortOverLoadCounter.4.10	.1.3.6.1.2.1.105.1.1.1.13.4.10	Counter32	0
pethPsePortOverLoadCounter.4.11	.1.3.6.1.2.1.105.1.1.1.13.4.11	Counter32	0
pethPsePortOverLoadCounter.4.12	.1.3.6.1.2.1.105.1.1.1.13.4.12	Counter32	0
pethPsePortOverLoadCounter.4.13	.1.3.6.1.2.1.105.1.1.1.13.4.13	Counter32	0
pethPsePortOverLoadCounter.4.14	.1.3.6.1.2.1.105.1.1.1.13.4.14	Counter32	0
pethPsePortOverLoadCounter.4.15	.1.3.6.1.2.1.105.1.1.1.13.4.15	Counter32	0
pethPsePortOverLoadCounter.4.16	.1.3.6.1.2.1.105.1.1.1.13.4.16	Counter32	0
pethPsePortOverLoadCounter.4.17	.1.3.6.1.2.1.105.1.1.1.13.4.17	Counter32	0
pethPsePortOverLoadCounter.4.18	.1.3.6.1.2.1.105.1.1.1.13.4.18	Counter32	0
pethPsePortOverLoadCounter.4.19	.1.3.6.1.2.1.105.1.1.1.13.4.19	Counter32	0
pethPsePortOverLoadCounter.4.20	.1.3.6.1.2.1.105.1.1.1.13.4.20	Counter32	0
pethPsePortOverLoadCounter.4.21	.1.3.6.1.2.1.105.1.1.1.13.4.21	Counter32	0
pethPsePortOverLoadCounter.4.22	.1.3.6.1.2.1.105.1.1.1.13.4.22	Counter32	0
pethPsePortOverLoadCounter.4.23	.1.3.6.1.2.1.105.1.1.1.13.4.23	Counter32	0
pethPsePortOverLoadCounter.4.24	.1.3.6.1.2.1.105.1.1.1.13.4.24	Counter32	0
pethPsePortOverLoadCounter.4.25	.1.3.6.1.2.1.105.1.1.1.13.4.25	Counter32	0
pethPsePortOverLoadCounter.4.26	.1.3.6.1.2.1.105.1.1.1.13.4.26	Counter32	0
pethPsePortOverLoadCounter.4.27	.1.3.6.1.2.1.105.1.1.1.13.4.27	Counter32	0
pethPsePortOverLoadCounter.4.28	.1.3.6.1.2.1.105.1.1.1.13.4.28	Counter32	0
pethPsePortOverLoadCounter.4.29	.1.3.6.1.2.1.105.1.1.1.13.4.29	Counter32	0
pethPsePortOverLoadCounter.4.30	.1.3.6.1.2.1.105.1.1.1.13.4.30	Counter32	0
pethPsePortOverLoadCounter.4.31	.1.3.6.1.2.1.105.1.1.1.13.4.31	Counter32	0

Name	OID	Value Type	Value Example
pethPsePortOverLoadCounter.4.32	.1.3.6.1.2.1.105.1.1.1.13.4.32	Counter32	0
pethPsePortOverLoadCounter.4.33	.1.3.6.1.2.1.105.1.1.1.13.4.33	Counter32	0
pethPsePortOverLoadCounter.4.34	.1.3.6.1.2.1.105.1.1.1.13.4.34	Counter32	0
pethPsePortOverLoadCounter.4.35	.1.3.6.1.2.1.105.1.1.1.13.4.35	Counter32	0
pethPsePortOverLoadCounter.4.36	.1.3.6.1.2.1.105.1.1.1.13.4.36	Counter32	0
pethPsePortOverLoadCounter.4.37	.1.3.6.1.2.1.105.1.1.1.13.4.37	Counter32	0
pethPsePortOverLoadCounter.4.38	.1.3.6.1.2.1.105.1.1.1.13.4.38	Counter32	0
pethPsePortOverLoadCounter.4.39	.1.3.6.1.2.1.105.1.1.1.13.4.39	Counter32	0
pethPsePortOverLoadCounter.4.40	.1.3.6.1.2.1.105.1.1.1.13.4.40	Counter32	0
pethPsePortOverLoadCounter.4.41	.1.3.6.1.2.1.105.1.1.1.13.4.41	Counter32	0
pethPsePortOverLoadCounter.4.42	.1.3.6.1.2.1.105.1.1.1.13.4.42	Counter32	0
pethPsePortOverLoadCounter.4.43	.1.3.6.1.2.1.105.1.1.1.13.4.43	Counter32	0
pethPsePortOverLoadCounter.4.44	.1.3.6.1.2.1.105.1.1.1.13.4.44	Counter32	0
pethPsePortOverLoadCounter.4.45	.1.3.6.1.2.1.105.1.1.1.13.4.45	Counter32	0
pethPsePortOverLoadCounter.4.46	.1.3.6.1.2.1.105.1.1.1.13.4.46	Counter32	0
pethPsePortOverLoadCounter.4.47	.1.3.6.1.2.1.105.1.1.1.13.4.47	Counter32	0
pethPsePortOverLoadCounter.4.48	.1.3.6.1.2.1.105.1.1.1.13.4.48	Counter32	0
pethPsePortShortCounter.4.1	.1.3.6.1.2.1.105.1.1.1.14.4.1	Counter32	0
pethPsePortShortCounter.4.2	.1.3.6.1.2.1.105.1.1.1.14.4.2	Counter32	0
pethPsePortShortCounter.4.3	.1.3.6.1.2.1.105.1.1.1.14.4.3	Counter32	0
pethPsePortShortCounter.4.4	.1.3.6.1.2.1.105.1.1.1.14.4.4	Counter32	0
pethPsePortShortCounter.4.5	.1.3.6.1.2.1.105.1.1.1.14.4.5	Counter32	0
pethPsePortShortCounter.4.6	.1.3.6.1.2.1.105.1.1.1.14.4.6	Counter32	0
pethPsePortShortCounter.4.7	.1.3.6.1.2.1.105.1.1.1.14.4.7	Counter32	0
pethPsePortShortCounter.4.8	.1.3.6.1.2.1.105.1.1.1.14.4.8	Counter32	0
pethPsePortShortCounter.4.9	.1.3.6.1.2.1.105.1.1.1.14.4.9	Counter32	0
pethPsePortShortCounter.4.10	.1.3.6.1.2.1.105.1.1.1.14.4.10	Counter32	0
pethPsePortShortCounter.4.11	.1.3.6.1.2.1.105.1.1.1.14.4.11	Counter32	0
pethPsePortShortCounter.4.12	.1.3.6.1.2.1.105.1.1.1.14.4.12	Counter32	0
pethPsePortShortCounter.4.13	.1.3.6.1.2.1.105.1.1.1.14.4.13	Counter32	0
pethPsePortShortCounter.4.14	.1.3.6.1.2.1.105.1.1.1.14.4.14	Counter32	0

Name	OID	Value Type	Value Example
pethPsePortShortCounter.4.15	.1.3.6.1.2.1.105.1.1.1.14.4.15	Counter32	0
pethPsePortShortCounter.4.16	.1.3.6.1.2.1.105.1.1.1.14.4.16	Counter32	0
pethPsePortShortCounter.4.17	.1.3.6.1.2.1.105.1.1.1.14.4.17	Counter32	0
pethPsePortShortCounter.4.18	.1.3.6.1.2.1.105.1.1.1.14.4.18	Counter32	0
pethPsePortShortCounter.4.19	.1.3.6.1.2.1.105.1.1.1.14.4.19	Counter32	0
pethPsePortShortCounter.4.20	.1.3.6.1.2.1.105.1.1.1.14.4.20	Counter32	0
pethPsePortShortCounter.4.21	.1.3.6.1.2.1.105.1.1.1.14.4.21	Counter32	0
pethPsePortShortCounter.4.22	.1.3.6.1.2.1.105.1.1.1.14.4.22	Counter32	0
pethPsePortShortCounter.4.23	.1.3.6.1.2.1.105.1.1.1.14.4.23	Counter32	0
pethPsePortShortCounter.4.24	.1.3.6.1.2.1.105.1.1.1.14.4.24	Counter32	0
pethPsePortShortCounter.4.25	.1.3.6.1.2.1.105.1.1.1.14.4.25	Counter32	0
pethPsePortShortCounter.4.26	.1.3.6.1.2.1.105.1.1.1.14.4.26	Counter32	0
pethPsePortShortCounter.4.27	.1.3.6.1.2.1.105.1.1.1.14.4.27	Counter32	0
pethPsePortShortCounter.4.28	.1.3.6.1.2.1.105.1.1.1.14.4.28	Counter32	0
pethPsePortShortCounter.4.29	.1.3.6.1.2.1.105.1.1.1.14.4.29	Counter32	0
pethPsePortShortCounter.4.30	.1.3.6.1.2.1.105.1.1.1.14.4.30	Counter32	0
pethPsePortShortCounter.4.31	.1.3.6.1.2.1.105.1.1.1.14.4.31	Counter32	0
pethPsePortShortCounter.4.32	.1.3.6.1.2.1.105.1.1.1.14.4.32	Counter32	0
pethPsePortShortCounter.4.33	.1.3.6.1.2.1.105.1.1.1.14.4.33	Counter32	0
pethPsePortShortCounter.4.34	.1.3.6.1.2.1.105.1.1.1.14.4.34	Counter32	0
pethPsePortShortCounter.4.35	.1.3.6.1.2.1.105.1.1.1.14.4.35	Counter32	0
pethPsePortShortCounter.4.36	.1.3.6.1.2.1.105.1.1.1.14.4.36	Counter32	0
pethPsePortShortCounter.4.37	.1.3.6.1.2.1.105.1.1.1.14.4.37	Counter32	0
pethPsePortShortCounter.4.38	.1.3.6.1.2.1.105.1.1.1.14.4.38	Counter32	0
pethPsePortShortCounter.4.39	.1.3.6.1.2.1.105.1.1.1.14.4.39	Counter32	0
pethPsePortShortCounter.4.40	.1.3.6.1.2.1.105.1.1.1.14.4.40	Counter32	0
pethPsePortShortCounter.4.41	.1.3.6.1.2.1.105.1.1.1.14.4.41	Counter32	0
pethPsePortShortCounter.4.42	.1.3.6.1.2.1.105.1.1.1.14.4.42	Counter32	0
pethPsePortShortCounter.4.43	.1.3.6.1.2.1.105.1.1.1.14.4.43	Counter32	0
pethPsePortShortCounter.4.44	.1.3.6.1.2.1.105.1.1.1.14.4.44	Counter32	0
pethPsePortShortCounter.4.45	.1.3.6.1.2.1.105.1.1.1.14.4.45	Counter32	0
pethPsePortShortCounter.4.46	.1.3.6.1.2.1.105.1.1.1.14.4.46	Counter32	0
pethPsePortShortCounter.4.47	.1.3.6.1.2.1.105.1.1.1.14.4.47	Counter32	0
pethPsePortShortCounter.4.48	.1.3.6.1.2.1.105.1.1.1.14.4.48	Counter32	0
pethMainPsePower.4	.1.3.6.1.2.1.105.1.3.1.1.2.4	Gauge	530
pethMainPseOperStatus.4	.1.3.6.1.2.1.105.1.3.1.1.3.4	Integer	off (2)
pethMainPseConsumption-Power.4	.1.3.6.1.2.1.105.1.3.1.1.4.4	Gauge	0
pethMainPseUsageThreshold.4	.1.3.6.1.2.1.105.1.3.1.1.5.4	Integer	80
pethNotificationControlEnable.4	.1.3.6.1.2.1.105.1.4.1.1.2.4	Integer	true (1)
syslogMsgTableMaxSize.0	.1.3.6.1.2.1.192.1.1.1.0	Gauge	128
syslogMsgEnableNotifications.0	.1.3.6.1.2.1.192.1.1.2.0	Integer	false (2)

Name	OID	Value Type	Value Example
ibSysLocalClock.0	.1.3.6.1.4.1.26138.2.3.1.1.1.0	OctetString	2024-8-30,17:59:21.4,-3:0
ibSysSummerTimeEnable.0	.1.3.6.1.4.1.26138.2.3.1.1.2.1.0	Integer	disable (2)
ibSysSummerTimeZone.0	.1.3.6.1.4.1.26138.2.3.1.1.2.2.0	OctetString	
ibSysSummerTimeMethod.0	.1.3.6.1.4.1.26138.2.3.1.1.2.3.0	Integer	repeating (2)
ibSysSummerTimeStart.0	.1.3.6.1.4.1.26138.2.3.1.1.2.4.0	OctetString	0-0-0,0:0:0.0
ibSysSummerTimeEnd.0	.1.3.6.1.4.1.26138.2.3.1.1.2.5.0	OctetString	0-0-0,0:0:0.0
ibSysSummerTimeOffset.0	.1.3.6.1.4.1.26138.2.3.1.1.2.6.0	Integer	0
ibSysLocalClockString.0	.1.3.6.1.4.1.26138.2.3.1.1.3.0	OctetString	2024-8-30T17:59:21.5Z
ibSysClockProtocol.0	.1.3.6.1.4.1.26138.2.3.1.1.4.1.0	Integer	ntp (2)
ibSysClockProtocolSrcMdc.0	.1.3.6.1.4.1.26138.2.3.1.1.4.2.0	Integer	0
ibSysClockProtocolSrcContext.0	.1.3.6.1.4.1.26138.2.3.1.1.4.3.0	Integer	0
ibSysCurCFGFileIndex.212	1.3.6.1.4.1.26138.2.3.1.2.1.1.2.212	Integer	13893633
ibSysReloadSchedule.0	.1.3.6.1.4.1.26138.2.3.1.3.1.0	Integer	0
ibSysReloadAction.0	.1.3.6.1.4.1.26138.2.3.1.3.2.0	Integer	reloadUnavailable (1)
ibSysReloadEntity.13893632	.1.3.6.1.4.1.26138.2.3.1.3.3.1.2.13893632	Integer	212
ibSysReloadCfgFile.13893632	.1.3.6.1.4.1.26138.2.3.1.3.3.1.3.13893632	Integer	0
ibSysReloadReason.13893632	.1.3.6.1.4.1.26138.2.3.1.3.3.1.5.13893632	OctetString	Upgrade
ibSysReloadScheduleTime.13893632	.1.3.6.1.4.1.26138.2.3.1.3.3.1.6.13893632	OctetString	2012-12-31,21:11:23.0
ibSysReloadRowStatus.13893632	.1.3.6.1.4.1.26138.2.3.1.3.3.1.7.13893632	Integer	active (1)
ibSysReloadScheduleTagList.13893632	.1.3.6.1.4.1.26138.2.3.1.3.3.1.8.13893632	OctetString	Network-SuperVisor
ibSysReloadTag.0	.1.3.6.1.4.1.26138.2.3.1.3.4.0	OctetString	Network-SuperVisor
ibSysCFGFileNum.0	.1.3.6.1.4.1.26138.2.3.1.5.1.0	Integer	1
ibSysCFGFileName.13893634	.1.3.6.1.4.1.26138.2.3.1.5.2.1.2.13893634	OctetString	startup.cfg
ibSysCFGFileSize.13893634	.1.3.6.1.4.1.26138.2.3.1.5.2.1.3.13893634	Integer	7290
ibSysCFGFileLocation.13893634	.1.3.6.1.4.1.26138.2.3.1.5.2.1.4.13893634	OctetString	flash:/
ibSysBtmLoadMaxNumber.0	.1.3.6.1.4.1.26138.2.3.1.6.1.1.0	Integer	4
ibSysPackageNum.0	.1.3.6.1.4.1.26138.2.3.1.7.1.0	Integer	10
ibSysPackageName.13893633	.1.3.6.1.4.1.26138.2.3.1.7.2.1.2.13893633	OctetString	sc3570-ibos710-system-r1124-bin
ibSysPackageName.13893634	.1.3.6.1.4.1.26138.2.3.1.7.2.1.2.13893634	OctetString	sc3570-ibos710-system-f1125p01.bin
ibSysPackageName.13893635	.1.3.6.1.4.1.26138.2.3.1.7.2.1.2.13893635	OctetString	sc3570-ibos710-system-a1122p02.bin
ibSysPackageName.13893636	.1.3.6.1.4.1.26138.2.3.1.7.2.1.2.13893636	OctetString	sc3570-ibos710-system-r1122-bin
ibSysPackageName.13893637	.1.3.6.1.4.1.26138.2.3.1.7.2.1.2.13893637	OctetString	sc3570-ibos710-boot-r1122.bin
ibSysPackageName.13893638	.1.3.6.1.4.1.26138.2.3.1.7.2.1.2.13893638	OctetString	sc3570-ibos710-boot-f1125p01.bin
ibSysPackageName.13893639	.1.3.6.1.4.1.26138.2.3.1.7.2.1.2.13893639	OctetString	sc3570-ibos710-boot-r1124.bin
ibSysPackageName.13893640	.1.3.6.1.4.1.26138.2.3.1.7.2.1.2.13893640	OctetString	sc3570-ibos710-boot-a1122p02.bin



Name	OID	Value Type	Value Example
ibSysPackageName.13893641	.1.3.6.1.4.1.26138.2.3.1.7.2.1.2.13893641	OcetetString	s5570s_ei-cmw710-system-r1115.bin
ibSysPackageName.13893642	.1.3.6.1.4.1.26138.2.3.1.7.2.1.2.13893642	OcetetString	s5570s_ei-cmw710-boot-r1115.bin
ibSysPackageSize.13893633	.1.3.6.1.4.1.26138.2.3.1.7.2.1.3.13893633	Gauge	54367232
ibSysPackageSize.13893634	.1.3.6.1.4.1.26138.2.3.1.7.2.1.3.13893634	Gauge	54606848
ibSysPackageSize.13893635	.1.3.6.1.4.1.26138.2.3.1.7.2.1.3.13893635	Gauge	49741824
ibSysPackageSize.13893636	.1.3.6.1.4.1.26138.2.3.1.7.2.1.3.13893636	Gauge	49377280
ibSysPackageSize.13893637	.1.3.6.1.4.1.26138.2.3.1.7.2.1.3.13893637	Gauge	4864000
ibSysPackageSize.13893638	.1.3.6.1.4.1.26138.2.3.1.7.2.1.3.13893638	Gauge	4864000
ibSysPackageSize.13893639	.1.3.6.1.4.1.26138.2.3.1.7.2.1.3.13893639	Gauge	4858880
ibSysPackageSize.13893640	.1.3.6.1.4.1.26138.2.3.1.7.2.1.3.13893640	Gauge	4864000
ibSysPackageSize.13893641	.1.3.6.1.4.1.26138.2.3.1.7.2.1.3.13893641	Gauge	81301504
ibSysPackageSize.13893642	.1.3.6.1.4.1.26138.2.3.1.7.2.1.3.13893642	Gauge	6330368
ibSysPackageLocation.13893633	.1.3.6.1.4.1.26138.2.3.1.7.2.1.4.13893633	OcetetString	flash:/
ibSysPackageLocation.13893634	.1.3.6.1.4.1.26138.2.3.1.7.2.1.4.13893634	OcetetString	flash:/
ibSysPackageLocation.13893635	.1.3.6.1.4.1.26138.2.3.1.7.2.1.4.13893635	OcetetString	flash:/
ibSysPackageLocation.13893636	.1.3.6.1.4.1.26138.2.3.1.7.2.1.4.13893636	OcetetString	flash:/
ibSysPackageLocation.13893637	.1.3.6.1.4.1.26138.2.3.1.7.2.1.4.13893637	OcetetString	flash:/
ibSysPackageLocation.13893638	.1.3.6.1.4.1.26138.2.3.1.7.2.1.4.13893638	OcetetString	flash:/
ibSysPackageLocation.13893639	.1.3.6.1.4.1.26138.2.3.1.7.2.1.4.13893639	OcetetString	flash:/
ibSysPackageLocation.13893640	.1.3.6.1.4.1.26138.2.3.1.7.2.1.4.13893640	OcetetString	flash:/
ibSysPackageLocation.13893641	.1.3.6.1.4.1.26138.2.3.1.7.2.1.4.13893641	OcetetString	flash:/
ibSysPackageLocation.13893642	.1.3.6.1.4.1.26138.2.3.1.7.2.1.4.13893642	OcetetString	flash:/
ibSysPackageType.13893633	.1.3.6.1.4.1.26138.2.3.1.7.2.1.5.13893633	Integer	system (2)
ibSysPackageType.13893634	.1.3.6.1.4.1.26138.2.3.1.7.2.1.5.13893634	Integer	system (2)
ibSysPackageType.13893635	.1.3.6.1.4.1.26138.2.3.1.7.2.1.5.13893635	Integer	system (2)
ibSysPackageType.13893636	.1.3.6.1.4.1.26138.2.3.1.7.2.1.5.13893636	Integer	system (2)
ibSysPackageType.13893637	.1.3.6.1.4.1.26138.2.3.1.7.2.1.5.13893637	Integer	boot (1)
ibSysPackageType.13893638	.1.3.6.1.4.1.26138.2.3.1.7.2.1.5.13893638	Integer	boot (1)
ibSysPackageType.13893639	.1.3.6.1.4.1.26138.2.3.1.7.2.1.5.13893639	Integer	boot (1)
ibSysPackageType.13893640	.1.3.6.1.4.1.26138.2.3.1.7.2.1.5.13893640	Integer	boot (1)
ibSysPackageType.13893641	.1.3.6.1.4.1.26138.2.3.1.7.2.1.5.13893641	Integer	system (2)
ibSysPackageType.13893642	.1.3.6.1.4.1.26138.2.3.1.7.2.1.5.13893642	Integer	boot (1)
ibSysPackageAttribute.13893633	.1.3.6.1.4.1.26138.2.3.1.7.2.1.6.13893633	Integer	primary (2)

Name	OID	Value Type	Value Example
ibSysPackageAttribute.13893634	.1.3.6.1.4.1.26138.2.3.1.7.2.1.6.13893634	Integer	none (1)
ibSysPackageAttribute.13893635	.1.3.6.1.4.1.26138.2.3.1.7.2.1.6.13893635	Integer	none (1)
ibSysPackageAttribute.13893636	.1.3.6.1.4.1.26138.2.3.1.7.2.1.6.13893636	Integer	none (1)
ibSysPackageAttribute.13893637	.1.3.6.1.4.1.26138.2.3.1.7.2.1.6.13893637	Integer	none (1)
ibSysPackageAttribute.13893638	.1.3.6.1.4.1.26138.2.3.1.7.2.1.6.13893638	Integer	none (1)
ibSysPackageAttribute.13893639	.1.3.6.1.4.1.26138.2.3.1.7.2.1.6.13893639	Integer	primary (2)
ibSysPackageAttribute.13893640	.1.3.6.1.4.1.26138.2.3.1.7.2.1.6.13893640	Integer	none (1)
ibSysPackageAttribute.13893641	.1.3.6.1.4.1.26138.2.3.1.7.2.1.6.13893641	Integer	none (1)
ibSysPackageAttribute.13893642	.1.3.6.1.4.1.26138.2.3.1.7.2.1.6.13893642	Integer	none (1)
ibSysPackageStatus.138936331	.1.3.6.1.4.1.26138.2.3.1.7.2.1.7.138936331	Integer	active (1)
ibSysPackageStatus.138936341	.1.3.6.1.4.1.26138.2.3.1.7.2.1.7.138936341	Integer	inactive (2)
ibSysPackageStatus.138936351	.1.3.6.1.4.1.26138.2.3.1.7.2.1.7.138936351	Integer	inactive (2)
ibSysPackageStatus.138936361	.1.3.6.1.4.1.26138.2.3.1.7.2.1.7.138936361	Integer	inactive (2)
ibSysPackageStatus.138936371	.1.3.6.1.4.1.26138.2.3.1.7.2.1.7.138936371	Integer	inactive (2)
ibSysPackageStatus.138936381	.1.3.6.1.4.1.26138.2.3.1.7.2.1.7.138936381	Integer	inactive (2)
ibSysPackageStatus.138936391	.1.3.6.1.4.1.26138.2.3.1.7.2.1.7.138936391	Integer	active (1)
ibSysPackageStatus.138936401	.1.3.6.1.4.1.26138.2.3.1.7.2.1.7.138936401	Integer	inactive (2)
ibSysPackageStatus.138936411	.1.3.6.1.4.1.26138.2.3.1.7.2.1.7.138936411	Integer	inactive (2)
ibSysPackageStatus.138936421	.1.3.6.1.4.1.26138.2.3.1.7.2.1.7.138936421	Integer	inactive (2)
ibSysPackageDescription.13893633	.1.3.6.1.4.1.26138.2.3.1.7.2.1.8.13893633	OctetString	system package
ibSysPackageDescription.13893634	.1.3.6.1.4.1.26138.2.3.1.7.2.1.8.13893634	OctetString	system package
ibSysPackageDescription.13893635	.1.3.6.1.4.1.26138.2.3.1.7.2.1.8.13893635	OctetString	system package
ibSysPackageDescription.13893636	.1.3.6.1.4.1.26138.2.3.1.7.2.1.8.13893636	OctetString	system package
ibSysPackageDescription.13893637	.1.3.6.1.4.1.26138.2.3.1.7.2.1.8.13893637	OctetString	boot package
ibSysPackageDescription.13893638	.1.3.6.1.4.1.26138.2.3.1.7.2.1.8.13893638	OctetString	boot package
ibSysPackageDescription.13893639	.1.3.6.1.4.1.26138.2.3.1.7.2.1.8.13893639	OctetString	boot package
ibSysPackageDescription.13893640	.1.3.6.1.4.1.26138.2.3.1.7.2.1.8.13893640	OctetString	boot package
ibSysPackageDescription.13893641	.1.3.6.1.4.1.26138.2.3.1.7.2.1.8.13893641	OctetString	system package
ibSysPackageDescription.13893642	.1.3.6.1.4.1.26138.2.3.1.7.2.1.8.13893642	OctetString	boot package

Name	OID	Value Type	Value Example
ibSysPackageFeature.13893633	.1.3.6.1.4.1.26138.2.3.1.7.2.1.9.13893633	OcctetString	system
ibSysPackageFeature.13893634	.1.3.6.1.4.1.26138.2.3.1.7.2.1.9.13893634	OcctetString	system
ibSysPackageFeature.13893635	.1.3.6.1.4.1.26138.2.3.1.7.2.1.9.13893635	OcctetString	system
ibSysPackageFeature.13893636	.1.3.6.1.4.1.26138.2.3.1.7.2.1.9.13893636	OcctetString	system
ibSysPackageFeature.13893637	.1.3.6.1.4.1.26138.2.3.1.7.2.1.9.13893637	OcctetString	boot
ibSysPackageFeature.13893638	.1.3.6.1.4.1.26138.2.3.1.7.2.1.9.13893638	OcctetString	boot
ibSysPackageFeature.13893639	.1.3.6.1.4.1.26138.2.3.1.7.2.1.9.13893639	OcctetString	boot
ibSysPackageFeature.13893640	.1.3.6.1.4.1.26138.2.3.1.7.2.1.9.13893640	OcctetString	boot
ibSysPackageFeature.13893641	.1.3.6.1.4.1.26138.2.3.1.7.2.1.9.13893641	OcctetString	system
ibSysPackageFeature.13893642	.1.3.6.1.4.1.26138.2.3.1.7.2.1.9.13893642	OcctetString	boot
ibSysPackageVersion.13893633	.1.3.6.1.4.1.26138.2.3.1.7.2.1.10.13893633	OcctetString	Release 1124
ibSysPackageVersion.13893634	.1.3.6.1.4.1.26138.2.3.1.7.2.1.10.13893634	OcctetString	Feature 1125P01
ibSysPackageVersion.13893635	.1.3.6.1.4.1.26138.2.3.1.7.2.1.10.13893635	OcctetString	Alpha 1122P02
ibSysPackageVersion.13893636	.1.3.6.1.4.1.26138.2.3.1.7.2.1.10.13893636	OcctetString	Release 1122
ibSysPackageVersion.13893637	.1.3.6.1.4.1.26138.2.3.1.7.2.1.10.13893637	OcctetString	Release 1122
ibSysPackageVersion.13893638	.1.3.6.1.4.1.26138.2.3.1.7.2.1.10.13893638	OcctetString	Feature 1125P01
ibSysPackageVersion.13893639	.1.3.6.1.4.1.26138.2.3.1.7.2.1.10.13893639	OcctetString	Release 1124
ibSysPackageVersion.13893640	.1.3.6.1.4.1.26138.2.3.1.7.2.1.10.13893640	OcctetString	Alpha 1122P02
ibSysPackageVersion.13893641	.1.3.6.1.4.1.26138.2.3.1.7.2.1.10.13893641	OcctetString	Release 1115
ibSysPackageVersion.13893642	.1.3.6.1.4.1.26138.2.3.1.7.2.1.10.13893642	OcctetString	Release 1115
ibSysPackageLoadAttribute.13893633	.1.3.6.1.4.1.26138.2.3.1.7.2.1.11.13893633	Integer	none (1)
ibSysPackageLoadAttribute.13893634	.1.3.6.1.4.1.26138.2.3.1.7.2.1.11.13893634	Integer	none (1)
ibSysPackageLoadAttribute.13893635	.1.3.6.1.4.1.26138.2.3.1.7.2.1.11.13893635	Integer	none (1)
ibSysPackageLoadAttribute.13893636	.1.3.6.1.4.1.26138.2.3.1.7.2.1.11.13893636	Integer	none (1)
ibSysPackageLoadAttribute.13893637	.1.3.6.1.4.1.26138.2.3.1.7.2.1.11.13893637	Integer	none (1)

Name	OID	Value Type	Value Example
ibSysPackageLoadAttribute.13893638	.1.3.6.1.4.1.26138.2.3.1.7.2.1.11.13893638	Integer	none (1)
ibSysPackageLoadAttribute.13893639	.1.3.6.1.4.1.26138.2.3.1.7.2.1.11.13893639	Integer	none (1)
ibSysPackageLoadAttribute.13893640	.1.3.6.1.4.1.26138.2.3.1.7.2.1.11.13893640	Integer	none (1)
ibSysPackageLoadAttribute.13893641	.1.3.6.1.4.1.26138.2.3.1.7.2.1.11.13893641	Integer	none (1)
ibSysPackageLoadAttribute.13893642	.1.3.6.1.4.1.26138.2.3.1.7.2.1.11.13893642	Integer	none (1)
ibSysPackageModel.13893633	.1.3.6.1.4.1.26138.2.3.1.7.2.1.12.13893633	OctetString	mpu
ibSysPackageModel.13893634	.1.3.6.1.4.1.26138.2.3.1.7.2.1.12.13893634	OctetString	mpu
ibSysPackageModel.13893635	.1.3.6.1.4.1.26138.2.3.1.7.2.1.12.13893635	OctetString	mpu
ibSysPackageModel.13893636	.1.3.6.1.4.1.26138.2.3.1.7.2.1.12.13893636	OctetString	mpu
ibSysPackageModel.13893637	.1.3.6.1.4.1.26138.2.3.1.7.2.1.12.13893637	OctetString	mpu
ibSysPackageModel.13893638	.1.3.6.1.4.1.26138.2.3.1.7.2.1.12.13893638	OctetString	mpu
ibSysPackageModel.13893639	.1.3.6.1.4.1.26138.2.3.1.7.2.1.12.13893639	OctetString	mpu
ibSysPackageModel.13893640	.1.3.6.1.4.1.26138.2.3.1.7.2.1.12.13893640	OctetString	mpu
ibSysPackageModel.13893641	.1.3.6.1.4.1.26138.2.3.1.7.2.1.12.13893641	OctetString	mpu
ibSysPackageModel.13893642	.1.3.6.1.4.1.26138.2.3.1.7.2.1.12.13893642	OctetString	mpu
ibSysPackageOperateEntryLimit.0	.1.3.6.1.4.1.26138.2.3.1.7.3.0	Integer	32
ibSysIpeFileNum.0	.1.3.6.1.4.1.26138.2.3.1.8.1.0	Integer	0
ibSysSetBootImageAction.0	.1.3.6.1.4.1.26138.2.3.1.9.1.1.0	Integer	none (1)
ibSysSetBootImageFileOverWrite.0	.1.3.6.1.4.1.26138.2.3.1.9.1.2.0	Integer	false (2)
ibSysSetBootImageRemoveIpeFile.0	.1.3.6.1.4.1.26138.2.3.1.9.1.3.0	Integer	false (2)
ibSysSetBootImageStatus.0	.1.3.6.1.4.1.26138.2.3.1.9.1.4.0	Integer	none (1)
ibSysSetBootImageFailedReason.0	.1.3.6.1.4.1.26138.2.3.1.9.1.5.0	OctetString	
ibCfgRunModifiedLast.0	.1.3.6.1.4.1.26138.2.4.1.1.1.0	TimeTicks	23 minutes 28.82 seconds (140882)
ibCfgRunSavedLast.0	.1.3.6.1.4.1.26138.2.4.1.1.2.0	TimeTicks	28 minutes 24.54 seconds (170454)
ibCfgStartModifiedLast.0	.1.3.6.1.4.1.26138.2.4.1.1.3.0	TimeTicks	5 minutes 56.39 seconds (35639)
ibCfgLogLimitedEntries.0	.1.3.6.1.4.1.26138.2.4.1.1.4.0	Integer	10
ibCfgLogDeletedEntries.0	.1.3.6.1.4.1.26138.2.4.1.1.5.0	Counter32	0
ibCfgLogWantBackup.0	.1.3.6.1.4.1.26138.2.4.1.1.6.0	Integer	true (1)
ibCfgLogTime.1	.1.3.6.1.4.1.26138.2.4.1.1.7.1.2.1	TimeTicks	5 minutes 56.4 seconds (35640)
ibCfgLogTime.2	.1.3.6.1.4.1.26138.2.4.1.1.7.1.2.2	TimeTicks	13 minutes 58.76 seconds (83876)
ibCfgLogTime.3	.1.3.6.1.4.1.26138.2.4.1.1.7.1.2.3	TimeTicks	23 minutes 58.76 seconds (143876)
ibCfgLogSrcCmd.1	.1.3.6.1.4.1.26138.2.4.1.1.7.1.3.1	Integer	cmdLine (1)
ibCfgLogSrcCmd.2	.1.3.6.1.4.1.26138.2.4.1.1.7.1.3.2	Integer	snmp (2)

Name	OID	Value Type	Value Example
ibCfgLogSrcCmd.3	.1.3.6.1.4.1.26138.2.4.1.1.7.1.3.3	Integer	snmp (2)
ibCfgLogSrcData.1	.1.3.6.1.4.1.26138.2.4.1.1.7.1.4.1	Integer	runningData (2)
ibCfgLogSrcData.2	.1.3.6.1.4.1.26138.2.4.1.1.7.1.4.2	Integer	startupData (4)
ibCfgLogSrcData.3	.1.3.6.1.4.1.26138.2.4.1.1.7.1.4.3	Integer	startupData (4)
ibCfgLogDesData.1	.1.3.6.1.4.1.26138.2.4.1.1.7.1.5.1	Integer	startupData (4)
ibCfgLogDesData.2	.1.3.6.1.4.1.26138.2.4.1.1.7.1.5.2	Integer	runningData (2)
ibCfgLogDesData.3	.1.3.6.1.4.1.26138.2.4.1.1.7.1.5.3	Integer	runningData (2)
ibCfgLogTerminalType.1	.1.3.6.1.4.1.26138.2.4.1.1.7.1.6.1	Integer	auxiliary (6)
ibCfgLogTerminalType.2	.1.3.6.1.4.1.26138.2.4.1.1.7.1.6.2	Integer	notApplicable (1)
ibCfgLogTerminalType.3	.1.3.6.1.4.1.26138.2.4.1.1.7.1.6.3	Integer	notApplicable (1)
ibCfgLogTerminalUser.1	.1.3.6.1.4.1.26138.2.4.1.1.7.1.7.1	OctetString	
ibCfgLogTerminalUser.2	.1.3.6.1.4.1.26138.2.4.1.1.7.1.7.2	OctetString	
ibCfgLogTerminalUser.3	.1.3.6.1.4.1.26138.2.4.1.1.7.1.7.3	OctetString	
ibCfgLogTerminalNum.1	.1.3.6.1.4.1.26138.2.4.1.1.7.1.8.1	Integer	0
ibCfgLogTerminalNum.2	.1.3.6.1.4.1.26138.2.4.1.1.7.1.8.2	Integer	-1
ibCfgLogTerminalNum.3	.1.3.6.1.4.1.26138.2.4.1.1.7.1.8.3	Integer	-1
ibCfgLogTerminalLocation.1	.1.3.6.1.4.1.26138.2.4.1.1.7.1.9.1	OctetString	AUX
ibCfgLogTerminalLocation.2	.1.3.6.1.4.1.26138.2.4.1.1.7.1.9.2	OctetString	
ibCfgLogTerminalLocation.3	.1.3.6.1.4.1.26138.2.4.1.1.7.1.9.3	OctetString	
ibCfgLogCmdSrcAddress.1	.1.3.6.1.4.1.26138.2.4.1.1.7.1.10.1	IpAddress	0.0.0.0
ibCfgLogCmdSrcAddress.2	.1.3.6.1.4.1.26138.2.4.1.1.7.1.10.2	IpAddress	0.0.0.0
ibCfgLogCmdSrcAddress.3	.1.3.6.1.4.1.26138.2.4.1.1.7.1.10.3	IpAddress	0.0.0.0
ibCfgLogVirHost.1	.1.3.6.1.4.1.26138.2.4.1.1.7.1.11.1	OctetString	
ibCfgLogVirHost.2	.1.3.6.1.4.1.26138.2.4.1.1.7.1.11.2	OctetString	
ibCfgLogVirHost.3	.1.3.6.1.4.1.26138.2.4.1.1.7.1.11.3	OctetString	
ibCfgLogUserName.1	.1.3.6.1.4.1.26138.2.4.1.1.7.1.12.1	OctetString	
ibCfgLogUserName.2	.1.3.6.1.4.1.26138.2.4.1.1.7.1.12.2	OctetString	
ibCfgLogUserName.3	.1.3.6.1.4.1.26138.2.4.1.1.7.1.12.3	OctetString	
ibCfgLogServerAddress.1	.1.3.6.1.4.1.26138.2.4.1.1.7.1.13.1	IpAddress	0.0.0.0
ibCfgLogServerAddress.2	.1.3.6.1.4.1.26138.2.4.1.1.7.1.13.2	IpAddress	0.0.0.0
ibCfgLogServerAddress.3	.1.3.6.1.4.1.26138.2.4.1.1.7.1.13.3	IpAddress	0.0.0.0
ibCfgLogFile.1	.1.3.6.1.4.1.26138.2.4.1.1.7.1.14.1	OctetString	
ibCfgLogFile.2	.1.3.6.1.4.1.26138.2.4.1.1.7.1.14.2	OctetString	
ibCfgLogFile.3	.1.3.6.1.4.1.26138.2.4.1.1.7.1.14.3	OctetString	
ibCfgOperateGlobalEntryLimit.0	.1.3.6.1.4.1.26138.2.4.1.2.1.0	Integer	5
ibCfgOperateEntryAgeOutTime.0	.1.3.6.1.4.1.26138.2.4.1.2.2.0	Integer	5
ibCfgOperateResultGlobalEntryLimit.0	.1.3.6.1.4.1.26138.2.4.1.2.3.0	Integer	5
ibCfgExecuteOperateResultEntryLimit.0	.1.3.6.1.4.1.26138.2.4.1.2.6.1.0	Integer	5
ibCfgReset.0	.1.3.6.1.4.1.26138.2.4.1.2.7.0	Integer	normal (1)
ibFlhSupportNum.0	.1.3.6.1.4.1.26138.2.5.1.1.1.0	Integer	32

Name	OID	Value Type	Value Example
ibFlhIndex.13893633	.1.3.6.1.4.1.26138.2.5.1.1.2.1.1.13893633	Integer	13893633
ibFlhSize.13893633	.1.3.6.1.4.1.26138.2.5.1.1.2.1.2.13893633	Integer	517996544
ibFlhName.13893633	.1.3.6.1.4.1.26138.2.5.1.1.2.1.4.13893633	OctetString	flash:
ibFlhKbyteSize.13893633	.1.3.6.1.4.1.26138.2.5.1.1.2.1.15.13893633	Integer	505856
ibFlhPartSpace.13893633.1	.1.3.6.1.4.1.26138.2.5.1.1.4.1.1.4.13893633	Integer	517996544
ibFlhPartSpace-Free.13893633.1	.1.3.6.1.4.1.26138.2.5.1.1.4.1.1.5.13893633	Gauge	187088896
ibFlhPartStatus.13893633.1	.1.3.6.1.4.1.26138.2.5.1.1.4.1.1.8.13893633	Integer	readWrite (3)
ibFlhPartName.13893633.1	.1.3.6.1.4.1.26138.2.5.1.1.4.1.1.10.13893633	OctetString	flash:
ibFlhPartBootable.13893633.1	.1.3.6.1.4.1.26138.2.5.1.1.4.1.1.13.13893633	Integer	true (1)
ibFlhPartPathForGlobalOpt.13893633.1	.1.3.6.1.4.1.26138.2.5.1.1.4.1.1.14.13893633	Integer	true (1)
ibFlhFileName.13893633.1	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/startup.mdb
ibFlhFileName.13893633.2	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/startup.cfg
ibFlhFileName.13893633.3	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/ifindex.dat
ibFlhFileName.13893633.4	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/sc3570-ibos710-system-r1124.bin
ibFlhFileName.13893633.5	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/sc3570-ibos710-system-f1125p01.bin
ibFlhFileName.13893633.6	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/sc3570-ibos710-system-a1122p02.bin
ibFlhFileName.13893633.7	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/sc3570-ibos710-system-r1122.bin
ibFlhFileName.13893633.8	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/sc3570-ibos710-boot-r1122.bin
ibFlhFileName.13893633.9	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/sc3570-ibos710-boot-f1125p01.bin
ibFlhFileName.13893633.10	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/sc3570-ibos710-boot-r1124.bin
ibFlhFileName.13893633.11	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/sc3570-ibos710-boot-a1122p02.bin
ibFlhFileName.13893633.12	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/s5570s_ei-cmw710-system-r1115.bin
ibFlhFileName.13893633.13	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/s5570s_ei-cmw710-boot-r1115.bin
ibFlhFileName.13893633.14	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/versionInfo
ibFlhFileName.13893633.15	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/versionInfo/version1.dat
ibFlhFileName.13893633.16	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/versionInfo/version0.dat
ibFlhFileName.13893633.17	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/versionInfo/versionCtl.dat
ibFlhFileName.13893633.18	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/pki
ibFlhFileName.13893633.19	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/pki/https-server.p12
ibFlhFileName.13893633.20	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/serverkey
ibFlhFileName.13893633.21	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/hostkey
ibFlhFileName.13893633.22	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/seclog
ibFlhFileName.13893633.23	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/logfile
ibFlhFileName.13893633.24	.1.3.6.1.4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/logfile/logfile.log

Name	OID	Value Type	Value Example
ibFlhFileName.13893633.1.256.1	4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/diagfile
ibFlhFileName.13893633.1.266.1	4.1.26138.2.5.1.1.4.2.1.1.2.13893633	OctetString	flash:/snmpboots
ibFlhFileSize.13893633.1.1.1.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	309150
ibFlhFileSize.13893633.1.2.1.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	7290
ibFlhFileSize.13893633.1.3.1.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	1563
ibFlhFileSize.13893633.1.4.1.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	54367232
ibFlhFileSize.13893633.1.5.1.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	54606848
ibFlhFileSize.13893633.1.6.1.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	49741824
ibFlhFileSize.13893633.1.7.1.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	49377280
ibFlhFileSize.13893633.1.8.1.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	4864000
ibFlhFileSize.13893633.1.9.1.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	4864000
ibFlhFileSize.13893633.1.10.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	4858880
ibFlhFileSize.13893633.1.11.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	4864000
ibFlhFileSize.13893633.1.12.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	81301504
ibFlhFileSize.13893633.1.13.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	6330368
ibFlhFileSize.13893633.1.14.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	2048
ibFlhFileSize.13893633.1.15.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	536
ibFlhFileSize.13893633.1.16.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	536
ibFlhFileSize.13893633.1.17.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	8
ibFlhFileSize.13893633.1.18.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	2048
ibFlhFileSize.13893633.1.19.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	2398
ibFlhFileSize.13893633.1.20.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	591
ibFlhFileSize.13893633.1.21.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	735
ibFlhFileSize.13893633.1.22.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	2048
ibFlhFileSize.13893633.1.23.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	2048
ibFlhFileSize.13893633.1.24.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	10485745
ibFlhFileSize.13893633.1.25.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	2048
ibFlhFileSize.13893633.1.26.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.3.13893633	Integer	21
ibFlhFileStatus.13893633.113.6.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1123.6.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1133.6.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1143.6.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1153.6.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1163.6.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1173.6.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1183.6.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1193.6.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1.206.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1.216.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1.226.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1.236.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1.246.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1.256.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)



Name	OID	Value Type	Value Example
ibFlhFileStatus.13893633.1.136.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1.137.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1.138.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1.139.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1.140.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1.141.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1.142.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1.143.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1.144.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1.145.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileStatus.13893633.1.146.1	4.1.26138.2.5.1.1.4.2.1.1.4.13893633	Integer	valid (3)
ibFlhFileType.13893633.1.11.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	file (1)
ibFlhFileType.13893633.1.12.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	file (1)
ibFlhFileType.13893633.1.13.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	file (1)
ibFlhFileType.13893633.1.14.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	file (1)
ibFlhFileType.13893633.1.15.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	file (1)
ibFlhFileType.13893633.1.16.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	file (1)
ibFlhFileType.13893633.1.17.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	file (1)
ibFlhFileType.13893633.1.18.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	file (1)
ibFlhFileType.13893633.1.19.3.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	file (1)
ibFlhFileType.13893633.1.10.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	file (1)
ibFlhFileType.13893633.1.11.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	file (1)
ibFlhFileType.13893633.1.12.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	file (1)
ibFlhFileType.13893633.1.13.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	file (1)
ibFlhFileType.13893633.1.14.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	directory (2)
ibFlhFileType.13893633.1.15.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	file (1)
ibFlhFileType.13893633.1.16.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	file (1)
ibFlhFileType.13893633.1.17.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	file (1)
ibFlhFileType.13893633.1.18.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	directory (2)
ibFlhFileType.13893633.1.19.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	file (1)
ibFlhFileType.13893633.1.20.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	file (1)
ibFlhFileType.13893633.1.21.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	file (1)
ibFlhFileType.13893633.1.22.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	directory (2)
ibFlhFileType.13893633.1.23.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	directory (2)
ibFlhFileType.13893633.1.24.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	file (1)
ibFlhFileType.13893633.1.25.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	directory (2)
ibFlhFileType.13893633.1.26.6.1	4.1.26138.2.5.1.1.4.2.1.1.7.13893633	Integer	file (1)
ibEntityExtAdminStatus.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.2.1	Integer	notSupported (1)
ibEntityExtAdminStatus.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.2.2	Integer	notSupported (1)
ibEntityExtAdminStatus.12	.1.3.6.1.4.1.26138.2.6.1.1.1.1.2.12	Integer	notSupported (1)
ibEntityExtAdminStatus.13	.1.3.6.1.4.1.26138.2.6.1.1.1.1.2.13	Integer	notSupported (1)
ibEntityExtAdminStatus.14	.1.3.6.1.4.1.26138.2.6.1.1.1.1.2.14	Integer	notSupported (1)
ibEntityExtAdminStatus.15	.1.3.6.1.4.1.26138.2.6.1.1.1.1.2.15	Integer	notSupported (1)



Name	OID	Value Type	Value Example
ibEntityExtAdminStatus.16	.1.3.6.1.4.1.26138.2.6.1.1.1.1.2.16	Integer	notSupported (1)
ibEntityExtAdminStatus.17	.1.3.6.1.4.1.26138.2.6.1.1.1.1.2.17	Integer	notSupported (1)
ibEntityExtAdminStatus.18	.1.3.6.1.4.1.26138.2.6.1.1.1.1.2.18	Integer	notSupported (1)
ibEntityExtAdminStatus.19	.1.3.6.1.4.1.26138.2.6.1.1.1.1.2.19	Integer	notSupported (1)
ibEntityExtAdminStatus.20	.1.3.6.1.4.1.26138.2.6.1.1.1.1.2.20	Integer	notSupported (1)
ibEntityExtAdminStatus.21	.1.3.6.1.4.1.26138.2.6.1.1.1.1.2.21	Integer	notSupported (1)
ibEntityExtAdminStatus.22	.1.3.6.1.4.1.26138.2.6.1.1.1.1.2.22	Integer	notSupported (1)
ibEntityExtAdminStatus.23	.1.3.6.1.4.1.26138.2.6.1.1.1.1.2.23	Integer	notSupported (1)
ibEntityExtAdminStatus.24	.1.3.6.1.4.1.26138.2.6.1.1.1.1.2.24	Integer	notSupported (1)
ibEntityExtAdminStatus.25	.1.3.6.1.4.1.26138.2.6.1.1.1.1.2.25	Integer	notSupported (1)
ibEntityExtAdminStatus.26	.1.3.6.1.4.1.26138.2.6.1.1.1.1.2.26	Integer	notSupported (1)
ibEntityExtAdminStatus.27	.1.3.6.1.4.1.26138.2.6.1.1.1.1.2.27	Integer	notSupported (1)
ibEntityExtAdminStatus.28	.1.3.6.1.4.1.26138.2.6.1.1.1.1.2.28	Integer	notSupported (1)
ibEntityExtAdminStatus.29	.1.3.6.1.4.1.26138.2.6.1.1.1.1.2.29	Integer	notSupported (1)
ibEntityExtAdminStatus.30	.1.3.6.1.4.1.26138.2.6.1.1.1.1.2.30	Integer	notSupported (1)
ibEntityExtAdminStatus.31	.1.3.6.1.4.1.26138.2.6.1.1.1.1.2.31	Integer	notSupported (1)
ibEntityExtAdminStatus.212	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.212	Integer	notSupported (1)
ibEntityExtAdminStatus.213	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.213	Integer	notSupported (1)
ibEntityExtAdminStatus.216	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.216	Integer	notSupported (1)
ibEntityExtAdminStatus.220	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.220	Integer	notSupported (1)
ibEntityExtAdminStatus.221	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.221	Integer	notSupported (1)
ibEntityExtAdminStatus.412	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.412	Integer	notSupported (1)
ibEntityExtAdminStatus.413	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.413	Integer	notSupported (1)
ibEntityExtAdminStatus.414	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.414	Integer	notSupported (1)
ibEntityExtAdminStatus.442	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.442	Integer	notSupported (1)
ibEntityExtAdminStatus.472	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.472	Integer	unlocked (4)
ibEntityExtAdminStatus.473	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.473	Integer	unlocked (4)
ibEntityExtAdminStatus.474	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.474	Integer	unlocked (4)
ibEntityExtAdminStatus.475	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.475	Integer	unlocked (4)
ibEntityExtAdminStatus.476	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.476	Integer	unlocked (4)
ibEntityExtAdminStatus.477	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.477	Integer	unlocked (4)
ibEntityExtAdminStatus.478	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.478	Integer	unlocked (4)
ibEntityExtAdminStatus.479	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.479	Integer	unlocked (4)
ibEntityExtAdminStatus.480	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.480	Integer	unlocked (4)
ibEntityExtAdminStatus.481	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.481	Integer	unlocked (4)
ibEntityExtAdminStatus.482	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.482	Integer	unlocked (4)
ibEntityExtAdminStatus.483	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.483	Integer	unlocked (4)
ibEntityExtAdminStatus.484	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.484	Integer	unlocked (4)
ibEntityExtAdminStatus.485	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.485	Integer	unlocked (4)
ibEntityExtAdminStatus.486	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.486	Integer	unlocked (4)
ibEntityExtAdminStatus.487	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.487	Integer	unlocked (4)
ibEntityExtAdminStatus.488	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.488	Integer	unlocked (4)
ibEntityExtAdminStatus.489	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.489	Integer	unlocked (4)

Name	OID	Value Type	Value Example
ibEntityExtAdminStatus.490	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.490	Integer	unlocked (4)
ibEntityExtAdminStatus.491	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.491	Integer	unlocked (4)
ibEntityExtAdminStatus.492	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.492	Integer	unlocked (4)
ibEntityExtAdminStatus.493	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.493	Integer	unlocked (4)
ibEntityExtAdminStatus.494	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.494	Integer	unlocked (4)
ibEntityExtAdminStatus.495	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.495	Integer	unlocked (4)
ibEntityExtAdminStatus.496	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.496	Integer	unlocked (4)
ibEntityExtAdminStatus.497	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.497	Integer	unlocked (4)
ibEntityExtAdminStatus.498	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.498	Integer	unlocked (4)
ibEntityExtAdminStatus.499	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.499	Integer	unlocked (4)
ibEntityExtAdminStatus.500	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.500	Integer	unlocked (4)
ibEntityExtAdminStatus.501	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.501	Integer	unlocked (4)
ibEntityExtAdminStatus.502	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.502	Integer	unlocked (4)
ibEntityExtAdminStatus.503	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.503	Integer	unlocked (4)
ibEntityExtAdminStatus.504	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.504	Integer	unlocked (4)
ibEntityExtAdminStatus.505	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.505	Integer	unlocked (4)
ibEntityExtAdminStatus.506	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.506	Integer	unlocked (4)
ibEntityExtAdminStatus.507	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.507	Integer	unlocked (4)
ibEntityExtAdminStatus.508	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.508	Integer	unlocked (4)
ibEntityExtAdminStatus.509	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.509	Integer	unlocked (4)
ibEntityExtAdminStatus.510	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.510	Integer	unlocked (4)
ibEntityExtAdminStatus.511	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.511	Integer	unlocked (4)
ibEntityExtAdminStatus.512	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.512	Integer	unlocked (4)
ibEntityExtAdminStatus.513	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.513	Integer	unlocked (4)
ibEntityExtAdminStatus.514	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.514	Integer	unlocked (4)
ibEntityExtAdminStatus.515	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.515	Integer	unlocked (4)
ibEntityExtAdminStatus.516	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.516	Integer	unlocked (4)
ibEntityExtAdminStatus.517	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.517	Integer	unlocked (4)
ibEntityExtAdminStatus.518	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.518	Integer	unlocked (4)
ibEntityExtAdminStatus.519	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.519	Integer	unlocked (4)
ibEntityExtAdminStatus.520	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.520	Integer	unlocked (4)
ibEntityExtAdminStatus.521	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.521	Integer	unlocked (4)
ibEntityExtAdminStatus.522	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.522	Integer	unlocked (4)
ibEntityExtAdminStatus.523	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.523	Integer	unlocked (4)
ibEntityExtAdminStatus.524	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.524	Integer	unlocked (4)
ibEntityExtAdminStatus.525	1.3.6.1.4.1.26138.2.6.1.1.1.1.2.525	Integer	unlocked (4)
ibEntityExtOperStatus.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.3.1	Integer	notSupported (1)
ibEntityExtOperStatus.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.3.2	Integer	notSupported (1)
ibEntityExtOperStatus.12	.1.3.6.1.4.1.26138.2.6.1.1.1.1.3.12	Integer	enabled (3)
ibEntityExtOperStatus.13	.1.3.6.1.4.1.26138.2.6.1.1.1.1.3.13	Integer	enabled (3)
ibEntityExtOperStatus.14	.1.3.6.1.4.1.26138.2.6.1.1.1.1.3.14	Integer	enabled (3)
ibEntityExtOperStatus.15	.1.3.6.1.4.1.26138.2.6.1.1.1.1.3.15	Integer	enabled (3)
ibEntityExtOperStatus.16	.1.3.6.1.4.1.26138.2.6.1.1.1.1.3.16	Integer	enabled (3)

Name	OID	Value Type	Value Example
ibEntityExtOperStatus.17	.1.3.6.1.4.1.26138.2.6.1.1.1.1.3.17	Integer	enabled (3)
ibEntityExtOperStatus.18	.1.3.6.1.4.1.26138.2.6.1.1.1.1.3.18	Integer	enabled (3)
ibEntityExtOperStatus.19	.1.3.6.1.4.1.26138.2.6.1.1.1.1.3.19	Integer	enabled (3)
ibEntityExtOperStatus.20	.1.3.6.1.4.1.26138.2.6.1.1.1.1.3.20	Integer	enabled (3)
ibEntityExtOperStatus.21	.1.3.6.1.4.1.26138.2.6.1.1.1.1.3.21	Integer	enabled (3)
ibEntityExtOperStatus.22	.1.3.6.1.4.1.26138.2.6.1.1.1.1.3.22	Integer	enabled (3)
ibEntityExtOperStatus.23	.1.3.6.1.4.1.26138.2.6.1.1.1.1.3.23	Integer	enabled (3)
ibEntityExtOperStatus.24	.1.3.6.1.4.1.26138.2.6.1.1.1.1.3.24	Integer	enabled (3)
ibEntityExtOperStatus.25	.1.3.6.1.4.1.26138.2.6.1.1.1.1.3.25	Integer	enabled (3)
ibEntityExtOperStatus.26	.1.3.6.1.4.1.26138.2.6.1.1.1.1.3.26	Integer	enabled (3)
ibEntityExtOperStatus.27	.1.3.6.1.4.1.26138.2.6.1.1.1.1.3.27	Integer	enabled (3)
ibEntityExtOperStatus.28	.1.3.6.1.4.1.26138.2.6.1.1.1.1.3.28	Integer	enabled (3)
ibEntityExtOperStatus.29	.1.3.6.1.4.1.26138.2.6.1.1.1.1.3.29	Integer	enabled (3)
ibEntityExtOperStatus.30	.1.3.6.1.4.1.26138.2.6.1.1.1.1.3.30	Integer	enabled (3)
ibEntityExtOperStatus.31	.1.3.6.1.4.1.26138.2.6.1.1.1.1.3.31	Integer	enabled (3)
ibEntityExtOperStatus.212	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.212	Integer	enabled (3)
ibEntityExtOperStatus.213	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.213	Integer	enabled (3)
ibEntityExtOperStatus.216	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.216	Integer	enabled (3)
ibEntityExtOperStatus.220	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.220	Integer	notSupported (1)
ibEntityExtOperStatus.221	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.221	Integer	notSupported (1)
ibEntityExtOperStatus.412	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.412	Integer	enabled (3)
ibEntityExtOperStatus.413	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.413	Integer	notSupported (1)
ibEntityExtOperStatus.414	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.414	Integer	notSupported (1)
ibEntityExtOperStatus.442	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.442	Integer	enabled (3)
ibEntityExtOperStatus.472	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.472	Integer	enabled (3)
ibEntityExtOperStatus.473	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.473	Integer	disabled (2)
ibEntityExtOperStatus.474	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.474	Integer	disabled (2)
ibEntityExtOperStatus.475	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.475	Integer	disabled (2)
ibEntityExtOperStatus.476	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.476	Integer	disabled (2)
ibEntityExtOperStatus.477	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.477	Integer	disabled (2)
ibEntityExtOperStatus.478	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.478	Integer	disabled (2)
ibEntityExtOperStatus.479	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.479	Integer	disabled (2)
ibEntityExtOperStatus.480	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.480	Integer	disabled (2)
ibEntityExtOperStatus.481	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.481	Integer	disabled (2)
ibEntityExtOperStatus.482	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.482	Integer	disabled (2)
ibEntityExtOperStatus.483	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.483	Integer	disabled (2)
ibEntityExtOperStatus.484	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.484	Integer	disabled (2)
ibEntityExtOperStatus.485	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.485	Integer	disabled (2)
ibEntityExtOperStatus.486	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.486	Integer	disabled (2)
ibEntityExtOperStatus.487	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.487	Integer	disabled (2)
ibEntityExtOperStatus.488	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.488	Integer	disabled (2)
ibEntityExtOperStatus.489	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.489	Integer	disabled (2)
ibEntityExtOperStatus.490	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.490	Integer	disabled (2)

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ibEntityExtOperStatus.491	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.491	Integer	disabled (2)
ibEntityExtOperStatus.492	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.492	Integer	disabled (2)
ibEntityExtOperStatus.493	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.493	Integer	disabled (2)
ibEntityExtOperStatus.494	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.494	Integer	disabled (2)
ibEntityExtOperStatus.495	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.495	Integer	disabled (2)
ibEntityExtOperStatus.496	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.496	Integer	disabled (2)
ibEntityExtOperStatus.497	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.497	Integer	disabled (2)
ibEntityExtOperStatus.498	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.498	Integer	disabled (2)
ibEntityExtOperStatus.499	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.499	Integer	disabled (2)
ibEntityExtOperStatus.500	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.500	Integer	disabled (2)
ibEntityExtOperStatus.501	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.501	Integer	disabled (2)
ibEntityExtOperStatus.502	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.502	Integer	disabled (2)
ibEntityExtOperStatus.503	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.503	Integer	disabled (2)
ibEntityExtOperStatus.504	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.504	Integer	disabled (2)
ibEntityExtOperStatus.505	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.505	Integer	disabled (2)
ibEntityExtOperStatus.506	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.506	Integer	disabled (2)
ibEntityExtOperStatus.507	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.507	Integer	disabled (2)
ibEntityExtOperStatus.508	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.508	Integer	disabled (2)
ibEntityExtOperStatus.509	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.509	Integer	disabled (2)
ibEntityExtOperStatus.510	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.510	Integer	disabled (2)
ibEntityExtOperStatus.511	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.511	Integer	disabled (2)
ibEntityExtOperStatus.512	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.512	Integer	disabled (2)
ibEntityExtOperStatus.513	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.513	Integer	disabled (2)
ibEntityExtOperStatus.514	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.514	Integer	disabled (2)
ibEntityExtOperStatus.515	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.515	Integer	disabled (2)
ibEntityExtOperStatus.516	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.516	Integer	disabled (2)
ibEntityExtOperStatus.517	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.517	Integer	disabled (2)
ibEntityExtOperStatus.518	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.518	Integer	disabled (2)
ibEntityExtOperStatus.519	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.519	Integer	disabled (2)
ibEntityExtOperStatus.520	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.520	Integer	disabled (2)
ibEntityExtOperStatus.521	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.521	Integer	disabled (2)
ibEntityExtOperStatus.522	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.522	Integer	disabled (2)
ibEntityExtOperStatus.523	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.523	Integer	disabled (2)
ibEntityExtOperStatus.524	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.524	Integer	disabled (2)
ibEntityExtOperStatus.525	1.3.6.1.4.1.26138.2.6.1.1.1.1.3.525	Integer	disabled (2)
ibEntityExtStandbyStatus.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.4.1	Integer	notSupported (1)
ibEntityExtStandbyStatus.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.4.2	Integer	notSupported (1)
ibEntityExtStandbyStatus.12	.1.3.6.1.4.1.26138.2.6.1.1.1.1.4.12	Integer	notSupported (1)
ibEntityExtStandbyStatus.13	.1.3.6.1.4.1.26138.2.6.1.1.1.1.4.13	Integer	notSupported (1)
ibEntityExtStandbyStatus.14	.1.3.6.1.4.1.26138.2.6.1.1.1.1.4.14	Integer	notSupported (1)
ibEntityExtStandbyStatus.15	.1.3.6.1.4.1.26138.2.6.1.1.1.1.4.15	Integer	notSupported (1)
ibEntityExtStandbyStatus.16	.1.3.6.1.4.1.26138.2.6.1.1.1.1.4.16	Integer	notSupported (1)
ibEntityExtStandbyStatus.17	.1.3.6.1.4.1.26138.2.6.1.1.1.1.4.17	Integer	notSupported (1)

Name	OID	Value Type	Value Example
ibEntityExtStandbyStatus.18	.1.3.6.1.4.1.26138.2.6.1.1.1.1.4.18	Integer	notSupported (1)
ibEntityExtStandbyStatus.19	.1.3.6.1.4.1.26138.2.6.1.1.1.1.4.19	Integer	notSupported (1)
ibEntityExtStandbyStatus.20	.1.3.6.1.4.1.26138.2.6.1.1.1.1.4.20	Integer	notSupported (1)
ibEntityExtStandbyStatus.21	.1.3.6.1.4.1.26138.2.6.1.1.1.1.4.21	Integer	notSupported (1)
ibEntityExtStandbyStatus.22	.1.3.6.1.4.1.26138.2.6.1.1.1.1.4.22	Integer	notSupported (1)
ibEntityExtStandbyStatus.23	.1.3.6.1.4.1.26138.2.6.1.1.1.1.4.23	Integer	notSupported (1)
ibEntityExtStandbyStatus.24	.1.3.6.1.4.1.26138.2.6.1.1.1.1.4.24	Integer	notSupported (1)
ibEntityExtStandbyStatus.25	.1.3.6.1.4.1.26138.2.6.1.1.1.1.4.25	Integer	notSupported (1)
ibEntityExtStandbyStatus.26	.1.3.6.1.4.1.26138.2.6.1.1.1.1.4.26	Integer	notSupported (1)
ibEntityExtStandbyStatus.27	.1.3.6.1.4.1.26138.2.6.1.1.1.1.4.27	Integer	notSupported (1)
ibEntityExtStandbyStatus.28	.1.3.6.1.4.1.26138.2.6.1.1.1.1.4.28	Integer	notSupported (1)
ibEntityExtStandbyStatus.29	.1.3.6.1.4.1.26138.2.6.1.1.1.1.4.29	Integer	notSupported (1)
ibEntityExtStandbyStatus.30	.1.3.6.1.4.1.26138.2.6.1.1.1.1.4.30	Integer	notSupported (1)
ibEntityExtStandbyStatus.31	.1.3.6.1.4.1.26138.2.6.1.1.1.1.4.31	Integer	notSupported (1)
ibEntityExtStandbyStatus.212	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.212	Integer	providingService (4)
ibEntityExtStandbyStatus.213	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.213	Integer	providingService (4)
ibEntityExtStandbyStatus.216	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.216	Integer	providingService (4)
ibEntityExtStandbyStatus.220	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.220	Integer	notSupported (1)
ibEntityExtStandbyStatus.221	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.221	Integer	notSupported (1)
ibEntityExtStandbyStatus.412	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.412	Integer	notSupported (1)
ibEntityExtStandbyStatus.413	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.413	Integer	notSupported (1)
ibEntityExtStandbyStatus.414	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.414	Integer	notSupported (1)
ibEntityExtStandbyStatus.442	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.442	Integer	providingService (4)
ibEntityExtStandbyStatus.472	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.472	Integer	notSupported (1)
ibEntityExtStandbyStatus.473	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.473	Integer	notSupported (1)
ibEntityExtStandbyStatus.474	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.474	Integer	notSupported (1)
ibEntityExtStandbyStatus.475	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.475	Integer	notSupported (1)
ibEntityExtStandbyStatus.476	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.476	Integer	notSupported (1)
ibEntityExtStandbyStatus.477	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.477	Integer	notSupported (1)
ibEntityExtStandbyStatus.478	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.478	Integer	notSupported (1)
ibEntityExtStandbyStatus.479	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.479	Integer	notSupported (1)
ibEntityExtStandbyStatus.480	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.480	Integer	notSupported (1)
ibEntityExtStandbyStatus.481	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.481	Integer	notSupported (1)
ibEntityExtStandbyStatus.482	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.482	Integer	notSupported (1)
ibEntityExtStandbyStatus.483	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.483	Integer	notSupported (1)
ibEntityExtStandbyStatus.484	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.484	Integer	notSupported (1)
ibEntityExtStandbyStatus.485	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.485	Integer	notSupported (1)
ibEntityExtStandbyStatus.486	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.486	Integer	notSupported (1)
ibEntityExtStandbyStatus.487	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.487	Integer	notSupported (1)
ibEntityExtStandbyStatus.488	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.488	Integer	notSupported (1)
ibEntityExtStandbyStatus.489	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.489	Integer	notSupported (1)
ibEntityExtStandbyStatus.490	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.490	Integer	notSupported (1)
ibEntityExtStandbyStatus.491	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.491	Integer	notSupported (1)

Name	OID	Value Type	Value Example
ibEntityExtStandbyStatus.492	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.492	Integer	notSupported (1)
ibEntityExtStandbyStatus.493	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.493	Integer	notSupported (1)
ibEntityExtStandbyStatus.494	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.494	Integer	notSupported (1)
ibEntityExtStandbyStatus.495	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.495	Integer	notSupported (1)
ibEntityExtStandbyStatus.496	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.496	Integer	notSupported (1)
ibEntityExtStandbyStatus.497	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.497	Integer	notSupported (1)
ibEntityExtStandbyStatus.498	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.498	Integer	notSupported (1)
ibEntityExtStandbyStatus.499	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.499	Integer	notSupported (1)
ibEntityExtStandbyStatus.500	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.500	Integer	notSupported (1)
ibEntityExtStandbyStatus.501	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.501	Integer	notSupported (1)
ibEntityExtStandbyStatus.502	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.502	Integer	notSupported (1)
ibEntityExtStandbyStatus.503	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.503	Integer	notSupported (1)
ibEntityExtStandbyStatus.504	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.504	Integer	notSupported (1)
ibEntityExtStandbyStatus.505	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.505	Integer	notSupported (1)
ibEntityExtStandbyStatus.506	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.506	Integer	notSupported (1)
ibEntityExtStandbyStatus.507	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.507	Integer	notSupported (1)
ibEntityExtStandbyStatus.508	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.508	Integer	notSupported (1)
ibEntityExtStandbyStatus.509	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.509	Integer	notSupported (1)
ibEntityExtStandbyStatus.510	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.510	Integer	notSupported (1)
ibEntityExtStandbyStatus.511	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.511	Integer	notSupported (1)
ibEntityExtStandbyStatus.512	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.512	Integer	notSupported (1)
ibEntityExtStandbyStatus.513	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.513	Integer	notSupported (1)
ibEntityExtStandbyStatus.514	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.514	Integer	notSupported (1)
ibEntityExtStandbyStatus.515	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.515	Integer	notSupported (1)
ibEntityExtStandbyStatus.516	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.516	Integer	notSupported (1)
ibEntityExtStandbyStatus.517	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.517	Integer	notSupported (1)
ibEntityExtStandbyStatus.518	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.518	Integer	notSupported (1)
ibEntityExtStandbyStatus.519	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.519	Integer	notSupported (1)
ibEntityExtStandbyStatus.520	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.520	Integer	notSupported (1)
ibEntityExtStandbyStatus.521	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.521	Integer	notSupported (1)
ibEntityExtStandbyStatus.522	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.522	Integer	notSupported (1)
ibEntityExtStandbyStatus.523	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.523	Integer	notSupported (1)
ibEntityExtStandbyStatus.524	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.524	Integer	notSupported (1)
ibEntityExtStandbyStatus.525	1.3.6.1.4.1.26138.2.6.1.1.1.1.4.525	Integer	notSupported (1)
ibEntityExtAlarmLight.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.5.1	OctetString	{}
ibEntityExtAlarmLight.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.5.2	OctetString	{}
ibEntityExtAlarmLight.12	.1.3.6.1.4.1.26138.2.6.1.1.1.1.5.12	OctetString	{}
ibEntityExtAlarmLight.13	.1.3.6.1.4.1.26138.2.6.1.1.1.1.5.13	OctetString	{}
ibEntityExtAlarmLight.14	.1.3.6.1.4.1.26138.2.6.1.1.1.1.5.14	OctetString	{}
ibEntityExtAlarmLight.15	.1.3.6.1.4.1.26138.2.6.1.1.1.1.5.15	OctetString	{}
ibEntityExtAlarmLight.16	.1.3.6.1.4.1.26138.2.6.1.1.1.1.5.16	OctetString	{}
ibEntityExtAlarmLight.17	.1.3.6.1.4.1.26138.2.6.1.1.1.1.5.17	OctetString	{}
ibEntityExtAlarmLight.18	.1.3.6.1.4.1.26138.2.6.1.1.1.1.5.18	OctetString	{}



Name	OID	Value Type	Value Example
ibEntityExtAlarmLight.19	.1.3.6.1.4.1.26138.2.6.1.1.1.1.5.19	OctetString	{}
ibEntityExtAlarmLight.20	.1.3.6.1.4.1.26138.2.6.1.1.1.1.5.20	OctetString	{}
ibEntityExtAlarmLight.21	.1.3.6.1.4.1.26138.2.6.1.1.1.1.5.21	OctetString	{}
ibEntityExtAlarmLight.22	.1.3.6.1.4.1.26138.2.6.1.1.1.1.5.22	OctetString	{}
ibEntityExtAlarmLight.23	.1.3.6.1.4.1.26138.2.6.1.1.1.1.5.23	OctetString	{}
ibEntityExtAlarmLight.24	.1.3.6.1.4.1.26138.2.6.1.1.1.1.5.24	OctetString	{}
ibEntityExtAlarmLight.25	.1.3.6.1.4.1.26138.2.6.1.1.1.1.5.25	OctetString	{}
ibEntityExtAlarmLight.26	.1.3.6.1.4.1.26138.2.6.1.1.1.1.5.26	OctetString	{}
ibEntityExtAlarmLight.27	.1.3.6.1.4.1.26138.2.6.1.1.1.1.5.27	OctetString	{}
ibEntityExtAlarmLight.28	.1.3.6.1.4.1.26138.2.6.1.1.1.1.5.28	OctetString	{}
ibEntityExtAlarmLight.29	.1.3.6.1.4.1.26138.2.6.1.1.1.1.5.29	OctetString	{}
ibEntityExtAlarmLight.30	.1.3.6.1.4.1.26138.2.6.1.1.1.1.5.30	OctetString	{}
ibEntityExtAlarmLight.31	.1.3.6.1.4.1.26138.2.6.1.1.1.1.5.31	OctetString	{}
ibEntityExtAlarmLight.212	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.212	OctetString	{}
ibEntityExtAlarmLight.213	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.213	OctetString	{}
ibEntityExtAlarmLight.216	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.216	OctetString	{}
ibEntityExtAlarmLight.220	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.220	OctetString	{}
ibEntityExtAlarmLight.221	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.221	OctetString	{}
ibEntityExtAlarmLight.412	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.412	OctetString	{}
ibEntityExtAlarmLight.413	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.413	OctetString	{}
ibEntityExtAlarmLight.414	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.414	OctetString	{}
ibEntityExtAlarmLight.442	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.442	OctetString	{}
ibEntityExtAlarmLight.472	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.472	OctetString	{}
ibEntityExtAlarmLight.473	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.473	OctetString	{}
ibEntityExtAlarmLight.474	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.474	OctetString	{}
ibEntityExtAlarmLight.475	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.475	OctetString	{}
ibEntityExtAlarmLight.476	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.476	OctetString	{}
ibEntityExtAlarmLight.477	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.477	OctetString	{}
ibEntityExtAlarmLight.478	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.478	OctetString	{}
ibEntityExtAlarmLight.479	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.479	OctetString	{}
ibEntityExtAlarmLight.480	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.480	OctetString	{}
ibEntityExtAlarmLight.481	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.481	OctetString	{}
ibEntityExtAlarmLight.482	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.482	OctetString	{}
ibEntityExtAlarmLight.483	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.483	OctetString	{}
ibEntityExtAlarmLight.484	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.484	OctetString	{}
ibEntityExtAlarmLight.485	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.485	OctetString	{}
ibEntityExtAlarmLight.486	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.486	OctetString	{}
ibEntityExtAlarmLight.487	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.487	OctetString	{}
ibEntityExtAlarmLight.488	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.488	OctetString	{}
ibEntityExtAlarmLight.489	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.489	OctetString	{}
ibEntityExtAlarmLight.490	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.490	OctetString	{}
ibEntityExtAlarmLight.491	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.491	OctetString	{}
ibEntityExtAlarmLight.492	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.492	OctetString	{}

Name	OID	Value Type	Value Example
ibEntityExtAlarmLight.493	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.493	OctetString	{}
ibEntityExtAlarmLight.494	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.494	OctetString	{}
ibEntityExtAlarmLight.495	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.495	OctetString	{}
ibEntityExtAlarmLight.496	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.496	OctetString	{}
ibEntityExtAlarmLight.497	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.497	OctetString	{}
ibEntityExtAlarmLight.498	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.498	OctetString	{}
ibEntityExtAlarmLight.499	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.499	OctetString	{}
ibEntityExtAlarmLight.500	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.500	OctetString	{}
ibEntityExtAlarmLight.501	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.501	OctetString	{}
ibEntityExtAlarmLight.502	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.502	OctetString	{}
ibEntityExtAlarmLight.503	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.503	OctetString	{}
ibEntityExtAlarmLight.504	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.504	OctetString	{}
ibEntityExtAlarmLight.505	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.505	OctetString	{}
ibEntityExtAlarmLight.506	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.506	OctetString	{}
ibEntityExtAlarmLight.507	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.507	OctetString	{}
ibEntityExtAlarmLight.508	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.508	OctetString	{}
ibEntityExtAlarmLight.509	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.509	OctetString	{}
ibEntityExtAlarmLight.510	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.510	OctetString	{}
ibEntityExtAlarmLight.511	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.511	OctetString	{}
ibEntityExtAlarmLight.512	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.512	OctetString	{}
ibEntityExtAlarmLight.513	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.513	OctetString	{}
ibEntityExtAlarmLight.514	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.514	OctetString	{}
ibEntityExtAlarmLight.515	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.515	OctetString	{}
ibEntityExtAlarmLight.516	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.516	OctetString	{}
ibEntityExtAlarmLight.517	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.517	OctetString	{}
ibEntityExtAlarmLight.518	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.518	OctetString	{}
ibEntityExtAlarmLight.519	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.519	OctetString	{}
ibEntityExtAlarmLight.520	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.520	OctetString	{}
ibEntityExtAlarmLight.521	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.521	OctetString	{}
ibEntityExtAlarmLight.522	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.522	OctetString	{}
ibEntityExtAlarmLight.523	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.523	OctetString	{}
ibEntityExtAlarmLight.524	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.524	OctetString	{}
ibEntityExtAlarmLight.525	1.3.6.1.4.1.26138.2.6.1.1.1.1.5.525	OctetString	{}
ibEntityExtCpuUsage.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.6.1	Integer	0
ibEntityExtCpuUsage.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.6.2	Integer	0
ibEntityExtCpuUsage.12	.1.3.6.1.4.1.26138.2.6.1.1.1.1.6.12	Integer	0
ibEntityExtCpuUsage.13	.1.3.6.1.4.1.26138.2.6.1.1.1.1.6.13	Integer	0
ibEntityExtCpuUsage.14	.1.3.6.1.4.1.26138.2.6.1.1.1.1.6.14	Integer	0
ibEntityExtCpuUsage.15	.1.3.6.1.4.1.26138.2.6.1.1.1.1.6.15	Integer	0
ibEntityExtCpuUsage.16	.1.3.6.1.4.1.26138.2.6.1.1.1.1.6.16	Integer	0
ibEntityExtCpuUsage.17	.1.3.6.1.4.1.26138.2.6.1.1.1.1.6.17	Integer	0
ibEntityExtCpuUsage.18	.1.3.6.1.4.1.26138.2.6.1.1.1.1.6.18	Integer	0
ibEntityExtCpuUsage.19	.1.3.6.1.4.1.26138.2.6.1.1.1.1.6.19	Integer	0



Name	OID	Value Type	Value Example
ibEntityExtCpuUsage.20	.1.3.6.1.4.1.26138.2.6.1.1.1.1.6.20	Integer	0
ibEntityExtCpuUsage.21	.1.3.6.1.4.1.26138.2.6.1.1.1.1.6.21	Integer	0
ibEntityExtCpuUsage.22	.1.3.6.1.4.1.26138.2.6.1.1.1.1.6.22	Integer	0
ibEntityExtCpuUsage.23	.1.3.6.1.4.1.26138.2.6.1.1.1.1.6.23	Integer	0
ibEntityExtCpuUsage.24	.1.3.6.1.4.1.26138.2.6.1.1.1.1.6.24	Integer	0
ibEntityExtCpuUsage.25	.1.3.6.1.4.1.26138.2.6.1.1.1.1.6.25	Integer	0
ibEntityExtCpuUsage.26	.1.3.6.1.4.1.26138.2.6.1.1.1.1.6.26	Integer	0
ibEntityExtCpuUsage.27	.1.3.6.1.4.1.26138.2.6.1.1.1.1.6.27	Integer	0
ibEntityExtCpuUsage.28	.1.3.6.1.4.1.26138.2.6.1.1.1.1.6.28	Integer	0
ibEntityExtCpuUsage.29	.1.3.6.1.4.1.26138.2.6.1.1.1.1.6.29	Integer	0
ibEntityExtCpuUsage.30	.1.3.6.1.4.1.26138.2.6.1.1.1.1.6.30	Integer	0
ibEntityExtCpuUsage.31	.1.3.6.1.4.1.26138.2.6.1.1.1.1.6.31	Integer	0
ibEntityExtCpuUsage.212	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.212	Integer	25
ibEntityExtCpuUsage.213	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.213	Integer	0
ibEntityExtCpuUsage.216	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.216	Integer	0
ibEntityExtCpuUsage.220	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.220	Integer	0
ibEntityExtCpuUsage.221	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.221	Integer	0
ibEntityExtCpuUsage.412	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.412	Integer	0
ibEntityExtCpuUsage.413	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.413	Integer	0
ibEntityExtCpuUsage.414	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.414	Integer	0
ibEntityExtCpuUsage.442	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.442	Integer	0
ibEntityExtCpuUsage.472	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.472	Integer	0
ibEntityExtCpuUsage.473	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.473	Integer	0
ibEntityExtCpuUsage.474	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.474	Integer	0
ibEntityExtCpuUsage.475	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.475	Integer	0
ibEntityExtCpuUsage.476	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.476	Integer	0
ibEntityExtCpuUsage.477	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.477	Integer	0
ibEntityExtCpuUsage.478	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.478	Integer	0
ibEntityExtCpuUsage.479	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.479	Integer	0
ibEntityExtCpuUsage.480	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.480	Integer	0
ibEntityExtCpuUsage.481	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.481	Integer	0
ibEntityExtCpuUsage.482	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.482	Integer	0
ibEntityExtCpuUsage.483	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.483	Integer	0
ibEntityExtCpuUsage.484	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.484	Integer	0
ibEntityExtCpuUsage.485	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.485	Integer	0
ibEntityExtCpuUsage.486	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.486	Integer	0
ibEntityExtCpuUsage.487	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.487	Integer	0
ibEntityExtCpuUsage.488	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.488	Integer	0
ibEntityExtCpuUsage.489	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.489	Integer	0
ibEntityExtCpuUsage.490	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.490	Integer	0
ibEntityExtCpuUsage.491	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.491	Integer	0
ibEntityExtCpuUsage.492	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.492	Integer	0
ibEntityExtCpuUsage.493	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.493	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtCpuUsage.494	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.494	Integer	0
ibEntityExtCpuUsage.495	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.495	Integer	0
ibEntityExtCpuUsage.496	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.496	Integer	0
ibEntityExtCpuUsage.497	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.497	Integer	0
ibEntityExtCpuUsage.498	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.498	Integer	0
ibEntityExtCpuUsage.499	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.499	Integer	0
ibEntityExtCpuUsage.500	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.500	Integer	0
ibEntityExtCpuUsage.501	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.501	Integer	0
ibEntityExtCpuUsage.502	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.502	Integer	0
ibEntityExtCpuUsage.503	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.503	Integer	0
ibEntityExtCpuUsage.504	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.504	Integer	0
ibEntityExtCpuUsage.505	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.505	Integer	0
ibEntityExtCpuUsage.506	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.506	Integer	0
ibEntityExtCpuUsage.507	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.507	Integer	0
ibEntityExtCpuUsage.508	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.508	Integer	0
ibEntityExtCpuUsage.509	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.509	Integer	0
ibEntityExtCpuUsage.510	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.510	Integer	0
ibEntityExtCpuUsage.511	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.511	Integer	0
ibEntityExtCpuUsage.512	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.512	Integer	0
ibEntityExtCpuUsage.513	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.513	Integer	0
ibEntityExtCpuUsage.514	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.514	Integer	0
ibEntityExtCpuUsage.515	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.515	Integer	0
ibEntityExtCpuUsage.516	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.516	Integer	0
ibEntityExtCpuUsage.517	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.517	Integer	0
ibEntityExtCpuUsage.518	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.518	Integer	0
ibEntityExtCpuUsage.519	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.519	Integer	0
ibEntityExtCpuUsage.520	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.520	Integer	0
ibEntityExtCpuUsage.521	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.521	Integer	0
ibEntityExtCpuUsage.522	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.522	Integer	0
ibEntityExtCpuUsage.523	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.523	Integer	0
ibEntityExtCpuUsage.524	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.524	Integer	0
ibEntityExtCpuUsage.525	1.3.6.1.4.1.26138.2.6.1.1.1.1.6.525	Integer	0
ibEntityExtCpuUsageThreshold.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.7.1	Integer	0
ibEntityExtCpuUsageThreshold.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.7.2	Integer	0
ibEntityExtCpuUsageThreshold.12	.1.3.6.1.4.1.26138.2.6.1.1.1.1.7.12	Integer	0
ibEntityExtCpuUsageThreshold.13	.1.3.6.1.4.1.26138.2.6.1.1.1.1.7.13	Integer	0
ibEntityExtCpuUsageThreshold.14	.1.3.6.1.4.1.26138.2.6.1.1.1.1.7.14	Integer	0
ibEntityExtCpuUsageThreshold.15	.1.3.6.1.4.1.26138.2.6.1.1.1.1.7.15	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtCpuUsageThreshold.16	.1.3.6.1.4.1.26138.2.6.1.1.1.1.7.16	Integer	0
ibEntityExtCpuUsageThreshold.17	.1.3.6.1.4.1.26138.2.6.1.1.1.1.7.17	Integer	0
ibEntityExtCpuUsageThreshold.18	.1.3.6.1.4.1.26138.2.6.1.1.1.1.7.18	Integer	0
ibEntityExtCpuUsageThreshold.19	.1.3.6.1.4.1.26138.2.6.1.1.1.1.7.19	Integer	0
ibEntityExtCpuUsageThreshold.20	.1.3.6.1.4.1.26138.2.6.1.1.1.1.7.20	Integer	0
ibEntityExtCpuUsageThreshold.21	.1.3.6.1.4.1.26138.2.6.1.1.1.1.7.21	Integer	0
ibEntityExtCpuUsageThreshold.22	.1.3.6.1.4.1.26138.2.6.1.1.1.1.7.22	Integer	0
ibEntityExtCpuUsageThreshold.23	.1.3.6.1.4.1.26138.2.6.1.1.1.1.7.23	Integer	0
ibEntityExtCpuUsageThreshold.24	.1.3.6.1.4.1.26138.2.6.1.1.1.1.7.24	Integer	0
ibEntityExtCpuUsageThreshold.25	.1.3.6.1.4.1.26138.2.6.1.1.1.1.7.25	Integer	0
ibEntityExtCpuUsageThreshold.26	.1.3.6.1.4.1.26138.2.6.1.1.1.1.7.26	Integer	0
ibEntityExtCpuUsageThreshold.27	.1.3.6.1.4.1.26138.2.6.1.1.1.1.7.27	Integer	0
ibEntityExtCpuUsageThreshold.28	.1.3.6.1.4.1.26138.2.6.1.1.1.1.7.28	Integer	0
ibEntityExtCpuUsageThreshold.29	.1.3.6.1.4.1.26138.2.6.1.1.1.1.7.29	Integer	0
ibEntityExtCpuUsageThreshold.30	.1.3.6.1.4.1.26138.2.6.1.1.1.1.7.30	Integer	0
ibEntityExtCpuUsageThreshold.31	.1.3.6.1.4.1.26138.2.6.1.1.1.1.7.31	Integer	0
ibEntityExtCpuUsageThreshold.212	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.212	Integer	99
ibEntityExtCpuUsageThreshold.213	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.213	Integer	0
ibEntityExtCpuUsageThreshold.216	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.216	Integer	0
ibEntityExtCpuUsageThreshold.220	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.220	Integer	0
ibEntityExtCpuUsageThreshold.221	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.221	Integer	0
ibEntityExtCpuUsageThreshold.412	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.412	Integer	0
ibEntityExtCpuUsageThreshold.413	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.413	Integer	0
ibEntityExtCpuUsageThreshold.414	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.414	Integer	0
ibEntityExtCpuUsageThreshold.442	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.442	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtCpuUsageThreshold.472	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.472	Integer	0
ibEntityExtCpuUsageThreshold.473	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.473	Integer	0
ibEntityExtCpuUsageThreshold.474	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.474	Integer	0
ibEntityExtCpuUsageThreshold.475	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.475	Integer	0
ibEntityExtCpuUsageThreshold.476	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.476	Integer	0
ibEntityExtCpuUsageThreshold.477	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.477	Integer	0
ibEntityExtCpuUsageThreshold.478	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.478	Integer	0
ibEntityExtCpuUsageThreshold.479	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.479	Integer	0
ibEntityExtCpuUsageThreshold.480	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.480	Integer	0
ibEntityExtCpuUsageThreshold.481	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.481	Integer	0
ibEntityExtCpuUsageThreshold.482	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.482	Integer	0
ibEntityExtCpuUsageThreshold.483	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.483	Integer	0
ibEntityExtCpuUsageThreshold.484	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.484	Integer	0
ibEntityExtCpuUsageThreshold.485	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.485	Integer	0
ibEntityExtCpuUsageThreshold.486	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.486	Integer	0
ibEntityExtCpuUsageThreshold.487	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.487	Integer	0
ibEntityExtCpuUsageThreshold.488	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.488	Integer	0
ibEntityExtCpuUsageThreshold.489	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.489	Integer	0
ibEntityExtCpuUsageThreshold.490	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.490	Integer	0
ibEntityExtCpuUsageThreshold.491	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.491	Integer	0
ibEntityExtCpuUsageThreshold.492	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.492	Integer	0
ibEntityExtCpuUsageThreshold.493	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.493	Integer	0
ibEntityExtCpuUsageThreshold.494	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.494	Integer	0
ibEntityExtCpuUsageThreshold.495	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.495	Integer	0
ibEntityExtCpuUsageThreshold.496	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.496	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtCpuUsageThreshold.497	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.497	Integer	0
ibEntityExtCpuUsageThreshold.498	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.498	Integer	0
ibEntityExtCpuUsageThreshold.499	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.499	Integer	0
ibEntityExtCpuUsageThreshold.500	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.500	Integer	0
ibEntityExtCpuUsageThreshold.501	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.501	Integer	0
ibEntityExtCpuUsageThreshold.502	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.502	Integer	0
ibEntityExtCpuUsageThreshold.503	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.503	Integer	0
ibEntityExtCpuUsageThreshold.504	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.504	Integer	0
ibEntityExtCpuUsageThreshold.505	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.505	Integer	0
ibEntityExtCpuUsageThreshold.506	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.506	Integer	0
ibEntityExtCpuUsageThreshold.507	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.507	Integer	0
ibEntityExtCpuUsageThreshold.508	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.508	Integer	0
ibEntityExtCpuUsageThreshold.509	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.509	Integer	0
ibEntityExtCpuUsageThreshold.510	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.510	Integer	0
ibEntityExtCpuUsageThreshold.511	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.511	Integer	0
ibEntityExtCpuUsageThreshold.512	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.512	Integer	0
ibEntityExtCpuUsageThreshold.513	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.513	Integer	0
ibEntityExtCpuUsageThreshold.514	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.514	Integer	0
ibEntityExtCpuUsageThreshold.515	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.515	Integer	0
ibEntityExtCpuUsageThreshold.516	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.516	Integer	0
ibEntityExtCpuUsageThreshold.517	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.517	Integer	0
ibEntityExtCpuUsageThreshold.518	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.518	Integer	0
ibEntityExtCpuUsageThreshold.519	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.519	Integer	0
ibEntityExtCpuUsageThreshold.520	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.520	Integer	0
ibEntityExtCpuUsageThreshold.521	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.521	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtCpuUsageThreshold.522	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.522	Integer	0
ibEntityExtCpuUsageThreshold.523	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.523	Integer	0
ibEntityExtCpuUsageThreshold.524	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.524	Integer	0
ibEntityExtCpuUsageThreshold.525	1.3.6.1.4.1.26138.2.6.1.1.1.1.7.525	Integer	0
ibEntityExtMemUsage.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.8.1	Integer	0
ibEntityExtMemUsage.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.8.2	Integer	0
ibEntityExtMemUsage.12	.1.3.6.1.4.1.26138.2.6.1.1.1.1.8.12	Integer	0
ibEntityExtMemUsage.13	.1.3.6.1.4.1.26138.2.6.1.1.1.1.8.13	Integer	0
ibEntityExtMemUsage.14	.1.3.6.1.4.1.26138.2.6.1.1.1.1.8.14	Integer	0
ibEntityExtMemUsage.15	.1.3.6.1.4.1.26138.2.6.1.1.1.1.8.15	Integer	0
ibEntityExtMemUsage.16	.1.3.6.1.4.1.26138.2.6.1.1.1.1.8.16	Integer	0
ibEntityExtMemUsage.17	.1.3.6.1.4.1.26138.2.6.1.1.1.1.8.17	Integer	0
ibEntityExtMemUsage.18	.1.3.6.1.4.1.26138.2.6.1.1.1.1.8.18	Integer	0
ibEntityExtMemUsage.19	.1.3.6.1.4.1.26138.2.6.1.1.1.1.8.19	Integer	0
ibEntityExtMemUsage.20	.1.3.6.1.4.1.26138.2.6.1.1.1.1.8.20	Integer	0
ibEntityExtMemUsage.21	.1.3.6.1.4.1.26138.2.6.1.1.1.1.8.21	Integer	0
ibEntityExtMemUsage.22	.1.3.6.1.4.1.26138.2.6.1.1.1.1.8.22	Integer	0
ibEntityExtMemUsage.23	.1.3.6.1.4.1.26138.2.6.1.1.1.1.8.23	Integer	0
ibEntityExtMemUsage.24	.1.3.6.1.4.1.26138.2.6.1.1.1.1.8.24	Integer	0
ibEntityExtMemUsage.25	.1.3.6.1.4.1.26138.2.6.1.1.1.1.8.25	Integer	0
ibEntityExtMemUsage.26	.1.3.6.1.4.1.26138.2.6.1.1.1.1.8.26	Integer	0
ibEntityExtMemUsage.27	.1.3.6.1.4.1.26138.2.6.1.1.1.1.8.27	Integer	0
ibEntityExtMemUsage.28	.1.3.6.1.4.1.26138.2.6.1.1.1.1.8.28	Integer	0
ibEntityExtMemUsage.29	.1.3.6.1.4.1.26138.2.6.1.1.1.1.8.29	Integer	0
ibEntityExtMemUsage.30	.1.3.6.1.4.1.26138.2.6.1.1.1.1.8.30	Integer	0
ibEntityExtMemUsage.31	.1.3.6.1.4.1.26138.2.6.1.1.1.1.8.31	Integer	0
ibEntityExtMemUsage.212	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.212	Integer	43
ibEntityExtMemUsage.213	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.213	Integer	0
ibEntityExtMemUsage.216	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.216	Integer	0
ibEntityExtMemUsage.220	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.220	Integer	0
ibEntityExtMemUsage.221	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.221	Integer	0
ibEntityExtMemUsage.412	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.412	Integer	0
ibEntityExtMemUsage.413	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.413	Integer	0
ibEntityExtMemUsage.414	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.414	Integer	0
ibEntityExtMemUsage.442	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.442	Integer	0
ibEntityExtMemUsage.472	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.472	Integer	0
ibEntityExtMemUsage.473	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.473	Integer	0
ibEntityExtMemUsage.474	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.474	Integer	0
ibEntityExtMemUsage.475	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.475	Integer	0
ibEntityExtMemUsage.476	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.476	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtMemUsage.477	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.477	Integer	0
ibEntityExtMemUsage.478	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.478	Integer	0
ibEntityExtMemUsage.479	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.479	Integer	0
ibEntityExtMemUsage.480	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.480	Integer	0
ibEntityExtMemUsage.481	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.481	Integer	0
ibEntityExtMemUsage.482	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.482	Integer	0
ibEntityExtMemUsage.483	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.483	Integer	0
ibEntityExtMemUsage.484	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.484	Integer	0
ibEntityExtMemUsage.485	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.485	Integer	0
ibEntityExtMemUsage.486	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.486	Integer	0
ibEntityExtMemUsage.487	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.487	Integer	0
ibEntityExtMemUsage.488	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.488	Integer	0
ibEntityExtMemUsage.489	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.489	Integer	0
ibEntityExtMemUsage.490	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.490	Integer	0
ibEntityExtMemUsage.491	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.491	Integer	0
ibEntityExtMemUsage.492	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.492	Integer	0
ibEntityExtMemUsage.493	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.493	Integer	0
ibEntityExtMemUsage.494	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.494	Integer	0
ibEntityExtMemUsage.495	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.495	Integer	0
ibEntityExtMemUsage.496	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.496	Integer	0
ibEntityExtMemUsage.497	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.497	Integer	0
ibEntityExtMemUsage.498	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.498	Integer	0
ibEntityExtMemUsage.499	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.499	Integer	0
ibEntityExtMemUsage.500	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.500	Integer	0
ibEntityExtMemUsage.501	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.501	Integer	0
ibEntityExtMemUsage.502	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.502	Integer	0
ibEntityExtMemUsage.503	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.503	Integer	0
ibEntityExtMemUsage.504	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.504	Integer	0
ibEntityExtMemUsage.505	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.505	Integer	0
ibEntityExtMemUsage.506	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.506	Integer	0
ibEntityExtMemUsage.507	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.507	Integer	0
ibEntityExtMemUsage.508	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.508	Integer	0
ibEntityExtMemUsage.509	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.509	Integer	0
ibEntityExtMemUsage.510	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.510	Integer	0
ibEntityExtMemUsage.511	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.511	Integer	0
ibEntityExtMemUsage.512	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.512	Integer	0
ibEntityExtMemUsage.513	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.513	Integer	0
ibEntityExtMemUsage.514	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.514	Integer	0
ibEntityExtMemUsage.515	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.515	Integer	0
ibEntityExtMemUsage.516	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.516	Integer	0
ibEntityExtMemUsage.517	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.517	Integer	0
ibEntityExtMemUsage.518	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.518	Integer	0
ibEntityExtMemUsage.519	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.519	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtMemUsage.520	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.520	Integer	0
ibEntityExtMemUsage.521	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.521	Integer	0
ibEntityExtMemUsage.522	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.522	Integer	0
ibEntityExtMemUsage.523	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.523	Integer	0
ibEntityExtMemUsage.524	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.524	Integer	0
ibEntityExtMemUsage.525	1.3.6.1.4.1.26138.2.6.1.1.1.1.8.525	Integer	0
ibEntityExtMemUsageThreshold.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.9.1	Integer	0
ibEntityExtMemUsageThreshold.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.9.2	Integer	0
ibEntityExtMemUsageThreshold.12	.1.3.6.1.4.1.26138.2.6.1.1.1.1.9.12	Integer	0
ibEntityExtMemUsageThreshold.13	.1.3.6.1.4.1.26138.2.6.1.1.1.1.9.13	Integer	0
ibEntityExtMemUsageThreshold.14	.1.3.6.1.4.1.26138.2.6.1.1.1.1.9.14	Integer	0
ibEntityExtMemUsageThreshold.15	.1.3.6.1.4.1.26138.2.6.1.1.1.1.9.15	Integer	0
ibEntityExtMemUsageThreshold.16	.1.3.6.1.4.1.26138.2.6.1.1.1.1.9.16	Integer	0
ibEntityExtMemUsageThreshold.17	.1.3.6.1.4.1.26138.2.6.1.1.1.1.9.17	Integer	0
ibEntityExtMemUsageThreshold.18	.1.3.6.1.4.1.26138.2.6.1.1.1.1.9.18	Integer	0
ibEntityExtMemUsageThreshold.19	.1.3.6.1.4.1.26138.2.6.1.1.1.1.9.19	Integer	0
ibEntityExtMemUsageThreshold.20	.1.3.6.1.4.1.26138.2.6.1.1.1.1.9.20	Integer	0
ibEntityExtMemUsageThreshold.21	.1.3.6.1.4.1.26138.2.6.1.1.1.1.9.21	Integer	0
ibEntityExtMemUsageThreshold.22	.1.3.6.1.4.1.26138.2.6.1.1.1.1.9.22	Integer	0
ibEntityExtMemUsageThreshold.23	.1.3.6.1.4.1.26138.2.6.1.1.1.1.9.23	Integer	0
ibEntityExtMemUsageThreshold.24	.1.3.6.1.4.1.26138.2.6.1.1.1.1.9.24	Integer	0
ibEntityExtMemUsageThreshold.25	.1.3.6.1.4.1.26138.2.6.1.1.1.1.9.25	Integer	0
ibEntityExtMemUsageThreshold.26	.1.3.6.1.4.1.26138.2.6.1.1.1.1.9.26	Integer	0
ibEntityExtMemUsageThreshold.27	.1.3.6.1.4.1.26138.2.6.1.1.1.1.9.27	Integer	0
ibEntityExtMemUsageThreshold.28	.1.3.6.1.4.1.26138.2.6.1.1.1.1.9.28	Integer	0
ibEntityExtMemUsageThreshold.29	.1.3.6.1.4.1.26138.2.6.1.1.1.1.9.29	Integer	0
ibEntityExtMemUsageThreshold.30	.1.3.6.1.4.1.26138.2.6.1.1.1.1.9.30	Integer	0
ibEntityExtMemUsageThreshold.31	.1.3.6.1.4.1.26138.2.6.1.1.1.1.9.31	Integer	0



Name	OID	Value Type	Value Example
ibEntityExtMemUsageThreshold.212	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.212	Integer	100
ibEntityExtMemUsageThreshold.213	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.213	Integer	0
ibEntityExtMemUsageThreshold.216	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.216	Integer	0
ibEntityExtMemUsageThreshold.220	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.220	Integer	0
ibEntityExtMemUsageThreshold.221	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.221	Integer	0
ibEntityExtMemUsageThreshold.412	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.412	Integer	0
ibEntityExtMemUsageThreshold.413	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.413	Integer	0
ibEntityExtMemUsageThreshold.414	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.414	Integer	0
ibEntityExtMemUsageThreshold.442	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.442	Integer	0
ibEntityExtMemUsageThreshold.472	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.472	Integer	0
ibEntityExtMemUsageThreshold.473	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.473	Integer	0
ibEntityExtMemUsageThreshold.474	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.474	Integer	0
ibEntityExtMemUsageThreshold.475	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.475	Integer	0
ibEntityExtMemUsageThreshold.476	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.476	Integer	0
ibEntityExtMemUsageThreshold.477	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.477	Integer	0
ibEntityExtMemUsageThreshold.478	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.478	Integer	0
ibEntityExtMemUsageThreshold.479	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.479	Integer	0
ibEntityExtMemUsageThreshold.480	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.480	Integer	0
ibEntityExtMemUsageThreshold.481	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.481	Integer	0
ibEntityExtMemUsageThreshold.482	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.482	Integer	0
ibEntityExtMemUsageThreshold.483	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.483	Integer	0
ibEntityExtMemUsageThreshold.484	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.484	Integer	0
ibEntityExtMemUsageThreshold.485	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.485	Integer	0
ibEntityExtMemUsageThreshold.486	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.486	Integer	0
ibEntityExtMemUsageThreshold.487	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.487	Integer	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ibEntityExtMemUsageThreshold.488	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.488	Integer	0
ibEntityExtMemUsageThreshold.489	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.489	Integer	0
ibEntityExtMemUsageThreshold.490	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.490	Integer	0
ibEntityExtMemUsageThreshold.491	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.491	Integer	0
ibEntityExtMemUsageThreshold.492	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.492	Integer	0
ibEntityExtMemUsageThreshold.493	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.493	Integer	0
ibEntityExtMemUsageThreshold.494	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.494	Integer	0
ibEntityExtMemUsageThreshold.495	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.495	Integer	0
ibEntityExtMemUsageThreshold.496	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.496	Integer	0
ibEntityExtMemUsageThreshold.497	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.497	Integer	0
ibEntityExtMemUsageThreshold.498	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.498	Integer	0
ibEntityExtMemUsageThreshold.499	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.499	Integer	0
ibEntityExtMemUsageThreshold.500	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.500	Integer	0
ibEntityExtMemUsageThreshold.501	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.501	Integer	0
ibEntityExtMemUsageThreshold.502	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.502	Integer	0
ibEntityExtMemUsageThreshold.503	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.503	Integer	0
ibEntityExtMemUsageThreshold.504	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.504	Integer	0
ibEntityExtMemUsageThreshold.505	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.505	Integer	0
ibEntityExtMemUsageThreshold.506	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.506	Integer	0
ibEntityExtMemUsageThreshold.507	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.507	Integer	0
ibEntityExtMemUsageThreshold.508	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.508	Integer	0
ibEntityExtMemUsageThreshold.509	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.509	Integer	0
ibEntityExtMemUsageThreshold.510	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.510	Integer	0
ibEntityExtMemUsageThreshold.511	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.511	Integer	0
ibEntityExtMemUsageThreshold.512	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.512	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtMemUsageThreshold.513	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.513	Integer	0
ibEntityExtMemUsageThreshold.514	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.514	Integer	0
ibEntityExtMemUsageThreshold.515	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.515	Integer	0
ibEntityExtMemUsageThreshold.516	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.516	Integer	0
ibEntityExtMemUsageThreshold.517	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.517	Integer	0
ibEntityExtMemUsageThreshold.518	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.518	Integer	0
ibEntityExtMemUsageThreshold.519	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.519	Integer	0
ibEntityExtMemUsageThreshold.520	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.520	Integer	0
ibEntityExtMemUsageThreshold.521	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.521	Integer	0
ibEntityExtMemUsageThreshold.522	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.522	Integer	0
ibEntityExtMemUsageThreshold.523	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.523	Integer	0
ibEntityExtMemUsageThreshold.524	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.524	Integer	0
ibEntityExtMemUsageThreshold.525	1.3.6.1.4.1.26138.2.6.1.1.1.1.9.525	Integer	0
ibEntityExtMemSize.1	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.1	Gauge	0
ibEntityExtMemSize.2	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.2	Gauge	0
ibEntityExtMemSize.12	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.12	Gauge	0
ibEntityExtMemSize.13	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.13	Gauge	0
ibEntityExtMemSize.14	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.14	Gauge	0
ibEntityExtMemSize.15	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.15	Gauge	0
ibEntityExtMemSize.16	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.16	Gauge	0
ibEntityExtMemSize.17	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.17	Gauge	0
ibEntityExtMemSize.18	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.18	Gauge	0
ibEntityExtMemSize.19	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.19	Gauge	0
ibEntityExtMemSize.20	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.20	Gauge	0
ibEntityExtMemSize.21	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.21	Gauge	0
ibEntityExtMemSize.22	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.22	Gauge	0
ibEntityExtMemSize.23	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.23	Gauge	0
ibEntityExtMemSize.24	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.24	Gauge	0
ibEntityExtMemSize.25	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.25	Gauge	0
ibEntityExtMemSize.26	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.26	Gauge	0
ibEntityExtMemSize.27	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.27	Gauge	0
ibEntityExtMemSize.28	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.28	Gauge	0
ibEntityExtMemSize.29	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.29	Gauge	0
ibEntityExtMemSize.30	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.30	Gauge	0

Name	OID	Value Type	Value Example
ibEntityExtMemSize.31	1.3.6.1.4.1.26138.2.6.1.1.1.10.31	Gauge	0
ibEntityExtMemSize.212	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.212	Gauge	1015533568
ibEntityExtMemSize.213	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.213	Gauge	0
ibEntityExtMemSize.216	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.216	Gauge	0
ibEntityExtMemSize.220	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.220	Gauge	0
ibEntityExtMemSize.221	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.221	Gauge	0
ibEntityExtMemSize.412	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.412	Gauge	0
ibEntityExtMemSize.413	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.413	Gauge	0
ibEntityExtMemSize.414	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.414	Gauge	0
ibEntityExtMemSize.442	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.442	Gauge	0
ibEntityExtMemSize.472	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.472	Gauge	0
ibEntityExtMemSize.473	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.473	Gauge	0
ibEntityExtMemSize.474	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.474	Gauge	0
ibEntityExtMemSize.475	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.475	Gauge	0
ibEntityExtMemSize.476	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.476	Gauge	0
ibEntityExtMemSize.477	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.477	Gauge	0
ibEntityExtMemSize.478	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.478	Gauge	0
ibEntityExtMemSize.479	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.479	Gauge	0
ibEntityExtMemSize.480	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.480	Gauge	0
ibEntityExtMemSize.481	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.481	Gauge	0
ibEntityExtMemSize.482	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.482	Gauge	0
ibEntityExtMemSize.483	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.483	Gauge	0
ibEntityExtMemSize.484	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.484	Gauge	0
ibEntityExtMemSize.485	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.485	Gauge	0
ibEntityExtMemSize.486	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.486	Gauge	0
ibEntityExtMemSize.487	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.487	Gauge	0
ibEntityExtMemSize.488	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.488	Gauge	0
ibEntityExtMemSize.489	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.489	Gauge	0
ibEntityExtMemSize.490	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.490	Gauge	0
ibEntityExtMemSize.491	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.491	Gauge	0
ibEntityExtMemSize.492	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.492	Gauge	0
ibEntityExtMemSize.493	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.493	Gauge	0
ibEntityExtMemSize.494	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.494	Gauge	0
ibEntityExtMemSize.495	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.495	Gauge	0
ibEntityExtMemSize.496	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.496	Gauge	0
ibEntityExtMemSize.497	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.497	Gauge	0
ibEntityExtMemSize.498	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.498	Gauge	0
ibEntityExtMemSize.499	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.499	Gauge	0
ibEntityExtMemSize.500	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.500	Gauge	0
ibEntityExtMemSize.501	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.501	Gauge	0
ibEntityExtMemSize.502	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.502	Gauge	0
ibEntityExtMemSize.503	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.503	Gauge	0
ibEntityExtMemSize.504	1.3.6.1.4.1.26138.2.6.1.1.1.1.10.504	Gauge	0

Name	OID	Value Type	Value Example
ibEntityExtMemSize.505	.1.3.6.1.4.1.26138.2.6.1.1.1.1.10.505	Gauge	0
ibEntityExtMemSize.506	.1.3.6.1.4.1.26138.2.6.1.1.1.1.10.506	Gauge	0
ibEntityExtMemSize.507	.1.3.6.1.4.1.26138.2.6.1.1.1.1.10.507	Gauge	0
ibEntityExtMemSize.508	.1.3.6.1.4.1.26138.2.6.1.1.1.1.10.508	Gauge	0
ibEntityExtMemSize.509	.1.3.6.1.4.1.26138.2.6.1.1.1.1.10.509	Gauge	0
ibEntityExtMemSize.510	.1.3.6.1.4.1.26138.2.6.1.1.1.1.10.510	Gauge	0
ibEntityExtMemSize.511	.1.3.6.1.4.1.26138.2.6.1.1.1.1.10.511	Gauge	0
ibEntityExtMemSize.512	.1.3.6.1.4.1.26138.2.6.1.1.1.1.10.512	Gauge	0
ibEntityExtMemSize.513	.1.3.6.1.4.1.26138.2.6.1.1.1.1.10.513	Gauge	0
ibEntityExtMemSize.514	.1.3.6.1.4.1.26138.2.6.1.1.1.1.10.514	Gauge	0
ibEntityExtMemSize.515	.1.3.6.1.4.1.26138.2.6.1.1.1.1.10.515	Gauge	0
ibEntityExtMemSize.516	.1.3.6.1.4.1.26138.2.6.1.1.1.1.10.516	Gauge	0
ibEntityExtMemSize.517	.1.3.6.1.4.1.26138.2.6.1.1.1.1.10.517	Gauge	0
ibEntityExtMemSize.518	.1.3.6.1.4.1.26138.2.6.1.1.1.1.10.518	Gauge	0
ibEntityExtMemSize.519	.1.3.6.1.4.1.26138.2.6.1.1.1.1.10.519	Gauge	0
ibEntityExtMemSize.520	.1.3.6.1.4.1.26138.2.6.1.1.1.1.10.520	Gauge	0
ibEntityExtMemSize.521	.1.3.6.1.4.1.26138.2.6.1.1.1.1.10.521	Gauge	0
ibEntityExtMemSize.522	.1.3.6.1.4.1.26138.2.6.1.1.1.1.10.522	Gauge	0
ibEntityExtMemSize.523	.1.3.6.1.4.1.26138.2.6.1.1.1.1.10.523	Gauge	0
ibEntityExtMemSize.524	.1.3.6.1.4.1.26138.2.6.1.1.1.1.10.524	Gauge	0
ibEntityExtMemSize.525	.1.3.6.1.4.1.26138.2.6.1.1.1.1.10.525	Gauge	0
ibEntityExtUpTime.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.11.2	Integer	1917
ibEntityExtTemperature.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.1	Integer	65535
ibEntityExtTemperature.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.2	Integer	65535
ibEntityExtTemperature.12	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.12	Integer	65535
ibEntityExtTemperature.13	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.13	Integer	65535
ibEntityExtTemperature.14	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.14	Integer	65535
ibEntityExtTemperature.15	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.15	Integer	65535
ibEntityExtTemperature.16	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.16	Integer	65535
ibEntityExtTemperature.17	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.17	Integer	65535
ibEntityExtTemperature.18	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.18	Integer	65535
ibEntityExtTemperature.19	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.19	Integer	65535
ibEntityExtTemperature.20	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.20	Integer	65535
ibEntityExtTemperature.21	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.21	Integer	65535
ibEntityExtTemperature.22	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.22	Integer	65535
ibEntityExtTemperature.23	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.23	Integer	65535
ibEntityExtTemperature.24	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.24	Integer	65535
ibEntityExtTemperature.25	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.25	Integer	65535
ibEntityExtTemperature.26	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.26	Integer	65535
ibEntityExtTemperature.27	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.27	Integer	65535
ibEntityExtTemperature.28	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.28	Integer	65535
ibEntityExtTemperature.29	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.29	Integer	65535
ibEntityExtTemperature.30	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.30	Integer	65535

Name	OID	Value Type	Value Example
ibEntityExtTemperature.31	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.31	Integer	65535
ibEntityExtTemperature.212	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.212	Integer	35
ibEntityExtTemperature.213	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.213	Integer	65535
ibEntityExtTemperature.216	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.216	Integer	65535
ibEntityExtTemperature.220	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.220	Integer	29
ibEntityExtTemperature.221	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.221	Integer	35
ibEntityExtTemperature.412	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.412	Integer	65535
ibEntityExtTemperature.413	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.413	Integer	65535
ibEntityExtTemperature.414	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.414	Integer	65535
ibEntityExtTemperature.442	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.442	Integer	35
ibEntityExtTemperature.472	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.472	Integer	65535
ibEntityExtTemperature.473	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.473	Integer	65535
ibEntityExtTemperature.474	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.474	Integer	65535
ibEntityExtTemperature.475	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.475	Integer	65535
ibEntityExtTemperature.476	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.476	Integer	65535
ibEntityExtTemperature.477	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.477	Integer	65535
ibEntityExtTemperature.478	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.478	Integer	65535
ibEntityExtTemperature.479	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.479	Integer	65535
ibEntityExtTemperature.480	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.480	Integer	65535
ibEntityExtTemperature.481	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.481	Integer	65535
ibEntityExtTemperature.482	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.482	Integer	65535
ibEntityExtTemperature.483	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.483	Integer	65535
ibEntityExtTemperature.484	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.484	Integer	65535
ibEntityExtTemperature.485	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.485	Integer	65535
ibEntityExtTemperature.486	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.486	Integer	65535
ibEntityExtTemperature.487	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.487	Integer	65535
ibEntityExtTemperature.488	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.488	Integer	65535
ibEntityExtTemperature.489	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.489	Integer	65535
ibEntityExtTemperature.490	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.490	Integer	65535
ibEntityExtTemperature.491	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.491	Integer	65535
ibEntityExtTemperature.492	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.492	Integer	65535
ibEntityExtTemperature.493	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.493	Integer	65535
ibEntityExtTemperature.494	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.494	Integer	65535
ibEntityExtTemperature.495	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.495	Integer	65535
ibEntityExtTemperature.496	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.496	Integer	65535
ibEntityExtTemperature.497	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.497	Integer	65535
ibEntityExtTemperature.498	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.498	Integer	65535
ibEntityExtTemperature.499	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.499	Integer	65535
ibEntityExtTemperature.500	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.500	Integer	65535
ibEntityExtTemperature.501	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.501	Integer	65535
ibEntityExtTemperature.502	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.502	Integer	65535
ibEntityExtTemperature.503	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.503	Integer	65535
ibEntityExtTemperature.504	1.3.6.1.4.1.26138.2.6.1.1.1.1.12.504	Integer	65535

Name	OID	Value Type	Value Example
ibEntityExtTemperature.505	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.505	Integer	65535
ibEntityExtTemperature.506	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.506	Integer	65535
ibEntityExtTemperature.507	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.507	Integer	65535
ibEntityExtTemperature.508	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.508	Integer	65535
ibEntityExtTemperature.509	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.509	Integer	65535
ibEntityExtTemperature.510	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.510	Integer	65535
ibEntityExtTemperature.511	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.511	Integer	65535
ibEntityExtTemperature.512	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.512	Integer	65535
ibEntityExtTemperature.513	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.513	Integer	65535
ibEntityExtTemperature.514	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.514	Integer	65535
ibEntityExtTemperature.515	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.515	Integer	65535
ibEntityExtTemperature.516	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.516	Integer	65535
ibEntityExtTemperature.517	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.517	Integer	65535
ibEntityExtTemperature.518	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.518	Integer	65535
ibEntityExtTemperature.519	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.519	Integer	65535
ibEntityExtTemperature.520	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.520	Integer	65535
ibEntityExtTemperature.521	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.521	Integer	65535
ibEntityExtTemperature.522	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.522	Integer	65535
ibEntityExtTemperature.523	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.523	Integer	65535
ibEntityExtTemperature.524	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.524	Integer	65535
ibEntityExtTemperature.525	.1.3.6.1.4.1.26138.2.6.1.1.1.1.12.525	Integer	65535
ibEntityExtTemperatureThreshhold.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.1	Integer	65535
ibEntityExtTemperatureThreshhold.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.2	Integer	65535
ibEntityExtTemperatureThreshhold.12	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.12	Integer	65535
ibEntityExtTemperatureThreshhold.13	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.13	Integer	65535
ibEntityExtTemperatureThreshhold.14	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.14	Integer	65535
ibEntityExtTemperatureThreshhold.15	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.15	Integer	65535
ibEntityExtTemperatureThreshhold.16	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.16	Integer	65535
ibEntityExtTemperatureThreshhold.17	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.17	Integer	65535
ibEntityExtTemperatureThreshhold.18	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.18	Integer	65535
ibEntityExtTemperatureThreshhold.19	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.19	Integer	65535
ibEntityExtTemperatureThreshhold.20	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.20	Integer	65535
ibEntityExtTemperatureThreshhold.21	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.21	Integer	65535
ibEntityExtTemperatureThreshhold.22	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.22	Integer	65535

Name	OID	Value Type	Value Example
ibEntityExtTemperatureThreshold.23	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.23	Integer	65535
ibEntityExtTemperatureThreshold.24	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.24	Integer	65535
ibEntityExtTemperatureThreshold.25	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.25	Integer	65535
ibEntityExtTemperatureThreshold.26	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.26	Integer	65535
ibEntityExtTemperatureThreshold.27	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.27	Integer	65535
ibEntityExtTemperatureThreshold.28	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.28	Integer	65535
ibEntityExtTemperatureThreshold.29	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.29	Integer	65535
ibEntityExtTemperatureThreshold.30	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.30	Integer	65535
ibEntityExtTemperatureThreshold.31	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.31	Integer	65535
ibEntityExtTemperatureThreshold.212	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.212	Integer	65535
ibEntityExtTemperatureThreshold.213	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.213	Integer	65535
ibEntityExtTemperatureThreshold.216	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.216	Integer	65535
ibEntityExtTemperatureThreshold.220	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.220	Integer	56
ibEntityExtTemperatureThreshold.221	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.221	Integer	100
ibEntityExtTemperatureThreshold.412	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.412	Integer	65535
ibEntityExtTemperatureThreshold.413	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.413	Integer	65535
ibEntityExtTemperatureThreshold.414	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.414	Integer	65535
ibEntityExtTemperatureThreshold.442	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.442	Integer	65535
ibEntityExtTemperatureThreshold.472	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.472	Integer	65535
ibEntityExtTemperatureThreshold.473	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.473	Integer	65535
ibEntityExtTemperatureThreshold.474	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.474	Integer	65535
ibEntityExtTemperatureThreshold.475	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.475	Integer	65535
ibEntityExtTemperatureThreshold.476	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.476	Integer	65535
ibEntityExtTemperatureThreshold.477	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.477	Integer	65535
ibEntityExtTemperatureThreshold.478	1.3.6.1.4.1.26138.2.6.1.1.1.1.13.478	Integer	65535



Name	OID	Value Type	Value Example
ibEntityExtTemperatureThreshold.479	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.479	Integer	65535
ibEntityExtTemperatureThreshold.480	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.480	Integer	65535
ibEntityExtTemperatureThreshold.481	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.481	Integer	65535
ibEntityExtTemperatureThreshold.482	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.482	Integer	65535
ibEntityExtTemperatureThreshold.483	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.483	Integer	65535
ibEntityExtTemperatureThreshold.484	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.484	Integer	65535
ibEntityExtTemperatureThreshold.485	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.485	Integer	65535
ibEntityExtTemperatureThreshold.486	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.486	Integer	65535
ibEntityExtTemperatureThreshold.487	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.487	Integer	65535
ibEntityExtTemperatureThreshold.488	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.488	Integer	65535
ibEntityExtTemperatureThreshold.489	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.489	Integer	65535
ibEntityExtTemperatureThreshold.490	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.490	Integer	65535
ibEntityExtTemperatureThreshold.491	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.491	Integer	65535
ibEntityExtTemperatureThreshold.492	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.492	Integer	65535
ibEntityExtTemperatureThreshold.493	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.493	Integer	65535
ibEntityExtTemperatureThreshold.494	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.494	Integer	65535
ibEntityExtTemperatureThreshold.495	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.495	Integer	65535
ibEntityExtTemperatureThreshold.496	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.496	Integer	65535
ibEntityExtTemperatureThreshold.497	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.497	Integer	65535
ibEntityExtTemperatureThreshold.498	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.498	Integer	65535
ibEntityExtTemperatureThreshold.499	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.499	Integer	65535
ibEntityExtTemperatureThreshold.500	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.500	Integer	65535
ibEntityExtTemperatureThreshold.501	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.501	Integer	65535
ibEntityExtTemperatureThreshold.502	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.502	Integer	65535
ibEntityExtTemperatureThreshold.503	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.503	Integer	65535

Name	OID	Value Type	Value Example
ibEntityExtTemperatureThreshold.504	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.504	Integer	65535
ibEntityExtTemperatureThreshold.505	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.505	Integer	65535
ibEntityExtTemperatureThreshold.506	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.506	Integer	65535
ibEntityExtTemperatureThreshold.507	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.507	Integer	65535
ibEntityExtTemperatureThreshold.508	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.508	Integer	65535
ibEntityExtTemperatureThreshold.509	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.509	Integer	65535
ibEntityExtTemperatureThreshold.510	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.510	Integer	65535
ibEntityExtTemperatureThreshold.511	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.511	Integer	65535
ibEntityExtTemperatureThreshold.512	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.512	Integer	65535
ibEntityExtTemperatureThreshold.513	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.513	Integer	65535
ibEntityExtTemperatureThreshold.514	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.514	Integer	65535
ibEntityExtTemperatureThreshold.515	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.515	Integer	65535
ibEntityExtTemperatureThreshold.516	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.516	Integer	65535
ibEntityExtTemperatureThreshold.517	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.517	Integer	65535
ibEntityExtTemperatureThreshold.518	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.518	Integer	65535
ibEntityExtTemperatureThreshold.519	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.519	Integer	65535
ibEntityExtTemperatureThreshold.520	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.520	Integer	65535
ibEntityExtTemperatureThreshold.521	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.521	Integer	65535
ibEntityExtTemperatureThreshold.522	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.522	Integer	65535
ibEntityExtTemperatureThreshold.523	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.523	Integer	65535
ibEntityExtTemperatureThreshold.524	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.524	Integer	65535
ibEntityExtTemperatureThreshold.525	.1.3.6.1.4.1.26138.2.6.1.1.1.1.13.525	Integer	65535
ibEntityExtVoltage.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.1	Integer	0
ibEntityExtVoltage.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.2	Integer	0
ibEntityExtVoltage.12	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.12	Integer	0
ibEntityExtVoltage.13	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.13	Integer	0
ibEntityExtVoltage.14	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.14	Integer	0
ibEntityExtVoltage.15	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.15	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtVoltage.16	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.16	Integer	0
ibEntityExtVoltage.17	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.17	Integer	0
ibEntityExtVoltage.18	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.18	Integer	0
ibEntityExtVoltage.19	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.19	Integer	0
ibEntityExtVoltage.20	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.20	Integer	0
ibEntityExtVoltage.21	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.21	Integer	0
ibEntityExtVoltage.22	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.22	Integer	0
ibEntityExtVoltage.23	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.23	Integer	0
ibEntityExtVoltage.24	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.24	Integer	0
ibEntityExtVoltage.25	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.25	Integer	0
ibEntityExtVoltage.26	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.26	Integer	0
ibEntityExtVoltage.27	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.27	Integer	0
ibEntityExtVoltage.28	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.28	Integer	0
ibEntityExtVoltage.29	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.29	Integer	0
ibEntityExtVoltage.30	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.30	Integer	0
ibEntityExtVoltage.31	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.31	Integer	0
ibEntityExtVoltage.212	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.212	Integer	0
ibEntityExtVoltage.213	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.213	Integer	0
ibEntityExtVoltage.216	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.216	Integer	0
ibEntityExtVoltage.220	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.220	Integer	0
ibEntityExtVoltage.221	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.221	Integer	0
ibEntityExtVoltage.412	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.412	Integer	0
ibEntityExtVoltage.413	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.413	Integer	0
ibEntityExtVoltage.414	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.414	Integer	0
ibEntityExtVoltage.442	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.442	Integer	0
ibEntityExtVoltage.472	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.472	Integer	0
ibEntityExtVoltage.473	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.473	Integer	0
ibEntityExtVoltage.474	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.474	Integer	0
ibEntityExtVoltage.475	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.475	Integer	0
ibEntityExtVoltage.476	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.476	Integer	0
ibEntityExtVoltage.477	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.477	Integer	0
ibEntityExtVoltage.478	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.478	Integer	0
ibEntityExtVoltage.479	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.479	Integer	0
ibEntityExtVoltage.480	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.480	Integer	0
ibEntityExtVoltage.481	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.481	Integer	0
ibEntityExtVoltage.482	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.482	Integer	0
ibEntityExtVoltage.483	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.483	Integer	0
ibEntityExtVoltage.484	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.484	Integer	0
ibEntityExtVoltage.485	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.485	Integer	0
ibEntityExtVoltage.486	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.486	Integer	0
ibEntityExtVoltage.487	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.487	Integer	0
ibEntityExtVoltage.488	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.488	Integer	0
ibEntityExtVoltage.489	1.3.6.1.4.1.26138.2.6.1.1.1.1.14.489	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtVoltage.490	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.490	Integer	0
ibEntityExtVoltage.491	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.491	Integer	0
ibEntityExtVoltage.492	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.492	Integer	0
ibEntityExtVoltage.493	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.493	Integer	0
ibEntityExtVoltage.494	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.494	Integer	0
ibEntityExtVoltage.495	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.495	Integer	0
ibEntityExtVoltage.496	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.496	Integer	0
ibEntityExtVoltage.497	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.497	Integer	0
ibEntityExtVoltage.498	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.498	Integer	0
ibEntityExtVoltage.499	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.499	Integer	0
ibEntityExtVoltage.500	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.500	Integer	0
ibEntityExtVoltage.501	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.501	Integer	0
ibEntityExtVoltage.502	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.502	Integer	0
ibEntityExtVoltage.503	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.503	Integer	0
ibEntityExtVoltage.504	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.504	Integer	0
ibEntityExtVoltage.505	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.505	Integer	0
ibEntityExtVoltage.506	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.506	Integer	0
ibEntityExtVoltage.507	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.507	Integer	0
ibEntityExtVoltage.508	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.508	Integer	0
ibEntityExtVoltage.509	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.509	Integer	0
ibEntityExtVoltage.510	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.510	Integer	0
ibEntityExtVoltage.511	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.511	Integer	0
ibEntityExtVoltage.512	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.512	Integer	0
ibEntityExtVoltage.513	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.513	Integer	0
ibEntityExtVoltage.514	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.514	Integer	0
ibEntityExtVoltage.515	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.515	Integer	0
ibEntityExtVoltage.516	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.516	Integer	0
ibEntityExtVoltage.517	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.517	Integer	0
ibEntityExtVoltage.518	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.518	Integer	0
ibEntityExtVoltage.519	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.519	Integer	0
ibEntityExtVoltage.520	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.520	Integer	0
ibEntityExtVoltage.521	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.521	Integer	0
ibEntityExtVoltage.522	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.522	Integer	0
ibEntityExtVoltage.523	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.523	Integer	0
ibEntityExtVoltage.524	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.524	Integer	0
ibEntityExtVoltage.525	.1.3.6.1.4.1.26138.2.6.1.1.1.1.14.525	Integer	0
ibEntityExtVoltageLowThreshold.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.1	Integer	0
ibEntityExtVoltageLowThreshold.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.2	Integer	0
ibEntityExtVoltageLowThreshold.12	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.12	Integer	0
ibEntityExtVoltageLowThreshold.13	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.13	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtVoltageLowThreshold.14	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.14	Integer	0
ibEntityExtVoltageLowThreshold.15	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.15	Integer	0
ibEntityExtVoltageLowThreshold.16	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.16	Integer	0
ibEntityExtVoltageLowThreshold.17	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.17	Integer	0
ibEntityExtVoltageLowThreshold.18	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.18	Integer	0
ibEntityExtVoltageLowThreshold.19	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.19	Integer	0
ibEntityExtVoltageLowThreshold.20	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.20	Integer	0
ibEntityExtVoltageLowThreshold.21	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.21	Integer	0
ibEntityExtVoltageLowThreshold.22	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.22	Integer	0
ibEntityExtVoltageLowThreshold.23	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.23	Integer	0
ibEntityExtVoltageLowThreshold.24	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.24	Integer	0
ibEntityExtVoltageLowThreshold.25	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.25	Integer	0
ibEntityExtVoltageLowThreshold.26	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.26	Integer	0
ibEntityExtVoltageLowThreshold.27	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.27	Integer	0
ibEntityExtVoltageLowThreshold.28	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.28	Integer	0
ibEntityExtVoltageLowThreshold.29	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.29	Integer	0
ibEntityExtVoltageLowThreshold.30	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.30	Integer	0
ibEntityExtVoltageLowThreshold.31	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.31	Integer	0
ibEntityExtVoltageLowThreshold.212	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.212	Integer	0
ibEntityExtVoltageLowThreshold.213	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.213	Integer	0
ibEntityExtVoltageLowThreshold.216	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.216	Integer	0
ibEntityExtVoltageLowThreshold.220	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.220	Integer	0
ibEntityExtVoltageLowThreshold.221	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.221	Integer	0
ibEntityExtVoltageLowThreshold.412	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.412	Integer	0
ibEntityExtVoltageLowThreshold.413	1.3.6.1.4.1.26138.2.6.1.1.1.1.15.413	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtVoltageLowThreshold.414	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.414	Integer	0
ibEntityExtVoltageLowThreshold.442	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.442	Integer	0
ibEntityExtVoltageLowThreshold.472	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.472	Integer	0
ibEntityExtVoltageLowThreshold.473	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.473	Integer	0
ibEntityExtVoltageLowThreshold.474	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.474	Integer	0
ibEntityExtVoltageLowThreshold.475	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.475	Integer	0
ibEntityExtVoltageLowThreshold.476	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.476	Integer	0
ibEntityExtVoltageLowThreshold.477	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.477	Integer	0
ibEntityExtVoltageLowThreshold.478	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.478	Integer	0
ibEntityExtVoltageLowThreshold.479	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.479	Integer	0
ibEntityExtVoltageLowThreshold.480	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.480	Integer	0
ibEntityExtVoltageLowThreshold.481	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.481	Integer	0
ibEntityExtVoltageLowThreshold.482	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.482	Integer	0
ibEntityExtVoltageLowThreshold.483	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.483	Integer	0
ibEntityExtVoltageLowThreshold.484	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.484	Integer	0
ibEntityExtVoltageLowThreshold.485	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.485	Integer	0
ibEntityExtVoltageLowThreshold.486	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.486	Integer	0
ibEntityExtVoltageLowThreshold.487	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.487	Integer	0
ibEntityExtVoltageLowThreshold.488	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.488	Integer	0
ibEntityExtVoltageLowThreshold.489	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.489	Integer	0
ibEntityExtVoltageLowThreshold.490	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.490	Integer	0
ibEntityExtVoltageLowThreshold.491	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.491	Integer	0
ibEntityExtVoltageLowThreshold.492	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.492	Integer	0
ibEntityExtVoltageLowThreshold.493	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.493	Integer	0
ibEntityExtVoltageLowThreshold.494	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.494	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtVoltageLowThreshold.495	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.495	Integer	0
ibEntityExtVoltageLowThreshold.496	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.496	Integer	0
ibEntityExtVoltageLowThreshold.497	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.497	Integer	0
ibEntityExtVoltageLowThreshold.498	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.498	Integer	0
ibEntityExtVoltageLowThreshold.499	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.499	Integer	0
ibEntityExtVoltageLowThreshold.500	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.500	Integer	0
ibEntityExtVoltageLowThreshold.501	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.501	Integer	0
ibEntityExtVoltageLowThreshold.502	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.502	Integer	0
ibEntityExtVoltageLowThreshold.503	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.503	Integer	0
ibEntityExtVoltageLowThreshold.504	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.504	Integer	0
ibEntityExtVoltageLowThreshold.505	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.505	Integer	0
ibEntityExtVoltageLowThreshold.506	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.506	Integer	0
ibEntityExtVoltageLowThreshold.507	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.507	Integer	0
ibEntityExtVoltageLowThreshold.508	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.508	Integer	0
ibEntityExtVoltageLowThreshold.509	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.509	Integer	0
ibEntityExtVoltageLowThreshold.510	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.510	Integer	0
ibEntityExtVoltageLowThreshold.511	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.511	Integer	0
ibEntityExtVoltageLowThreshold.512	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.512	Integer	0
ibEntityExtVoltageLowThreshold.513	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.513	Integer	0
ibEntityExtVoltageLowThreshold.514	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.514	Integer	0
ibEntityExtVoltageLowThreshold.515	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.515	Integer	0
ibEntityExtVoltageLowThreshold.516	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.516	Integer	0
ibEntityExtVoltageLowThreshold.517	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.517	Integer	0
ibEntityExtVoltageLowThreshold.518	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.518	Integer	0
ibEntityExtVoltageLowThreshold.519	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.519	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtVoltageLowThreshold.520	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.520	Integer	0
ibEntityExtVoltageLowThreshold.521	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.521	Integer	0
ibEntityExtVoltageLowThreshold.522	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.522	Integer	0
ibEntityExtVoltageLowThreshold.523	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.523	Integer	0
ibEntityExtVoltageLowThreshold.524	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.524	Integer	0
ibEntityExtVoltageLowThreshold.525	.1.3.6.1.4.1.26138.2.6.1.1.1.1.15.525	Integer	0
ibEntityExtVoltageHighThreshold.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.1	Integer	0
ibEntityExtVoltageHighThreshold.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.2	Integer	0
ibEntityExtVoltageHighThreshold.12	1.3.6.1.4.1.26138.2.6.1.1.1.1.16.12	Integer	0
ibEntityExtVoltageHighThreshold.13	1.3.6.1.4.1.26138.2.6.1.1.1.1.16.13	Integer	0
ibEntityExtVoltageHighThreshold.14	1.3.6.1.4.1.26138.2.6.1.1.1.1.16.14	Integer	0
ibEntityExtVoltageHighThreshold.15	1.3.6.1.4.1.26138.2.6.1.1.1.1.16.15	Integer	0
ibEntityExtVoltageHighThreshold.16	1.3.6.1.4.1.26138.2.6.1.1.1.1.16.16	Integer	0
ibEntityExtVoltageHighThreshold.17	1.3.6.1.4.1.26138.2.6.1.1.1.1.16.17	Integer	0
ibEntityExtVoltageHighThreshold.18	1.3.6.1.4.1.26138.2.6.1.1.1.1.16.18	Integer	0
ibEntityExtVoltageHighThreshold.19	1.3.6.1.4.1.26138.2.6.1.1.1.1.16.19	Integer	0
ibEntityExtVoltageHighThreshold.20	1.3.6.1.4.1.26138.2.6.1.1.1.1.16.20	Integer	0
ibEntityExtVoltageHighThreshold.21	1.3.6.1.4.1.26138.2.6.1.1.1.1.16.21	Integer	0
ibEntityExtVoltageHighThreshold.22	1.3.6.1.4.1.26138.2.6.1.1.1.1.16.22	Integer	0
ibEntityExtVoltageHighThreshold.23	1.3.6.1.4.1.26138.2.6.1.1.1.1.16.23	Integer	0
ibEntityExtVoltageHighThreshold.24	1.3.6.1.4.1.26138.2.6.1.1.1.1.16.24	Integer	0
ibEntityExtVoltageHighThreshold.25	1.3.6.1.4.1.26138.2.6.1.1.1.1.16.25	Integer	0
ibEntityExtVoltageHighThreshold.26	1.3.6.1.4.1.26138.2.6.1.1.1.1.16.26	Integer	0
ibEntityExtVoltageHighThreshold.27	1.3.6.1.4.1.26138.2.6.1.1.1.1.16.27	Integer	0
ibEntityExtVoltageHighThreshold.28	1.3.6.1.4.1.26138.2.6.1.1.1.1.16.28	Integer	0



Name	OID	Value Type	Value Example
ibEntityExtVoltageHighThreshold.29	1.3.6.1.4.1.26138.2.6.1.1.1.16.29	Integer	0
ibEntityExtVoltageHighThreshold.30	1.3.6.1.4.1.26138.2.6.1.1.1.16.30	Integer	0
ibEntityExtVoltageHighThreshold.31	1.3.6.1.4.1.26138.2.6.1.1.1.16.31	Integer	0
ibEntityExtVoltageHighThreshold.212	1.3.6.1.4.1.26138.2.6.1.1.1.16.212	Integer	0
ibEntityExtVoltageHighThreshold.213	1.3.6.1.4.1.26138.2.6.1.1.1.16.213	Integer	0
ibEntityExtVoltageHighThreshold.216	1.3.6.1.4.1.26138.2.6.1.1.1.16.216	Integer	0
ibEntityExtVoltageHighThreshold.220	1.3.6.1.4.1.26138.2.6.1.1.1.16.220	Integer	0
ibEntityExtVoltageHighThreshold.221	1.3.6.1.4.1.26138.2.6.1.1.1.16.221	Integer	0
ibEntityExtVoltageHighThreshold.412	1.3.6.1.4.1.26138.2.6.1.1.1.16.412	Integer	0
ibEntityExtVoltageHighThreshold.413	1.3.6.1.4.1.26138.2.6.1.1.1.16.413	Integer	0
ibEntityExtVoltageHighThreshold.414	1.3.6.1.4.1.26138.2.6.1.1.1.16.414	Integer	0
ibEntityExtVoltageHighThreshold.442	1.3.6.1.4.1.26138.2.6.1.1.1.16.442	Integer	0
ibEntityExtVoltageHighThreshold.472	1.3.6.1.4.1.26138.2.6.1.1.1.16.472	Integer	0
ibEntityExtVoltageHighThreshold.473	1.3.6.1.4.1.26138.2.6.1.1.1.16.473	Integer	0
ibEntityExtVoltageHighThreshold.474	1.3.6.1.4.1.26138.2.6.1.1.1.16.474	Integer	0
ibEntityExtVoltageHighThreshold.475	1.3.6.1.4.1.26138.2.6.1.1.1.16.475	Integer	0
ibEntityExtVoltageHighThreshold.476	1.3.6.1.4.1.26138.2.6.1.1.1.16.476	Integer	0
ibEntityExtVoltageHighThreshold.477	1.3.6.1.4.1.26138.2.6.1.1.1.16.477	Integer	0
ibEntityExtVoltageHighThreshold.478	1.3.6.1.4.1.26138.2.6.1.1.1.16.478	Integer	0
ibEntityExtVoltageHighThreshold.479	1.3.6.1.4.1.26138.2.6.1.1.1.16.479	Integer	0
ibEntityExtVoltageHighThreshold.480	1.3.6.1.4.1.26138.2.6.1.1.1.16.480	Integer	0
ibEntityExtVoltageHighThreshold.481	1.3.6.1.4.1.26138.2.6.1.1.1.16.481	Integer	0
ibEntityExtVoltageHighThreshold.482	1.3.6.1.4.1.26138.2.6.1.1.1.16.482	Integer	0
ibEntityExtVoltageHighThreshold.483	1.3.6.1.4.1.26138.2.6.1.1.1.16.483	Integer	0
ibEntityExtVoltageHighThreshold.484	1.3.6.1.4.1.26138.2.6.1.1.1.16.484	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtVoltageHighThreshold.485	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.485	Integer	0
ibEntityExtVoltageHighThreshold.486	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.486	Integer	0
ibEntityExtVoltageHighThreshold.487	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.487	Integer	0
ibEntityExtVoltageHighThreshold.488	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.488	Integer	0
ibEntityExtVoltageHighThreshold.489	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.489	Integer	0
ibEntityExtVoltageHighThreshold.490	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.490	Integer	0
ibEntityExtVoltageHighThreshold.491	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.491	Integer	0
ibEntityExtVoltageHighThreshold.492	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.492	Integer	0
ibEntityExtVoltageHighThreshold.493	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.493	Integer	0
ibEntityExtVoltageHighThreshold.494	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.494	Integer	0
ibEntityExtVoltageHighThreshold.495	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.495	Integer	0
ibEntityExtVoltageHighThreshold.496	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.496	Integer	0
ibEntityExtVoltageHighThreshold.497	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.497	Integer	0
ibEntityExtVoltageHighThreshold.498	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.498	Integer	0
ibEntityExtVoltageHighThreshold.499	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.499	Integer	0
ibEntityExtVoltageHighThreshold.500	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.500	Integer	0
ibEntityExtVoltageHighThreshold.501	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.501	Integer	0
ibEntityExtVoltageHighThreshold.502	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.502	Integer	0
ibEntityExtVoltageHighThreshold.503	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.503	Integer	0
ibEntityExtVoltageHighThreshold.504	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.504	Integer	0
ibEntityExtVoltageHighThreshold.505	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.505	Integer	0
ibEntityExtVoltageHighThreshold.506	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.506	Integer	0
ibEntityExtVoltageHighThreshold.507	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.507	Integer	0
ibEntityExtVoltageHighThreshold.508	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.508	Integer	0
ibEntityExtVoltageHighThreshold.509	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.509	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtVoltageHighThreshold.510	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.510	Integer	0
ibEntityExtVoltageHighThreshold.511	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.511	Integer	0
ibEntityExtVoltageHighThreshold.512	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.512	Integer	0
ibEntityExtVoltageHighThreshold.513	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.513	Integer	0
ibEntityExtVoltageHighThreshold.514	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.514	Integer	0
ibEntityExtVoltageHighThreshold.515	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.515	Integer	0
ibEntityExtVoltageHighThreshold.516	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.516	Integer	0
ibEntityExtVoltageHighThreshold.517	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.517	Integer	0
ibEntityExtVoltageHighThreshold.518	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.518	Integer	0
ibEntityExtVoltageHighThreshold.519	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.519	Integer	0
ibEntityExtVoltageHighThreshold.520	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.520	Integer	0
ibEntityExtVoltageHighThreshold.521	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.521	Integer	0
ibEntityExtVoltageHighThreshold.522	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.522	Integer	0
ibEntityExtVoltageHighThreshold.523	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.523	Integer	0
ibEntityExtVoltageHighThreshold.524	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.524	Integer	0
ibEntityExtVoltageHighThreshold.525	.1.3.6.1.4.1.26138.2.6.1.1.1.1.16.525	Integer	0
ibEntityExtCriticalTemperatureThreshold.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.1	Integer	65535
ibEntityExtCriticalTemperatureThreshold.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.2	Integer	65535
ibEntityExtCriticalTemperatureThreshold.12	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.12	Integer	65535
ibEntityExtCriticalTemperatureThreshold.13	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.13	Integer	65535
ibEntityExtCriticalTemperatureThreshold.14	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.14	Integer	65535
ibEntityExtCriticalTemperatureThreshold.15	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.15	Integer	65535
ibEntityExtCriticalTemperatureThreshold.16	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.16	Integer	65535
ibEntityExtCriticalTemperatureThreshold.17	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.17	Integer	65535
ibEntityExtCriticalTemperatureThreshold.18	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.18	Integer	65535

Name	OID	Value Type	Value Example
ibEntityExtCriticalTemperatureThreshold.19	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.19	Integer	65535
ibEntityExtCriticalTemperatureThreshold.20	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.20	Integer	65535
ibEntityExtCriticalTemperatureThreshold.21	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.21	Integer	65535
ibEntityExtCriticalTemperatureThreshold.22	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.22	Integer	65535
ibEntityExtCriticalTemperatureThreshold.23	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.23	Integer	65535
ibEntityExtCriticalTemperatureThreshold.24	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.24	Integer	65535
ibEntityExtCriticalTemperatureThreshold.25	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.25	Integer	65535
ibEntityExtCriticalTemperatureThreshold.26	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.26	Integer	65535
ibEntityExtCriticalTemperatureThreshold.27	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.27	Integer	65535
ibEntityExtCriticalTemperatureThreshold.28	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.28	Integer	65535
ibEntityExtCriticalTemperatureThreshold.29	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.29	Integer	65535
ibEntityExtCriticalTemperatureThreshold.30	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.30	Integer	65535
ibEntityExtCriticalTemperatureThreshold.31	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.31	Integer	65535
ibEntityExtCriticalTemperatureThreshold.212	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.212	Integer	65535
ibEntityExtCriticalTemperatureThreshold.213	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.213	Integer	65535
ibEntityExtCriticalTemperatureThreshold.216	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.216	Integer	65535
ibEntityExtCriticalTemperatureThreshold.220	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.220	Integer	61
ibEntityExtCriticalTemperatureThreshold.221	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.221	Integer	112
ibEntityExtCriticalTemperatureThreshold.412	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.412	Integer	65535
ibEntityExtCriticalTemperatureThreshold.413	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.413	Integer	65535
ibEntityExtCriticalTemperatureThreshold.414	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.414	Integer	65535
ibEntityExtCriticalTemperatureThreshold.442	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.442	Integer	65535
ibEntityExtCriticalTemperatureThreshold.472	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.472	Integer	65535
ibEntityExtCriticalTemperatureThreshold.473	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.473	Integer	65535
ibEntityExtCriticalTemperatureThreshold.474	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.474	Integer	65535

Name	OID	Value Type	Value Example
ibEntityExtCriticalTemperatureThreshold.475	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.475	Integer	65535
ibEntityExtCriticalTemperatureThreshold.476	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.476	Integer	65535
ibEntityExtCriticalTemperatureThreshold.477	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.477	Integer	65535
ibEntityExtCriticalTemperatureThreshold.478	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.478	Integer	65535
ibEntityExtCriticalTemperatureThreshold.479	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.479	Integer	65535
ibEntityExtCriticalTemperatureThreshold.480	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.480	Integer	65535
ibEntityExtCriticalTemperatureThreshold.481	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.481	Integer	65535
ibEntityExtCriticalTemperatureThreshold.482	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.482	Integer	65535
ibEntityExtCriticalTemperatureThreshold.483	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.483	Integer	65535
ibEntityExtCriticalTemperatureThreshold.484	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.484	Integer	65535
ibEntityExtCriticalTemperatureThreshold.485	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.485	Integer	65535
ibEntityExtCriticalTemperatureThreshold.486	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.486	Integer	65535
ibEntityExtCriticalTemperatureThreshold.487	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.487	Integer	65535
ibEntityExtCriticalTemperatureThreshold.488	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.488	Integer	65535
ibEntityExtCriticalTemperatureThreshold.489	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.489	Integer	65535
ibEntityExtCriticalTemperatureThreshold.490	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.490	Integer	65535
ibEntityExtCriticalTemperatureThreshold.491	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.491	Integer	65535
ibEntityExtCriticalTemperatureThreshold.492	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.492	Integer	65535
ibEntityExtCriticalTemperatureThreshold.493	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.493	Integer	65535
ibEntityExtCriticalTemperatureThreshold.494	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.494	Integer	65535
ibEntityExtCriticalTemperatureThreshold.495	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.495	Integer	65535
ibEntityExtCriticalTemperatureThreshold.496	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.496	Integer	65535
ibEntityExtCriticalTemperatureThreshold.497	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.497	Integer	65535
ibEntityExtCriticalTemperatureThreshold.498	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.498	Integer	65535
ibEntityExtCriticalTemperatureThreshold.499	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.499	Integer	65535

Name	OID	Value Type	Value Example
ibEntityExtCriticalTemperatureThreshold.500	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.500	Integer	65535
ibEntityExtCriticalTemperatureThreshold.501	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.501	Integer	65535
ibEntityExtCriticalTemperatureThreshold.502	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.502	Integer	65535
ibEntityExtCriticalTemperatureThreshold.503	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.503	Integer	65535
ibEntityExtCriticalTemperatureThreshold.504	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.504	Integer	65535
ibEntityExtCriticalTemperatureThreshold.505	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.505	Integer	65535
ibEntityExtCriticalTemperatureThreshold.506	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.506	Integer	65535
ibEntityExtCriticalTemperatureThreshold.507	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.507	Integer	65535
ibEntityExtCriticalTemperatureThreshold.508	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.508	Integer	65535
ibEntityExtCriticalTemperatureThreshold.509	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.509	Integer	65535
ibEntityExtCriticalTemperatureThreshold.510	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.510	Integer	65535
ibEntityExtCriticalTemperatureThreshold.511	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.511	Integer	65535
ibEntityExtCriticalTemperatureThreshold.512	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.512	Integer	65535
ibEntityExtCriticalTemperatureThreshold.513	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.513	Integer	65535
ibEntityExtCriticalTemperatureThreshold.514	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.514	Integer	65535
ibEntityExtCriticalTemperatureThreshold.515	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.515	Integer	65535
ibEntityExtCriticalTemperatureThreshold.516	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.516	Integer	65535
ibEntityExtCriticalTemperatureThreshold.517	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.517	Integer	65535
ibEntityExtCriticalTemperatureThreshold.518	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.518	Integer	65535
ibEntityExtCriticalTemperatureThreshold.519	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.519	Integer	65535
ibEntityExtCriticalTemperatureThreshold.520	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.520	Integer	65535
ibEntityExtCriticalTemperatureThreshold.521	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.521	Integer	65535
ibEntityExtCriticalTemperatureThreshold.522	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.522	Integer	65535
ibEntityExtCriticalTemperatureThreshold.523	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.523	Integer	65535
ibEntityExtCriticalTemperatureThreshold.524	.1.3.6.1.4.1.26138.2.6.1.1.1.1.17.524	Integer	65535

Name	OID	Value Type	Value Example
ibEntityExtCriticalTemperatureThreshold.525	1.3.6.1.4.1.26138.2.6.1.1.1.1.17.525	Integer	65535
ibEntityExtMacAddress.1	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.1	OctetString	14-84-77-95-1D-B0
ibEntityExtMacAddress.2	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.2	OctetString	14-84-77-95-1D-B0
ibEntityExtMacAddress.12	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.12	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.13	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.13	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.14	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.14	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.15	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.15	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.16	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.16	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.17	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.17	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.18	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.18	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.19	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.19	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.20	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.20	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.21	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.21	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.22	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.22	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.23	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.23	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.24	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.24	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.25	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.25	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.26	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.26	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.27	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.27	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.28	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.28	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.29	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.29	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.30	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.30	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.31	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.31	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.212	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.212	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.213	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.213	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.216	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.216	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.220	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.220	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.221	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.221	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.412	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.412	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.413	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.413	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.414	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.414	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.442	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.442	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.472	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.472	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.473	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.473	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.474	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.474	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.475	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.475	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.476	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.476	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.477	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.477	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.478	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.478	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.479	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.479	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.480	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.480	OctetString	00-00-00-00-00-00
ibEntityExtMacAddress.481	1.3.6.1.4.1.26138.2.6.1.1.1.1.18.481	OctetString	00-00-00-00-00-00





Name	OID	Value Type	Value Example
ibEntityExtMacAddress.525	.1.3.6.1.4.1.26138.2.6.1.1.1.1.18.525	OctetString	00-00-00-00-00-00
ibEntityExtErrorStatus.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.19.1	Integer	normal (2)
ibEntityExtErrorStatus.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.19.2	Integer	normal (2)
ibEntityExtErrorStatus.12	1.3.6.1.4.1.26138.2.6.1.1.1.1.19.12	Integer	normal (2)
ibEntityExtErrorStatus.13	1.3.6.1.4.1.26138.2.6.1.1.1.1.19.13	Integer	normal (2)
ibEntityExtErrorStatus.14	1.3.6.1.4.1.26138.2.6.1.1.1.1.19.14	Integer	normal (2)
ibEntityExtErrorStatus.15	1.3.6.1.4.1.26138.2.6.1.1.1.1.19.15	Integer	normal (2)
ibEntityExtErrorStatus.16	1.3.6.1.4.1.26138.2.6.1.1.1.1.19.16	Integer	normal (2)
ibEntityExtErrorStatus.17	1.3.6.1.4.1.26138.2.6.1.1.1.1.19.17	Integer	normal (2)
ibEntityExtErrorStatus.18	1.3.6.1.4.1.26138.2.6.1.1.1.1.19.18	Integer	normal (2)
ibEntityExtErrorStatus.19	1.3.6.1.4.1.26138.2.6.1.1.1.1.19.19	Integer	normal (2)
ibEntityExtErrorStatus.20	1.3.6.1.4.1.26138.2.6.1.1.1.1.19.20	Integer	normal (2)
ibEntityExtErrorStatus.21	1.3.6.1.4.1.26138.2.6.1.1.1.1.19.21	Integer	normal (2)
ibEntityExtErrorStatus.22	1.3.6.1.4.1.26138.2.6.1.1.1.1.19.22	Integer	normal (2)
ibEntityExtErrorStatus.23	1.3.6.1.4.1.26138.2.6.1.1.1.1.19.23	Integer	normal (2)
ibEntityExtErrorStatus.24	1.3.6.1.4.1.26138.2.6.1.1.1.1.19.24	Integer	normal (2)
ibEntityExtErrorStatus.25	1.3.6.1.4.1.26138.2.6.1.1.1.1.19.25	Integer	normal (2)
ibEntityExtErrorStatus.26	1.3.6.1.4.1.26138.2.6.1.1.1.1.19.26	Integer	normal (2)
ibEntityExtErrorStatus.27	1.3.6.1.4.1.26138.2.6.1.1.1.1.19.27	Integer	normal (2)
ibEntityExtErrorStatus.28	1.3.6.1.4.1.26138.2.6.1.1.1.1.19.28	Integer	normal (2)
ibEntityExtErrorStatus.29	1.3.6.1.4.1.26138.2.6.1.1.1.1.19.29	Integer	normal (2)
ibEntityExtErrorStatus.30	1.3.6.1.4.1.26138.2.6.1.1.1.1.19.30	Integer	normal (2)
ibEntityExtErrorStatus.31	1.3.6.1.4.1.26138.2.6.1.1.1.1.19.31	Integer	normal (2)
ibEntityExtErrorStatus.212	.1.3.6.1.4.1.26138.2.6.1.1.1.1.19.212	Integer	normal (2)
ibEntityExtErrorStatus.213	.1.3.6.1.4.1.26138.2.6.1.1.1.1.19.213	Integer	normal (2)
ibEntityExtErrorStatus.216	.1.3.6.1.4.1.26138.2.6.1.1.1.1.19.216	Integer	normal (2)
ibEntityExtErrorStatus.220	.1.3.6.1.4.1.26138.2.6.1.1.1.1.19.220	Integer	normal (2)
ibEntityExtErrorStatus.221	.1.3.6.1.4.1.26138.2.6.1.1.1.1.19.221	Integer	normal (2)
ibEntityExtErrorStatus.412	.1.3.6.1.4.1.26138.2.6.1.1.1.1.19.412	Integer	normal (2)
ibEntityExtErrorStatus.413	.1.3.6.1.4.1.26138.2.6.1.1.1.1.19.413	Integer	normal (2)
ibEntityExtErrorStatus.414	.1.3.6.1.4.1.26138.2.6.1.1.1.1.19.414	Integer	normal (2)
ibEntityExtErrorStatus.442	.1.3.6.1.4.1.26138.2.6.1.1.1.1.19.442	Integer	normal (2)
ibEntityExtErrorStatus.472	.1.3.6.1.4.1.26138.2.6.1.1.1.1.19.472	Integer	normal (2)
ibEntityExtErrorStatus.473	.1.3.6.1.4.1.26138.2.6.1.1.1.1.19.473	Integer	normal (2)
ibEntityExtErrorStatus.474	.1.3.6.1.4.1.26138.2.6.1.1.1.1.19.474	Integer	normal (2)
ibEntityExtErrorStatus.475	.1.3.6.1.4.1.26138.2.6.1.1.1.1.19.475	Integer	normal (2)
ibEntityExtErrorStatus.476	.1.3.6.1.4.1.26138.2.6.1.1.1.1.19.476	Integer	normal (2)
ibEntityExtErrorStatus.477	.1.3.6.1.4.1.26138.2.6.1.1.1.1.19.477	Integer	normal (2)
ibEntityExtErrorStatus.478	.1.3.6.1.4.1.26138.2.6.1.1.1.1.19.478	Integer	normal (2)
ibEntityExtErrorStatus.479	.1.3.6.1.4.1.26138.2.6.1.1.1.1.19.479	Integer	normal (2)
ibEntityExtErrorStatus.480	.1.3.6.1.4.1.26138.2.6.1.1.1.1.19.480	Integer	normal (2)
ibEntityExtErrorStatus.481	.1.3.6.1.4.1.26138.2.6.1.1.1.1.19.481	Integer	normal (2)
ibEntityExtErrorStatus.482	.1.3.6.1.4.1.26138.2.6.1.1.1.1.19.482	Integer	normal (2)



Name	OID	Value Type	Value Example
ibEntityExtCpuMaxUsage.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.1	Integer	0
ibEntityExtCpuMaxUsage.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.2	Integer	0
ibEntityExtCpuMaxUsage.12	1.3.6.1.4.1.26138.2.6.1.1.1.1.20.12	Integer	0
ibEntityExtCpuMaxUsage.13	1.3.6.1.4.1.26138.2.6.1.1.1.1.20.13	Integer	0
ibEntityExtCpuMaxUsage.14	1.3.6.1.4.1.26138.2.6.1.1.1.1.20.14	Integer	0
ibEntityExtCpuMaxUsage.15	1.3.6.1.4.1.26138.2.6.1.1.1.1.20.15	Integer	0
ibEntityExtCpuMaxUsage.16	1.3.6.1.4.1.26138.2.6.1.1.1.1.20.16	Integer	0
ibEntityExtCpuMaxUsage.17	1.3.6.1.4.1.26138.2.6.1.1.1.1.20.17	Integer	0
ibEntityExtCpuMaxUsage.18	1.3.6.1.4.1.26138.2.6.1.1.1.1.20.18	Integer	0
ibEntityExtCpuMaxUsage.19	1.3.6.1.4.1.26138.2.6.1.1.1.1.20.19	Integer	0
ibEntityExtCpuMaxUsage.20	1.3.6.1.4.1.26138.2.6.1.1.1.1.20.20	Integer	0
ibEntityExtCpuMaxUsage.21	1.3.6.1.4.1.26138.2.6.1.1.1.1.20.21	Integer	0
ibEntityExtCpuMaxUsage.22	1.3.6.1.4.1.26138.2.6.1.1.1.1.20.22	Integer	0
ibEntityExtCpuMaxUsage.23	1.3.6.1.4.1.26138.2.6.1.1.1.1.20.23	Integer	0
ibEntityExtCpuMaxUsage.24	1.3.6.1.4.1.26138.2.6.1.1.1.1.20.24	Integer	0
ibEntityExtCpuMaxUsage.25	1.3.6.1.4.1.26138.2.6.1.1.1.1.20.25	Integer	0
ibEntityExtCpuMaxUsage.26	1.3.6.1.4.1.26138.2.6.1.1.1.1.20.26	Integer	0
ibEntityExtCpuMaxUsage.27	1.3.6.1.4.1.26138.2.6.1.1.1.1.20.27	Integer	0
ibEntityExtCpuMaxUsage.28	1.3.6.1.4.1.26138.2.6.1.1.1.1.20.28	Integer	0
ibEntityExtCpuMaxUsage.29	1.3.6.1.4.1.26138.2.6.1.1.1.1.20.29	Integer	0
ibEntityExtCpuMaxUsage.30	1.3.6.1.4.1.26138.2.6.1.1.1.1.20.30	Integer	0
ibEntityExtCpuMaxUsage.31	1.3.6.1.4.1.26138.2.6.1.1.1.1.20.31	Integer	0
ibEntityExtCpuMaxUsage.212	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.212	Integer	28
ibEntityExtCpuMaxUsage.213	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.213	Integer	0
ibEntityExtCpuMaxUsage.216	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.216	Integer	0
ibEntityExtCpuMaxUsage.220	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.220	Integer	0
ibEntityExtCpuMaxUsage.221	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.221	Integer	0
ibEntityExtCpuMaxUsage.412	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.412	Integer	0
ibEntityExtCpuMaxUsage.413	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.413	Integer	0
ibEntityExtCpuMaxUsage.414	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.414	Integer	0
ibEntityExtCpuMaxUsage.442	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.442	Integer	0
ibEntityExtCpuMaxUsage.472	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.472	Integer	0
ibEntityExtCpuMaxUsage.473	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.473	Integer	0
ibEntityExtCpuMaxUsage.474	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.474	Integer	0
ibEntityExtCpuMaxUsage.475	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.475	Integer	0
ibEntityExtCpuMaxUsage.476	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.476	Integer	0
ibEntityExtCpuMaxUsage.477	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.477	Integer	0
ibEntityExtCpuMaxUsage.478	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.478	Integer	0
ibEntityExtCpuMaxUsage.479	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.479	Integer	0
ibEntityExtCpuMaxUsage.480	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.480	Integer	0
ibEntityExtCpuMaxUsage.481	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.481	Integer	0
ibEntityExtCpuMaxUsage.482	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.482	Integer	0
ibEntityExtCpuMaxUsage.483	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.483	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtCpuMaxUsage.484	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.484	Integer	0
ibEntityExtCpuMaxUsage.485	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.485	Integer	0
ibEntityExtCpuMaxUsage.486	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.486	Integer	0
ibEntityExtCpuMaxUsage.487	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.487	Integer	0
ibEntityExtCpuMaxUsage.488	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.488	Integer	0
ibEntityExtCpuMaxUsage.489	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.489	Integer	0
ibEntityExtCpuMaxUsage.490	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.490	Integer	0
ibEntityExtCpuMaxUsage.491	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.491	Integer	0
ibEntityExtCpuMaxUsage.492	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.492	Integer	0
ibEntityExtCpuMaxUsage.493	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.493	Integer	0
ibEntityExtCpuMaxUsage.494	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.494	Integer	0
ibEntityExtCpuMaxUsage.495	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.495	Integer	0
ibEntityExtCpuMaxUsage.496	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.496	Integer	0
ibEntityExtCpuMaxUsage.497	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.497	Integer	0
ibEntityExtCpuMaxUsage.498	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.498	Integer	0
ibEntityExtCpuMaxUsage.499	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.499	Integer	0
ibEntityExtCpuMaxUsage.500	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.500	Integer	0
ibEntityExtCpuMaxUsage.501	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.501	Integer	0
ibEntityExtCpuMaxUsage.502	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.502	Integer	0
ibEntityExtCpuMaxUsage.503	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.503	Integer	0
ibEntityExtCpuMaxUsage.504	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.504	Integer	0
ibEntityExtCpuMaxUsage.505	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.505	Integer	0
ibEntityExtCpuMaxUsage.506	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.506	Integer	0
ibEntityExtCpuMaxUsage.507	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.507	Integer	0
ibEntityExtCpuMaxUsage.508	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.508	Integer	0
ibEntityExtCpuMaxUsage.509	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.509	Integer	0
ibEntityExtCpuMaxUsage.510	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.510	Integer	0
ibEntityExtCpuMaxUsage.511	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.511	Integer	0
ibEntityExtCpuMaxUsage.512	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.512	Integer	0
ibEntityExtCpuMaxUsage.513	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.513	Integer	0
ibEntityExtCpuMaxUsage.514	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.514	Integer	0
ibEntityExtCpuMaxUsage.515	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.515	Integer	0
ibEntityExtCpuMaxUsage.516	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.516	Integer	0
ibEntityExtCpuMaxUsage.517	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.517	Integer	0
ibEntityExtCpuMaxUsage.518	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.518	Integer	0
ibEntityExtCpuMaxUsage.519	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.519	Integer	0
ibEntityExtCpuMaxUsage.520	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.520	Integer	0
ibEntityExtCpuMaxUsage.521	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.521	Integer	0
ibEntityExtCpuMaxUsage.522	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.522	Integer	0
ibEntityExtCpuMaxUsage.523	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.523	Integer	0
ibEntityExtCpuMaxUsage.524	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.524	Integer	0
ibEntityExtCpuMaxUsage.525	.1.3.6.1.4.1.26138.2.6.1.1.1.1.20.525	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtLowerTemperatureThreshold.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.1	Integer	65535
ibEntityExtLowerTemperatureThreshold.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.2	Integer	65535
ibEntityExtLowerTemperatureThreshold.12	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.12	Integer	65535
ibEntityExtLowerTemperatureThreshold.13	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.13	Integer	65535
ibEntityExtLowerTemperatureThreshold.14	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.14	Integer	65535
ibEntityExtLowerTemperatureThreshold.15	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.15	Integer	65535
ibEntityExtLowerTemperatureThreshold.16	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.16	Integer	65535
ibEntityExtLowerTemperatureThreshold.17	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.17	Integer	65535
ibEntityExtLowerTemperatureThreshold.18	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.18	Integer	65535
ibEntityExtLowerTemperatureThreshold.19	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.19	Integer	65535
ibEntityExtLowerTemperatureThreshold.20	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.20	Integer	65535
ibEntityExtLowerTemperatureThreshold.21	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.21	Integer	65535
ibEntityExtLowerTemperatureThreshold.22	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.22	Integer	65535
ibEntityExtLowerTemperatureThreshold.23	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.23	Integer	65535
ibEntityExtLowerTemperatureThreshold.24	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.24	Integer	65535
ibEntityExtLowerTemperatureThreshold.25	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.25	Integer	65535
ibEntityExtLowerTemperatureThreshold.26	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.26	Integer	65535
ibEntityExtLowerTemperatureThreshold.27	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.27	Integer	65535
ibEntityExtLowerTemperatureThreshold.28	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.28	Integer	65535
ibEntityExtLowerTemperatureThreshold.29	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.29	Integer	65535
ibEntityExtLowerTemperatureThreshold.30	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.30	Integer	65535
ibEntityExtLowerTemperatureThreshold.31	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.31	Integer	65535
ibEntityExtLowerTemperatureThreshold.212	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.212	Integer	65535
ibEntityExtLowerTemperatureThreshold.213	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.213	Integer	65535
ibEntityExtLowerTemperatureThreshold.216	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.216	Integer	65535

Name	OID	Value Type	Value Example
ibEntityExtLowerTemperatureThreshold.220	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.220	Integer	-10
ibEntityExtLowerTemperatureThreshold.221	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.221	Integer	0
ibEntityExtLowerTemperatureThreshold.412	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.412	Integer	65535
ibEntityExtLowerTemperatureThreshold.413	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.413	Integer	65535
ibEntityExtLowerTemperatureThreshold.414	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.414	Integer	65535
ibEntityExtLowerTemperatureThreshold.442	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.442	Integer	65535
ibEntityExtLowerTemperatureThreshold.472	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.472	Integer	65535
ibEntityExtLowerTemperatureThreshold.473	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.473	Integer	65535
ibEntityExtLowerTemperatureThreshold.474	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.474	Integer	65535
ibEntityExtLowerTemperatureThreshold.475	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.475	Integer	65535
ibEntityExtLowerTemperatureThreshold.476	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.476	Integer	65535
ibEntityExtLowerTemperatureThreshold.477	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.477	Integer	65535
ibEntityExtLowerTemperatureThreshold.478	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.478	Integer	65535
ibEntityExtLowerTemperatureThreshold.479	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.479	Integer	65535
ibEntityExtLowerTemperatureThreshold.480	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.480	Integer	65535
ibEntityExtLowerTemperatureThreshold.481	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.481	Integer	65535
ibEntityExtLowerTemperatureThreshold.482	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.482	Integer	65535
ibEntityExtLowerTemperatureThreshold.483	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.483	Integer	65535
ibEntityExtLowerTemperatureThreshold.484	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.484	Integer	65535
ibEntityExtLowerTemperatureThreshold.485	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.485	Integer	65535
ibEntityExtLowerTemperatureThreshold.486	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.486	Integer	65535
ibEntityExtLowerTemperatureThreshold.487	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.487	Integer	65535
ibEntityExtLowerTemperatureThreshold.488	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.488	Integer	65535
ibEntityExtLowerTemperatureThreshold.489	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.489	Integer	65535
ibEntityExtLowerTemperatureThreshold.490	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.490	Integer	65535

Name	OID	Value Type	Value Example
ibEntityExtLowerTemperatureThreshold.491	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.491	Integer	65535
ibEntityExtLowerTemperatureThreshold.492	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.492	Integer	65535
ibEntityExtLowerTemperatureThreshold.493	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.493	Integer	65535
ibEntityExtLowerTemperatureThreshold.494	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.494	Integer	65535
ibEntityExtLowerTemperatureThreshold.495	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.495	Integer	65535
ibEntityExtLowerTemperatureThreshold.496	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.496	Integer	65535
ibEntityExtLowerTemperatureThreshold.497	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.497	Integer	65535
ibEntityExtLowerTemperatureThreshold.498	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.498	Integer	65535
ibEntityExtLowerTemperatureThreshold.499	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.499	Integer	65535
ibEntityExtLowerTemperatureThreshold.500	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.500	Integer	65535
ibEntityExtLowerTemperatureThreshold.501	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.501	Integer	65535
ibEntityExtLowerTemperatureThreshold.502	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.502	Integer	65535
ibEntityExtLowerTemperatureThreshold.503	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.503	Integer	65535
ibEntityExtLowerTemperatureThreshold.504	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.504	Integer	65535
ibEntityExtLowerTemperatureThreshold.505	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.505	Integer	65535
ibEntityExtLowerTemperatureThreshold.506	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.506	Integer	65535
ibEntityExtLowerTemperatureThreshold.507	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.507	Integer	65535
ibEntityExtLowerTemperatureThreshold.508	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.508	Integer	65535
ibEntityExtLowerTemperatureThreshold.509	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.509	Integer	65535
ibEntityExtLowerTemperatureThreshold.510	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.510	Integer	65535
ibEntityExtLowerTemperatureThreshold.511	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.511	Integer	65535
ibEntityExtLowerTemperatureThreshold.512	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.512	Integer	65535
ibEntityExtLowerTemperatureThreshold.513	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.513	Integer	65535
ibEntityExtLowerTemperatureThreshold.514	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.514	Integer	65535
ibEntityExtLowerTemperatureThreshold.515	.1.3.6.1.4.1.26138.2.6.1.1.1.1.21.515	Integer	65535



Name	OID	Value Type	Value Example
ibEntityExtLowerTemperatureThreshold.516	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.516	Integer	65535
ibEntityExtLowerTemperatureThreshold.517	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.517	Integer	65535
ibEntityExtLowerTemperatureThreshold.518	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.518	Integer	65535
ibEntityExtLowerTemperatureThreshold.519	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.519	Integer	65535
ibEntityExtLowerTemperatureThreshold.520	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.520	Integer	65535
ibEntityExtLowerTemperatureThreshold.521	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.521	Integer	65535
ibEntityExtLowerTemperatureThreshold.522	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.522	Integer	65535
ibEntityExtLowerTemperatureThreshold.523	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.523	Integer	65535
ibEntityExtLowerTemperatureThreshold.524	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.524	Integer	65535
ibEntityExtLowerTemperatureThreshold.525	1.3.6.1.4.1.26138.2.6.1.1.1.1.21.525	Integer	65535
ibEntityExtShutdownTemperatureThreshold.1	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.1	Integer	65535
ibEntityExtShutdownTemperatureThreshold.2	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.2	Integer	65535
ibEntityExtShutdownTemperatureThreshold.12	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.12	Integer	65535
ibEntityExtShutdownTemperatureThreshold.13	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.13	Integer	65535
ibEntityExtShutdownTemperatureThreshold.14	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.14	Integer	65535
ibEntityExtShutdownTemperatureThreshold.15	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.15	Integer	65535
ibEntityExtShutdownTemperatureThreshold.16	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.16	Integer	65535
ibEntityExtShutdownTemperatureThreshold.17	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.17	Integer	65535
ibEntityExtShutdownTemperatureThreshold.18	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.18	Integer	65535
ibEntityExtShutdownTemperatureThreshold.19	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.19	Integer	65535
ibEntityExtShutdownTemperatureThreshold.20	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.20	Integer	65535
ibEntityExtShutdownTemperatureThreshold.21	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.21	Integer	65535
ibEntityExtShutdownTemperatureThreshold.22	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.22	Integer	65535
ibEntityExtShutdownTemperatureThreshold.23	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.23	Integer	65535
ibEntityExtShutdownTemperatureThreshold.24	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.24	Integer	65535



Name	OID	Value Type	Value Example
ibEntityExtShutdownTemperatureThreshold.25	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.25	Integer	65535
ibEntityExtShutdownTemperatureThreshold.26	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.26	Integer	65535
ibEntityExtShutdownTemperatureThreshold.27	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.27	Integer	65535
ibEntityExtShutdownTemperatureThreshold.28	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.28	Integer	65535
ibEntityExtShutdownTemperatureThreshold.29	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.29	Integer	65535
ibEntityExtShutdownTemperatureThreshold.30	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.30	Integer	65535
ibEntityExtShutdownTemperatureThreshold.31	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.31	Integer	65535
ibEntityExtShutdownTemperatureThreshold.212	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.212	Integer	65535
ibEntityExtShutdownTemperatureThreshold.213	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.213	Integer	65535
ibEntityExtShutdownTemperatureThreshold.216	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.216	Integer	65535
ibEntityExtShutdownTemperatureThreshold.220	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.220	Integer	95
ibEntityExtShutdownTemperatureThreshold.221	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.221	Integer	65535
ibEntityExtShutdownTemperatureThreshold.412	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.412	Integer	65535
ibEntityExtShutdownTemperatureThreshold.413	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.413	Integer	65535
ibEntityExtShutdownTemperatureThreshold.414	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.414	Integer	65535
ibEntityExtShutdownTemperatureThreshold.442	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.442	Integer	65535
ibEntityExtShutdownTemperatureThreshold.472	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.472	Integer	65535
ibEntityExtShutdownTemperatureThreshold.473	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.473	Integer	65535
ibEntityExtShutdownTemperatureThreshold.474	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.474	Integer	65535
ibEntityExtShutdownTemperatureThreshold.475	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.475	Integer	65535
ibEntityExtShutdownTemperatureThreshold.476	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.476	Integer	65535
ibEntityExtShutdownTemperatureThreshold.477	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.477	Integer	65535
ibEntityExtShutdownTemperatureThreshold.478	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.478	Integer	65535
ibEntityExtShutdownTemperatureThreshold.479	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.479	Integer	65535
ibEntityExtShutdownTemperatureThreshold.480	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.480	Integer	65535

Name	OID	Value Type	Value Example
ibEntityExtShutdownTemperatureThreshold.481	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.481	Integer	65535
ibEntityExtShutdownTemperatureThreshold.482	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.482	Integer	65535
ibEntityExtShutdownTemperatureThreshold.483	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.483	Integer	65535
ibEntityExtShutdownTemperatureThreshold.484	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.484	Integer	65535
ibEntityExtShutdownTemperatureThreshold.485	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.485	Integer	65535
ibEntityExtShutdownTemperatureThreshold.486	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.486	Integer	65535
ibEntityExtShutdownTemperatureThreshold.487	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.487	Integer	65535
ibEntityExtShutdownTemperatureThreshold.488	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.488	Integer	65535
ibEntityExtShutdownTemperatureThreshold.489	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.489	Integer	65535
ibEntityExtShutdownTemperatureThreshold.490	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.490	Integer	65535
ibEntityExtShutdownTemperatureThreshold.491	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.491	Integer	65535
ibEntityExtShutdownTemperatureThreshold.492	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.492	Integer	65535
ibEntityExtShutdownTemperatureThreshold.493	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.493	Integer	65535
ibEntityExtShutdownTemperatureThreshold.494	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.494	Integer	65535
ibEntityExtShutdownTemperatureThreshold.495	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.495	Integer	65535
ibEntityExtShutdownTemperatureThreshold.496	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.496	Integer	65535
ibEntityExtShutdownTemperatureThreshold.497	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.497	Integer	65535
ibEntityExtShutdownTemperatureThreshold.498	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.498	Integer	65535
ibEntityExtShutdownTemperatureThreshold.499	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.499	Integer	65535
ibEntityExtShutdownTemperatureThreshold.500	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.500	Integer	65535
ibEntityExtShutdownTemperatureThreshold.501	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.501	Integer	65535
ibEntityExtShutdownTemperatureThreshold.502	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.502	Integer	65535
ibEntityExtShutdownTemperatureThreshold.503	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.503	Integer	65535
ibEntityExtShutdownTemperatureThreshold.504	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.504	Integer	65535
ibEntityExtShutdownTemperatureThreshold.505	1.3.6.1.4.1.26138.2.6.1.1.1.1.22.505	Integer	65535

Name	OID	Value Type	Value Example
ibEntityExtShutdownTemperatureThreshold.506	.1.3.6.1.4.1.26138.2.6.1.1.1.1.22.506	Integer	65535
ibEntityExtShutdownTemperatureThreshold.507	.1.3.6.1.4.1.26138.2.6.1.1.1.1.22.507	Integer	65535
ibEntityExtShutdownTemperatureThreshold.508	.1.3.6.1.4.1.26138.2.6.1.1.1.1.22.508	Integer	65535
ibEntityExtShutdownTemperatureThreshold.509	.1.3.6.1.4.1.26138.2.6.1.1.1.1.22.509	Integer	65535
ibEntityExtShutdownTemperatureThreshold.510	.1.3.6.1.4.1.26138.2.6.1.1.1.1.22.510	Integer	65535
ibEntityExtShutdownTemperatureThreshold.511	.1.3.6.1.4.1.26138.2.6.1.1.1.1.22.511	Integer	65535
ibEntityExtShutdownTemperatureThreshold.512	.1.3.6.1.4.1.26138.2.6.1.1.1.1.22.512	Integer	65535
ibEntityExtShutdownTemperatureThreshold.513	.1.3.6.1.4.1.26138.2.6.1.1.1.1.22.513	Integer	65535
ibEntityExtShutdownTemperatureThreshold.514	.1.3.6.1.4.1.26138.2.6.1.1.1.1.22.514	Integer	65535
ibEntityExtShutdownTemperatureThreshold.515	.1.3.6.1.4.1.26138.2.6.1.1.1.1.22.515	Integer	65535
ibEntityExtShutdownTemperatureThreshold.516	.1.3.6.1.4.1.26138.2.6.1.1.1.1.22.516	Integer	65535
ibEntityExtShutdownTemperatureThreshold.517	.1.3.6.1.4.1.26138.2.6.1.1.1.1.22.517	Integer	65535
ibEntityExtShutdownTemperatureThreshold.518	.1.3.6.1.4.1.26138.2.6.1.1.1.1.22.518	Integer	65535
ibEntityExtShutdownTemperatureThreshold.519	.1.3.6.1.4.1.26138.2.6.1.1.1.1.22.519	Integer	65535
ibEntityExtShutdownTemperatureThreshold.520	.1.3.6.1.4.1.26138.2.6.1.1.1.1.22.520	Integer	65535
ibEntityExtShutdownTemperatureThreshold.521	.1.3.6.1.4.1.26138.2.6.1.1.1.1.22.521	Integer	65535
ibEntityExtShutdownTemperatureThreshold.522	.1.3.6.1.4.1.26138.2.6.1.1.1.1.22.522	Integer	65535
ibEntityExtShutdownTemperatureThreshold.523	.1.3.6.1.4.1.26138.2.6.1.1.1.1.22.523	Integer	65535
ibEntityExtShutdownTemperatureThreshold.524	.1.3.6.1.4.1.26138.2.6.1.1.1.1.22.524	Integer	65535
ibEntityExtShutdownTemperatureThreshold.525	.1.3.6.1.4.1.26138.2.6.1.1.1.1.22.525	Integer	65535
ibEntityExtPhyMemSize.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.1	Gauge	0
ibEntityExtPhyMemSize.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.2	Gauge	0
ibEntityExtPhyMemSize.12	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.12	Gauge	0
ibEntityExtPhyMemSize.13	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.13	Gauge	0
ibEntityExtPhyMemSize.14	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.14	Gauge	0
ibEntityExtPhyMemSize.15	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.15	Gauge	0
ibEntityExtPhyMemSize.16	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.16	Gauge	0
ibEntityExtPhyMemSize.17	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.17	Gauge	0
ibEntityExtPhyMemSize.18	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.18	Gauge	0

Name	OID	Value Type	Value Example
ibEntityExtPhyMemSize.19	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.19	Gauge	0
ibEntityExtPhyMemSize.20	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.20	Gauge	0
ibEntityExtPhyMemSize.21	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.21	Gauge	0
ibEntityExtPhyMemSize.22	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.22	Gauge	0
ibEntityExtPhyMemSize.23	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.23	Gauge	0
ibEntityExtPhyMemSize.24	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.24	Gauge	0
ibEntityExtPhyMemSize.25	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.25	Gauge	0
ibEntityExtPhyMemSize.26	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.26	Gauge	0
ibEntityExtPhyMemSize.27	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.27	Gauge	0
ibEntityExtPhyMemSize.28	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.28	Gauge	0
ibEntityExtPhyMemSize.29	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.29	Gauge	0
ibEntityExtPhyMemSize.30	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.30	Gauge	0
ibEntityExtPhyMemSize.31	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.31	Gauge	0
ibEntityExtPhyMemSize.212	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.212	Gauge	1024
ibEntityExtPhyMemSize.213	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.213	Gauge	0
ibEntityExtPhyMemSize.216	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.216	Gauge	0
ibEntityExtPhyMemSize.220	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.220	Gauge	0
ibEntityExtPhyMemSize.221	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.221	Gauge	0
ibEntityExtPhyMemSize.412	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.412	Gauge	0
ibEntityExtPhyMemSize.413	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.413	Gauge	0
ibEntityExtPhyMemSize.414	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.414	Gauge	0
ibEntityExtPhyMemSize.442	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.442	Gauge	0
ibEntityExtPhyMemSize.472	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.472	Gauge	0
ibEntityExtPhyMemSize.473	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.473	Gauge	0
ibEntityExtPhyMemSize.474	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.474	Gauge	0
ibEntityExtPhyMemSize.475	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.475	Gauge	0
ibEntityExtPhyMemSize.476	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.476	Gauge	0
ibEntityExtPhyMemSize.477	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.477	Gauge	0
ibEntityExtPhyMemSize.478	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.478	Gauge	0
ibEntityExtPhyMemSize.479	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.479	Gauge	0
ibEntityExtPhyMemSize.480	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.480	Gauge	0
ibEntityExtPhyMemSize.481	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.481	Gauge	0
ibEntityExtPhyMemSize.482	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.482	Gauge	0
ibEntityExtPhyMemSize.483	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.483	Gauge	0
ibEntityExtPhyMemSize.484	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.484	Gauge	0
ibEntityExtPhyMemSize.485	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.485	Gauge	0
ibEntityExtPhyMemSize.486	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.486	Gauge	0
ibEntityExtPhyMemSize.487	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.487	Gauge	0
ibEntityExtPhyMemSize.488	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.488	Gauge	0
ibEntityExtPhyMemSize.489	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.489	Gauge	0
ibEntityExtPhyMemSize.490	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.490	Gauge	0
ibEntityExtPhyMemSize.491	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.491	Gauge	0
ibEntityExtPhyMemSize.492	1.3.6.1.4.1.26138.2.6.1.1.1.1.23.492	Gauge	0

Name	OID	Value Type	Value Example
ibEntityExtPhyMemSize.493	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.493	Gauge	0
ibEntityExtPhyMemSize.494	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.494	Gauge	0
ibEntityExtPhyMemSize.495	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.495	Gauge	0
ibEntityExtPhyMemSize.496	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.496	Gauge	0
ibEntityExtPhyMemSize.497	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.497	Gauge	0
ibEntityExtPhyMemSize.498	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.498	Gauge	0
ibEntityExtPhyMemSize.499	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.499	Gauge	0
ibEntityExtPhyMemSize.500	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.500	Gauge	0
ibEntityExtPhyMemSize.501	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.501	Gauge	0
ibEntityExtPhyMemSize.502	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.502	Gauge	0
ibEntityExtPhyMemSize.503	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.503	Gauge	0
ibEntityExtPhyMemSize.504	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.504	Gauge	0
ibEntityExtPhyMemSize.505	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.505	Gauge	0
ibEntityExtPhyMemSize.506	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.506	Gauge	0
ibEntityExtPhyMemSize.507	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.507	Gauge	0
ibEntityExtPhyMemSize.508	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.508	Gauge	0
ibEntityExtPhyMemSize.509	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.509	Gauge	0
ibEntityExtPhyMemSize.510	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.510	Gauge	0
ibEntityExtPhyMemSize.511	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.511	Gauge	0
ibEntityExtPhyMemSize.512	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.512	Gauge	0
ibEntityExtPhyMemSize.513	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.513	Gauge	0
ibEntityExtPhyMemSize.514	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.514	Gauge	0
ibEntityExtPhyMemSize.515	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.515	Gauge	0
ibEntityExtPhyMemSize.516	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.516	Gauge	0
ibEntityExtPhyMemSize.517	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.517	Gauge	0
ibEntityExtPhyMemSize.518	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.518	Gauge	0
ibEntityExtPhyMemSize.519	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.519	Gauge	0
ibEntityExtPhyMemSize.520	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.520	Gauge	0
ibEntityExtPhyMemSize.521	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.521	Gauge	0
ibEntityExtPhyMemSize.522	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.522	Gauge	0
ibEntityExtPhyMemSize.523	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.523	Gauge	0
ibEntityExtPhyMemSize.524	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.524	Gauge	0
ibEntityExtPhyMemSize.525	.1.3.6.1.4.1.26138.2.6.1.1.1.1.23.525	Gauge	0
ibEntityExtPhyCpuFrequency.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.1	Integer	0
ibEntityExtPhyCpuFrequency.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.2	Integer	0
ibEntityExtPhyCpuFrequency.12	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.12	Integer	0
ibEntityExtPhyCpuFrequency.13	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.13	Integer	0
ibEntityExtPhyCpuFrequency.14	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.14	Integer	0
ibEntityExtPhyCpuFrequency.15	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.15	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtPhyCpuFrequency.16	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.16	Integer	0
ibEntityExtPhyCpuFrequency.17	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.17	Integer	0
ibEntityExtPhyCpuFrequency.18	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.18	Integer	0
ibEntityExtPhyCpuFrequency.19	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.19	Integer	0
ibEntityExtPhyCpuFrequency.20	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.20	Integer	0
ibEntityExtPhyCpuFrequency.21	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.21	Integer	0
ibEntityExtPhyCpuFrequency.22	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.22	Integer	0
ibEntityExtPhyCpuFrequency.23	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.23	Integer	0
ibEntityExtPhyCpuFrequency.24	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.24	Integer	0
ibEntityExtPhyCpuFrequency.25	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.25	Integer	0
ibEntityExtPhyCpuFrequency.26	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.26	Integer	0
ibEntityExtPhyCpuFrequency.27	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.27	Integer	0
ibEntityExtPhyCpuFrequency.28	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.28	Integer	0
ibEntityExtPhyCpuFrequency.29	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.29	Integer	0
ibEntityExtPhyCpuFrequency.30	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.30	Integer	0
ibEntityExtPhyCpuFrequency.31	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.31	Integer	0
ibEntityExtPhyCpuFrequency.212	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.212	Integer	0
ibEntityExtPhyCpuFrequency.213	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.213	Integer	0
ibEntityExtPhyCpuFrequency.216	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.216	Integer	0
ibEntityExtPhyCpuFrequency.220	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.220	Integer	0
ibEntityExtPhyCpuFrequency.221	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.221	Integer	0
ibEntityExtPhyCpuFrequency.412	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.412	Integer	0
ibEntityExtPhyCpuFrequency.413	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.413	Integer	0
ibEntityExtPhyCpuFrequency.414	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.414	Integer	0
ibEntityExtPhyCpuFrequency.442	1.3.6.1.4.1.26138.2.6.1.1.1.1.24.442	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtPhyCpuFrequency.472	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.472	Integer	0
ibEntityExtPhyCpuFrequency.473	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.473	Integer	0
ibEntityExtPhyCpuFrequency.474	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.474	Integer	0
ibEntityExtPhyCpuFrequency.475	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.475	Integer	0
ibEntityExtPhyCpuFrequency.476	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.476	Integer	0
ibEntityExtPhyCpuFrequency.477	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.477	Integer	0
ibEntityExtPhyCpuFrequency.478	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.478	Integer	0
ibEntityExtPhyCpuFrequency.479	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.479	Integer	0
ibEntityExtPhyCpuFrequency.480	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.480	Integer	0
ibEntityExtPhyCpuFrequency.481	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.481	Integer	0
ibEntityExtPhyCpuFrequency.482	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.482	Integer	0
ibEntityExtPhyCpuFrequency.483	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.483	Integer	0
ibEntityExtPhyCpuFrequency.484	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.484	Integer	0
ibEntityExtPhyCpuFrequency.485	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.485	Integer	0
ibEntityExtPhyCpuFrequency.486	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.486	Integer	0
ibEntityExtPhyCpuFrequency.487	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.487	Integer	0
ibEntityExtPhyCpuFrequency.488	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.488	Integer	0
ibEntityExtPhyCpuFrequency.489	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.489	Integer	0
ibEntityExtPhyCpuFrequency.490	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.490	Integer	0
ibEntityExtPhyCpuFrequency.491	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.491	Integer	0
ibEntityExtPhyCpuFrequency.492	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.492	Integer	0
ibEntityExtPhyCpuFrequency.493	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.493	Integer	0
ibEntityExtPhyCpuFrequency.494	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.494	Integer	0
ibEntityExtPhyCpuFrequency.495	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.495	Integer	0
ibEntityExtPhyCpuFrequency.496	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.496	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtPhyCpuFrequency.497	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.497	Integer	0
ibEntityExtPhyCpuFrequency.498	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.498	Integer	0
ibEntityExtPhyCpuFrequency.499	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.499	Integer	0
ibEntityExtPhyCpuFrequency.500	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.500	Integer	0
ibEntityExtPhyCpuFrequency.501	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.501	Integer	0
ibEntityExtPhyCpuFrequency.502	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.502	Integer	0
ibEntityExtPhyCpuFrequency.503	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.503	Integer	0
ibEntityExtPhyCpuFrequency.504	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.504	Integer	0
ibEntityExtPhyCpuFrequency.505	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.505	Integer	0
ibEntityExtPhyCpuFrequency.506	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.506	Integer	0
ibEntityExtPhyCpuFrequency.507	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.507	Integer	0
ibEntityExtPhyCpuFrequency.508	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.508	Integer	0
ibEntityExtPhyCpuFrequency.509	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.509	Integer	0
ibEntityExtPhyCpuFrequency.510	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.510	Integer	0
ibEntityExtPhyCpuFrequency.511	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.511	Integer	0
ibEntityExtPhyCpuFrequency.512	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.512	Integer	0
ibEntityExtPhyCpuFrequency.513	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.513	Integer	0
ibEntityExtPhyCpuFrequency.514	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.514	Integer	0
ibEntityExtPhyCpuFrequency.515	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.515	Integer	0
ibEntityExtPhyCpuFrequency.516	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.516	Integer	0
ibEntityExtPhyCpuFrequency.517	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.517	Integer	0
ibEntityExtPhyCpuFrequency.518	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.518	Integer	0
ibEntityExtPhyCpuFrequency.519	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.519	Integer	0
ibEntityExtPhyCpuFrequency.520	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.520	Integer	0
ibEntityExtPhyCpuFrequency.521	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.521	Integer	0



Name	OID	Value Type	Value Example
ibEntityExtPhyCpuFrequency.522	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.522	Integer	0
ibEntityExtPhyCpuFrequency.523	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.523	Integer	0
ibEntityExtPhyCpuFrequency.524	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.524	Integer	0
ibEntityExtPhyCpuFrequency.525	.1.3.6.1.4.1.26138.2.6.1.1.1.1.24.525	Integer	0
ibEntityExtFirstUsedDate.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.25.1	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.25.2	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.12	1.3.6.1.4.1.26138.2.6.1.1.1.1.25.12	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.13	1.3.6.1.4.1.26138.2.6.1.1.1.1.25.13	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.14	1.3.6.1.4.1.26138.2.6.1.1.1.1.25.14	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.15	1.3.6.1.4.1.26138.2.6.1.1.1.1.25.15	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.16	1.3.6.1.4.1.26138.2.6.1.1.1.1.25.16	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.17	1.3.6.1.4.1.26138.2.6.1.1.1.1.25.17	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.18	1.3.6.1.4.1.26138.2.6.1.1.1.1.25.18	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.19	1.3.6.1.4.1.26138.2.6.1.1.1.1.25.19	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.20	1.3.6.1.4.1.26138.2.6.1.1.1.1.25.20	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.21	1.3.6.1.4.1.26138.2.6.1.1.1.1.25.21	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.22	1.3.6.1.4.1.26138.2.6.1.1.1.1.25.22	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.23	1.3.6.1.4.1.26138.2.6.1.1.1.1.25.23	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.24	1.3.6.1.4.1.26138.2.6.1.1.1.1.25.24	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.25	1.3.6.1.4.1.26138.2.6.1.1.1.1.25.25	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.26	1.3.6.1.4.1.26138.2.6.1.1.1.1.25.26	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.27	1.3.6.1.4.1.26138.2.6.1.1.1.1.25.27	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.28	1.3.6.1.4.1.26138.2.6.1.1.1.1.25.28	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.29	1.3.6.1.4.1.26138.2.6.1.1.1.1.25.29	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.30	1.3.6.1.4.1.26138.2.6.1.1.1.1.25.30	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.31	1.3.6.1.4.1.26138.2.6.1.1.1.1.25.31	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.212	.1.3.6.1.4.1.26138.2.6.1.1.1.1.25.212	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.213	.1.3.6.1.4.1.26138.2.6.1.1.1.1.25.213	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.216	.1.3.6.1.4.1.26138.2.6.1.1.1.1.25.216	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.220	.1.3.6.1.4.1.26138.2.6.1.1.1.1.25.220	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.221	.1.3.6.1.4.1.26138.2.6.1.1.1.1.25.221	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.412	.1.3.6.1.4.1.26138.2.6.1.1.1.1.25.412	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.413	.1.3.6.1.4.1.26138.2.6.1.1.1.1.25.413	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.414	.1.3.6.1.4.1.26138.2.6.1.1.1.1.25.414	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.442	.1.3.6.1.4.1.26138.2.6.1.1.1.1.25.442	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.472	.1.3.6.1.4.1.26138.2.6.1.1.1.1.25.472	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.473	.1.3.6.1.4.1.26138.2.6.1.1.1.1.25.473	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.474	.1.3.6.1.4.1.26138.2.6.1.1.1.1.25.474	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.475	.1.3.6.1.4.1.26138.2.6.1.1.1.1.25.475	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.476	.1.3.6.1.4.1.26138.2.6.1.1.1.1.25.476	OctetString	0-0-0,0:0:0.0



Name	OID	Value Type	Value Example
ibEntityExtFirstUsedDate.520	.1.3.6.1.4.1.26138.2.6.1.1.1.1.25.520	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.521	.1.3.6.1.4.1.26138.2.6.1.1.1.1.25.521	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.522	.1.3.6.1.4.1.26138.2.6.1.1.1.1.25.522	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.523	.1.3.6.1.4.1.26138.2.6.1.1.1.1.25.523	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.524	.1.3.6.1.4.1.26138.2.6.1.1.1.1.25.524	OctetString	0-0-0,0:0:0.0
ibEntityExtFirstUsedDate.525	.1.3.6.1.4.1.26138.2.6.1.1.1.1.25.525	OctetString	0-0-0,0:0:0.0
ibEntityExtCpuAvgUsage.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.26.1	Integer	0
ibEntityExtCpuAvgUsage.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.26.2	Integer	0
ibEntityExtCpuAvgUsage.12	1.3.6.1.4.1.26138.2.6.1.1.1.1.26.12	Integer	0
ibEntityExtCpuAvgUsage.13	1.3.6.1.4.1.26138.2.6.1.1.1.1.26.13	Integer	0
ibEntityExtCpuAvgUsage.14	1.3.6.1.4.1.26138.2.6.1.1.1.1.26.14	Integer	0
ibEntityExtCpuAvgUsage.15	1.3.6.1.4.1.26138.2.6.1.1.1.1.26.15	Integer	0
ibEntityExtCpuAvgUsage.16	1.3.6.1.4.1.26138.2.6.1.1.1.1.26.16	Integer	0
ibEntityExtCpuAvgUsage.17	1.3.6.1.4.1.26138.2.6.1.1.1.1.26.17	Integer	0
ibEntityExtCpuAvgUsage.18	1.3.6.1.4.1.26138.2.6.1.1.1.1.26.18	Integer	0
ibEntityExtCpuAvgUsage.19	1.3.6.1.4.1.26138.2.6.1.1.1.1.26.19	Integer	0
ibEntityExtCpuAvgUsage.20	1.3.6.1.4.1.26138.2.6.1.1.1.1.26.20	Integer	0
ibEntityExtCpuAvgUsage.21	1.3.6.1.4.1.26138.2.6.1.1.1.1.26.21	Integer	0
ibEntityExtCpuAvgUsage.22	1.3.6.1.4.1.26138.2.6.1.1.1.1.26.22	Integer	0
ibEntityExtCpuAvgUsage.23	1.3.6.1.4.1.26138.2.6.1.1.1.1.26.23	Integer	0
ibEntityExtCpuAvgUsage.24	1.3.6.1.4.1.26138.2.6.1.1.1.1.26.24	Integer	0
ibEntityExtCpuAvgUsage.25	1.3.6.1.4.1.26138.2.6.1.1.1.1.26.25	Integer	0
ibEntityExtCpuAvgUsage.26	1.3.6.1.4.1.26138.2.6.1.1.1.1.26.26	Integer	0
ibEntityExtCpuAvgUsage.27	1.3.6.1.4.1.26138.2.6.1.1.1.1.26.27	Integer	0
ibEntityExtCpuAvgUsage.28	1.3.6.1.4.1.26138.2.6.1.1.1.1.26.28	Integer	0
ibEntityExtCpuAvgUsage.29	1.3.6.1.4.1.26138.2.6.1.1.1.1.26.29	Integer	0
ibEntityExtCpuAvgUsage.30	1.3.6.1.4.1.26138.2.6.1.1.1.1.26.30	Integer	0
ibEntityExtCpuAvgUsage.31	1.3.6.1.4.1.26138.2.6.1.1.1.1.26.31	Integer	0
ibEntityExtCpuAvgUsage.212	.1.3.6.1.4.1.26138.2.6.1.1.1.1.26.212	Integer	10
ibEntityExtCpuAvgUsage.213	.1.3.6.1.4.1.26138.2.6.1.1.1.1.26.213	Integer	0
ibEntityExtCpuAvgUsage.216	.1.3.6.1.4.1.26138.2.6.1.1.1.1.26.216	Integer	0
ibEntityExtCpuAvgUsage.220	.1.3.6.1.4.1.26138.2.6.1.1.1.1.26.220	Integer	0
ibEntityExtCpuAvgUsage.221	.1.3.6.1.4.1.26138.2.6.1.1.1.1.26.221	Integer	0
ibEntityExtCpuAvgUsage.412	.1.3.6.1.4.1.26138.2.6.1.1.1.1.26.412	Integer	0
ibEntityExtCpuAvgUsage.413	.1.3.6.1.4.1.26138.2.6.1.1.1.1.26.413	Integer	0
ibEntityExtCpuAvgUsage.414	.1.3.6.1.4.1.26138.2.6.1.1.1.1.26.414	Integer	0
ibEntityExtCpuAvgUsage.442	.1.3.6.1.4.1.26138.2.6.1.1.1.1.26.442	Integer	0
ibEntityExtCpuAvgUsage.472	.1.3.6.1.4.1.26138.2.6.1.1.1.1.26.472	Integer	0
ibEntityExtCpuAvgUsage.473	.1.3.6.1.4.1.26138.2.6.1.1.1.1.26.473	Integer	0
ibEntityExtCpuAvgUsage.474	.1.3.6.1.4.1.26138.2.6.1.1.1.1.26.474	Integer	0
ibEntityExtCpuAvgUsage.475	.1.3.6.1.4.1.26138.2.6.1.1.1.1.26.475	Integer	0
ibEntityExtCpuAvgUsage.476	.1.3.6.1.4.1.26138.2.6.1.1.1.1.26.476	Integer	0
ibEntityExtCpuAvgUsage.477	.1.3.6.1.4.1.26138.2.6.1.1.1.1.26.477	Integer	0



Name	OID	Value Type	Value Example
ibEntityExtCpuAvgUsage.521	.1.3.6.1.4.1.26138.2.6.1.1.1.1.26.521	Integer	0
ibEntityExtCpuAvgUsage.522	.1.3.6.1.4.1.26138.2.6.1.1.1.1.26.522	Integer	0
ibEntityExtCpuAvgUsage.523	.1.3.6.1.4.1.26138.2.6.1.1.1.1.26.523	Integer	0
ibEntityExtCpuAvgUsage.524	.1.3.6.1.4.1.26138.2.6.1.1.1.1.26.524	Integer	0
ibEntityExtCpuAvgUsage.525	.1.3.6.1.4.1.26138.2.6.1.1.1.1.26.525	Integer	0
ibEntityExtMemAvgUsage.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.27.1	Integer	0
ibEntityExtMemAvgUsage.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.27.2	Integer	0
ibEntityExtMemAvgUsage.12	1.3.6.1.4.1.26138.2.6.1.1.1.1.27.12	Integer	0
ibEntityExtMemAvgUsage.13	1.3.6.1.4.1.26138.2.6.1.1.1.1.27.13	Integer	0
ibEntityExtMemAvgUsage.14	1.3.6.1.4.1.26138.2.6.1.1.1.1.27.14	Integer	0
ibEntityExtMemAvgUsage.15	1.3.6.1.4.1.26138.2.6.1.1.1.1.27.15	Integer	0
ibEntityExtMemAvgUsage.16	1.3.6.1.4.1.26138.2.6.1.1.1.1.27.16	Integer	0
ibEntityExtMemAvgUsage.17	1.3.6.1.4.1.26138.2.6.1.1.1.1.27.17	Integer	0
ibEntityExtMemAvgUsage.18	1.3.6.1.4.1.26138.2.6.1.1.1.1.27.18	Integer	0
ibEntityExtMemAvgUsage.19	1.3.6.1.4.1.26138.2.6.1.1.1.1.27.19	Integer	0
ibEntityExtMemAvgUsage.20	1.3.6.1.4.1.26138.2.6.1.1.1.1.27.20	Integer	0
ibEntityExtMemAvgUsage.21	1.3.6.1.4.1.26138.2.6.1.1.1.1.27.21	Integer	0
ibEntityExtMemAvgUsage.22	1.3.6.1.4.1.26138.2.6.1.1.1.1.27.22	Integer	0
ibEntityExtMemAvgUsage.23	1.3.6.1.4.1.26138.2.6.1.1.1.1.27.23	Integer	0
ibEntityExtMemAvgUsage.24	1.3.6.1.4.1.26138.2.6.1.1.1.1.27.24	Integer	0
ibEntityExtMemAvgUsage.25	1.3.6.1.4.1.26138.2.6.1.1.1.1.27.25	Integer	0
ibEntityExtMemAvgUsage.26	1.3.6.1.4.1.26138.2.6.1.1.1.1.27.26	Integer	0
ibEntityExtMemAvgUsage.27	1.3.6.1.4.1.26138.2.6.1.1.1.1.27.27	Integer	0
ibEntityExtMemAvgUsage.28	1.3.6.1.4.1.26138.2.6.1.1.1.1.27.28	Integer	0
ibEntityExtMemAvgUsage.29	1.3.6.1.4.1.26138.2.6.1.1.1.1.27.29	Integer	0
ibEntityExtMemAvgUsage.30	1.3.6.1.4.1.26138.2.6.1.1.1.1.27.30	Integer	0
ibEntityExtMemAvgUsage.31	1.3.6.1.4.1.26138.2.6.1.1.1.1.27.31	Integer	0
ibEntityExtMemAvgUsage.212	.1.3.6.1.4.1.26138.2.6.1.1.1.1.27.212	Integer	42
ibEntityExtMemAvgUsage.213	.1.3.6.1.4.1.26138.2.6.1.1.1.1.27.213	Integer	0
ibEntityExtMemAvgUsage.216	.1.3.6.1.4.1.26138.2.6.1.1.1.1.27.216	Integer	0
ibEntityExtMemAvgUsage.220	.1.3.6.1.4.1.26138.2.6.1.1.1.1.27.220	Integer	0
ibEntityExtMemAvgUsage.221	.1.3.6.1.4.1.26138.2.6.1.1.1.1.27.221	Integer	0
ibEntityExtMemAvgUsage.412	.1.3.6.1.4.1.26138.2.6.1.1.1.1.27.412	Integer	0
ibEntityExtMemAvgUsage.413	.1.3.6.1.4.1.26138.2.6.1.1.1.1.27.413	Integer	0
ibEntityExtMemAvgUsage.414	.1.3.6.1.4.1.26138.2.6.1.1.1.1.27.414	Integer	0
ibEntityExtMemAvgUsage.442	.1.3.6.1.4.1.26138.2.6.1.1.1.1.27.442	Integer	0
ibEntityExtMemAvgUsage.472	.1.3.6.1.4.1.26138.2.6.1.1.1.1.27.472	Integer	0
ibEntityExtMemAvgUsage.473	.1.3.6.1.4.1.26138.2.6.1.1.1.1.27.473	Integer	0
ibEntityExtMemAvgUsage.474	.1.3.6.1.4.1.26138.2.6.1.1.1.1.27.474	Integer	0
ibEntityExtMemAvgUsage.475	.1.3.6.1.4.1.26138.2.6.1.1.1.1.27.475	Integer	0
ibEntityExtMemAvgUsage.476	.1.3.6.1.4.1.26138.2.6.1.1.1.1.27.476	Integer	0
ibEntityExtMemAvgUsage.477	.1.3.6.1.4.1.26138.2.6.1.1.1.1.27.477	Integer	0
ibEntityExtMemAvgUsage.478	.1.3.6.1.4.1.26138.2.6.1.1.1.1.27.478	Integer	0





Name	OID	Value Type	Value Example
ibEntityExtMemAvgUsage.522	.1.3.6.1.4.1.26138.2.6.1.1.1.1.27.522	Integer	0
ibEntityExtMemAvgUsage.523	.1.3.6.1.4.1.26138.2.6.1.1.1.1.27.523	Integer	0
ibEntityExtMemAvgUsage.524	.1.3.6.1.4.1.26138.2.6.1.1.1.1.27.524	Integer	0
ibEntityExtMemAvgUsage.525	.1.3.6.1.4.1.26138.2.6.1.1.1.1.27.525	Integer	0
ibEntityExtMemType.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.1	OctetString	
ibEntityExtMemType.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.2	OctetString	
ibEntityExtMemType.12	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.12	OctetString	
ibEntityExtMemType.13	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.13	OctetString	
ibEntityExtMemType.14	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.14	OctetString	
ibEntityExtMemType.15	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.15	OctetString	
ibEntityExtMemType.16	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.16	OctetString	
ibEntityExtMemType.17	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.17	OctetString	
ibEntityExtMemType.18	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.18	OctetString	
ibEntityExtMemType.19	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.19	OctetString	
ibEntityExtMemType.20	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.20	OctetString	
ibEntityExtMemType.21	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.21	OctetString	
ibEntityExtMemType.22	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.22	OctetString	
ibEntityExtMemType.23	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.23	OctetString	
ibEntityExtMemType.24	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.24	OctetString	
ibEntityExtMemType.25	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.25	OctetString	
ibEntityExtMemType.26	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.26	OctetString	
ibEntityExtMemType.27	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.27	OctetString	
ibEntityExtMemType.28	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.28	OctetString	
ibEntityExtMemType.29	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.29	OctetString	
ibEntityExtMemType.30	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.30	OctetString	
ibEntityExtMemType.31	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.31	OctetString	
ibEntityExtMemType.212	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.212	OctetString	
ibEntityExtMemType.213	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.213	OctetString	
ibEntityExtMemType.216	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.216	OctetString	
ibEntityExtMemType.220	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.220	OctetString	
ibEntityExtMemType.221	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.221	OctetString	
ibEntityExtMemType.412	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.412	OctetString	
ibEntityExtMemType.413	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.413	OctetString	
ibEntityExtMemType.414	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.414	OctetString	
ibEntityExtMemType.442	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.442	OctetString	
ibEntityExtMemType.472	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.472	OctetString	
ibEntityExtMemType.473	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.473	OctetString	
ibEntityExtMemType.474	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.474	OctetString	
ibEntityExtMemType.475	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.475	OctetString	
ibEntityExtMemType.476	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.476	OctetString	
ibEntityExtMemType.477	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.477	OctetString	
ibEntityExtMemType.478	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.478	OctetString	
ibEntityExtMemType.479	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.479	OctetString	

Name	OID	Value Type	Value Example
ibEntityExtMemType.480	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.480	OctetString	
ibEntityExtMemType.481	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.481	OctetString	
ibEntityExtMemType.482	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.482	OctetString	
ibEntityExtMemType.483	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.483	OctetString	
ibEntityExtMemType.484	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.484	OctetString	
ibEntityExtMemType.485	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.485	OctetString	
ibEntityExtMemType.486	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.486	OctetString	
ibEntityExtMemType.487	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.487	OctetString	
ibEntityExtMemType.488	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.488	OctetString	
ibEntityExtMemType.489	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.489	OctetString	
ibEntityExtMemType.490	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.490	OctetString	
ibEntityExtMemType.491	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.491	OctetString	
ibEntityExtMemType.492	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.492	OctetString	
ibEntityExtMemType.493	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.493	OctetString	
ibEntityExtMemType.494	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.494	OctetString	
ibEntityExtMemType.495	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.495	OctetString	
ibEntityExtMemType.496	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.496	OctetString	
ibEntityExtMemType.497	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.497	OctetString	
ibEntityExtMemType.498	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.498	OctetString	
ibEntityExtMemType.499	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.499	OctetString	
ibEntityExtMemType.500	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.500	OctetString	
ibEntityExtMemType.501	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.501	OctetString	
ibEntityExtMemType.502	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.502	OctetString	
ibEntityExtMemType.503	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.503	OctetString	
ibEntityExtMemType.504	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.504	OctetString	
ibEntityExtMemType.505	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.505	OctetString	
ibEntityExtMemType.506	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.506	OctetString	
ibEntityExtMemType.507	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.507	OctetString	
ibEntityExtMemType.508	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.508	OctetString	
ibEntityExtMemType.509	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.509	OctetString	
ibEntityExtMemType.510	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.510	OctetString	
ibEntityExtMemType.511	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.511	OctetString	
ibEntityExtMemType.512	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.512	OctetString	
ibEntityExtMemType.513	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.513	OctetString	
ibEntityExtMemType.514	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.514	OctetString	
ibEntityExtMemType.515	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.515	OctetString	
ibEntityExtMemType.516	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.516	OctetString	
ibEntityExtMemType.517	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.517	OctetString	
ibEntityExtMemType.518	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.518	OctetString	
ibEntityExtMemType.519	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.519	OctetString	
ibEntityExtMemType.520	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.520	OctetString	
ibEntityExtMemType.521	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.521	OctetString	
ibEntityExtMemType.522	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.522	OctetString	



Name	OID	Value Type	Value Example
ibEntityExtMemType.523	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.523	OctetString	
ibEntityExtMemType.524	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.524	OctetString	
ibEntityExtMemType.525	.1.3.6.1.4.1.26138.2.6.1.1.1.1.28.525	OctetString	
ibEntityExtCpuUsageIn1Minute.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.1	Integer	0
ibEntityExtCpuUsageIn1Minute.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.2	Integer	0
ibEntityExtCpuUsageIn1Minute.12	1.3.6.1.4.1.26138.2.6.1.1.1.1.33.12	Integer	0
ibEntityExtCpuUsageIn1Minute.13	1.3.6.1.4.1.26138.2.6.1.1.1.1.33.13	Integer	0
ibEntityExtCpuUsageIn1Minute.14	1.3.6.1.4.1.26138.2.6.1.1.1.1.33.14	Integer	0
ibEntityExtCpuUsageIn1Minute.15	1.3.6.1.4.1.26138.2.6.1.1.1.1.33.15	Integer	0
ibEntityExtCpuUsageIn1Minute.16	1.3.6.1.4.1.26138.2.6.1.1.1.1.33.16	Integer	0
ibEntityExtCpuUsageIn1Minute.17	1.3.6.1.4.1.26138.2.6.1.1.1.1.33.17	Integer	0
ibEntityExtCpuUsageIn1Minute.18	1.3.6.1.4.1.26138.2.6.1.1.1.1.33.18	Integer	0
ibEntityExtCpuUsageIn1Minute.19	1.3.6.1.4.1.26138.2.6.1.1.1.1.33.19	Integer	0
ibEntityExtCpuUsageIn1Minute.20	1.3.6.1.4.1.26138.2.6.1.1.1.1.33.20	Integer	0
ibEntityExtCpuUsageIn1Minute.21	1.3.6.1.4.1.26138.2.6.1.1.1.1.33.21	Integer	0
ibEntityExtCpuUsageIn1Minute.22	1.3.6.1.4.1.26138.2.6.1.1.1.1.33.22	Integer	0
ibEntityExtCpuUsageIn1Minute.23	1.3.6.1.4.1.26138.2.6.1.1.1.1.33.23	Integer	0
ibEntityExtCpuUsageIn1Minute.24	1.3.6.1.4.1.26138.2.6.1.1.1.1.33.24	Integer	0
ibEntityExtCpuUsageIn1Minute.25	1.3.6.1.4.1.26138.2.6.1.1.1.1.33.25	Integer	0
ibEntityExtCpuUsageIn1Minute.26	1.3.6.1.4.1.26138.2.6.1.1.1.1.33.26	Integer	0
ibEntityExtCpuUsageIn1Minute.27	1.3.6.1.4.1.26138.2.6.1.1.1.1.33.27	Integer	0
ibEntityExtCpuUsageIn1Minute.28	1.3.6.1.4.1.26138.2.6.1.1.1.1.33.28	Integer	0
ibEntityExtCpuUsageIn1Minute.29	1.3.6.1.4.1.26138.2.6.1.1.1.1.33.29	Integer	0
ibEntityExtCpuUsageIn1Minute.30	1.3.6.1.4.1.26138.2.6.1.1.1.1.33.30	Integer	0
ibEntityExtCpuUsageIn1Minute.31	1.3.6.1.4.1.26138.2.6.1.1.1.1.33.31	Integer	0
ibEntityExtCpuUsageIn1Minute.212	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.212	Integer	15

Name	OID	Value Type	Value Example
ibEntityExtCpuUsageIn1Minute.213	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.213	Integer	0
ibEntityExtCpuUsageIn1Minute.216	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.216	Integer	0
ibEntityExtCpuUsageIn1Minute.220	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.220	Integer	0
ibEntityExtCpuUsageIn1Minute.221	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.221	Integer	0
ibEntityExtCpuUsageIn1Minute.412	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.412	Integer	0
ibEntityExtCpuUsageIn1Minute.413	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.413	Integer	0
ibEntityExtCpuUsageIn1Minute.414	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.414	Integer	0
ibEntityExtCpuUsageIn1Minute.442	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.442	Integer	0
ibEntityExtCpuUsageIn1Minute.472	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.472	Integer	0
ibEntityExtCpuUsageIn1Minute.473	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.473	Integer	0
ibEntityExtCpuUsageIn1Minute.474	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.474	Integer	0
ibEntityExtCpuUsageIn1Minute.475	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.475	Integer	0
ibEntityExtCpuUsageIn1Minute.476	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.476	Integer	0
ibEntityExtCpuUsageIn1Minute.477	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.477	Integer	0
ibEntityExtCpuUsageIn1Minute.478	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.478	Integer	0
ibEntityExtCpuUsageIn1Minute.479	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.479	Integer	0
ibEntityExtCpuUsageIn1Minute.480	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.480	Integer	0
ibEntityExtCpuUsageIn1Minute.481	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.481	Integer	0
ibEntityExtCpuUsageIn1Minute.482	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.482	Integer	0
ibEntityExtCpuUsageIn1Minute.483	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.483	Integer	0
ibEntityExtCpuUsageIn1Minute.484	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.484	Integer	0
ibEntityExtCpuUsageIn1Minute.485	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.485	Integer	0
ibEntityExtCpuUsageIn1Minute.486	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.486	Integer	0
ibEntityExtCpuUsageIn1Minute.487	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.487	Integer	0
ibEntityExtCpuUsageIn1Minute.488	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.488	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtCpuUsageIn1Minute.489	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.489	Integer	0
ibEntityExtCpuUsageIn1Minute.490	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.490	Integer	0
ibEntityExtCpuUsageIn1Minute.491	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.491	Integer	0
ibEntityExtCpuUsageIn1Minute.492	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.492	Integer	0
ibEntityExtCpuUsageIn1Minute.493	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.493	Integer	0
ibEntityExtCpuUsageIn1Minute.494	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.494	Integer	0
ibEntityExtCpuUsageIn1Minute.495	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.495	Integer	0
ibEntityExtCpuUsageIn1Minute.496	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.496	Integer	0
ibEntityExtCpuUsageIn1Minute.497	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.497	Integer	0
ibEntityExtCpuUsageIn1Minute.498	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.498	Integer	0
ibEntityExtCpuUsageIn1Minute.499	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.499	Integer	0
ibEntityExtCpuUsageIn1Minute.500	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.500	Integer	0
ibEntityExtCpuUsageIn1Minute.501	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.501	Integer	0
ibEntityExtCpuUsageIn1Minute.502	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.502	Integer	0
ibEntityExtCpuUsageIn1Minute.503	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.503	Integer	0
ibEntityExtCpuUsageIn1Minute.504	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.504	Integer	0
ibEntityExtCpuUsageIn1Minute.505	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.505	Integer	0
ibEntityExtCpuUsageIn1Minute.506	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.506	Integer	0
ibEntityExtCpuUsageIn1Minute.507	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.507	Integer	0
ibEntityExtCpuUsageIn1Minute.508	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.508	Integer	0
ibEntityExtCpuUsageIn1Minute.509	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.509	Integer	0
ibEntityExtCpuUsageIn1Minute.510	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.510	Integer	0
ibEntityExtCpuUsageIn1Minute.511	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.511	Integer	0
ibEntityExtCpuUsageIn1Minute.512	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.512	Integer	0
ibEntityExtCpuUsageIn1Minute.513	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.513	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtCpuUsageIn1Minute.514	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.514	Integer	0
ibEntityExtCpuUsageIn1Minute.515	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.515	Integer	0
ibEntityExtCpuUsageIn1Minute.516	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.516	Integer	0
ibEntityExtCpuUsageIn1Minute.517	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.517	Integer	0
ibEntityExtCpuUsageIn1Minute.518	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.518	Integer	0
ibEntityExtCpuUsageIn1Minute.519	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.519	Integer	0
ibEntityExtCpuUsageIn1Minute.520	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.520	Integer	0
ibEntityExtCpuUsageIn1Minute.521	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.521	Integer	0
ibEntityExtCpuUsageIn1Minute.522	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.522	Integer	0
ibEntityExtCpuUsageIn1Minute.523	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.523	Integer	0
ibEntityExtCpuUsageIn1Minute.524	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.524	Integer	0
ibEntityExtCpuUsageIn1Minute.525	.1.3.6.1.4.1.26138.2.6.1.1.1.1.33.525	Integer	0
ibEntityExtCpuUsageIn5Minutes.1	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.1	Integer	0
ibEntityExtCpuUsageIn5Minutes.2	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.2	Integer	0
ibEntityExtCpuUsageIn5Minutes.12	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.12	Integer	0
ibEntityExtCpuUsageIn5Minutes.13	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.13	Integer	0
ibEntityExtCpuUsageIn5Minutes.14	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.14	Integer	0
ibEntityExtCpuUsageIn5Minutes.15	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.15	Integer	0
ibEntityExtCpuUsageIn5Minutes.16	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.16	Integer	0
ibEntityExtCpuUsageIn5Minutes.17	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.17	Integer	0
ibEntityExtCpuUsageIn5Minutes.18	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.18	Integer	0
ibEntityExtCpuUsageIn5Minutes.19	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.19	Integer	0
ibEntityExtCpuUsageIn5Minutes.20	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.20	Integer	0
ibEntityExtCpuUsageIn5Minutes.21	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.21	Integer	0
ibEntityExtCpuUsageIn5Minutes.22	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.22	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtCpuUsageIn5Minutes.23	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.23	Integer	0
ibEntityExtCpuUsageIn5Minutes.24	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.24	Integer	0
ibEntityExtCpuUsageIn5Minutes.25	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.25	Integer	0
ibEntityExtCpuUsageIn5Minutes.26	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.26	Integer	0
ibEntityExtCpuUsageIn5Minutes.27	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.27	Integer	0
ibEntityExtCpuUsageIn5Minutes.28	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.28	Integer	0
ibEntityExtCpuUsageIn5Minutes.29	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.29	Integer	0
ibEntityExtCpuUsageIn5Minutes.30	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.30	Integer	0
ibEntityExtCpuUsageIn5Minutes.31	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.31	Integer	0
ibEntityExtCpuUsageIn5Minutes.212	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.212	Integer	12
ibEntityExtCpuUsageIn5Minutes.213	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.213	Integer	0
ibEntityExtCpuUsageIn5Minutes.216	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.216	Integer	0
ibEntityExtCpuUsageIn5Minutes.220	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.220	Integer	0
ibEntityExtCpuUsageIn5Minutes.221	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.221	Integer	0
ibEntityExtCpuUsageIn5Minutes.412	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.412	Integer	0
ibEntityExtCpuUsageIn5Minutes.413	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.413	Integer	0
ibEntityExtCpuUsageIn5Minutes.414	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.414	Integer	0
ibEntityExtCpuUsageIn5Minutes.442	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.442	Integer	0
ibEntityExtCpuUsageIn5Minutes.472	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.472	Integer	0
ibEntityExtCpuUsageIn5Minutes.473	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.473	Integer	0
ibEntityExtCpuUsageIn5Minutes.474	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.474	Integer	0
ibEntityExtCpuUsageIn5Minutes.475	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.475	Integer	0
ibEntityExtCpuUsageIn5Minutes.476	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.476	Integer	0
ibEntityExtCpuUsageIn5Minutes.477	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.477	Integer	0
ibEntityExtCpuUsageIn5Minutes.478	1.3.6.1.4.1.26138.2.6.1.1.1.1.34.478	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtCpuUsageIn5Minutes.479	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.479	Integer	0
ibEntityExtCpuUsageIn5Minutes.480	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.480	Integer	0
ibEntityExtCpuUsageIn5Minutes.481	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.481	Integer	0
ibEntityExtCpuUsageIn5Minutes.482	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.482	Integer	0
ibEntityExtCpuUsageIn5Minutes.483	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.483	Integer	0
ibEntityExtCpuUsageIn5Minutes.484	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.484	Integer	0
ibEntityExtCpuUsageIn5Minutes.485	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.485	Integer	0
ibEntityExtCpuUsageIn5Minutes.486	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.486	Integer	0
ibEntityExtCpuUsageIn5Minutes.487	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.487	Integer	0
ibEntityExtCpuUsageIn5Minutes.488	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.488	Integer	0
ibEntityExtCpuUsageIn5Minutes.489	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.489	Integer	0
ibEntityExtCpuUsageIn5Minutes.490	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.490	Integer	0
ibEntityExtCpuUsageIn5Minutes.491	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.491	Integer	0
ibEntityExtCpuUsageIn5Minutes.492	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.492	Integer	0
ibEntityExtCpuUsageIn5Minutes.493	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.493	Integer	0
ibEntityExtCpuUsageIn5Minutes.494	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.494	Integer	0
ibEntityExtCpuUsageIn5Minutes.495	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.495	Integer	0
ibEntityExtCpuUsageIn5Minutes.496	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.496	Integer	0
ibEntityExtCpuUsageIn5Minutes.497	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.497	Integer	0
ibEntityExtCpuUsageIn5Minutes.498	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.498	Integer	0
ibEntityExtCpuUsageIn5Minutes.499	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.499	Integer	0
ibEntityExtCpuUsageIn5Minutes.500	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.500	Integer	0
ibEntityExtCpuUsageIn5Minutes.501	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.501	Integer	0
ibEntityExtCpuUsageIn5Minutes.502	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.502	Integer	0
ibEntityExtCpuUsageIn5Minutes.503	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.503	Integer	0

Name	OID	Value Type	Value Example
ibEntityExtCpuUsageIn5Minutes.504	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.504	Integer	0
ibEntityExtCpuUsageIn5Minutes.505	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.505	Integer	0
ibEntityExtCpuUsageIn5Minutes.506	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.506	Integer	0
ibEntityExtCpuUsageIn5Minutes.507	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.507	Integer	0
ibEntityExtCpuUsageIn5Minutes.508	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.508	Integer	0
ibEntityExtCpuUsageIn5Minutes.509	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.509	Integer	0
ibEntityExtCpuUsageIn5Minutes.510	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.510	Integer	0
ibEntityExtCpuUsageIn5Minutes.511	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.511	Integer	0
ibEntityExtCpuUsageIn5Minutes.512	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.512	Integer	0
ibEntityExtCpuUsageIn5Minutes.513	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.513	Integer	0
ibEntityExtCpuUsageIn5Minutes.514	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.514	Integer	0
ibEntityExtCpuUsageIn5Minutes.515	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.515	Integer	0
ibEntityExtCpuUsageIn5Minutes.516	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.516	Integer	0
ibEntityExtCpuUsageIn5Minutes.517	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.517	Integer	0
ibEntityExtCpuUsageIn5Minutes.518	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.518	Integer	0
ibEntityExtCpuUsageIn5Minutes.519	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.519	Integer	0
ibEntityExtCpuUsageIn5Minutes.520	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.520	Integer	0
ibEntityExtCpuUsageIn5Minutes.521	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.521	Integer	0
ibEntityExtCpuUsageIn5Minutes.522	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.522	Integer	0
ibEntityExtCpuUsageIn5Minutes.523	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.523	Integer	0
ibEntityExtCpuUsageIn5Minutes.524	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.524	Integer	0
ibEntityExtCpuUsageIn5Minutes.525	.1.3.6.1.4.1.26138.2.6.1.1.1.1.34.525	Integer	0
ibEntityExtManuSerialNum.1	.1.3.6.1.4.1.26138.2.6.1.2.1.1.2.1	OctetString	
ibEntityExtManuSerialNum.2	.1.3.6.1.4.1.26138.2.6.1.2.1.1.2.2	OctetString	219801A3PQP23400006H
ibEntityExtManuSerialNum.12	.1.3.6.1.4.1.26138.2.6.1.2.1.1.2.12	OctetString	
ibEntityExtManuSerialNum.13	.1.3.6.1.4.1.26138.2.6.1.2.1.1.2.13	OctetString	
ibEntityExtManuSerialNum.14	.1.3.6.1.4.1.26138.2.6.1.2.1.1.2.14	OctetString	
ibEntityExtManuSerialNum.15	.1.3.6.1.4.1.26138.2.6.1.2.1.1.2.15	OctetString	

Name	OID	Value Type	Value Example
ibEntityExtManuSerialNum.16	.1.3.6.1.4.1.26138.2.6.1.2.1.1.2.16	OctetString	
ibEntityExtManuSerialNum.17	.1.3.6.1.4.1.26138.2.6.1.2.1.1.2.17	OctetString	
ibEntityExtManuSerialNum.18	.1.3.6.1.4.1.26138.2.6.1.2.1.1.2.18	OctetString	
ibEntityExtManuSerialNum.19	.1.3.6.1.4.1.26138.2.6.1.2.1.1.2.19	OctetString	
ibEntityExtManuSerialNum.20	.1.3.6.1.4.1.26138.2.6.1.2.1.1.2.20	OctetString	
ibEntityExtManuSerialNum.21	.1.3.6.1.4.1.26138.2.6.1.2.1.1.2.21	OctetString	
ibEntityExtManuSerialNum.22	.1.3.6.1.4.1.26138.2.6.1.2.1.1.2.22	OctetString	
ibEntityExtManuSerialNum.23	.1.3.6.1.4.1.26138.2.6.1.2.1.1.2.23	OctetString	
ibEntityExtManuSerialNum.24	.1.3.6.1.4.1.26138.2.6.1.2.1.1.2.24	OctetString	
ibEntityExtManuSerialNum.25	.1.3.6.1.4.1.26138.2.6.1.2.1.1.2.25	OctetString	
ibEntityExtManuSerialNum.26	.1.3.6.1.4.1.26138.2.6.1.2.1.1.2.26	OctetString	
ibEntityExtManuSerialNum.27	.1.3.6.1.4.1.26138.2.6.1.2.1.1.2.27	OctetString	
ibEntityExtManuSerialNum.28	.1.3.6.1.4.1.26138.2.6.1.2.1.1.2.28	OctetString	
ibEntityExtManuSerialNum.29	.1.3.6.1.4.1.26138.2.6.1.2.1.1.2.29	OctetString	
ibEntityExtManuSerialNum.30	.1.3.6.1.4.1.26138.2.6.1.2.1.1.2.30	OctetString	
ibEntityExtManuSerialNum.31	.1.3.6.1.4.1.26138.2.6.1.2.1.1.2.31	OctetString	
ibEntityExtManuSerialNum.212	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.212	OctetString	
ibEntityExtManuSerialNum.213	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.213	OctetString	
ibEntityExtManuSerialNum.216	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.216	OctetString	
ibEntityExtManuSerialNum.220	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.220	OctetString	
ibEntityExtManuSerialNum.221	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.221	OctetString	
ibEntityExtManuSerialNum.412	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.412	OctetString	
ibEntityExtManuSerialNum.413	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.413	OctetString	
ibEntityExtManuSerialNum.414	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.414	OctetString	
ibEntityExtManuSerialNum.442	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.442	OctetString	
ibEntityExtManuSerialNum.472	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.472	OctetString	
ibEntityExtManuSerialNum.473	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.473	OctetString	
ibEntityExtManuSerialNum.474	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.474	OctetString	
ibEntityExtManuSerialNum.475	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.475	OctetString	
ibEntityExtManuSerialNum.476	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.476	OctetString	
ibEntityExtManuSerialNum.477	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.477	OctetString	
ibEntityExtManuSerialNum.478	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.478	OctetString	
ibEntityExtManuSerialNum.479	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.479	OctetString	
ibEntityExtManuSerialNum.480	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.480	OctetString	
ibEntityExtManuSerialNum.481	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.481	OctetString	
ibEntityExtManuSerialNum.482	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.482	OctetString	
ibEntityExtManuSerialNum.483	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.483	OctetString	
ibEntityExtManuSerialNum.484	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.484	OctetString	
ibEntityExtManuSerialNum.485	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.485	OctetString	
ibEntityExtManuSerialNum.486	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.486	OctetString	
ibEntityExtManuSerialNum.487	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.487	OctetString	
ibEntityExtManuSerialNum.488	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.488	OctetString	
ibEntityExtManuSerialNum.489	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.489	OctetString	



Name	OID	Value Type	Value Example
ibEntityExtManuSerialNum.490	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.490	OctetString	
ibEntityExtManuSerialNum.491	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.491	OctetString	
ibEntityExtManuSerialNum.492	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.492	OctetString	
ibEntityExtManuSerialNum.493	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.493	OctetString	
ibEntityExtManuSerialNum.494	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.494	OctetString	
ibEntityExtManuSerialNum.495	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.495	OctetString	
ibEntityExtManuSerialNum.496	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.496	OctetString	
ibEntityExtManuSerialNum.497	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.497	OctetString	
ibEntityExtManuSerialNum.498	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.498	OctetString	
ibEntityExtManuSerialNum.499	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.499	OctetString	
ibEntityExtManuSerialNum.500	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.500	OctetString	
ibEntityExtManuSerialNum.501	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.501	OctetString	
ibEntityExtManuSerialNum.502	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.502	OctetString	
ibEntityExtManuSerialNum.503	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.503	OctetString	
ibEntityExtManuSerialNum.504	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.504	OctetString	
ibEntityExtManuSerialNum.505	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.505	OctetString	
ibEntityExtManuSerialNum.506	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.506	OctetString	
ibEntityExtManuSerialNum.507	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.507	OctetString	
ibEntityExtManuSerialNum.508	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.508	OctetString	
ibEntityExtManuSerialNum.509	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.509	OctetString	
ibEntityExtManuSerialNum.510	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.510	OctetString	
ibEntityExtManuSerialNum.511	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.511	OctetString	
ibEntityExtManuSerialNum.512	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.512	OctetString	
ibEntityExtManuSerialNum.513	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.513	OctetString	
ibEntityExtManuSerialNum.514	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.514	OctetString	
ibEntityExtManuSerialNum.515	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.515	OctetString	
ibEntityExtManuSerialNum.516	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.516	OctetString	
ibEntityExtManuSerialNum.517	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.517	OctetString	
ibEntityExtManuSerialNum.518	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.518	OctetString	
ibEntityExtManuSerialNum.519	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.519	OctetString	
ibEntityExtManuSerialNum.520	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.520	OctetString	
ibEntityExtManuSerialNum.521	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.521	OctetString	
ibEntityExtManuSerialNum.522	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.522	OctetString	
ibEntityExtManuSerialNum.523	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.523	OctetString	
ibEntityExtManuSerialNum.524	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.524	OctetString	
ibEntityExtManuSerialNum.525	1.3.6.1.4.1.26138.2.6.1.2.1.1.2.525	OctetString	
ibEntityExtManuBuildInfo.1	.1.3.6.1.4.1.26138.2.6.1.2.1.1.3.1	OctetString	
ibEntityExtManuBuildInfo.2	.1.3.6.1.4.1.26138.2.6.1.2.1.1.3.2	OctetString	00.00.00
ibEntityExtManuBuildInfo.12	.1.3.6.1.4.1.26138.2.6.1.2.1.1.3.12	OctetString	
ibEntityExtManuBuildInfo.13	.1.3.6.1.4.1.26138.2.6.1.2.1.1.3.13	OctetString	
ibEntityExtManuBuildInfo.14	.1.3.6.1.4.1.26138.2.6.1.2.1.1.3.14	OctetString	
ibEntityExtManuBuildInfo.15	.1.3.6.1.4.1.26138.2.6.1.2.1.1.3.15	OctetString	
ibEntityExtManuBuildInfo.16	.1.3.6.1.4.1.26138.2.6.1.2.1.1.3.16	OctetString	

Name	OID	Value Type	Value Example
ibEntityExtManuBuildInfo.17	.1.3.6.1.4.1.26138.2.6.1.2.1.1.3.17	OctetString	
ibEntityExtManuBuildInfo.18	.1.3.6.1.4.1.26138.2.6.1.2.1.1.3.18	OctetString	
ibEntityExtManuBuildInfo.19	.1.3.6.1.4.1.26138.2.6.1.2.1.1.3.19	OctetString	
ibEntityExtManuBuildInfo.20	.1.3.6.1.4.1.26138.2.6.1.2.1.1.3.20	OctetString	
ibEntityExtManuBuildInfo.21	.1.3.6.1.4.1.26138.2.6.1.2.1.1.3.21	OctetString	
ibEntityExtManuBuildInfo.22	.1.3.6.1.4.1.26138.2.6.1.2.1.1.3.22	OctetString	
ibEntityExtManuBuildInfo.23	.1.3.6.1.4.1.26138.2.6.1.2.1.1.3.23	OctetString	
ibEntityExtManuBuildInfo.24	.1.3.6.1.4.1.26138.2.6.1.2.1.1.3.24	OctetString	
ibEntityExtManuBuildInfo.25	.1.3.6.1.4.1.26138.2.6.1.2.1.1.3.25	OctetString	
ibEntityExtManuBuildInfo.26	.1.3.6.1.4.1.26138.2.6.1.2.1.1.3.26	OctetString	
ibEntityExtManuBuildInfo.27	.1.3.6.1.4.1.26138.2.6.1.2.1.1.3.27	OctetString	
ibEntityExtManuBuildInfo.28	.1.3.6.1.4.1.26138.2.6.1.2.1.1.3.28	OctetString	
ibEntityExtManuBuildInfo.29	.1.3.6.1.4.1.26138.2.6.1.2.1.1.3.29	OctetString	
ibEntityExtManuBuildInfo.30	.1.3.6.1.4.1.26138.2.6.1.2.1.1.3.30	OctetString	
ibEntityExtManuBuildInfo.31	.1.3.6.1.4.1.26138.2.6.1.2.1.1.3.31	OctetString	
ibEntityExtManuBuildInfo.212	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.212	OctetString	
ibEntityExtManuBuildInfo.213	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.213	OctetString	
ibEntityExtManuBuildInfo.216	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.216	OctetString	
ibEntityExtManuBuildInfo.220	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.220	OctetString	
ibEntityExtManuBuildInfo.221	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.221	OctetString	
ibEntityExtManuBuildInfo.412	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.412	OctetString	
ibEntityExtManuBuildInfo.413	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.413	OctetString	
ibEntityExtManuBuildInfo.414	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.414	OctetString	
ibEntityExtManuBuildInfo.442	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.442	OctetString	
ibEntityExtManuBuildInfo.472	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.472	OctetString	
ibEntityExtManuBuildInfo.473	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.473	OctetString	
ibEntityExtManuBuildInfo.474	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.474	OctetString	
ibEntityExtManuBuildInfo.475	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.475	OctetString	
ibEntityExtManuBuildInfo.476	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.476	OctetString	
ibEntityExtManuBuildInfo.477	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.477	OctetString	
ibEntityExtManuBuildInfo.478	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.478	OctetString	
ibEntityExtManuBuildInfo.479	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.479	OctetString	
ibEntityExtManuBuildInfo.480	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.480	OctetString	
ibEntityExtManuBuildInfo.481	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.481	OctetString	
ibEntityExtManuBuildInfo.482	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.482	OctetString	
ibEntityExtManuBuildInfo.483	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.483	OctetString	
ibEntityExtManuBuildInfo.484	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.484	OctetString	
ibEntityExtManuBuildInfo.485	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.485	OctetString	
ibEntityExtManuBuildInfo.486	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.486	OctetString	
ibEntityExtManuBuildInfo.487	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.487	OctetString	
ibEntityExtManuBuildInfo.488	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.488	OctetString	
ibEntityExtManuBuildInfo.489	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.489	OctetString	
ibEntityExtManuBuildInfo.490	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.490	OctetString	

Name	OID	Value Type	Value Example
ibEntityExtManuBuildInfo.491	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.491	OctetString	
ibEntityExtManuBuildInfo.492	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.492	OctetString	
ibEntityExtManuBuildInfo.493	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.493	OctetString	
ibEntityExtManuBuildInfo.494	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.494	OctetString	
ibEntityExtManuBuildInfo.495	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.495	OctetString	
ibEntityExtManuBuildInfo.496	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.496	OctetString	
ibEntityExtManuBuildInfo.497	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.497	OctetString	
ibEntityExtManuBuildInfo.498	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.498	OctetString	
ibEntityExtManuBuildInfo.499	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.499	OctetString	
ibEntityExtManuBuildInfo.500	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.500	OctetString	
ibEntityExtManuBuildInfo.501	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.501	OctetString	
ibEntityExtManuBuildInfo.502	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.502	OctetString	
ibEntityExtManuBuildInfo.503	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.503	OctetString	
ibEntityExtManuBuildInfo.504	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.504	OctetString	
ibEntityExtManuBuildInfo.505	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.505	OctetString	
ibEntityExtManuBuildInfo.506	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.506	OctetString	
ibEntityExtManuBuildInfo.507	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.507	OctetString	
ibEntityExtManuBuildInfo.508	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.508	OctetString	
ibEntityExtManuBuildInfo.509	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.509	OctetString	
ibEntityExtManuBuildInfo.510	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.510	OctetString	
ibEntityExtManuBuildInfo.511	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.511	OctetString	
ibEntityExtManuBuildInfo.512	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.512	OctetString	
ibEntityExtManuBuildInfo.513	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.513	OctetString	
ibEntityExtManuBuildInfo.514	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.514	OctetString	
ibEntityExtManuBuildInfo.515	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.515	OctetString	
ibEntityExtManuBuildInfo.516	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.516	OctetString	
ibEntityExtManuBuildInfo.517	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.517	OctetString	
ibEntityExtManuBuildInfo.518	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.518	OctetString	
ibEntityExtManuBuildInfo.519	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.519	OctetString	
ibEntityExtManuBuildInfo.520	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.520	OctetString	
ibEntityExtManuBuildInfo.521	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.521	OctetString	
ibEntityExtManuBuildInfo.522	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.522	OctetString	
ibEntityExtManuBuildInfo.523	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.523	OctetString	
ibEntityExtManuBuildInfo.524	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.524	OctetString	
ibEntityExtManuBuildInfo.525	1.3.6.1.4.1.26138.2.6.1.2.1.1.3.525	OctetString	
ibEntityExtManuBOM.1	.1.3.6.1.4.1.26138.2.6.1.2.1.1.4.1	OctetString	
ibEntityExtManuBOM.2	.1.3.6.1.4.1.26138.2.6.1.2.1.1.4.2	OctetString	9801A3PQ
ibEntityExtManuBOM.12	.1.3.6.1.4.1.26138.2.6.1.2.1.1.4.12	OctetString	
ibEntityExtManuBOM.13	.1.3.6.1.4.1.26138.2.6.1.2.1.1.4.13	OctetString	
ibEntityExtManuBOM.14	.1.3.6.1.4.1.26138.2.6.1.2.1.1.4.14	OctetString	
ibEntityExtManuBOM.15	.1.3.6.1.4.1.26138.2.6.1.2.1.1.4.15	OctetString	
ibEntityExtManuBOM.16	.1.3.6.1.4.1.26138.2.6.1.2.1.1.4.16	OctetString	
ibEntityExtManuBOM.17	.1.3.6.1.4.1.26138.2.6.1.2.1.1.4.17	OctetString	

Name	OID	Value Type	Value Example
ibEntityExtManuBOM.18	.1.3.6.1.4.1.26138.2.6.1.2.1.1.4.18	OctetString	
ibEntityExtManuBOM.19	.1.3.6.1.4.1.26138.2.6.1.2.1.1.4.19	OctetString	
ibEntityExtManuBOM.20	.1.3.6.1.4.1.26138.2.6.1.2.1.1.4.20	OctetString	
ibEntityExtManuBOM.21	.1.3.6.1.4.1.26138.2.6.1.2.1.1.4.21	OctetString	
ibEntityExtManuBOM.22	.1.3.6.1.4.1.26138.2.6.1.2.1.1.4.22	OctetString	
ibEntityExtManuBOM.23	.1.3.6.1.4.1.26138.2.6.1.2.1.1.4.23	OctetString	
ibEntityExtManuBOM.24	.1.3.6.1.4.1.26138.2.6.1.2.1.1.4.24	OctetString	
ibEntityExtManuBOM.25	.1.3.6.1.4.1.26138.2.6.1.2.1.1.4.25	OctetString	
ibEntityExtManuBOM.26	.1.3.6.1.4.1.26138.2.6.1.2.1.1.4.26	OctetString	
ibEntityExtManuBOM.27	.1.3.6.1.4.1.26138.2.6.1.2.1.1.4.27	OctetString	
ibEntityExtManuBOM.28	.1.3.6.1.4.1.26138.2.6.1.2.1.1.4.28	OctetString	
ibEntityExtManuBOM.29	.1.3.6.1.4.1.26138.2.6.1.2.1.1.4.29	OctetString	
ibEntityExtManuBOM.30	.1.3.6.1.4.1.26138.2.6.1.2.1.1.4.30	OctetString	
ibEntityExtManuBOM.31	.1.3.6.1.4.1.26138.2.6.1.2.1.1.4.31	OctetString	
ibEntityExtManuBOM.212	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.212	OctetString	
ibEntityExtManuBOM.213	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.213	OctetString	
ibEntityExtManuBOM.216	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.216	OctetString	
ibEntityExtManuBOM.220	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.220	OctetString	
ibEntityExtManuBOM.221	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.221	OctetString	
ibEntityExtManuBOM.412	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.412	OctetString	
ibEntityExtManuBOM.413	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.413	OctetString	
ibEntityExtManuBOM.414	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.414	OctetString	
ibEntityExtManuBOM.442	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.442	OctetString	
ibEntityExtManuBOM.472	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.472	OctetString	
ibEntityExtManuBOM.473	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.473	OctetString	
ibEntityExtManuBOM.474	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.474	OctetString	
ibEntityExtManuBOM.475	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.475	OctetString	
ibEntityExtManuBOM.476	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.476	OctetString	
ibEntityExtManuBOM.477	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.477	OctetString	
ibEntityExtManuBOM.478	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.478	OctetString	
ibEntityExtManuBOM.479	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.479	OctetString	
ibEntityExtManuBOM.480	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.480	OctetString	
ibEntityExtManuBOM.481	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.481	OctetString	
ibEntityExtManuBOM.482	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.482	OctetString	
ibEntityExtManuBOM.483	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.483	OctetString	
ibEntityExtManuBOM.484	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.484	OctetString	
ibEntityExtManuBOM.485	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.485	OctetString	
ibEntityExtManuBOM.486	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.486	OctetString	
ibEntityExtManuBOM.487	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.487	OctetString	
ibEntityExtManuBOM.488	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.488	OctetString	
ibEntityExtManuBOM.489	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.489	OctetString	
ibEntityExtManuBOM.490	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.490	OctetString	
ibEntityExtManuBOM.491	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.491	OctetString	

Name	OID	Value Type	Value Example
ibEntityExtManuBOM.492	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.492	OctetString	
ibEntityExtManuBOM.493	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.493	OctetString	
ibEntityExtManuBOM.494	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.494	OctetString	
ibEntityExtManuBOM.495	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.495	OctetString	
ibEntityExtManuBOM.496	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.496	OctetString	
ibEntityExtManuBOM.497	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.497	OctetString	
ibEntityExtManuBOM.498	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.498	OctetString	
ibEntityExtManuBOM.499	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.499	OctetString	
ibEntityExtManuBOM.500	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.500	OctetString	
ibEntityExtManuBOM.501	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.501	OctetString	
ibEntityExtManuBOM.502	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.502	OctetString	
ibEntityExtManuBOM.503	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.503	OctetString	
ibEntityExtManuBOM.504	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.504	OctetString	
ibEntityExtManuBOM.505	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.505	OctetString	
ibEntityExtManuBOM.506	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.506	OctetString	
ibEntityExtManuBOM.507	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.507	OctetString	
ibEntityExtManuBOM.508	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.508	OctetString	
ibEntityExtManuBOM.509	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.509	OctetString	
ibEntityExtManuBOM.510	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.510	OctetString	
ibEntityExtManuBOM.511	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.511	OctetString	
ibEntityExtManuBOM.512	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.512	OctetString	
ibEntityExtManuBOM.513	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.513	OctetString	
ibEntityExtManuBOM.514	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.514	OctetString	
ibEntityExtManuBOM.515	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.515	OctetString	
ibEntityExtManuBOM.516	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.516	OctetString	
ibEntityExtManuBOM.517	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.517	OctetString	
ibEntityExtManuBOM.518	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.518	OctetString	
ibEntityExtManuBOM.519	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.519	OctetString	
ibEntityExtManuBOM.520	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.520	OctetString	
ibEntityExtManuBOM.521	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.521	OctetString	
ibEntityExtManuBOM.522	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.522	OctetString	
ibEntityExtManuBOM.523	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.523	OctetString	
ibEntityExtManuBOM.524	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.524	OctetString	
ibEntityExtManuBOM.525	1.3.6.1.4.1.26138.2.6.1.2.1.1.4.525	OctetString	
ibEntityExtMacAddressCount.1	.1.3.6.1.4.1.26138.2.6.1.2.1.1.5.1	Gauge	0
ibEntityExtMacAddressCount.2	.1.3.6.1.4.1.26138.2.6.1.2.1.1.5.2	Gauge	98
ibEntityExtMacAddress-Count.12	.1.3.6.1.4.1.26138.2.6.1.2.1.1.5.12	Gauge	0
ibEntityExtMacAddress-Count.13	.1.3.6.1.4.1.26138.2.6.1.2.1.1.5.13	Gauge	0
ibEntityExtMacAddress-Count.14	.1.3.6.1.4.1.26138.2.6.1.2.1.1.5.14	Gauge	0
ibEntityExtMacAddress-Count.15	.1.3.6.1.4.1.26138.2.6.1.2.1.1.5.15	Gauge	0

Name	OID	Value Type	Value Example
ibEntityExtMacAddress-Count.16	.1.3.6.1.4.1.26138.2.6.1.2.1.1.5.16	Gauge	0
ibEntityExtMacAddress-Count.17	.1.3.6.1.4.1.26138.2.6.1.2.1.1.5.17	Gauge	0
ibEntityExtMacAddress-Count.18	.1.3.6.1.4.1.26138.2.6.1.2.1.1.5.18	Gauge	0
ibEntityExtMacAddress-Count.19	.1.3.6.1.4.1.26138.2.6.1.2.1.1.5.19	Gauge	0
ibEntityExtMacAddress-Count.20	.1.3.6.1.4.1.26138.2.6.1.2.1.1.5.20	Gauge	0
ibEntityExtMacAddress-Count.21	.1.3.6.1.4.1.26138.2.6.1.2.1.1.5.21	Gauge	0
ibEntityExtMacAddress-Count.22	.1.3.6.1.4.1.26138.2.6.1.2.1.1.5.22	Gauge	0
ibEntityExtMacAddress-Count.23	.1.3.6.1.4.1.26138.2.6.1.2.1.1.5.23	Gauge	0
ibEntityExtMacAddress-Count.24	.1.3.6.1.4.1.26138.2.6.1.2.1.1.5.24	Gauge	0
ibEntityExtMacAddress-Count.25	.1.3.6.1.4.1.26138.2.6.1.2.1.1.5.25	Gauge	0
ibEntityExtMacAddress-Count.26	.1.3.6.1.4.1.26138.2.6.1.2.1.1.5.26	Gauge	0
ibEntityExtMacAddress-Count.27	.1.3.6.1.4.1.26138.2.6.1.2.1.1.5.27	Gauge	0
ibEntityExtMacAddress-Count.28	.1.3.6.1.4.1.26138.2.6.1.2.1.1.5.28	Gauge	0
ibEntityExtMacAddress-Count.29	.1.3.6.1.4.1.26138.2.6.1.2.1.1.5.29	Gauge	0
ibEntityExtMacAddress-Count.30	.1.3.6.1.4.1.26138.2.6.1.2.1.1.5.30	Gauge	0
ibEntityExtMacAddress-Count.31	.1.3.6.1.4.1.26138.2.6.1.2.1.1.5.31	Gauge	0
ibEntityExtMacAddress-Count.212	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.212	Gauge	0
ibEntityExtMacAddress-Count.213	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.213	Gauge	0
ibEntityExtMacAddress-Count.216	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.216	Gauge	0
ibEntityExtMacAddress-Count.220	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.220	Gauge	0
ibEntityExtMacAddress-Count.221	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.221	Gauge	0
ibEntityExtMacAddress-Count.412	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.412	Gauge	0
ibEntityExtMacAddress-Count.413	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.413	Gauge	0
ibEntityExtMacAddress-Count.414	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.414	Gauge	0
ibEntityExtMacAddress-Count.442	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.442	Gauge	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ibEntityExtMacAddress-Count.472	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.472	Gauge	1
ibEntityExtMacAddress-Count.473	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.473	Gauge	1
ibEntityExtMacAddress-Count.474	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.474	Gauge	1
ibEntityExtMacAddress-Count.475	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.475	Gauge	1
ibEntityExtMacAddress-Count.476	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.476	Gauge	1
ibEntityExtMacAddress-Count.477	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.477	Gauge	1
ibEntityExtMacAddress-Count.478	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.478	Gauge	1
ibEntityExtMacAddress-Count.479	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.479	Gauge	1
ibEntityExtMacAddress-Count.480	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.480	Gauge	1
ibEntityExtMacAddress-Count.481	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.481	Gauge	1
ibEntityExtMacAddress-Count.482	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.482	Gauge	1
ibEntityExtMacAddress-Count.483	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.483	Gauge	1
ibEntityExtMacAddress-Count.484	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.484	Gauge	1
ibEntityExtMacAddress-Count.485	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.485	Gauge	1
ibEntityExtMacAddress-Count.486	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.486	Gauge	1
ibEntityExtMacAddress-Count.487	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.487	Gauge	1
ibEntityExtMacAddress-Count.488	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.488	Gauge	1
ibEntityExtMacAddress-Count.489	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.489	Gauge	1
ibEntityExtMacAddress-Count.490	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.490	Gauge	1
ibEntityExtMacAddress-Count.491	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.491	Gauge	1
ibEntityExtMacAddress-Count.492	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.492	Gauge	1
ibEntityExtMacAddress-Count.493	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.493	Gauge	1
ibEntityExtMacAddress-Count.494	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.494	Gauge	1
ibEntityExtMacAddress-Count.495	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.495	Gauge	1
ibEntityExtMacAddress-Count.496	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.496	Gauge	1



Name	OID	Value Type	Value Example
ibEntityExtMacAddress-Count.497	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.497	Gauge	1
ibEntityExtMacAddress-Count.498	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.498	Gauge	1
ibEntityExtMacAddress-Count.499	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.499	Gauge	1
ibEntityExtMacAddress-Count.500	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.500	Gauge	1
ibEntityExtMacAddress-Count.501	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.501	Gauge	1
ibEntityExtMacAddress-Count.502	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.502	Gauge	1
ibEntityExtMacAddress-Count.503	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.503	Gauge	1
ibEntityExtMacAddress-Count.504	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.504	Gauge	1
ibEntityExtMacAddress-Count.505	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.505	Gauge	1
ibEntityExtMacAddress-Count.506	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.506	Gauge	1
ibEntityExtMacAddress-Count.507	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.507	Gauge	1
ibEntityExtMacAddress-Count.508	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.508	Gauge	1
ibEntityExtMacAddress-Count.509	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.509	Gauge	1
ibEntityExtMacAddress-Count.510	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.510	Gauge	1
ibEntityExtMacAddress-Count.511	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.511	Gauge	1
ibEntityExtMacAddress-Count.512	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.512	Gauge	1
ibEntityExtMacAddress-Count.513	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.513	Gauge	1
ibEntityExtMacAddress-Count.514	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.514	Gauge	1
ibEntityExtMacAddress-Count.515	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.515	Gauge	1
ibEntityExtMacAddress-Count.516	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.516	Gauge	1
ibEntityExtMacAddress-Count.517	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.517	Gauge	1
ibEntityExtMacAddress-Count.518	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.518	Gauge	1
ibEntityExtMacAddress-Count.519	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.519	Gauge	1
ibEntityExtMacAddress-Count.520	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.520	Gauge	1
ibEntityExtMacAddress-Count.521	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.521	Gauge	1



Name	OID	Value Type	Value Example
ibEntityExtMacAddress-Count.522	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.522	Gauge	1
ibEntityExtMacAddress-Count.523	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.523	Gauge	1
ibEntityExtMacAddress-Count.524	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.524	Gauge	1
ibEntityExtMacAddress-Count.525	1.3.6.1.4.1.26138.2.6.1.2.1.1.5.525	Gauge	1
ibProcessID.1	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.1	Gauge	1
ibProcessID.2	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.2	Gauge	2
ibProcessID.3	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.3	Gauge	3
ibProcessID.4	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.4	Gauge	4
ibProcessID.5	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.5	Gauge	5
ibProcessID.7	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7	Gauge	7
ibProcessID.8	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.8	Gauge	8
ibProcessID.9	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9	Gauge	9
ibProcessID.10	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10	Gauge	10
ibProcessID.11	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11	Gauge	11
ibProcessID.12	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.12	Gauge	12
ibProcessID.13	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.13	Gauge	13
ibProcessID.14	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.14	Gauge	14
ibProcessID.15	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.15	Gauge	15
ibProcessID.16	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.16	Gauge	16
ibProcessID.17	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.17	Gauge	17
ibProcessID.18	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.18	Gauge	18
ibProcessID.19	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.19	Gauge	19
ibProcessID.20	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.20	Gauge	20
ibProcessID.21	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.21	Gauge	21
ibProcessID.22	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.22	Gauge	22
ibProcessID.23	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.23	Gauge	23
ibProcessID.45	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.45	Gauge	45
ibProcessID.120	1.3.6.1.4.1.26138.2.6.1.4.1.1.1.120	Gauge	120
ibProcessID.122	1.3.6.1.4.1.26138.2.6.1.4.1.1.1.122	Gauge	122
ibProcessID.123	1.3.6.1.4.1.26138.2.6.1.4.1.1.1.123	Gauge	123
ibProcessID.145	1.3.6.1.4.1.26138.2.6.1.4.1.1.1.145	Gauge	145
ibProcessID.146	1.3.6.1.4.1.26138.2.6.1.4.1.1.1.146	Gauge	146
ibProcessID.147	1.3.6.1.4.1.26138.2.6.1.4.1.1.1.147	Gauge	147
ibProcessID.148	1.3.6.1.4.1.26138.2.6.1.4.1.1.1.148	Gauge	148
ibProcessID.159	1.3.6.1.4.1.26138.2.6.1.4.1.1.1.159	Gauge	159
ibProcessID.161	1.3.6.1.4.1.26138.2.6.1.4.1.1.1.161	Gauge	161
ibProcessID.235	1.3.6.1.4.1.26138.2.6.1.4.1.1.1.235	Gauge	235
ibProcessID.5818	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.5818	Gauge	5818
ibProcessID.5850	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.5850	Gauge	5850
ibProcessID.5879	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.5879	Gauge	5879

Name	OID	Value Type	Value Example
ibProcessID.5909	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.5909	Gauge	5909
ibProcessID.5934	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.5934	Gauge	5934
ibProcessID.5974	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.5974	Gauge	5974
ibProcessID.6006	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.6006	Gauge	6006
ibProcessID.6033	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.6033	Gauge	6033
ibProcessID.6066	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.6066	Gauge	6066
ibProcessID.6092	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.6092	Gauge	6092
ibProcessID.6109	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.6109	Gauge	6109
ibProcessID.6127	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.6127	Gauge	6127
ibProcessID.6150	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.6150	Gauge	6150
ibProcessID.6179	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.6179	Gauge	6179
ibProcessID.6204	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.6204	Gauge	6204
ibProcessID.6225	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.6225	Gauge	6225
ibProcessID.6529	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.6529	Gauge	6529
ibProcessID.6541	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.6541	Gauge	6541
ibProcessID.6565	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.6565	Gauge	6565
ibProcessID.6588	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.6588	Gauge	6588
ibProcessID.6604	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.6604	Gauge	6604
ibProcessID.6648	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.6648	Gauge	6648
ibProcessID.6676	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.6676	Gauge	6676
ibProcessID.6700	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.6700	Gauge	6700
ibProcessID.7402	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7402	Gauge	7402
ibProcessID.7424	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7424	Gauge	7424
ibProcessID.7449	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7449	Gauge	7449
ibProcessID.7459	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7459	Gauge	7459
ibProcessID.7467	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7467	Gauge	7467
ibProcessID.7468	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7468	Gauge	7468
ibProcessID.7558	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7558	Gauge	7558
ibProcessID.7563	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7563	Gauge	7563
ibProcessID.7642	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7642	Gauge	7642
ibProcessID.7671	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7671	Gauge	7671
ibProcessID.7672	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7672	Gauge	7672
ibProcessID.7673	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7673	Gauge	7673
ibProcessID.7674	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7674	Gauge	7674
ibProcessID.7675	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7675	Gauge	7675
ibProcessID.7676	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7676	Gauge	7676
ibProcessID.7677	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7677	Gauge	7677
ibProcessID.7678	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7678	Gauge	7678
ibProcessID.7679	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7679	Gauge	7679
ibProcessID.7680	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7680	Gauge	7680
ibProcessID.7681	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7681	Gauge	7681
ibProcessID.7682	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7682	Gauge	7682
ibProcessID.7683	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7683	Gauge	7683

Name	OID	Value Type	Value Example
ibProcessID.7685	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7685	Gauge	7685
ibProcessID.7686	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7686	Gauge	7686
ibProcessID.7687	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7687	Gauge	7687
ibProcessID.7690	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7690	Gauge	7690
ibProcessID.7691	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7691	Gauge	7691
ibProcessID.7692	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7692	Gauge	7692
ibProcessID.7693	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7693	Gauge	7693
ibProcessID.7694	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7694	Gauge	7694
ibProcessID.7695	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7695	Gauge	7695
ibProcessID.7696	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7696	Gauge	7696
ibProcessID.7697	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7697	Gauge	7697
ibProcessID.7698	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7698	Gauge	7698
ibProcessID.7699	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7699	Gauge	7699
ibProcessID.7700	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7700	Gauge	7700
ibProcessID.7701	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7701	Gauge	7701
ibProcessID.7702	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7702	Gauge	7702
ibProcessID.7703	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7703	Gauge	7703
ibProcessID.7704	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7704	Gauge	7704
ibProcessID.7705	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7705	Gauge	7705
ibProcessID.7706	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7706	Gauge	7706
ibProcessID.7707	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7707	Gauge	7707
ibProcessID.7708	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7708	Gauge	7708
ibProcessID.7709	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7709	Gauge	7709
ibProcessID.7710	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7710	Gauge	7710
ibProcessID.7711	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7711	Gauge	7711
ibProcessID.7712	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7712	Gauge	7712
ibProcessID.7713	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7713	Gauge	7713
ibProcessID.7714	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7714	Gauge	7714
ibProcessID.7715	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7715	Gauge	7715
ibProcessID.7716	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7716	Gauge	7716
ibProcessID.7717	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7717	Gauge	7717
ibProcessID.7718	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7718	Gauge	7718
ibProcessID.7719	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7719	Gauge	7719
ibProcessID.7720	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7720	Gauge	7720
ibProcessID.7721	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7721	Gauge	7721
ibProcessID.7722	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7722	Gauge	7722
ibProcessID.7723	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7723	Gauge	7723
ibProcessID.7724	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7724	Gauge	7724
ibProcessID.7725	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7725	Gauge	7725
ibProcessID.7726	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7726	Gauge	7726
ibProcessID.7727	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7727	Gauge	7727
ibProcessID.7728	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7728	Gauge	7728
ibProcessID.7729	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7729	Gauge	7729

Name	OID	Value Type	Value Example
ibProcessID.7771	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.7771	Gauge	7771
ibProcessID.8043	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.8043	Gauge	8043
ibProcessID.8044	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.8044	Gauge	8044
ibProcessID.8045	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.8045	Gauge	8045
ibProcessID.8046	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.8046	Gauge	8046
ibProcessID.8047	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.8047	Gauge	8047
ibProcessID.8048	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.8048	Gauge	8048
ibProcessID.8049	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.8049	Gauge	8049
ibProcessID.8050	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.8050	Gauge	8050
ibProcessID.8051	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.8051	Gauge	8051
ibProcessID.8055	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.8055	Gauge	8055
ibProcessID.8057	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.8057	Gauge	8057
ibProcessID.8062	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.8062	Gauge	8062
ibProcessID.8067	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.8067	Gauge	8067
ibProcessID.8116	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.8116	Gauge	8116
ibProcessID.8117	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.8117	Gauge	8117
ibProcessID.8118	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.8118	Gauge	8118
ibProcessID.8120	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.8120	Gauge	8120
ibProcessID.8123	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.8123	Gauge	8123
ibProcessID.8563	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.8563	Gauge	8563
ibProcessID.8565	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.8565	Gauge	8565
ibProcessID.9334	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9334	Gauge	9334
ibProcessID.9335	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9335	Gauge	9335
ibProcessID.9338	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9338	Gauge	9338
ibProcessID.9341	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9341	Gauge	9341
ibProcessID.9342	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9342	Gauge	9342
ibProcessID.9343	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9343	Gauge	9343
ibProcessID.9345	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9345	Gauge	9345
ibProcessID.9348	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9348	Gauge	9348
ibProcessID.9354	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9354	Gauge	9354
ibProcessID.9355	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9355	Gauge	9355
ibProcessID.9482	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9482	Gauge	9482
ibProcessID.9484	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9484	Gauge	9484
ibProcessID.9486	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9486	Gauge	9486
ibProcessID.9487	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9487	Gauge	9487
ibProcessID.9488	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9488	Gauge	9488
ibProcessID.9489	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9489	Gauge	9489
ibProcessID.9490	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9490	Gauge	9490
ibProcessID.9492	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9492	Gauge	9492
ibProcessID.9493	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9493	Gauge	9493
ibProcessID.9494	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9494	Gauge	9494
ibProcessID.9495	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9495	Gauge	9495
ibProcessID.9497	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9497	Gauge	9497

Name	OID	Value Type	Value Example
ibProcessID.9509	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9509	Gauge	9509
ibProcessID.9511	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9511	Gauge	9511
ibProcessID.9532	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9532	Gauge	9532
ibProcessID.9540	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9540	Gauge	9540
ibProcessID.9541	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9541	Gauge	9541
ibProcessID.9561	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9561	Gauge	9561
ibProcessID.9562	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9562	Gauge	9562
ibProcessID.9571	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9571	Gauge	9571
ibProcessID.9576	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9576	Gauge	9576
ibProcessID.9581	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9581	Gauge	9581
ibProcessID.9586	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9586	Gauge	9586
ibProcessID.9592	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9592	Gauge	9592
ibProcessID.9598	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9598	Gauge	9598
ibProcessID.9603	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9603	Gauge	9603
ibProcessID.9608	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9608	Gauge	9608
ibProcessID.9613	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9613	Gauge	9613
ibProcessID.9616	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9616	Gauge	9616
ibProcessID.9637	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9637	Gauge	9637
ibProcessID.9642	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9642	Gauge	9642
ibProcessID.9659	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9659	Gauge	9659
ibProcessID.9662	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9662	Gauge	9662
ibProcessID.9689	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9689	Gauge	9689
ibProcessID.9698	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9698	Gauge	9698
ibProcessID.9718	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9718	Gauge	9718
ibProcessID.9721	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9721	Gauge	9721
ibProcessID.9744	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9744	Gauge	9744
ibProcessID.9747	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9747	Gauge	9747
ibProcessID.9770	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9770	Gauge	9770
ibProcessID.9773	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9773	Gauge	9773
ibProcessID.9789	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9789	Gauge	9789
ibProcessID.9796	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9796	Gauge	9796
ibProcessID.9822	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9822	Gauge	9822
ibProcessID.9825	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9825	Gauge	9825
ibProcessID.9848	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9848	Gauge	9848
ibProcessID.9851	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9851	Gauge	9851
ibProcessID.9862	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9862	Gauge	9862
ibProcessID.9865	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9865	Gauge	9865
ibProcessID.9889	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9889	Gauge	9889
ibProcessID.9897	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9897	Gauge	9897
ibProcessID.9922	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9922	Gauge	9922
ibProcessID.9926	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9926	Gauge	9926
ibProcessID.9938	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9938	Gauge	9938
ibProcessID.9946	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9946	Gauge	9946

Name	OID	Value Type	Value Example
ibProcessID.9978	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9978	Gauge	9978
ibProcessID.9981	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.9981	Gauge	9981
ibProcessID.10005	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10005	Gauge	10005
ibProcessID.10008	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10008	Gauge	10008
ibProcessID.10031	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10031	Gauge	10031
ibProcessID.10034	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10034	Gauge	10034
ibProcessID.10057	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10057	Gauge	10057
ibProcessID.10060	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10060	Gauge	10060
ibProcessID.10078	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10078	Gauge	10078
ibProcessID.10085	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10085	Gauge	10085
ibProcessID.10106	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10106	Gauge	10106
ibProcessID.10112	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10112	Gauge	10112
ibProcessID.10136	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10136	Gauge	10136
ibProcessID.10139	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10139	Gauge	10139
ibProcessID.10162	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10162	Gauge	10162
ibProcessID.10165	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10165	Gauge	10165
ibProcessID.10185	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10185	Gauge	10185
ibProcessID.10191	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10191	Gauge	10191
ibProcessID.10208	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10208	Gauge	10208
ibProcessID.10210	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10210	Gauge	10210
ibProcessID.10235	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10235	Gauge	10235
ibProcessID.10238	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10238	Gauge	10238
ibProcessID.10256	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10256	Gauge	10256
ibProcessID.10259	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10259	Gauge	10259
ibProcessID.10289	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10289	Gauge	10289
ibProcessID.10296	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10296	Gauge	10296
ibProcessID.10324	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10324	Gauge	10324
ibProcessID.10327	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10327	Gauge	10327
ibProcessID.10351	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10351	Gauge	10351
ibProcessID.10357	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10357	Gauge	10357
ibProcessID.10377	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10377	Gauge	10377
ibProcessID.10380	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10380	Gauge	10380
ibProcessID.10403	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10403	Gauge	10403
ibProcessID.10406	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10406	Gauge	10406
ibProcessID.10429	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10429	Gauge	10429
ibProcessID.10432	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10432	Gauge	10432
ibProcessID.10455	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10455	Gauge	10455
ibProcessID.10458	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10458	Gauge	10458
ibProcessID.10481	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10481	Gauge	10481
ibProcessID.10484	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10484	Gauge	10484
ibProcessID.10507	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10507	Gauge	10507
ibProcessID.10510	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10510	Gauge	10510
ibProcessID.10533	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10533	Gauge	10533

Name	OID	Value Type	Value Example
ibProcessID.10536	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10536	Gauge	10536
ibProcessID.10558	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10558	Gauge	10558
ibProcessID.10562	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10562	Gauge	10562
ibProcessID.10579	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10579	Gauge	10579
ibProcessID.10581	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10581	Gauge	10581
ibProcessID.10611	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10611	Gauge	10611
ibProcessID.10614	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10614	Gauge	10614
ibProcessID.10637	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10637	Gauge	10637
ibProcessID.10640	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10640	Gauge	10640
ibProcessID.10663	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10663	Gauge	10663
ibProcessID.10666	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10666	Gauge	10666
ibProcessID.10689	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10689	Gauge	10689
ibProcessID.10692	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10692	Gauge	10692
ibProcessID.10715	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10715	Gauge	10715
ibProcessID.10718	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10718	Gauge	10718
ibProcessID.10741	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10741	Gauge	10741
ibProcessID.10744	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10744	Gauge	10744
ibProcessID.10767	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10767	Gauge	10767
ibProcessID.10770	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10770	Gauge	10770
ibProcessID.10793	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10793	Gauge	10793
ibProcessID.10796	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10796	Gauge	10796
ibProcessID.10819	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10819	Gauge	10819
ibProcessID.10822	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10822	Gauge	10822
ibProcessID.10845	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10845	Gauge	10845
ibProcessID.10848	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10848	Gauge	10848
ibProcessID.10871	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10871	Gauge	10871
ibProcessID.10874	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10874	Gauge	10874
ibProcessID.10897	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10897	Gauge	10897
ibProcessID.10900	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10900	Gauge	10900
ibProcessID.10923	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10923	Gauge	10923
ibProcessID.10926	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10926	Gauge	10926
ibProcessID.10949	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10949	Gauge	10949
ibProcessID.10952	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10952	Gauge	10952
ibProcessID.10975	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10975	Gauge	10975
ibProcessID.10978	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.10978	Gauge	10978
ibProcessID.11001	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11001	Gauge	11001
ibProcessID.11004	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11004	Gauge	11004
ibProcessID.11027	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11027	Gauge	11027
ibProcessID.11030	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11030	Gauge	11030
ibProcessID.11053	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11053	Gauge	11053
ibProcessID.11059	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11059	Gauge	11059
ibProcessID.11079	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11079	Gauge	11079
ibProcessID.11086	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11086	Gauge	11086



Name	OID	Value Type	Value Example
ibProcessID.11105	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11105	Gauge	11105
ibProcessID.11108	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11108	Gauge	11108
ibProcessID.11133	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11133	Gauge	11133
ibProcessID.11136	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11136	Gauge	11136
ibProcessID.11153	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11153	Gauge	11153
ibProcessID.11156	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11156	Gauge	11156
ibProcessID.11176	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11176	Gauge	11176
ibProcessID.11181	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11181	Gauge	11181
ibProcessID.11214	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11214	Gauge	11214
ibProcessID.11217	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11217	Gauge	11217
ibProcessID.11236	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11236	Gauge	11236
ibProcessID.11241	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11241	Gauge	11241
ibProcessID.11266	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11266	Gauge	11266
ibProcessID.11270	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11270	Gauge	11270
ibProcessID.11286	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11286	Gauge	11286
ibProcessID.11290	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11290	Gauge	11290
ibProcessID.11313	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11313	Gauge	11313
ibProcessID.11316	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11316	Gauge	11316
ibProcessID.11339	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11339	Gauge	11339
ibProcessID.11344	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11344	Gauge	11344
ibProcessID.11364	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11364	Gauge	11364
ibProcessID.11578	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11578	Gauge	11578
ibProcessID.11579	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11579	Gauge	11579
ibProcessID.11582	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11582	Gauge	11582
ibProcessID.11583	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11583	Gauge	11583
ibProcessID.11584	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11584	Gauge	11584
ibProcessID.11593	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11593	Gauge	11593
ibProcessID.11597	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11597	Gauge	11597
ibProcessID.11603	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11603	Gauge	11603
ibProcessID.11604	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11604	Gauge	11604
ibProcessID.11609	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11609	Gauge	11609
ibProcessID.11612	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11612	Gauge	11612
ibProcessID.11613	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11613	Gauge	11613
ibProcessID.11617	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11617	Gauge	11617
ibProcessID.11622	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11622	Gauge	11622
ibProcessID.11631	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11631	Gauge	11631
ibProcessID.11636	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11636	Gauge	11636
ibProcessID.11748	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11748	Gauge	11748
ibProcessID.11797	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11797	Gauge	11797
ibProcessID.11801	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11801	Gauge	11801
ibProcessID.11806	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11806	Gauge	11806
ibProcessID.11812	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11812	Gauge	11812
ibProcessID.11815	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11815	Gauge	11815



Name	OID	Value Type	Value Example
ibProcessID.11827	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.11827	Gauge	11827
ibProcessID.12039	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.12039	Gauge	12039
ibProcessID.12041	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.12041	Gauge	12041
ibProcessID.12044	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.12044	Gauge	12044
ibProcessID.12049	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.12049	Gauge	12049
ibProcessID.15402	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.15402	Gauge	15402
ibProcessID.15409	.1.3.6.1.4.1.26138.2.6.1.4.1.1.1.15409	Gauge	15409
ibProcessName.1	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.1	OctetString	scmd
ibProcessName.2	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.2	OctetString	kthreadd
ibProcessName.3	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.3	OctetString	ksoftirqd/0
ibProcessName.4	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.4	OctetString	kworker/0:0
ibProcessName.5	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.5	OctetString	kworker/0:0H
ibProcessName.7	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7	OctetString	rcu_sched
ibProcessName.8	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.8	OctetString	rcu_bh
ibProcessName.9	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9	OctetString	migration/0
ibProcessName.10	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10	OctetString	migration/1
ibProcessName.11	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11	OctetString	ksoftirqd/1
ibProcessName.12	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.12	OctetString	kworker/1:0
ibProcessName.13	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.13	OctetString	kworker/1:0H
ibProcessName.14	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.14	OctetString	migration/2
ibProcessName.15	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.15	OctetString	ksoftirqd/2
ibProcessName.16	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.16	OctetString	kworker/2:0
ibProcessName.17	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.17	OctetString	kworker/2:0H
ibProcessName.18	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.18	OctetString	migration/3
ibProcessName.19	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.19	OctetString	ksoftirqd/3
ibProcessName.20	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.20	OctetString	kworker/3:0
ibProcessName.21	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.21	OctetString	kworker/3:0H
ibProcessName.22	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.22	OctetString	kdevtmpfs
ibProcessName.23	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.23	OctetString	perf
ibProcessName.45	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.45	OctetString	kworker/u8:3
ibProcessName.120	1.3.6.1.4.1.26138.2.6.1.4.1.1.2.120	OctetString	writeback
ibProcessName.122	1.3.6.1.4.1.26138.2.6.1.4.1.1.2.122	OctetString	bioset
ibProcessName.123	1.3.6.1.4.1.26138.2.6.1.4.1.1.2.123	OctetString	kblockd
ibProcessName.145	1.3.6.1.4.1.26138.2.6.1.4.1.1.2.145	OctetString	kworker/0:1
ibProcessName.146	1.3.6.1.4.1.26138.2.6.1.4.1.1.2.146	OctetString	kworker/2:1
ibProcessName.147	1.3.6.1.4.1.26138.2.6.1.4.1.1.2.147	OctetString	kworker/3:1
ibProcessName.148	1.3.6.1.4.1.26138.2.6.1.4.1.1.2.148	OctetString	kworker/1:1
ibProcessName.159	1.3.6.1.4.1.26138.2.6.1.4.1.1.2.159	OctetString	kswapd0
ibProcessName.161	1.3.6.1.4.1.26138.2.6.1.4.1.1.2.161	OctetString	vmstat
ibProcessName.235	1.3.6.1.4.1.26138.2.6.1.4.1.1.2.235	OctetString	fsnotify_mark
ibProcessName.5818	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.5818	OctetString	bioset
ibProcessName.5850	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.5850	OctetString	bioset
ibProcessName.5879	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.5879	OctetString	bioset

Name	OID	Value Type	Value Example
ibProcessName.5909	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.5909	OctetString	bioset
ibProcessName.5934	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.5934	OctetString	bioset
ibProcessName.5974	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.5974	OctetString	bioset
ibProcessName.6006	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.6006	OctetString	bioset
ibProcessName.6033	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.6033	OctetString	bioset
ibProcessName.6066	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.6066	OctetString	bioset
ibProcessName.6092	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.6092	OctetString	bioset
ibProcessName.6109	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.6109	OctetString	bioset
ibProcessName.6127	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.6127	OctetString	bioset
ibProcessName.6150	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.6150	OctetString	bioset
ibProcessName.6179	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.6179	OctetString	bioset
ibProcessName.6204	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.6204	OctetString	bioset
ibProcessName.6225	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.6225	OctetString	bioset
ibProcessName.6529	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.6529	OctetString	bioset
ibProcessName.6541	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.6541	OctetString	bioset
ibProcessName.6565	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.6565	OctetString	bioset
ibProcessName.6588	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.6588	OctetString	bioset
ibProcessName.6604	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.6604	OctetString	bioset
ibProcessName.6648	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.6648	OctetString	bioset
ibProcessName.6676	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.6676	OctetString	bioset
ibProcessName.6700	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.6700	OctetString	bioset
ibProcessName.7402	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7402	OctetString	deferwq
ibProcessName.7424	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7424	OctetString	watchdog/0
ibProcessName.7449	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7449	OctetString	watchdog/1
ibProcessName.7459	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7459	OctetString	watchdog/2
ibProcessName.7467	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7467	OctetString	watchdog/3
ibProcessName.7468	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7468	OctetString	kstarvationtask
ibProcessName.7558	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7558	OctetString	bioset
ibProcessName.7563	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7563	OctetString	bioset
ibProcessName.7642	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7642	OctetString	yaffs-bg-1
ibProcessName.7671	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7671	OctetString	TMTH
ibProcessName.7672	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7672	OctetString	dGDB
ibProcessName.7673	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7673	OctetString	DSTK
ibProcessName.7674	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7674	OctetString	DST2
ibProcessName.7675	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7675	OctetString	DST3
ibProcessName.7676	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7676	OctetString	TSTK
ibProcessName.7677	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7677	OctetString	DrvD
ibProcessName.7678	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7678	OctetString	DSYN
ibProcessName.7679	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7679	OctetString	DIPC
ibProcessName.7680	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7680	OctetString	TXAT
ibProcessName.7681	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7681	OctetString	DVP
ibProcessName.7682	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7682	OctetString	DDEV
ibProcessName.7683	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7683	OctetString	DTIM

Name	OID	Value Type	Value Example
ibProcessName.7685	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7685	OctetString	LinkMonPollThre
ibProcessName.7686	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7686	OctetString	LinkMonIsrThrea
ibProcessName.7687	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7687	OctetString	linkChgIsr
ibProcessName.7690	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7690	OctetString	DQIT
ibProcessName.7691	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7691	OctetString	STAT
ibProcessName.7692	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7692	OctetString	D_MI
ibProcessName.7693	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7693	OctetString	BUF_
ibProcessName.7694	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7694	OctetString	FMCK
ibProcessName.7695	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7695	OctetString	dAUR
ibProcessName.7696	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7696	OctetString	PSED
ibProcessName.7697	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7697	OctetString	T_DM
ibProcessName.7698	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7698	OctetString	mIPC
ibProcessName.7699	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7699	OctetString	TMCS
ibProcessName.7700	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7700	OctetString	TMCC
ibProcessName.7701	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7701	OctetString	DARP
ibProcessName.7702	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7702	OctetString	T_ST
ibProcessName.7703	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7703	OctetString	TMCN
ibProcessName.7704	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7704	OctetString	T_SI
ibProcessName.7705	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7705	OctetString	IPSG
ibProcessName.7706	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7706	OctetString	TARP
ibProcessName.7707	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7707	OctetString	TL3P
ibProcessName.7708	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7708	OctetString	MRFS
ibProcessName.7709	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7709	OctetString	IPMC
ibProcessName.7710	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7710	OctetString	Isr_Thread_0
ibProcessName.7711	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7711	OctetString	Isr_Thread_1
ibProcessName.7712	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7712	OctetString	Isr_Thread_2
ibProcessName.7713	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7713	OctetString	Isr_Thread_3
ibProcessName.7714	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7714	OctetString	Isr_L2NTFY_Thre
ibProcessName.7715	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7715	OctetString	SCAR
ibProcessName.7716	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7716	OctetString	TxQ/0
ibProcessName.7717	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7717	OctetString	TxQ/1
ibProcessName.7718	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7718	OctetString	TxQ/2
ibProcessName.7719	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7719	OctetString	TxQ/3
ibProcessName.7720	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7720	OctetString	TxQ/4
ibProcessName.7721	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7721	OctetString	TxQ/5
ibProcessName.7722	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7722	OctetString	TxQ/6
ibProcessName.7723	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7723	OctetString	TxQ/7
ibProcessName.7724	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7724	OctetString	TxF/7
ibProcessName.7725	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7725	OctetString	D_UN
ibProcessName.7726	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7726	OctetString	RSF0
ibProcessName.7727	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7727	OctetString	ICM1
ibProcessName.7728	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7728	OctetString	ICM2
ibProcessName.7729	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7729	OctetString	PMOT

Name	OID	Value Type	Value Example
ibProcessName.7771	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.7771	OctetString	lipc_topology
ibProcessName.8043	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.8043	OctetString	LOAD
ibProcessName.8044	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.8044	OctetString	LOADProc
ibProcessName.8045	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.8045	OctetString	kdlipc
ibProcessName.8046	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.8046	OctetString	krpc_event
ibProcessName.8047	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.8047	OctetString	krpc_serv
ibProcessName.8048	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.8048	OctetString	STM_Main
ibProcessName.8049	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.8049	OctetString	hellopkt
ibProcessName.8050	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.8050	OctetString	timesyncs
ibProcessName.8051	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.8051	OctetString	lipc_portevt
ibProcessName.8055	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.8055	OctetString	kevent
ibProcessName.8057	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.8057	OctetString	kifupdown
ibProcessName.8062	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.8062	OctetString	kifbufmon
ibProcessName.8067	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.8067	OctetString	kiftcb
ibProcessName.8116	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.8116	OctetString	DRVR
ibProcessName.8117	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.8117	OctetString	OPTK
ibProcessName.8118	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.8118	OctetString	kmac/1
ibProcessName.8120	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.8120	OctetString	kipfs/1
ibProcessName.8123	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.8123	OctetString	kip6fs/1
ibProcessName.8563	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.8563	OctetString	mbuf_main
ibProcessName.8565	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.8565	OctetString	sock/1
ibProcessName.9334	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9334	OctetString	ciocld
ibProcessName.9335	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9335	OctetString	fsd
ibProcessName.9338	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9338	OctetString	dbmd
ibProcessName.9341	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9341	OctetString	resmond
ibProcessName.9342	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9342	OctetString	diagd
ibProcessName.9343	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9343	OctetString	had
ibProcessName.9345	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9345	OctetString	syslogd
ibProcessName.9348	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9348	OctetString	devd
ibProcessName.9354	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9354	OctetString	ifmgr
ibProcessName.9355	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9355	OctetString	edev
ibProcessName.9482	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9482	OctetString	aaamngtd
ibProcessName.9484	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9484	OctetString	aprd
ibProcessName.9486	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9486	OctetString	comsh
ibProcessName.9487	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9487	OctetString	sysmand
ibProcessName.9488	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9488	OctetString	lauthd
ibProcessName.9489	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9489	OctetString	ttymgrd
ibProcessName.9490	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9490	OctetString	aaad
ibProcessName.9492	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9492	OctetString	cfad
ibProcessName.9493	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9493	OctetString	laggd
ibProcessName.9494	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9494	OctetString	tranged
ibProcessName.9495	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9495	OctetString	vland
ibProcessName.9497	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9497	OctetString	httpredrd

Name	OID	Value Type	Value Example
ibProcessName.9509	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9509	OctetString	aclmgrd
ibProcessName.9511	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9511	OctetString	taed
ibProcessName.9532	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9532	OctetString	qosd
ibProcessName.9540	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9540	OctetString	ethd
ibProcessName.9541	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9541	OctetString	coppd
ibProcessName.9561	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9561	OctetString	wsald
ibProcessName.9562	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9562	OctetString	xmlcfgd
ibProcessName.9571	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9571	OctetString	loop0
ibProcessName.9576	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9576	OctetString	loop1
ibProcessName.9581	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9581	OctetString	loop2
ibProcessName.9586	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9586	OctetString	loop3
ibProcessName.9592	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9592	OctetString	loop4
ibProcessName.9598	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9598	OctetString	loop5
ibProcessName.9603	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9603	OctetString	loop6
ibProcessName.9608	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9608	OctetString	loop7
ibProcessName.9613	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9613	OctetString	bioset
ibProcessName.9616	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9616	OctetString	loop8
ibProcessName.9637	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9637	OctetString	bioset
ibProcessName.9642	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9642	OctetString	loop9
ibProcessName.9659	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9659	OctetString	bioset
ibProcessName.9662	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9662	OctetString	loop10
ibProcessName.9689	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9689	OctetString	bioset
ibProcessName.9698	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9698	OctetString	loop11
ibProcessName.9718	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9718	OctetString	bioset
ibProcessName.9721	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9721	OctetString	loop12
ibProcessName.9744	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9744	OctetString	bioset
ibProcessName.9747	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9747	OctetString	loop13
ibProcessName.9770	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9770	OctetString	bioset
ibProcessName.9773	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9773	OctetString	loop14
ibProcessName.9789	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9789	OctetString	bioset
ibProcessName.9796	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9796	OctetString	loop15
ibProcessName.9822	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9822	OctetString	bioset
ibProcessName.9825	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9825	OctetString	loop16
ibProcessName.9848	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9848	OctetString	bioset
ibProcessName.9851	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9851	OctetString	loop17
ibProcessName.9862	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9862	OctetString	bioset
ibProcessName.9865	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9865	OctetString	loop18
ibProcessName.9889	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9889	OctetString	bioset
ibProcessName.9897	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9897	OctetString	loop19
ibProcessName.9922	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9922	OctetString	bioset
ibProcessName.9926	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9926	OctetString	loop20
ibProcessName.9938	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9938	OctetString	bioset
ibProcessName.9946	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9946	OctetString	loop21

Name	OID	Value Type	Value Example
ibProcessName.9978	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9978	OctetString	bioset
ibProcessName.9981	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.9981	OctetString	loop22
ibProcessName.10005	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10005	OctetString	bioset
ibProcessName.10008	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10008	OctetString	loop23
ibProcessName.10031	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10031	OctetString	bioset
ibProcessName.10034	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10034	OctetString	loop24
ibProcessName.10057	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10057	OctetString	bioset
ibProcessName.10060	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10060	OctetString	loop25
ibProcessName.10078	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10078	OctetString	bioset
ibProcessName.10085	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10085	OctetString	loop26
ibProcessName.10106	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10106	OctetString	bioset
ibProcessName.10112	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10112	OctetString	loop27
ibProcessName.10136	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10136	OctetString	bioset
ibProcessName.10139	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10139	OctetString	loop28
ibProcessName.10162	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10162	OctetString	bioset
ibProcessName.10165	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10165	OctetString	loop29
ibProcessName.10185	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10185	OctetString	bioset
ibProcessName.10191	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10191	OctetString	loop30
ibProcessName.10208	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10208	OctetString	bioset
ibProcessName.10210	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10210	OctetString	loop31
ibProcessName.10235	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10235	OctetString	bioset
ibProcessName.10238	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10238	OctetString	loop32
ibProcessName.10256	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10256	OctetString	bioset
ibProcessName.10259	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10259	OctetString	loop33
ibProcessName.10289	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10289	OctetString	bioset
ibProcessName.10296	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10296	OctetString	loop34
ibProcessName.10324	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10324	OctetString	bioset
ibProcessName.10327	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10327	OctetString	loop35
ibProcessName.10351	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10351	OctetString	bioset
ibProcessName.10357	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10357	OctetString	loop36
ibProcessName.10377	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10377	OctetString	bioset
ibProcessName.10380	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10380	OctetString	loop37
ibProcessName.10403	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10403	OctetString	bioset
ibProcessName.10406	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10406	OctetString	loop38
ibProcessName.10429	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10429	OctetString	bioset
ibProcessName.10432	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10432	OctetString	loop39
ibProcessName.10455	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10455	OctetString	bioset
ibProcessName.10458	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10458	OctetString	loop40
ibProcessName.10481	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10481	OctetString	bioset
ibProcessName.10484	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10484	OctetString	loop41
ibProcessName.10507	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10507	OctetString	bioset
ibProcessName.10510	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10510	OctetString	loop42
ibProcessName.10533	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10533	OctetString	bioset



Name	OID	Value Type	Value Example
ibProcessName.10536	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10536	OctetString	loop43
ibProcessName.10558	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10558	OctetString	bioset
ibProcessName.10562	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10562	OctetString	loop44
ibProcessName.10579	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10579	OctetString	bioset
ibProcessName.10581	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10581	OctetString	loop45
ibProcessName.10611	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10611	OctetString	bioset
ibProcessName.10614	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10614	OctetString	loop46
ibProcessName.10637	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10637	OctetString	bioset
ibProcessName.10640	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10640	OctetString	loop47
ibProcessName.10663	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10663	OctetString	bioset
ibProcessName.10666	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10666	OctetString	loop48
ibProcessName.10689	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10689	OctetString	bioset
ibProcessName.10692	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10692	OctetString	loop49
ibProcessName.10715	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10715	OctetString	bioset
ibProcessName.10718	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10718	OctetString	loop50
ibProcessName.10741	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10741	OctetString	bioset
ibProcessName.10744	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10744	OctetString	loop51
ibProcessName.10767	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10767	OctetString	bioset
ibProcessName.10770	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10770	OctetString	loop52
ibProcessName.10793	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10793	OctetString	bioset
ibProcessName.10796	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10796	OctetString	loop53
ibProcessName.10819	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10819	OctetString	bioset
ibProcessName.10822	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10822	OctetString	loop54
ibProcessName.10845	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10845	OctetString	bioset
ibProcessName.10848	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10848	OctetString	loop55
ibProcessName.10871	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10871	OctetString	bioset
ibProcessName.10874	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10874	OctetString	loop56
ibProcessName.10897	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10897	OctetString	bioset
ibProcessName.10900	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10900	OctetString	loop57
ibProcessName.10923	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10923	OctetString	bioset
ibProcessName.10926	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10926	OctetString	loop58
ibProcessName.10949	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10949	OctetString	bioset
ibProcessName.10952	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10952	OctetString	loop59
ibProcessName.10975	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10975	OctetString	bioset
ibProcessName.10978	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.10978	OctetString	loop60
ibProcessName.11001	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11001	OctetString	bioset
ibProcessName.11004	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11004	OctetString	loop61
ibProcessName.11027	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11027	OctetString	bioset
ibProcessName.11030	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11030	OctetString	loop62
ibProcessName.11053	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11053	OctetString	bioset
ibProcessName.11059	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11059	OctetString	loop63
ibProcessName.11079	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11079	OctetString	bioset
ibProcessName.11086	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11086	OctetString	loop64

Name	OID	Value Type	Value Example
ibProcessName.11105	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11105	OctetString	bioset
ibProcessName.11108	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11108	OctetString	loop65
ibProcessName.11133	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11133	OctetString	bioset
ibProcessName.11136	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11136	OctetString	loop66
ibProcessName.11153	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11153	OctetString	bioset
ibProcessName.11156	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11156	OctetString	loop67
ibProcessName.11176	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11176	OctetString	bioset
ibProcessName.11181	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11181	OctetString	loop68
ibProcessName.11214	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11214	OctetString	bioset
ibProcessName.11217	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11217	OctetString	loop69
ibProcessName.11236	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11236	OctetString	bioset
ibProcessName.11241	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11241	OctetString	loop70
ibProcessName.11266	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11266	OctetString	bioset
ibProcessName.11270	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11270	OctetString	loop71
ibProcessName.11286	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11286	OctetString	bioset
ibProcessName.11290	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11290	OctetString	loop72
ibProcessName.11313	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11313	OctetString	bioset
ibProcessName.11316	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11316	OctetString	loop73
ibProcessName.11339	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11339	OctetString	bioset
ibProcessName.11344	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11344	OctetString	loop74
ibProcessName.11364	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11364	OctetString	kworker/1:1H
ibProcessName.11578	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11578	OctetString	dhcpcd
ibProcessName.11579	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11579	OctetString	ipstackd
ibProcessName.11582	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11582	OctetString	karp/1
ibProcessName.11583	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11583	OctetString	kwadj/1
ibProcessName.11584	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11584	OctetString	kfib/1
ibProcessName.11593	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11593	OctetString	routed
ibProcessName.11597	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11597	OctetString	ipcmd
ibProcessName.11603	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11603	OctetString	staticrtd
ibProcessName.11604	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11604	OctetString	dhcpcpd
ibProcessName.11609	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11609	OctetString	dnsc
ibProcessName.11612	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11612	OctetString	KDNS/1
ibProcessName.11613	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11613	OctetString	mgroupd
ibProcessName.11617	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11617	OctetString	lldpd
ibProcessName.11622	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11622	OctetString	stpd
ibProcessName.11631	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11631	OctetString	dhcpcd
ibProcessName.11636	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11636	OctetString	poed
ibProcessName.11748	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11748	OctetString	snmpd
ibProcessName.11797	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11797	OctetString	sshd
ibProcessName.11801	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11801	OctetString	ntpd
ibProcessName.11806	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11806	OctetString	httpd
ibProcessName.11812	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11812	OctetString	cmtnlmgd
ibProcessName.11815	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11815	OctetString	cmdevmonitord



Name	OID	Value Type	Value Example
ibProcessName.11827	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.11827	OctetString	telnetd
ibProcessName.12039	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.12039	OctetString	getty
ibProcessName.12041	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.12041	OctetString	login
ibProcessName.12044	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.12044	OctetString	comshc
ibProcessName.12049	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.12049	OctetString	comsh
ibProcessName.15402	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.15402	OctetString	comsh
ibProcessName.15409	.1.3.6.1.4.1.26138.2.6.1.4.1.1.2.15409	OctetString	kworker/u8:0
ibProcessUtil5Min.1	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.1	Gauge	0
ibProcessUtil5Min.2	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.2	Gauge	0
ibProcessUtil5Min.3	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.3	Gauge	0
ibProcessUtil5Min.4	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.4	Gauge	0
ibProcessUtil5Min.5	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.5	Gauge	0
ibProcessUtil5Min.7	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7	Gauge	0
ibProcessUtil5Min.8	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.8	Gauge	0
ibProcessUtil5Min.9	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9	Gauge	0
ibProcessUtil5Min.10	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10	Gauge	0
ibProcessUtil5Min.11	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11	Gauge	0
ibProcessUtil5Min.12	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.12	Gauge	0
ibProcessUtil5Min.13	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.13	Gauge	0
ibProcessUtil5Min.14	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.14	Gauge	0
ibProcessUtil5Min.15	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.15	Gauge	0
ibProcessUtil5Min.16	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.16	Gauge	0
ibProcessUtil5Min.17	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.17	Gauge	0
ibProcessUtil5Min.18	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.18	Gauge	0
ibProcessUtil5Min.19	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.19	Gauge	0
ibProcessUtil5Min.20	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.20	Gauge	0
ibProcessUtil5Min.21	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.21	Gauge	0
ibProcessUtil5Min.22	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.22	Gauge	0
ibProcessUtil5Min.23	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.23	Gauge	0
ibProcessUtil5Min.45	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.45	Gauge	0
ibProcessUtil5Min.120	1.3.6.1.4.1.26138.2.6.1.4.1.1.3.120	Gauge	0
ibProcessUtil5Min.122	1.3.6.1.4.1.26138.2.6.1.4.1.1.3.122	Gauge	0
ibProcessUtil5Min.123	1.3.6.1.4.1.26138.2.6.1.4.1.1.3.123	Gauge	0
ibProcessUtil5Min.145	1.3.6.1.4.1.26138.2.6.1.4.1.1.3.145	Gauge	0
ibProcessUtil5Min.146	1.3.6.1.4.1.26138.2.6.1.4.1.1.3.146	Gauge	0
ibProcessUtil5Min.147	1.3.6.1.4.1.26138.2.6.1.4.1.1.3.147	Gauge	0
ibProcessUtil5Min.148	1.3.6.1.4.1.26138.2.6.1.4.1.1.3.148	Gauge	0
ibProcessUtil5Min.159	1.3.6.1.4.1.26138.2.6.1.4.1.1.3.159	Gauge	0
ibProcessUtil5Min.161	1.3.6.1.4.1.26138.2.6.1.4.1.1.3.161	Gauge	0
ibProcessUtil5Min.235	1.3.6.1.4.1.26138.2.6.1.4.1.1.3.235	Gauge	0
ibProcessUtil5Min.5818	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.5818	Gauge	0
ibProcessUtil5Min.5850	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.5850	Gauge	0
ibProcessUtil5Min.5879	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.5879	Gauge	0

Name	OID	Value Type	Value Example
ibProcessUtil5Min.5909	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.5909	Gauge	0
ibProcessUtil5Min.5934	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.5934	Gauge	0
ibProcessUtil5Min.5974	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.5974	Gauge	0
ibProcessUtil5Min.6006	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.6006	Gauge	0
ibProcessUtil5Min.6033	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.6033	Gauge	0
ibProcessUtil5Min.6066	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.6066	Gauge	0
ibProcessUtil5Min.6092	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.6092	Gauge	0
ibProcessUtil5Min.6109	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.6109	Gauge	0
ibProcessUtil5Min.6127	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.6127	Gauge	0
ibProcessUtil5Min.6150	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.6150	Gauge	0
ibProcessUtil5Min.6179	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.6179	Gauge	0
ibProcessUtil5Min.6204	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.6204	Gauge	0
ibProcessUtil5Min.6225	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.6225	Gauge	0
ibProcessUtil5Min.6529	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.6529	Gauge	0
ibProcessUtil5Min.6541	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.6541	Gauge	0
ibProcessUtil5Min.6565	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.6565	Gauge	0
ibProcessUtil5Min.6588	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.6588	Gauge	0
ibProcessUtil5Min.6604	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.6604	Gauge	0
ibProcessUtil5Min.6648	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.6648	Gauge	0
ibProcessUtil5Min.6676	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.6676	Gauge	0
ibProcessUtil5Min.6700	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.6700	Gauge	0
ibProcessUtil5Min.7402	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7402	Gauge	0
ibProcessUtil5Min.7424	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7424	Gauge	0
ibProcessUtil5Min.7449	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7449	Gauge	0
ibProcessUtil5Min.7459	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7459	Gauge	0
ibProcessUtil5Min.7467	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7467	Gauge	0
ibProcessUtil5Min.7468	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7468	Gauge	0
ibProcessUtil5Min.7558	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7558	Gauge	0
ibProcessUtil5Min.7563	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7563	Gauge	0
ibProcessUtil5Min.7642	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7642	Gauge	0
ibProcessUtil5Min.7671	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7671	Gauge	0
ibProcessUtil5Min.7672	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7672	Gauge	0
ibProcessUtil5Min.7673	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7673	Gauge	0
ibProcessUtil5Min.7674	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7674	Gauge	0
ibProcessUtil5Min.7675	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7675	Gauge	0
ibProcessUtil5Min.7676	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7676	Gauge	0
ibProcessUtil5Min.7677	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7677	Gauge	0
ibProcessUtil5Min.7678	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7678	Gauge	0
ibProcessUtil5Min.7679	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7679	Gauge	0
ibProcessUtil5Min.7680	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7680	Gauge	0
ibProcessUtil5Min.7681	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7681	Gauge	0
ibProcessUtil5Min.7682	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7682	Gauge	0
ibProcessUtil5Min.7683	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7683	Gauge	0

Name	OID	Value Type	Value Example
ibProcessUtil5Min.7685	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7685	Gauge	0
ibProcessUtil5Min.7686	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7686	Gauge	0
ibProcessUtil5Min.7687	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7687	Gauge	0
ibProcessUtil5Min.7690	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7690	Gauge	0
ibProcessUtil5Min.7691	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7691	Gauge	0
ibProcessUtil5Min.7692	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7692	Gauge	0
ibProcessUtil5Min.7693	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7693	Gauge	0
ibProcessUtil5Min.7694	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7694	Gauge	0
ibProcessUtil5Min.7695	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7695	Gauge	0
ibProcessUtil5Min.7696	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7696	Gauge	1
ibProcessUtil5Min.7697	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7697	Gauge	0
ibProcessUtil5Min.7698	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7698	Gauge	0
ibProcessUtil5Min.7699	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7699	Gauge	0
ibProcessUtil5Min.7700	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7700	Gauge	0
ibProcessUtil5Min.7701	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7701	Gauge	0
ibProcessUtil5Min.7702	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7702	Gauge	0
ibProcessUtil5Min.7703	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7703	Gauge	0
ibProcessUtil5Min.7704	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7704	Gauge	0
ibProcessUtil5Min.7705	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7705	Gauge	0
ibProcessUtil5Min.7706	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7706	Gauge	0
ibProcessUtil5Min.7707	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7707	Gauge	0
ibProcessUtil5Min.7708	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7708	Gauge	0
ibProcessUtil5Min.7709	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7709	Gauge	0
ibProcessUtil5Min.7710	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7710	Gauge	2
ibProcessUtil5Min.7711	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7711	Gauge	0
ibProcessUtil5Min.7712	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7712	Gauge	0
ibProcessUtil5Min.7713	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7713	Gauge	0
ibProcessUtil5Min.7714	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7714	Gauge	0
ibProcessUtil5Min.7715	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7715	Gauge	0
ibProcessUtil5Min.7716	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7716	Gauge	0
ibProcessUtil5Min.7717	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7717	Gauge	0
ibProcessUtil5Min.7718	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7718	Gauge	0
ibProcessUtil5Min.7719	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7719	Gauge	0
ibProcessUtil5Min.7720	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7720	Gauge	0
ibProcessUtil5Min.7721	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7721	Gauge	0
ibProcessUtil5Min.7722	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7722	Gauge	0
ibProcessUtil5Min.7723	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7723	Gauge	0
ibProcessUtil5Min.7724	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7724	Gauge	0
ibProcessUtil5Min.7725	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7725	Gauge	0
ibProcessUtil5Min.7726	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7726	Gauge	0
ibProcessUtil5Min.7727	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7727	Gauge	0
ibProcessUtil5Min.7728	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7728	Gauge	0
ibProcessUtil5Min.7729	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7729	Gauge	0

Name	OID	Value Type	Value Example
ibProcessUtil5Min.7771	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.7771	Gauge	0
ibProcessUtil5Min.8043	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.8043	Gauge	0
ibProcessUtil5Min.8044	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.8044	Gauge	0
ibProcessUtil5Min.8045	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.8045	Gauge	0
ibProcessUtil5Min.8046	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.8046	Gauge	0
ibProcessUtil5Min.8047	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.8047	Gauge	0
ibProcessUtil5Min.8048	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.8048	Gauge	0
ibProcessUtil5Min.8049	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.8049	Gauge	0
ibProcessUtil5Min.8050	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.8050	Gauge	0
ibProcessUtil5Min.8051	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.8051	Gauge	0
ibProcessUtil5Min.8055	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.8055	Gauge	0
ibProcessUtil5Min.8057	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.8057	Gauge	0
ibProcessUtil5Min.8062	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.8062	Gauge	0
ibProcessUtil5Min.8067	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.8067	Gauge	0
ibProcessUtil5Min.8116	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.8116	Gauge	0
ibProcessUtil5Min.8117	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.8117	Gauge	0
ibProcessUtil5Min.8118	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.8118	Gauge	0
ibProcessUtil5Min.8120	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.8120	Gauge	0
ibProcessUtil5Min.8123	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.8123	Gauge	0
ibProcessUtil5Min.8563	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.8563	Gauge	0
ibProcessUtil5Min.8565	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.8565	Gauge	0
ibProcessUtil5Min.9334	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9334	Gauge	0
ibProcessUtil5Min.9335	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9335	Gauge	0
ibProcessUtil5Min.9338	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9338	Gauge	0
ibProcessUtil5Min.9341	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9341	Gauge	0
ibProcessUtil5Min.9342	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9342	Gauge	1
ibProcessUtil5Min.9343	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9343	Gauge	0
ibProcessUtil5Min.9345	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9345	Gauge	0
ibProcessUtil5Min.9348	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9348	Gauge	0
ibProcessUtil5Min.9354	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9354	Gauge	0
ibProcessUtil5Min.9355	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9355	Gauge	0
ibProcessUtil5Min.9482	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9482	Gauge	0
ibProcessUtil5Min.9484	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9484	Gauge	0
ibProcessUtil5Min.9486	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9486	Gauge	0
ibProcessUtil5Min.9487	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9487	Gauge	0
ibProcessUtil5Min.9488	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9488	Gauge	0
ibProcessUtil5Min.9489	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9489	Gauge	0
ibProcessUtil5Min.9490	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9490	Gauge	0
ibProcessUtil5Min.9492	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9492	Gauge	0
ibProcessUtil5Min.9493	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9493	Gauge	0
ibProcessUtil5Min.9494	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9494	Gauge	0
ibProcessUtil5Min.9495	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9495	Gauge	0
ibProcessUtil5Min.9497	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9497	Gauge	0

Name	OID	Value Type	Value Example
ibProcessUtil5Min.9509	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9509	Gauge	0
ibProcessUtil5Min.9511	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9511	Gauge	0
ibProcessUtil5Min.9532	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9532	Gauge	0
ibProcessUtil5Min.9540	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9540	Gauge	0
ibProcessUtil5Min.9541	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9541	Gauge	0
ibProcessUtil5Min.9561	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9561	Gauge	0
ibProcessUtil5Min.9562	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9562	Gauge	0
ibProcessUtil5Min.9571	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9571	Gauge	0
ibProcessUtil5Min.9576	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9576	Gauge	0
ibProcessUtil5Min.9581	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9581	Gauge	0
ibProcessUtil5Min.9586	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9586	Gauge	0
ibProcessUtil5Min.9592	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9592	Gauge	0
ibProcessUtil5Min.9598	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9598	Gauge	0
ibProcessUtil5Min.9603	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9603	Gauge	0
ibProcessUtil5Min.9608	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9608	Gauge	0
ibProcessUtil5Min.9613	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9613	Gauge	0
ibProcessUtil5Min.9616	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9616	Gauge	0
ibProcessUtil5Min.9637	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9637	Gauge	0
ibProcessUtil5Min.9642	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9642	Gauge	0
ibProcessUtil5Min.9659	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9659	Gauge	0
ibProcessUtil5Min.9662	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9662	Gauge	0
ibProcessUtil5Min.9689	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9689	Gauge	0
ibProcessUtil5Min.9698	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9698	Gauge	0
ibProcessUtil5Min.9718	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9718	Gauge	0
ibProcessUtil5Min.9721	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9721	Gauge	0
ibProcessUtil5Min.9744	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9744	Gauge	0
ibProcessUtil5Min.9747	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9747	Gauge	0
ibProcessUtil5Min.9770	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9770	Gauge	0
ibProcessUtil5Min.9773	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9773	Gauge	0
ibProcessUtil5Min.9789	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9789	Gauge	0
ibProcessUtil5Min.9796	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9796	Gauge	0
ibProcessUtil5Min.9822	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9822	Gauge	0
ibProcessUtil5Min.9825	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9825	Gauge	0
ibProcessUtil5Min.9848	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9848	Gauge	0
ibProcessUtil5Min.9851	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9851	Gauge	0
ibProcessUtil5Min.9862	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9862	Gauge	0
ibProcessUtil5Min.9865	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9865	Gauge	0
ibProcessUtil5Min.9889	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9889	Gauge	0
ibProcessUtil5Min.9897	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9897	Gauge	0
ibProcessUtil5Min.9922	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9922	Gauge	0
ibProcessUtil5Min.9926	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9926	Gauge	0
ibProcessUtil5Min.9938	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9938	Gauge	0
ibProcessUtil5Min.9946	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9946	Gauge	0

Name	OID	Value Type	Value Example
ibProcessUtil5Min.9978	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9978	Gauge	0
ibProcessUtil5Min.9981	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.9981	Gauge	0
ibProcessUtil5Min.10005	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10005	Gauge	0
ibProcessUtil5Min.10008	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10008	Gauge	0
ibProcessUtil5Min.10031	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10031	Gauge	0
ibProcessUtil5Min.10034	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10034	Gauge	0
ibProcessUtil5Min.10057	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10057	Gauge	0
ibProcessUtil5Min.10060	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10060	Gauge	0
ibProcessUtil5Min.10078	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10078	Gauge	0
ibProcessUtil5Min.10085	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10085	Gauge	0
ibProcessUtil5Min.10106	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10106	Gauge	0
ibProcessUtil5Min.10112	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10112	Gauge	0
ibProcessUtil5Min.10136	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10136	Gauge	0
ibProcessUtil5Min.10139	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10139	Gauge	0
ibProcessUtil5Min.10162	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10162	Gauge	0
ibProcessUtil5Min.10165	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10165	Gauge	0
ibProcessUtil5Min.10185	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10185	Gauge	0
ibProcessUtil5Min.10191	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10191	Gauge	0
ibProcessUtil5Min.10208	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10208	Gauge	0
ibProcessUtil5Min.10210	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10210	Gauge	0
ibProcessUtil5Min.10235	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10235	Gauge	0
ibProcessUtil5Min.10238	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10238	Gauge	0
ibProcessUtil5Min.10256	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10256	Gauge	0
ibProcessUtil5Min.10259	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10259	Gauge	0
ibProcessUtil5Min.10289	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10289	Gauge	0
ibProcessUtil5Min.10296	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10296	Gauge	0
ibProcessUtil5Min.10324	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10324	Gauge	0
ibProcessUtil5Min.10327	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10327	Gauge	0
ibProcessUtil5Min.10351	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10351	Gauge	0
ibProcessUtil5Min.10357	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10357	Gauge	0
ibProcessUtil5Min.10377	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10377	Gauge	0
ibProcessUtil5Min.10380	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10380	Gauge	0
ibProcessUtil5Min.10403	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10403	Gauge	0
ibProcessUtil5Min.10406	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10406	Gauge	0
ibProcessUtil5Min.10429	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10429	Gauge	0
ibProcessUtil5Min.10432	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10432	Gauge	0
ibProcessUtil5Min.10455	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10455	Gauge	0
ibProcessUtil5Min.10458	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10458	Gauge	0
ibProcessUtil5Min.10481	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10481	Gauge	0
ibProcessUtil5Min.10484	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10484	Gauge	0
ibProcessUtil5Min.10507	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10507	Gauge	0
ibProcessUtil5Min.10510	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10510	Gauge	0
ibProcessUtil5Min.10533	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10533	Gauge	0

Name	OID	Value Type	Value Example
ibProcessUtil5Min.10536	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10536	Gauge	0
ibProcessUtil5Min.10558	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10558	Gauge	0
ibProcessUtil5Min.10562	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10562	Gauge	0
ibProcessUtil5Min.10579	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10579	Gauge	0
ibProcessUtil5Min.10581	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10581	Gauge	0
ibProcessUtil5Min.10611	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10611	Gauge	0
ibProcessUtil5Min.10614	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10614	Gauge	0
ibProcessUtil5Min.10637	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10637	Gauge	0
ibProcessUtil5Min.10640	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10640	Gauge	0
ibProcessUtil5Min.10663	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10663	Gauge	0
ibProcessUtil5Min.10666	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10666	Gauge	0
ibProcessUtil5Min.10689	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10689	Gauge	0
ibProcessUtil5Min.10692	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10692	Gauge	0
ibProcessUtil5Min.10715	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10715	Gauge	0
ibProcessUtil5Min.10718	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10718	Gauge	0
ibProcessUtil5Min.10741	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10741	Gauge	0
ibProcessUtil5Min.10744	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10744	Gauge	0
ibProcessUtil5Min.10767	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10767	Gauge	0
ibProcessUtil5Min.10770	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10770	Gauge	0
ibProcessUtil5Min.10793	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10793	Gauge	0
ibProcessUtil5Min.10796	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10796	Gauge	0
ibProcessUtil5Min.10819	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10819	Gauge	0
ibProcessUtil5Min.10822	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10822	Gauge	0
ibProcessUtil5Min.10845	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10845	Gauge	0
ibProcessUtil5Min.10848	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10848	Gauge	0
ibProcessUtil5Min.10871	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10871	Gauge	0
ibProcessUtil5Min.10874	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10874	Gauge	0
ibProcessUtil5Min.10897	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10897	Gauge	0
ibProcessUtil5Min.10900	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10900	Gauge	0
ibProcessUtil5Min.10923	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10923	Gauge	0
ibProcessUtil5Min.10926	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10926	Gauge	0
ibProcessUtil5Min.10949	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10949	Gauge	0
ibProcessUtil5Min.10952	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10952	Gauge	0
ibProcessUtil5Min.10975	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10975	Gauge	0
ibProcessUtil5Min.10978	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.10978	Gauge	0
ibProcessUtil5Min.11001	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11001	Gauge	0
ibProcessUtil5Min.11004	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11004	Gauge	0
ibProcessUtil5Min.11027	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11027	Gauge	0
ibProcessUtil5Min.11030	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11030	Gauge	0
ibProcessUtil5Min.11053	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11053	Gauge	0
ibProcessUtil5Min.11059	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11059	Gauge	0
ibProcessUtil5Min.11079	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11079	Gauge	0
ibProcessUtil5Min.11086	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11086	Gauge	0



Name	OID	Value Type	Value Example
ibProcessUtil5Min.11105	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11105	Gauge	0
ibProcessUtil5Min.11108	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11108	Gauge	0
ibProcessUtil5Min.11133	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11133	Gauge	0
ibProcessUtil5Min.11136	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11136	Gauge	0
ibProcessUtil5Min.11153	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11153	Gauge	0
ibProcessUtil5Min.11156	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11156	Gauge	0
ibProcessUtil5Min.11176	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11176	Gauge	0
ibProcessUtil5Min.11181	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11181	Gauge	0
ibProcessUtil5Min.11214	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11214	Gauge	0
ibProcessUtil5Min.11217	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11217	Gauge	0
ibProcessUtil5Min.11236	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11236	Gauge	0
ibProcessUtil5Min.11241	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11241	Gauge	0
ibProcessUtil5Min.11266	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11266	Gauge	0
ibProcessUtil5Min.11270	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11270	Gauge	0
ibProcessUtil5Min.11286	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11286	Gauge	0
ibProcessUtil5Min.11290	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11290	Gauge	0
ibProcessUtil5Min.11313	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11313	Gauge	0
ibProcessUtil5Min.11316	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11316	Gauge	0
ibProcessUtil5Min.11339	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11339	Gauge	0
ibProcessUtil5Min.11344	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11344	Gauge	0
ibProcessUtil5Min.11364	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11364	Gauge	0
ibProcessUtil5Min.11578	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11578	Gauge	0
ibProcessUtil5Min.11579	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11579	Gauge	0
ibProcessUtil5Min.11582	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11582	Gauge	0
ibProcessUtil5Min.11583	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11583	Gauge	0
ibProcessUtil5Min.11584	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11584	Gauge	0
ibProcessUtil5Min.11593	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11593	Gauge	0
ibProcessUtil5Min.11597	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11597	Gauge	0
ibProcessUtil5Min.11603	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11603	Gauge	0
ibProcessUtil5Min.11604	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11604	Gauge	0
ibProcessUtil5Min.11609	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11609	Gauge	0
ibProcessUtil5Min.11612	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11612	Gauge	0
ibProcessUtil5Min.11613	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11613	Gauge	0
ibProcessUtil5Min.11617	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11617	Gauge	0
ibProcessUtil5Min.11622	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11622	Gauge	0
ibProcessUtil5Min.11631	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11631	Gauge	0
ibProcessUtil5Min.11636	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11636	Gauge	0
ibProcessUtil5Min.11748	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11748	Gauge	3
ibProcessUtil5Min.11797	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11797	Gauge	0
ibProcessUtil5Min.11801	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11801	Gauge	0
ibProcessUtil5Min.11806	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11806	Gauge	0
ibProcessUtil5Min.11812	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11812	Gauge	0
ibProcessUtil5Min.11815	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11815	Gauge	0



Name	OID	Value Type	Value Example
ibProcessUtil5Min.11827	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.11827	Gauge	0
ibProcessUtil5Min.12039	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.12039	Gauge	0
ibProcessUtil5Min.12041	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.12041	Gauge	0
ibProcessUtil5Min.12044	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.12044	Gauge	0
ibProcessUtil5Min.12049	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.12049	Gauge	0
ibProcessUtil5Min.15402	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.15402	Gauge	0
ibProcessUtil5Min.15409	.1.3.6.1.4.1.26138.2.6.1.4.1.1.3.15409	Gauge	0
ibAcLMib2ObjectsCapabilities.0	.1.3.6.1.4.1.26138.2.8.2.1.1.3.0	OctetString	{ibAcLMib2ObjectsCapabilities, ibAcLMib2CapabilityTable, ibAcLMib2NumberGroupTable, ibAcLMib2PAclBasicTable, ibAcLMib2PAclAdvancedTable, ibAcLMib2MACTable, ibAcLMib2ProcessingStatus}
ibAcLMib2ProcessingStatus.0	.1.3.6.1.4.1.26138.2.8.2.1.1.4.0	Integer	done (2)
ibAcLMib2ResourceThreshold.0	.1.3.6.1.4.1.26138.2.8.2.1.1.5.0	Integer	0
ibAcLMib2ResourceLogInterval.0	.1.3.6.1.4.1.26138.2.8.2.1.1.6.0	Integer	5
ibAcLMib2Characteristics-Desc.1.0.3.2	.1.3.6.1.4.1.26138.2.8.2.1.2.1.5.1.0.3.2	OctetString	
ibAcLMib2Characteristics-Desc.1.0.3.4	.1.3.6.1.4.1.26138.2.8.2.1.2.1.5.1.0.3.4	OctetString	
ibAcLMib2Characteristics-Desc.1.0.3.5	.1.3.6.1.4.1.26138.2.8.2.1.2.1.5.1.0.3.5	OctetString	
ibAcLMib2Characteristics-Desc.1.0.3.6	.1.3.6.1.4.1.26138.2.8.2.1.2.1.5.1.0.3.6	OctetString	
ibAcLMib2CharacteristicsValue.1.0.3.2	.1.3.6.1.4.1.26138.2.8.2.1.2.1.6.1.0.3.2	Gauge	0
ibAcLMib2CharacteristicsValue.1.0.3.4	.1.3.6.1.4.1.26138.2.8.2.1.2.1.6.1.0.3.4	Gauge	0
ibAcLMib2CharacteristicsValue.1.0.3.5	.1.3.6.1.4.1.26138.2.8.2.1.2.1.6.1.0.3.5	Gauge	0
ibAcLMib2CharacteristicsValue.1.0.3.6	.1.3.6.1.4.1.26138.2.8.2.1.2.1.6.1.0.3.6	Gauge	0
ibAcLMib2PortRange.0.1.0.1	.1.3.6.1.4.1.26138.2.8.2.5.1.1.5.0.1.0.1	OctetString	GigabitEthernet1/0/1 to GigabitEthernet1/0/48, Ten-GigabitEthernet1/0/49 to Ten-GigabitEthernet1/0/54
ibAcLMib2PortRange.0.1.0.2	.1.3.6.1.4.1.26138.2.8.2.5.1.1.5.0.1.0.2	OctetString	GigabitEthernet1/0/1 to GigabitEthernet1/0/48, Ten-GigabitEthernet1/0/49 to Ten-GigabitEthernet1/0/54
ibAcLMib2PortRange.0.1.0.3	.1.3.6.1.4.1.26138.2.8.2.5.1.1.5.0.1.0.3	OctetString	GigabitEthernet1/0/1 to GigabitEthernet1/0/48, Ten-GigabitEthernet1/0/49 to Ten-GigabitEthernet1/0/54
ibAcLMib2PortRange.0.1.0.4	.1.3.6.1.4.1.26138.2.8.2.5.1.1.5.0.1.0.4	OctetString	GigabitEthernet1/0/1 to GigabitEthernet1/0/48, Ten-GigabitEthernet1/0/49 to Ten-GigabitEthernet1/0/54
ibAcLMib2ResourceTotal.0.1.0.1	.1.3.6.1.4.1.26138.2.8.2.5.1.1.6.0.1.0.1	Gauge	512
ibAcLMib2ResourceTotal.0.1.0.2	.1.3.6.1.4.1.26138.2.8.2.5.1.1.6.0.1.0.2	Gauge	1280

Name	OID	Value Type	Value Example
ibAclResourceTotal.0.1.0.3	.1.3.6.1.4.1.26138.2.8.2.5.1.1.6.0.1.0.3	Gauge	512
ibAclResourceTotal.0.1.0.4	.1.3.6.1.4.1.26138.2.8.2.5.1.1.6.0.1.0.4	Gauge	512
ibAclResourceReserved.0.1.0.1.1	.1.3.6.1.4.1.26138.2.8.2.5.1.1.7.0.1.0.1	Gauge	0
ibAclResourceReserved.0.1.0.2.1	.1.3.6.1.4.1.26138.2.8.2.5.1.1.7.0.1.0.2	Gauge	128
ibAclResourceReserved.0.1.0.3.1	.1.3.6.1.4.1.26138.2.8.2.5.1.1.7.0.1.0.3	Gauge	64
ibAclResourceReserved.0.1.0.4.1	.1.3.6.1.4.1.26138.2.8.2.5.1.1.7.0.1.0.4	Gauge	0
ibAclResourceConfigured.0.1.0.1	.1.3.6.1.4.1.26138.2.8.2.5.1.1.8.0.1.0.1	Gauge	1
ibAclResourceConfigured.0.1.0.2	.1.3.6.1.4.1.26138.2.8.2.5.1.1.8.0.1.0.2	Gauge	9
ibAclResourceConfigured.0.1.0.3	.1.3.6.1.4.1.26138.2.8.2.5.1.1.8.0.1.0.3	Gauge	0
ibAclResourceConfigured.0.1.0.4	.1.3.6.1.4.1.26138.2.8.2.5.1.1.8.0.1.0.4	Gauge	26
ibAclResourceUsagePercent.0.1.0.1	.1.3.6.1.4.1.26138.2.8.2.5.1.1.9.0.1.0.1	Gauge	0
ibAclResourceUsagePercent.0.1.0.2	.1.3.6.1.4.1.26138.2.8.2.5.1.1.9.0.1.0.2	Gauge	10
ibAclResourceUsagePercent.0.1.0.3	.1.3.6.1.4.1.26138.2.8.2.5.1.1.9.0.1.0.3	Gauge	12
ibAclResourceUsagePercent.0.1.0.4	.1.3.6.1.4.1.26138.2.8.2.5.1.1.9.0.1.0.4	Gauge	5
ibAclResourceTypeDescription.0.1.0.1	.1.3.6.1.4.1.26138.2.8.2.5.1.1.10.0.1.0.1	OctetString	VACL
ibAclResourceTypeDescription.0.1.0.2	.1.3.6.1.4.1.26138.2.8.2.5.1.1.10.0.1.0.2	OctetString	IACL
ibAclResourceTypeDescription.0.1.0.3	.1.3.6.1.4.1.26138.2.8.2.5.1.1.10.0.1.0.3	OctetString	EACL
ibAclResourceTypeDescription.0.1.0.4	.1.3.6.1.4.1.26138.2.8.2.5.1.1.10.0.1.0.4	OctetString	ACL Meter
ibPfilterDefaultAction.0	.1.3.6.1.4.1.26138.2.8.3.1.1.0	Integer	permit (1)
ibPfilterProcessingStatus.0	.1.3.6.1.4.1.26138.2.8.3.1.2.0	Integer	done (2)
ibVoiceVlanOuiAddress.0.1.227.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.1.0.1.227.0.0.0	OctetString	00-01-E3-00-00-00
ibVoiceVlanOuiAddress.0.3.107.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.1.0.3.107.0.0.0	OctetString	00-03-6B-00-00-00
ibVoiceVlanOuiAddress.0.4.13.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.1.0.4.13.0.0.0	OctetString	00-04-0D-00-00-00
ibVoiceVlanOuiAddress.0.15.226.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.1.0.15.226.0.0.0	OctetString	00-0F-E2-00-00-00
ibVoiceVlanOuiAddress.0.96.185.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.1.0.96.185.0.0.0	OctetString	00-60-B9-00-00-00
ibVoiceVlanOuiAddress.0.208.30.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.1.0.208.30.0.0.0	OctetString	00-D0-1E-00-00-00
ibVoiceVlanOuiAddress.0.224.117.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.1.0.224.117.0.0.0	OctetString	00-E0-75-00-00-00
ibVoiceVlanOuiAddress.0.224.187.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.1.0.224.187.0.0.0	OctetString	00-E0-BB-00-00-00

Name	OID	Value Type	Value Example
ibVoiceVlanOui-Mask.0.1.227.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.2.0.1.227.0.0	OctetString	FF-FF-FF-00-00-00
ibVoiceVlanOui-Mask.0.3.107.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.2.0.3.107.0.0	OctetString	FF-FF-FF-00-00-00
ibVoiceVlanOui-Mask.0.4.13.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.2.0.4.13.0.0	OctetString	FF-FF-FF-00-00-00
ibVoiceVlanOui-Mask.0.15.226.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.2.0.15.226.0.0	OctetString	FF-FF-FF-00-00-00
ibVoiceVlanOui-Mask.0.96.185.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.2.0.96.185.0.0	OctetString	FF-FF-FF-00-00-00
ibVoiceVlanOui-Mask.0.208.30.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.2.0.208.30.0.0	OctetString	FF-FF-FF-00-00-00
ibVoiceVlanOui-Mask.0.224.117.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.2.0.224.117.0.0	OctetString	FF-FF-FF-00-00-00
ibVoiceVlanOui-Mask.0.224.187.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.2.0.224.187.0.0	OctetString	FF-FF-FF-00-00-00
ibVoiceVlanOuiDescription.0.1.227.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.3.0.1.227.0.0	OctetString	Siemens phone
ibVoiceVlanOuiDescription.0.3.107.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.3.0.3.107.0.0	OctetString	Cisco phone
ibVoiceVlanOuiDescription.0.4.13.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.3.0.4.13.0.0	OctetString	Avaya phone
ibVoiceVlanOuiDescription.0.15.226.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.3.0.15.226.0.0	OctetString	H3C Aolynk phone
ibVoiceVlanOuiDescription.0.96.185.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.3.0.96.185.0.0	OctetString	Philips/NEC phone
ibVoiceVlanOuiDescription.0.208.30.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.3.0.208.30.0.0	OctetString	Pingtel phone
ibVoiceVlanOuiDescription.0.224.117.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.3.0.224.117.0.0	OctetString	Polycom phone
ibVoiceVlanOuiDescription.0.224.187.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.3.0.224.187.0.0	OctetString	3Com phone
ibVoiceVlanOuiRowStatus.0.1.227.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.4.0.1.227.0.0	Integer	active (1)
ibVoiceVlanOuiRowStatus.0.3.107.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.4.0.3.107.0.0	Integer	active (1)
ibVoiceVlanOuiRowStatus.0.4.13.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.4.0.4.13.0.0	Integer	active (1)
ibVoiceVlanOuiRowStatus.0.15.226.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.4.0.15.226.0.0	Integer	active (1)
ibVoiceVlanOuiRowStatus.0.96.185.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.4.0.96.185.0.0	Integer	active (1)
ibVoiceVlanOuiRowStatus.0.208.30.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.4.0.208.30.0.0	Integer	active (1)
ibVoiceVlanOuiRowStatus.0.224.117.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.4.0.224.117.0.0	Integer	active (1)
ibVoiceVlanOuiRowStatus.0.224.187.0.0.0	.1.3.6.1.4.1.26138.2.9.1.1.4.0.224.187.0.0	Integer	active (1)
ibVoiceVlanAgingTime.0	.1.3.6.1.4.1.26138.2.9.4.0	Integer	1440
ibVoiceVlanSecurityState.0	.1.3.6.1.4.1.26138.2.9.6.0	Integer	security (1)

Name	OID	Value Type	Value Example
ibUserMaxNum.0	.1.3.6.1.4.1.26138.2.12.1.3.0	Integer	1024
ibUserCurrNum.0	.1.3.6.1.4.1.26138.2.12.1.4.0	Integer	0
ibUserIndexIndicator.0	.1.3.6.1.4.1.26138.2.12.1.5.0	Integer	1
ibUserGroupInfoRowStatus.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.12.2.1.1.2.6.115.121.115.116.101.109	Integer	active (1)
ibRdPrimUdpPort.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.1.1.1.3.6.115.121.115.116.101.109	Integer	1812
ibRdPrimState.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.1.1.1.4.6.115.121.115.116.101.109	Integer	block (2)
ibRdSecUdpPort.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.1.1.1.5.6.115.121.115.116.101.109	Integer	1812
ibRdSecState.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.1.1.1.6.7.6.115.121.115.116.101.109	Integer	block (2)
ibRd-Key.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.1.1.1.8.6.115.121.115.116.101.109	Octet String	
ibRdRe-try.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.1.1.1.9.6.115.121.115.116.101.109	Integer	3
ibRdTime-out.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.1.1.1.10.6.115.121.115.116.101.109	Integer	3
ibRdPrimAuthIpAddrType.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.6.101.109.6.115.121.115.116.101.109	Integer	ipv4 (1)
ibRdPrimAuthIpAddr.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.6.101.109.12.6.115.121.115.116.101.109	Octet String	0.0.0.0
ibRdSecAuthIpAddrType.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.6.101.109.6.115.121.115.116.101.109	Integer	ipv4 (1)
ibRdSecAuthIpAddr.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.6.101.109.14.6.115.121.115.116.101.109	Octet String	0.0.0.0
ibRdQuietTime.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.1.1.1.16.6.115.121.115.116.101.109	Integer	5
ibRdUserNameFormat.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.01109.7.6.115.121.115.116.101.109	Integer	withoutdomain (1)
ibRdRowStatus.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.1.1.1.18.6.115.121.115.116.101.109	Integer	active (1)
ibRdSec-Key.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.1.1.1.19.6.115.121.115.116.101.109	Octet String	
ibRdPrimVpnName.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.109.1.20.6.115.121.115.116.101.109	Octet String	
ibRdSecVpnName.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.109.1.21.6.115.121.115.116.101.109	Octet String	
ibRdAuthNasIpAddr.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.109.23.6.115.121.115.116.101.109	IpAddress	0.0.0.0
ibRdAuthNasIpv6Addr.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.109.24.6.115.121.115.116.101.109	Octet String	0x00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
ibRdPrimAccIpAddrType.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.16.102.109.6.115.121.115.116.101.109	Integer	ipv4 (1)
ibRdPrimAccIpAddr.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.16.102.109.13.6.115.121.115.116.101.109	Octet String	0.0.0.0
ibRdPrimAccUdpPort.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.16.103.109.4.6.115.121.115.116.101.109	Integer	1813
ibRdPrimAccState.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.16.103.109.2.1.5.6.115.121.115.116.101.109	Integer	block (2)
ibRdSecAccIpAddrType.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.16.3012109.6.115.121.115.116.101.109	Integer	ipv4 (1)
ibRdSecAccIpAddr.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.16.3012109.2.1.7.6.115.121.115.116.101.109	Octet String	0.0.0.0
ibRdSecAccUdpPort.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.16.3012109.1.8.6.115.121.115.116.101.109	Integer	1813
ibRdSecAccState.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.16.3012109.1.2.1.9.6.115.121.115.116.101.109	Integer	block (2)
ibRdAcc-Key.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.1.2.1.10.6.115.121.115.116.101.109	Octet String	
ibRdAccRe-try.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.1.2.1.11.6.115.121.115.116.101.109	Integer	3
ibRdAccTime-out.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.1.2.1.12.6.115.121.115.116.101.109	Integer	3
ibRdAccQuietTime.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.09.1.14.6.115.121.115.116.101.109	Integer	5
ibRdAccRealTime.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.13.09.2.1.16.6.115.121.115.116.101.109	Integer	12

Name	OID	Value Type	Value Example
ibRdAccRealTimeRe-try.1.3.6.1.4.1.26138.2.13.1.2.1.17.6.115.121.115.116.101.109	1.3.6.1.4.1.26138.2.13.1.2.1.17.6.115.121.115.116.101.109	Integer109	5
ibRdAccDataFlowUnit.1.3.6.1.4.1.26138.2.13.1.2.1.20.6.115.121.115.116.101.109	1.3.6.1.4.1.26138.2.13.1.2.1.20.6.115.121.115.116.101.109	Integer109	byte (1)
ibRdAccPacketUnit.1.3.6.1.4.1.26138.2.13.1.2.1.21.6.115.121.115.116.101.109	1.3.6.1.4.1.26138.2.13.1.2.1.21.6.115.121.115.116.101.109	Integer109	onePacket (1)
ibRdAccRowStatus.1.3.6.1.4.1.26138.2.13.1.2.1.22.6.115.121.115.116.101.109	1.3.6.1.4.1.26138.2.13.1.2.1.22.6.115.121.115.116.101.109	Integer109	active (1)
ibRdAcctOnEnable.1.3.6.1.4.1.26138.2.13.1.2.1.23.6.115.121.115.116.101.109	1.3.6.1.4.1.26138.2.13.1.2.1.23.6.115.121.115.116.101.109	Integer109	false (2)
ibRdAcctOnSendTimes.1.3.6.1.4.1.26138.2.13.1.2.1.24.6.115.121.115.116.101.109	1.3.6.1.4.1.26138.2.13.1.2.1.24.6.115.121.115.116.101.109	Integer109	50
ibRdAcctOnSendInterval.1.3.6.1.4.1.26138.2.13.1.2.1.25.6.115.121.115.116.101.109	1.3.6.1.4.1.26138.2.13.1.2.1.25.6.115.121.115.116.101.109	Integer109	3
ibRdSecAccKey.1.3.6.1.4.1.26138.2.13.1.2.1.26.6.115.121.115.116.101.109	1.3.6.1.4.1.26138.2.13.1.2.1.26.6.115.121.115.116.101.109	OctetString	
ibRdPrimAccVpnName.1.3.6.1.4.1.26138.2.13.1.2.1.27.6.115.121.115.116.101.109	1.3.6.1.4.1.26138.2.13.1.2.1.27.6.115.121.115.116.101.109	OctetString	
ibRdSecAccVpnName.1.3.6.1.4.1.26138.2.13.1.2.1.28.6.115.121.115.116.101.109	1.3.6.1.4.1.26138.2.13.1.2.1.28.6.115.121.115.116.101.109	OctetString	
ibRdAccNasIpAddr.1.3.6.1.4.1.26138.2.13.1.2.1.29.6.115.121.115.116.101.109	1.3.6.1.4.1.26138.2.13.1.2.1.29.6.115.121.115.116.101.109	IpAddress	0.0.0.0
ibRdAccNasIpv6Addr.1.3.6.1.4.1.26138.2.13.1.2.1.30.6.115.121.115.116.101.109	1.3.6.1.4.1.26138.2.13.1.2.1.30.6.115.121.115.116.101.109	OctetString	0x00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
ibRdAccRealTimeUnit.1.3.6.1.4.1.26138.2.13.1.2.1.32.6.115.121.115.116.101.109	1.3.6.1.4.1.26138.2.13.1.2.1.32.6.115.121.115.116.101.109	Integer109	minute (0)
ibRadiusAuthErrThreshold.0	1.3.6.1.4.1.26138.2.13.1.3.1.0	Gauge	30
ibPsePortFaultDescription.4.1	1.3.6.1.4.1.26138.2.14.1.1.2.4.1	OctetString	
ibPsePortFaultDescription.4.2	1.3.6.1.4.1.26138.2.14.1.1.2.4.2	OctetString	
ibPsePortFaultDescription.4.3	1.3.6.1.4.1.26138.2.14.1.1.2.4.3	OctetString	
ibPsePortFaultDescription.4.4	1.3.6.1.4.1.26138.2.14.1.1.2.4.4	OctetString	
ibPsePortFaultDescription.4.5	1.3.6.1.4.1.26138.2.14.1.1.2.4.5	OctetString	
ibPsePortFaultDescription.4.6	1.3.6.1.4.1.26138.2.14.1.1.2.4.6	OctetString	
ibPsePortFaultDescription.4.7	1.3.6.1.4.1.26138.2.14.1.1.2.4.7	OctetString	
ibPsePortFaultDescription.4.8	1.3.6.1.4.1.26138.2.14.1.1.2.4.8	OctetString	
ibPsePortFaultDescription.4.9	1.3.6.1.4.1.26138.2.14.1.1.2.4.9	OctetString	
ibPsePortFaultDescription.4.10	1.3.6.1.4.1.26138.2.14.1.1.2.4.10	OctetString	
ibPsePortFaultDescription.4.11	1.3.6.1.4.1.26138.2.14.1.1.2.4.11	OctetString	
ibPsePortFaultDescription.4.12	1.3.6.1.4.1.26138.2.14.1.1.2.4.12	OctetString	
ibPsePortFaultDescription.4.13	1.3.6.1.4.1.26138.2.14.1.1.2.4.13	OctetString	
ibPsePortFaultDescription.4.14	1.3.6.1.4.1.26138.2.14.1.1.2.4.14	OctetString	
ibPsePortFaultDescription.4.15	1.3.6.1.4.1.26138.2.14.1.1.2.4.15	OctetString	
ibPsePortFaultDescription.4.16	1.3.6.1.4.1.26138.2.14.1.1.2.4.16	OctetString	
ibPsePortFaultDescription.4.17	1.3.6.1.4.1.26138.2.14.1.1.2.4.17	OctetString	
ibPsePortFaultDescription.4.18	1.3.6.1.4.1.26138.2.14.1.1.2.4.18	OctetString	
ibPsePortFaultDescription.4.19	1.3.6.1.4.1.26138.2.14.1.1.2.4.19	OctetString	
ibPsePortFaultDescription.4.20	1.3.6.1.4.1.26138.2.14.1.1.2.4.20	OctetString	
ibPsePortFaultDescription.4.21	1.3.6.1.4.1.26138.2.14.1.1.2.4.21	OctetString	
ibPsePortFaultDescription.4.22	1.3.6.1.4.1.26138.2.14.1.1.2.4.22	OctetString	
ibPsePortFaultDescription.4.23	1.3.6.1.4.1.26138.2.14.1.1.2.4.23	OctetString	

Name	OID	Value Type	Value Example
ibPsePortFaultDescription.4.24	.1.3.6.1.4.1.26138.2.14.1.1.2.4.24	OctetString	
ibPsePortFaultDescription.4.25	.1.3.6.1.4.1.26138.2.14.1.1.2.4.25	OctetString	
ibPsePortFaultDescription.4.26	.1.3.6.1.4.1.26138.2.14.1.1.2.4.26	OctetString	
ibPsePortFaultDescription.4.27	.1.3.6.1.4.1.26138.2.14.1.1.2.4.27	OctetString	
ibPsePortFaultDescription.4.28	.1.3.6.1.4.1.26138.2.14.1.1.2.4.28	OctetString	
ibPsePortFaultDescription.4.29	.1.3.6.1.4.1.26138.2.14.1.1.2.4.29	OctetString	
ibPsePortFaultDescription.4.30	.1.3.6.1.4.1.26138.2.14.1.1.2.4.30	OctetString	
ibPsePortFaultDescription.4.31	.1.3.6.1.4.1.26138.2.14.1.1.2.4.31	OctetString	
ibPsePortFaultDescription.4.32	.1.3.6.1.4.1.26138.2.14.1.1.2.4.32	OctetString	
ibPsePortFaultDescription.4.33	.1.3.6.1.4.1.26138.2.14.1.1.2.4.33	OctetString	
ibPsePortFaultDescription.4.34	.1.3.6.1.4.1.26138.2.14.1.1.2.4.34	OctetString	
ibPsePortFaultDescription.4.35	.1.3.6.1.4.1.26138.2.14.1.1.2.4.35	OctetString	
ibPsePortFaultDescription.4.36	.1.3.6.1.4.1.26138.2.14.1.1.2.4.36	OctetString	
ibPsePortFaultDescription.4.37	.1.3.6.1.4.1.26138.2.14.1.1.2.4.37	OctetString	
ibPsePortFaultDescription.4.38	.1.3.6.1.4.1.26138.2.14.1.1.2.4.38	OctetString	
ibPsePortFaultDescription.4.39	.1.3.6.1.4.1.26138.2.14.1.1.2.4.39	OctetString	
ibPsePortFaultDescription.4.40	.1.3.6.1.4.1.26138.2.14.1.1.2.4.40	OctetString	
ibPsePortFaultDescription.4.41	.1.3.6.1.4.1.26138.2.14.1.1.2.4.41	OctetString	
ibPsePortFaultDescription.4.42	.1.3.6.1.4.1.26138.2.14.1.1.2.4.42	OctetString	
ibPsePortFaultDescription.4.43	.1.3.6.1.4.1.26138.2.14.1.1.2.4.43	OctetString	
ibPsePortFaultDescription.4.44	.1.3.6.1.4.1.26138.2.14.1.1.2.4.44	OctetString	
ibPsePortFaultDescription.4.45	.1.3.6.1.4.1.26138.2.14.1.1.2.4.45	OctetString	
ibPsePortFaultDescription.4.46	.1.3.6.1.4.1.26138.2.14.1.1.2.4.46	OctetString	
ibPsePortFaultDescription.4.47	.1.3.6.1.4.1.26138.2.14.1.1.2.4.47	OctetString	
ibPsePortFaultDescription.4.48	.1.3.6.1.4.1.26138.2.14.1.1.2.4.48	OctetString	
ibPsePortPeakPower.4.1	.1.3.6.1.4.1.26138.2.14.1.1.3.4.1	Integer	0
ibPsePortPeakPower.4.2	.1.3.6.1.4.1.26138.2.14.1.1.3.4.2	Integer	0
ibPsePortPeakPower.4.3	.1.3.6.1.4.1.26138.2.14.1.1.3.4.3	Integer	0
ibPsePortPeakPower.4.4	.1.3.6.1.4.1.26138.2.14.1.1.3.4.4	Integer	0
ibPsePortPeakPower.4.5	.1.3.6.1.4.1.26138.2.14.1.1.3.4.5	Integer	0
ibPsePortPeakPower.4.6	.1.3.6.1.4.1.26138.2.14.1.1.3.4.6	Integer	0
ibPsePortPeakPower.4.7	.1.3.6.1.4.1.26138.2.14.1.1.3.4.7	Integer	0
ibPsePortPeakPower.4.8	.1.3.6.1.4.1.26138.2.14.1.1.3.4.8	Integer	0
ibPsePortPeakPower.4.9	.1.3.6.1.4.1.26138.2.14.1.1.3.4.9	Integer	0
ibPsePortPeakPower.4.10	.1.3.6.1.4.1.26138.2.14.1.1.3.4.10	Integer	0
ibPsePortPeakPower.4.11	.1.3.6.1.4.1.26138.2.14.1.1.3.4.11	Integer	0
ibPsePortPeakPower.4.12	.1.3.6.1.4.1.26138.2.14.1.1.3.4.12	Integer	0
ibPsePortPeakPower.4.13	.1.3.6.1.4.1.26138.2.14.1.1.3.4.13	Integer	0
ibPsePortPeakPower.4.14	.1.3.6.1.4.1.26138.2.14.1.1.3.4.14	Integer	0
ibPsePortPeakPower.4.15	.1.3.6.1.4.1.26138.2.14.1.1.3.4.15	Integer	0
ibPsePortPeakPower.4.16	.1.3.6.1.4.1.26138.2.14.1.1.3.4.16	Integer	0
ibPsePortPeakPower.4.17	.1.3.6.1.4.1.26138.2.14.1.1.3.4.17	Integer	0
ibPsePortPeakPower.4.18	.1.3.6.1.4.1.26138.2.14.1.1.3.4.18	Integer	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ibPsePortPeakPower.4.19	.1.3.6.1.4.1.26138.2.14.1.1.3.4.19	Integer	0
ibPsePortPeakPower.4.20	.1.3.6.1.4.1.26138.2.14.1.1.3.4.20	Integer	0
ibPsePortPeakPower.4.21	.1.3.6.1.4.1.26138.2.14.1.1.3.4.21	Integer	0
ibPsePortPeakPower.4.22	.1.3.6.1.4.1.26138.2.14.1.1.3.4.22	Integer	0
ibPsePortPeakPower.4.23	.1.3.6.1.4.1.26138.2.14.1.1.3.4.23	Integer	0
ibPsePortPeakPower.4.24	.1.3.6.1.4.1.26138.2.14.1.1.3.4.24	Integer	0
ibPsePortPeakPower.4.25	.1.3.6.1.4.1.26138.2.14.1.1.3.4.25	Integer	0
ibPsePortPeakPower.4.26	.1.3.6.1.4.1.26138.2.14.1.1.3.4.26	Integer	0
ibPsePortPeakPower.4.27	.1.3.6.1.4.1.26138.2.14.1.1.3.4.27	Integer	0
ibPsePortPeakPower.4.28	.1.3.6.1.4.1.26138.2.14.1.1.3.4.28	Integer	0
ibPsePortPeakPower.4.29	.1.3.6.1.4.1.26138.2.14.1.1.3.4.29	Integer	0
ibPsePortPeakPower.4.30	.1.3.6.1.4.1.26138.2.14.1.1.3.4.30	Integer	0
ibPsePortPeakPower.4.31	.1.3.6.1.4.1.26138.2.14.1.1.3.4.31	Integer	0
ibPsePortPeakPower.4.32	.1.3.6.1.4.1.26138.2.14.1.1.3.4.32	Integer	0
ibPsePortPeakPower.4.33	.1.3.6.1.4.1.26138.2.14.1.1.3.4.33	Integer	0
ibPsePortPeakPower.4.34	.1.3.6.1.4.1.26138.2.14.1.1.3.4.34	Integer	0
ibPsePortPeakPower.4.35	.1.3.6.1.4.1.26138.2.14.1.1.3.4.35	Integer	0
ibPsePortPeakPower.4.36	.1.3.6.1.4.1.26138.2.14.1.1.3.4.36	Integer	0
ibPsePortPeakPower.4.37	.1.3.6.1.4.1.26138.2.14.1.1.3.4.37	Integer	0
ibPsePortPeakPower.4.38	.1.3.6.1.4.1.26138.2.14.1.1.3.4.38	Integer	0
ibPsePortPeakPower.4.39	.1.3.6.1.4.1.26138.2.14.1.1.3.4.39	Integer	0
ibPsePortPeakPower.4.40	.1.3.6.1.4.1.26138.2.14.1.1.3.4.40	Integer	0
ibPsePortPeakPower.4.41	.1.3.6.1.4.1.26138.2.14.1.1.3.4.41	Integer	0
ibPsePortPeakPower.4.42	.1.3.6.1.4.1.26138.2.14.1.1.3.4.42	Integer	0
ibPsePortPeakPower.4.43	.1.3.6.1.4.1.26138.2.14.1.1.3.4.43	Integer	0
ibPsePortPeakPower.4.44	.1.3.6.1.4.1.26138.2.14.1.1.3.4.44	Integer	0
ibPsePortPeakPower.4.45	.1.3.6.1.4.1.26138.2.14.1.1.3.4.45	Integer	0
ibPsePortPeakPower.4.46	.1.3.6.1.4.1.26138.2.14.1.1.3.4.46	Integer	0
ibPsePortPeakPower.4.47	.1.3.6.1.4.1.26138.2.14.1.1.3.4.47	Integer	0
ibPsePortPeakPower.4.48	.1.3.6.1.4.1.26138.2.14.1.1.3.4.48	Integer	0
ibPsePortAveragePower.4.1	.1.3.6.1.4.1.26138.2.14.1.1.4.4.1	Integer	0
ibPsePortAveragePower.4.2	.1.3.6.1.4.1.26138.2.14.1.1.4.4.2	Integer	0
ibPsePortAveragePower.4.3	.1.3.6.1.4.1.26138.2.14.1.1.4.4.3	Integer	0
ibPsePortAveragePower.4.4	.1.3.6.1.4.1.26138.2.14.1.1.4.4.4	Integer	0
ibPsePortAveragePower.4.5	.1.3.6.1.4.1.26138.2.14.1.1.4.4.5	Integer	0
ibPsePortAveragePower.4.6	.1.3.6.1.4.1.26138.2.14.1.1.4.4.6	Integer	0
ibPsePortAveragePower.4.7	.1.3.6.1.4.1.26138.2.14.1.1.4.4.7	Integer	0
ibPsePortAveragePower.4.8	.1.3.6.1.4.1.26138.2.14.1.1.4.4.8	Integer	0
ibPsePortAveragePower.4.9	.1.3.6.1.4.1.26138.2.14.1.1.4.4.9	Integer	0
ibPsePortAveragePower.4.10	.1.3.6.1.4.1.26138.2.14.1.1.4.4.10	Integer	0
ibPsePortAveragePower.4.11	.1.3.6.1.4.1.26138.2.14.1.1.4.4.11	Integer	0
ibPsePortAveragePower.4.12	.1.3.6.1.4.1.26138.2.14.1.1.4.4.12	Integer	0
ibPsePortAveragePower.4.13	.1.3.6.1.4.1.26138.2.14.1.1.4.4.13	Integer	0



Name	OID	Value Type	Value Example
ibPsePortAveragePower.4.14	.1.3.6.1.4.1.26138.2.14.1.1.4.4.14	Integer	0
ibPsePortAveragePower.4.15	.1.3.6.1.4.1.26138.2.14.1.1.4.4.15	Integer	0
ibPsePortAveragePower.4.16	.1.3.6.1.4.1.26138.2.14.1.1.4.4.16	Integer	0
ibPsePortAveragePower.4.17	.1.3.6.1.4.1.26138.2.14.1.1.4.4.17	Integer	0
ibPsePortAveragePower.4.18	.1.3.6.1.4.1.26138.2.14.1.1.4.4.18	Integer	0
ibPsePortAveragePower.4.19	.1.3.6.1.4.1.26138.2.14.1.1.4.4.19	Integer	0
ibPsePortAveragePower.4.20	.1.3.6.1.4.1.26138.2.14.1.1.4.4.20	Integer	0
ibPsePortAveragePower.4.21	.1.3.6.1.4.1.26138.2.14.1.1.4.4.21	Integer	0
ibPsePortAveragePower.4.22	.1.3.6.1.4.1.26138.2.14.1.1.4.4.22	Integer	0
ibPsePortAveragePower.4.23	.1.3.6.1.4.1.26138.2.14.1.1.4.4.23	Integer	0
ibPsePortAveragePower.4.24	.1.3.6.1.4.1.26138.2.14.1.1.4.4.24	Integer	0
ibPsePortAveragePower.4.25	.1.3.6.1.4.1.26138.2.14.1.1.4.4.25	Integer	0
ibPsePortAveragePower.4.26	.1.3.6.1.4.1.26138.2.14.1.1.4.4.26	Integer	0
ibPsePortAveragePower.4.27	.1.3.6.1.4.1.26138.2.14.1.1.4.4.27	Integer	0
ibPsePortAveragePower.4.28	.1.3.6.1.4.1.26138.2.14.1.1.4.4.28	Integer	0
ibPsePortAveragePower.4.29	.1.3.6.1.4.1.26138.2.14.1.1.4.4.29	Integer	0
ibPsePortAveragePower.4.30	.1.3.6.1.4.1.26138.2.14.1.1.4.4.30	Integer	0
ibPsePortAveragePower.4.31	.1.3.6.1.4.1.26138.2.14.1.1.4.4.31	Integer	0
ibPsePortAveragePower.4.32	.1.3.6.1.4.1.26138.2.14.1.1.4.4.32	Integer	0
ibPsePortAveragePower.4.33	.1.3.6.1.4.1.26138.2.14.1.1.4.4.33	Integer	0
ibPsePortAveragePower.4.34	.1.3.6.1.4.1.26138.2.14.1.1.4.4.34	Integer	0
ibPsePortAveragePower.4.35	.1.3.6.1.4.1.26138.2.14.1.1.4.4.35	Integer	0
ibPsePortAveragePower.4.36	.1.3.6.1.4.1.26138.2.14.1.1.4.4.36	Integer	0
ibPsePortAveragePower.4.37	.1.3.6.1.4.1.26138.2.14.1.1.4.4.37	Integer	0
ibPsePortAveragePower.4.38	.1.3.6.1.4.1.26138.2.14.1.1.4.4.38	Integer	0
ibPsePortAveragePower.4.39	.1.3.6.1.4.1.26138.2.14.1.1.4.4.39	Integer	0
ibPsePortAveragePower.4.40	.1.3.6.1.4.1.26138.2.14.1.1.4.4.40	Integer	0
ibPsePortAveragePower.4.41	.1.3.6.1.4.1.26138.2.14.1.1.4.4.41	Integer	0
ibPsePortAveragePower.4.42	.1.3.6.1.4.1.26138.2.14.1.1.4.4.42	Integer	0
ibPsePortAveragePower.4.43	.1.3.6.1.4.1.26138.2.14.1.1.4.4.43	Integer	0
ibPsePortAveragePower.4.44	.1.3.6.1.4.1.26138.2.14.1.1.4.4.44	Integer	0
ibPsePortAveragePower.4.45	.1.3.6.1.4.1.26138.2.14.1.1.4.4.45	Integer	0
ibPsePortAveragePower.4.46	.1.3.6.1.4.1.26138.2.14.1.1.4.4.46	Integer	0
ibPsePortAveragePower.4.47	.1.3.6.1.4.1.26138.2.14.1.1.4.4.47	Integer	0
ibPsePortAveragePower.4.48	.1.3.6.1.4.1.26138.2.14.1.1.4.4.48	Integer	0
ibPsePortCurrentPower.4.1	.1.3.6.1.4.1.26138.2.14.1.1.5.4.1	Integer	0
ibPsePortCurrentPower.4.2	.1.3.6.1.4.1.26138.2.14.1.1.5.4.2	Integer	0
ibPsePortCurrentPower.4.3	.1.3.6.1.4.1.26138.2.14.1.1.5.4.3	Integer	0
ibPsePortCurrentPower.4.4	.1.3.6.1.4.1.26138.2.14.1.1.5.4.4	Integer	0
ibPsePortCurrentPower.4.5	.1.3.6.1.4.1.26138.2.14.1.1.5.4.5	Integer	0
ibPsePortCurrentPower.4.6	.1.3.6.1.4.1.26138.2.14.1.1.5.4.6	Integer	0
ibPsePortCurrentPower.4.7	.1.3.6.1.4.1.26138.2.14.1.1.5.4.7	Integer	0
ibPsePortCurrentPower.4.8	.1.3.6.1.4.1.26138.2.14.1.1.5.4.8	Integer	0



Name	OID	Value Type	Value Example
ibPsePortCurrentPower.4.9	.1.3.6.1.4.1.26138.2.14.1.1.5.4.9	Integer	0
ibPsePortCurrentPower.4.10	.1.3.6.1.4.1.26138.2.14.1.1.5.4.10	Integer	0
ibPsePortCurrentPower.4.11	.1.3.6.1.4.1.26138.2.14.1.1.5.4.11	Integer	0
ibPsePortCurrentPower.4.12	.1.3.6.1.4.1.26138.2.14.1.1.5.4.12	Integer	0
ibPsePortCurrentPower.4.13	.1.3.6.1.4.1.26138.2.14.1.1.5.4.13	Integer	0
ibPsePortCurrentPower.4.14	.1.3.6.1.4.1.26138.2.14.1.1.5.4.14	Integer	0
ibPsePortCurrentPower.4.15	.1.3.6.1.4.1.26138.2.14.1.1.5.4.15	Integer	0
ibPsePortCurrentPower.4.16	.1.3.6.1.4.1.26138.2.14.1.1.5.4.16	Integer	0
ibPsePortCurrentPower.4.17	.1.3.6.1.4.1.26138.2.14.1.1.5.4.17	Integer	0
ibPsePortCurrentPower.4.18	.1.3.6.1.4.1.26138.2.14.1.1.5.4.18	Integer	0
ibPsePortCurrentPower.4.19	.1.3.6.1.4.1.26138.2.14.1.1.5.4.19	Integer	0
ibPsePortCurrentPower.4.20	.1.3.6.1.4.1.26138.2.14.1.1.5.4.20	Integer	0
ibPsePortCurrentPower.4.21	.1.3.6.1.4.1.26138.2.14.1.1.5.4.21	Integer	0
ibPsePortCurrentPower.4.22	.1.3.6.1.4.1.26138.2.14.1.1.5.4.22	Integer	0
ibPsePortCurrentPower.4.23	.1.3.6.1.4.1.26138.2.14.1.1.5.4.23	Integer	0
ibPsePortCurrentPower.4.24	.1.3.6.1.4.1.26138.2.14.1.1.5.4.24	Integer	0
ibPsePortCurrentPower.4.25	.1.3.6.1.4.1.26138.2.14.1.1.5.4.25	Integer	0
ibPsePortCurrentPower.4.26	.1.3.6.1.4.1.26138.2.14.1.1.5.4.26	Integer	0
ibPsePortCurrentPower.4.27	.1.3.6.1.4.1.26138.2.14.1.1.5.4.27	Integer	0
ibPsePortCurrentPower.4.28	.1.3.6.1.4.1.26138.2.14.1.1.5.4.28	Integer	0
ibPsePortCurrentPower.4.29	.1.3.6.1.4.1.26138.2.14.1.1.5.4.29	Integer	0
ibPsePortCurrentPower.4.30	.1.3.6.1.4.1.26138.2.14.1.1.5.4.30	Integer	0
ibPsePortCurrentPower.4.31	.1.3.6.1.4.1.26138.2.14.1.1.5.4.31	Integer	0
ibPsePortCurrentPower.4.32	.1.3.6.1.4.1.26138.2.14.1.1.5.4.32	Integer	0
ibPsePortCurrentPower.4.33	.1.3.6.1.4.1.26138.2.14.1.1.5.4.33	Integer	0
ibPsePortCurrentPower.4.34	.1.3.6.1.4.1.26138.2.14.1.1.5.4.34	Integer	0
ibPsePortCurrentPower.4.35	.1.3.6.1.4.1.26138.2.14.1.1.5.4.35	Integer	0
ibPsePortCurrentPower.4.36	.1.3.6.1.4.1.26138.2.14.1.1.5.4.36	Integer	0
ibPsePortCurrentPower.4.37	.1.3.6.1.4.1.26138.2.14.1.1.5.4.37	Integer	0
ibPsePortCurrentPower.4.38	.1.3.6.1.4.1.26138.2.14.1.1.5.4.38	Integer	0
ibPsePortCurrentPower.4.39	.1.3.6.1.4.1.26138.2.14.1.1.5.4.39	Integer	0
ibPsePortCurrentPower.4.40	.1.3.6.1.4.1.26138.2.14.1.1.5.4.40	Integer	0
ibPsePortCurrentPower.4.41	.1.3.6.1.4.1.26138.2.14.1.1.5.4.41	Integer	0
ibPsePortCurrentPower.4.42	.1.3.6.1.4.1.26138.2.14.1.1.5.4.42	Integer	0
ibPsePortCurrentPower.4.43	.1.3.6.1.4.1.26138.2.14.1.1.5.4.43	Integer	0
ibPsePortCurrentPower.4.44	.1.3.6.1.4.1.26138.2.14.1.1.5.4.44	Integer	0
ibPsePortCurrentPower.4.45	.1.3.6.1.4.1.26138.2.14.1.1.5.4.45	Integer	0
ibPsePortCurrentPower.4.46	.1.3.6.1.4.1.26138.2.14.1.1.5.4.46	Integer	0
ibPsePortCurrentPower.4.47	.1.3.6.1.4.1.26138.2.14.1.1.5.4.47	Integer	0
ibPsePortCurrentPower.4.48	.1.3.6.1.4.1.26138.2.14.1.1.5.4.48	Integer	0
ibPsePortPowerLimit.4.1	.1.3.6.1.4.1.26138.2.14.1.1.6.4.1	Integer	35000
ibPsePortPowerLimit.4.2	.1.3.6.1.4.1.26138.2.14.1.1.6.4.2	Integer	35000
ibPsePortPowerLimit.4.3	.1.3.6.1.4.1.26138.2.14.1.1.6.4.3	Integer	35000

Name	OID	Value Type	Value Example
ibPsePortPowerLimit.4.4	.1.3.6.1.4.1.26138.2.14.1.1.6.4.4	Integer	35000
ibPsePortPowerLimit.4.5	.1.3.6.1.4.1.26138.2.14.1.1.6.4.5	Integer	35000
ibPsePortPowerLimit.4.6	.1.3.6.1.4.1.26138.2.14.1.1.6.4.6	Integer	35000
ibPsePortPowerLimit.4.7	.1.3.6.1.4.1.26138.2.14.1.1.6.4.7	Integer	35000
ibPsePortPowerLimit.4.8	.1.3.6.1.4.1.26138.2.14.1.1.6.4.8	Integer	35000
ibPsePortPowerLimit.4.9	.1.3.6.1.4.1.26138.2.14.1.1.6.4.9	Integer	35000
ibPsePortPowerLimit.4.10	.1.3.6.1.4.1.26138.2.14.1.1.6.4.10	Integer	35000
ibPsePortPowerLimit.4.11	.1.3.6.1.4.1.26138.2.14.1.1.6.4.11	Integer	35000
ibPsePortPowerLimit.4.12	.1.3.6.1.4.1.26138.2.14.1.1.6.4.12	Integer	35000
ibPsePortPowerLimit.4.13	.1.3.6.1.4.1.26138.2.14.1.1.6.4.13	Integer	35000
ibPsePortPowerLimit.4.14	.1.3.6.1.4.1.26138.2.14.1.1.6.4.14	Integer	35000
ibPsePortPowerLimit.4.15	.1.3.6.1.4.1.26138.2.14.1.1.6.4.15	Integer	35000
ibPsePortPowerLimit.4.16	.1.3.6.1.4.1.26138.2.14.1.1.6.4.16	Integer	35000
ibPsePortPowerLimit.4.17	.1.3.6.1.4.1.26138.2.14.1.1.6.4.17	Integer	35000
ibPsePortPowerLimit.4.18	.1.3.6.1.4.1.26138.2.14.1.1.6.4.18	Integer	35000
ibPsePortPowerLimit.4.19	.1.3.6.1.4.1.26138.2.14.1.1.6.4.19	Integer	35000
ibPsePortPowerLimit.4.20	.1.3.6.1.4.1.26138.2.14.1.1.6.4.20	Integer	35000
ibPsePortPowerLimit.4.21	.1.3.6.1.4.1.26138.2.14.1.1.6.4.21	Integer	35000
ibPsePortPowerLimit.4.22	.1.3.6.1.4.1.26138.2.14.1.1.6.4.22	Integer	35000
ibPsePortPowerLimit.4.23	.1.3.6.1.4.1.26138.2.14.1.1.6.4.23	Integer	35000
ibPsePortPowerLimit.4.24	.1.3.6.1.4.1.26138.2.14.1.1.6.4.24	Integer	35000
ibPsePortPowerLimit.4.25	.1.3.6.1.4.1.26138.2.14.1.1.6.4.25	Integer	35000
ibPsePortPowerLimit.4.26	.1.3.6.1.4.1.26138.2.14.1.1.6.4.26	Integer	35000
ibPsePortPowerLimit.4.27	.1.3.6.1.4.1.26138.2.14.1.1.6.4.27	Integer	35000
ibPsePortPowerLimit.4.28	.1.3.6.1.4.1.26138.2.14.1.1.6.4.28	Integer	35000
ibPsePortPowerLimit.4.29	.1.3.6.1.4.1.26138.2.14.1.1.6.4.29	Integer	35000
ibPsePortPowerLimit.4.30	.1.3.6.1.4.1.26138.2.14.1.1.6.4.30	Integer	35000
ibPsePortPowerLimit.4.31	.1.3.6.1.4.1.26138.2.14.1.1.6.4.31	Integer	35000
ibPsePortPowerLimit.4.32	.1.3.6.1.4.1.26138.2.14.1.1.6.4.32	Integer	35000
ibPsePortPowerLimit.4.33	.1.3.6.1.4.1.26138.2.14.1.1.6.4.33	Integer	35000
ibPsePortPowerLimit.4.34	.1.3.6.1.4.1.26138.2.14.1.1.6.4.34	Integer	35000
ibPsePortPowerLimit.4.35	.1.3.6.1.4.1.26138.2.14.1.1.6.4.35	Integer	35000
ibPsePortPowerLimit.4.36	.1.3.6.1.4.1.26138.2.14.1.1.6.4.36	Integer	35000
ibPsePortPowerLimit.4.37	.1.3.6.1.4.1.26138.2.14.1.1.6.4.37	Integer	35000
ibPsePortPowerLimit.4.38	.1.3.6.1.4.1.26138.2.14.1.1.6.4.38	Integer	35000
ibPsePortPowerLimit.4.39	.1.3.6.1.4.1.26138.2.14.1.1.6.4.39	Integer	35000
ibPsePortPowerLimit.4.40	.1.3.6.1.4.1.26138.2.14.1.1.6.4.40	Integer	35000
ibPsePortPowerLimit.4.41	.1.3.6.1.4.1.26138.2.14.1.1.6.4.41	Integer	35000
ibPsePortPowerLimit.4.42	.1.3.6.1.4.1.26138.2.14.1.1.6.4.42	Integer	35000
ibPsePortPowerLimit.4.43	.1.3.6.1.4.1.26138.2.14.1.1.6.4.43	Integer	35000
ibPsePortPowerLimit.4.44	.1.3.6.1.4.1.26138.2.14.1.1.6.4.44	Integer	35000
ibPsePortPowerLimit.4.45	.1.3.6.1.4.1.26138.2.14.1.1.6.4.45	Integer	35000
ibPsePortPowerLimit.4.46	.1.3.6.1.4.1.26138.2.14.1.1.6.4.46	Integer	35000

Name	OID	Value Type	Value Example
ibPsePortPowerLimit.4.47	.1.3.6.1.4.1.26138.2.14.1.1.6.4.47	Integer	35000
ibPsePortPowerLimit.4.48	.1.3.6.1.4.1.26138.2.14.1.1.6.4.48	Integer	35000
ibPsePortProfileIndex.4.1	.1.3.6.1.4.1.26138.2.14.1.1.7.4.1	Integer	0
ibPsePortProfileIndex.4.2	.1.3.6.1.4.1.26138.2.14.1.1.7.4.2	Integer	0
ibPsePortProfileIndex.4.3	.1.3.6.1.4.1.26138.2.14.1.1.7.4.3	Integer	0
ibPsePortProfileIndex.4.4	.1.3.6.1.4.1.26138.2.14.1.1.7.4.4	Integer	0
ibPsePortProfileIndex.4.5	.1.3.6.1.4.1.26138.2.14.1.1.7.4.5	Integer	0
ibPsePortProfileIndex.4.6	.1.3.6.1.4.1.26138.2.14.1.1.7.4.6	Integer	0
ibPsePortProfileIndex.4.7	.1.3.6.1.4.1.26138.2.14.1.1.7.4.7	Integer	0
ibPsePortProfileIndex.4.8	.1.3.6.1.4.1.26138.2.14.1.1.7.4.8	Integer	0
ibPsePortProfileIndex.4.9	.1.3.6.1.4.1.26138.2.14.1.1.7.4.9	Integer	0
ibPsePortProfileIndex.4.10	.1.3.6.1.4.1.26138.2.14.1.1.7.4.10	Integer	0
ibPsePortProfileIndex.4.11	.1.3.6.1.4.1.26138.2.14.1.1.7.4.11	Integer	0
ibPsePortProfileIndex.4.12	.1.3.6.1.4.1.26138.2.14.1.1.7.4.12	Integer	0
ibPsePortProfileIndex.4.13	.1.3.6.1.4.1.26138.2.14.1.1.7.4.13	Integer	0
ibPsePortProfileIndex.4.14	.1.3.6.1.4.1.26138.2.14.1.1.7.4.14	Integer	0
ibPsePortProfileIndex.4.15	.1.3.6.1.4.1.26138.2.14.1.1.7.4.15	Integer	0
ibPsePortProfileIndex.4.16	.1.3.6.1.4.1.26138.2.14.1.1.7.4.16	Integer	0
ibPsePortProfileIndex.4.17	.1.3.6.1.4.1.26138.2.14.1.1.7.4.17	Integer	0
ibPsePortProfileIndex.4.18	.1.3.6.1.4.1.26138.2.14.1.1.7.4.18	Integer	0
ibPsePortProfileIndex.4.19	.1.3.6.1.4.1.26138.2.14.1.1.7.4.19	Integer	0
ibPsePortProfileIndex.4.20	.1.3.6.1.4.1.26138.2.14.1.1.7.4.20	Integer	0
ibPsePortProfileIndex.4.21	.1.3.6.1.4.1.26138.2.14.1.1.7.4.21	Integer	0
ibPsePortProfileIndex.4.22	.1.3.6.1.4.1.26138.2.14.1.1.7.4.22	Integer	0
ibPsePortProfileIndex.4.23	.1.3.6.1.4.1.26138.2.14.1.1.7.4.23	Integer	0
ibPsePortProfileIndex.4.24	.1.3.6.1.4.1.26138.2.14.1.1.7.4.24	Integer	0
ibPsePortProfileIndex.4.25	.1.3.6.1.4.1.26138.2.14.1.1.7.4.25	Integer	0
ibPsePortProfileIndex.4.26	.1.3.6.1.4.1.26138.2.14.1.1.7.4.26	Integer	0
ibPsePortProfileIndex.4.27	.1.3.6.1.4.1.26138.2.14.1.1.7.4.27	Integer	0
ibPsePortProfileIndex.4.28	.1.3.6.1.4.1.26138.2.14.1.1.7.4.28	Integer	0
ibPsePortProfileIndex.4.29	.1.3.6.1.4.1.26138.2.14.1.1.7.4.29	Integer	0
ibPsePortProfileIndex.4.30	.1.3.6.1.4.1.26138.2.14.1.1.7.4.30	Integer	0
ibPsePortProfileIndex.4.31	.1.3.6.1.4.1.26138.2.14.1.1.7.4.31	Integer	0
ibPsePortProfileIndex.4.32	.1.3.6.1.4.1.26138.2.14.1.1.7.4.32	Integer	0
ibPsePortProfileIndex.4.33	.1.3.6.1.4.1.26138.2.14.1.1.7.4.33	Integer	0
ibPsePortProfileIndex.4.34	.1.3.6.1.4.1.26138.2.14.1.1.7.4.34	Integer	0
ibPsePortProfileIndex.4.35	.1.3.6.1.4.1.26138.2.14.1.1.7.4.35	Integer	0
ibPsePortProfileIndex.4.36	.1.3.6.1.4.1.26138.2.14.1.1.7.4.36	Integer	0
ibPsePortProfileIndex.4.37	.1.3.6.1.4.1.26138.2.14.1.1.7.4.37	Integer	0
ibPsePortProfileIndex.4.38	.1.3.6.1.4.1.26138.2.14.1.1.7.4.38	Integer	0
ibPsePortProfileIndex.4.39	.1.3.6.1.4.1.26138.2.14.1.1.7.4.39	Integer	0
ibPsePortProfileIndex.4.40	.1.3.6.1.4.1.26138.2.14.1.1.7.4.40	Integer	0
ibPsePortProfileIndex.4.41	.1.3.6.1.4.1.26138.2.14.1.1.7.4.41	Integer	0

Name	OID	Value Type	Value Example
ibPsePortProfileIndex.4.42	.1.3.6.1.4.1.26138.2.14.1.1.7.4.42	Integer	0
ibPsePortProfileIndex.4.43	.1.3.6.1.4.1.26138.2.14.1.1.7.4.43	Integer	0
ibPsePortProfileIndex.4.44	.1.3.6.1.4.1.26138.2.14.1.1.7.4.44	Integer	0
ibPsePortProfileIndex.4.45	.1.3.6.1.4.1.26138.2.14.1.1.7.4.45	Integer	0
ibPsePortProfileIndex.4.46	.1.3.6.1.4.1.26138.2.14.1.1.7.4.46	Integer	0
ibPsePortProfileIndex.4.47	.1.3.6.1.4.1.26138.2.14.1.1.7.4.47	Integer	0
ibPsePortProfileIndex.4.48	.1.3.6.1.4.1.26138.2.14.1.1.7.4.48	Integer	0
ibMainPsePowerLimit.4	.1.3.6.1.4.1.26138.2.14.2.1.1.4	Integer	530
ibMainPseAveragePower.4	.1.3.6.1.4.1.26138.2.14.2.1.2.4	Integer	0
ibMainPsePeakPower.4	.1.3.6.1.4.1.26138.2.14.2.1.3.4	Integer	0
ibMainGuaranteedPowerRe- maining.4	.1.3.6.1.4.1.26138.2.14.2.1.4.4	Integer	530
ibMainPseLegacy.4	.1.3.6.1.4.1.26138.2.14.2.1.6.4	Integer	disable (1)
ibMainPsePowerPriority.4	.1.3.6.1.4.1.26138.2.14.2.1.7.4	Integer	low (3)
ibPDPolicyMode.0	.1.3.6.1.4.1.26138.2.14.10.0	Integer	disabled (1)
ibProtocolNumAllVlan.0	.1.3.6.1.4.1.26138.2.16.1.1.0	Integer	32752
ibProtocolNumPerVlan.0	.1.3.6.1.4.1.26138.2.16.1.2.0	Integer	8
ibSSHServerVersion.0	.1.3.6.1.4.1.26138.2.22.1.1.1.1.0	OctetString	2.0
ibSSHServerCompatibleS- SH1x.0	.1.3.6.1.4.1.26138.2.22.1.1.1.2.0	Integer	disableCompatibleSSH1x (2)
ibSSHServerRekeyInterval.0	.1.3.6.1.4.1.26138.2.22.1.1.1.3.0	Integer	0
ibSSHServerAuthRetries.0	.1.3.6.1.4.1.26138.2.22.1.1.1.4.0	Integer	3
ibSSHServerAuthTimeout.0	.1.3.6.1.4.1.26138.2.22.1.1.1.5.0	Integer	60
ibSFTPServerIdleTimeout.0	.1.3.6.1.4.1.26138.2.22.1.1.1.6.0	Integer	10
ibSSHServerEnable.0	.1.3.6.1.4.1.26138.2.22.1.1.1.7.0	Integer	enableSSHServer (1)
ibSFTPServerEnable.0	.1.3.6.1.4.1.26138.2.22.1.1.1.8.0	Integer	disableSFTPService (2)
ibSTelnetServerEnable.0	.1.3.6.1.4.1.26138.2.22.1.1.1.9.0	Integer	enableSTelnetServer (1)
ibSCPServerEnable.0	.1.3.6.1.4.1.26138.2.22.1.1.1.10.0	Integer	disableSCPService (2)
ibTrapDesIPAddress.1	.1.3.6.1.4.1.26138.2.38.1.7.1.1.2.1	IpAddress	10.100.26.141
ibTrapDesIPAddress.2	.1.3.6.1.4.1.26138.2.38.1.7.1.1.2.2	IpAddress	10.100.26.163
ibTrapDesIPAddress.3	.1.3.6.1.4.1.26138.2.38.1.7.1.1.2.3	IpAddress	10.100.26.164
ibTrapDesPort.1	.1.3.6.1.4.1.26138.2.38.1.7.1.1.3.1	Integer	162
ibTrapDesPort.2	.1.3.6.1.4.1.26138.2.38.1.7.1.1.3.2	Integer	162
ibTrapDesPort.3	.1.3.6.1.4.1.26138.2.38.1.7.1.1.3.3	Integer	162
ibTrapDesRowStatus.1	.1.3.6.1.4.1.26138.2.38.1.7.1.1.4.1	Integer	active (1)
ibTrapDesRowStatus.2	.1.3.6.1.4.1.26138.2.38.1.7.1.1.4.2	Integer	active (1)
ibTrapDesRowStatus.3	.1.3.6.1.4.1.26138.2.38.1.7.1.1.4.3	Integer	active (1)
ibTrapDesAddrTAddress.1	.1.3.6.1.4.1.26138.2.38.1.7.1.1.5.1	OctetString	0A-64-1A-8D-00-A2
ibTrapDesAddrTAddress.2	.1.3.6.1.4.1.26138.2.38.1.7.1.1.5.2	OctetString	0A-64-1A-A3-00-A2
ibTrapDesAddrTAddress.3	.1.3.6.1.4.1.26138.2.38.1.7.1.1.5.3	OctetString	0A-64-1A-A4-00-A2
ibTrapConfigName.1	.1.3.6.1.4.1.26138.2.38.1.8.1.1.2.1	OctetString	TemperatureTooHighTrap
ibTrapConfigName.2	.1.3.6.1.4.1.26138.2.38.1.8.1.1.2.2	OctetString	TemperTooHighRecovTrap
ibTrapConfigName.3	.1.3.6.1.4.1.26138.2.38.1.8.1.1.2.3	OctetString	SystemColdStartTrap

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ibTrapConfigName.4	.1.3.6.1.4.1.26138.2.38.1.8.1.1.2.4	OctetString	SystemWarmStartTrap
ibTrapConfigName.5	.1.3.6.1.4.1.26138.2.38.1.8.1.1.2.5	OctetString	PowerOffTrap
ibTrapConfigName.6	.1.3.6.1.4.1.26138.2.38.1.8.1.1.2.6	OctetString	PowerOffRecovTrap
ibTrapConfigName.7	.1.3.6.1.4.1.26138.2.38.1.8.1.1.2.7	OctetString	APCPUUsageTooHighTrap
ibTrapConfigName.8	.1.3.6.1.4.1.26138.2.38.1.8.1.1.2.8	OctetString	APMemUsageTooHighTrap
ibTrapConfigName.9	.1.3.6.1.4.1.26138.2.38.1.8.1.1.2.9	OctetString	APCPUUsageTooHighRecov-Trap
ibTrapConfigName.10	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.10	OctetString	APMemUsageTooHighRecov-Trap
ibTrapConfigName.11	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.11	OctetString	PortalServerUnavailableTrap
ibTrapConfigName.12	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.12	OctetString	PortalServerAvailableTrap
ibTrapConfigName.13	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.13	OctetString	IPAddChangeTrap
ibTrapConfigName.14	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.14	OctetString	ACHeartbeatTrap
ibTrapConfigName.15	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.15	OctetString	ConfigurationErrorTrap
ibTrapConfigName.16	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.16	OctetString	ACCPUUsageTooHighTrap
ibTrapConfigName.17	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.17	OctetString	ACMemUsageTooHighTrap
ibTrapConfigName.18	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.18	OctetString	TemperatureTooHighTrap2
ibTrapConfigName.19	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.19	OctetString	TemperatureTooHighRecov-Trap2
ibTrapConfigName.20	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.20	OctetString	ACCPUUsageTooHighRecov-Trap
ibTrapConfigName.21	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.21	OctetString	ACMemUsageTooHighRecov-Trap
ibTrapConfigName.22	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.22	OctetString	RadiusAuthServerUnavailable-Trap
ibTrapConfigName.23	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.23	OctetString	RadiusAuthServerAvailable-Trap
ibTrapConfigName.24	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.24	OctetString	RadioAccServerUnavailable-Trap
ibTrapConfigName.25	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.25	OctetString	RadiusAccServerAvailableTrap
ibTrapConfigName.26	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.26	OctetString	UserWithInvalidCertificateIn-breakNetworkTrap
ibTrapConfigName.27	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.27	OctetString	StationReplayAttackTrap
ibTrapConfigName.28	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.28	OctetString	TamperAttackTrap
ibTrapConfigName.29	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.29	OctetString	LowSafeLevelAttackTrap
ibTrapConfigName.30	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.30	OctetString	AddressRedirectionAttackTrap
ibTrapConfigName.31	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.31	OctetString	APMtWorkModeChgTrap
ibTrapConfigName.32	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.32	OctetString	ModuleTroubleTrap
ibTrapConfigName.33	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.33	OctetString	RadioDownTrap
ibTrapConfigName.34	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.34	OctetString	APStaFullTrap
ibTrapConfigName.35	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.35	OctetString	APMtRdoChanlChgTrap
ibTrapConfigName.36	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.36	OctetString	StaAuthErrorTrap
ibTrapConfigName.37	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.37	OctetString	StAssociationFailTrap
ibTrapConfigName.38	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.38	OctetString	SSIDkeyConflictTrap
ibTrapConfigName.39	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.39	OctetString	RadioDownRecovTrap
ibTrapConfigName.40	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.40	OctetString	APStaFullRecoverTrap

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ibTrapConfigName.41	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.41	OctetString	APModuleTroubleClearTrap
ibTrapConfigName.42	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.42	OctetString	StationDisconnectTrap
ibTrapConfigName.43	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.43	OctetString	StaAuthSuccTrap
ibTrapConfigName.44	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.44	OctetString	StaDeAssocTrap
ibTrapConfigName.45	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.45	OctetString	StaDeauthenticateTrap
ibTrapConfigName.46	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.46	OctetString	WIDSDetectRogueTrap
ibTrapConfigName.47	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.47	OctetString	WIDSUnauthorSSIDTrap
ibTrapConfigName.48	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.48	OctetString	WIDSDetectAttack
ibTrapConfigName.49	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.49	OctetString	AdjacentChAPInterfDetected-Trap
ibTrapConfigName.50	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.50	OctetString	AdjacentChAPInterfClearTrap
ibTrapConfigName.51	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.51	OctetString	CoChAPInterfDetectedTrap
ibTrapConfigName.52	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.52	OctetString	StaInterfDetectedTrap
ibTrapConfigName.53	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.53	OctetString	OtherDeviceInterfDetected-Trap
ibTrapConfigName.54	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.54	OctetString	DFSFreeCountBelowThreshhd-Trap
ibTrapConfigName.55	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.55	OctetString	DFSFreeCntBelowThrRecov
ibTrapConfigName.56	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.56	OctetString	CoChAPInterfClearTrap
ibTrapConfigName.57	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.57	OctetString	StaInterfClearTrap
ibTrapConfigName.58	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.58	OctetString	OtherDevIntClearTrap
ibTrapConfigName.59	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.59	OctetString	APOfflineTrap
ibTrapConfigName.60	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.60	OctetString	ACTurnToBackupDeviceTrap
ibTrapConfigName.61	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.61	OctetString	APSWUpdateFailTrap
ibTrapConfigName.62	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.62	OctetString	APACTimeSyncFailureTrap
ibTrapConfigName.63	1.3.6.1.4.1.26138.2.38.1.8.1.1.2.63	OctetString	APOnlineTrap
ibTrapConfigDescr.1	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.1	OctetString	TemperatureTooHighTrap
ibTrapConfigDescr.2	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.2	OctetString	TemperTooHighRecovTrap
ibTrapConfigDescr.3	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.3	OctetString	SystemColdStartTrap
ibTrapConfigDescr.4	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.4	OctetString	SystemWarmStartTrap
ibTrapConfigDescr.5	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.5	OctetString	PowerOffTrap
ibTrapConfigDescr.6	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.6	OctetString	PowerOffRecovTrap
ibTrapConfigDescr.7	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.7	OctetString	APCPUUsageTooHighTrap
ibTrapConfigDescr.8	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.8	OctetString	APMemUsageTooHighTrap
ibTrapConfigDescr.9	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.9	OctetString	APCPUUsageTooHighRecov-Trap
ibTrapConfigDescr.10	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.10	OctetString	APMemUsageTooHighRecov-Trap
ibTrapConfigDescr.11	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.11	OctetString	PortalServerUnavailableTrap
ibTrapConfigDescr.12	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.12	OctetString	PortalServerAvailableTrap
ibTrapConfigDescr.13	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.13	OctetString	IPAddChangeTrap
ibTrapConfigDescr.14	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.14	OctetString	ACHeartbeatTrap
ibTrapConfigDescr.15	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.15	OctetString	ConfigurationErrorTrap
ibTrapConfigDescr.16	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.16	OctetString	ACCPUUsageTooHighTrap



<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ibTrapConfigDescr.17	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.17	OctetString	ACMemUsageTooHighTrap
ibTrapConfigDescr.18	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.18	OctetString	TemperatureTooHighTrap2
ibTrapConfigDescr.19	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.19	OctetString	TemperatureTooHighRecov-Trap2
ibTrapConfigDescr.20	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.20	OctetString	ACCPUUsageTooHighRecov-Trap
ibTrapConfigDescr.21	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.21	OctetString	ACMemUsageTooHighRecov-Trap
ibTrapConfigDescr.22	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.22	OctetString	RadiusAuthServerUnavailable-Trap
ibTrapConfigDescr.23	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.23	OctetString	RadiusAuthServerAvailable-Trap
ibTrapConfigDescr.24	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.24	OctetString	RadioAccServerUnavailable-Trap
ibTrapConfigDescr.25	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.25	OctetString	RadiusAccServerAvailableTrap
ibTrapConfigDescr.26	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.26	OctetString	UserWithInvalidCertificateIn-breakNetworkTrap
ibTrapConfigDescr.27	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.27	OctetString	StationReplayAttackTrap
ibTrapConfigDescr.28	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.28	OctetString	TamperAttackTrap
ibTrapConfigDescr.29	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.29	OctetString	LowSafeLevelAttackTrap
ibTrapConfigDescr.30	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.30	OctetString	AddressRedirectionAttackTrap
ibTrapConfigDescr.31	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.31	OctetString	APMtWorkModeChgTrap
ibTrapConfigDescr.32	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.32	OctetString	ModuleTroubleTrap
ibTrapConfigDescr.33	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.33	OctetString	RadioDownTrap
ibTrapConfigDescr.34	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.34	OctetString	APStaFullTrap
ibTrapConfigDescr.35	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.35	OctetString	APMtRdoChanlChgTrap
ibTrapConfigDescr.36	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.36	OctetString	StaAuthErrorTrap
ibTrapConfigDescr.37	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.37	OctetString	StAssociationFailTrap
ibTrapConfigDescr.38	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.38	OctetString	SSIDkeyConflictTrap
ibTrapConfigDescr.39	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.39	OctetString	RadioDownRecovTrap
ibTrapConfigDescr.40	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.40	OctetString	APStaFullRecoverTrap
ibTrapConfigDescr.41	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.41	OctetString	APModuleTroubleClearTrap
ibTrapConfigDescr.42	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.42	OctetString	StationDisconnectTrap
ibTrapConfigDescr.43	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.43	OctetString	StaAuthSuccTrap
ibTrapConfigDescr.44	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.44	OctetString	StaDeAssocTrap
ibTrapConfigDescr.45	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.45	OctetString	StaDeauthenticateTrap
ibTrapConfigDescr.46	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.46	OctetString	WIDSdetectRogueTrap
ibTrapConfigDescr.47	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.47	OctetString	WIDSUnauthorSSIDTrap
ibTrapConfigDescr.48	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.48	OctetString	WIDSdetectAttack
ibTrapConfigDescr.49	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.49	OctetString	AdjacentChAPInterfDetected-Trap
ibTrapConfigDescr.50	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.50	OctetString	AdjacentChAPInterfClearTrap
ibTrapConfigDescr.51	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.51	OctetString	CoChAPInterfDetectedTrap
ibTrapConfigDescr.52	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.52	OctetString	StaInterfDetectedTrap
ibTrapConfigDescr.53	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.53	OctetString	OtherDeviceInterfDetected-Trap

Name	OID	Value Type	Value Example
ibTrapConfigDescr.54	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.54	OctetString	DFSFreeCountBelowThreshhd-Trap
ibTrapConfigDescr.55	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.55	OctetString	DFSFreeCntBelowThrRecov
ibTrapConfigDescr.56	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.56	OctetString	CoChAPInterfClearTrap
ibTrapConfigDescr.57	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.57	OctetString	StaInterfClearTrap
ibTrapConfigDescr.58	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.58	OctetString	OtherDevIntClearTrap
ibTrapConfigDescr.59	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.59	OctetString	APOfflineTrap
ibTrapConfigDescr.60	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.60	OctetString	ACTurnToBackupDeviceTrap
ibTrapConfigDescr.61	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.61	OctetString	APSWUpdateFailTrap
ibTrapConfigDescr.62	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.62	OctetString	APACTimeSyncFailureTrap
ibTrapConfigDescr.63	1.3.6.1.4.1.26138.2.38.1.8.1.1.3.63	OctetString	APOnlineTrap
ibTrapConfigSwitch.1	.1.3.6.1.4.1.26138.2.38.1.8.1.1.4.1	Integer	enable (1)
ibTrapConfigSwitch.2	.1.3.6.1.4.1.26138.2.38.1.8.1.1.4.2	Integer	enable (1)
ibTrapConfigSwitch.3	.1.3.6.1.4.1.26138.2.38.1.8.1.1.4.3	Integer	enable (1)
ibTrapConfigSwitch.4	.1.3.6.1.4.1.26138.2.38.1.8.1.1.4.4	Integer	enable (1)
ibTrapConfigSwitch.5	.1.3.6.1.4.1.26138.2.38.1.8.1.1.4.5	Integer	enable (1)
ibTrapConfigSwitch.6	.1.3.6.1.4.1.26138.2.38.1.8.1.1.4.6	Integer	enable (1)
ibTrapConfigSwitch.7	.1.3.6.1.4.1.26138.2.38.1.8.1.1.4.7	Integer	enable (1)
ibTrapConfigSwitch.8	.1.3.6.1.4.1.26138.2.38.1.8.1.1.4.8	Integer	enable (1)
ibTrapConfigSwitch.9	.1.3.6.1.4.1.26138.2.38.1.8.1.1.4.9	Integer	enable (1)
ibTrapConfigSwitch.10	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.10	Integer	enable (1)
ibTrapConfigSwitch.11	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.11	Integer	enable (1)
ibTrapConfigSwitch.12	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.12	Integer	enable (1)
ibTrapConfigSwitch.13	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.13	Integer	enable (1)
ibTrapConfigSwitch.14	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.14	Integer	enable (1)
ibTrapConfigSwitch.15	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.15	Integer	enable (1)
ibTrapConfigSwitch.16	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.16	Integer	enable (1)
ibTrapConfigSwitch.17	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.17	Integer	enable (1)
ibTrapConfigSwitch.18	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.18	Integer	enable (1)
ibTrapConfigSwitch.19	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.19	Integer	enable (1)
ibTrapConfigSwitch.20	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.20	Integer	enable (1)
ibTrapConfigSwitch.21	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.21	Integer	enable (1)
ibTrapConfigSwitch.22	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.22	Integer	enable (1)
ibTrapConfigSwitch.23	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.23	Integer	enable (1)
ibTrapConfigSwitch.24	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.24	Integer	enable (1)
ibTrapConfigSwitch.25	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.25	Integer	enable (1)
ibTrapConfigSwitch.26	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.26	Integer	enable (1)
ibTrapConfigSwitch.27	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.27	Integer	enable (1)
ibTrapConfigSwitch.28	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.28	Integer	enable (1)
ibTrapConfigSwitch.29	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.29	Integer	enable (1)
ibTrapConfigSwitch.30	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.30	Integer	enable (1)
ibTrapConfigSwitch.31	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.31	Integer	enable (1)
ibTrapConfigSwitch.32	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.32	Integer	enable (1)



Name	OID	Value Type	Value Example
ibTrapConfigSwitch.33	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.33	Integer	enable (1)
ibTrapConfigSwitch.34	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.34	Integer	enable (1)
ibTrapConfigSwitch.35	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.35	Integer	enable (1)
ibTrapConfigSwitch.36	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.36	Integer	enable (1)
ibTrapConfigSwitch.37	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.37	Integer	enable (1)
ibTrapConfigSwitch.38	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.38	Integer	enable (1)
ibTrapConfigSwitch.39	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.39	Integer	enable (1)
ibTrapConfigSwitch.40	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.40	Integer	enable (1)
ibTrapConfigSwitch.41	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.41	Integer	enable (1)
ibTrapConfigSwitch.42	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.42	Integer	enable (1)
ibTrapConfigSwitch.43	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.43	Integer	enable (1)
ibTrapConfigSwitch.44	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.44	Integer	enable (1)
ibTrapConfigSwitch.45	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.45	Integer	enable (1)
ibTrapConfigSwitch.46	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.46	Integer	enable (1)
ibTrapConfigSwitch.47	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.47	Integer	enable (1)
ibTrapConfigSwitch.48	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.48	Integer	enable (1)
ibTrapConfigSwitch.49	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.49	Integer	enable (1)
ibTrapConfigSwitch.50	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.50	Integer	enable (1)
ibTrapConfigSwitch.51	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.51	Integer	enable (1)
ibTrapConfigSwitch.52	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.52	Integer	enable (1)
ibTrapConfigSwitch.53	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.53	Integer	enable (1)
ibTrapConfigSwitch.54	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.54	Integer	enable (1)
ibTrapConfigSwitch.55	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.55	Integer	enable (1)
ibTrapConfigSwitch.56	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.56	Integer	enable (1)
ibTrapConfigSwitch.57	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.57	Integer	enable (1)
ibTrapConfigSwitch.58	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.58	Integer	enable (1)
ibTrapConfigSwitch.59	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.59	Integer	enable (1)
ibTrapConfigSwitch.60	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.60	Integer	enable (1)
ibTrapConfigSwitch.61	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.61	Integer	enable (1)
ibTrapConfigSwitch.62	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.62	Integer	enable (1)
ibTrapConfigSwitch.63	1.3.6.1.4.1.26138.2.38.1.8.1.1.4.63	Integer	enable (1)
ibIfShutDownInterval.0	1.3.6.1.4.1.26138.2.40.1.2.0	Integer	30
ibIfStatFlowInterval.1	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.1	Integer	300
ibIfStatFlowInterval.2	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2	Integer	300
ibIfStatFlowInterval.3	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3	Integer	300
ibIfStatFlowInterval.4	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.4	Integer	300
ibIfStatFlowInterval.5	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5	Integer	300
ibIfStatFlowInterval.6	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6	Integer	300
ibIfStatFlowInterval.7	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7	Integer	300
ibIfStatFlowInterval.8	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.8	Integer	300
ibIfStatFlowInterval.9	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.9	Integer	300
ibIfStatFlowInterval.10	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.10	Integer	300
ibIfStatFlowInterval.11	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.11	Integer	300

Name	OID	Value Type	Value Example
ibLfStatFlowInterval.12	.3.6.1.4.1.26138.2.40.2.1.2.1.1.12	Integer	300
ibLfStatFlowInterval.13	.3.6.1.4.1.26138.2.40.2.1.2.1.1.13	Integer	300
ibLfStatFlowInterval.14	.3.6.1.4.1.26138.2.40.2.1.2.1.1.14	Integer	300
ibLfStatFlowInterval.15	.3.6.1.4.1.26138.2.40.2.1.2.1.1.15	Integer	300
ibLfStatFlowInterval.16	.3.6.1.4.1.26138.2.40.2.1.2.1.1.16	Integer	300
ibLfStatFlowInterval.17	.3.6.1.4.1.26138.2.40.2.1.2.1.1.17	Integer	300
ibLfStatFlowInterval.18	.3.6.1.4.1.26138.2.40.2.1.2.1.1.18	Integer	300
ibLfStatFlowInterval.19	.3.6.1.4.1.26138.2.40.2.1.2.1.1.19	Integer	300
ibLfStatFlowInterval.20	.3.6.1.4.1.26138.2.40.2.1.2.1.1.20	Integer	300
ibLfStatFlowInterval.21	.3.6.1.4.1.26138.2.40.2.1.2.1.1.21	Integer	300
ibLfStatFlowInterval.22	.3.6.1.4.1.26138.2.40.2.1.2.1.1.22	Integer	300
ibLfStatFlowInterval.23	.3.6.1.4.1.26138.2.40.2.1.2.1.1.23	Integer	300
ibLfStatFlowInterval.24	.3.6.1.4.1.26138.2.40.2.1.2.1.1.24	Integer	300
ibLfStatFlowInterval.25	.3.6.1.4.1.26138.2.40.2.1.2.1.1.25	Integer	300
ibLfStatFlowInterval.26	.3.6.1.4.1.26138.2.40.2.1.2.1.1.26	Integer	300
ibLfStatFlowInterval.27	.3.6.1.4.1.26138.2.40.2.1.2.1.1.27	Integer	300
ibLfStatFlowInterval.28	.3.6.1.4.1.26138.2.40.2.1.2.1.1.28	Integer	300
ibLfStatFlowInterval.29	.3.6.1.4.1.26138.2.40.2.1.2.1.1.29	Integer	300
ibLfStatFlowInterval.30	.3.6.1.4.1.26138.2.40.2.1.2.1.1.30	Integer	300
ibLfStatFlowInterval.31	.3.6.1.4.1.26138.2.40.2.1.2.1.1.31	Integer	300
ibLfStatFlowInterval.32	.3.6.1.4.1.26138.2.40.2.1.2.1.1.32	Integer	300
ibLfStatFlowInterval.33	.3.6.1.4.1.26138.2.40.2.1.2.1.1.33	Integer	300
ibLfStatFlowInterval.34	.3.6.1.4.1.26138.2.40.2.1.2.1.1.34	Integer	300
ibLfStatFlowInterval.35	.3.6.1.4.1.26138.2.40.2.1.2.1.1.35	Integer	300
ibLfStatFlowInterval.36	.3.6.1.4.1.26138.2.40.2.1.2.1.1.36	Integer	300
ibLfStatFlowInterval.37	.3.6.1.4.1.26138.2.40.2.1.2.1.1.37	Integer	300
ibLfStatFlowInterval.38	.3.6.1.4.1.26138.2.40.2.1.2.1.1.38	Integer	300
ibLfStatFlowInterval.39	.3.6.1.4.1.26138.2.40.2.1.2.1.1.39	Integer	300
ibLfStatFlowInterval.40	.3.6.1.4.1.26138.2.40.2.1.2.1.1.40	Integer	300
ibLfStatFlowInterval.41	.3.6.1.4.1.26138.2.40.2.1.2.1.1.41	Integer	300
ibLfStatFlowInterval.42	.3.6.1.4.1.26138.2.40.2.1.2.1.1.42	Integer	300
ibLfStatFlowInterval.43	.3.6.1.4.1.26138.2.40.2.1.2.1.1.43	Integer	300
ibLfStatFlowInterval.44	.3.6.1.4.1.26138.2.40.2.1.2.1.1.44	Integer	300
ibLfStatFlowInterval.45	.3.6.1.4.1.26138.2.40.2.1.2.1.1.45	Integer	300
ibLfStatFlowInterval.46	.3.6.1.4.1.26138.2.40.2.1.2.1.1.46	Integer	300
ibLfStatFlowInterval.47	.3.6.1.4.1.26138.2.40.2.1.2.1.1.47	Integer	300
ibLfStatFlowInterval.48	.3.6.1.4.1.26138.2.40.2.1.2.1.1.48	Integer	300
ibLfStatFlowInterval.49	.3.6.1.4.1.26138.2.40.2.1.2.1.1.49	Integer	300
ibLfStatFlowInterval.50	.3.6.1.4.1.26138.2.40.2.1.2.1.1.50	Integer	300
ibLfStatFlowInterval.51	.3.6.1.4.1.26138.2.40.2.1.2.1.1.51	Integer	300
ibLfStatFlowInterval.52	.3.6.1.4.1.26138.2.40.2.1.2.1.1.52	Integer	300
ibLfStatFlowInterval.53	.3.6.1.4.1.26138.2.40.2.1.2.1.1.53	Integer	300
ibLfStatFlowInterval.54	.3.6.1.4.1.26138.2.40.2.1.2.1.1.54	Integer	300

Name	OID	Value Type	Value Example
ibLfStatFlowInterval.631	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.1.631	Integer	300
ibLfStatFlowInterval.632	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.1.632	Integer	300
ibLfStatFlowInterval.633	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.1.633	Integer	300
ibLfStatFlowInterval.634	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.1.634	Integer	300
ibLfStatFlowInBits.1	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.1	Gauge	56908280
ibLfStatFlowInBits.2	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.2	Gauge	0
ibLfStatFlowInBits.3	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.3	Gauge	0
ibLfStatFlowInBits.4	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.4	Gauge	0
ibLfStatFlowInBits.5	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.5	Gauge	0
ibLfStatFlowInBits.6	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.6	Gauge	0
ibLfStatFlowInBits.7	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.7	Gauge	0
ibLfStatFlowInBits.8	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.8	Gauge	0
ibLfStatFlowInBits.9	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.9	Gauge	0
ibLfStatFlowInBits.10	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.10	Gauge	0
ibLfStatFlowInBits.11	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.11	Gauge	0
ibLfStatFlowInBits.12	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.12	Gauge	0
ibLfStatFlowInBits.13	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.13	Gauge	0
ibLfStatFlowInBits.14	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.14	Gauge	0
ibLfStatFlowInBits.15	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.15	Gauge	0
ibLfStatFlowInBits.16	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.16	Gauge	0
ibLfStatFlowInBits.17	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.17	Gauge	0
ibLfStatFlowInBits.18	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.18	Gauge	0
ibLfStatFlowInBits.19	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.19	Gauge	0
ibLfStatFlowInBits.20	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.20	Gauge	0
ibLfStatFlowInBits.21	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.21	Gauge	0
ibLfStatFlowInBits.22	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.22	Gauge	0
ibLfStatFlowInBits.23	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.23	Gauge	0
ibLfStatFlowInBits.24	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.24	Gauge	0
ibLfStatFlowInBits.25	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.25	Gauge	0
ibLfStatFlowInBits.26	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.26	Gauge	0
ibLfStatFlowInBits.27	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.27	Gauge	0
ibLfStatFlowInBits.28	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.28	Gauge	0
ibLfStatFlowInBits.29	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.29	Gauge	0
ibLfStatFlowInBits.30	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.30	Gauge	0
ibLfStatFlowInBits.31	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.31	Gauge	0
ibLfStatFlowInBits.32	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.32	Gauge	0
ibLfStatFlowInBits.33	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.33	Gauge	0
ibLfStatFlowInBits.34	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.34	Gauge	0
ibLfStatFlowInBits.35	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.35	Gauge	0
ibLfStatFlowInBits.36	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.36	Gauge	0
ibLfStatFlowInBits.37	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.37	Gauge	0
ibLfStatFlowInBits.38	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.38	Gauge	0
ibLfStatFlowInBits.39	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.39	Gauge	0

Name	OID	Value Type	Value Example
ibLfStatFlowInBits.40	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.40	Gauge	0
ibLfStatFlowInBits.41	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.41	Gauge	0
ibLfStatFlowInBits.42	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.42	Gauge	0
ibLfStatFlowInBits.43	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.43	Gauge	0
ibLfStatFlowInBits.44	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.44	Gauge	0
ibLfStatFlowInBits.45	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.45	Gauge	0
ibLfStatFlowInBits.46	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.46	Gauge	0
ibLfStatFlowInBits.47	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.47	Gauge	0
ibLfStatFlowInBits.48	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.48	Gauge	0
ibLfStatFlowInBits.49	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.49	Gauge	0
ibLfStatFlowInBits.50	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.50	Gauge	0
ibLfStatFlowInBits.51	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.51	Gauge	0
ibLfStatFlowInBits.52	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.52	Gauge	0
ibLfStatFlowInBits.53	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.53	Gauge	0
ibLfStatFlowInBits.54	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.54	Gauge	0
ibLfStatFlowInBits.631	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.631	Gauge	0
ibLfStatFlowInBits.632	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.632	Gauge	0
ibLfStatFlowInBits.633	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.633	Gauge	0
ibLfStatFlowInBits.634	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.2.634	Gauge	0
ibLfStatFlowOutBits.1	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.1	Gauge	12459808
ibLfStatFlowOutBits.2	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.2	Gauge	0
ibLfStatFlowOutBits.3	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.3	Gauge	0
ibLfStatFlowOutBits.4	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.4	Gauge	0
ibLfStatFlowOutBits.5	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.5	Gauge	0
ibLfStatFlowOutBits.6	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.6	Gauge	0
ibLfStatFlowOutBits.7	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.7	Gauge	0
ibLfStatFlowOutBits.8	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.8	Gauge	0
ibLfStatFlowOutBits.9	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.9	Gauge	0
ibLfStatFlowOutBits.10	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.10	Gauge	0
ibLfStatFlowOutBits.11	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.11	Gauge	0
ibLfStatFlowOutBits.12	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.12	Gauge	0
ibLfStatFlowOutBits.13	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.13	Gauge	0
ibLfStatFlowOutBits.14	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.14	Gauge	0
ibLfStatFlowOutBits.15	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.15	Gauge	0
ibLfStatFlowOutBits.16	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.16	Gauge	0
ibLfStatFlowOutBits.17	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.17	Gauge	0
ibLfStatFlowOutBits.18	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.18	Gauge	0
ibLfStatFlowOutBits.19	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.19	Gauge	0
ibLfStatFlowOutBits.20	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.20	Gauge	0
ibLfStatFlowOutBits.21	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.21	Gauge	0
ibLfStatFlowOutBits.22	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.22	Gauge	0
ibLfStatFlowOutBits.23	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.23	Gauge	0
ibLfStatFlowOutBits.24	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.24	Gauge	0

Name	OID	Value Type	Value Example
ibIfStatFlowOutBits.25	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.25	Gauge	0
ibIfStatFlowOutBits.26	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.26	Gauge	0
ibIfStatFlowOutBits.27	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.27	Gauge	0
ibIfStatFlowOutBits.28	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.28	Gauge	0
ibIfStatFlowOutBits.29	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.29	Gauge	0
ibIfStatFlowOutBits.30	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.30	Gauge	0
ibIfStatFlowOutBits.31	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.31	Gauge	0
ibIfStatFlowOutBits.32	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.32	Gauge	0
ibIfStatFlowOutBits.33	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.33	Gauge	0
ibIfStatFlowOutBits.34	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.34	Gauge	0
ibIfStatFlowOutBits.35	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.35	Gauge	0
ibIfStatFlowOutBits.36	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.36	Gauge	0
ibIfStatFlowOutBits.37	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.37	Gauge	0
ibIfStatFlowOutBits.38	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.38	Gauge	0
ibIfStatFlowOutBits.39	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.39	Gauge	0
ibIfStatFlowOutBits.40	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.40	Gauge	0
ibIfStatFlowOutBits.41	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.41	Gauge	0
ibIfStatFlowOutBits.42	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.42	Gauge	0
ibIfStatFlowOutBits.43	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.43	Gauge	0
ibIfStatFlowOutBits.44	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.44	Gauge	0
ibIfStatFlowOutBits.45	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.45	Gauge	0
ibIfStatFlowOutBits.46	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.46	Gauge	0
ibIfStatFlowOutBits.47	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.47	Gauge	0
ibIfStatFlowOutBits.48	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.48	Gauge	0
ibIfStatFlowOutBits.49	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.49	Gauge	0
ibIfStatFlowOutBits.50	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.50	Gauge	0
ibIfStatFlowOutBits.51	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.51	Gauge	0
ibIfStatFlowOutBits.52	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.52	Gauge	0
ibIfStatFlowOutBits.53	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.53	Gauge	0
ibIfStatFlowOutBits.54	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.54	Gauge	0
ibIfStatFlowOutBits.631	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.631	Gauge	0
ibIfStatFlowOutBits.632	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.632	Gauge	0
ibIfStatFlowOutBits.633	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.633	Gauge	0
ibIfStatFlowOutBits.634	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.3.634	Gauge	0
ibIfStatFlowInPkts.1	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.1	Gauge	86448
ibIfStatFlowInPkts.2	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.2	Gauge	0
ibIfStatFlowInPkts.3	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.3	Gauge	0
ibIfStatFlowInPkts.4	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.4	Gauge	0
ibIfStatFlowInPkts.5	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.5	Gauge	0
ibIfStatFlowInPkts.6	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.6	Gauge	0
ibIfStatFlowInPkts.7	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.7	Gauge	0
ibIfStatFlowInPkts.8	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.8	Gauge	0
ibIfStatFlowInPkts.9	1.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.9	Gauge	0

Name	OID	Value Type	Value Example
ibLfStatFlowInPkts.10	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.10	Gauge	0
ibLfStatFlowInPkts.11	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.11	Gauge	0
ibLfStatFlowInPkts.12	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.12	Gauge	0
ibLfStatFlowInPkts.13	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.13	Gauge	0
ibLfStatFlowInPkts.14	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.14	Gauge	0
ibLfStatFlowInPkts.15	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.15	Gauge	0
ibLfStatFlowInPkts.16	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.16	Gauge	0
ibLfStatFlowInPkts.17	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.17	Gauge	0
ibLfStatFlowInPkts.18	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.18	Gauge	0
ibLfStatFlowInPkts.19	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.19	Gauge	0
ibLfStatFlowInPkts.20	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.20	Gauge	0
ibLfStatFlowInPkts.21	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.21	Gauge	0
ibLfStatFlowInPkts.22	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.22	Gauge	0
ibLfStatFlowInPkts.23	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.23	Gauge	0
ibLfStatFlowInPkts.24	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.24	Gauge	0
ibLfStatFlowInPkts.25	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.25	Gauge	0
ibLfStatFlowInPkts.26	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.26	Gauge	0
ibLfStatFlowInPkts.27	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.27	Gauge	0
ibLfStatFlowInPkts.28	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.28	Gauge	0
ibLfStatFlowInPkts.29	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.29	Gauge	0
ibLfStatFlowInPkts.30	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.30	Gauge	0
ibLfStatFlowInPkts.31	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.31	Gauge	0
ibLfStatFlowInPkts.32	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.32	Gauge	0
ibLfStatFlowInPkts.33	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.33	Gauge	0
ibLfStatFlowInPkts.34	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.34	Gauge	0
ibLfStatFlowInPkts.35	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.35	Gauge	0
ibLfStatFlowInPkts.36	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.36	Gauge	0
ibLfStatFlowInPkts.37	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.37	Gauge	0
ibLfStatFlowInPkts.38	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.38	Gauge	0
ibLfStatFlowInPkts.39	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.39	Gauge	0
ibLfStatFlowInPkts.40	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.40	Gauge	0
ibLfStatFlowInPkts.41	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.41	Gauge	0
ibLfStatFlowInPkts.42	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.42	Gauge	0
ibLfStatFlowInPkts.43	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.43	Gauge	0
ibLfStatFlowInPkts.44	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.44	Gauge	0
ibLfStatFlowInPkts.45	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.45	Gauge	0
ibLfStatFlowInPkts.46	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.46	Gauge	0
ibLfStatFlowInPkts.47	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.47	Gauge	0
ibLfStatFlowInPkts.48	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.48	Gauge	0
ibLfStatFlowInPkts.49	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.49	Gauge	0
ibLfStatFlowInPkts.50	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.50	Gauge	0
ibLfStatFlowInPkts.51	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.51	Gauge	0
ibLfStatFlowInPkts.52	.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.52	Gauge	0

Name	OID	Value Type	Value Example
ibLfStatFlowInPkts.53	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.53	Gauge	0
ibLfStatFlowInPkts.54	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.54	Gauge	0
ibLfStatFlowInPkts.631	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.631	Gauge	0
ibLfStatFlowInPkts.632	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.632	Gauge	0
ibLfStatFlowInPkts.633	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.633	Gauge	0
ibLfStatFlowInPkts.634	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.4.634	Gauge	0
ibLfStatFlowOutPkts.1	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.1	Gauge	16004
ibLfStatFlowOutPkts.2	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.2	Gauge	0
ibLfStatFlowOutPkts.3	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.3	Gauge	0
ibLfStatFlowOutPkts.4	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.4	Gauge	0
ibLfStatFlowOutPkts.5	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.5	Gauge	0
ibLfStatFlowOutPkts.6	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.6	Gauge	0
ibLfStatFlowOutPkts.7	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.7	Gauge	0
ibLfStatFlowOutPkts.8	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.8	Gauge	0
ibLfStatFlowOutPkts.9	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.9	Gauge	0
ibLfStatFlowOutPkts.10	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.10	Gauge	0
ibLfStatFlowOutPkts.11	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.11	Gauge	0
ibLfStatFlowOutPkts.12	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.12	Gauge	0
ibLfStatFlowOutPkts.13	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.13	Gauge	0
ibLfStatFlowOutPkts.14	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.14	Gauge	0
ibLfStatFlowOutPkts.15	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.15	Gauge	0
ibLfStatFlowOutPkts.16	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.16	Gauge	0
ibLfStatFlowOutPkts.17	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.17	Gauge	0
ibLfStatFlowOutPkts.18	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.18	Gauge	0
ibLfStatFlowOutPkts.19	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.19	Gauge	0
ibLfStatFlowOutPkts.20	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.20	Gauge	0
ibLfStatFlowOutPkts.21	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.21	Gauge	0
ibLfStatFlowOutPkts.22	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.22	Gauge	0
ibLfStatFlowOutPkts.23	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.23	Gauge	0
ibLfStatFlowOutPkts.24	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.24	Gauge	0
ibLfStatFlowOutPkts.25	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.25	Gauge	0
ibLfStatFlowOutPkts.26	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.26	Gauge	0
ibLfStatFlowOutPkts.27	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.27	Gauge	0
ibLfStatFlowOutPkts.28	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.28	Gauge	0
ibLfStatFlowOutPkts.29	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.29	Gauge	0
ibLfStatFlowOutPkts.30	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.30	Gauge	0
ibLfStatFlowOutPkts.31	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.31	Gauge	0
ibLfStatFlowOutPkts.32	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.32	Gauge	0
ibLfStatFlowOutPkts.33	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.33	Gauge	0
ibLfStatFlowOutPkts.34	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.34	Gauge	0
ibLfStatFlowOutPkts.35	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.35	Gauge	0
ibLfStatFlowOutPkts.36	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.36	Gauge	0
ibLfStatFlowOutPkts.37	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.37	Gauge	0



Name	OID	Value Type	Value Example
ibIfStatFlowOutPkts.38	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.38	Gauge	0
ibIfStatFlowOutPkts.39	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.39	Gauge	0
ibIfStatFlowOutPkts.40	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.40	Gauge	0
ibIfStatFlowOutPkts.41	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.41	Gauge	0
ibIfStatFlowOutPkts.42	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.42	Gauge	0
ibIfStatFlowOutPkts.43	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.43	Gauge	0
ibIfStatFlowOutPkts.44	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.44	Gauge	0
ibIfStatFlowOutPkts.45	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.45	Gauge	0
ibIfStatFlowOutPkts.46	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.46	Gauge	0
ibIfStatFlowOutPkts.47	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.47	Gauge	0
ibIfStatFlowOutPkts.48	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.48	Gauge	0
ibIfStatFlowOutPkts.49	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.49	Gauge	0
ibIfStatFlowOutPkts.50	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.50	Gauge	0
ibIfStatFlowOutPkts.51	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.51	Gauge	0
ibIfStatFlowOutPkts.52	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.52	Gauge	0
ibIfStatFlowOutPkts.53	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.53	Gauge	0
ibIfStatFlowOutPkts.54	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.54	Gauge	0
ibIfStatFlowOutPkts.631	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.631	Gauge	0
ibIfStatFlowOutPkts.632	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.632	Gauge	0
ibIfStatFlowOutPkts.633	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.633	Gauge	0
ibIfStatFlowOutPkts.634	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.5.634	Gauge	0
ibIfStatFlowInBytes.1	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.1	Gauge	7141577
ibIfStatFlowInBytes.2	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.2	Gauge	0
ibIfStatFlowInBytes.3	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.3	Gauge	0
ibIfStatFlowInBytes.4	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.4	Gauge	0
ibIfStatFlowInBytes.5	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.5	Gauge	0
ibIfStatFlowInBytes.6	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.6	Gauge	0
ibIfStatFlowInBytes.7	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.7	Gauge	0
ibIfStatFlowInBytes.8	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.8	Gauge	0
ibIfStatFlowInBytes.9	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.9	Gauge	0
ibIfStatFlowInBytes.10	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.10	Gauge	0
ibIfStatFlowInBytes.11	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.11	Gauge	0
ibIfStatFlowInBytes.12	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.12	Gauge	0
ibIfStatFlowInBytes.13	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.13	Gauge	0
ibIfStatFlowInBytes.14	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.14	Gauge	0
ibIfStatFlowInBytes.15	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.15	Gauge	0
ibIfStatFlowInBytes.16	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.16	Gauge	0
ibIfStatFlowInBytes.17	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.17	Gauge	0
ibIfStatFlowInBytes.18	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.18	Gauge	0
ibIfStatFlowInBytes.19	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.19	Gauge	0
ibIfStatFlowInBytes.20	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.20	Gauge	0
ibIfStatFlowInBytes.21	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.21	Gauge	0
ibIfStatFlowInBytes.22	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.22	Gauge	0



Name	OID	Value Type	Value Example
ibIfStatFlowInBytes.23	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.23	Gauge	0
ibIfStatFlowInBytes.24	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.24	Gauge	0
ibIfStatFlowInBytes.25	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.25	Gauge	0
ibIfStatFlowInBytes.26	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.26	Gauge	0
ibIfStatFlowInBytes.27	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.27	Gauge	0
ibIfStatFlowInBytes.28	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.28	Gauge	0
ibIfStatFlowInBytes.29	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.29	Gauge	0
ibIfStatFlowInBytes.30	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.30	Gauge	0
ibIfStatFlowInBytes.31	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.31	Gauge	0
ibIfStatFlowInBytes.32	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.32	Gauge	0
ibIfStatFlowInBytes.33	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.33	Gauge	0
ibIfStatFlowInBytes.34	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.34	Gauge	0
ibIfStatFlowInBytes.35	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.35	Gauge	0
ibIfStatFlowInBytes.36	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.36	Gauge	0
ibIfStatFlowInBytes.37	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.37	Gauge	0
ibIfStatFlowInBytes.38	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.38	Gauge	0
ibIfStatFlowInBytes.39	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.39	Gauge	0
ibIfStatFlowInBytes.40	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.40	Gauge	0
ibIfStatFlowInBytes.41	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.41	Gauge	0
ibIfStatFlowInBytes.42	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.42	Gauge	0
ibIfStatFlowInBytes.43	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.43	Gauge	0
ibIfStatFlowInBytes.44	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.44	Gauge	0
ibIfStatFlowInBytes.45	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.45	Gauge	0
ibIfStatFlowInBytes.46	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.46	Gauge	0
ibIfStatFlowInBytes.47	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.47	Gauge	0
ibIfStatFlowInBytes.48	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.48	Gauge	0
ibIfStatFlowInBytes.49	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.49	Gauge	0
ibIfStatFlowInBytes.50	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.50	Gauge	0
ibIfStatFlowInBytes.51	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.51	Gauge	0
ibIfStatFlowInBytes.52	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.52	Gauge	0
ibIfStatFlowInBytes.53	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.53	Gauge	0
ibIfStatFlowInBytes.54	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.54	Gauge	0
ibIfStatFlowInBytes.631	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.631	Gauge	0
ibIfStatFlowInBytes.632	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.632	Gauge	0
ibIfStatFlowInBytes.633	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.633	Gauge	0
ibIfStatFlowInBytes.634	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.6.634	Gauge	0
ibIfStatFlowOutBytes.1	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.1	Gauge	1602880
ibIfStatFlowOutBytes.2	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.2	Gauge	0
ibIfStatFlowOutBytes.3	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.3	Gauge	0
ibIfStatFlowOutBytes.4	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.4	Gauge	0
ibIfStatFlowOutBytes.5	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.5	Gauge	0
ibIfStatFlowOutBytes.6	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.6	Gauge	0
ibIfStatFlowOutBytes.7	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.7	Gauge	0

Name	OID	Value Type	Value Example
ibLfStatFlowOutBytes.8	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.8	Gauge	0
ibLfStatFlowOutBytes.9	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.9	Gauge	0
ibLfStatFlowOutBytes.10	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.10	Gauge	0
ibLfStatFlowOutBytes.11	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.11	Gauge	0
ibLfStatFlowOutBytes.12	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.12	Gauge	0
ibLfStatFlowOutBytes.13	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.13	Gauge	0
ibLfStatFlowOutBytes.14	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.14	Gauge	0
ibLfStatFlowOutBytes.15	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.15	Gauge	0
ibLfStatFlowOutBytes.16	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.16	Gauge	0
ibLfStatFlowOutBytes.17	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.17	Gauge	0
ibLfStatFlowOutBytes.18	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.18	Gauge	0
ibLfStatFlowOutBytes.19	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.19	Gauge	0
ibLfStatFlowOutBytes.20	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.20	Gauge	0
ibLfStatFlowOutBytes.21	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.21	Gauge	0
ibLfStatFlowOutBytes.22	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.22	Gauge	0
ibLfStatFlowOutBytes.23	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.23	Gauge	0
ibLfStatFlowOutBytes.24	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.24	Gauge	0
ibLfStatFlowOutBytes.25	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.25	Gauge	0
ibLfStatFlowOutBytes.26	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.26	Gauge	0
ibLfStatFlowOutBytes.27	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.27	Gauge	0
ibLfStatFlowOutBytes.28	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.28	Gauge	0
ibLfStatFlowOutBytes.29	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.29	Gauge	0
ibLfStatFlowOutBytes.30	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.30	Gauge	0
ibLfStatFlowOutBytes.31	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.31	Gauge	0
ibLfStatFlowOutBytes.32	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.32	Gauge	0
ibLfStatFlowOutBytes.33	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.33	Gauge	0
ibLfStatFlowOutBytes.34	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.34	Gauge	0
ibLfStatFlowOutBytes.35	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.35	Gauge	0
ibLfStatFlowOutBytes.36	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.36	Gauge	0
ibLfStatFlowOutBytes.37	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.37	Gauge	0
ibLfStatFlowOutBytes.38	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.38	Gauge	0
ibLfStatFlowOutBytes.39	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.39	Gauge	0
ibLfStatFlowOutBytes.40	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.40	Gauge	0
ibLfStatFlowOutBytes.41	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.41	Gauge	0
ibLfStatFlowOutBytes.42	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.42	Gauge	0
ibLfStatFlowOutBytes.43	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.43	Gauge	0
ibLfStatFlowOutBytes.44	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.44	Gauge	0
ibLfStatFlowOutBytes.45	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.45	Gauge	0
ibLfStatFlowOutBytes.46	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.46	Gauge	0
ibLfStatFlowOutBytes.47	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.47	Gauge	0
ibLfStatFlowOutBytes.48	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.48	Gauge	0
ibLfStatFlowOutBytes.49	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.49	Gauge	0
ibLfStatFlowOutBytes.50	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.50	Gauge	0

Name	OID	Value Type	Value Example
iblfStatFlowOutBytes.51	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.51	Gauge	0
iblfStatFlowOutBytes.52	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.52	Gauge	0
iblfStatFlowOutBytes.53	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.53	Gauge	0
iblfStatFlowOutBytes.54	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.54	Gauge	0
iblfStatFlowOutBytes.631	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.631	Gauge	0
iblfStatFlowOutBytes.632	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.632	Gauge	0
iblfStatFlowOutBytes.633	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.633	Gauge	0
iblfStatFlowOutBytes.634	.1.3.6.1.4.1.26138.2.40.2.1.2.1.1.7.634	Gauge	0
iblfSpeedStatInterval.1	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.1	Integer	300
iblfSpeedStatInterval.2	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.2	Integer	300
iblfSpeedStatInterval.3	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.3	Integer	300
iblfSpeedStatInterval.4	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.4	Integer	300
iblfSpeedStatInterval.5	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.5	Integer	300
iblfSpeedStatInterval.6	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.6	Integer	300
iblfSpeedStatInterval.7	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.7	Integer	300
iblfSpeedStatInterval.8	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.8	Integer	300
iblfSpeedStatInterval.9	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.9	Integer	300
iblfSpeedStatInterval.10	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.10	Integer	300
iblfSpeedStatInterval.11	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.11	Integer	300
iblfSpeedStatInterval.12	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.12	Integer	300
iblfSpeedStatInterval.13	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.13	Integer	300
iblfSpeedStatInterval.14	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.14	Integer	300
iblfSpeedStatInterval.15	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.15	Integer	300
iblfSpeedStatInterval.16	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.16	Integer	300
iblfSpeedStatInterval.17	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.17	Integer	300
iblfSpeedStatInterval.18	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.18	Integer	300
iblfSpeedStatInterval.19	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.19	Integer	300
iblfSpeedStatInterval.20	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.20	Integer	300
iblfSpeedStatInterval.21	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.21	Integer	300
iblfSpeedStatInterval.22	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.22	Integer	300
iblfSpeedStatInterval.23	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.23	Integer	300
iblfSpeedStatInterval.24	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.24	Integer	300
iblfSpeedStatInterval.25	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.25	Integer	300
iblfSpeedStatInterval.26	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.26	Integer	300
iblfSpeedStatInterval.27	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.27	Integer	300
iblfSpeedStatInterval.28	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.28	Integer	300
iblfSpeedStatInterval.29	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.29	Integer	300
iblfSpeedStatInterval.30	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.30	Integer	300
iblfSpeedStatInterval.31	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.31	Integer	300
iblfSpeedStatInterval.32	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.32	Integer	300
iblfSpeedStatInterval.33	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.33	Integer	300
iblfSpeedStatInterval.34	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.34	Integer	300
iblfSpeedStatInterval.35	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.35	Integer	300

Name	OID	Value Type	Value Example
ibLfSpeedStatInterval.36	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.36	Integer	300
ibLfSpeedStatInterval.37	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.37	Integer	300
ibLfSpeedStatInterval.38	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.38	Integer	300
ibLfSpeedStatInterval.39	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.39	Integer	300
ibLfSpeedStatInterval.40	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.40	Integer	300
ibLfSpeedStatInterval.41	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.41	Integer	300
ibLfSpeedStatInterval.42	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.42	Integer	300
ibLfSpeedStatInterval.43	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.43	Integer	300
ibLfSpeedStatInterval.44	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.44	Integer	300
ibLfSpeedStatInterval.45	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.45	Integer	300
ibLfSpeedStatInterval.46	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.46	Integer	300
ibLfSpeedStatInterval.47	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.47	Integer	300
ibLfSpeedStatInterval.48	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.48	Integer	300
ibLfSpeedStatInterval.49	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.49	Integer	300
ibLfSpeedStatInterval.50	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.50	Integer	300
ibLfSpeedStatInterval.51	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.51	Integer	300
ibLfSpeedStatInterval.52	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.52	Integer	300
ibLfSpeedStatInterval.53	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.53	Integer	300
ibLfSpeedStatInterval.54	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.54	Integer	300
ibLfSpeedStatInterval.631	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.631	Integer	300
ibLfSpeedStatInterval.632	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.632	Integer	300
ibLfSpeedStatInterval.633	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.1.633	Integer	300
ibLfSpeedStatInPkts.1	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.1	Gauge	250
ibLfSpeedStatInPkts.2	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.2	Gauge	0
ibLfSpeedStatInPkts.3	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.3	Gauge	0
ibLfSpeedStatInPkts.4	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.4	Gauge	0
ibLfSpeedStatInPkts.5	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.5	Gauge	0
ibLfSpeedStatInPkts.6	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.6	Gauge	0
ibLfSpeedStatInPkts.7	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.7	Gauge	0
ibLfSpeedStatInPkts.8	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.8	Gauge	0
ibLfSpeedStatInPkts.9	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.9	Gauge	0
ibLfSpeedStatInPkts.10	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.10	Gauge	0
ibLfSpeedStatInPkts.11	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.11	Gauge	0
ibLfSpeedStatInPkts.12	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.12	Gauge	0
ibLfSpeedStatInPkts.13	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.13	Gauge	0
ibLfSpeedStatInPkts.14	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.14	Gauge	0
ibLfSpeedStatInPkts.15	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.15	Gauge	0
ibLfSpeedStatInPkts.16	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.16	Gauge	0
ibLfSpeedStatInPkts.17	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.17	Gauge	0
ibLfSpeedStatInPkts.18	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.18	Gauge	0
ibLfSpeedStatInPkts.19	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.19	Gauge	0
ibLfSpeedStatInPkts.20	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.20	Gauge	0
ibLfSpeedStatInPkts.21	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.21	Gauge	0

Name	OID	Value Type	Value Example
ibLfSpeedStatInPkts.22	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.22	Gauge	0
ibLfSpeedStatInPkts.23	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.23	Gauge	0
ibLfSpeedStatInPkts.24	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.24	Gauge	0
ibLfSpeedStatInPkts.25	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.25	Gauge	0
ibLfSpeedStatInPkts.26	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.26	Gauge	0
ibLfSpeedStatInPkts.27	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.27	Gauge	0
ibLfSpeedStatInPkts.28	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.28	Gauge	0
ibLfSpeedStatInPkts.29	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.29	Gauge	0
ibLfSpeedStatInPkts.30	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.30	Gauge	0
ibLfSpeedStatInPkts.31	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.31	Gauge	0
ibLfSpeedStatInPkts.32	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.32	Gauge	0
ibLfSpeedStatInPkts.33	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.33	Gauge	0
ibLfSpeedStatInPkts.34	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.34	Gauge	0
ibLfSpeedStatInPkts.35	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.35	Gauge	0
ibLfSpeedStatInPkts.36	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.36	Gauge	0
ibLfSpeedStatInPkts.37	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.37	Gauge	0
ibLfSpeedStatInPkts.38	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.38	Gauge	0
ibLfSpeedStatInPkts.39	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.39	Gauge	0
ibLfSpeedStatInPkts.40	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.40	Gauge	0
ibLfSpeedStatInPkts.41	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.41	Gauge	0
ibLfSpeedStatInPkts.42	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.42	Gauge	0
ibLfSpeedStatInPkts.43	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.43	Gauge	0
ibLfSpeedStatInPkts.44	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.44	Gauge	0
ibLfSpeedStatInPkts.45	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.45	Gauge	0
ibLfSpeedStatInPkts.46	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.46	Gauge	0
ibLfSpeedStatInPkts.47	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.47	Gauge	0
ibLfSpeedStatInPkts.48	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.48	Gauge	0
ibLfSpeedStatInPkts.49	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.49	Gauge	0
ibLfSpeedStatInPkts.50	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.50	Gauge	0
ibLfSpeedStatInPkts.51	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.51	Gauge	0
ibLfSpeedStatInPkts.52	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.52	Gauge	0
ibLfSpeedStatInPkts.53	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.53	Gauge	0
ibLfSpeedStatInPkts.54	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.54	Gauge	0
ibLfSpeedStatInPkts.631	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.631	Gauge	0
ibLfSpeedStatInPkts.632	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.632	Gauge	0
ibLfSpeedStatInPkts.633	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.2.633	Gauge	0
ibLfSpeedStatOutPkts.1	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.1	Gauge	46
ibLfSpeedStatOutPkts.2	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.2	Gauge	0
ibLfSpeedStatOutPkts.3	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.3	Gauge	0
ibLfSpeedStatOutPkts.4	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.4	Gauge	0
ibLfSpeedStatOutPkts.5	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.5	Gauge	0
ibLfSpeedStatOutPkts.6	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.6	Gauge	0
ibLfSpeedStatOutPkts.7	1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.7	Gauge	0

Name	OID	Value Type	Value Example
ibLfSpeedStatOutPkts.8	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.8	Gauge	0
ibLfSpeedStatOutPkts.9	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.9	Gauge	0
ibLfSpeedStatOutPkts.10	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.10	Gauge	0
ibLfSpeedStatOutPkts.11	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.11	Gauge	0
ibLfSpeedStatOutPkts.12	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.12	Gauge	0
ibLfSpeedStatOutPkts.13	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.13	Gauge	0
ibLfSpeedStatOutPkts.14	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.14	Gauge	0
ibLfSpeedStatOutPkts.15	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.15	Gauge	0
ibLfSpeedStatOutPkts.16	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.16	Gauge	0
ibLfSpeedStatOutPkts.17	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.17	Gauge	0
ibLfSpeedStatOutPkts.18	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.18	Gauge	0
ibLfSpeedStatOutPkts.19	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.19	Gauge	0
ibLfSpeedStatOutPkts.20	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.20	Gauge	0
ibLfSpeedStatOutPkts.21	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.21	Gauge	0
ibLfSpeedStatOutPkts.22	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.22	Gauge	0
ibLfSpeedStatOutPkts.23	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.23	Gauge	0
ibLfSpeedStatOutPkts.24	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.24	Gauge	0
ibLfSpeedStatOutPkts.25	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.25	Gauge	0
ibLfSpeedStatOutPkts.26	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.26	Gauge	0
ibLfSpeedStatOutPkts.27	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.27	Gauge	0
ibLfSpeedStatOutPkts.28	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.28	Gauge	0
ibLfSpeedStatOutPkts.29	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.29	Gauge	0
ibLfSpeedStatOutPkts.30	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.30	Gauge	0
ibLfSpeedStatOutPkts.31	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.31	Gauge	0
ibLfSpeedStatOutPkts.32	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.32	Gauge	0
ibLfSpeedStatOutPkts.33	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.33	Gauge	0
ibLfSpeedStatOutPkts.34	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.34	Gauge	0
ibLfSpeedStatOutPkts.35	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.35	Gauge	0
ibLfSpeedStatOutPkts.36	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.36	Gauge	0
ibLfSpeedStatOutPkts.37	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.37	Gauge	0
ibLfSpeedStatOutPkts.38	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.38	Gauge	0
ibLfSpeedStatOutPkts.39	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.39	Gauge	0
ibLfSpeedStatOutPkts.40	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.40	Gauge	0
ibLfSpeedStatOutPkts.41	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.41	Gauge	0
ibLfSpeedStatOutPkts.42	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.42	Gauge	0
ibLfSpeedStatOutPkts.43	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.43	Gauge	0
ibLfSpeedStatOutPkts.44	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.44	Gauge	0
ibLfSpeedStatOutPkts.45	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.45	Gauge	0
ibLfSpeedStatOutPkts.46	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.46	Gauge	0
ibLfSpeedStatOutPkts.47	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.47	Gauge	0
ibLfSpeedStatOutPkts.48	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.48	Gauge	0
ibLfSpeedStatOutPkts.49	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.49	Gauge	0
ibLfSpeedStatOutPkts.50	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.50	Gauge	0



Name	OID	Value Type	Value Example
ibLfSpeedStatOutPkts.51	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.51	Gauge	0
ibLfSpeedStatOutPkts.52	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.52	Gauge	0
ibLfSpeedStatOutPkts.53	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.53	Gauge	0
ibLfSpeedStatOutPkts.54	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.54	Gauge	0
ibLfSpeedStatOutPkts.631	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.631	Gauge	0
ibLfSpeedStatOutPkts.632	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.632	Gauge	0
ibLfSpeedStatOutPkts.633	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.3.633	Gauge	0
ibLfSpeedStatInBytes.1	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.1	Gauge	20661
ibLfSpeedStatInBytes.2	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.2	Gauge	0
ibLfSpeedStatInBytes.3	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.3	Gauge	0
ibLfSpeedStatInBytes.4	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.4	Gauge	0
ibLfSpeedStatInBytes.5	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.5	Gauge	0
ibLfSpeedStatInBytes.6	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.6	Gauge	0
ibLfSpeedStatInBytes.7	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.7	Gauge	0
ibLfSpeedStatInBytes.8	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.8	Gauge	0
ibLfSpeedStatInBytes.9	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.9	Gauge	0
ibLfSpeedStatInBytes.10	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.10	Gauge	0
ibLfSpeedStatInBytes.11	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.11	Gauge	0
ibLfSpeedStatInBytes.12	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.12	Gauge	0
ibLfSpeedStatInBytes.13	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.13	Gauge	0
ibLfSpeedStatInBytes.14	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.14	Gauge	0
ibLfSpeedStatInBytes.15	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.15	Gauge	0
ibLfSpeedStatInBytes.16	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.16	Gauge	0
ibLfSpeedStatInBytes.17	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.17	Gauge	0
ibLfSpeedStatInBytes.18	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.18	Gauge	0
ibLfSpeedStatInBytes.19	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.19	Gauge	0
ibLfSpeedStatInBytes.20	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.20	Gauge	0
ibLfSpeedStatInBytes.21	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.21	Gauge	0
ibLfSpeedStatInBytes.22	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.22	Gauge	0
ibLfSpeedStatInBytes.23	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.23	Gauge	0
ibLfSpeedStatInBytes.24	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.24	Gauge	0
ibLfSpeedStatInBytes.25	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.25	Gauge	0
ibLfSpeedStatInBytes.26	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.26	Gauge	0
ibLfSpeedStatInBytes.27	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.27	Gauge	0
ibLfSpeedStatInBytes.28	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.28	Gauge	0
ibLfSpeedStatInBytes.29	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.29	Gauge	0
ibLfSpeedStatInBytes.30	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.30	Gauge	0
ibLfSpeedStatInBytes.31	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.31	Gauge	0
ibLfSpeedStatInBytes.32	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.32	Gauge	0
ibLfSpeedStatInBytes.33	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.33	Gauge	0
ibLfSpeedStatInBytes.34	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.34	Gauge	0
ibLfSpeedStatInBytes.35	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.35	Gauge	0
ibLfSpeedStatInBytes.36	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.36	Gauge	0

Name	OID	Value Type	Value Example
ibLfSpeedStatInBytes.37	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.37	Gauge	0
ibLfSpeedStatInBytes.38	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.38	Gauge	0
ibLfSpeedStatInBytes.39	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.39	Gauge	0
ibLfSpeedStatInBytes.40	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.40	Gauge	0
ibLfSpeedStatInBytes.41	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.41	Gauge	0
ibLfSpeedStatInBytes.42	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.42	Gauge	0
ibLfSpeedStatInBytes.43	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.43	Gauge	0
ibLfSpeedStatInBytes.44	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.44	Gauge	0
ibLfSpeedStatInBytes.45	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.45	Gauge	0
ibLfSpeedStatInBytes.46	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.46	Gauge	0
ibLfSpeedStatInBytes.47	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.47	Gauge	0
ibLfSpeedStatInBytes.48	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.48	Gauge	0
ibLfSpeedStatInBytes.49	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.49	Gauge	0
ibLfSpeedStatInBytes.50	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.50	Gauge	0
ibLfSpeedStatInBytes.51	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.51	Gauge	0
ibLfSpeedStatInBytes.52	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.52	Gauge	0
ibLfSpeedStatInBytes.53	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.53	Gauge	0
ibLfSpeedStatInBytes.54	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.54	Gauge	0
ibLfSpeedStatInBytes.631	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.631	Gauge	0
ibLfSpeedStatInBytes.632	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.632	Gauge	0
ibLfSpeedStatInBytes.633	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.4.633	Gauge	0
ibLfSpeedStatOutBytes.1	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.1	Gauge	4780
ibLfSpeedStatOutBytes.2	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.2	Gauge	0
ibLfSpeedStatOutBytes.3	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.3	Gauge	0
ibLfSpeedStatOutBytes.4	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.4	Gauge	0
ibLfSpeedStatOutBytes.5	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.5	Gauge	0
ibLfSpeedStatOutBytes.6	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.6	Gauge	0
ibLfSpeedStatOutBytes.7	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.7	Gauge	0
ibLfSpeedStatOutBytes.8	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.8	Gauge	0
ibLfSpeedStatOutBytes.9	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.9	Gauge	0
ibLfSpeedStatOutBytes.10	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.10	Gauge	0
ibLfSpeedStatOutBytes.11	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.11	Gauge	0
ibLfSpeedStatOutBytes.12	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.12	Gauge	0
ibLfSpeedStatOutBytes.13	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.13	Gauge	0
ibLfSpeedStatOutBytes.14	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.14	Gauge	0
ibLfSpeedStatOutBytes.15	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.15	Gauge	0
ibLfSpeedStatOutBytes.16	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.16	Gauge	0
ibLfSpeedStatOutBytes.17	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.17	Gauge	0
ibLfSpeedStatOutBytes.18	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.18	Gauge	0
ibLfSpeedStatOutBytes.19	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.19	Gauge	0
ibLfSpeedStatOutBytes.20	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.20	Gauge	0
ibLfSpeedStatOutBytes.21	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.21	Gauge	0
ibLfSpeedStatOutBytes.22	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.22	Gauge	0



Name	OID	Value Type	Value Example
ibLfSpeedStatOutBytes.23	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.23	Gauge	0
ibLfSpeedStatOutBytes.24	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.24	Gauge	0
ibLfSpeedStatOutBytes.25	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.25	Gauge	0
ibLfSpeedStatOutBytes.26	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.26	Gauge	0
ibLfSpeedStatOutBytes.27	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.27	Gauge	0
ibLfSpeedStatOutBytes.28	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.28	Gauge	0
ibLfSpeedStatOutBytes.29	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.29	Gauge	0
ibLfSpeedStatOutBytes.30	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.30	Gauge	0
ibLfSpeedStatOutBytes.31	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.31	Gauge	0
ibLfSpeedStatOutBytes.32	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.32	Gauge	0
ibLfSpeedStatOutBytes.33	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.33	Gauge	0
ibLfSpeedStatOutBytes.34	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.34	Gauge	0
ibLfSpeedStatOutBytes.35	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.35	Gauge	0
ibLfSpeedStatOutBytes.36	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.36	Gauge	0
ibLfSpeedStatOutBytes.37	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.37	Gauge	0
ibLfSpeedStatOutBytes.38	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.38	Gauge	0
ibLfSpeedStatOutBytes.39	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.39	Gauge	0
ibLfSpeedStatOutBytes.40	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.40	Gauge	0
ibLfSpeedStatOutBytes.41	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.41	Gauge	0
ibLfSpeedStatOutBytes.42	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.42	Gauge	0
ibLfSpeedStatOutBytes.43	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.43	Gauge	0
ibLfSpeedStatOutBytes.44	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.44	Gauge	0
ibLfSpeedStatOutBytes.45	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.45	Gauge	0
ibLfSpeedStatOutBytes.46	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.46	Gauge	0
ibLfSpeedStatOutBytes.47	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.47	Gauge	0
ibLfSpeedStatOutBytes.48	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.48	Gauge	0
ibLfSpeedStatOutBytes.49	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.49	Gauge	0
ibLfSpeedStatOutBytes.50	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.50	Gauge	0
ibLfSpeedStatOutBytes.51	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.51	Gauge	0
ibLfSpeedStatOutBytes.52	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.52	Gauge	0
ibLfSpeedStatOutBytes.53	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.53	Gauge	0
ibLfSpeedStatOutBytes.54	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.54	Gauge	0
ibLfSpeedStatOutBytes.631	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.631	Gauge	0
ibLfSpeedStatOutBytes.632	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.632	Gauge	0
ibLfSpeedStatOutBytes.633	.1.3.6.1.4.1.26138.2.40.2.1.2.2.1.5.633	Gauge	0
ibLfLinkMode.1	.1.3.6.1.4.1.26138.2.40.2.2.3.1.2.1	Integer	bridgeMode (1)
ibLfLinkMode.2	.1.3.6.1.4.1.26138.2.40.2.2.3.1.2.2	Integer	bridgeMode (1)
ibLfLinkMode.3	.1.3.6.1.4.1.26138.2.40.2.2.3.1.2.3	Integer	bridgeMode (1)
ibLfLinkMode.4	.1.3.6.1.4.1.26138.2.40.2.2.3.1.2.4	Integer	bridgeMode (1)
ibLfLinkMode.5	.1.3.6.1.4.1.26138.2.40.2.2.3.1.2.5	Integer	bridgeMode (1)
ibLfLinkMode.6	.1.3.6.1.4.1.26138.2.40.2.2.3.1.2.6	Integer	bridgeMode (1)
ibLfLinkMode.7	.1.3.6.1.4.1.26138.2.40.2.2.3.1.2.7	Integer	bridgeMode (1)
ibLfLinkMode.8	.1.3.6.1.4.1.26138.2.40.2.2.3.1.2.8	Integer	bridgeMode (1)

Name	OID	Value Type	Value Example
ibLfLinkMode.9	.1.3.6.1.4.1.26138.2.40.2.2.3.1.2.9	Integer	bridgeMode (1)
ibLfLinkMode.10	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.10	Integer	bridgeMode (1)
ibLfLinkMode.11	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.11	Integer	bridgeMode (1)
ibLfLinkMode.12	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.12	Integer	bridgeMode (1)
ibLfLinkMode.13	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.13	Integer	bridgeMode (1)
ibLfLinkMode.14	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.14	Integer	bridgeMode (1)
ibLfLinkMode.15	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.15	Integer	bridgeMode (1)
ibLfLinkMode.16	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.16	Integer	bridgeMode (1)
ibLfLinkMode.17	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.17	Integer	bridgeMode (1)
ibLfLinkMode.18	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.18	Integer	bridgeMode (1)
ibLfLinkMode.19	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.19	Integer	bridgeMode (1)
ibLfLinkMode.20	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.20	Integer	bridgeMode (1)
ibLfLinkMode.21	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.21	Integer	bridgeMode (1)
ibLfLinkMode.22	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.22	Integer	bridgeMode (1)
ibLfLinkMode.23	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.23	Integer	bridgeMode (1)
ibLfLinkMode.24	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.24	Integer	bridgeMode (1)
ibLfLinkMode.25	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.25	Integer	bridgeMode (1)
ibLfLinkMode.26	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.26	Integer	bridgeMode (1)
ibLfLinkMode.27	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.27	Integer	bridgeMode (1)
ibLfLinkMode.28	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.28	Integer	bridgeMode (1)
ibLfLinkMode.29	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.29	Integer	bridgeMode (1)
ibLfLinkMode.30	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.30	Integer	bridgeMode (1)
ibLfLinkMode.31	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.31	Integer	bridgeMode (1)
ibLfLinkMode.32	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.32	Integer	bridgeMode (1)
ibLfLinkMode.33	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.33	Integer	bridgeMode (1)
ibLfLinkMode.34	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.34	Integer	bridgeMode (1)
ibLfLinkMode.35	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.35	Integer	bridgeMode (1)
ibLfLinkMode.36	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.36	Integer	bridgeMode (1)
ibLfLinkMode.37	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.37	Integer	bridgeMode (1)
ibLfLinkMode.38	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.38	Integer	bridgeMode (1)
ibLfLinkMode.39	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.39	Integer	bridgeMode (1)
ibLfLinkMode.40	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.40	Integer	bridgeMode (1)
ibLfLinkMode.41	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.41	Integer	bridgeMode (1)
ibLfLinkMode.42	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.42	Integer	bridgeMode (1)
ibLfLinkMode.43	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.43	Integer	bridgeMode (1)
ibLfLinkMode.44	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.44	Integer	bridgeMode (1)
ibLfLinkMode.45	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.45	Integer	bridgeMode (1)
ibLfLinkMode.46	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.46	Integer	bridgeMode (1)
ibLfLinkMode.47	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.47	Integer	bridgeMode (1)
ibLfLinkMode.48	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.48	Integer	bridgeMode (1)
ibLfLinkMode.49	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.49	Integer	bridgeMode (1)
ibLfLinkMode.50	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.50	Integer	bridgeMode (1)
ibLfLinkMode.51	1.3.6.1.4.1.26138.2.40.2.2.3.1.2.51	Integer	bridgeMode (1)



Name	OID	Value Type	Value Example
ibLfLinkModeSwitchSupport.41	1.3.6.1.4.1.26138.2.40.2.2.3.1.3.41	Integer	true (1)
ibLfLinkModeSwitchSupport.42	1.3.6.1.4.1.26138.2.40.2.2.3.1.3.42	Integer	true (1)
ibLfLinkModeSwitchSupport.43	1.3.6.1.4.1.26138.2.40.2.2.3.1.3.43	Integer	true (1)
ibLfLinkModeSwitchSupport.44	1.3.6.1.4.1.26138.2.40.2.2.3.1.3.44	Integer	true (1)
ibLfLinkModeSwitchSupport.45	1.3.6.1.4.1.26138.2.40.2.2.3.1.3.45	Integer	true (1)
ibLfLinkModeSwitchSupport.46	1.3.6.1.4.1.26138.2.40.2.2.3.1.3.46	Integer	true (1)
ibLfLinkModeSwitchSupport.47	1.3.6.1.4.1.26138.2.40.2.2.3.1.3.47	Integer	true (1)
ibLfLinkModeSwitchSupport.48	1.3.6.1.4.1.26138.2.40.2.2.3.1.3.48	Integer	true (1)
ibLfLinkModeSwitchSupport.49	1.3.6.1.4.1.26138.2.40.2.2.3.1.3.49	Integer	true (1)
ibLfLinkModeSwitchSupport.50	1.3.6.1.4.1.26138.2.40.2.2.3.1.3.50	Integer	true (1)
ibLfLinkModeSwitchSupport.51	1.3.6.1.4.1.26138.2.40.2.2.3.1.3.51	Integer	true (1)
ibLfLinkModeSwitchSupport.52	1.3.6.1.4.1.26138.2.40.2.2.3.1.3.52	Integer	true (1)
ibLfLinkModeSwitchSupport.53	1.3.6.1.4.1.26138.2.40.2.2.3.1.3.53	Integer	true (1)
ibLfLinkModeSwitchSupport.54	1.3.6.1.4.1.26138.2.40.2.2.3.1.3.54	Integer	true (1)
ibLfPortType.49	1.3.6.1.4.1.26138.2.40.2.2.4.1.2.49	Integer	other (1)
ibLfPortType.50	1.3.6.1.4.1.26138.2.40.2.2.4.1.2.50	Integer	other (1)
ibLfPortType.51	1.3.6.1.4.1.26138.2.40.2.2.4.1.2.51	Integer	other (1)
ibLfPortType.52	1.3.6.1.4.1.26138.2.40.2.2.4.1.2.52	Integer	other (1)
ibLfPortType.53	1.3.6.1.4.1.26138.2.40.2.2.4.1.2.53	Integer	other (1)
ibLfPortType.54	1.3.6.1.4.1.26138.2.40.2.2.4.1.2.54	Integer	other (1)
ibLfQueld.1.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.1.1	Integer	que0 (1)
ibLfQueld.1.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.1.2	Integer	que1 (2)
ibLfQueld.1.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.1.3	Integer	que2 (3)
ibLfQueld.1.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.1.4	Integer	que3 (4)
ibLfQueld.1.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.1.5	Integer	que4 (5)
ibLfQueld.1.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.1.6	Integer	que5 (6)
ibLfQueld.1.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.1.7	Integer	que6 (7)
ibLfQueld.1.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.1.8	Integer	que7 (8)
ibLfQueld.2.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.2.1	Integer	que0 (1)
ibLfQueld.2.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.2.2	Integer	que1 (2)
ibLfQueld.2.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.2.3	Integer	que2 (3)
ibLfQueld.2.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.2.4	Integer	que3 (4)
ibLfQueld.2.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.2.5	Integer	que4 (5)
ibLfQueld.2.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.2.6	Integer	que5 (6)
ibLfQueld.2.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.2.7	Integer	que6 (7)
ibLfQueld.2.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.2.8	Integer	que7 (8)
ibLfQueld.3.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.3.1	Integer	que0 (1)
ibLfQueld.3.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.3.2	Integer	que1 (2)
ibLfQueld.3.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.3.3	Integer	que2 (3)
ibLfQueld.3.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.3.4	Integer	que3 (4)
ibLfQueld.3.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.3.5	Integer	que4 (5)
ibLfQueld.3.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.3.6	Integer	que5 (6)
ibLfQueld.3.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.3.7	Integer	que6 (7)

Name	OID	Value Type	Value Example
iblfQueld.3.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.3.8	Integer	que7 (8)
iblfQueld.4.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.4.1	Integer	que0 (1)
iblfQueld.4.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.4.2	Integer	que1 (2)
iblfQueld.4.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.4.3	Integer	que2 (3)
iblfQueld.4.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.4.4	Integer	que3 (4)
iblfQueld.4.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.4.5	Integer	que4 (5)
iblfQueld.4.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.4.6	Integer	que5 (6)
iblfQueld.4.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.4.7	Integer	que6 (7)
iblfQueld.4.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.4.8	Integer	que7 (8)
iblfQueld.5.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.5.1	Integer	que0 (1)
iblfQueld.5.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.5.2	Integer	que1 (2)
iblfQueld.5.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.5.3	Integer	que2 (3)
iblfQueld.5.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.5.4	Integer	que3 (4)
iblfQueld.5.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.5.5	Integer	que4 (5)
iblfQueld.5.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.5.6	Integer	que5 (6)
iblfQueld.5.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.5.7	Integer	que6 (7)
iblfQueld.5.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.5.8	Integer	que7 (8)
iblfQueld.6.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.6.1	Integer	que0 (1)
iblfQueld.6.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.6.2	Integer	que1 (2)
iblfQueld.6.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.6.3	Integer	que2 (3)
iblfQueld.6.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.6.4	Integer	que3 (4)
iblfQueld.6.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.6.5	Integer	que4 (5)
iblfQueld.6.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.6.6	Integer	que5 (6)
iblfQueld.6.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.6.7	Integer	que6 (7)
iblfQueld.6.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.6.8	Integer	que7 (8)
iblfQueld.7.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.7.1	Integer	que0 (1)
iblfQueld.7.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.7.2	Integer	que1 (2)
iblfQueld.7.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.7.3	Integer	que2 (3)
iblfQueld.7.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.7.4	Integer	que3 (4)
iblfQueld.7.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.7.5	Integer	que4 (5)
iblfQueld.7.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.7.6	Integer	que5 (6)
iblfQueld.7.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.7.7	Integer	que6 (7)
iblfQueld.7.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.7.8	Integer	que7 (8)
iblfQueld.8.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.8.1	Integer	que0 (1)
iblfQueld.8.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.8.2	Integer	que1 (2)
iblfQueld.8.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.8.3	Integer	que2 (3)
iblfQueld.8.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.8.4	Integer	que3 (4)
iblfQueld.8.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.8.5	Integer	que4 (5)
iblfQueld.8.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.8.6	Integer	que5 (6)
iblfQueld.8.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.8.7	Integer	que6 (7)
iblfQueld.8.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.8.8	Integer	que7 (8)
iblfQueld.9.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.9.1	Integer	que0 (1)
iblfQueld.9.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.9.2	Integer	que1 (2)

Name	OID	Value Type	Value Example
iblfQueld.9.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.9.3	Integer	que2 (3)
iblfQueld.9.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.9.4	Integer	que3 (4)
iblfQueld.9.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.9.5	Integer	que4 (5)
iblfQueld.9.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.9.6	Integer	que5 (6)
iblfQueld.9.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.9.7	Integer	que6 (7)
iblfQueld.9.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.9.8	Integer	que7 (8)
iblfQueld.10.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.10.1	Integer	que0 (1)
iblfQueld.10.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.10.2	Integer	que1 (2)
iblfQueld.10.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.10.3	Integer	que2 (3)
iblfQueld.10.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.10.4	Integer	que3 (4)
iblfQueld.10.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.10.5	Integer	que4 (5)
iblfQueld.10.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.10.6	Integer	que5 (6)
iblfQueld.10.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.10.7	Integer	que6 (7)
iblfQueld.10.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.10.8	Integer	que7 (8)
iblfQueld.11.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.11.1	Integer	que0 (1)
iblfQueld.11.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.11.2	Integer	que1 (2)
iblfQueld.11.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.11.3	Integer	que2 (3)
iblfQueld.11.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.11.4	Integer	que3 (4)
iblfQueld.11.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.11.5	Integer	que4 (5)
iblfQueld.11.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.11.6	Integer	que5 (6)
iblfQueld.11.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.11.7	Integer	que6 (7)
iblfQueld.11.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.11.8	Integer	que7 (8)
iblfQueld.12.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.12.1	Integer	que0 (1)
iblfQueld.12.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.12.2	Integer	que1 (2)
iblfQueld.12.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.12.3	Integer	que2 (3)
iblfQueld.12.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.12.4	Integer	que3 (4)
iblfQueld.12.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.12.5	Integer	que4 (5)
iblfQueld.12.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.12.6	Integer	que5 (6)
iblfQueld.12.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.12.7	Integer	que6 (7)
iblfQueld.12.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.12.8	Integer	que7 (8)
iblfQueld.13.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.13.1	Integer	que0 (1)
iblfQueld.13.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.13.2	Integer	que1 (2)
iblfQueld.13.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.13.3	Integer	que2 (3)
iblfQueld.13.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.13.4	Integer	que3 (4)
iblfQueld.13.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.13.5	Integer	que4 (5)
iblfQueld.13.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.13.6	Integer	que5 (6)
iblfQueld.13.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.13.7	Integer	que6 (7)
iblfQueld.13.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.13.8	Integer	que7 (8)
iblfQueld.14.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.14.1	Integer	que0 (1)
iblfQueld.14.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.14.2	Integer	que1 (2)
iblfQueld.14.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.14.3	Integer	que2 (3)
iblfQueld.14.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.14.4	Integer	que3 (4)
iblfQueld.14.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.14.5	Integer	que4 (5)

Name	OID	Value Type	Value Example
iblfQueld.14.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.14.6	Integer	que5 (6)
iblfQueld.14.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.14.7	Integer	que6 (7)
iblfQueld.14.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.14.8	Integer	que7 (8)
iblfQueld.15.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.15.1	Integer	que0 (1)
iblfQueld.15.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.15.2	Integer	que1 (2)
iblfQueld.15.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.15.3	Integer	que2 (3)
iblfQueld.15.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.15.4	Integer	que3 (4)
iblfQueld.15.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.15.5	Integer	que4 (5)
iblfQueld.15.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.15.6	Integer	que5 (6)
iblfQueld.15.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.15.7	Integer	que6 (7)
iblfQueld.15.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.15.8	Integer	que7 (8)
iblfQueld.16.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.16.1	Integer	que0 (1)
iblfQueld.16.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.16.2	Integer	que1 (2)
iblfQueld.16.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.16.3	Integer	que2 (3)
iblfQueld.16.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.16.4	Integer	que3 (4)
iblfQueld.16.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.16.5	Integer	que4 (5)
iblfQueld.16.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.16.6	Integer	que5 (6)
iblfQueld.16.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.16.7	Integer	que6 (7)
iblfQueld.16.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.16.8	Integer	que7 (8)
iblfQueld.17.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.17.1	Integer	que0 (1)
iblfQueld.17.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.17.2	Integer	que1 (2)
iblfQueld.17.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.17.3	Integer	que2 (3)
iblfQueld.17.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.17.4	Integer	que3 (4)
iblfQueld.17.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.17.5	Integer	que4 (5)
iblfQueld.17.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.17.6	Integer	que5 (6)
iblfQueld.17.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.17.7	Integer	que6 (7)
iblfQueld.17.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.17.8	Integer	que7 (8)
iblfQueld.18.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.18.1	Integer	que0 (1)
iblfQueld.18.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.18.2	Integer	que1 (2)
iblfQueld.18.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.18.3	Integer	que2 (3)
iblfQueld.18.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.18.4	Integer	que3 (4)
iblfQueld.18.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.18.5	Integer	que4 (5)
iblfQueld.18.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.18.6	Integer	que5 (6)
iblfQueld.18.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.18.7	Integer	que6 (7)
iblfQueld.18.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.18.8	Integer	que7 (8)
iblfQueld.19.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.19.1	Integer	que0 (1)
iblfQueld.19.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.19.2	Integer	que1 (2)
iblfQueld.19.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.19.3	Integer	que2 (3)
iblfQueld.19.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.19.4	Integer	que3 (4)
iblfQueld.19.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.19.5	Integer	que4 (5)
iblfQueld.19.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.19.6	Integer	que5 (6)
iblfQueld.19.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.19.7	Integer	que6 (7)
iblfQueld.19.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.19.8	Integer	que7 (8)



Name	OID	Value Type	Value Example
iblfQueld.20.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.20.1	Integer	que0 (1)
iblfQueld.20.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.20.2	Integer	que1 (2)
iblfQueld.20.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.20.3	Integer	que2 (3)
iblfQueld.20.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.20.4	Integer	que3 (4)
iblfQueld.20.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.20.5	Integer	que4 (5)
iblfQueld.20.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.20.6	Integer	que5 (6)
iblfQueld.20.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.20.7	Integer	que6 (7)
iblfQueld.20.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.20.8	Integer	que7 (8)
iblfQueld.21.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.21.1	Integer	que0 (1)
iblfQueld.21.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.21.2	Integer	que1 (2)
iblfQueld.21.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.21.3	Integer	que2 (3)
iblfQueld.21.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.21.4	Integer	que3 (4)
iblfQueld.21.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.21.5	Integer	que4 (5)
iblfQueld.21.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.21.6	Integer	que5 (6)
iblfQueld.21.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.21.7	Integer	que6 (7)
iblfQueld.21.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.21.8	Integer	que7 (8)
iblfQueld.22.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.22.1	Integer	que0 (1)
iblfQueld.22.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.22.2	Integer	que1 (2)
iblfQueld.22.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.22.3	Integer	que2 (3)
iblfQueld.22.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.22.4	Integer	que3 (4)
iblfQueld.22.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.22.5	Integer	que4 (5)
iblfQueld.22.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.22.6	Integer	que5 (6)
iblfQueld.22.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.22.7	Integer	que6 (7)
iblfQueld.22.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.22.8	Integer	que7 (8)
iblfQueld.23.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.23.1	Integer	que0 (1)
iblfQueld.23.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.23.2	Integer	que1 (2)
iblfQueld.23.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.23.3	Integer	que2 (3)
iblfQueld.23.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.23.4	Integer	que3 (4)
iblfQueld.23.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.23.5	Integer	que4 (5)
iblfQueld.23.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.23.6	Integer	que5 (6)
iblfQueld.23.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.23.7	Integer	que6 (7)
iblfQueld.23.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.23.8	Integer	que7 (8)
iblfQueld.24.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.24.1	Integer	que0 (1)
iblfQueld.24.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.24.2	Integer	que1 (2)
iblfQueld.24.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.24.3	Integer	que2 (3)
iblfQueld.24.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.24.4	Integer	que3 (4)
iblfQueld.24.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.24.5	Integer	que4 (5)
iblfQueld.24.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.24.6	Integer	que5 (6)
iblfQueld.24.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.24.7	Integer	que6 (7)
iblfQueld.24.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.24.8	Integer	que7 (8)
iblfQueld.25.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.25.1	Integer	que0 (1)
iblfQueld.25.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.25.2	Integer	que1 (2)
iblfQueld.25.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.25.3	Integer	que2 (3)



Name	OID	Value Type	Value Example
iblfQueld.25.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.25.4	Integer	que3 (4)
iblfQueld.25.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.25.5	Integer	que4 (5)
iblfQueld.25.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.25.6	Integer	que5 (6)
iblfQueld.25.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.25.7	Integer	que6 (7)
iblfQueld.25.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.25.8	Integer	que7 (8)
iblfQueld.26.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.26.1	Integer	que0 (1)
iblfQueld.26.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.26.2	Integer	que1 (2)
iblfQueld.26.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.26.3	Integer	que2 (3)
iblfQueld.26.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.26.4	Integer	que3 (4)
iblfQueld.26.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.26.5	Integer	que4 (5)
iblfQueld.26.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.26.6	Integer	que5 (6)
iblfQueld.26.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.26.7	Integer	que6 (7)
iblfQueld.26.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.26.8	Integer	que7 (8)
iblfQueld.27.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.27.1	Integer	que0 (1)
iblfQueld.27.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.27.2	Integer	que1 (2)
iblfQueld.27.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.27.3	Integer	que2 (3)
iblfQueld.27.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.27.4	Integer	que3 (4)
iblfQueld.27.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.27.5	Integer	que4 (5)
iblfQueld.27.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.27.6	Integer	que5 (6)
iblfQueld.27.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.27.7	Integer	que6 (7)
iblfQueld.27.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.27.8	Integer	que7 (8)
iblfQueld.28.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.28.1	Integer	que0 (1)
iblfQueld.28.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.28.2	Integer	que1 (2)
iblfQueld.28.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.28.3	Integer	que2 (3)
iblfQueld.28.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.28.4	Integer	que3 (4)
iblfQueld.28.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.28.5	Integer	que4 (5)
iblfQueld.28.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.28.6	Integer	que5 (6)
iblfQueld.28.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.28.7	Integer	que6 (7)
iblfQueld.28.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.28.8	Integer	que7 (8)
iblfQueld.29.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.29.1	Integer	que0 (1)
iblfQueld.29.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.29.2	Integer	que1 (2)
iblfQueld.29.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.29.3	Integer	que2 (3)
iblfQueld.29.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.29.4	Integer	que3 (4)
iblfQueld.29.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.29.5	Integer	que4 (5)
iblfQueld.29.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.29.6	Integer	que5 (6)
iblfQueld.29.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.29.7	Integer	que6 (7)
iblfQueld.29.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.29.8	Integer	que7 (8)
iblfQueld.30.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.30.1	Integer	que0 (1)
iblfQueld.30.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.30.2	Integer	que1 (2)
iblfQueld.30.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.30.3	Integer	que2 (3)
iblfQueld.30.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.30.4	Integer	que3 (4)
iblfQueld.30.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.30.5	Integer	que4 (5)
iblfQueld.30.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.30.6	Integer	que5 (6)

Name	OID	Value Type	Value Example
iblfQueld.30.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.30.7	Integer	que6 (7)
iblfQueld.30.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.30.8	Integer	que7 (8)
iblfQueld.31.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.31.1	Integer	que0 (1)
iblfQueld.31.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.31.2	Integer	que1 (2)
iblfQueld.31.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.31.3	Integer	que2 (3)
iblfQueld.31.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.31.4	Integer	que3 (4)
iblfQueld.31.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.31.5	Integer	que4 (5)
iblfQueld.31.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.31.6	Integer	que5 (6)
iblfQueld.31.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.31.7	Integer	que6 (7)
iblfQueld.31.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.31.8	Integer	que7 (8)
iblfQueld.32.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.32.1	Integer	que0 (1)
iblfQueld.32.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.32.2	Integer	que1 (2)
iblfQueld.32.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.32.3	Integer	que2 (3)
iblfQueld.32.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.32.4	Integer	que3 (4)
iblfQueld.32.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.32.5	Integer	que4 (5)
iblfQueld.32.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.32.6	Integer	que5 (6)
iblfQueld.32.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.32.7	Integer	que6 (7)
iblfQueld.32.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.32.8	Integer	que7 (8)
iblfQueld.33.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.33.1	Integer	que0 (1)
iblfQueld.33.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.33.2	Integer	que1 (2)
iblfQueld.33.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.33.3	Integer	que2 (3)
iblfQueld.33.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.33.4	Integer	que3 (4)
iblfQueld.33.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.33.5	Integer	que4 (5)
iblfQueld.33.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.33.6	Integer	que5 (6)
iblfQueld.33.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.33.7	Integer	que6 (7)
iblfQueld.33.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.33.8	Integer	que7 (8)
iblfQueld.34.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.34.1	Integer	que0 (1)
iblfQueld.34.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.34.2	Integer	que1 (2)
iblfQueld.34.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.34.3	Integer	que2 (3)
iblfQueld.34.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.34.4	Integer	que3 (4)
iblfQueld.34.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.34.5	Integer	que4 (5)
iblfQueld.34.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.34.6	Integer	que5 (6)
iblfQueld.34.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.34.7	Integer	que6 (7)
iblfQueld.34.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.34.8	Integer	que7 (8)
iblfQueld.35.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.35.1	Integer	que0 (1)
iblfQueld.35.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.35.2	Integer	que1 (2)
iblfQueld.35.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.35.3	Integer	que2 (3)
iblfQueld.35.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.35.4	Integer	que3 (4)
iblfQueld.35.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.35.5	Integer	que4 (5)
iblfQueld.35.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.35.6	Integer	que5 (6)
iblfQueld.35.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.35.7	Integer	que6 (7)
iblfQueld.35.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.35.8	Integer	que7 (8)
iblfQueld.36.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.36.1	Integer	que0 (1)

Name	OID	Value Type	Value Example
iblfQueld.36.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.36.2	Integer	que1 (2)
iblfQueld.36.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.36.3	Integer	que2 (3)
iblfQueld.36.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.36.4	Integer	que3 (4)
iblfQueld.36.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.36.5	Integer	que4 (5)
iblfQueld.36.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.36.6	Integer	que5 (6)
iblfQueld.36.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.36.7	Integer	que6 (7)
iblfQueld.36.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.36.8	Integer	que7 (8)
iblfQueld.37.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.37.1	Integer	que0 (1)
iblfQueld.37.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.37.2	Integer	que1 (2)
iblfQueld.37.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.37.3	Integer	que2 (3)
iblfQueld.37.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.37.4	Integer	que3 (4)
iblfQueld.37.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.37.5	Integer	que4 (5)
iblfQueld.37.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.37.6	Integer	que5 (6)
iblfQueld.37.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.37.7	Integer	que6 (7)
iblfQueld.37.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.37.8	Integer	que7 (8)
iblfQueld.38.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.38.1	Integer	que0 (1)
iblfQueld.38.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.38.2	Integer	que1 (2)
iblfQueld.38.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.38.3	Integer	que2 (3)
iblfQueld.38.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.38.4	Integer	que3 (4)
iblfQueld.38.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.38.5	Integer	que4 (5)
iblfQueld.38.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.38.6	Integer	que5 (6)
iblfQueld.38.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.38.7	Integer	que6 (7)
iblfQueld.38.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.38.8	Integer	que7 (8)
iblfQueld.39.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.39.1	Integer	que0 (1)
iblfQueld.39.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.39.2	Integer	que1 (2)
iblfQueld.39.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.39.3	Integer	que2 (3)
iblfQueld.39.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.39.4	Integer	que3 (4)
iblfQueld.39.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.39.5	Integer	que4 (5)
iblfQueld.39.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.39.6	Integer	que5 (6)
iblfQueld.39.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.39.7	Integer	que6 (7)
iblfQueld.39.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.39.8	Integer	que7 (8)
iblfQueld.40.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.40.1	Integer	que0 (1)
iblfQueld.40.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.40.2	Integer	que1 (2)
iblfQueld.40.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.40.3	Integer	que2 (3)
iblfQueld.40.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.40.4	Integer	que3 (4)
iblfQueld.40.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.40.5	Integer	que4 (5)
iblfQueld.40.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.40.6	Integer	que5 (6)
iblfQueld.40.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.40.7	Integer	que6 (7)
iblfQueld.40.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.40.8	Integer	que7 (8)
iblfQueld.41.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.41.1	Integer	que0 (1)
iblfQueld.41.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.41.2	Integer	que1 (2)
iblfQueld.41.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.41.3	Integer	que2 (3)
iblfQueld.41.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.41.4	Integer	que3 (4)

Name	OID	Value Type	Value Example
iblfQueld.41.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.41.5	Integer	que4 (5)
iblfQueld.41.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.41.6	Integer	que5 (6)
iblfQueld.41.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.41.7	Integer	que6 (7)
iblfQueld.41.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.41.8	Integer	que7 (8)
iblfQueld.42.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.42.1	Integer	que0 (1)
iblfQueld.42.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.42.2	Integer	que1 (2)
iblfQueld.42.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.42.3	Integer	que2 (3)
iblfQueld.42.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.42.4	Integer	que3 (4)
iblfQueld.42.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.42.5	Integer	que4 (5)
iblfQueld.42.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.42.6	Integer	que5 (6)
iblfQueld.42.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.42.7	Integer	que6 (7)
iblfQueld.42.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.42.8	Integer	que7 (8)
iblfQueld.43.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.43.1	Integer	que0 (1)
iblfQueld.43.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.43.2	Integer	que1 (2)
iblfQueld.43.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.43.3	Integer	que2 (3)
iblfQueld.43.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.43.4	Integer	que3 (4)
iblfQueld.43.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.43.5	Integer	que4 (5)
iblfQueld.43.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.43.6	Integer	que5 (6)
iblfQueld.43.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.43.7	Integer	que6 (7)
iblfQueld.43.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.43.8	Integer	que7 (8)
iblfQueld.44.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.44.1	Integer	que0 (1)
iblfQueld.44.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.44.2	Integer	que1 (2)
iblfQueld.44.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.44.3	Integer	que2 (3)
iblfQueld.44.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.44.4	Integer	que3 (4)
iblfQueld.44.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.44.5	Integer	que4 (5)
iblfQueld.44.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.44.6	Integer	que5 (6)
iblfQueld.44.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.44.7	Integer	que6 (7)
iblfQueld.44.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.44.8	Integer	que7 (8)
iblfQueld.45.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.45.1	Integer	que0 (1)
iblfQueld.45.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.45.2	Integer	que1 (2)
iblfQueld.45.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.45.3	Integer	que2 (3)
iblfQueld.45.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.45.4	Integer	que3 (4)
iblfQueld.45.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.45.5	Integer	que4 (5)
iblfQueld.45.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.45.6	Integer	que5 (6)
iblfQueld.45.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.45.7	Integer	que6 (7)
iblfQueld.45.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.45.8	Integer	que7 (8)
iblfQueld.46.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.46.1	Integer	que0 (1)
iblfQueld.46.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.46.2	Integer	que1 (2)
iblfQueld.46.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.46.3	Integer	que2 (3)
iblfQueld.46.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.46.4	Integer	que3 (4)
iblfQueld.46.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.46.5	Integer	que4 (5)
iblfQueld.46.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.46.6	Integer	que5 (6)
iblfQueld.46.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.46.7	Integer	que6 (7)

Name	OID	Value Type	Value Example
iblfQueld.46.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.46.8	Integer	que7 (8)
iblfQueld.47.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.47.1	Integer	que0 (1)
iblfQueld.47.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.47.2	Integer	que1 (2)
iblfQueld.47.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.47.3	Integer	que2 (3)
iblfQueld.47.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.47.4	Integer	que3 (4)
iblfQueld.47.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.47.5	Integer	que4 (5)
iblfQueld.47.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.47.6	Integer	que5 (6)
iblfQueld.47.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.47.7	Integer	que6 (7)
iblfQueld.47.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.47.8	Integer	que7 (8)
iblfQueld.48.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.48.1	Integer	que0 (1)
iblfQueld.48.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.48.2	Integer	que1 (2)
iblfQueld.48.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.48.3	Integer	que2 (3)
iblfQueld.48.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.48.4	Integer	que3 (4)
iblfQueld.48.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.48.5	Integer	que4 (5)
iblfQueld.48.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.48.6	Integer	que5 (6)
iblfQueld.48.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.48.7	Integer	que6 (7)
iblfQueld.48.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.48.8	Integer	que7 (8)
iblfQueld.49.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.49.1	Integer	que0 (1)
iblfQueld.49.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.49.2	Integer	que1 (2)
iblfQueld.49.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.49.3	Integer	que2 (3)
iblfQueld.49.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.49.4	Integer	que3 (4)
iblfQueld.49.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.49.5	Integer	que4 (5)
iblfQueld.49.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.49.6	Integer	que5 (6)
iblfQueld.49.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.49.7	Integer	que6 (7)
iblfQueld.49.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.49.8	Integer	que7 (8)
iblfQueld.50.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.50.1	Integer	que0 (1)
iblfQueld.50.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.50.2	Integer	que1 (2)
iblfQueld.50.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.50.3	Integer	que2 (3)
iblfQueld.50.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.50.4	Integer	que3 (4)
iblfQueld.50.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.50.5	Integer	que4 (5)
iblfQueld.50.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.50.6	Integer	que5 (6)
iblfQueld.50.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.50.7	Integer	que6 (7)
iblfQueld.50.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.50.8	Integer	que7 (8)
iblfQueld.51.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.51.1	Integer	que0 (1)
iblfQueld.51.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.51.2	Integer	que1 (2)
iblfQueld.51.3	.3.6.1.4.1.26138.2.40.2.2.6.1.1.51.3	Integer	que2 (3)
iblfQueld.51.4	.3.6.1.4.1.26138.2.40.2.2.6.1.1.51.4	Integer	que3 (4)
iblfQueld.51.5	.3.6.1.4.1.26138.2.40.2.2.6.1.1.51.5	Integer	que4 (5)
iblfQueld.51.6	.3.6.1.4.1.26138.2.40.2.2.6.1.1.51.6	Integer	que5 (6)
iblfQueld.51.7	.3.6.1.4.1.26138.2.40.2.2.6.1.1.51.7	Integer	que6 (7)
iblfQueld.51.8	.3.6.1.4.1.26138.2.40.2.2.6.1.1.51.8	Integer	que7 (8)
iblfQueld.52.1	.3.6.1.4.1.26138.2.40.2.2.6.1.1.52.1	Integer	que0 (1)
iblfQueld.52.2	.3.6.1.4.1.26138.2.40.2.2.6.1.1.52.2	Integer	que1 (2)

Name	OID	Value Type	Value Example
iblfQueId.52.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.52.3	Integer	que2 (3)
iblfQueId.52.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.52.4	Integer	que3 (4)
iblfQueId.52.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.52.5	Integer	que4 (5)
iblfQueId.52.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.52.6	Integer	que5 (6)
iblfQueId.52.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.52.7	Integer	que6 (7)
iblfQueId.52.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.52.8	Integer	que7 (8)
iblfQueId.53.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.53.1	Integer	que0 (1)
iblfQueId.53.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.53.2	Integer	que1 (2)
iblfQueId.53.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.53.3	Integer	que2 (3)
iblfQueId.53.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.53.4	Integer	que3 (4)
iblfQueId.53.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.53.5	Integer	que4 (5)
iblfQueId.53.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.53.6	Integer	que5 (6)
iblfQueId.53.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.53.7	Integer	que6 (7)
iblfQueId.53.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.53.8	Integer	que7 (8)
iblfQueId.54.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.54.1	Integer	que0 (1)
iblfQueId.54.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.54.2	Integer	que1 (2)
iblfQueId.54.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.54.3	Integer	que2 (3)
iblfQueId.54.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.54.4	Integer	que3 (4)
iblfQueId.54.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.54.5	Integer	que4 (5)
iblfQueId.54.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.54.6	Integer	que5 (6)
iblfQueId.54.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.54.7	Integer	que6 (7)
iblfQueId.54.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.1.54.8	Integer	que7 (8)
iblfQueOutUcastTotal.1.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.1.1	Gauge	0
iblfQueOutUcastTotal.1.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.1.2	Gauge	0
iblfQueOutUcastTotal.1.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.1.3	Gauge	0
iblfQueOutUcastTotal.1.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.1.4	Gauge	0
iblfQueOutUcastTotal.1.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.1.5	Gauge	0
iblfQueOutUcastTotal.1.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.1.6	Gauge	0
iblfQueOutUcastTotal.1.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.1.7	Gauge	0
iblfQueOutUcastTotal.1.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.1.8	Gauge	0
iblfQueOutUcastTotal.2.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.2.1	Gauge	0
iblfQueOutUcastTotal.2.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.2.2	Gauge	0
iblfQueOutUcastTotal.2.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.2.3	Gauge	0
iblfQueOutUcastTotal.2.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.2.4	Gauge	0
iblfQueOutUcastTotal.2.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.2.5	Gauge	0
iblfQueOutUcastTotal.2.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.2.6	Gauge	0
iblfQueOutUcastTotal.2.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.2.7	Gauge	0
iblfQueOutUcastTotal.2.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.2.8	Gauge	0
iblfQueOutUcastTotal.3.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.3.1	Gauge	0
iblfQueOutUcastTotal.3.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.3.2	Gauge	0
iblfQueOutUcastTotal.3.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.3.3	Gauge	0
iblfQueOutUcastTotal.3.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.3.4	Gauge	0
iblfQueOutUcastTotal.3.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.3.5	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastTotal.3.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.3.6	Gauge	0
iblfQueOutUcastTotal.3.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.3.7	Gauge	0
iblfQueOutUcastTotal.3.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.3.8	Gauge	0
iblfQueOutUcastTotal.4.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.4.1	Gauge	0
iblfQueOutUcastTotal.4.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.4.2	Gauge	0
iblfQueOutUcastTotal.4.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.4.3	Gauge	0
iblfQueOutUcastTotal.4.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.4.4	Gauge	0
iblfQueOutUcastTotal.4.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.4.5	Gauge	0
iblfQueOutUcastTotal.4.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.4.6	Gauge	0
iblfQueOutUcastTotal.4.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.4.7	Gauge	0
iblfQueOutUcastTotal.4.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.4.8	Gauge	0
iblfQueOutUcastTotal.5.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.5.1	Gauge	0
iblfQueOutUcastTotal.5.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.5.2	Gauge	0
iblfQueOutUcastTotal.5.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.5.3	Gauge	0
iblfQueOutUcastTotal.5.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.5.4	Gauge	0
iblfQueOutUcastTotal.5.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.5.5	Gauge	0
iblfQueOutUcastTotal.5.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.5.6	Gauge	0
iblfQueOutUcastTotal.5.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.5.7	Gauge	0
iblfQueOutUcastTotal.5.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.5.8	Gauge	0
iblfQueOutUcastTotal.6.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.6.1	Gauge	0
iblfQueOutUcastTotal.6.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.6.2	Gauge	0
iblfQueOutUcastTotal.6.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.6.3	Gauge	0
iblfQueOutUcastTotal.6.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.6.4	Gauge	0
iblfQueOutUcastTotal.6.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.6.5	Gauge	0
iblfQueOutUcastTotal.6.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.6.6	Gauge	0
iblfQueOutUcastTotal.6.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.6.7	Gauge	0
iblfQueOutUcastTotal.6.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.6.8	Gauge	0
iblfQueOutUcastTotal.7.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.7.1	Gauge	0
iblfQueOutUcastTotal.7.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.7.2	Gauge	0
iblfQueOutUcastTotal.7.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.7.3	Gauge	0
iblfQueOutUcastTotal.7.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.7.4	Gauge	0
iblfQueOutUcastTotal.7.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.7.5	Gauge	0
iblfQueOutUcastTotal.7.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.7.6	Gauge	0
iblfQueOutUcastTotal.7.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.7.7	Gauge	0
iblfQueOutUcastTotal.7.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.7.8	Gauge	0
iblfQueOutUcastTotal.8.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.8.1	Gauge	0
iblfQueOutUcastTotal.8.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.8.2	Gauge	0
iblfQueOutUcastTotal.8.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.8.3	Gauge	0
iblfQueOutUcastTotal.8.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.8.4	Gauge	0
iblfQueOutUcastTotal.8.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.8.5	Gauge	0
iblfQueOutUcastTotal.8.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.8.6	Gauge	0
iblfQueOutUcastTotal.8.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.8.7	Gauge	0
iblfQueOutUcastTotal.8.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.8.8	Gauge	0



Name	OID	Value Type	Value Example
iblfQueOutUcastTotal.9.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.9.1	Gauge	0
iblfQueOutUcastTotal.9.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.9.2	Gauge	0
iblfQueOutUcastTotal.9.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.9.3	Gauge	0
iblfQueOutUcastTotal.9.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.9.4	Gauge	0
iblfQueOutUcastTotal.9.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.9.5	Gauge	0
iblfQueOutUcastTotal.9.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.9.6	Gauge	0
iblfQueOutUcastTotal.9.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.9.7	Gauge	0
iblfQueOutUcastTotal.9.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.9.8	Gauge	0
iblfQueOutUcastTotal.10.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.10.1	Gauge	0
iblfQueOutUcastTotal.10.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.10.2	Gauge	0
iblfQueOutUcastTotal.10.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.10.3	Gauge	0
iblfQueOutUcastTotal.10.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.10.4	Gauge	0
iblfQueOutUcastTotal.10.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.10.5	Gauge	0
iblfQueOutUcastTotal.10.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.10.6	Gauge	0
iblfQueOutUcastTotal.10.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.10.7	Gauge	0
iblfQueOutUcastTotal.10.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.10.8	Gauge	0
iblfQueOutUcastTotal.11.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.11.1	Gauge	0
iblfQueOutUcastTotal.11.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.11.2	Gauge	0
iblfQueOutUcastTotal.11.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.11.3	Gauge	0
iblfQueOutUcastTotal.11.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.11.4	Gauge	0
iblfQueOutUcastTotal.11.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.11.5	Gauge	0
iblfQueOutUcastTotal.11.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.11.6	Gauge	0
iblfQueOutUcastTotal.11.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.11.7	Gauge	0
iblfQueOutUcastTotal.11.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.11.8	Gauge	0
iblfQueOutUcastTotal.12.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.12.1	Gauge	0
iblfQueOutUcastTotal.12.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.12.2	Gauge	0
iblfQueOutUcastTotal.12.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.12.3	Gauge	0
iblfQueOutUcastTotal.12.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.12.4	Gauge	0
iblfQueOutUcastTotal.12.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.12.5	Gauge	0
iblfQueOutUcastTotal.12.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.12.6	Gauge	0
iblfQueOutUcastTotal.12.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.12.7	Gauge	0
iblfQueOutUcastTotal.12.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.12.8	Gauge	0
iblfQueOutUcastTotal.13.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.13.1	Gauge	0
iblfQueOutUcastTotal.13.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.13.2	Gauge	0
iblfQueOutUcastTotal.13.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.13.3	Gauge	0
iblfQueOutUcastTotal.13.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.13.4	Gauge	0
iblfQueOutUcastTotal.13.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.13.5	Gauge	0
iblfQueOutUcastTotal.13.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.13.6	Gauge	0
iblfQueOutUcastTotal.13.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.13.7	Gauge	0
iblfQueOutUcastTotal.13.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.13.8	Gauge	0
iblfQueOutUcastTotal.14.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.14.1	Gauge	0
iblfQueOutUcastTotal.14.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.14.2	Gauge	0
iblfQueOutUcastTotal.14.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.2.14.3	Gauge	0



Name	OID	Value Type	Value Example
iblfQueOutUcastTotal.14.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.14.4	Gauge	0
iblfQueOutUcastTotal.14.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.14.5	Gauge	0
iblfQueOutUcastTotal.14.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.14.6	Gauge	0
iblfQueOutUcastTotal.14.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.14.7	Gauge	0
iblfQueOutUcastTotal.14.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.14.8	Gauge	0
iblfQueOutUcastTotal.15.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.15.1	Gauge	0
iblfQueOutUcastTotal.15.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.15.2	Gauge	0
iblfQueOutUcastTotal.15.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.15.3	Gauge	0
iblfQueOutUcastTotal.15.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.15.4	Gauge	0
iblfQueOutUcastTotal.15.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.15.5	Gauge	0
iblfQueOutUcastTotal.15.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.15.6	Gauge	0
iblfQueOutUcastTotal.15.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.15.7	Gauge	0
iblfQueOutUcastTotal.15.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.15.8	Gauge	0
iblfQueOutUcastTotal.16.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.16.1	Gauge	0
iblfQueOutUcastTotal.16.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.16.2	Gauge	0
iblfQueOutUcastTotal.16.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.16.3	Gauge	0
iblfQueOutUcastTotal.16.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.16.4	Gauge	0
iblfQueOutUcastTotal.16.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.16.5	Gauge	0
iblfQueOutUcastTotal.16.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.16.6	Gauge	0
iblfQueOutUcastTotal.16.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.16.7	Gauge	0
iblfQueOutUcastTotal.16.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.16.8	Gauge	0
iblfQueOutUcastTotal.17.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.17.1	Gauge	0
iblfQueOutUcastTotal.17.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.17.2	Gauge	0
iblfQueOutUcastTotal.17.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.17.3	Gauge	0
iblfQueOutUcastTotal.17.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.17.4	Gauge	0
iblfQueOutUcastTotal.17.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.17.5	Gauge	0
iblfQueOutUcastTotal.17.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.17.6	Gauge	0
iblfQueOutUcastTotal.17.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.17.7	Gauge	0
iblfQueOutUcastTotal.17.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.17.8	Gauge	0
iblfQueOutUcastTotal.18.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.18.1	Gauge	0
iblfQueOutUcastTotal.18.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.18.2	Gauge	0
iblfQueOutUcastTotal.18.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.18.3	Gauge	0
iblfQueOutUcastTotal.18.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.18.4	Gauge	0
iblfQueOutUcastTotal.18.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.18.5	Gauge	0
iblfQueOutUcastTotal.18.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.18.6	Gauge	0
iblfQueOutUcastTotal.18.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.18.7	Gauge	0
iblfQueOutUcastTotal.18.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.18.8	Gauge	0
iblfQueOutUcastTotal.19.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.19.1	Gauge	0
iblfQueOutUcastTotal.19.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.19.2	Gauge	0
iblfQueOutUcastTotal.19.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.19.3	Gauge	0
iblfQueOutUcastTotal.19.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.19.4	Gauge	0
iblfQueOutUcastTotal.19.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.19.5	Gauge	0
iblfQueOutUcastTotal.19.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.19.6	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastTotal.19.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.19.7	Gauge	0
iblfQueOutUcastTotal.19.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.19.8	Gauge	0
iblfQueOutUcastTotal.20.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.20.1	Gauge	0
iblfQueOutUcastTotal.20.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.20.2	Gauge	0
iblfQueOutUcastTotal.20.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.20.3	Gauge	0
iblfQueOutUcastTotal.20.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.20.4	Gauge	0
iblfQueOutUcastTotal.20.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.20.5	Gauge	0
iblfQueOutUcastTotal.20.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.20.6	Gauge	0
iblfQueOutUcastTotal.20.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.20.7	Gauge	0
iblfQueOutUcastTotal.20.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.20.8	Gauge	0
iblfQueOutUcastTotal.21.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.21.1	Gauge	0
iblfQueOutUcastTotal.21.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.21.2	Gauge	0
iblfQueOutUcastTotal.21.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.21.3	Gauge	0
iblfQueOutUcastTotal.21.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.21.4	Gauge	0
iblfQueOutUcastTotal.21.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.21.5	Gauge	0
iblfQueOutUcastTotal.21.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.21.6	Gauge	0
iblfQueOutUcastTotal.21.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.21.7	Gauge	0
iblfQueOutUcastTotal.21.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.21.8	Gauge	0
iblfQueOutUcastTotal.22.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.22.1	Gauge	0
iblfQueOutUcastTotal.22.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.22.2	Gauge	0
iblfQueOutUcastTotal.22.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.22.3	Gauge	0
iblfQueOutUcastTotal.22.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.22.4	Gauge	0
iblfQueOutUcastTotal.22.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.22.5	Gauge	0
iblfQueOutUcastTotal.22.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.22.6	Gauge	0
iblfQueOutUcastTotal.22.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.22.7	Gauge	0
iblfQueOutUcastTotal.22.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.22.8	Gauge	0
iblfQueOutUcastTotal.23.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.23.1	Gauge	0
iblfQueOutUcastTotal.23.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.23.2	Gauge	0
iblfQueOutUcastTotal.23.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.23.3	Gauge	0
iblfQueOutUcastTotal.23.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.23.4	Gauge	0
iblfQueOutUcastTotal.23.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.23.5	Gauge	0
iblfQueOutUcastTotal.23.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.23.6	Gauge	0
iblfQueOutUcastTotal.23.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.23.7	Gauge	0
iblfQueOutUcastTotal.23.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.23.8	Gauge	0
iblfQueOutUcastTotal.24.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.24.1	Gauge	0
iblfQueOutUcastTotal.24.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.24.2	Gauge	0
iblfQueOutUcastTotal.24.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.24.3	Gauge	0
iblfQueOutUcastTotal.24.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.24.4	Gauge	0
iblfQueOutUcastTotal.24.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.24.5	Gauge	0
iblfQueOutUcastTotal.24.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.24.6	Gauge	0
iblfQueOutUcastTotal.24.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.24.7	Gauge	0
iblfQueOutUcastTotal.24.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.24.8	Gauge	0
iblfQueOutUcastTotal.25.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.25.1	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastTotal.25.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.25.2	Gauge	0
iblfQueOutUcastTotal.25.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.25.3	Gauge	0
iblfQueOutUcastTotal.25.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.25.4	Gauge	0
iblfQueOutUcastTotal.25.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.25.5	Gauge	0
iblfQueOutUcastTotal.25.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.25.6	Gauge	0
iblfQueOutUcastTotal.25.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.25.7	Gauge	0
iblfQueOutUcastTotal.25.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.25.8	Gauge	0
iblfQueOutUcastTotal.26.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.26.1	Gauge	0
iblfQueOutUcastTotal.26.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.26.2	Gauge	0
iblfQueOutUcastTotal.26.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.26.3	Gauge	0
iblfQueOutUcastTotal.26.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.26.4	Gauge	0
iblfQueOutUcastTotal.26.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.26.5	Gauge	0
iblfQueOutUcastTotal.26.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.26.6	Gauge	0
iblfQueOutUcastTotal.26.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.26.7	Gauge	0
iblfQueOutUcastTotal.26.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.26.8	Gauge	0
iblfQueOutUcastTotal.27.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.27.1	Gauge	0
iblfQueOutUcastTotal.27.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.27.2	Gauge	0
iblfQueOutUcastTotal.27.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.27.3	Gauge	0
iblfQueOutUcastTotal.27.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.27.4	Gauge	0
iblfQueOutUcastTotal.27.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.27.5	Gauge	0
iblfQueOutUcastTotal.27.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.27.6	Gauge	0
iblfQueOutUcastTotal.27.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.27.7	Gauge	0
iblfQueOutUcastTotal.27.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.27.8	Gauge	0
iblfQueOutUcastTotal.28.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.28.1	Gauge	0
iblfQueOutUcastTotal.28.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.28.2	Gauge	0
iblfQueOutUcastTotal.28.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.28.3	Gauge	0
iblfQueOutUcastTotal.28.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.28.4	Gauge	0
iblfQueOutUcastTotal.28.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.28.5	Gauge	0
iblfQueOutUcastTotal.28.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.28.6	Gauge	0
iblfQueOutUcastTotal.28.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.28.7	Gauge	0
iblfQueOutUcastTotal.28.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.28.8	Gauge	0
iblfQueOutUcastTotal.29.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.29.1	Gauge	0
iblfQueOutUcastTotal.29.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.29.2	Gauge	0
iblfQueOutUcastTotal.29.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.29.3	Gauge	0
iblfQueOutUcastTotal.29.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.29.4	Gauge	0
iblfQueOutUcastTotal.29.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.29.5	Gauge	0
iblfQueOutUcastTotal.29.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.29.6	Gauge	0
iblfQueOutUcastTotal.29.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.29.7	Gauge	0
iblfQueOutUcastTotal.29.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.29.8	Gauge	0
iblfQueOutUcastTotal.30.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.30.1	Gauge	0
iblfQueOutUcastTotal.30.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.30.2	Gauge	0
iblfQueOutUcastTotal.30.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.30.3	Gauge	0
iblfQueOutUcastTotal.30.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.30.4	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastTotal.30.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.30.5	Gauge	0
iblfQueOutUcastTotal.30.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.30.6	Gauge	0
iblfQueOutUcastTotal.30.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.30.7	Gauge	0
iblfQueOutUcastTotal.30.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.30.8	Gauge	0
iblfQueOutUcastTotal.31.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.31.1	Gauge	0
iblfQueOutUcastTotal.31.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.31.2	Gauge	0
iblfQueOutUcastTotal.31.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.31.3	Gauge	0
iblfQueOutUcastTotal.31.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.31.4	Gauge	0
iblfQueOutUcastTotal.31.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.31.5	Gauge	0
iblfQueOutUcastTotal.31.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.31.6	Gauge	0
iblfQueOutUcastTotal.31.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.31.7	Gauge	0
iblfQueOutUcastTotal.31.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.31.8	Gauge	0
iblfQueOutUcastTotal.32.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.32.1	Gauge	0
iblfQueOutUcastTotal.32.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.32.2	Gauge	0
iblfQueOutUcastTotal.32.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.32.3	Gauge	0
iblfQueOutUcastTotal.32.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.32.4	Gauge	0
iblfQueOutUcastTotal.32.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.32.5	Gauge	0
iblfQueOutUcastTotal.32.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.32.6	Gauge	0
iblfQueOutUcastTotal.32.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.32.7	Gauge	0
iblfQueOutUcastTotal.32.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.32.8	Gauge	0
iblfQueOutUcastTotal.33.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.33.1	Gauge	0
iblfQueOutUcastTotal.33.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.33.2	Gauge	0
iblfQueOutUcastTotal.33.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.33.3	Gauge	0
iblfQueOutUcastTotal.33.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.33.4	Gauge	0
iblfQueOutUcastTotal.33.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.33.5	Gauge	0
iblfQueOutUcastTotal.33.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.33.6	Gauge	0
iblfQueOutUcastTotal.33.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.33.7	Gauge	0
iblfQueOutUcastTotal.33.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.33.8	Gauge	0
iblfQueOutUcastTotal.34.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.34.1	Gauge	0
iblfQueOutUcastTotal.34.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.34.2	Gauge	0
iblfQueOutUcastTotal.34.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.34.3	Gauge	0
iblfQueOutUcastTotal.34.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.34.4	Gauge	0
iblfQueOutUcastTotal.34.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.34.5	Gauge	0
iblfQueOutUcastTotal.34.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.34.6	Gauge	0
iblfQueOutUcastTotal.34.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.34.7	Gauge	0
iblfQueOutUcastTotal.34.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.34.8	Gauge	0
iblfQueOutUcastTotal.35.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.35.1	Gauge	0
iblfQueOutUcastTotal.35.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.35.2	Gauge	0
iblfQueOutUcastTotal.35.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.35.3	Gauge	0
iblfQueOutUcastTotal.35.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.35.4	Gauge	0
iblfQueOutUcastTotal.35.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.35.5	Gauge	0
iblfQueOutUcastTotal.35.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.35.6	Gauge	0
iblfQueOutUcastTotal.35.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.35.7	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastTotal.35.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.35.8	Gauge	0
iblfQueOutUcastTotal.36.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.36.1	Gauge	0
iblfQueOutUcastTotal.36.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.36.2	Gauge	0
iblfQueOutUcastTotal.36.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.36.3	Gauge	0
iblfQueOutUcastTotal.36.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.36.4	Gauge	0
iblfQueOutUcastTotal.36.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.36.5	Gauge	0
iblfQueOutUcastTotal.36.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.36.6	Gauge	0
iblfQueOutUcastTotal.36.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.36.7	Gauge	0
iblfQueOutUcastTotal.36.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.36.8	Gauge	0
iblfQueOutUcastTotal.37.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.37.1	Gauge	0
iblfQueOutUcastTotal.37.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.37.2	Gauge	0
iblfQueOutUcastTotal.37.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.37.3	Gauge	0
iblfQueOutUcastTotal.37.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.37.4	Gauge	0
iblfQueOutUcastTotal.37.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.37.5	Gauge	0
iblfQueOutUcastTotal.37.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.37.6	Gauge	0
iblfQueOutUcastTotal.37.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.37.7	Gauge	0
iblfQueOutUcastTotal.37.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.37.8	Gauge	0
iblfQueOutUcastTotal.38.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.38.1	Gauge	0
iblfQueOutUcastTotal.38.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.38.2	Gauge	0
iblfQueOutUcastTotal.38.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.38.3	Gauge	0
iblfQueOutUcastTotal.38.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.38.4	Gauge	0
iblfQueOutUcastTotal.38.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.38.5	Gauge	0
iblfQueOutUcastTotal.38.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.38.6	Gauge	0
iblfQueOutUcastTotal.38.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.38.7	Gauge	0
iblfQueOutUcastTotal.38.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.38.8	Gauge	0
iblfQueOutUcastTotal.39.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.39.1	Gauge	0
iblfQueOutUcastTotal.39.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.39.2	Gauge	0
iblfQueOutUcastTotal.39.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.39.3	Gauge	0
iblfQueOutUcastTotal.39.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.39.4	Gauge	0
iblfQueOutUcastTotal.39.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.39.5	Gauge	0
iblfQueOutUcastTotal.39.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.39.6	Gauge	0
iblfQueOutUcastTotal.39.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.39.7	Gauge	0
iblfQueOutUcastTotal.39.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.39.8	Gauge	0
iblfQueOutUcastTotal.40.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.40.1	Gauge	0
iblfQueOutUcastTotal.40.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.40.2	Gauge	0
iblfQueOutUcastTotal.40.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.40.3	Gauge	0
iblfQueOutUcastTotal.40.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.40.4	Gauge	0
iblfQueOutUcastTotal.40.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.40.5	Gauge	0
iblfQueOutUcastTotal.40.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.40.6	Gauge	0
iblfQueOutUcastTotal.40.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.40.7	Gauge	0
iblfQueOutUcastTotal.40.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.40.8	Gauge	0
iblfQueOutUcastTotal.41.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.41.1	Gauge	0
iblfQueOutUcastTotal.41.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.41.2	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastTotal.41.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.41.3	Gauge	0
iblfQueOutUcastTotal.41.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.41.4	Gauge	0
iblfQueOutUcastTotal.41.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.41.5	Gauge	0
iblfQueOutUcastTotal.41.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.41.6	Gauge	0
iblfQueOutUcastTotal.41.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.41.7	Gauge	0
iblfQueOutUcastTotal.41.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.41.8	Gauge	0
iblfQueOutUcastTotal.42.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.42.1	Gauge	0
iblfQueOutUcastTotal.42.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.42.2	Gauge	0
iblfQueOutUcastTotal.42.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.42.3	Gauge	0
iblfQueOutUcastTotal.42.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.42.4	Gauge	0
iblfQueOutUcastTotal.42.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.42.5	Gauge	0
iblfQueOutUcastTotal.42.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.42.6	Gauge	0
iblfQueOutUcastTotal.42.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.42.7	Gauge	0
iblfQueOutUcastTotal.42.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.42.8	Gauge	0
iblfQueOutUcastTotal.43.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.43.1	Gauge	0
iblfQueOutUcastTotal.43.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.43.2	Gauge	0
iblfQueOutUcastTotal.43.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.43.3	Gauge	0
iblfQueOutUcastTotal.43.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.43.4	Gauge	0
iblfQueOutUcastTotal.43.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.43.5	Gauge	0
iblfQueOutUcastTotal.43.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.43.6	Gauge	0
iblfQueOutUcastTotal.43.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.43.7	Gauge	0
iblfQueOutUcastTotal.43.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.43.8	Gauge	0
iblfQueOutUcastTotal.44.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.44.1	Gauge	0
iblfQueOutUcastTotal.44.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.44.2	Gauge	0
iblfQueOutUcastTotal.44.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.44.3	Gauge	0
iblfQueOutUcastTotal.44.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.44.4	Gauge	0
iblfQueOutUcastTotal.44.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.44.5	Gauge	0
iblfQueOutUcastTotal.44.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.44.6	Gauge	0
iblfQueOutUcastTotal.44.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.44.7	Gauge	0
iblfQueOutUcastTotal.44.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.44.8	Gauge	0
iblfQueOutUcastTotal.45.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.45.1	Gauge	0
iblfQueOutUcastTotal.45.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.45.2	Gauge	0
iblfQueOutUcastTotal.45.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.45.3	Gauge	0
iblfQueOutUcastTotal.45.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.45.4	Gauge	0
iblfQueOutUcastTotal.45.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.45.5	Gauge	0
iblfQueOutUcastTotal.45.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.45.6	Gauge	0
iblfQueOutUcastTotal.45.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.45.7	Gauge	0
iblfQueOutUcastTotal.45.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.45.8	Gauge	0
iblfQueOutUcastTotal.46.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.46.1	Gauge	0
iblfQueOutUcastTotal.46.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.46.2	Gauge	0
iblfQueOutUcastTotal.46.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.46.3	Gauge	0
iblfQueOutUcastTotal.46.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.46.4	Gauge	0
iblfQueOutUcastTotal.46.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.46.5	Gauge	0



Name	OID	Value Type	Value Example
iblfQueOutUcastTotal.46.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.46.6	Gauge	0
iblfQueOutUcastTotal.46.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.46.7	Gauge	0
iblfQueOutUcastTotal.46.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.46.8	Gauge	0
iblfQueOutUcastTotal.47.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.47.1	Gauge	0
iblfQueOutUcastTotal.47.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.47.2	Gauge	0
iblfQueOutUcastTotal.47.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.47.3	Gauge	0
iblfQueOutUcastTotal.47.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.47.4	Gauge	0
iblfQueOutUcastTotal.47.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.47.5	Gauge	0
iblfQueOutUcastTotal.47.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.47.6	Gauge	0
iblfQueOutUcastTotal.47.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.47.7	Gauge	0
iblfQueOutUcastTotal.47.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.47.8	Gauge	0
iblfQueOutUcastTotal.48.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.48.1	Gauge	0
iblfQueOutUcastTotal.48.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.48.2	Gauge	0
iblfQueOutUcastTotal.48.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.48.3	Gauge	0
iblfQueOutUcastTotal.48.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.48.4	Gauge	0
iblfQueOutUcastTotal.48.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.48.5	Gauge	0
iblfQueOutUcastTotal.48.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.48.6	Gauge	0
iblfQueOutUcastTotal.48.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.48.7	Gauge	0
iblfQueOutUcastTotal.48.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.48.8	Gauge	0
iblfQueOutUcastTotal.49.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.49.1	Gauge	0
iblfQueOutUcastTotal.49.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.49.2	Gauge	0
iblfQueOutUcastTotal.49.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.49.3	Gauge	0
iblfQueOutUcastTotal.49.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.49.4	Gauge	0
iblfQueOutUcastTotal.49.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.49.5	Gauge	0
iblfQueOutUcastTotal.49.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.49.6	Gauge	0
iblfQueOutUcastTotal.49.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.49.7	Gauge	0
iblfQueOutUcastTotal.49.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.49.8	Gauge	0
iblfQueOutUcastTotal.50.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.50.1	Gauge	0
iblfQueOutUcastTotal.50.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.50.2	Gauge	0
iblfQueOutUcastTotal.50.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.50.3	Gauge	0
iblfQueOutUcastTotal.50.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.50.4	Gauge	0
iblfQueOutUcastTotal.50.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.50.5	Gauge	0
iblfQueOutUcastTotal.50.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.50.6	Gauge	0
iblfQueOutUcastTotal.50.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.50.7	Gauge	0
iblfQueOutUcastTotal.50.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.50.8	Gauge	0
iblfQueOutUcastTotal.51.1	.3.6.1.4.1.26138.2.40.2.2.6.1.2.51.1	Gauge	0
iblfQueOutUcastTotal.51.2	.3.6.1.4.1.26138.2.40.2.2.6.1.2.51.2	Gauge	0
iblfQueOutUcastTotal.51.3	.3.6.1.4.1.26138.2.40.2.2.6.1.2.51.3	Gauge	0
iblfQueOutUcastTotal.51.4	.3.6.1.4.1.26138.2.40.2.2.6.1.2.51.4	Gauge	0
iblfQueOutUcastTotal.51.5	.3.6.1.4.1.26138.2.40.2.2.6.1.2.51.5	Gauge	0
iblfQueOutUcastTotal.51.6	.3.6.1.4.1.26138.2.40.2.2.6.1.2.51.6	Gauge	0
iblfQueOutUcastTotal.51.7	.3.6.1.4.1.26138.2.40.2.2.6.1.2.51.7	Gauge	0
iblfQueOutUcastTotal.51.8	.3.6.1.4.1.26138.2.40.2.2.6.1.2.51.8	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastTotal.52.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.52.1	Gauge	0
iblfQueOutUcastTotal.52.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.52.2	Gauge	0
iblfQueOutUcastTotal.52.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.52.3	Gauge	0
iblfQueOutUcastTotal.52.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.52.4	Gauge	0
iblfQueOutUcastTotal.52.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.52.5	Gauge	0
iblfQueOutUcastTotal.52.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.52.6	Gauge	0
iblfQueOutUcastTotal.52.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.52.7	Gauge	0
iblfQueOutUcastTotal.52.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.52.8	Gauge	0
iblfQueOutUcastTotal.53.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.53.1	Gauge	0
iblfQueOutUcastTotal.53.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.53.2	Gauge	0
iblfQueOutUcastTotal.53.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.53.3	Gauge	0
iblfQueOutUcastTotal.53.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.53.4	Gauge	0
iblfQueOutUcastTotal.53.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.53.5	Gauge	0
iblfQueOutUcastTotal.53.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.53.6	Gauge	0
iblfQueOutUcastTotal.53.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.53.7	Gauge	0
iblfQueOutUcastTotal.53.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.53.8	Gauge	0
iblfQueOutUcastTotal.54.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.54.1	Gauge	0
iblfQueOutUcastTotal.54.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.54.2	Gauge	0
iblfQueOutUcastTotal.54.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.54.3	Gauge	0
iblfQueOutUcastTotal.54.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.54.4	Gauge	0
iblfQueOutUcastTotal.54.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.54.5	Gauge	0
iblfQueOutUcastTotal.54.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.54.6	Gauge	0
iblfQueOutUcastTotal.54.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.54.7	Gauge	0
iblfQueOutUcastTotal.54.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.2.54.8	Gauge	0
iblfQueOutUcastFree.1.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.3.1.1	Gauge	0
iblfQueOutUcastFree.1.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.3.1.2	Gauge	0
iblfQueOutUcastFree.1.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.3.1.3	Gauge	0
iblfQueOutUcastFree.1.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.3.1.4	Gauge	0
iblfQueOutUcastFree.1.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.3.1.5	Gauge	0
iblfQueOutUcastFree.1.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.3.1.6	Gauge	0
iblfQueOutUcastFree.1.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.3.1.7	Gauge	0
iblfQueOutUcastFree.1.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.3.1.8	Gauge	0
iblfQueOutUcastFree.2.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.3.2.1	Gauge	0
iblfQueOutUcastFree.2.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.3.2.2	Gauge	0
iblfQueOutUcastFree.2.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.3.2.3	Gauge	0
iblfQueOutUcastFree.2.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.3.2.4	Gauge	0
iblfQueOutUcastFree.2.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.3.2.5	Gauge	0
iblfQueOutUcastFree.2.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.3.2.6	Gauge	0
iblfQueOutUcastFree.2.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.3.2.7	Gauge	0
iblfQueOutUcastFree.2.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.3.2.8	Gauge	0
iblfQueOutUcastFree.3.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.3.3.1	Gauge	0
iblfQueOutUcastFree.3.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.3.3.2	Gauge	0
iblfQueOutUcastFree.3.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.3.3.3	Gauge	0



Name	OID	Value Type	Value Example
iblfQueOutUcastFree.3.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.3.4	Gauge	0
iblfQueOutUcastFree.3.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.3.5	Gauge	0
iblfQueOutUcastFree.3.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.3.6	Gauge	0
iblfQueOutUcastFree.3.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.3.7	Gauge	0
iblfQueOutUcastFree.3.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.3.8	Gauge	0
iblfQueOutUcastFree.4.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.4.1	Gauge	0
iblfQueOutUcastFree.4.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.4.2	Gauge	0
iblfQueOutUcastFree.4.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.4.3	Gauge	0
iblfQueOutUcastFree.4.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.4.4	Gauge	0
iblfQueOutUcastFree.4.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.4.5	Gauge	0
iblfQueOutUcastFree.4.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.4.6	Gauge	0
iblfQueOutUcastFree.4.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.4.7	Gauge	0
iblfQueOutUcastFree.4.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.4.8	Gauge	0
iblfQueOutUcastFree.5.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.5.1	Gauge	0
iblfQueOutUcastFree.5.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.5.2	Gauge	0
iblfQueOutUcastFree.5.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.5.3	Gauge	0
iblfQueOutUcastFree.5.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.5.4	Gauge	0
iblfQueOutUcastFree.5.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.5.5	Gauge	0
iblfQueOutUcastFree.5.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.5.6	Gauge	0
iblfQueOutUcastFree.5.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.5.7	Gauge	0
iblfQueOutUcastFree.5.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.5.8	Gauge	0
iblfQueOutUcastFree.6.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.6.1	Gauge	0
iblfQueOutUcastFree.6.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.6.2	Gauge	0
iblfQueOutUcastFree.6.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.6.3	Gauge	0
iblfQueOutUcastFree.6.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.6.4	Gauge	0
iblfQueOutUcastFree.6.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.6.5	Gauge	0
iblfQueOutUcastFree.6.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.6.6	Gauge	0
iblfQueOutUcastFree.6.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.6.7	Gauge	0
iblfQueOutUcastFree.6.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.6.8	Gauge	0
iblfQueOutUcastFree.7.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.7.1	Gauge	0
iblfQueOutUcastFree.7.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.7.2	Gauge	0
iblfQueOutUcastFree.7.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.7.3	Gauge	0
iblfQueOutUcastFree.7.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.7.4	Gauge	0
iblfQueOutUcastFree.7.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.7.5	Gauge	0
iblfQueOutUcastFree.7.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.7.6	Gauge	0
iblfQueOutUcastFree.7.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.7.7	Gauge	0
iblfQueOutUcastFree.7.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.7.8	Gauge	0
iblfQueOutUcastFree.8.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.8.1	Gauge	0
iblfQueOutUcastFree.8.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.8.2	Gauge	0
iblfQueOutUcastFree.8.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.8.3	Gauge	0
iblfQueOutUcastFree.8.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.8.4	Gauge	0
iblfQueOutUcastFree.8.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.8.5	Gauge	0
iblfQueOutUcastFree.8.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.8.6	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastFree.8.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.8.7	Gauge	0
iblfQueOutUcastFree.8.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.8.8	Gauge	0
iblfQueOutUcastFree.9.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.9.1	Gauge	0
iblfQueOutUcastFree.9.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.9.2	Gauge	0
iblfQueOutUcastFree.9.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.9.3	Gauge	0
iblfQueOutUcastFree.9.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.9.4	Gauge	0
iblfQueOutUcastFree.9.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.9.5	Gauge	0
iblfQueOutUcastFree.9.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.9.6	Gauge	0
iblfQueOutUcastFree.9.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.9.7	Gauge	0
iblfQueOutUcastFree.9.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.9.8	Gauge	0
iblfQueOutUcastFree.10.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.10.1	Gauge	0
iblfQueOutUcastFree.10.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.10.2	Gauge	0
iblfQueOutUcastFree.10.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.10.3	Gauge	0
iblfQueOutUcastFree.10.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.10.4	Gauge	0
iblfQueOutUcastFree.10.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.10.5	Gauge	0
iblfQueOutUcastFree.10.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.10.6	Gauge	0
iblfQueOutUcastFree.10.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.10.7	Gauge	0
iblfQueOutUcastFree.10.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.10.8	Gauge	0
iblfQueOutUcastFree.11.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.11.1	Gauge	0
iblfQueOutUcastFree.11.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.11.2	Gauge	0
iblfQueOutUcastFree.11.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.11.3	Gauge	0
iblfQueOutUcastFree.11.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.11.4	Gauge	0
iblfQueOutUcastFree.11.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.11.5	Gauge	0
iblfQueOutUcastFree.11.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.11.6	Gauge	0
iblfQueOutUcastFree.11.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.11.7	Gauge	0
iblfQueOutUcastFree.11.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.11.8	Gauge	0
iblfQueOutUcastFree.12.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.12.1	Gauge	0
iblfQueOutUcastFree.12.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.12.2	Gauge	0
iblfQueOutUcastFree.12.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.12.3	Gauge	0
iblfQueOutUcastFree.12.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.12.4	Gauge	0
iblfQueOutUcastFree.12.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.12.5	Gauge	0
iblfQueOutUcastFree.12.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.12.6	Gauge	0
iblfQueOutUcastFree.12.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.12.7	Gauge	0
iblfQueOutUcastFree.12.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.12.8	Gauge	0
iblfQueOutUcastFree.13.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.13.1	Gauge	0
iblfQueOutUcastFree.13.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.13.2	Gauge	0
iblfQueOutUcastFree.13.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.13.3	Gauge	0
iblfQueOutUcastFree.13.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.13.4	Gauge	0
iblfQueOutUcastFree.13.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.13.5	Gauge	0
iblfQueOutUcastFree.13.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.13.6	Gauge	0
iblfQueOutUcastFree.13.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.13.7	Gauge	0
iblfQueOutUcastFree.13.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.13.8	Gauge	0
iblfQueOutUcastFree.14.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.14.1	Gauge	0

Name	OID	Value Type	Value Example
ibLfQueOutUcastFree.14.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.14.2	Gauge	0
ibLfQueOutUcastFree.14.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.14.3	Gauge	0
ibLfQueOutUcastFree.14.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.14.4	Gauge	0
ibLfQueOutUcastFree.14.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.14.5	Gauge	0
ibLfQueOutUcastFree.14.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.14.6	Gauge	0
ibLfQueOutUcastFree.14.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.14.7	Gauge	0
ibLfQueOutUcastFree.14.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.14.8	Gauge	0
ibLfQueOutUcastFree.15.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.15.1	Gauge	0
ibLfQueOutUcastFree.15.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.15.2	Gauge	0
ibLfQueOutUcastFree.15.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.15.3	Gauge	0
ibLfQueOutUcastFree.15.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.15.4	Gauge	0
ibLfQueOutUcastFree.15.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.15.5	Gauge	0
ibLfQueOutUcastFree.15.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.15.6	Gauge	0
ibLfQueOutUcastFree.15.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.15.7	Gauge	0
ibLfQueOutUcastFree.15.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.15.8	Gauge	0
ibLfQueOutUcastFree.16.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.16.1	Gauge	0
ibLfQueOutUcastFree.16.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.16.2	Gauge	0
ibLfQueOutUcastFree.16.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.16.3	Gauge	0
ibLfQueOutUcastFree.16.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.16.4	Gauge	0
ibLfQueOutUcastFree.16.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.16.5	Gauge	0
ibLfQueOutUcastFree.16.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.16.6	Gauge	0
ibLfQueOutUcastFree.16.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.16.7	Gauge	0
ibLfQueOutUcastFree.16.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.16.8	Gauge	0
ibLfQueOutUcastFree.17.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.17.1	Gauge	0
ibLfQueOutUcastFree.17.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.17.2	Gauge	0
ibLfQueOutUcastFree.17.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.17.3	Gauge	0
ibLfQueOutUcastFree.17.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.17.4	Gauge	0
ibLfQueOutUcastFree.17.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.17.5	Gauge	0
ibLfQueOutUcastFree.17.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.17.6	Gauge	0
ibLfQueOutUcastFree.17.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.17.7	Gauge	0
ibLfQueOutUcastFree.17.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.17.8	Gauge	0
ibLfQueOutUcastFree.18.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.18.1	Gauge	0
ibLfQueOutUcastFree.18.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.18.2	Gauge	0
ibLfQueOutUcastFree.18.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.18.3	Gauge	0
ibLfQueOutUcastFree.18.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.18.4	Gauge	0
ibLfQueOutUcastFree.18.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.18.5	Gauge	0
ibLfQueOutUcastFree.18.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.18.6	Gauge	0
ibLfQueOutUcastFree.18.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.18.7	Gauge	0
ibLfQueOutUcastFree.18.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.18.8	Gauge	0
ibLfQueOutUcastFree.19.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.19.1	Gauge	0
ibLfQueOutUcastFree.19.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.19.2	Gauge	0
ibLfQueOutUcastFree.19.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.19.3	Gauge	0
ibLfQueOutUcastFree.19.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.19.4	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastFree.19.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.19.5	Gauge	0
iblfQueOutUcastFree.19.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.19.6	Gauge	0
iblfQueOutUcastFree.19.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.19.7	Gauge	0
iblfQueOutUcastFree.19.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.19.8	Gauge	0
iblfQueOutUcastFree.20.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.20.1	Gauge	0
iblfQueOutUcastFree.20.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.20.2	Gauge	0
iblfQueOutUcastFree.20.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.20.3	Gauge	0
iblfQueOutUcastFree.20.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.20.4	Gauge	0
iblfQueOutUcastFree.20.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.20.5	Gauge	0
iblfQueOutUcastFree.20.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.20.6	Gauge	0
iblfQueOutUcastFree.20.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.20.7	Gauge	0
iblfQueOutUcastFree.20.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.20.8	Gauge	0
iblfQueOutUcastFree.21.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.21.1	Gauge	0
iblfQueOutUcastFree.21.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.21.2	Gauge	0
iblfQueOutUcastFree.21.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.21.3	Gauge	0
iblfQueOutUcastFree.21.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.21.4	Gauge	0
iblfQueOutUcastFree.21.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.21.5	Gauge	0
iblfQueOutUcastFree.21.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.21.6	Gauge	0
iblfQueOutUcastFree.21.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.21.7	Gauge	0
iblfQueOutUcastFree.21.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.21.8	Gauge	0
iblfQueOutUcastFree.22.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.22.1	Gauge	0
iblfQueOutUcastFree.22.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.22.2	Gauge	0
iblfQueOutUcastFree.22.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.22.3	Gauge	0
iblfQueOutUcastFree.22.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.22.4	Gauge	0
iblfQueOutUcastFree.22.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.22.5	Gauge	0
iblfQueOutUcastFree.22.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.22.6	Gauge	0
iblfQueOutUcastFree.22.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.22.7	Gauge	0
iblfQueOutUcastFree.22.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.22.8	Gauge	0
iblfQueOutUcastFree.23.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.23.1	Gauge	0
iblfQueOutUcastFree.23.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.23.2	Gauge	0
iblfQueOutUcastFree.23.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.23.3	Gauge	0
iblfQueOutUcastFree.23.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.23.4	Gauge	0
iblfQueOutUcastFree.23.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.23.5	Gauge	0
iblfQueOutUcastFree.23.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.23.6	Gauge	0
iblfQueOutUcastFree.23.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.23.7	Gauge	0
iblfQueOutUcastFree.23.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.23.8	Gauge	0
iblfQueOutUcastFree.24.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.24.1	Gauge	0
iblfQueOutUcastFree.24.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.24.2	Gauge	0
iblfQueOutUcastFree.24.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.24.3	Gauge	0
iblfQueOutUcastFree.24.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.24.4	Gauge	0
iblfQueOutUcastFree.24.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.24.5	Gauge	0
iblfQueOutUcastFree.24.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.24.6	Gauge	0
iblfQueOutUcastFree.24.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.24.7	Gauge	0

Name	OID	Value Type	Value Example
ibLfQueOutUcastFree.24.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.24.8	Gauge	0
ibLfQueOutUcastFree.25.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.25.1	Gauge	0
ibLfQueOutUcastFree.25.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.25.2	Gauge	0
ibLfQueOutUcastFree.25.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.25.3	Gauge	0
ibLfQueOutUcastFree.25.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.25.4	Gauge	0
ibLfQueOutUcastFree.25.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.25.5	Gauge	0
ibLfQueOutUcastFree.25.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.25.6	Gauge	0
ibLfQueOutUcastFree.25.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.25.7	Gauge	0
ibLfQueOutUcastFree.25.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.25.8	Gauge	0
ibLfQueOutUcastFree.26.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.26.1	Gauge	0
ibLfQueOutUcastFree.26.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.26.2	Gauge	0
ibLfQueOutUcastFree.26.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.26.3	Gauge	0
ibLfQueOutUcastFree.26.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.26.4	Gauge	0
ibLfQueOutUcastFree.26.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.26.5	Gauge	0
ibLfQueOutUcastFree.26.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.26.6	Gauge	0
ibLfQueOutUcastFree.26.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.26.7	Gauge	0
ibLfQueOutUcastFree.26.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.26.8	Gauge	0
ibLfQueOutUcastFree.27.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.27.1	Gauge	0
ibLfQueOutUcastFree.27.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.27.2	Gauge	0
ibLfQueOutUcastFree.27.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.27.3	Gauge	0
ibLfQueOutUcastFree.27.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.27.4	Gauge	0
ibLfQueOutUcastFree.27.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.27.5	Gauge	0
ibLfQueOutUcastFree.27.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.27.6	Gauge	0
ibLfQueOutUcastFree.27.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.27.7	Gauge	0
ibLfQueOutUcastFree.27.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.27.8	Gauge	0
ibLfQueOutUcastFree.28.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.28.1	Gauge	0
ibLfQueOutUcastFree.28.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.28.2	Gauge	0
ibLfQueOutUcastFree.28.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.28.3	Gauge	0
ibLfQueOutUcastFree.28.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.28.4	Gauge	0
ibLfQueOutUcastFree.28.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.28.5	Gauge	0
ibLfQueOutUcastFree.28.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.28.6	Gauge	0
ibLfQueOutUcastFree.28.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.28.7	Gauge	0
ibLfQueOutUcastFree.28.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.28.8	Gauge	0
ibLfQueOutUcastFree.29.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.29.1	Gauge	0
ibLfQueOutUcastFree.29.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.29.2	Gauge	0
ibLfQueOutUcastFree.29.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.29.3	Gauge	0
ibLfQueOutUcastFree.29.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.29.4	Gauge	0
ibLfQueOutUcastFree.29.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.29.5	Gauge	0
ibLfQueOutUcastFree.29.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.29.6	Gauge	0
ibLfQueOutUcastFree.29.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.29.7	Gauge	0
ibLfQueOutUcastFree.29.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.29.8	Gauge	0
ibLfQueOutUcastFree.30.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.30.1	Gauge	0
ibLfQueOutUcastFree.30.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.30.2	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastFree.30.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.30.3	Gauge	0
iblfQueOutUcastFree.30.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.30.4	Gauge	0
iblfQueOutUcastFree.30.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.30.5	Gauge	0
iblfQueOutUcastFree.30.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.30.6	Gauge	0
iblfQueOutUcastFree.30.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.30.7	Gauge	0
iblfQueOutUcastFree.30.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.30.8	Gauge	0
iblfQueOutUcastFree.31.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.31.1	Gauge	0
iblfQueOutUcastFree.31.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.31.2	Gauge	0
iblfQueOutUcastFree.31.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.31.3	Gauge	0
iblfQueOutUcastFree.31.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.31.4	Gauge	0
iblfQueOutUcastFree.31.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.31.5	Gauge	0
iblfQueOutUcastFree.31.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.31.6	Gauge	0
iblfQueOutUcastFree.31.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.31.7	Gauge	0
iblfQueOutUcastFree.31.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.31.8	Gauge	0
iblfQueOutUcastFree.32.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.32.1	Gauge	0
iblfQueOutUcastFree.32.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.32.2	Gauge	0
iblfQueOutUcastFree.32.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.32.3	Gauge	0
iblfQueOutUcastFree.32.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.32.4	Gauge	0
iblfQueOutUcastFree.32.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.32.5	Gauge	0
iblfQueOutUcastFree.32.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.32.6	Gauge	0
iblfQueOutUcastFree.32.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.32.7	Gauge	0
iblfQueOutUcastFree.32.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.32.8	Gauge	0
iblfQueOutUcastFree.33.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.33.1	Gauge	0
iblfQueOutUcastFree.33.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.33.2	Gauge	0
iblfQueOutUcastFree.33.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.33.3	Gauge	0
iblfQueOutUcastFree.33.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.33.4	Gauge	0
iblfQueOutUcastFree.33.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.33.5	Gauge	0
iblfQueOutUcastFree.33.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.33.6	Gauge	0
iblfQueOutUcastFree.33.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.33.7	Gauge	0
iblfQueOutUcastFree.33.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.33.8	Gauge	0
iblfQueOutUcastFree.34.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.34.1	Gauge	0
iblfQueOutUcastFree.34.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.34.2	Gauge	0
iblfQueOutUcastFree.34.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.34.3	Gauge	0
iblfQueOutUcastFree.34.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.34.4	Gauge	0
iblfQueOutUcastFree.34.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.34.5	Gauge	0
iblfQueOutUcastFree.34.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.34.6	Gauge	0
iblfQueOutUcastFree.34.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.34.7	Gauge	0
iblfQueOutUcastFree.34.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.34.8	Gauge	0
iblfQueOutUcastFree.35.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.35.1	Gauge	0
iblfQueOutUcastFree.35.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.35.2	Gauge	0
iblfQueOutUcastFree.35.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.35.3	Gauge	0
iblfQueOutUcastFree.35.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.35.4	Gauge	0
iblfQueOutUcastFree.35.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.35.5	Gauge	0

Name	OID	Value Type	Value Example
ibLfQueOutUcastFree.35.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.35.6	Gauge	0
ibLfQueOutUcastFree.35.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.35.7	Gauge	0
ibLfQueOutUcastFree.35.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.35.8	Gauge	0
ibLfQueOutUcastFree.36.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.36.1	Gauge	0
ibLfQueOutUcastFree.36.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.36.2	Gauge	0
ibLfQueOutUcastFree.36.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.36.3	Gauge	0
ibLfQueOutUcastFree.36.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.36.4	Gauge	0
ibLfQueOutUcastFree.36.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.36.5	Gauge	0
ibLfQueOutUcastFree.36.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.36.6	Gauge	0
ibLfQueOutUcastFree.36.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.36.7	Gauge	0
ibLfQueOutUcastFree.36.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.36.8	Gauge	0
ibLfQueOutUcastFree.37.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.37.1	Gauge	0
ibLfQueOutUcastFree.37.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.37.2	Gauge	0
ibLfQueOutUcastFree.37.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.37.3	Gauge	0
ibLfQueOutUcastFree.37.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.37.4	Gauge	0
ibLfQueOutUcastFree.37.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.37.5	Gauge	0
ibLfQueOutUcastFree.37.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.37.6	Gauge	0
ibLfQueOutUcastFree.37.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.37.7	Gauge	0
ibLfQueOutUcastFree.37.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.37.8	Gauge	0
ibLfQueOutUcastFree.38.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.38.1	Gauge	0
ibLfQueOutUcastFree.38.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.38.2	Gauge	0
ibLfQueOutUcastFree.38.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.38.3	Gauge	0
ibLfQueOutUcastFree.38.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.38.4	Gauge	0
ibLfQueOutUcastFree.38.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.38.5	Gauge	0
ibLfQueOutUcastFree.38.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.38.6	Gauge	0
ibLfQueOutUcastFree.38.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.38.7	Gauge	0
ibLfQueOutUcastFree.38.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.38.8	Gauge	0
ibLfQueOutUcastFree.39.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.39.1	Gauge	0
ibLfQueOutUcastFree.39.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.39.2	Gauge	0
ibLfQueOutUcastFree.39.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.39.3	Gauge	0
ibLfQueOutUcastFree.39.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.39.4	Gauge	0
ibLfQueOutUcastFree.39.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.39.5	Gauge	0
ibLfQueOutUcastFree.39.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.39.6	Gauge	0
ibLfQueOutUcastFree.39.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.39.7	Gauge	0
ibLfQueOutUcastFree.39.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.39.8	Gauge	0
ibLfQueOutUcastFree.40.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.40.1	Gauge	0
ibLfQueOutUcastFree.40.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.40.2	Gauge	0
ibLfQueOutUcastFree.40.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.40.3	Gauge	0
ibLfQueOutUcastFree.40.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.40.4	Gauge	0
ibLfQueOutUcastFree.40.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.40.5	Gauge	0
ibLfQueOutUcastFree.40.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.40.6	Gauge	0
ibLfQueOutUcastFree.40.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.40.7	Gauge	0
ibLfQueOutUcastFree.40.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.40.8	Gauge	0



Name	OID	Value Type	Value Example
iblfQueOutUcastFree.41.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.41.1	Gauge	0
iblfQueOutUcastFree.41.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.41.2	Gauge	0
iblfQueOutUcastFree.41.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.41.3	Gauge	0
iblfQueOutUcastFree.41.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.41.4	Gauge	0
iblfQueOutUcastFree.41.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.41.5	Gauge	0
iblfQueOutUcastFree.41.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.41.6	Gauge	0
iblfQueOutUcastFree.41.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.41.7	Gauge	0
iblfQueOutUcastFree.41.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.41.8	Gauge	0
iblfQueOutUcastFree.42.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.42.1	Gauge	0
iblfQueOutUcastFree.42.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.42.2	Gauge	0
iblfQueOutUcastFree.42.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.42.3	Gauge	0
iblfQueOutUcastFree.42.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.42.4	Gauge	0
iblfQueOutUcastFree.42.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.42.5	Gauge	0
iblfQueOutUcastFree.42.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.42.6	Gauge	0
iblfQueOutUcastFree.42.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.42.7	Gauge	0
iblfQueOutUcastFree.42.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.42.8	Gauge	0
iblfQueOutUcastFree.43.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.43.1	Gauge	0
iblfQueOutUcastFree.43.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.43.2	Gauge	0
iblfQueOutUcastFree.43.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.43.3	Gauge	0
iblfQueOutUcastFree.43.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.43.4	Gauge	0
iblfQueOutUcastFree.43.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.43.5	Gauge	0
iblfQueOutUcastFree.43.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.43.6	Gauge	0
iblfQueOutUcastFree.43.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.43.7	Gauge	0
iblfQueOutUcastFree.43.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.43.8	Gauge	0
iblfQueOutUcastFree.44.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.44.1	Gauge	0
iblfQueOutUcastFree.44.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.44.2	Gauge	0
iblfQueOutUcastFree.44.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.44.3	Gauge	0
iblfQueOutUcastFree.44.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.44.4	Gauge	0
iblfQueOutUcastFree.44.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.44.5	Gauge	0
iblfQueOutUcastFree.44.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.44.6	Gauge	0
iblfQueOutUcastFree.44.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.44.7	Gauge	0
iblfQueOutUcastFree.44.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.44.8	Gauge	0
iblfQueOutUcastFree.45.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.45.1	Gauge	0
iblfQueOutUcastFree.45.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.45.2	Gauge	0
iblfQueOutUcastFree.45.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.45.3	Gauge	0
iblfQueOutUcastFree.45.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.45.4	Gauge	0
iblfQueOutUcastFree.45.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.45.5	Gauge	0
iblfQueOutUcastFree.45.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.45.6	Gauge	0
iblfQueOutUcastFree.45.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.45.7	Gauge	0
iblfQueOutUcastFree.45.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.45.8	Gauge	0
iblfQueOutUcastFree.46.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.46.1	Gauge	0
iblfQueOutUcastFree.46.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.46.2	Gauge	0
iblfQueOutUcastFree.46.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.46.3	Gauge	0



Name	OID	Value Type	Value Example
iblfQueOutUcastFree.46.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.46.4	Gauge	0
iblfQueOutUcastFree.46.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.46.5	Gauge	0
iblfQueOutUcastFree.46.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.46.6	Gauge	0
iblfQueOutUcastFree.46.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.46.7	Gauge	0
iblfQueOutUcastFree.46.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.46.8	Gauge	0
iblfQueOutUcastFree.47.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.47.1	Gauge	0
iblfQueOutUcastFree.47.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.47.2	Gauge	0
iblfQueOutUcastFree.47.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.47.3	Gauge	0
iblfQueOutUcastFree.47.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.47.4	Gauge	0
iblfQueOutUcastFree.47.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.47.5	Gauge	0
iblfQueOutUcastFree.47.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.47.6	Gauge	0
iblfQueOutUcastFree.47.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.47.7	Gauge	0
iblfQueOutUcastFree.47.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.47.8	Gauge	0
iblfQueOutUcastFree.48.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.48.1	Gauge	0
iblfQueOutUcastFree.48.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.48.2	Gauge	0
iblfQueOutUcastFree.48.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.48.3	Gauge	0
iblfQueOutUcastFree.48.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.48.4	Gauge	0
iblfQueOutUcastFree.48.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.48.5	Gauge	0
iblfQueOutUcastFree.48.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.48.6	Gauge	0
iblfQueOutUcastFree.48.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.48.7	Gauge	0
iblfQueOutUcastFree.48.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.48.8	Gauge	0
iblfQueOutUcastFree.49.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.49.1	Gauge	0
iblfQueOutUcastFree.49.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.49.2	Gauge	0
iblfQueOutUcastFree.49.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.49.3	Gauge	0
iblfQueOutUcastFree.49.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.49.4	Gauge	0
iblfQueOutUcastFree.49.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.49.5	Gauge	0
iblfQueOutUcastFree.49.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.49.6	Gauge	0
iblfQueOutUcastFree.49.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.49.7	Gauge	0
iblfQueOutUcastFree.49.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.49.8	Gauge	0
iblfQueOutUcastFree.50.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.50.1	Gauge	0
iblfQueOutUcastFree.50.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.50.2	Gauge	0
iblfQueOutUcastFree.50.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.50.3	Gauge	0
iblfQueOutUcastFree.50.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.50.4	Gauge	0
iblfQueOutUcastFree.50.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.50.5	Gauge	0
iblfQueOutUcastFree.50.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.50.6	Gauge	0
iblfQueOutUcastFree.50.7	.3.6.1.4.1.26138.2.40.2.2.6.1.3.50.7	Gauge	0
iblfQueOutUcastFree.50.8	.3.6.1.4.1.26138.2.40.2.2.6.1.3.50.8	Gauge	0
iblfQueOutUcastFree.51.1	.3.6.1.4.1.26138.2.40.2.2.6.1.3.51.1	Gauge	0
iblfQueOutUcastFree.51.2	.3.6.1.4.1.26138.2.40.2.2.6.1.3.51.2	Gauge	0
iblfQueOutUcastFree.51.3	.3.6.1.4.1.26138.2.40.2.2.6.1.3.51.3	Gauge	0
iblfQueOutUcastFree.51.4	.3.6.1.4.1.26138.2.40.2.2.6.1.3.51.4	Gauge	0
iblfQueOutUcastFree.51.5	.3.6.1.4.1.26138.2.40.2.2.6.1.3.51.5	Gauge	0
iblfQueOutUcastFree.51.6	.3.6.1.4.1.26138.2.40.2.2.6.1.3.51.6	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastFree.51.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.51.7	Gauge	0
iblfQueOutUcastFree.51.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.51.8	Gauge	0
iblfQueOutUcastFree.52.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.52.1	Gauge	0
iblfQueOutUcastFree.52.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.52.2	Gauge	0
iblfQueOutUcastFree.52.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.52.3	Gauge	0
iblfQueOutUcastFree.52.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.52.4	Gauge	0
iblfQueOutUcastFree.52.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.52.5	Gauge	0
iblfQueOutUcastFree.52.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.52.6	Gauge	0
iblfQueOutUcastFree.52.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.52.7	Gauge	0
iblfQueOutUcastFree.52.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.52.8	Gauge	0
iblfQueOutUcastFree.53.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.53.1	Gauge	0
iblfQueOutUcastFree.53.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.53.2	Gauge	0
iblfQueOutUcastFree.53.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.53.3	Gauge	0
iblfQueOutUcastFree.53.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.53.4	Gauge	0
iblfQueOutUcastFree.53.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.53.5	Gauge	0
iblfQueOutUcastFree.53.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.53.6	Gauge	0
iblfQueOutUcastFree.53.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.53.7	Gauge	0
iblfQueOutUcastFree.53.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.53.8	Gauge	0
iblfQueOutUcastFree.54.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.54.1	Gauge	0
iblfQueOutUcastFree.54.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.54.2	Gauge	0
iblfQueOutUcastFree.54.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.54.3	Gauge	0
iblfQueOutUcastFree.54.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.54.4	Gauge	0
iblfQueOutUcastFree.54.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.54.5	Gauge	0
iblfQueOutUcastFree.54.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.54.6	Gauge	0
iblfQueOutUcastFree.54.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.54.7	Gauge	0
iblfQueOutUcastFree.54.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.3.54.8	Gauge	0
iblfQueOutUcastUsedRatio.1.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.1.1	Gauge	0
iblfQueOutUcastUsedRatio.1.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.1.2	Gauge	0
iblfQueOutUcastUsedRatio.1.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.1.3	Gauge	0
iblfQueOutUcastUsedRatio.1.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.1.4	Gauge	0
iblfQueOutUcastUsedRatio.1.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.1.5	Gauge	0
iblfQueOutUcastUsedRatio.1.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.1.6	Gauge	0
iblfQueOutUcastUsedRatio.1.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.1.7	Gauge	0
iblfQueOutUcastUsedRatio.1.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.1.8	Gauge	0
iblfQueOutUcastUsedRatio.2.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.2.1	Gauge	0
iblfQueOutUcastUsedRatio.2.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.2.2	Gauge	0
iblfQueOutUcastUsedRatio.2.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.2.3	Gauge	0
iblfQueOutUcastUsedRatio.2.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.2.4	Gauge	0
iblfQueOutUcastUsedRatio.2.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.2.5	Gauge	0
iblfQueOutUcastUsedRatio.2.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.2.6	Gauge	0
iblfQueOutUcastUsedRatio.2.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.2.7	Gauge	0
iblfQueOutUcastUsedRatio.2.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.2.8	Gauge	0
iblfQueOutUcastUsedRatio.3.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.3.1	Gauge	0



Name	OID	Value Type	Value Example
iblfQueOutUcastUsedRatio.8.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.8.5	Gauge	0
iblfQueOutUcastUsedRatio.8.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.8.6	Gauge	0
iblfQueOutUcastUsedRatio.8.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.8.7	Gauge	0
iblfQueOutUcastUsedRatio.8.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.8.8	Gauge	0
iblfQueOutUcastUsedRatio.9.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.9.1	Gauge	0
iblfQueOutUcastUsedRatio.9.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.9.2	Gauge	0
iblfQueOutUcastUsedRatio.9.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.9.3	Gauge	0
iblfQueOutUcastUsedRatio.9.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.9.4	Gauge	0
iblfQueOutUcastUsedRatio.9.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.9.5	Gauge	0
iblfQueOutUcastUsedRatio.9.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.9.6	Gauge	0
iblfQueOutUcastUsedRatio.9.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.9.7	Gauge	0
iblfQueOutUcastUsedRatio.9.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.9.8	Gauge	0
iblfQueOutUcastUsedRatio.10.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.10.1	Gauge	0
iblfQueOutUcastUsedRatio.10.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.10.2	Gauge	0
iblfQueOutUcastUsedRatio.10.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.10.3	Gauge	0
iblfQueOutUcastUsedRatio.10.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.10.4	Gauge	0
iblfQueOutUcastUsedRatio.10.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.10.5	Gauge	0
iblfQueOutUcastUsedRatio.10.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.10.6	Gauge	0
iblfQueOutUcastUsedRatio.10.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.10.7	Gauge	0
iblfQueOutUcastUsedRatio.10.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.10.8	Gauge	0
iblfQueOutUcastUsedRatio.11.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.11.1	Gauge	0
iblfQueOutUcastUsedRatio.11.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.11.2	Gauge	0
iblfQueOutUcastUsedRatio.11.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.11.3	Gauge	0
iblfQueOutUcastUsedRatio.11.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.11.4	Gauge	0
iblfQueOutUcastUsedRatio.11.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.11.5	Gauge	0
iblfQueOutUcastUsedRatio.11.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.11.6	Gauge	0
iblfQueOutUcastUsedRatio.11.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.11.7	Gauge	0
iblfQueOutUcastUsedRatio.11.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.11.8	Gauge	0
iblfQueOutUcastUsedRatio.12.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.12.1	Gauge	0
iblfQueOutUcastUsedRatio.12.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.12.2	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsedRatio.12.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.12.3	Gauge	0
iblfQueOutUcastUsedRatio.12.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.12.4	Gauge	0
iblfQueOutUcastUsedRatio.12.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.12.5	Gauge	0
iblfQueOutUcastUsedRatio.12.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.12.6	Gauge	0
iblfQueOutUcastUsedRatio.12.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.12.7	Gauge	0
iblfQueOutUcastUsedRatio.12.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.12.8	Gauge	0
iblfQueOutUcastUsedRatio.13.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.13.1	Gauge	0
iblfQueOutUcastUsedRatio.13.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.13.2	Gauge	0
iblfQueOutUcastUsedRatio.13.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.13.3	Gauge	0
iblfQueOutUcastUsedRatio.13.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.13.4	Gauge	0
iblfQueOutUcastUsedRatio.13.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.13.5	Gauge	0
iblfQueOutUcastUsedRatio.13.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.13.6	Gauge	0
iblfQueOutUcastUsedRatio.13.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.13.7	Gauge	0
iblfQueOutUcastUsedRatio.13.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.13.8	Gauge	0
iblfQueOutUcastUsedRatio.14.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.14.1	Gauge	0
iblfQueOutUcastUsedRatio.14.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.14.2	Gauge	0
iblfQueOutUcastUsedRatio.14.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.14.3	Gauge	0
iblfQueOutUcastUsedRatio.14.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.14.4	Gauge	0
iblfQueOutUcastUsedRatio.14.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.14.5	Gauge	0
iblfQueOutUcastUsedRatio.14.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.14.6	Gauge	0
iblfQueOutUcastUsedRatio.14.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.14.7	Gauge	0
iblfQueOutUcastUsedRatio.14.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.14.8	Gauge	0
iblfQueOutUcastUsedRatio.15.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.15.1	Gauge	0
iblfQueOutUcastUsedRatio.15.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.15.2	Gauge	0
iblfQueOutUcastUsedRatio.15.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.15.3	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsedRatio.15.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.15.4	Gauge	0
iblfQueOutUcastUsedRatio.15.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.15.5	Gauge	0
iblfQueOutUcastUsedRatio.15.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.15.6	Gauge	0
iblfQueOutUcastUsedRatio.15.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.15.7	Gauge	0
iblfQueOutUcastUsedRatio.15.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.15.8	Gauge	0
iblfQueOutUcastUsedRatio.16.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.16.1	Gauge	0
iblfQueOutUcastUsedRatio.16.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.16.2	Gauge	0
iblfQueOutUcastUsedRatio.16.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.16.3	Gauge	0
iblfQueOutUcastUsedRatio.16.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.16.4	Gauge	0
iblfQueOutUcastUsedRatio.16.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.16.5	Gauge	0
iblfQueOutUcastUsedRatio.16.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.16.6	Gauge	0
iblfQueOutUcastUsedRatio.16.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.16.7	Gauge	0
iblfQueOutUcastUsedRatio.16.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.16.8	Gauge	0
iblfQueOutUcastUsedRatio.17.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.17.1	Gauge	0
iblfQueOutUcastUsedRatio.17.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.17.2	Gauge	0
iblfQueOutUcastUsedRatio.17.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.17.3	Gauge	0
iblfQueOutUcastUsedRatio.17.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.17.4	Gauge	0
iblfQueOutUcastUsedRatio.17.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.17.5	Gauge	0
iblfQueOutUcastUsedRatio.17.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.17.6	Gauge	0
iblfQueOutUcastUsedRatio.17.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.17.7	Gauge	0
iblfQueOutUcastUsedRatio.17.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.17.8	Gauge	0
iblfQueOutUcastUsedRatio.18.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.18.1	Gauge	0
iblfQueOutUcastUsedRatio.18.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.18.2	Gauge	0
iblfQueOutUcastUsedRatio.18.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.18.3	Gauge	0
iblfQueOutUcastUsedRatio.18.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.18.4	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsedRatio.18.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.18.5	Gauge	0
iblfQueOutUcastUsedRatio.18.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.18.6	Gauge	0
iblfQueOutUcastUsedRatio.18.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.18.7	Gauge	0
iblfQueOutUcastUsedRatio.18.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.18.8	Gauge	0
iblfQueOutUcastUsedRatio.19.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.19.1	Gauge	0
iblfQueOutUcastUsedRatio.19.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.19.2	Gauge	0
iblfQueOutUcastUsedRatio.19.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.19.3	Gauge	0
iblfQueOutUcastUsedRatio.19.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.19.4	Gauge	0
iblfQueOutUcastUsedRatio.19.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.19.5	Gauge	0
iblfQueOutUcastUsedRatio.19.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.19.6	Gauge	0
iblfQueOutUcastUsedRatio.19.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.19.7	Gauge	0
iblfQueOutUcastUsedRatio.19.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.19.8	Gauge	0
iblfQueOutUcastUsedRatio.20.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.20.1	Gauge	0
iblfQueOutUcastUsedRatio.20.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.20.2	Gauge	0
iblfQueOutUcastUsedRatio.20.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.20.3	Gauge	0
iblfQueOutUcastUsedRatio.20.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.20.4	Gauge	0
iblfQueOutUcastUsedRatio.20.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.20.5	Gauge	0
iblfQueOutUcastUsedRatio.20.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.20.6	Gauge	0
iblfQueOutUcastUsedRatio.20.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.20.7	Gauge	0
iblfQueOutUcastUsedRatio.20.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.20.8	Gauge	0
iblfQueOutUcastUsedRatio.21.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.21.1	Gauge	0
iblfQueOutUcastUsedRatio.21.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.21.2	Gauge	0
iblfQueOutUcastUsedRatio.21.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.21.3	Gauge	0
iblfQueOutUcastUsedRatio.21.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.21.4	Gauge	0
iblfQueOutUcastUsedRatio.21.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.21.5	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsedRatio.21.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.21.6	Gauge	0
iblfQueOutUcastUsedRatio.21.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.21.7	Gauge	0
iblfQueOutUcastUsedRatio.21.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.21.8	Gauge	0
iblfQueOutUcastUsedRatio.22.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.22.1	Gauge	0
iblfQueOutUcastUsedRatio.22.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.22.2	Gauge	0
iblfQueOutUcastUsedRatio.22.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.22.3	Gauge	0
iblfQueOutUcastUsedRatio.22.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.22.4	Gauge	0
iblfQueOutUcastUsedRatio.22.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.22.5	Gauge	0
iblfQueOutUcastUsedRatio.22.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.22.6	Gauge	0
iblfQueOutUcastUsedRatio.22.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.22.7	Gauge	0
iblfQueOutUcastUsedRatio.22.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.22.8	Gauge	0
iblfQueOutUcastUsedRatio.23.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.23.1	Gauge	0
iblfQueOutUcastUsedRatio.23.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.23.2	Gauge	0
iblfQueOutUcastUsedRatio.23.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.23.3	Gauge	0
iblfQueOutUcastUsedRatio.23.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.23.4	Gauge	0
iblfQueOutUcastUsedRatio.23.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.23.5	Gauge	0
iblfQueOutUcastUsedRatio.23.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.23.6	Gauge	0
iblfQueOutUcastUsedRatio.23.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.23.7	Gauge	0
iblfQueOutUcastUsedRatio.23.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.23.8	Gauge	0
iblfQueOutUcastUsedRatio.24.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.24.1	Gauge	0
iblfQueOutUcastUsedRatio.24.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.24.2	Gauge	0
iblfQueOutUcastUsedRatio.24.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.24.3	Gauge	0
iblfQueOutUcastUsedRatio.24.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.24.4	Gauge	0
iblfQueOutUcastUsedRatio.24.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.24.5	Gauge	0
iblfQueOutUcastUsedRatio.24.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.24.6	Gauge	0



Name	OID	Value Type	Value Example
iblfQueOutUcastUsedRatio.24.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.24.7	Gauge	0
iblfQueOutUcastUsedRatio.24.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.24.8	Gauge	0
iblfQueOutUcastUsedRatio.25.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.25.1	Gauge	0
iblfQueOutUcastUsedRatio.25.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.25.2	Gauge	0
iblfQueOutUcastUsedRatio.25.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.25.3	Gauge	0
iblfQueOutUcastUsedRatio.25.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.25.4	Gauge	0
iblfQueOutUcastUsedRatio.25.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.25.5	Gauge	0
iblfQueOutUcastUsedRatio.25.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.25.6	Gauge	0
iblfQueOutUcastUsedRatio.25.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.25.7	Gauge	0
iblfQueOutUcastUsedRatio.25.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.25.8	Gauge	0
iblfQueOutUcastUsedRatio.26.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.26.1	Gauge	0
iblfQueOutUcastUsedRatio.26.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.26.2	Gauge	0
iblfQueOutUcastUsedRatio.26.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.26.3	Gauge	0
iblfQueOutUcastUsedRatio.26.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.26.4	Gauge	0
iblfQueOutUcastUsedRatio.26.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.26.5	Gauge	0
iblfQueOutUcastUsedRatio.26.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.26.6	Gauge	0
iblfQueOutUcastUsedRatio.26.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.26.7	Gauge	0
iblfQueOutUcastUsedRatio.26.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.26.8	Gauge	0
iblfQueOutUcastUsedRatio.27.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.27.1	Gauge	0
iblfQueOutUcastUsedRatio.27.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.27.2	Gauge	0
iblfQueOutUcastUsedRatio.27.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.27.3	Gauge	0
iblfQueOutUcastUsedRatio.27.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.27.4	Gauge	0
iblfQueOutUcastUsedRatio.27.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.27.5	Gauge	0
iblfQueOutUcastUsedRatio.27.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.27.6	Gauge	0
iblfQueOutUcastUsedRatio.27.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.27.7	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsedRatio.27.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.27.8	Gauge	0
iblfQueOutUcastUsedRatio.28.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.28.1	Gauge	0
iblfQueOutUcastUsedRatio.28.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.28.2	Gauge	0
iblfQueOutUcastUsedRatio.28.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.28.3	Gauge	0
iblfQueOutUcastUsedRatio.28.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.28.4	Gauge	0
iblfQueOutUcastUsedRatio.28.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.28.5	Gauge	0
iblfQueOutUcastUsedRatio.28.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.28.6	Gauge	0
iblfQueOutUcastUsedRatio.28.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.28.7	Gauge	0
iblfQueOutUcastUsedRatio.28.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.28.8	Gauge	0
iblfQueOutUcastUsedRatio.29.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.29.1	Gauge	0
iblfQueOutUcastUsedRatio.29.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.29.2	Gauge	0
iblfQueOutUcastUsedRatio.29.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.29.3	Gauge	0
iblfQueOutUcastUsedRatio.29.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.29.4	Gauge	0
iblfQueOutUcastUsedRatio.29.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.29.5	Gauge	0
iblfQueOutUcastUsedRatio.29.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.29.6	Gauge	0
iblfQueOutUcastUsedRatio.29.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.29.7	Gauge	0
iblfQueOutUcastUsedRatio.29.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.29.8	Gauge	0
iblfQueOutUcastUsedRatio.30.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.30.1	Gauge	0
iblfQueOutUcastUsedRatio.30.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.30.2	Gauge	0
iblfQueOutUcastUsedRatio.30.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.30.3	Gauge	0
iblfQueOutUcastUsedRatio.30.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.30.4	Gauge	0
iblfQueOutUcastUsedRatio.30.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.30.5	Gauge	0
iblfQueOutUcastUsedRatio.30.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.30.6	Gauge	0
iblfQueOutUcastUsedRatio.30.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.30.7	Gauge	0
iblfQueOutUcastUsedRatio.30.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.30.8	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsedRatio.31.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.31.1	Gauge	0
iblfQueOutUcastUsedRatio.31.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.31.2	Gauge	0
iblfQueOutUcastUsedRatio.31.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.31.3	Gauge	0
iblfQueOutUcastUsedRatio.31.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.31.4	Gauge	0
iblfQueOutUcastUsedRatio.31.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.31.5	Gauge	0
iblfQueOutUcastUsedRatio.31.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.31.6	Gauge	0
iblfQueOutUcastUsedRatio.31.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.31.7	Gauge	0
iblfQueOutUcastUsedRatio.31.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.31.8	Gauge	0
iblfQueOutUcastUsedRatio.32.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.32.1	Gauge	0
iblfQueOutUcastUsedRatio.32.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.32.2	Gauge	0
iblfQueOutUcastUsedRatio.32.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.32.3	Gauge	0
iblfQueOutUcastUsedRatio.32.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.32.4	Gauge	0
iblfQueOutUcastUsedRatio.32.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.32.5	Gauge	0
iblfQueOutUcastUsedRatio.32.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.32.6	Gauge	0
iblfQueOutUcastUsedRatio.32.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.32.7	Gauge	0
iblfQueOutUcastUsedRatio.32.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.32.8	Gauge	0
iblfQueOutUcastUsedRatio.33.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.33.1	Gauge	0
iblfQueOutUcastUsedRatio.33.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.33.2	Gauge	0
iblfQueOutUcastUsedRatio.33.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.33.3	Gauge	0
iblfQueOutUcastUsedRatio.33.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.33.4	Gauge	0
iblfQueOutUcastUsedRatio.33.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.33.5	Gauge	0
iblfQueOutUcastUsedRatio.33.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.33.6	Gauge	0
iblfQueOutUcastUsedRatio.33.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.33.7	Gauge	0
iblfQueOutUcastUsedRatio.33.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.33.8	Gauge	0
iblfQueOutUcastUsedRatio.34.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.34.1	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsedRatio.34.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.34.2	Gauge	0
iblfQueOutUcastUsedRatio.34.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.34.3	Gauge	0
iblfQueOutUcastUsedRatio.34.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.34.4	Gauge	0
iblfQueOutUcastUsedRatio.34.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.34.5	Gauge	0
iblfQueOutUcastUsedRatio.34.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.34.6	Gauge	0
iblfQueOutUcastUsedRatio.34.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.34.7	Gauge	0
iblfQueOutUcastUsedRatio.34.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.34.8	Gauge	0
iblfQueOutUcastUsedRatio.35.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.35.1	Gauge	0
iblfQueOutUcastUsedRatio.35.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.35.2	Gauge	0
iblfQueOutUcastUsedRatio.35.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.35.3	Gauge	0
iblfQueOutUcastUsedRatio.35.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.35.4	Gauge	0
iblfQueOutUcastUsedRatio.35.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.35.5	Gauge	0
iblfQueOutUcastUsedRatio.35.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.35.6	Gauge	0
iblfQueOutUcastUsedRatio.35.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.35.7	Gauge	0
iblfQueOutUcastUsedRatio.35.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.35.8	Gauge	0
iblfQueOutUcastUsedRatio.36.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.36.1	Gauge	0
iblfQueOutUcastUsedRatio.36.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.36.2	Gauge	0
iblfQueOutUcastUsedRatio.36.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.36.3	Gauge	0
iblfQueOutUcastUsedRatio.36.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.36.4	Gauge	0
iblfQueOutUcastUsedRatio.36.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.36.5	Gauge	0
iblfQueOutUcastUsedRatio.36.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.36.6	Gauge	0
iblfQueOutUcastUsedRatio.36.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.36.7	Gauge	0
iblfQueOutUcastUsedRatio.36.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.36.8	Gauge	0
iblfQueOutUcastUsedRatio.37.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.37.1	Gauge	0
iblfQueOutUcastUsedRatio.37.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.37.2	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsedRatio.37.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.37.3	Gauge	0
iblfQueOutUcastUsedRatio.37.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.37.4	Gauge	0
iblfQueOutUcastUsedRatio.37.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.37.5	Gauge	0
iblfQueOutUcastUsedRatio.37.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.37.6	Gauge	0
iblfQueOutUcastUsedRatio.37.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.37.7	Gauge	0
iblfQueOutUcastUsedRatio.37.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.37.8	Gauge	0
iblfQueOutUcastUsedRatio.38.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.38.1	Gauge	0
iblfQueOutUcastUsedRatio.38.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.38.2	Gauge	0
iblfQueOutUcastUsedRatio.38.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.38.3	Gauge	0
iblfQueOutUcastUsedRatio.38.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.38.4	Gauge	0
iblfQueOutUcastUsedRatio.38.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.38.5	Gauge	0
iblfQueOutUcastUsedRatio.38.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.38.6	Gauge	0
iblfQueOutUcastUsedRatio.38.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.38.7	Gauge	0
iblfQueOutUcastUsedRatio.38.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.38.8	Gauge	0
iblfQueOutUcastUsedRatio.39.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.39.1	Gauge	0
iblfQueOutUcastUsedRatio.39.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.39.2	Gauge	0
iblfQueOutUcastUsedRatio.39.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.39.3	Gauge	0
iblfQueOutUcastUsedRatio.39.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.39.4	Gauge	0
iblfQueOutUcastUsedRatio.39.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.39.5	Gauge	0
iblfQueOutUcastUsedRatio.39.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.39.6	Gauge	0
iblfQueOutUcastUsedRatio.39.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.39.7	Gauge	0
iblfQueOutUcastUsedRatio.39.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.39.8	Gauge	0
iblfQueOutUcastUsedRatio.40.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.40.1	Gauge	0
iblfQueOutUcastUsedRatio.40.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.40.2	Gauge	0
iblfQueOutUcastUsedRatio.40.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.40.3	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsedRatio.40.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.40.4	Gauge	0
iblfQueOutUcastUsedRatio.40.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.40.5	Gauge	0
iblfQueOutUcastUsedRatio.40.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.40.6	Gauge	0
iblfQueOutUcastUsedRatio.40.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.40.7	Gauge	0
iblfQueOutUcastUsedRatio.40.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.40.8	Gauge	0
iblfQueOutUcastUsedRatio.41.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.41.1	Gauge	0
iblfQueOutUcastUsedRatio.41.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.41.2	Gauge	0
iblfQueOutUcastUsedRatio.41.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.41.3	Gauge	0
iblfQueOutUcastUsedRatio.41.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.41.4	Gauge	0
iblfQueOutUcastUsedRatio.41.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.41.5	Gauge	0
iblfQueOutUcastUsedRatio.41.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.41.6	Gauge	0
iblfQueOutUcastUsedRatio.41.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.41.7	Gauge	0
iblfQueOutUcastUsedRatio.41.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.41.8	Gauge	0
iblfQueOutUcastUsedRatio.42.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.42.1	Gauge	0
iblfQueOutUcastUsedRatio.42.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.42.2	Gauge	0
iblfQueOutUcastUsedRatio.42.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.42.3	Gauge	0
iblfQueOutUcastUsedRatio.42.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.42.4	Gauge	0
iblfQueOutUcastUsedRatio.42.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.42.5	Gauge	0
iblfQueOutUcastUsedRatio.42.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.42.6	Gauge	0
iblfQueOutUcastUsedRatio.42.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.42.7	Gauge	0
iblfQueOutUcastUsedRatio.42.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.42.8	Gauge	0
iblfQueOutUcastUsedRatio.43.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.43.1	Gauge	0
iblfQueOutUcastUsedRatio.43.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.43.2	Gauge	0
iblfQueOutUcastUsedRatio.43.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.43.3	Gauge	0
iblfQueOutUcastUsedRatio.43.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.43.4	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsedRatio.43.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.43.5	Gauge	0
iblfQueOutUcastUsedRatio.43.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.43.6	Gauge	0
iblfQueOutUcastUsedRatio.43.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.43.7	Gauge	0
iblfQueOutUcastUsedRatio.43.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.43.8	Gauge	0
iblfQueOutUcastUsedRatio.44.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.44.1	Gauge	0
iblfQueOutUcastUsedRatio.44.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.44.2	Gauge	0
iblfQueOutUcastUsedRatio.44.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.44.3	Gauge	0
iblfQueOutUcastUsedRatio.44.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.44.4	Gauge	0
iblfQueOutUcastUsedRatio.44.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.44.5	Gauge	0
iblfQueOutUcastUsedRatio.44.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.44.6	Gauge	0
iblfQueOutUcastUsedRatio.44.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.44.7	Gauge	0
iblfQueOutUcastUsedRatio.44.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.44.8	Gauge	0
iblfQueOutUcastUsedRatio.45.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.45.1	Gauge	0
iblfQueOutUcastUsedRatio.45.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.45.2	Gauge	0
iblfQueOutUcastUsedRatio.45.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.45.3	Gauge	0
iblfQueOutUcastUsedRatio.45.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.45.4	Gauge	0
iblfQueOutUcastUsedRatio.45.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.45.5	Gauge	0
iblfQueOutUcastUsedRatio.45.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.45.6	Gauge	0
iblfQueOutUcastUsedRatio.45.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.45.7	Gauge	0
iblfQueOutUcastUsedRatio.45.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.45.8	Gauge	0
iblfQueOutUcastUsedRatio.46.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.46.1	Gauge	0
iblfQueOutUcastUsedRatio.46.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.46.2	Gauge	0
iblfQueOutUcastUsedRatio.46.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.46.3	Gauge	0
iblfQueOutUcastUsedRatio.46.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.46.4	Gauge	0
iblfQueOutUcastUsedRatio.46.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.46.5	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsedRatio.46.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.46.6	Gauge	0
iblfQueOutUcastUsedRatio.46.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.46.7	Gauge	0
iblfQueOutUcastUsedRatio.46.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.46.8	Gauge	0
iblfQueOutUcastUsedRatio.47.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.47.1	Gauge	0
iblfQueOutUcastUsedRatio.47.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.47.2	Gauge	0
iblfQueOutUcastUsedRatio.47.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.47.3	Gauge	0
iblfQueOutUcastUsedRatio.47.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.47.4	Gauge	0
iblfQueOutUcastUsedRatio.47.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.47.5	Gauge	0
iblfQueOutUcastUsedRatio.47.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.47.6	Gauge	0
iblfQueOutUcastUsedRatio.47.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.47.7	Gauge	0
iblfQueOutUcastUsedRatio.47.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.47.8	Gauge	0
iblfQueOutUcastUsedRatio.48.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.48.1	Gauge	0
iblfQueOutUcastUsedRatio.48.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.48.2	Gauge	0
iblfQueOutUcastUsedRatio.48.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.48.3	Gauge	0
iblfQueOutUcastUsedRatio.48.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.48.4	Gauge	0
iblfQueOutUcastUsedRatio.48.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.48.5	Gauge	0
iblfQueOutUcastUsedRatio.48.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.48.6	Gauge	0
iblfQueOutUcastUsedRatio.48.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.48.7	Gauge	0
iblfQueOutUcastUsedRatio.48.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.48.8	Gauge	0
iblfQueOutUcastUsedRatio.49.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.49.1	Gauge	0
iblfQueOutUcastUsedRatio.49.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.49.2	Gauge	0
iblfQueOutUcastUsedRatio.49.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.49.3	Gauge	0
iblfQueOutUcastUsedRatio.49.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.49.4	Gauge	0
iblfQueOutUcastUsedRatio.49.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.49.5	Gauge	0
iblfQueOutUcastUsedRatio.49.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.49.6	Gauge	0



Name	OID	Value Type	Value Example
iblfQueOutUcastUsedRatio.49.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.49.7	Gauge	0
iblfQueOutUcastUsedRatio.49.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.49.8	Gauge	0
iblfQueOutUcastUsedRatio.50.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.50.1	Gauge	0
iblfQueOutUcastUsedRatio.50.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.50.2	Gauge	0
iblfQueOutUcastUsedRatio.50.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.50.3	Gauge	0
iblfQueOutUcastUsedRatio.50.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.50.4	Gauge	0
iblfQueOutUcastUsedRatio.50.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.50.5	Gauge	0
iblfQueOutUcastUsedRatio.50.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.50.6	Gauge	0
iblfQueOutUcastUsedRatio.50.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.50.7	Gauge	0
iblfQueOutUcastUsedRatio.50.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.50.8	Gauge	0
iblfQueOutUcastUsedRatio.51.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.51.1	Gauge	0
iblfQueOutUcastUsedRatio.51.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.51.2	Gauge	0
iblfQueOutUcastUsedRatio.51.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.51.3	Gauge	0
iblfQueOutUcastUsedRatio.51.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.51.4	Gauge	0
iblfQueOutUcastUsedRatio.51.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.51.5	Gauge	0
iblfQueOutUcastUsedRatio.51.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.51.6	Gauge	0
iblfQueOutUcastUsedRatio.51.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.51.7	Gauge	0
iblfQueOutUcastUsedRatio.51.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.51.8	Gauge	0
iblfQueOutUcastUsedRatio.52.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.52.1	Gauge	0
iblfQueOutUcastUsedRatio.52.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.52.2	Gauge	0
iblfQueOutUcastUsedRatio.52.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.52.3	Gauge	0
iblfQueOutUcastUsedRatio.52.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.52.4	Gauge	0
iblfQueOutUcastUsedRatio.52.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.52.5	Gauge	0
iblfQueOutUcastUsedRatio.52.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.52.6	Gauge	0
iblfQueOutUcastUsedRatio.52.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.4.52.7	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsedRatio.52.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.52.8	Gauge	0
iblfQueOutUcastUsedRatio.53.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.53.1	Gauge	0
iblfQueOutUcastUsedRatio.53.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.53.2	Gauge	0
iblfQueOutUcastUsedRatio.53.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.53.3	Gauge	0
iblfQueOutUcastUsedRatio.53.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.53.4	Gauge	0
iblfQueOutUcastUsedRatio.53.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.53.5	Gauge	0
iblfQueOutUcastUsedRatio.53.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.53.6	Gauge	0
iblfQueOutUcastUsedRatio.53.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.53.7	Gauge	0
iblfQueOutUcastUsedRatio.53.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.53.8	Gauge	0
iblfQueOutUcastUsedRatio.54.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.54.1	Gauge	0
iblfQueOutUcastUsedRatio.54.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.54.2	Gauge	0
iblfQueOutUcastUsedRatio.54.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.54.3	Gauge	0
iblfQueOutUcastUsedRatio.54.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.54.4	Gauge	0
iblfQueOutUcastUsedRatio.54.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.54.5	Gauge	0
iblfQueOutUcastUsedRatio.54.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.54.6	Gauge	0
iblfQueOutUcastUsedRatio.54.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.54.7	Gauge	0
iblfQueOutUcastUsedRatio.54.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.4.54.8	Gauge	0
iblfQueOutUcastUsedPeak.1.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.1.1	Gauge	0
iblfQueOutUcastUsedPeak.1.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.1.2	Gauge	0
iblfQueOutUcastUsedPeak.1.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.1.3	Gauge	0
iblfQueOutUcastUsedPeak.1.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.1.4	Gauge	0
iblfQueOutUcastUsedPeak.1.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.1.5	Gauge	0
iblfQueOutUcastUsedPeak.1.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.1.6	Gauge	0
iblfQueOutUcastUsedPeak.1.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.1.7	Gauge	0
iblfQueOutUcastUsedPeak.1.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.1.8	Gauge	0
iblfQueOutUcastUsedPeak.2.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.2.1	Gauge	0
iblfQueOutUcastUsedPeak.2.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.2.2	Gauge	0
iblfQueOutUcastUsedPeak.2.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.2.3	Gauge	0
iblfQueOutUcastUsedPeak.2.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.2.4	Gauge	0
iblfQueOutUcastUsedPeak.2.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.2.5	Gauge	0
iblfQueOutUcastUsedPeak.2.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.2.6	Gauge	0



Name	OID	Value Type	Value Example
iblfQueOutUcastUsedPeak.8.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.8.2	Gauge	0
iblfQueOutUcastUsedPeak.8.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.8.3	Gauge	0
iblfQueOutUcastUsedPeak.8.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.8.4	Gauge	0
iblfQueOutUcastUsedPeak.8.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.8.5	Gauge	0
iblfQueOutUcastUsedPeak.8.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.8.6	Gauge	0
iblfQueOutUcastUsedPeak.8.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.8.7	Gauge	0
iblfQueOutUcastUsedPeak.8.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.8.8	Gauge	0
iblfQueOutUcastUsedPeak.9.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.9.1	Gauge	0
iblfQueOutUcastUsedPeak.9.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.9.2	Gauge	0
iblfQueOutUcastUsedPeak.9.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.9.3	Gauge	0
iblfQueOutUcastUsedPeak.9.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.9.4	Gauge	0
iblfQueOutUcastUsedPeak.9.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.9.5	Gauge	0
iblfQueOutUcastUsedPeak.9.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.9.6	Gauge	0
iblfQueOutUcastUsedPeak.9.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.9.7	Gauge	0
iblfQueOutUcastUsedPeak.9.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.9.8	Gauge	0
iblfQueOutUcastUsed-Peak.10.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.10.1	Gauge	0
iblfQueOutUcastUsed-Peak.10.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.10.2	Gauge	0
iblfQueOutUcastUsed-Peak.10.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.10.3	Gauge	0
iblfQueOutUcastUsed-Peak.10.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.10.4	Gauge	0
iblfQueOutUcastUsed-Peak.10.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.10.5	Gauge	0
iblfQueOutUcastUsed-Peak.10.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.10.6	Gauge	0
iblfQueOutUcastUsed-Peak.10.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.10.7	Gauge	0
iblfQueOutUcastUsed-Peak.10.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.10.8	Gauge	0
iblfQueOutUcastUsed-Peak.11.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.11.1	Gauge	0
iblfQueOutUcastUsed-Peak.11.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.11.2	Gauge	0
iblfQueOutUcastUsed-Peak.11.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.11.3	Gauge	0
iblfQueOutUcastUsed-Peak.11.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.11.4	Gauge	0
iblfQueOutUcastUsed-Peak.11.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.11.5	Gauge	0
iblfQueOutUcastUsed-Peak.11.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.11.6	Gauge	0
iblfQueOutUcastUsed-Peak.11.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.11.7	Gauge	0
iblfQueOutUcastUsed-Peak.11.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.11.8	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsed-Peak.12.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.12.1	Gauge	0
iblfQueOutUcastUsed-Peak.12.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.12.2	Gauge	0
iblfQueOutUcastUsed-Peak.12.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.12.3	Gauge	0
iblfQueOutUcastUsed-Peak.12.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.12.4	Gauge	0
iblfQueOutUcastUsed-Peak.12.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.12.5	Gauge	0
iblfQueOutUcastUsed-Peak.12.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.12.6	Gauge	0
iblfQueOutUcastUsed-Peak.12.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.12.7	Gauge	0
iblfQueOutUcastUsed-Peak.12.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.12.8	Gauge	0
iblfQueOutUcastUsed-Peak.13.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.13.1	Gauge	0
iblfQueOutUcastUsed-Peak.13.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.13.2	Gauge	0
iblfQueOutUcastUsed-Peak.13.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.13.3	Gauge	0
iblfQueOutUcastUsed-Peak.13.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.13.4	Gauge	0
iblfQueOutUcastUsed-Peak.13.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.13.5	Gauge	0
iblfQueOutUcastUsed-Peak.13.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.13.6	Gauge	0
iblfQueOutUcastUsed-Peak.13.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.13.7	Gauge	0
iblfQueOutUcastUsed-Peak.13.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.13.8	Gauge	0
iblfQueOutUcastUsed-Peak.14.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.14.1	Gauge	0
iblfQueOutUcastUsed-Peak.14.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.14.2	Gauge	0
iblfQueOutUcastUsed-Peak.14.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.14.3	Gauge	0
iblfQueOutUcastUsed-Peak.14.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.14.4	Gauge	0
iblfQueOutUcastUsed-Peak.14.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.14.5	Gauge	0
iblfQueOutUcastUsed-Peak.14.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.14.6	Gauge	0
iblfQueOutUcastUsed-Peak.14.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.14.7	Gauge	0
iblfQueOutUcastUsed-Peak.14.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.14.8	Gauge	0
iblfQueOutUcastUsed-Peak.15.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.15.1	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsed-Peak.15.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.15.2	Gauge	0
iblfQueOutUcastUsed-Peak.15.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.15.3	Gauge	0
iblfQueOutUcastUsed-Peak.15.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.15.4	Gauge	0
iblfQueOutUcastUsed-Peak.15.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.15.5	Gauge	0
iblfQueOutUcastUsed-Peak.15.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.15.6	Gauge	0
iblfQueOutUcastUsed-Peak.15.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.15.7	Gauge	0
iblfQueOutUcastUsed-Peak.15.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.15.8	Gauge	0
iblfQueOutUcastUsed-Peak.16.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.16.1	Gauge	0
iblfQueOutUcastUsed-Peak.16.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.16.2	Gauge	0
iblfQueOutUcastUsed-Peak.16.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.16.3	Gauge	0
iblfQueOutUcastUsed-Peak.16.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.16.4	Gauge	0
iblfQueOutUcastUsed-Peak.16.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.16.5	Gauge	0
iblfQueOutUcastUsed-Peak.16.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.16.6	Gauge	0
iblfQueOutUcastUsed-Peak.16.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.16.7	Gauge	0
iblfQueOutUcastUsed-Peak.16.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.16.8	Gauge	0
iblfQueOutUcastUsed-Peak.17.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.17.1	Gauge	0
iblfQueOutUcastUsed-Peak.17.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.17.2	Gauge	0
iblfQueOutUcastUsed-Peak.17.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.17.3	Gauge	0
iblfQueOutUcastUsed-Peak.17.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.17.4	Gauge	0
iblfQueOutUcastUsed-Peak.17.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.17.5	Gauge	0
iblfQueOutUcastUsed-Peak.17.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.17.6	Gauge	0
iblfQueOutUcastUsed-Peak.17.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.17.7	Gauge	0
iblfQueOutUcastUsed-Peak.17.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.17.8	Gauge	0
iblfQueOutUcastUsed-Peak.18.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.18.1	Gauge	0
iblfQueOutUcastUsed-Peak.18.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.18.2	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsed-Peak.18.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.18.3	Gauge	0
iblfQueOutUcastUsed-Peak.18.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.18.4	Gauge	0
iblfQueOutUcastUsed-Peak.18.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.18.5	Gauge	0
iblfQueOutUcastUsed-Peak.18.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.18.6	Gauge	0
iblfQueOutUcastUsed-Peak.18.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.18.7	Gauge	0
iblfQueOutUcastUsed-Peak.18.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.18.8	Gauge	0
iblfQueOutUcastUsed-Peak.19.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.19.1	Gauge	0
iblfQueOutUcastUsed-Peak.19.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.19.2	Gauge	0
iblfQueOutUcastUsed-Peak.19.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.19.3	Gauge	0
iblfQueOutUcastUsed-Peak.19.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.19.4	Gauge	0
iblfQueOutUcastUsed-Peak.19.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.19.5	Gauge	0
iblfQueOutUcastUsed-Peak.19.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.19.6	Gauge	0
iblfQueOutUcastUsed-Peak.19.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.19.7	Gauge	0
iblfQueOutUcastUsed-Peak.19.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.19.8	Gauge	0
iblfQueOutUcastUsed-Peak.20.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.20.1	Gauge	0
iblfQueOutUcastUsed-Peak.20.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.20.2	Gauge	0
iblfQueOutUcastUsed-Peak.20.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.20.3	Gauge	0
iblfQueOutUcastUsed-Peak.20.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.20.4	Gauge	0
iblfQueOutUcastUsed-Peak.20.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.20.5	Gauge	0
iblfQueOutUcastUsed-Peak.20.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.20.6	Gauge	0
iblfQueOutUcastUsed-Peak.20.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.20.7	Gauge	0
iblfQueOutUcastUsed-Peak.20.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.20.8	Gauge	0
iblfQueOutUcastUsed-Peak.21.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.21.1	Gauge	0
iblfQueOutUcastUsed-Peak.21.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.21.2	Gauge	0
iblfQueOutUcastUsed-Peak.21.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.21.3	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsed-Peak.21.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.21.4	Gauge	0
iblfQueOutUcastUsed-Peak.21.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.21.5	Gauge	0
iblfQueOutUcastUsed-Peak.21.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.21.6	Gauge	0
iblfQueOutUcastUsed-Peak.21.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.21.7	Gauge	0
iblfQueOutUcastUsed-Peak.21.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.21.8	Gauge	0
iblfQueOutUcastUsed-Peak.22.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.22.1	Gauge	0
iblfQueOutUcastUsed-Peak.22.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.22.2	Gauge	0
iblfQueOutUcastUsed-Peak.22.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.22.3	Gauge	0
iblfQueOutUcastUsed-Peak.22.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.22.4	Gauge	0
iblfQueOutUcastUsed-Peak.22.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.22.5	Gauge	0
iblfQueOutUcastUsed-Peak.22.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.22.6	Gauge	0
iblfQueOutUcastUsed-Peak.22.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.22.7	Gauge	0
iblfQueOutUcastUsed-Peak.22.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.22.8	Gauge	0
iblfQueOutUcastUsed-Peak.23.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.23.1	Gauge	0
iblfQueOutUcastUsed-Peak.23.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.23.2	Gauge	0
iblfQueOutUcastUsed-Peak.23.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.23.3	Gauge	0
iblfQueOutUcastUsed-Peak.23.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.23.4	Gauge	0
iblfQueOutUcastUsed-Peak.23.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.23.5	Gauge	0
iblfQueOutUcastUsed-Peak.23.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.23.6	Gauge	0
iblfQueOutUcastUsed-Peak.23.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.23.7	Gauge	0
iblfQueOutUcastUsed-Peak.23.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.23.8	Gauge	0
iblfQueOutUcastUsed-Peak.24.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.24.1	Gauge	0
iblfQueOutUcastUsed-Peak.24.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.24.2	Gauge	0
iblfQueOutUcastUsed-Peak.24.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.24.3	Gauge	0
iblfQueOutUcastUsed-Peak.24.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.24.4	Gauge	0



Name	OID	Value Type	Value Example
iblfQueOutUcastUsed-Peak.24.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.24.5	Gauge	0
iblfQueOutUcastUsed-Peak.24.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.24.6	Gauge	0
iblfQueOutUcastUsed-Peak.24.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.24.7	Gauge	0
iblfQueOutUcastUsed-Peak.24.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.24.8	Gauge	0
iblfQueOutUcastUsed-Peak.25.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.25.1	Gauge	0
iblfQueOutUcastUsed-Peak.25.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.25.2	Gauge	0
iblfQueOutUcastUsed-Peak.25.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.25.3	Gauge	0
iblfQueOutUcastUsed-Peak.25.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.25.4	Gauge	0
iblfQueOutUcastUsed-Peak.25.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.25.5	Gauge	0
iblfQueOutUcastUsed-Peak.25.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.25.6	Gauge	0
iblfQueOutUcastUsed-Peak.25.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.25.7	Gauge	0
iblfQueOutUcastUsed-Peak.25.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.25.8	Gauge	0
iblfQueOutUcastUsed-Peak.26.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.26.1	Gauge	0
iblfQueOutUcastUsed-Peak.26.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.26.2	Gauge	0
iblfQueOutUcastUsed-Peak.26.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.26.3	Gauge	0
iblfQueOutUcastUsed-Peak.26.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.26.4	Gauge	0
iblfQueOutUcastUsed-Peak.26.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.26.5	Gauge	0
iblfQueOutUcastUsed-Peak.26.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.26.6	Gauge	0
iblfQueOutUcastUsed-Peak.26.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.26.7	Gauge	0
iblfQueOutUcastUsed-Peak.26.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.26.8	Gauge	0
iblfQueOutUcastUsed-Peak.27.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.27.1	Gauge	0
iblfQueOutUcastUsed-Peak.27.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.27.2	Gauge	0
iblfQueOutUcastUsed-Peak.27.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.27.3	Gauge	0
iblfQueOutUcastUsed-Peak.27.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.27.4	Gauge	0
iblfQueOutUcastUsed-Peak.27.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.27.5	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsed-Peak.27.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.27.6	Gauge	0
iblfQueOutUcastUsed-Peak.27.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.27.7	Gauge	0
iblfQueOutUcastUsed-Peak.27.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.27.8	Gauge	0
iblfQueOutUcastUsed-Peak.28.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.28.1	Gauge	0
iblfQueOutUcastUsed-Peak.28.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.28.2	Gauge	0
iblfQueOutUcastUsed-Peak.28.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.28.3	Gauge	0
iblfQueOutUcastUsed-Peak.28.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.28.4	Gauge	0
iblfQueOutUcastUsed-Peak.28.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.28.5	Gauge	0
iblfQueOutUcastUsed-Peak.28.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.28.6	Gauge	0
iblfQueOutUcastUsed-Peak.28.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.28.7	Gauge	0
iblfQueOutUcastUsed-Peak.28.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.28.8	Gauge	0
iblfQueOutUcastUsed-Peak.29.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.29.1	Gauge	0
iblfQueOutUcastUsed-Peak.29.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.29.2	Gauge	0
iblfQueOutUcastUsed-Peak.29.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.29.3	Gauge	0
iblfQueOutUcastUsed-Peak.29.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.29.4	Gauge	0
iblfQueOutUcastUsed-Peak.29.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.29.5	Gauge	0
iblfQueOutUcastUsed-Peak.29.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.29.6	Gauge	0
iblfQueOutUcastUsed-Peak.29.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.29.7	Gauge	0
iblfQueOutUcastUsed-Peak.29.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.29.8	Gauge	0
iblfQueOutUcastUsed-Peak.30.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.30.1	Gauge	0
iblfQueOutUcastUsed-Peak.30.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.30.2	Gauge	0
iblfQueOutUcastUsed-Peak.30.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.30.3	Gauge	0
iblfQueOutUcastUsed-Peak.30.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.30.4	Gauge	0
iblfQueOutUcastUsed-Peak.30.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.30.5	Gauge	0
iblfQueOutUcastUsed-Peak.30.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.30.6	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsed-Peak.30.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.30.7	Gauge	0
iblfQueOutUcastUsed-Peak.30.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.30.8	Gauge	0
iblfQueOutUcastUsed-Peak.31.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.31.1	Gauge	0
iblfQueOutUcastUsed-Peak.31.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.31.2	Gauge	0
iblfQueOutUcastUsed-Peak.31.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.31.3	Gauge	0
iblfQueOutUcastUsed-Peak.31.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.31.4	Gauge	0
iblfQueOutUcastUsed-Peak.31.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.31.5	Gauge	0
iblfQueOutUcastUsed-Peak.31.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.31.6	Gauge	0
iblfQueOutUcastUsed-Peak.31.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.31.7	Gauge	0
iblfQueOutUcastUsed-Peak.31.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.31.8	Gauge	0
iblfQueOutUcastUsed-Peak.32.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.32.1	Gauge	0
iblfQueOutUcastUsed-Peak.32.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.32.2	Gauge	0
iblfQueOutUcastUsed-Peak.32.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.32.3	Gauge	0
iblfQueOutUcastUsed-Peak.32.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.32.4	Gauge	0
iblfQueOutUcastUsed-Peak.32.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.32.5	Gauge	0
iblfQueOutUcastUsed-Peak.32.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.32.6	Gauge	0
iblfQueOutUcastUsed-Peak.32.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.32.7	Gauge	0
iblfQueOutUcastUsed-Peak.32.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.32.8	Gauge	0
iblfQueOutUcastUsed-Peak.33.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.33.1	Gauge	0
iblfQueOutUcastUsed-Peak.33.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.33.2	Gauge	0
iblfQueOutUcastUsed-Peak.33.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.33.3	Gauge	0
iblfQueOutUcastUsed-Peak.33.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.33.4	Gauge	0
iblfQueOutUcastUsed-Peak.33.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.33.5	Gauge	0
iblfQueOutUcastUsed-Peak.33.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.33.6	Gauge	0
iblfQueOutUcastUsed-Peak.33.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.33.7	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsed-Peak.33.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.33.8	Gauge	0
iblfQueOutUcastUsed-Peak.34.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.34.1	Gauge	0
iblfQueOutUcastUsed-Peak.34.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.34.2	Gauge	0
iblfQueOutUcastUsed-Peak.34.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.34.3	Gauge	0
iblfQueOutUcastUsed-Peak.34.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.34.4	Gauge	0
iblfQueOutUcastUsed-Peak.34.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.34.5	Gauge	0
iblfQueOutUcastUsed-Peak.34.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.34.6	Gauge	0
iblfQueOutUcastUsed-Peak.34.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.34.7	Gauge	0
iblfQueOutUcastUsed-Peak.34.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.34.8	Gauge	0
iblfQueOutUcastUsed-Peak.35.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.35.1	Gauge	0
iblfQueOutUcastUsed-Peak.35.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.35.2	Gauge	0
iblfQueOutUcastUsed-Peak.35.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.35.3	Gauge	0
iblfQueOutUcastUsed-Peak.35.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.35.4	Gauge	0
iblfQueOutUcastUsed-Peak.35.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.35.5	Gauge	0
iblfQueOutUcastUsed-Peak.35.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.35.6	Gauge	0
iblfQueOutUcastUsed-Peak.35.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.35.7	Gauge	0
iblfQueOutUcastUsed-Peak.35.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.35.8	Gauge	0
iblfQueOutUcastUsed-Peak.36.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.36.1	Gauge	0
iblfQueOutUcastUsed-Peak.36.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.36.2	Gauge	0
iblfQueOutUcastUsed-Peak.36.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.36.3	Gauge	0
iblfQueOutUcastUsed-Peak.36.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.36.4	Gauge	0
iblfQueOutUcastUsed-Peak.36.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.36.5	Gauge	0
iblfQueOutUcastUsed-Peak.36.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.36.6	Gauge	0
iblfQueOutUcastUsed-Peak.36.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.36.7	Gauge	0
iblfQueOutUcastUsed-Peak.36.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.36.8	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsed-Peak.37.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.37.1	Gauge	0
iblfQueOutUcastUsed-Peak.37.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.37.2	Gauge	0
iblfQueOutUcastUsed-Peak.37.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.37.3	Gauge	0
iblfQueOutUcastUsed-Peak.37.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.37.4	Gauge	0
iblfQueOutUcastUsed-Peak.37.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.37.5	Gauge	0
iblfQueOutUcastUsed-Peak.37.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.37.6	Gauge	0
iblfQueOutUcastUsed-Peak.37.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.37.7	Gauge	0
iblfQueOutUcastUsed-Peak.37.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.37.8	Gauge	0
iblfQueOutUcastUsed-Peak.38.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.38.1	Gauge	0
iblfQueOutUcastUsed-Peak.38.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.38.2	Gauge	0
iblfQueOutUcastUsed-Peak.38.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.38.3	Gauge	0
iblfQueOutUcastUsed-Peak.38.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.38.4	Gauge	0
iblfQueOutUcastUsed-Peak.38.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.38.5	Gauge	0
iblfQueOutUcastUsed-Peak.38.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.38.6	Gauge	0
iblfQueOutUcastUsed-Peak.38.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.38.7	Gauge	0
iblfQueOutUcastUsed-Peak.38.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.38.8	Gauge	0
iblfQueOutUcastUsed-Peak.39.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.39.1	Gauge	0
iblfQueOutUcastUsed-Peak.39.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.39.2	Gauge	0
iblfQueOutUcastUsed-Peak.39.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.39.3	Gauge	0
iblfQueOutUcastUsed-Peak.39.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.39.4	Gauge	0
iblfQueOutUcastUsed-Peak.39.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.39.5	Gauge	0
iblfQueOutUcastUsed-Peak.39.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.39.6	Gauge	0
iblfQueOutUcastUsed-Peak.39.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.39.7	Gauge	0
iblfQueOutUcastUsed-Peak.39.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.39.8	Gauge	0
iblfQueOutUcastUsed-Peak.40.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.40.1	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsed-Peak.40.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.40.2	Gauge	0
iblfQueOutUcastUsed-Peak.40.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.40.3	Gauge	0
iblfQueOutUcastUsed-Peak.40.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.40.4	Gauge	0
iblfQueOutUcastUsed-Peak.40.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.40.5	Gauge	0
iblfQueOutUcastUsed-Peak.40.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.40.6	Gauge	0
iblfQueOutUcastUsed-Peak.40.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.40.7	Gauge	0
iblfQueOutUcastUsed-Peak.40.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.40.8	Gauge	0
iblfQueOutUcastUsed-Peak.41.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.41.1	Gauge	0
iblfQueOutUcastUsed-Peak.41.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.41.2	Gauge	0
iblfQueOutUcastUsed-Peak.41.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.41.3	Gauge	0
iblfQueOutUcastUsed-Peak.41.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.41.4	Gauge	0
iblfQueOutUcastUsed-Peak.41.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.41.5	Gauge	0
iblfQueOutUcastUsed-Peak.41.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.41.6	Gauge	0
iblfQueOutUcastUsed-Peak.41.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.41.7	Gauge	0
iblfQueOutUcastUsed-Peak.41.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.41.8	Gauge	0
iblfQueOutUcastUsed-Peak.42.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.42.1	Gauge	0
iblfQueOutUcastUsed-Peak.42.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.42.2	Gauge	0
iblfQueOutUcastUsed-Peak.42.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.42.3	Gauge	0
iblfQueOutUcastUsed-Peak.42.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.42.4	Gauge	0
iblfQueOutUcastUsed-Peak.42.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.42.5	Gauge	0
iblfQueOutUcastUsed-Peak.42.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.42.6	Gauge	0
iblfQueOutUcastUsed-Peak.42.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.42.7	Gauge	0
iblfQueOutUcastUsed-Peak.42.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.42.8	Gauge	0
iblfQueOutUcastUsed-Peak.43.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.43.1	Gauge	0
iblfQueOutUcastUsed-Peak.43.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.43.2	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsed-Peak.43.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.43.3	Gauge	0
iblfQueOutUcastUsed-Peak.43.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.43.4	Gauge	0
iblfQueOutUcastUsed-Peak.43.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.43.5	Gauge	0
iblfQueOutUcastUsed-Peak.43.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.43.6	Gauge	0
iblfQueOutUcastUsed-Peak.43.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.43.7	Gauge	0
iblfQueOutUcastUsed-Peak.43.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.43.8	Gauge	0
iblfQueOutUcastUsed-Peak.44.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.44.1	Gauge	0
iblfQueOutUcastUsed-Peak.44.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.44.2	Gauge	0
iblfQueOutUcastUsed-Peak.44.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.44.3	Gauge	0
iblfQueOutUcastUsed-Peak.44.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.44.4	Gauge	0
iblfQueOutUcastUsed-Peak.44.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.44.5	Gauge	0
iblfQueOutUcastUsed-Peak.44.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.44.6	Gauge	0
iblfQueOutUcastUsed-Peak.44.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.44.7	Gauge	0
iblfQueOutUcastUsed-Peak.44.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.44.8	Gauge	0
iblfQueOutUcastUsed-Peak.45.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.45.1	Gauge	0
iblfQueOutUcastUsed-Peak.45.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.45.2	Gauge	0
iblfQueOutUcastUsed-Peak.45.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.45.3	Gauge	0
iblfQueOutUcastUsed-Peak.45.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.45.4	Gauge	0
iblfQueOutUcastUsed-Peak.45.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.45.5	Gauge	0
iblfQueOutUcastUsed-Peak.45.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.45.6	Gauge	0
iblfQueOutUcastUsed-Peak.45.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.45.7	Gauge	0
iblfQueOutUcastUsed-Peak.45.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.45.8	Gauge	0
iblfQueOutUcastUsed-Peak.46.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.46.1	Gauge	0
iblfQueOutUcastUsed-Peak.46.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.46.2	Gauge	0
iblfQueOutUcastUsed-Peak.46.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.46.3	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsed-Peak.46.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.46.4	Gauge	0
iblfQueOutUcastUsed-Peak.46.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.46.5	Gauge	0
iblfQueOutUcastUsed-Peak.46.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.46.6	Gauge	0
iblfQueOutUcastUsed-Peak.46.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.46.7	Gauge	0
iblfQueOutUcastUsed-Peak.46.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.46.8	Gauge	0
iblfQueOutUcastUsed-Peak.47.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.47.1	Gauge	0
iblfQueOutUcastUsed-Peak.47.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.47.2	Gauge	0
iblfQueOutUcastUsed-Peak.47.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.47.3	Gauge	0
iblfQueOutUcastUsed-Peak.47.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.47.4	Gauge	0
iblfQueOutUcastUsed-Peak.47.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.47.5	Gauge	0
iblfQueOutUcastUsed-Peak.47.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.47.6	Gauge	0
iblfQueOutUcastUsed-Peak.47.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.47.7	Gauge	0
iblfQueOutUcastUsed-Peak.47.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.47.8	Gauge	0
iblfQueOutUcastUsed-Peak.48.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.48.1	Gauge	0
iblfQueOutUcastUsed-Peak.48.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.48.2	Gauge	0
iblfQueOutUcastUsed-Peak.48.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.48.3	Gauge	0
iblfQueOutUcastUsed-Peak.48.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.48.4	Gauge	0
iblfQueOutUcastUsed-Peak.48.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.48.5	Gauge	0
iblfQueOutUcastUsed-Peak.48.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.48.6	Gauge	0
iblfQueOutUcastUsed-Peak.48.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.48.7	Gauge	0
iblfQueOutUcastUsed-Peak.48.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.48.8	Gauge	0
iblfQueOutUcastUsed-Peak.49.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.49.1	Gauge	0
iblfQueOutUcastUsed-Peak.49.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.49.2	Gauge	0
iblfQueOutUcastUsed-Peak.49.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.49.3	Gauge	0
iblfQueOutUcastUsed-Peak.49.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.49.4	Gauge	0



Name	OID	Value Type	Value Example
iblfQueOutUcastUsed-Peak.49.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.49.5	Gauge	0
iblfQueOutUcastUsed-Peak.49.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.49.6	Gauge	0
iblfQueOutUcastUsed-Peak.49.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.49.7	Gauge	0
iblfQueOutUcastUsed-Peak.49.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.49.8	Gauge	0
iblfQueOutUcastUsed-Peak.50.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.50.1	Gauge	0
iblfQueOutUcastUsed-Peak.50.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.50.2	Gauge	0
iblfQueOutUcastUsed-Peak.50.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.50.3	Gauge	0
iblfQueOutUcastUsed-Peak.50.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.50.4	Gauge	0
iblfQueOutUcastUsed-Peak.50.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.50.5	Gauge	0
iblfQueOutUcastUsed-Peak.50.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.50.6	Gauge	0
iblfQueOutUcastUsed-Peak.50.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.50.7	Gauge	0
iblfQueOutUcastUsed-Peak.50.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.50.8	Gauge	0
iblfQueOutUcastUsed-Peak.51.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.51.1	Gauge	0
iblfQueOutUcastUsed-Peak.51.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.51.2	Gauge	0
iblfQueOutUcastUsed-Peak.51.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.51.3	Gauge	0
iblfQueOutUcastUsed-Peak.51.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.51.4	Gauge	0
iblfQueOutUcastUsed-Peak.51.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.51.5	Gauge	0
iblfQueOutUcastUsed-Peak.51.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.51.6	Gauge	0
iblfQueOutUcastUsed-Peak.51.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.51.7	Gauge	0
iblfQueOutUcastUsed-Peak.51.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.51.8	Gauge	0
iblfQueOutUcastUsed-Peak.52.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.52.1	Gauge	0
iblfQueOutUcastUsed-Peak.52.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.52.2	Gauge	0
iblfQueOutUcastUsed-Peak.52.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.52.3	Gauge	0
iblfQueOutUcastUsed-Peak.52.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.52.4	Gauge	0
iblfQueOutUcastUsed-Peak.52.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.5.52.5	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastUsed-Peak.52.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.52.6	Gauge	0
iblfQueOutUcastUsed-Peak.52.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.52.7	Gauge	0
iblfQueOutUcastUsed-Peak.52.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.52.8	Gauge	0
iblfQueOutUcastUsed-Peak.53.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.53.1	Gauge	0
iblfQueOutUcastUsed-Peak.53.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.53.2	Gauge	0
iblfQueOutUcastUsed-Peak.53.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.53.3	Gauge	0
iblfQueOutUcastUsed-Peak.53.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.53.4	Gauge	0
iblfQueOutUcastUsed-Peak.53.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.53.5	Gauge	0
iblfQueOutUcastUsed-Peak.53.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.53.6	Gauge	0
iblfQueOutUcastUsed-Peak.53.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.53.7	Gauge	0
iblfQueOutUcastUsed-Peak.53.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.53.8	Gauge	0
iblfQueOutUcastUsed-Peak.54.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.54.1	Gauge	0
iblfQueOutUcastUsed-Peak.54.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.54.2	Gauge	0
iblfQueOutUcastUsed-Peak.54.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.54.3	Gauge	0
iblfQueOutUcastUsed-Peak.54.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.54.4	Gauge	0
iblfQueOutUcastUsed-Peak.54.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.54.5	Gauge	0
iblfQueOutUcastUsed-Peak.54.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.54.6	Gauge	0
iblfQueOutUcastUsed-Peak.54.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.54.7	Gauge	0
iblfQueOutUcastUsed-Peak.54.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.5.54.8	Gauge	0
iblfQueOutUcastThreshold.1.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.1.1	Gauge	0
iblfQueOutUcastThreshold.1.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.1.2	Gauge	0
iblfQueOutUcastThreshold.1.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.1.3	Gauge	0
iblfQueOutUcastThreshold.1.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.1.4	Gauge	0
iblfQueOutUcastThreshold.1.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.1.5	Gauge	0
iblfQueOutUcastThreshold.1.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.1.6	Gauge	0
iblfQueOutUcastThreshold.1.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.1.7	Gauge	0
iblfQueOutUcastThreshold.1.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.1.8	Gauge	0
iblfQueOutUcastThreshold.2.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.2.1	Gauge	0
iblfQueOutUcastThreshold.2.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.2.2	Gauge	0
iblfQueOutUcastThreshold.2.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.2.3	Gauge	0



Name	OID	Value Type	Value Example
iblfQueOutUcastThreshold.7.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.7.7	Gauge	0
iblfQueOutUcastThreshold.7.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.7.8	Gauge	0
iblfQueOutUcastThreshold.8.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.8.1	Gauge	0
iblfQueOutUcastThreshold.8.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.8.2	Gauge	0
iblfQueOutUcastThreshold.8.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.8.3	Gauge	0
iblfQueOutUcastThreshold.8.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.8.4	Gauge	0
iblfQueOutUcastThreshold.8.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.8.5	Gauge	0
iblfQueOutUcastThreshold.8.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.8.6	Gauge	0
iblfQueOutUcastThreshold.8.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.8.7	Gauge	0
iblfQueOutUcastThreshold.8.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.8.8	Gauge	0
iblfQueOutUcastThreshold.9.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.9.1	Gauge	0
iblfQueOutUcastThreshold.9.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.9.2	Gauge	0
iblfQueOutUcastThreshold.9.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.9.3	Gauge	0
iblfQueOutUcastThreshold.9.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.9.4	Gauge	0
iblfQueOutUcastThreshold.9.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.9.5	Gauge	0
iblfQueOutUcastThreshold.9.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.9.6	Gauge	0
iblfQueOutUcastThreshold.9.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.9.7	Gauge	0
iblfQueOutUcastThreshold.9.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.9.8	Gauge	0
iblfQueOutUcastThreshold.10.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.10.1	Gauge	0
iblfQueOutUcastThreshold.10.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.10.2	Gauge	0
iblfQueOutUcastThreshold.10.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.10.3	Gauge	0
iblfQueOutUcastThreshold.10.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.10.4	Gauge	0
iblfQueOutUcastThreshold.10.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.10.5	Gauge	0
iblfQueOutUcastThreshold.10.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.10.6	Gauge	0
iblfQueOutUcastThreshold.10.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.10.7	Gauge	0
iblfQueOutUcastThreshold.10.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.10.8	Gauge	0
iblfQueOutUcastThreshold.11.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.11.1	Gauge	0
iblfQueOutUcastThreshold.11.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.11.2	Gauge	0
iblfQueOutUcastThreshold.11.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.11.3	Gauge	0
iblfQueOutUcastThreshold.11.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.11.4	Gauge	0
iblfQueOutUcastThreshold.11.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.11.5	Gauge	0
iblfQueOutUcastThreshold.11.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.11.6	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastThreshold.11.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.11.7	Gauge	0
iblfQueOutUcastThreshold.11.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.11.8	Gauge	0
iblfQueOutUcastThreshold.12.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.12.1	Gauge	0
iblfQueOutUcastThreshold.12.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.12.2	Gauge	0
iblfQueOutUcastThreshold.12.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.12.3	Gauge	0
iblfQueOutUcastThreshold.12.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.12.4	Gauge	0
iblfQueOutUcastThreshold.12.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.12.5	Gauge	0
iblfQueOutUcastThreshold.12.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.12.6	Gauge	0
iblfQueOutUcastThreshold.12.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.12.7	Gauge	0
iblfQueOutUcastThreshold.12.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.12.8	Gauge	0
iblfQueOutUcastThreshold.13.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.13.1	Gauge	0
iblfQueOutUcastThreshold.13.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.13.2	Gauge	0
iblfQueOutUcastThreshold.13.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.13.3	Gauge	0
iblfQueOutUcastThreshold.13.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.13.4	Gauge	0
iblfQueOutUcastThreshold.13.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.13.5	Gauge	0
iblfQueOutUcastThreshold.13.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.13.6	Gauge	0
iblfQueOutUcastThreshold.13.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.13.7	Gauge	0
iblfQueOutUcastThreshold.13.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.13.8	Gauge	0
iblfQueOutUcastThreshold.14.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.14.1	Gauge	0
iblfQueOutUcastThreshold.14.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.14.2	Gauge	0
iblfQueOutUcastThreshold.14.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.14.3	Gauge	0
iblfQueOutUcastThreshold.14.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.14.4	Gauge	0
iblfQueOutUcastThreshold.14.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.14.5	Gauge	0
iblfQueOutUcastThreshold.14.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.14.6	Gauge	0
iblfQueOutUcastThreshold.14.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.14.7	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastThreshold.14.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.14.8	Gauge	0
iblfQueOutUcastThreshold.15.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.15.1	Gauge	0
iblfQueOutUcastThreshold.15.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.15.2	Gauge	0
iblfQueOutUcastThreshold.15.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.15.3	Gauge	0
iblfQueOutUcastThreshold.15.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.15.4	Gauge	0
iblfQueOutUcastThreshold.15.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.15.5	Gauge	0
iblfQueOutUcastThreshold.15.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.15.6	Gauge	0
iblfQueOutUcastThreshold.15.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.15.7	Gauge	0
iblfQueOutUcastThreshold.15.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.15.8	Gauge	0
iblfQueOutUcastThreshold.16.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.16.1	Gauge	0
iblfQueOutUcastThreshold.16.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.16.2	Gauge	0
iblfQueOutUcastThreshold.16.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.16.3	Gauge	0
iblfQueOutUcastThreshold.16.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.16.4	Gauge	0
iblfQueOutUcastThreshold.16.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.16.5	Gauge	0
iblfQueOutUcastThreshold.16.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.16.6	Gauge	0
iblfQueOutUcastThreshold.16.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.16.7	Gauge	0
iblfQueOutUcastThreshold.16.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.16.8	Gauge	0
iblfQueOutUcastThreshold.17.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.17.1	Gauge	0
iblfQueOutUcastThreshold.17.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.17.2	Gauge	0
iblfQueOutUcastThreshold.17.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.17.3	Gauge	0
iblfQueOutUcastThreshold.17.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.17.4	Gauge	0
iblfQueOutUcastThreshold.17.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.17.5	Gauge	0
iblfQueOutUcastThreshold.17.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.17.6	Gauge	0
iblfQueOutUcastThreshold.17.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.17.7	Gauge	0
iblfQueOutUcastThreshold.17.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.17.8	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastThreshold.18.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.18.1	Gauge	0
iblfQueOutUcastThreshold.18.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.18.2	Gauge	0
iblfQueOutUcastThreshold.18.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.18.3	Gauge	0
iblfQueOutUcastThreshold.18.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.18.4	Gauge	0
iblfQueOutUcastThreshold.18.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.18.5	Gauge	0
iblfQueOutUcastThreshold.18.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.18.6	Gauge	0
iblfQueOutUcastThreshold.18.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.18.7	Gauge	0
iblfQueOutUcastThreshold.18.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.18.8	Gauge	0
iblfQueOutUcastThreshold.19.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.19.1	Gauge	0
iblfQueOutUcastThreshold.19.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.19.2	Gauge	0
iblfQueOutUcastThreshold.19.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.19.3	Gauge	0
iblfQueOutUcastThreshold.19.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.19.4	Gauge	0
iblfQueOutUcastThreshold.19.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.19.5	Gauge	0
iblfQueOutUcastThreshold.19.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.19.6	Gauge	0
iblfQueOutUcastThreshold.19.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.19.7	Gauge	0
iblfQueOutUcastThreshold.19.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.19.8	Gauge	0
iblfQueOutUcastThreshold.20.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.20.1	Gauge	0
iblfQueOutUcastThreshold.20.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.20.2	Gauge	0
iblfQueOutUcastThreshold.20.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.20.3	Gauge	0
iblfQueOutUcastThreshold.20.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.20.4	Gauge	0
iblfQueOutUcastThreshold.20.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.20.5	Gauge	0
iblfQueOutUcastThreshold.20.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.20.6	Gauge	0
iblfQueOutUcastThreshold.20.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.20.7	Gauge	0
iblfQueOutUcastThreshold.20.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.20.8	Gauge	0
iblfQueOutUcastThreshold.21.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.21.1	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastThreshold.21.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.21.2	Gauge	0
iblfQueOutUcastThreshold.21.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.21.3	Gauge	0
iblfQueOutUcastThreshold.21.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.21.4	Gauge	0
iblfQueOutUcastThreshold.21.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.21.5	Gauge	0
iblfQueOutUcastThreshold.21.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.21.6	Gauge	0
iblfQueOutUcastThreshold.21.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.21.7	Gauge	0
iblfQueOutUcastThreshold.21.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.21.8	Gauge	0
iblfQueOutUcastThreshold.22.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.22.1	Gauge	0
iblfQueOutUcastThreshold.22.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.22.2	Gauge	0
iblfQueOutUcastThreshold.22.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.22.3	Gauge	0
iblfQueOutUcastThreshold.22.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.22.4	Gauge	0
iblfQueOutUcastThreshold.22.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.22.5	Gauge	0
iblfQueOutUcastThreshold.22.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.22.6	Gauge	0
iblfQueOutUcastThreshold.22.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.22.7	Gauge	0
iblfQueOutUcastThreshold.22.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.22.8	Gauge	0
iblfQueOutUcastThreshold.23.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.23.1	Gauge	0
iblfQueOutUcastThreshold.23.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.23.2	Gauge	0
iblfQueOutUcastThreshold.23.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.23.3	Gauge	0
iblfQueOutUcastThreshold.23.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.23.4	Gauge	0
iblfQueOutUcastThreshold.23.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.23.5	Gauge	0
iblfQueOutUcastThreshold.23.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.23.6	Gauge	0
iblfQueOutUcastThreshold.23.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.23.7	Gauge	0
iblfQueOutUcastThreshold.23.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.23.8	Gauge	0
iblfQueOutUcastThreshold.24.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.24.1	Gauge	0
iblfQueOutUcastThreshold.24.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.24.2	Gauge	0



Name	OID	Value Type	Value Example
iblfQueOutUcastThreshold.24.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.24.3	Gauge	0
iblfQueOutUcastThreshold.24.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.24.4	Gauge	0
iblfQueOutUcastThreshold.24.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.24.5	Gauge	0
iblfQueOutUcastThreshold.24.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.24.6	Gauge	0
iblfQueOutUcastThreshold.24.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.24.7	Gauge	0
iblfQueOutUcastThreshold.24.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.24.8	Gauge	0
iblfQueOutUcastThreshold.25.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.25.1	Gauge	0
iblfQueOutUcastThreshold.25.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.25.2	Gauge	0
iblfQueOutUcastThreshold.25.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.25.3	Gauge	0
iblfQueOutUcastThreshold.25.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.25.4	Gauge	0
iblfQueOutUcastThreshold.25.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.25.5	Gauge	0
iblfQueOutUcastThreshold.25.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.25.6	Gauge	0
iblfQueOutUcastThreshold.25.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.25.7	Gauge	0
iblfQueOutUcastThreshold.25.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.25.8	Gauge	0
iblfQueOutUcastThreshold.26.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.26.1	Gauge	0
iblfQueOutUcastThreshold.26.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.26.2	Gauge	0
iblfQueOutUcastThreshold.26.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.26.3	Gauge	0
iblfQueOutUcastThreshold.26.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.26.4	Gauge	0
iblfQueOutUcastThreshold.26.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.26.5	Gauge	0
iblfQueOutUcastThreshold.26.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.26.6	Gauge	0
iblfQueOutUcastThreshold.26.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.26.7	Gauge	0
iblfQueOutUcastThreshold.26.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.26.8	Gauge	0
iblfQueOutUcastThreshold.27.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.27.1	Gauge	0
iblfQueOutUcastThreshold.27.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.27.2	Gauge	0
iblfQueOutUcastThreshold.27.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.27.3	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastThreshold.27.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.27.4	Gauge	0
iblfQueOutUcastThreshold.27.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.27.5	Gauge	0
iblfQueOutUcastThreshold.27.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.27.6	Gauge	0
iblfQueOutUcastThreshold.27.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.27.7	Gauge	0
iblfQueOutUcastThreshold.27.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.27.8	Gauge	0
iblfQueOutUcastThreshold.28.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.28.1	Gauge	0
iblfQueOutUcastThreshold.28.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.28.2	Gauge	0
iblfQueOutUcastThreshold.28.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.28.3	Gauge	0
iblfQueOutUcastThreshold.28.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.28.4	Gauge	0
iblfQueOutUcastThreshold.28.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.28.5	Gauge	0
iblfQueOutUcastThreshold.28.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.28.6	Gauge	0
iblfQueOutUcastThreshold.28.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.28.7	Gauge	0
iblfQueOutUcastThreshold.28.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.28.8	Gauge	0
iblfQueOutUcastThreshold.29.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.29.1	Gauge	0
iblfQueOutUcastThreshold.29.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.29.2	Gauge	0
iblfQueOutUcastThreshold.29.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.29.3	Gauge	0
iblfQueOutUcastThreshold.29.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.29.4	Gauge	0
iblfQueOutUcastThreshold.29.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.29.5	Gauge	0
iblfQueOutUcastThreshold.29.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.29.6	Gauge	0
iblfQueOutUcastThreshold.29.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.29.7	Gauge	0
iblfQueOutUcastThreshold.29.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.29.8	Gauge	0
iblfQueOutUcastThreshold.30.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.30.1	Gauge	0
iblfQueOutUcastThreshold.30.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.30.2	Gauge	0
iblfQueOutUcastThreshold.30.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.30.3	Gauge	0
iblfQueOutUcastThreshold.30.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.30.4	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastThreshold.30.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.30.5	Gauge	0
iblfQueOutUcastThreshold.30.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.30.6	Gauge	0
iblfQueOutUcastThreshold.30.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.30.7	Gauge	0
iblfQueOutUcastThreshold.30.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.30.8	Gauge	0
iblfQueOutUcastThreshold.31.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.31.1	Gauge	0
iblfQueOutUcastThreshold.31.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.31.2	Gauge	0
iblfQueOutUcastThreshold.31.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.31.3	Gauge	0
iblfQueOutUcastThreshold.31.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.31.4	Gauge	0
iblfQueOutUcastThreshold.31.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.31.5	Gauge	0
iblfQueOutUcastThreshold.31.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.31.6	Gauge	0
iblfQueOutUcastThreshold.31.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.31.7	Gauge	0
iblfQueOutUcastThreshold.31.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.31.8	Gauge	0
iblfQueOutUcastThreshold.32.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.32.1	Gauge	0
iblfQueOutUcastThreshold.32.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.32.2	Gauge	0
iblfQueOutUcastThreshold.32.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.32.3	Gauge	0
iblfQueOutUcastThreshold.32.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.32.4	Gauge	0
iblfQueOutUcastThreshold.32.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.32.5	Gauge	0
iblfQueOutUcastThreshold.32.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.32.6	Gauge	0
iblfQueOutUcastThreshold.32.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.32.7	Gauge	0
iblfQueOutUcastThreshold.32.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.32.8	Gauge	0
iblfQueOutUcastThreshold.33.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.33.1	Gauge	0
iblfQueOutUcastThreshold.33.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.33.2	Gauge	0
iblfQueOutUcastThreshold.33.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.33.3	Gauge	0
iblfQueOutUcastThreshold.33.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.33.4	Gauge	0
iblfQueOutUcastThreshold.33.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.33.5	Gauge	0

Name	OID	Value Type	Value Example
ibLfQueOutUcastThreshold.33.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.33.6	Gauge	0
ibLfQueOutUcastThreshold.33.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.33.7	Gauge	0
ibLfQueOutUcastThreshold.33.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.33.8	Gauge	0
ibLfQueOutUcastThreshold.34.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.34.1	Gauge	0
ibLfQueOutUcastThreshold.34.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.34.2	Gauge	0
ibLfQueOutUcastThreshold.34.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.34.3	Gauge	0
ibLfQueOutUcastThreshold.34.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.34.4	Gauge	0
ibLfQueOutUcastThreshold.34.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.34.5	Gauge	0
ibLfQueOutUcastThreshold.34.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.34.6	Gauge	0
ibLfQueOutUcastThreshold.34.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.34.7	Gauge	0
ibLfQueOutUcastThreshold.34.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.34.8	Gauge	0
ibLfQueOutUcastThreshold.35.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.35.1	Gauge	0
ibLfQueOutUcastThreshold.35.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.35.2	Gauge	0
ibLfQueOutUcastThreshold.35.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.35.3	Gauge	0
ibLfQueOutUcastThreshold.35.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.35.4	Gauge	0
ibLfQueOutUcastThreshold.35.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.35.5	Gauge	0
ibLfQueOutUcastThreshold.35.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.35.6	Gauge	0
ibLfQueOutUcastThreshold.35.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.35.7	Gauge	0
ibLfQueOutUcastThreshold.35.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.35.8	Gauge	0
ibLfQueOutUcastThreshold.36.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.36.1	Gauge	0
ibLfQueOutUcastThreshold.36.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.36.2	Gauge	0
ibLfQueOutUcastThreshold.36.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.36.3	Gauge	0
ibLfQueOutUcastThreshold.36.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.36.4	Gauge	0
ibLfQueOutUcastThreshold.36.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.36.5	Gauge	0
ibLfQueOutUcastThreshold.36.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.36.6	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastThreshold.36.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.36.7	Gauge	0
iblfQueOutUcastThreshold.36.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.36.8	Gauge	0
iblfQueOutUcastThreshold.37.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.37.1	Gauge	0
iblfQueOutUcastThreshold.37.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.37.2	Gauge	0
iblfQueOutUcastThreshold.37.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.37.3	Gauge	0
iblfQueOutUcastThreshold.37.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.37.4	Gauge	0
iblfQueOutUcastThreshold.37.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.37.5	Gauge	0
iblfQueOutUcastThreshold.37.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.37.6	Gauge	0
iblfQueOutUcastThreshold.37.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.37.7	Gauge	0
iblfQueOutUcastThreshold.37.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.37.8	Gauge	0
iblfQueOutUcastThreshold.38.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.38.1	Gauge	0
iblfQueOutUcastThreshold.38.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.38.2	Gauge	0
iblfQueOutUcastThreshold.38.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.38.3	Gauge	0
iblfQueOutUcastThreshold.38.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.38.4	Gauge	0
iblfQueOutUcastThreshold.38.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.38.5	Gauge	0
iblfQueOutUcastThreshold.38.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.38.6	Gauge	0
iblfQueOutUcastThreshold.38.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.38.7	Gauge	0
iblfQueOutUcastThreshold.38.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.38.8	Gauge	0
iblfQueOutUcastThreshold.39.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.39.1	Gauge	0
iblfQueOutUcastThreshold.39.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.39.2	Gauge	0
iblfQueOutUcastThreshold.39.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.39.3	Gauge	0
iblfQueOutUcastThreshold.39.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.39.4	Gauge	0
iblfQueOutUcastThreshold.39.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.39.5	Gauge	0
iblfQueOutUcastThreshold.39.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.39.6	Gauge	0
iblfQueOutUcastThreshold.39.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.39.7	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastThreshold.39.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.39.8	Gauge	0
iblfQueOutUcastThreshold.40.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.40.1	Gauge	0
iblfQueOutUcastThreshold.40.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.40.2	Gauge	0
iblfQueOutUcastThreshold.40.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.40.3	Gauge	0
iblfQueOutUcastThreshold.40.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.40.4	Gauge	0
iblfQueOutUcastThreshold.40.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.40.5	Gauge	0
iblfQueOutUcastThreshold.40.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.40.6	Gauge	0
iblfQueOutUcastThreshold.40.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.40.7	Gauge	0
iblfQueOutUcastThreshold.40.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.40.8	Gauge	0
iblfQueOutUcastThreshold.41.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.41.1	Gauge	0
iblfQueOutUcastThreshold.41.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.41.2	Gauge	0
iblfQueOutUcastThreshold.41.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.41.3	Gauge	0
iblfQueOutUcastThreshold.41.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.41.4	Gauge	0
iblfQueOutUcastThreshold.41.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.41.5	Gauge	0
iblfQueOutUcastThreshold.41.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.41.6	Gauge	0
iblfQueOutUcastThreshold.41.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.41.7	Gauge	0
iblfQueOutUcastThreshold.41.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.41.8	Gauge	0
iblfQueOutUcastThreshold.42.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.42.1	Gauge	0
iblfQueOutUcastThreshold.42.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.42.2	Gauge	0
iblfQueOutUcastThreshold.42.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.42.3	Gauge	0
iblfQueOutUcastThreshold.42.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.42.4	Gauge	0
iblfQueOutUcastThreshold.42.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.42.5	Gauge	0
iblfQueOutUcastThreshold.42.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.42.6	Gauge	0
iblfQueOutUcastThreshold.42.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.42.7	Gauge	0
iblfQueOutUcastThreshold.42.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.42.8	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastThreshold.43.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.43.1	Gauge	0
iblfQueOutUcastThreshold.43.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.43.2	Gauge	0
iblfQueOutUcastThreshold.43.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.43.3	Gauge	0
iblfQueOutUcastThreshold.43.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.43.4	Gauge	0
iblfQueOutUcastThreshold.43.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.43.5	Gauge	0
iblfQueOutUcastThreshold.43.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.43.6	Gauge	0
iblfQueOutUcastThreshold.43.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.43.7	Gauge	0
iblfQueOutUcastThreshold.43.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.43.8	Gauge	0
iblfQueOutUcastThreshold.44.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.44.1	Gauge	0
iblfQueOutUcastThreshold.44.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.44.2	Gauge	0
iblfQueOutUcastThreshold.44.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.44.3	Gauge	0
iblfQueOutUcastThreshold.44.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.44.4	Gauge	0
iblfQueOutUcastThreshold.44.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.44.5	Gauge	0
iblfQueOutUcastThreshold.44.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.44.6	Gauge	0
iblfQueOutUcastThreshold.44.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.44.7	Gauge	0
iblfQueOutUcastThreshold.44.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.44.8	Gauge	0
iblfQueOutUcastThreshold.45.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.45.1	Gauge	0
iblfQueOutUcastThreshold.45.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.45.2	Gauge	0
iblfQueOutUcastThreshold.45.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.45.3	Gauge	0
iblfQueOutUcastThreshold.45.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.45.4	Gauge	0
iblfQueOutUcastThreshold.45.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.45.5	Gauge	0
iblfQueOutUcastThreshold.45.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.45.6	Gauge	0
iblfQueOutUcastThreshold.45.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.45.7	Gauge	0
iblfQueOutUcastThreshold.45.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.45.8	Gauge	0
iblfQueOutUcastThreshold.46.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.46.1	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastThreshold.46.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.46.2	Gauge	0
iblfQueOutUcastThreshold.46.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.46.3	Gauge	0
iblfQueOutUcastThreshold.46.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.46.4	Gauge	0
iblfQueOutUcastThreshold.46.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.46.5	Gauge	0
iblfQueOutUcastThreshold.46.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.46.6	Gauge	0
iblfQueOutUcastThreshold.46.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.46.7	Gauge	0
iblfQueOutUcastThreshold.46.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.46.8	Gauge	0
iblfQueOutUcastThreshold.47.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.47.1	Gauge	0
iblfQueOutUcastThreshold.47.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.47.2	Gauge	0
iblfQueOutUcastThreshold.47.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.47.3	Gauge	0
iblfQueOutUcastThreshold.47.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.47.4	Gauge	0
iblfQueOutUcastThreshold.47.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.47.5	Gauge	0
iblfQueOutUcastThreshold.47.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.47.6	Gauge	0
iblfQueOutUcastThreshold.47.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.47.7	Gauge	0
iblfQueOutUcastThreshold.47.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.47.8	Gauge	0
iblfQueOutUcastThreshold.48.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.48.1	Gauge	0
iblfQueOutUcastThreshold.48.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.48.2	Gauge	0
iblfQueOutUcastThreshold.48.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.48.3	Gauge	0
iblfQueOutUcastThreshold.48.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.48.4	Gauge	0
iblfQueOutUcastThreshold.48.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.48.5	Gauge	0
iblfQueOutUcastThreshold.48.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.48.6	Gauge	0
iblfQueOutUcastThreshold.48.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.48.7	Gauge	0
iblfQueOutUcastThreshold.48.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.48.8	Gauge	0
iblfQueOutUcastThreshold.49.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.49.1	Gauge	0
iblfQueOutUcastThreshold.49.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.49.2	Gauge	0



Name	OID	Value Type	Value Example
iblfQueOutUcastThreshold.49.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.49.3	Gauge	0
iblfQueOutUcastThreshold.49.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.49.4	Gauge	0
iblfQueOutUcastThreshold.49.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.49.5	Gauge	0
iblfQueOutUcastThreshold.49.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.49.6	Gauge	0
iblfQueOutUcastThreshold.49.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.49.7	Gauge	0
iblfQueOutUcastThreshold.49.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.49.8	Gauge	0
iblfQueOutUcastThreshold.50.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.50.1	Gauge	0
iblfQueOutUcastThreshold.50.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.50.2	Gauge	0
iblfQueOutUcastThreshold.50.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.50.3	Gauge	0
iblfQueOutUcastThreshold.50.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.50.4	Gauge	0
iblfQueOutUcastThreshold.50.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.50.5	Gauge	0
iblfQueOutUcastThreshold.50.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.50.6	Gauge	0
iblfQueOutUcastThreshold.50.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.50.7	Gauge	0
iblfQueOutUcastThreshold.50.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.50.8	Gauge	0
iblfQueOutUcastThreshold.51.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.51.1	Gauge	0
iblfQueOutUcastThreshold.51.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.51.2	Gauge	0
iblfQueOutUcastThreshold.51.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.51.3	Gauge	0
iblfQueOutUcastThreshold.51.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.51.4	Gauge	0
iblfQueOutUcastThreshold.51.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.51.5	Gauge	0
iblfQueOutUcastThreshold.51.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.51.6	Gauge	0
iblfQueOutUcastThreshold.51.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.51.7	Gauge	0
iblfQueOutUcastThreshold.51.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.51.8	Gauge	0
iblfQueOutUcastThreshold.52.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.52.1	Gauge	0
iblfQueOutUcastThreshold.52.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.52.2	Gauge	0
iblfQueOutUcastThreshold.52.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.6.52.3	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastThreshold.52.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.52.4	Gauge	0
iblfQueOutUcastThreshold.52.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.52.5	Gauge	0
iblfQueOutUcastThreshold.52.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.52.6	Gauge	0
iblfQueOutUcastThreshold.52.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.52.7	Gauge	0
iblfQueOutUcastThreshold.52.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.52.8	Gauge	0
iblfQueOutUcastThreshold.53.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.53.1	Gauge	0
iblfQueOutUcastThreshold.53.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.53.2	Gauge	0
iblfQueOutUcastThreshold.53.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.53.3	Gauge	0
iblfQueOutUcastThreshold.53.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.53.4	Gauge	0
iblfQueOutUcastThreshold.53.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.53.5	Gauge	0
iblfQueOutUcastThreshold.53.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.53.6	Gauge	0
iblfQueOutUcastThreshold.53.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.53.7	Gauge	0
iblfQueOutUcastThreshold.53.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.53.8	Gauge	0
iblfQueOutUcastThreshold.54.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.54.1	Gauge	0
iblfQueOutUcastThreshold.54.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.54.2	Gauge	0
iblfQueOutUcastThreshold.54.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.54.3	Gauge	0
iblfQueOutUcastThreshold.54.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.54.4	Gauge	0
iblfQueOutUcastThreshold.54.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.54.5	Gauge	0
iblfQueOutUcastThreshold.54.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.54.6	Gauge	0
iblfQueOutUcastThreshold.54.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.54.7	Gauge	0
iblfQueOutUcastThreshold.54.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.6.54.8	Gauge	0
iblfQueOutUcastOverThres.1.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.1.1	Gauge	0
iblfQueOutUcastOverThres.1.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.1.2	Gauge	0
iblfQueOutUcastOverThres.1.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.1.3	Gauge	0
iblfQueOutUcastOverThres.1.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.1.4	Gauge	0
iblfQueOutUcastOverThres.1.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.1.5	Gauge	0
iblfQueOutUcastOverThres.1.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.1.6	Gauge	0
iblfQueOutUcastOverThres.1.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.1.7	Gauge	0



Name	OID	Value Type	Value Example
iblfQueOutUcastOverThres.7.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.7.3	Gauge	0
iblfQueOutUcastOverThres.7.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.7.4	Gauge	0
iblfQueOutUcastOverThres.7.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.7.5	Gauge	0
iblfQueOutUcastOverThres.7.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.7.6	Gauge	0
iblfQueOutUcastOverThres.7.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.7.7	Gauge	0
iblfQueOutUcastOverThres.7.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.7.8	Gauge	0
iblfQueOutUcastOverThres.8.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.8.1	Gauge	0
iblfQueOutUcastOverThres.8.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.8.2	Gauge	0
iblfQueOutUcastOverThres.8.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.8.3	Gauge	0
iblfQueOutUcastOverThres.8.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.8.4	Gauge	0
iblfQueOutUcastOverThres.8.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.8.5	Gauge	0
iblfQueOutUcastOverThres.8.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.8.6	Gauge	0
iblfQueOutUcastOverThres.8.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.8.7	Gauge	0
iblfQueOutUcastOverThres.8.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.8.8	Gauge	0
iblfQueOutUcastOverThres.9.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.9.1	Gauge	0
iblfQueOutUcastOverThres.9.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.9.2	Gauge	0
iblfQueOutUcastOverThres.9.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.9.3	Gauge	0
iblfQueOutUcastOverThres.9.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.9.4	Gauge	0
iblfQueOutUcastOverThres.9.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.9.5	Gauge	0
iblfQueOutUcastOverThres.9.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.9.6	Gauge	0
iblfQueOutUcastOverThres.9.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.9.7	Gauge	0
iblfQueOutUcastOverThres.9.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.9.8	Gauge	0
iblfQueOutUcastOverThres.10.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.10.1	Gauge	0
iblfQueOutUcastOverThres.10.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.10.2	Gauge	0
iblfQueOutUcastOverThres.10.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.10.3	Gauge	0
iblfQueOutUcastOverThres.10.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.10.4	Gauge	0
iblfQueOutUcastOverThres.10.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.10.5	Gauge	0
iblfQueOutUcastOverThres.10.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.10.6	Gauge	0
iblfQueOutUcastOverThres.10.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.10.7	Gauge	0
iblfQueOutUcastOverThres.10.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.10.8	Gauge	0
iblfQueOutUcastOverThres.11.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.11.1	Gauge	0
iblfQueOutUcastOverThres.11.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.11.2	Gauge	0
iblfQueOutUcastOverThres.11.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.11.3	Gauge	0
iblfQueOutUcastOverThres.11.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.11.4	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastOverTh-res.11.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.11.5	Gauge	0
iblfQueOutUcastOverTh-res.11.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.11.6	Gauge	0
iblfQueOutUcastOverTh-res.11.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.11.7	Gauge	0
iblfQueOutUcastOverTh-res.11.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.11.8	Gauge	0
iblfQueOutUcastOverTh-res.12.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.12.1	Gauge	0
iblfQueOutUcastOverTh-res.12.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.12.2	Gauge	0
iblfQueOutUcastOverTh-res.12.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.12.3	Gauge	0
iblfQueOutUcastOverTh-res.12.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.12.4	Gauge	0
iblfQueOutUcastOverTh-res.12.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.12.5	Gauge	0
iblfQueOutUcastOverTh-res.12.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.12.6	Gauge	0
iblfQueOutUcastOverTh-res.12.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.12.7	Gauge	0
iblfQueOutUcastOverTh-res.12.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.12.8	Gauge	0
iblfQueOutUcastOverTh-res.13.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.13.1	Gauge	0
iblfQueOutUcastOverTh-res.13.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.13.2	Gauge	0
iblfQueOutUcastOverTh-res.13.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.13.3	Gauge	0
iblfQueOutUcastOverTh-res.13.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.13.4	Gauge	0
iblfQueOutUcastOverTh-res.13.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.13.5	Gauge	0
iblfQueOutUcastOverTh-res.13.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.13.6	Gauge	0
iblfQueOutUcastOverTh-res.13.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.13.7	Gauge	0
iblfQueOutUcastOverTh-res.13.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.13.8	Gauge	0
iblfQueOutUcastOverTh-res.14.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.14.1	Gauge	0
iblfQueOutUcastOverTh-res.14.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.14.2	Gauge	0
iblfQueOutUcastOverTh-res.14.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.14.3	Gauge	0
iblfQueOutUcastOverTh-res.14.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.14.4	Gauge	0
iblfQueOutUcastOverTh-res.14.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.14.5	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastOverThres.14.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.14.6	Gauge	0
iblfQueOutUcastOverThres.14.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.14.7	Gauge	0
iblfQueOutUcastOverThres.14.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.14.8	Gauge	0
iblfQueOutUcastOverThres.15.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.15.1	Gauge	0
iblfQueOutUcastOverThres.15.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.15.2	Gauge	0
iblfQueOutUcastOverThres.15.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.15.3	Gauge	0
iblfQueOutUcastOverThres.15.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.15.4	Gauge	0
iblfQueOutUcastOverThres.15.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.15.5	Gauge	0
iblfQueOutUcastOverThres.15.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.15.6	Gauge	0
iblfQueOutUcastOverThres.15.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.15.7	Gauge	0
iblfQueOutUcastOverThres.15.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.15.8	Gauge	0
iblfQueOutUcastOverThres.16.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.16.1	Gauge	0
iblfQueOutUcastOverThres.16.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.16.2	Gauge	0
iblfQueOutUcastOverThres.16.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.16.3	Gauge	0
iblfQueOutUcastOverThres.16.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.16.4	Gauge	0
iblfQueOutUcastOverThres.16.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.16.5	Gauge	0
iblfQueOutUcastOverThres.16.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.16.6	Gauge	0
iblfQueOutUcastOverThres.16.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.16.7	Gauge	0
iblfQueOutUcastOverThres.16.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.16.8	Gauge	0
iblfQueOutUcastOverThres.17.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.17.1	Gauge	0
iblfQueOutUcastOverThres.17.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.17.2	Gauge	0
iblfQueOutUcastOverThres.17.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.17.3	Gauge	0
iblfQueOutUcastOverThres.17.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.17.4	Gauge	0
iblfQueOutUcastOverThres.17.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.17.5	Gauge	0
iblfQueOutUcastOverThres.17.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.17.6	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastOverThres.17.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.17.7	Gauge	0
iblfQueOutUcastOverThres.17.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.17.8	Gauge	0
iblfQueOutUcastOverThres.18.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.18.1	Gauge	0
iblfQueOutUcastOverThres.18.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.18.2	Gauge	0
iblfQueOutUcastOverThres.18.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.18.3	Gauge	0
iblfQueOutUcastOverThres.18.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.18.4	Gauge	0
iblfQueOutUcastOverThres.18.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.18.5	Gauge	0
iblfQueOutUcastOverThres.18.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.18.6	Gauge	0
iblfQueOutUcastOverThres.18.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.18.7	Gauge	0
iblfQueOutUcastOverThres.18.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.18.8	Gauge	0
iblfQueOutUcastOverThres.19.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.19.1	Gauge	0
iblfQueOutUcastOverThres.19.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.19.2	Gauge	0
iblfQueOutUcastOverThres.19.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.19.3	Gauge	0
iblfQueOutUcastOverThres.19.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.19.4	Gauge	0
iblfQueOutUcastOverThres.19.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.19.5	Gauge	0
iblfQueOutUcastOverThres.19.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.19.6	Gauge	0
iblfQueOutUcastOverThres.19.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.19.7	Gauge	0
iblfQueOutUcastOverThres.19.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.19.8	Gauge	0
iblfQueOutUcastOverThres.20.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.20.1	Gauge	0
iblfQueOutUcastOverThres.20.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.20.2	Gauge	0
iblfQueOutUcastOverThres.20.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.20.3	Gauge	0
iblfQueOutUcastOverThres.20.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.20.4	Gauge	0
iblfQueOutUcastOverThres.20.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.20.5	Gauge	0
iblfQueOutUcastOverThres.20.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.20.6	Gauge	0
iblfQueOutUcastOverThres.20.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.20.7	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastOverTh-res.20.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.20.8	Gauge	0
iblfQueOutUcastOverTh-res.21.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.21.1	Gauge	0
iblfQueOutUcastOverTh-res.21.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.21.2	Gauge	0
iblfQueOutUcastOverTh-res.21.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.21.3	Gauge	0
iblfQueOutUcastOverTh-res.21.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.21.4	Gauge	0
iblfQueOutUcastOverTh-res.21.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.21.5	Gauge	0
iblfQueOutUcastOverTh-res.21.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.21.6	Gauge	0
iblfQueOutUcastOverTh-res.21.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.21.7	Gauge	0
iblfQueOutUcastOverTh-res.21.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.21.8	Gauge	0
iblfQueOutUcastOverTh-res.22.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.22.1	Gauge	0
iblfQueOutUcastOverTh-res.22.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.22.2	Gauge	0
iblfQueOutUcastOverTh-res.22.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.22.3	Gauge	0
iblfQueOutUcastOverTh-res.22.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.22.4	Gauge	0
iblfQueOutUcastOverTh-res.22.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.22.5	Gauge	0
iblfQueOutUcastOverTh-res.22.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.22.6	Gauge	0
iblfQueOutUcastOverTh-res.22.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.22.7	Gauge	0
iblfQueOutUcastOverTh-res.22.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.22.8	Gauge	0
iblfQueOutUcastOverTh-res.23.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.23.1	Gauge	0
iblfQueOutUcastOverTh-res.23.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.23.2	Gauge	0
iblfQueOutUcastOverTh-res.23.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.23.3	Gauge	0
iblfQueOutUcastOverTh-res.23.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.23.4	Gauge	0
iblfQueOutUcastOverTh-res.23.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.23.5	Gauge	0
iblfQueOutUcastOverTh-res.23.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.23.6	Gauge	0
iblfQueOutUcastOverTh-res.23.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.23.7	Gauge	0
iblfQueOutUcastOverTh-res.23.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.23.8	Gauge	0



Name	OID	Value Type	Value Example
iblfQueOutUcastOverTh-res.24.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.24.1	Gauge	0
iblfQueOutUcastOverTh-res.24.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.24.2	Gauge	0
iblfQueOutUcastOverTh-res.24.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.24.3	Gauge	0
iblfQueOutUcastOverTh-res.24.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.24.4	Gauge	0
iblfQueOutUcastOverTh-res.24.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.24.5	Gauge	0
iblfQueOutUcastOverTh-res.24.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.24.6	Gauge	0
iblfQueOutUcastOverTh-res.24.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.24.7	Gauge	0
iblfQueOutUcastOverTh-res.24.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.24.8	Gauge	0
iblfQueOutUcastOverTh-res.25.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.25.1	Gauge	0
iblfQueOutUcastOverTh-res.25.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.25.2	Gauge	0
iblfQueOutUcastOverTh-res.25.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.25.3	Gauge	0
iblfQueOutUcastOverTh-res.25.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.25.4	Gauge	0
iblfQueOutUcastOverTh-res.25.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.25.5	Gauge	0
iblfQueOutUcastOverTh-res.25.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.25.6	Gauge	0
iblfQueOutUcastOverTh-res.25.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.25.7	Gauge	0
iblfQueOutUcastOverTh-res.25.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.25.8	Gauge	0
iblfQueOutUcastOverTh-res.26.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.26.1	Gauge	0
iblfQueOutUcastOverTh-res.26.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.26.2	Gauge	0
iblfQueOutUcastOverTh-res.26.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.26.3	Gauge	0
iblfQueOutUcastOverTh-res.26.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.26.4	Gauge	0
iblfQueOutUcastOverTh-res.26.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.26.5	Gauge	0
iblfQueOutUcastOverTh-res.26.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.26.6	Gauge	0
iblfQueOutUcastOverTh-res.26.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.26.7	Gauge	0
iblfQueOutUcastOverTh-res.26.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.26.8	Gauge	0
iblfQueOutUcastOverTh-res.27.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.27.1	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastOverTh-res.27.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.27.2	Gauge	0
iblfQueOutUcastOverTh-res.27.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.27.3	Gauge	0
iblfQueOutUcastOverTh-res.27.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.27.4	Gauge	0
iblfQueOutUcastOverTh-res.27.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.27.5	Gauge	0
iblfQueOutUcastOverTh-res.27.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.27.6	Gauge	0
iblfQueOutUcastOverTh-res.27.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.27.7	Gauge	0
iblfQueOutUcastOverTh-res.27.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.27.8	Gauge	0
iblfQueOutUcastOverTh-res.28.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.28.1	Gauge	0
iblfQueOutUcastOverTh-res.28.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.28.2	Gauge	0
iblfQueOutUcastOverTh-res.28.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.28.3	Gauge	0
iblfQueOutUcastOverTh-res.28.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.28.4	Gauge	0
iblfQueOutUcastOverTh-res.28.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.28.5	Gauge	0
iblfQueOutUcastOverTh-res.28.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.28.6	Gauge	0
iblfQueOutUcastOverTh-res.28.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.28.7	Gauge	0
iblfQueOutUcastOverTh-res.28.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.28.8	Gauge	0
iblfQueOutUcastOverTh-res.29.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.29.1	Gauge	0
iblfQueOutUcastOverTh-res.29.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.29.2	Gauge	0
iblfQueOutUcastOverTh-res.29.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.29.3	Gauge	0
iblfQueOutUcastOverTh-res.29.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.29.4	Gauge	0
iblfQueOutUcastOverTh-res.29.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.29.5	Gauge	0
iblfQueOutUcastOverTh-res.29.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.29.6	Gauge	0
iblfQueOutUcastOverTh-res.29.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.29.7	Gauge	0
iblfQueOutUcastOverTh-res.29.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.29.8	Gauge	0
iblfQueOutUcastOverTh-res.30.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.30.1	Gauge	0
iblfQueOutUcastOverTh-res.30.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.30.2	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastOverTh-res.30.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.30.3	Gauge	0
iblfQueOutUcastOverTh-res.30.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.30.4	Gauge	0
iblfQueOutUcastOverTh-res.30.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.30.5	Gauge	0
iblfQueOutUcastOverTh-res.30.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.30.6	Gauge	0
iblfQueOutUcastOverTh-res.30.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.30.7	Gauge	0
iblfQueOutUcastOverTh-res.30.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.30.8	Gauge	0
iblfQueOutUcastOverTh-res.31.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.31.1	Gauge	0
iblfQueOutUcastOverTh-res.31.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.31.2	Gauge	0
iblfQueOutUcastOverTh-res.31.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.31.3	Gauge	0
iblfQueOutUcastOverTh-res.31.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.31.4	Gauge	0
iblfQueOutUcastOverTh-res.31.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.31.5	Gauge	0
iblfQueOutUcastOverTh-res.31.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.31.6	Gauge	0
iblfQueOutUcastOverTh-res.31.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.31.7	Gauge	0
iblfQueOutUcastOverTh-res.31.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.31.8	Gauge	0
iblfQueOutUcastOverTh-res.32.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.32.1	Gauge	0
iblfQueOutUcastOverTh-res.32.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.32.2	Gauge	0
iblfQueOutUcastOverTh-res.32.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.32.3	Gauge	0
iblfQueOutUcastOverTh-res.32.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.32.4	Gauge	0
iblfQueOutUcastOverTh-res.32.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.32.5	Gauge	0
iblfQueOutUcastOverTh-res.32.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.32.6	Gauge	0
iblfQueOutUcastOverTh-res.32.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.32.7	Gauge	0
iblfQueOutUcastOverTh-res.32.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.32.8	Gauge	0
iblfQueOutUcastOverTh-res.33.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.33.1	Gauge	0
iblfQueOutUcastOverTh-res.33.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.33.2	Gauge	0
iblfQueOutUcastOverTh-res.33.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.33.3	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastOverTh-res.33.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.33.4	Gauge	0
iblfQueOutUcastOverTh-res.33.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.33.5	Gauge	0
iblfQueOutUcastOverTh-res.33.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.33.6	Gauge	0
iblfQueOutUcastOverTh-res.33.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.33.7	Gauge	0
iblfQueOutUcastOverTh-res.33.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.33.8	Gauge	0
iblfQueOutUcastOverTh-res.34.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.34.1	Gauge	0
iblfQueOutUcastOverTh-res.34.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.34.2	Gauge	0
iblfQueOutUcastOverTh-res.34.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.34.3	Gauge	0
iblfQueOutUcastOverTh-res.34.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.34.4	Gauge	0
iblfQueOutUcastOverTh-res.34.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.34.5	Gauge	0
iblfQueOutUcastOverTh-res.34.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.34.6	Gauge	0
iblfQueOutUcastOverTh-res.34.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.34.7	Gauge	0
iblfQueOutUcastOverTh-res.34.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.34.8	Gauge	0
iblfQueOutUcastOverTh-res.35.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.35.1	Gauge	0
iblfQueOutUcastOverTh-res.35.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.35.2	Gauge	0
iblfQueOutUcastOverTh-res.35.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.35.3	Gauge	0
iblfQueOutUcastOverTh-res.35.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.35.4	Gauge	0
iblfQueOutUcastOverTh-res.35.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.35.5	Gauge	0
iblfQueOutUcastOverTh-res.35.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.35.6	Gauge	0
iblfQueOutUcastOverTh-res.35.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.35.7	Gauge	0
iblfQueOutUcastOverTh-res.35.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.35.8	Gauge	0
iblfQueOutUcastOverTh-res.36.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.36.1	Gauge	0
iblfQueOutUcastOverTh-res.36.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.36.2	Gauge	0
iblfQueOutUcastOverTh-res.36.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.36.3	Gauge	0
iblfQueOutUcastOverTh-res.36.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.36.4	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastOverTh-res.36.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.36.5	Gauge	0
iblfQueOutUcastOverTh-res.36.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.36.6	Gauge	0
iblfQueOutUcastOverTh-res.36.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.36.7	Gauge	0
iblfQueOutUcastOverTh-res.36.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.36.8	Gauge	0
iblfQueOutUcastOverTh-res.37.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.37.1	Gauge	0
iblfQueOutUcastOverTh-res.37.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.37.2	Gauge	0
iblfQueOutUcastOverTh-res.37.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.37.3	Gauge	0
iblfQueOutUcastOverTh-res.37.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.37.4	Gauge	0
iblfQueOutUcastOverTh-res.37.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.37.5	Gauge	0
iblfQueOutUcastOverTh-res.37.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.37.6	Gauge	0
iblfQueOutUcastOverTh-res.37.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.37.7	Gauge	0
iblfQueOutUcastOverTh-res.37.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.37.8	Gauge	0
iblfQueOutUcastOverTh-res.38.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.38.1	Gauge	0
iblfQueOutUcastOverTh-res.38.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.38.2	Gauge	0
iblfQueOutUcastOverTh-res.38.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.38.3	Gauge	0
iblfQueOutUcastOverTh-res.38.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.38.4	Gauge	0
iblfQueOutUcastOverTh-res.38.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.38.5	Gauge	0
iblfQueOutUcastOverTh-res.38.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.38.6	Gauge	0
iblfQueOutUcastOverTh-res.38.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.38.7	Gauge	0
iblfQueOutUcastOverTh-res.38.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.38.8	Gauge	0
iblfQueOutUcastOverTh-res.39.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.39.1	Gauge	0
iblfQueOutUcastOverTh-res.39.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.39.2	Gauge	0
iblfQueOutUcastOverTh-res.39.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.39.3	Gauge	0
iblfQueOutUcastOverTh-res.39.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.39.4	Gauge	0
iblfQueOutUcastOverTh-res.39.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.39.5	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastOverTh-res.39.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.39.6	Gauge	0
iblfQueOutUcastOverTh-res.39.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.39.7	Gauge	0
iblfQueOutUcastOverTh-res.39.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.39.8	Gauge	0
iblfQueOutUcastOverTh-res.40.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.40.1	Gauge	0
iblfQueOutUcastOverTh-res.40.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.40.2	Gauge	0
iblfQueOutUcastOverTh-res.40.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.40.3	Gauge	0
iblfQueOutUcastOverTh-res.40.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.40.4	Gauge	0
iblfQueOutUcastOverTh-res.40.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.40.5	Gauge	0
iblfQueOutUcastOverTh-res.40.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.40.6	Gauge	0
iblfQueOutUcastOverTh-res.40.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.40.7	Gauge	0
iblfQueOutUcastOverTh-res.40.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.40.8	Gauge	0
iblfQueOutUcastOverTh-res.41.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.41.1	Gauge	0
iblfQueOutUcastOverTh-res.41.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.41.2	Gauge	0
iblfQueOutUcastOverTh-res.41.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.41.3	Gauge	0
iblfQueOutUcastOverTh-res.41.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.41.4	Gauge	0
iblfQueOutUcastOverTh-res.41.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.41.5	Gauge	0
iblfQueOutUcastOverTh-res.41.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.41.6	Gauge	0
iblfQueOutUcastOverTh-res.41.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.41.7	Gauge	0
iblfQueOutUcastOverTh-res.41.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.41.8	Gauge	0
iblfQueOutUcastOverTh-res.42.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.42.1	Gauge	0
iblfQueOutUcastOverTh-res.42.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.42.2	Gauge	0
iblfQueOutUcastOverTh-res.42.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.42.3	Gauge	0
iblfQueOutUcastOverTh-res.42.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.42.4	Gauge	0
iblfQueOutUcastOverTh-res.42.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.42.5	Gauge	0
iblfQueOutUcastOverTh-res.42.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.42.6	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastOverTh-res.42.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.42.7	Gauge	0
iblfQueOutUcastOverTh-res.42.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.42.8	Gauge	0
iblfQueOutUcastOverTh-res.43.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.43.1	Gauge	0
iblfQueOutUcastOverTh-res.43.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.43.2	Gauge	0
iblfQueOutUcastOverTh-res.43.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.43.3	Gauge	0
iblfQueOutUcastOverTh-res.43.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.43.4	Gauge	0
iblfQueOutUcastOverTh-res.43.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.43.5	Gauge	0
iblfQueOutUcastOverTh-res.43.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.43.6	Gauge	0
iblfQueOutUcastOverTh-res.43.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.43.7	Gauge	0
iblfQueOutUcastOverTh-res.43.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.43.8	Gauge	0
iblfQueOutUcastOverTh-res.44.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.44.1	Gauge	0
iblfQueOutUcastOverTh-res.44.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.44.2	Gauge	0
iblfQueOutUcastOverTh-res.44.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.44.3	Gauge	0
iblfQueOutUcastOverTh-res.44.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.44.4	Gauge	0
iblfQueOutUcastOverTh-res.44.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.44.5	Gauge	0
iblfQueOutUcastOverTh-res.44.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.44.6	Gauge	0
iblfQueOutUcastOverTh-res.44.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.44.7	Gauge	0
iblfQueOutUcastOverTh-res.44.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.44.8	Gauge	0
iblfQueOutUcastOverTh-res.45.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.45.1	Gauge	0
iblfQueOutUcastOverTh-res.45.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.45.2	Gauge	0
iblfQueOutUcastOverTh-res.45.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.45.3	Gauge	0
iblfQueOutUcastOverTh-res.45.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.45.4	Gauge	0
iblfQueOutUcastOverTh-res.45.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.45.5	Gauge	0
iblfQueOutUcastOverTh-res.45.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.45.6	Gauge	0
iblfQueOutUcastOverTh-res.45.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.45.7	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastOverTh-res.45.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.45.8	Gauge	0
iblfQueOutUcastOverTh-res.46.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.46.1	Gauge	0
iblfQueOutUcastOverTh-res.46.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.46.2	Gauge	0
iblfQueOutUcastOverTh-res.46.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.46.3	Gauge	0
iblfQueOutUcastOverTh-res.46.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.46.4	Gauge	0
iblfQueOutUcastOverTh-res.46.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.46.5	Gauge	0
iblfQueOutUcastOverTh-res.46.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.46.6	Gauge	0
iblfQueOutUcastOverTh-res.46.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.46.7	Gauge	0
iblfQueOutUcastOverTh-res.46.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.46.8	Gauge	0
iblfQueOutUcastOverTh-res.47.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.47.1	Gauge	0
iblfQueOutUcastOverTh-res.47.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.47.2	Gauge	0
iblfQueOutUcastOverTh-res.47.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.47.3	Gauge	0
iblfQueOutUcastOverTh-res.47.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.47.4	Gauge	0
iblfQueOutUcastOverTh-res.47.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.47.5	Gauge	0
iblfQueOutUcastOverTh-res.47.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.47.6	Gauge	0
iblfQueOutUcastOverTh-res.47.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.47.7	Gauge	0
iblfQueOutUcastOverTh-res.47.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.47.8	Gauge	0
iblfQueOutUcastOverTh-res.48.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.48.1	Gauge	0
iblfQueOutUcastOverTh-res.48.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.48.2	Gauge	0
iblfQueOutUcastOverTh-res.48.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.48.3	Gauge	0
iblfQueOutUcastOverTh-res.48.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.48.4	Gauge	0
iblfQueOutUcastOverTh-res.48.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.48.5	Gauge	0
iblfQueOutUcastOverTh-res.48.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.48.6	Gauge	0
iblfQueOutUcastOverTh-res.48.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.48.7	Gauge	0
iblfQueOutUcastOverTh-res.48.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.48.8	Gauge	0



Name	OID	Value Type	Value Example
iblfQueOutUcastOverTh-res.49.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.49.1	Gauge	0
iblfQueOutUcastOverTh-res.49.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.49.2	Gauge	0
iblfQueOutUcastOverTh-res.49.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.49.3	Gauge	0
iblfQueOutUcastOverTh-res.49.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.49.4	Gauge	0
iblfQueOutUcastOverTh-res.49.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.49.5	Gauge	0
iblfQueOutUcastOverTh-res.49.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.49.6	Gauge	0
iblfQueOutUcastOverTh-res.49.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.49.7	Gauge	0
iblfQueOutUcastOverTh-res.49.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.49.8	Gauge	0
iblfQueOutUcastOverTh-res.50.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.50.1	Gauge	0
iblfQueOutUcastOverTh-res.50.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.50.2	Gauge	0
iblfQueOutUcastOverTh-res.50.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.50.3	Gauge	0
iblfQueOutUcastOverTh-res.50.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.50.4	Gauge	0
iblfQueOutUcastOverTh-res.50.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.50.5	Gauge	0
iblfQueOutUcastOverTh-res.50.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.50.6	Gauge	0
iblfQueOutUcastOverTh-res.50.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.50.7	Gauge	0
iblfQueOutUcastOverTh-res.50.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.50.8	Gauge	0
iblfQueOutUcastOverTh-res.51.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.51.1	Gauge	0
iblfQueOutUcastOverTh-res.51.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.51.2	Gauge	0
iblfQueOutUcastOverTh-res.51.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.51.3	Gauge	0
iblfQueOutUcastOverTh-res.51.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.51.4	Gauge	0
iblfQueOutUcastOverTh-res.51.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.51.5	Gauge	0
iblfQueOutUcastOverTh-res.51.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.51.6	Gauge	0
iblfQueOutUcastOverTh-res.51.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.51.7	Gauge	0
iblfQueOutUcastOverTh-res.51.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.51.8	Gauge	0
iblfQueOutUcastOverTh-res.52.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.7.52.1	Gauge	0

Name	OID	Value Type	Value Example
iblfQueOutUcastOverTh-res.52.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.52.2	Gauge	0
iblfQueOutUcastOverTh-res.52.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.52.3	Gauge	0
iblfQueOutUcastOverTh-res.52.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.52.4	Gauge	0
iblfQueOutUcastOverTh-res.52.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.52.5	Gauge	0
iblfQueOutUcastOverTh-res.52.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.52.6	Gauge	0
iblfQueOutUcastOverTh-res.52.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.52.7	Gauge	0
iblfQueOutUcastOverTh-res.52.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.52.8	Gauge	0
iblfQueOutUcastOverTh-res.53.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.53.1	Gauge	0
iblfQueOutUcastOverTh-res.53.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.53.2	Gauge	0
iblfQueOutUcastOverTh-res.53.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.53.3	Gauge	0
iblfQueOutUcastOverTh-res.53.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.53.4	Gauge	0
iblfQueOutUcastOverTh-res.53.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.53.5	Gauge	0
iblfQueOutUcastOverTh-res.53.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.53.6	Gauge	0
iblfQueOutUcastOverTh-res.53.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.53.7	Gauge	0
iblfQueOutUcastOverTh-res.53.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.53.8	Gauge	0
iblfQueOutUcastOverTh-res.54.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.54.1	Gauge	0
iblfQueOutUcastOverTh-res.54.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.54.2	Gauge	0
iblfQueOutUcastOverTh-res.54.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.54.3	Gauge	0
iblfQueOutUcastOverTh-res.54.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.54.4	Gauge	0
iblfQueOutUcastOverTh-res.54.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.54.5	Gauge	0
iblfQueOutUcastOverTh-res.54.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.54.6	Gauge	0
iblfQueOutUcastOverTh-res.54.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.54.7	Gauge	0
iblfQueOutUcastOverTh-res.54.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.7.54.8	Gauge	0
iblfQueInTotal.1.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.1.1	Gauge	0
iblfQueInTotal.1.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.1.2	Gauge	0
iblfQueInTotal.1.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.1.3	Gauge	0
iblfQueInTotal.1.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.1.4	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnTotal.1.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.1.5	Gauge	0
iblfQuelnTotal.1.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.1.6	Gauge	0
iblfQuelnTotal.1.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.1.7	Gauge	0
iblfQuelnTotal.1.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.1.8	Gauge	0
iblfQuelnTotal.2.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.2.1	Gauge	0
iblfQuelnTotal.2.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.2.2	Gauge	0
iblfQuelnTotal.2.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.2.3	Gauge	0
iblfQuelnTotal.2.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.2.4	Gauge	0
iblfQuelnTotal.2.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.2.5	Gauge	0
iblfQuelnTotal.2.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.2.6	Gauge	0
iblfQuelnTotal.2.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.2.7	Gauge	0
iblfQuelnTotal.2.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.2.8	Gauge	0
iblfQuelnTotal.3.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.3.1	Gauge	0
iblfQuelnTotal.3.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.3.2	Gauge	0
iblfQuelnTotal.3.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.3.3	Gauge	0
iblfQuelnTotal.3.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.3.4	Gauge	0
iblfQuelnTotal.3.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.3.5	Gauge	0
iblfQuelnTotal.3.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.3.6	Gauge	0
iblfQuelnTotal.3.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.3.7	Gauge	0
iblfQuelnTotal.3.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.3.8	Gauge	0
iblfQuelnTotal.4.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.4.1	Gauge	0
iblfQuelnTotal.4.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.4.2	Gauge	0
iblfQuelnTotal.4.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.4.3	Gauge	0
iblfQuelnTotal.4.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.4.4	Gauge	0
iblfQuelnTotal.4.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.4.5	Gauge	0
iblfQuelnTotal.4.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.4.6	Gauge	0
iblfQuelnTotal.4.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.4.7	Gauge	0
iblfQuelnTotal.4.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.4.8	Gauge	0
iblfQuelnTotal.5.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.5.1	Gauge	0
iblfQuelnTotal.5.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.5.2	Gauge	0
iblfQuelnTotal.5.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.5.3	Gauge	0
iblfQuelnTotal.5.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.5.4	Gauge	0
iblfQuelnTotal.5.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.5.5	Gauge	0
iblfQuelnTotal.5.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.5.6	Gauge	0
iblfQuelnTotal.5.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.5.7	Gauge	0
iblfQuelnTotal.5.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.5.8	Gauge	0
iblfQuelnTotal.6.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.6.1	Gauge	0
iblfQuelnTotal.6.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.6.2	Gauge	0
iblfQuelnTotal.6.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.6.3	Gauge	0
iblfQuelnTotal.6.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.6.4	Gauge	0
iblfQuelnTotal.6.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.6.5	Gauge	0
iblfQuelnTotal.6.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.6.6	Gauge	0
iblfQuelnTotal.6.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.6.7	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnTotal.6.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.6.8	Gauge	0
iblfQuelnTotal.7.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.7.1	Gauge	0
iblfQuelnTotal.7.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.7.2	Gauge	0
iblfQuelnTotal.7.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.7.3	Gauge	0
iblfQuelnTotal.7.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.7.4	Gauge	0
iblfQuelnTotal.7.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.7.5	Gauge	0
iblfQuelnTotal.7.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.7.6	Gauge	0
iblfQuelnTotal.7.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.7.7	Gauge	0
iblfQuelnTotal.7.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.7.8	Gauge	0
iblfQuelnTotal.8.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.8.1	Gauge	0
iblfQuelnTotal.8.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.8.2	Gauge	0
iblfQuelnTotal.8.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.8.3	Gauge	0
iblfQuelnTotal.8.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.8.4	Gauge	0
iblfQuelnTotal.8.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.8.5	Gauge	0
iblfQuelnTotal.8.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.8.6	Gauge	0
iblfQuelnTotal.8.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.8.7	Gauge	0
iblfQuelnTotal.8.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.8.8	Gauge	0
iblfQuelnTotal.9.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.9.1	Gauge	0
iblfQuelnTotal.9.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.9.2	Gauge	0
iblfQuelnTotal.9.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.9.3	Gauge	0
iblfQuelnTotal.9.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.9.4	Gauge	0
iblfQuelnTotal.9.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.9.5	Gauge	0
iblfQuelnTotal.9.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.9.6	Gauge	0
iblfQuelnTotal.9.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.9.7	Gauge	0
iblfQuelnTotal.9.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.9.8	Gauge	0
iblfQuelnTotal.10.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.10.1	Gauge	0
iblfQuelnTotal.10.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.10.2	Gauge	0
iblfQuelnTotal.10.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.10.3	Gauge	0
iblfQuelnTotal.10.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.10.4	Gauge	0
iblfQuelnTotal.10.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.10.5	Gauge	0
iblfQuelnTotal.10.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.10.6	Gauge	0
iblfQuelnTotal.10.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.10.7	Gauge	0
iblfQuelnTotal.10.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.10.8	Gauge	0
iblfQuelnTotal.11.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.11.1	Gauge	0
iblfQuelnTotal.11.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.11.2	Gauge	0
iblfQuelnTotal.11.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.11.3	Gauge	0
iblfQuelnTotal.11.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.11.4	Gauge	0
iblfQuelnTotal.11.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.11.5	Gauge	0
iblfQuelnTotal.11.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.11.6	Gauge	0
iblfQuelnTotal.11.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.11.7	Gauge	0
iblfQuelnTotal.11.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.11.8	Gauge	0
iblfQuelnTotal.12.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.12.1	Gauge	0
iblfQuelnTotal.12.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.8.12.2	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnTotal.12.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.12.3	Gauge	0
iblfQuelnTotal.12.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.12.4	Gauge	0
iblfQuelnTotal.12.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.12.5	Gauge	0
iblfQuelnTotal.12.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.12.6	Gauge	0
iblfQuelnTotal.12.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.12.7	Gauge	0
iblfQuelnTotal.12.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.12.8	Gauge	0
iblfQuelnTotal.13.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.13.1	Gauge	0
iblfQuelnTotal.13.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.13.2	Gauge	0
iblfQuelnTotal.13.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.13.3	Gauge	0
iblfQuelnTotal.13.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.13.4	Gauge	0
iblfQuelnTotal.13.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.13.5	Gauge	0
iblfQuelnTotal.13.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.13.6	Gauge	0
iblfQuelnTotal.13.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.13.7	Gauge	0
iblfQuelnTotal.13.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.13.8	Gauge	0
iblfQuelnTotal.14.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.14.1	Gauge	0
iblfQuelnTotal.14.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.14.2	Gauge	0
iblfQuelnTotal.14.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.14.3	Gauge	0
iblfQuelnTotal.14.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.14.4	Gauge	0
iblfQuelnTotal.14.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.14.5	Gauge	0
iblfQuelnTotal.14.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.14.6	Gauge	0
iblfQuelnTotal.14.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.14.7	Gauge	0
iblfQuelnTotal.14.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.14.8	Gauge	0
iblfQuelnTotal.15.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.15.1	Gauge	0
iblfQuelnTotal.15.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.15.2	Gauge	0
iblfQuelnTotal.15.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.15.3	Gauge	0
iblfQuelnTotal.15.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.15.4	Gauge	0
iblfQuelnTotal.15.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.15.5	Gauge	0
iblfQuelnTotal.15.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.15.6	Gauge	0
iblfQuelnTotal.15.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.15.7	Gauge	0
iblfQuelnTotal.15.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.15.8	Gauge	0
iblfQuelnTotal.16.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.16.1	Gauge	0
iblfQuelnTotal.16.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.16.2	Gauge	0
iblfQuelnTotal.16.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.16.3	Gauge	0
iblfQuelnTotal.16.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.16.4	Gauge	0
iblfQuelnTotal.16.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.16.5	Gauge	0
iblfQuelnTotal.16.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.16.6	Gauge	0
iblfQuelnTotal.16.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.16.7	Gauge	0
iblfQuelnTotal.16.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.16.8	Gauge	0
iblfQuelnTotal.17.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.17.1	Gauge	0
iblfQuelnTotal.17.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.17.2	Gauge	0
iblfQuelnTotal.17.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.17.3	Gauge	0
iblfQuelnTotal.17.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.17.4	Gauge	0
iblfQuelnTotal.17.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.17.5	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnTotal.17.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.17.6	Gauge	0
iblfQuelnTotal.17.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.17.7	Gauge	0
iblfQuelnTotal.17.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.17.8	Gauge	0
iblfQuelnTotal.18.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.18.1	Gauge	0
iblfQuelnTotal.18.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.18.2	Gauge	0
iblfQuelnTotal.18.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.18.3	Gauge	0
iblfQuelnTotal.18.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.18.4	Gauge	0
iblfQuelnTotal.18.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.18.5	Gauge	0
iblfQuelnTotal.18.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.18.6	Gauge	0
iblfQuelnTotal.18.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.18.7	Gauge	0
iblfQuelnTotal.18.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.18.8	Gauge	0
iblfQuelnTotal.19.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.19.1	Gauge	0
iblfQuelnTotal.19.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.19.2	Gauge	0
iblfQuelnTotal.19.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.19.3	Gauge	0
iblfQuelnTotal.19.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.19.4	Gauge	0
iblfQuelnTotal.19.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.19.5	Gauge	0
iblfQuelnTotal.19.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.19.6	Gauge	0
iblfQuelnTotal.19.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.19.7	Gauge	0
iblfQuelnTotal.19.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.19.8	Gauge	0
iblfQuelnTotal.20.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.20.1	Gauge	0
iblfQuelnTotal.20.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.20.2	Gauge	0
iblfQuelnTotal.20.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.20.3	Gauge	0
iblfQuelnTotal.20.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.20.4	Gauge	0
iblfQuelnTotal.20.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.20.5	Gauge	0
iblfQuelnTotal.20.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.20.6	Gauge	0
iblfQuelnTotal.20.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.20.7	Gauge	0
iblfQuelnTotal.20.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.20.8	Gauge	0
iblfQuelnTotal.21.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.21.1	Gauge	0
iblfQuelnTotal.21.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.21.2	Gauge	0
iblfQuelnTotal.21.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.21.3	Gauge	0
iblfQuelnTotal.21.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.21.4	Gauge	0
iblfQuelnTotal.21.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.21.5	Gauge	0
iblfQuelnTotal.21.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.21.6	Gauge	0
iblfQuelnTotal.21.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.21.7	Gauge	0
iblfQuelnTotal.21.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.21.8	Gauge	0
iblfQuelnTotal.22.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.22.1	Gauge	0
iblfQuelnTotal.22.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.22.2	Gauge	0
iblfQuelnTotal.22.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.22.3	Gauge	0
iblfQuelnTotal.22.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.22.4	Gauge	0
iblfQuelnTotal.22.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.22.5	Gauge	0
iblfQuelnTotal.22.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.22.6	Gauge	0
iblfQuelnTotal.22.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.22.7	Gauge	0
iblfQuelnTotal.22.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.22.8	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnTotal.23.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.23.1	Gauge	0
iblfQuelnTotal.23.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.23.2	Gauge	0
iblfQuelnTotal.23.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.23.3	Gauge	0
iblfQuelnTotal.23.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.23.4	Gauge	0
iblfQuelnTotal.23.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.23.5	Gauge	0
iblfQuelnTotal.23.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.23.6	Gauge	0
iblfQuelnTotal.23.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.23.7	Gauge	0
iblfQuelnTotal.23.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.23.8	Gauge	0
iblfQuelnTotal.24.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.24.1	Gauge	0
iblfQuelnTotal.24.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.24.2	Gauge	0
iblfQuelnTotal.24.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.24.3	Gauge	0
iblfQuelnTotal.24.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.24.4	Gauge	0
iblfQuelnTotal.24.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.24.5	Gauge	0
iblfQuelnTotal.24.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.24.6	Gauge	0
iblfQuelnTotal.24.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.24.7	Gauge	0
iblfQuelnTotal.24.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.24.8	Gauge	0
iblfQuelnTotal.25.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.25.1	Gauge	0
iblfQuelnTotal.25.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.25.2	Gauge	0
iblfQuelnTotal.25.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.25.3	Gauge	0
iblfQuelnTotal.25.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.25.4	Gauge	0
iblfQuelnTotal.25.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.25.5	Gauge	0
iblfQuelnTotal.25.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.25.6	Gauge	0
iblfQuelnTotal.25.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.25.7	Gauge	0
iblfQuelnTotal.25.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.25.8	Gauge	0
iblfQuelnTotal.26.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.26.1	Gauge	0
iblfQuelnTotal.26.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.26.2	Gauge	0
iblfQuelnTotal.26.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.26.3	Gauge	0
iblfQuelnTotal.26.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.26.4	Gauge	0
iblfQuelnTotal.26.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.26.5	Gauge	0
iblfQuelnTotal.26.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.26.6	Gauge	0
iblfQuelnTotal.26.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.26.7	Gauge	0
iblfQuelnTotal.26.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.26.8	Gauge	0
iblfQuelnTotal.27.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.27.1	Gauge	0
iblfQuelnTotal.27.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.27.2	Gauge	0
iblfQuelnTotal.27.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.27.3	Gauge	0
iblfQuelnTotal.27.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.27.4	Gauge	0
iblfQuelnTotal.27.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.27.5	Gauge	0
iblfQuelnTotal.27.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.27.6	Gauge	0
iblfQuelnTotal.27.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.27.7	Gauge	0
iblfQuelnTotal.27.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.27.8	Gauge	0
iblfQuelnTotal.28.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.28.1	Gauge	0
iblfQuelnTotal.28.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.28.2	Gauge	0
iblfQuelnTotal.28.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.28.3	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnTotal.28.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.28.4	Gauge	0
iblfQuelnTotal.28.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.28.5	Gauge	0
iblfQuelnTotal.28.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.28.6	Gauge	0
iblfQuelnTotal.28.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.28.7	Gauge	0
iblfQuelnTotal.28.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.28.8	Gauge	0
iblfQuelnTotal.29.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.29.1	Gauge	0
iblfQuelnTotal.29.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.29.2	Gauge	0
iblfQuelnTotal.29.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.29.3	Gauge	0
iblfQuelnTotal.29.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.29.4	Gauge	0
iblfQuelnTotal.29.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.29.5	Gauge	0
iblfQuelnTotal.29.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.29.6	Gauge	0
iblfQuelnTotal.29.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.29.7	Gauge	0
iblfQuelnTotal.29.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.29.8	Gauge	0
iblfQuelnTotal.30.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.30.1	Gauge	0
iblfQuelnTotal.30.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.30.2	Gauge	0
iblfQuelnTotal.30.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.30.3	Gauge	0
iblfQuelnTotal.30.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.30.4	Gauge	0
iblfQuelnTotal.30.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.30.5	Gauge	0
iblfQuelnTotal.30.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.30.6	Gauge	0
iblfQuelnTotal.30.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.30.7	Gauge	0
iblfQuelnTotal.30.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.30.8	Gauge	0
iblfQuelnTotal.31.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.31.1	Gauge	0
iblfQuelnTotal.31.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.31.2	Gauge	0
iblfQuelnTotal.31.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.31.3	Gauge	0
iblfQuelnTotal.31.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.31.4	Gauge	0
iblfQuelnTotal.31.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.31.5	Gauge	0
iblfQuelnTotal.31.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.31.6	Gauge	0
iblfQuelnTotal.31.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.31.7	Gauge	0
iblfQuelnTotal.31.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.31.8	Gauge	0
iblfQuelnTotal.32.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.32.1	Gauge	0
iblfQuelnTotal.32.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.32.2	Gauge	0
iblfQuelnTotal.32.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.32.3	Gauge	0
iblfQuelnTotal.32.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.32.4	Gauge	0
iblfQuelnTotal.32.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.32.5	Gauge	0
iblfQuelnTotal.32.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.32.6	Gauge	0
iblfQuelnTotal.32.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.32.7	Gauge	0
iblfQuelnTotal.32.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.32.8	Gauge	0
iblfQuelnTotal.33.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.33.1	Gauge	0
iblfQuelnTotal.33.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.33.2	Gauge	0
iblfQuelnTotal.33.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.33.3	Gauge	0
iblfQuelnTotal.33.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.33.4	Gauge	0
iblfQuelnTotal.33.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.33.5	Gauge	0
iblfQuelnTotal.33.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.33.6	Gauge	0



Name	OID	Value Type	Value Example
iblfQuelnTotal.33.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.33.7	Gauge	0
iblfQuelnTotal.33.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.33.8	Gauge	0
iblfQuelnTotal.34.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.34.1	Gauge	0
iblfQuelnTotal.34.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.34.2	Gauge	0
iblfQuelnTotal.34.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.34.3	Gauge	0
iblfQuelnTotal.34.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.34.4	Gauge	0
iblfQuelnTotal.34.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.34.5	Gauge	0
iblfQuelnTotal.34.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.34.6	Gauge	0
iblfQuelnTotal.34.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.34.7	Gauge	0
iblfQuelnTotal.34.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.34.8	Gauge	0
iblfQuelnTotal.35.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.35.1	Gauge	0
iblfQuelnTotal.35.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.35.2	Gauge	0
iblfQuelnTotal.35.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.35.3	Gauge	0
iblfQuelnTotal.35.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.35.4	Gauge	0
iblfQuelnTotal.35.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.35.5	Gauge	0
iblfQuelnTotal.35.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.35.6	Gauge	0
iblfQuelnTotal.35.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.35.7	Gauge	0
iblfQuelnTotal.35.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.35.8	Gauge	0
iblfQuelnTotal.36.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.36.1	Gauge	0
iblfQuelnTotal.36.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.36.2	Gauge	0
iblfQuelnTotal.36.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.36.3	Gauge	0
iblfQuelnTotal.36.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.36.4	Gauge	0
iblfQuelnTotal.36.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.36.5	Gauge	0
iblfQuelnTotal.36.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.36.6	Gauge	0
iblfQuelnTotal.36.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.36.7	Gauge	0
iblfQuelnTotal.36.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.36.8	Gauge	0
iblfQuelnTotal.37.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.37.1	Gauge	0
iblfQuelnTotal.37.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.37.2	Gauge	0
iblfQuelnTotal.37.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.37.3	Gauge	0
iblfQuelnTotal.37.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.37.4	Gauge	0
iblfQuelnTotal.37.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.37.5	Gauge	0
iblfQuelnTotal.37.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.37.6	Gauge	0
iblfQuelnTotal.37.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.37.7	Gauge	0
iblfQuelnTotal.37.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.37.8	Gauge	0
iblfQuelnTotal.38.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.38.1	Gauge	0
iblfQuelnTotal.38.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.38.2	Gauge	0
iblfQuelnTotal.38.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.38.3	Gauge	0
iblfQuelnTotal.38.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.38.4	Gauge	0
iblfQuelnTotal.38.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.38.5	Gauge	0
iblfQuelnTotal.38.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.38.6	Gauge	0
iblfQuelnTotal.38.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.38.7	Gauge	0
iblfQuelnTotal.38.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.38.8	Gauge	0
iblfQuelnTotal.39.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.39.1	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnTotal.39.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.39.2	Gauge	0
iblfQuelnTotal.39.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.39.3	Gauge	0
iblfQuelnTotal.39.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.39.4	Gauge	0
iblfQuelnTotal.39.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.39.5	Gauge	0
iblfQuelnTotal.39.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.39.6	Gauge	0
iblfQuelnTotal.39.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.39.7	Gauge	0
iblfQuelnTotal.39.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.39.8	Gauge	0
iblfQuelnTotal.40.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.40.1	Gauge	0
iblfQuelnTotal.40.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.40.2	Gauge	0
iblfQuelnTotal.40.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.40.3	Gauge	0
iblfQuelnTotal.40.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.40.4	Gauge	0
iblfQuelnTotal.40.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.40.5	Gauge	0
iblfQuelnTotal.40.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.40.6	Gauge	0
iblfQuelnTotal.40.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.40.7	Gauge	0
iblfQuelnTotal.40.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.40.8	Gauge	0
iblfQuelnTotal.41.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.41.1	Gauge	0
iblfQuelnTotal.41.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.41.2	Gauge	0
iblfQuelnTotal.41.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.41.3	Gauge	0
iblfQuelnTotal.41.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.41.4	Gauge	0
iblfQuelnTotal.41.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.41.5	Gauge	0
iblfQuelnTotal.41.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.41.6	Gauge	0
iblfQuelnTotal.41.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.41.7	Gauge	0
iblfQuelnTotal.41.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.41.8	Gauge	0
iblfQuelnTotal.42.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.42.1	Gauge	0
iblfQuelnTotal.42.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.42.2	Gauge	0
iblfQuelnTotal.42.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.42.3	Gauge	0
iblfQuelnTotal.42.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.42.4	Gauge	0
iblfQuelnTotal.42.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.42.5	Gauge	0
iblfQuelnTotal.42.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.42.6	Gauge	0
iblfQuelnTotal.42.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.42.7	Gauge	0
iblfQuelnTotal.42.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.42.8	Gauge	0
iblfQuelnTotal.43.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.43.1	Gauge	0
iblfQuelnTotal.43.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.43.2	Gauge	0
iblfQuelnTotal.43.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.43.3	Gauge	0
iblfQuelnTotal.43.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.43.4	Gauge	0
iblfQuelnTotal.43.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.43.5	Gauge	0
iblfQuelnTotal.43.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.43.6	Gauge	0
iblfQuelnTotal.43.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.43.7	Gauge	0
iblfQuelnTotal.43.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.43.8	Gauge	0
iblfQuelnTotal.44.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.44.1	Gauge	0
iblfQuelnTotal.44.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.44.2	Gauge	0
iblfQuelnTotal.44.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.44.3	Gauge	0
iblfQuelnTotal.44.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.44.4	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnTotal.44.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.44.5	Gauge	0
iblfQuelnTotal.44.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.44.6	Gauge	0
iblfQuelnTotal.44.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.44.7	Gauge	0
iblfQuelnTotal.44.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.44.8	Gauge	0
iblfQuelnTotal.45.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.45.1	Gauge	0
iblfQuelnTotal.45.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.45.2	Gauge	0
iblfQuelnTotal.45.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.45.3	Gauge	0
iblfQuelnTotal.45.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.45.4	Gauge	0
iblfQuelnTotal.45.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.45.5	Gauge	0
iblfQuelnTotal.45.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.45.6	Gauge	0
iblfQuelnTotal.45.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.45.7	Gauge	0
iblfQuelnTotal.45.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.45.8	Gauge	0
iblfQuelnTotal.46.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.46.1	Gauge	0
iblfQuelnTotal.46.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.46.2	Gauge	0
iblfQuelnTotal.46.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.46.3	Gauge	0
iblfQuelnTotal.46.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.46.4	Gauge	0
iblfQuelnTotal.46.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.46.5	Gauge	0
iblfQuelnTotal.46.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.46.6	Gauge	0
iblfQuelnTotal.46.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.46.7	Gauge	0
iblfQuelnTotal.46.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.46.8	Gauge	0
iblfQuelnTotal.47.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.47.1	Gauge	0
iblfQuelnTotal.47.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.47.2	Gauge	0
iblfQuelnTotal.47.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.47.3	Gauge	0
iblfQuelnTotal.47.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.47.4	Gauge	0
iblfQuelnTotal.47.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.47.5	Gauge	0
iblfQuelnTotal.47.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.47.6	Gauge	0
iblfQuelnTotal.47.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.47.7	Gauge	0
iblfQuelnTotal.47.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.47.8	Gauge	0
iblfQuelnTotal.48.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.48.1	Gauge	0
iblfQuelnTotal.48.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.48.2	Gauge	0
iblfQuelnTotal.48.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.48.3	Gauge	0
iblfQuelnTotal.48.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.48.4	Gauge	0
iblfQuelnTotal.48.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.48.5	Gauge	0
iblfQuelnTotal.48.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.48.6	Gauge	0
iblfQuelnTotal.48.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.48.7	Gauge	0
iblfQuelnTotal.48.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.48.8	Gauge	0
iblfQuelnTotal.49.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.49.1	Gauge	0
iblfQuelnTotal.49.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.49.2	Gauge	0
iblfQuelnTotal.49.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.49.3	Gauge	0
iblfQuelnTotal.49.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.49.4	Gauge	0
iblfQuelnTotal.49.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.49.5	Gauge	0
iblfQuelnTotal.49.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.49.6	Gauge	0
iblfQuelnTotal.49.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.49.7	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnTotal.49.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.49.8	Gauge	0
iblfQuelnTotal.50.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.50.1	Gauge	0
iblfQuelnTotal.50.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.50.2	Gauge	0
iblfQuelnTotal.50.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.50.3	Gauge	0
iblfQuelnTotal.50.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.50.4	Gauge	0
iblfQuelnTotal.50.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.50.5	Gauge	0
iblfQuelnTotal.50.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.50.6	Gauge	0
iblfQuelnTotal.50.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.50.7	Gauge	0
iblfQuelnTotal.50.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.50.8	Gauge	0
iblfQuelnTotal.51.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.51.1	Gauge	0
iblfQuelnTotal.51.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.51.2	Gauge	0
iblfQuelnTotal.51.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.51.3	Gauge	0
iblfQuelnTotal.51.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.51.4	Gauge	0
iblfQuelnTotal.51.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.51.5	Gauge	0
iblfQuelnTotal.51.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.51.6	Gauge	0
iblfQuelnTotal.51.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.51.7	Gauge	0
iblfQuelnTotal.51.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.51.8	Gauge	0
iblfQuelnTotal.52.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.52.1	Gauge	0
iblfQuelnTotal.52.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.52.2	Gauge	0
iblfQuelnTotal.52.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.52.3	Gauge	0
iblfQuelnTotal.52.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.52.4	Gauge	0
iblfQuelnTotal.52.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.52.5	Gauge	0
iblfQuelnTotal.52.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.52.6	Gauge	0
iblfQuelnTotal.52.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.52.7	Gauge	0
iblfQuelnTotal.52.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.52.8	Gauge	0
iblfQuelnTotal.53.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.53.1	Gauge	0
iblfQuelnTotal.53.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.53.2	Gauge	0
iblfQuelnTotal.53.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.53.3	Gauge	0
iblfQuelnTotal.53.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.53.4	Gauge	0
iblfQuelnTotal.53.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.53.5	Gauge	0
iblfQuelnTotal.53.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.53.6	Gauge	0
iblfQuelnTotal.53.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.53.7	Gauge	0
iblfQuelnTotal.53.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.53.8	Gauge	0
iblfQuelnTotal.54.1	.3.6.1.4.1.26138.2.40.2.2.6.1.8.54.1	Gauge	0
iblfQuelnTotal.54.2	.3.6.1.4.1.26138.2.40.2.2.6.1.8.54.2	Gauge	0
iblfQuelnTotal.54.3	.3.6.1.4.1.26138.2.40.2.2.6.1.8.54.3	Gauge	0
iblfQuelnTotal.54.4	.3.6.1.4.1.26138.2.40.2.2.6.1.8.54.4	Gauge	0
iblfQuelnTotal.54.5	.3.6.1.4.1.26138.2.40.2.2.6.1.8.54.5	Gauge	0
iblfQuelnTotal.54.6	.3.6.1.4.1.26138.2.40.2.2.6.1.8.54.6	Gauge	0
iblfQuelnTotal.54.7	.3.6.1.4.1.26138.2.40.2.2.6.1.8.54.7	Gauge	0
iblfQuelnTotal.54.8	.3.6.1.4.1.26138.2.40.2.2.6.1.8.54.8	Gauge	0
iblfQuelnFree.1.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.1.1	Gauge	0
iblfQuelnFree.1.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.1.2	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnFree.1.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.1.3	Gauge	0
iblfQuelnFree.1.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.1.4	Gauge	0
iblfQuelnFree.1.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.1.5	Gauge	0
iblfQuelnFree.1.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.1.6	Gauge	0
iblfQuelnFree.1.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.1.7	Gauge	0
iblfQuelnFree.1.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.1.8	Gauge	0
iblfQuelnFree.2.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.2.1	Gauge	0
iblfQuelnFree.2.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.2.2	Gauge	0
iblfQuelnFree.2.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.2.3	Gauge	0
iblfQuelnFree.2.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.2.4	Gauge	0
iblfQuelnFree.2.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.2.5	Gauge	0
iblfQuelnFree.2.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.2.6	Gauge	0
iblfQuelnFree.2.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.2.7	Gauge	0
iblfQuelnFree.2.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.2.8	Gauge	0
iblfQuelnFree.3.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.3.1	Gauge	0
iblfQuelnFree.3.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.3.2	Gauge	0
iblfQuelnFree.3.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.3.3	Gauge	0
iblfQuelnFree.3.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.3.4	Gauge	0
iblfQuelnFree.3.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.3.5	Gauge	0
iblfQuelnFree.3.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.3.6	Gauge	0
iblfQuelnFree.3.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.3.7	Gauge	0
iblfQuelnFree.3.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.3.8	Gauge	0
iblfQuelnFree.4.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.4.1	Gauge	0
iblfQuelnFree.4.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.4.2	Gauge	0
iblfQuelnFree.4.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.4.3	Gauge	0
iblfQuelnFree.4.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.4.4	Gauge	0
iblfQuelnFree.4.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.4.5	Gauge	0
iblfQuelnFree.4.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.4.6	Gauge	0
iblfQuelnFree.4.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.4.7	Gauge	0
iblfQuelnFree.4.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.4.8	Gauge	0
iblfQuelnFree.5.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.5.1	Gauge	0
iblfQuelnFree.5.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.5.2	Gauge	0
iblfQuelnFree.5.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.5.3	Gauge	0
iblfQuelnFree.5.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.5.4	Gauge	0
iblfQuelnFree.5.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.5.5	Gauge	0
iblfQuelnFree.5.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.5.6	Gauge	0
iblfQuelnFree.5.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.5.7	Gauge	0
iblfQuelnFree.5.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.5.8	Gauge	0
iblfQuelnFree.6.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.6.1	Gauge	0
iblfQuelnFree.6.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.6.2	Gauge	0
iblfQuelnFree.6.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.6.3	Gauge	0
iblfQuelnFree.6.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.6.4	Gauge	0
iblfQuelnFree.6.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.6.5	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnFree.6.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.6.6	Gauge	0
iblfQuelnFree.6.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.6.7	Gauge	0
iblfQuelnFree.6.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.6.8	Gauge	0
iblfQuelnFree.7.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.7.1	Gauge	0
iblfQuelnFree.7.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.7.2	Gauge	0
iblfQuelnFree.7.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.7.3	Gauge	0
iblfQuelnFree.7.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.7.4	Gauge	0
iblfQuelnFree.7.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.7.5	Gauge	0
iblfQuelnFree.7.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.7.6	Gauge	0
iblfQuelnFree.7.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.7.7	Gauge	0
iblfQuelnFree.7.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.7.8	Gauge	0
iblfQuelnFree.8.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.8.1	Gauge	0
iblfQuelnFree.8.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.8.2	Gauge	0
iblfQuelnFree.8.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.8.3	Gauge	0
iblfQuelnFree.8.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.8.4	Gauge	0
iblfQuelnFree.8.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.8.5	Gauge	0
iblfQuelnFree.8.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.8.6	Gauge	0
iblfQuelnFree.8.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.8.7	Gauge	0
iblfQuelnFree.8.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.8.8	Gauge	0
iblfQuelnFree.9.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.9.1	Gauge	0
iblfQuelnFree.9.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.9.2	Gauge	0
iblfQuelnFree.9.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.9.3	Gauge	0
iblfQuelnFree.9.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.9.4	Gauge	0
iblfQuelnFree.9.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.9.5	Gauge	0
iblfQuelnFree.9.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.9.6	Gauge	0
iblfQuelnFree.9.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.9.7	Gauge	0
iblfQuelnFree.9.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.9.8	Gauge	0
iblfQuelnFree.10.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.10.1	Gauge	0
iblfQuelnFree.10.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.10.2	Gauge	0
iblfQuelnFree.10.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.10.3	Gauge	0
iblfQuelnFree.10.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.10.4	Gauge	0
iblfQuelnFree.10.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.10.5	Gauge	0
iblfQuelnFree.10.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.10.6	Gauge	0
iblfQuelnFree.10.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.10.7	Gauge	0
iblfQuelnFree.10.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.10.8	Gauge	0
iblfQuelnFree.11.1	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.11.1	Gauge	0
iblfQuelnFree.11.2	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.11.2	Gauge	0
iblfQuelnFree.11.3	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.11.3	Gauge	0
iblfQuelnFree.11.4	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.11.4	Gauge	0
iblfQuelnFree.11.5	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.11.5	Gauge	0
iblfQuelnFree.11.6	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.11.6	Gauge	0
iblfQuelnFree.11.7	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.11.7	Gauge	0
iblfQuelnFree.11.8	1.3.6.1.4.1.26138.2.40.2.2.6.1.9.11.8	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnFree.12.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.12.1	Gauge	0
iblfQuelnFree.12.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.12.2	Gauge	0
iblfQuelnFree.12.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.12.3	Gauge	0
iblfQuelnFree.12.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.12.4	Gauge	0
iblfQuelnFree.12.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.12.5	Gauge	0
iblfQuelnFree.12.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.12.6	Gauge	0
iblfQuelnFree.12.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.12.7	Gauge	0
iblfQuelnFree.12.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.12.8	Gauge	0
iblfQuelnFree.13.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.13.1	Gauge	0
iblfQuelnFree.13.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.13.2	Gauge	0
iblfQuelnFree.13.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.13.3	Gauge	0
iblfQuelnFree.13.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.13.4	Gauge	0
iblfQuelnFree.13.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.13.5	Gauge	0
iblfQuelnFree.13.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.13.6	Gauge	0
iblfQuelnFree.13.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.13.7	Gauge	0
iblfQuelnFree.13.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.13.8	Gauge	0
iblfQuelnFree.14.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.14.1	Gauge	0
iblfQuelnFree.14.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.14.2	Gauge	0
iblfQuelnFree.14.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.14.3	Gauge	0
iblfQuelnFree.14.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.14.4	Gauge	0
iblfQuelnFree.14.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.14.5	Gauge	0
iblfQuelnFree.14.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.14.6	Gauge	0
iblfQuelnFree.14.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.14.7	Gauge	0
iblfQuelnFree.14.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.14.8	Gauge	0
iblfQuelnFree.15.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.15.1	Gauge	0
iblfQuelnFree.15.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.15.2	Gauge	0
iblfQuelnFree.15.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.15.3	Gauge	0
iblfQuelnFree.15.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.15.4	Gauge	0
iblfQuelnFree.15.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.15.5	Gauge	0
iblfQuelnFree.15.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.15.6	Gauge	0
iblfQuelnFree.15.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.15.7	Gauge	0
iblfQuelnFree.15.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.15.8	Gauge	0
iblfQuelnFree.16.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.16.1	Gauge	0
iblfQuelnFree.16.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.16.2	Gauge	0
iblfQuelnFree.16.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.16.3	Gauge	0
iblfQuelnFree.16.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.16.4	Gauge	0
iblfQuelnFree.16.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.16.5	Gauge	0
iblfQuelnFree.16.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.16.6	Gauge	0
iblfQuelnFree.16.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.16.7	Gauge	0
iblfQuelnFree.16.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.16.8	Gauge	0
iblfQuelnFree.17.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.17.1	Gauge	0
iblfQuelnFree.17.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.17.2	Gauge	0
iblfQuelnFree.17.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.17.3	Gauge	0



Name	OID	Value Type	Value Example
iblfQuelnFree.17.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.17.4	Gauge	0
iblfQuelnFree.17.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.17.5	Gauge	0
iblfQuelnFree.17.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.17.6	Gauge	0
iblfQuelnFree.17.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.17.7	Gauge	0
iblfQuelnFree.17.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.17.8	Gauge	0
iblfQuelnFree.18.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.18.1	Gauge	0
iblfQuelnFree.18.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.18.2	Gauge	0
iblfQuelnFree.18.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.18.3	Gauge	0
iblfQuelnFree.18.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.18.4	Gauge	0
iblfQuelnFree.18.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.18.5	Gauge	0
iblfQuelnFree.18.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.18.6	Gauge	0
iblfQuelnFree.18.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.18.7	Gauge	0
iblfQuelnFree.18.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.18.8	Gauge	0
iblfQuelnFree.19.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.19.1	Gauge	0
iblfQuelnFree.19.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.19.2	Gauge	0
iblfQuelnFree.19.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.19.3	Gauge	0
iblfQuelnFree.19.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.19.4	Gauge	0
iblfQuelnFree.19.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.19.5	Gauge	0
iblfQuelnFree.19.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.19.6	Gauge	0
iblfQuelnFree.19.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.19.7	Gauge	0
iblfQuelnFree.19.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.19.8	Gauge	0
iblfQuelnFree.20.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.20.1	Gauge	0
iblfQuelnFree.20.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.20.2	Gauge	0
iblfQuelnFree.20.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.20.3	Gauge	0
iblfQuelnFree.20.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.20.4	Gauge	0
iblfQuelnFree.20.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.20.5	Gauge	0
iblfQuelnFree.20.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.20.6	Gauge	0
iblfQuelnFree.20.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.20.7	Gauge	0
iblfQuelnFree.20.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.20.8	Gauge	0
iblfQuelnFree.21.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.21.1	Gauge	0
iblfQuelnFree.21.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.21.2	Gauge	0
iblfQuelnFree.21.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.21.3	Gauge	0
iblfQuelnFree.21.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.21.4	Gauge	0
iblfQuelnFree.21.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.21.5	Gauge	0
iblfQuelnFree.21.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.21.6	Gauge	0
iblfQuelnFree.21.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.21.7	Gauge	0
iblfQuelnFree.21.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.21.8	Gauge	0
iblfQuelnFree.22.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.22.1	Gauge	0
iblfQuelnFree.22.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.22.2	Gauge	0
iblfQuelnFree.22.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.22.3	Gauge	0
iblfQuelnFree.22.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.22.4	Gauge	0
iblfQuelnFree.22.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.22.5	Gauge	0
iblfQuelnFree.22.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.22.6	Gauge	0



Name	OID	Value Type	Value Example
iblfQuelnFree.22.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.22.7	Gauge	0
iblfQuelnFree.22.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.22.8	Gauge	0
iblfQuelnFree.23.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.23.1	Gauge	0
iblfQuelnFree.23.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.23.2	Gauge	0
iblfQuelnFree.23.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.23.3	Gauge	0
iblfQuelnFree.23.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.23.4	Gauge	0
iblfQuelnFree.23.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.23.5	Gauge	0
iblfQuelnFree.23.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.23.6	Gauge	0
iblfQuelnFree.23.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.23.7	Gauge	0
iblfQuelnFree.23.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.23.8	Gauge	0
iblfQuelnFree.24.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.24.1	Gauge	0
iblfQuelnFree.24.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.24.2	Gauge	0
iblfQuelnFree.24.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.24.3	Gauge	0
iblfQuelnFree.24.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.24.4	Gauge	0
iblfQuelnFree.24.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.24.5	Gauge	0
iblfQuelnFree.24.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.24.6	Gauge	0
iblfQuelnFree.24.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.24.7	Gauge	0
iblfQuelnFree.24.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.24.8	Gauge	0
iblfQuelnFree.25.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.25.1	Gauge	0
iblfQuelnFree.25.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.25.2	Gauge	0
iblfQuelnFree.25.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.25.3	Gauge	0
iblfQuelnFree.25.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.25.4	Gauge	0
iblfQuelnFree.25.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.25.5	Gauge	0
iblfQuelnFree.25.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.25.6	Gauge	0
iblfQuelnFree.25.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.25.7	Gauge	0
iblfQuelnFree.25.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.25.8	Gauge	0
iblfQuelnFree.26.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.26.1	Gauge	0
iblfQuelnFree.26.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.26.2	Gauge	0
iblfQuelnFree.26.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.26.3	Gauge	0
iblfQuelnFree.26.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.26.4	Gauge	0
iblfQuelnFree.26.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.26.5	Gauge	0
iblfQuelnFree.26.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.26.6	Gauge	0
iblfQuelnFree.26.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.26.7	Gauge	0
iblfQuelnFree.26.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.26.8	Gauge	0
iblfQuelnFree.27.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.27.1	Gauge	0
iblfQuelnFree.27.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.27.2	Gauge	0
iblfQuelnFree.27.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.27.3	Gauge	0
iblfQuelnFree.27.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.27.4	Gauge	0
iblfQuelnFree.27.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.27.5	Gauge	0
iblfQuelnFree.27.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.27.6	Gauge	0
iblfQuelnFree.27.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.27.7	Gauge	0
iblfQuelnFree.27.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.27.8	Gauge	0
iblfQuelnFree.28.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.28.1	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnFree.28.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.28.2	Gauge	0
iblfQuelnFree.28.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.28.3	Gauge	0
iblfQuelnFree.28.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.28.4	Gauge	0
iblfQuelnFree.28.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.28.5	Gauge	0
iblfQuelnFree.28.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.28.6	Gauge	0
iblfQuelnFree.28.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.28.7	Gauge	0
iblfQuelnFree.28.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.28.8	Gauge	0
iblfQuelnFree.29.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.29.1	Gauge	0
iblfQuelnFree.29.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.29.2	Gauge	0
iblfQuelnFree.29.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.29.3	Gauge	0
iblfQuelnFree.29.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.29.4	Gauge	0
iblfQuelnFree.29.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.29.5	Gauge	0
iblfQuelnFree.29.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.29.6	Gauge	0
iblfQuelnFree.29.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.29.7	Gauge	0
iblfQuelnFree.29.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.29.8	Gauge	0
iblfQuelnFree.30.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.30.1	Gauge	0
iblfQuelnFree.30.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.30.2	Gauge	0
iblfQuelnFree.30.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.30.3	Gauge	0
iblfQuelnFree.30.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.30.4	Gauge	0
iblfQuelnFree.30.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.30.5	Gauge	0
iblfQuelnFree.30.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.30.6	Gauge	0
iblfQuelnFree.30.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.30.7	Gauge	0
iblfQuelnFree.30.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.30.8	Gauge	0
iblfQuelnFree.31.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.31.1	Gauge	0
iblfQuelnFree.31.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.31.2	Gauge	0
iblfQuelnFree.31.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.31.3	Gauge	0
iblfQuelnFree.31.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.31.4	Gauge	0
iblfQuelnFree.31.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.31.5	Gauge	0
iblfQuelnFree.31.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.31.6	Gauge	0
iblfQuelnFree.31.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.31.7	Gauge	0
iblfQuelnFree.31.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.31.8	Gauge	0
iblfQuelnFree.32.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.32.1	Gauge	0
iblfQuelnFree.32.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.32.2	Gauge	0
iblfQuelnFree.32.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.32.3	Gauge	0
iblfQuelnFree.32.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.32.4	Gauge	0
iblfQuelnFree.32.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.32.5	Gauge	0
iblfQuelnFree.32.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.32.6	Gauge	0
iblfQuelnFree.32.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.32.7	Gauge	0
iblfQuelnFree.32.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.32.8	Gauge	0
iblfQuelnFree.33.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.33.1	Gauge	0
iblfQuelnFree.33.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.33.2	Gauge	0
iblfQuelnFree.33.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.33.3	Gauge	0
iblfQuelnFree.33.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.33.4	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnFree.33.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.33.5	Gauge	0
iblfQuelnFree.33.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.33.6	Gauge	0
iblfQuelnFree.33.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.33.7	Gauge	0
iblfQuelnFree.33.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.33.8	Gauge	0
iblfQuelnFree.34.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.34.1	Gauge	0
iblfQuelnFree.34.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.34.2	Gauge	0
iblfQuelnFree.34.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.34.3	Gauge	0
iblfQuelnFree.34.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.34.4	Gauge	0
iblfQuelnFree.34.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.34.5	Gauge	0
iblfQuelnFree.34.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.34.6	Gauge	0
iblfQuelnFree.34.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.34.7	Gauge	0
iblfQuelnFree.34.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.34.8	Gauge	0
iblfQuelnFree.35.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.35.1	Gauge	0
iblfQuelnFree.35.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.35.2	Gauge	0
iblfQuelnFree.35.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.35.3	Gauge	0
iblfQuelnFree.35.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.35.4	Gauge	0
iblfQuelnFree.35.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.35.5	Gauge	0
iblfQuelnFree.35.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.35.6	Gauge	0
iblfQuelnFree.35.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.35.7	Gauge	0
iblfQuelnFree.35.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.35.8	Gauge	0
iblfQuelnFree.36.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.36.1	Gauge	0
iblfQuelnFree.36.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.36.2	Gauge	0
iblfQuelnFree.36.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.36.3	Gauge	0
iblfQuelnFree.36.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.36.4	Gauge	0
iblfQuelnFree.36.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.36.5	Gauge	0
iblfQuelnFree.36.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.36.6	Gauge	0
iblfQuelnFree.36.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.36.7	Gauge	0
iblfQuelnFree.36.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.36.8	Gauge	0
iblfQuelnFree.37.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.37.1	Gauge	0
iblfQuelnFree.37.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.37.2	Gauge	0
iblfQuelnFree.37.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.37.3	Gauge	0
iblfQuelnFree.37.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.37.4	Gauge	0
iblfQuelnFree.37.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.37.5	Gauge	0
iblfQuelnFree.37.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.37.6	Gauge	0
iblfQuelnFree.37.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.37.7	Gauge	0
iblfQuelnFree.37.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.37.8	Gauge	0
iblfQuelnFree.38.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.38.1	Gauge	0
iblfQuelnFree.38.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.38.2	Gauge	0
iblfQuelnFree.38.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.38.3	Gauge	0
iblfQuelnFree.38.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.38.4	Gauge	0
iblfQuelnFree.38.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.38.5	Gauge	0
iblfQuelnFree.38.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.38.6	Gauge	0
iblfQuelnFree.38.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.38.7	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnFree.38.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.38.8	Gauge	0
iblfQuelnFree.39.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.39.1	Gauge	0
iblfQuelnFree.39.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.39.2	Gauge	0
iblfQuelnFree.39.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.39.3	Gauge	0
iblfQuelnFree.39.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.39.4	Gauge	0
iblfQuelnFree.39.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.39.5	Gauge	0
iblfQuelnFree.39.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.39.6	Gauge	0
iblfQuelnFree.39.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.39.7	Gauge	0
iblfQuelnFree.39.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.39.8	Gauge	0
iblfQuelnFree.40.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.40.1	Gauge	0
iblfQuelnFree.40.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.40.2	Gauge	0
iblfQuelnFree.40.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.40.3	Gauge	0
iblfQuelnFree.40.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.40.4	Gauge	0
iblfQuelnFree.40.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.40.5	Gauge	0
iblfQuelnFree.40.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.40.6	Gauge	0
iblfQuelnFree.40.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.40.7	Gauge	0
iblfQuelnFree.40.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.40.8	Gauge	0
iblfQuelnFree.41.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.41.1	Gauge	0
iblfQuelnFree.41.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.41.2	Gauge	0
iblfQuelnFree.41.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.41.3	Gauge	0
iblfQuelnFree.41.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.41.4	Gauge	0
iblfQuelnFree.41.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.41.5	Gauge	0
iblfQuelnFree.41.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.41.6	Gauge	0
iblfQuelnFree.41.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.41.7	Gauge	0
iblfQuelnFree.41.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.41.8	Gauge	0
iblfQuelnFree.42.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.42.1	Gauge	0
iblfQuelnFree.42.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.42.2	Gauge	0
iblfQuelnFree.42.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.42.3	Gauge	0
iblfQuelnFree.42.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.42.4	Gauge	0
iblfQuelnFree.42.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.42.5	Gauge	0
iblfQuelnFree.42.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.42.6	Gauge	0
iblfQuelnFree.42.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.42.7	Gauge	0
iblfQuelnFree.42.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.42.8	Gauge	0
iblfQuelnFree.43.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.43.1	Gauge	0
iblfQuelnFree.43.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.43.2	Gauge	0
iblfQuelnFree.43.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.43.3	Gauge	0
iblfQuelnFree.43.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.43.4	Gauge	0
iblfQuelnFree.43.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.43.5	Gauge	0
iblfQuelnFree.43.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.43.6	Gauge	0
iblfQuelnFree.43.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.43.7	Gauge	0
iblfQuelnFree.43.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.43.8	Gauge	0
iblfQuelnFree.44.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.44.1	Gauge	0
iblfQuelnFree.44.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.44.2	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnFree.44.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.44.3	Gauge	0
iblfQuelnFree.44.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.44.4	Gauge	0
iblfQuelnFree.44.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.44.5	Gauge	0
iblfQuelnFree.44.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.44.6	Gauge	0
iblfQuelnFree.44.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.44.7	Gauge	0
iblfQuelnFree.44.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.44.8	Gauge	0
iblfQuelnFree.45.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.45.1	Gauge	0
iblfQuelnFree.45.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.45.2	Gauge	0
iblfQuelnFree.45.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.45.3	Gauge	0
iblfQuelnFree.45.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.45.4	Gauge	0
iblfQuelnFree.45.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.45.5	Gauge	0
iblfQuelnFree.45.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.45.6	Gauge	0
iblfQuelnFree.45.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.45.7	Gauge	0
iblfQuelnFree.45.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.45.8	Gauge	0
iblfQuelnFree.46.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.46.1	Gauge	0
iblfQuelnFree.46.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.46.2	Gauge	0
iblfQuelnFree.46.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.46.3	Gauge	0
iblfQuelnFree.46.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.46.4	Gauge	0
iblfQuelnFree.46.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.46.5	Gauge	0
iblfQuelnFree.46.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.46.6	Gauge	0
iblfQuelnFree.46.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.46.7	Gauge	0
iblfQuelnFree.46.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.46.8	Gauge	0
iblfQuelnFree.47.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.47.1	Gauge	0
iblfQuelnFree.47.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.47.2	Gauge	0
iblfQuelnFree.47.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.47.3	Gauge	0
iblfQuelnFree.47.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.47.4	Gauge	0
iblfQuelnFree.47.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.47.5	Gauge	0
iblfQuelnFree.47.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.47.6	Gauge	0
iblfQuelnFree.47.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.47.7	Gauge	0
iblfQuelnFree.47.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.47.8	Gauge	0
iblfQuelnFree.48.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.48.1	Gauge	0
iblfQuelnFree.48.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.48.2	Gauge	0
iblfQuelnFree.48.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.48.3	Gauge	0
iblfQuelnFree.48.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.48.4	Gauge	0
iblfQuelnFree.48.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.48.5	Gauge	0
iblfQuelnFree.48.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.48.6	Gauge	0
iblfQuelnFree.48.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.48.7	Gauge	0
iblfQuelnFree.48.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.48.8	Gauge	0
iblfQuelnFree.49.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.49.1	Gauge	0
iblfQuelnFree.49.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.49.2	Gauge	0
iblfQuelnFree.49.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.49.3	Gauge	0
iblfQuelnFree.49.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.49.4	Gauge	0
iblfQuelnFree.49.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.49.5	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnFree.49.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.49.6	Gauge	0
iblfQuelnFree.49.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.49.7	Gauge	0
iblfQuelnFree.49.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.49.8	Gauge	0
iblfQuelnFree.50.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.50.1	Gauge	0
iblfQuelnFree.50.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.50.2	Gauge	0
iblfQuelnFree.50.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.50.3	Gauge	0
iblfQuelnFree.50.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.50.4	Gauge	0
iblfQuelnFree.50.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.50.5	Gauge	0
iblfQuelnFree.50.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.50.6	Gauge	0
iblfQuelnFree.50.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.50.7	Gauge	0
iblfQuelnFree.50.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.50.8	Gauge	0
iblfQuelnFree.51.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.51.1	Gauge	0
iblfQuelnFree.51.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.51.2	Gauge	0
iblfQuelnFree.51.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.51.3	Gauge	0
iblfQuelnFree.51.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.51.4	Gauge	0
iblfQuelnFree.51.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.51.5	Gauge	0
iblfQuelnFree.51.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.51.6	Gauge	0
iblfQuelnFree.51.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.51.7	Gauge	0
iblfQuelnFree.51.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.51.8	Gauge	0
iblfQuelnFree.52.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.52.1	Gauge	0
iblfQuelnFree.52.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.52.2	Gauge	0
iblfQuelnFree.52.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.52.3	Gauge	0
iblfQuelnFree.52.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.52.4	Gauge	0
iblfQuelnFree.52.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.52.5	Gauge	0
iblfQuelnFree.52.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.52.6	Gauge	0
iblfQuelnFree.52.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.52.7	Gauge	0
iblfQuelnFree.52.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.52.8	Gauge	0
iblfQuelnFree.53.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.53.1	Gauge	0
iblfQuelnFree.53.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.53.2	Gauge	0
iblfQuelnFree.53.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.53.3	Gauge	0
iblfQuelnFree.53.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.53.4	Gauge	0
iblfQuelnFree.53.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.53.5	Gauge	0
iblfQuelnFree.53.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.53.6	Gauge	0
iblfQuelnFree.53.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.53.7	Gauge	0
iblfQuelnFree.53.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.53.8	Gauge	0
iblfQuelnFree.54.1	.3.6.1.4.1.26138.2.40.2.2.6.1.9.54.1	Gauge	0
iblfQuelnFree.54.2	.3.6.1.4.1.26138.2.40.2.2.6.1.9.54.2	Gauge	0
iblfQuelnFree.54.3	.3.6.1.4.1.26138.2.40.2.2.6.1.9.54.3	Gauge	0
iblfQuelnFree.54.4	.3.6.1.4.1.26138.2.40.2.2.6.1.9.54.4	Gauge	0
iblfQuelnFree.54.5	.3.6.1.4.1.26138.2.40.2.2.6.1.9.54.5	Gauge	0
iblfQuelnFree.54.6	.3.6.1.4.1.26138.2.40.2.2.6.1.9.54.6	Gauge	0
iblfQuelnFree.54.7	.3.6.1.4.1.26138.2.40.2.2.6.1.9.54.7	Gauge	0
iblfQuelnFree.54.8	.3.6.1.4.1.26138.2.40.2.2.6.1.9.54.8	Gauge	0

Name	OID	Value Type	Value Example
ibLfQueInUsedRatio.1.1	.3.6.1.4.1.26138.2.40.2.2.6.1.10.1.1	Gauge	0
ibLfQueInUsedRatio.1.2	.3.6.1.4.1.26138.2.40.2.2.6.1.10.1.2	Gauge	0
ibLfQueInUsedRatio.1.3	.3.6.1.4.1.26138.2.40.2.2.6.1.10.1.3	Gauge	0
ibLfQueInUsedRatio.1.4	.3.6.1.4.1.26138.2.40.2.2.6.1.10.1.4	Gauge	0
ibLfQueInUsedRatio.1.5	.3.6.1.4.1.26138.2.40.2.2.6.1.10.1.5	Gauge	0
ibLfQueInUsedRatio.1.6	.3.6.1.4.1.26138.2.40.2.2.6.1.10.1.6	Gauge	0
ibLfQueInUsedRatio.1.7	.3.6.1.4.1.26138.2.40.2.2.6.1.10.1.7	Gauge	0
ibLfQueInUsedRatio.1.8	.3.6.1.4.1.26138.2.40.2.2.6.1.10.1.8	Gauge	0
ibLfQueInUsedRatio.2.1	.3.6.1.4.1.26138.2.40.2.2.6.1.10.2.1	Gauge	0
ibLfQueInUsedRatio.2.2	.3.6.1.4.1.26138.2.40.2.2.6.1.10.2.2	Gauge	0
ibLfQueInUsedRatio.2.3	.3.6.1.4.1.26138.2.40.2.2.6.1.10.2.3	Gauge	0
ibLfQueInUsedRatio.2.4	.3.6.1.4.1.26138.2.40.2.2.6.1.10.2.4	Gauge	0
ibLfQueInUsedRatio.2.5	.3.6.1.4.1.26138.2.40.2.2.6.1.10.2.5	Gauge	0
ibLfQueInUsedRatio.2.6	.3.6.1.4.1.26138.2.40.2.2.6.1.10.2.6	Gauge	0
ibLfQueInUsedRatio.2.7	.3.6.1.4.1.26138.2.40.2.2.6.1.10.2.7	Gauge	0
ibLfQueInUsedRatio.2.8	.3.6.1.4.1.26138.2.40.2.2.6.1.10.2.8	Gauge	0
ibLfQueInUsedRatio.3.1	.3.6.1.4.1.26138.2.40.2.2.6.1.10.3.1	Gauge	0
ibLfQueInUsedRatio.3.2	.3.6.1.4.1.26138.2.40.2.2.6.1.10.3.2	Gauge	0
ibLfQueInUsedRatio.3.3	.3.6.1.4.1.26138.2.40.2.2.6.1.10.3.3	Gauge	0
ibLfQueInUsedRatio.3.4	.3.6.1.4.1.26138.2.40.2.2.6.1.10.3.4	Gauge	0
ibLfQueInUsedRatio.3.5	.3.6.1.4.1.26138.2.40.2.2.6.1.10.3.5	Gauge	0
ibLfQueInUsedRatio.3.6	.3.6.1.4.1.26138.2.40.2.2.6.1.10.3.6	Gauge	0
ibLfQueInUsedRatio.3.7	.3.6.1.4.1.26138.2.40.2.2.6.1.10.3.7	Gauge	0
ibLfQueInUsedRatio.3.8	.3.6.1.4.1.26138.2.40.2.2.6.1.10.3.8	Gauge	0
ibLfQueInUsedRatio.4.1	.3.6.1.4.1.26138.2.40.2.2.6.1.10.4.1	Gauge	0
ibLfQueInUsedRatio.4.2	.3.6.1.4.1.26138.2.40.2.2.6.1.10.4.2	Gauge	0
ibLfQueInUsedRatio.4.3	.3.6.1.4.1.26138.2.40.2.2.6.1.10.4.3	Gauge	0
ibLfQueInUsedRatio.4.4	.3.6.1.4.1.26138.2.40.2.2.6.1.10.4.4	Gauge	0
ibLfQueInUsedRatio.4.5	.3.6.1.4.1.26138.2.40.2.2.6.1.10.4.5	Gauge	0
ibLfQueInUsedRatio.4.6	.3.6.1.4.1.26138.2.40.2.2.6.1.10.4.6	Gauge	0
ibLfQueInUsedRatio.4.7	.3.6.1.4.1.26138.2.40.2.2.6.1.10.4.7	Gauge	0
ibLfQueInUsedRatio.4.8	.3.6.1.4.1.26138.2.40.2.2.6.1.10.4.8	Gauge	0
ibLfQueInUsedRatio.5.1	.3.6.1.4.1.26138.2.40.2.2.6.1.10.5.1	Gauge	0
ibLfQueInUsedRatio.5.2	.3.6.1.4.1.26138.2.40.2.2.6.1.10.5.2	Gauge	0
ibLfQueInUsedRatio.5.3	.3.6.1.4.1.26138.2.40.2.2.6.1.10.5.3	Gauge	0
ibLfQueInUsedRatio.5.4	.3.6.1.4.1.26138.2.40.2.2.6.1.10.5.4	Gauge	0
ibLfQueInUsedRatio.5.5	.3.6.1.4.1.26138.2.40.2.2.6.1.10.5.5	Gauge	0
ibLfQueInUsedRatio.5.6	.3.6.1.4.1.26138.2.40.2.2.6.1.10.5.6	Gauge	0
ibLfQueInUsedRatio.5.7	.3.6.1.4.1.26138.2.40.2.2.6.1.10.5.7	Gauge	0
ibLfQueInUsedRatio.5.8	.3.6.1.4.1.26138.2.40.2.2.6.1.10.5.8	Gauge	0
ibLfQueInUsedRatio.6.1	.3.6.1.4.1.26138.2.40.2.2.6.1.10.6.1	Gauge	0
ibLfQueInUsedRatio.6.2	.3.6.1.4.1.26138.2.40.2.2.6.1.10.6.2	Gauge	0
ibLfQueInUsedRatio.6.3	.3.6.1.4.1.26138.2.40.2.2.6.1.10.6.3	Gauge	0



Name	OID	Value Type	Value Example
iblfQueInUsedRatio.6.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.6.4	Gauge	0
iblfQueInUsedRatio.6.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.6.5	Gauge	0
iblfQueInUsedRatio.6.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.6.6	Gauge	0
iblfQueInUsedRatio.6.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.6.7	Gauge	0
iblfQueInUsedRatio.6.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.6.8	Gauge	0
iblfQueInUsedRatio.7.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.7.1	Gauge	0
iblfQueInUsedRatio.7.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.7.2	Gauge	0
iblfQueInUsedRatio.7.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.7.3	Gauge	0
iblfQueInUsedRatio.7.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.7.4	Gauge	0
iblfQueInUsedRatio.7.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.7.5	Gauge	0
iblfQueInUsedRatio.7.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.7.6	Gauge	0
iblfQueInUsedRatio.7.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.7.7	Gauge	0
iblfQueInUsedRatio.7.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.7.8	Gauge	0
iblfQueInUsedRatio.8.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.8.1	Gauge	0
iblfQueInUsedRatio.8.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.8.2	Gauge	0
iblfQueInUsedRatio.8.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.8.3	Gauge	0
iblfQueInUsedRatio.8.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.8.4	Gauge	0
iblfQueInUsedRatio.8.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.8.5	Gauge	0
iblfQueInUsedRatio.8.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.8.6	Gauge	0
iblfQueInUsedRatio.8.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.8.7	Gauge	0
iblfQueInUsedRatio.8.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.8.8	Gauge	0
iblfQueInUsedRatio.9.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.9.1	Gauge	0
iblfQueInUsedRatio.9.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.9.2	Gauge	0
iblfQueInUsedRatio.9.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.9.3	Gauge	0
iblfQueInUsedRatio.9.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.9.4	Gauge	0
iblfQueInUsedRatio.9.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.9.5	Gauge	0
iblfQueInUsedRatio.9.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.9.6	Gauge	0
iblfQueInUsedRatio.9.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.9.7	Gauge	0
iblfQueInUsedRatio.9.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.9.8	Gauge	0
iblfQueInUsedRatio.10.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.10.1	Gauge	0
iblfQueInUsedRatio.10.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.10.2	Gauge	0
iblfQueInUsedRatio.10.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.10.3	Gauge	0
iblfQueInUsedRatio.10.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.10.4	Gauge	0
iblfQueInUsedRatio.10.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.10.5	Gauge	0
iblfQueInUsedRatio.10.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.10.6	Gauge	0
iblfQueInUsedRatio.10.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.10.7	Gauge	0
iblfQueInUsedRatio.10.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.10.8	Gauge	0
iblfQueInUsedRatio.11.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.11.1	Gauge	0
iblfQueInUsedRatio.11.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.11.2	Gauge	0
iblfQueInUsedRatio.11.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.11.3	Gauge	0
iblfQueInUsedRatio.11.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.11.4	Gauge	0
iblfQueInUsedRatio.11.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.11.5	Gauge	0
iblfQueInUsedRatio.11.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.11.6	Gauge	0



Name	OID	Value Type	Value Example
iblfQuelnUsedRatio.11.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.11	7Gauge	0
iblfQuelnUsedRatio.11.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.11	8Gauge	0
iblfQuelnUsedRatio.12.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.12	1Gauge	0
iblfQuelnUsedRatio.12.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.12	2Gauge	0
iblfQuelnUsedRatio.12.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.12	3Gauge	0
iblfQuelnUsedRatio.12.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.12	4Gauge	0
iblfQuelnUsedRatio.12.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.12	5Gauge	0
iblfQuelnUsedRatio.12.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.12	6Gauge	0
iblfQuelnUsedRatio.12.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.12	7Gauge	0
iblfQuelnUsedRatio.12.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.12	8Gauge	0
iblfQuelnUsedRatio.13.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.13	1Gauge	0
iblfQuelnUsedRatio.13.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.13	2Gauge	0
iblfQuelnUsedRatio.13.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.13	3Gauge	0
iblfQuelnUsedRatio.13.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.13	4Gauge	0
iblfQuelnUsedRatio.13.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.13	5Gauge	0
iblfQuelnUsedRatio.13.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.13	6Gauge	0
iblfQuelnUsedRatio.13.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.13	7Gauge	0
iblfQuelnUsedRatio.13.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.13	8Gauge	0
iblfQuelnUsedRatio.14.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.14	1Gauge	0
iblfQuelnUsedRatio.14.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.14	2Gauge	0
iblfQuelnUsedRatio.14.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.14	3Gauge	0
iblfQuelnUsedRatio.14.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.14	4Gauge	0
iblfQuelnUsedRatio.14.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.14	5Gauge	0
iblfQuelnUsedRatio.14.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.14	6Gauge	0
iblfQuelnUsedRatio.14.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.14	7Gauge	0
iblfQuelnUsedRatio.14.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.14	8Gauge	0
iblfQuelnUsedRatio.15.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.15	1Gauge	0
iblfQuelnUsedRatio.15.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.15	2Gauge	0
iblfQuelnUsedRatio.15.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.15	3Gauge	0
iblfQuelnUsedRatio.15.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.15	4Gauge	0
iblfQuelnUsedRatio.15.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.15	5Gauge	0
iblfQuelnUsedRatio.15.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.15	6Gauge	0
iblfQuelnUsedRatio.15.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.15	7Gauge	0
iblfQuelnUsedRatio.15.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.15	8Gauge	0
iblfQuelnUsedRatio.16.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.16	1Gauge	0
iblfQuelnUsedRatio.16.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.16	2Gauge	0
iblfQuelnUsedRatio.16.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.16	3Gauge	0
iblfQuelnUsedRatio.16.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.16	4Gauge	0
iblfQuelnUsedRatio.16.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.16	5Gauge	0
iblfQuelnUsedRatio.16.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.16	6Gauge	0
iblfQuelnUsedRatio.16.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.16	7Gauge	0
iblfQuelnUsedRatio.16.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.16	8Gauge	0
iblfQuelnUsedRatio.17.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.17	1Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnUsedRatio.17.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.17	2Gauge	0
iblfQuelnUsedRatio.17.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.17	3Gauge	0
iblfQuelnUsedRatio.17.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.17	4Gauge	0
iblfQuelnUsedRatio.17.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.17	5Gauge	0
iblfQuelnUsedRatio.17.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.17	6Gauge	0
iblfQuelnUsedRatio.17.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.17	7Gauge	0
iblfQuelnUsedRatio.17.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.17	8Gauge	0
iblfQuelnUsedRatio.18.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.18	1Gauge	0
iblfQuelnUsedRatio.18.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.18	2Gauge	0
iblfQuelnUsedRatio.18.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.18	3Gauge	0
iblfQuelnUsedRatio.18.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.18	4Gauge	0
iblfQuelnUsedRatio.18.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.18	5Gauge	0
iblfQuelnUsedRatio.18.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.18	6Gauge	0
iblfQuelnUsedRatio.18.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.18	7Gauge	0
iblfQuelnUsedRatio.18.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.18	8Gauge	0
iblfQuelnUsedRatio.19.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.19	1Gauge	0
iblfQuelnUsedRatio.19.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.19	2Gauge	0
iblfQuelnUsedRatio.19.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.19	3Gauge	0
iblfQuelnUsedRatio.19.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.19	4Gauge	0
iblfQuelnUsedRatio.19.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.19	5Gauge	0
iblfQuelnUsedRatio.19.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.19	6Gauge	0
iblfQuelnUsedRatio.19.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.19	7Gauge	0
iblfQuelnUsedRatio.19.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.19	8Gauge	0
iblfQuelnUsedRatio.20.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.20	1Gauge	0
iblfQuelnUsedRatio.20.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.20	2Gauge	0
iblfQuelnUsedRatio.20.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.20	3Gauge	0
iblfQuelnUsedRatio.20.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.20	4Gauge	0
iblfQuelnUsedRatio.20.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.20	5Gauge	0
iblfQuelnUsedRatio.20.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.20	6Gauge	0
iblfQuelnUsedRatio.20.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.20	7Gauge	0
iblfQuelnUsedRatio.20.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.20	8Gauge	0
iblfQuelnUsedRatio.21.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.21	1Gauge	0
iblfQuelnUsedRatio.21.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.21	2Gauge	0
iblfQuelnUsedRatio.21.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.21	3Gauge	0
iblfQuelnUsedRatio.21.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.21	4Gauge	0
iblfQuelnUsedRatio.21.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.21	5Gauge	0
iblfQuelnUsedRatio.21.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.21	6Gauge	0
iblfQuelnUsedRatio.21.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.21	7Gauge	0
iblfQuelnUsedRatio.21.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.21	8Gauge	0
iblfQuelnUsedRatio.22.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.22	1Gauge	0
iblfQuelnUsedRatio.22.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.22	2Gauge	0
iblfQuelnUsedRatio.22.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.22	3Gauge	0
iblfQuelnUsedRatio.22.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.22	4Gauge	0

Name	OID	Value Type	Value Example
iblfQueInUsedRatio.22.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.22	5Gauge	0
iblfQueInUsedRatio.22.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.22	6Gauge	0
iblfQueInUsedRatio.22.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.22	7Gauge	0
iblfQueInUsedRatio.22.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.22	8Gauge	0
iblfQueInUsedRatio.23.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.23	1Gauge	0
iblfQueInUsedRatio.23.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.23	2Gauge	0
iblfQueInUsedRatio.23.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.23	3Gauge	0
iblfQueInUsedRatio.23.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.23	4Gauge	0
iblfQueInUsedRatio.23.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.23	5Gauge	0
iblfQueInUsedRatio.23.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.23	6Gauge	0
iblfQueInUsedRatio.23.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.23	7Gauge	0
iblfQueInUsedRatio.23.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.23	8Gauge	0
iblfQueInUsedRatio.24.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.24	1Gauge	0
iblfQueInUsedRatio.24.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.24	2Gauge	0
iblfQueInUsedRatio.24.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.24	3Gauge	0
iblfQueInUsedRatio.24.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.24	4Gauge	0
iblfQueInUsedRatio.24.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.24	5Gauge	0
iblfQueInUsedRatio.24.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.24	6Gauge	0
iblfQueInUsedRatio.24.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.24	7Gauge	0
iblfQueInUsedRatio.24.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.24	8Gauge	0
iblfQueInUsedRatio.25.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.25	1Gauge	0
iblfQueInUsedRatio.25.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.25	2Gauge	0
iblfQueInUsedRatio.25.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.25	3Gauge	0
iblfQueInUsedRatio.25.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.25	4Gauge	0
iblfQueInUsedRatio.25.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.25	5Gauge	0
iblfQueInUsedRatio.25.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.25	6Gauge	0
iblfQueInUsedRatio.25.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.25	7Gauge	0
iblfQueInUsedRatio.25.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.25	8Gauge	0
iblfQueInUsedRatio.26.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.26	1Gauge	0
iblfQueInUsedRatio.26.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.26	2Gauge	0
iblfQueInUsedRatio.26.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.26	3Gauge	0
iblfQueInUsedRatio.26.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.26	4Gauge	0
iblfQueInUsedRatio.26.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.26	5Gauge	0
iblfQueInUsedRatio.26.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.26	6Gauge	0
iblfQueInUsedRatio.26.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.26	7Gauge	0
iblfQueInUsedRatio.26.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.26	8Gauge	0
iblfQueInUsedRatio.27.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.27	1Gauge	0
iblfQueInUsedRatio.27.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.27	2Gauge	0
iblfQueInUsedRatio.27.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.27	3Gauge	0
iblfQueInUsedRatio.27.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.27	4Gauge	0
iblfQueInUsedRatio.27.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.27	5Gauge	0
iblfQueInUsedRatio.27.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.27	6Gauge	0
iblfQueInUsedRatio.27.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.27	7Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnUsedRatio.27.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.27	8Gauge	0
iblfQuelnUsedRatio.28.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.28	1Gauge	0
iblfQuelnUsedRatio.28.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.28	2Gauge	0
iblfQuelnUsedRatio.28.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.28	3Gauge	0
iblfQuelnUsedRatio.28.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.28	4Gauge	0
iblfQuelnUsedRatio.28.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.28	5Gauge	0
iblfQuelnUsedRatio.28.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.28	6Gauge	0
iblfQuelnUsedRatio.28.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.28	7Gauge	0
iblfQuelnUsedRatio.28.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.28	8Gauge	0
iblfQuelnUsedRatio.29.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.29	1Gauge	0
iblfQuelnUsedRatio.29.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.29	2Gauge	0
iblfQuelnUsedRatio.29.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.29	3Gauge	0
iblfQuelnUsedRatio.29.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.29	4Gauge	0
iblfQuelnUsedRatio.29.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.29	5Gauge	0
iblfQuelnUsedRatio.29.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.29	6Gauge	0
iblfQuelnUsedRatio.29.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.29	7Gauge	0
iblfQuelnUsedRatio.29.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.29	8Gauge	0
iblfQuelnUsedRatio.30.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.30	1Gauge	0
iblfQuelnUsedRatio.30.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.30	2Gauge	0
iblfQuelnUsedRatio.30.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.30	3Gauge	0
iblfQuelnUsedRatio.30.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.30	4Gauge	0
iblfQuelnUsedRatio.30.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.30	5Gauge	0
iblfQuelnUsedRatio.30.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.30	6Gauge	0
iblfQuelnUsedRatio.30.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.30	7Gauge	0
iblfQuelnUsedRatio.30.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.30	8Gauge	0
iblfQuelnUsedRatio.31.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.31	1Gauge	0
iblfQuelnUsedRatio.31.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.31	2Gauge	0
iblfQuelnUsedRatio.31.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.31	3Gauge	0
iblfQuelnUsedRatio.31.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.31	4Gauge	0
iblfQuelnUsedRatio.31.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.31	5Gauge	0
iblfQuelnUsedRatio.31.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.31	6Gauge	0
iblfQuelnUsedRatio.31.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.31	7Gauge	0
iblfQuelnUsedRatio.31.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.31	8Gauge	0
iblfQuelnUsedRatio.32.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.32	1Gauge	0
iblfQuelnUsedRatio.32.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.32	2Gauge	0
iblfQuelnUsedRatio.32.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.32	3Gauge	0
iblfQuelnUsedRatio.32.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.32	4Gauge	0
iblfQuelnUsedRatio.32.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.32	5Gauge	0
iblfQuelnUsedRatio.32.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.32	6Gauge	0
iblfQuelnUsedRatio.32.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.32	7Gauge	0
iblfQuelnUsedRatio.32.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.32	8Gauge	0
iblfQuelnUsedRatio.33.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.33	1Gauge	0
iblfQuelnUsedRatio.33.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.33	2Gauge	0

Name	OID	Value Type	Value Example
iblfQueInUsedRatio.33.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.33	3Gauge	0
iblfQueInUsedRatio.33.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.33	4Gauge	0
iblfQueInUsedRatio.33.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.33	5Gauge	0
iblfQueInUsedRatio.33.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.33	6Gauge	0
iblfQueInUsedRatio.33.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.33	7Gauge	0
iblfQueInUsedRatio.33.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.33	8Gauge	0
iblfQueInUsedRatio.34.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.34	1Gauge	0
iblfQueInUsedRatio.34.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.34	2Gauge	0
iblfQueInUsedRatio.34.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.34	3Gauge	0
iblfQueInUsedRatio.34.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.34	4Gauge	0
iblfQueInUsedRatio.34.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.34	5Gauge	0
iblfQueInUsedRatio.34.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.34	6Gauge	0
iblfQueInUsedRatio.34.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.34	7Gauge	0
iblfQueInUsedRatio.34.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.34	8Gauge	0
iblfQueInUsedRatio.35.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.35	1Gauge	0
iblfQueInUsedRatio.35.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.35	2Gauge	0
iblfQueInUsedRatio.35.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.35	3Gauge	0
iblfQueInUsedRatio.35.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.35	4Gauge	0
iblfQueInUsedRatio.35.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.35	5Gauge	0
iblfQueInUsedRatio.35.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.35	6Gauge	0
iblfQueInUsedRatio.35.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.35	7Gauge	0
iblfQueInUsedRatio.35.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.35	8Gauge	0
iblfQueInUsedRatio.36.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.36	1Gauge	0
iblfQueInUsedRatio.36.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.36	2Gauge	0
iblfQueInUsedRatio.36.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.36	3Gauge	0
iblfQueInUsedRatio.36.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.36	4Gauge	0
iblfQueInUsedRatio.36.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.36	5Gauge	0
iblfQueInUsedRatio.36.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.36	6Gauge	0
iblfQueInUsedRatio.36.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.36	7Gauge	0
iblfQueInUsedRatio.36.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.36	8Gauge	0
iblfQueInUsedRatio.37.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.37	1Gauge	0
iblfQueInUsedRatio.37.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.37	2Gauge	0
iblfQueInUsedRatio.37.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.37	3Gauge	0
iblfQueInUsedRatio.37.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.37	4Gauge	0
iblfQueInUsedRatio.37.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.37	5Gauge	0
iblfQueInUsedRatio.37.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.37	6Gauge	0
iblfQueInUsedRatio.37.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.37	7Gauge	0
iblfQueInUsedRatio.37.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.37	8Gauge	0
iblfQueInUsedRatio.38.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.38	1Gauge	0
iblfQueInUsedRatio.38.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.38	2Gauge	0
iblfQueInUsedRatio.38.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.38	3Gauge	0
iblfQueInUsedRatio.38.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.38	4Gauge	0
iblfQueInUsedRatio.38.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.38	5Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnUsedRatio.38.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.38	6Gauge	0
iblfQuelnUsedRatio.38.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.38	7Gauge	0
iblfQuelnUsedRatio.38.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.38	8Gauge	0
iblfQuelnUsedRatio.39.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.39	1Gauge	0
iblfQuelnUsedRatio.39.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.39	2Gauge	0
iblfQuelnUsedRatio.39.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.39	3Gauge	0
iblfQuelnUsedRatio.39.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.39	4Gauge	0
iblfQuelnUsedRatio.39.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.39	5Gauge	0
iblfQuelnUsedRatio.39.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.39	6Gauge	0
iblfQuelnUsedRatio.39.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.39	7Gauge	0
iblfQuelnUsedRatio.39.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.39	8Gauge	0
iblfQuelnUsedRatio.40.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.40	1Gauge	0
iblfQuelnUsedRatio.40.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.40	2Gauge	0
iblfQuelnUsedRatio.40.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.40	3Gauge	0
iblfQuelnUsedRatio.40.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.40	4Gauge	0
iblfQuelnUsedRatio.40.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.40	5Gauge	0
iblfQuelnUsedRatio.40.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.40	6Gauge	0
iblfQuelnUsedRatio.40.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.40	7Gauge	0
iblfQuelnUsedRatio.40.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.40	8Gauge	0
iblfQuelnUsedRatio.41.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.41	1Gauge	0
iblfQuelnUsedRatio.41.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.41	2Gauge	0
iblfQuelnUsedRatio.41.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.41	3Gauge	0
iblfQuelnUsedRatio.41.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.41	4Gauge	0
iblfQuelnUsedRatio.41.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.41	5Gauge	0
iblfQuelnUsedRatio.41.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.41	6Gauge	0
iblfQuelnUsedRatio.41.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.41	7Gauge	0
iblfQuelnUsedRatio.41.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.41	8Gauge	0
iblfQuelnUsedRatio.42.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.42	1Gauge	0
iblfQuelnUsedRatio.42.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.42	2Gauge	0
iblfQuelnUsedRatio.42.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.42	3Gauge	0
iblfQuelnUsedRatio.42.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.42	4Gauge	0
iblfQuelnUsedRatio.42.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.42	5Gauge	0
iblfQuelnUsedRatio.42.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.42	6Gauge	0
iblfQuelnUsedRatio.42.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.42	7Gauge	0
iblfQuelnUsedRatio.42.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.42	8Gauge	0
iblfQuelnUsedRatio.43.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.43	1Gauge	0
iblfQuelnUsedRatio.43.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.43	2Gauge	0
iblfQuelnUsedRatio.43.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.43	3Gauge	0
iblfQuelnUsedRatio.43.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.43	4Gauge	0
iblfQuelnUsedRatio.43.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.43	5Gauge	0
iblfQuelnUsedRatio.43.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.43	6Gauge	0
iblfQuelnUsedRatio.43.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.43	7Gauge	0
iblfQuelnUsedRatio.43.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.43	8Gauge	0



Name	OID	Value Type	Value Example
iblfQueInUsedRatio.44.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.44	1Gauge	0
iblfQueInUsedRatio.44.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.44	2Gauge	0
iblfQueInUsedRatio.44.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.44	3Gauge	0
iblfQueInUsedRatio.44.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.44	4Gauge	0
iblfQueInUsedRatio.44.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.44	5Gauge	0
iblfQueInUsedRatio.44.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.44	6Gauge	0
iblfQueInUsedRatio.44.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.44	7Gauge	0
iblfQueInUsedRatio.44.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.44	8Gauge	0
iblfQueInUsedRatio.45.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.45	1Gauge	0
iblfQueInUsedRatio.45.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.45	2Gauge	0
iblfQueInUsedRatio.45.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.45	3Gauge	0
iblfQueInUsedRatio.45.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.45	4Gauge	0
iblfQueInUsedRatio.45.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.45	5Gauge	0
iblfQueInUsedRatio.45.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.45	6Gauge	0
iblfQueInUsedRatio.45.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.45	7Gauge	0
iblfQueInUsedRatio.45.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.45	8Gauge	0
iblfQueInUsedRatio.46.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.46	1Gauge	0
iblfQueInUsedRatio.46.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.46	2Gauge	0
iblfQueInUsedRatio.46.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.46	3Gauge	0
iblfQueInUsedRatio.46.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.46	4Gauge	0
iblfQueInUsedRatio.46.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.46	5Gauge	0
iblfQueInUsedRatio.46.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.46	6Gauge	0
iblfQueInUsedRatio.46.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.46	7Gauge	0
iblfQueInUsedRatio.46.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.46	8Gauge	0
iblfQueInUsedRatio.47.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.47	1Gauge	0
iblfQueInUsedRatio.47.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.47	2Gauge	0
iblfQueInUsedRatio.47.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.47	3Gauge	0
iblfQueInUsedRatio.47.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.47	4Gauge	0
iblfQueInUsedRatio.47.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.47	5Gauge	0
iblfQueInUsedRatio.47.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.47	6Gauge	0
iblfQueInUsedRatio.47.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.47	7Gauge	0
iblfQueInUsedRatio.47.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.47	8Gauge	0
iblfQueInUsedRatio.48.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.48	1Gauge	0
iblfQueInUsedRatio.48.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.48	2Gauge	0
iblfQueInUsedRatio.48.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.48	3Gauge	0
iblfQueInUsedRatio.48.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.48	4Gauge	0
iblfQueInUsedRatio.48.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.48	5Gauge	0
iblfQueInUsedRatio.48.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.48	6Gauge	0
iblfQueInUsedRatio.48.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.48	7Gauge	0
iblfQueInUsedRatio.48.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.48	8Gauge	0
iblfQueInUsedRatio.49.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.49	1Gauge	0
iblfQueInUsedRatio.49.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.49	2Gauge	0
iblfQueInUsedRatio.49.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.49	3Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnUsedRatio.49.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.49	4Gauge	0
iblfQuelnUsedRatio.49.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.49	5Gauge	0
iblfQuelnUsedRatio.49.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.49	6Gauge	0
iblfQuelnUsedRatio.49.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.49	7Gauge	0
iblfQuelnUsedRatio.49.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.49	8Gauge	0
iblfQuelnUsedRatio.50.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.50	1Gauge	0
iblfQuelnUsedRatio.50.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.50	2Gauge	0
iblfQuelnUsedRatio.50.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.50	3Gauge	0
iblfQuelnUsedRatio.50.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.50	4Gauge	0
iblfQuelnUsedRatio.50.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.50	5Gauge	0
iblfQuelnUsedRatio.50.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.50	6Gauge	0
iblfQuelnUsedRatio.50.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.50	7Gauge	0
iblfQuelnUsedRatio.50.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.50	8Gauge	0
iblfQuelnUsedRatio.51.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.51	1Gauge	0
iblfQuelnUsedRatio.51.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.51	2Gauge	0
iblfQuelnUsedRatio.51.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.51	3Gauge	0
iblfQuelnUsedRatio.51.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.51	4Gauge	0
iblfQuelnUsedRatio.51.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.51	5Gauge	0
iblfQuelnUsedRatio.51.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.51	6Gauge	0
iblfQuelnUsedRatio.51.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.51	7Gauge	0
iblfQuelnUsedRatio.51.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.51	8Gauge	0
iblfQuelnUsedRatio.52.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.52	1Gauge	0
iblfQuelnUsedRatio.52.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.52	2Gauge	0
iblfQuelnUsedRatio.52.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.52	3Gauge	0
iblfQuelnUsedRatio.52.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.52	4Gauge	0
iblfQuelnUsedRatio.52.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.52	5Gauge	0
iblfQuelnUsedRatio.52.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.52	6Gauge	0
iblfQuelnUsedRatio.52.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.52	7Gauge	0
iblfQuelnUsedRatio.52.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.52	8Gauge	0
iblfQuelnUsedRatio.53.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.53	1Gauge	0
iblfQuelnUsedRatio.53.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.53	2Gauge	0
iblfQuelnUsedRatio.53.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.53	3Gauge	0
iblfQuelnUsedRatio.53.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.53	4Gauge	0
iblfQuelnUsedRatio.53.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.53	5Gauge	0
iblfQuelnUsedRatio.53.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.53	6Gauge	0
iblfQuelnUsedRatio.53.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.53	7Gauge	0
iblfQuelnUsedRatio.53.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.53	8Gauge	0
iblfQuelnUsedRatio.54.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.54	1Gauge	0
iblfQuelnUsedRatio.54.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.54	2Gauge	0
iblfQuelnUsedRatio.54.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.54	3Gauge	0
iblfQuelnUsedRatio.54.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.54	4Gauge	0
iblfQuelnUsedRatio.54.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.54	5Gauge	0
iblfQuelnUsedRatio.54.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.54	6Gauge	0



Name	OID	Value Type	Value Example
ibLfQuelnUsedRatio.54.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.54.7	Gauge	0
ibLfQuelnUsedRatio.54.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.10.54.8	Gauge	0
ibLfQuelnUsedPeak.1.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.1.1	Gauge	0
ibLfQuelnUsedPeak.1.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.1.2	Gauge	0
ibLfQuelnUsedPeak.1.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.1.3	Gauge	0
ibLfQuelnUsedPeak.1.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.1.4	Gauge	0
ibLfQuelnUsedPeak.1.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.1.5	Gauge	0
ibLfQuelnUsedPeak.1.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.1.6	Gauge	0
ibLfQuelnUsedPeak.1.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.1.7	Gauge	0
ibLfQuelnUsedPeak.1.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.1.8	Gauge	0
ibLfQuelnUsedPeak.2.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.2.1	Gauge	0
ibLfQuelnUsedPeak.2.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.2.2	Gauge	0
ibLfQuelnUsedPeak.2.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.2.3	Gauge	0
ibLfQuelnUsedPeak.2.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.2.4	Gauge	0
ibLfQuelnUsedPeak.2.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.2.5	Gauge	0
ibLfQuelnUsedPeak.2.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.2.6	Gauge	0
ibLfQuelnUsedPeak.2.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.2.7	Gauge	0
ibLfQuelnUsedPeak.2.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.2.8	Gauge	0
ibLfQuelnUsedPeak.3.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.3.1	Gauge	0
ibLfQuelnUsedPeak.3.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.3.2	Gauge	0
ibLfQuelnUsedPeak.3.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.3.3	Gauge	0
ibLfQuelnUsedPeak.3.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.3.4	Gauge	0
ibLfQuelnUsedPeak.3.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.3.5	Gauge	0
ibLfQuelnUsedPeak.3.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.3.6	Gauge	0
ibLfQuelnUsedPeak.3.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.3.7	Gauge	0
ibLfQuelnUsedPeak.3.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.3.8	Gauge	0
ibLfQuelnUsedPeak.4.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.4.1	Gauge	0
ibLfQuelnUsedPeak.4.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.4.2	Gauge	0
ibLfQuelnUsedPeak.4.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.4.3	Gauge	0
ibLfQuelnUsedPeak.4.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.4.4	Gauge	0
ibLfQuelnUsedPeak.4.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.4.5	Gauge	0
ibLfQuelnUsedPeak.4.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.4.6	Gauge	0
ibLfQuelnUsedPeak.4.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.4.7	Gauge	0
ibLfQuelnUsedPeak.4.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.4.8	Gauge	0
ibLfQuelnUsedPeak.5.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.5.1	Gauge	0
ibLfQuelnUsedPeak.5.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.5.2	Gauge	0
ibLfQuelnUsedPeak.5.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.5.3	Gauge	0
ibLfQuelnUsedPeak.5.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.5.4	Gauge	0
ibLfQuelnUsedPeak.5.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.5.5	Gauge	0
ibLfQuelnUsedPeak.5.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.5.6	Gauge	0
ibLfQuelnUsedPeak.5.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.5.7	Gauge	0
ibLfQuelnUsedPeak.5.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.5.8	Gauge	0
ibLfQuelnUsedPeak.6.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.6.1	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnUsedPeak.6.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.6.2	Gauge	0
iblfQuelnUsedPeak.6.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.6.3	Gauge	0
iblfQuelnUsedPeak.6.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.6.4	Gauge	0
iblfQuelnUsedPeak.6.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.6.5	Gauge	0
iblfQuelnUsedPeak.6.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.6.6	Gauge	0
iblfQuelnUsedPeak.6.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.6.7	Gauge	0
iblfQuelnUsedPeak.6.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.6.8	Gauge	0
iblfQuelnUsedPeak.7.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.7.1	Gauge	0
iblfQuelnUsedPeak.7.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.7.2	Gauge	0
iblfQuelnUsedPeak.7.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.7.3	Gauge	0
iblfQuelnUsedPeak.7.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.7.4	Gauge	0
iblfQuelnUsedPeak.7.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.7.5	Gauge	0
iblfQuelnUsedPeak.7.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.7.6	Gauge	0
iblfQuelnUsedPeak.7.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.7.7	Gauge	0
iblfQuelnUsedPeak.7.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.7.8	Gauge	0
iblfQuelnUsedPeak.8.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.8.1	Gauge	0
iblfQuelnUsedPeak.8.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.8.2	Gauge	0
iblfQuelnUsedPeak.8.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.8.3	Gauge	0
iblfQuelnUsedPeak.8.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.8.4	Gauge	0
iblfQuelnUsedPeak.8.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.8.5	Gauge	0
iblfQuelnUsedPeak.8.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.8.6	Gauge	0
iblfQuelnUsedPeak.8.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.8.7	Gauge	0
iblfQuelnUsedPeak.8.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.8.8	Gauge	0
iblfQuelnUsedPeak.9.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.9.1	Gauge	0
iblfQuelnUsedPeak.9.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.9.2	Gauge	0
iblfQuelnUsedPeak.9.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.9.3	Gauge	0
iblfQuelnUsedPeak.9.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.9.4	Gauge	0
iblfQuelnUsedPeak.9.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.9.5	Gauge	0
iblfQuelnUsedPeak.9.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.9.6	Gauge	0
iblfQuelnUsedPeak.9.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.9.7	Gauge	0
iblfQuelnUsedPeak.9.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.9.8	Gauge	0
iblfQuelnUsedPeak.10.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.10.1	Gauge	0
iblfQuelnUsedPeak.10.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.10.2	Gauge	0
iblfQuelnUsedPeak.10.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.10.3	Gauge	0
iblfQuelnUsedPeak.10.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.10.4	Gauge	0
iblfQuelnUsedPeak.10.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.10.5	Gauge	0
iblfQuelnUsedPeak.10.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.10.6	Gauge	0
iblfQuelnUsedPeak.10.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.10.7	Gauge	0
iblfQuelnUsedPeak.10.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.10.8	Gauge	0
iblfQuelnUsedPeak.11.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.11.1	Gauge	0
iblfQuelnUsedPeak.11.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.11.2	Gauge	0
iblfQuelnUsedPeak.11.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.11.3	Gauge	0
iblfQuelnUsedPeak.11.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.11.4	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnUsedPeak.11.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.11	5Gauge	0
iblfQuelnUsedPeak.11.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.11	6Gauge	0
iblfQuelnUsedPeak.11.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.11	7Gauge	0
iblfQuelnUsedPeak.11.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.11	8Gauge	0
iblfQuelnUsedPeak.12.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.12	1Gauge	0
iblfQuelnUsedPeak.12.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.12	2Gauge	0
iblfQuelnUsedPeak.12.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.12	3Gauge	0
iblfQuelnUsedPeak.12.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.12	4Gauge	0
iblfQuelnUsedPeak.12.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.12	5Gauge	0
iblfQuelnUsedPeak.12.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.12	6Gauge	0
iblfQuelnUsedPeak.12.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.12	7Gauge	0
iblfQuelnUsedPeak.12.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.12	8Gauge	0
iblfQuelnUsedPeak.13.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.13	1Gauge	0
iblfQuelnUsedPeak.13.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.13	2Gauge	0
iblfQuelnUsedPeak.13.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.13	3Gauge	0
iblfQuelnUsedPeak.13.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.13	4Gauge	0
iblfQuelnUsedPeak.13.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.13	5Gauge	0
iblfQuelnUsedPeak.13.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.13	6Gauge	0
iblfQuelnUsedPeak.13.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.13	7Gauge	0
iblfQuelnUsedPeak.13.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.13	8Gauge	0
iblfQuelnUsedPeak.14.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.14	1Gauge	0
iblfQuelnUsedPeak.14.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.14	2Gauge	0
iblfQuelnUsedPeak.14.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.14	3Gauge	0
iblfQuelnUsedPeak.14.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.14	4Gauge	0
iblfQuelnUsedPeak.14.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.14	5Gauge	0
iblfQuelnUsedPeak.14.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.14	6Gauge	0
iblfQuelnUsedPeak.14.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.14	7Gauge	0
iblfQuelnUsedPeak.14.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.14	8Gauge	0
iblfQuelnUsedPeak.15.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.15	1Gauge	0
iblfQuelnUsedPeak.15.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.15	2Gauge	0
iblfQuelnUsedPeak.15.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.15	3Gauge	0
iblfQuelnUsedPeak.15.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.15	4Gauge	0
iblfQuelnUsedPeak.15.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.15	5Gauge	0
iblfQuelnUsedPeak.15.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.15	6Gauge	0
iblfQuelnUsedPeak.15.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.15	7Gauge	0
iblfQuelnUsedPeak.15.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.15	8Gauge	0
iblfQuelnUsedPeak.16.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.16	1Gauge	0
iblfQuelnUsedPeak.16.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.16	2Gauge	0
iblfQuelnUsedPeak.16.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.16	3Gauge	0
iblfQuelnUsedPeak.16.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.16	4Gauge	0
iblfQuelnUsedPeak.16.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.16	5Gauge	0
iblfQuelnUsedPeak.16.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.16	6Gauge	0
iblfQuelnUsedPeak.16.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.16	7Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnUsedPeak.16.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.16	8Gauge	0
iblfQuelnUsedPeak.17.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.17	1Gauge	0
iblfQuelnUsedPeak.17.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.17	2Gauge	0
iblfQuelnUsedPeak.17.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.17	3Gauge	0
iblfQuelnUsedPeak.17.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.17	4Gauge	0
iblfQuelnUsedPeak.17.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.17	5Gauge	0
iblfQuelnUsedPeak.17.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.17	6Gauge	0
iblfQuelnUsedPeak.17.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.17	7Gauge	0
iblfQuelnUsedPeak.17.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.17	8Gauge	0
iblfQuelnUsedPeak.18.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.18	1Gauge	0
iblfQuelnUsedPeak.18.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.18	2Gauge	0
iblfQuelnUsedPeak.18.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.18	3Gauge	0
iblfQuelnUsedPeak.18.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.18	4Gauge	0
iblfQuelnUsedPeak.18.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.18	5Gauge	0
iblfQuelnUsedPeak.18.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.18	6Gauge	0
iblfQuelnUsedPeak.18.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.18	7Gauge	0
iblfQuelnUsedPeak.18.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.18	8Gauge	0
iblfQuelnUsedPeak.19.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.19	1Gauge	0
iblfQuelnUsedPeak.19.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.19	2Gauge	0
iblfQuelnUsedPeak.19.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.19	3Gauge	0
iblfQuelnUsedPeak.19.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.19	4Gauge	0
iblfQuelnUsedPeak.19.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.19	5Gauge	0
iblfQuelnUsedPeak.19.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.19	6Gauge	0
iblfQuelnUsedPeak.19.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.19	7Gauge	0
iblfQuelnUsedPeak.19.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.19	8Gauge	0
iblfQuelnUsedPeak.20.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.20	1Gauge	0
iblfQuelnUsedPeak.20.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.20	2Gauge	0
iblfQuelnUsedPeak.20.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.20	3Gauge	0
iblfQuelnUsedPeak.20.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.20	4Gauge	0
iblfQuelnUsedPeak.20.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.20	5Gauge	0
iblfQuelnUsedPeak.20.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.20	6Gauge	0
iblfQuelnUsedPeak.20.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.20	7Gauge	0
iblfQuelnUsedPeak.20.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.20	8Gauge	0
iblfQuelnUsedPeak.21.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.21	1Gauge	0
iblfQuelnUsedPeak.21.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.21	2Gauge	0
iblfQuelnUsedPeak.21.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.21	3Gauge	0
iblfQuelnUsedPeak.21.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.21	4Gauge	0
iblfQuelnUsedPeak.21.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.21	5Gauge	0
iblfQuelnUsedPeak.21.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.21	6Gauge	0
iblfQuelnUsedPeak.21.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.21	7Gauge	0
iblfQuelnUsedPeak.21.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.21	8Gauge	0
iblfQuelnUsedPeak.22.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.22	1Gauge	0
iblfQuelnUsedPeak.22.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.22	2Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnUsedPeak.22.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.22	3Gauge	0
iblfQuelnUsedPeak.22.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.22	4Gauge	0
iblfQuelnUsedPeak.22.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.22	5Gauge	0
iblfQuelnUsedPeak.22.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.22	6Gauge	0
iblfQuelnUsedPeak.22.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.22	7Gauge	0
iblfQuelnUsedPeak.22.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.22	8Gauge	0
iblfQuelnUsedPeak.23.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.23	1Gauge	0
iblfQuelnUsedPeak.23.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.23	2Gauge	0
iblfQuelnUsedPeak.23.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.23	3Gauge	0
iblfQuelnUsedPeak.23.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.23	4Gauge	0
iblfQuelnUsedPeak.23.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.23	5Gauge	0
iblfQuelnUsedPeak.23.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.23	6Gauge	0
iblfQuelnUsedPeak.23.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.23	7Gauge	0
iblfQuelnUsedPeak.23.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.23	8Gauge	0
iblfQuelnUsedPeak.24.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.24	1Gauge	0
iblfQuelnUsedPeak.24.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.24	2Gauge	0
iblfQuelnUsedPeak.24.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.24	3Gauge	0
iblfQuelnUsedPeak.24.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.24	4Gauge	0
iblfQuelnUsedPeak.24.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.24	5Gauge	0
iblfQuelnUsedPeak.24.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.24	6Gauge	0
iblfQuelnUsedPeak.24.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.24	7Gauge	0
iblfQuelnUsedPeak.24.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.24	8Gauge	0
iblfQuelnUsedPeak.25.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.25	1Gauge	0
iblfQuelnUsedPeak.25.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.25	2Gauge	0
iblfQuelnUsedPeak.25.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.25	3Gauge	0
iblfQuelnUsedPeak.25.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.25	4Gauge	0
iblfQuelnUsedPeak.25.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.25	5Gauge	0
iblfQuelnUsedPeak.25.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.25	6Gauge	0
iblfQuelnUsedPeak.25.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.25	7Gauge	0
iblfQuelnUsedPeak.25.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.25	8Gauge	0
iblfQuelnUsedPeak.26.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.26	1Gauge	0
iblfQuelnUsedPeak.26.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.26	2Gauge	0
iblfQuelnUsedPeak.26.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.26	3Gauge	0
iblfQuelnUsedPeak.26.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.26	4Gauge	0
iblfQuelnUsedPeak.26.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.26	5Gauge	0
iblfQuelnUsedPeak.26.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.26	6Gauge	0
iblfQuelnUsedPeak.26.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.26	7Gauge	0
iblfQuelnUsedPeak.26.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.26	8Gauge	0
iblfQuelnUsedPeak.27.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.27	1Gauge	0
iblfQuelnUsedPeak.27.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.27	2Gauge	0
iblfQuelnUsedPeak.27.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.27	3Gauge	0
iblfQuelnUsedPeak.27.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.27	4Gauge	0
iblfQuelnUsedPeak.27.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.27	5Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnUsedPeak.27.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.27	6Gauge	0
iblfQuelnUsedPeak.27.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.27	7Gauge	0
iblfQuelnUsedPeak.27.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.27	8Gauge	0
iblfQuelnUsedPeak.28.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.28	1Gauge	0
iblfQuelnUsedPeak.28.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.28	2Gauge	0
iblfQuelnUsedPeak.28.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.28	3Gauge	0
iblfQuelnUsedPeak.28.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.28	4Gauge	0
iblfQuelnUsedPeak.28.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.28	5Gauge	0
iblfQuelnUsedPeak.28.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.28	6Gauge	0
iblfQuelnUsedPeak.28.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.28	7Gauge	0
iblfQuelnUsedPeak.28.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.28	8Gauge	0
iblfQuelnUsedPeak.29.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.29	1Gauge	0
iblfQuelnUsedPeak.29.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.29	2Gauge	0
iblfQuelnUsedPeak.29.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.29	3Gauge	0
iblfQuelnUsedPeak.29.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.29	4Gauge	0
iblfQuelnUsedPeak.29.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.29	5Gauge	0
iblfQuelnUsedPeak.29.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.29	6Gauge	0
iblfQuelnUsedPeak.29.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.29	7Gauge	0
iblfQuelnUsedPeak.29.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.29	8Gauge	0
iblfQuelnUsedPeak.30.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.30	1Gauge	0
iblfQuelnUsedPeak.30.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.30	2Gauge	0
iblfQuelnUsedPeak.30.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.30	3Gauge	0
iblfQuelnUsedPeak.30.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.30	4Gauge	0
iblfQuelnUsedPeak.30.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.30	5Gauge	0
iblfQuelnUsedPeak.30.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.30	6Gauge	0
iblfQuelnUsedPeak.30.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.30	7Gauge	0
iblfQuelnUsedPeak.30.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.30	8Gauge	0
iblfQuelnUsedPeak.31.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.31	1Gauge	0
iblfQuelnUsedPeak.31.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.31	2Gauge	0
iblfQuelnUsedPeak.31.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.31	3Gauge	0
iblfQuelnUsedPeak.31.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.31	4Gauge	0
iblfQuelnUsedPeak.31.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.31	5Gauge	0
iblfQuelnUsedPeak.31.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.31	6Gauge	0
iblfQuelnUsedPeak.31.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.31	7Gauge	0
iblfQuelnUsedPeak.31.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.31	8Gauge	0
iblfQuelnUsedPeak.32.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.32	1Gauge	0
iblfQuelnUsedPeak.32.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.32	2Gauge	0
iblfQuelnUsedPeak.32.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.32	3Gauge	0
iblfQuelnUsedPeak.32.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.32	4Gauge	0
iblfQuelnUsedPeak.32.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.32	5Gauge	0
iblfQuelnUsedPeak.32.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.32	6Gauge	0
iblfQuelnUsedPeak.32.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.32	7Gauge	0
iblfQuelnUsedPeak.32.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.32	8Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnUsedPeak.33.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.33	1Gauge	0
iblfQuelnUsedPeak.33.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.33	2Gauge	0
iblfQuelnUsedPeak.33.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.33	3Gauge	0
iblfQuelnUsedPeak.33.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.33	4Gauge	0
iblfQuelnUsedPeak.33.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.33	5Gauge	0
iblfQuelnUsedPeak.33.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.33	6Gauge	0
iblfQuelnUsedPeak.33.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.33	7Gauge	0
iblfQuelnUsedPeak.33.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.33	8Gauge	0
iblfQuelnUsedPeak.34.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.34	1Gauge	0
iblfQuelnUsedPeak.34.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.34	2Gauge	0
iblfQuelnUsedPeak.34.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.34	3Gauge	0
iblfQuelnUsedPeak.34.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.34	4Gauge	0
iblfQuelnUsedPeak.34.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.34	5Gauge	0
iblfQuelnUsedPeak.34.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.34	6Gauge	0
iblfQuelnUsedPeak.34.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.34	7Gauge	0
iblfQuelnUsedPeak.34.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.34	8Gauge	0
iblfQuelnUsedPeak.35.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.35	1Gauge	0
iblfQuelnUsedPeak.35.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.35	2Gauge	0
iblfQuelnUsedPeak.35.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.35	3Gauge	0
iblfQuelnUsedPeak.35.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.35	4Gauge	0
iblfQuelnUsedPeak.35.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.35	5Gauge	0
iblfQuelnUsedPeak.35.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.35	6Gauge	0
iblfQuelnUsedPeak.35.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.35	7Gauge	0
iblfQuelnUsedPeak.35.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.35	8Gauge	0
iblfQuelnUsedPeak.36.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.36	1Gauge	0
iblfQuelnUsedPeak.36.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.36	2Gauge	0
iblfQuelnUsedPeak.36.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.36	3Gauge	0
iblfQuelnUsedPeak.36.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.36	4Gauge	0
iblfQuelnUsedPeak.36.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.36	5Gauge	0
iblfQuelnUsedPeak.36.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.36	6Gauge	0
iblfQuelnUsedPeak.36.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.36	7Gauge	0
iblfQuelnUsedPeak.36.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.36	8Gauge	0
iblfQuelnUsedPeak.37.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.37	1Gauge	0
iblfQuelnUsedPeak.37.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.37	2Gauge	0
iblfQuelnUsedPeak.37.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.37	3Gauge	0
iblfQuelnUsedPeak.37.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.37	4Gauge	0
iblfQuelnUsedPeak.37.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.37	5Gauge	0
iblfQuelnUsedPeak.37.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.37	6Gauge	0
iblfQuelnUsedPeak.37.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.37	7Gauge	0
iblfQuelnUsedPeak.37.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.37	8Gauge	0
iblfQuelnUsedPeak.38.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.38	1Gauge	0
iblfQuelnUsedPeak.38.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.38	2Gauge	0
iblfQuelnUsedPeak.38.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.38	3Gauge	0



Name	OID	Value Type	Value Example
iblfQuelnUsedPeak.38.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.38	4Gauge	0
iblfQuelnUsedPeak.38.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.38	5Gauge	0
iblfQuelnUsedPeak.38.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.38	6Gauge	0
iblfQuelnUsedPeak.38.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.38	7Gauge	0
iblfQuelnUsedPeak.38.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.38	8Gauge	0
iblfQuelnUsedPeak.39.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.39	1Gauge	0
iblfQuelnUsedPeak.39.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.39	2Gauge	0
iblfQuelnUsedPeak.39.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.39	3Gauge	0
iblfQuelnUsedPeak.39.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.39	4Gauge	0
iblfQuelnUsedPeak.39.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.39	5Gauge	0
iblfQuelnUsedPeak.39.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.39	6Gauge	0
iblfQuelnUsedPeak.39.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.39	7Gauge	0
iblfQuelnUsedPeak.39.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.39	8Gauge	0
iblfQuelnUsedPeak.40.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.40	1Gauge	0
iblfQuelnUsedPeak.40.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.40	2Gauge	0
iblfQuelnUsedPeak.40.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.40	3Gauge	0
iblfQuelnUsedPeak.40.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.40	4Gauge	0
iblfQuelnUsedPeak.40.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.40	5Gauge	0
iblfQuelnUsedPeak.40.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.40	6Gauge	0
iblfQuelnUsedPeak.40.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.40	7Gauge	0
iblfQuelnUsedPeak.40.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.40	8Gauge	0
iblfQuelnUsedPeak.41.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.41	1Gauge	0
iblfQuelnUsedPeak.41.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.41	2Gauge	0
iblfQuelnUsedPeak.41.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.41	3Gauge	0
iblfQuelnUsedPeak.41.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.41	4Gauge	0
iblfQuelnUsedPeak.41.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.41	5Gauge	0
iblfQuelnUsedPeak.41.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.41	6Gauge	0
iblfQuelnUsedPeak.41.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.41	7Gauge	0
iblfQuelnUsedPeak.41.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.41	8Gauge	0
iblfQuelnUsedPeak.42.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.42	1Gauge	0
iblfQuelnUsedPeak.42.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.42	2Gauge	0
iblfQuelnUsedPeak.42.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.42	3Gauge	0
iblfQuelnUsedPeak.42.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.42	4Gauge	0
iblfQuelnUsedPeak.42.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.42	5Gauge	0
iblfQuelnUsedPeak.42.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.42	6Gauge	0
iblfQuelnUsedPeak.42.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.42	7Gauge	0
iblfQuelnUsedPeak.42.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.42	8Gauge	0
iblfQuelnUsedPeak.43.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.43	1Gauge	0
iblfQuelnUsedPeak.43.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.43	2Gauge	0
iblfQuelnUsedPeak.43.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.43	3Gauge	0
iblfQuelnUsedPeak.43.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.43	4Gauge	0
iblfQuelnUsedPeak.43.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.43	5Gauge	0
iblfQuelnUsedPeak.43.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.43	6Gauge	0



Name	OID	Value Type	Value Example
iblfQuelnUsedPeak.43.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.43	7Gauge	0
iblfQuelnUsedPeak.43.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.43	8Gauge	0
iblfQuelnUsedPeak.44.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.44	1Gauge	0
iblfQuelnUsedPeak.44.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.44	2Gauge	0
iblfQuelnUsedPeak.44.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.44	3Gauge	0
iblfQuelnUsedPeak.44.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.44	4Gauge	0
iblfQuelnUsedPeak.44.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.44	5Gauge	0
iblfQuelnUsedPeak.44.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.44	6Gauge	0
iblfQuelnUsedPeak.44.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.44	7Gauge	0
iblfQuelnUsedPeak.44.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.44	8Gauge	0
iblfQuelnUsedPeak.45.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.45	1Gauge	0
iblfQuelnUsedPeak.45.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.45	2Gauge	0
iblfQuelnUsedPeak.45.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.45	3Gauge	0
iblfQuelnUsedPeak.45.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.45	4Gauge	0
iblfQuelnUsedPeak.45.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.45	5Gauge	0
iblfQuelnUsedPeak.45.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.45	6Gauge	0
iblfQuelnUsedPeak.45.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.45	7Gauge	0
iblfQuelnUsedPeak.45.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.45	8Gauge	0
iblfQuelnUsedPeak.46.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.46	1Gauge	0
iblfQuelnUsedPeak.46.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.46	2Gauge	0
iblfQuelnUsedPeak.46.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.46	3Gauge	0
iblfQuelnUsedPeak.46.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.46	4Gauge	0
iblfQuelnUsedPeak.46.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.46	5Gauge	0
iblfQuelnUsedPeak.46.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.46	6Gauge	0
iblfQuelnUsedPeak.46.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.46	7Gauge	0
iblfQuelnUsedPeak.46.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.46	8Gauge	0
iblfQuelnUsedPeak.47.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.47	1Gauge	0
iblfQuelnUsedPeak.47.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.47	2Gauge	0
iblfQuelnUsedPeak.47.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.47	3Gauge	0
iblfQuelnUsedPeak.47.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.47	4Gauge	0
iblfQuelnUsedPeak.47.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.47	5Gauge	0
iblfQuelnUsedPeak.47.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.47	6Gauge	0
iblfQuelnUsedPeak.47.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.47	7Gauge	0
iblfQuelnUsedPeak.47.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.47	8Gauge	0
iblfQuelnUsedPeak.48.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.48	1Gauge	0
iblfQuelnUsedPeak.48.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.48	2Gauge	0
iblfQuelnUsedPeak.48.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.48	3Gauge	0
iblfQuelnUsedPeak.48.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.48	4Gauge	0
iblfQuelnUsedPeak.48.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.48	5Gauge	0
iblfQuelnUsedPeak.48.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.48	6Gauge	0
iblfQuelnUsedPeak.48.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.48	7Gauge	0
iblfQuelnUsedPeak.48.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.48	8Gauge	0
iblfQuelnUsedPeak.49.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.49	1Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnUsedPeak.49.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.49	2Gauge	0
iblfQuelnUsedPeak.49.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.49	3Gauge	0
iblfQuelnUsedPeak.49.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.49	4Gauge	0
iblfQuelnUsedPeak.49.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.49	5Gauge	0
iblfQuelnUsedPeak.49.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.49	6Gauge	0
iblfQuelnUsedPeak.49.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.49	7Gauge	0
iblfQuelnUsedPeak.49.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.49	8Gauge	0
iblfQuelnUsedPeak.50.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.50	1Gauge	0
iblfQuelnUsedPeak.50.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.50	2Gauge	0
iblfQuelnUsedPeak.50.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.50	3Gauge	0
iblfQuelnUsedPeak.50.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.50	4Gauge	0
iblfQuelnUsedPeak.50.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.50	5Gauge	0
iblfQuelnUsedPeak.50.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.50	6Gauge	0
iblfQuelnUsedPeak.50.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.50	7Gauge	0
iblfQuelnUsedPeak.50.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.50	8Gauge	0
iblfQuelnUsedPeak.51.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.51	1Gauge	0
iblfQuelnUsedPeak.51.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.51	2Gauge	0
iblfQuelnUsedPeak.51.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.51	3Gauge	0
iblfQuelnUsedPeak.51.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.51	4Gauge	0
iblfQuelnUsedPeak.51.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.51	5Gauge	0
iblfQuelnUsedPeak.51.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.51	6Gauge	0
iblfQuelnUsedPeak.51.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.51	7Gauge	0
iblfQuelnUsedPeak.51.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.51	8Gauge	0
iblfQuelnUsedPeak.52.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.52	1Gauge	0
iblfQuelnUsedPeak.52.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.52	2Gauge	0
iblfQuelnUsedPeak.52.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.52	3Gauge	0
iblfQuelnUsedPeak.52.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.52	4Gauge	0
iblfQuelnUsedPeak.52.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.52	5Gauge	0
iblfQuelnUsedPeak.52.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.52	6Gauge	0
iblfQuelnUsedPeak.52.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.52	7Gauge	0
iblfQuelnUsedPeak.52.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.52	8Gauge	0
iblfQuelnUsedPeak.53.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.53	1Gauge	0
iblfQuelnUsedPeak.53.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.53	2Gauge	0
iblfQuelnUsedPeak.53.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.53	3Gauge	0
iblfQuelnUsedPeak.53.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.53	4Gauge	0
iblfQuelnUsedPeak.53.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.53	5Gauge	0
iblfQuelnUsedPeak.53.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.53	6Gauge	0
iblfQuelnUsedPeak.53.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.53	7Gauge	0
iblfQuelnUsedPeak.53.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.53	8Gauge	0
iblfQuelnUsedPeak.54.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.54	1Gauge	0
iblfQuelnUsedPeak.54.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.54	2Gauge	0
iblfQuelnUsedPeak.54.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.54	3Gauge	0
iblfQuelnUsedPeak.54.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.54	4Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnUsedPeak.54.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.54.5	Gauge	0
iblfQuelnUsedPeak.54.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.54.6	Gauge	0
iblfQuelnUsedPeak.54.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.54.7	Gauge	0
iblfQuelnUsedPeak.54.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.11.54.8	Gauge	0
iblfQuelnThreshold.1.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.1.1	Gauge	0
iblfQuelnThreshold.1.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.1.2	Gauge	0
iblfQuelnThreshold.1.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.1.3	Gauge	0
iblfQuelnThreshold.1.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.1.4	Gauge	0
iblfQuelnThreshold.1.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.1.5	Gauge	0
iblfQuelnThreshold.1.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.1.6	Gauge	0
iblfQuelnThreshold.1.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.1.7	Gauge	0
iblfQuelnThreshold.1.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.1.8	Gauge	0
iblfQuelnThreshold.2.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.2.1	Gauge	0
iblfQuelnThreshold.2.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.2.2	Gauge	0
iblfQuelnThreshold.2.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.2.3	Gauge	0
iblfQuelnThreshold.2.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.2.4	Gauge	0
iblfQuelnThreshold.2.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.2.5	Gauge	0
iblfQuelnThreshold.2.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.2.6	Gauge	0
iblfQuelnThreshold.2.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.2.7	Gauge	0
iblfQuelnThreshold.2.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.2.8	Gauge	0
iblfQuelnThreshold.3.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.3.1	Gauge	0
iblfQuelnThreshold.3.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.3.2	Gauge	0
iblfQuelnThreshold.3.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.3.3	Gauge	0
iblfQuelnThreshold.3.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.3.4	Gauge	0
iblfQuelnThreshold.3.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.3.5	Gauge	0
iblfQuelnThreshold.3.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.3.6	Gauge	0
iblfQuelnThreshold.3.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.3.7	Gauge	0
iblfQuelnThreshold.3.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.3.8	Gauge	0
iblfQuelnThreshold.4.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.4.1	Gauge	0
iblfQuelnThreshold.4.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.4.2	Gauge	0
iblfQuelnThreshold.4.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.4.3	Gauge	0
iblfQuelnThreshold.4.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.4.4	Gauge	0
iblfQuelnThreshold.4.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.4.5	Gauge	0
iblfQuelnThreshold.4.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.4.6	Gauge	0
iblfQuelnThreshold.4.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.4.7	Gauge	0
iblfQuelnThreshold.4.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.4.8	Gauge	0
iblfQuelnThreshold.5.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.5.1	Gauge	0
iblfQuelnThreshold.5.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.5.2	Gauge	0
iblfQuelnThreshold.5.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.5.3	Gauge	0
iblfQuelnThreshold.5.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.5.4	Gauge	0
iblfQuelnThreshold.5.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.5.5	Gauge	0
iblfQuelnThreshold.5.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.5.6	Gauge	0
iblfQuelnThreshold.5.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.5.7	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnThreshold.5.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.5.8	Gauge	0
iblfQuelnThreshold.6.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.6.1	Gauge	0
iblfQuelnThreshold.6.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.6.2	Gauge	0
iblfQuelnThreshold.6.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.6.3	Gauge	0
iblfQuelnThreshold.6.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.6.4	Gauge	0
iblfQuelnThreshold.6.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.6.5	Gauge	0
iblfQuelnThreshold.6.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.6.6	Gauge	0
iblfQuelnThreshold.6.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.6.7	Gauge	0
iblfQuelnThreshold.6.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.6.8	Gauge	0
iblfQuelnThreshold.7.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.7.1	Gauge	0
iblfQuelnThreshold.7.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.7.2	Gauge	0
iblfQuelnThreshold.7.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.7.3	Gauge	0
iblfQuelnThreshold.7.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.7.4	Gauge	0
iblfQuelnThreshold.7.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.7.5	Gauge	0
iblfQuelnThreshold.7.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.7.6	Gauge	0
iblfQuelnThreshold.7.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.7.7	Gauge	0
iblfQuelnThreshold.7.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.7.8	Gauge	0
iblfQuelnThreshold.8.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.8.1	Gauge	0
iblfQuelnThreshold.8.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.8.2	Gauge	0
iblfQuelnThreshold.8.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.8.3	Gauge	0
iblfQuelnThreshold.8.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.8.4	Gauge	0
iblfQuelnThreshold.8.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.8.5	Gauge	0
iblfQuelnThreshold.8.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.8.6	Gauge	0
iblfQuelnThreshold.8.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.8.7	Gauge	0
iblfQuelnThreshold.8.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.8.8	Gauge	0
iblfQuelnThreshold.9.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.9.1	Gauge	0
iblfQuelnThreshold.9.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.9.2	Gauge	0
iblfQuelnThreshold.9.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.9.3	Gauge	0
iblfQuelnThreshold.9.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.9.4	Gauge	0
iblfQuelnThreshold.9.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.9.5	Gauge	0
iblfQuelnThreshold.9.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.9.6	Gauge	0
iblfQuelnThreshold.9.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.9.7	Gauge	0
iblfQuelnThreshold.9.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.9.8	Gauge	0
iblfQuelnThreshold.10.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.10.1	Gauge	0
iblfQuelnThreshold.10.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.10.2	Gauge	0
iblfQuelnThreshold.10.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.10.3	Gauge	0
iblfQuelnThreshold.10.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.10.4	Gauge	0
iblfQuelnThreshold.10.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.10.5	Gauge	0
iblfQuelnThreshold.10.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.10.6	Gauge	0
iblfQuelnThreshold.10.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.10.7	Gauge	0
iblfQuelnThreshold.10.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.10.8	Gauge	0
iblfQuelnThreshold.11.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.11.1	Gauge	0
iblfQuelnThreshold.11.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.11.2	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnThreshold.11.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.11	3Gauge	0
iblfQuelnThreshold.11.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.11	4Gauge	0
iblfQuelnThreshold.11.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.11	5Gauge	0
iblfQuelnThreshold.11.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.11	6Gauge	0
iblfQuelnThreshold.11.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.11	7Gauge	0
iblfQuelnThreshold.11.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.11	8Gauge	0
iblfQuelnThreshold.12.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.12	1Gauge	0
iblfQuelnThreshold.12.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.12	2Gauge	0
iblfQuelnThreshold.12.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.12	3Gauge	0
iblfQuelnThreshold.12.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.12	4Gauge	0
iblfQuelnThreshold.12.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.12	5Gauge	0
iblfQuelnThreshold.12.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.12	6Gauge	0
iblfQuelnThreshold.12.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.12	7Gauge	0
iblfQuelnThreshold.12.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.12	8Gauge	0
iblfQuelnThreshold.13.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.13	1Gauge	0
iblfQuelnThreshold.13.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.13	2Gauge	0
iblfQuelnThreshold.13.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.13	3Gauge	0
iblfQuelnThreshold.13.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.13	4Gauge	0
iblfQuelnThreshold.13.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.13	5Gauge	0
iblfQuelnThreshold.13.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.13	6Gauge	0
iblfQuelnThreshold.13.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.13	7Gauge	0
iblfQuelnThreshold.13.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.13	8Gauge	0
iblfQuelnThreshold.14.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.14	1Gauge	0
iblfQuelnThreshold.14.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.14	2Gauge	0
iblfQuelnThreshold.14.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.14	3Gauge	0
iblfQuelnThreshold.14.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.14	4Gauge	0
iblfQuelnThreshold.14.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.14	5Gauge	0
iblfQuelnThreshold.14.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.14	6Gauge	0
iblfQuelnThreshold.14.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.14	7Gauge	0
iblfQuelnThreshold.14.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.14	8Gauge	0
iblfQuelnThreshold.15.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.15	1Gauge	0
iblfQuelnThreshold.15.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.15	2Gauge	0
iblfQuelnThreshold.15.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.15	3Gauge	0
iblfQuelnThreshold.15.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.15	4Gauge	0
iblfQuelnThreshold.15.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.15	5Gauge	0
iblfQuelnThreshold.15.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.15	6Gauge	0
iblfQuelnThreshold.15.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.15	7Gauge	0
iblfQuelnThreshold.15.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.15	8Gauge	0
iblfQuelnThreshold.16.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.16	1Gauge	0
iblfQuelnThreshold.16.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.16	2Gauge	0
iblfQuelnThreshold.16.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.16	3Gauge	0
iblfQuelnThreshold.16.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.16	4Gauge	0
iblfQuelnThreshold.16.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.16	5Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnThreshold.16.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.16	6Gauge	0
iblfQuelnThreshold.16.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.16	7Gauge	0
iblfQuelnThreshold.16.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.16	8Gauge	0
iblfQuelnThreshold.17.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.17	1Gauge	0
iblfQuelnThreshold.17.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.17	2Gauge	0
iblfQuelnThreshold.17.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.17	3Gauge	0
iblfQuelnThreshold.17.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.17	4Gauge	0
iblfQuelnThreshold.17.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.17	5Gauge	0
iblfQuelnThreshold.17.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.17	6Gauge	0
iblfQuelnThreshold.17.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.17	7Gauge	0
iblfQuelnThreshold.17.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.17	8Gauge	0
iblfQuelnThreshold.18.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.18	1Gauge	0
iblfQuelnThreshold.18.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.18	2Gauge	0
iblfQuelnThreshold.18.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.18	3Gauge	0
iblfQuelnThreshold.18.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.18	4Gauge	0
iblfQuelnThreshold.18.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.18	5Gauge	0
iblfQuelnThreshold.18.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.18	6Gauge	0
iblfQuelnThreshold.18.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.18	7Gauge	0
iblfQuelnThreshold.18.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.18	8Gauge	0
iblfQuelnThreshold.19.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.19	1Gauge	0
iblfQuelnThreshold.19.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.19	2Gauge	0
iblfQuelnThreshold.19.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.19	3Gauge	0
iblfQuelnThreshold.19.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.19	4Gauge	0
iblfQuelnThreshold.19.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.19	5Gauge	0
iblfQuelnThreshold.19.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.19	6Gauge	0
iblfQuelnThreshold.19.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.19	7Gauge	0
iblfQuelnThreshold.19.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.19	8Gauge	0
iblfQuelnThreshold.20.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.20	1Gauge	0
iblfQuelnThreshold.20.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.20	2Gauge	0
iblfQuelnThreshold.20.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.20	3Gauge	0
iblfQuelnThreshold.20.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.20	4Gauge	0
iblfQuelnThreshold.20.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.20	5Gauge	0
iblfQuelnThreshold.20.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.20	6Gauge	0
iblfQuelnThreshold.20.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.20	7Gauge	0
iblfQuelnThreshold.20.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.20	8Gauge	0
iblfQuelnThreshold.21.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.21	1Gauge	0
iblfQuelnThreshold.21.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.21	2Gauge	0
iblfQuelnThreshold.21.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.21	3Gauge	0
iblfQuelnThreshold.21.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.21	4Gauge	0
iblfQuelnThreshold.21.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.21	5Gauge	0
iblfQuelnThreshold.21.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.21	6Gauge	0
iblfQuelnThreshold.21.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.21	7Gauge	0
iblfQuelnThreshold.21.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.21	8Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnThreshold.22.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.22	1Gauge	0
iblfQuelnThreshold.22.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.22	2Gauge	0
iblfQuelnThreshold.22.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.22	3Gauge	0
iblfQuelnThreshold.22.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.22	4Gauge	0
iblfQuelnThreshold.22.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.22	5Gauge	0
iblfQuelnThreshold.22.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.22	6Gauge	0
iblfQuelnThreshold.22.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.22	7Gauge	0
iblfQuelnThreshold.22.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.22	8Gauge	0
iblfQuelnThreshold.23.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.23	1Gauge	0
iblfQuelnThreshold.23.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.23	2Gauge	0
iblfQuelnThreshold.23.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.23	3Gauge	0
iblfQuelnThreshold.23.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.23	4Gauge	0
iblfQuelnThreshold.23.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.23	5Gauge	0
iblfQuelnThreshold.23.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.23	6Gauge	0
iblfQuelnThreshold.23.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.23	7Gauge	0
iblfQuelnThreshold.23.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.23	8Gauge	0
iblfQuelnThreshold.24.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.24	1Gauge	0
iblfQuelnThreshold.24.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.24	2Gauge	0
iblfQuelnThreshold.24.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.24	3Gauge	0
iblfQuelnThreshold.24.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.24	4Gauge	0
iblfQuelnThreshold.24.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.24	5Gauge	0
iblfQuelnThreshold.24.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.24	6Gauge	0
iblfQuelnThreshold.24.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.24	7Gauge	0
iblfQuelnThreshold.24.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.24	8Gauge	0
iblfQuelnThreshold.25.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.25	1Gauge	0
iblfQuelnThreshold.25.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.25	2Gauge	0
iblfQuelnThreshold.25.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.25	3Gauge	0
iblfQuelnThreshold.25.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.25	4Gauge	0
iblfQuelnThreshold.25.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.25	5Gauge	0
iblfQuelnThreshold.25.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.25	6Gauge	0
iblfQuelnThreshold.25.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.25	7Gauge	0
iblfQuelnThreshold.25.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.25	8Gauge	0
iblfQuelnThreshold.26.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.26	1Gauge	0
iblfQuelnThreshold.26.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.26	2Gauge	0
iblfQuelnThreshold.26.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.26	3Gauge	0
iblfQuelnThreshold.26.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.26	4Gauge	0
iblfQuelnThreshold.26.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.26	5Gauge	0
iblfQuelnThreshold.26.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.26	6Gauge	0
iblfQuelnThreshold.26.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.26	7Gauge	0
iblfQuelnThreshold.26.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.26	8Gauge	0
iblfQuelnThreshold.27.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.27	1Gauge	0
iblfQuelnThreshold.27.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.27	2Gauge	0
iblfQuelnThreshold.27.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.27	3Gauge	0



Name	OID	Value Type	Value Example
iblfQuelnThreshold.27.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.27	4Gauge	0
iblfQuelnThreshold.27.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.27	5Gauge	0
iblfQuelnThreshold.27.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.27	6Gauge	0
iblfQuelnThreshold.27.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.27	7Gauge	0
iblfQuelnThreshold.27.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.27	8Gauge	0
iblfQuelnThreshold.28.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.28	1Gauge	0
iblfQuelnThreshold.28.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.28	2Gauge	0
iblfQuelnThreshold.28.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.28	3Gauge	0
iblfQuelnThreshold.28.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.28	4Gauge	0
iblfQuelnThreshold.28.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.28	5Gauge	0
iblfQuelnThreshold.28.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.28	6Gauge	0
iblfQuelnThreshold.28.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.28	7Gauge	0
iblfQuelnThreshold.28.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.28	8Gauge	0
iblfQuelnThreshold.29.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.29	1Gauge	0
iblfQuelnThreshold.29.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.29	2Gauge	0
iblfQuelnThreshold.29.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.29	3Gauge	0
iblfQuelnThreshold.29.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.29	4Gauge	0
iblfQuelnThreshold.29.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.29	5Gauge	0
iblfQuelnThreshold.29.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.29	6Gauge	0
iblfQuelnThreshold.29.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.29	7Gauge	0
iblfQuelnThreshold.29.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.29	8Gauge	0
iblfQuelnThreshold.30.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.30	1Gauge	0
iblfQuelnThreshold.30.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.30	2Gauge	0
iblfQuelnThreshold.30.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.30	3Gauge	0
iblfQuelnThreshold.30.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.30	4Gauge	0
iblfQuelnThreshold.30.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.30	5Gauge	0
iblfQuelnThreshold.30.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.30	6Gauge	0
iblfQuelnThreshold.30.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.30	7Gauge	0
iblfQuelnThreshold.30.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.30	8Gauge	0
iblfQuelnThreshold.31.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.31	1Gauge	0
iblfQuelnThreshold.31.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.31	2Gauge	0
iblfQuelnThreshold.31.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.31	3Gauge	0
iblfQuelnThreshold.31.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.31	4Gauge	0
iblfQuelnThreshold.31.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.31	5Gauge	0
iblfQuelnThreshold.31.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.31	6Gauge	0
iblfQuelnThreshold.31.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.31	7Gauge	0
iblfQuelnThreshold.31.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.31	8Gauge	0
iblfQuelnThreshold.32.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.32	1Gauge	0
iblfQuelnThreshold.32.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.32	2Gauge	0
iblfQuelnThreshold.32.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.32	3Gauge	0
iblfQuelnThreshold.32.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.32	4Gauge	0
iblfQuelnThreshold.32.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.32	5Gauge	0
iblfQuelnThreshold.32.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.32	6Gauge	0



Name	OID	Value Type	Value Example
iblfQuelnThreshold.32.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.32	7Gauge	0
iblfQuelnThreshold.32.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.32	8Gauge	0
iblfQuelnThreshold.33.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.33	1Gauge	0
iblfQuelnThreshold.33.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.33	2Gauge	0
iblfQuelnThreshold.33.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.33	3Gauge	0
iblfQuelnThreshold.33.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.33	4Gauge	0
iblfQuelnThreshold.33.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.33	5Gauge	0
iblfQuelnThreshold.33.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.33	6Gauge	0
iblfQuelnThreshold.33.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.33	7Gauge	0
iblfQuelnThreshold.33.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.33	8Gauge	0
iblfQuelnThreshold.34.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.34	1Gauge	0
iblfQuelnThreshold.34.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.34	2Gauge	0
iblfQuelnThreshold.34.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.34	3Gauge	0
iblfQuelnThreshold.34.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.34	4Gauge	0
iblfQuelnThreshold.34.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.34	5Gauge	0
iblfQuelnThreshold.34.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.34	6Gauge	0
iblfQuelnThreshold.34.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.34	7Gauge	0
iblfQuelnThreshold.34.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.34	8Gauge	0
iblfQuelnThreshold.35.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.35	1Gauge	0
iblfQuelnThreshold.35.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.35	2Gauge	0
iblfQuelnThreshold.35.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.35	3Gauge	0
iblfQuelnThreshold.35.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.35	4Gauge	0
iblfQuelnThreshold.35.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.35	5Gauge	0
iblfQuelnThreshold.35.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.35	6Gauge	0
iblfQuelnThreshold.35.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.35	7Gauge	0
iblfQuelnThreshold.35.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.35	8Gauge	0
iblfQuelnThreshold.36.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.36	1Gauge	0
iblfQuelnThreshold.36.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.36	2Gauge	0
iblfQuelnThreshold.36.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.36	3Gauge	0
iblfQuelnThreshold.36.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.36	4Gauge	0
iblfQuelnThreshold.36.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.36	5Gauge	0
iblfQuelnThreshold.36.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.36	6Gauge	0
iblfQuelnThreshold.36.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.36	7Gauge	0
iblfQuelnThreshold.36.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.36	8Gauge	0
iblfQuelnThreshold.37.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.37	1Gauge	0
iblfQuelnThreshold.37.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.37	2Gauge	0
iblfQuelnThreshold.37.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.37	3Gauge	0
iblfQuelnThreshold.37.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.37	4Gauge	0
iblfQuelnThreshold.37.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.37	5Gauge	0
iblfQuelnThreshold.37.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.37	6Gauge	0
iblfQuelnThreshold.37.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.37	7Gauge	0
iblfQuelnThreshold.37.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.37	8Gauge	0
iblfQuelnThreshold.38.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.38	1Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnThreshold.38.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.38	2Gauge	0
iblfQuelnThreshold.38.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.38	3Gauge	0
iblfQuelnThreshold.38.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.38	4Gauge	0
iblfQuelnThreshold.38.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.38	5Gauge	0
iblfQuelnThreshold.38.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.38	6Gauge	0
iblfQuelnThreshold.38.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.38	7Gauge	0
iblfQuelnThreshold.38.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.38	8Gauge	0
iblfQuelnThreshold.39.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.39	1Gauge	0
iblfQuelnThreshold.39.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.39	2Gauge	0
iblfQuelnThreshold.39.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.39	3Gauge	0
iblfQuelnThreshold.39.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.39	4Gauge	0
iblfQuelnThreshold.39.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.39	5Gauge	0
iblfQuelnThreshold.39.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.39	6Gauge	0
iblfQuelnThreshold.39.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.39	7Gauge	0
iblfQuelnThreshold.39.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.39	8Gauge	0
iblfQuelnThreshold.40.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.40	1Gauge	0
iblfQuelnThreshold.40.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.40	2Gauge	0
iblfQuelnThreshold.40.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.40	3Gauge	0
iblfQuelnThreshold.40.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.40	4Gauge	0
iblfQuelnThreshold.40.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.40	5Gauge	0
iblfQuelnThreshold.40.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.40	6Gauge	0
iblfQuelnThreshold.40.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.40	7Gauge	0
iblfQuelnThreshold.40.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.40	8Gauge	0
iblfQuelnThreshold.41.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.41	1Gauge	0
iblfQuelnThreshold.41.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.41	2Gauge	0
iblfQuelnThreshold.41.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.41	3Gauge	0
iblfQuelnThreshold.41.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.41	4Gauge	0
iblfQuelnThreshold.41.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.41	5Gauge	0
iblfQuelnThreshold.41.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.41	6Gauge	0
iblfQuelnThreshold.41.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.41	7Gauge	0
iblfQuelnThreshold.41.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.41	8Gauge	0
iblfQuelnThreshold.42.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.42	1Gauge	0
iblfQuelnThreshold.42.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.42	2Gauge	0
iblfQuelnThreshold.42.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.42	3Gauge	0
iblfQuelnThreshold.42.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.42	4Gauge	0
iblfQuelnThreshold.42.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.42	5Gauge	0
iblfQuelnThreshold.42.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.42	6Gauge	0
iblfQuelnThreshold.42.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.42	7Gauge	0
iblfQuelnThreshold.42.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.42	8Gauge	0
iblfQuelnThreshold.43.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.43	1Gauge	0
iblfQuelnThreshold.43.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.43	2Gauge	0
iblfQuelnThreshold.43.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.43	3Gauge	0
iblfQuelnThreshold.43.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.43	4Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnThreshold.43.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.43	5Gauge	0
iblfQuelnThreshold.43.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.43	6Gauge	0
iblfQuelnThreshold.43.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.43	7Gauge	0
iblfQuelnThreshold.43.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.43	8Gauge	0
iblfQuelnThreshold.44.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.44	1Gauge	0
iblfQuelnThreshold.44.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.44	2Gauge	0
iblfQuelnThreshold.44.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.44	3Gauge	0
iblfQuelnThreshold.44.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.44	4Gauge	0
iblfQuelnThreshold.44.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.44	5Gauge	0
iblfQuelnThreshold.44.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.44	6Gauge	0
iblfQuelnThreshold.44.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.44	7Gauge	0
iblfQuelnThreshold.44.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.44	8Gauge	0
iblfQuelnThreshold.45.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.45	1Gauge	0
iblfQuelnThreshold.45.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.45	2Gauge	0
iblfQuelnThreshold.45.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.45	3Gauge	0
iblfQuelnThreshold.45.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.45	4Gauge	0
iblfQuelnThreshold.45.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.45	5Gauge	0
iblfQuelnThreshold.45.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.45	6Gauge	0
iblfQuelnThreshold.45.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.45	7Gauge	0
iblfQuelnThreshold.45.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.45	8Gauge	0
iblfQuelnThreshold.46.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.46	1Gauge	0
iblfQuelnThreshold.46.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.46	2Gauge	0
iblfQuelnThreshold.46.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.46	3Gauge	0
iblfQuelnThreshold.46.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.46	4Gauge	0
iblfQuelnThreshold.46.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.46	5Gauge	0
iblfQuelnThreshold.46.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.46	6Gauge	0
iblfQuelnThreshold.46.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.46	7Gauge	0
iblfQuelnThreshold.46.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.46	8Gauge	0
iblfQuelnThreshold.47.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.47	1Gauge	0
iblfQuelnThreshold.47.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.47	2Gauge	0
iblfQuelnThreshold.47.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.47	3Gauge	0
iblfQuelnThreshold.47.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.47	4Gauge	0
iblfQuelnThreshold.47.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.47	5Gauge	0
iblfQuelnThreshold.47.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.47	6Gauge	0
iblfQuelnThreshold.47.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.47	7Gauge	0
iblfQuelnThreshold.47.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.47	8Gauge	0
iblfQuelnThreshold.48.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.48	1Gauge	0
iblfQuelnThreshold.48.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.48	2Gauge	0
iblfQuelnThreshold.48.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.48	3Gauge	0
iblfQuelnThreshold.48.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.48	4Gauge	0
iblfQuelnThreshold.48.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.48	5Gauge	0
iblfQuelnThreshold.48.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.48	6Gauge	0
iblfQuelnThreshold.48.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.48	7Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnThreshold.48.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.48	8Gauge	0
iblfQuelnThreshold.49.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.49	1Gauge	0
iblfQuelnThreshold.49.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.49	2Gauge	0
iblfQuelnThreshold.49.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.49	3Gauge	0
iblfQuelnThreshold.49.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.49	4Gauge	0
iblfQuelnThreshold.49.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.49	5Gauge	0
iblfQuelnThreshold.49.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.49	6Gauge	0
iblfQuelnThreshold.49.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.49	7Gauge	0
iblfQuelnThreshold.49.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.49	8Gauge	0
iblfQuelnThreshold.50.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.50	1Gauge	0
iblfQuelnThreshold.50.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.50	2Gauge	0
iblfQuelnThreshold.50.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.50	3Gauge	0
iblfQuelnThreshold.50.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.50	4Gauge	0
iblfQuelnThreshold.50.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.50	5Gauge	0
iblfQuelnThreshold.50.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.50	6Gauge	0
iblfQuelnThreshold.50.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.50	7Gauge	0
iblfQuelnThreshold.50.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.50	8Gauge	0
iblfQuelnThreshold.51.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.51	1Gauge	0
iblfQuelnThreshold.51.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.51	2Gauge	0
iblfQuelnThreshold.51.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.51	3Gauge	0
iblfQuelnThreshold.51.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.51	4Gauge	0
iblfQuelnThreshold.51.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.51	5Gauge	0
iblfQuelnThreshold.51.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.51	6Gauge	0
iblfQuelnThreshold.51.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.51	7Gauge	0
iblfQuelnThreshold.51.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.51	8Gauge	0
iblfQuelnThreshold.52.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.52	1Gauge	0
iblfQuelnThreshold.52.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.52	2Gauge	0
iblfQuelnThreshold.52.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.52	3Gauge	0
iblfQuelnThreshold.52.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.52	4Gauge	0
iblfQuelnThreshold.52.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.52	5Gauge	0
iblfQuelnThreshold.52.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.52	6Gauge	0
iblfQuelnThreshold.52.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.52	7Gauge	0
iblfQuelnThreshold.52.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.52	8Gauge	0
iblfQuelnThreshold.53.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.53	1Gauge	0
iblfQuelnThreshold.53.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.53	2Gauge	0
iblfQuelnThreshold.53.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.53	3Gauge	0
iblfQuelnThreshold.53.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.53	4Gauge	0
iblfQuelnThreshold.53.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.53	5Gauge	0
iblfQuelnThreshold.53.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.53	6Gauge	0
iblfQuelnThreshold.53.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.53	7Gauge	0
iblfQuelnThreshold.53.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.53	8Gauge	0
iblfQuelnThreshold.54.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.54	1Gauge	0
iblfQuelnThreshold.54.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.54	2Gauge	0

Name	OID	Value Type	Value Example
ibLfQuelnThreshold.54.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.54.3	Gauge	0
ibLfQuelnThreshold.54.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.54.4	Gauge	0
ibLfQuelnThreshold.54.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.54.5	Gauge	0
ibLfQuelnThreshold.54.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.54.6	Gauge	0
ibLfQuelnThreshold.54.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.54.7	Gauge	0
ibLfQuelnThreshold.54.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.12.54.8	Gauge	0
ibLfQuelnOverThres.1.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.1.1	Gauge	0
ibLfQuelnOverThres.1.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.1.2	Gauge	0
ibLfQuelnOverThres.1.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.1.3	Gauge	0
ibLfQuelnOverThres.1.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.1.4	Gauge	0
ibLfQuelnOverThres.1.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.1.5	Gauge	0
ibLfQuelnOverThres.1.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.1.6	Gauge	0
ibLfQuelnOverThres.1.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.1.7	Gauge	0
ibLfQuelnOverThres.1.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.1.8	Gauge	0
ibLfQuelnOverThres.2.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.2.1	Gauge	0
ibLfQuelnOverThres.2.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.2.2	Gauge	0
ibLfQuelnOverThres.2.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.2.3	Gauge	0
ibLfQuelnOverThres.2.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.2.4	Gauge	0
ibLfQuelnOverThres.2.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.2.5	Gauge	0
ibLfQuelnOverThres.2.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.2.6	Gauge	0
ibLfQuelnOverThres.2.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.2.7	Gauge	0
ibLfQuelnOverThres.2.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.2.8	Gauge	0
ibLfQuelnOverThres.3.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.3.1	Gauge	0
ibLfQuelnOverThres.3.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.3.2	Gauge	0
ibLfQuelnOverThres.3.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.3.3	Gauge	0
ibLfQuelnOverThres.3.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.3.4	Gauge	0
ibLfQuelnOverThres.3.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.3.5	Gauge	0
ibLfQuelnOverThres.3.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.3.6	Gauge	0
ibLfQuelnOverThres.3.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.3.7	Gauge	0
ibLfQuelnOverThres.3.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.3.8	Gauge	0
ibLfQuelnOverThres.4.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.4.1	Gauge	0
ibLfQuelnOverThres.4.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.4.2	Gauge	0
ibLfQuelnOverThres.4.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.4.3	Gauge	0
ibLfQuelnOverThres.4.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.4.4	Gauge	0
ibLfQuelnOverThres.4.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.4.5	Gauge	0
ibLfQuelnOverThres.4.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.4.6	Gauge	0
ibLfQuelnOverThres.4.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.4.7	Gauge	0
ibLfQuelnOverThres.4.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.4.8	Gauge	0
ibLfQuelnOverThres.5.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.5.1	Gauge	0
ibLfQuelnOverThres.5.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.5.2	Gauge	0
ibLfQuelnOverThres.5.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.5.3	Gauge	0
ibLfQuelnOverThres.5.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.5.4	Gauge	0
ibLfQuelnOverThres.5.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.5.5	Gauge	0

Name	OID	Value Type	Value Example
ibLfQuelnOverThres.5.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.5.6	Gauge	0
ibLfQuelnOverThres.5.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.5.7	Gauge	0
ibLfQuelnOverThres.5.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.5.8	Gauge	0
ibLfQuelnOverThres.6.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.6.1	Gauge	0
ibLfQuelnOverThres.6.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.6.2	Gauge	0
ibLfQuelnOverThres.6.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.6.3	Gauge	0
ibLfQuelnOverThres.6.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.6.4	Gauge	0
ibLfQuelnOverThres.6.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.6.5	Gauge	0
ibLfQuelnOverThres.6.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.6.6	Gauge	0
ibLfQuelnOverThres.6.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.6.7	Gauge	0
ibLfQuelnOverThres.6.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.6.8	Gauge	0
ibLfQuelnOverThres.7.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.7.1	Gauge	0
ibLfQuelnOverThres.7.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.7.2	Gauge	0
ibLfQuelnOverThres.7.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.7.3	Gauge	0
ibLfQuelnOverThres.7.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.7.4	Gauge	0
ibLfQuelnOverThres.7.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.7.5	Gauge	0
ibLfQuelnOverThres.7.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.7.6	Gauge	0
ibLfQuelnOverThres.7.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.7.7	Gauge	0
ibLfQuelnOverThres.7.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.7.8	Gauge	0
ibLfQuelnOverThres.8.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.8.1	Gauge	0
ibLfQuelnOverThres.8.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.8.2	Gauge	0
ibLfQuelnOverThres.8.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.8.3	Gauge	0
ibLfQuelnOverThres.8.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.8.4	Gauge	0
ibLfQuelnOverThres.8.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.8.5	Gauge	0
ibLfQuelnOverThres.8.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.8.6	Gauge	0
ibLfQuelnOverThres.8.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.8.7	Gauge	0
ibLfQuelnOverThres.8.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.8.8	Gauge	0
ibLfQuelnOverThres.9.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.9.1	Gauge	0
ibLfQuelnOverThres.9.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.9.2	Gauge	0
ibLfQuelnOverThres.9.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.9.3	Gauge	0
ibLfQuelnOverThres.9.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.9.4	Gauge	0
ibLfQuelnOverThres.9.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.9.5	Gauge	0
ibLfQuelnOverThres.9.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.9.6	Gauge	0
ibLfQuelnOverThres.9.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.9.7	Gauge	0
ibLfQuelnOverThres.9.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.9.8	Gauge	0
ibLfQuelnOverThres.10.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.10.1	Gauge	0
ibLfQuelnOverThres.10.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.10.2	Gauge	0
ibLfQuelnOverThres.10.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.10.3	Gauge	0
ibLfQuelnOverThres.10.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.10.4	Gauge	0
ibLfQuelnOverThres.10.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.10.5	Gauge	0
ibLfQuelnOverThres.10.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.10.6	Gauge	0
ibLfQuelnOverThres.10.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.10.7	Gauge	0
ibLfQuelnOverThres.10.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.10.8	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnOverThres.11.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.11	1Gauge	0
iblfQuelnOverThres.11.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.11	2Gauge	0
iblfQuelnOverThres.11.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.11	3Gauge	0
iblfQuelnOverThres.11.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.11	4Gauge	0
iblfQuelnOverThres.11.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.11	5Gauge	0
iblfQuelnOverThres.11.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.11	6Gauge	0
iblfQuelnOverThres.11.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.11	7Gauge	0
iblfQuelnOverThres.11.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.11	8Gauge	0
iblfQuelnOverThres.12.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.12	1Gauge	0
iblfQuelnOverThres.12.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.12	2Gauge	0
iblfQuelnOverThres.12.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.12	3Gauge	0
iblfQuelnOverThres.12.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.12	4Gauge	0
iblfQuelnOverThres.12.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.12	5Gauge	0
iblfQuelnOverThres.12.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.12	6Gauge	0
iblfQuelnOverThres.12.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.12	7Gauge	0
iblfQuelnOverThres.12.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.12	8Gauge	0
iblfQuelnOverThres.13.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.13	1Gauge	0
iblfQuelnOverThres.13.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.13	2Gauge	0
iblfQuelnOverThres.13.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.13	3Gauge	0
iblfQuelnOverThres.13.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.13	4Gauge	0
iblfQuelnOverThres.13.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.13	5Gauge	0
iblfQuelnOverThres.13.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.13	6Gauge	0
iblfQuelnOverThres.13.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.13	7Gauge	0
iblfQuelnOverThres.13.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.13	8Gauge	0
iblfQuelnOverThres.14.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.14	1Gauge	0
iblfQuelnOverThres.14.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.14	2Gauge	0
iblfQuelnOverThres.14.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.14	3Gauge	0
iblfQuelnOverThres.14.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.14	4Gauge	0
iblfQuelnOverThres.14.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.14	5Gauge	0
iblfQuelnOverThres.14.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.14	6Gauge	0
iblfQuelnOverThres.14.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.14	7Gauge	0
iblfQuelnOverThres.14.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.14	8Gauge	0
iblfQuelnOverThres.15.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.15	1Gauge	0
iblfQuelnOverThres.15.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.15	2Gauge	0
iblfQuelnOverThres.15.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.15	3Gauge	0
iblfQuelnOverThres.15.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.15	4Gauge	0
iblfQuelnOverThres.15.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.15	5Gauge	0
iblfQuelnOverThres.15.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.15	6Gauge	0
iblfQuelnOverThres.15.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.15	7Gauge	0
iblfQuelnOverThres.15.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.15	8Gauge	0
iblfQuelnOverThres.16.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.16	1Gauge	0
iblfQuelnOverThres.16.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.16	2Gauge	0
iblfQuelnOverThres.16.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.16	3Gauge	0



Name	OID	Value Type	Value Example
iblfQuelnOverThres.16.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.16.4	Gauge	0
iblfQuelnOverThres.16.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.16.5	Gauge	0
iblfQuelnOverThres.16.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.16.6	Gauge	0
iblfQuelnOverThres.16.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.16.7	Gauge	0
iblfQuelnOverThres.16.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.16.8	Gauge	0
iblfQuelnOverThres.17.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.17.1	Gauge	0
iblfQuelnOverThres.17.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.17.2	Gauge	0
iblfQuelnOverThres.17.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.17.3	Gauge	0
iblfQuelnOverThres.17.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.17.4	Gauge	0
iblfQuelnOverThres.17.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.17.5	Gauge	0
iblfQuelnOverThres.17.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.17.6	Gauge	0
iblfQuelnOverThres.17.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.17.7	Gauge	0
iblfQuelnOverThres.17.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.17.8	Gauge	0
iblfQuelnOverThres.18.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.18.1	Gauge	0
iblfQuelnOverThres.18.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.18.2	Gauge	0
iblfQuelnOverThres.18.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.18.3	Gauge	0
iblfQuelnOverThres.18.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.18.4	Gauge	0
iblfQuelnOverThres.18.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.18.5	Gauge	0
iblfQuelnOverThres.18.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.18.6	Gauge	0
iblfQuelnOverThres.18.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.18.7	Gauge	0
iblfQuelnOverThres.18.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.18.8	Gauge	0
iblfQuelnOverThres.19.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.19.1	Gauge	0
iblfQuelnOverThres.19.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.19.2	Gauge	0
iblfQuelnOverThres.19.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.19.3	Gauge	0
iblfQuelnOverThres.19.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.19.4	Gauge	0
iblfQuelnOverThres.19.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.19.5	Gauge	0
iblfQuelnOverThres.19.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.19.6	Gauge	0
iblfQuelnOverThres.19.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.19.7	Gauge	0
iblfQuelnOverThres.19.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.19.8	Gauge	0
iblfQuelnOverThres.20.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.20.1	Gauge	0
iblfQuelnOverThres.20.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.20.2	Gauge	0
iblfQuelnOverThres.20.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.20.3	Gauge	0
iblfQuelnOverThres.20.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.20.4	Gauge	0
iblfQuelnOverThres.20.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.20.5	Gauge	0
iblfQuelnOverThres.20.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.20.6	Gauge	0
iblfQuelnOverThres.20.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.20.7	Gauge	0
iblfQuelnOverThres.20.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.20.8	Gauge	0
iblfQuelnOverThres.21.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.21.1	Gauge	0
iblfQuelnOverThres.21.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.21.2	Gauge	0
iblfQuelnOverThres.21.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.21.3	Gauge	0
iblfQuelnOverThres.21.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.21.4	Gauge	0
iblfQuelnOverThres.21.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.21.5	Gauge	0
iblfQuelnOverThres.21.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.21.6	Gauge	0



Name	OID	Value Type	Value Example
iblfQuelnOverThres.21.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.21	7Gauge	0
iblfQuelnOverThres.21.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.21	8Gauge	0
iblfQuelnOverThres.22.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.22	1Gauge	0
iblfQuelnOverThres.22.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.22	2Gauge	0
iblfQuelnOverThres.22.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.22	3Gauge	0
iblfQuelnOverThres.22.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.22	4Gauge	0
iblfQuelnOverThres.22.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.22	5Gauge	0
iblfQuelnOverThres.22.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.22	6Gauge	0
iblfQuelnOverThres.22.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.22	7Gauge	0
iblfQuelnOverThres.22.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.22	8Gauge	0
iblfQuelnOverThres.23.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.23	1Gauge	0
iblfQuelnOverThres.23.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.23	2Gauge	0
iblfQuelnOverThres.23.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.23	3Gauge	0
iblfQuelnOverThres.23.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.23	4Gauge	0
iblfQuelnOverThres.23.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.23	5Gauge	0
iblfQuelnOverThres.23.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.23	6Gauge	0
iblfQuelnOverThres.23.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.23	7Gauge	0
iblfQuelnOverThres.23.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.23	8Gauge	0
iblfQuelnOverThres.24.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.24	1Gauge	0
iblfQuelnOverThres.24.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.24	2Gauge	0
iblfQuelnOverThres.24.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.24	3Gauge	0
iblfQuelnOverThres.24.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.24	4Gauge	0
iblfQuelnOverThres.24.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.24	5Gauge	0
iblfQuelnOverThres.24.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.24	6Gauge	0
iblfQuelnOverThres.24.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.24	7Gauge	0
iblfQuelnOverThres.24.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.24	8Gauge	0
iblfQuelnOverThres.25.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.25	1Gauge	0
iblfQuelnOverThres.25.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.25	2Gauge	0
iblfQuelnOverThres.25.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.25	3Gauge	0
iblfQuelnOverThres.25.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.25	4Gauge	0
iblfQuelnOverThres.25.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.25	5Gauge	0
iblfQuelnOverThres.25.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.25	6Gauge	0
iblfQuelnOverThres.25.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.25	7Gauge	0
iblfQuelnOverThres.25.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.25	8Gauge	0
iblfQuelnOverThres.26.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.26	1Gauge	0
iblfQuelnOverThres.26.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.26	2Gauge	0
iblfQuelnOverThres.26.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.26	3Gauge	0
iblfQuelnOverThres.26.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.26	4Gauge	0
iblfQuelnOverThres.26.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.26	5Gauge	0
iblfQuelnOverThres.26.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.26	6Gauge	0
iblfQuelnOverThres.26.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.26	7Gauge	0
iblfQuelnOverThres.26.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.26	8Gauge	0
iblfQuelnOverThres.27.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.27	1Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnOverThres.27.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.27	2Gauge	0
iblfQuelnOverThres.27.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.27	3Gauge	0
iblfQuelnOverThres.27.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.27	4Gauge	0
iblfQuelnOverThres.27.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.27	5Gauge	0
iblfQuelnOverThres.27.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.27	6Gauge	0
iblfQuelnOverThres.27.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.27	7Gauge	0
iblfQuelnOverThres.27.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.27	8Gauge	0
iblfQuelnOverThres.28.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.28	1Gauge	0
iblfQuelnOverThres.28.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.28	2Gauge	0
iblfQuelnOverThres.28.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.28	3Gauge	0
iblfQuelnOverThres.28.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.28	4Gauge	0
iblfQuelnOverThres.28.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.28	5Gauge	0
iblfQuelnOverThres.28.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.28	6Gauge	0
iblfQuelnOverThres.28.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.28	7Gauge	0
iblfQuelnOverThres.28.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.28	8Gauge	0
iblfQuelnOverThres.29.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.29	1Gauge	0
iblfQuelnOverThres.29.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.29	2Gauge	0
iblfQuelnOverThres.29.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.29	3Gauge	0
iblfQuelnOverThres.29.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.29	4Gauge	0
iblfQuelnOverThres.29.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.29	5Gauge	0
iblfQuelnOverThres.29.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.29	6Gauge	0
iblfQuelnOverThres.29.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.29	7Gauge	0
iblfQuelnOverThres.29.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.29	8Gauge	0
iblfQuelnOverThres.30.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.30	1Gauge	0
iblfQuelnOverThres.30.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.30	2Gauge	0
iblfQuelnOverThres.30.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.30	3Gauge	0
iblfQuelnOverThres.30.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.30	4Gauge	0
iblfQuelnOverThres.30.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.30	5Gauge	0
iblfQuelnOverThres.30.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.30	6Gauge	0
iblfQuelnOverThres.30.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.30	7Gauge	0
iblfQuelnOverThres.30.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.30	8Gauge	0
iblfQuelnOverThres.31.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.31	1Gauge	0
iblfQuelnOverThres.31.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.31	2Gauge	0
iblfQuelnOverThres.31.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.31	3Gauge	0
iblfQuelnOverThres.31.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.31	4Gauge	0
iblfQuelnOverThres.31.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.31	5Gauge	0
iblfQuelnOverThres.31.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.31	6Gauge	0
iblfQuelnOverThres.31.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.31	7Gauge	0
iblfQuelnOverThres.31.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.31	8Gauge	0
iblfQuelnOverThres.32.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.32	1Gauge	0
iblfQuelnOverThres.32.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.32	2Gauge	0
iblfQuelnOverThres.32.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.32	3Gauge	0
iblfQuelnOverThres.32.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.32	4Gauge	0

Name	OID	Value Type	Value Example
ibLfQuelnOverThres.32.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.32	5Gauge	0
ibLfQuelnOverThres.32.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.32	6Gauge	0
ibLfQuelnOverThres.32.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.32	7Gauge	0
ibLfQuelnOverThres.32.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.32	8Gauge	0
ibLfQuelnOverThres.33.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.33	1Gauge	0
ibLfQuelnOverThres.33.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.33	2Gauge	0
ibLfQuelnOverThres.33.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.33	3Gauge	0
ibLfQuelnOverThres.33.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.33	4Gauge	0
ibLfQuelnOverThres.33.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.33	5Gauge	0
ibLfQuelnOverThres.33.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.33	6Gauge	0
ibLfQuelnOverThres.33.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.33	7Gauge	0
ibLfQuelnOverThres.33.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.33	8Gauge	0
ibLfQuelnOverThres.34.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.34	1Gauge	0
ibLfQuelnOverThres.34.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.34	2Gauge	0
ibLfQuelnOverThres.34.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.34	3Gauge	0
ibLfQuelnOverThres.34.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.34	4Gauge	0
ibLfQuelnOverThres.34.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.34	5Gauge	0
ibLfQuelnOverThres.34.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.34	6Gauge	0
ibLfQuelnOverThres.34.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.34	7Gauge	0
ibLfQuelnOverThres.34.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.34	8Gauge	0
ibLfQuelnOverThres.35.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.35	1Gauge	0
ibLfQuelnOverThres.35.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.35	2Gauge	0
ibLfQuelnOverThres.35.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.35	3Gauge	0
ibLfQuelnOverThres.35.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.35	4Gauge	0
ibLfQuelnOverThres.35.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.35	5Gauge	0
ibLfQuelnOverThres.35.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.35	6Gauge	0
ibLfQuelnOverThres.35.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.35	7Gauge	0
ibLfQuelnOverThres.35.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.35	8Gauge	0
ibLfQuelnOverThres.36.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.36	1Gauge	0
ibLfQuelnOverThres.36.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.36	2Gauge	0
ibLfQuelnOverThres.36.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.36	3Gauge	0
ibLfQuelnOverThres.36.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.36	4Gauge	0
ibLfQuelnOverThres.36.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.36	5Gauge	0
ibLfQuelnOverThres.36.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.36	6Gauge	0
ibLfQuelnOverThres.36.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.36	7Gauge	0
ibLfQuelnOverThres.36.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.36	8Gauge	0
ibLfQuelnOverThres.37.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.37	1Gauge	0
ibLfQuelnOverThres.37.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.37	2Gauge	0
ibLfQuelnOverThres.37.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.37	3Gauge	0
ibLfQuelnOverThres.37.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.37	4Gauge	0
ibLfQuelnOverThres.37.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.37	5Gauge	0
ibLfQuelnOverThres.37.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.37	6Gauge	0
ibLfQuelnOverThres.37.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.37	7Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnOverThres.37.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.37	8Gauge	0
iblfQuelnOverThres.38.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.38	1Gauge	0
iblfQuelnOverThres.38.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.38	2Gauge	0
iblfQuelnOverThres.38.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.38	3Gauge	0
iblfQuelnOverThres.38.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.38	4Gauge	0
iblfQuelnOverThres.38.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.38	5Gauge	0
iblfQuelnOverThres.38.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.38	6Gauge	0
iblfQuelnOverThres.38.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.38	7Gauge	0
iblfQuelnOverThres.38.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.38	8Gauge	0
iblfQuelnOverThres.39.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.39	1Gauge	0
iblfQuelnOverThres.39.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.39	2Gauge	0
iblfQuelnOverThres.39.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.39	3Gauge	0
iblfQuelnOverThres.39.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.39	4Gauge	0
iblfQuelnOverThres.39.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.39	5Gauge	0
iblfQuelnOverThres.39.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.39	6Gauge	0
iblfQuelnOverThres.39.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.39	7Gauge	0
iblfQuelnOverThres.39.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.39	8Gauge	0
iblfQuelnOverThres.40.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.40	1Gauge	0
iblfQuelnOverThres.40.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.40	2Gauge	0
iblfQuelnOverThres.40.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.40	3Gauge	0
iblfQuelnOverThres.40.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.40	4Gauge	0
iblfQuelnOverThres.40.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.40	5Gauge	0
iblfQuelnOverThres.40.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.40	6Gauge	0
iblfQuelnOverThres.40.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.40	7Gauge	0
iblfQuelnOverThres.40.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.40	8Gauge	0
iblfQuelnOverThres.41.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.41	1Gauge	0
iblfQuelnOverThres.41.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.41	2Gauge	0
iblfQuelnOverThres.41.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.41	3Gauge	0
iblfQuelnOverThres.41.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.41	4Gauge	0
iblfQuelnOverThres.41.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.41	5Gauge	0
iblfQuelnOverThres.41.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.41	6Gauge	0
iblfQuelnOverThres.41.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.41	7Gauge	0
iblfQuelnOverThres.41.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.41	8Gauge	0
iblfQuelnOverThres.42.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.42	1Gauge	0
iblfQuelnOverThres.42.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.42	2Gauge	0
iblfQuelnOverThres.42.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.42	3Gauge	0
iblfQuelnOverThres.42.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.42	4Gauge	0
iblfQuelnOverThres.42.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.42	5Gauge	0
iblfQuelnOverThres.42.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.42	6Gauge	0
iblfQuelnOverThres.42.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.42	7Gauge	0
iblfQuelnOverThres.42.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.42	8Gauge	0
iblfQuelnOverThres.43.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.43	1Gauge	0
iblfQuelnOverThres.43.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.43	2Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnOverThres.43.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.43	3Gauge	0
iblfQuelnOverThres.43.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.43	4Gauge	0
iblfQuelnOverThres.43.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.43	5Gauge	0
iblfQuelnOverThres.43.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.43	6Gauge	0
iblfQuelnOverThres.43.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.43	7Gauge	0
iblfQuelnOverThres.43.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.43	8Gauge	0
iblfQuelnOverThres.44.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.44	1Gauge	0
iblfQuelnOverThres.44.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.44	2Gauge	0
iblfQuelnOverThres.44.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.44	3Gauge	0
iblfQuelnOverThres.44.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.44	4Gauge	0
iblfQuelnOverThres.44.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.44	5Gauge	0
iblfQuelnOverThres.44.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.44	6Gauge	0
iblfQuelnOverThres.44.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.44	7Gauge	0
iblfQuelnOverThres.44.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.44	8Gauge	0
iblfQuelnOverThres.45.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.45	1Gauge	0
iblfQuelnOverThres.45.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.45	2Gauge	0
iblfQuelnOverThres.45.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.45	3Gauge	0
iblfQuelnOverThres.45.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.45	4Gauge	0
iblfQuelnOverThres.45.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.45	5Gauge	0
iblfQuelnOverThres.45.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.45	6Gauge	0
iblfQuelnOverThres.45.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.45	7Gauge	0
iblfQuelnOverThres.45.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.45	8Gauge	0
iblfQuelnOverThres.46.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.46	1Gauge	0
iblfQuelnOverThres.46.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.46	2Gauge	0
iblfQuelnOverThres.46.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.46	3Gauge	0
iblfQuelnOverThres.46.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.46	4Gauge	0
iblfQuelnOverThres.46.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.46	5Gauge	0
iblfQuelnOverThres.46.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.46	6Gauge	0
iblfQuelnOverThres.46.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.46	7Gauge	0
iblfQuelnOverThres.46.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.46	8Gauge	0
iblfQuelnOverThres.47.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.47	1Gauge	0
iblfQuelnOverThres.47.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.47	2Gauge	0
iblfQuelnOverThres.47.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.47	3Gauge	0
iblfQuelnOverThres.47.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.47	4Gauge	0
iblfQuelnOverThres.47.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.47	5Gauge	0
iblfQuelnOverThres.47.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.47	6Gauge	0
iblfQuelnOverThres.47.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.47	7Gauge	0
iblfQuelnOverThres.47.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.47	8Gauge	0
iblfQuelnOverThres.48.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.48	1Gauge	0
iblfQuelnOverThres.48.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.48	2Gauge	0
iblfQuelnOverThres.48.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.48	3Gauge	0
iblfQuelnOverThres.48.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.48	4Gauge	0
iblfQuelnOverThres.48.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.48	5Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnOverThres.48.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.48	6Gauge	0
iblfQuelnOverThres.48.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.48	7Gauge	0
iblfQuelnOverThres.48.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.48	8Gauge	0
iblfQuelnOverThres.49.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.49	1Gauge	0
iblfQuelnOverThres.49.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.49	2Gauge	0
iblfQuelnOverThres.49.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.49	3Gauge	0
iblfQuelnOverThres.49.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.49	4Gauge	0
iblfQuelnOverThres.49.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.49	5Gauge	0
iblfQuelnOverThres.49.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.49	6Gauge	0
iblfQuelnOverThres.49.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.49	7Gauge	0
iblfQuelnOverThres.49.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.49	8Gauge	0
iblfQuelnOverThres.50.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.50	1Gauge	0
iblfQuelnOverThres.50.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.50	2Gauge	0
iblfQuelnOverThres.50.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.50	3Gauge	0
iblfQuelnOverThres.50.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.50	4Gauge	0
iblfQuelnOverThres.50.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.50	5Gauge	0
iblfQuelnOverThres.50.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.50	6Gauge	0
iblfQuelnOverThres.50.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.50	7Gauge	0
iblfQuelnOverThres.50.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.50	8Gauge	0
iblfQuelnOverThres.51.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.51	1Gauge	0
iblfQuelnOverThres.51.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.51	2Gauge	0
iblfQuelnOverThres.51.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.51	3Gauge	0
iblfQuelnOverThres.51.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.51	4Gauge	0
iblfQuelnOverThres.51.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.51	5Gauge	0
iblfQuelnOverThres.51.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.51	6Gauge	0
iblfQuelnOverThres.51.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.51	7Gauge	0
iblfQuelnOverThres.51.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.51	8Gauge	0
iblfQuelnOverThres.52.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.52	1Gauge	0
iblfQuelnOverThres.52.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.52	2Gauge	0
iblfQuelnOverThres.52.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.52	3Gauge	0
iblfQuelnOverThres.52.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.52	4Gauge	0
iblfQuelnOverThres.52.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.52	5Gauge	0
iblfQuelnOverThres.52.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.52	6Gauge	0
iblfQuelnOverThres.52.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.52	7Gauge	0
iblfQuelnOverThres.52.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.52	8Gauge	0
iblfQuelnOverThres.53.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.53	1Gauge	0
iblfQuelnOverThres.53.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.53	2Gauge	0
iblfQuelnOverThres.53.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.53	3Gauge	0
iblfQuelnOverThres.53.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.53	4Gauge	0
iblfQuelnOverThres.53.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.53	5Gauge	0
iblfQuelnOverThres.53.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.53	6Gauge	0
iblfQuelnOverThres.53.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.53	7Gauge	0
iblfQuelnOverThres.53.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.53	8Gauge	0

Name	OID	Value Type	Value Example
ibLfQuelnOverThres.54.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.54.1	Gauge	0
ibLfQuelnOverThres.54.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.54.2	Gauge	0
ibLfQuelnOverThres.54.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.54.3	Gauge	0
ibLfQuelnOverThres.54.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.54.4	Gauge	0
ibLfQuelnOverThres.54.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.54.5	Gauge	0
ibLfQuelnOverThres.54.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.54.6	Gauge	0
ibLfQuelnOverThres.54.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.54.7	Gauge	0
ibLfQuelnOverThres.54.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.13.54.8	Gauge	0
ibLfQuelnHeadRoomTotal.1.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.1.1	Gauge	0
ibLfQuelnHeadRoomTotal.1.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.1.2	Gauge	0
ibLfQuelnHeadRoomTotal.1.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.1.3	Gauge	0
ibLfQuelnHeadRoomTotal.1.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.1.4	Gauge	0
ibLfQuelnHeadRoomTotal.1.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.1.5	Gauge	0
ibLfQuelnHeadRoomTotal.1.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.1.6	Gauge	0
ibLfQuelnHeadRoomTotal.1.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.1.7	Gauge	0
ibLfQuelnHeadRoomTotal.1.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.1.8	Gauge	0
ibLfQuelnHeadRoomTotal.2.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.2.1	Gauge	0
ibLfQuelnHeadRoomTotal.2.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.2.2	Gauge	0
ibLfQuelnHeadRoomTotal.2.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.2.3	Gauge	0
ibLfQuelnHeadRoomTotal.2.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.2.4	Gauge	0
ibLfQuelnHeadRoomTotal.2.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.2.5	Gauge	0
ibLfQuelnHeadRoomTotal.2.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.2.6	Gauge	0
ibLfQuelnHeadRoomTotal.2.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.2.7	Gauge	0
ibLfQuelnHeadRoomTotal.2.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.2.8	Gauge	0
ibLfQuelnHeadRoomTotal.3.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.3.1	Gauge	0
ibLfQuelnHeadRoomTotal.3.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.3.2	Gauge	0
ibLfQuelnHeadRoomTotal.3.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.3.3	Gauge	0
ibLfQuelnHeadRoomTotal.3.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.3.4	Gauge	0
ibLfQuelnHeadRoomTotal.3.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.3.5	Gauge	0
ibLfQuelnHeadRoomTotal.3.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.3.6	Gauge	0
ibLfQuelnHeadRoomTotal.3.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.3.7	Gauge	0
ibLfQuelnHeadRoomTotal.3.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.3.8	Gauge	0
ibLfQuelnHeadRoomTotal.4.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.4.1	Gauge	0
ibLfQuelnHeadRoomTotal.4.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.4.2	Gauge	0
ibLfQuelnHeadRoomTotal.4.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.4.3	Gauge	0
ibLfQuelnHeadRoomTotal.4.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.4.4	Gauge	0
ibLfQuelnHeadRoomTotal.4.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.4.5	Gauge	0
ibLfQuelnHeadRoomTotal.4.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.4.6	Gauge	0
ibLfQuelnHeadRoomTotal.4.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.4.7	Gauge	0
ibLfQuelnHeadRoomTotal.4.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.4.8	Gauge	0
ibLfQuelnHeadRoomTotal.5.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.5.1	Gauge	0
ibLfQuelnHeadRoomTotal.5.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.5.2	Gauge	0
ibLfQuelnHeadRoomTotal.5.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.5.3	Gauge	0



Name	OID	Value Type	Value Example
iblfQuelnHeadRoomTotal.5.4	.3.6.1.4.1.26138.2.40.2.2.6.1.14.5.4	Gauge	0
iblfQuelnHeadRoomTotal.5.5	.3.6.1.4.1.26138.2.40.2.2.6.1.14.5.5	Gauge	0
iblfQuelnHeadRoomTotal.5.6	.3.6.1.4.1.26138.2.40.2.2.6.1.14.5.6	Gauge	0
iblfQuelnHeadRoomTotal.5.7	.3.6.1.4.1.26138.2.40.2.2.6.1.14.5.7	Gauge	0
iblfQuelnHeadRoomTotal.5.8	.3.6.1.4.1.26138.2.40.2.2.6.1.14.5.8	Gauge	0
iblfQuelnHeadRoomTotal.6.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.6.1	Gauge	0
iblfQuelnHeadRoomTotal.6.2	.3.6.1.4.1.26138.2.40.2.2.6.1.14.6.2	Gauge	0
iblfQuelnHeadRoomTotal.6.3	.3.6.1.4.1.26138.2.40.2.2.6.1.14.6.3	Gauge	0
iblfQuelnHeadRoomTotal.6.4	.3.6.1.4.1.26138.2.40.2.2.6.1.14.6.4	Gauge	0
iblfQuelnHeadRoomTotal.6.5	.3.6.1.4.1.26138.2.40.2.2.6.1.14.6.5	Gauge	0
iblfQuelnHeadRoomTotal.6.6	.3.6.1.4.1.26138.2.40.2.2.6.1.14.6.6	Gauge	0
iblfQuelnHeadRoomTotal.6.7	.3.6.1.4.1.26138.2.40.2.2.6.1.14.6.7	Gauge	0
iblfQuelnHeadRoomTotal.6.8	.3.6.1.4.1.26138.2.40.2.2.6.1.14.6.8	Gauge	0
iblfQuelnHeadRoomTotal.7.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.7.1	Gauge	0
iblfQuelnHeadRoomTotal.7.2	.3.6.1.4.1.26138.2.40.2.2.6.1.14.7.2	Gauge	0
iblfQuelnHeadRoomTotal.7.3	.3.6.1.4.1.26138.2.40.2.2.6.1.14.7.3	Gauge	0
iblfQuelnHeadRoomTotal.7.4	.3.6.1.4.1.26138.2.40.2.2.6.1.14.7.4	Gauge	0
iblfQuelnHeadRoomTotal.7.5	.3.6.1.4.1.26138.2.40.2.2.6.1.14.7.5	Gauge	0
iblfQuelnHeadRoomTotal.7.6	.3.6.1.4.1.26138.2.40.2.2.6.1.14.7.6	Gauge	0
iblfQuelnHeadRoomTotal.7.7	.3.6.1.4.1.26138.2.40.2.2.6.1.14.7.7	Gauge	0
iblfQuelnHeadRoomTotal.7.8	.3.6.1.4.1.26138.2.40.2.2.6.1.14.7.8	Gauge	0
iblfQuelnHeadRoomTotal.8.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.8.1	Gauge	0
iblfQuelnHeadRoomTotal.8.2	.3.6.1.4.1.26138.2.40.2.2.6.1.14.8.2	Gauge	0
iblfQuelnHeadRoomTotal.8.3	.3.6.1.4.1.26138.2.40.2.2.6.1.14.8.3	Gauge	0
iblfQuelnHeadRoomTotal.8.4	.3.6.1.4.1.26138.2.40.2.2.6.1.14.8.4	Gauge	0
iblfQuelnHeadRoomTotal.8.5	.3.6.1.4.1.26138.2.40.2.2.6.1.14.8.5	Gauge	0
iblfQuelnHeadRoomTotal.8.6	.3.6.1.4.1.26138.2.40.2.2.6.1.14.8.6	Gauge	0
iblfQuelnHeadRoomTotal.8.7	.3.6.1.4.1.26138.2.40.2.2.6.1.14.8.7	Gauge	0
iblfQuelnHeadRoomTotal.8.8	.3.6.1.4.1.26138.2.40.2.2.6.1.14.8.8	Gauge	0
iblfQuelnHeadRoomTotal.9.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.9.1	Gauge	0
iblfQuelnHeadRoomTotal.9.2	.3.6.1.4.1.26138.2.40.2.2.6.1.14.9.2	Gauge	0
iblfQuelnHeadRoomTotal.9.3	.3.6.1.4.1.26138.2.40.2.2.6.1.14.9.3	Gauge	0
iblfQuelnHeadRoomTotal.9.4	.3.6.1.4.1.26138.2.40.2.2.6.1.14.9.4	Gauge	0
iblfQuelnHeadRoomTotal.9.5	.3.6.1.4.1.26138.2.40.2.2.6.1.14.9.5	Gauge	0
iblfQuelnHeadRoomTotal.9.6	.3.6.1.4.1.26138.2.40.2.2.6.1.14.9.6	Gauge	0
iblfQuelnHeadRoomTotal.9.7	.3.6.1.4.1.26138.2.40.2.2.6.1.14.9.7	Gauge	0
iblfQuelnHeadRoomTotal.9.8	.3.6.1.4.1.26138.2.40.2.2.6.1.14.9.8	Gauge	0
iblfQuelnHeadRoomTotal.10.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.10.1	Gauge	0
iblfQuelnHeadRoomTotal.10.2	.3.6.1.4.1.26138.2.40.2.2.6.1.14.10.2	Gauge	0
iblfQuelnHeadRoomTotal.10.3	.3.6.1.4.1.26138.2.40.2.2.6.1.14.10.3	Gauge	0
iblfQuelnHeadRoomTotal.10.4	.3.6.1.4.1.26138.2.40.2.2.6.1.14.10.4	Gauge	0
iblfQuelnHeadRoomTotal.10.5	.3.6.1.4.1.26138.2.40.2.2.6.1.14.10.5	Gauge	0
iblfQuelnHeadRoomTotal.10.6	.3.6.1.4.1.26138.2.40.2.2.6.1.14.10.6	Gauge	0



Name	OID	Value Type	Value Example
iblfQuelnHeadRoomTotal.10.7.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.10	7Gauge	0
iblfQuelnHeadRoomTotal.10.8.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.10	8Gauge	0
iblfQuelnHeadRoomTotal.11.1.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.11	1Gauge	0
iblfQuelnHeadRoomTotal.11.2.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.11	2Gauge	0
iblfQuelnHeadRoomTotal.11.3.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.11	3Gauge	0
iblfQuelnHeadRoomTotal.11.4.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.11	4Gauge	0
iblfQuelnHeadRoomTotal.11.5.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.11	5Gauge	0
iblfQuelnHeadRoomTotal.11.6.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.11	6Gauge	0
iblfQuelnHeadRoomTotal.11.7.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.11	7Gauge	0
iblfQuelnHeadRoomTotal.11.8.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.11	8Gauge	0
iblfQuelnHeadRoomTotal.12.1.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.12	1Gauge	0
iblfQuelnHeadRoomTotal.12.2.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.12	2Gauge	0
iblfQuelnHeadRoomTotal.12.3.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.12	3Gauge	0
iblfQuelnHeadRoomTotal.12.4.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.12	4Gauge	0
iblfQuelnHeadRoomTotal.12.5.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.12	5Gauge	0
iblfQuelnHeadRoomTotal.12.6.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.12	6Gauge	0
iblfQuelnHeadRoomTotal.12.7.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.12	7Gauge	0
iblfQuelnHeadRoomTotal.12.8.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.12	8Gauge	0
iblfQuelnHeadRoomTotal.13.1.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.13	1Gauge	0
iblfQuelnHeadRoomTotal.13.2.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.13	2Gauge	0
iblfQuelnHeadRoomTotal.13.3.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.13	3Gauge	0
iblfQuelnHeadRoomTotal.13.4.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.13	4Gauge	0
iblfQuelnHeadRoomTotal.13.5.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.13	5Gauge	0
iblfQuelnHeadRoomTotal.13.6.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.13	6Gauge	0
iblfQuelnHeadRoomTotal.13.7.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.13	7Gauge	0
iblfQuelnHeadRoomTotal.13.8.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.13	8Gauge	0
iblfQuelnHeadRoomTotal.14.1.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.14	1Gauge	0
iblfQuelnHeadRoomTotal.14.2.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.14	2Gauge	0
iblfQuelnHeadRoomTotal.14.3.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.14	3Gauge	0
iblfQuelnHeadRoomTotal.14.4.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.14	4Gauge	0
iblfQuelnHeadRoomTotal.14.5.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.14	5Gauge	0
iblfQuelnHeadRoomTotal.14.6.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.14	6Gauge	0
iblfQuelnHeadRoomTotal.14.7.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.14	7Gauge	0
iblfQuelnHeadRoomTotal.14.8.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.14	8Gauge	0
iblfQuelnHeadRoomTotal.15.1.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.15	1Gauge	0
iblfQuelnHeadRoomTotal.15.2.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.15	2Gauge	0
iblfQuelnHeadRoomTotal.15.3.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.15	3Gauge	0
iblfQuelnHeadRoomTotal.15.4.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.15	4Gauge	0
iblfQuelnHeadRoomTotal.15.5.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.15	5Gauge	0
iblfQuelnHeadRoomTotal.15.6.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.15	6Gauge	0
iblfQuelnHeadRoomTotal.15.7.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.15	7Gauge	0
iblfQuelnHeadRoomTotal.15.8.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.15	8Gauge	0
iblfQuelnHeadRoomTotal.16.1.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.16	1Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnHeadRoomTotal.16.2.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.16	2Gauge	0
iblfQuelnHeadRoomTotal.16.3.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.16	3Gauge	0
iblfQuelnHeadRoomTotal.16.4.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.16	4Gauge	0
iblfQuelnHeadRoomTotal.16.5.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.16	5Gauge	0
iblfQuelnHeadRoomTotal.16.6.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.16	6Gauge	0
iblfQuelnHeadRoomTotal.16.7.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.16	7Gauge	0
iblfQuelnHeadRoomTotal.16.8.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.16	8Gauge	0
iblfQuelnHeadRoomTotal.17.1.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.17	1Gauge	0
iblfQuelnHeadRoomTotal.17.2.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.17	2Gauge	0
iblfQuelnHeadRoomTotal.17.3.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.17	3Gauge	0
iblfQuelnHeadRoomTotal.17.4.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.17	4Gauge	0
iblfQuelnHeadRoomTotal.17.5.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.17	5Gauge	0
iblfQuelnHeadRoomTotal.17.6.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.17	6Gauge	0
iblfQuelnHeadRoomTotal.17.7.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.17	7Gauge	0
iblfQuelnHeadRoomTotal.17.8.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.17	8Gauge	0
iblfQuelnHeadRoomTotal.18.1.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.18	1Gauge	0
iblfQuelnHeadRoomTotal.18.2.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.18	2Gauge	0
iblfQuelnHeadRoomTotal.18.3.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.18	3Gauge	0
iblfQuelnHeadRoomTotal.18.4.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.18	4Gauge	0
iblfQuelnHeadRoomTotal.18.5.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.18	5Gauge	0
iblfQuelnHeadRoomTotal.18.6.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.18	6Gauge	0
iblfQuelnHeadRoomTotal.18.7.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.18	7Gauge	0
iblfQuelnHeadRoomTotal.18.8.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.18	8Gauge	0
iblfQuelnHeadRoomTotal.19.1.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.19	1Gauge	0
iblfQuelnHeadRoomTotal.19.2.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.19	2Gauge	0
iblfQuelnHeadRoomTotal.19.3.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.19	3Gauge	0
iblfQuelnHeadRoomTotal.19.4.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.19	4Gauge	0
iblfQuelnHeadRoomTotal.19.5.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.19	5Gauge	0
iblfQuelnHeadRoomTotal.19.6.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.19	6Gauge	0
iblfQuelnHeadRoomTotal.19.7.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.19	7Gauge	0
iblfQuelnHeadRoomTotal.19.8.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.19	8Gauge	0
iblfQuelnHeadRoomTotal.20.1.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.20	1Gauge	0
iblfQuelnHeadRoomTotal.20.2.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.20	2Gauge	0
iblfQuelnHeadRoomTotal.20.3.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.20	3Gauge	0
iblfQuelnHeadRoomTotal.20.4.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.20	4Gauge	0
iblfQuelnHeadRoomTotal.20.5.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.20	5Gauge	0
iblfQuelnHeadRoomTotal.20.6.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.20	6Gauge	0
iblfQuelnHeadRoomTotal.20.7.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.20	7Gauge	0
iblfQuelnHeadRoomTotal.20.8.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.20	8Gauge	0
iblfQuelnHeadRoomTotal.21.1.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.21	1Gauge	0
iblfQuelnHeadRoomTotal.21.2.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.21	2Gauge	0
iblfQuelnHeadRoomTotal.21.3.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.21	3Gauge	0
iblfQuelnHeadRoomTotal.21.4.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.21	4Gauge	0



Name	OID	Value Type	Value Example
iblfQuelnHeadRoomTotal.26.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.26	8Gauge	0
iblfQuelnHeadRoomTotal.27.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.27	1Gauge	0
iblfQuelnHeadRoomTotal.27.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.27	2Gauge	0
iblfQuelnHeadRoomTotal.27.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.27	3Gauge	0
iblfQuelnHeadRoomTotal.27.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.27	4Gauge	0
iblfQuelnHeadRoomTotal.27.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.27	5Gauge	0
iblfQuelnHeadRoomTotal.27.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.27	6Gauge	0
iblfQuelnHeadRoomTotal.27.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.27	7Gauge	0
iblfQuelnHeadRoomTotal.27.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.27	8Gauge	0
iblfQuelnHeadRoomTotal.28.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.28	1Gauge	0
iblfQuelnHeadRoomTotal.28.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.28	2Gauge	0
iblfQuelnHeadRoomTotal.28.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.28	3Gauge	0
iblfQuelnHeadRoomTotal.28.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.28	4Gauge	0
iblfQuelnHeadRoomTotal.28.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.28	5Gauge	0
iblfQuelnHeadRoomTotal.28.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.28	6Gauge	0
iblfQuelnHeadRoomTotal.28.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.28	7Gauge	0
iblfQuelnHeadRoomTotal.28.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.28	8Gauge	0
iblfQuelnHeadRoomTotal.29.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.29	1Gauge	0
iblfQuelnHeadRoomTotal.29.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.29	2Gauge	0
iblfQuelnHeadRoomTotal.29.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.29	3Gauge	0
iblfQuelnHeadRoomTotal.29.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.29	4Gauge	0
iblfQuelnHeadRoomTotal.29.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.29	5Gauge	0
iblfQuelnHeadRoomTotal.29.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.29	6Gauge	0
iblfQuelnHeadRoomTotal.29.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.29	7Gauge	0
iblfQuelnHeadRoomTotal.29.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.29	8Gauge	0
iblfQuelnHeadRoomTotal.30.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.30	1Gauge	0
iblfQuelnHeadRoomTotal.30.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.30	2Gauge	0
iblfQuelnHeadRoomTotal.30.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.30	3Gauge	0
iblfQuelnHeadRoomTotal.30.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.30	4Gauge	0
iblfQuelnHeadRoomTotal.30.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.30	5Gauge	0
iblfQuelnHeadRoomTotal.30.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.30	6Gauge	0
iblfQuelnHeadRoomTotal.30.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.30	7Gauge	0
iblfQuelnHeadRoomTotal.30.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.30	8Gauge	0
iblfQuelnHeadRoomTotal.31.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.31	1Gauge	0
iblfQuelnHeadRoomTotal.31.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.31	2Gauge	0
iblfQuelnHeadRoomTotal.31.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.31	3Gauge	0
iblfQuelnHeadRoomTotal.31.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.31	4Gauge	0
iblfQuelnHeadRoomTotal.31.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.31	5Gauge	0
iblfQuelnHeadRoomTotal.31.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.31	6Gauge	0
iblfQuelnHeadRoomTotal.31.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.31	7Gauge	0
iblfQuelnHeadRoomTotal.31.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.31	8Gauge	0
iblfQuelnHeadRoomTotal.32.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.32	1Gauge	0
iblfQuelnHeadRoomTotal.32.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.14.32	2Gauge	0



Name	OID	Value Type	Value Example
iblfQuelnHeadRoomTotal.37.6 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.37		6Gauge	0
iblfQuelnHeadRoomTotal.37.7 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.37		7Gauge	0
iblfQuelnHeadRoomTotal.37.8 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.37		8Gauge	0
iblfQuelnHeadRoomTotal.38.1 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.38		1Gauge	0
iblfQuelnHeadRoomTotal.38.2 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.38		2Gauge	0
iblfQuelnHeadRoomTotal.38.3 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.38		3Gauge	0
iblfQuelnHeadRoomTotal.38.4 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.38		4Gauge	0
iblfQuelnHeadRoomTotal.38.5 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.38		5Gauge	0
iblfQuelnHeadRoomTotal.38.6 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.38		6Gauge	0
iblfQuelnHeadRoomTotal.38.7 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.38		7Gauge	0
iblfQuelnHeadRoomTotal.38.8 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.38		8Gauge	0
iblfQuelnHeadRoomTotal.39.1 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.39		1Gauge	0
iblfQuelnHeadRoomTotal.39.2 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.39		2Gauge	0
iblfQuelnHeadRoomTotal.39.3 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.39		3Gauge	0
iblfQuelnHeadRoomTotal.39.4 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.39		4Gauge	0
iblfQuelnHeadRoomTotal.39.5 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.39		5Gauge	0
iblfQuelnHeadRoomTotal.39.6 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.39		6Gauge	0
iblfQuelnHeadRoomTotal.39.7 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.39		7Gauge	0
iblfQuelnHeadRoomTotal.39.8 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.39		8Gauge	0
iblfQuelnHeadRoomTotal.40.1 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.40		1Gauge	0
iblfQuelnHeadRoomTotal.40.2 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.40		2Gauge	0
iblfQuelnHeadRoomTotal.40.3 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.40		3Gauge	0
iblfQuelnHeadRoomTotal.40.4 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.40		4Gauge	0
iblfQuelnHeadRoomTotal.40.5 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.40		5Gauge	0
iblfQuelnHeadRoomTotal.40.6 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.40		6Gauge	0
iblfQuelnHeadRoomTotal.40.7 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.40		7Gauge	0
iblfQuelnHeadRoomTotal.40.8 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.40		8Gauge	0
iblfQuelnHeadRoomTotal.41.1 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.41		1Gauge	0
iblfQuelnHeadRoomTotal.41.2 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.41		2Gauge	0
iblfQuelnHeadRoomTotal.41.3 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.41		3Gauge	0
iblfQuelnHeadRoomTotal.41.4 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.41		4Gauge	0
iblfQuelnHeadRoomTotal.41.5 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.41		5Gauge	0
iblfQuelnHeadRoomTotal.41.6 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.41		6Gauge	0
iblfQuelnHeadRoomTotal.41.7 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.41		7Gauge	0
iblfQuelnHeadRoomTotal.41.8 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.41		8Gauge	0
iblfQuelnHeadRoomTotal.42.1 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.42		1Gauge	0
iblfQuelnHeadRoomTotal.42.2 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.42		2Gauge	0
iblfQuelnHeadRoomTotal.42.3 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.42		3Gauge	0
iblfQuelnHeadRoomTotal.42.4 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.42		4Gauge	0
iblfQuelnHeadRoomTotal.42.5 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.42		5Gauge	0
iblfQuelnHeadRoomTotal.42.6 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.42		6Gauge	0
iblfQuelnHeadRoomTotal.42.7 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.42		7Gauge	0
iblfQuelnHeadRoomTotal.42.8 .1.3.6.1.4.1.26138.2.40.2.2.6.1.14.42		8Gauge	0









Name	OID	Value Type	Value Example
iblfQuelnHeadRoomTotal.53.7.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.53	7Gauge	0
iblfQuelnHeadRoomTotal.53.8.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.53	8Gauge	0
iblfQuelnHeadRoomTotal.54.1.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.54	1Gauge	0
iblfQuelnHeadRoomTotal.54.2.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.54	2Gauge	0
iblfQuelnHeadRoomTotal.54.3.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.54	3Gauge	0
iblfQuelnHeadRoomTotal.54.4.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.54	4Gauge	0
iblfQuelnHeadRoomTotal.54.5.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.54	5Gauge	0
iblfQuelnHeadRoomTotal.54.6.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.54	6Gauge	0
iblfQuelnHeadRoomTotal.54.7.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.54	7Gauge	0
iblfQuelnHeadRoomTotal.54.8.1	.3.6.1.4.1.26138.2.40.2.2.6.1.14.54	8Gauge	0
iblfQuelnHeadRoomFree.1.1	.3.6.1.4.1.26138.2.40.2.2.6.1.15.1.1	1 Gauge	0
iblfQuelnHeadRoomFree.1.2	.3.6.1.4.1.26138.2.40.2.2.6.1.15.1.2	2 Gauge	0
iblfQuelnHeadRoomFree.1.3	.3.6.1.4.1.26138.2.40.2.2.6.1.15.1.3	3 Gauge	0
iblfQuelnHeadRoomFree.1.4	.3.6.1.4.1.26138.2.40.2.2.6.1.15.1.4	4 Gauge	0
iblfQuelnHeadRoomFree.1.5	.3.6.1.4.1.26138.2.40.2.2.6.1.15.1.5	5 Gauge	0
iblfQuelnHeadRoomFree.1.6	.3.6.1.4.1.26138.2.40.2.2.6.1.15.1.6	6 Gauge	0
iblfQuelnHeadRoomFree.1.7	.3.6.1.4.1.26138.2.40.2.2.6.1.15.1.7	7 Gauge	0
iblfQuelnHeadRoomFree.1.8	.3.6.1.4.1.26138.2.40.2.2.6.1.15.1.8	8 Gauge	0
iblfQuelnHeadRoomFree.2.1	.3.6.1.4.1.26138.2.40.2.2.6.1.15.2.1	1 Gauge	0
iblfQuelnHeadRoomFree.2.2	.3.6.1.4.1.26138.2.40.2.2.6.1.15.2.2	2 Gauge	0
iblfQuelnHeadRoomFree.2.3	.3.6.1.4.1.26138.2.40.2.2.6.1.15.2.3	3 Gauge	0
iblfQuelnHeadRoomFree.2.4	.3.6.1.4.1.26138.2.40.2.2.6.1.15.2.4	4 Gauge	0
iblfQuelnHeadRoomFree.2.5	.3.6.1.4.1.26138.2.40.2.2.6.1.15.2.5	5 Gauge	0
iblfQuelnHeadRoomFree.2.6	.3.6.1.4.1.26138.2.40.2.2.6.1.15.2.6	6 Gauge	0
iblfQuelnHeadRoomFree.2.7	.3.6.1.4.1.26138.2.40.2.2.6.1.15.2.7	7 Gauge	0
iblfQuelnHeadRoomFree.2.8	.3.6.1.4.1.26138.2.40.2.2.6.1.15.2.8	8 Gauge	0
iblfQuelnHeadRoomFree.3.1	.3.6.1.4.1.26138.2.40.2.2.6.1.15.3.1	1 Gauge	0
iblfQuelnHeadRoomFree.3.2	.3.6.1.4.1.26138.2.40.2.2.6.1.15.3.2	2 Gauge	0
iblfQuelnHeadRoomFree.3.3	.3.6.1.4.1.26138.2.40.2.2.6.1.15.3.3	3 Gauge	0
iblfQuelnHeadRoomFree.3.4	.3.6.1.4.1.26138.2.40.2.2.6.1.15.3.4	4 Gauge	0
iblfQuelnHeadRoomFree.3.5	.3.6.1.4.1.26138.2.40.2.2.6.1.15.3.5	5 Gauge	0
iblfQuelnHeadRoomFree.3.6	.3.6.1.4.1.26138.2.40.2.2.6.1.15.3.6	6 Gauge	0
iblfQuelnHeadRoomFree.3.7	.3.6.1.4.1.26138.2.40.2.2.6.1.15.3.7	7 Gauge	0
iblfQuelnHeadRoomFree.3.8	.3.6.1.4.1.26138.2.40.2.2.6.1.15.3.8	8 Gauge	0
iblfQuelnHeadRoomFree.4.1	.3.6.1.4.1.26138.2.40.2.2.6.1.15.4.1	1 Gauge	0
iblfQuelnHeadRoomFree.4.2	.3.6.1.4.1.26138.2.40.2.2.6.1.15.4.2	2 Gauge	0
iblfQuelnHeadRoomFree.4.3	.3.6.1.4.1.26138.2.40.2.2.6.1.15.4.3	3 Gauge	0
iblfQuelnHeadRoomFree.4.4	.3.6.1.4.1.26138.2.40.2.2.6.1.15.4.4	4 Gauge	0
iblfQuelnHeadRoomFree.4.5	.3.6.1.4.1.26138.2.40.2.2.6.1.15.4.5	5 Gauge	0
iblfQuelnHeadRoomFree.4.6	.3.6.1.4.1.26138.2.40.2.2.6.1.15.4.6	6 Gauge	0
iblfQuelnHeadRoomFree.4.7	.3.6.1.4.1.26138.2.40.2.2.6.1.15.4.7	7 Gauge	0
iblfQuelnHeadRoomFree.4.8	.3.6.1.4.1.26138.2.40.2.2.6.1.15.4.8	8 Gauge	0
iblfQuelnHeadRoomFree.5.1	.3.6.1.4.1.26138.2.40.2.2.6.1.15.5.1	1 Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnHeadRoomFree.5.2	.3.6.1.4.1.26138.2.40.2.2.6.1.15.5.2	Gauge	0
iblfQuelnHeadRoomFree.5.3	.3.6.1.4.1.26138.2.40.2.2.6.1.15.5.3	Gauge	0
iblfQuelnHeadRoomFree.5.4	.3.6.1.4.1.26138.2.40.2.2.6.1.15.5.4	Gauge	0
iblfQuelnHeadRoomFree.5.5	.3.6.1.4.1.26138.2.40.2.2.6.1.15.5.5	Gauge	0
iblfQuelnHeadRoomFree.5.6	.3.6.1.4.1.26138.2.40.2.2.6.1.15.5.6	Gauge	0
iblfQuelnHeadRoomFree.5.7	.3.6.1.4.1.26138.2.40.2.2.6.1.15.5.7	Gauge	0
iblfQuelnHeadRoomFree.5.8	.3.6.1.4.1.26138.2.40.2.2.6.1.15.5.8	Gauge	0
iblfQuelnHeadRoomFree.6.1	.3.6.1.4.1.26138.2.40.2.2.6.1.15.6.1	Gauge	0
iblfQuelnHeadRoomFree.6.2	.3.6.1.4.1.26138.2.40.2.2.6.1.15.6.2	Gauge	0
iblfQuelnHeadRoomFree.6.3	.3.6.1.4.1.26138.2.40.2.2.6.1.15.6.3	Gauge	0
iblfQuelnHeadRoomFree.6.4	.3.6.1.4.1.26138.2.40.2.2.6.1.15.6.4	Gauge	0
iblfQuelnHeadRoomFree.6.5	.3.6.1.4.1.26138.2.40.2.2.6.1.15.6.5	Gauge	0
iblfQuelnHeadRoomFree.6.6	.3.6.1.4.1.26138.2.40.2.2.6.1.15.6.6	Gauge	0
iblfQuelnHeadRoomFree.6.7	.3.6.1.4.1.26138.2.40.2.2.6.1.15.6.7	Gauge	0
iblfQuelnHeadRoomFree.6.8	.3.6.1.4.1.26138.2.40.2.2.6.1.15.6.8	Gauge	0
iblfQuelnHeadRoomFree.7.1	.3.6.1.4.1.26138.2.40.2.2.6.1.15.7.1	Gauge	0
iblfQuelnHeadRoomFree.7.2	.3.6.1.4.1.26138.2.40.2.2.6.1.15.7.2	Gauge	0
iblfQuelnHeadRoomFree.7.3	.3.6.1.4.1.26138.2.40.2.2.6.1.15.7.3	Gauge	0
iblfQuelnHeadRoomFree.7.4	.3.6.1.4.1.26138.2.40.2.2.6.1.15.7.4	Gauge	0
iblfQuelnHeadRoomFree.7.5	.3.6.1.4.1.26138.2.40.2.2.6.1.15.7.5	Gauge	0
iblfQuelnHeadRoomFree.7.6	.3.6.1.4.1.26138.2.40.2.2.6.1.15.7.6	Gauge	0
iblfQuelnHeadRoomFree.7.7	.3.6.1.4.1.26138.2.40.2.2.6.1.15.7.7	Gauge	0
iblfQuelnHeadRoomFree.7.8	.3.6.1.4.1.26138.2.40.2.2.6.1.15.7.8	Gauge	0
iblfQuelnHeadRoomFree.8.1	.3.6.1.4.1.26138.2.40.2.2.6.1.15.8.1	Gauge	0
iblfQuelnHeadRoomFree.8.2	.3.6.1.4.1.26138.2.40.2.2.6.1.15.8.2	Gauge	0
iblfQuelnHeadRoomFree.8.3	.3.6.1.4.1.26138.2.40.2.2.6.1.15.8.3	Gauge	0
iblfQuelnHeadRoomFree.8.4	.3.6.1.4.1.26138.2.40.2.2.6.1.15.8.4	Gauge	0
iblfQuelnHeadRoomFree.8.5	.3.6.1.4.1.26138.2.40.2.2.6.1.15.8.5	Gauge	0
iblfQuelnHeadRoomFree.8.6	.3.6.1.4.1.26138.2.40.2.2.6.1.15.8.6	Gauge	0
iblfQuelnHeadRoomFree.8.7	.3.6.1.4.1.26138.2.40.2.2.6.1.15.8.7	Gauge	0
iblfQuelnHeadRoomFree.8.8	.3.6.1.4.1.26138.2.40.2.2.6.1.15.8.8	Gauge	0
iblfQuelnHeadRoomFree.9.1	.3.6.1.4.1.26138.2.40.2.2.6.1.15.9.1	Gauge	0
iblfQuelnHeadRoomFree.9.2	.3.6.1.4.1.26138.2.40.2.2.6.1.15.9.2	Gauge	0
iblfQuelnHeadRoomFree.9.3	.3.6.1.4.1.26138.2.40.2.2.6.1.15.9.3	Gauge	0
iblfQuelnHeadRoomFree.9.4	.3.6.1.4.1.26138.2.40.2.2.6.1.15.9.4	Gauge	0
iblfQuelnHeadRoomFree.9.5	.3.6.1.4.1.26138.2.40.2.2.6.1.15.9.5	Gauge	0
iblfQuelnHeadRoomFree.9.6	.3.6.1.4.1.26138.2.40.2.2.6.1.15.9.6	Gauge	0
iblfQuelnHeadRoomFree.9.7	.3.6.1.4.1.26138.2.40.2.2.6.1.15.9.7	Gauge	0
iblfQuelnHeadRoomFree.9.8	.3.6.1.4.1.26138.2.40.2.2.6.1.15.9.8	Gauge	0
iblfQuelnHeadRoomFree.10.1	.3.6.1.4.1.26138.2.40.2.2.6.1.15.10.1	Gauge	0
iblfQuelnHeadRoomFree.10.2	.3.6.1.4.1.26138.2.40.2.2.6.1.15.10.2	Gauge	0
iblfQuelnHeadRoomFree.10.3	.3.6.1.4.1.26138.2.40.2.2.6.1.15.10.3	Gauge	0
iblfQuelnHeadRoomFree.10.4	.3.6.1.4.1.26138.2.40.2.2.6.1.15.10.4	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnHeadRoomFree.10.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.10	5Gauge	0
iblfQuelnHeadRoomFree.10.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.10	6Gauge	0
iblfQuelnHeadRoomFree.10.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.10	7Gauge	0
iblfQuelnHeadRoomFree.10.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.10	8Gauge	0
iblfQuelnHeadRoomFree.11.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.11	1Gauge	0
iblfQuelnHeadRoomFree.11.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.11	2Gauge	0
iblfQuelnHeadRoomFree.11.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.11	3Gauge	0
iblfQuelnHeadRoomFree.11.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.11	4Gauge	0
iblfQuelnHeadRoomFree.11.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.11	5Gauge	0
iblfQuelnHeadRoomFree.11.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.11	6Gauge	0
iblfQuelnHeadRoomFree.11.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.11	7Gauge	0
iblfQuelnHeadRoomFree.11.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.11	8Gauge	0
iblfQuelnHeadRoomFree.12.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.12	1Gauge	0
iblfQuelnHeadRoomFree.12.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.12	2Gauge	0
iblfQuelnHeadRoomFree.12.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.12	3Gauge	0
iblfQuelnHeadRoomFree.12.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.12	4Gauge	0
iblfQuelnHeadRoomFree.12.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.12	5Gauge	0
iblfQuelnHeadRoomFree.12.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.12	6Gauge	0
iblfQuelnHeadRoomFree.12.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.12	7Gauge	0
iblfQuelnHeadRoomFree.12.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.12	8Gauge	0
iblfQuelnHeadRoomFree.13.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.13	1Gauge	0
iblfQuelnHeadRoomFree.13.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.13	2Gauge	0
iblfQuelnHeadRoomFree.13.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.13	3Gauge	0
iblfQuelnHeadRoomFree.13.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.13	4Gauge	0
iblfQuelnHeadRoomFree.13.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.13	5Gauge	0
iblfQuelnHeadRoomFree.13.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.13	6Gauge	0
iblfQuelnHeadRoomFree.13.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.13	7Gauge	0
iblfQuelnHeadRoomFree.13.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.13	8Gauge	0
iblfQuelnHeadRoomFree.14.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.14	1Gauge	0
iblfQuelnHeadRoomFree.14.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.14	2Gauge	0
iblfQuelnHeadRoomFree.14.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.14	3Gauge	0
iblfQuelnHeadRoomFree.14.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.14	4Gauge	0
iblfQuelnHeadRoomFree.14.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.14	5Gauge	0
iblfQuelnHeadRoomFree.14.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.14	6Gauge	0
iblfQuelnHeadRoomFree.14.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.14	7Gauge	0
iblfQuelnHeadRoomFree.14.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.14	8Gauge	0
iblfQuelnHeadRoomFree.15.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.15	1Gauge	0
iblfQuelnHeadRoomFree.15.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.15	2Gauge	0
iblfQuelnHeadRoomFree.15.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.15	3Gauge	0
iblfQuelnHeadRoomFree.15.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.15	4Gauge	0
iblfQuelnHeadRoomFree.15.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.15	5Gauge	0
iblfQuelnHeadRoomFree.15.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.15	6Gauge	0
iblfQuelnHeadRoomFree.15.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.15	7Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnHeadRoomFree.15.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.15	8Gauge	0
iblfQuelnHeadRoomFree.16.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.16	1Gauge	0
iblfQuelnHeadRoomFree.16.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.16	2Gauge	0
iblfQuelnHeadRoomFree.16.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.16	3Gauge	0
iblfQuelnHeadRoomFree.16.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.16	4Gauge	0
iblfQuelnHeadRoomFree.16.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.16	5Gauge	0
iblfQuelnHeadRoomFree.16.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.16	6Gauge	0
iblfQuelnHeadRoomFree.16.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.16	7Gauge	0
iblfQuelnHeadRoomFree.16.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.16	8Gauge	0
iblfQuelnHeadRoomFree.17.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.17	1Gauge	0
iblfQuelnHeadRoomFree.17.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.17	2Gauge	0
iblfQuelnHeadRoomFree.17.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.17	3Gauge	0
iblfQuelnHeadRoomFree.17.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.17	4Gauge	0
iblfQuelnHeadRoomFree.17.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.17	5Gauge	0
iblfQuelnHeadRoomFree.17.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.17	6Gauge	0
iblfQuelnHeadRoomFree.17.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.17	7Gauge	0
iblfQuelnHeadRoomFree.17.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.17	8Gauge	0
iblfQuelnHeadRoomFree.18.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.18	1Gauge	0
iblfQuelnHeadRoomFree.18.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.18	2Gauge	0
iblfQuelnHeadRoomFree.18.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.18	3Gauge	0
iblfQuelnHeadRoomFree.18.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.18	4Gauge	0
iblfQuelnHeadRoomFree.18.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.18	5Gauge	0
iblfQuelnHeadRoomFree.18.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.18	6Gauge	0
iblfQuelnHeadRoomFree.18.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.18	7Gauge	0
iblfQuelnHeadRoomFree.18.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.18	8Gauge	0
iblfQuelnHeadRoomFree.19.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.19	1Gauge	0
iblfQuelnHeadRoomFree.19.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.19	2Gauge	0
iblfQuelnHeadRoomFree.19.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.19	3Gauge	0
iblfQuelnHeadRoomFree.19.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.19	4Gauge	0
iblfQuelnHeadRoomFree.19.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.19	5Gauge	0
iblfQuelnHeadRoomFree.19.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.19	6Gauge	0
iblfQuelnHeadRoomFree.19.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.19	7Gauge	0
iblfQuelnHeadRoomFree.19.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.19	8Gauge	0
iblfQuelnHeadRoomFree.20.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.20	1Gauge	0
iblfQuelnHeadRoomFree.20.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.20	2Gauge	0
iblfQuelnHeadRoomFree.20.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.20	3Gauge	0
iblfQuelnHeadRoomFree.20.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.20	4Gauge	0
iblfQuelnHeadRoomFree.20.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.20	5Gauge	0
iblfQuelnHeadRoomFree.20.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.20	6Gauge	0
iblfQuelnHeadRoomFree.20.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.20	7Gauge	0
iblfQuelnHeadRoomFree.20.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.20	8Gauge	0
iblfQuelnHeadRoomFree.21.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.21	1Gauge	0
iblfQuelnHeadRoomFree.21.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.21	2Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnHeadRoomFree.21.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.21	3Gauge	0
iblfQuelnHeadRoomFree.21.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.21	4Gauge	0
iblfQuelnHeadRoomFree.21.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.21	5Gauge	0
iblfQuelnHeadRoomFree.21.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.21	6Gauge	0
iblfQuelnHeadRoomFree.21.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.21	7Gauge	0
iblfQuelnHeadRoomFree.21.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.21	8Gauge	0
iblfQuelnHeadRoomFree.22.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.22	1Gauge	0
iblfQuelnHeadRoomFree.22.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.22	2Gauge	0
iblfQuelnHeadRoomFree.22.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.22	3Gauge	0
iblfQuelnHeadRoomFree.22.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.22	4Gauge	0
iblfQuelnHeadRoomFree.22.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.22	5Gauge	0
iblfQuelnHeadRoomFree.22.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.22	6Gauge	0
iblfQuelnHeadRoomFree.22.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.22	7Gauge	0
iblfQuelnHeadRoomFree.22.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.22	8Gauge	0
iblfQuelnHeadRoomFree.23.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.23	1Gauge	0
iblfQuelnHeadRoomFree.23.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.23	2Gauge	0
iblfQuelnHeadRoomFree.23.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.23	3Gauge	0
iblfQuelnHeadRoomFree.23.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.23	4Gauge	0
iblfQuelnHeadRoomFree.23.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.23	5Gauge	0
iblfQuelnHeadRoomFree.23.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.23	6Gauge	0
iblfQuelnHeadRoomFree.23.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.23	7Gauge	0
iblfQuelnHeadRoomFree.23.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.23	8Gauge	0
iblfQuelnHeadRoomFree.24.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.24	1Gauge	0
iblfQuelnHeadRoomFree.24.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.24	2Gauge	0
iblfQuelnHeadRoomFree.24.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.24	3Gauge	0
iblfQuelnHeadRoomFree.24.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.24	4Gauge	0
iblfQuelnHeadRoomFree.24.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.24	5Gauge	0
iblfQuelnHeadRoomFree.24.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.24	6Gauge	0
iblfQuelnHeadRoomFree.24.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.24	7Gauge	0
iblfQuelnHeadRoomFree.24.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.24	8Gauge	0
iblfQuelnHeadRoomFree.25.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.25	1Gauge	0
iblfQuelnHeadRoomFree.25.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.25	2Gauge	0
iblfQuelnHeadRoomFree.25.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.25	3Gauge	0
iblfQuelnHeadRoomFree.25.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.25	4Gauge	0
iblfQuelnHeadRoomFree.25.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.25	5Gauge	0
iblfQuelnHeadRoomFree.25.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.25	6Gauge	0
iblfQuelnHeadRoomFree.25.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.25	7Gauge	0
iblfQuelnHeadRoomFree.25.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.25	8Gauge	0
iblfQuelnHeadRoomFree.26.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.26	1Gauge	0
iblfQuelnHeadRoomFree.26.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.26	2Gauge	0
iblfQuelnHeadRoomFree.26.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.26	3Gauge	0
iblfQuelnHeadRoomFree.26.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.26	4Gauge	0
iblfQuelnHeadRoomFree.26.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.26	5Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnHeadRoomFree.26.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.26	6Gauge	0
iblfQuelnHeadRoomFree.26.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.26	7Gauge	0
iblfQuelnHeadRoomFree.26.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.26	8Gauge	0
iblfQuelnHeadRoomFree.27.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.27	1Gauge	0
iblfQuelnHeadRoomFree.27.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.27	2Gauge	0
iblfQuelnHeadRoomFree.27.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.27	3Gauge	0
iblfQuelnHeadRoomFree.27.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.27	4Gauge	0
iblfQuelnHeadRoomFree.27.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.27	5Gauge	0
iblfQuelnHeadRoomFree.27.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.27	6Gauge	0
iblfQuelnHeadRoomFree.27.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.27	7Gauge	0
iblfQuelnHeadRoomFree.27.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.27	8Gauge	0
iblfQuelnHeadRoomFree.28.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.28	1Gauge	0
iblfQuelnHeadRoomFree.28.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.28	2Gauge	0
iblfQuelnHeadRoomFree.28.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.28	3Gauge	0
iblfQuelnHeadRoomFree.28.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.28	4Gauge	0
iblfQuelnHeadRoomFree.28.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.28	5Gauge	0
iblfQuelnHeadRoomFree.28.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.28	6Gauge	0
iblfQuelnHeadRoomFree.28.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.28	7Gauge	0
iblfQuelnHeadRoomFree.28.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.28	8Gauge	0
iblfQuelnHeadRoomFree.29.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.29	1Gauge	0
iblfQuelnHeadRoomFree.29.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.29	2Gauge	0
iblfQuelnHeadRoomFree.29.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.29	3Gauge	0
iblfQuelnHeadRoomFree.29.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.29	4Gauge	0
iblfQuelnHeadRoomFree.29.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.29	5Gauge	0
iblfQuelnHeadRoomFree.29.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.29	6Gauge	0
iblfQuelnHeadRoomFree.29.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.29	7Gauge	0
iblfQuelnHeadRoomFree.29.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.29	8Gauge	0
iblfQuelnHeadRoomFree.30.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.30	1Gauge	0
iblfQuelnHeadRoomFree.30.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.30	2Gauge	0
iblfQuelnHeadRoomFree.30.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.30	3Gauge	0
iblfQuelnHeadRoomFree.30.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.30	4Gauge	0
iblfQuelnHeadRoomFree.30.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.30	5Gauge	0
iblfQuelnHeadRoomFree.30.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.30	6Gauge	0
iblfQuelnHeadRoomFree.30.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.30	7Gauge	0
iblfQuelnHeadRoomFree.30.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.30	8Gauge	0
iblfQuelnHeadRoomFree.31.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.31	1Gauge	0
iblfQuelnHeadRoomFree.31.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.31	2Gauge	0
iblfQuelnHeadRoomFree.31.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.31	3Gauge	0
iblfQuelnHeadRoomFree.31.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.31	4Gauge	0
iblfQuelnHeadRoomFree.31.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.31	5Gauge	0
iblfQuelnHeadRoomFree.31.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.31	6Gauge	0
iblfQuelnHeadRoomFree.31.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.31	7Gauge	0
iblfQuelnHeadRoomFree.31.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.31	8Gauge	0



Name	OID	Value Type	Value Example
iblfQuelnHeadRoomFree.32.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.32	1Gauge	0
iblfQuelnHeadRoomFree.32.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.32	2Gauge	0
iblfQuelnHeadRoomFree.32.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.32	3Gauge	0
iblfQuelnHeadRoomFree.32.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.32	4Gauge	0
iblfQuelnHeadRoomFree.32.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.32	5Gauge	0
iblfQuelnHeadRoomFree.32.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.32	6Gauge	0
iblfQuelnHeadRoomFree.32.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.32	7Gauge	0
iblfQuelnHeadRoomFree.32.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.32	8Gauge	0
iblfQuelnHeadRoomFree.33.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.33	1Gauge	0
iblfQuelnHeadRoomFree.33.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.33	2Gauge	0
iblfQuelnHeadRoomFree.33.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.33	3Gauge	0
iblfQuelnHeadRoomFree.33.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.33	4Gauge	0
iblfQuelnHeadRoomFree.33.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.33	5Gauge	0
iblfQuelnHeadRoomFree.33.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.33	6Gauge	0
iblfQuelnHeadRoomFree.33.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.33	7Gauge	0
iblfQuelnHeadRoomFree.33.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.33	8Gauge	0
iblfQuelnHeadRoomFree.34.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.34	1Gauge	0
iblfQuelnHeadRoomFree.34.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.34	2Gauge	0
iblfQuelnHeadRoomFree.34.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.34	3Gauge	0
iblfQuelnHeadRoomFree.34.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.34	4Gauge	0
iblfQuelnHeadRoomFree.34.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.34	5Gauge	0
iblfQuelnHeadRoomFree.34.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.34	6Gauge	0
iblfQuelnHeadRoomFree.34.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.34	7Gauge	0
iblfQuelnHeadRoomFree.34.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.34	8Gauge	0
iblfQuelnHeadRoomFree.35.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.35	1Gauge	0
iblfQuelnHeadRoomFree.35.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.35	2Gauge	0
iblfQuelnHeadRoomFree.35.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.35	3Gauge	0
iblfQuelnHeadRoomFree.35.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.35	4Gauge	0
iblfQuelnHeadRoomFree.35.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.35	5Gauge	0
iblfQuelnHeadRoomFree.35.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.35	6Gauge	0
iblfQuelnHeadRoomFree.35.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.35	7Gauge	0
iblfQuelnHeadRoomFree.35.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.35	8Gauge	0
iblfQuelnHeadRoomFree.36.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.36	1Gauge	0
iblfQuelnHeadRoomFree.36.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.36	2Gauge	0
iblfQuelnHeadRoomFree.36.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.36	3Gauge	0
iblfQuelnHeadRoomFree.36.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.36	4Gauge	0
iblfQuelnHeadRoomFree.36.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.36	5Gauge	0
iblfQuelnHeadRoomFree.36.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.36	6Gauge	0
iblfQuelnHeadRoomFree.36.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.36	7Gauge	0
iblfQuelnHeadRoomFree.36.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.36	8Gauge	0
iblfQuelnHeadRoomFree.37.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.37	1Gauge	0
iblfQuelnHeadRoomFree.37.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.37	2Gauge	0
iblfQuelnHeadRoomFree.37.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.37	3Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnHeadRoomFree.37.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.37	4Gauge	0
iblfQuelnHeadRoomFree.37.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.37	5Gauge	0
iblfQuelnHeadRoomFree.37.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.37	6Gauge	0
iblfQuelnHeadRoomFree.37.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.37	7Gauge	0
iblfQuelnHeadRoomFree.37.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.37	8Gauge	0
iblfQuelnHeadRoomFree.38.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.38	1Gauge	0
iblfQuelnHeadRoomFree.38.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.38	2Gauge	0
iblfQuelnHeadRoomFree.38.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.38	3Gauge	0
iblfQuelnHeadRoomFree.38.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.38	4Gauge	0
iblfQuelnHeadRoomFree.38.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.38	5Gauge	0
iblfQuelnHeadRoomFree.38.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.38	6Gauge	0
iblfQuelnHeadRoomFree.38.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.38	7Gauge	0
iblfQuelnHeadRoomFree.38.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.38	8Gauge	0
iblfQuelnHeadRoomFree.39.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.39	1Gauge	0
iblfQuelnHeadRoomFree.39.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.39	2Gauge	0
iblfQuelnHeadRoomFree.39.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.39	3Gauge	0
iblfQuelnHeadRoomFree.39.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.39	4Gauge	0
iblfQuelnHeadRoomFree.39.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.39	5Gauge	0
iblfQuelnHeadRoomFree.39.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.39	6Gauge	0
iblfQuelnHeadRoomFree.39.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.39	7Gauge	0
iblfQuelnHeadRoomFree.39.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.39	8Gauge	0
iblfQuelnHeadRoomFree.40.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.40	1Gauge	0
iblfQuelnHeadRoomFree.40.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.40	2Gauge	0
iblfQuelnHeadRoomFree.40.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.40	3Gauge	0
iblfQuelnHeadRoomFree.40.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.40	4Gauge	0
iblfQuelnHeadRoomFree.40.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.40	5Gauge	0
iblfQuelnHeadRoomFree.40.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.40	6Gauge	0
iblfQuelnHeadRoomFree.40.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.40	7Gauge	0
iblfQuelnHeadRoomFree.40.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.40	8Gauge	0
iblfQuelnHeadRoomFree.41.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.41	1Gauge	0
iblfQuelnHeadRoomFree.41.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.41	2Gauge	0
iblfQuelnHeadRoomFree.41.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.41	3Gauge	0
iblfQuelnHeadRoomFree.41.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.41	4Gauge	0
iblfQuelnHeadRoomFree.41.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.41	5Gauge	0
iblfQuelnHeadRoomFree.41.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.41	6Gauge	0
iblfQuelnHeadRoomFree.41.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.41	7Gauge	0
iblfQuelnHeadRoomFree.41.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.41	8Gauge	0
iblfQuelnHeadRoomFree.42.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.42	1Gauge	0
iblfQuelnHeadRoomFree.42.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.42	2Gauge	0
iblfQuelnHeadRoomFree.42.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.42	3Gauge	0
iblfQuelnHeadRoomFree.42.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.42	4Gauge	0
iblfQuelnHeadRoomFree.42.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.42	5Gauge	0
iblfQuelnHeadRoomFree.42.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.42	6Gauge	0



Name	OID	Value Type	Value Example
iblfQueInHeadRoomFree.42.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.42	7Gauge	0
iblfQueInHeadRoomFree.42.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.42	8Gauge	0
iblfQueInHeadRoomFree.43.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.43	1Gauge	0
iblfQueInHeadRoomFree.43.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.43	2Gauge	0
iblfQueInHeadRoomFree.43.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.43	3Gauge	0
iblfQueInHeadRoomFree.43.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.43	4Gauge	0
iblfQueInHeadRoomFree.43.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.43	5Gauge	0
iblfQueInHeadRoomFree.43.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.43	6Gauge	0
iblfQueInHeadRoomFree.43.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.43	7Gauge	0
iblfQueInHeadRoomFree.43.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.43	8Gauge	0
iblfQueInHeadRoomFree.44.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.44	1Gauge	0
iblfQueInHeadRoomFree.44.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.44	2Gauge	0
iblfQueInHeadRoomFree.44.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.44	3Gauge	0
iblfQueInHeadRoomFree.44.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.44	4Gauge	0
iblfQueInHeadRoomFree.44.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.44	5Gauge	0
iblfQueInHeadRoomFree.44.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.44	6Gauge	0
iblfQueInHeadRoomFree.44.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.44	7Gauge	0
iblfQueInHeadRoomFree.44.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.44	8Gauge	0
iblfQueInHeadRoomFree.45.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.45	1Gauge	0
iblfQueInHeadRoomFree.45.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.45	2Gauge	0
iblfQueInHeadRoomFree.45.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.45	3Gauge	0
iblfQueInHeadRoomFree.45.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.45	4Gauge	0
iblfQueInHeadRoomFree.45.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.45	5Gauge	0
iblfQueInHeadRoomFree.45.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.45	6Gauge	0
iblfQueInHeadRoomFree.45.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.45	7Gauge	0
iblfQueInHeadRoomFree.45.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.45	8Gauge	0
iblfQueInHeadRoomFree.46.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.46	1Gauge	0
iblfQueInHeadRoomFree.46.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.46	2Gauge	0
iblfQueInHeadRoomFree.46.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.46	3Gauge	0
iblfQueInHeadRoomFree.46.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.46	4Gauge	0
iblfQueInHeadRoomFree.46.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.46	5Gauge	0
iblfQueInHeadRoomFree.46.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.46	6Gauge	0
iblfQueInHeadRoomFree.46.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.46	7Gauge	0
iblfQueInHeadRoomFree.46.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.46	8Gauge	0
iblfQueInHeadRoomFree.47.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.47	1Gauge	0
iblfQueInHeadRoomFree.47.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.47	2Gauge	0
iblfQueInHeadRoomFree.47.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.47	3Gauge	0
iblfQueInHeadRoomFree.47.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.47	4Gauge	0
iblfQueInHeadRoomFree.47.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.47	5Gauge	0
iblfQueInHeadRoomFree.47.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.47	6Gauge	0
iblfQueInHeadRoomFree.47.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.47	7Gauge	0
iblfQueInHeadRoomFree.47.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.47	8Gauge	0
iblfQueInHeadRoomFree.48.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.48	1Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnHeadRoomFree.48.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.48	2Gauge	0
iblfQuelnHeadRoomFree.48.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.48	3Gauge	0
iblfQuelnHeadRoomFree.48.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.48	4Gauge	0
iblfQuelnHeadRoomFree.48.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.48	5Gauge	0
iblfQuelnHeadRoomFree.48.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.48	6Gauge	0
iblfQuelnHeadRoomFree.48.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.48	7Gauge	0
iblfQuelnHeadRoomFree.48.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.48	8Gauge	0
iblfQuelnHeadRoomFree.49.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.49	1Gauge	0
iblfQuelnHeadRoomFree.49.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.49	2Gauge	0
iblfQuelnHeadRoomFree.49.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.49	3Gauge	0
iblfQuelnHeadRoomFree.49.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.49	4Gauge	0
iblfQuelnHeadRoomFree.49.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.49	5Gauge	0
iblfQuelnHeadRoomFree.49.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.49	6Gauge	0
iblfQuelnHeadRoomFree.49.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.49	7Gauge	0
iblfQuelnHeadRoomFree.49.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.49	8Gauge	0
iblfQuelnHeadRoomFree.50.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.50	1Gauge	0
iblfQuelnHeadRoomFree.50.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.50	2Gauge	0
iblfQuelnHeadRoomFree.50.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.50	3Gauge	0
iblfQuelnHeadRoomFree.50.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.50	4Gauge	0
iblfQuelnHeadRoomFree.50.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.50	5Gauge	0
iblfQuelnHeadRoomFree.50.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.50	6Gauge	0
iblfQuelnHeadRoomFree.50.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.50	7Gauge	0
iblfQuelnHeadRoomFree.50.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.50	8Gauge	0
iblfQuelnHeadRoomFree.51.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.51	1Gauge	0
iblfQuelnHeadRoomFree.51.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.51	2Gauge	0
iblfQuelnHeadRoomFree.51.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.51	3Gauge	0
iblfQuelnHeadRoomFree.51.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.51	4Gauge	0
iblfQuelnHeadRoomFree.51.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.51	5Gauge	0
iblfQuelnHeadRoomFree.51.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.51	6Gauge	0
iblfQuelnHeadRoomFree.51.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.51	7Gauge	0
iblfQuelnHeadRoomFree.51.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.51	8Gauge	0
iblfQuelnHeadRoomFree.52.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.52	1Gauge	0
iblfQuelnHeadRoomFree.52.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.52	2Gauge	0
iblfQuelnHeadRoomFree.52.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.52	3Gauge	0
iblfQuelnHeadRoomFree.52.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.52	4Gauge	0
iblfQuelnHeadRoomFree.52.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.52	5Gauge	0
iblfQuelnHeadRoomFree.52.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.52	6Gauge	0
iblfQuelnHeadRoomFree.52.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.52	7Gauge	0
iblfQuelnHeadRoomFree.52.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.52	8Gauge	0
iblfQuelnHeadRoomFree.53.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.53	1Gauge	0
iblfQuelnHeadRoomFree.53.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.53	2Gauge	0
iblfQuelnHeadRoomFree.53.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.53	3Gauge	0
iblfQuelnHeadRoomFree.53.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.53	4Gauge	0

Name	OID	Value Type	Value Example
ibLfQueInHeadRoomFree.53.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.53	5Gauge	0
ibLfQueInHeadRoomFree.53.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.53	6Gauge	0
ibLfQueInHeadRoomFree.53.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.53	7Gauge	0
ibLfQueInHeadRoomFree.53.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.53	8Gauge	0
ibLfQueInHeadRoomFree.54.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.54	1Gauge	0
ibLfQueInHeadRoomFree.54.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.54	2Gauge	0
ibLfQueInHeadRoomFree.54.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.54	3Gauge	0
ibLfQueInHeadRoomFree.54.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.54	4Gauge	0
ibLfQueInHeadRoomFree.54.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.54	5Gauge	0
ibLfQueInHeadRoomFree.54.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.54	6Gauge	0
ibLfQueInHeadRoomFree.54.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.54	7Gauge	0
ibLfQueInHeadRoomFree.54.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.15.54	8Gauge	0
ibLfQueInHeadRoomUsedRatio.1.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.1	1 Gauge	0
ibLfQueInHeadRoomUsedRatio.1.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.1	2 Gauge	0
ibLfQueInHeadRoomUsedRatio.1.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.1	3 Gauge	0
ibLfQueInHeadRoomUsedRatio.1.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.1	4 Gauge	0
ibLfQueInHeadRoomUsedRatio.1.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.1	5 Gauge	0
ibLfQueInHeadRoomUsedRatio.1.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.1	6 Gauge	0
ibLfQueInHeadRoomUsedRatio.1.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.1	7 Gauge	0
ibLfQueInHeadRoomUsedRatio.1.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.1	8 Gauge	0
ibLfQueInHeadRoomUsedRatio.2.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.2	1 Gauge	0
ibLfQueInHeadRoomUsedRatio.2.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.2	2 Gauge	0
ibLfQueInHeadRoomUsedRatio.2.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.2	3 Gauge	0
ibLfQueInHeadRoomUsedRatio.2.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.2	4 Gauge	0
ibLfQueInHeadRoomUsedRatio.2.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.2	5 Gauge	0
ibLfQueInHeadRoomUsedRatio.2.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.2	6 Gauge	0
ibLfQueInHeadRoomUsedRatio.2.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.2	7 Gauge	0
ibLfQueInHeadRoomUsedRatio.2.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.2	8 Gauge	0
ibLfQueInHeadRoomUsedRatio.3.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.3	1 Gauge	0
ibLfQueInHeadRoomUsedRatio.3.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.3	2 Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnHeadRoomUsedRatio.3.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.3.3	Gauge	0
iblfQuelnHeadRoomUsedRatio.3.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.3.4	Gauge	0
iblfQuelnHeadRoomUsedRatio.3.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.3.5	Gauge	0
iblfQuelnHeadRoomUsedRatio.3.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.3.6	Gauge	0
iblfQuelnHeadRoomUsedRatio.3.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.3.7	Gauge	0
iblfQuelnHeadRoomUsedRatio.3.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.3.8	Gauge	0
iblfQuelnHeadRoomUsedRatio.4.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.4.1	Gauge	0
iblfQuelnHeadRoomUsedRatio.4.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.4.2	Gauge	0
iblfQuelnHeadRoomUsedRatio.4.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.4.3	Gauge	0
iblfQuelnHeadRoomUsedRatio.4.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.4.4	Gauge	0
iblfQuelnHeadRoomUsedRatio.4.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.4.5	Gauge	0
iblfQuelnHeadRoomUsedRatio.4.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.4.6	Gauge	0
iblfQuelnHeadRoomUsedRatio.4.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.4.7	Gauge	0
iblfQuelnHeadRoomUsedRatio.4.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.4.8	Gauge	0
iblfQuelnHeadRoomUsedRatio.5.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.5.1	Gauge	0
iblfQuelnHeadRoomUsedRatio.5.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.5.2	Gauge	0
iblfQuelnHeadRoomUsedRatio.5.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.5.3	Gauge	0
iblfQuelnHeadRoomUsedRatio.5.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.5.4	Gauge	0
iblfQuelnHeadRoomUsedRatio.5.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.5.5	Gauge	0
iblfQuelnHeadRoomUsedRatio.5.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.5.6	Gauge	0
iblfQuelnHeadRoomUsedRatio.5.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.5.7	Gauge	0
iblfQuelnHeadRoomUsedRatio.5.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.5.8	Gauge	0
iblfQuelnHeadRoomUsedRatio.6.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.6.1	Gauge	0
iblfQuelnHeadRoomUsedRatio.6.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.6.2	Gauge	0
iblfQuelnHeadRoomUsedRatio.6.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.6.3	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnHeadRoomUsedRatio.6.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.6.4	Gauge	0
iblfQuelnHeadRoomUsedRatio.6.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.6.5	Gauge	0
iblfQuelnHeadRoomUsedRatio.6.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.6.6	Gauge	0
iblfQuelnHeadRoomUsedRatio.6.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.6.7	Gauge	0
iblfQuelnHeadRoomUsedRatio.6.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.6.8	Gauge	0
iblfQuelnHeadRoomUsedRatio.7.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.7.1	Gauge	0
iblfQuelnHeadRoomUsedRatio.7.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.7.2	Gauge	0
iblfQuelnHeadRoomUsedRatio.7.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.7.3	Gauge	0
iblfQuelnHeadRoomUsedRatio.7.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.7.4	Gauge	0
iblfQuelnHeadRoomUsedRatio.7.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.7.5	Gauge	0
iblfQuelnHeadRoomUsedRatio.7.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.7.6	Gauge	0
iblfQuelnHeadRoomUsedRatio.7.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.7.7	Gauge	0
iblfQuelnHeadRoomUsedRatio.7.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.7.8	Gauge	0
iblfQuelnHeadRoomUsedRatio.8.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.8.1	Gauge	0
iblfQuelnHeadRoomUsedRatio.8.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.8.2	Gauge	0
iblfQuelnHeadRoomUsedRatio.8.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.8.3	Gauge	0
iblfQuelnHeadRoomUsedRatio.8.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.8.4	Gauge	0
iblfQuelnHeadRoomUsedRatio.8.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.8.5	Gauge	0
iblfQuelnHeadRoomUsedRatio.8.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.8.6	Gauge	0
iblfQuelnHeadRoomUsedRatio.8.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.8.7	Gauge	0
iblfQuelnHeadRoomUsedRatio.8.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.8.8	Gauge	0
iblfQuelnHeadRoomUsedRatio.9.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.9.1	Gauge	0
iblfQuelnHeadRoomUsedRatio.9.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.9.2	Gauge	0
iblfQuelnHeadRoomUsedRatio.9.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.9.3	Gauge	0
iblfQuelnHeadRoomUsedRatio.9.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.9.4	Gauge	0

Name	OID	Value Type	Value Example
iblfQueInHeadRoomUsedRatio.9.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.9.5	Gauge	0
iblfQueInHeadRoomUsedRatio.9.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.9.6	Gauge	0
iblfQueInHeadRoomUsedRatio.9.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.9.7	Gauge	0
iblfQueInHeadRoomUsedRatio.9.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.9.8	Gauge	0
iblfQueInHeadRoomUsedRatio.10.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.10.1	Gauge	0
iblfQueInHeadRoomUsedRatio.10.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.10.2	Gauge	0
iblfQueInHeadRoomUsedRatio.10.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.10.3	Gauge	0
iblfQueInHeadRoomUsedRatio.10.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.10.4	Gauge	0
iblfQueInHeadRoomUsedRatio.10.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.10.5	Gauge	0
iblfQueInHeadRoomUsedRatio.10.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.10.6	Gauge	0
iblfQueInHeadRoomUsedRatio.10.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.10.7	Gauge	0
iblfQueInHeadRoomUsedRatio.10.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.10.8	Gauge	0
iblfQueInHeadRoomUsedRatio.11.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.11.1	Gauge	0
iblfQueInHeadRoomUsedRatio.11.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.11.2	Gauge	0
iblfQueInHeadRoomUsedRatio.11.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.11.3	Gauge	0
iblfQueInHeadRoomUsedRatio.11.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.11.4	Gauge	0
iblfQueInHeadRoomUsedRatio.11.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.11.5	Gauge	0
iblfQueInHeadRoomUsedRatio.11.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.11.6	Gauge	0
iblfQueInHeadRoomUsedRatio.11.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.11.7	Gauge	0
iblfQueInHeadRoomUsedRatio.11.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.11.8	Gauge	0
iblfQueInHeadRoomUsedRatio.12.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.12.1	Gauge	0
iblfQueInHeadRoomUsedRatio.12.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.12.2	Gauge	0
iblfQueInHeadRoomUsedRatio.12.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.12.3	Gauge	0
iblfQueInHeadRoomUsedRatio.12.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.12.4	Gauge	0
iblfQueInHeadRoomUsedRatio.12.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.12.5	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnHeadRoomUsedRatio.12.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.12.6	Gauge	0
iblfQuelnHeadRoomUsedRatio.12.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.12.7	Gauge	0
iblfQuelnHeadRoomUsedRatio.12.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.12.8	Gauge	0
iblfQuelnHeadRoomUsedRatio.13.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.13.1	Gauge	0
iblfQuelnHeadRoomUsedRatio.13.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.13.2	Gauge	0
iblfQuelnHeadRoomUsedRatio.13.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.13.3	Gauge	0
iblfQuelnHeadRoomUsedRatio.13.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.13.4	Gauge	0
iblfQuelnHeadRoomUsedRatio.13.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.13.5	Gauge	0
iblfQuelnHeadRoomUsedRatio.13.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.13.6	Gauge	0
iblfQuelnHeadRoomUsedRatio.13.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.13.7	Gauge	0
iblfQuelnHeadRoomUsedRatio.13.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.13.8	Gauge	0
iblfQuelnHeadRoomUsedRatio.14.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.14.1	Gauge	0
iblfQuelnHeadRoomUsedRatio.14.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.14.2	Gauge	0
iblfQuelnHeadRoomUsedRatio.14.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.14.3	Gauge	0
iblfQuelnHeadRoomUsedRatio.14.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.14.4	Gauge	0
iblfQuelnHeadRoomUsedRatio.14.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.14.5	Gauge	0
iblfQuelnHeadRoomUsedRatio.14.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.14.6	Gauge	0
iblfQuelnHeadRoomUsedRatio.14.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.14.7	Gauge	0
iblfQuelnHeadRoomUsedRatio.14.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.14.8	Gauge	0
iblfQuelnHeadRoomUsedRatio.15.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.15.1	Gauge	0
iblfQuelnHeadRoomUsedRatio.15.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.15.2	Gauge	0
iblfQuelnHeadRoomUsedRatio.15.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.15.3	Gauge	0
iblfQuelnHeadRoomUsedRatio.15.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.15.4	Gauge	0
iblfQuelnHeadRoomUsedRatio.15.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.15.5	Gauge	0
iblfQuelnHeadRoomUsedRatio.15.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.15.6	Gauge	0

Name	OID	Value Type	Value Example
iblfQueInHeadRoomUsedRatio.15.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.15.7	Gauge	0
iblfQueInHeadRoomUsedRatio.15.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.15.8	Gauge	0
iblfQueInHeadRoomUsedRatio.16.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.16.1	Gauge	0
iblfQueInHeadRoomUsedRatio.16.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.16.2	Gauge	0
iblfQueInHeadRoomUsedRatio.16.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.16.3	Gauge	0
iblfQueInHeadRoomUsedRatio.16.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.16.4	Gauge	0
iblfQueInHeadRoomUsedRatio.16.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.16.5	Gauge	0
iblfQueInHeadRoomUsedRatio.16.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.16.6	Gauge	0
iblfQueInHeadRoomUsedRatio.16.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.16.7	Gauge	0
iblfQueInHeadRoomUsedRatio.16.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.16.8	Gauge	0
iblfQueInHeadRoomUsedRatio.17.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.17.1	Gauge	0
iblfQueInHeadRoomUsedRatio.17.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.17.2	Gauge	0
iblfQueInHeadRoomUsedRatio.17.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.17.3	Gauge	0
iblfQueInHeadRoomUsedRatio.17.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.17.4	Gauge	0
iblfQueInHeadRoomUsedRatio.17.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.17.5	Gauge	0
iblfQueInHeadRoomUsedRatio.17.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.17.6	Gauge	0
iblfQueInHeadRoomUsedRatio.17.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.17.7	Gauge	0
iblfQueInHeadRoomUsedRatio.17.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.17.8	Gauge	0
iblfQueInHeadRoomUsedRatio.18.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.18.1	Gauge	0
iblfQueInHeadRoomUsedRatio.18.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.18.2	Gauge	0
iblfQueInHeadRoomUsedRatio.18.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.18.3	Gauge	0
iblfQueInHeadRoomUsedRatio.18.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.18.4	Gauge	0
iblfQueInHeadRoomUsedRatio.18.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.18.5	Gauge	0
iblfQueInHeadRoomUsedRatio.18.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.18.6	Gauge	0
iblfQueInHeadRoomUsedRatio.18.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.18.7	Gauge	0



Name	OID	Value Type	Value Example
iblfQueInHeadRoomUsedRatio.18.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.18	8Gauge	0
iblfQueInHeadRoomUsedRatio.19.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.19	1Gauge	0
iblfQueInHeadRoomUsedRatio.19.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.19	2Gauge	0
iblfQueInHeadRoomUsedRatio.19.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.19	3Gauge	0
iblfQueInHeadRoomUsedRatio.19.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.19	4Gauge	0
iblfQueInHeadRoomUsedRatio.19.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.19	5Gauge	0
iblfQueInHeadRoomUsedRatio.19.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.19	6Gauge	0
iblfQueInHeadRoomUsedRatio.19.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.19	7Gauge	0
iblfQueInHeadRoomUsedRatio.19.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.19	8Gauge	0
iblfQueInHeadRoomUsedRatio.20.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.20	1Gauge	0
iblfQueInHeadRoomUsedRatio.20.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.20	2Gauge	0
iblfQueInHeadRoomUsedRatio.20.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.20	3Gauge	0
iblfQueInHeadRoomUsedRatio.20.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.20	4Gauge	0
iblfQueInHeadRoomUsedRatio.20.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.20	5Gauge	0
iblfQueInHeadRoomUsedRatio.20.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.20	6Gauge	0
iblfQueInHeadRoomUsedRatio.20.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.20	7Gauge	0
iblfQueInHeadRoomUsedRatio.20.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.20	8Gauge	0
iblfQueInHeadRoomUsedRatio.21.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.21	1Gauge	0
iblfQueInHeadRoomUsedRatio.21.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.21	2Gauge	0
iblfQueInHeadRoomUsedRatio.21.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.21	3Gauge	0
iblfQueInHeadRoomUsedRatio.21.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.21	4Gauge	0
iblfQueInHeadRoomUsedRatio.21.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.21	5Gauge	0
iblfQueInHeadRoomUsedRatio.21.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.21	6Gauge	0
iblfQueInHeadRoomUsedRatio.21.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.21	7Gauge	0
iblfQueInHeadRoomUsedRatio.21.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.21	8Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnHeadRoomUsedRatio.22.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.22	1Gauge	0
iblfQuelnHeadRoomUsedRatio.22.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.22	2Gauge	0
iblfQuelnHeadRoomUsedRatio.22.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.22	3Gauge	0
iblfQuelnHeadRoomUsedRatio.22.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.22	4Gauge	0
iblfQuelnHeadRoomUsedRatio.22.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.22	5Gauge	0
iblfQuelnHeadRoomUsedRatio.22.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.22	6Gauge	0
iblfQuelnHeadRoomUsedRatio.22.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.22	7Gauge	0
iblfQuelnHeadRoomUsedRatio.22.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.22	8Gauge	0
iblfQuelnHeadRoomUsedRatio.23.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.23	1Gauge	0
iblfQuelnHeadRoomUsedRatio.23.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.23	2Gauge	0
iblfQuelnHeadRoomUsedRatio.23.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.23	3Gauge	0
iblfQuelnHeadRoomUsedRatio.23.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.23	4Gauge	0
iblfQuelnHeadRoomUsedRatio.23.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.23	5Gauge	0
iblfQuelnHeadRoomUsedRatio.23.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.23	6Gauge	0
iblfQuelnHeadRoomUsedRatio.23.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.23	7Gauge	0
iblfQuelnHeadRoomUsedRatio.23.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.23	8Gauge	0
iblfQuelnHeadRoomUsedRatio.24.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.24	1Gauge	0
iblfQuelnHeadRoomUsedRatio.24.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.24	2Gauge	0
iblfQuelnHeadRoomUsedRatio.24.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.24	3Gauge	0
iblfQuelnHeadRoomUsedRatio.24.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.24	4Gauge	0
iblfQuelnHeadRoomUsedRatio.24.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.24	5Gauge	0
iblfQuelnHeadRoomUsedRatio.24.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.24	6Gauge	0
iblfQuelnHeadRoomUsedRatio.24.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.24	7Gauge	0
iblfQuelnHeadRoomUsedRatio.24.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.24	8Gauge	0
iblfQuelnHeadRoomUsedRatio.25.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.25	1Gauge	0

Name	OID	Value Type	Value Example
iblfQueInHeadRoomUsedRatio.25.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.25.2	Gauge	0
iblfQueInHeadRoomUsedRatio.25.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.25.3	Gauge	0
iblfQueInHeadRoomUsedRatio.25.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.25.4	Gauge	0
iblfQueInHeadRoomUsedRatio.25.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.25.5	Gauge	0
iblfQueInHeadRoomUsedRatio.25.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.25.6	Gauge	0
iblfQueInHeadRoomUsedRatio.25.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.25.7	Gauge	0
iblfQueInHeadRoomUsedRatio.25.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.25.8	Gauge	0
iblfQueInHeadRoomUsedRatio.26.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.26.1	Gauge	0
iblfQueInHeadRoomUsedRatio.26.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.26.2	Gauge	0
iblfQueInHeadRoomUsedRatio.26.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.26.3	Gauge	0
iblfQueInHeadRoomUsedRatio.26.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.26.4	Gauge	0
iblfQueInHeadRoomUsedRatio.26.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.26.5	Gauge	0
iblfQueInHeadRoomUsedRatio.26.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.26.6	Gauge	0
iblfQueInHeadRoomUsedRatio.26.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.26.7	Gauge	0
iblfQueInHeadRoomUsedRatio.26.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.26.8	Gauge	0
iblfQueInHeadRoomUsedRatio.27.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.27.1	Gauge	0
iblfQueInHeadRoomUsedRatio.27.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.27.2	Gauge	0
iblfQueInHeadRoomUsedRatio.27.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.27.3	Gauge	0
iblfQueInHeadRoomUsedRatio.27.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.27.4	Gauge	0
iblfQueInHeadRoomUsedRatio.27.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.27.5	Gauge	0
iblfQueInHeadRoomUsedRatio.27.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.27.6	Gauge	0
iblfQueInHeadRoomUsedRatio.27.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.27.7	Gauge	0
iblfQueInHeadRoomUsedRatio.27.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.27.8	Gauge	0
iblfQueInHeadRoomUsedRatio.28.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.28.1	Gauge	0
iblfQueInHeadRoomUsedRatio.28.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.28.2	Gauge	0

Name	OID	Value Type	Value Example
iblfQueInHeadRoomUsedRatio.28.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.283	Gauge	0
iblfQueInHeadRoomUsedRatio.28.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.284	Gauge	0
iblfQueInHeadRoomUsedRatio.28.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.285	Gauge	0
iblfQueInHeadRoomUsedRatio.28.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.286	Gauge	0
iblfQueInHeadRoomUsedRatio.28.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.287	Gauge	0
iblfQueInHeadRoomUsedRatio.28.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.288	Gauge	0
iblfQueInHeadRoomUsedRatio.29.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.291	Gauge	0
iblfQueInHeadRoomUsedRatio.29.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.292	Gauge	0
iblfQueInHeadRoomUsedRatio.29.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.293	Gauge	0
iblfQueInHeadRoomUsedRatio.29.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.294	Gauge	0
iblfQueInHeadRoomUsedRatio.29.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.295	Gauge	0
iblfQueInHeadRoomUsedRatio.29.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.296	Gauge	0
iblfQueInHeadRoomUsedRatio.29.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.297	Gauge	0
iblfQueInHeadRoomUsedRatio.29.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.298	Gauge	0
iblfQueInHeadRoomUsedRatio.30.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.301	Gauge	0
iblfQueInHeadRoomUsedRatio.30.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.302	Gauge	0
iblfQueInHeadRoomUsedRatio.30.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.303	Gauge	0
iblfQueInHeadRoomUsedRatio.30.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.304	Gauge	0
iblfQueInHeadRoomUsedRatio.30.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.305	Gauge	0
iblfQueInHeadRoomUsedRatio.30.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.306	Gauge	0
iblfQueInHeadRoomUsedRatio.30.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.307	Gauge	0
iblfQueInHeadRoomUsedRatio.30.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.308	Gauge	0
iblfQueInHeadRoomUsedRatio.31.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.311	Gauge	0
iblfQueInHeadRoomUsedRatio.31.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.312	Gauge	0
iblfQueInHeadRoomUsedRatio.31.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.313	Gauge	0

Name	OID	Value Type	Value Example
iblfQueInHeadRoomUsedRatio.31.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.31.4	Gauge	0
iblfQueInHeadRoomUsedRatio.31.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.31.5	Gauge	0
iblfQueInHeadRoomUsedRatio.31.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.31.6	Gauge	0
iblfQueInHeadRoomUsedRatio.31.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.31.7	Gauge	0
iblfQueInHeadRoomUsedRatio.31.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.31.8	Gauge	0
iblfQueInHeadRoomUsedRatio.32.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.32.1	Gauge	0
iblfQueInHeadRoomUsedRatio.32.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.32.2	Gauge	0
iblfQueInHeadRoomUsedRatio.32.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.32.3	Gauge	0
iblfQueInHeadRoomUsedRatio.32.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.32.4	Gauge	0
iblfQueInHeadRoomUsedRatio.32.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.32.5	Gauge	0
iblfQueInHeadRoomUsedRatio.32.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.32.6	Gauge	0
iblfQueInHeadRoomUsedRatio.32.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.32.7	Gauge	0
iblfQueInHeadRoomUsedRatio.32.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.32.8	Gauge	0
iblfQueInHeadRoomUsedRatio.33.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.33.1	Gauge	0
iblfQueInHeadRoomUsedRatio.33.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.33.2	Gauge	0
iblfQueInHeadRoomUsedRatio.33.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.33.3	Gauge	0
iblfQueInHeadRoomUsedRatio.33.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.33.4	Gauge	0
iblfQueInHeadRoomUsedRatio.33.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.33.5	Gauge	0
iblfQueInHeadRoomUsedRatio.33.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.33.6	Gauge	0
iblfQueInHeadRoomUsedRatio.33.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.33.7	Gauge	0
iblfQueInHeadRoomUsedRatio.33.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.33.8	Gauge	0
iblfQueInHeadRoomUsedRatio.34.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.34.1	Gauge	0
iblfQueInHeadRoomUsedRatio.34.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.34.2	Gauge	0
iblfQueInHeadRoomUsedRatio.34.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.34.3	Gauge	0
iblfQueInHeadRoomUsedRatio.34.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.34.4	Gauge	0

Name	OID	Value Type	Value Example
iblfQueInHeadRoomUsedRatio.34.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.34.5	Gauge	0
iblfQueInHeadRoomUsedRatio.34.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.34.6	Gauge	0
iblfQueInHeadRoomUsedRatio.34.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.34.7	Gauge	0
iblfQueInHeadRoomUsedRatio.34.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.34.8	Gauge	0
iblfQueInHeadRoomUsedRatio.35.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.35.1	Gauge	0
iblfQueInHeadRoomUsedRatio.35.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.35.2	Gauge	0
iblfQueInHeadRoomUsedRatio.35.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.35.3	Gauge	0
iblfQueInHeadRoomUsedRatio.35.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.35.4	Gauge	0
iblfQueInHeadRoomUsedRatio.35.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.35.5	Gauge	0
iblfQueInHeadRoomUsedRatio.35.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.35.6	Gauge	0
iblfQueInHeadRoomUsedRatio.35.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.35.7	Gauge	0
iblfQueInHeadRoomUsedRatio.35.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.35.8	Gauge	0
iblfQueInHeadRoomUsedRatio.36.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.36.1	Gauge	0
iblfQueInHeadRoomUsedRatio.36.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.36.2	Gauge	0
iblfQueInHeadRoomUsedRatio.36.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.36.3	Gauge	0
iblfQueInHeadRoomUsedRatio.36.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.36.4	Gauge	0
iblfQueInHeadRoomUsedRatio.36.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.36.5	Gauge	0
iblfQueInHeadRoomUsedRatio.36.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.36.6	Gauge	0
iblfQueInHeadRoomUsedRatio.36.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.36.7	Gauge	0
iblfQueInHeadRoomUsedRatio.36.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.36.8	Gauge	0
iblfQueInHeadRoomUsedRatio.37.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.37.1	Gauge	0
iblfQueInHeadRoomUsedRatio.37.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.37.2	Gauge	0
iblfQueInHeadRoomUsedRatio.37.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.37.3	Gauge	0
iblfQueInHeadRoomUsedRatio.37.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.37.4	Gauge	0
iblfQueInHeadRoomUsedRatio.37.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.37.5	Gauge	0

Name	OID	Value Type	Value Example
iblfQueInHeadRoomUsedRatio.37.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.37.6	Gauge	0
iblfQueInHeadRoomUsedRatio.37.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.37.7	Gauge	0
iblfQueInHeadRoomUsedRatio.37.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.37.8	Gauge	0
iblfQueInHeadRoomUsedRatio.38.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.38.1	Gauge	0
iblfQueInHeadRoomUsedRatio.38.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.38.2	Gauge	0
iblfQueInHeadRoomUsedRatio.38.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.38.3	Gauge	0
iblfQueInHeadRoomUsedRatio.38.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.38.4	Gauge	0
iblfQueInHeadRoomUsedRatio.38.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.38.5	Gauge	0
iblfQueInHeadRoomUsedRatio.38.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.38.6	Gauge	0
iblfQueInHeadRoomUsedRatio.38.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.38.7	Gauge	0
iblfQueInHeadRoomUsedRatio.38.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.38.8	Gauge	0
iblfQueInHeadRoomUsedRatio.39.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.39.1	Gauge	0
iblfQueInHeadRoomUsedRatio.39.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.39.2	Gauge	0
iblfQueInHeadRoomUsedRatio.39.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.39.3	Gauge	0
iblfQueInHeadRoomUsedRatio.39.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.39.4	Gauge	0
iblfQueInHeadRoomUsedRatio.39.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.39.5	Gauge	0
iblfQueInHeadRoomUsedRatio.39.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.39.6	Gauge	0
iblfQueInHeadRoomUsedRatio.39.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.39.7	Gauge	0
iblfQueInHeadRoomUsedRatio.39.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.39.8	Gauge	0
iblfQueInHeadRoomUsedRatio.40.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.40.1	Gauge	0
iblfQueInHeadRoomUsedRatio.40.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.40.2	Gauge	0
iblfQueInHeadRoomUsedRatio.40.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.40.3	Gauge	0
iblfQueInHeadRoomUsedRatio.40.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.40.4	Gauge	0
iblfQueInHeadRoomUsedRatio.40.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.40.5	Gauge	0
iblfQueInHeadRoomUsedRatio.40.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.40.6	Gauge	0

Name	OID	Value Type	Value Example
iblfQueInHeadRoomUsedRatio.40.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.40.7	Gauge	0
iblfQueInHeadRoomUsedRatio.40.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.40.8	Gauge	0
iblfQueInHeadRoomUsedRatio.41.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.41.1	Gauge	0
iblfQueInHeadRoomUsedRatio.41.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.41.2	Gauge	0
iblfQueInHeadRoomUsedRatio.41.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.41.3	Gauge	0
iblfQueInHeadRoomUsedRatio.41.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.41.4	Gauge	0
iblfQueInHeadRoomUsedRatio.41.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.41.5	Gauge	0
iblfQueInHeadRoomUsedRatio.41.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.41.6	Gauge	0
iblfQueInHeadRoomUsedRatio.41.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.41.7	Gauge	0
iblfQueInHeadRoomUsedRatio.41.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.41.8	Gauge	0
iblfQueInHeadRoomUsedRatio.42.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.42.1	Gauge	0
iblfQueInHeadRoomUsedRatio.42.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.42.2	Gauge	0
iblfQueInHeadRoomUsedRatio.42.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.42.3	Gauge	0
iblfQueInHeadRoomUsedRatio.42.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.42.4	Gauge	0
iblfQueInHeadRoomUsedRatio.42.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.42.5	Gauge	0
iblfQueInHeadRoomUsedRatio.42.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.42.6	Gauge	0
iblfQueInHeadRoomUsedRatio.42.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.42.7	Gauge	0
iblfQueInHeadRoomUsedRatio.42.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.42.8	Gauge	0
iblfQueInHeadRoomUsedRatio.43.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.43.1	Gauge	0
iblfQueInHeadRoomUsedRatio.43.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.43.2	Gauge	0
iblfQueInHeadRoomUsedRatio.43.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.43.3	Gauge	0
iblfQueInHeadRoomUsedRatio.43.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.43.4	Gauge	0
iblfQueInHeadRoomUsedRatio.43.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.43.5	Gauge	0
iblfQueInHeadRoomUsedRatio.43.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.43.6	Gauge	0
iblfQueInHeadRoomUsedRatio.43.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.43.7	Gauge	0



Name	OID	Value Type	Value Example
iblfQueInHeadRoomUsedRatio.43.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.43	8Gauge	0
iblfQueInHeadRoomUsedRatio.44.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.44	1Gauge	0
iblfQueInHeadRoomUsedRatio.44.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.44	2Gauge	0
iblfQueInHeadRoomUsedRatio.44.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.44	3Gauge	0
iblfQueInHeadRoomUsedRatio.44.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.44	4Gauge	0
iblfQueInHeadRoomUsedRatio.44.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.44	5Gauge	0
iblfQueInHeadRoomUsedRatio.44.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.44	6Gauge	0
iblfQueInHeadRoomUsedRatio.44.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.44	7Gauge	0
iblfQueInHeadRoomUsedRatio.44.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.44	8Gauge	0
iblfQueInHeadRoomUsedRatio.45.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.45	1Gauge	0
iblfQueInHeadRoomUsedRatio.45.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.45	2Gauge	0
iblfQueInHeadRoomUsedRatio.45.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.45	3Gauge	0
iblfQueInHeadRoomUsedRatio.45.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.45	4Gauge	0
iblfQueInHeadRoomUsedRatio.45.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.45	5Gauge	0
iblfQueInHeadRoomUsedRatio.45.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.45	6Gauge	0
iblfQueInHeadRoomUsedRatio.45.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.45	7Gauge	0
iblfQueInHeadRoomUsedRatio.45.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.45	8Gauge	0
iblfQueInHeadRoomUsedRatio.46.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.46	1Gauge	0
iblfQueInHeadRoomUsedRatio.46.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.46	2Gauge	0
iblfQueInHeadRoomUsedRatio.46.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.46	3Gauge	0
iblfQueInHeadRoomUsedRatio.46.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.46	4Gauge	0
iblfQueInHeadRoomUsedRatio.46.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.46	5Gauge	0
iblfQueInHeadRoomUsedRatio.46.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.46	6Gauge	0
iblfQueInHeadRoomUsedRatio.46.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.46	7Gauge	0
iblfQueInHeadRoomUsedRatio.46.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.46	8Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnHeadRoomUsedRatio.47.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.47	1Gauge	0
iblfQuelnHeadRoomUsedRatio.47.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.47	2Gauge	0
iblfQuelnHeadRoomUsedRatio.47.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.47	3Gauge	0
iblfQuelnHeadRoomUsedRatio.47.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.47	4Gauge	0
iblfQuelnHeadRoomUsedRatio.47.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.47	5Gauge	0
iblfQuelnHeadRoomUsedRatio.47.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.47	6Gauge	0
iblfQuelnHeadRoomUsedRatio.47.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.47	7Gauge	0
iblfQuelnHeadRoomUsedRatio.47.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.47	8Gauge	0
iblfQuelnHeadRoomUsedRatio.48.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.48	1Gauge	0
iblfQuelnHeadRoomUsedRatio.48.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.48	2Gauge	0
iblfQuelnHeadRoomUsedRatio.48.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.48	3Gauge	0
iblfQuelnHeadRoomUsedRatio.48.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.48	4Gauge	0
iblfQuelnHeadRoomUsedRatio.48.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.48	5Gauge	0
iblfQuelnHeadRoomUsedRatio.48.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.48	6Gauge	0
iblfQuelnHeadRoomUsedRatio.48.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.48	7Gauge	0
iblfQuelnHeadRoomUsedRatio.48.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.48	8Gauge	0
iblfQuelnHeadRoomUsedRatio.49.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.49	1Gauge	0
iblfQuelnHeadRoomUsedRatio.49.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.49	2Gauge	0
iblfQuelnHeadRoomUsedRatio.49.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.49	3Gauge	0
iblfQuelnHeadRoomUsedRatio.49.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.49	4Gauge	0
iblfQuelnHeadRoomUsedRatio.49.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.49	5Gauge	0
iblfQuelnHeadRoomUsedRatio.49.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.49	6Gauge	0
iblfQuelnHeadRoomUsedRatio.49.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.49	7Gauge	0
iblfQuelnHeadRoomUsedRatio.49.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.49	8Gauge	0
iblfQuelnHeadRoomUsedRatio.50.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.50	1Gauge	0

Name	OID	Value Type	Value Example
iblfQueInHeadRoomUsedRatio.50.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.50	2Gauge	0
iblfQueInHeadRoomUsedRatio.50.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.50	3Gauge	0
iblfQueInHeadRoomUsedRatio.50.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.50	4Gauge	0
iblfQueInHeadRoomUsedRatio.50.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.50	5Gauge	0
iblfQueInHeadRoomUsedRatio.50.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.50	6Gauge	0
iblfQueInHeadRoomUsedRatio.50.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.50	7Gauge	0
iblfQueInHeadRoomUsedRatio.50.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.50	8Gauge	0
iblfQueInHeadRoomUsedRatio.51.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.51	1Gauge	0
iblfQueInHeadRoomUsedRatio.51.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.51	2Gauge	0
iblfQueInHeadRoomUsedRatio.51.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.51	3Gauge	0
iblfQueInHeadRoomUsedRatio.51.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.51	4Gauge	0
iblfQueInHeadRoomUsedRatio.51.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.51	5Gauge	0
iblfQueInHeadRoomUsedRatio.51.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.51	6Gauge	0
iblfQueInHeadRoomUsedRatio.51.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.51	7Gauge	0
iblfQueInHeadRoomUsedRatio.51.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.51	8Gauge	0
iblfQueInHeadRoomUsedRatio.52.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.52	1Gauge	0
iblfQueInHeadRoomUsedRatio.52.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.52	2Gauge	0
iblfQueInHeadRoomUsedRatio.52.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.52	3Gauge	0
iblfQueInHeadRoomUsedRatio.52.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.52	4Gauge	0
iblfQueInHeadRoomUsedRatio.52.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.52	5Gauge	0
iblfQueInHeadRoomUsedRatio.52.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.52	6Gauge	0
iblfQueInHeadRoomUsedRatio.52.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.52	7Gauge	0
iblfQueInHeadRoomUsedRatio.52.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.52	8Gauge	0
iblfQueInHeadRoomUsedRatio.53.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.53	1Gauge	0
iblfQueInHeadRoomUsedRatio.53.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.53	2Gauge	0

Name	OID	Value Type	Value Example
iblfQueInHeadRoomUsedRatio.53.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.53.3	Gauge	0
iblfQueInHeadRoomUsedRatio.53.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.53.4	Gauge	0
iblfQueInHeadRoomUsedRatio.53.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.53.5	Gauge	0
iblfQueInHeadRoomUsedRatio.53.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.53.6	Gauge	0
iblfQueInHeadRoomUsedRatio.53.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.53.7	Gauge	0
iblfQueInHeadRoomUsedRatio.53.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.53.8	Gauge	0
iblfQueInHeadRoomUsedRatio.54.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.54.1	Gauge	0
iblfQueInHeadRoomUsedRatio.54.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.54.2	Gauge	0
iblfQueInHeadRoomUsedRatio.54.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.54.3	Gauge	0
iblfQueInHeadRoomUsedRatio.54.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.54.4	Gauge	0
iblfQueInHeadRoomUsedRatio.54.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.54.5	Gauge	0
iblfQueInHeadRoomUsedRatio.54.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.54.6	Gauge	0
iblfQueInHeadRoomUsedRatio.54.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.54.7	Gauge	0
iblfQueInHeadRoomUsedRatio.54.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.16.54.8	Gauge	0
iblfQueInHeadRoomUsedPeak.1.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.1.1	Gauge	0
iblfQueInHeadRoomUsedPeak.1.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.1.2	Gauge	0
iblfQueInHeadRoomUsedPeak.1.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.1.3	Gauge	0
iblfQueInHeadRoomUsedPeak.1.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.1.4	Gauge	0
iblfQueInHeadRoomUsedPeak.1.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.1.5	Gauge	0
iblfQueInHeadRoomUsedPeak.1.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.1.6	Gauge	0
iblfQueInHeadRoomUsedPeak.1.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.1.7	Gauge	0
iblfQueInHeadRoomUsedPeak.1.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.1.8	Gauge	0
iblfQueInHeadRoomUsedPeak.2.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.2.1	Gauge	0
iblfQueInHeadRoomUsedPeak.2.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.2.2	Gauge	0
iblfQueInHeadRoomUsedPeak.2.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.2.3	Gauge	0

Name	OID	Value Type	Value Example
iblfQueInHeadRoomUsed-Peak.2.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.2.4	Gauge	0
iblfQueInHeadRoomUsed-Peak.2.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.2.5	Gauge	0
iblfQueInHeadRoomUsed-Peak.2.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.2.6	Gauge	0
iblfQueInHeadRoomUsed-Peak.2.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.2.7	Gauge	0
iblfQueInHeadRoomUsed-Peak.2.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.2.8	Gauge	0
iblfQueInHeadRoomUsed-Peak.3.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.3.1	Gauge	0
iblfQueInHeadRoomUsed-Peak.3.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.3.2	Gauge	0
iblfQueInHeadRoomUsed-Peak.3.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.3.3	Gauge	0
iblfQueInHeadRoomUsed-Peak.3.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.3.4	Gauge	0
iblfQueInHeadRoomUsed-Peak.3.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.3.5	Gauge	0
iblfQueInHeadRoomUsed-Peak.3.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.3.6	Gauge	0
iblfQueInHeadRoomUsed-Peak.3.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.3.7	Gauge	0
iblfQueInHeadRoomUsed-Peak.3.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.3.8	Gauge	0
iblfQueInHeadRoomUsed-Peak.4.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.4.1	Gauge	0
iblfQueInHeadRoomUsed-Peak.4.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.4.2	Gauge	0
iblfQueInHeadRoomUsed-Peak.4.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.4.3	Gauge	0
iblfQueInHeadRoomUsed-Peak.4.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.4.4	Gauge	0
iblfQueInHeadRoomUsed-Peak.4.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.4.5	Gauge	0
iblfQueInHeadRoomUsed-Peak.4.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.4.6	Gauge	0
iblfQueInHeadRoomUsed-Peak.4.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.4.7	Gauge	0
iblfQueInHeadRoomUsed-Peak.4.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.4.8	Gauge	0
iblfQueInHeadRoomUsed-Peak.5.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.5.1	Gauge	0
iblfQueInHeadRoomUsed-Peak.5.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.5.2	Gauge	0
iblfQueInHeadRoomUsed-Peak.5.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.5.3	Gauge	0
iblfQueInHeadRoomUsed-Peak.5.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.5.4	Gauge	0

Name	OID	Value Type	Value Example
iblfQueInHeadRoomUsed-Peak.5.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.5.5	Gauge	0
iblfQueInHeadRoomUsed-Peak.5.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.5.6	Gauge	0
iblfQueInHeadRoomUsed-Peak.5.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.5.7	Gauge	0
iblfQueInHeadRoomUsed-Peak.5.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.5.8	Gauge	0
iblfQueInHeadRoomUsed-Peak.6.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.6.1	Gauge	0
iblfQueInHeadRoomUsed-Peak.6.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.6.2	Gauge	0
iblfQueInHeadRoomUsed-Peak.6.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.6.3	Gauge	0
iblfQueInHeadRoomUsed-Peak.6.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.6.4	Gauge	0
iblfQueInHeadRoomUsed-Peak.6.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.6.5	Gauge	0
iblfQueInHeadRoomUsed-Peak.6.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.6.6	Gauge	0
iblfQueInHeadRoomUsed-Peak.6.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.6.7	Gauge	0
iblfQueInHeadRoomUsed-Peak.6.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.6.8	Gauge	0
iblfQueInHeadRoomUsed-Peak.7.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.7.1	Gauge	0
iblfQueInHeadRoomUsed-Peak.7.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.7.2	Gauge	0
iblfQueInHeadRoomUsed-Peak.7.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.7.3	Gauge	0
iblfQueInHeadRoomUsed-Peak.7.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.7.4	Gauge	0
iblfQueInHeadRoomUsed-Peak.7.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.7.5	Gauge	0
iblfQueInHeadRoomUsed-Peak.7.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.7.6	Gauge	0
iblfQueInHeadRoomUsed-Peak.7.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.7.7	Gauge	0
iblfQueInHeadRoomUsed-Peak.7.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.7.8	Gauge	0
iblfQueInHeadRoomUsed-Peak.8.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.8.1	Gauge	0
iblfQueInHeadRoomUsed-Peak.8.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.8.2	Gauge	0
iblfQueInHeadRoomUsed-Peak.8.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.8.3	Gauge	0
iblfQueInHeadRoomUsed-Peak.8.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.8.4	Gauge	0
iblfQueInHeadRoomUsed-Peak.8.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.8.5	Gauge	0

Name	OID	Value Type	Value Example
iblfQueInHeadRoomUsed-Peak.8.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.8.6	Gauge	0
iblfQueInHeadRoomUsed-Peak.8.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.8.7	Gauge	0
iblfQueInHeadRoomUsed-Peak.8.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.8.8	Gauge	0
iblfQueInHeadRoomUsed-Peak.9.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.9.1	Gauge	0
iblfQueInHeadRoomUsed-Peak.9.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.9.2	Gauge	0
iblfQueInHeadRoomUsed-Peak.9.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.9.3	Gauge	0
iblfQueInHeadRoomUsed-Peak.9.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.9.4	Gauge	0
iblfQueInHeadRoomUsed-Peak.9.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.9.5	Gauge	0
iblfQueInHeadRoomUsed-Peak.9.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.9.6	Gauge	0
iblfQueInHeadRoomUsed-Peak.9.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.9.7	Gauge	0
iblfQueInHeadRoomUsed-Peak.9.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.9.8	Gauge	0
iblfQueInHeadRoomUsed-Peak.10.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.10.1	Gauge	0
iblfQueInHeadRoomUsed-Peak.10.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.10.2	Gauge	0
iblfQueInHeadRoomUsed-Peak.10.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.10.3	Gauge	0
iblfQueInHeadRoomUsed-Peak.10.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.10.4	Gauge	0
iblfQueInHeadRoomUsed-Peak.10.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.10.5	Gauge	0
iblfQueInHeadRoomUsed-Peak.10.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.10.6	Gauge	0
iblfQueInHeadRoomUsed-Peak.10.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.10.7	Gauge	0
iblfQueInHeadRoomUsed-Peak.10.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.10.8	Gauge	0
iblfQueInHeadRoomUsed-Peak.11.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.11.1	Gauge	0
iblfQueInHeadRoomUsed-Peak.11.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.11.2	Gauge	0
iblfQueInHeadRoomUsed-Peak.11.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.11.3	Gauge	0
iblfQueInHeadRoomUsed-Peak.11.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.11.4	Gauge	0
iblfQueInHeadRoomUsed-Peak.11.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.11.5	Gauge	0
iblfQueInHeadRoomUsed-Peak.11.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.11.6	Gauge	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
iblfQuelnHeadRoomUsed-Peak.11.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.11.7	Gauge	0
iblfQuelnHeadRoomUsed-Peak.11.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.11.8	Gauge	0
iblfQuelnHeadRoomUsed-Peak.12.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.12.1	Gauge	0
iblfQuelnHeadRoomUsed-Peak.12.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.12.2	Gauge	0
iblfQuelnHeadRoomUsed-Peak.12.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.12.3	Gauge	0
iblfQuelnHeadRoomUsed-Peak.12.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.12.4	Gauge	0
iblfQuelnHeadRoomUsed-Peak.12.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.12.5	Gauge	0
iblfQuelnHeadRoomUsed-Peak.12.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.12.6	Gauge	0
iblfQuelnHeadRoomUsed-Peak.12.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.12.7	Gauge	0
iblfQuelnHeadRoomUsed-Peak.12.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.12.8	Gauge	0
iblfQuelnHeadRoomUsed-Peak.13.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.13.1	Gauge	0
iblfQuelnHeadRoomUsed-Peak.13.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.13.2	Gauge	0
iblfQuelnHeadRoomUsed-Peak.13.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.13.3	Gauge	0
iblfQuelnHeadRoomUsed-Peak.13.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.13.4	Gauge	0
iblfQuelnHeadRoomUsed-Peak.13.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.13.5	Gauge	0
iblfQuelnHeadRoomUsed-Peak.13.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.13.6	Gauge	0
iblfQuelnHeadRoomUsed-Peak.13.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.13.7	Gauge	0
iblfQuelnHeadRoomUsed-Peak.13.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.13.8	Gauge	0
iblfQuelnHeadRoomUsed-Peak.14.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.14.1	Gauge	0
iblfQuelnHeadRoomUsed-Peak.14.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.14.2	Gauge	0
iblfQuelnHeadRoomUsed-Peak.14.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.14.3	Gauge	0
iblfQuelnHeadRoomUsed-Peak.14.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.14.4	Gauge	0
iblfQuelnHeadRoomUsed-Peak.14.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.14.5	Gauge	0
iblfQuelnHeadRoomUsed-Peak.14.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.14.6	Gauge	0
iblfQuelnHeadRoomUsed-Peak.14.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.14.7	Gauge	0



<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
iblfQuelnHeadRoomUsed-Peak.14.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.14.8	Gauge	0
iblfQuelnHeadRoomUsed-Peak.15.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.15.1	Gauge	0
iblfQuelnHeadRoomUsed-Peak.15.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.15.2	Gauge	0
iblfQuelnHeadRoomUsed-Peak.15.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.15.3	Gauge	0
iblfQuelnHeadRoomUsed-Peak.15.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.15.4	Gauge	0
iblfQuelnHeadRoomUsed-Peak.15.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.15.5	Gauge	0
iblfQuelnHeadRoomUsed-Peak.15.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.15.6	Gauge	0
iblfQuelnHeadRoomUsed-Peak.15.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.15.7	Gauge	0
iblfQuelnHeadRoomUsed-Peak.15.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.15.8	Gauge	0
iblfQuelnHeadRoomUsed-Peak.16.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.16.1	Gauge	0
iblfQuelnHeadRoomUsed-Peak.16.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.16.2	Gauge	0
iblfQuelnHeadRoomUsed-Peak.16.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.16.3	Gauge	0
iblfQuelnHeadRoomUsed-Peak.16.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.16.4	Gauge	0
iblfQuelnHeadRoomUsed-Peak.16.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.16.5	Gauge	0
iblfQuelnHeadRoomUsed-Peak.16.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.16.6	Gauge	0
iblfQuelnHeadRoomUsed-Peak.16.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.16.7	Gauge	0
iblfQuelnHeadRoomUsed-Peak.16.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.16.8	Gauge	0
iblfQuelnHeadRoomUsed-Peak.17.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.17.1	Gauge	0
iblfQuelnHeadRoomUsed-Peak.17.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.17.2	Gauge	0
iblfQuelnHeadRoomUsed-Peak.17.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.17.3	Gauge	0
iblfQuelnHeadRoomUsed-Peak.17.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.17.4	Gauge	0
iblfQuelnHeadRoomUsed-Peak.17.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.17.5	Gauge	0
iblfQuelnHeadRoomUsed-Peak.17.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.17.6	Gauge	0
iblfQuelnHeadRoomUsed-Peak.17.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.17.7	Gauge	0
iblfQuelnHeadRoomUsed-Peak.17.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.17.8	Gauge	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
iblfQuelnHeadRoomUsed-Peak.18.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.18	1Gauge	0
iblfQuelnHeadRoomUsed-Peak.18.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.18	2Gauge	0
iblfQuelnHeadRoomUsed-Peak.18.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.18	3Gauge	0
iblfQuelnHeadRoomUsed-Peak.18.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.18	4Gauge	0
iblfQuelnHeadRoomUsed-Peak.18.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.18	5Gauge	0
iblfQuelnHeadRoomUsed-Peak.18.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.18	6Gauge	0
iblfQuelnHeadRoomUsed-Peak.18.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.18	7Gauge	0
iblfQuelnHeadRoomUsed-Peak.18.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.18	8Gauge	0
iblfQuelnHeadRoomUsed-Peak.19.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.19	1Gauge	0
iblfQuelnHeadRoomUsed-Peak.19.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.19	2Gauge	0
iblfQuelnHeadRoomUsed-Peak.19.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.19	3Gauge	0
iblfQuelnHeadRoomUsed-Peak.19.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.19	4Gauge	0
iblfQuelnHeadRoomUsed-Peak.19.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.19	5Gauge	0
iblfQuelnHeadRoomUsed-Peak.19.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.19	6Gauge	0
iblfQuelnHeadRoomUsed-Peak.19.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.19	7Gauge	0
iblfQuelnHeadRoomUsed-Peak.19.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.19	8Gauge	0
iblfQuelnHeadRoomUsed-Peak.20.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.20	1Gauge	0
iblfQuelnHeadRoomUsed-Peak.20.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.20	2Gauge	0
iblfQuelnHeadRoomUsed-Peak.20.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.20	3Gauge	0
iblfQuelnHeadRoomUsed-Peak.20.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.20	4Gauge	0
iblfQuelnHeadRoomUsed-Peak.20.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.20	5Gauge	0
iblfQuelnHeadRoomUsed-Peak.20.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.20	6Gauge	0
iblfQuelnHeadRoomUsed-Peak.20.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.20	7Gauge	0
iblfQuelnHeadRoomUsed-Peak.20.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.20	8Gauge	0
iblfQuelnHeadRoomUsed-Peak.21.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.21	1Gauge	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
iblfQuelnHeadRoomUsed-Peak.21.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.21	2Gauge	0
iblfQuelnHeadRoomUsed-Peak.21.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.21	3Gauge	0
iblfQuelnHeadRoomUsed-Peak.21.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.21	4Gauge	0
iblfQuelnHeadRoomUsed-Peak.21.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.21	5Gauge	0
iblfQuelnHeadRoomUsed-Peak.21.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.21	6Gauge	0
iblfQuelnHeadRoomUsed-Peak.21.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.21	7Gauge	0
iblfQuelnHeadRoomUsed-Peak.21.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.21	8Gauge	0
iblfQuelnHeadRoomUsed-Peak.22.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.22	1Gauge	0
iblfQuelnHeadRoomUsed-Peak.22.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.22	2Gauge	0
iblfQuelnHeadRoomUsed-Peak.22.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.22	3Gauge	0
iblfQuelnHeadRoomUsed-Peak.22.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.22	4Gauge	0
iblfQuelnHeadRoomUsed-Peak.22.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.22	5Gauge	0
iblfQuelnHeadRoomUsed-Peak.22.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.22	6Gauge	0
iblfQuelnHeadRoomUsed-Peak.22.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.22	7Gauge	0
iblfQuelnHeadRoomUsed-Peak.22.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.22	8Gauge	0
iblfQuelnHeadRoomUsed-Peak.23.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.23	1Gauge	0
iblfQuelnHeadRoomUsed-Peak.23.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.23	2Gauge	0
iblfQuelnHeadRoomUsed-Peak.23.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.23	3Gauge	0
iblfQuelnHeadRoomUsed-Peak.23.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.23	4Gauge	0
iblfQuelnHeadRoomUsed-Peak.23.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.23	5Gauge	0
iblfQuelnHeadRoomUsed-Peak.23.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.23	6Gauge	0
iblfQuelnHeadRoomUsed-Peak.23.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.23	7Gauge	0
iblfQuelnHeadRoomUsed-Peak.23.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.23	8Gauge	0
iblfQuelnHeadRoomUsed-Peak.24.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.24	1Gauge	0
iblfQuelnHeadRoomUsed-Peak.24.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.24	2Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnHeadRoomUsed-Peak.24.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.24.3	Gauge	0
iblfQuelnHeadRoomUsed-Peak.24.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.24.4	Gauge	0
iblfQuelnHeadRoomUsed-Peak.24.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.24.5	Gauge	0
iblfQuelnHeadRoomUsed-Peak.24.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.24.6	Gauge	0
iblfQuelnHeadRoomUsed-Peak.24.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.24.7	Gauge	0
iblfQuelnHeadRoomUsed-Peak.24.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.24.8	Gauge	0
iblfQuelnHeadRoomUsed-Peak.25.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.25.1	Gauge	0
iblfQuelnHeadRoomUsed-Peak.25.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.25.2	Gauge	0
iblfQuelnHeadRoomUsed-Peak.25.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.25.3	Gauge	0
iblfQuelnHeadRoomUsed-Peak.25.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.25.4	Gauge	0
iblfQuelnHeadRoomUsed-Peak.25.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.25.5	Gauge	0
iblfQuelnHeadRoomUsed-Peak.25.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.25.6	Gauge	0
iblfQuelnHeadRoomUsed-Peak.25.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.25.7	Gauge	0
iblfQuelnHeadRoomUsed-Peak.25.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.25.8	Gauge	0
iblfQuelnHeadRoomUsed-Peak.26.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.26.1	Gauge	0
iblfQuelnHeadRoomUsed-Peak.26.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.26.2	Gauge	0
iblfQuelnHeadRoomUsed-Peak.26.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.26.3	Gauge	0
iblfQuelnHeadRoomUsed-Peak.26.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.26.4	Gauge	0
iblfQuelnHeadRoomUsed-Peak.26.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.26.5	Gauge	0
iblfQuelnHeadRoomUsed-Peak.26.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.26.6	Gauge	0
iblfQuelnHeadRoomUsed-Peak.26.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.26.7	Gauge	0
iblfQuelnHeadRoomUsed-Peak.26.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.26.8	Gauge	0
iblfQuelnHeadRoomUsed-Peak.27.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.27.1	Gauge	0
iblfQuelnHeadRoomUsed-Peak.27.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.27.2	Gauge	0
iblfQuelnHeadRoomUsed-Peak.27.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.27.3	Gauge	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
iblfQuelnHeadRoomUsed-Peak.27.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.27.4	Gauge	0
iblfQuelnHeadRoomUsed-Peak.27.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.27.5	Gauge	0
iblfQuelnHeadRoomUsed-Peak.27.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.27.6	Gauge	0
iblfQuelnHeadRoomUsed-Peak.27.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.27.7	Gauge	0
iblfQuelnHeadRoomUsed-Peak.27.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.27.8	Gauge	0
iblfQuelnHeadRoomUsed-Peak.28.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.28.1	Gauge	0
iblfQuelnHeadRoomUsed-Peak.28.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.28.2	Gauge	0
iblfQuelnHeadRoomUsed-Peak.28.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.28.3	Gauge	0
iblfQuelnHeadRoomUsed-Peak.28.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.28.4	Gauge	0
iblfQuelnHeadRoomUsed-Peak.28.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.28.5	Gauge	0
iblfQuelnHeadRoomUsed-Peak.28.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.28.6	Gauge	0
iblfQuelnHeadRoomUsed-Peak.28.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.28.7	Gauge	0
iblfQuelnHeadRoomUsed-Peak.28.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.28.8	Gauge	0
iblfQuelnHeadRoomUsed-Peak.29.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.29.1	Gauge	0
iblfQuelnHeadRoomUsed-Peak.29.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.29.2	Gauge	0
iblfQuelnHeadRoomUsed-Peak.29.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.29.3	Gauge	0
iblfQuelnHeadRoomUsed-Peak.29.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.29.4	Gauge	0
iblfQuelnHeadRoomUsed-Peak.29.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.29.5	Gauge	0
iblfQuelnHeadRoomUsed-Peak.29.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.29.6	Gauge	0
iblfQuelnHeadRoomUsed-Peak.29.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.29.7	Gauge	0
iblfQuelnHeadRoomUsed-Peak.29.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.29.8	Gauge	0
iblfQuelnHeadRoomUsed-Peak.30.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.30.1	Gauge	0
iblfQuelnHeadRoomUsed-Peak.30.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.30.2	Gauge	0
iblfQuelnHeadRoomUsed-Peak.30.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.30.3	Gauge	0
iblfQuelnHeadRoomUsed-Peak.30.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.30.4	Gauge	0

Name	OID	Value Type	Value Example
iblfQuelnHeadRoomUsed-Peak.30.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.305	Gauge	0
iblfQuelnHeadRoomUsed-Peak.30.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.306	Gauge	0
iblfQuelnHeadRoomUsed-Peak.30.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.307	Gauge	0
iblfQuelnHeadRoomUsed-Peak.30.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.308	Gauge	0
iblfQuelnHeadRoomUsed-Peak.31.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.311	Gauge	0
iblfQuelnHeadRoomUsed-Peak.31.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.312	Gauge	0
iblfQuelnHeadRoomUsed-Peak.31.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.313	Gauge	0
iblfQuelnHeadRoomUsed-Peak.31.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.314	Gauge	0
iblfQuelnHeadRoomUsed-Peak.31.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.315	Gauge	0
iblfQuelnHeadRoomUsed-Peak.31.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.316	Gauge	0
iblfQuelnHeadRoomUsed-Peak.31.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.317	Gauge	0
iblfQuelnHeadRoomUsed-Peak.31.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.318	Gauge	0
iblfQuelnHeadRoomUsed-Peak.32.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.321	Gauge	0
iblfQuelnHeadRoomUsed-Peak.32.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.322	Gauge	0
iblfQuelnHeadRoomUsed-Peak.32.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.323	Gauge	0
iblfQuelnHeadRoomUsed-Peak.32.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.324	Gauge	0
iblfQuelnHeadRoomUsed-Peak.32.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.325	Gauge	0
iblfQuelnHeadRoomUsed-Peak.32.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.326	Gauge	0
iblfQuelnHeadRoomUsed-Peak.32.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.327	Gauge	0
iblfQuelnHeadRoomUsed-Peak.32.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.328	Gauge	0
iblfQuelnHeadRoomUsed-Peak.33.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.331	Gauge	0
iblfQuelnHeadRoomUsed-Peak.33.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.332	Gauge	0
iblfQuelnHeadRoomUsed-Peak.33.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.333	Gauge	0
iblfQuelnHeadRoomUsed-Peak.33.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.334	Gauge	0
iblfQuelnHeadRoomUsed-Peak.33.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.335	Gauge	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
iblfQuelnHeadRoomUsed-Peak.33.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.33.6	Gauge	0
iblfQuelnHeadRoomUsed-Peak.33.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.33.7	Gauge	0
iblfQuelnHeadRoomUsed-Peak.33.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.33.8	Gauge	0
iblfQuelnHeadRoomUsed-Peak.34.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.34.1	Gauge	0
iblfQuelnHeadRoomUsed-Peak.34.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.34.2	Gauge	0
iblfQuelnHeadRoomUsed-Peak.34.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.34.3	Gauge	0
iblfQuelnHeadRoomUsed-Peak.34.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.34.4	Gauge	0
iblfQuelnHeadRoomUsed-Peak.34.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.34.5	Gauge	0
iblfQuelnHeadRoomUsed-Peak.34.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.34.6	Gauge	0
iblfQuelnHeadRoomUsed-Peak.34.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.34.7	Gauge	0
iblfQuelnHeadRoomUsed-Peak.34.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.34.8	Gauge	0
iblfQuelnHeadRoomUsed-Peak.35.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.35.1	Gauge	0
iblfQuelnHeadRoomUsed-Peak.35.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.35.2	Gauge	0
iblfQuelnHeadRoomUsed-Peak.35.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.35.3	Gauge	0
iblfQuelnHeadRoomUsed-Peak.35.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.35.4	Gauge	0
iblfQuelnHeadRoomUsed-Peak.35.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.35.5	Gauge	0
iblfQuelnHeadRoomUsed-Peak.35.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.35.6	Gauge	0
iblfQuelnHeadRoomUsed-Peak.35.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.35.7	Gauge	0
iblfQuelnHeadRoomUsed-Peak.35.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.35.8	Gauge	0
iblfQuelnHeadRoomUsed-Peak.36.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.36.1	Gauge	0
iblfQuelnHeadRoomUsed-Peak.36.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.36.2	Gauge	0
iblfQuelnHeadRoomUsed-Peak.36.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.36.3	Gauge	0
iblfQuelnHeadRoomUsed-Peak.36.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.36.4	Gauge	0
iblfQuelnHeadRoomUsed-Peak.36.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.36.5	Gauge	0
iblfQuelnHeadRoomUsed-Peak.36.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.36.6	Gauge	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
iblfQuelnHeadRoomUsed-Peak.36.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.367	Gauge	0
iblfQuelnHeadRoomUsed-Peak.36.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.368	Gauge	0
iblfQuelnHeadRoomUsed-Peak.37.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.371	Gauge	0
iblfQuelnHeadRoomUsed-Peak.37.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.372	Gauge	0
iblfQuelnHeadRoomUsed-Peak.37.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.373	Gauge	0
iblfQuelnHeadRoomUsed-Peak.37.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.374	Gauge	0
iblfQuelnHeadRoomUsed-Peak.37.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.375	Gauge	0
iblfQuelnHeadRoomUsed-Peak.37.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.376	Gauge	0
iblfQuelnHeadRoomUsed-Peak.37.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.377	Gauge	0
iblfQuelnHeadRoomUsed-Peak.37.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.378	Gauge	0
iblfQuelnHeadRoomUsed-Peak.38.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.381	Gauge	0
iblfQuelnHeadRoomUsed-Peak.38.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.382	Gauge	0
iblfQuelnHeadRoomUsed-Peak.38.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.383	Gauge	0
iblfQuelnHeadRoomUsed-Peak.38.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.384	Gauge	0
iblfQuelnHeadRoomUsed-Peak.38.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.385	Gauge	0
iblfQuelnHeadRoomUsed-Peak.38.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.386	Gauge	0
iblfQuelnHeadRoomUsed-Peak.38.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.387	Gauge	0
iblfQuelnHeadRoomUsed-Peak.38.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.388	Gauge	0
iblfQuelnHeadRoomUsed-Peak.39.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.391	Gauge	0
iblfQuelnHeadRoomUsed-Peak.39.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.392	Gauge	0
iblfQuelnHeadRoomUsed-Peak.39.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.393	Gauge	0
iblfQuelnHeadRoomUsed-Peak.39.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.394	Gauge	0
iblfQuelnHeadRoomUsed-Peak.39.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.395	Gauge	0
iblfQuelnHeadRoomUsed-Peak.39.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.396	Gauge	0
iblfQuelnHeadRoomUsed-Peak.39.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.397	Gauge	0



<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
iblfQuelnHeadRoomUsed-Peak.39.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.39	8Gauge	0
iblfQuelnHeadRoomUsed-Peak.40.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.40	1Gauge	0
iblfQuelnHeadRoomUsed-Peak.40.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.40	2Gauge	0
iblfQuelnHeadRoomUsed-Peak.40.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.40	3Gauge	0
iblfQuelnHeadRoomUsed-Peak.40.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.40	4Gauge	0
iblfQuelnHeadRoomUsed-Peak.40.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.40	5Gauge	0
iblfQuelnHeadRoomUsed-Peak.40.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.40	6Gauge	0
iblfQuelnHeadRoomUsed-Peak.40.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.40	7Gauge	0
iblfQuelnHeadRoomUsed-Peak.40.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.40	8Gauge	0
iblfQuelnHeadRoomUsed-Peak.41.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.41	1Gauge	0
iblfQuelnHeadRoomUsed-Peak.41.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.41	2Gauge	0
iblfQuelnHeadRoomUsed-Peak.41.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.41	3Gauge	0
iblfQuelnHeadRoomUsed-Peak.41.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.41	4Gauge	0
iblfQuelnHeadRoomUsed-Peak.41.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.41	5Gauge	0
iblfQuelnHeadRoomUsed-Peak.41.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.41	6Gauge	0
iblfQuelnHeadRoomUsed-Peak.41.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.41	7Gauge	0
iblfQuelnHeadRoomUsed-Peak.41.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.41	8Gauge	0
iblfQuelnHeadRoomUsed-Peak.42.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.42	1Gauge	0
iblfQuelnHeadRoomUsed-Peak.42.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.42	2Gauge	0
iblfQuelnHeadRoomUsed-Peak.42.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.42	3Gauge	0
iblfQuelnHeadRoomUsed-Peak.42.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.42	4Gauge	0
iblfQuelnHeadRoomUsed-Peak.42.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.42	5Gauge	0
iblfQuelnHeadRoomUsed-Peak.42.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.42	6Gauge	0
iblfQuelnHeadRoomUsed-Peak.42.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.42	7Gauge	0
iblfQuelnHeadRoomUsed-Peak.42.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.42	8Gauge	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
iblfQuelnHeadRoomUsed-Peak.43.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.43	1Gauge	0
iblfQuelnHeadRoomUsed-Peak.43.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.43	2Gauge	0
iblfQuelnHeadRoomUsed-Peak.43.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.43	3Gauge	0
iblfQuelnHeadRoomUsed-Peak.43.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.43	4Gauge	0
iblfQuelnHeadRoomUsed-Peak.43.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.43	5Gauge	0
iblfQuelnHeadRoomUsed-Peak.43.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.43	6Gauge	0
iblfQuelnHeadRoomUsed-Peak.43.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.43	7Gauge	0
iblfQuelnHeadRoomUsed-Peak.43.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.43	8Gauge	0
iblfQuelnHeadRoomUsed-Peak.44.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.44	1Gauge	0
iblfQuelnHeadRoomUsed-Peak.44.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.44	2Gauge	0
iblfQuelnHeadRoomUsed-Peak.44.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.44	3Gauge	0
iblfQuelnHeadRoomUsed-Peak.44.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.44	4Gauge	0
iblfQuelnHeadRoomUsed-Peak.44.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.44	5Gauge	0
iblfQuelnHeadRoomUsed-Peak.44.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.44	6Gauge	0
iblfQuelnHeadRoomUsed-Peak.44.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.44	7Gauge	0
iblfQuelnHeadRoomUsed-Peak.44.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.44	8Gauge	0
iblfQuelnHeadRoomUsed-Peak.45.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.45	1Gauge	0
iblfQuelnHeadRoomUsed-Peak.45.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.45	2Gauge	0
iblfQuelnHeadRoomUsed-Peak.45.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.45	3Gauge	0
iblfQuelnHeadRoomUsed-Peak.45.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.45	4Gauge	0
iblfQuelnHeadRoomUsed-Peak.45.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.45	5Gauge	0
iblfQuelnHeadRoomUsed-Peak.45.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.45	6Gauge	0
iblfQuelnHeadRoomUsed-Peak.45.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.45	7Gauge	0
iblfQuelnHeadRoomUsed-Peak.45.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.45	8Gauge	0
iblfQuelnHeadRoomUsed-Peak.46.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.46	1Gauge	0

Name	OID	Value Type	Value Example
iblfQueInHeadRoomUsed-Peak.46.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.46.2	Gauge	0
iblfQueInHeadRoomUsed-Peak.46.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.46.3	Gauge	0
iblfQueInHeadRoomUsed-Peak.46.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.46.4	Gauge	0
iblfQueInHeadRoomUsed-Peak.46.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.46.5	Gauge	0
iblfQueInHeadRoomUsed-Peak.46.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.46.6	Gauge	0
iblfQueInHeadRoomUsed-Peak.46.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.46.7	Gauge	0
iblfQueInHeadRoomUsed-Peak.46.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.46.8	Gauge	0
iblfQueInHeadRoomUsed-Peak.47.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.47.1	Gauge	0
iblfQueInHeadRoomUsed-Peak.47.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.47.2	Gauge	0
iblfQueInHeadRoomUsed-Peak.47.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.47.3	Gauge	0
iblfQueInHeadRoomUsed-Peak.47.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.47.4	Gauge	0
iblfQueInHeadRoomUsed-Peak.47.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.47.5	Gauge	0
iblfQueInHeadRoomUsed-Peak.47.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.47.6	Gauge	0
iblfQueInHeadRoomUsed-Peak.47.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.47.7	Gauge	0
iblfQueInHeadRoomUsed-Peak.47.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.47.8	Gauge	0
iblfQueInHeadRoomUsed-Peak.48.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.48.1	Gauge	0
iblfQueInHeadRoomUsed-Peak.48.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.48.2	Gauge	0
iblfQueInHeadRoomUsed-Peak.48.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.48.3	Gauge	0
iblfQueInHeadRoomUsed-Peak.48.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.48.4	Gauge	0
iblfQueInHeadRoomUsed-Peak.48.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.48.5	Gauge	0
iblfQueInHeadRoomUsed-Peak.48.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.48.6	Gauge	0
iblfQueInHeadRoomUsed-Peak.48.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.48.7	Gauge	0
iblfQueInHeadRoomUsed-Peak.48.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.48.8	Gauge	0
iblfQueInHeadRoomUsed-Peak.49.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.49.1	Gauge	0
iblfQueInHeadRoomUsed-Peak.49.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.49.2	Gauge	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
iblfQuelnHeadRoomUsed-Peak.49.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.49.3	Gauge	0
iblfQuelnHeadRoomUsed-Peak.49.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.49.4	Gauge	0
iblfQuelnHeadRoomUsed-Peak.49.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.49.5	Gauge	0
iblfQuelnHeadRoomUsed-Peak.49.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.49.6	Gauge	0
iblfQuelnHeadRoomUsed-Peak.49.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.49.7	Gauge	0
iblfQuelnHeadRoomUsed-Peak.49.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.49.8	Gauge	0
iblfQuelnHeadRoomUsed-Peak.50.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.50.1	Gauge	0
iblfQuelnHeadRoomUsed-Peak.50.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.50.2	Gauge	0
iblfQuelnHeadRoomUsed-Peak.50.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.50.3	Gauge	0
iblfQuelnHeadRoomUsed-Peak.50.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.50.4	Gauge	0
iblfQuelnHeadRoomUsed-Peak.50.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.50.5	Gauge	0
iblfQuelnHeadRoomUsed-Peak.50.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.50.6	Gauge	0
iblfQuelnHeadRoomUsed-Peak.50.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.50.7	Gauge	0
iblfQuelnHeadRoomUsed-Peak.50.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.50.8	Gauge	0
iblfQuelnHeadRoomUsed-Peak.51.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.51.1	Gauge	0
iblfQuelnHeadRoomUsed-Peak.51.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.51.2	Gauge	0
iblfQuelnHeadRoomUsed-Peak.51.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.51.3	Gauge	0
iblfQuelnHeadRoomUsed-Peak.51.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.51.4	Gauge	0
iblfQuelnHeadRoomUsed-Peak.51.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.51.5	Gauge	0
iblfQuelnHeadRoomUsed-Peak.51.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.51.6	Gauge	0
iblfQuelnHeadRoomUsed-Peak.51.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.51.7	Gauge	0
iblfQuelnHeadRoomUsed-Peak.51.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.51.8	Gauge	0
iblfQuelnHeadRoomUsed-Peak.52.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.52.1	Gauge	0
iblfQuelnHeadRoomUsed-Peak.52.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.52.2	Gauge	0
iblfQuelnHeadRoomUsed-Peak.52.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.52.3	Gauge	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
iblfQueInHeadRoomUsed-Peak.52.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.52.4	Gauge	0
iblfQueInHeadRoomUsed-Peak.52.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.52.5	Gauge	0
iblfQueInHeadRoomUsed-Peak.52.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.52.6	Gauge	0
iblfQueInHeadRoomUsed-Peak.52.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.52.7	Gauge	0
iblfQueInHeadRoomUsed-Peak.52.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.52.8	Gauge	0
iblfQueInHeadRoomUsed-Peak.53.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.53.1	Gauge	0
iblfQueInHeadRoomUsed-Peak.53.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.53.2	Gauge	0
iblfQueInHeadRoomUsed-Peak.53.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.53.3	Gauge	0
iblfQueInHeadRoomUsed-Peak.53.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.53.4	Gauge	0
iblfQueInHeadRoomUsed-Peak.53.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.53.5	Gauge	0
iblfQueInHeadRoomUsed-Peak.53.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.53.6	Gauge	0
iblfQueInHeadRoomUsed-Peak.53.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.53.7	Gauge	0
iblfQueInHeadRoomUsed-Peak.53.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.53.8	Gauge	0
iblfQueInHeadRoomUsed-Peak.54.1	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.54.1	Gauge	0
iblfQueInHeadRoomUsed-Peak.54.2	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.54.2	Gauge	0
iblfQueInHeadRoomUsed-Peak.54.3	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.54.3	Gauge	0
iblfQueInHeadRoomUsed-Peak.54.4	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.54.4	Gauge	0
iblfQueInHeadRoomUsed-Peak.54.5	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.54.5	Gauge	0
iblfQueInHeadRoomUsed-Peak.54.6	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.54.6	Gauge	0
iblfQueInHeadRoomUsed-Peak.54.7	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.54.7	Gauge	0
iblfQueInHeadRoomUsed-Peak.54.8	.1.3.6.1.4.1.26138.2.40.2.2.6.1.17.54.8	Gauge	0
iblfPhysicalNumber.0	.1.3.6.1.4.1.26138.2.40.2.3.1.0	Integer	54
iblfUpDownTimes.1	.1.3.6.1.4.1.26138.2.40.2.3.2.1.1.1	Integer	3
iblfUpDownTimes.2	.1.3.6.1.4.1.26138.2.40.2.3.2.1.1.2	Integer	0
iblfUpDownTimes.3	.1.3.6.1.4.1.26138.2.40.2.3.2.1.1.3	Integer	0
iblfUpDownTimes.4	.1.3.6.1.4.1.26138.2.40.2.3.2.1.1.4	Integer	0
iblfUpDownTimes.5	.1.3.6.1.4.1.26138.2.40.2.3.2.1.1.5	Integer	0
iblfUpDownTimes.6	.1.3.6.1.4.1.26138.2.40.2.3.2.1.1.6	Integer	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
iblfUpDownTimes.7	.1.3.6.1.4.1.26138.2.40.2.3.2.1.1.7	Integer	0
iblfUpDownTimes.8	.1.3.6.1.4.1.26138.2.40.2.3.2.1.1.8	Integer	0
iblfUpDownTimes.9	.1.3.6.1.4.1.26138.2.40.2.3.2.1.1.9	Integer	0
iblfUpDownTimes.10	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.10	Integer	0
iblfUpDownTimes.11	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.11	Integer	0
iblfUpDownTimes.12	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.12	Integer	0
iblfUpDownTimes.13	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.13	Integer	0
iblfUpDownTimes.14	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.14	Integer	0
iblfUpDownTimes.15	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.15	Integer	0
iblfUpDownTimes.16	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.16	Integer	0
iblfUpDownTimes.17	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.17	Integer	0
iblfUpDownTimes.18	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.18	Integer	0
iblfUpDownTimes.19	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.19	Integer	0
iblfUpDownTimes.20	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.20	Integer	0
iblfUpDownTimes.21	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.21	Integer	0
iblfUpDownTimes.22	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.22	Integer	0
iblfUpDownTimes.23	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.23	Integer	0
iblfUpDownTimes.24	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.24	Integer	0
iblfUpDownTimes.25	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.25	Integer	0
iblfUpDownTimes.26	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.26	Integer	0
iblfUpDownTimes.27	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.27	Integer	0
iblfUpDownTimes.28	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.28	Integer	0
iblfUpDownTimes.29	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.29	Integer	0
iblfUpDownTimes.30	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.30	Integer	0
iblfUpDownTimes.31	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.31	Integer	0
iblfUpDownTimes.32	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.32	Integer	0
iblfUpDownTimes.33	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.33	Integer	0
iblfUpDownTimes.34	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.34	Integer	0
iblfUpDownTimes.35	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.35	Integer	0
iblfUpDownTimes.36	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.36	Integer	0
iblfUpDownTimes.37	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.37	Integer	0
iblfUpDownTimes.38	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.38	Integer	0
iblfUpDownTimes.39	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.39	Integer	0
iblfUpDownTimes.40	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.40	Integer	0
iblfUpDownTimes.41	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.41	Integer	0
iblfUpDownTimes.42	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.42	Integer	0
iblfUpDownTimes.43	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.43	Integer	0
iblfUpDownTimes.44	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.44	Integer	0
iblfUpDownTimes.45	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.45	Integer	0
iblfUpDownTimes.46	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.46	Integer	0
iblfUpDownTimes.47	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.47	Integer	0
iblfUpDownTimes.48	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.48	Integer	0
iblfUpDownTimes.49	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.49	Integer	0

Name	OID	Value Type	Value Example
iblfUpDownTimes.50	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.50	Integer	0
iblfUpDownTimes.51	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.51	Integer	0
iblfUpDownTimes.52	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.52	Integer	0
iblfUpDownTimes.53	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.53	Integer	0
iblfUpDownTimes.54	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.54	Integer	0
iblfUpDownTimes.631	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.631	Integer	1
iblfUpDownTimes.632	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.632	Integer	1
iblfUpDownTimes.633	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.633	Integer	0
iblfUpDownTimes.634	1.3.6.1.4.1.26138.2.40.2.3.2.1.1.634	Integer	3
iblfMtu.1	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.1	Integer	12288
iblfMtu.2	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.2	Integer	12288
iblfMtu.3	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.3	Integer	12288
iblfMtu.4	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.4	Integer	12288
iblfMtu.5	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.5	Integer	12288
iblfMtu.6	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.6	Integer	12288
iblfMtu.7	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.7	Integer	12288
iblfMtu.8	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.8	Integer	12288
iblfMtu.9	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.9	Integer	12288
iblfMtu.10	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.10	Integer	12288
iblfMtu.11	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.11	Integer	12288
iblfMtu.12	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.12	Integer	12288
iblfMtu.13	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.13	Integer	12288
iblfMtu.14	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.14	Integer	12288
iblfMtu.15	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.15	Integer	12288
iblfMtu.16	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.16	Integer	12288
iblfMtu.17	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.17	Integer	12288
iblfMtu.18	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.18	Integer	12288
iblfMtu.19	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.19	Integer	12288
iblfMtu.20	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.20	Integer	12288
iblfMtu.21	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.21	Integer	12288
iblfMtu.22	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.22	Integer	12288
iblfMtu.23	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.23	Integer	12288
iblfMtu.24	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.24	Integer	12288
iblfMtu.25	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.25	Integer	12288
iblfMtu.26	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.26	Integer	12288
iblfMtu.27	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.27	Integer	12288
iblfMtu.28	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.28	Integer	12288
iblfMtu.29	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.29	Integer	12288
iblfMtu.30	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.30	Integer	12288
iblfMtu.31	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.31	Integer	12288
iblfMtu.32	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.32	Integer	12288
iblfMtu.33	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.33	Integer	12288
iblfMtu.34	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.34	Integer	12288

Name	OID	Value Type	Value Example
iblfMtu.35	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.35	Integer	12288
iblfMtu.36	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.36	Integer	12288
iblfMtu.37	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.37	Integer	12288
iblfMtu.38	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.38	Integer	12288
iblfMtu.39	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.39	Integer	12288
iblfMtu.40	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.40	Integer	12288
iblfMtu.41	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.41	Integer	12288
iblfMtu.42	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.42	Integer	12288
iblfMtu.43	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.43	Integer	12288
iblfMtu.44	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.44	Integer	12288
iblfMtu.45	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.45	Integer	12288
iblfMtu.46	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.46	Integer	12288
iblfMtu.47	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.47	Integer	12288
iblfMtu.48	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.48	Integer	12288
iblfMtu.49	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.49	Integer	12288
iblfMtu.50	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.50	Integer	12288
iblfMtu.51	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.51	Integer	12288
iblfMtu.52	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.52	Integer	12288
iblfMtu.53	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.53	Integer	12288
iblfMtu.54	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.54	Integer	12288
iblfMtu.631	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.631	Integer	1500
iblfMtu.632	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.632	Integer	1536
iblfMtu.633	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.633	Integer	1536
iblfMtu.634	1.3.6.1.4.1.26138.2.40.2.3.2.1.2.634	Integer	1500
iblfStatusKeepTime.1	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.1	TimeTicks	12 minutes 41.29 seconds (76129)
iblfStatusKeepTime.2	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.2	TimeTicks	33 minutes 58.39 seconds (203839)
iblfStatusKeepTime.3	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.3	TimeTicks	33 minutes 58.41 seconds (203841)
iblfStatusKeepTime.4	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.4	TimeTicks	33 minutes 58.43 seconds (203843)
iblfStatusKeepTime.5	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.5	TimeTicks	33 minutes 58.45 seconds (203845)
iblfStatusKeepTime.6	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.6	TimeTicks	33 minutes 58.46 seconds (203846)
iblfStatusKeepTime.7	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.7	TimeTicks	33 minutes 58.48 seconds (203848)
iblfStatusKeepTime.8	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.8	TimeTicks	33 minutes 58.5 seconds (203850)
iblfStatusKeepTime.9	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.9	TimeTicks	33 minutes 58.52 seconds (203852)
iblfStatusKeepTime.10	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.10	TimeTicks	33 minutes 58.54 seconds (203854)
iblfStatusKeepTime.11	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.11	TimeTicks	33 minutes 58.56 seconds (203856)



Name	OID	Value Type	Value Example
ibLfStatusKeepTime.12	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.12	TimeTicks	33 minutes 58.58 seconds (203858)
ibLfStatusKeepTime.13	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.13	TimeTicks	33 minutes 58.6 seconds (203860)
ibLfStatusKeepTime.14	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.14	TimeTicks	33 minutes 58.62 seconds (203862)
ibLfStatusKeepTime.15	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.15	TimeTicks	33 minutes 58.64 seconds (203864)
ibLfStatusKeepTime.16	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.16	TimeTicks	33 minutes 58.66 seconds (203866)
ibLfStatusKeepTime.17	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.17	TimeTicks	33 minutes 58.68 seconds (203868)
ibLfStatusKeepTime.18	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.18	TimeTicks	33 minutes 58.71 seconds (203871)
ibLfStatusKeepTime.19	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.19	TimeTicks	33 minutes 58.74 seconds (203874)
ibLfStatusKeepTime.20	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.20	TimeTicks	33 minutes 58.76 seconds (203876)
ibLfStatusKeepTime.21	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.21	TimeTicks	33 minutes 58.78 seconds (203878)
ibLfStatusKeepTime.22	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.22	TimeTicks	33 minutes 58.8 seconds (203880)
ibLfStatusKeepTime.23	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.23	TimeTicks	33 minutes 58.82 seconds (203882)
ibLfStatusKeepTime.24	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.24	TimeTicks	33 minutes 58.84 seconds (203884)
ibLfStatusKeepTime.25	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.25	TimeTicks	33 minutes 58.86 seconds (203886)
ibLfStatusKeepTime.26	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.26	TimeTicks	33 minutes 58.88 seconds (203888)
ibLfStatusKeepTime.27	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.27	TimeTicks	33 minutes 58.89 seconds (203889)
ibLfStatusKeepTime.28	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.28	TimeTicks	33 minutes 58.91 seconds (203891)
ibLfStatusKeepTime.29	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.29	TimeTicks	33 minutes 58.94 seconds (203894)
ibLfStatusKeepTime.30	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.30	TimeTicks	33 minutes 58.96 seconds (203896)
ibLfStatusKeepTime.31	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.31	TimeTicks	33 minutes 58.99 seconds (203899)
ibLfStatusKeepTime.32	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.32	TimeTicks	33 minutes 59.03 seconds (203903)
ibLfStatusKeepTime.33	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.33	TimeTicks	33 minutes 59.06 seconds (203906)
ibLfStatusKeepTime.34	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.34	TimeTicks	33 minutes 59.09 seconds (203909)
ibLfStatusKeepTime.35	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.35	TimeTicks	33 minutes 59.12 seconds (203912)
ibLfStatusKeepTime.36	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.36	TimeTicks	33 minutes 59.15 seconds (203915)

Name	OID	Value Type	Value Example
ibLfStatusKeepTime.37	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.37	TimeTicks	33 minutes 59.18 seconds (203918)
ibLfStatusKeepTime.38	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.38	TimeTicks	33 minutes 59.21 seconds (203921)
ibLfStatusKeepTime.39	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.39	TimeTicks	33 minutes 59.24 seconds (203924)
ibLfStatusKeepTime.40	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.40	TimeTicks	33 minutes 59.27 seconds (203927)
ibLfStatusKeepTime.41	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.41	TimeTicks	33 minutes 59.3 seconds (203930)
ibLfStatusKeepTime.42	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.42	TimeTicks	33 minutes 59.33 seconds (203933)
ibLfStatusKeepTime.43	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.43	TimeTicks	33 minutes 59.35 seconds (203935)
ibLfStatusKeepTime.44	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.44	TimeTicks	33 minutes 59.37 seconds (203937)
ibLfStatusKeepTime.45	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.45	TimeTicks	33 minutes 59.39 seconds (203939)
ibLfStatusKeepTime.46	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.46	TimeTicks	33 minutes 59.41 seconds (203941)
ibLfStatusKeepTime.47	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.47	TimeTicks	33 minutes 59.43 seconds (203943)
ibLfStatusKeepTime.48	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.48	TimeTicks	33 minutes 59.47 seconds (203947)
ibLfStatusKeepTime.49	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.49	TimeTicks	33 minutes 59.52 seconds (203952)
ibLfStatusKeepTime.50	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.50	TimeTicks	33 minutes 59.55 seconds (203955)
ibLfStatusKeepTime.51	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.51	TimeTicks	33 minutes 59.57 seconds (203957)
ibLfStatusKeepTime.52	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.52	TimeTicks	33 minutes 59.6 seconds (203960)
ibLfStatusKeepTime.53	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.53	TimeTicks	33 minutes 59.62 seconds (203962)
ibLfStatusKeepTime.54	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.54	TimeTicks	33 minutes 59.62 seconds (203962)
ibLfStatusKeepTime.631	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.631	TimeTicks	33 minutes 59.65 seconds (203965)
ibLfStatusKeepTime.632	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.632	TimeTicks	32 minutes 15.83 seconds (193583)
ibLfStatusKeepTime.633	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.633	TimeTicks	33 minutes 59.74 seconds (203974)
ibLfStatusKeepTime.634	1.3.6.1.4.1.26138.2.40.2.3.2.1.5.634	TimeTicks	12 minutes 42.58 seconds (76258)
ibLfPfcStatus.1	1.3.6.1.4.1.26138.2.40.2.3.2.1.11.1	Integer	disable (2)
ibLfPfcStatus.2	1.3.6.1.4.1.26138.2.40.2.3.2.1.11.2	Integer	disable (2)
ibLfPfcStatus.3	1.3.6.1.4.1.26138.2.40.2.3.2.1.11.3	Integer	disable (2)
ibLfPfcStatus.4	1.3.6.1.4.1.26138.2.40.2.3.2.1.11.4	Integer	disable (2)
ibLfPfcStatus.5	1.3.6.1.4.1.26138.2.40.2.3.2.1.11.5	Integer	disable (2)
ibLfPfcStatus.6	1.3.6.1.4.1.26138.2.40.2.3.2.1.11.6	Integer	disable (2)



Name	OID	Value Type	Value Example
iblfPfcStatus.50	1.3.6.1.4.1.26138.2.40.2.3.2.1.11.50	Integer	disable (2)
iblfPfcStatus.51	1.3.6.1.4.1.26138.2.40.2.3.2.1.11.51	Integer	disable (2)
iblfPfcStatus.52	1.3.6.1.4.1.26138.2.40.2.3.2.1.11.52	Integer	disable (2)
iblfPfcStatus.53	1.3.6.1.4.1.26138.2.40.2.3.2.1.11.53	Integer	disable (2)
iblfPfcStatus.54	1.3.6.1.4.1.26138.2.40.2.3.2.1.11.54	Integer	disable (2)
iblfPfcStatus.631	1.3.6.1.4.1.26138.2.40.2.3.2.1.11.631	Integer	disable (2)
iblfPfcStatus.632	1.3.6.1.4.1.26138.2.40.2.3.2.1.11.632	Integer	disable (2)
iblfPfcStatus.633	1.3.6.1.4.1.26138.2.40.2.3.2.1.11.633	Integer	disable (2)
iblfPfcStatus.634	1.3.6.1.4.1.26138.2.40.2.3.2.1.11.634	Integer	disable (2)
iblfPfcDot1pNoDrop.1	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.1	OctetString	{}
iblfPfcDot1pNoDrop.2	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.2	OctetString	{}
iblfPfcDot1pNoDrop.3	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.3	OctetString	{}
iblfPfcDot1pNoDrop.4	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.4	OctetString	{}
iblfPfcDot1pNoDrop.5	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.5	OctetString	{}
iblfPfcDot1pNoDrop.6	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.6	OctetString	{}
iblfPfcDot1pNoDrop.7	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.7	OctetString	{}
iblfPfcDot1pNoDrop.8	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.8	OctetString	{}
iblfPfcDot1pNoDrop.9	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.9	OctetString	{}
iblfPfcDot1pNoDrop.10	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.10	OctetString	{}
iblfPfcDot1pNoDrop.11	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.11	OctetString	{}
iblfPfcDot1pNoDrop.12	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.12	OctetString	{}
iblfPfcDot1pNoDrop.13	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.13	OctetString	{}
iblfPfcDot1pNoDrop.14	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.14	OctetString	{}
iblfPfcDot1pNoDrop.15	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.15	OctetString	{}
iblfPfcDot1pNoDrop.16	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.16	OctetString	{}
iblfPfcDot1pNoDrop.17	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.17	OctetString	{}
iblfPfcDot1pNoDrop.18	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.18	OctetString	{}
iblfPfcDot1pNoDrop.19	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.19	OctetString	{}
iblfPfcDot1pNoDrop.20	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.20	OctetString	{}
iblfPfcDot1pNoDrop.21	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.21	OctetString	{}
iblfPfcDot1pNoDrop.22	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.22	OctetString	{}
iblfPfcDot1pNoDrop.23	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.23	OctetString	{}
iblfPfcDot1pNoDrop.24	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.24	OctetString	{}
iblfPfcDot1pNoDrop.25	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.25	OctetString	{}
iblfPfcDot1pNoDrop.26	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.26	OctetString	{}
iblfPfcDot1pNoDrop.27	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.27	OctetString	{}
iblfPfcDot1pNoDrop.28	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.28	OctetString	{}
iblfPfcDot1pNoDrop.29	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.29	OctetString	{}
iblfPfcDot1pNoDrop.30	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.30	OctetString	{}
iblfPfcDot1pNoDrop.31	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.31	OctetString	{}
iblfPfcDot1pNoDrop.32	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.32	OctetString	{}
iblfPfcDot1pNoDrop.33	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.33	OctetString	{}
iblfPfcDot1pNoDrop.34	1.3.6.1.4.1.26138.2.40.2.3.2.1.12.34	OctetString	{}

Name	OID	Value Type	Value Example
iblfPfcDot1pNoDrop.35	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.35	OctetString	{}
iblfPfcDot1pNoDrop.36	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.36	OctetString	{}
iblfPfcDot1pNoDrop.37	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.37	OctetString	{}
iblfPfcDot1pNoDrop.38	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.38	OctetString	{}
iblfPfcDot1pNoDrop.39	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.39	OctetString	{}
iblfPfcDot1pNoDrop.40	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.40	OctetString	{}
iblfPfcDot1pNoDrop.41	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.41	OctetString	{}
iblfPfcDot1pNoDrop.42	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.42	OctetString	{}
iblfPfcDot1pNoDrop.43	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.43	OctetString	{}
iblfPfcDot1pNoDrop.44	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.44	OctetString	{}
iblfPfcDot1pNoDrop.45	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.45	OctetString	{}
iblfPfcDot1pNoDrop.46	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.46	OctetString	{}
iblfPfcDot1pNoDrop.47	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.47	OctetString	{}
iblfPfcDot1pNoDrop.48	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.48	OctetString	{}
iblfPfcDot1pNoDrop.49	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.49	OctetString	{}
iblfPfcDot1pNoDrop.50	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.50	OctetString	{}
iblfPfcDot1pNoDrop.51	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.51	OctetString	{}
iblfPfcDot1pNoDrop.52	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.52	OctetString	{}
iblfPfcDot1pNoDrop.53	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.53	OctetString	{}
iblfPfcDot1pNoDrop.54	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.54	OctetString	{}
iblfPfcDot1pNoDrop.631	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.631	OctetString	{}
iblfPfcDot1pNoDrop.632	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.632	OctetString	{}
iblfPfcDot1pNoDrop.633	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.633	OctetString	{}
iblfPfcDot1pNoDrop.634	.1.3.6.1.4.1.26138.2.40.2.3.2.1.12.634	OctetString	{}
iblfDescription.1	1.3.6.1.4.1.26138.2.40.2.3.2.1.13.1	OctetString	UPLINK
iblfDescription.2	1.3.6.1.4.1.26138.2.40.2.3.2.1.13.2	OctetString	GigabitEthernet1/0/2 Interface
iblfDescription.3	1.3.6.1.4.1.26138.2.40.2.3.2.1.13.3	OctetString	GigabitEthernet1/0/3 Interface
iblfDescription.4	1.3.6.1.4.1.26138.2.40.2.3.2.1.13.4	OctetString	GigabitEthernet1/0/4 Interface
iblfDescription.5	1.3.6.1.4.1.26138.2.40.2.3.2.1.13.5	OctetString	GigabitEthernet1/0/5 Interface
iblfDescription.6	1.3.6.1.4.1.26138.2.40.2.3.2.1.13.6	OctetString	GigabitEthernet1/0/6 Interface
iblfDescription.7	1.3.6.1.4.1.26138.2.40.2.3.2.1.13.7	OctetString	GigabitEthernet1/0/7 Interface
iblfDescription.8	1.3.6.1.4.1.26138.2.40.2.3.2.1.13.8	OctetString	GigabitEthernet1/0/8 Interface
iblfDescription.9	1.3.6.1.4.1.26138.2.40.2.3.2.1.13.9	OctetString	GigabitEthernet1/0/9 Interface
iblfDescription.10	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.10	OctetString	GigabitEthernet1/0/10 Interface
iblfDescription.11	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.11	OctetString	GigabitEthernet1/0/11 Interface
iblfDescription.12	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.12	OctetString	GigabitEthernet1/0/12 Interface
iblfDescription.13	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.13	OctetString	GigabitEthernet1/0/13 Interface
iblfDescription.14	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.14	OctetString	GigabitEthernet1/0/14 Interface
iblfDescription.15	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.15	OctetString	GigabitEthernet1/0/15 Interface

Name	OID	Value Type	Value Example
ibLfDescription.16	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.16	OctetString	GigabitEthernet1/0/16 Interface
ibLfDescription.17	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.17	OctetString	GigabitEthernet1/0/17 Interface
ibLfDescription.18	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.18	OctetString	GigabitEthernet1/0/18 Interface
ibLfDescription.19	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.19	OctetString	GigabitEthernet1/0/19 Interface
ibLfDescription.20	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.20	OctetString	GigabitEthernet1/0/20 Interface
ibLfDescription.21	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.21	OctetString	GigabitEthernet1/0/21 Interface
ibLfDescription.22	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.22	OctetString	GigabitEthernet1/0/22 Interface
ibLfDescription.23	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.23	OctetString	GigabitEthernet1/0/23 Interface
ibLfDescription.24	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.24	OctetString	GigabitEthernet1/0/24 Interface
ibLfDescription.25	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.25	OctetString	GigabitEthernet1/0/25 Interface
ibLfDescription.26	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.26	OctetString	GigabitEthernet1/0/26 Interface
ibLfDescription.27	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.27	OctetString	GigabitEthernet1/0/27 Interface
ibLfDescription.28	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.28	OctetString	GigabitEthernet1/0/28 Interface
ibLfDescription.29	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.29	OctetString	GigabitEthernet1/0/29 Interface
ibLfDescription.30	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.30	OctetString	GigabitEthernet1/0/30 Interface
ibLfDescription.31	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.31	OctetString	GigabitEthernet1/0/31 Interface
ibLfDescription.32	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.32	OctetString	GigabitEthernet1/0/32 Interface
ibLfDescription.33	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.33	OctetString	GigabitEthernet1/0/33 Interface
ibLfDescription.34	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.34	OctetString	GigabitEthernet1/0/34 Interface
ibLfDescription.35	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.35	OctetString	GigabitEthernet1/0/35 Interface
ibLfDescription.36	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.36	OctetString	GigabitEthernet1/0/36 Interface
ibLfDescription.37	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.37	OctetString	GigabitEthernet1/0/37 Interface
ibLfDescription.38	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.38	OctetString	GigabitEthernet1/0/38 Interface
ibLfDescription.39	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.39	OctetString	GigabitEthernet1/0/39 Interface
ibLfDescription.40	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.40	OctetString	GigabitEthernet1/0/40 Interface

Name	OID	Value Type	Value Example
ibLfDescription.41	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.41	OctetString	GigabitEthernet1/0/41 Interface
ibLfDescription.42	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.42	OctetString	GigabitEthernet1/0/42 Interface
ibLfDescription.43	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.43	OctetString	GigabitEthernet1/0/43 Interface
ibLfDescription.44	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.44	OctetString	GigabitEthernet1/0/44 Interface
ibLfDescription.45	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.45	OctetString	RODRIGO-PC
ibLfDescription.46	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.46	OctetString	GigabitEthernet1/0/46 Interface
ibLfDescription.47	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.47	OctetString	ANA-PC
ibLfDescription.48	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.48	OctetString	GigabitEthernet1/0/48 Interface
ibLfDescription.49	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.49	OctetString	Ten-GigabitEthernet1/0/49 Interface
ibLfDescription.50	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.50	OctetString	Ten-GigabitEthernet1/0/50 Interface
ibLfDescription.51	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.51	OctetString	Ten-GigabitEthernet1/0/51 Interface
ibLfDescription.52	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.52	OctetString	Ten-GigabitEthernet1/0/52 Interface
ibLfDescription.53	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.53	OctetString	Ten-GigabitEthernet1/0/53 Interface
ibLfDescription.54	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.54	OctetString	Ten-GigabitEthernet1/0/54 Interface
ibLfDescription.631	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.631	OctetString	NULL0 Interface
ibLfDescription.632	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.632	OctetString	InLoopBack0 Interface
ibLfDescription.633	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.633	OctetString	Register-Tunnel0 Interface
ibLfDescription.634	.1.3.6.1.4.1.26138.2.40.2.3.2.1.13.634	OctetString	Vlan-interface1 Interface
ibLfFwdErrDiscards.1	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.1	Gauge	0
ibLfFwdErrDiscards.2	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.2	Gauge	0
ibLfFwdErrDiscards.3	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.3	Gauge	0
ibLfFwdErrDiscards.4	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.4	Gauge	0
ibLfFwdErrDiscards.5	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.5	Gauge	0
ibLfFwdErrDiscards.6	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.6	Gauge	0
ibLfFwdErrDiscards.7	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.7	Gauge	0
ibLfFwdErrDiscards.8	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.8	Gauge	0
ibLfFwdErrDiscards.9	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.9	Gauge	0
ibLfFwdErrDiscards.10	.1.3.6.1.4.1.26138.2.40.2.3.2.1.14.10	Gauge	0
ibLfFwdErrDiscards.11	.1.3.6.1.4.1.26138.2.40.2.3.2.1.14.11	Gauge	0
ibLfFwdErrDiscards.12	.1.3.6.1.4.1.26138.2.40.2.3.2.1.14.12	Gauge	0
ibLfFwdErrDiscards.13	.1.3.6.1.4.1.26138.2.40.2.3.2.1.14.13	Gauge	0
ibLfFwdErrDiscards.14	.1.3.6.1.4.1.26138.2.40.2.3.2.1.14.14	Gauge	0
ibLfFwdErrDiscards.15	.1.3.6.1.4.1.26138.2.40.2.3.2.1.14.15	Gauge	0
ibLfFwdErrDiscards.16	.1.3.6.1.4.1.26138.2.40.2.3.2.1.14.16	Gauge	0
ibLfFwdErrDiscards.17	.1.3.6.1.4.1.26138.2.40.2.3.2.1.14.17	Gauge	0



Name	OID	Value Type	Value Example
iblfFwdErrDiscards.18	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.18	Gauge	0
iblfFwdErrDiscards.19	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.19	Gauge	0
iblfFwdErrDiscards.20	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.20	Gauge	0
iblfFwdErrDiscards.21	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.21	Gauge	0
iblfFwdErrDiscards.22	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.22	Gauge	0
iblfFwdErrDiscards.23	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.23	Gauge	0
iblfFwdErrDiscards.24	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.24	Gauge	0
iblfFwdErrDiscards.25	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.25	Gauge	0
iblfFwdErrDiscards.26	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.26	Gauge	0
iblfFwdErrDiscards.27	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.27	Gauge	0
iblfFwdErrDiscards.28	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.28	Gauge	0
iblfFwdErrDiscards.29	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.29	Gauge	0
iblfFwdErrDiscards.30	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.30	Gauge	0
iblfFwdErrDiscards.31	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.31	Gauge	0
iblfFwdErrDiscards.32	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.32	Gauge	0
iblfFwdErrDiscards.33	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.33	Gauge	0
iblfFwdErrDiscards.34	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.34	Gauge	0
iblfFwdErrDiscards.35	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.35	Gauge	0
iblfFwdErrDiscards.36	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.36	Gauge	0
iblfFwdErrDiscards.37	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.37	Gauge	0
iblfFwdErrDiscards.38	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.38	Gauge	0
iblfFwdErrDiscards.39	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.39	Gauge	0
iblfFwdErrDiscards.40	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.40	Gauge	0
iblfFwdErrDiscards.41	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.41	Gauge	0
iblfFwdErrDiscards.42	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.42	Gauge	0
iblfFwdErrDiscards.43	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.43	Gauge	0
iblfFwdErrDiscards.44	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.44	Gauge	0
iblfFwdErrDiscards.45	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.45	Gauge	0
iblfFwdErrDiscards.46	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.46	Gauge	0
iblfFwdErrDiscards.47	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.47	Gauge	0
iblfFwdErrDiscards.48	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.48	Gauge	0
iblfFwdErrDiscards.49	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.49	Gauge	0
iblfFwdErrDiscards.50	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.50	Gauge	0
iblfFwdErrDiscards.51	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.51	Gauge	0
iblfFwdErrDiscards.52	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.52	Gauge	0
iblfFwdErrDiscards.53	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.53	Gauge	0
iblfFwdErrDiscards.54	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.54	Gauge	0
iblfFwdErrDiscards.631	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.631	Gauge	0
iblfFwdErrDiscards.632	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.632	Gauge	0
iblfFwdErrDiscards.633	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.633	Gauge	0
iblfFwdErrDiscards.634	1.3.6.1.4.1.26138.2.40.2.3.2.1.14.634	Gauge	0
iblfFiberOrCopper.1	1.3.6.1.4.1.26138.2.40.2.3.2.1.15.1	Integer	copper (2)
iblfFiberOrCopper.2	1.3.6.1.4.1.26138.2.40.2.3.2.1.15.2	Integer	copper (2)





Name	OID	Value Type	Value Example
ibIfFiberOrCopper.46	.1.3.6.1.4.1.26138.2.40.2.3.2.1.15.46	Integer	copper (2)
ibIfFiberOrCopper.47	.1.3.6.1.4.1.26138.2.40.2.3.2.1.15.47	Integer	copper (2)
ibIfFiberOrCopper.48	.1.3.6.1.4.1.26138.2.40.2.3.2.1.15.48	Integer	copper (2)
ibIfFiberOrCopper.49	.1.3.6.1.4.1.26138.2.40.2.3.2.1.15.49	Integer	fiber (1)
ibIfFiberOrCopper.50	.1.3.6.1.4.1.26138.2.40.2.3.2.1.15.50	Integer	fiber (1)
ibIfFiberOrCopper.51	.1.3.6.1.4.1.26138.2.40.2.3.2.1.15.51	Integer	fiber (1)
ibIfFiberOrCopper.52	.1.3.6.1.4.1.26138.2.40.2.3.2.1.15.52	Integer	fiber (1)
ibIfFiberOrCopper.53	.1.3.6.1.4.1.26138.2.40.2.3.2.1.15.53	Integer	fiber (1)
ibIfFiberOrCopper.54	.1.3.6.1.4.1.26138.2.40.2.3.2.1.15.54	Integer	fiber (1)
ibDomainDefault.0	.1.3.6.1.4.1.26138.2.46.1.1.0	OctetString	system
ibDomainState.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.46.2.1.1.2.6.115.121.115.116.101.109	Integer	active (1)
ibDomainRowStatus.6.115.121.115.116.101.109	.1.3.6.1.4.1.26138.2.46.2.1.1.14.6.115.121.115.116.101.109	Integer	active (1)
ibDomainSchemeModel.6.115.121.115.116.101.109.1	.1.3.6.1.4.1.26138.2.46.2.1.1.0.95115.121.115.116.101.109.1	Integer	local (2)
ibDomainSchemeModel.6.115.121.115.116.101.109.2	.1.3.6.1.4.1.26138.2.46.2.1.1.0.95215.121.115.116.101.109.2	Integer	local (2)
ibDomainSchemeModel.6.115.121.115.116.101.109.3	.1.3.6.1.4.1.26138.2.46.2.1.1.0.95315.121.115.116.101.109.3	Integer	local (2)
ibDomainSchemeRowStatus.6.115.121.115.116.101.109.1	.1.3.6.1.4.1.26138.2.46.2.1.1.5.6.115.121.115.116.101.109.1	Integer	active (1)
ibDomainSchemeRowStatus.6.115.121.115.116.101.109.2	.1.3.6.1.4.1.26138.2.46.2.1.1.5.6.115.121.115.116.101.109.2	Integer	active (1)
ibDomainSchemeRowStatus.6.115.121.115.116.101.109.3	.1.3.6.1.4.1.26138.2.46.2.1.1.5.6.115.121.115.116.101.109.3	Integer	active (1)
ibDomainSchemeAAAType.6.115.121.115.116.101.109.1	.1.3.6.1.4.1.26138.2.46.2.1.1.5.6.115.121.115.116.101.109.1	Integer	authentication (2)
ibDomainSchemeAAAType.6.115.121.115.116.101.109.2	.1.3.6.1.4.1.26138.2.46.2.1.1.5.6.115.121.115.116.101.109.2	Integer	authorization (3)
ibDomainSchemeAAAType.6.115.121.115.116.101.109.3	.1.3.6.1.4.1.26138.2.46.2.1.1.5.6.115.121.115.116.101.109.3	Integer	accounting (1)
ibDomainSchemeAAAName.6.115.121.115.116.101.109.1	.1.3.6.1.4.1.26138.2.45.2.15.110.16.109.1.21.115.116.101.109.1	OctetString	
ibDomainSchemeAAAName.6.115.121.115.116.101.109.2	.1.3.6.1.4.1.26138.2.45.2.15.110.16.109.2.21.115.116.101.109.2	OctetString	
ibDomainSchemeAAAName.6.115.121.115.116.101.109.3	.1.3.6.1.4.1.26138.2.45.2.15.110.16.109.3.21.115.116.101.109.3	OctetString	
ibDomainSchemeAccessModel.6.115.121.115.116.101.109.1	.1.3.6.1.4.1.26138.2.46.1.5.2.1.6.115.121.115.116.101.109.1	Integer	default (1)
ibDomainSchemeAccessModel.6.115.121.115.116.101.109.2	.1.3.6.1.4.1.26138.2.46.1.5.2.1.6.115.121.115.116.101.109.2	Integer	default (1)
ibDomainSchemeAccessModel.6.115.121.115.116.101.109.3	.1.3.6.1.4.1.26138.2.46.1.5.2.1.6.115.121.115.116.101.109.3	Integer	default (1)
ibSubnetNumAllVlan.0	.1.3.6.1.4.1.26138.2.61.1.1.1.0	Integer	2096128
ibSubnetNumPerVlan.0	.1.3.6.1.4.1.26138.2.61.1.1.2.0	Integer	512
ibIfQoSMode.1	.1.3.6.1.4.1.26138.2.65.1.1.1.1.1.1	Integer	wrr (5)
ibIfQoSMode.2	.1.3.6.1.4.1.26138.2.65.1.1.1.1.1.2	Integer	wrr (5)
ibIfQoSMode.3	.1.3.6.1.4.1.26138.2.65.1.1.1.1.1.3	Integer	wrr (5)
ibIfQoSMode.4	.1.3.6.1.4.1.26138.2.65.1.1.1.1.1.4	Integer	wrr (5)
ibIfQoSMode.5	.1.3.6.1.4.1.26138.2.65.1.1.1.1.1.5	Integer	wrr (5)
ibIfQoSMode.6	.1.3.6.1.4.1.26138.2.65.1.1.1.1.1.6	Integer	wrr (5)
ibIfQoSMode.7	.1.3.6.1.4.1.26138.2.65.1.1.1.1.1.7	Integer	wrr (5)
ibIfQoSMode.8	.1.3.6.1.4.1.26138.2.65.1.1.1.1.1.8	Integer	wrr (5)
ibIfQoSMode.9	.1.3.6.1.4.1.26138.2.65.1.1.1.1.1.9	Integer	wrr (5)
ibIfQoSMode.10	.1.3.6.1.4.1.26138.2.65.1.1.1.1.1.10	Integer	wrr (5)
ibIfQoSMode.11	.1.3.6.1.4.1.26138.2.65.1.1.1.1.1.11	Integer	wrr (5)
ibIfQoSMode.12	.1.3.6.1.4.1.26138.2.65.1.1.1.1.1.12	Integer	wrr (5)
ibIfQoSMode.13	.1.3.6.1.4.1.26138.2.65.1.1.1.1.1.13	Integer	wrr (5)

Name	OID	Value Type	Value Example
iblfQoSQSMode.14	.3.6.1.4.1.26138.2.65.1.1.1.1.1.14	Integer	wrr (5)
iblfQoSQSMode.15	.3.6.1.4.1.26138.2.65.1.1.1.1.1.15	Integer	wrr (5)
iblfQoSQSMode.16	.3.6.1.4.1.26138.2.65.1.1.1.1.1.16	Integer	wrr (5)
iblfQoSQSMode.17	.3.6.1.4.1.26138.2.65.1.1.1.1.1.17	Integer	wrr (5)
iblfQoSQSMode.18	.3.6.1.4.1.26138.2.65.1.1.1.1.1.18	Integer	wrr (5)
iblfQoSQSMode.19	.3.6.1.4.1.26138.2.65.1.1.1.1.1.19	Integer	wrr (5)
iblfQoSQSMode.20	.3.6.1.4.1.26138.2.65.1.1.1.1.1.20	Integer	wrr (5)
iblfQoSQSMode.21	.3.6.1.4.1.26138.2.65.1.1.1.1.1.21	Integer	wrr (5)
iblfQoSQSMode.22	.3.6.1.4.1.26138.2.65.1.1.1.1.1.22	Integer	wrr (5)
iblfQoSQSMode.23	.3.6.1.4.1.26138.2.65.1.1.1.1.1.23	Integer	wrr (5)
iblfQoSQSMode.24	.3.6.1.4.1.26138.2.65.1.1.1.1.1.24	Integer	wrr (5)
iblfQoSQSMode.25	.3.6.1.4.1.26138.2.65.1.1.1.1.1.25	Integer	wrr (5)
iblfQoSQSMode.26	.3.6.1.4.1.26138.2.65.1.1.1.1.1.26	Integer	wrr (5)
iblfQoSQSMode.27	.3.6.1.4.1.26138.2.65.1.1.1.1.1.27	Integer	wrr (5)
iblfQoSQSMode.28	.3.6.1.4.1.26138.2.65.1.1.1.1.1.28	Integer	wrr (5)
iblfQoSQSMode.29	.3.6.1.4.1.26138.2.65.1.1.1.1.1.29	Integer	wrr (5)
iblfQoSQSMode.30	.3.6.1.4.1.26138.2.65.1.1.1.1.1.30	Integer	wrr (5)
iblfQoSQSMode.31	.3.6.1.4.1.26138.2.65.1.1.1.1.1.31	Integer	wrr (5)
iblfQoSQSMode.32	.3.6.1.4.1.26138.2.65.1.1.1.1.1.32	Integer	wrr (5)
iblfQoSQSMode.33	.3.6.1.4.1.26138.2.65.1.1.1.1.1.33	Integer	wrr (5)
iblfQoSQSMode.34	.3.6.1.4.1.26138.2.65.1.1.1.1.1.34	Integer	wrr (5)
iblfQoSQSMode.35	.3.6.1.4.1.26138.2.65.1.1.1.1.1.35	Integer	wrr (5)
iblfQoSQSMode.36	.3.6.1.4.1.26138.2.65.1.1.1.1.1.36	Integer	wrr (5)
iblfQoSQSMode.37	.3.6.1.4.1.26138.2.65.1.1.1.1.1.37	Integer	wrr (5)
iblfQoSQSMode.38	.3.6.1.4.1.26138.2.65.1.1.1.1.1.38	Integer	wrr (5)
iblfQoSQSMode.39	.3.6.1.4.1.26138.2.65.1.1.1.1.1.39	Integer	wrr (5)
iblfQoSQSMode.40	.3.6.1.4.1.26138.2.65.1.1.1.1.1.40	Integer	wrr (5)
iblfQoSQSMode.41	.3.6.1.4.1.26138.2.65.1.1.1.1.1.41	Integer	wrr (5)
iblfQoSQSMode.42	.3.6.1.4.1.26138.2.65.1.1.1.1.1.42	Integer	wrr (5)
iblfQoSQSMode.43	.3.6.1.4.1.26138.2.65.1.1.1.1.1.43	Integer	wrr (5)
iblfQoSQSMode.44	.3.6.1.4.1.26138.2.65.1.1.1.1.1.44	Integer	wrr (5)
iblfQoSQSMode.45	.3.6.1.4.1.26138.2.65.1.1.1.1.1.45	Integer	wrr (5)
iblfQoSQSMode.46	.3.6.1.4.1.26138.2.65.1.1.1.1.1.46	Integer	wrr (5)
iblfQoSQSMode.47	.3.6.1.4.1.26138.2.65.1.1.1.1.1.47	Integer	wrr (5)
iblfQoSQSMode.48	.3.6.1.4.1.26138.2.65.1.1.1.1.1.48	Integer	wrr (5)
iblfQoSQSMode.49	.3.6.1.4.1.26138.2.65.1.1.1.1.1.49	Integer	wrr (5)
iblfQoSQSMode.50	.3.6.1.4.1.26138.2.65.1.1.1.1.1.50	Integer	wrr (5)
iblfQoSQSMode.51	.3.6.1.4.1.26138.2.65.1.1.1.1.1.51	Integer	wrr (5)
iblfQoSQSMode.52	.3.6.1.4.1.26138.2.65.1.1.1.1.1.52	Integer	wrr (5)
iblfQoSQSMode.53	.3.6.1.4.1.26138.2.65.1.1.1.1.1.53	Integer	wrr (5)
iblfQoSQSMode.54	.3.6.1.4.1.26138.2.65.1.1.1.1.1.54	Integer	wrr (5)
iblfQoSQueueGroupType.1.0	.3.6.1.4.1.26138.2.65.1.1.1.2.1.0	Integer	group1 (2)
iblfQoSQueueGroupType.1.1	.3.6.1.4.1.26138.2.65.1.1.1.2.1.1	Integer	group1 (2)





























Name	OID	Value Type	Value Example
iblfQoSQSType.6.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.6.3	Integer	weight (1)
iblfQoSQSType.6.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.6.4	Integer	weight (1)
iblfQoSQSType.6.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.6.5	Integer	weight (1)
iblfQoSQSType.6.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.6.6	Integer	weight (1)
iblfQoSQSType.6.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.6.7	Integer	weight (1)
iblfQoSQSType.7.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.7.0	Integer	weight (1)
iblfQoSQSType.7.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.7.1	Integer	weight (1)
iblfQoSQSType.7.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.7.2	Integer	weight (1)
iblfQoSQSType.7.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.7.3	Integer	weight (1)
iblfQoSQSType.7.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.7.4	Integer	weight (1)
iblfQoSQSType.7.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.7.5	Integer	weight (1)
iblfQoSQSType.7.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.7.6	Integer	weight (1)
iblfQoSQSType.7.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.7.7	Integer	weight (1)
iblfQoSQSType.8.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.8.0	Integer	weight (1)
iblfQoSQSType.8.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.8.1	Integer	weight (1)
iblfQoSQSType.8.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.8.2	Integer	weight (1)
iblfQoSQSType.8.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.8.3	Integer	weight (1)
iblfQoSQSType.8.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.8.4	Integer	weight (1)
iblfQoSQSType.8.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.8.5	Integer	weight (1)
iblfQoSQSType.8.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.8.6	Integer	weight (1)
iblfQoSQSType.8.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.8.7	Integer	weight (1)
iblfQoSQSType.9.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.9.0	Integer	weight (1)
iblfQoSQSType.9.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.9.1	Integer	weight (1)
iblfQoSQSType.9.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.9.2	Integer	weight (1)
iblfQoSQSType.9.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.9.3	Integer	weight (1)
iblfQoSQSType.9.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.9.4	Integer	weight (1)
iblfQoSQSType.9.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.9.5	Integer	weight (1)
iblfQoSQSType.9.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.9.6	Integer	weight (1)
iblfQoSQSType.9.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.9.7	Integer	weight (1)
iblfQoSQSType.10.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.10.0	Integer	weight (1)
iblfQoSQSType.10.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.10.1	Integer	weight (1)
iblfQoSQSType.10.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.10.2	Integer	weight (1)
iblfQoSQSType.10.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.10.3	Integer	weight (1)
iblfQoSQSType.10.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.10.4	Integer	weight (1)
iblfQoSQSType.10.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.10.5	Integer	weight (1)
iblfQoSQSType.10.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.10.6	Integer	weight (1)
iblfQoSQSType.10.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.10.7	Integer	weight (1)
iblfQoSQSType.11.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.11.0	Integer	weight (1)
iblfQoSQSType.11.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.11.1	Integer	weight (1)
iblfQoSQSType.11.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.11.2	Integer	weight (1)
iblfQoSQSType.11.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.11.3	Integer	weight (1)
iblfQoSQSType.11.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.11.4	Integer	weight (1)
iblfQoSQSType.11.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.11.5	Integer	weight (1)





















Name	OID	Value Type	Value Example
iblfQoSQSType.54.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.54.6	Integer	weight (1)
iblfQoSQSType.54.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.3.54.7	Integer	weight (1)
iblfQoSQSValue.1.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.1.0	Integer	1
iblfQoSQSValue.1.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.1.1	Integer	2
iblfQoSQSValue.1.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.1.2	Integer	3
iblfQoSQSValue.1.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.1.3	Integer	4
iblfQoSQSValue.1.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.1.4	Integer	5
iblfQoSQSValue.1.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.1.5	Integer	9
iblfQoSQSValue.1.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.1.6	Integer	13
iblfQoSQSValue.1.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.1.7	Integer	15
iblfQoSQSValue.2.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.2.0	Integer	1
iblfQoSQSValue.2.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.2.1	Integer	2
iblfQoSQSValue.2.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.2.2	Integer	3
iblfQoSQSValue.2.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.2.3	Integer	4
iblfQoSQSValue.2.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.2.4	Integer	5
iblfQoSQSValue.2.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.2.5	Integer	9
iblfQoSQSValue.2.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.2.6	Integer	13
iblfQoSQSValue.2.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.2.7	Integer	15
iblfQoSQSValue.3.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.3.0	Integer	1
iblfQoSQSValue.3.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.3.1	Integer	2
iblfQoSQSValue.3.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.3.2	Integer	3
iblfQoSQSValue.3.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.3.3	Integer	4
iblfQoSQSValue.3.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.3.4	Integer	5
iblfQoSQSValue.3.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.3.5	Integer	9
iblfQoSQSValue.3.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.3.6	Integer	13
iblfQoSQSValue.3.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.3.7	Integer	15
iblfQoSQSValue.4.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.4.0	Integer	1
iblfQoSQSValue.4.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.4.1	Integer	2
iblfQoSQSValue.4.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.4.2	Integer	3
iblfQoSQSValue.4.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.4.3	Integer	4
iblfQoSQSValue.4.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.4.4	Integer	5
iblfQoSQSValue.4.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.4.5	Integer	9
iblfQoSQSValue.4.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.4.6	Integer	13
iblfQoSQSValue.4.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.4.7	Integer	15
iblfQoSQSValue.5.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.5.0	Integer	1
iblfQoSQSValue.5.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.5.1	Integer	2
iblfQoSQSValue.5.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.5.2	Integer	3
iblfQoSQSValue.5.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.5.3	Integer	4
iblfQoSQSValue.5.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.5.4	Integer	5
iblfQoSQSValue.5.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.5.5	Integer	9
iblfQoSQSValue.5.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.5.6	Integer	13
iblfQoSQSValue.5.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.5.7	Integer	15
iblfQoSQSValue.6.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.6.0	Integer	1



Name	OID	Value Type	Value Example
iblfQoSQSValue.6.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.6.1	Integer	2
iblfQoSQSValue.6.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.6.2	Integer	3
iblfQoSQSValue.6.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.6.3	Integer	4
iblfQoSQSValue.6.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.6.4	Integer	5
iblfQoSQSValue.6.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.6.5	Integer	9
iblfQoSQSValue.6.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.6.6	Integer	13
iblfQoSQSValue.6.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.6.7	Integer	15
iblfQoSQSValue.7.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.7.0	Integer	1
iblfQoSQSValue.7.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.7.1	Integer	2
iblfQoSQSValue.7.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.7.2	Integer	3
iblfQoSQSValue.7.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.7.3	Integer	4
iblfQoSQSValue.7.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.7.4	Integer	5
iblfQoSQSValue.7.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.7.5	Integer	9
iblfQoSQSValue.7.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.7.6	Integer	13
iblfQoSQSValue.7.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.7.7	Integer	15
iblfQoSQSValue.8.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.8.0	Integer	1
iblfQoSQSValue.8.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.8.1	Integer	2
iblfQoSQSValue.8.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.8.2	Integer	3
iblfQoSQSValue.8.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.8.3	Integer	4
iblfQoSQSValue.8.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.8.4	Integer	5
iblfQoSQSValue.8.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.8.5	Integer	9
iblfQoSQSValue.8.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.8.6	Integer	13
iblfQoSQSValue.8.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.8.7	Integer	15
iblfQoSQSValue.9.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.9.0	Integer	1
iblfQoSQSValue.9.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.9.1	Integer	2
iblfQoSQSValue.9.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.9.2	Integer	3
iblfQoSQSValue.9.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.9.3	Integer	4
iblfQoSQSValue.9.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.9.4	Integer	5
iblfQoSQSValue.9.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.9.5	Integer	9
iblfQoSQSValue.9.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.9.6	Integer	13
iblfQoSQSValue.9.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.9.7	Integer	15
iblfQoSQSValue.10.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.10.0	Integer	1
iblfQoSQSValue.10.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.10.1	Integer	2
iblfQoSQSValue.10.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.10.2	Integer	3
iblfQoSQSValue.10.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.10.3	Integer	4
iblfQoSQSValue.10.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.10.4	Integer	5
iblfQoSQSValue.10.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.10.5	Integer	9
iblfQoSQSValue.10.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.10.6	Integer	13
iblfQoSQSValue.10.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.10.7	Integer	15
iblfQoSQSValue.11.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.11.0	Integer	1
iblfQoSQSValue.11.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.11.1	Integer	2
iblfQoSQSValue.11.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.11.2	Integer	3
iblfQoSQSValue.11.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.11.3	Integer	4

Name	OID	Value Type	Value Example
iblfQoSQSValue.11.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.11.4	Integer	5
iblfQoSQSValue.11.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.11.5	Integer	9
iblfQoSQSValue.11.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.11.6	Integer	13
iblfQoSQSValue.11.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.11.7	Integer	15
iblfQoSQSValue.12.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.12.0	Integer	1
iblfQoSQSValue.12.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.12.1	Integer	2
iblfQoSQSValue.12.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.12.2	Integer	3
iblfQoSQSValue.12.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.12.3	Integer	4
iblfQoSQSValue.12.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.12.4	Integer	5
iblfQoSQSValue.12.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.12.5	Integer	9
iblfQoSQSValue.12.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.12.6	Integer	13
iblfQoSQSValue.12.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.12.7	Integer	15
iblfQoSQSValue.13.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.13.0	Integer	1
iblfQoSQSValue.13.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.13.1	Integer	2
iblfQoSQSValue.13.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.13.2	Integer	3
iblfQoSQSValue.13.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.13.3	Integer	4
iblfQoSQSValue.13.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.13.4	Integer	5
iblfQoSQSValue.13.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.13.5	Integer	9
iblfQoSQSValue.13.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.13.6	Integer	13
iblfQoSQSValue.13.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.13.7	Integer	15
iblfQoSQSValue.14.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.14.0	Integer	1
iblfQoSQSValue.14.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.14.1	Integer	2
iblfQoSQSValue.14.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.14.2	Integer	3
iblfQoSQSValue.14.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.14.3	Integer	4
iblfQoSQSValue.14.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.14.4	Integer	5
iblfQoSQSValue.14.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.14.5	Integer	9
iblfQoSQSValue.14.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.14.6	Integer	13
iblfQoSQSValue.14.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.14.7	Integer	15
iblfQoSQSValue.15.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.15.0	Integer	1
iblfQoSQSValue.15.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.15.1	Integer	2
iblfQoSQSValue.15.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.15.2	Integer	3
iblfQoSQSValue.15.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.15.3	Integer	4
iblfQoSQSValue.15.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.15.4	Integer	5
iblfQoSQSValue.15.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.15.5	Integer	9
iblfQoSQSValue.15.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.15.6	Integer	13
iblfQoSQSValue.15.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.15.7	Integer	15
iblfQoSQSValue.16.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.16.0	Integer	1
iblfQoSQSValue.16.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.16.1	Integer	2
iblfQoSQSValue.16.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.16.2	Integer	3
iblfQoSQSValue.16.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.16.3	Integer	4
iblfQoSQSValue.16.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.16.4	Integer	5
iblfQoSQSValue.16.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.16.5	Integer	9
iblfQoSQSValue.16.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.16.6	Integer	13

Name	OID	Value Type	Value Example
iblfQoSQSValue.16.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.16.7	Integer	15
iblfQoSQSValue.17.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.17.0	Integer	1
iblfQoSQSValue.17.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.17.1	Integer	2
iblfQoSQSValue.17.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.17.2	Integer	3
iblfQoSQSValue.17.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.17.3	Integer	4
iblfQoSQSValue.17.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.17.4	Integer	5
iblfQoSQSValue.17.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.17.5	Integer	9
iblfQoSQSValue.17.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.17.6	Integer	13
iblfQoSQSValue.17.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.17.7	Integer	15
iblfQoSQSValue.18.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.18.0	Integer	1
iblfQoSQSValue.18.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.18.1	Integer	2
iblfQoSQSValue.18.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.18.2	Integer	3
iblfQoSQSValue.18.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.18.3	Integer	4
iblfQoSQSValue.18.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.18.4	Integer	5
iblfQoSQSValue.18.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.18.5	Integer	9
iblfQoSQSValue.18.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.18.6	Integer	13
iblfQoSQSValue.18.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.18.7	Integer	15
iblfQoSQSValue.19.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.19.0	Integer	1
iblfQoSQSValue.19.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.19.1	Integer	2
iblfQoSQSValue.19.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.19.2	Integer	3
iblfQoSQSValue.19.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.19.3	Integer	4
iblfQoSQSValue.19.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.19.4	Integer	5
iblfQoSQSValue.19.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.19.5	Integer	9
iblfQoSQSValue.19.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.19.6	Integer	13
iblfQoSQSValue.19.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.19.7	Integer	15
iblfQoSQSValue.20.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.20.0	Integer	1
iblfQoSQSValue.20.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.20.1	Integer	2
iblfQoSQSValue.20.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.20.2	Integer	3
iblfQoSQSValue.20.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.20.3	Integer	4
iblfQoSQSValue.20.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.20.4	Integer	5
iblfQoSQSValue.20.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.20.5	Integer	9
iblfQoSQSValue.20.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.20.6	Integer	13
iblfQoSQSValue.20.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.20.7	Integer	15
iblfQoSQSValue.21.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.21.0	Integer	1
iblfQoSQSValue.21.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.21.1	Integer	2
iblfQoSQSValue.21.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.21.2	Integer	3
iblfQoSQSValue.21.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.21.3	Integer	4
iblfQoSQSValue.21.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.21.4	Integer	5
iblfQoSQSValue.21.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.21.5	Integer	9
iblfQoSQSValue.21.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.21.6	Integer	13
iblfQoSQSValue.21.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.21.7	Integer	15
iblfQoSQSValue.22.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.22.0	Integer	1
iblfQoSQSValue.22.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.22.1	Integer	2

Name	OID	Value Type	Value Example
iblfQoSQSValue.22.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.22	Integer	3
iblfQoSQSValue.22.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.22	Integer	4
iblfQoSQSValue.22.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.22	Integer	5
iblfQoSQSValue.22.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.22	Integer	9
iblfQoSQSValue.22.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.22	Integer	13
iblfQoSQSValue.22.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.22	Integer	15
iblfQoSQSValue.23.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.23	Integer	1
iblfQoSQSValue.23.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.23	Integer	2
iblfQoSQSValue.23.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.23	Integer	3
iblfQoSQSValue.23.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.23	Integer	4
iblfQoSQSValue.23.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.23	Integer	5
iblfQoSQSValue.23.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.23	Integer	9
iblfQoSQSValue.23.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.23	Integer	13
iblfQoSQSValue.23.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.23	Integer	15
iblfQoSQSValue.24.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.24	Integer	1
iblfQoSQSValue.24.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.24	Integer	2
iblfQoSQSValue.24.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.24	Integer	3
iblfQoSQSValue.24.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.24	Integer	4
iblfQoSQSValue.24.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.24	Integer	5
iblfQoSQSValue.24.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.24	Integer	9
iblfQoSQSValue.24.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.24	Integer	13
iblfQoSQSValue.24.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.24	Integer	15
iblfQoSQSValue.25.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.25	Integer	1
iblfQoSQSValue.25.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.25	Integer	2
iblfQoSQSValue.25.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.25	Integer	3
iblfQoSQSValue.25.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.25	Integer	4
iblfQoSQSValue.25.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.25	Integer	5
iblfQoSQSValue.25.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.25	Integer	9
iblfQoSQSValue.25.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.25	Integer	13
iblfQoSQSValue.25.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.25	Integer	15
iblfQoSQSValue.26.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.26	Integer	1
iblfQoSQSValue.26.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.26	Integer	2
iblfQoSQSValue.26.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.26	Integer	3
iblfQoSQSValue.26.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.26	Integer	4
iblfQoSQSValue.26.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.26	Integer	5
iblfQoSQSValue.26.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.26	Integer	9
iblfQoSQSValue.26.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.26	Integer	13
iblfQoSQSValue.26.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.26	Integer	15
iblfQoSQSValue.27.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.27	Integer	1
iblfQoSQSValue.27.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.27	Integer	2
iblfQoSQSValue.27.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.27	Integer	3
iblfQoSQSValue.27.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.27	Integer	4
iblfQoSQSValue.27.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.27	Integer	5

Name	OID	Value Type	Value Example
iblfQoSQSValue.27.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.27.5	Integer	9
iblfQoSQSValue.27.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.27.6	Integer	13
iblfQoSQSValue.27.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.27.7	Integer	15
iblfQoSQSValue.28.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.28.0	Integer	1
iblfQoSQSValue.28.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.28.1	Integer	2
iblfQoSQSValue.28.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.28.2	Integer	3
iblfQoSQSValue.28.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.28.3	Integer	4
iblfQoSQSValue.28.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.28.4	Integer	5
iblfQoSQSValue.28.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.28.5	Integer	9
iblfQoSQSValue.28.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.28.6	Integer	13
iblfQoSQSValue.28.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.28.7	Integer	15
iblfQoSQSValue.29.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.29.0	Integer	1
iblfQoSQSValue.29.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.29.1	Integer	2
iblfQoSQSValue.29.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.29.2	Integer	3
iblfQoSQSValue.29.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.29.3	Integer	4
iblfQoSQSValue.29.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.29.4	Integer	5
iblfQoSQSValue.29.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.29.5	Integer	9
iblfQoSQSValue.29.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.29.6	Integer	13
iblfQoSQSValue.29.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.29.7	Integer	15
iblfQoSQSValue.30.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.30.0	Integer	1
iblfQoSQSValue.30.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.30.1	Integer	2
iblfQoSQSValue.30.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.30.2	Integer	3
iblfQoSQSValue.30.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.30.3	Integer	4
iblfQoSQSValue.30.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.30.4	Integer	5
iblfQoSQSValue.30.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.30.5	Integer	9
iblfQoSQSValue.30.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.30.6	Integer	13
iblfQoSQSValue.30.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.30.7	Integer	15
iblfQoSQSValue.31.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.31.0	Integer	1
iblfQoSQSValue.31.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.31.1	Integer	2
iblfQoSQSValue.31.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.31.2	Integer	3
iblfQoSQSValue.31.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.31.3	Integer	4
iblfQoSQSValue.31.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.31.4	Integer	5
iblfQoSQSValue.31.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.31.5	Integer	9
iblfQoSQSValue.31.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.31.6	Integer	13
iblfQoSQSValue.31.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.31.7	Integer	15
iblfQoSQSValue.32.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.32.0	Integer	1
iblfQoSQSValue.32.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.32.1	Integer	2
iblfQoSQSValue.32.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.32.2	Integer	3
iblfQoSQSValue.32.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.32.3	Integer	4
iblfQoSQSValue.32.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.32.4	Integer	5
iblfQoSQSValue.32.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.32.5	Integer	9
iblfQoSQSValue.32.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.32.6	Integer	13
iblfQoSQSValue.32.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.32.7	Integer	15

Name	OID	Value Type	Value Example
iblfQoSQSValue.33.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.33.0	Integer	1
iblfQoSQSValue.33.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.33.1	Integer	2
iblfQoSQSValue.33.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.33.2	Integer	3
iblfQoSQSValue.33.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.33.3	Integer	4
iblfQoSQSValue.33.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.33.4	Integer	5
iblfQoSQSValue.33.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.33.5	Integer	9
iblfQoSQSValue.33.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.33.6	Integer	13
iblfQoSQSValue.33.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.33.7	Integer	15
iblfQoSQSValue.34.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.34.0	Integer	1
iblfQoSQSValue.34.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.34.1	Integer	2
iblfQoSQSValue.34.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.34.2	Integer	3
iblfQoSQSValue.34.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.34.3	Integer	4
iblfQoSQSValue.34.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.34.4	Integer	5
iblfQoSQSValue.34.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.34.5	Integer	9
iblfQoSQSValue.34.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.34.6	Integer	13
iblfQoSQSValue.34.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.34.7	Integer	15
iblfQoSQSValue.35.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.35.0	Integer	1
iblfQoSQSValue.35.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.35.1	Integer	2
iblfQoSQSValue.35.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.35.2	Integer	3
iblfQoSQSValue.35.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.35.3	Integer	4
iblfQoSQSValue.35.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.35.4	Integer	5
iblfQoSQSValue.35.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.35.5	Integer	9
iblfQoSQSValue.35.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.35.6	Integer	13
iblfQoSQSValue.35.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.35.7	Integer	15
iblfQoSQSValue.36.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.36.0	Integer	1
iblfQoSQSValue.36.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.36.1	Integer	2
iblfQoSQSValue.36.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.36.2	Integer	3
iblfQoSQSValue.36.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.36.3	Integer	4
iblfQoSQSValue.36.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.36.4	Integer	5
iblfQoSQSValue.36.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.36.5	Integer	9
iblfQoSQSValue.36.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.36.6	Integer	13
iblfQoSQSValue.36.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.36.7	Integer	15
iblfQoSQSValue.37.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.37.0	Integer	1
iblfQoSQSValue.37.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.37.1	Integer	2
iblfQoSQSValue.37.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.37.2	Integer	3
iblfQoSQSValue.37.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.37.3	Integer	4
iblfQoSQSValue.37.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.37.4	Integer	5
iblfQoSQSValue.37.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.37.5	Integer	9
iblfQoSQSValue.37.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.37.6	Integer	13
iblfQoSQSValue.37.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.37.7	Integer	15
iblfQoSQSValue.38.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.38.0	Integer	1
iblfQoSQSValue.38.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.38.1	Integer	2
iblfQoSQSValue.38.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.38.2	Integer	3

Name	OID	Value Type	Value Example
iblfQoSQSValue.38.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.38.3	Integer	4
iblfQoSQSValue.38.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.38.4	Integer	5
iblfQoSQSValue.38.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.38.5	Integer	9
iblfQoSQSValue.38.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.38.6	Integer	13
iblfQoSQSValue.38.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.38.7	Integer	15
iblfQoSQSValue.39.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.39.0	Integer	1
iblfQoSQSValue.39.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.39.1	Integer	2
iblfQoSQSValue.39.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.39.2	Integer	3
iblfQoSQSValue.39.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.39.3	Integer	4
iblfQoSQSValue.39.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.39.4	Integer	5
iblfQoSQSValue.39.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.39.5	Integer	9
iblfQoSQSValue.39.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.39.6	Integer	13
iblfQoSQSValue.39.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.39.7	Integer	15
iblfQoSQSValue.40.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.40.0	Integer	1
iblfQoSQSValue.40.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.40.1	Integer	2
iblfQoSQSValue.40.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.40.2	Integer	3
iblfQoSQSValue.40.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.40.3	Integer	4
iblfQoSQSValue.40.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.40.4	Integer	5
iblfQoSQSValue.40.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.40.5	Integer	9
iblfQoSQSValue.40.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.40.6	Integer	13
iblfQoSQSValue.40.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.40.7	Integer	15
iblfQoSQSValue.41.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.41.0	Integer	1
iblfQoSQSValue.41.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.41.1	Integer	2
iblfQoSQSValue.41.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.41.2	Integer	3
iblfQoSQSValue.41.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.41.3	Integer	4
iblfQoSQSValue.41.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.41.4	Integer	5
iblfQoSQSValue.41.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.41.5	Integer	9
iblfQoSQSValue.41.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.41.6	Integer	13
iblfQoSQSValue.41.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.41.7	Integer	15
iblfQoSQSValue.42.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.42.0	Integer	1
iblfQoSQSValue.42.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.42.1	Integer	2
iblfQoSQSValue.42.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.42.2	Integer	3
iblfQoSQSValue.42.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.42.3	Integer	4
iblfQoSQSValue.42.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.42.4	Integer	5
iblfQoSQSValue.42.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.42.5	Integer	9
iblfQoSQSValue.42.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.42.6	Integer	13
iblfQoSQSValue.42.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.42.7	Integer	15
iblfQoSQSValue.43.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.43.0	Integer	1
iblfQoSQSValue.43.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.43.1	Integer	2
iblfQoSQSValue.43.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.43.2	Integer	3
iblfQoSQSValue.43.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.43.3	Integer	4
iblfQoSQSValue.43.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.43.4	Integer	5
iblfQoSQSValue.43.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.43.5	Integer	9



Name	OID	Value Type	Value Example
iblfQoSQSValue.43.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.43.6	Integer	13
iblfQoSQSValue.43.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.43.7	Integer	15
iblfQoSQSValue.44.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.44.0	Integer	1
iblfQoSQSValue.44.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.44.1	Integer	2
iblfQoSQSValue.44.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.44.2	Integer	3
iblfQoSQSValue.44.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.44.3	Integer	4
iblfQoSQSValue.44.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.44.4	Integer	5
iblfQoSQSValue.44.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.44.5	Integer	9
iblfQoSQSValue.44.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.44.6	Integer	13
iblfQoSQSValue.44.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.44.7	Integer	15
iblfQoSQSValue.45.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.45.0	Integer	1
iblfQoSQSValue.45.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.45.1	Integer	2
iblfQoSQSValue.45.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.45.2	Integer	3
iblfQoSQSValue.45.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.45.3	Integer	4
iblfQoSQSValue.45.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.45.4	Integer	5
iblfQoSQSValue.45.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.45.5	Integer	9
iblfQoSQSValue.45.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.45.6	Integer	13
iblfQoSQSValue.45.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.45.7	Integer	15
iblfQoSQSValue.46.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.46.0	Integer	1
iblfQoSQSValue.46.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.46.1	Integer	2
iblfQoSQSValue.46.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.46.2	Integer	3
iblfQoSQSValue.46.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.46.3	Integer	4
iblfQoSQSValue.46.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.46.4	Integer	5
iblfQoSQSValue.46.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.46.5	Integer	9
iblfQoSQSValue.46.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.46.6	Integer	13
iblfQoSQSValue.46.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.46.7	Integer	15
iblfQoSQSValue.47.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.47.0	Integer	1
iblfQoSQSValue.47.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.47.1	Integer	2
iblfQoSQSValue.47.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.47.2	Integer	3
iblfQoSQSValue.47.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.47.3	Integer	4
iblfQoSQSValue.47.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.47.4	Integer	5
iblfQoSQSValue.47.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.47.5	Integer	9
iblfQoSQSValue.47.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.47.6	Integer	13
iblfQoSQSValue.47.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.47.7	Integer	15
iblfQoSQSValue.48.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.48.0	Integer	1
iblfQoSQSValue.48.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.48.1	Integer	2
iblfQoSQSValue.48.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.48.2	Integer	3
iblfQoSQSValue.48.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.48.3	Integer	4
iblfQoSQSValue.48.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.48.4	Integer	5
iblfQoSQSValue.48.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.48.5	Integer	9
iblfQoSQSValue.48.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.48.6	Integer	13
iblfQoSQSValue.48.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.48.7	Integer	15
iblfQoSQSValue.49.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.49.0	Integer	1



Name	OID	Value Type	Value Example
iblfQoSQSValue.49.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.49.1	Integer	2
iblfQoSQSValue.49.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.49.2	Integer	3
iblfQoSQSValue.49.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.49.3	Integer	4
iblfQoSQSValue.49.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.49.4	Integer	5
iblfQoSQSValue.49.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.49.5	Integer	9
iblfQoSQSValue.49.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.49.6	Integer	13
iblfQoSQSValue.49.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.49.7	Integer	15
iblfQoSQSValue.50.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.50.0	Integer	1
iblfQoSQSValue.50.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.50.1	Integer	2
iblfQoSQSValue.50.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.50.2	Integer	3
iblfQoSQSValue.50.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.50.3	Integer	4
iblfQoSQSValue.50.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.50.4	Integer	5
iblfQoSQSValue.50.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.50.5	Integer	9
iblfQoSQSValue.50.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.50.6	Integer	13
iblfQoSQSValue.50.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.50.7	Integer	15
iblfQoSQSValue.51.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.51.0	Integer	1
iblfQoSQSValue.51.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.51.1	Integer	2
iblfQoSQSValue.51.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.51.2	Integer	3
iblfQoSQSValue.51.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.51.3	Integer	4
iblfQoSQSValue.51.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.51.4	Integer	5
iblfQoSQSValue.51.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.51.5	Integer	9
iblfQoSQSValue.51.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.51.6	Integer	13
iblfQoSQSValue.51.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.51.7	Integer	15
iblfQoSQSValue.52.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.52.0	Integer	1
iblfQoSQSValue.52.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.52.1	Integer	2
iblfQoSQSValue.52.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.52.2	Integer	3
iblfQoSQSValue.52.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.52.3	Integer	4
iblfQoSQSValue.52.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.52.4	Integer	5
iblfQoSQSValue.52.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.52.5	Integer	9
iblfQoSQSValue.52.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.52.6	Integer	13
iblfQoSQSValue.52.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.52.7	Integer	15
iblfQoSQSValue.53.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.53.0	Integer	1
iblfQoSQSValue.53.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.53.1	Integer	2
iblfQoSQSValue.53.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.53.2	Integer	3
iblfQoSQSValue.53.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.53.3	Integer	4
iblfQoSQSValue.53.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.53.4	Integer	5
iblfQoSQSValue.53.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.53.5	Integer	9
iblfQoSQSValue.53.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.53.6	Integer	13
iblfQoSQSValue.53.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.53.7	Integer	15
iblfQoSQSValue.54.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.54.0	Integer	1
iblfQoSQSValue.54.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.54.1	Integer	2
iblfQoSQSValue.54.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.54.2	Integer	3
iblfQoSQSValue.54.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.4.54.3	Integer	4

Name	OID	Value Type	Value Example
iblfQoSQSValue.54.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.54.4	Integer	5
iblfQoSQSValue.54.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.54.5	Integer	9
iblfQoSQSValue.54.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.54.6	Integer	13
iblfQoSQSValue.54.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.4.54.7	Integer	15
iblfQoSQSMaxDelay.1.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.1.0	Integer	9
iblfQoSQSMaxDelay.1.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.1.1	Integer	9
iblfQoSQSMaxDelay.1.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.1.2	Integer	9
iblfQoSQSMaxDelay.1.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.1.3	Integer	9
iblfQoSQSMaxDelay.1.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.1.4	Integer	9
iblfQoSQSMaxDelay.1.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.1.5	Integer	9
iblfQoSQSMaxDelay.1.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.1.6	Integer	9
iblfQoSQSMaxDelay.1.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.1.7	Integer	9
iblfQoSQSMaxDelay.2.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.2.0	Integer	9
iblfQoSQSMaxDelay.2.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.2.1	Integer	9
iblfQoSQSMaxDelay.2.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.2.2	Integer	9
iblfQoSQSMaxDelay.2.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.2.3	Integer	9
iblfQoSQSMaxDelay.2.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.2.4	Integer	9
iblfQoSQSMaxDelay.2.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.2.5	Integer	9
iblfQoSQSMaxDelay.2.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.2.6	Integer	9
iblfQoSQSMaxDelay.2.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.2.7	Integer	9
iblfQoSQSMaxDelay.3.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.3.0	Integer	9
iblfQoSQSMaxDelay.3.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.3.1	Integer	9
iblfQoSQSMaxDelay.3.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.3.2	Integer	9
iblfQoSQSMaxDelay.3.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.3.3	Integer	9
iblfQoSQSMaxDelay.3.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.3.4	Integer	9
iblfQoSQSMaxDelay.3.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.3.5	Integer	9
iblfQoSQSMaxDelay.3.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.3.6	Integer	9
iblfQoSQSMaxDelay.3.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.3.7	Integer	9
iblfQoSQSMaxDelay.4.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.4.0	Integer	9
iblfQoSQSMaxDelay.4.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.4.1	Integer	9
iblfQoSQSMaxDelay.4.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.4.2	Integer	9
iblfQoSQSMaxDelay.4.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.4.3	Integer	9
iblfQoSQSMaxDelay.4.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.4.4	Integer	9
iblfQoSQSMaxDelay.4.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.4.5	Integer	9
iblfQoSQSMaxDelay.4.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.4.6	Integer	9
iblfQoSQSMaxDelay.4.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.4.7	Integer	9
iblfQoSQSMaxDelay.5.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.5.0	Integer	9
iblfQoSQSMaxDelay.5.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.5.1	Integer	9
iblfQoSQSMaxDelay.5.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.5.2	Integer	9
iblfQoSQSMaxDelay.5.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.5.3	Integer	9
iblfQoSQSMaxDelay.5.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.5.4	Integer	9
iblfQoSQSMaxDelay.5.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.5.5	Integer	9
iblfQoSQSMaxDelay.5.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.5.6	Integer	9

Name	OID	Value Type	Value Example
iblfQoSQSMaxDelay.5.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.5.7	Integer	9
iblfQoSQSMaxDelay.6.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.6.0	Integer	9
iblfQoSQSMaxDelay.6.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.6.1	Integer	9
iblfQoSQSMaxDelay.6.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.6.2	Integer	9
iblfQoSQSMaxDelay.6.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.6.3	Integer	9
iblfQoSQSMaxDelay.6.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.6.4	Integer	9
iblfQoSQSMaxDelay.6.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.6.5	Integer	9
iblfQoSQSMaxDelay.6.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.6.6	Integer	9
iblfQoSQSMaxDelay.6.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.6.7	Integer	9
iblfQoSQSMaxDelay.7.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.7.0	Integer	9
iblfQoSQSMaxDelay.7.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.7.1	Integer	9
iblfQoSQSMaxDelay.7.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.7.2	Integer	9
iblfQoSQSMaxDelay.7.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.7.3	Integer	9
iblfQoSQSMaxDelay.7.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.7.4	Integer	9
iblfQoSQSMaxDelay.7.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.7.5	Integer	9
iblfQoSQSMaxDelay.7.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.7.6	Integer	9
iblfQoSQSMaxDelay.7.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.7.7	Integer	9
iblfQoSQSMaxDelay.8.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.8.0	Integer	9
iblfQoSQSMaxDelay.8.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.8.1	Integer	9
iblfQoSQSMaxDelay.8.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.8.2	Integer	9
iblfQoSQSMaxDelay.8.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.8.3	Integer	9
iblfQoSQSMaxDelay.8.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.8.4	Integer	9
iblfQoSQSMaxDelay.8.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.8.5	Integer	9
iblfQoSQSMaxDelay.8.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.8.6	Integer	9
iblfQoSQSMaxDelay.8.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.8.7	Integer	9
iblfQoSQSMaxDelay.9.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.9.0	Integer	9
iblfQoSQSMaxDelay.9.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.9.1	Integer	9
iblfQoSQSMaxDelay.9.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.9.2	Integer	9
iblfQoSQSMaxDelay.9.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.9.3	Integer	9
iblfQoSQSMaxDelay.9.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.9.4	Integer	9
iblfQoSQSMaxDelay.9.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.9.5	Integer	9
iblfQoSQSMaxDelay.9.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.9.6	Integer	9
iblfQoSQSMaxDelay.9.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.9.7	Integer	9
iblfQoSQSMaxDelay.10.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.10.0	Integer	9
iblfQoSQSMaxDelay.10.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.10.1	Integer	9
iblfQoSQSMaxDelay.10.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.10.2	Integer	9
iblfQoSQSMaxDelay.10.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.10.3	Integer	9
iblfQoSQSMaxDelay.10.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.10.4	Integer	9
iblfQoSQSMaxDelay.10.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.10.5	Integer	9
iblfQoSQSMaxDelay.10.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.10.6	Integer	9
iblfQoSQSMaxDelay.10.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.10.7	Integer	9
iblfQoSQSMaxDelay.11.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.11.0	Integer	9
iblfQoSQSMaxDelay.11.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.5.11.1	Integer	9

Name	OID	Value Type	Value Example
iblfQoSQSMaxDelay.11.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.11.2	Integer	9
iblfQoSQSMaxDelay.11.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.11.3	Integer	9
iblfQoSQSMaxDelay.11.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.11.4	Integer	9
iblfQoSQSMaxDelay.11.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.11.5	Integer	9
iblfQoSQSMaxDelay.11.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.11.6	Integer	9
iblfQoSQSMaxDelay.11.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.11.7	Integer	9
iblfQoSQSMaxDelay.12.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.12.0	Integer	9
iblfQoSQSMaxDelay.12.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.12.1	Integer	9
iblfQoSQSMaxDelay.12.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.12.2	Integer	9
iblfQoSQSMaxDelay.12.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.12.3	Integer	9
iblfQoSQSMaxDelay.12.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.12.4	Integer	9
iblfQoSQSMaxDelay.12.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.12.5	Integer	9
iblfQoSQSMaxDelay.12.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.12.6	Integer	9
iblfQoSQSMaxDelay.12.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.12.7	Integer	9
iblfQoSQSMaxDelay.13.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.13.0	Integer	9
iblfQoSQSMaxDelay.13.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.13.1	Integer	9
iblfQoSQSMaxDelay.13.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.13.2	Integer	9
iblfQoSQSMaxDelay.13.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.13.3	Integer	9
iblfQoSQSMaxDelay.13.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.13.4	Integer	9
iblfQoSQSMaxDelay.13.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.13.5	Integer	9
iblfQoSQSMaxDelay.13.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.13.6	Integer	9
iblfQoSQSMaxDelay.13.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.13.7	Integer	9
iblfQoSQSMaxDelay.14.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.14.0	Integer	9
iblfQoSQSMaxDelay.14.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.14.1	Integer	9
iblfQoSQSMaxDelay.14.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.14.2	Integer	9
iblfQoSQSMaxDelay.14.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.14.3	Integer	9
iblfQoSQSMaxDelay.14.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.14.4	Integer	9
iblfQoSQSMaxDelay.14.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.14.5	Integer	9
iblfQoSQSMaxDelay.14.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.14.6	Integer	9
iblfQoSQSMaxDelay.14.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.14.7	Integer	9
iblfQoSQSMaxDelay.15.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.15.0	Integer	9
iblfQoSQSMaxDelay.15.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.15.1	Integer	9
iblfQoSQSMaxDelay.15.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.15.2	Integer	9
iblfQoSQSMaxDelay.15.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.15.3	Integer	9
iblfQoSQSMaxDelay.15.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.15.4	Integer	9
iblfQoSQSMaxDelay.15.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.15.5	Integer	9
iblfQoSQSMaxDelay.15.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.15.6	Integer	9
iblfQoSQSMaxDelay.15.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.15.7	Integer	9
iblfQoSQSMaxDelay.16.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.16.0	Integer	9
iblfQoSQSMaxDelay.16.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.16.1	Integer	9
iblfQoSQSMaxDelay.16.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.16.2	Integer	9
iblfQoSQSMaxDelay.16.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.16.3	Integer	9
iblfQoSQSMaxDelay.16.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.16.4	Integer	9

Name	OID	Value Type	Value Example
iblfQoSQSMaxDelay.16.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.16.5	Integer	9
iblfQoSQSMaxDelay.16.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.16.6	Integer	9
iblfQoSQSMaxDelay.16.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.16.7	Integer	9
iblfQoSQSMaxDelay.17.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.17.0	Integer	9
iblfQoSQSMaxDelay.17.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.17.1	Integer	9
iblfQoSQSMaxDelay.17.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.17.2	Integer	9
iblfQoSQSMaxDelay.17.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.17.3	Integer	9
iblfQoSQSMaxDelay.17.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.17.4	Integer	9
iblfQoSQSMaxDelay.17.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.17.5	Integer	9
iblfQoSQSMaxDelay.17.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.17.6	Integer	9
iblfQoSQSMaxDelay.17.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.17.7	Integer	9
iblfQoSQSMaxDelay.18.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.18.0	Integer	9
iblfQoSQSMaxDelay.18.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.18.1	Integer	9
iblfQoSQSMaxDelay.18.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.18.2	Integer	9
iblfQoSQSMaxDelay.18.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.18.3	Integer	9
iblfQoSQSMaxDelay.18.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.18.4	Integer	9
iblfQoSQSMaxDelay.18.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.18.5	Integer	9
iblfQoSQSMaxDelay.18.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.18.6	Integer	9
iblfQoSQSMaxDelay.18.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.18.7	Integer	9
iblfQoSQSMaxDelay.19.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.19.0	Integer	9
iblfQoSQSMaxDelay.19.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.19.1	Integer	9
iblfQoSQSMaxDelay.19.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.19.2	Integer	9
iblfQoSQSMaxDelay.19.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.19.3	Integer	9
iblfQoSQSMaxDelay.19.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.19.4	Integer	9
iblfQoSQSMaxDelay.19.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.19.5	Integer	9
iblfQoSQSMaxDelay.19.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.19.6	Integer	9
iblfQoSQSMaxDelay.19.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.19.7	Integer	9
iblfQoSQSMaxDelay.20.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.20.0	Integer	9
iblfQoSQSMaxDelay.20.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.20.1	Integer	9
iblfQoSQSMaxDelay.20.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.20.2	Integer	9
iblfQoSQSMaxDelay.20.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.20.3	Integer	9
iblfQoSQSMaxDelay.20.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.20.4	Integer	9
iblfQoSQSMaxDelay.20.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.20.5	Integer	9
iblfQoSQSMaxDelay.20.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.20.6	Integer	9
iblfQoSQSMaxDelay.20.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.20.7	Integer	9
iblfQoSQSMaxDelay.21.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.21.0	Integer	9
iblfQoSQSMaxDelay.21.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.21.1	Integer	9
iblfQoSQSMaxDelay.21.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.21.2	Integer	9
iblfQoSQSMaxDelay.21.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.21.3	Integer	9
iblfQoSQSMaxDelay.21.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.21.4	Integer	9
iblfQoSQSMaxDelay.21.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.21.5	Integer	9
iblfQoSQSMaxDelay.21.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.21.6	Integer	9
iblfQoSQSMaxDelay.21.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.21.7	Integer	9

Name	OID	Value Type	Value Example
iblfQoSQSMaxDelay.22.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.22.0	Integer	9
iblfQoSQSMaxDelay.22.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.22.1	Integer	9
iblfQoSQSMaxDelay.22.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.22.2	Integer	9
iblfQoSQSMaxDelay.22.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.22.3	Integer	9
iblfQoSQSMaxDelay.22.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.22.4	Integer	9
iblfQoSQSMaxDelay.22.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.22.5	Integer	9
iblfQoSQSMaxDelay.22.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.22.6	Integer	9
iblfQoSQSMaxDelay.22.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.22.7	Integer	9
iblfQoSQSMaxDelay.23.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.23.0	Integer	9
iblfQoSQSMaxDelay.23.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.23.1	Integer	9
iblfQoSQSMaxDelay.23.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.23.2	Integer	9
iblfQoSQSMaxDelay.23.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.23.3	Integer	9
iblfQoSQSMaxDelay.23.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.23.4	Integer	9
iblfQoSQSMaxDelay.23.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.23.5	Integer	9
iblfQoSQSMaxDelay.23.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.23.6	Integer	9
iblfQoSQSMaxDelay.23.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.23.7	Integer	9
iblfQoSQSMaxDelay.24.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.24.0	Integer	9
iblfQoSQSMaxDelay.24.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.24.1	Integer	9
iblfQoSQSMaxDelay.24.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.24.2	Integer	9
iblfQoSQSMaxDelay.24.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.24.3	Integer	9
iblfQoSQSMaxDelay.24.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.24.4	Integer	9
iblfQoSQSMaxDelay.24.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.24.5	Integer	9
iblfQoSQSMaxDelay.24.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.24.6	Integer	9
iblfQoSQSMaxDelay.24.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.24.7	Integer	9
iblfQoSQSMaxDelay.25.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.25.0	Integer	9
iblfQoSQSMaxDelay.25.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.25.1	Integer	9
iblfQoSQSMaxDelay.25.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.25.2	Integer	9
iblfQoSQSMaxDelay.25.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.25.3	Integer	9
iblfQoSQSMaxDelay.25.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.25.4	Integer	9
iblfQoSQSMaxDelay.25.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.25.5	Integer	9
iblfQoSQSMaxDelay.25.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.25.6	Integer	9
iblfQoSQSMaxDelay.25.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.25.7	Integer	9
iblfQoSQSMaxDelay.26.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.26.0	Integer	9
iblfQoSQSMaxDelay.26.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.26.1	Integer	9
iblfQoSQSMaxDelay.26.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.26.2	Integer	9
iblfQoSQSMaxDelay.26.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.26.3	Integer	9
iblfQoSQSMaxDelay.26.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.26.4	Integer	9
iblfQoSQSMaxDelay.26.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.26.5	Integer	9
iblfQoSQSMaxDelay.26.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.26.6	Integer	9
iblfQoSQSMaxDelay.26.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.26.7	Integer	9
iblfQoSQSMaxDelay.27.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.27.0	Integer	9
iblfQoSQSMaxDelay.27.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.27.1	Integer	9
iblfQoSQSMaxDelay.27.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.27.2	Integer	9



Name	OID	Value Type	Value Example
iblfQoSQSMaxDelay.27.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.27.3	Integer	9
iblfQoSQSMaxDelay.27.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.27.4	Integer	9
iblfQoSQSMaxDelay.27.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.27.5	Integer	9
iblfQoSQSMaxDelay.27.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.27.6	Integer	9
iblfQoSQSMaxDelay.27.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.27.7	Integer	9
iblfQoSQSMaxDelay.28.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.28.0	Integer	9
iblfQoSQSMaxDelay.28.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.28.1	Integer	9
iblfQoSQSMaxDelay.28.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.28.2	Integer	9
iblfQoSQSMaxDelay.28.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.28.3	Integer	9
iblfQoSQSMaxDelay.28.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.28.4	Integer	9
iblfQoSQSMaxDelay.28.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.28.5	Integer	9
iblfQoSQSMaxDelay.28.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.28.6	Integer	9
iblfQoSQSMaxDelay.28.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.28.7	Integer	9
iblfQoSQSMaxDelay.29.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.29.0	Integer	9
iblfQoSQSMaxDelay.29.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.29.1	Integer	9
iblfQoSQSMaxDelay.29.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.29.2	Integer	9
iblfQoSQSMaxDelay.29.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.29.3	Integer	9
iblfQoSQSMaxDelay.29.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.29.4	Integer	9
iblfQoSQSMaxDelay.29.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.29.5	Integer	9
iblfQoSQSMaxDelay.29.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.29.6	Integer	9
iblfQoSQSMaxDelay.29.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.29.7	Integer	9
iblfQoSQSMaxDelay.30.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.30.0	Integer	9
iblfQoSQSMaxDelay.30.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.30.1	Integer	9
iblfQoSQSMaxDelay.30.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.30.2	Integer	9
iblfQoSQSMaxDelay.30.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.30.3	Integer	9
iblfQoSQSMaxDelay.30.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.30.4	Integer	9
iblfQoSQSMaxDelay.30.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.30.5	Integer	9
iblfQoSQSMaxDelay.30.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.30.6	Integer	9
iblfQoSQSMaxDelay.30.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.30.7	Integer	9
iblfQoSQSMaxDelay.31.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.31.0	Integer	9
iblfQoSQSMaxDelay.31.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.31.1	Integer	9
iblfQoSQSMaxDelay.31.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.31.2	Integer	9
iblfQoSQSMaxDelay.31.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.31.3	Integer	9
iblfQoSQSMaxDelay.31.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.31.4	Integer	9
iblfQoSQSMaxDelay.31.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.31.5	Integer	9
iblfQoSQSMaxDelay.31.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.31.6	Integer	9
iblfQoSQSMaxDelay.31.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.31.7	Integer	9
iblfQoSQSMaxDelay.32.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.32.0	Integer	9
iblfQoSQSMaxDelay.32.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.32.1	Integer	9
iblfQoSQSMaxDelay.32.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.32.2	Integer	9
iblfQoSQSMaxDelay.32.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.32.3	Integer	9
iblfQoSQSMaxDelay.32.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.32.4	Integer	9
iblfQoSQSMaxDelay.32.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.32.5	Integer	9

Name	OID	Value Type	Value Example
iblfQoSQSMaxDelay.32.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.32.6	Integer	9
iblfQoSQSMaxDelay.32.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.32.7	Integer	9
iblfQoSQSMaxDelay.33.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.33.0	Integer	9
iblfQoSQSMaxDelay.33.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.33.1	Integer	9
iblfQoSQSMaxDelay.33.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.33.2	Integer	9
iblfQoSQSMaxDelay.33.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.33.3	Integer	9
iblfQoSQSMaxDelay.33.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.33.4	Integer	9
iblfQoSQSMaxDelay.33.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.33.5	Integer	9
iblfQoSQSMaxDelay.33.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.33.6	Integer	9
iblfQoSQSMaxDelay.33.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.33.7	Integer	9
iblfQoSQSMaxDelay.34.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.34.0	Integer	9
iblfQoSQSMaxDelay.34.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.34.1	Integer	9
iblfQoSQSMaxDelay.34.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.34.2	Integer	9
iblfQoSQSMaxDelay.34.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.34.3	Integer	9
iblfQoSQSMaxDelay.34.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.34.4	Integer	9
iblfQoSQSMaxDelay.34.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.34.5	Integer	9
iblfQoSQSMaxDelay.34.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.34.6	Integer	9
iblfQoSQSMaxDelay.34.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.34.7	Integer	9
iblfQoSQSMaxDelay.35.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.35.0	Integer	9
iblfQoSQSMaxDelay.35.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.35.1	Integer	9
iblfQoSQSMaxDelay.35.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.35.2	Integer	9
iblfQoSQSMaxDelay.35.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.35.3	Integer	9
iblfQoSQSMaxDelay.35.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.35.4	Integer	9
iblfQoSQSMaxDelay.35.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.35.5	Integer	9
iblfQoSQSMaxDelay.35.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.35.6	Integer	9
iblfQoSQSMaxDelay.35.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.35.7	Integer	9
iblfQoSQSMaxDelay.36.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.36.0	Integer	9
iblfQoSQSMaxDelay.36.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.36.1	Integer	9
iblfQoSQSMaxDelay.36.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.36.2	Integer	9
iblfQoSQSMaxDelay.36.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.36.3	Integer	9
iblfQoSQSMaxDelay.36.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.36.4	Integer	9
iblfQoSQSMaxDelay.36.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.36.5	Integer	9
iblfQoSQSMaxDelay.36.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.36.6	Integer	9
iblfQoSQSMaxDelay.36.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.36.7	Integer	9
iblfQoSQSMaxDelay.37.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.37.0	Integer	9
iblfQoSQSMaxDelay.37.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.37.1	Integer	9
iblfQoSQSMaxDelay.37.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.37.2	Integer	9
iblfQoSQSMaxDelay.37.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.37.3	Integer	9
iblfQoSQSMaxDelay.37.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.37.4	Integer	9
iblfQoSQSMaxDelay.37.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.37.5	Integer	9
iblfQoSQSMaxDelay.37.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.37.6	Integer	9
iblfQoSQSMaxDelay.37.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.37.7	Integer	9
iblfQoSQSMaxDelay.38.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.38.0	Integer	9



Name	OID	Value Type	Value Example
iblfQoSQSMaxDelay.38.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.38.1	Integer	9
iblfQoSQSMaxDelay.38.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.38.2	Integer	9
iblfQoSQSMaxDelay.38.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.38.3	Integer	9
iblfQoSQSMaxDelay.38.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.38.4	Integer	9
iblfQoSQSMaxDelay.38.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.38.5	Integer	9
iblfQoSQSMaxDelay.38.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.38.6	Integer	9
iblfQoSQSMaxDelay.38.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.38.7	Integer	9
iblfQoSQSMaxDelay.39.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.39.0	Integer	9
iblfQoSQSMaxDelay.39.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.39.1	Integer	9
iblfQoSQSMaxDelay.39.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.39.2	Integer	9
iblfQoSQSMaxDelay.39.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.39.3	Integer	9
iblfQoSQSMaxDelay.39.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.39.4	Integer	9
iblfQoSQSMaxDelay.39.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.39.5	Integer	9
iblfQoSQSMaxDelay.39.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.39.6	Integer	9
iblfQoSQSMaxDelay.39.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.39.7	Integer	9
iblfQoSQSMaxDelay.40.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.40.0	Integer	9
iblfQoSQSMaxDelay.40.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.40.1	Integer	9
iblfQoSQSMaxDelay.40.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.40.2	Integer	9
iblfQoSQSMaxDelay.40.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.40.3	Integer	9
iblfQoSQSMaxDelay.40.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.40.4	Integer	9
iblfQoSQSMaxDelay.40.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.40.5	Integer	9
iblfQoSQSMaxDelay.40.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.40.6	Integer	9
iblfQoSQSMaxDelay.40.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.40.7	Integer	9
iblfQoSQSMaxDelay.41.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.41.0	Integer	9
iblfQoSQSMaxDelay.41.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.41.1	Integer	9
iblfQoSQSMaxDelay.41.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.41.2	Integer	9
iblfQoSQSMaxDelay.41.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.41.3	Integer	9
iblfQoSQSMaxDelay.41.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.41.4	Integer	9
iblfQoSQSMaxDelay.41.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.41.5	Integer	9
iblfQoSQSMaxDelay.41.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.41.6	Integer	9
iblfQoSQSMaxDelay.41.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.41.7	Integer	9
iblfQoSQSMaxDelay.42.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.42.0	Integer	9
iblfQoSQSMaxDelay.42.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.42.1	Integer	9
iblfQoSQSMaxDelay.42.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.42.2	Integer	9
iblfQoSQSMaxDelay.42.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.42.3	Integer	9
iblfQoSQSMaxDelay.42.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.42.4	Integer	9
iblfQoSQSMaxDelay.42.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.42.5	Integer	9
iblfQoSQSMaxDelay.42.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.42.6	Integer	9
iblfQoSQSMaxDelay.42.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.42.7	Integer	9
iblfQoSQSMaxDelay.43.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.43.0	Integer	9
iblfQoSQSMaxDelay.43.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.43.1	Integer	9
iblfQoSQSMaxDelay.43.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.43.2	Integer	9
iblfQoSQSMaxDelay.43.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.43.3	Integer	9

Name	OID	Value Type	Value Example
iblfQoSQSMaxDelay.43.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.43.4	Integer	9
iblfQoSQSMaxDelay.43.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.43.5	Integer	9
iblfQoSQSMaxDelay.43.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.43.6	Integer	9
iblfQoSQSMaxDelay.43.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.43.7	Integer	9
iblfQoSQSMaxDelay.44.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.44.0	Integer	9
iblfQoSQSMaxDelay.44.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.44.1	Integer	9
iblfQoSQSMaxDelay.44.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.44.2	Integer	9
iblfQoSQSMaxDelay.44.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.44.3	Integer	9
iblfQoSQSMaxDelay.44.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.44.4	Integer	9
iblfQoSQSMaxDelay.44.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.44.5	Integer	9
iblfQoSQSMaxDelay.44.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.44.6	Integer	9
iblfQoSQSMaxDelay.44.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.44.7	Integer	9
iblfQoSQSMaxDelay.45.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.45.0	Integer	9
iblfQoSQSMaxDelay.45.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.45.1	Integer	9
iblfQoSQSMaxDelay.45.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.45.2	Integer	9
iblfQoSQSMaxDelay.45.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.45.3	Integer	9
iblfQoSQSMaxDelay.45.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.45.4	Integer	9
iblfQoSQSMaxDelay.45.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.45.5	Integer	9
iblfQoSQSMaxDelay.45.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.45.6	Integer	9
iblfQoSQSMaxDelay.45.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.45.7	Integer	9
iblfQoSQSMaxDelay.46.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.46.0	Integer	9
iblfQoSQSMaxDelay.46.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.46.1	Integer	9
iblfQoSQSMaxDelay.46.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.46.2	Integer	9
iblfQoSQSMaxDelay.46.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.46.3	Integer	9
iblfQoSQSMaxDelay.46.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.46.4	Integer	9
iblfQoSQSMaxDelay.46.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.46.5	Integer	9
iblfQoSQSMaxDelay.46.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.46.6	Integer	9
iblfQoSQSMaxDelay.46.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.46.7	Integer	9
iblfQoSQSMaxDelay.47.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.47.0	Integer	9
iblfQoSQSMaxDelay.47.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.47.1	Integer	9
iblfQoSQSMaxDelay.47.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.47.2	Integer	9
iblfQoSQSMaxDelay.47.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.47.3	Integer	9
iblfQoSQSMaxDelay.47.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.47.4	Integer	9
iblfQoSQSMaxDelay.47.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.47.5	Integer	9
iblfQoSQSMaxDelay.47.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.47.6	Integer	9
iblfQoSQSMaxDelay.47.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.47.7	Integer	9
iblfQoSQSMaxDelay.48.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.48.0	Integer	9
iblfQoSQSMaxDelay.48.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.48.1	Integer	9
iblfQoSQSMaxDelay.48.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.48.2	Integer	9
iblfQoSQSMaxDelay.48.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.48.3	Integer	9
iblfQoSQSMaxDelay.48.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.48.4	Integer	9
iblfQoSQSMaxDelay.48.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.48.5	Integer	9
iblfQoSQSMaxDelay.48.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.48.6	Integer	9

Name	OID	Value Type	Value Example
iblfQoSQSMaxDelay.48.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.48.7	Integer	9
iblfQoSQSMaxDelay.49.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.49.0	Integer	9
iblfQoSQSMaxDelay.49.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.49.1	Integer	9
iblfQoSQSMaxDelay.49.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.49.2	Integer	9
iblfQoSQSMaxDelay.49.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.49.3	Integer	9
iblfQoSQSMaxDelay.49.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.49.4	Integer	9
iblfQoSQSMaxDelay.49.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.49.5	Integer	9
iblfQoSQSMaxDelay.49.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.49.6	Integer	9
iblfQoSQSMaxDelay.49.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.49.7	Integer	9
iblfQoSQSMaxDelay.50.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.50.0	Integer	9
iblfQoSQSMaxDelay.50.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.50.1	Integer	9
iblfQoSQSMaxDelay.50.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.50.2	Integer	9
iblfQoSQSMaxDelay.50.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.50.3	Integer	9
iblfQoSQSMaxDelay.50.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.50.4	Integer	9
iblfQoSQSMaxDelay.50.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.50.5	Integer	9
iblfQoSQSMaxDelay.50.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.50.6	Integer	9
iblfQoSQSMaxDelay.50.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.50.7	Integer	9
iblfQoSQSMaxDelay.51.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.51.0	Integer	9
iblfQoSQSMaxDelay.51.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.51.1	Integer	9
iblfQoSQSMaxDelay.51.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.51.2	Integer	9
iblfQoSQSMaxDelay.51.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.51.3	Integer	9
iblfQoSQSMaxDelay.51.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.51.4	Integer	9
iblfQoSQSMaxDelay.51.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.51.5	Integer	9
iblfQoSQSMaxDelay.51.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.51.6	Integer	9
iblfQoSQSMaxDelay.51.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.51.7	Integer	9
iblfQoSQSMaxDelay.52.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.52.0	Integer	9
iblfQoSQSMaxDelay.52.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.52.1	Integer	9
iblfQoSQSMaxDelay.52.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.52.2	Integer	9
iblfQoSQSMaxDelay.52.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.52.3	Integer	9
iblfQoSQSMaxDelay.52.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.52.4	Integer	9
iblfQoSQSMaxDelay.52.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.52.5	Integer	9
iblfQoSQSMaxDelay.52.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.52.6	Integer	9
iblfQoSQSMaxDelay.52.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.52.7	Integer	9
iblfQoSQSMaxDelay.53.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.53.0	Integer	9
iblfQoSQSMaxDelay.53.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.53.1	Integer	9
iblfQoSQSMaxDelay.53.2	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.53.2	Integer	9
iblfQoSQSMaxDelay.53.3	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.53.3	Integer	9
iblfQoSQSMaxDelay.53.4	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.53.4	Integer	9
iblfQoSQSMaxDelay.53.5	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.53.5	Integer	9
iblfQoSQSMaxDelay.53.6	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.53.6	Integer	9
iblfQoSQSMaxDelay.53.7	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.53.7	Integer	9
iblfQoSQSMaxDelay.54.0	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.54.0	Integer	9
iblfQoSQSMaxDelay.54.1	.13.6.1.4.1.26138.2.65.1.1.1.2.1.5.54.1	Integer	9

























Name	OID	Value Type	Value Example
ibLfQoSQSMInBandwidth.54.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.6.54.0	Integer	0
ibLfQoSQSMInBandwidth.54.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.6.54.1	Integer	0
ibLfQoSQSMInBandwidth.54.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.6.54.2	Integer	0
ibLfQoSQSMInBandwidth.54.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.6.54.3	Integer	0
ibLfQoSQSMInBandwidth.54.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.6.54.4	Integer	0
ibLfQoSQSMInBandwidth.54.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.6.54.5	Integer	0
ibLfQoSQSMInBandwidth.54.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.6.54.6	Integer	0
ibLfQoSQSMInBandwidth.54.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.6.54.7	Integer	0
ibLfQoSQSMInBandwidthPercent.1.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.1.0	Gauge	0
ibLfQoSQSMInBandwidthPercent.1.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.1.1	Gauge	0
ibLfQoSQSMInBandwidthPercent.1.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.1.2	Gauge	0
ibLfQoSQSMInBandwidthPercent.1.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.1.3	Gauge	0
ibLfQoSQSMInBandwidthPercent.1.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.1.4	Gauge	0
ibLfQoSQSMInBandwidthPercent.1.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.1.5	Gauge	0
ibLfQoSQSMInBandwidthPercent.1.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.1.6	Gauge	0
ibLfQoSQSMInBandwidthPercent.1.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.1.7	Gauge	0
ibLfQoSQSMInBandwidthPercent.2.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.2.0	Gauge	0
ibLfQoSQSMInBandwidthPercent.2.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.2.1	Gauge	0
ibLfQoSQSMInBandwidthPercent.2.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.2.2	Gauge	0
ibLfQoSQSMInBandwidthPercent.2.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.2.3	Gauge	0
ibLfQoSQSMInBandwidthPercent.2.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.2.4	Gauge	0
ibLfQoSQSMInBandwidthPercent.2.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.2.5	Gauge	0
ibLfQoSQSMInBandwidthPercent.2.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.2.6	Gauge	0
ibLfQoSQSMInBandwidthPercent.2.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.2.7	Gauge	0
ibLfQoSQSMInBandwidthPercent.3.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.3.0	Gauge	0
ibLfQoSQSMInBandwidthPercent.3.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.3.1	Gauge	0
ibLfQoSQSMInBandwidthPercent.3.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.3.2	Gauge	0
ibLfQoSQSMInBandwidthPercent.3.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.3.3	Gauge	0

Name	OID	Value Type	Value Example
iblfQoSQSMInBandwidthPercent.3.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.3.4	Gauge	0
iblfQoSQSMInBandwidthPercent.3.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.3.5	Gauge	0
iblfQoSQSMInBandwidthPercent.3.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.3.6	Gauge	0
iblfQoSQSMInBandwidthPercent.3.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.3.7	Gauge	0
iblfQoSQSMInBandwidthPercent.4.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.4.0	Gauge	0
iblfQoSQSMInBandwidthPercent.4.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.4.1	Gauge	0
iblfQoSQSMInBandwidthPercent.4.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.4.2	Gauge	0
iblfQoSQSMInBandwidthPercent.4.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.4.3	Gauge	0
iblfQoSQSMInBandwidthPercent.4.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.4.4	Gauge	0
iblfQoSQSMInBandwidthPercent.4.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.4.5	Gauge	0
iblfQoSQSMInBandwidthPercent.4.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.4.6	Gauge	0
iblfQoSQSMInBandwidthPercent.4.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.4.7	Gauge	0
iblfQoSQSMInBandwidthPercent.5.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.5.0	Gauge	0
iblfQoSQSMInBandwidthPercent.5.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.5.1	Gauge	0
iblfQoSQSMInBandwidthPercent.5.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.5.2	Gauge	0
iblfQoSQSMInBandwidthPercent.5.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.5.3	Gauge	0
iblfQoSQSMInBandwidthPercent.5.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.5.4	Gauge	0
iblfQoSQSMInBandwidthPercent.5.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.5.5	Gauge	0
iblfQoSQSMInBandwidthPercent.5.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.5.6	Gauge	0
iblfQoSQSMInBandwidthPercent.5.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.5.7	Gauge	0
iblfQoSQSMInBandwidthPercent.6.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.6.0	Gauge	0
iblfQoSQSMInBandwidthPercent.6.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.6.1	Gauge	0
iblfQoSQSMInBandwidthPercent.6.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.6.2	Gauge	0
iblfQoSQSMInBandwidthPercent.6.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.6.3	Gauge	0
iblfQoSQSMInBandwidthPercent.6.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.6.4	Gauge	0



Name	OID	Value Type	Value Example
iblfQoSQSMInBandwidthPercent.6.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.6.5	Gauge	0
iblfQoSQSMInBandwidthPercent.6.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.6.6	Gauge	0
iblfQoSQSMInBandwidthPercent.6.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.6.7	Gauge	0
iblfQoSQSMInBandwidthPercent.7.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.7.0	Gauge	0
iblfQoSQSMInBandwidthPercent.7.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.7.1	Gauge	0
iblfQoSQSMInBandwidthPercent.7.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.7.2	Gauge	0
iblfQoSQSMInBandwidthPercent.7.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.7.3	Gauge	0
iblfQoSQSMInBandwidthPercent.7.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.7.4	Gauge	0
iblfQoSQSMInBandwidthPercent.7.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.7.5	Gauge	0
iblfQoSQSMInBandwidthPercent.7.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.7.6	Gauge	0
iblfQoSQSMInBandwidthPercent.7.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.7.7	Gauge	0
iblfQoSQSMInBandwidthPercent.8.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.8.0	Gauge	0
iblfQoSQSMInBandwidthPercent.8.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.8.1	Gauge	0
iblfQoSQSMInBandwidthPercent.8.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.8.2	Gauge	0
iblfQoSQSMInBandwidthPercent.8.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.8.3	Gauge	0
iblfQoSQSMInBandwidthPercent.8.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.8.4	Gauge	0
iblfQoSQSMInBandwidthPercent.8.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.8.5	Gauge	0
iblfQoSQSMInBandwidthPercent.8.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.8.6	Gauge	0
iblfQoSQSMInBandwidthPercent.8.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.8.7	Gauge	0
iblfQoSQSMInBandwidthPercent.9.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.9.0	Gauge	0
iblfQoSQSMInBandwidthPercent.9.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.9.1	Gauge	0
iblfQoSQSMInBandwidthPercent.9.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.9.2	Gauge	0
iblfQoSQSMInBandwidthPercent.9.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.9.3	Gauge	0
iblfQoSQSMInBandwidthPercent.9.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.9.4	Gauge	0
iblfQoSQSMInBandwidthPercent.9.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.9.5	Gauge	0



Name	OID	Value Type	Value Example
iblfQoSQSMInBandwidthPercent.9.6	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.9.6	Gauge	0
iblfQoSQSMInBandwidthPercent.9.7	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.9.7	Gauge	0
iblfQoSQSMInBandwidthPercent.10.0	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.10.0	Gauge	0
iblfQoSQSMInBandwidthPercent.10.1	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.10.1	Gauge	0
iblfQoSQSMInBandwidthPercent.10.2	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.10.2	Gauge	0
iblfQoSQSMInBandwidthPercent.10.3	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.10.3	Gauge	0
iblfQoSQSMInBandwidthPercent.10.4	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.10.4	Gauge	0
iblfQoSQSMInBandwidthPercent.10.5	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.10.5	Gauge	0
iblfQoSQSMInBandwidthPercent.10.6	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.10.6	Gauge	0
iblfQoSQSMInBandwidthPercent.10.7	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.10.7	Gauge	0
iblfQoSQSMInBandwidthPercent.11.0	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.11.0	Gauge	0
iblfQoSQSMInBandwidthPercent.11.1	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.11.1	Gauge	0
iblfQoSQSMInBandwidthPercent.11.2	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.11.2	Gauge	0
iblfQoSQSMInBandwidthPercent.11.3	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.11.3	Gauge	0
iblfQoSQSMInBandwidthPercent.11.4	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.11.4	Gauge	0
iblfQoSQSMInBandwidthPercent.11.5	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.11.5	Gauge	0
iblfQoSQSMInBandwidthPercent.11.6	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.11.6	Gauge	0
iblfQoSQSMInBandwidthPercent.11.7	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.11.7	Gauge	0
iblfQoSQSMInBandwidthPercent.12.0	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.12.0	Gauge	0
iblfQoSQSMInBandwidthPercent.12.1	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.12.1	Gauge	0
iblfQoSQSMInBandwidthPercent.12.2	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.12.2	Gauge	0
iblfQoSQSMInBandwidthPercent.12.3	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.12.3	Gauge	0
iblfQoSQSMInBandwidthPercent.12.4	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.12.4	Gauge	0
iblfQoSQSMInBandwidthPercent.12.5	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.12.5	Gauge	0
iblfQoSQSMInBandwidthPercent.12.6	1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.12.6	Gauge	0

Name	OID	Value Type	Value Example
ibIfQoSQSMInBandwidthPercent.12.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.12.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.13.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.13.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.13.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.13.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.13.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.13.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.13.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.13.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.13.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.13.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.13.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.13.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.13.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.13.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.13.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.13.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.14.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.14.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.14.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.14.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.14.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.14.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.14.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.14.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.14.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.14.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.14.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.14.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.14.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.14.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.14.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.14.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.15.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.15.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.15.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.15.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.15.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.15.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.15.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.15.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.15.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.15.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.15.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.15.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.15.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.15.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.15.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.15.7	Gauge	0

Name	OID	Value Type	Value Example
ibIfQoSQSMInBandwidthPercent.16.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.16.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.16.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.16.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.16.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.16.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.16.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.16.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.16.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.16.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.16.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.16.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.16.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.16.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.16.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.16.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.17.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.17.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.17.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.17.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.17.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.17.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.17.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.17.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.17.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.17.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.17.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.17.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.17.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.17.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.17.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.17.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.18.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.18.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.18.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.18.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.18.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.18.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.18.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.18.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.18.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.18.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.18.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.18.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.18.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.18.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.18.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.18.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.19.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.19.0	Gauge	0

Name	OID	Value Type	Value Example
ibIfQoSQSMInBandwidthPercent.19.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.19.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.19.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.19.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.19.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.19.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.19.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.19.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.19.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.19.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.19.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.19.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.19.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.19.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.20.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.20.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.20.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.20.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.20.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.20.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.20.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.20.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.20.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.20.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.20.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.20.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.20.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.20.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.20.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.20.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.21.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.21.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.21.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.21.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.21.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.21.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.21.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.21.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.21.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.21.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.21.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.21.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.21.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.21.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.21.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.21.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.22.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.22.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.22.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.22.1	Gauge	0

Name	OID	Value Type	Value Example
ibIfQoSQSMInBandwidthPercent.22.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.22.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.22.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.22.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.22.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.22.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.22.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.22.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.22.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.22.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.22.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.22.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.23.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.23.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.23.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.23.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.23.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.23.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.23.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.23.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.23.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.23.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.23.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.23.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.23.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.23.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.23.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.23.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.24.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.24.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.24.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.24.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.24.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.24.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.24.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.24.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.24.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.24.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.24.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.24.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.24.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.24.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.24.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.24.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.25.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.25.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.25.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.25.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.25.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.25.2	Gauge	0

Name	OID	Value Type	Value Example
iblfQoSQSMInBandwidthPercent.25.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.25.3	Gauge	0
iblfQoSQSMInBandwidthPercent.25.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.25.4	Gauge	0
iblfQoSQSMInBandwidthPercent.25.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.25.5	Gauge	0
iblfQoSQSMInBandwidthPercent.25.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.25.6	Gauge	0
iblfQoSQSMInBandwidthPercent.25.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.25.7	Gauge	0
iblfQoSQSMInBandwidthPercent.26.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.26.0	Gauge	0
iblfQoSQSMInBandwidthPercent.26.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.26.1	Gauge	0
iblfQoSQSMInBandwidthPercent.26.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.26.2	Gauge	0
iblfQoSQSMInBandwidthPercent.26.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.26.3	Gauge	0
iblfQoSQSMInBandwidthPercent.26.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.26.4	Gauge	0
iblfQoSQSMInBandwidthPercent.26.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.26.5	Gauge	0
iblfQoSQSMInBandwidthPercent.26.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.26.6	Gauge	0
iblfQoSQSMInBandwidthPercent.26.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.26.7	Gauge	0
iblfQoSQSMInBandwidthPercent.27.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.27.0	Gauge	0
iblfQoSQSMInBandwidthPercent.27.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.27.1	Gauge	0
iblfQoSQSMInBandwidthPercent.27.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.27.2	Gauge	0
iblfQoSQSMInBandwidthPercent.27.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.27.3	Gauge	0
iblfQoSQSMInBandwidthPercent.27.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.27.4	Gauge	0
iblfQoSQSMInBandwidthPercent.27.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.27.5	Gauge	0
iblfQoSQSMInBandwidthPercent.27.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.27.6	Gauge	0
iblfQoSQSMInBandwidthPercent.27.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.27.7	Gauge	0
iblfQoSQSMInBandwidthPercent.28.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.28.0	Gauge	0
iblfQoSQSMInBandwidthPercent.28.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.28.1	Gauge	0
iblfQoSQSMInBandwidthPercent.28.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.28.2	Gauge	0
iblfQoSQSMInBandwidthPercent.28.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.28.3	Gauge	0

Name	OID	Value Type	Value Example
ibIfQoSQSMInBandwidthPercent.28.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.28.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.28.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.28.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.28.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.28.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.28.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.28.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.29.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.29.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.29.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.29.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.29.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.29.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.29.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.29.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.29.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.29.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.29.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.29.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.29.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.29.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.29.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.29.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.30.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.30.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.30.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.30.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.30.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.30.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.30.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.30.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.30.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.30.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.30.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.30.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.30.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.30.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.30.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.30.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.31.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.31.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.31.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.31.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.31.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.31.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.31.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.31.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.31.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.31.4	Gauge	0

Name	OID	Value Type	Value Example
ibIfQoSQSMInBandwidthPercent.31.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.31.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.31.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.31.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.31.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.31.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.32.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.32.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.32.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.32.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.32.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.32.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.32.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.32.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.32.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.32.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.32.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.32.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.32.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.32.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.32.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.32.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.33.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.33.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.33.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.33.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.33.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.33.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.33.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.33.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.33.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.33.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.33.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.33.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.33.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.33.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.33.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.33.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.34.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.34.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.34.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.34.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.34.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.34.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.34.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.34.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.34.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.34.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.34.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.34.5	Gauge	0



Name	OID	Value Type	Value Example
iblfQoSQSMInBandwidthPercent.34.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.34.6	Gauge	0
iblfQoSQSMInBandwidthPercent.34.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.34.7	Gauge	0
iblfQoSQSMInBandwidthPercent.35.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.35.0	Gauge	0
iblfQoSQSMInBandwidthPercent.35.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.35.1	Gauge	0
iblfQoSQSMInBandwidthPercent.35.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.35.2	Gauge	0
iblfQoSQSMInBandwidthPercent.35.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.35.3	Gauge	0
iblfQoSQSMInBandwidthPercent.35.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.35.4	Gauge	0
iblfQoSQSMInBandwidthPercent.35.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.35.5	Gauge	0
iblfQoSQSMInBandwidthPercent.35.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.35.6	Gauge	0
iblfQoSQSMInBandwidthPercent.35.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.35.7	Gauge	0
iblfQoSQSMInBandwidthPercent.36.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.36.0	Gauge	0
iblfQoSQSMInBandwidthPercent.36.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.36.1	Gauge	0
iblfQoSQSMInBandwidthPercent.36.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.36.2	Gauge	0
iblfQoSQSMInBandwidthPercent.36.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.36.3	Gauge	0
iblfQoSQSMInBandwidthPercent.36.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.36.4	Gauge	0
iblfQoSQSMInBandwidthPercent.36.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.36.5	Gauge	0
iblfQoSQSMInBandwidthPercent.36.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.36.6	Gauge	0
iblfQoSQSMInBandwidthPercent.36.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.36.7	Gauge	0
iblfQoSQSMInBandwidthPercent.37.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.37.0	Gauge	0
iblfQoSQSMInBandwidthPercent.37.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.37.1	Gauge	0
iblfQoSQSMInBandwidthPercent.37.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.37.2	Gauge	0
iblfQoSQSMInBandwidthPercent.37.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.37.3	Gauge	0
iblfQoSQSMInBandwidthPercent.37.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.37.4	Gauge	0
iblfQoSQSMInBandwidthPercent.37.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.37.5	Gauge	0
iblfQoSQSMInBandwidthPercent.37.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.37.6	Gauge	0

Name	OID	Value Type	Value Example
ibIfQoSQSMInBandwidthPercent.37.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.37.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.38.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.38.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.38.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.38.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.38.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.38.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.38.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.38.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.38.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.38.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.38.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.38.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.38.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.38.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.38.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.38.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.39.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.39.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.39.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.39.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.39.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.39.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.39.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.39.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.39.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.39.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.39.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.39.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.39.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.39.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.39.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.39.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.40.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.40.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.40.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.40.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.40.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.40.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.40.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.40.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.40.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.40.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.40.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.40.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.40.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.40.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.40.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.40.7	Gauge	0

Name	OID	Value Type	Value Example
ibIfQoSQSMInBandwidthPercent.41.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.41.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.41.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.41.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.41.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.41.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.41.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.41.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.41.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.41.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.41.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.41.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.41.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.41.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.41.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.41.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.42.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.42.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.42.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.42.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.42.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.42.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.42.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.42.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.42.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.42.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.42.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.42.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.42.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.42.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.42.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.42.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.43.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.43.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.43.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.43.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.43.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.43.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.43.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.43.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.43.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.43.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.43.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.43.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.43.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.43.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.43.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.43.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.44.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.44.0	Gauge	0

Name	OID	Value Type	Value Example
ibIfQoSQSMInBandwidthPercent.44.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.44.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.44.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.44.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.44.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.44.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.44.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.44.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.44.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.44.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.44.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.44.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.44.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.44.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.45.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.45.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.45.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.45.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.45.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.45.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.45.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.45.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.45.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.45.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.45.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.45.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.45.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.45.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.45.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.45.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.46.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.46.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.46.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.46.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.46.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.46.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.46.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.46.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.46.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.46.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.46.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.46.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.46.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.46.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.46.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.46.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.47.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.47.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.47.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.47.1	Gauge	0

Name	OID	Value Type	Value Example
ibIfQoSQSMInBandwidthPercent.47.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.47.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.47.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.47.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.47.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.47.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.47.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.47.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.47.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.47.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.47.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.47.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.48.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.48.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.48.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.48.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.48.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.48.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.48.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.48.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.48.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.48.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.48.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.48.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.48.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.48.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.48.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.48.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.49.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.49.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.49.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.49.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.49.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.49.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.49.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.49.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.49.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.49.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.49.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.49.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.49.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.49.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.49.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.49.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.50.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.50.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.50.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.50.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.50.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.50.2	Gauge	0

Name	OID	Value Type	Value Example
ibIfQoSQSMInBandwidthPercent.50.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.50.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.50.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.50.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.50.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.50.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.50.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.50.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.50.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.50.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.51.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.51.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.51.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.51.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.51.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.51.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.51.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.51.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.51.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.51.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.51.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.51.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.51.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.51.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.51.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.51.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.52.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.52.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.52.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.52.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.52.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.52.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.52.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.52.3	Gauge	0
ibIfQoSQSMInBandwidthPercent.52.4	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.52.4	Gauge	0
ibIfQoSQSMInBandwidthPercent.52.5	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.52.5	Gauge	0
ibIfQoSQSMInBandwidthPercent.52.6	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.52.6	Gauge	0
ibIfQoSQSMInBandwidthPercent.52.7	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.52.7	Gauge	0
ibIfQoSQSMInBandwidthPercent.53.0	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.53.0	Gauge	0
ibIfQoSQSMInBandwidthPercent.53.1	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.53.1	Gauge	0
ibIfQoSQSMInBandwidthPercent.53.2	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.53.2	Gauge	0
ibIfQoSQSMInBandwidthPercent.53.3	3.6.1.4.1.26138.2.65.1.1.1.2.1.7.53.3	Gauge	0

Name	OID	Value Type	Value Example
iblfQoSQSMInBandwidthPercent.53.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.53.4	Gauge	0
iblfQoSQSMInBandwidthPercent.53.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.53.5	Gauge	0
iblfQoSQSMInBandwidthPercent.53.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.53.6	Gauge	0
iblfQoSQSMInBandwidthPercent.53.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.53.7	Gauge	0
iblfQoSQSMInBandwidthPercent.54.0	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.54.0	Gauge	0
iblfQoSQSMInBandwidthPercent.54.1	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.54.1	Gauge	0
iblfQoSQSMInBandwidthPercent.54.2	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.54.2	Gauge	0
iblfQoSQSMInBandwidthPercent.54.3	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.54.3	Gauge	0
iblfQoSQSMInBandwidthPercent.54.4	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.54.4	Gauge	0
iblfQoSQSMInBandwidthPercent.54.5	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.54.5	Gauge	0
iblfQoSQSMInBandwidthPercent.54.6	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.54.6	Gauge	0
iblfQoSQSMInBandwidthPercent.54.7	.1.3.6.1.4.1.26138.2.65.1.1.1.2.1.7.54.7	Gauge	0
iblfQoSPPassPPS.1.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.1.0	Gauge	0
iblfQoSPPassPPS.1.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.1.1	Gauge	0
iblfQoSPPassPPS.1.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.1.2	Gauge	0
iblfQoSPPassPPS.1.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.1.3	Gauge	0
iblfQoSPPassPPS.1.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.1.4	Gauge	0
iblfQoSPPassPPS.1.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.1.5	Gauge	0
iblfQoSPPassPPS.1.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.1.6	Gauge	0
iblfQoSPPassPPS.1.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.1.7	Gauge	0
iblfQoSPPassPPS.2.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.2.0	Gauge	0
iblfQoSPPassPPS.2.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.2.1	Gauge	0
iblfQoSPPassPPS.2.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.2.2	Gauge	0
iblfQoSPPassPPS.2.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.2.3	Gauge	0
iblfQoSPPassPPS.2.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.2.4	Gauge	0
iblfQoSPPassPPS.2.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.2.5	Gauge	0
iblfQoSPPassPPS.2.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.2.6	Gauge	0
iblfQoSPPassPPS.2.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.2.7	Gauge	0
iblfQoSPPassPPS.3.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.3.0	Gauge	0
iblfQoSPPassPPS.3.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.3.1	Gauge	0
iblfQoSPPassPPS.3.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.3.2	Gauge	0
iblfQoSPPassPPS.3.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.3.3	Gauge	0
iblfQoSPPassPPS.3.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.3.4	Gauge	0
iblfQoSPPassPPS.3.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.3.5	Gauge	0
iblfQoSPPassPPS.3.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.3.6	Gauge	0

Name	OID	Value Type	Value Example
iblfQoSPPassPPS.3.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.37	Gauge	0
iblfQoSPPassPPS.4.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.40	Gauge	0
iblfQoSPPassPPS.4.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.41	Gauge	0
iblfQoSPPassPPS.4.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.42	Gauge	0
iblfQoSPPassPPS.4.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.43	Gauge	0
iblfQoSPPassPPS.4.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.44	Gauge	0
iblfQoSPPassPPS.4.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.45	Gauge	0
iblfQoSPPassPPS.4.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.46	Gauge	0
iblfQoSPPassPPS.4.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.47	Gauge	0
iblfQoSPPassPPS.5.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.50	Gauge	0
iblfQoSPPassPPS.5.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.51	Gauge	0
iblfQoSPPassPPS.5.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.52	Gauge	0
iblfQoSPPassPPS.5.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.53	Gauge	0
iblfQoSPPassPPS.5.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.54	Gauge	0
iblfQoSPPassPPS.5.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.55	Gauge	0
iblfQoSPPassPPS.5.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.56	Gauge	0
iblfQoSPPassPPS.5.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.57	Gauge	0
iblfQoSPPassPPS.6.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.60	Gauge	0
iblfQoSPPassPPS.6.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.61	Gauge	0
iblfQoSPPassPPS.6.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.62	Gauge	0
iblfQoSPPassPPS.6.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.63	Gauge	0
iblfQoSPPassPPS.6.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.64	Gauge	0
iblfQoSPPassPPS.6.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.65	Gauge	0
iblfQoSPPassPPS.6.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.66	Gauge	0
iblfQoSPPassPPS.6.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.67	Gauge	0
iblfQoSPPassPPS.7.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.70	Gauge	0
iblfQoSPPassPPS.7.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.71	Gauge	0
iblfQoSPPassPPS.7.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.72	Gauge	0
iblfQoSPPassPPS.7.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.73	Gauge	0
iblfQoSPPassPPS.7.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.74	Gauge	0
iblfQoSPPassPPS.7.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.75	Gauge	0
iblfQoSPPassPPS.7.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.76	Gauge	0
iblfQoSPPassPPS.7.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.77	Gauge	0
iblfQoSPPassPPS.8.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.80	Gauge	0
iblfQoSPPassPPS.8.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.81	Gauge	0
iblfQoSPPassPPS.8.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.82	Gauge	0
iblfQoSPPassPPS.8.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.83	Gauge	0
iblfQoSPPassPPS.8.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.84	Gauge	0
iblfQoSPPassPPS.8.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.85	Gauge	0
iblfQoSPPassPPS.8.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.86	Gauge	0
iblfQoSPPassPPS.8.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.87	Gauge	0
iblfQoSPPassPPS.9.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.90	Gauge	0
iblfQoSPPassPPS.9.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.91	Gauge	0



Name	OID	Value Type	Value Example
iblfQoSPPassPPS.9.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.9.2	Gauge	0
iblfQoSPPassPPS.9.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.9.3	Gauge	0
iblfQoSPPassPPS.9.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.9.4	Gauge	0
iblfQoSPPassPPS.9.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.9.5	Gauge	0
iblfQoSPPassPPS.9.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.9.6	Gauge	0
iblfQoSPPassPPS.9.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.9.7	Gauge	0
iblfQoSPPassPPS.10.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.10.0	Gauge	0
iblfQoSPPassPPS.10.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.10.1	Gauge	0
iblfQoSPPassPPS.10.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.10.2	Gauge	0
iblfQoSPPassPPS.10.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.10.3	Gauge	0
iblfQoSPPassPPS.10.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.10.4	Gauge	0
iblfQoSPPassPPS.10.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.10.5	Gauge	0
iblfQoSPPassPPS.10.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.10.6	Gauge	0
iblfQoSPPassPPS.10.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.10.7	Gauge	0
iblfQoSPPassPPS.11.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.11.0	Gauge	0
iblfQoSPPassPPS.11.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.11.1	Gauge	0
iblfQoSPPassPPS.11.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.11.2	Gauge	0
iblfQoSPPassPPS.11.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.11.3	Gauge	0
iblfQoSPPassPPS.11.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.11.4	Gauge	0
iblfQoSPPassPPS.11.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.11.5	Gauge	0
iblfQoSPPassPPS.11.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.11.6	Gauge	0
iblfQoSPPassPPS.11.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.11.7	Gauge	0
iblfQoSPPassPPS.12.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.12.0	Gauge	0
iblfQoSPPassPPS.12.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.12.1	Gauge	0
iblfQoSPPassPPS.12.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.12.2	Gauge	0
iblfQoSPPassPPS.12.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.12.3	Gauge	0
iblfQoSPPassPPS.12.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.12.4	Gauge	0
iblfQoSPPassPPS.12.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.12.5	Gauge	0
iblfQoSPPassPPS.12.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.12.6	Gauge	0
iblfQoSPPassPPS.12.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.12.7	Gauge	0
iblfQoSPPassPPS.13.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.13.0	Gauge	0
iblfQoSPPassPPS.13.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.13.1	Gauge	0
iblfQoSPPassPPS.13.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.13.2	Gauge	0
iblfQoSPPassPPS.13.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.13.3	Gauge	0
iblfQoSPPassPPS.13.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.13.4	Gauge	0
iblfQoSPPassPPS.13.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.13.5	Gauge	0
iblfQoSPPassPPS.13.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.13.6	Gauge	0
iblfQoSPPassPPS.13.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.13.7	Gauge	0
iblfQoSPPassPPS.14.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.14.0	Gauge	0
iblfQoSPPassPPS.14.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.14.1	Gauge	0
iblfQoSPPassPPS.14.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.14.2	Gauge	0
iblfQoSPPassPPS.14.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.14.3	Gauge	0
iblfQoSPPassPPS.14.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.14.4	Gauge	0

Name	OID	Value Type	Value Example
iblfQoSPPassPPS.14.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.14.5	Gauge	0
iblfQoSPPassPPS.14.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.14.6	Gauge	0
iblfQoSPPassPPS.14.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.14.7	Gauge	0
iblfQoSPPassPPS.15.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.15.0	Gauge	0
iblfQoSPPassPPS.15.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.15.1	Gauge	0
iblfQoSPPassPPS.15.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.15.2	Gauge	0
iblfQoSPPassPPS.15.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.15.3	Gauge	0
iblfQoSPPassPPS.15.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.15.4	Gauge	0
iblfQoSPPassPPS.15.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.15.5	Gauge	0
iblfQoSPPassPPS.15.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.15.6	Gauge	0
iblfQoSPPassPPS.15.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.15.7	Gauge	0
iblfQoSPPassPPS.16.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.16.0	Gauge	0
iblfQoSPPassPPS.16.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.16.1	Gauge	0
iblfQoSPPassPPS.16.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.16.2	Gauge	0
iblfQoSPPassPPS.16.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.16.3	Gauge	0
iblfQoSPPassPPS.16.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.16.4	Gauge	0
iblfQoSPPassPPS.16.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.16.5	Gauge	0
iblfQoSPPassPPS.16.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.16.6	Gauge	0
iblfQoSPPassPPS.16.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.16.7	Gauge	0
iblfQoSPPassPPS.17.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.17.0	Gauge	0
iblfQoSPPassPPS.17.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.17.1	Gauge	0
iblfQoSPPassPPS.17.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.17.2	Gauge	0
iblfQoSPPassPPS.17.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.17.3	Gauge	0
iblfQoSPPassPPS.17.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.17.4	Gauge	0
iblfQoSPPassPPS.17.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.17.5	Gauge	0
iblfQoSPPassPPS.17.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.17.6	Gauge	0
iblfQoSPPassPPS.17.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.17.7	Gauge	0
iblfQoSPPassPPS.18.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.18.0	Gauge	0
iblfQoSPPassPPS.18.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.18.1	Gauge	0
iblfQoSPPassPPS.18.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.18.2	Gauge	0
iblfQoSPPassPPS.18.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.18.3	Gauge	0
iblfQoSPPassPPS.18.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.18.4	Gauge	0
iblfQoSPPassPPS.18.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.18.5	Gauge	0
iblfQoSPPassPPS.18.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.18.6	Gauge	0
iblfQoSPPassPPS.18.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.18.7	Gauge	0
iblfQoSPPassPPS.19.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.19.0	Gauge	0
iblfQoSPPassPPS.19.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.19.1	Gauge	0
iblfQoSPPassPPS.19.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.19.2	Gauge	0
iblfQoSPPassPPS.19.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.19.3	Gauge	0
iblfQoSPPassPPS.19.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.19.4	Gauge	0
iblfQoSPPassPPS.19.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.19.5	Gauge	0
iblfQoSPPassPPS.19.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.19.6	Gauge	0
iblfQoSPPassPPS.19.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.19.7	Gauge	0

Name	OID	Value Type	Value Example
iblfQoSPPassPPS.20.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.20.0	Gauge	0
iblfQoSPPassPPS.20.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.20.1	Gauge	0
iblfQoSPPassPPS.20.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.20.2	Gauge	0
iblfQoSPPassPPS.20.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.20.3	Gauge	0
iblfQoSPPassPPS.20.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.20.4	Gauge	0
iblfQoSPPassPPS.20.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.20.5	Gauge	0
iblfQoSPPassPPS.20.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.20.6	Gauge	0
iblfQoSPPassPPS.20.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.20.7	Gauge	0
iblfQoSPPassPPS.21.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.21.0	Gauge	0
iblfQoSPPassPPS.21.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.21.1	Gauge	0
iblfQoSPPassPPS.21.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.21.2	Gauge	0
iblfQoSPPassPPS.21.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.21.3	Gauge	0
iblfQoSPPassPPS.21.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.21.4	Gauge	0
iblfQoSPPassPPS.21.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.21.5	Gauge	0
iblfQoSPPassPPS.21.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.21.6	Gauge	0
iblfQoSPPassPPS.21.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.21.7	Gauge	0
iblfQoSPPassPPS.22.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.22.0	Gauge	0
iblfQoSPPassPPS.22.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.22.1	Gauge	0
iblfQoSPPassPPS.22.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.22.2	Gauge	0
iblfQoSPPassPPS.22.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.22.3	Gauge	0
iblfQoSPPassPPS.22.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.22.4	Gauge	0
iblfQoSPPassPPS.22.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.22.5	Gauge	0
iblfQoSPPassPPS.22.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.22.6	Gauge	0
iblfQoSPPassPPS.22.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.22.7	Gauge	0
iblfQoSPPassPPS.23.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.23.0	Gauge	0
iblfQoSPPassPPS.23.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.23.1	Gauge	0
iblfQoSPPassPPS.23.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.23.2	Gauge	0
iblfQoSPPassPPS.23.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.23.3	Gauge	0
iblfQoSPPassPPS.23.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.23.4	Gauge	0
iblfQoSPPassPPS.23.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.23.5	Gauge	0
iblfQoSPPassPPS.23.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.23.6	Gauge	0
iblfQoSPPassPPS.23.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.23.7	Gauge	0
iblfQoSPPassPPS.24.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.24.0	Gauge	0
iblfQoSPPassPPS.24.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.24.1	Gauge	0
iblfQoSPPassPPS.24.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.24.2	Gauge	0
iblfQoSPPassPPS.24.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.24.3	Gauge	0
iblfQoSPPassPPS.24.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.24.4	Gauge	0
iblfQoSPPassPPS.24.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.24.5	Gauge	0
iblfQoSPPassPPS.24.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.24.6	Gauge	0
iblfQoSPPassPPS.24.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.24.7	Gauge	0
iblfQoSPPassPPS.25.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.25.0	Gauge	0
iblfQoSPPassPPS.25.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.25.1	Gauge	0
iblfQoSPPassPPS.25.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.25.2	Gauge	0

Name	OID	Value Type	Value Example
iblfQoSPPassPPS.25.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.25.3	Gauge	0
iblfQoSPPassPPS.25.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.25.4	Gauge	0
iblfQoSPPassPPS.25.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.25.5	Gauge	0
iblfQoSPPassPPS.25.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.25.6	Gauge	0
iblfQoSPPassPPS.25.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.25.7	Gauge	0
iblfQoSPPassPPS.26.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.26.0	Gauge	0
iblfQoSPPassPPS.26.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.26.1	Gauge	0
iblfQoSPPassPPS.26.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.26.2	Gauge	0
iblfQoSPPassPPS.26.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.26.3	Gauge	0
iblfQoSPPassPPS.26.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.26.4	Gauge	0
iblfQoSPPassPPS.26.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.26.5	Gauge	0
iblfQoSPPassPPS.26.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.26.6	Gauge	0
iblfQoSPPassPPS.26.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.26.7	Gauge	0
iblfQoSPPassPPS.27.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.27.0	Gauge	0
iblfQoSPPassPPS.27.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.27.1	Gauge	0
iblfQoSPPassPPS.27.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.27.2	Gauge	0
iblfQoSPPassPPS.27.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.27.3	Gauge	0
iblfQoSPPassPPS.27.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.27.4	Gauge	0
iblfQoSPPassPPS.27.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.27.5	Gauge	0
iblfQoSPPassPPS.27.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.27.6	Gauge	0
iblfQoSPPassPPS.27.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.27.7	Gauge	0
iblfQoSPPassPPS.28.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.28.0	Gauge	0
iblfQoSPPassPPS.28.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.28.1	Gauge	0
iblfQoSPPassPPS.28.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.28.2	Gauge	0
iblfQoSPPassPPS.28.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.28.3	Gauge	0
iblfQoSPPassPPS.28.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.28.4	Gauge	0
iblfQoSPPassPPS.28.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.28.5	Gauge	0
iblfQoSPPassPPS.28.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.28.6	Gauge	0
iblfQoSPPassPPS.28.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.28.7	Gauge	0
iblfQoSPPassPPS.29.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.29.0	Gauge	0
iblfQoSPPassPPS.29.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.29.1	Gauge	0
iblfQoSPPassPPS.29.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.29.2	Gauge	0
iblfQoSPPassPPS.29.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.29.3	Gauge	0
iblfQoSPPassPPS.29.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.29.4	Gauge	0
iblfQoSPPassPPS.29.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.29.5	Gauge	0
iblfQoSPPassPPS.29.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.29.6	Gauge	0
iblfQoSPPassPPS.29.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.29.7	Gauge	0
iblfQoSPPassPPS.30.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.30.0	Gauge	0
iblfQoSPPassPPS.30.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.30.1	Gauge	0
iblfQoSPPassPPS.30.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.30.2	Gauge	0
iblfQoSPPassPPS.30.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.30.3	Gauge	0
iblfQoSPPassPPS.30.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.30.4	Gauge	0
iblfQoSPPassPPS.30.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.4.30.5	Gauge	0

Name	OID	Value Type	Value Example
iblfQoSPPassPPS.30.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.30.6	Gauge	0
iblfQoSPPassPPS.30.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.30.7	Gauge	0
iblfQoSPPassPPS.31.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.31.0	Gauge	0
iblfQoSPPassPPS.31.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.31.1	Gauge	0
iblfQoSPPassPPS.31.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.31.2	Gauge	0
iblfQoSPPassPPS.31.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.31.3	Gauge	0
iblfQoSPPassPPS.31.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.31.4	Gauge	0
iblfQoSPPassPPS.31.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.31.5	Gauge	0
iblfQoSPPassPPS.31.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.31.6	Gauge	0
iblfQoSPPassPPS.31.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.31.7	Gauge	0
iblfQoSPPassPPS.32.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.32.0	Gauge	0
iblfQoSPPassPPS.32.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.32.1	Gauge	0
iblfQoSPPassPPS.32.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.32.2	Gauge	0
iblfQoSPPassPPS.32.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.32.3	Gauge	0
iblfQoSPPassPPS.32.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.32.4	Gauge	0
iblfQoSPPassPPS.32.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.32.5	Gauge	0
iblfQoSPPassPPS.32.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.32.6	Gauge	0
iblfQoSPPassPPS.32.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.32.7	Gauge	0
iblfQoSPPassPPS.33.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.33.0	Gauge	0
iblfQoSPPassPPS.33.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.33.1	Gauge	0
iblfQoSPPassPPS.33.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.33.2	Gauge	0
iblfQoSPPassPPS.33.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.33.3	Gauge	0
iblfQoSPPassPPS.33.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.33.4	Gauge	0
iblfQoSPPassPPS.33.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.33.5	Gauge	0
iblfQoSPPassPPS.33.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.33.6	Gauge	0
iblfQoSPPassPPS.33.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.33.7	Gauge	0
iblfQoSPPassPPS.34.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.34.0	Gauge	0
iblfQoSPPassPPS.34.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.34.1	Gauge	0
iblfQoSPPassPPS.34.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.34.2	Gauge	0
iblfQoSPPassPPS.34.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.34.3	Gauge	0
iblfQoSPPassPPS.34.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.34.4	Gauge	0
iblfQoSPPassPPS.34.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.34.5	Gauge	0
iblfQoSPPassPPS.34.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.34.6	Gauge	0
iblfQoSPPassPPS.34.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.34.7	Gauge	0
iblfQoSPPassPPS.35.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.35.0	Gauge	0
iblfQoSPPassPPS.35.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.35.1	Gauge	0
iblfQoSPPassPPS.35.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.35.2	Gauge	0
iblfQoSPPassPPS.35.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.35.3	Gauge	0
iblfQoSPPassPPS.35.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.35.4	Gauge	0
iblfQoSPPassPPS.35.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.35.5	Gauge	0
iblfQoSPPassPPS.35.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.35.6	Gauge	0
iblfQoSPPassPPS.35.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.35.7	Gauge	0
iblfQoSPPassPPS.36.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.36.0	Gauge	0

Name	OID	Value Type	Value Example
iblfQoSPPassPPS.36.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.36.1	Gauge	0
iblfQoSPPassPPS.36.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.36.2	Gauge	0
iblfQoSPPassPPS.36.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.36.3	Gauge	0
iblfQoSPPassPPS.36.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.36.4	Gauge	0
iblfQoSPPassPPS.36.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.36.5	Gauge	0
iblfQoSPPassPPS.36.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.36.6	Gauge	0
iblfQoSPPassPPS.36.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.36.7	Gauge	0
iblfQoSPPassPPS.37.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.37.0	Gauge	0
iblfQoSPPassPPS.37.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.37.1	Gauge	0
iblfQoSPPassPPS.37.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.37.2	Gauge	0
iblfQoSPPassPPS.37.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.37.3	Gauge	0
iblfQoSPPassPPS.37.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.37.4	Gauge	0
iblfQoSPPassPPS.37.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.37.5	Gauge	0
iblfQoSPPassPPS.37.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.37.6	Gauge	0
iblfQoSPPassPPS.37.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.37.7	Gauge	0
iblfQoSPPassPPS.38.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.38.0	Gauge	0
iblfQoSPPassPPS.38.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.38.1	Gauge	0
iblfQoSPPassPPS.38.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.38.2	Gauge	0
iblfQoSPPassPPS.38.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.38.3	Gauge	0
iblfQoSPPassPPS.38.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.38.4	Gauge	0
iblfQoSPPassPPS.38.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.38.5	Gauge	0
iblfQoSPPassPPS.38.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.38.6	Gauge	0
iblfQoSPPassPPS.38.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.38.7	Gauge	0
iblfQoSPPassPPS.39.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.39.0	Gauge	0
iblfQoSPPassPPS.39.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.39.1	Gauge	0
iblfQoSPPassPPS.39.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.39.2	Gauge	0
iblfQoSPPassPPS.39.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.39.3	Gauge	0
iblfQoSPPassPPS.39.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.39.4	Gauge	0
iblfQoSPPassPPS.39.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.39.5	Gauge	0
iblfQoSPPassPPS.39.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.39.6	Gauge	0
iblfQoSPPassPPS.39.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.39.7	Gauge	0
iblfQoSPPassPPS.40.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.40.0	Gauge	0
iblfQoSPPassPPS.40.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.40.1	Gauge	0
iblfQoSPPassPPS.40.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.40.2	Gauge	0
iblfQoSPPassPPS.40.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.40.3	Gauge	0
iblfQoSPPassPPS.40.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.40.4	Gauge	0
iblfQoSPPassPPS.40.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.40.5	Gauge	0
iblfQoSPPassPPS.40.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.40.6	Gauge	0
iblfQoSPPassPPS.40.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.40.7	Gauge	0
iblfQoSPPassPPS.41.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.41.0	Gauge	0
iblfQoSPPassPPS.41.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.41.1	Gauge	0
iblfQoSPPassPPS.41.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.41.2	Gauge	0
iblfQoSPPassPPS.41.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.41.3	Gauge	0

Name	OID	Value Type	Value Example
iblfQoSPPassPPS.41.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.41.4	Gauge	0
iblfQoSPPassPPS.41.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.41.5	Gauge	0
iblfQoSPPassPPS.41.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.41.6	Gauge	0
iblfQoSPPassPPS.41.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.41.7	Gauge	0
iblfQoSPPassPPS.42.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.42.0	Gauge	0
iblfQoSPPassPPS.42.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.42.1	Gauge	0
iblfQoSPPassPPS.42.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.42.2	Gauge	0
iblfQoSPPassPPS.42.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.42.3	Gauge	0
iblfQoSPPassPPS.42.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.42.4	Gauge	0
iblfQoSPPassPPS.42.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.42.5	Gauge	0
iblfQoSPPassPPS.42.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.42.6	Gauge	0
iblfQoSPPassPPS.42.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.42.7	Gauge	0
iblfQoSPPassPPS.43.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.43.0	Gauge	0
iblfQoSPPassPPS.43.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.43.1	Gauge	0
iblfQoSPPassPPS.43.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.43.2	Gauge	0
iblfQoSPPassPPS.43.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.43.3	Gauge	0
iblfQoSPPassPPS.43.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.43.4	Gauge	0
iblfQoSPPassPPS.43.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.43.5	Gauge	0
iblfQoSPPassPPS.43.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.43.6	Gauge	0
iblfQoSPPassPPS.43.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.43.7	Gauge	0
iblfQoSPPassPPS.44.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.44.0	Gauge	0
iblfQoSPPassPPS.44.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.44.1	Gauge	0
iblfQoSPPassPPS.44.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.44.2	Gauge	0
iblfQoSPPassPPS.44.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.44.3	Gauge	0
iblfQoSPPassPPS.44.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.44.4	Gauge	0
iblfQoSPPassPPS.44.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.44.5	Gauge	0
iblfQoSPPassPPS.44.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.44.6	Gauge	0
iblfQoSPPassPPS.44.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.44.7	Gauge	0
iblfQoSPPassPPS.45.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.45.0	Gauge	0
iblfQoSPPassPPS.45.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.45.1	Gauge	0
iblfQoSPPassPPS.45.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.45.2	Gauge	0
iblfQoSPPassPPS.45.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.45.3	Gauge	0
iblfQoSPPassPPS.45.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.45.4	Gauge	0
iblfQoSPPassPPS.45.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.45.5	Gauge	0
iblfQoSPPassPPS.45.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.45.6	Gauge	0
iblfQoSPPassPPS.45.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.45.7	Gauge	0
iblfQoSPPassPPS.46.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.46.0	Gauge	0
iblfQoSPPassPPS.46.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.46.1	Gauge	0
iblfQoSPPassPPS.46.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.46.2	Gauge	0
iblfQoSPPassPPS.46.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.46.3	Gauge	0
iblfQoSPPassPPS.46.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.46.4	Gauge	0
iblfQoSPPassPPS.46.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.46.5	Gauge	0
iblfQoSPPassPPS.46.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.46.6	Gauge	0



Name	OID	Value Type	Value Example
iblfQoSPPassPPS.46.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.46.7	Gauge	0
iblfQoSPPassPPS.47.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.47.0	Gauge	0
iblfQoSPPassPPS.47.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.47.1	Gauge	0
iblfQoSPPassPPS.47.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.47.2	Gauge	0
iblfQoSPPassPPS.47.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.47.3	Gauge	0
iblfQoSPPassPPS.47.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.47.4	Gauge	0
iblfQoSPPassPPS.47.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.47.5	Gauge	0
iblfQoSPPassPPS.47.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.47.6	Gauge	0
iblfQoSPPassPPS.47.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.47.7	Gauge	0
iblfQoSPPassPPS.48.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.48.0	Gauge	0
iblfQoSPPassPPS.48.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.48.1	Gauge	0
iblfQoSPPassPPS.48.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.48.2	Gauge	0
iblfQoSPPassPPS.48.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.48.3	Gauge	0
iblfQoSPPassPPS.48.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.48.4	Gauge	0
iblfQoSPPassPPS.48.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.48.5	Gauge	0
iblfQoSPPassPPS.48.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.48.6	Gauge	0
iblfQoSPPassPPS.48.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.48.7	Gauge	0
iblfQoSPPassPPS.49.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.49.0	Gauge	0
iblfQoSPPassPPS.49.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.49.1	Gauge	0
iblfQoSPPassPPS.49.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.49.2	Gauge	0
iblfQoSPPassPPS.49.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.49.3	Gauge	0
iblfQoSPPassPPS.49.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.49.4	Gauge	0
iblfQoSPPassPPS.49.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.49.5	Gauge	0
iblfQoSPPassPPS.49.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.49.6	Gauge	0
iblfQoSPPassPPS.49.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.49.7	Gauge	0
iblfQoSPPassPPS.50.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.50.0	Gauge	0
iblfQoSPPassPPS.50.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.50.1	Gauge	0
iblfQoSPPassPPS.50.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.50.2	Gauge	0
iblfQoSPPassPPS.50.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.50.3	Gauge	0
iblfQoSPPassPPS.50.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.50.4	Gauge	0
iblfQoSPPassPPS.50.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.50.5	Gauge	0
iblfQoSPPassPPS.50.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.50.6	Gauge	0
iblfQoSPPassPPS.50.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.50.7	Gauge	0
iblfQoSPPassPPS.51.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.51.0	Gauge	0
iblfQoSPPassPPS.51.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.51.1	Gauge	0
iblfQoSPPassPPS.51.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.51.2	Gauge	0
iblfQoSPPassPPS.51.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.51.3	Gauge	0
iblfQoSPPassPPS.51.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.51.4	Gauge	0
iblfQoSPPassPPS.51.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.51.5	Gauge	0
iblfQoSPPassPPS.51.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.51.6	Gauge	0
iblfQoSPPassPPS.51.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.51.7	Gauge	0
iblfQoSPPassPPS.52.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.52.0	Gauge	0
iblfQoSPPassPPS.52.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.52.1	Gauge	0



Name	OID	Value Type	Value Example
iblfQoSPPassPPS.52.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.52.2	Gauge	0
iblfQoSPPassPPS.52.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.52.3	Gauge	0
iblfQoSPPassPPS.52.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.52.4	Gauge	0
iblfQoSPPassPPS.52.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.52.5	Gauge	0
iblfQoSPPassPPS.52.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.52.6	Gauge	0
iblfQoSPPassPPS.52.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.52.7	Gauge	0
iblfQoSPPassPPS.53.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.53.0	Gauge	0
iblfQoSPPassPPS.53.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.53.1	Gauge	0
iblfQoSPPassPPS.53.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.53.2	Gauge	0
iblfQoSPPassPPS.53.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.53.3	Gauge	0
iblfQoSPPassPPS.53.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.53.4	Gauge	0
iblfQoSPPassPPS.53.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.53.5	Gauge	0
iblfQoSPPassPPS.53.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.53.6	Gauge	0
iblfQoSPPassPPS.53.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.53.7	Gauge	0
iblfQoSPPassPPS.54.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.54.0	Gauge	0
iblfQoSPPassPPS.54.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.54.1	Gauge	0
iblfQoSPPassPPS.54.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.54.2	Gauge	0
iblfQoSPPassPPS.54.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.54.3	Gauge	0
iblfQoSPPassPPS.54.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.54.4	Gauge	0
iblfQoSPPassPPS.54.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.54.5	Gauge	0
iblfQoSPPassPPS.54.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.54.6	Gauge	0
iblfQoSPPassPPS.54.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.4.54.7	Gauge	0
iblfQoSPPassBPS.1.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.5.1.0	Gauge	4294967295
iblfQoSPPassBPS.1.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.5.1.1	Gauge	4294967295
iblfQoSPPassBPS.1.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.5.1.2	Gauge	4294967295
iblfQoSPPassBPS.1.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.5.1.3	Gauge	4294967295
iblfQoSPPassBPS.1.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.5.1.4	Gauge	4294967295
iblfQoSPPassBPS.1.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.5.1.5	Gauge	4294967295
iblfQoSPPassBPS.1.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.5.1.6	Gauge	4294967295
iblfQoSPPassBPS.1.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.5.1.7	Gauge	4294967295
iblfQoSPPassBPS.2.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.5.2.0	Gauge	4294967295
iblfQoSPPassBPS.2.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.5.2.1	Gauge	4294967295
iblfQoSPPassBPS.2.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.5.2.2	Gauge	4294967295
iblfQoSPPassBPS.2.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.5.2.3	Gauge	4294967295
iblfQoSPPassBPS.2.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.5.2.4	Gauge	4294967295
iblfQoSPPassBPS.2.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.5.2.5	Gauge	4294967295
iblfQoSPPassBPS.2.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.5.2.6	Gauge	4294967295
iblfQoSPPassBPS.2.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.5.2.7	Gauge	4294967295
iblfQoSPPassBPS.3.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.5.3.0	Gauge	4294967295
iblfQoSPPassBPS.3.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.5.3.1	Gauge	4294967295
iblfQoSPPassBPS.3.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.5.3.2	Gauge	4294967295
iblfQoSPPassBPS.3.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.5.3.3	Gauge	4294967295
iblfQoSPPassBPS.3.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.5.3.4	Gauge	4294967295



























Name	OID	Value Type	Value Example
iblfQoSQueueLengthInPkts.8.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.8.6	Gauge	4294967295
iblfQoSQueueLengthInPkts.8.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.8.7	Gauge	4294967295
iblfQoSQueueLengthInPkts.9.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.9.0	Gauge	4294967295
iblfQoSQueueLengthInPkts.9.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.9.1	Gauge	4294967295
iblfQoSQueueLengthInPkts.9.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.9.2	Gauge	4294967295
iblfQoSQueueLengthInPkts.9.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.9.3	Gauge	4294967295
iblfQoSQueueLengthInPkts.9.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.9.4	Gauge	4294967295
iblfQoSQueueLengthInPkts.9.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.9.5	Gauge	4294967295
iblfQoSQueueLengthInPkts.9.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.9.6	Gauge	4294967295
iblfQoSQueueLengthInPkts.9.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.9.7	Gauge	4294967295
iblfQoSQueueLengthInPkts.10.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.10.0	Gauge	4294967295
iblfQoSQueueLengthInPkts.10.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.10.1	Gauge	4294967295
iblfQoSQueueLengthInPkts.10.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.10.2	Gauge	4294967295
iblfQoSQueueLengthInPkts.10.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.10.3	Gauge	4294967295
iblfQoSQueueLengthInPkts.10.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.10.4	Gauge	4294967295
iblfQoSQueueLengthInPkts.10.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.10.5	Gauge	4294967295
iblfQoSQueueLengthInPkts.10.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.10.6	Gauge	4294967295
iblfQoSQueueLengthInPkts.10.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.10.7	Gauge	4294967295
iblfQoSQueueLengthInPkts.11.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.11.0	Gauge	4294967295
iblfQoSQueueLengthInPkts.11.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.11.1	Gauge	4294967295
iblfQoSQueueLengthInPkts.11.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.11.2	Gauge	4294967295
iblfQoSQueueLengthInPkts.11.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.11.3	Gauge	4294967295
iblfQoSQueueLengthInPkts.11.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.11.4	Gauge	4294967295
iblfQoSQueueLengthInPkts.11.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.11.5	Gauge	4294967295
iblfQoSQueueLengthInPkts.11.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.11.6	Gauge	4294967295
iblfQoSQueueLengthInPkts.11.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.11.7	Gauge	4294967295
iblfQoSQueueLengthInPkts.12.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.12.0	Gauge	4294967295
iblfQoSQueueLengthInPkts.12.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.12.1	Gauge	4294967295
iblfQoSQueueLengthInPkts.12.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.12.2	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueue-LengthInPkts.12.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.12.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.12.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.12.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.12.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.12.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.12.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.12.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.12.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.12.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.13.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.13.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.13.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.13.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.13.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.13.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.13.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.13.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.13.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.13.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.13.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.13.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.13.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.13.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.13.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.13.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.14.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.14.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.14.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.14.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.14.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.14.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.14.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.14.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.14.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.14.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.14.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.14.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.14.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.14.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.14.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.14.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.15.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.15.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.15.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.15.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.15.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.15.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.15.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.15.3	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueue-LengthInPkts.15.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.15.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.15.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.15.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.15.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.15.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.15.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.15.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.16.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.16.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.16.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.16.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.16.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.16.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.16.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.16.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.16.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.16.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.16.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.16.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.16.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.16.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.16.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.16.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.17.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.17.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.17.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.17.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.17.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.17.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.17.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.17.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.17.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.17.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.17.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.17.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.17.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.17.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.17.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.17.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.18.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.18.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.18.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.18.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.18.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.18.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.18.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.18.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.18.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.18.4	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSQueue-LengthInPkts.18.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.18.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.18.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.18.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.18.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.18.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.19.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.19.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.19.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.19.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.19.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.19.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.19.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.19.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.19.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.19.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.19.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.19.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.19.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.19.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.19.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.19.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.20.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.20.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.20.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.20.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.20.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.20.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.20.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.20.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.20.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.20.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.20.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.20.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.20.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.20.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.20.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.20.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.21.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.21.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.21.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.21.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.21.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.21.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.21.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.21.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.21.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.21.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.21.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.21.5	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSQueue- LengthInPkts.21.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.21.6	Gauge	4294967295
iblfQoSQueue- LengthInPkts.21.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.21.7	Gauge	4294967295
iblfQoSQueue- LengthInPkts.22.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.22.0	Gauge	4294967295
iblfQoSQueue- LengthInPkts.22.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.22.1	Gauge	4294967295
iblfQoSQueue- LengthInPkts.22.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.22.2	Gauge	4294967295
iblfQoSQueue- LengthInPkts.22.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.22.3	Gauge	4294967295
iblfQoSQueue- LengthInPkts.22.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.22.4	Gauge	4294967295
iblfQoSQueue- LengthInPkts.22.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.22.5	Gauge	4294967295
iblfQoSQueue- LengthInPkts.22.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.22.6	Gauge	4294967295
iblfQoSQueue- LengthInPkts.22.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.22.7	Gauge	4294967295
iblfQoSQueue- LengthInPkts.23.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.23.0	Gauge	4294967295
iblfQoSQueue- LengthInPkts.23.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.23.1	Gauge	4294967295
iblfQoSQueue- LengthInPkts.23.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.23.2	Gauge	4294967295
iblfQoSQueue- LengthInPkts.23.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.23.3	Gauge	4294967295
iblfQoSQueue- LengthInPkts.23.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.23.4	Gauge	4294967295
iblfQoSQueue- LengthInPkts.23.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.23.5	Gauge	4294967295
iblfQoSQueue- LengthInPkts.23.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.23.6	Gauge	4294967295
iblfQoSQueue- LengthInPkts.23.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.23.7	Gauge	4294967295
iblfQoSQueue- LengthInPkts.24.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.24.0	Gauge	4294967295
iblfQoSQueue- LengthInPkts.24.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.24.1	Gauge	4294967295
iblfQoSQueue- LengthInPkts.24.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.24.2	Gauge	4294967295
iblfQoSQueue- LengthInPkts.24.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.24.3	Gauge	4294967295
iblfQoSQueue- LengthInPkts.24.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.24.4	Gauge	4294967295
iblfQoSQueue- LengthInPkts.24.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.24.5	Gauge	4294967295
iblfQoSQueue- LengthInPkts.24.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.24.6	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueue-LengthInPkts.24.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.24.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.25.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.25.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.25.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.25.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.25.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.25.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.25.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.25.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.25.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.25.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.25.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.25.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.25.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.25.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.25.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.25.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.26.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.26.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.26.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.26.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.26.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.26.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.26.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.26.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.26.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.26.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.26.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.26.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.26.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.26.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.26.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.26.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.27.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.27.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.27.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.27.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.27.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.27.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.27.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.27.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.27.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.27.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.27.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.27.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.27.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.27.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.27.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.27.7	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueue-LengthInPkts.28.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.28.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.28.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.28.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.28.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.28.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.28.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.28.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.28.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.28.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.28.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.28.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.28.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.28.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.28.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.28.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.29.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.29.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.29.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.29.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.29.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.29.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.29.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.29.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.29.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.29.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.29.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.29.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.29.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.29.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.29.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.29.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.30.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.30.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.30.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.30.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.30.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.30.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.30.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.30.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.30.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.30.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.30.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.30.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.30.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.30.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.30.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.30.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.31.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.31.0	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueue-LengthInPkts.31.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.31.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.31.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.31.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.31.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.31.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.31.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.31.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.31.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.31.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.31.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.31.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.31.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.31.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.32.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.32.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.32.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.32.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.32.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.32.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.32.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.32.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.32.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.32.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.32.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.32.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.32.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.32.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.32.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.32.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.33.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.33.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.33.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.33.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.33.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.33.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.33.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.33.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.33.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.33.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.33.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.33.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.33.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.33.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.33.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.33.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.34.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.34.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.34.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.34.1	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueue- LengthInPkts.34.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.34.2	Gauge	4294967295
iblfQoSQueue- LengthInPkts.34.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.34.3	Gauge	4294967295
iblfQoSQueue- LengthInPkts.34.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.34.4	Gauge	4294967295
iblfQoSQueue- LengthInPkts.34.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.34.5	Gauge	4294967295
iblfQoSQueue- LengthInPkts.34.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.34.6	Gauge	4294967295
iblfQoSQueue- LengthInPkts.34.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.34.7	Gauge	4294967295
iblfQoSQueue- LengthInPkts.35.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.35.0	Gauge	4294967295
iblfQoSQueue- LengthInPkts.35.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.35.1	Gauge	4294967295
iblfQoSQueue- LengthInPkts.35.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.35.2	Gauge	4294967295
iblfQoSQueue- LengthInPkts.35.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.35.3	Gauge	4294967295
iblfQoSQueue- LengthInPkts.35.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.35.4	Gauge	4294967295
iblfQoSQueue- LengthInPkts.35.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.35.5	Gauge	4294967295
iblfQoSQueue- LengthInPkts.35.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.35.6	Gauge	4294967295
iblfQoSQueue- LengthInPkts.35.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.35.7	Gauge	4294967295
iblfQoSQueue- LengthInPkts.36.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.36.0	Gauge	4294967295
iblfQoSQueue- LengthInPkts.36.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.36.1	Gauge	4294967295
iblfQoSQueue- LengthInPkts.36.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.36.2	Gauge	4294967295
iblfQoSQueue- LengthInPkts.36.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.36.3	Gauge	4294967295
iblfQoSQueue- LengthInPkts.36.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.36.4	Gauge	4294967295
iblfQoSQueue- LengthInPkts.36.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.36.5	Gauge	4294967295
iblfQoSQueue- LengthInPkts.36.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.36.6	Gauge	4294967295
iblfQoSQueue- LengthInPkts.36.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.36.7	Gauge	4294967295
iblfQoSQueue- LengthInPkts.37.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.37.0	Gauge	4294967295
iblfQoSQueue- LengthInPkts.37.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.37.1	Gauge	4294967295
iblfQoSQueue- LengthInPkts.37.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.37.2	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueue-LengthInPkts.37.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.37.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.37.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.37.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.37.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.37.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.37.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.37.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.37.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.37.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.38.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.38.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.38.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.38.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.38.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.38.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.38.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.38.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.38.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.38.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.38.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.38.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.38.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.38.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.38.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.38.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.39.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.39.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.39.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.39.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.39.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.39.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.39.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.39.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.39.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.39.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.39.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.39.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.39.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.39.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.39.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.39.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.40.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.40.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.40.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.40.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.40.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.40.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.40.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.40.3	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueue-LengthInPkts.40.4	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.40.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.40.5	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.40.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.40.6	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.40.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.40.7	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.40.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.41.0	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.41.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.41.1	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.41.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.41.2	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.41.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.41.3	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.41.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.41.4	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.41.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.41.5	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.41.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.41.6	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.41.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.41.7	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.41.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.42.0	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.42.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.42.1	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.42.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.42.2	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.42.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.42.3	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.42.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.42.4	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.42.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.42.5	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.42.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.42.6	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.42.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.42.7	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.42.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.43.0	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.43.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.43.1	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.43.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.43.2	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.43.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.43.3	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.43.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.43.4	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.7.43.4	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueue-LengthInPkts.43.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.43.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.43.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.43.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.43.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.43.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.44.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.44.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.44.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.44.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.44.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.44.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.44.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.44.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.44.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.44.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.44.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.44.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.44.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.44.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.44.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.44.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.45.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.45.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.45.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.45.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.45.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.45.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.45.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.45.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.45.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.45.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.45.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.45.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.45.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.45.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.45.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.45.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.46.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.46.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.46.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.46.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.46.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.46.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.46.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.46.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.46.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.46.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.46.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.46.5	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSQueue-LengthInPkts.46.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.46.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.46.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.46.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.47.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.47.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.47.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.47.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.47.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.47.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.47.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.47.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.47.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.47.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.47.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.47.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.47.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.47.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.47.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.47.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.48.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.48.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.48.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.48.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.48.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.48.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.48.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.48.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.48.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.48.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.48.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.48.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.48.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.48.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.48.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.48.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.49.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.49.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.49.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.49.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.49.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.49.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.49.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.49.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.49.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.49.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.49.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.49.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.49.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.49.6	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueue-LengthInPkts.49.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.49.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.50.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.50.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.50.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.50.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.50.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.50.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.50.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.50.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.50.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.50.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.50.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.50.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.50.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.50.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.50.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.50.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.51.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.51.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.51.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.51.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.51.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.51.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.51.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.51.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.51.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.51.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.51.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.51.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.51.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.51.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.51.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.51.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.52.0	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.52.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.52.1	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.52.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.52.2	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.52.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.52.3	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.52.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.52.4	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.52.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.52.5	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.52.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.52.6	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.52.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.52.7	.13.6.1.4.1.26138.2.65.1.1.2.1.1.7.52.7	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueue-LengthInPkts.53.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.53.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.53.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.53.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.53.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.53.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.53.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.53.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.53.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.53.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.53.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.53.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.53.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.53.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.53.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.53.7	Gauge	4294967295
iblfQoSQueue-LengthInPkts.54.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.54.0	Gauge	4294967295
iblfQoSQueue-LengthInPkts.54.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.54.1	Gauge	4294967295
iblfQoSQueue-LengthInPkts.54.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.54.2	Gauge	4294967295
iblfQoSQueue-LengthInPkts.54.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.54.3	Gauge	4294967295
iblfQoSQueue-LengthInPkts.54.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.54.4	Gauge	4294967295
iblfQoSQueue-LengthInPkts.54.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.54.5	Gauge	4294967295
iblfQoSQueue-LengthInPkts.54.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.54.6	Gauge	4294967295
iblfQoSQueue-LengthInPkts.54.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.7.54.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.1.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.1.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.1.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.1.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.1.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.1.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.1.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.1.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.1.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.1.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.1.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.1.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.1.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.1.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.1.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.1.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.2.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.2.0	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueueLengthInBytes.2.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.2.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.2.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.2.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.2.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.2.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.2.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.2.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.2.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.2.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.2.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.2.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.2.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.2.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.3.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.3.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.3.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.3.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.3.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.3.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.3.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.3.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.3.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.3.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.3.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.3.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.3.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.3.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.3.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.3.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.4.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.4.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.4.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.4.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.4.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.4.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.4.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.4.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.4.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.4.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.4.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.4.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.4.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.4.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.4.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.4.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.5.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.5.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.5.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.5.1	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueueLengthInBytes.5.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.5.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.5.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.5.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.5.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.5.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.5.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.5.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.5.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.5.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.5.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.5.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.6.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.6.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.6.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.6.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.6.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.6.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.6.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.6.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.6.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.6.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.6.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.6.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.6.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.6.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.6.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.6.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.7.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.7.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.7.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.7.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.7.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.7.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.7.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.7.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.7.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.7.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.7.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.7.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.7.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.7.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.7.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.7.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.8.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.8.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.8.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.8.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.8.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.8.2	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueueLengthInBytes.8.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.8.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.8.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.8.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.8.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.8.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.8.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.8.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.8.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.8.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.9.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.9.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.9.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.9.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.9.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.9.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.9.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.9.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.9.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.9.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.9.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.9.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.9.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.9.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.9.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.9.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.10.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.10.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.10.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.10.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.10.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.10.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.10.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.10.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.10.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.10.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.10.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.10.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.10.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.10.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.10.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.10.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.11.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.11.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.11.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.11.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.11.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.11.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.11.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.11.3	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueueLengthInBytes.11.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.11.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.11.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.11.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.11.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.11.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.11.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.11.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.12.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.12.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.12.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.12.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.12.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.12.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.12.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.12.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.12.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.12.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.12.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.12.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.12.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.12.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.12.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.12.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.13.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.13.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.13.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.13.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.13.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.13.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.13.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.13.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.13.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.13.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.13.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.13.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.13.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.13.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.13.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.13.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.14.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.14.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.14.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.14.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.14.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.14.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.14.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.14.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.14.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.14.4	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueueLengthInBytes.14.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.14.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.14.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.14.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.14.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.14.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.15.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.15.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.15.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.15.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.15.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.15.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.15.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.15.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.15.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.15.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.15.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.15.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.15.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.15.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.15.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.15.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.16.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.16.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.16.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.16.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.16.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.16.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.16.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.16.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.16.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.16.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.16.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.16.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.16.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.16.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.16.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.16.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.17.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.17.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.17.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.17.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.17.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.17.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.17.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.17.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.17.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.17.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.17.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.17.5	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSQueueLengthInBytes.17.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.17.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.17.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.17.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.18.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.18.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.18.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.18.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.18.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.18.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.18.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.18.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.18.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.18.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.18.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.18.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.18.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.18.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.18.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.18.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.19.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.19.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.19.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.19.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.19.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.19.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.19.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.19.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.19.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.19.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.19.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.19.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.19.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.19.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.19.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.19.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.20.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.20.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.20.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.20.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.20.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.20.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.20.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.20.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.20.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.20.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.20.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.20.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.20.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.20.6	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueueLengthInBytes.20.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.20.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.21.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.21.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.21.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.21.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.21.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.21.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.21.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.21.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.21.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.21.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.21.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.21.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.21.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.21.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.21.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.21.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.22.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.22.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.22.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.22.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.22.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.22.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.22.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.22.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.22.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.22.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.22.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.22.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.22.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.22.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.22.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.22.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.23.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.23.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.23.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.23.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.23.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.23.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.23.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.23.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.23.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.23.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.23.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.23.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.23.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.23.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.23.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.23.7	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueueLengthInBytes.24.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.24.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.24.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.24.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.24.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.24.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.24.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.24.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.24.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.24.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.24.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.24.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.24.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.24.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.24.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.24.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.25.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.25.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.25.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.25.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.25.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.25.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.25.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.25.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.25.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.25.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.25.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.25.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.25.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.25.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.25.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.25.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.26.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.26.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.26.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.26.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.26.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.26.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.26.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.26.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.26.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.26.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.26.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.26.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.26.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.26.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.26.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.26.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.27.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.27.0	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueueLengthInBytes.27.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.27.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.27.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.27.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.27.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.27.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.27.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.27.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.27.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.27.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.27.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.27.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.27.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.27.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.28.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.28.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.28.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.28.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.28.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.28.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.28.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.28.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.28.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.28.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.28.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.28.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.28.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.28.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.28.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.28.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.29.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.29.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.29.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.29.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.29.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.29.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.29.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.29.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.29.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.29.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.29.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.29.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.29.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.29.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.29.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.29.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.30.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.30.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.30.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.30.1	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueueLengthInBytes.30.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.30.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.30.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.30.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.30.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.30.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.30.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.30.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.30.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.30.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.30.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.30.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.31.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.31.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.31.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.31.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.31.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.31.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.31.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.31.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.31.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.31.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.31.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.31.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.31.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.31.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.31.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.31.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.32.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.32.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.32.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.32.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.32.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.32.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.32.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.32.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.32.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.32.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.32.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.32.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.32.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.32.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.32.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.32.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.33.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.33.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.33.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.33.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.33.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.33.2	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueueLengthInBytes.33.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.33.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.33.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.33.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.33.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.33.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.33.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.33.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.33.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.33.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.34.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.34.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.34.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.34.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.34.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.34.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.34.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.34.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.34.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.34.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.34.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.34.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.34.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.34.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.34.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.34.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.35.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.35.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.35.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.35.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.35.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.35.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.35.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.35.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.35.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.35.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.35.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.35.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.35.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.35.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.35.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.35.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.36.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.36.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.36.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.36.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.36.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.36.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.36.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.36.3	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueueLengthInBytes.36.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.36.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.36.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.36.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.36.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.36.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.36.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.36.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.37.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.37.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.37.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.37.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.37.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.37.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.37.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.37.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.37.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.37.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.37.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.37.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.37.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.37.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.37.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.37.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.38.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.38.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.38.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.38.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.38.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.38.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.38.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.38.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.38.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.38.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.38.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.38.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.38.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.38.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.38.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.38.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.39.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.39.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.39.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.39.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.39.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.39.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.39.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.39.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.39.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.39.4	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueueLengthInBytes.39.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.39.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.39.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.39.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.39.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.39.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.40.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.40.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.40.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.40.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.40.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.40.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.40.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.40.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.40.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.40.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.40.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.40.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.40.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.40.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.40.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.40.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.41.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.41.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.41.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.41.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.41.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.41.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.41.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.41.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.41.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.41.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.41.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.41.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.41.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.41.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.41.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.41.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.42.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.42.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.42.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.42.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.42.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.42.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.42.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.42.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.42.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.42.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.42.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.42.5	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSQueueLengthInBytes.42.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.42.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.42.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.42.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.43.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.43.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.43.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.43.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.43.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.43.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.43.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.43.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.43.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.43.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.43.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.43.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.43.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.43.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.43.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.43.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.44.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.44.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.44.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.44.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.44.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.44.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.44.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.44.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.44.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.44.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.44.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.44.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.44.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.44.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.44.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.44.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.45.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.45.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.45.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.45.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.45.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.45.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.45.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.45.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.45.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.45.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.45.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.45.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.45.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.45.6	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueueLengthInBytes.45.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.45.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.46.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.46.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.46.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.46.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.46.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.46.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.46.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.46.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.46.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.46.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.46.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.46.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.46.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.46.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.46.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.46.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.47.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.47.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.47.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.47.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.47.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.47.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.47.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.47.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.47.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.47.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.47.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.47.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.47.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.47.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.47.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.47.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.48.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.48.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.48.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.48.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.48.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.48.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.48.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.48.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.48.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.48.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.48.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.48.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.48.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.48.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.48.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.48.7	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueueLengthInBytes.49.0	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.49.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.49.1	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.49.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.49.2	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.49.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.49.3	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.49.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.49.4	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.49.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.49.5	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.49.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.49.6	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.49.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.49.7	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.49.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.50.0	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.50.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.50.1	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.50.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.50.2	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.50.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.50.3	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.50.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.50.4	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.50.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.50.5	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.50.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.50.6	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.50.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.50.7	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.50.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.51.0	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.51.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.51.1	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.51.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.51.2	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.51.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.51.3	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.51.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.51.4	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.51.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.51.5	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.51.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.51.6	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.51.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.51.7	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.51.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.52.0	.1 3.6.1.4.1.26138.2.65.1.1.2.1.1.8.52.0	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSQueueLengthInBytes.52.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.52.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.52.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.52.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.52.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.52.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.52.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.52.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.52.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.52.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.52.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.52.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.52.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.52.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.53.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.53.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.53.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.53.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.53.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.53.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.53.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.53.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.53.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.53.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.53.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.53.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.53.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.53.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.53.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.53.7	Gauge	4294967295
iblfQoSQueueLengthInBytes.54.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.54.0	Gauge	4294967295
iblfQoSQueueLengthInBytes.54.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.54.1	Gauge	4294967295
iblfQoSQueueLengthInBytes.54.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.54.2	Gauge	4294967295
iblfQoSQueueLengthInBytes.54.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.54.3	Gauge	4294967295
iblfQoSQueueLengthInBytes.54.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.54.4	Gauge	4294967295
iblfQoSQueueLengthInBytes.54.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.54.5	Gauge	4294967295
iblfQoSQueueLengthInBytes.54.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.54.6	Gauge	4294967295
iblfQoSQueueLengthInBytes.54.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.8.54.7	Gauge	4294967295
iblfQoSCurQueuePkts.1.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.9.1.0	Gauge	4294967295
iblfQoSCurQueuePkts.1.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.9.1.1	Gauge	4294967295
iblfQoSCurQueuePkts.1.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.9.1.2	Gauge	4294967295
iblfQoSCurQueuePkts.1.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.9.1.3	Gauge	4294967295























































Name	OID	Value Type	Value Example
iblfQoSQueuePPS.6.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.6.3	Gauge	4294967295
iblfQoSQueuePPS.6.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.6.4	Gauge	4294967295
iblfQoSQueuePPS.6.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.6.5	Gauge	4294967295
iblfQoSQueuePPS.6.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.6.6	Gauge	4294967295
iblfQoSQueuePPS.6.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.6.7	Gauge	4294967295
iblfQoSQueuePPS.7.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.7.0	Gauge	4294967295
iblfQoSQueuePPS.7.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.7.1	Gauge	4294967295
iblfQoSQueuePPS.7.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.7.2	Gauge	4294967295
iblfQoSQueuePPS.7.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.7.3	Gauge	4294967295
iblfQoSQueuePPS.7.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.7.4	Gauge	4294967295
iblfQoSQueuePPS.7.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.7.5	Gauge	4294967295
iblfQoSQueuePPS.7.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.7.6	Gauge	4294967295
iblfQoSQueuePPS.7.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.7.7	Gauge	4294967295
iblfQoSQueuePPS.8.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.8.0	Gauge	4294967295
iblfQoSQueuePPS.8.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.8.1	Gauge	4294967295
iblfQoSQueuePPS.8.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.8.2	Gauge	4294967295
iblfQoSQueuePPS.8.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.8.3	Gauge	4294967295
iblfQoSQueuePPS.8.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.8.4	Gauge	4294967295
iblfQoSQueuePPS.8.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.8.5	Gauge	4294967295
iblfQoSQueuePPS.8.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.8.6	Gauge	4294967295
iblfQoSQueuePPS.8.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.8.7	Gauge	4294967295
iblfQoSQueuePPS.9.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.9.0	Gauge	4294967295
iblfQoSQueuePPS.9.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.9.1	Gauge	4294967295
iblfQoSQueuePPS.9.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.9.2	Gauge	4294967295
iblfQoSQueuePPS.9.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.9.3	Gauge	4294967295
iblfQoSQueuePPS.9.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.9.4	Gauge	4294967295
iblfQoSQueuePPS.9.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.9.5	Gauge	4294967295
iblfQoSQueuePPS.9.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.9.6	Gauge	4294967295
iblfQoSQueuePPS.9.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.9.7	Gauge	4294967295
iblfQoSQueuePPS.10.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.10.0	Gauge	4294967295
iblfQoSQueuePPS.10.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.10.1	Gauge	4294967295
iblfQoSQueuePPS.10.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.10.2	Gauge	4294967295
iblfQoSQueuePPS.10.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.10.3	Gauge	4294967295
iblfQoSQueuePPS.10.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.10.4	Gauge	4294967295
iblfQoSQueuePPS.10.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.10.5	Gauge	4294967295
iblfQoSQueuePPS.10.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.10.6	Gauge	4294967295
iblfQoSQueuePPS.10.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.10.7	Gauge	4294967295
iblfQoSQueuePPS.11.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.11.0	Gauge	4294967295
iblfQoSQueuePPS.11.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.11.1	Gauge	4294967295
iblfQoSQueuePPS.11.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.11.2	Gauge	4294967295
iblfQoSQueuePPS.11.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.11.3	Gauge	4294967295
iblfQoSQueuePPS.11.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.11.4	Gauge	4294967295
iblfQoSQueuePPS.11.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.11.11.5	Gauge	4294967295









































































































































































































Name	OID	Value Type	Value Example
iblfQoSPeakPassBPS.53.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.25.53	Gauge	4294967295
iblfQoSPeakPassBPS.53.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.25.53	Gauge	4294967295
iblfQoSPeakPassBPS.53.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.25.53	Gauge	4294967295
iblfQoSPeakPassBPS.53.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.25.53	Gauge	4294967295
iblfQoSPeakPassBPS.53.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.25.53	Gauge	4294967295
iblfQoSPeakPassBPS.53.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.25.53	Gauge	4294967295
iblfQoSPeakPassBPS.53.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.25.53	Gauge	4294967295
iblfQoSPeakPassBPS.53.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.25.53	Gauge	4294967295
iblfQoSPeakPassBPS.54.0	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.25.54	Gauge	4294967295
iblfQoSPeakPassBPS.54.1	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.25.54	Gauge	4294967295
iblfQoSPeakPassBPS.54.2	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.25.54	Gauge	4294967295
iblfQoSPeakPassBPS.54.3	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.25.54	Gauge	4294967295
iblfQoSPeakPassBPS.54.4	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.25.54	Gauge	4294967295
iblfQoSPeakPassBPS.54.5	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.25.54	Gauge	4294967295
iblfQoSPeakPassBPS.54.6	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.25.54	Gauge	4294967295
iblfQoSPeakPassBPS.54.7	.1.3.6.1.4.1.26138.2.65.1.1.2.1.1.25.54	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.1.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.1.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.1.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.1.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.1.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.1.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.1.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.1.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.1.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.1.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.1.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.1.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.1.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.1.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.1.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.1.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.2.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.2.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.2.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.2.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.2.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.2.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.2.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.2.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.2.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.2.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.2.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.2.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.2.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.2.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.2.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.2.7	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpPPS.3.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.3.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.3.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.3.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.3.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.3.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.3.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.3.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.3.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.3.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.3.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.3.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.3.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.3.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.3.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.3.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.4.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.4.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.4.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.4.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.4.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.4.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.4.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.4.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.4.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.4.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.4.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.4.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.4.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.4.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.4.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.4.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.5.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.5.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.5.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.5.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.5.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.5.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.5.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.5.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.5.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.5.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.5.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.5.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.5.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.5.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.5.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.5.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.6.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.6.0	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpPPS.6.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.6.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.6.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.6.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.6.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.6.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.6.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.6.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.6.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.6.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.6.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.6.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.6.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.6.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.7.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.7.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.7.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.7.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.7.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.7.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.7.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.7.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.7.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.7.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.7.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.7.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.7.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.7.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.7.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.7.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.8.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.8.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.8.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.8.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.8.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.8.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.8.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.8.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.8.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.8.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.8.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.8.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.8.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.8.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.8.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.8.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.9.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.9.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.9.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.9.1	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpPPS.9.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.9.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.9.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.9.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.9.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.9.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.9.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.9.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.9.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.9.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.9.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.9.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.10.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.10.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.10.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.10.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.10.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.10.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.10.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.10.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.10.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.10.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.10.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.10.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.10.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.10.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.10.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.10.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.11.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.11.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.11.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.11.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.11.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.11.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.11.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.11.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.11.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.11.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.11.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.11.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.11.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.11.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.11.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.11.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.12.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.12.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.12.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.12.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.12.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.12.2	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpPPS.12.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.12.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.12.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.12.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.12.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.12.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.12.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.12.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.12.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.12.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.13.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.13.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.13.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.13.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.13.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.13.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.13.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.13.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.13.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.13.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.13.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.13.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.13.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.13.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.13.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.13.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.14.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.14.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.14.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.14.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.14.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.14.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.14.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.14.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.14.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.14.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.14.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.14.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.14.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.14.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.14.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.14.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.15.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.15.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.15.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.15.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.15.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.15.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.15.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.15.3	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpPPS.15.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.15.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.15.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.15.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.15.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.15.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.15.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.15.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.16.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.16.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.16.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.16.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.16.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.16.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.16.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.16.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.16.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.16.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.16.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.16.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.16.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.16.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.16.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.16.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.17.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.17.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.17.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.17.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.17.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.17.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.17.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.17.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.17.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.17.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.17.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.17.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.17.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.17.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.17.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.17.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.18.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.18.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.18.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.18.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.18.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.18.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.18.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.18.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.18.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.18.4	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpPPS.18.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.18.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.18.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.18.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.18.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.18.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.19.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.19.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.19.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.19.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.19.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.19.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.19.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.19.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.19.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.19.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.19.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.19.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.19.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.19.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.19.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.19.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.20.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.20.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.20.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.20.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.20.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.20.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.20.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.20.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.20.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.20.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.20.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.20.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.20.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.20.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.20.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.20.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.21.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.21.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.21.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.21.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.21.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.21.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.21.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.21.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.21.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.21.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.21.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.21.5	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpPPS.21.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.21.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.21.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.21.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.22.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.22.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.22.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.22.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.22.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.22.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.22.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.22.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.22.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.22.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.22.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.22.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.22.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.22.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.22.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.22.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.23.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.23.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.23.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.23.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.23.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.23.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.23.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.23.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.23.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.23.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.23.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.23.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.23.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.23.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.23.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.23.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.24.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.24.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.24.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.24.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.24.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.24.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.24.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.24.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.24.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.24.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.24.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.24.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.24.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.24.6	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpPPS.24.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.24.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.25.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.25.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.25.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.25.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.25.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.25.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.25.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.25.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.25.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.25.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.25.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.25.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.25.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.25.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.25.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.25.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.26.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.26.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.26.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.26.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.26.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.26.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.26.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.26.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.26.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.26.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.26.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.26.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.26.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.26.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.26.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.26.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.27.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.27.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.27.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.27.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.27.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.27.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.27.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.27.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.27.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.27.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.27.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.27.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.27.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.27.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.27.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.27.7	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpPPS.28.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.28.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.28.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.28.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.28.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.28.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.28.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.28.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.28.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.28.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.28.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.28.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.28.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.28.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.28.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.28.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.29.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.29.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.29.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.29.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.29.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.29.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.29.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.29.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.29.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.29.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.29.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.29.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.29.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.29.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.29.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.29.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.30.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.30.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.30.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.30.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.30.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.30.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.30.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.30.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.30.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.30.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.30.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.30.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.30.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.30.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.30.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.30.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.31.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.31.0	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpPPS.31.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.31.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.31.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.31.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.31.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.31.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.31.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.31.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.31.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.31.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.31.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.31.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.31.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.31.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.32.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.32.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.32.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.32.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.32.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.32.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.32.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.32.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.32.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.32.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.32.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.32.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.32.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.32.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.32.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.32.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.33.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.33.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.33.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.33.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.33.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.33.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.33.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.33.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.33.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.33.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.33.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.33.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.33.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.33.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.33.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.33.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.34.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.34.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.34.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.34.1	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpPPS.34.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.34.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.34.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.34.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.34.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.34.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.34.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.34.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.34.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.34.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.34.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.34.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.35.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.35.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.35.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.35.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.35.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.35.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.35.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.35.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.35.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.35.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.35.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.35.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.35.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.35.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.35.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.35.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.36.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.36.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.36.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.36.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.36.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.36.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.36.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.36.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.36.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.36.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.36.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.36.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.36.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.36.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.36.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.36.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.37.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.37.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.37.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.37.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.37.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.37.2	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpPPS.37.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.37.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.37.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.37.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.37.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.37.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.37.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.37.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.37.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.37.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.38.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.38.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.38.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.38.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.38.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.38.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.38.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.38.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.38.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.38.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.38.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.38.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.38.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.38.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.38.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.38.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.39.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.39.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.39.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.39.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.39.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.39.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.39.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.39.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.39.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.39.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.39.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.39.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.39.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.39.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.39.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.39.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.40.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.40.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.40.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.40.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.40.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.40.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.40.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.40.3	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpPPS.40.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.40.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.40.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.40.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.40.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.40.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.40.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.40.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.41.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.41.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.41.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.41.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.41.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.41.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.41.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.41.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.41.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.41.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.41.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.41.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.41.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.41.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.41.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.41.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.42.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.42.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.42.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.42.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.42.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.42.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.42.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.42.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.42.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.42.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.42.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.42.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.42.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.42.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.42.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.42.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.43.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.43.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.43.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.43.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.43.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.43.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.43.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.43.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.43.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.43.4	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpPPS.43.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.43.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.43.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.43.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.43.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.43.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.44.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.44.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.44.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.44.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.44.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.44.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.44.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.44.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.44.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.44.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.44.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.44.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.44.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.44.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.44.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.44.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.45.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.45.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.45.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.45.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.45.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.45.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.45.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.45.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.45.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.45.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.45.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.45.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.45.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.45.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.45.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.45.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.46.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.46.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.46.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.46.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.46.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.46.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.46.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.46.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.46.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.46.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.46.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.46.5	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpPPS.46.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.46.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.46.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.46.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.47.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.47.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.47.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.47.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.47.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.47.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.47.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.47.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.47.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.47.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.47.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.47.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.47.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.47.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.47.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.47.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.48.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.48.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.48.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.48.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.48.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.48.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.48.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.48.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.48.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.48.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.48.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.48.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.48.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.48.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.48.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.48.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.49.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.49.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.49.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.49.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.49.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.49.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.49.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.49.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.49.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.49.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.49.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.49.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.49.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.49.6	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpPPS.49.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.49.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.50.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.50.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.50.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.50.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.50.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.50.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.50.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.50.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.50.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.50.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.50.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.50.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.50.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.50.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.50.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.50.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.51.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.51.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.51.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.51.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.51.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.51.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.51.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.51.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.51.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.51.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.51.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.51.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.51.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.51.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.51.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.51.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.52.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.52.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.52.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.52.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.52.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.52.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.52.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.52.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.52.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.52.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.52.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.52.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.52.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.52.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.52.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.52.7	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpPPS.53.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.53.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.53.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.53.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.53.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.53.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.53.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.53.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.53.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.53.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.53.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.53.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.53.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.53.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.53.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.53.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.54.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.54.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.54.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.54.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.54.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.54.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.54.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.54.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.54.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.54.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.54.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.54.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.54.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.54.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpPPS.54.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.3.54.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.1.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.1.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.1.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.1.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.1.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.1.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.1.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.1.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.1.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.1.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.1.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.1.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.1.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.1.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.1.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.1.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.2.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.2.0	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpBPS.2.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.2.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.2.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.2.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.2.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.2.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.2.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.2.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.2.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.2.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.2.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.2.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.2.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.2.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.3.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.3.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.3.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.3.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.3.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.3.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.3.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.3.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.3.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.3.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.3.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.3.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.3.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.3.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.3.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.3.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.4.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.4.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.4.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.4.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.4.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.4.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.4.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.4.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.4.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.4.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.4.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.4.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.4.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.4.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.4.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.4.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.5.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.5.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.5.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.5.1	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpBPS.5.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.5.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.5.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.5.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.5.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.5.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.5.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.5.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.5.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.5.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.5.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.5.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.6.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.6.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.6.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.6.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.6.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.6.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.6.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.6.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.6.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.6.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.6.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.6.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.6.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.6.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.6.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.6.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.7.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.7.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.7.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.7.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.7.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.7.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.7.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.7.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.7.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.7.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.7.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.7.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.7.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.7.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.7.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.7.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.8.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.8.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.8.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.8.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.8.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.8.2	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpBPS.8.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.8.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.8.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.8.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.8.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.8.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.8.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.8.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.8.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.8.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.9.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.9.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.9.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.9.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.9.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.9.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.9.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.9.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.9.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.9.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.9.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.9.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.9.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.9.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.9.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.9.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.10.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.10.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.10.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.10.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.10.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.10.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.10.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.10.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.10.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.10.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.10.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.10.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.10.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.10.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.10.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.10.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.11.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.11.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.11.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.11.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.11.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.11.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.11.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.11.3	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpBPS.11.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.11.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.11.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.11.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.11.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.11.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.11.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.11.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.12.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.12.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.12.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.12.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.12.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.12.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.12.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.12.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.12.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.12.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.12.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.12.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.12.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.12.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.12.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.12.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.13.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.13.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.13.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.13.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.13.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.13.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.13.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.13.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.13.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.13.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.13.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.13.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.13.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.13.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.13.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.13.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.14.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.14.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.14.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.14.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.14.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.14.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.14.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.14.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.14.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.14.4	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpBPS.14.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.14.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.14.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.14.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.14.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.14.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.15.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.15.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.15.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.15.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.15.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.15.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.15.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.15.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.15.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.15.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.15.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.15.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.15.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.15.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.15.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.15.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.16.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.16.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.16.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.16.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.16.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.16.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.16.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.16.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.16.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.16.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.16.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.16.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.16.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.16.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.16.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.16.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.17.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.17.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.17.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.17.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.17.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.17.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.17.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.17.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.17.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.17.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.17.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.17.5	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpBPS.17.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.17.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.17.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.17.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.18.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.18.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.18.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.18.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.18.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.18.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.18.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.18.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.18.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.18.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.18.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.18.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.18.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.18.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.18.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.18.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.19.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.19.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.19.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.19.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.19.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.19.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.19.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.19.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.19.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.19.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.19.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.19.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.19.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.19.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.19.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.19.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.20.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.20.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.20.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.20.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.20.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.20.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.20.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.20.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.20.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.20.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.20.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.20.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.20.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.20.6	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpBPS.20.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.20.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.21.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.21.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.21.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.21.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.21.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.21.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.21.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.21.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.21.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.21.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.21.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.21.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.21.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.21.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.21.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.21.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.22.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.22.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.22.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.22.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.22.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.22.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.22.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.22.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.22.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.22.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.22.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.22.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.22.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.22.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.22.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.22.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.23.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.23.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.23.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.23.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.23.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.23.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.23.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.23.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.23.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.23.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.23.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.23.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.23.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.23.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.23.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.23.7	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpBPS.24.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.24.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.24.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.24.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.24.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.24.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.24.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.24.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.24.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.24.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.24.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.24.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.24.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.24.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.24.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.24.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.25.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.25.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.25.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.25.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.25.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.25.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.25.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.25.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.25.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.25.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.25.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.25.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.25.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.25.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.25.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.25.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.26.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.26.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.26.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.26.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.26.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.26.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.26.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.26.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.26.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.26.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.26.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.26.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.26.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.26.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.26.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.26.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.27.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.27.0	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpBPS.27.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.27.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.27.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.27.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.27.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.27.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.27.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.27.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.27.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.27.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.27.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.27.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.27.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.27.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.28.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.28.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.28.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.28.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.28.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.28.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.28.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.28.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.28.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.28.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.28.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.28.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.28.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.28.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.28.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.28.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.29.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.29.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.29.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.29.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.29.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.29.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.29.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.29.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.29.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.29.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.29.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.29.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.29.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.29.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.29.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.29.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.30.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.30.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.30.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.30.1	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpBPS.30.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.30.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.30.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.30.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.30.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.30.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.30.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.30.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.30.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.30.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.30.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.30.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.31.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.31.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.31.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.31.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.31.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.31.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.31.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.31.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.31.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.31.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.31.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.31.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.31.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.31.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.31.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.31.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.32.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.32.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.32.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.32.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.32.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.32.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.32.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.32.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.32.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.32.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.32.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.32.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.32.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.32.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.32.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.32.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.33.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.33.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.33.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.33.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.33.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.33.2	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpBPS.33.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.33.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.33.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.33.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.33.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.33.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.33.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.33.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.33.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.33.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.34.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.34.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.34.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.34.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.34.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.34.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.34.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.34.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.34.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.34.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.34.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.34.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.34.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.34.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.34.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.34.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.35.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.35.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.35.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.35.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.35.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.35.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.35.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.35.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.35.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.35.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.35.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.35.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.35.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.35.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.35.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.35.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.36.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.36.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.36.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.36.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.36.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.36.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.36.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.36.3	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpBPS.36.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.36.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.36.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.36.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.36.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.36.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.36.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.36.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.37.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.37.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.37.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.37.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.37.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.37.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.37.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.37.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.37.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.37.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.37.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.37.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.37.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.37.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.37.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.37.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.38.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.38.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.38.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.38.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.38.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.38.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.38.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.38.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.38.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.38.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.38.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.38.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.38.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.38.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.38.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.38.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.39.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.39.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.39.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.39.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.39.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.39.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.39.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.39.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.39.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.39.4	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpBPS.39.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.39.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.39.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.39.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.39.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.39.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.40.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.40.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.40.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.40.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.40.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.40.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.40.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.40.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.40.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.40.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.40.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.40.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.40.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.40.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.40.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.40.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.41.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.41.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.41.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.41.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.41.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.41.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.41.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.41.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.41.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.41.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.41.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.41.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.41.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.41.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.41.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.41.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.42.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.42.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.42.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.42.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.42.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.42.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.42.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.42.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.42.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.42.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.42.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.42.5	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpBPS.42.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.42.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.42.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.42.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.43.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.43.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.43.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.43.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.43.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.43.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.43.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.43.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.43.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.43.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.43.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.43.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.43.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.43.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.43.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.43.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.44.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.44.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.44.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.44.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.44.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.44.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.44.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.44.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.44.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.44.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.44.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.44.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.44.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.44.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.44.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.44.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.45.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.45.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.45.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.45.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.45.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.45.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.45.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.45.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.45.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.45.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.45.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.45.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.45.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.45.6	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpBPS.45.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.45.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.46.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.46.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.46.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.46.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.46.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.46.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.46.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.46.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.46.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.46.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.46.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.46.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.46.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.46.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.46.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.46.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.47.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.47.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.47.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.47.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.47.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.47.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.47.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.47.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.47.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.47.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.47.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.47.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.47.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.47.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.47.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.47.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.48.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.48.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.48.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.48.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.48.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.48.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.48.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.48.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.48.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.48.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.48.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.48.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.48.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.48.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.48.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.48.7	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpBPS.49.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.49.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.49.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.49.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.49.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.49.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.49.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.49.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.49.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.49.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.49.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.49.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.49.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.49.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.49.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.49.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.50.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.50.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.50.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.50.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.50.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.50.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.50.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.50.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.50.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.50.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.50.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.50.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.50.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.50.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.50.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.50.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.51.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.51.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.51.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.51.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.51.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.51.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.51.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.51.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.51.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.51.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.51.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.51.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.51.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.51.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.51.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.51.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.52.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.52.0	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreNTcpBPS.52.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.52.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.52.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.52.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.52.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.52.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.52.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.52.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.52.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.52.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.52.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.52.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.52.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.52.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.53.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.53.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.53.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.53.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.53.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.53.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.53.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.53.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.53.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.53.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.53.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.53.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.53.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.53.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.53.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.53.7	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.54.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.54.0	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.54.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.54.1	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.54.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.54.2	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.54.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.54.3	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.54.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.54.4	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.54.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.54.5	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.54.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.54.6	Gauge	4294967295
iblfQoSWredDropL-PreNTcpBPS.54.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.4.54.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpsPPS.1.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.1.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpsPPS.1.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.1.1	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpPPS.1.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.1.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.1.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.1.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.1.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.1.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.1.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.1.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.1.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.1.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.1.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.1.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.2.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.2.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.2.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.2.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.2.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.2.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.2.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.2.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.2.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.2.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.2.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.2.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.2.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.2.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.2.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.2.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.3.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.3.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.3.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.3.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.3.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.3.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.3.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.3.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.3.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.3.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.3.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.3.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.3.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.3.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.3.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.3.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.4.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.4.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.4.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.4.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.4.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.4.2	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpPPS.4.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.4.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.4.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.4.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.4.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.4.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.4.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.4.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.4.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.4.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.5.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.5.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.5.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.5.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.5.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.5.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.5.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.5.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.5.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.5.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.5.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.5.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.5.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.5.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.5.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.5.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.6.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.6.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.6.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.6.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.6.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.6.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.6.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.6.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.6.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.6.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.6.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.6.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.6.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.6.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.6.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.6.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.7.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.7.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.7.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.7.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.7.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.7.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.7.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.7.3	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpPPS.7.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.7.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.7.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.7.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.7.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.7.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.7.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.7.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.8.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.8.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.8.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.8.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.8.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.8.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.8.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.8.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.8.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.8.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.8.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.8.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.8.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.8.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.8.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.8.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.9.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.9.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.9.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.9.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.9.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.9.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.9.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.9.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.9.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.9.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.9.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.9.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.9.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.9.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.9.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.9.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.10.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.10.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.10.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.10.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.10.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.10.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.10.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.10.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.10.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.10.4	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpPPS.10.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.10.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.10.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.10.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.10.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.10.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.11.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.11.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.11.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.11.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.11.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.11.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.11.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.11.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.11.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.11.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.11.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.11.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.11.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.11.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.11.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.11.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.12.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.12.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.12.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.12.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.12.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.12.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.12.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.12.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.12.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.12.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.12.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.12.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.12.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.12.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.12.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.12.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.13.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.13.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.13.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.13.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.13.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.13.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.13.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.13.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.13.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.13.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.13.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.13.5	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpPPS.13.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.13.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.13.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.13.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.14.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.14.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.14.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.14.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.14.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.14.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.14.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.14.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.14.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.14.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.14.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.14.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.14.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.14.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.14.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.14.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.15.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.15.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.15.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.15.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.15.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.15.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.15.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.15.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.15.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.15.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.15.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.15.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.15.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.15.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.15.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.15.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.16.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.16.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.16.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.16.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.16.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.16.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.16.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.16.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.16.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.16.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.16.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.16.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.16.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.16.6	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpPPS.16.7	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.16.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.17.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.17.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.17.1	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.17.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.17.2	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.17.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.17.3	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.17.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.17.4	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.17.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.17.5	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.17.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.17.6	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.17.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.17.7	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.17.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.18.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.18.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.18.1	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.18.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.18.2	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.18.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.18.3	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.18.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.18.4	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.18.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.18.5	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.18.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.18.6	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.18.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.18.7	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.18.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.19.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.19.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.19.1	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.19.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.19.2	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.19.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.19.3	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.19.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.19.4	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.19.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.19.5	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.19.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.19.6	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.19.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.19.7	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.19.7	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpPPS.20.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.20.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.20.1	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.20.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.20.2	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.20.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.20.3	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.20.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.20.4	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.20.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.20.5	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.20.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.20.6	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.20.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.20.7	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.20.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.21.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.21.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.21.1	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.21.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.21.2	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.21.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.21.3	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.21.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.21.4	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.21.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.21.5	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.21.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.21.6	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.21.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.21.7	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.21.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.22.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.22.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.22.1	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.22.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.22.2	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.22.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.22.3	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.22.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.22.4	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.22.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.22.5	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.22.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.22.6	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.22.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.22.7	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.22.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.23.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.23.0	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpPPS.23.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.23.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.23.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.23.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.23.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.23.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.23.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.23.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.23.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.23.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.23.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.23.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.23.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.23.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.24.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.24.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.24.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.24.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.24.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.24.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.24.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.24.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.24.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.24.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.24.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.24.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.24.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.24.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.24.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.24.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.25.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.25.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.25.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.25.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.25.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.25.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.25.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.25.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.25.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.25.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.25.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.25.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.25.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.25.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.25.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.25.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.26.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.26.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.26.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.26.1	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpPPS.26.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.26.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.26.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.26.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.26.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.26.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.26.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.26.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.26.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.26.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.26.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.26.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.27.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.27.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.27.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.27.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.27.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.27.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.27.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.27.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.27.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.27.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.27.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.27.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.27.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.27.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.27.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.27.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.28.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.28.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.28.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.28.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.28.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.28.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.28.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.28.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.28.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.28.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.28.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.28.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.28.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.28.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.28.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.28.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.29.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.29.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.29.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.29.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.29.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.29.2	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpPPS.29.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.29.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.29.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.29.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.29.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.29.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.29.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.29.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.29.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.29.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.30.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.30.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.30.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.30.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.30.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.30.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.30.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.30.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.30.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.30.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.30.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.30.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.30.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.30.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.30.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.30.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.31.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.31.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.31.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.31.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.31.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.31.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.31.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.31.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.31.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.31.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.31.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.31.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.31.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.31.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.31.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.31.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.32.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.32.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.32.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.32.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.32.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.32.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.32.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.32.3	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpPPS.32.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.32.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.32.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.32.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.32.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.32.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.32.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.32.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.33.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.33.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.33.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.33.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.33.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.33.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.33.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.33.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.33.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.33.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.33.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.33.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.33.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.33.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.33.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.33.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.34.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.34.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.34.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.34.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.34.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.34.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.34.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.34.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.34.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.34.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.34.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.34.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.34.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.34.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.34.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.34.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.35.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.35.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.35.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.35.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.35.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.35.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.35.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.35.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.35.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.35.4	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpPPS.35.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.35.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.35.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.35.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.35.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.35.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.36.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.36.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.36.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.36.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.36.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.36.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.36.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.36.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.36.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.36.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.36.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.36.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.36.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.36.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.36.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.36.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.37.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.37.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.37.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.37.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.37.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.37.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.37.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.37.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.37.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.37.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.37.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.37.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.37.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.37.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.37.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.37.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.38.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.38.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.38.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.38.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.38.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.38.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.38.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.38.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.38.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.38.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.38.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.38.5	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpPPS.38.6	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.38.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.38.7	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.38.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.39.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.39.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.39.1	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.39.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.39.2	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.39.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.39.3	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.39.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.39.4	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.39.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.39.5	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.39.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.39.6	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.39.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.39.7	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.39.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.40.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.40.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.40.1	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.40.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.40.2	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.40.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.40.3	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.40.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.40.4	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.40.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.40.5	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.40.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.40.6	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.40.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.40.7	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.40.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.41.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.41.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.41.1	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.41.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.41.2	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.41.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.41.3	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.41.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.41.4	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.41.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.41.5	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.41.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.41.6	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.41.6	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpPPS.41.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.41.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.42.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.42.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.42.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.42.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.42.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.42.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.42.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.42.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.42.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.42.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.42.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.42.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.42.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.42.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.42.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.42.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.43.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.43.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.43.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.43.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.43.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.43.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.43.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.43.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.43.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.43.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.43.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.43.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.43.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.43.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.43.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.43.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.44.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.44.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.44.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.44.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.44.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.44.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.44.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.44.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.44.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.44.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.44.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.44.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.44.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.44.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.44.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.44.7	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpPPS.45.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.45.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.45.1	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.45.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.45.2	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.45.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.45.3	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.45.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.45.4	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.45.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.45.5	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.45.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.45.6	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.45.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.45.7	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.45.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.46.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.46.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.46.1	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.46.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.46.2	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.46.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.46.3	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.46.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.46.4	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.46.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.46.5	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.46.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.46.6	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.46.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.46.7	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.46.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.47.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.47.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.47.1	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.47.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.47.2	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.47.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.47.3	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.47.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.47.4	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.47.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.47.5	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.47.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.47.6	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.47.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.47.7	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.47.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.48.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.7.48.0	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpPPS.48.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.48.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.48.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.48.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.48.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.48.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.48.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.48.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.48.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.48.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.48.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.48.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.48.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.48.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.49.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.49.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.49.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.49.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.49.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.49.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.49.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.49.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.49.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.49.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.49.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.49.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.49.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.49.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.49.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.49.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.50.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.50.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.50.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.50.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.50.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.50.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.50.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.50.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.50.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.50.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.50.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.50.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.50.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.50.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.50.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.50.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.51.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.51.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.51.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.51.1	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpPPS.51.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.51.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.51.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.51.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.51.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.51.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.51.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.51.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.51.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.51.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.51.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.51.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.52.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.52.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.52.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.52.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.52.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.52.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.52.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.52.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.52.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.52.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.52.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.52.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.52.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.52.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.52.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.52.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.53.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.53.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.53.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.53.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.53.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.53.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.53.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.53.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.53.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.53.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.53.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.53.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.53.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.53.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.53.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.53.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.54.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.54.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.54.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.54.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.54.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.54.2	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpPPS.54.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.54.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.54.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.54.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.54.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.54.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.54.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.54.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpPPS.54.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.7.54.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.1.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.1.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.1.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.1.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.1.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.1.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.1.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.1.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.1.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.1.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.1.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.1.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.1.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.1.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.1.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.1.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.2.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.2.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.2.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.2.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.2.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.2.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.2.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.2.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.2.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.2.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.2.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.2.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.2.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.2.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.2.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.2.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.3.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.3.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.3.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.3.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.3.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.3.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.3.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.3.3	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpBPS.3.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.3.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.3.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.3.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.3.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.3.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.3.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.3.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.4.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.4.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.4.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.4.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.4.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.4.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.4.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.4.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.4.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.4.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.4.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.4.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.4.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.4.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.4.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.4.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.5.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.5.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.5.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.5.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.5.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.5.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.5.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.5.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.5.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.5.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.5.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.5.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.5.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.5.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.5.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.5.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.6.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.6.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.6.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.6.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.6.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.6.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.6.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.6.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.6.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.6.4	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpBPS.6.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.6.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.6.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.6.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.6.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.6.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.7.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.7.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.7.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.7.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.7.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.7.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.7.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.7.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.7.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.7.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.7.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.7.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.7.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.7.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.7.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.7.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.8.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.8.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.8.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.8.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.8.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.8.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.8.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.8.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.8.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.8.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.8.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.8.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.8.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.8.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.8.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.8.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.9.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.9.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.9.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.9.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.9.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.9.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.9.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.9.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.9.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.9.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.9.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.9.5	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpBPS.9.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.9.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.9.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.9.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.10.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.10.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.10.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.10.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.10.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.10.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.10.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.10.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.10.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.10.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.10.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.10.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.10.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.10.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.10.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.10.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.11.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.11.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.11.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.11.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.11.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.11.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.11.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.11.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.11.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.11.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.11.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.11.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.11.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.11.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.11.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.11.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.12.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.12.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.12.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.12.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.12.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.12.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.12.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.12.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.12.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.12.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.12.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.12.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.12.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.12.6	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpBPS.12.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.12.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.13.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.13.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.13.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.13.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.13.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.13.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.13.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.13.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.13.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.13.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.13.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.13.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.13.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.13.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.13.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.13.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.14.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.14.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.14.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.14.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.14.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.14.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.14.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.14.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.14.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.14.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.14.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.14.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.14.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.14.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.14.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.14.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.15.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.15.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.15.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.15.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.15.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.15.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.15.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.15.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.15.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.15.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.15.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.15.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.15.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.15.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.15.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.15.7	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpBPS.16.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.16.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.16.1	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.16.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.16.2	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.16.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.16.3	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.16.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.16.4	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.16.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.16.5	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.16.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.16.6	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.16.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.16.7	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.16.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.17.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.17.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.17.1	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.17.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.17.2	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.17.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.17.3	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.17.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.17.4	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.17.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.17.5	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.17.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.17.6	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.17.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.17.7	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.17.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.18.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.18.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.18.1	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.18.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.18.2	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.18.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.18.3	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.18.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.18.4	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.18.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.18.5	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.18.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.18.6	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.18.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.18.7	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.18.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.19.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.19.0	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpBPS.19.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.19.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.19.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.19.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.19.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.19.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.19.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.19.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.19.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.19.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.19.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.19.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.19.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.19.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.20.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.20.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.20.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.20.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.20.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.20.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.20.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.20.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.20.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.20.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.20.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.20.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.20.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.20.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.20.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.20.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.21.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.21.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.21.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.21.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.21.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.21.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.21.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.21.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.21.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.21.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.21.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.21.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.21.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.21.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.21.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.21.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.22.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.22.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.22.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.22.1	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpBPS.22.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.22.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.22.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.22.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.22.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.22.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.22.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.22.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.22.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.22.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.22.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.22.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.23.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.23.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.23.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.23.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.23.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.23.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.23.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.23.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.23.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.23.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.23.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.23.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.23.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.23.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.23.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.23.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.24.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.24.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.24.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.24.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.24.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.24.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.24.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.24.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.24.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.24.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.24.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.24.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.24.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.24.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.24.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.24.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.25.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.25.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.25.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.25.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.25.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.25.2	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpBPS.25.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.25.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.25.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.25.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.25.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.25.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.25.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.25.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.25.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.25.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.26.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.26.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.26.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.26.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.26.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.26.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.26.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.26.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.26.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.26.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.26.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.26.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.26.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.26.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.26.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.26.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.27.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.27.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.27.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.27.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.27.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.27.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.27.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.27.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.27.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.27.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.27.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.27.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.27.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.27.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.27.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.27.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.28.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.28.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.28.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.28.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.28.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.28.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.28.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.28.3	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpBPS.28.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.28.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.28.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.28.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.28.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.28.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.28.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.28.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.29.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.29.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.29.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.29.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.29.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.29.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.29.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.29.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.29.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.29.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.29.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.29.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.29.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.29.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.29.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.29.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.30.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.30.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.30.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.30.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.30.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.30.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.30.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.30.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.30.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.30.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.30.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.30.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.30.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.30.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.30.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.30.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.31.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.31.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.31.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.31.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.31.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.31.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.31.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.31.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.31.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.31.4	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpBPS.31.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.31.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.31.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.31.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.31.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.31.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.32.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.32.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.32.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.32.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.32.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.32.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.32.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.32.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.32.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.32.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.32.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.32.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.32.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.32.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.32.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.32.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.33.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.33.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.33.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.33.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.33.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.33.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.33.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.33.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.33.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.33.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.33.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.33.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.33.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.33.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.33.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.33.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.34.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.34.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.34.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.34.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.34.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.34.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.34.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.34.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.34.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.34.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.34.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.34.5	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpBPS.34.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.34.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.34.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.34.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.35.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.35.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.35.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.35.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.35.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.35.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.35.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.35.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.35.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.35.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.35.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.35.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.35.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.35.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.35.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.35.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.36.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.36.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.36.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.36.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.36.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.36.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.36.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.36.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.36.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.36.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.36.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.36.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.36.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.36.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.36.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.36.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.37.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.37.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.37.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.37.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.37.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.37.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.37.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.37.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.37.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.37.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.37.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.37.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.37.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.37.6	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpBPS.37.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.37.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.38.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.38.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.38.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.38.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.38.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.38.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.38.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.38.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.38.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.38.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.38.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.38.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.38.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.38.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.38.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.38.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.39.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.39.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.39.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.39.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.39.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.39.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.39.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.39.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.39.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.39.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.39.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.39.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.39.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.39.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.39.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.39.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.40.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.40.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.40.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.40.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.40.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.40.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.40.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.40.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.40.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.40.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.40.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.40.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.40.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.40.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.40.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.40.7	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpBPS.41.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.41.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.41.1	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.41.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.41.2	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.41.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.41.3	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.41.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.41.4	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.41.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.41.5	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.41.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.41.6	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.41.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.41.7	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.41.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.42.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.42.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.42.1	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.42.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.42.2	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.42.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.42.3	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.42.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.42.4	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.42.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.42.5	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.42.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.42.6	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.42.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.42.7	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.42.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.43.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.43.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.43.1	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.43.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.43.2	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.43.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.43.3	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.43.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.43.4	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.43.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.43.5	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.43.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.43.6	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.43.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.43.7	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.43.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.44.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.8.44.0	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpBPS.44.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.44.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.44.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.44.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.44.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.44.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.44.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.44.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.44.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.44.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.44.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.44.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.44.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.44.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.45.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.45.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.45.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.45.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.45.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.45.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.45.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.45.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.45.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.45.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.45.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.45.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.45.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.45.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.45.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.45.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.46.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.46.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.46.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.46.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.46.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.46.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.46.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.46.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.46.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.46.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.46.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.46.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.46.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.46.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.46.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.46.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.47.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.47.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.47.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.47.1	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpBPS.47.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.47.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.47.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.47.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.47.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.47.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.47.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.47.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.47.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.47.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.47.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.47.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.48.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.48.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.48.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.48.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.48.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.48.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.48.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.48.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.48.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.48.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.48.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.48.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.48.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.48.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.48.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.48.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.49.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.49.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.49.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.49.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.49.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.49.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.49.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.49.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.49.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.49.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.49.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.49.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.49.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.49.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.49.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.49.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.50.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.50.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.50.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.50.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.50.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.50.2	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpBPS.50.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.50.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.50.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.50.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.50.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.50.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.50.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.50.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.50.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.50.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.51.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.51.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.51.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.51.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.51.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.51.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.51.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.51.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.51.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.51.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.51.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.51.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.51.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.51.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.51.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.51.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.52.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.52.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.52.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.52.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.52.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.52.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.52.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.52.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.52.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.52.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.52.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.52.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.52.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.52.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.52.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.52.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.53.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.53.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.53.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.53.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.53.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.53.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.53.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.53.3	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropL-PreTcpBPS.53.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.53.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.53.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.53.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.53.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.53.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.53.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.53.7	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.54.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.54.0	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.54.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.54.1	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.54.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.54.2	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.54.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.54.3	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.54.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.54.4	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.54.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.54.5	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.54.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.54.6	Gauge	4294967295
iblfQoSWredDropL-PreTcpBPS.54.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.8.54.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.1.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.1.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.1.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.1.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.1.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.1.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.1.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.1.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.1.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.1.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.1.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.1.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.1.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.1.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.1.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.1.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.2.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.2.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.2.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.2.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.2.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.2.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.2.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.2.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.2.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.2.4	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpPPS.2.5	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.2.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.2.6	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.2.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.2.7	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.2.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.3.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.3.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.3.1	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.3.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.3.2	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.3.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.3.3	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.3.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.3.4	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.3.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.3.5	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.3.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.3.6	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.3.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.3.7	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.3.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.4.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.4.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.4.1	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.4.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.4.2	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.4.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.4.3	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.4.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.4.4	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.4.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.4.5	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.4.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.4.6	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.4.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.4.7	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.4.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.5.0	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.5.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.5.1	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.5.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.5.2	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.5.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.5.3	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.5.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.5.4	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.5.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.5.5	.13.6.1.4.1.26138.2.65.1.1.2.2.1.11.5.5	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpPPS.5.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.5.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.5.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.5.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.6.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.6.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.6.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.6.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.6.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.6.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.6.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.6.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.6.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.6.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.6.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.6.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.6.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.6.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.6.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.6.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.7.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.7.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.7.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.7.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.7.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.7.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.7.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.7.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.7.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.7.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.7.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.7.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.7.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.7.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.7.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.7.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.8.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.8.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.8.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.8.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.8.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.8.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.8.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.8.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.8.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.8.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.8.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.8.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.8.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.8.6	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpPPS.8.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.8.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.9.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.9.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.9.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.9.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.9.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.9.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.9.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.9.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.9.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.9.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.9.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.9.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.9.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.9.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.9.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.9.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.10.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.10.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.10.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.10.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.10.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.10.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.10.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.10.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.10.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.10.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.10.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.10.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.10.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.10.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.10.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.10.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.11.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.11.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.11.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.11.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.11.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.11.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.11.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.11.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.11.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.11.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.11.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.11.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.11.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.11.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.11.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.11.7	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpPPS.12.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.12	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.12.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.12	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.12.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.12	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.12.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.12	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.12.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.12	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.12.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.12	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.12.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.12	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.12.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.12	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.13.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.13	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.13.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.13	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.13.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.13	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.13.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.13	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.13.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.13	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.13.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.13	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.13.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.13	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.13.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.13	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.14.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.14	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.14.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.14	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.14.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.14	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.14.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.14	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.14.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.14	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.14.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.14	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.14.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.14	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.14.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.14	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.15.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.15	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpPPS.15.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.15	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.15.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.15	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.15.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.15	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.15.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.15	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.15.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.15	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.15.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.15	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.15.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.15	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.16.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.16	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.16.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.16	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.16.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.16	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.16.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.16	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.16.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.16	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.16.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.16	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.16.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.16	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.16.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.16	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.17.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.17	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.17.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.17	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.17.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.17	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.17.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.17	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.17.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.17	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.17.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.17	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.17.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.17	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.17.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.17	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.18.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.18	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.18.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.18	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpPPS.18.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.18.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.18.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.18.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.18.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.18.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.18.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.18.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.18.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.18.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.18.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.18.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.19.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.19.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.19.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.19.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.19.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.19.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.19.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.19.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.19.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.19.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.19.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.19.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.19.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.19.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.19.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.19.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.20.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.20.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.20.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.20.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.20.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.20.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.20.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.20.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.20.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.20.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.20.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.20.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.20.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.20.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.20.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.20.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.21.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.21.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.21.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.21.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.21.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.21.2	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpPPS.21.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.21	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.21.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.21	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.21.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.21	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.21.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.21	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.21.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.21	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.22.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.22	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.22.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.22	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.22.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.22	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.22.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.22	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.22.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.22	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.22.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.22	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.22.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.22	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.22.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.22	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.23.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.23	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.23.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.23	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.23.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.23	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.23.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.23	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.23.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.23	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.23.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.23	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.23.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.23	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.23.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.23	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.24.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.24	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.24.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.24	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.24.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.24	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.24.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.24	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpPPS.24.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.24	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.24.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.24	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.24.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.24	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.24.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.24	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.25.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.25	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.25.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.25	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.25.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.25	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.25.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.25	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.25.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.25	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.25.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.25	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.25.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.25	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.25.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.25	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.26.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.26	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.26.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.26	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.26.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.26	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.26.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.26	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.26.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.26	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.26.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.26	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.26.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.26	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.26.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.26	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.27.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.27	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.27.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.27	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.27.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.27	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.27.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.27	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.27.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.27	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpPPS.27.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.27.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.27.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.27.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.27.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.27.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.28.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.28.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.28.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.28.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.28.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.28.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.28.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.28.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.28.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.28.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.28.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.28.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.28.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.28.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.28.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.28.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.29.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.29.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.29.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.29.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.29.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.29.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.29.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.29.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.29.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.29.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.29.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.29.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.29.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.29.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.29.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.29.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.30.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.30.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.30.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.30.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.30.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.30.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.30.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.30.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.30.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.30.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.30.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.30.5	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpPPS.30.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.30.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.30.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.30.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.31.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.31.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.31.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.31.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.31.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.31.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.31.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.31.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.31.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.31.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.31.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.31.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.31.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.31.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.31.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.31.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.32.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.32.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.32.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.32.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.32.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.32.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.32.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.32.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.32.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.32.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.32.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.32.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.32.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.32.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.32.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.32.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.33.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.33.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.33.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.33.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.33.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.33.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.33.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.33.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.33.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.33.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.33.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.33.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.33.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.33.6	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpPPS.33.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.33.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.34.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.34.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.34.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.34.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.34.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.34.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.34.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.34.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.34.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.34.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.34.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.34.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.34.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.34.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.34.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.34.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.35.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.35.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.35.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.35.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.35.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.35.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.35.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.35.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.35.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.35.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.35.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.35.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.35.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.35.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.35.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.35.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.36.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.36.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.36.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.36.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.36.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.36.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.36.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.36.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.36.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.36.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.36.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.36.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.36.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.36.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.36.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.36.7	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpPPS.37.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.37	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.37.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.37	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.37.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.37	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.37.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.37	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.37.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.37	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.37.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.37	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.37.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.37	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.37.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.37	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.38.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.38	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.38.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.38	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.38.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.38	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.38.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.38	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.38.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.38	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.38.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.38	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.38.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.38	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.38.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.38	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.39.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.39	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.39.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.39	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.39.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.39	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.39.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.39	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.39.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.39	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.39.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.39	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.39.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.39	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.39.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.39	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.40.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.40	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpPPS.40.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.40	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.40.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.40	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.40.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.40	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.40.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.40	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.40.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.40	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.40.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.40	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.40.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.40	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.41.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.41	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.41.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.41	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.41.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.41	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.41.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.41	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.41.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.41	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.41.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.41	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.41.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.41	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.41.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.41	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.42.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.42	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.42.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.42	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.42.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.42	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.42.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.42	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.42.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.42	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.42.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.42	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.42.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.42	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.42.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.42	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.43.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.43	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.43.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.43	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpPPS.43.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.43.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.43.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.43.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.43.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.43.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.43.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.43.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.43.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.43.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.43.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.43.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.44.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.44.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.44.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.44.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.44.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.44.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.44.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.44.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.44.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.44.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.44.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.44.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.44.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.44.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.44.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.44.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.45.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.45.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.45.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.45.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.45.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.45.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.45.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.45.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.45.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.45.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.45.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.45.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.45.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.45.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.45.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.45.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.46.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.46.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.46.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.46.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.46.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.46.2	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpPPS.46.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.46.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.46.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.46.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.46.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.46.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.46.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.46.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.46.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.46.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.47.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.47.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.47.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.47.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.47.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.47.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.47.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.47.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.47.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.47.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.47.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.47.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.47.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.47.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.47.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.47.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.48.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.48.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.48.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.48.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.48.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.48.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.48.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.48.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.48.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.48.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.48.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.48.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.48.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.48.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.48.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.48.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.49.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.49.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.49.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.49.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.49.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.49.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.49.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.49.3	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpPPS.49.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.49.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.49.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.49.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.49.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.49.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.49.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.49.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.50.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.50.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.50.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.50.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.50.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.50.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.50.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.50.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.50.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.50.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.50.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.50.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.50.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.50.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.50.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.50.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.51.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.51.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.51.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.51.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.51.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.51.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.51.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.51.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.51.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.51.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.51.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.51.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.51.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.51.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.51.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.51.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.52.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.52.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.52.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.52.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.52.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.52.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.52.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.52.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.52.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.52.4	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpPPS.52.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.52.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.52.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.52.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.52.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.52.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.53.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.53.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.53.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.53.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.53.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.53.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.53.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.53.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.53.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.53.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.53.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.53.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.53.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.53.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.53.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.53.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.54.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.54.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.54.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.54.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.54.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.54.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.54.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.54.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.54.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.54.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.54.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.54.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.54.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.54.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpPPS.54.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.11.54.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.1.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.1.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.1.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.1.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.1.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.1.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.1.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.1.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.1.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.1.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.1.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.1.5	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpBPS.1.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.1.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.1.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.1.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.2.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.2.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.2.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.2.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.2.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.2.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.2.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.2.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.2.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.2.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.2.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.2.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.2.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.2.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.2.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.2.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.3.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.3.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.3.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.3.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.3.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.3.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.3.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.3.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.3.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.3.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.3.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.3.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.3.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.3.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.3.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.3.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.4.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.4.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.4.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.4.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.4.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.4.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.4.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.4.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.4.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.4.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.4.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.4.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.4.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.4.6	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpBPS.4.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.4.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.5.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.5.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.5.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.5.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.5.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.5.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.5.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.5.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.5.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.5.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.5.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.5.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.5.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.5.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.5.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.5.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.6.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.6.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.6.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.6.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.6.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.6.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.6.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.6.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.6.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.6.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.6.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.6.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.6.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.6.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.6.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.6.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.7.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.7.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.7.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.7.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.7.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.7.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.7.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.7.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.7.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.7.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.7.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.7.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.7.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.7.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.7.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.7.7	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpBPS.8.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.8.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.8.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.8.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.8.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.8.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.8.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.8.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.8.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.8.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.8.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.8.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.8.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.8.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.8.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.8.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.9.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.9.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.9.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.9.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.9.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.9.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.9.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.9.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.9.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.9.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.9.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.9.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.9.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.9.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.9.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.9.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.10.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.10.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.10.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.10.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.10.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.10.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.10.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.10.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.10.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.10.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.10.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.10.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.10.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.10.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.10.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.10.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.11.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.11.0	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpBPS.11.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.11	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.11.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.11	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.11.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.11	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.11.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.11	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.11.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.11	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.11.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.11	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.11.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.11	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.12.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.12	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.12.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.12	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.12.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.12	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.12.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.12	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.12.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.12	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.12.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.12	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.12.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.12	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.12.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.12	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.13.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.13	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.13.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.13	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.13.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.13	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.13.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.13	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.13.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.13	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.13.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.13	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.13.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.13	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.13.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.13	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.14.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.14	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.14.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.14	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpBPS.14.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.14.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.14.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.14.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.14.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.14.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.14.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.14.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.14.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.14.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.14.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.14.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.15.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.15.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.15.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.15.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.15.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.15.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.15.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.15.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.15.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.15.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.15.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.15.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.15.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.15.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.15.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.15.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.16.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.16.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.16.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.16.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.16.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.16.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.16.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.16.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.16.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.16.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.16.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.16.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.16.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.16.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.16.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.16.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.17.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.17.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.17.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.17.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.17.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.17.2	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpBPS.17.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.17.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.17.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.17.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.17.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.17.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.17.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.17.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.17.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.17.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.18.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.18.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.18.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.18.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.18.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.18.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.18.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.18.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.18.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.18.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.18.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.18.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.18.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.18.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.18.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.18.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.19.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.19.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.19.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.19.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.19.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.19.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.19.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.19.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.19.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.19.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.19.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.19.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.19.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.19.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.19.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.19.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.20.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.20.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.20.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.20.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.20.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.20.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.20.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.20.3	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpBPS.20.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.20	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.20.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.20	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.20.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.20	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.20.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.20	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.21.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.21	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.21.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.21	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.21.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.21	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.21.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.21	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.21.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.21	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.21.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.21	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.21.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.21	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.21.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.21	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.22.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.22	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.22.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.22	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.22.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.22	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.22.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.22	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.22.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.22	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.22.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.22	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.22.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.22	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.22.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.22	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.23.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.23	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.23.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.23	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.23.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.23	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.23.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.23	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.23.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.23	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpBPS.23.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.23	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.23.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.23	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.23.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.23	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.24.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.24	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.24.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.24	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.24.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.24	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.24.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.24	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.24.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.24	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.24.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.24	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.24.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.24	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.24.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.24	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.25.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.25	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.25.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.25	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.25.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.25	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.25.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.25	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.25.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.25	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.25.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.25	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.25.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.25	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.25.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.25	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.26.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.26	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.26.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.26	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.26.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.26	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.26.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.26	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.26.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.26	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.26.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.26	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpBPS.26.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.26.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.26.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.26.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.27.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.27.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.27.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.27.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.27.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.27.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.27.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.27.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.27.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.27.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.27.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.27.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.27.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.27.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.27.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.27.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.28.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.28.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.28.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.28.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.28.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.28.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.28.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.28.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.28.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.28.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.28.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.28.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.28.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.28.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.28.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.28.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.29.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.29.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.29.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.29.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.29.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.29.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.29.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.29.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.29.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.29.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.29.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.29.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.29.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.29.6	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpBPS.29.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.29.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.30.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.30.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.30.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.30.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.30.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.30.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.30.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.30.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.30.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.30.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.30.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.30.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.30.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.30.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.30.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.30.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.31.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.31.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.31.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.31.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.31.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.31.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.31.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.31.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.31.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.31.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.31.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.31.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.31.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.31.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.31.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.31.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.32.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.32.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.32.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.32.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.32.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.32.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.32.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.32.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.32.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.32.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.32.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.32.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.32.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.32.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.32.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.32.7	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpBPS.33.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.33.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.33.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.33.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.33.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.33.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.33.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.33.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.33.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.33.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.33.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.33.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.33.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.33.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.33.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.33.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.34.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.34.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.34.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.34.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.34.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.34.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.34.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.34.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.34.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.34.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.34.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.34.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.34.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.34.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.34.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.34.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.35.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.35.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.35.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.35.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.35.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.35.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.35.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.35.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.35.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.35.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.35.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.35.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.35.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.35.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.35.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.35.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.36.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.36.0	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpBPS.36.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.36.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.36.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.36.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.36.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.36.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.36.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.36.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.36.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.36.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.36.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.36.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.36.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.36.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.37.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.37.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.37.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.37.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.37.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.37.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.37.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.37.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.37.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.37.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.37.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.37.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.37.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.37.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.37.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.37.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.38.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.38.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.38.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.38.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.38.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.38.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.38.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.38.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.38.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.38.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.38.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.38.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.38.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.38.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.38.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.38.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.39.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.39.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.39.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.39.1	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpBPS.39.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.39.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.39.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.39.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.39.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.39.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.39.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.39.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.39.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.39.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.39.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.39.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.40.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.40.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.40.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.40.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.40.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.40.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.40.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.40.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.40.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.40.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.40.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.40.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.40.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.40.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.40.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.40.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.41.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.41.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.41.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.41.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.41.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.41.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.41.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.41.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.41.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.41.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.41.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.41.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.41.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.41.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.41.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.41.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.42.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.42.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.42.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.42.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.42.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.42.2	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpBPS.42.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.42.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.42.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.42.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.42.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.42.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.42.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.42.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.42.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.42.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.43.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.43.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.43.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.43.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.43.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.43.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.43.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.43.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.43.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.43.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.43.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.43.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.43.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.43.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.43.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.43.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.44.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.44.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.44.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.44.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.44.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.44.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.44.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.44.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.44.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.44.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.44.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.44.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.44.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.44.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.44.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.44.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.45.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.45.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.45.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.45.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.45.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.45.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.45.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.45.3	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpBPS.45.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.45.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.45.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.45.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.45.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.45.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.45.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.45.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.46.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.46.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.46.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.46.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.46.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.46.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.46.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.46.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.46.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.46.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.46.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.46.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.46.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.46.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.46.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.46.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.47.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.47.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.47.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.47.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.47.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.47.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.47.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.47.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.47.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.47.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.47.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.47.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.47.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.47.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.47.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.47.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.48.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.48.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.48.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.48.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.48.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.48.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.48.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.48.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.48.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.48.4	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpBPS.48.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.48.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.48.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.48.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.48.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.48.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.49.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.49.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.49.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.49.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.49.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.49.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.49.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.49.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.49.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.49.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.49.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.49.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.49.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.49.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.49.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.49.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.50.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.50.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.50.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.50.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.50.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.50.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.50.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.50.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.50.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.50.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.50.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.50.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.50.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.50.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.50.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.50.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.51.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.51.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.51.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.51.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.51.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.51.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.51.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.51.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.51.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.51.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.51.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.51.5	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpBPS.51.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.51.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.51.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.51.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.52.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.52.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.52.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.52.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.52.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.52.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.52.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.52.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.52.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.52.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.52.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.52.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.52.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.52.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.52.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.52.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.53.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.53.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.53.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.53.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.53.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.53.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.53.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.53.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.53.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.53.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.53.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.53.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.53.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.53.6	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.53.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.53.7	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.54.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.54.0	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.54.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.54.1	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.54.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.54.2	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.54.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.54.3	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.54.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.54.4	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.54.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.54.5	Gauge	4294967295
iblfQoSWredDropH-PreNTcpBPS.54.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.54.6	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreNTcpBPS.54.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.12.54.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.1.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.1.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.1.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.1.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.1.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.1.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.1.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.1.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.1.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.1.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.1.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.1.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.1.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.1.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.1.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.1.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.2.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.2.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.2.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.2.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.2.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.2.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.2.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.2.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.2.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.2.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.2.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.2.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.2.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.2.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.2.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.2.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.3.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.3.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.3.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.3.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.3.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.3.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.3.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.3.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.3.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.3.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.3.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.3.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.3.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.3.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.3.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.3.7	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpPPS.4.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.4.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.4.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.4.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.4.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.4.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.4.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.4.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.4.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.4.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.4.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.4.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.4.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.4.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.4.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.4.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.5.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.5.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.5.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.5.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.5.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.5.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.5.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.5.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.5.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.5.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.5.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.5.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.5.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.5.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.5.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.5.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.6.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.6.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.6.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.6.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.6.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.6.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.6.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.6.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.6.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.6.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.6.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.6.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.6.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.6.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.6.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.6.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.7.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.7.0	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpPPS.7.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.7.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.7.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.7.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.7.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.7.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.7.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.7.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.7.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.7.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.7.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.7.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.7.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.7.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.8.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.8.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.8.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.8.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.8.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.8.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.8.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.8.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.8.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.8.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.8.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.8.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.8.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.8.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.8.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.8.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.9.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.9.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.9.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.9.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.9.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.9.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.9.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.9.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.9.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.9.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.9.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.9.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.9.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.9.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.9.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.9.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.10.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.10.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.10.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.10.1	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpPPS.10.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.10.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.10.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.10.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.10.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.10.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.10.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.10.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.10.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.10.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.10.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.10.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.11.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.11.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.11.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.11.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.11.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.11.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.11.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.11.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.11.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.11.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.11.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.11.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.11.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.11.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.11.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.11.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.12.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.12.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.12.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.12.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.12.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.12.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.12.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.12.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.12.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.12.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.12.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.12.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.12.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.12.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.12.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.12.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.13.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.13.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.13.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.13.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.13.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.13.2	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpPPS.13.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.13.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.13.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.13.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.13.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.13.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.13.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.13.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.13.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.13.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.14.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.14.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.14.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.14.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.14.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.14.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.14.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.14.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.14.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.14.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.14.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.14.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.14.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.14.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.14.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.14.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.15.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.15.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.15.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.15.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.15.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.15.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.15.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.15.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.15.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.15.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.15.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.15.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.15.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.15.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.15.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.15.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.16.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.16.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.16.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.16.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.16.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.16.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.16.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.16.3	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpPPS.16.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.16.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.16.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.16.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.16.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.16.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.16.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.16.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.17.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.17.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.17.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.17.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.17.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.17.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.17.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.17.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.17.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.17.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.17.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.17.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.17.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.17.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.17.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.17.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.18.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.18.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.18.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.18.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.18.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.18.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.18.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.18.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.18.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.18.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.18.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.18.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.18.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.18.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.18.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.18.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.19.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.19.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.19.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.19.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.19.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.19.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.19.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.19.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.19.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.19.4	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpPPS.19.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.19.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.19.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.19.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.19.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.19.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.20.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.20.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.20.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.20.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.20.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.20.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.20.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.20.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.20.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.20.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.20.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.20.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.20.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.20.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.20.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.20.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.21.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.21.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.21.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.21.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.21.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.21.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.21.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.21.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.21.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.21.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.21.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.21.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.21.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.21.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.21.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.21.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.22.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.22.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.22.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.22.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.22.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.22.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.22.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.22.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.22.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.22.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.22.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.22.5	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpPPS.22.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.22.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.22.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.22.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.23.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.23.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.23.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.23.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.23.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.23.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.23.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.23.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.23.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.23.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.23.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.23.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.23.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.23.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.23.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.23.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.24.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.24.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.24.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.24.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.24.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.24.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.24.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.24.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.24.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.24.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.24.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.24.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.24.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.24.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.24.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.24.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.25.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.25.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.25.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.25.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.25.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.25.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.25.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.25.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.25.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.25.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.25.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.25.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.25.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.25.6	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpPPS.25.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.25.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.26.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.26.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.26.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.26.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.26.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.26.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.26.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.26.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.26.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.26.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.26.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.26.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.26.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.26.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.26.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.26.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.27.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.27.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.27.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.27.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.27.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.27.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.27.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.27.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.27.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.27.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.27.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.27.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.27.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.27.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.27.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.27.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.28.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.28.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.28.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.28.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.28.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.28.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.28.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.28.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.28.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.28.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.28.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.28.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.28.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.28.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.28.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.28.7	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpPPS.29.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.29.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.29.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.29.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.29.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.29.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.29.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.29.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.29.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.29.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.29.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.29.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.29.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.29.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.29.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.29.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.30.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.30.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.30.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.30.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.30.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.30.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.30.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.30.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.30.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.30.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.30.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.30.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.30.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.30.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.30.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.30.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.31.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.31.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.31.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.31.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.31.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.31.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.31.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.31.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.31.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.31.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.31.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.31.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.31.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.31.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.31.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.31.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.32.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.32.0	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpPPS.32.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.32	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.32.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.32	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.32.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.32	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.32.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.32	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.32.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.32	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.32.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.32	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.32.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.32	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.33.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.33	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.33.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.33	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.33.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.33	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.33.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.33	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.33.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.33	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.33.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.33	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.33.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.33	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.33.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.33	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.34.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.34	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.34.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.34	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.34.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.34	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.34.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.34	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.34.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.34	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.34.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.34	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.34.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.34	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.34.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.34	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.35.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.35	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.35.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.35	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpPPS.35.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.35.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.35.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.35.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.35.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.35.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.35.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.35.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.35.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.35.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.35.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.35.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.36.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.36.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.36.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.36.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.36.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.36.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.36.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.36.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.36.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.36.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.36.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.36.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.36.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.36.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.36.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.36.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.37.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.37.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.37.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.37.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.37.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.37.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.37.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.37.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.37.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.37.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.37.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.37.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.37.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.37.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.37.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.37.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.38.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.38.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.38.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.38.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.38.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.38.2	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpPPS.38.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.38.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.38.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.38.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.38.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.38.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.38.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.38.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.38.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.38.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.39.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.39.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.39.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.39.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.39.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.39.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.39.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.39.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.39.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.39.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.39.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.39.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.39.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.39.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.39.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.39.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.40.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.40.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.40.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.40.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.40.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.40.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.40.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.40.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.40.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.40.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.40.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.40.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.40.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.40.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.40.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.40.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.41.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.41.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.41.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.41.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.41.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.41.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.41.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.41.3	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpPPS.41.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.41	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.41.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.41	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.41.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.41	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.41.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.41	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.42.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.42	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.42.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.42	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.42.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.42	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.42.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.42	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.42.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.42	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.42.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.42	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.42.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.42	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.42.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.42	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.43.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.43	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.43.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.43	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.43.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.43	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.43.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.43	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.43.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.43	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.43.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.43	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.43.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.43	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.43.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.43	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.44.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.44	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.44.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.44	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.44.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.44	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.44.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.44	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.44.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.44	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpPPS.44.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.44.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.44.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.44.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.44.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.44.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.45.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.45.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.45.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.45.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.45.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.45.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.45.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.45.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.45.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.45.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.45.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.45.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.45.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.45.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.45.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.45.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.46.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.46.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.46.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.46.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.46.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.46.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.46.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.46.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.46.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.46.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.46.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.46.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.46.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.46.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.46.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.46.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.47.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.47.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.47.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.47.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.47.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.47.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.47.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.47.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.47.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.47.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.47.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.47.5	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpPPS.47.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.47.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.47.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.47.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.48.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.48.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.48.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.48.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.48.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.48.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.48.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.48.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.48.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.48.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.48.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.48.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.48.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.48.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.48.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.48.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.49.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.49.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.49.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.49.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.49.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.49.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.49.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.49.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.49.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.49.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.49.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.49.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.49.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.49.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.49.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.49.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.50.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.50.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.50.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.50.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.50.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.50.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.50.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.50.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.50.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.50.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.50.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.50.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.50.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.50.6	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpPPS.50.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.50	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.51.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.51	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.51.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.51	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.51.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.51	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.51.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.51	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.51.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.51	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.51.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.51	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.51.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.51	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.51.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.51	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.52.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.52	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.52.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.52	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.52.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.52	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.52.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.52	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.52.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.52	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.52.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.52	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.52.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.52	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.52.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.52	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.53.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.53	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.53.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.53	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.53.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.53	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.53.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.53	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.53.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.53	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.53.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.53	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.53.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.53	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.53.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.53	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpPPS.54.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.54.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.54.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.54.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.54.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.54.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.54.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.54.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.54.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.54.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.54.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.54.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.54.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.54.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpPPS.54.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.15.54.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.1.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.1.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.1.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.1.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.1.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.1.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.1.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.1.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.1.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.1.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.1.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.1.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.1.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.1.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.1.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.1.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.2.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.2.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.2.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.2.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.2.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.2.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.2.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.2.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.2.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.2.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.2.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.2.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.2.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.2.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.2.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.2.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.3.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.3.0	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpBPS.3.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.3.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.3.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.3.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.3.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.3.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.3.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.3.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.3.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.3.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.3.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.3.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.3.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.3.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.4.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.4.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.4.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.4.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.4.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.4.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.4.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.4.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.4.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.4.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.4.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.4.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.4.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.4.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.4.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.4.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.5.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.5.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.5.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.5.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.5.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.5.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.5.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.5.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.5.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.5.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.5.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.5.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.5.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.5.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.5.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.5.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.6.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.6.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.6.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.6.1	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpBPS.6.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.6.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.6.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.6.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.6.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.6.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.6.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.6.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.6.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.6.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.6.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.6.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.7.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.7.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.7.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.7.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.7.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.7.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.7.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.7.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.7.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.7.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.7.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.7.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.7.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.7.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.7.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.7.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.8.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.8.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.8.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.8.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.8.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.8.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.8.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.8.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.8.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.8.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.8.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.8.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.8.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.8.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.8.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.8.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.9.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.9.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.9.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.9.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.9.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.9.2	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpBPS.9.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.9.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.9.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.9.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.9.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.9.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.9.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.9.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.9.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.9.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.10.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.10.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.10.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.10.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.10.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.10.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.10.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.10.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.10.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.10.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.10.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.10.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.10.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.10.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.10.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.10.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.11.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.11.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.11.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.11.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.11.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.11.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.11.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.11.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.11.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.11.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.11.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.11.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.11.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.11.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.11.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.11.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.12.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.12.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.12.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.12.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.12.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.12.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.12.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.12.3	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpBPS.12.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.12.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.12.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.12.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.12.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.12.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.12.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.12.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.13.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.13.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.13.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.13.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.13.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.13.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.13.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.13.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.13.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.13.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.13.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.13.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.13.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.13.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.13.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.13.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.14.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.14.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.14.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.14.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.14.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.14.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.14.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.14.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.14.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.14.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.14.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.14.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.14.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.14.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.14.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.14.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.15.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.15.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.15.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.15.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.15.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.15.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.15.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.15.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.15.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.15.4	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpBPS.15.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.15.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.15.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.15.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.15.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.15.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.16.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.16.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.16.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.16.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.16.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.16.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.16.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.16.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.16.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.16.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.16.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.16.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.16.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.16.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.16.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.16.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.17.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.17.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.17.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.17.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.17.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.17.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.17.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.17.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.17.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.17.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.17.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.17.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.17.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.17.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.17.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.17.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.18.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.18.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.18.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.18.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.18.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.18.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.18.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.18.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.18.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.18.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.18.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.18.5	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpBPS.18.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.18.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.18.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.18.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.19.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.19.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.19.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.19.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.19.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.19.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.19.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.19.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.19.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.19.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.19.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.19.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.19.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.19.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.19.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.19.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.20.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.20.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.20.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.20.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.20.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.20.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.20.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.20.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.20.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.20.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.20.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.20.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.20.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.20.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.20.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.20.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.21.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.21.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.21.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.21.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.21.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.21.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.21.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.21.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.21.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.21.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.21.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.21.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.21.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.21.6	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpBPS.21.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.21.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.22.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.22.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.22.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.22.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.22.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.22.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.22.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.22.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.22.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.22.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.22.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.22.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.22.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.22.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.22.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.22.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.23.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.23.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.23.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.23.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.23.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.23.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.23.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.23.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.23.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.23.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.23.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.23.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.23.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.23.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.23.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.23.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.24.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.24.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.24.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.24.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.24.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.24.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.24.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.24.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.24.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.24.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.24.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.24.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.24.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.24.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.24.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.24.7	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpBPS.25.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.25	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.25.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.25	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.25.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.25	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.25.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.25	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.25.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.25	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.25.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.25	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.25.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.25	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.25.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.25	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.26.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.26	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.26.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.26	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.26.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.26	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.26.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.26	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.26.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.26	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.26.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.26	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.26.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.26	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.26.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.26	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.27.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.27	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.27.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.27	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.27.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.27	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.27.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.27	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.27.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.27	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.27.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.27	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.27.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.27	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.27.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.27	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.28.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.28	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpBPS.28.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.28	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.28.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.28	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.28.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.28	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.28.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.28	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.28.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.28	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.28.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.28	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.28.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.28	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.29.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.29	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.29.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.29	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.29.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.29	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.29.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.29	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.29.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.29	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.29.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.29	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.29.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.29	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.29.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.29	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.30.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.30	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.30.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.30	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.30.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.30	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.30.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.30	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.30.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.30	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.30.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.30	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.30.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.30	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.30.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.30	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.31.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.31	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.31.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.31	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpBPS.31.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.31.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.31.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.31.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.31.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.31.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.31.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.31.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.31.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.31.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.31.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.31.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.32.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.32.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.32.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.32.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.32.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.32.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.32.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.32.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.32.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.32.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.32.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.32.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.32.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.32.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.32.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.32.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.33.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.33.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.33.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.33.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.33.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.33.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.33.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.33.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.33.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.33.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.33.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.33.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.33.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.33.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.33.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.33.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.34.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.34.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.34.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.34.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.34.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.34.2	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpBPS.34.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.34.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.34.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.34.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.34.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.34.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.34.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.34.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.34.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.34.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.35.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.35.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.35.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.35.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.35.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.35.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.35.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.35.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.35.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.35.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.35.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.35.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.35.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.35.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.35.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.35.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.36.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.36.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.36.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.36.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.36.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.36.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.36.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.36.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.36.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.36.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.36.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.36.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.36.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.36.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.36.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.36.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.37.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.37.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.37.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.37.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.37.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.37.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.37.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.37.3	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpBPS.37.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.37.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.37.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.37.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.37.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.37.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.37.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.37.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.38.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.38.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.38.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.38.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.38.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.38.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.38.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.38.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.38.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.38.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.38.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.38.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.38.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.38.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.38.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.38.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.39.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.39.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.39.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.39.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.39.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.39.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.39.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.39.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.39.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.39.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.39.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.39.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.39.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.39.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.39.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.39.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.40.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.40.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.40.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.40.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.40.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.40.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.40.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.40.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.40.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.40.4	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpBPS.40.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.40.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.40.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.40.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.40.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.40.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.41.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.41.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.41.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.41.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.41.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.41.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.41.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.41.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.41.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.41.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.41.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.41.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.41.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.41.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.41.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.41.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.42.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.42.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.42.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.42.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.42.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.42.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.42.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.42.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.42.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.42.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.42.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.42.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.42.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.42.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.42.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.42.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.43.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.43.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.43.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.43.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.43.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.43.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.43.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.43.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.43.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.43.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.43.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.43.5	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpBPS.43.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.43.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.43.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.43.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.44.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.44.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.44.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.44.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.44.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.44.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.44.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.44.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.44.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.44.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.44.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.44.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.44.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.44.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.44.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.44.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.45.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.45.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.45.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.45.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.45.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.45.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.45.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.45.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.45.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.45.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.45.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.45.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.45.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.45.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.45.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.45.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.46.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.46.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.46.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.46.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.46.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.46.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.46.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.46.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.46.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.46.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.46.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.46.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.46.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.46.6	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpBPS.46.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.46.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.47.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.47.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.47.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.47.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.47.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.47.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.47.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.47.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.47.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.47.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.47.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.47.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.47.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.47.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.47.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.47.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.48.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.48.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.48.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.48.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.48.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.48.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.48.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.48.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.48.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.48.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.48.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.48.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.48.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.48.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.48.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.48.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.49.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.49.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.49.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.49.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.49.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.49.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.49.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.49.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.49.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.49.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.49.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.49.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.49.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.49.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.49.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.49.7	Gauge	4294967295



Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpBPS.50.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.50	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.50.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.50	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.50.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.50	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.50.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.50	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.50.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.50	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.50.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.50	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.50.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.50	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.50.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.50	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.51.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.51	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.51.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.51	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.51.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.51	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.51.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.51	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.51.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.51	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.51.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.51	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.51.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.51	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.51.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.51	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.52.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.52	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.52.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.52	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.52.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.52	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.52.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.52	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.52.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.52	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.52.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.52	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.52.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.52	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.52.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.52	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.53.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.53	Gauge	4294967295

Name	OID	Value Type	Value Example
iblfQoSWredDropH-PreTcpBPS.53.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.53.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.53.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.53.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.53.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.53.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.53.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.53.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.53.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.53.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.53.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.53.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.53.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.53.7	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.54.0	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.54.0	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.54.1	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.54.1	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.54.2	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.54.2	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.54.3	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.54.3	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.54.4	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.54.4	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.54.5	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.54.5	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.54.6	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.54.6	Gauge	4294967295
iblfQoSWredDropH-PreTcpBPS.54.7	.1.3.6.1.4.1.26138.2.65.1.1.2.2.1.16.54.7	Gauge	4294967295
iblfQoSAggregativeCarNextIndex.0	.1.3.6.1.4.1.26138.2.65.1.4.1.1.0	Integer	1
iblfQoSWredGroupNextIndex.0	.1.3.6.1.4.1.26138.2.65.1.6.1.1.0	Integer	1
iblfQoSPortPriorityValue.1	.1.3.6.1.4.1.26138.2.65.1.7.1.1.1.1	Integer	0
iblfQoSPortPriorityValue.2	.1.3.6.1.4.1.26138.2.65.1.7.1.1.1.2	Integer	0
iblfQoSPortPriorityValue.3	.1.3.6.1.4.1.26138.2.65.1.7.1.1.1.3	Integer	0
iblfQoSPortPriorityValue.4	.1.3.6.1.4.1.26138.2.65.1.7.1.1.1.4	Integer	0
iblfQoSPortPriorityValue.5	.1.3.6.1.4.1.26138.2.65.1.7.1.1.1.5	Integer	0
iblfQoSPortPriorityValue.6	.1.3.6.1.4.1.26138.2.65.1.7.1.1.1.6	Integer	0
iblfQoSPortPriorityValue.7	.1.3.6.1.4.1.26138.2.65.1.7.1.1.1.7	Integer	0
iblfQoSPortPriorityValue.8	.1.3.6.1.4.1.26138.2.65.1.7.1.1.1.8	Integer	0
iblfQoSPortPriorityValue.9	.1.3.6.1.4.1.26138.2.65.1.7.1.1.1.9	Integer	0
iblfQoSPortPriorityValue.10	.1.3.6.1.4.1.26138.2.65.1.7.1.1.1.10	Integer	0
iblfQoSPortPriorityValue.11	.1.3.6.1.4.1.26138.2.65.1.7.1.1.1.11	Integer	0
iblfQoSPortPriorityValue.12	.1.3.6.1.4.1.26138.2.65.1.7.1.1.1.12	Integer	0
iblfQoSPortPriorityValue.13	.1.3.6.1.4.1.26138.2.65.1.7.1.1.1.13	Integer	0
iblfQoSPortPriorityValue.14	.1.3.6.1.4.1.26138.2.65.1.7.1.1.1.14	Integer	0
iblfQoSPortPriorityValue.15	.1.3.6.1.4.1.26138.2.65.1.7.1.1.1.15	Integer	0

Name	OID	Value Type	Value Example
iblfQoSPortPriorityValue.16	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.16	Integer	0
iblfQoSPortPriorityValue.17	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.17	Integer	0
iblfQoSPortPriorityValue.18	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.18	Integer	0
iblfQoSPortPriorityValue.19	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.19	Integer	0
iblfQoSPortPriorityValue.20	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.20	Integer	0
iblfQoSPortPriorityValue.21	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.21	Integer	0
iblfQoSPortPriorityValue.22	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.22	Integer	0
iblfQoSPortPriorityValue.23	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.23	Integer	0
iblfQoSPortPriorityValue.24	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.24	Integer	0
iblfQoSPortPriorityValue.25	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.25	Integer	0
iblfQoSPortPriorityValue.26	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.26	Integer	0
iblfQoSPortPriorityValue.27	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.27	Integer	0
iblfQoSPortPriorityValue.28	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.28	Integer	0
iblfQoSPortPriorityValue.29	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.29	Integer	0
iblfQoSPortPriorityValue.30	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.30	Integer	0
iblfQoSPortPriorityValue.31	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.31	Integer	0
iblfQoSPortPriorityValue.32	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.32	Integer	0
iblfQoSPortPriorityValue.33	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.33	Integer	0
iblfQoSPortPriorityValue.34	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.34	Integer	0
iblfQoSPortPriorityValue.35	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.35	Integer	0
iblfQoSPortPriorityValue.36	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.36	Integer	0
iblfQoSPortPriorityValue.37	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.37	Integer	0
iblfQoSPortPriorityValue.38	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.38	Integer	0
iblfQoSPortPriorityValue.39	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.39	Integer	0
iblfQoSPortPriorityValue.40	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.40	Integer	0
iblfQoSPortPriorityValue.41	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.41	Integer	0
iblfQoSPortPriorityValue.42	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.42	Integer	0
iblfQoSPortPriorityValue.43	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.43	Integer	0
iblfQoSPortPriorityValue.44	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.44	Integer	0
iblfQoSPortPriorityValue.45	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.45	Integer	0
iblfQoSPortPriorityValue.46	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.46	Integer	0
iblfQoSPortPriorityValue.47	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.47	Integer	0
iblfQoSPortPriorityValue.48	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.48	Integer	0
iblfQoSPortPriorityValue.49	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.49	Integer	0
iblfQoSPortPriorityValue.50	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.50	Integer	0
iblfQoSPortPriorityValue.51	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.51	Integer	0
iblfQoSPortPriorityValue.52	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.52	Integer	0
iblfQoSPortPriorityValue.53	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.53	Integer	0
iblfQoSPortPriorityValue.54	.3.6.1.4.1.26138.2.65.1.7.1.1.1.1.54	Integer	0
iblfQoSPortPriorityTrust-TrustType.1	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.2	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2	Integer	untrust (1)

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
iblfQoSPortPriorityTrust-TrustType.3	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.3	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.4	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.4	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.5	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.5	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.6	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.6	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.7	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.7	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.8	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.8	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.9	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.9	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.10	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.10	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.11	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.11	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.12	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.12	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.13	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.13	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.14	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.14	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.15	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.15	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.16	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.16	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.17	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.17	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.18	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.18	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.19	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.19	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.20	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.20	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.21	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.21	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.22	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.22	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.23	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.23	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.24	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.24	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.25	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.25	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.26	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.26	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.27	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.27	Integer	untrust (1)

Name	OID	Value Type	Value Example
iblfQoSPortPriorityTrust-TrustType.28	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.28	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.29	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.29	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.30	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.30	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.31	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.31	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.32	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.32	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.33	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.33	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.34	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.34	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.35	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.35	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.36	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.36	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.37	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.37	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.38	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.38	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.39	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.39	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.40	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.40	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.41	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.41	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.42	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.42	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.43	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.43	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.44	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.44	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.45	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.45	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.46	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.46	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.47	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.47	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.48	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.48	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.49	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.49	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.50	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.50	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.51	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.51	Integer	untrust (1)
iblfQoSPortPriorityTrust-TrustType.52	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.52	Integer	untrust (1)

Name	OID	Value Type	Value Example
iblfQoSPortPriorityTrustTrustType.53	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.53	Integer	untrust (1)
iblfQoSPortPriorityTrustTrustType.54	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.1.54	Integer	untrust (1)
iblfQoSPortPriorityTrustOvercastType.1	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.1	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.2	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.2	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.3	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.3	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.4	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.4	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.5	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.5	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.6	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.6	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.7	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.7	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.8	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.8	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.9	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.9	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.10	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.10	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.11	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.11	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.12	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.12	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.13	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.13	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.14	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.14	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.15	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.15	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.16	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.16	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.17	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.17	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.18	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.18	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.19	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.19	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.20	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.20	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.21	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.21	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.22	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.22	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.23	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.23	Integer	noOvercast (1)

Name	OID	Value Type	Value Example
iblfQoSPortPriorityTrustOvercastType.24	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.24	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.25	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.25	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.26	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.26	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.27	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.27	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.28	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.28	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.29	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.29	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.30	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.30	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.31	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.31	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.32	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.32	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.33	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.33	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.34	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.34	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.35	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.35	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.36	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.36	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.37	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.37	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.38	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.38	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.39	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.39	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.40	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.40	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.41	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.41	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.42	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.42	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.43	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.43	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.44	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.44	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.45	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.45	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.46	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.46	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.47	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.47	Integer	noOvercast (1)
iblfQoSPortPriorityTrustOvercastType.48	.1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.48	Integer	noOvercast (1)



Name	OID	Value Type	Value Example
ibIfQoSPortPriorityTrustOvercastType.49	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.49	Integer	noOvercast (1)
ibIfQoSPortPriorityTrustOvercastType.50	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.50	Integer	noOvercast (1)
ibIfQoSPortPriorityTrustOvercastType.51	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.51	Integer	noOvercast (1)
ibIfQoSPortPriorityTrustOvercastType.52	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.52	Integer	noOvercast (1)
ibIfQoSPortPriorityTrustOvercastType.53	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.53	Integer	noOvercast (1)
ibIfQoSPortPriorityTrustOvercastType.54	1.3.6.1.4.1.26138.2.65.1.7.1.2.1.2.54	Integer	noOvercast (1)
ibIfQoSPrePriMapTableExportValue.1.1.1.0	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.1.1.1.0	Integer	2
ibIfQoSPrePriMapTableExportValue.1.1.1.1	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.1.1.1.1	Integer	0
ibIfQoSPrePriMapTableExportValue.1.1.1.2	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.1.1.1.2	Integer	1
ibIfQoSPrePriMapTableExportValue.1.1.1.3	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.1.1.1.3	Integer	3
ibIfQoSPrePriMapTableExportValue.1.1.1.4	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.1.1.1.4	Integer	4
ibIfQoSPrePriMapTableExportValue.1.1.1.5	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.1.1.1.5	Integer	5
ibIfQoSPrePriMapTableExportValue.1.1.1.6	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.1.1.1.6	Integer	6
ibIfQoSPrePriMapTableExportValue.1.1.1.7	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.1.1.1.7	Integer	7
ibIfQoSPrePriMapTableExportValue.2.1.1.0	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.2.1.1.0	Integer	0
ibIfQoSPrePriMapTableExportValue.2.1.1.1	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.2.1.1.1	Integer	0
ibIfQoSPrePriMapTableExportValue.2.1.1.2	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.2.1.1.2	Integer	0
ibIfQoSPrePriMapTableExportValue.2.1.1.3	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.2.1.1.3	Integer	0
ibIfQoSPrePriMapTableExportValue.2.1.1.4	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.2.1.1.4	Integer	0
ibIfQoSPrePriMapTableExportValue.2.1.1.5	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.2.1.1.5	Integer	0
ibIfQoSPrePriMapTableExportValue.2.1.1.6	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.2.1.1.6	Integer	0
ibIfQoSPrePriMapTableExportValue.2.1.1.7	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.2.1.1.7	Integer	0
ibIfQoSPrePriMapTableExportValue.5.1.1.0	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.5.1.1.0	Integer	0
ibIfQoSPrePriMapTableExportValue.5.1.1.1	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.5.1.1.1	Integer	0
ibIfQoSPrePriMapTableExportValue.5.1.1.2	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.5.1.1.2	Integer	0

Name	OID	Value Type	Value Example
ibIfQoSPrePriMapTableExportValue.5.1.1.3	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.5.1.113	Integer	0
ibIfQoSPrePriMapTableExportValue.5.1.1.4	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.5.1.114	Integer	0
ibIfQoSPrePriMapTableExportValue.5.1.1.5	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.5.1.115	Integer	0
ibIfQoSPrePriMapTableExportValue.5.1.1.6	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.5.1.116	Integer	0
ibIfQoSPrePriMapTableExportValue.5.1.1.7	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.5.1.117	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.0	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.110	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.1	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.111	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.2	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.112	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.3	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.113	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.4	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.114	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.5	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.115	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.6	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.116	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.7	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.117	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.8	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.118	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.9	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.119	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.10	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.120	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.11	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.121	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.12	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.122	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.13	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.123	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.14	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.124	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.15	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.125	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.16	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.126	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.17	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.127	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.18	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.128	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.19	1.3.6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.129	Integer	0

Name	OID	Value Type	Value Example
ibIfQoSPrePriMapTableExportValue.6.1.1.20	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.20	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.21	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.21	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.22	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.22	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.23	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.23	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.24	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.24	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.25	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.25	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.26	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.26	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.27	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.27	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.28	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.28	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.29	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.29	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.30	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.30	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.31	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.31	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.32	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.32	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.33	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.33	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.34	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.34	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.35	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.35	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.36	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.36	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.37	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.37	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.38	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.38	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.39	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.39	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.40	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.40	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.41	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.41	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.42	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.42	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.43	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.43	Integer	0
ibIfQoSPrePriMapTableExportValue.6.1.1.44	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.1.44	Integer	0

Name	OID	Value Type	Value Example
iblfQoSPrePriMapTableExportValue.6.1.1.45	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.45	Integer	0
iblfQoSPrePriMapTableExportValue.6.1.1.46	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.46	Integer	0
iblfQoSPrePriMapTableExportValue.6.1.1.47	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.47	Integer	0
iblfQoSPrePriMapTableExportValue.6.1.1.48	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.48	Integer	0
iblfQoSPrePriMapTableExportValue.6.1.1.49	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.49	Integer	0
iblfQoSPrePriMapTableExportValue.6.1.1.50	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.50	Integer	0
iblfQoSPrePriMapTableExportValue.6.1.1.51	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.51	Integer	0
iblfQoSPrePriMapTableExportValue.6.1.1.52	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.52	Integer	0
iblfQoSPrePriMapTableExportValue.6.1.1.53	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.53	Integer	0
iblfQoSPrePriMapTableExportValue.6.1.1.54	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.54	Integer	0
iblfQoSPrePriMapTableExportValue.6.1.1.55	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.55	Integer	0
iblfQoSPrePriMapTableExportValue.6.1.1.56	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.56	Integer	0
iblfQoSPrePriMapTableExportValue.6.1.1.57	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.57	Integer	0
iblfQoSPrePriMapTableExportValue.6.1.1.58	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.58	Integer	0
iblfQoSPrePriMapTableExportValue.6.1.1.59	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.59	Integer	0
iblfQoSPrePriMapTableExportValue.6.1.1.60	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.60	Integer	0
iblfQoSPrePriMapTableExportValue.6.1.1.61	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.61	Integer	0
iblfQoSPrePriMapTableExportValue.6.1.1.62	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.62	Integer	0
iblfQoSPrePriMapTableExportValue.6.1.1.63	6.1.4.1.26138.2.65.1.9.1.4.1.5.6.1.63	Integer	0
iblfQoSPrePriMapTableExportValue.7.1.1.0	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.0	Integer	0
iblfQoSPrePriMapTableExportValue.7.1.1.1	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1	Integer	0
iblfQoSPrePriMapTableExportValue.7.1.1.2	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.2	Integer	0
iblfQoSPrePriMapTableExportValue.7.1.1.3	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.3	Integer	0
iblfQoSPrePriMapTableExportValue.7.1.1.4	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.4	Integer	0
iblfQoSPrePriMapTableExportValue.7.1.1.5	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.5	Integer	0

Name	OID	Value Type	Value Example
iblfQoSPrePriMapTableExportValue.7.1.1.6	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.6	Integer	0
iblfQoSPrePriMapTableExportValue.7.1.1.7	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.7	Integer	0
iblfQoSPrePriMapTableExportValue.7.1.1.8	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.8	Integer	1
iblfQoSPrePriMapTableExportValue.7.1.1.9	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.9	Integer	1
iblfQoSPrePriMapTableExportValue.7.1.1.10	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.10	Integer	1
iblfQoSPrePriMapTableExportValue.7.1.1.11	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.11	Integer	1
iblfQoSPrePriMapTableExportValue.7.1.1.12	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.12	Integer	1
iblfQoSPrePriMapTableExportValue.7.1.1.13	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.13	Integer	1
iblfQoSPrePriMapTableExportValue.7.1.1.14	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.14	Integer	1
iblfQoSPrePriMapTableExportValue.7.1.1.15	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.15	Integer	1
iblfQoSPrePriMapTableExportValue.7.1.1.16	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.16	Integer	2
iblfQoSPrePriMapTableExportValue.7.1.1.17	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.17	Integer	2
iblfQoSPrePriMapTableExportValue.7.1.1.18	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.18	Integer	2
iblfQoSPrePriMapTableExportValue.7.1.1.19	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.19	Integer	2
iblfQoSPrePriMapTableExportValue.7.1.1.20	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.20	Integer	2
iblfQoSPrePriMapTableExportValue.7.1.1.21	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.21	Integer	2
iblfQoSPrePriMapTableExportValue.7.1.1.22	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.22	Integer	2
iblfQoSPrePriMapTableExportValue.7.1.1.23	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.23	Integer	2
iblfQoSPrePriMapTableExportValue.7.1.1.24	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.24	Integer	3
iblfQoSPrePriMapTableExportValue.7.1.1.25	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.25	Integer	3
iblfQoSPrePriMapTableExportValue.7.1.1.26	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.26	Integer	3
iblfQoSPrePriMapTableExportValue.7.1.1.27	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.27	Integer	3
iblfQoSPrePriMapTableExportValue.7.1.1.28	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.28	Integer	3
iblfQoSPrePriMapTableExportValue.7.1.1.29	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.29	Integer	3
iblfQoSPrePriMapTableExportValue.7.1.1.30	3.6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.30	Integer	3

Name	OID	Value Type	Value Example
iblfQoSPrePriMapTableExportValue.7.1.1.31	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.31	Integer	3
iblfQoSPrePriMapTableExportValue.7.1.1.32	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.32	Integer	4
iblfQoSPrePriMapTableExportValue.7.1.1.33	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.33	Integer	4
iblfQoSPrePriMapTableExportValue.7.1.1.34	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.34	Integer	4
iblfQoSPrePriMapTableExportValue.7.1.1.35	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.35	Integer	4
iblfQoSPrePriMapTableExportValue.7.1.1.36	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.36	Integer	4
iblfQoSPrePriMapTableExportValue.7.1.1.37	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.37	Integer	4
iblfQoSPrePriMapTableExportValue.7.1.1.38	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.38	Integer	4
iblfQoSPrePriMapTableExportValue.7.1.1.39	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.39	Integer	4
iblfQoSPrePriMapTableExportValue.7.1.1.40	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.40	Integer	5
iblfQoSPrePriMapTableExportValue.7.1.1.41	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.41	Integer	5
iblfQoSPrePriMapTableExportValue.7.1.1.42	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.42	Integer	5
iblfQoSPrePriMapTableExportValue.7.1.1.43	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.43	Integer	5
iblfQoSPrePriMapTableExportValue.7.1.1.44	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.44	Integer	5
iblfQoSPrePriMapTableExportValue.7.1.1.45	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.45	Integer	5
iblfQoSPrePriMapTableExportValue.7.1.1.46	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.46	Integer	5
iblfQoSPrePriMapTableExportValue.7.1.1.47	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.47	Integer	5
iblfQoSPrePriMapTableExportValue.7.1.1.48	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.48	Integer	6
iblfQoSPrePriMapTableExportValue.7.1.1.49	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.49	Integer	6
iblfQoSPrePriMapTableExportValue.7.1.1.50	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.50	Integer	6
iblfQoSPrePriMapTableExportValue.7.1.1.51	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.51	Integer	6
iblfQoSPrePriMapTableExportValue.7.1.1.52	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.52	Integer	6
iblfQoSPrePriMapTableExportValue.7.1.1.53	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.53	Integer	6
iblfQoSPrePriMapTableExportValue.7.1.1.54	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.54	Integer	6
iblfQoSPrePriMapTableExportValue.7.1.1.55	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.1.55	Integer	6

Name	OID	Value Type	Value Example
ibIfQoSPrePriMapTableExportValue.7.1.1.56	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.56	Integer	7
ibIfQoSPrePriMapTableExportValue.7.1.1.57	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.57	Integer	7
ibIfQoSPrePriMapTableExportValue.7.1.1.58	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.58	Integer	7
ibIfQoSPrePriMapTableExportValue.7.1.1.59	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.59	Integer	7
ibIfQoSPrePriMapTableExportValue.7.1.1.60	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.60	Integer	7
ibIfQoSPrePriMapTableExportValue.7.1.1.61	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.61	Integer	7
ibIfQoSPrePriMapTableExportValue.7.1.1.62	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.62	Integer	7
ibIfQoSPrePriMapTableExportValue.7.1.1.63	6.1.4.1.26138.2.65.1.9.1.4.1.5.7.1.63	Integer	7
ibIfQoSPrePriMapTableExportValue.9.1.1.0	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.0	Integer	0
ibIfQoSPrePriMapTableExportValue.9.1.1.1	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.1	Integer	1
ibIfQoSPrePriMapTableExportValue.9.1.1.2	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.2	Integer	2
ibIfQoSPrePriMapTableExportValue.9.1.1.3	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.3	Integer	3
ibIfQoSPrePriMapTableExportValue.9.1.1.4	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.4	Integer	4
ibIfQoSPrePriMapTableExportValue.9.1.1.5	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.5	Integer	5
ibIfQoSPrePriMapTableExportValue.9.1.1.6	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.6	Integer	6
ibIfQoSPrePriMapTableExportValue.9.1.1.7	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.7	Integer	7
ibIfQoSPrePriMapTableExportValue.9.1.1.8	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.8	Integer	8
ibIfQoSPrePriMapTableExportValue.9.1.1.9	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.9	Integer	9
ibIfQoSPrePriMapTableExportValue.9.1.1.10	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.10	Integer	10
ibIfQoSPrePriMapTableExportValue.9.1.1.11	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.11	Integer	11
ibIfQoSPrePriMapTableExportValue.9.1.1.12	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.12	Integer	12
ibIfQoSPrePriMapTableExportValue.9.1.1.13	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.13	Integer	13
ibIfQoSPrePriMapTableExportValue.9.1.1.14	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.14	Integer	14
ibIfQoSPrePriMapTableExportValue.9.1.1.15	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.15	Integer	15
ibIfQoSPrePriMapTableExportValue.9.1.1.16	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.16	Integer	16



Name	OID	Value Type	Value Example
ibIfQoSPrePriMapTableExportValue.9.1.1.17	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.17	Integer	17
ibIfQoSPrePriMapTableExportValue.9.1.1.18	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.18	Integer	18
ibIfQoSPrePriMapTableExportValue.9.1.1.19	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.19	Integer	19
ibIfQoSPrePriMapTableExportValue.9.1.1.20	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.20	Integer	20
ibIfQoSPrePriMapTableExportValue.9.1.1.21	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.21	Integer	21
ibIfQoSPrePriMapTableExportValue.9.1.1.22	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.22	Integer	22
ibIfQoSPrePriMapTableExportValue.9.1.1.23	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.23	Integer	23
ibIfQoSPrePriMapTableExportValue.9.1.1.24	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.24	Integer	24
ibIfQoSPrePriMapTableExportValue.9.1.1.25	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.25	Integer	25
ibIfQoSPrePriMapTableExportValue.9.1.1.26	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.26	Integer	26
ibIfQoSPrePriMapTableExportValue.9.1.1.27	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.27	Integer	27
ibIfQoSPrePriMapTableExportValue.9.1.1.28	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.28	Integer	28
ibIfQoSPrePriMapTableExportValue.9.1.1.29	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.29	Integer	29
ibIfQoSPrePriMapTableExportValue.9.1.1.30	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.30	Integer	30
ibIfQoSPrePriMapTableExportValue.9.1.1.31	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.31	Integer	31
ibIfQoSPrePriMapTableExportValue.9.1.1.32	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.32	Integer	32
ibIfQoSPrePriMapTableExportValue.9.1.1.33	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.33	Integer	33
ibIfQoSPrePriMapTableExportValue.9.1.1.34	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.34	Integer	34
ibIfQoSPrePriMapTableExportValue.9.1.1.35	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.35	Integer	35
ibIfQoSPrePriMapTableExportValue.9.1.1.36	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.36	Integer	36
ibIfQoSPrePriMapTableExportValue.9.1.1.37	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.37	Integer	37
ibIfQoSPrePriMapTableExportValue.9.1.1.38	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.38	Integer	38
ibIfQoSPrePriMapTableExportValue.9.1.1.39	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.39	Integer	39
ibIfQoSPrePriMapTableExportValue.9.1.1.40	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.40	Integer	40
ibIfQoSPrePriMapTableExportValue.9.1.1.41	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.41	Integer	41

Name	OID	Value Type	Value Example
ibIfQoSPrePriMapTableExportValue.9.1.1.42	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.42	Integer	42
ibIfQoSPrePriMapTableExportValue.9.1.1.43	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.43	Integer	43
ibIfQoSPrePriMapTableExportValue.9.1.1.44	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.44	Integer	44
ibIfQoSPrePriMapTableExportValue.9.1.1.45	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.45	Integer	45
ibIfQoSPrePriMapTableExportValue.9.1.1.46	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.46	Integer	46
ibIfQoSPrePriMapTableExportValue.9.1.1.47	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.47	Integer	47
ibIfQoSPrePriMapTableExportValue.9.1.1.48	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.48	Integer	48
ibIfQoSPrePriMapTableExportValue.9.1.1.49	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.49	Integer	49
ibIfQoSPrePriMapTableExportValue.9.1.1.50	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.50	Integer	50
ibIfQoSPrePriMapTableExportValue.9.1.1.51	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.51	Integer	51
ibIfQoSPrePriMapTableExportValue.9.1.1.52	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.52	Integer	52
ibIfQoSPrePriMapTableExportValue.9.1.1.53	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.53	Integer	53
ibIfQoSPrePriMapTableExportValue.9.1.1.54	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.54	Integer	54
ibIfQoSPrePriMapTableExportValue.9.1.1.55	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.55	Integer	55
ibIfQoSPrePriMapTableExportValue.9.1.1.56	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.56	Integer	56
ibIfQoSPrePriMapTableExportValue.9.1.1.57	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.57	Integer	57
ibIfQoSPrePriMapTableExportValue.9.1.1.58	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.58	Integer	58
ibIfQoSPrePriMapTableExportValue.9.1.1.59	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.59	Integer	59
ibIfQoSPrePriMapTableExportValue.9.1.1.60	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.60	Integer	60
ibIfQoSPrePriMapTableExportValue.9.1.1.61	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.61	Integer	61
ibIfQoSPrePriMapTableExportValue.9.1.1.62	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.62	Integer	62
ibIfQoSPrePriMapTableExportValue.9.1.1.63	6.1.4.1.26138.2.65.1.9.1.4.1.5.9.1.63	Integer	63
ibIfQoSPrePriMapTableExportValue.12.1.1.0	6.1.4.1.26138.2.65.1.9.1.4.1.5.12.1.0	Integer	0
ibIfQoSPrePriMapTableExportValue.12.1.1.1	6.1.4.1.26138.2.65.1.9.1.4.1.5.12.1.1	Integer	1
ibIfQoSPrePriMapTableExportValue.12.1.1.2	6.1.4.1.26138.2.65.1.9.1.4.1.5.12.1.2	Integer	2

Name	OID	Value Type	Value Example
ibIfQoSPrePriMapTableExportValue.12.1.1.3	6.1.4.1.26138.2.65.1.9.1.4.1.5.12.1.3	Integer	3
ibIfQoSPrePriMapTableExportValue.12.1.1.4	6.1.4.1.26138.2.65.1.9.1.4.1.5.12.1.4	Integer	4
ibIfQoSPrePriMapTableExportValue.12.1.1.5	6.1.4.1.26138.2.65.1.9.1.4.1.5.12.1.5	Integer	5
ibIfQoSPrePriMapTableExportValue.12.1.1.6	6.1.4.1.26138.2.65.1.9.1.4.1.5.12.1.6	Integer	6
ibIfQoSPrePriMapTableExportValue.12.1.1.7	6.1.4.1.26138.2.65.1.9.1.4.1.5.12.1.7	Integer	7
ibIfQoSPrePriMapTableExportValue.30.1.1.0	6.1.4.1.26138.2.65.1.9.1.4.1.5.30.1.0	Integer	0
ibIfQoSPrePriMapTableExportValue.30.1.1.1	6.1.4.1.26138.2.65.1.9.1.4.1.5.30.1.1	Integer	1
ibIfQoSPrePriMapTableExportValue.30.1.1.2	6.1.4.1.26138.2.65.1.9.1.4.1.5.30.1.2	Integer	2
ibIfQoSPrePriMapTableExportValue.30.1.1.3	6.1.4.1.26138.2.65.1.9.1.4.1.5.30.1.3	Integer	3
ibIfQoSPrePriMapTableExportValue.30.1.1.4	6.1.4.1.26138.2.65.1.9.1.4.1.5.30.1.4	Integer	4
ibIfQoSPrePriMapTableExportValue.30.1.1.5	6.1.4.1.26138.2.65.1.9.1.4.1.5.30.1.5	Integer	5
ibIfQoSPrePriMapTableExportValue.30.1.1.6	6.1.4.1.26138.2.65.1.9.1.4.1.5.30.1.6	Integer	6
ibIfQoSPrePriMapTableExportValue.30.1.1.7	6.1.4.1.26138.2.65.1.9.1.4.1.5.30.1.7	Integer	7
ibIfQoSProcessingStatus.0	.1.3.6.1.4.1.26138.2.65.1.13.1.0	Integer	idle (1)
ibCBQoSClassifierIndexNext.0	.1.3.6.1.4.1.26138.2.65.2.1.1.1.0	Integer	100
ibCBQoSBehaviorIndexNext.0	.1.3.6.1.4.1.26138.2.65.2.1.2.1.0	Integer	100
ibCBQoSPolicyIndexNext.0	.1.3.6.1.4.1.26138.2.65.2.1.3.1.0	Integer	100
ibCBQoSApplyingStatus.0	.1.3.6.1.4.1.26138.2.65.2.1.6.1.0	Integer	idle (1)
ibIpAddrSetMask.634.1.4.10.100.65.116	.1.3.6.1.4.1.26138.2.67.1.1.1.1.4.634.1.4.10.100.65.116	IpAddress	255.255.255.0
ibIpAddrSetSourceType.634.1.4.10.100.65.116	.1.3.6.1.4.1.26138.2.67.1.1.1.1.5.634.1.4.10.100.65.116	Integer	assignedIp (1)
ibIpAddrSetCatalog.634.1.4.10.100.65.116	.1.3.6.1.4.1.26138.2.67.1.1.1.1.6.634.1.4.10.100.65.116	Integer	primary (1)
ibIpAddrSetRowStatus.634.1.4.10.100.65.116	.1.3.6.1.4.1.26138.2.67.1.1.1.1.7.634.1.4.10.100.65.116	Integer	active (1)
ibIpAddrReadMask.634.1.4.10.100.65.116	.1.3.6.1.4.1.26138.2.67.1.1.2.1.4.634.1.4.10.100.65.116	IpAddress	255.255.255.0
ibIpAddrReadSourceType.634.1.4.10.100.65.116	.1.3.6.1.4.1.26138.2.67.1.1.2.1.5.634.1.4.10.100.65.116	Integer	assignedIp (1)
ibIpAddrReadCatalog.634.1.4.10.100.65.116	.1.3.6.1.4.1.26138.2.67.1.1.2.1.6.634.1.4.10.100.65.116	Integer	primary (1)
ibIpv4AddrAddr.634	.1.3.6.1.4.1.26138.2.67.1.1.3.1.1.634	IpAddress	10.100.65.116
ibIpv4AddrMask.634	.1.3.6.1.4.1.26138.2.67.1.1.3.1.2.634	IpAddress	255.255.255.0
ibIpv4AddrRowStatus.634	.1.3.6.1.4.1.26138.2.67.1.1.3.1.3.634	Integer	active (1)
ibMGType.1	.1.3.6.1.4.1.26138.2.68.1.1.1.1.2.1	Integer	local (1)

Name	OID	Value Type	Value Example
ibMGStatus.1	.1.3.6.1.4.1.26138.2.68.1.1.1.3.1	Integer	active (1)
ibMGRowStatus.1	.1.3.6.1.4.1.26138.2.68.1.1.1.4.1	Integer	active (1)
ibMGMirrorRowStatus.1.2.3	.1.3.6.1.4.1.26138.2.68.1.2.1.1.3.1.2.3	Integer	active (1)
ibMGMonitorRowStatus.1.39	.1.3.6.1.4.1.26138.2.68.1.3.1.1.2.1.39	Integer	active (1)
ibTransceiverExtrAlarmEnable.0	.1.3.6.1.4.1.26138.2.70.2.1.0	Integer	true (1)
ibMACInformationEnabled.0	.1.3.6.1.4.1.26138.2.87.1.1.1.0	Integer	disabled (2)
ibMACInformationcSendInterval.0	.1.3.6.1.4.1.26138.2.87.1.1.2.0	Gauge	1
ibMACInformationLearntMACNum.0	.1.3.6.1.4.1.26138.2.87.1.1.3.0	Counter32	0
ibMACInformationRemovedMACNum.0	.1.3.6.1.4.1.26138.2.87.1.1.4.0	Counter32	0
ibMACInformationTrapSendNum.0	.1.3.6.1.4.1.26138.2.87.1.1.5.0	Counter32	0
ibMACInformationSyslogSendNum.0	.1.3.6.1.4.1.26138.2.87.1.1.6.0	Counter32	0
ibMACInformationCacheLen.0	.1.3.6.1.4.1.26138.2.87.1.1.7.0	Gauge	50
ibMACInfomationWorkMode.0	.1.3.6.1.4.1.26138.2.87.1.1.8.0	Integer	trap (1)
ibMACLearntEnable.1	.1.3.6.1.4.1.26138.2.87.1.2.1.1.1.1	Integer	disabled (2)
ibMACLearntEnable.2	.1.3.6.1.4.1.26138.2.87.1.2.1.1.1.2	Integer	disabled (2)
ibMACLearntEnable.3	.1.3.6.1.4.1.26138.2.87.1.2.1.1.1.3	Integer	disabled (2)
ibMACLearntEnable.4	.1.3.6.1.4.1.26138.2.87.1.2.1.1.1.4	Integer	disabled (2)
ibMACLearntEnable.5	.1.3.6.1.4.1.26138.2.87.1.2.1.1.1.5	Integer	disabled (2)
ibMACLearntEnable.6	.1.3.6.1.4.1.26138.2.87.1.2.1.1.1.6	Integer	disabled (2)
ibMACLearntEnable.7	.1.3.6.1.4.1.26138.2.87.1.2.1.1.1.7	Integer	disabled (2)
ibMACLearntEnable.8	.1.3.6.1.4.1.26138.2.87.1.2.1.1.1.8	Integer	disabled (2)
ibMACLearntEnable.9	.1.3.6.1.4.1.26138.2.87.1.2.1.1.1.9	Integer	disabled (2)
ibMACLearntEnable.10	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.10	Integer	disabled (2)
ibMACLearntEnable.11	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.11	Integer	disabled (2)
ibMACLearntEnable.12	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.12	Integer	disabled (2)
ibMACLearntEnable.13	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.13	Integer	disabled (2)
ibMACLearntEnable.14	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.14	Integer	disabled (2)
ibMACLearntEnable.15	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.15	Integer	disabled (2)
ibMACLearntEnable.16	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.16	Integer	disabled (2)
ibMACLearntEnable.17	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.17	Integer	disabled (2)
ibMACLearntEnable.18	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.18	Integer	disabled (2)
ibMACLearntEnable.19	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.19	Integer	disabled (2)
ibMACLearntEnable.20	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.20	Integer	disabled (2)
ibMACLearntEnable.21	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.21	Integer	disabled (2)
ibMACLearntEnable.22	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.22	Integer	disabled (2)
ibMACLearntEnable.23	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.23	Integer	disabled (2)
ibMACLearntEnable.24	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.24	Integer	disabled (2)
ibMACLearntEnable.25	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.25	Integer	disabled (2)
ibMACLearntEnable.26	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.26	Integer	disabled (2)

Name	OID	Value Type	Value Example
ibMACLearntEnable.27	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.27	Integer	disabled (2)
ibMACLearntEnable.28	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.28	Integer	disabled (2)
ibMACLearntEnable.29	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.29	Integer	disabled (2)
ibMACLearntEnable.30	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.30	Integer	disabled (2)
ibMACLearntEnable.31	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.31	Integer	disabled (2)
ibMACLearntEnable.32	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.32	Integer	disabled (2)
ibMACLearntEnable.33	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.33	Integer	disabled (2)
ibMACLearntEnable.34	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.34	Integer	disabled (2)
ibMACLearntEnable.35	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.35	Integer	disabled (2)
ibMACLearntEnable.36	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.36	Integer	disabled (2)
ibMACLearntEnable.37	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.37	Integer	disabled (2)
ibMACLearntEnable.38	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.38	Integer	disabled (2)
ibMACLearntEnable.39	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.39	Integer	disabled (2)
ibMACLearntEnable.40	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.40	Integer	disabled (2)
ibMACLearntEnable.41	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.41	Integer	disabled (2)
ibMACLearntEnable.42	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.42	Integer	disabled (2)
ibMACLearntEnable.43	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.43	Integer	disabled (2)
ibMACLearntEnable.44	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.44	Integer	disabled (2)
ibMACLearntEnable.45	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.45	Integer	disabled (2)
ibMACLearntEnable.46	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.46	Integer	disabled (2)
ibMACLearntEnable.47	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.47	Integer	disabled (2)
ibMACLearntEnable.48	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.48	Integer	disabled (2)
ibMACLearntEnable.49	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.49	Integer	disabled (2)
ibMACLearntEnable.50	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.50	Integer	disabled (2)
ibMACLearntEnable.51	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.51	Integer	disabled (2)
ibMACLearntEnable.52	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.52	Integer	disabled (2)
ibMACLearntEnable.53	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.53	Integer	disabled (2)
ibMACLearntEnable.54	1.3.6.1.4.1.26138.2.87.1.2.1.1.1.54	Integer	disabled (2)
ibMACRemovedEnable.1	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.1	Integer	disabled (2)
ibMACRemovedEnable.2	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.2	Integer	disabled (2)
ibMACRemovedEnable.3	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.3	Integer	disabled (2)
ibMACRemovedEnable.4	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.4	Integer	disabled (2)
ibMACRemovedEnable.5	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.5	Integer	disabled (2)
ibMACRemovedEnable.6	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.6	Integer	disabled (2)
ibMACRemovedEnable.7	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.7	Integer	disabled (2)
ibMACRemovedEnable.8	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.8	Integer	disabled (2)
ibMACRemovedEnable.9	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.9	Integer	disabled (2)
ibMACRemovedEnable.10	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.10	Integer	disabled (2)
ibMACRemovedEnable.11	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.11	Integer	disabled (2)
ibMACRemovedEnable.12	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.12	Integer	disabled (2)
ibMACRemovedEnable.13	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.13	Integer	disabled (2)
ibMACRemovedEnable.14	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.14	Integer	disabled (2)
ibMACRemovedEnable.15	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.15	Integer	disabled (2)

Name	OID	Value Type	Value Example
ibMACRemovedEnable.16	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.16	Integer	disabled (2)
ibMACRemovedEnable.17	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.17	Integer	disabled (2)
ibMACRemovedEnable.18	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.18	Integer	disabled (2)
ibMACRemovedEnable.19	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.19	Integer	disabled (2)
ibMACRemovedEnable.20	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.20	Integer	disabled (2)
ibMACRemovedEnable.21	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.21	Integer	disabled (2)
ibMACRemovedEnable.22	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.22	Integer	disabled (2)
ibMACRemovedEnable.23	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.23	Integer	disabled (2)
ibMACRemovedEnable.24	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.24	Integer	disabled (2)
ibMACRemovedEnable.25	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.25	Integer	disabled (2)
ibMACRemovedEnable.26	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.26	Integer	disabled (2)
ibMACRemovedEnable.27	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.27	Integer	disabled (2)
ibMACRemovedEnable.28	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.28	Integer	disabled (2)
ibMACRemovedEnable.29	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.29	Integer	disabled (2)
ibMACRemovedEnable.30	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.30	Integer	disabled (2)
ibMACRemovedEnable.31	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.31	Integer	disabled (2)
ibMACRemovedEnable.32	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.32	Integer	disabled (2)
ibMACRemovedEnable.33	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.33	Integer	disabled (2)
ibMACRemovedEnable.34	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.34	Integer	disabled (2)
ibMACRemovedEnable.35	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.35	Integer	disabled (2)
ibMACRemovedEnable.36	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.36	Integer	disabled (2)
ibMACRemovedEnable.37	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.37	Integer	disabled (2)
ibMACRemovedEnable.38	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.38	Integer	disabled (2)
ibMACRemovedEnable.39	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.39	Integer	disabled (2)
ibMACRemovedEnable.40	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.40	Integer	disabled (2)
ibMACRemovedEnable.41	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.41	Integer	disabled (2)
ibMACRemovedEnable.42	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.42	Integer	disabled (2)
ibMACRemovedEnable.43	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.43	Integer	disabled (2)
ibMACRemovedEnable.44	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.44	Integer	disabled (2)
ibMACRemovedEnable.45	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.45	Integer	disabled (2)
ibMACRemovedEnable.46	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.46	Integer	disabled (2)
ibMACRemovedEnable.47	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.47	Integer	disabled (2)
ibMACRemovedEnable.48	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.48	Integer	disabled (2)
ibMACRemovedEnable.49	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.49	Integer	disabled (2)
ibMACRemovedEnable.50	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.50	Integer	disabled (2)
ibMACRemovedEnable.51	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.51	Integer	disabled (2)
ibMACRemovedEnable.52	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.52	Integer	disabled (2)
ibMACRemovedEnable.53	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.53	Integer	disabled (2)
ibMACRemovedEnable.54	1.3.6.1.4.1.26138.2.87.1.2.1.1.2.54	Integer	disabled (2)
ibStackMaxMember.0	.1.3.6.1.4.1.26138.2.91.1.1.0	Integer	10
ibStackMemberNum.0	.1.3.6.1.4.1.26138.2.91.1.2.0	Integer	1
ibStackMaxConfigPriority.0	.1.3.6.1.4.1.26138.2.91.1.3.0	Integer	32
ibStackAutoUpdate.0	.1.3.6.1.4.1.26138.2.91.1.4.0	Integer	enabled (2)

Name	OID	Value Type	Value Example
ibStackMacPersistence.0	.1.3.6.1.4.1.26138.2.91.1.5.0	Integer	persistForSixMin (2)
ibStackLinkDelayInterval.0	.1.3.6.1.4.1.26138.2.91.1.6.0	Integer	4000
ibStackTopology.0	.1.3.6.1.4.1.26138.2.91.1.7.0	Integer	chainConn (1)
ibStackDomainId.0	.1.3.6.1.4.1.26138.2.91.1.8.0	Gauge	0
ibStackPortConfigActivate.0	.1.3.6.1.4.1.26138.2.91.1.9.0	Integer	none (1)
ibStackMemberID.2	.1.3.6.1.4.1.26138.2.91.2.1.1.2	Integer	1
ibStackConfigMemberID.2	.1.3.6.1.4.1.26138.2.91.2.1.2.2	Integer	1
ibStackPriority.2	.1.3.6.1.4.1.26138.2.91.2.1.3.2	Integer	1
ibStackPortNum.2	.1.3.6.1.4.1.26138.2.91.2.1.4.2	Integer	0
ibStackPortMaxNum.2	.1.3.6.1.4.1.26138.2.91.2.1.5.2	Integer	2
ibStackBoardRole.212	.1.3.6.1.4.1.26138.2.91.3.1.1.212	Integer	master (2)
ibStackBoardBelongtoMember.212	.1.3.6.1.4.1.26138.2.91.3.1.2.212	Integer	1
ibStackPortEnable.1.1	.1.3.6.1.4.1.26138.2.91.4.1.2.1.1	Integer	disabled (1)
ibStackPortEnable.1.2	.1.3.6.1.4.1.26138.2.91.4.1.2.1.2	Integer	disabled (1)
ibStackPortStatus.1.1	.1.3.6.1.4.1.26138.2.91.4.1.3.1.1	Integer	disabled (4)
ibStackPortStatus.1.2	.1.3.6.1.4.1.26138.2.91.4.1.3.1.2	Integer	disabled (4)
ibStackNeighbor.1.1	.1.3.6.1.4.1.26138.2.91.4.1.4.1.1	Integer	0
ibStackNeighbor.1.2	.1.3.6.1.4.1.26138.2.91.4.1.4.1.2	Integer	0
ibStackPortForwardingPath.1.1	.1.3.6.1.4.1.26138.2.91.4.1.5.1.1	OctetString	
ibStackPortForwardingPath.1.2	.1.3.6.1.4.1.26138.2.91.4.1.5.1.2	OctetString	
ibStackBelongtoPort.520	.1.3.6.1.4.1.26138.2.91.5.1.1.520	Integer	0
ibStackBelongtoPort.521	.1.3.6.1.4.1.26138.2.91.5.1.1.521	Integer	0
ibStackBelongtoPort.522	.1.3.6.1.4.1.26138.2.91.5.1.1.522	Integer	0
ibStackBelongtoPort.523	.1.3.6.1.4.1.26138.2.91.5.1.1.523	Integer	0
ibStackBelongtoPort.524	.1.3.6.1.4.1.26138.2.91.5.1.1.524	Integer	0
ibStackBelongtoPort.525	.1.3.6.1.4.1.26138.2.91.5.1.1.525	Integer	0
ibDnsStaticSrvIpPriority.1.4.1.1.1.1	.1.3.6.1.4.1.26138.2.97.1.1.1.3.1.4.1.1.1	Integer	1
ibDnsStaticSrvIpPriority.1.4.8.8.8.8	.1.3.6.1.4.1.26138.2.97.1.1.1.3.1.4.8.8.8	Integer	0
ibDnsStaticSrvIpRowStatus.1.4.1.1.1.1	.1.3.6.1.4.1.26138.2.97.1.1.1.4.1.4.1.1.1	Integer	active (1)
ibDnsStaticSrvIpRowStatus.1.4.8.8.8.8	.1.3.6.1.4.1.26138.2.97.1.1.1.4.1.4.8.8.8	Integer	active (1)
ibSnmpExtMaxContextNum.0	.1.3.6.1.4.1.26138.2.104.1.4.0	Integer	20
ibSnmpExtVersion.0	.1.3.6.1.4.1.26138.2.104.1.5.0	OctetString	{snmpV1, snmpV2c, snmpV3}
ibSnmpExtTrapSource.0	.1.3.6.1.4.1.26138.2.104.1.6.0	OctetString	
ibSnmpExtInformSource.0	.1.3.6.1.4.1.26138.2.104.1.7.0	OctetString	
ibSnmpExtCommunityName.102	2.105.130.126.061108.98.104.908.96.49.50.51	Integer	intelbras123
ibSnmpExtCommunityName.202	2.105.130.126.061108.98.104.908.96.49.50.51	Integer	intelbras123
ibSnmpExtCommunityName.302	2.1105.1102.165.010.08.88011408.96.49.50.51	Integer	0
ibSnmpExtCommunityName.402	2.1105.1202.165.010.08.88011408.96.49.50.51	Integer	0
ibSnmpExtCommunityName.502	2.112105.2105.160.010.08.88011408.96.49.50.51	Integer	0



Name	OID	Value Type	Value Example
ibSnmplibCommunityName.0	.1.3.6.1.4.1.26138.2.119.1.1.1.0	Gauge	0
ibICMaxLogbufferSize.0	.1.3.6.1.4.1.26138.2.119.1.1.1.0	Gauge	1024
ibICLogbufferSize.0	.1.3.6.1.4.1.26138.2.119.1.1.2.0	Gauge	512
ibICLogbufferCurrentMessages.0	.1.3.6.1.4.1.26138.2.119.1.1.3.0	Gauge	512
ibICLogbufferOverwrittenMessages.0	.1.3.6.1.4.1.26138.2.119.1.1.4.0	Counter32	178
ibICLogbufferDroppedMessages.0	.1.3.6.1.4.1.26138.2.119.1.1.5.0	Counter32	0
ibICLogbufferContDescription.1	.1.3.6.1.4.1.26138.2.119.1.2.1.2.1	OctetString	%Aug 30 17:54:33:354 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.2	.1.3.6.1.4.1.26138.2.119.1.2.1.2.2	OctetString	%Aug 30 17:54:33:443 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.3	.1.3.6.1.4.1.26138.2.119.1.2.1.2.3	OctetString	%Aug 30 17:54:36:349 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.4	.1.3.6.1.4.1.26138.2.119.1.2.1.2.4	OctetString	%Aug 30 17:54:36:880 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.5	.1.3.6.1.4.1.26138.2.119.1.2.1.2.5	OctetString	%Aug 30 17:54:39:363 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.6	.1.3.6.1.4.1.26138.2.119.1.2.1.2.6	OctetString	%Aug 30 17:54:39:628 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.7	.1.3.6.1.4.1.26138.2.119.1.2.1.2.7	OctetString	%Aug 30 17:54:42:349 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.8	.1.3.6.1.4.1.26138.2.119.1.2.1.2.8	OctetString	%Aug 30 17:54:43:632 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.9	.1.3.6.1.4.1.26138.2.119.1.2.1.2.9	OctetString	%Aug 30 17:54:46:350 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.

Name	OID	Value Type	Value Example
ibICLogbufferContDescription.10	.1.3.6.1.4.1.26138.2.119.1.2.1.2.10	OctetString	%Aug 30 17:54:47:670 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.11	.1.3.6.1.4.1.26138.2.119.1.2.1.2.11	OctetString	%Aug 30 17:54:50:350 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.12	.1.3.6.1.4.1.26138.2.119.1.2.1.2.12	OctetString	%Aug 30 17:54:55:909 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.13	.1.3.6.1.4.1.26138.2.119.1.2.1.2.13	OctetString	%Aug 30 17:54:58:350 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.14	.1.3.6.1.4.1.26138.2.119.1.2.1.2.14	OctetString	%Aug 30 17:54:58:631 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.15	.1.3.6.1.4.1.26138.2.119.1.2.1.2.15	OctetString	%Aug 30 17:55:01:371 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.16	.1.3.6.1.4.1.26138.2.119.1.2.1.2.16	OctetString	%Aug 30 17:55:02:630 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.17	.1.3.6.1.4.1.26138.2.119.1.2.1.2.17	OctetString	%Aug 30 17:55:05:351 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.18	.1.3.6.1.4.1.26138.2.119.1.2.1.2.18	OctetString	%Aug 30 17:55:06:311 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.19	.1.3.6.1.4.1.26138.2.119.1.2.1.2.19	OctetString	%Aug 30 17:55:08:350 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.20	.1.3.6.1.4.1.26138.2.119.1.2.1.2.20	OctetString	%Aug 30 17:55:08:628 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.21	.1.3.6.1.4.1.26138.2.119.1.2.1.2.21	OctetString	%Aug 30 17:55:11:350 2024 SC 3570-48GP-6X STP/6/STP_-

Name	OID	Value Type	Value Example
			NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.22	.1.3.6.1.4.1.26138.2.119.1.2.1.2.22	OctetString	%Aug 30 17:55:12:670 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.23	.1.3.6.1.4.1.26138.2.119.1.2.1.2.23	OctetString	%Aug 30 17:55:15:352 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.24	.1.3.6.1.4.1.26138.2.119.1.2.1.2.24	OctetString	%Aug 30 17:55:15:630 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.25	.1.3.6.1.4.1.26138.2.119.1.2.1.2.25	OctetString	%Aug 30 17:55:18:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.26	.1.3.6.1.4.1.26138.2.119.1.2.1.2.26	OctetString	%Aug 30 17:55:19:703 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.27	.1.3.6.1.4.1.26138.2.119.1.2.1.2.27	OctetString	%Aug 30 17:55:22:365 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.28	.1.3.6.1.4.1.26138.2.119.1.2.1.2.28	OctetString	%Aug 30 17:55:23:639 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.29	.1.3.6.1.4.1.26138.2.119.1.2.1.2.29	OctetString	%Aug 30 17:55:26:353 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.30	.1.3.6.1.4.1.26138.2.119.1.2.1.2.30	OctetString	%Aug 30 17:55:27:686 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.31	.1.3.6.1.4.1.26138.2.119.1.2.1.2.31	OctetString	%Aug 30 17:55:30:352 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.32	.1.3.6.1.4.1.26138.2.119.1.2.1.2.32	OctetString	%Aug 30 17:55:31:490 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port

Name	OID	Value Type	Value Example
			GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.33	.1.3.6.1.4.1.26138.2.119.1.2.1.2.33	OctetString	%Aug 30 17:55:34:350 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.34	.1.3.6.1.4.1.26138.2.119.1.2.1.2.34	OctetString	%Aug 30 17:55:34:443 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.35	.1.3.6.1.4.1.26138.2.119.1.2.1.2.35	OctetString	%Aug 30 17:55:37:351 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.36	.1.3.6.1.4.1.26138.2.119.1.2.1.2.36	OctetString	%Aug 30 17:55:37:776 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.37	.1.3.6.1.4.1.26138.2.119.1.2.1.2.37	OctetString	%Aug 30 17:55:40:365 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.38	.1.3.6.1.4.1.26138.2.119.1.2.1.2.38	OctetString	%Aug 30 17:55:40:657 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.39	.1.3.6.1.4.1.26138.2.119.1.2.1.2.39	OctetString	%Aug 30 17:55:43:350 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.40	.1.3.6.1.4.1.26138.2.119.1.2.1.2.40	OctetString	%Aug 30 17:55:44:075 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.41	.1.3.6.1.4.1.26138.2.119.1.2.1.2.41	OctetString	%Aug 30 17:55:46:370 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.42	.1.3.6.1.4.1.26138.2.119.1.2.1.2.42	OctetString	%Aug 30 17:55:46:638 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.43	.1.3.6.1.4.1.26138.2.119.1.2.1.2.43	OctetString	%Aug 30 17:55:49:351 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.

Name	OID	Value Type	Value Example
ibICLogbufferContDescription.44	.1.3.6.1.4.1.26138.2.119.1.2.1.2.44	OctetString	%Aug 30 17:55:50:415 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.45	.1.3.6.1.4.1.26138.2.119.1.2.1.2.45	OctetString	%Aug 30 17:55:53:362 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.46	.1.3.6.1.4.1.26138.2.119.1.2.1.2.46	OctetString	%Aug 30 17:55:55:522 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.47	.1.3.6.1.4.1.26138.2.119.1.2.1.2.47	OctetString	%Aug 30 17:55:58:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.48	.1.3.6.1.4.1.26138.2.119.1.2.1.2.48	OctetString	%Aug 30 17:55:59:475 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.49	.1.3.6.1.4.1.26138.2.119.1.2.1.2.49	OctetString	%Aug 30 17:56:02:362 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.50	.1.3.6.1.4.1.26138.2.119.1.2.1.2.50	OctetString	%Aug 30 17:56:03:546 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.51	.1.3.6.1.4.1.26138.2.119.1.2.1.2.51	OctetString	%Aug 30 17:56:06:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.52	.1.3.6.1.4.1.26138.2.119.1.2.1.2.52	OctetString	%Aug 30 17:56:07:501 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.53	.1.3.6.1.4.1.26138.2.119.1.2.1.2.53	OctetString	%Aug 30 17:56:10:351 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.54	.1.3.6.1.4.1.26138.2.119.1.2.1.2.54	OctetString	%Aug 30 17:56:11:515 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.55	.1.3.6.1.4.1.26138.2.119.1.2.1.2.55	OctetString	%Aug 30 17:56:14:351 2024 SC 3570-48GP-6X STP/6/STP_-

Name	OID	Value Type	Value Example
			NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.56	.1.3.6.1.4.1.26138.2.119.1.2.1.2.56	OctetString	%Aug 30 17:56:15:638 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.57	.1.3.6.1.4.1.26138.2.119.1.2.1.2.57	OctetString	%Aug 30 17:56:18:351 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.58	.1.3.6.1.4.1.26138.2.119.1.2.1.2.58	OctetString	%Aug 30 17:56:18:446 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.59	.1.3.6.1.4.1.26138.2.119.1.2.1.2.59	OctetString	%Aug 30 17:56:21:351 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.60	.1.3.6.1.4.1.26138.2.119.1.2.1.2.60	OctetString	%Aug 30 17:56:22:501 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.61	.1.3.6.1.4.1.26138.2.119.1.2.1.2.61	OctetString	%Aug 30 17:56:25:393 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.62	.1.3.6.1.4.1.26138.2.119.1.2.1.2.62	OctetString	%Aug 30 17:56:26:102 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.63	.1.3.6.1.4.1.26138.2.119.1.2.1.2.63	OctetString	%Aug 30 17:56:28:352 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.64	.1.3.6.1.4.1.26138.2.119.1.2.1.2.64	OctetString	%Aug 30 17:56:28:668 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.65	.1.3.6.1.4.1.26138.2.119.1.2.1.2.65	OctetString	%Aug 30 17:56:31:351 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.66	.1.3.6.1.4.1.26138.2.119.1.2.1.2.66	OctetString	%Aug 30 17:56:32:658 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port

Name	OID	Value Type	Value Example
			GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.67	.1.3.6.1.4.1.26138.2.119.1.2.1.2.67	OctetString	%Aug 30 17:56:35:364 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.68	.1.3.6.1.4.1.26138.2.119.1.2.1.2.68	OctetString	%Aug 30 17:56:36:698 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.69	.1.3.6.1.4.1.26138.2.119.1.2.1.2.69	OctetString	%Aug 30 17:56:39:353 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.70	.1.3.6.1.4.1.26138.2.119.1.2.1.2.70	OctetString	%Aug 30 17:56:39:673 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.71	.1.3.6.1.4.1.26138.2.119.1.2.1.2.71	OctetString	%Aug 30 17:56:42:351 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.72	.1.3.6.1.4.1.26138.2.119.1.2.1.2.72	OctetString	%Aug 30 17:56:43:632 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.73	.1.3.6.1.4.1.26138.2.119.1.2.1.2.73	OctetString	%Aug 30 17:56:46:352 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.74	.1.3.6.1.4.1.26138.2.119.1.2.1.2.74	OctetString	%Aug 30 17:56:47:638 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.75	.1.3.6.1.4.1.26138.2.119.1.2.1.2.75	OctetString	%Aug 30 17:56:50:410 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.76	.1.3.6.1.4.1.26138.2.119.1.2.1.2.76	OctetString	%Aug 30 17:56:53:389 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.77	.1.3.6.1.4.1.26138.2.119.1.2.1.2.77	OctetString	%Aug 30 17:56:56:352 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.



Name	OID	Value Type	Value Example
ibICLogbufferContDescription.78	.1.3.6.1.4.1.26138.2.119.1.2.1.2.78	OctetString	%Aug 30 17:56:58:505 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.79	.1.3.6.1.4.1.26138.2.119.1.2.1.2.79	OctetString	%Aug 30 17:57:01:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.80	.1.3.6.1.4.1.26138.2.119.1.2.1.2.80	OctetString	%Aug 30 17:57:02:486 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.81	.1.3.6.1.4.1.26138.2.119.1.2.1.2.81	OctetString	%Aug 30 17:57:05:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.82	.1.3.6.1.4.1.26138.2.119.1.2.1.2.82	OctetString	%Aug 30 17:57:06:513 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.83	.1.3.6.1.4.1.26138.2.119.1.2.1.2.83	OctetString	%Aug 30 17:57:09:354 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.84	.1.3.6.1.4.1.26138.2.119.1.2.1.2.84	OctetString	%Aug 30 17:57:10:503 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.85	.1.3.6.1.4.1.26138.2.119.1.2.1.2.85	OctetString	%Aug 30 17:57:13:390 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.86	.1.3.6.1.4.1.26138.2.119.1.2.1.2.86	OctetString	%Aug 30 17:57:16:477 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.87	.1.3.6.1.4.1.26138.2.119.1.2.1.2.87	OctetString	%Aug 30 17:57:19:352 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.88	.1.3.6.1.4.1.26138.2.119.1.2.1.2.88	OctetString	%Aug 30 17:57:19:457 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.89	.1.3.6.1.4.1.26138.2.119.1.2.1.2.89	OctetString	%Aug 30 17:57:22:352 2024 SC 3570-48GP-6X STP/6/STP_-

Name	OID	Value Type	Value Example
			NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.90	.1.3.6.1.4.1.26138.2.119.1.2.1.2.90	OctetString	%Aug 30 17:57:22:784 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.91	.1.3.6.1.4.1.26138.2.119.1.2.1.2.91	OctetString	%Aug 30 17:57:25:352 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.92	.1.3.6.1.4.1.26138.2.119.1.2.1.2.92	OctetString	%Aug 30 17:57:25:658 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.93	.1.3.6.1.4.1.26138.2.119.1.2.1.2.93	OctetString	%Aug 30 17:57:28:371 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.94	.1.3.6.1.4.1.26138.2.119.1.2.1.2.94	OctetString	%Aug 30 17:57:29:630 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.95	.1.3.6.1.4.1.26138.2.119.1.2.1.2.95	OctetString	%Aug 30 17:57:32:356 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.96	.1.3.6.1.4.1.26138.2.119.1.2.1.2.96	OctetString	%Aug 30 17:57:33:632 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.97	.1.3.6.1.4.1.26138.2.119.1.2.1.2.97	OctetString	%Aug 30 17:57:36:352 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.98	.1.3.6.1.4.1.26138.2.119.1.2.1.2.98	OctetString	%Aug 30 17:57:39:635 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.99	.1.3.6.1.4.1.26138.2.119.1.2.1.2.99	OctetString	%Aug 30 17:57:42:353 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.100	.1.3.6.1.4.1.26138.2.119.1.2.1.2.100	OctetString	%Aug 30 17:57:42:440 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port

Name	OID	Value Type	Value Example
			GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.101	1.3.6.1.4.1.26138.2.119.1.2.1.2.101	OctetString	%Aug 30 17:57:45:375 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.102	1.3.6.1.4.1.26138.2.119.1.2.1.2.102	OctetString	%Aug 30 17:57:45:911 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.103	1.3.6.1.4.1.26138.2.119.1.2.1.2.103	OctetString	%Aug 30 17:57:48:365 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.104	1.3.6.1.4.1.26138.2.119.1.2.1.2.104	OctetString	%Aug 30 17:57:48:633 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.105	1.3.6.1.4.1.26138.2.119.1.2.1.2.105	OctetString	%Aug 30 17:57:51:353 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.106	1.3.6.1.4.1.26138.2.119.1.2.1.2.106	OctetString	%Aug 30 17:57:52:651 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.107	1.3.6.1.4.1.26138.2.119.1.2.1.2.107	OctetString	%Aug 30 17:57:55:354 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.108	1.3.6.1.4.1.26138.2.119.1.2.1.2.108	OctetString	%Aug 30 17:57:56:454 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.109	1.3.6.1.4.1.26138.2.119.1.2.1.2.109	OctetString	%Aug 30 17:57:59:363 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.110	1.3.6.1.4.1.26138.2.119.1.2.1.2.110	OctetString	%Aug 30 17:58:01:439 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.111	1.3.6.1.4.1.26138.2.119.1.2.1.2.111	OctetString	%Aug 30 17:58:04:355 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.

Name	OID	Value Type	Value Example
ibICLogbufferContDescription.112	1.3.6.1.4.1.26138.2.119.1.2.1.2.112	OctetString	%Aug 30 17:58:05:447 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.113	1.3.6.1.4.1.26138.2.119.1.2.1.2.113	OctetString	%Aug 30 17:58:08:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.114	1.3.6.1.4.1.26138.2.119.1.2.1.2.114	OctetString	%Aug 30 17:58:09:449 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.115	1.3.6.1.4.1.26138.2.119.1.2.1.2.115	OctetString	%Aug 30 17:58:12:353 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.116	1.3.6.1.4.1.26138.2.119.1.2.1.2.116	OctetString	%Aug 30 17:58:13:190 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.117	1.3.6.1.4.1.26138.2.119.1.2.1.2.117	OctetString	%Aug 30 17:58:15:376 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.118	1.3.6.1.4.1.26138.2.119.1.2.1.2.118	OctetString	%Aug 30 17:58:15:634 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.119	1.3.6.1.4.1.26138.2.119.1.2.1.2.119	OctetString	%Aug 30 17:58:18:354 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.120	1.3.6.1.4.1.26138.2.119.1.2.1.2.120	OctetString	%Aug 30 17:58:19:536 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.121	1.3.6.1.4.1.26138.2.119.1.2.1.2.121	OctetString	%Aug 30 17:58:22:380 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.122	1.3.6.1.4.1.26138.2.119.1.2.1.2.122	OctetString	%Aug 30 17:58:22:442 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.123	1.3.6.1.4.1.26138.2.119.1.2.1.2.123	OctetString	%Aug 30 17:58:25:381 2024 SC 3570-48GP-6X STP/6/STP_-

Name	OID	Value Type	Value Example
			NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.124	1.3.6.1.4.1.26138.2.119.1.2.1.2.124	OctetString	%Aug 30 17:58:26:499 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.125	1.3.6.1.4.1.26138.2.119.1.2.1.2.125	OctetString	%Aug 30 17:58:29:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.126	1.3.6.1.4.1.26138.2.119.1.2.1.2.126	OctetString	%Aug 30 17:58:30:483 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.127	1.3.6.1.4.1.26138.2.119.1.2.1.2.127	OctetString	%Aug 30 17:58:33:374 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.128	1.3.6.1.4.1.26138.2.119.1.2.1.2.128	OctetString	%Aug 30 17:58:36:286 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.129	1.3.6.1.4.1.26138.2.119.1.2.1.2.129	OctetString	%Aug 30 17:58:38:354 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.130	1.3.6.1.4.1.26138.2.119.1.2.1.2.130	OctetString	%Aug 30 17:58:38:644 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.131	1.3.6.1.4.1.26138.2.119.1.2.1.2.131	OctetString	%Aug 30 17:58:41:354 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.132	1.3.6.1.4.1.26138.2.119.1.2.1.2.132	OctetString	%Aug 30 17:58:42:682 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.133	1.3.6.1.4.1.26138.2.119.1.2.1.2.133	OctetString	%Aug 30 17:58:45:372 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.134	1.3.6.1.4.1.26138.2.119.1.2.1.2.134	OctetString	%Aug 30 17:58:45:676 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port

Name	OID	Value Type	Value Example
			GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.135	1.3.6.1.4.1.26138.2.119.1.2.1.2.135	OctetString	%Aug 30 17:58:48:354 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.136	1.3.6.1.4.1.26138.2.119.1.2.1.2.136	OctetString	%Aug 30 17:58:49:665 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.137	1.3.6.1.4.1.26138.2.119.1.2.1.2.137	OctetString	%Aug 30 17:58:52:354 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.138	1.3.6.1.4.1.26138.2.119.1.2.1.2.138	OctetString	%Aug 30 17:58:53:666 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.139	1.3.6.1.4.1.26138.2.119.1.2.1.2.139	OctetString	%Aug 30 17:58:56:354 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.140	1.3.6.1.4.1.26138.2.119.1.2.1.2.140	OctetString	%Aug 30 17:58:57:679 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.141	1.3.6.1.4.1.26138.2.119.1.2.1.2.141	OctetString	%Aug 30 17:59:00:396 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.142	1.3.6.1.4.1.26138.2.119.1.2.1.2.142	OctetString	%Aug 30 17:59:01:632 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.143	1.3.6.1.4.1.26138.2.119.1.2.1.2.143	OctetString	%Aug 30 17:59:04:372 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.144	1.3.6.1.4.1.26138.2.119.1.2.1.2.144	OctetString	%Aug 30 17:59:05:634 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.145	1.3.6.1.4.1.26138.2.119.1.2.1.2.145	OctetString	%Aug 30 17:59:08:354 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.

Name	OID	Value Type	Value Example
ibICLogbufferContDescription.146	1.3.6.1.4.1.26138.2.119.1.2.1.2.146	OctetString	%Aug 30 17:59:08:657 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.147	1.3.6.1.4.1.26138.2.119.1.2.1.2.147	OctetString	%Aug 30 17:59:11:356 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.148	1.3.6.1.4.1.26138.2.119.1.2.1.2.148	OctetString	%Aug 30 17:59:12:651 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.149	1.3.6.1.4.1.26138.2.119.1.2.1.2.149	OctetString	%Aug 30 17:59:15:364 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.150	1.3.6.1.4.1.26138.2.119.1.2.1.2.150	OctetString	%Aug 30 17:59:16:730 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.151	1.3.6.1.4.1.26138.2.119.1.2.1.2.151	OctetString	%Aug 30 17:59:19:366 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.152	1.3.6.1.4.1.26138.2.119.1.2.1.2.152	OctetString	%Aug 30 17:59:20:688 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.153	1.3.6.1.4.1.26138.2.119.1.2.1.2.153	OctetString	%Aug 30 17:59:23:372 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.154	1.3.6.1.4.1.26138.2.119.1.2.1.2.154	OctetString	%Aug 30 17:59:24:670 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.155	1.3.6.1.4.1.26138.2.119.1.2.1.2.155	OctetString	%Aug 30 17:59:27:366 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.156	1.3.6.1.4.1.26138.2.119.1.2.1.2.156	OctetString	%Aug 30 17:59:27:454 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.157	1.3.6.1.4.1.26138.2.119.1.2.1.2.157	OctetString	%Aug 30 17:59:30:356 2024 SC 3570-48GP-6X STP/6/STP_-



Name	OID	Value Type	Value Example
			NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.158	1.3.6.1.4.1.26138.2.119.1.2.1.2.158	OctetString	%Aug 30 17:59:31:528 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.159	1.3.6.1.4.1.26138.2.119.1.2.1.2.159	OctetString	%Aug 30 17:59:34:375 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.160	1.3.6.1.4.1.26138.2.119.1.2.1.2.160	OctetString	%Aug 30 17:59:37:246 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.161	1.3.6.1.4.1.26138.2.119.1.2.1.2.161	OctetString	%Aug 30 17:59:39:354 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.162	1.3.6.1.4.1.26138.2.119.1.2.1.2.162	OctetString	%Aug 30 17:59:39:635 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.163	1.3.6.1.4.1.26138.2.119.1.2.1.2.163	OctetString	%Aug 30 17:59:42:358 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.164	1.3.6.1.4.1.26138.2.119.1.2.1.2.164	OctetString	%Aug 30 17:59:43:643 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.165	1.3.6.1.4.1.26138.2.119.1.2.1.2.165	OctetString	%Aug 30 17:59:46:359 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.166	1.3.6.1.4.1.26138.2.119.1.2.1.2.166	OctetString	%Aug 30 17:59:46:484 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.167	1.3.6.1.4.1.26138.2.119.1.2.1.2.167	OctetString	%Aug 30 17:59:49:355 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.168	1.3.6.1.4.1.26138.2.119.1.2.1.2.168	OctetString	%Aug 30 17:59:50:491 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port

Name	OID	Value Type	Value Example
			GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.169	1.3.6.1.4.1.26138.2.119.1.2.1.2.169	OctetString	%Aug 30 17:59:53:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.170	1.3.6.1.4.1.26138.2.119.1.2.1.2.170	OctetString	%Aug 30 17:59:54:455 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.171	1.3.6.1.4.1.26138.2.119.1.2.1.2.171	OctetString	%Aug 30 17:59:57:355 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.172	1.3.6.1.4.1.26138.2.119.1.2.1.2.172	OctetString	%Aug 30 17:59:58:492 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.173	1.3.6.1.4.1.26138.2.119.1.2.1.2.173	OctetString	%Aug 30 18:00:01:357 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.174	1.3.6.1.4.1.26138.2.119.1.2.1.2.174	OctetString	%Aug 30 18:00:02:445 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.175	1.3.6.1.4.1.26138.2.119.1.2.1.2.175	OctetString	%Aug 30 18:00:05:356 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.176	1.3.6.1.4.1.26138.2.119.1.2.1.2.176	OctetString	%Aug 30 18:00:07:447 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.177	1.3.6.1.4.1.26138.2.119.1.2.1.2.177	OctetString	%Aug 30 18:00:10:432 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.178	1.3.6.1.4.1.26138.2.119.1.2.1.2.178	OctetString	%Aug 30 18:00:10:805 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.179	1.3.6.1.4.1.26138.2.119.1.2.1.2.179	OctetString	%Aug 30 18:00:13:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.

Name	OID	Value Type	Value Example
ibICLogbufferContDescription.180	1.3.6.1.4.1.26138.2.119.1.2.1.2.180	OctetString	%Aug 30 18:00:13:637 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.181	1.3.6.1.4.1.26138.2.119.1.2.1.2.181	OctetString	%Aug 30 18:00:16:374 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.182	1.3.6.1.4.1.26138.2.119.1.2.1.2.182	OctetString	%Aug 30 18:00:17:656 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.183	1.3.6.1.4.1.26138.2.119.1.2.1.2.183	OctetString	%Aug 30 18:00:20:362 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.184	1.3.6.1.4.1.26138.2.119.1.2.1.2.184	OctetString	%Aug 30 18:00:21:327 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.185	1.3.6.1.4.1.26138.2.119.1.2.1.2.185	OctetString	%Aug 30 18:00:23:355 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.186	1.3.6.1.4.1.26138.2.119.1.2.1.2.186	OctetString	%Aug 30 18:00:23:638 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.187	1.3.6.1.4.1.26138.2.119.1.2.1.2.187	OctetString	%Aug 30 18:00:26:355 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.188	1.3.6.1.4.1.26138.2.119.1.2.1.2.188	OctetString	%Aug 30 18:00:27:590 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.189	1.3.6.1.4.1.26138.2.119.1.2.1.2.189	OctetString	%Aug 30 18:00:30:357 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.190	1.3.6.1.4.1.26138.2.119.1.2.1.2.190	OctetString	%Aug 30 18:00:30:474 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.191	1.3.6.1.4.1.26138.2.119.1.2.1.2.191	OctetString	%Aug 30 18:00:33:357 2024 SC 3570-48GP-6X STP/6/STP_-

Name	OID	Value Type	Value Example
			NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.192	1.3.6.1.4.1.26138.2.119.1.2.1.2.192	OctetString	%Aug 30 18:00:33:958 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.193	1.3.6.1.4.1.26138.2.119.1.2.1.2.193	OctetString	%Aug 30 18:00:36:357 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.194	1.3.6.1.4.1.26138.2.119.1.2.1.2.194	OctetString	%Aug 30 18:00:36:642 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.195	1.3.6.1.4.1.26138.2.119.1.2.1.2.195	OctetString	%Aug 30 18:00:39:365 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.196	1.3.6.1.4.1.26138.2.119.1.2.1.2.196	OctetString	%Aug 30 18:00:40:671 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.197	1.3.6.1.4.1.26138.2.119.1.2.1.2.197	OctetString	%Aug 30 18:00:43:358 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.198	1.3.6.1.4.1.26138.2.119.1.2.1.2.198	OctetString	%Aug 30 18:00:44:435 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.199	1.3.6.1.4.1.26138.2.119.1.2.1.2.199	OctetString	%Aug 30 18:00:47:356 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.200	1.3.6.1.4.1.26138.2.119.1.2.1.2.200	OctetString	%Aug 30 18:00:49:462 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.201	1.3.6.1.4.1.26138.2.119.1.2.1.2.201	OctetString	%Aug 30 18:00:52:359 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.202	1.3.6.1.4.1.26138.2.119.1.2.1.2.202	OctetString	%Aug 30 18:00:53:519 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port

Name	OID	Value Type	Value Example
			GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.203	1.3.6.1.4.1.26138.2.119.1.2.1.2.203	OctetString	%Aug 30 18:00:56:359 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.204	1.3.6.1.4.1.26138.2.119.1.2.1.2.204	OctetString	%Aug 30 18:00:57:521 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.205	1.3.6.1.4.1.26138.2.119.1.2.1.2.205	OctetString	%Aug 30 18:01:00:357 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.206	1.3.6.1.4.1.26138.2.119.1.2.1.2.206	OctetString	%Aug 30 18:01:01:252 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.207	1.3.6.1.4.1.26138.2.119.1.2.1.2.207	OctetString	%Aug 30 18:01:03:357 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.208	1.3.6.1.4.1.26138.2.119.1.2.1.2.208	OctetString	%Aug 30 18:01:03:639 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.209	1.3.6.1.4.1.26138.2.119.1.2.1.2.209	OctetString	%Aug 30 18:01:06:357 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.210	1.3.6.1.4.1.26138.2.119.1.2.1.2.210	OctetString	%Aug 30 18:01:07:162 2024 SC 3570-48GP-6X SHELL/5/SHELL_LOGOUT: TTY logged out from aux0.
ibICLogbufferContDescription.211	1.3.6.1.4.1.26138.2.119.1.2.1.2.211	OctetString	%Aug 30 18:01:07:499 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.212	1.3.6.1.4.1.26138.2.119.1.2.1.2.212	OctetString	%Aug 30 18:01:10:357 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.213	1.3.6.1.4.1.26138.2.119.1.2.1.2.213	OctetString	%Aug 30 18:01:10:481 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.

Name	OID	Value Type	Value Example
ibICLogbufferContDescription.214	1.3.6.1.4.1.26138.2.119.1.2.1.2.214	OctetString	%Aug 30 18:01:13:359 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.215	1.3.6.1.4.1.26138.2.119.1.2.1.2.215	OctetString	%Aug 30 18:01:14:449 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.216	1.3.6.1.4.1.26138.2.119.1.2.1.2.216	OctetString	%Aug 30 18:01:17:371 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.217	1.3.6.1.4.1.26138.2.119.1.2.1.2.217	OctetString	%Aug 30 18:01:18:492 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.218	1.3.6.1.4.1.26138.2.119.1.2.1.2.218	OctetString	%Aug 30 18:01:21:372 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.219	1.3.6.1.4.1.26138.2.119.1.2.1.2.219	OctetString	%Aug 30 18:01:22:283 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.220	1.3.6.1.4.1.26138.2.119.1.2.1.2.220	OctetString	%Aug 30 18:01:24:358 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.221	1.3.6.1.4.1.26138.2.119.1.2.1.2.221	OctetString	%Aug 30 18:01:24:634 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.222	1.3.6.1.4.1.26138.2.119.1.2.1.2.222	OctetString	%Aug 30 18:01:27:358 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.223	1.3.6.1.4.1.26138.2.119.1.2.1.2.223	OctetString	%Aug 30 18:01:28:530 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.224	1.3.6.1.4.1.26138.2.119.1.2.1.2.224	OctetString	%Aug 30 18:01:31:370 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.225	1.3.6.1.4.1.26138.2.119.1.2.1.2.225	OctetString	%Aug 30 18:01:31:444 2024 SC 3570-48GP-6X STP/6/STP_-

Name	OID	Value Type	Value Example
			NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.226	1.3.6.1.4.1.26138.2.119.1.2.1.2.226	OctetString	%Aug 30 18:01:34:357 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.227	1.3.6.1.4.1.26138.2.119.1.2.1.2.227	OctetString	%Aug 30 18:01:35:447 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.228	1.3.6.1.4.1.26138.2.119.1.2.1.2.228	OctetString	%Aug 30 18:01:38:359 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.229	1.3.6.1.4.1.26138.2.119.1.2.1.2.229	OctetString	%Aug 30 18:01:39:522 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.230	1.3.6.1.4.1.26138.2.119.1.2.1.2.230	OctetString	%Aug 30 18:01:42:359 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.231	1.3.6.1.4.1.26138.2.119.1.2.1.2.231	OctetString	%Aug 30 18:01:43:205 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.232	1.3.6.1.4.1.26138.2.119.1.2.1.2.232	OctetString	%Aug 30 18:01:45:358 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.233	1.3.6.1.4.1.26138.2.119.1.2.1.2.233	OctetString	%Aug 30 18:01:45:660 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.234	1.3.6.1.4.1.26138.2.119.1.2.1.2.234	OctetString	%Aug 30 18:01:48:358 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.235	1.3.6.1.4.1.26138.2.119.1.2.1.2.235	OctetString	%Aug 30 18:01:49:644 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.236	1.3.6.1.4.1.26138.2.119.1.2.1.2.236	OctetString	%Aug 30 18:01:52:377 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port



Name	OID	Value Type	Value Example
			GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.237	1.3.6.1.4.1.26138.2.119.1.2.1.2.237	OctetString	%Aug 30 18:01:52:440 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.238	1.3.6.1.4.1.26138.2.119.1.2.1.2.238	OctetString	%Aug 30 18:01:55:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.239	1.3.6.1.4.1.26138.2.119.1.2.1.2.239	OctetString	%Aug 30 18:01:56:444 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.240	1.3.6.1.4.1.26138.2.119.1.2.1.2.240	OctetString	%Aug 30 18:01:59:376 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.241	1.3.6.1.4.1.26138.2.119.1.2.1.2.241	OctetString	%Aug 30 18:02:00:447 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.242	1.3.6.1.4.1.26138.2.119.1.2.1.2.242	OctetString	%Aug 30 18:02:03:363 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.243	1.3.6.1.4.1.26138.2.119.1.2.1.2.243	OctetString	%Aug 30 18:02:04:478 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.244	1.3.6.1.4.1.26138.2.119.1.2.1.2.244	OctetString	%Aug 30 18:02:07:378 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.245	1.3.6.1.4.1.26138.2.119.1.2.1.2.245	OctetString	%Aug 30 18:02:08:451 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.246	1.3.6.1.4.1.26138.2.119.1.2.1.2.246	OctetString	%Aug 30 18:02:11:370 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.247	1.3.6.1.4.1.26138.2.119.1.2.1.2.247	OctetString	%Aug 30 18:02:13:448 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.

Name	OID	Value Type	Value Example
ibICLogbufferContDescription.248	1.3.6.1.4.1.26138.2.119.1.2.1.2.248	OctetString	%Aug 30 18:02:16:380 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.249	1.3.6.1.4.1.26138.2.119.1.2.1.2.249	OctetString	%Aug 30 18:02:17:480 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.250	1.3.6.1.4.1.26138.2.119.1.2.1.2.250	OctetString	%Aug 30 18:02:20:364 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.251	1.3.6.1.4.1.26138.2.119.1.2.1.2.251	OctetString	%Aug 30 18:02:23:122 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.252	1.3.6.1.4.1.26138.2.119.1.2.1.2.252	OctetString	%Aug 30 18:02:25:359 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.253	1.3.6.1.4.1.26138.2.119.1.2.1.2.253	OctetString	%Aug 30 18:02:25:637 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.254	1.3.6.1.4.1.26138.2.119.1.2.1.2.254	OctetString	%Aug 30 18:02:28:364 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.255	1.3.6.1.4.1.26138.2.119.1.2.1.2.255	OctetString	%Aug 30 18:02:29:692 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.256	1.3.6.1.4.1.26138.2.119.1.2.1.2.256	OctetString	%Aug 30 18:02:32:368 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.257	1.3.6.1.4.1.26138.2.119.1.2.1.2.257	OctetString	%Aug 30 18:02:33:705 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.258	1.3.6.1.4.1.26138.2.119.1.2.1.2.258	OctetString	%Aug 30 18:02:36:377 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.259	1.3.6.1.4.1.26138.2.119.1.2.1.2.259	OctetString	%Aug 30 18:02:36:660 2024 SC 3570-48GP-6X STP/6/STP_-

Name	OID	Value Type	Value Example
			NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.260	1.3.6.1.4.1.26138.2.119.1.2.1.2.260	OctetString	%Aug 30 18:02:39:359 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.261	1.3.6.1.4.1.26138.2.119.1.2.1.2.261	OctetString	%Aug 30 18:02:40:644 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.262	1.3.6.1.4.1.26138.2.119.1.2.1.2.262	OctetString	%Aug 30 18:02:43:359 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.263	1.3.6.1.4.1.26138.2.119.1.2.1.2.263	OctetString	%Aug 30 18:02:44:700 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.264	1.3.6.1.4.1.26138.2.119.1.2.1.2.264	OctetString	%Aug 30 18:02:47:358 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.265	1.3.6.1.4.1.26138.2.119.1.2.1.2.265	OctetString	%Aug 30 18:02:50:445 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.266	1.3.6.1.4.1.26138.2.119.1.2.1.2.266	OctetString	%Aug 30 18:02:53:385 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.267	1.3.6.1.4.1.26138.2.119.1.2.1.2.267	OctetString	%Aug 30 18:02:55:498 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.268	1.3.6.1.4.1.26138.2.119.1.2.1.2.268	OctetString	%Aug 30 18:02:58:359 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.269	1.3.6.1.4.1.26138.2.119.1.2.1.2.269	OctetString	%Aug 30 18:02:59:499 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.270	1.3.6.1.4.1.26138.2.119.1.2.1.2.270	OctetString	%Aug 30 18:03:02:359 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port

Name	OID	Value Type	Value Example
			GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.271	1.3.6.1.4.1.26138.2.119.1.2.1.2.271	OctetString	%Aug 30 18:03:03:455 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.272	1.3.6.1.4.1.26138.2.119.1.2.1.2.272	OctetString	%Aug 30 18:03:06:359 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.273	1.3.6.1.4.1.26138.2.119.1.2.1.2.273	OctetString	%Aug 30 18:03:07:487 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.274	1.3.6.1.4.1.26138.2.119.1.2.1.2.274	OctetString	%Aug 30 18:03:10:359 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.275	1.3.6.1.4.1.26138.2.119.1.2.1.2.275	OctetString	%Aug 30 18:03:11:446 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.276	1.3.6.1.4.1.26138.2.119.1.2.1.2.276	OctetString	%Aug 30 18:03:14:371 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.277	1.3.6.1.4.1.26138.2.119.1.2.1.2.277	OctetString	%Aug 30 18:03:17:735 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.278	1.3.6.1.4.1.26138.2.119.1.2.1.2.278	OctetString	%Aug 30 18:03:20:359 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.279	1.3.6.1.4.1.26138.2.119.1.2.1.2.279	OctetString	%Aug 30 18:03:20:678 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.280	1.3.6.1.4.1.26138.2.119.1.2.1.2.280	OctetString	%Aug 30 18:03:23:379 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.281	1.3.6.1.4.1.26138.2.119.1.2.1.2.281	OctetString	%Aug 30 18:03:24:637 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.

Name	OID	Value Type	Value Example
ibICLogbufferContDescription.282	1.3.6.1.4.1.26138.2.119.1.2.1.2.282	OctetString	%Aug 30 18:03:27:383 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.283	1.3.6.1.4.1.26138.2.119.1.2.1.2.283	OctetString	%Aug 30 18:03:28:637 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.284	1.3.6.1.4.1.26138.2.119.1.2.1.2.284	OctetString	%Aug 30 18:03:31:374 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.285	1.3.6.1.4.1.26138.2.119.1.2.1.2.285	OctetString	%Aug 30 18:03:34:507 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.286	1.3.6.1.4.1.26138.2.119.1.2.1.2.286	OctetString	%Aug 30 18:03:37:381 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.287	1.3.6.1.4.1.26138.2.119.1.2.1.2.287	OctetString	%Aug 30 18:03:37:514 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.288	1.3.6.1.4.1.26138.2.119.1.2.1.2.288	OctetString	%Aug 30 18:03:40:389 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.289	1.3.6.1.4.1.26138.2.119.1.2.1.2.289	OctetString	%Aug 30 18:03:40:804 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.290	1.3.6.1.4.1.26138.2.119.1.2.1.2.290	OctetString	%Aug 30 18:03:43:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.291	1.3.6.1.4.1.26138.2.119.1.2.1.2.291	OctetString	%Aug 30 18:03:43:640 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.292	1.3.6.1.4.1.26138.2.119.1.2.1.2.292	OctetString	%Aug 30 18:03:46:362 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.293	1.3.6.1.4.1.26138.2.119.1.2.1.2.293	OctetString	%Aug 30 18:03:47:093 2024 SC 3570-48GP-6X STP/6/STP_-

Name	OID	Value Type	Value Example
			NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.294	1.3.6.1.4.1.26138.2.119.1.2.1.2.294	OctetString	%Aug 30 18:03:49:386 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.295	1.3.6.1.4.1.26138.2.119.1.2.1.2.295	OctetString	%Aug 30 18:03:49:672 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.296	1.3.6.1.4.1.26138.2.119.1.2.1.2.296	OctetString	%Aug 30 18:03:52:359 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.297	1.3.6.1.4.1.26138.2.119.1.2.1.2.297	OctetString	%Aug 30 18:03:53:517 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.298	1.3.6.1.4.1.26138.2.119.1.2.1.2.298	OctetString	%Aug 30 18:03:56:359 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.299	1.3.6.1.4.1.26138.2.119.1.2.1.2.299	OctetString	%Aug 30 18:03:58:517 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.300	1.3.6.1.4.1.26138.2.119.1.2.1.2.300	OctetString	%Aug 30 18:04:01:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.301	1.3.6.1.4.1.26138.2.119.1.2.1.2.301	OctetString	%Aug 30 18:04:02:458 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.302	1.3.6.1.4.1.26138.2.119.1.2.1.2.302	OctetString	%Aug 30 18:04:05:362 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.303	1.3.6.1.4.1.26138.2.119.1.2.1.2.303	OctetString	%Aug 30 18:04:06:450 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.304	1.3.6.1.4.1.26138.2.119.1.2.1.2.304	OctetString	%Aug 30 18:04:09:366 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port

Name	OID	Value Type	Value Example
			GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.305	1.3.6.1.4.1.26138.2.119.1.2.1.2.305	OctetString	%Aug 30 18:04:10:478 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.306	1.3.6.1.4.1.26138.2.119.1.2.1.2.306	OctetString	%Aug 30 18:04:13:359 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.307	1.3.6.1.4.1.26138.2.119.1.2.1.2.307	OctetString	%Aug 30 18:04:14:442 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.308	1.3.6.1.4.1.26138.2.119.1.2.1.2.308	OctetString	%Aug 30 18:04:17:359 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.309	1.3.6.1.4.1.26138.2.119.1.2.1.2.309	OctetString	%Aug 30 18:04:19:518 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.310	1.3.6.1.4.1.26138.2.119.1.2.1.2.310	OctetString	%Aug 30 18:04:22:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.311	1.3.6.1.4.1.26138.2.119.1.2.1.2.311	OctetString	%Aug 30 18:04:23:447 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.312	1.3.6.1.4.1.26138.2.119.1.2.1.2.312	OctetString	%Aug 30 18:04:26:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.313	1.3.6.1.4.1.26138.2.119.1.2.1.2.313	OctetString	%Aug 30 18:04:27:523 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.314	1.3.6.1.4.1.26138.2.119.1.2.1.2.314	OctetString	%Aug 30 18:04:30:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.315	1.3.6.1.4.1.26138.2.119.1.2.1.2.315	OctetString	%Aug 30 18:04:31:504 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.



Name	OID	Value Type	Value Example
ibICLogbufferContDescription.316	1.3.6.1.4.1.26138.2.119.1.2.1.2.316	OctetString	%Aug 30 18:04:34:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.317	1.3.6.1.4.1.26138.2.119.1.2.1.2.317	OctetString	%Aug 30 18:04:35:491 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.318	1.3.6.1.4.1.26138.2.119.1.2.1.2.318	OctetString	%Aug 30 18:04:38:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.319	1.3.6.1.4.1.26138.2.119.1.2.1.2.319	OctetString	%Aug 30 18:04:40:495 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.320	1.3.6.1.4.1.26138.2.119.1.2.1.2.320	OctetString	%Aug 30 18:04:43:359 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.321	1.3.6.1.4.1.26138.2.119.1.2.1.2.321	OctetString	%Aug 30 18:04:44:476 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.322	1.3.6.1.4.1.26138.2.119.1.2.1.2.322	OctetString	%Aug 30 18:04:47:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.323	1.3.6.1.4.1.26138.2.119.1.2.1.2.323	OctetString	%Aug 30 18:04:50:107 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.324	1.3.6.1.4.1.26138.2.119.1.2.1.2.324	OctetString	%Aug 30 18:04:52:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.325	1.3.6.1.4.1.26138.2.119.1.2.1.2.325	OctetString	%Aug 30 18:04:52:641 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.326	1.3.6.1.4.1.26138.2.119.1.2.1.2.326	OctetString	%Aug 30 18:04:55:362 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.327	1.3.6.1.4.1.26138.2.119.1.2.1.2.327	OctetString	%Aug 30 18:04:56:672 2024 SC 3570-48GP-6X STP/6/STP_-

Name	OID	Value Type	Value Example
			NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.328	1.3.6.1.4.1.26138.2.119.1.2.1.2.328	OctetString	%Aug 30 18:04:59:365 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.329	1.3.6.1.4.1.26138.2.119.1.2.1.2.329	OctetString	%Aug 30 18:05:00:703 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.330	1.3.6.1.4.1.26138.2.119.1.2.1.2.330	OctetString	%Aug 30 18:05:03:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.331	1.3.6.1.4.1.26138.2.119.1.2.1.2.331	OctetString	%Aug 30 18:05:03:672 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.332	1.3.6.1.4.1.26138.2.119.1.2.1.2.332	OctetString	%Aug 30 18:05:06:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.333	1.3.6.1.4.1.26138.2.119.1.2.1.2.333	OctetString	%Aug 30 18:05:06:906 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.334	1.3.6.1.4.1.26138.2.119.1.2.1.2.334	OctetString	%Aug 30 18:05:09:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.335	1.3.6.1.4.1.26138.2.119.1.2.1.2.335	OctetString	%Aug 30 18:05:09:643 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.336	1.3.6.1.4.1.26138.2.119.1.2.1.2.336	OctetString	%Aug 30 18:05:12:369 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.337	1.3.6.1.4.1.26138.2.119.1.2.1.2.337	OctetString	%Aug 30 18:05:13:268 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.338	1.3.6.1.4.1.26138.2.119.1.2.1.2.338	OctetString	%Aug 30 18:05:15:364 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port

Name	OID	Value Type	Value Example
			GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.339	1.3.6.1.4.1.26138.2.119.1.2.1.2.339	OctetString	%Aug 30 18:05:15:672 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.340	1.3.6.1.4.1.26138.2.119.1.2.1.2.340	OctetString	%Aug 30 18:05:18:362 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.341	1.3.6.1.4.1.26138.2.119.1.2.1.2.341	OctetString	%Aug 30 18:05:19:647 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.342	1.3.6.1.4.1.26138.2.119.1.2.1.2.342	OctetString	%Aug 30 18:05:22:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.343	1.3.6.1.4.1.26138.2.119.1.2.1.2.343	OctetString	%Aug 30 18:05:22:470 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.344	1.3.6.1.4.1.26138.2.119.1.2.1.2.344	OctetString	%Aug 30 18:05:25:363 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.345	1.3.6.1.4.1.26138.2.119.1.2.1.2.345	OctetString	%Aug 30 18:05:26:446 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.346	1.3.6.1.4.1.26138.2.119.1.2.1.2.346	OctetString	%Aug 30 18:05:29:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.347	1.3.6.1.4.1.26138.2.119.1.2.1.2.347	OctetString	%Aug 30 18:05:30:445 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.348	1.3.6.1.4.1.26138.2.119.1.2.1.2.348	OctetString	%Aug 30 18:05:33:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.349	1.3.6.1.4.1.26138.2.119.1.2.1.2.349	OctetString	%Aug 30 18:05:34:453 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.

Name	OID	Value Type	Value Example
ibICLogbufferContDescription.350	1.3.6.1.4.1.26138.2.119.1.2.1.2.350	OctetString	%Aug 30 18:05:37:363 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.351	1.3.6.1.4.1.26138.2.119.1.2.1.2.351	OctetString	%Aug 30 18:05:38:513 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.352	1.3.6.1.4.1.26138.2.119.1.2.1.2.352	OctetString	%Aug 30 18:05:41:366 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.353	1.3.6.1.4.1.26138.2.119.1.2.1.2.353	OctetString	%Aug 30 18:05:44:742 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.354	1.3.6.1.4.1.26138.2.119.1.2.1.2.354	OctetString	%Aug 30 18:05:47:363 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.355	1.3.6.1.4.1.26138.2.119.1.2.1.2.355	OctetString	%Aug 30 18:05:47:641 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.356	1.3.6.1.4.1.26138.2.119.1.2.1.2.356	OctetString	%Aug 30 18:05:50:368 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.357	1.3.6.1.4.1.26138.2.119.1.2.1.2.357	OctetString	%Aug 30 18:05:51:705 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.358	1.3.6.1.4.1.26138.2.119.1.2.1.2.358	OctetString	%Aug 30 18:05:54:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.359	1.3.6.1.4.1.26138.2.119.1.2.1.2.359	OctetString	%Aug 30 18:05:55:640 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.360	1.3.6.1.4.1.26138.2.119.1.2.1.2.360	OctetString	%Aug 30 18:05:58:372 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.361	1.3.6.1.4.1.26138.2.119.1.2.1.2.361	OctetString	%Aug 30 18:06:01:490 2024 SC 3570-48GP-6X STP/6/STP_-

Name	OID	Value Type	Value Example
			NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.362	1.3.6.1.4.1.26138.2.119.1.2.1.2.362	OctetString	%Aug 30 18:06:04:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.363	1.3.6.1.4.1.26138.2.119.1.2.1.2.363	OctetString	%Aug 30 18:06:04:448 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.364	1.3.6.1.4.1.26138.2.119.1.2.1.2.364	OctetString	%Aug 30 18:06:07:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.365	1.3.6.1.4.1.26138.2.119.1.2.1.2.365	OctetString	%Aug 30 18:06:08:455 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.366	1.3.6.1.4.1.26138.2.119.1.2.1.2.366	OctetString	%Aug 30 18:06:11:375 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.367	1.3.6.1.4.1.26138.2.119.1.2.1.2.367	OctetString	%Aug 30 18:06:14:640 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.368	1.3.6.1.4.1.26138.2.119.1.2.1.2.368	OctetString	%Aug 30 18:06:17:364 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.369	1.3.6.1.4.1.26138.2.119.1.2.1.2.369	OctetString	%Aug 30 18:06:18:307 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.370	1.3.6.1.4.1.26138.2.119.1.2.1.2.370	OctetString	%Aug 30 18:06:20:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.371	1.3.6.1.4.1.26138.2.119.1.2.1.2.371	OctetString	%Aug 30 18:06:20:640 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.372	1.3.6.1.4.1.26138.2.119.1.2.1.2.372	OctetString	%Aug 30 18:06:23:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port

Name	OID	Value Type	Value Example
			GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.373	1.3.6.1.4.1.26138.2.119.1.2.1.2.373	OctetString	%Aug 30 18:06:24:650 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.374	1.3.6.1.4.1.26138.2.119.1.2.1.2.374	OctetString	%Aug 30 18:06:27:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.375	1.3.6.1.4.1.26138.2.119.1.2.1.2.375	OctetString	%Aug 30 18:06:27:441 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.376	1.3.6.1.4.1.26138.2.119.1.2.1.2.376	OctetString	%Aug 30 18:06:30:374 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.377	1.3.6.1.4.1.26138.2.119.1.2.1.2.377	OctetString	%Aug 30 18:06:30:893 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.378	1.3.6.1.4.1.26138.2.119.1.2.1.2.378	OctetString	%Aug 30 18:06:33:362 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.379	1.3.6.1.4.1.26138.2.119.1.2.1.2.379	OctetString	%Aug 30 18:06:33:663 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.380	1.3.6.1.4.1.26138.2.119.1.2.1.2.380	OctetString	%Aug 30 18:06:36:381 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.381	1.3.6.1.4.1.26138.2.119.1.2.1.2.381	OctetString	%Aug 30 18:06:37:268 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.382	1.3.6.1.4.1.26138.2.119.1.2.1.2.382	OctetString	%Aug 30 18:06:39:365 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.383	1.3.6.1.4.1.26138.2.119.1.2.1.2.383	OctetString	%Aug 30 18:06:39:640 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.

Name	OID	Value Type	Value Example
ibICLogbufferContDescription.384	1.3.6.1.4.1.26138.2.119.1.2.1.2.384	OctetString	%Aug 30 18:06:42:364 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.385	1.3.6.1.4.1.26138.2.119.1.2.1.2.385	OctetString	%Aug 30 18:06:43:642 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.386	1.3.6.1.4.1.26138.2.119.1.2.1.2.386	OctetString	%Aug 30 18:06:46:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.387	1.3.6.1.4.1.26138.2.119.1.2.1.2.387	OctetString	%Aug 30 18:06:46:497 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.388	1.3.6.1.4.1.26138.2.119.1.2.1.2.388	OctetString	%Aug 30 18:06:49:370 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.389	1.3.6.1.4.1.26138.2.119.1.2.1.2.389	OctetString	%Aug 30 18:06:50:457 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.390	1.3.6.1.4.1.26138.2.119.1.2.1.2.390	OctetString	%Aug 30 18:06:53:363 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.391	1.3.6.1.4.1.26138.2.119.1.2.1.2.391	OctetString	%Aug 30 18:06:54:511 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.392	1.3.6.1.4.1.26138.2.119.1.2.1.2.392	OctetString	%Aug 30 18:06:57:364 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.393	1.3.6.1.4.1.26138.2.119.1.2.1.2.393	OctetString	%Aug 30 18:06:58:195 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.394	1.3.6.1.4.1.26138.2.119.1.2.1.2.394	OctetString	%Aug 30 18:07:00:364 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.395	1.3.6.1.4.1.26138.2.119.1.2.1.2.395	OctetString	%Aug 30 18:07:00:638 2024 SC 3570-48GP-6X STP/6/STP_-



Name	OID	Value Type	Value Example
			NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.396	1.3.6.1.4.1.26138.2.119.1.2.1.2.396	OctetString	%Aug 30 18:07:03:372 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.397	1.3.6.1.4.1.26138.2.119.1.2.1.2.397	OctetString	%Aug 30 18:07:04:710 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.398	1.3.6.1.4.1.26138.2.119.1.2.1.2.398	OctetString	%Aug 30 18:07:07:368 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.399	1.3.6.1.4.1.26138.2.119.1.2.1.2.399	OctetString	%Aug 30 18:07:07:511 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.400	1.3.6.1.4.1.26138.2.119.1.2.1.2.400	OctetString	%Aug 30 18:07:10:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.401	1.3.6.1.4.1.26138.2.119.1.2.1.2.401	OctetString	%Aug 30 18:07:11:508 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.402	1.3.6.1.4.1.26138.2.119.1.2.1.2.402	OctetString	%Aug 30 18:07:14:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.403	1.3.6.1.4.1.26138.2.119.1.2.1.2.403	OctetString	%Aug 30 18:07:15:462 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.404	1.3.6.1.4.1.26138.2.119.1.2.1.2.404	OctetString	%Aug 30 18:07:18:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.405	1.3.6.1.4.1.26138.2.119.1.2.1.2.405	OctetString	%Aug 30 18:07:19:513 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.406	1.3.6.1.4.1.26138.2.119.1.2.1.2.406	OctetString	%Aug 30 18:07:22:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port

Name	OID	Value Type	Value Example
			GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.407	1.3.6.1.4.1.26138.2.119.1.2.1.2.407	OctetString	%Aug 30 18:07:23:511 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.408	1.3.6.1.4.1.26138.2.119.1.2.1.2.408	OctetString	%Aug 30 18:07:26:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.409	1.3.6.1.4.1.26138.2.119.1.2.1.2.409	OctetString	%Aug 30 18:07:29:767 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.410	1.3.6.1.4.1.26138.2.119.1.2.1.2.410	OctetString	%Aug 30 18:07:32:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.411	1.3.6.1.4.1.26138.2.119.1.2.1.2.411	OctetString	%Aug 30 18:07:32:655 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.412	1.3.6.1.4.1.26138.2.119.1.2.1.2.412	OctetString	%Aug 30 18:07:35:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.413	1.3.6.1.4.1.26138.2.119.1.2.1.2.413	OctetString	%Aug 30 18:07:36:714 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.414	1.3.6.1.4.1.26138.2.119.1.2.1.2.414	OctetString	%Aug 30 18:07:39:362 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.415	1.3.6.1.4.1.26138.2.119.1.2.1.2.415	OctetString	%Aug 30 18:07:40:231 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.416	1.3.6.1.4.1.26138.2.119.1.2.1.2.416	OctetString	%Aug 30 18:07:42:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.417	1.3.6.1.4.1.26138.2.119.1.2.1.2.417	OctetString	%Aug 30 18:07:42:648 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.

Name	OID	Value Type	Value Example
ibICLogbufferContDescription.418	1.3.6.1.4.1.26138.2.119.1.2.1.2.418	OctetString	%Aug 30 18:07:45:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.419	1.3.6.1.4.1.26138.2.119.1.2.1.2.419	OctetString	%Aug 30 18:07:46:687 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.420	1.3.6.1.4.1.26138.2.119.1.2.1.2.420	OctetString	%Aug 30 18:07:49:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.421	1.3.6.1.4.1.26138.2.119.1.2.1.2.421	OctetString	%Aug 30 18:07:49:440 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.422	1.3.6.1.4.1.26138.2.119.1.2.1.2.422	OctetString	%Aug 30 18:07:52:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.423	1.3.6.1.4.1.26138.2.119.1.2.1.2.423	OctetString	%Aug 30 18:07:53:488 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.424	1.3.6.1.4.1.26138.2.119.1.2.1.2.424	OctetString	%Aug 30 18:07:56:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.425	1.3.6.1.4.1.26138.2.119.1.2.1.2.425	OctetString	%Aug 30 18:07:57:457 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.426	1.3.6.1.4.1.26138.2.119.1.2.1.2.426	OctetString	%Aug 30 18:08:00:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.427	1.3.6.1.4.1.26138.2.119.1.2.1.2.427	OctetString	%Aug 30 18:08:01:454 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.428	1.3.6.1.4.1.26138.2.119.1.2.1.2.428	OctetString	%Aug 30 18:08:04:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.429	1.3.6.1.4.1.26138.2.119.1.2.1.2.429	OctetString	%Aug 30 18:08:05:465 2024 SC 3570-48GP-6X STP/6/STP_-

Name	OID	Value Type	Value Example
			NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.430	1.3.6.1.4.1.26138.2.119.1.2.1.2.430	OctetString	%Aug 30 18:08:08:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.431	1.3.6.1.4.1.26138.2.119.1.2.1.2.431	OctetString	%Aug 30 18:08:10:493 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.432	1.3.6.1.4.1.26138.2.119.1.2.1.2.432	OctetString	%Aug 30 18:08:13:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.433	1.3.6.1.4.1.26138.2.119.1.2.1.2.433	OctetString	%Aug 30 18:08:14:442 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.434	1.3.6.1.4.1.26138.2.119.1.2.1.2.434	OctetString	%Aug 30 18:08:17:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.435	1.3.6.1.4.1.26138.2.119.1.2.1.2.435	OctetString	%Aug 30 18:08:18:506 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.436	1.3.6.1.4.1.26138.2.119.1.2.1.2.436	OctetString	%Aug 30 18:08:21:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.437	1.3.6.1.4.1.26138.2.119.1.2.1.2.437	OctetString	%Aug 30 18:08:22:463 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.438	1.3.6.1.4.1.26138.2.119.1.2.1.2.438	OctetString	%Aug 30 18:08:25:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.439	1.3.6.1.4.1.26138.2.119.1.2.1.2.439	OctetString	%Aug 30 18:08:28:494 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.440	1.3.6.1.4.1.26138.2.119.1.2.1.2.440	OctetString	%Aug 30 18:08:31:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port

Name	OID	Value Type	Value Example
			GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.441	1.3.6.1.4.1.26138.2.119.1.2.1.2.441	OctetString	%Aug 30 18:08:31:439 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.442	1.3.6.1.4.1.26138.2.119.1.2.1.2.442	OctetString	%Aug 30 18:08:34:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.443	1.3.6.1.4.1.26138.2.119.1.2.1.2.443	OctetString	%Aug 30 18:08:35:503 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.444	1.3.6.1.4.1.26138.2.119.1.2.1.2.444	OctetString	%Aug 30 18:08:38:376 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.445	1.3.6.1.4.1.26138.2.119.1.2.1.2.445	OctetString	%Aug 30 18:08:39:004 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.446	1.3.6.1.4.1.26138.2.119.1.2.1.2.446	OctetString	%Aug 30 18:08:41:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.447	1.3.6.1.4.1.26138.2.119.1.2.1.2.447	OctetString	%Aug 30 18:08:41:638 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.448	1.3.6.1.4.1.26138.2.119.1.2.1.2.448	OctetString	%Aug 30 18:08:44:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.449	1.3.6.1.4.1.26138.2.119.1.2.1.2.449	OctetString	%Aug 30 18:08:45:651 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.450	1.3.6.1.4.1.26138.2.119.1.2.1.2.450	OctetString	%Aug 30 18:08:48:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.451	1.3.6.1.4.1.26138.2.119.1.2.1.2.451	OctetString	%Aug 30 18:08:49:500 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.

Name	OID	Value Type	Value Example
ibICLogbufferContDescription.452	1.3.6.1.4.1.26138.2.119.1.2.1.2.452	OctetString	%Aug 30 18:08:52:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.453	1.3.6.1.4.1.26138.2.119.1.2.1.2.453	OctetString	%Aug 30 18:08:52:438 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.454	1.3.6.1.4.1.26138.2.119.1.2.1.2.454	OctetString	%Aug 30 18:08:55:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.455	1.3.6.1.4.1.26138.2.119.1.2.1.2.455	OctetString	%Aug 30 18:08:55:801 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.456	1.3.6.1.4.1.26138.2.119.1.2.1.2.456	OctetString	%Aug 30 18:08:58:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.457	1.3.6.1.4.1.26138.2.119.1.2.1.2.457	OctetString	%Aug 30 18:08:58:661 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.458	1.3.6.1.4.1.26138.2.119.1.2.1.2.458	OctetString	%Aug 30 18:09:01:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.459	1.3.6.1.4.1.26138.2.119.1.2.1.2.459	OctetString	%Aug 30 18:09:02:638 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.460	1.3.6.1.4.1.26138.2.119.1.2.1.2.460	OctetString	%Aug 30 18:09:05:362 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.461	1.3.6.1.4.1.26138.2.119.1.2.1.2.461	OctetString	%Aug 30 18:09:06:343 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.462	1.3.6.1.4.1.26138.2.119.1.2.1.2.462	OctetString	%Aug 30 18:09:08:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.463	1.3.6.1.4.1.26138.2.119.1.2.1.2.463	OctetString	%Aug 30 18:09:08:641 2024 SC 3570-48GP-6X STP/6/STP_-

Name	OID	Value Type	Value Example
			NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.464	1.3.6.1.4.1.26138.2.119.1.2.1.2.464	OctetString	%Aug 30 18:09:11:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.465	1.3.6.1.4.1.26138.2.119.1.2.1.2.465	OctetString	%Aug 30 18:09:12:602 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.466	1.3.6.1.4.1.26138.2.119.1.2.1.2.466	OctetString	%Aug 30 18:09:15:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.467	1.3.6.1.4.1.26138.2.119.1.2.1.2.467	OctetString	%Aug 30 18:09:15:464 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.468	1.3.6.1.4.1.26138.2.119.1.2.1.2.468	OctetString	%Aug 30 18:09:18:365 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.469	1.3.6.1.4.1.26138.2.119.1.2.1.2.469	OctetString	%Aug 30 18:09:18:966 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.470	1.3.6.1.4.1.26138.2.119.1.2.1.2.470	OctetString	%Aug 30 18:09:21:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.471	1.3.6.1.4.1.26138.2.119.1.2.1.2.471	OctetString	%Aug 30 18:09:21:644 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.472	1.3.6.1.4.1.26138.2.119.1.2.1.2.472	OctetString	%Aug 30 18:09:24:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.473	1.3.6.1.4.1.26138.2.119.1.2.1.2.473	OctetString	%Aug 30 18:09:25:232 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.474	1.3.6.1.4.1.26138.2.119.1.2.1.2.474	OctetString	%Aug 30 18:09:27:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port



Name	OID	Value Type	Value Example
			GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.475	1.3.6.1.4.1.26138.2.119.1.2.1.2.475	OctetString	%Aug 30 18:09:27:641 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.476	1.3.6.1.4.1.26138.2.119.1.2.1.2.476	OctetString	%Aug 30 18:09:30:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.477	1.3.6.1.4.1.26138.2.119.1.2.1.2.477	OctetString	%Aug 30 18:09:31:661 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.478	1.3.6.1.4.1.26138.2.119.1.2.1.2.478	OctetString	%Aug 30 18:09:34:360 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.479	1.3.6.1.4.1.26138.2.119.1.2.1.2.479	OctetString	%Aug 30 18:09:34:438 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.480	1.3.6.1.4.1.26138.2.119.1.2.1.2.480	OctetString	%Aug 30 18:09:37:364 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.481	1.3.6.1.4.1.26138.2.119.1.2.1.2.481	OctetString	%Aug 30 18:09:38:445 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.482	1.3.6.1.4.1.26138.2.119.1.2.1.2.482	OctetString	%Aug 30 18:09:41:371 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.483	1.3.6.1.4.1.26138.2.119.1.2.1.2.483	OctetString	%Aug 30 18:09:42:515 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.484	1.3.6.1.4.1.26138.2.119.1.2.1.2.484	OctetString	%Aug 30 18:09:45:362 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.485	1.3.6.1.4.1.26138.2.119.1.2.1.2.485	OctetString	%Aug 30 18:09:46:256 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.

Name	OID	Value Type	Value Example
ibICLogbufferContDescription.486	1.3.6.1.4.1.26138.2.119.1.2.1.2.486	OctetString	%Aug 30 18:09:48:368 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.487	1.3.6.1.4.1.26138.2.119.1.2.1.2.487	OctetString	%Aug 30 18:09:48:641 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.488	1.3.6.1.4.1.26138.2.119.1.2.1.2.488	OctetString	%Aug 30 18:09:51:366 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.489	1.3.6.1.4.1.26138.2.119.1.2.1.2.489	OctetString	%Aug 30 18:09:52:557 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.490	1.3.6.1.4.1.26138.2.119.1.2.1.2.490	OctetString	%Aug 30 18:09:55:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.491	1.3.6.1.4.1.26138.2.119.1.2.1.2.491	OctetString	%Aug 30 18:09:55:442 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.492	1.3.6.1.4.1.26138.2.119.1.2.1.2.492	OctetString	%Aug 30 18:09:58:364 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.493	1.3.6.1.4.1.26138.2.119.1.2.1.2.493	OctetString	%Aug 30 18:09:59:442 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.494	1.3.6.1.4.1.26138.2.119.1.2.1.2.494	OctetString	%Aug 30 18:10:02:362 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.495	1.3.6.1.4.1.26138.2.119.1.2.1.2.495	OctetString	%Aug 30 18:10:05:684 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.496	1.3.6.1.4.1.26138.2.119.1.2.1.2.496	OctetString	%Aug 30 18:10:08:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.497	1.3.6.1.4.1.26138.2.119.1.2.1.2.497	OctetString	%Aug 30 18:10:09:304 2024 SC 3570-48GP-6X STP/6/STP_-

Name	OID	Value Type	Value Example
			NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.498	1.3.6.1.4.1.26138.2.119.1.2.1.2.498	OctetString	%Aug 30 18:10:11:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.499	1.3.6.1.4.1.26138.2.119.1.2.1.2.499	OctetString	%Aug 30 18:10:11:667 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.500	1.3.6.1.4.1.26138.2.119.1.2.1.2.500	OctetString	%Aug 30 18:10:14:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.501	1.3.6.1.4.1.26138.2.119.1.2.1.2.501	OctetString	%Aug 30 18:10:15:639 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.502	1.3.6.1.4.1.26138.2.119.1.2.1.2.502	OctetString	%Aug 30 18:10:18:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.503	1.3.6.1.4.1.26138.2.119.1.2.1.2.503	OctetString	%Aug 30 18:10:18:641 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.504	1.3.6.1.4.1.26138.2.119.1.2.1.2.504	OctetString	%Aug 30 18:10:21:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.505	1.3.6.1.4.1.26138.2.119.1.2.1.2.505	OctetString	%Aug 30 18:10:22:647 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.506	1.3.6.1.4.1.26138.2.119.1.2.1.2.506	OctetString	%Aug 30 18:10:25:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.507	1.3.6.1.4.1.26138.2.119.1.2.1.2.507	OctetString	%Aug 30 18:10:26:645 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.508	1.3.6.1.4.1.26138.2.119.1.2.1.2.508	OctetString	%Aug 30 18:10:29:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port

Name	OID	Value Type	Value Example
			GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.509	.1.3.6.1.4.1.26138.2.119.1.2.1.2.509	OctetString	%Aug 30 18:10:30:301 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.510	.1.3.6.1.4.1.26138.2.119.1.2.1.2.510	OctetString	%Aug 30 18:10:32:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.511	.1.3.6.1.4.1.26138.2.119.1.2.1.2.511	OctetString	%Aug 30 18:10:32:638 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICLogbufferContDescription.512	.1.3.6.1.4.1.26138.2.119.1.2.1.2.512	OctetString	%Aug 30 18:10:35:361 2024 SC 3570-48GP-6X STP/6/STP_-NOTIFIED_TC: Instance 0's port GigabitEthernet1/0/1 was notified a topology change.
ibICMaxLoghost.0	.1.3.6.1.4.1.26138.2.119.2.1.1.0	Gauge	20
ibICLoghostSourceInterface.0	.1.3.6.1.4.1.26138.2.119.2.1.2.0	Integer	0
ibICLoghostTimestampType.0	.1.3.6.1.4.1.26138.2.119.2.1.3.0	Integer	date (0)
ibICLoghostIpAddressType.1	.1.3.6.1.4.1.26138.2.119.2.2.1.2.1	Integer	ipv4 (1)
ibICLoghostIpAddress.1	.1.3.6.1.4.1.26138.2.119.2.2.1.3.1	OctetString	10.100.26.141 (0x0A 64 1A 8D)
ibICLoghostVPNName.1	.1.3.6.1.4.1.26138.2.119.2.2.1.4.1	OctetString	
ibICLoghostFacility.1	.1.3.6.1.4.1.26138.2.119.2.2.1.5.1	Integer	local7 (23)
ibICLoghostOperateRowStatus.1	.1.3.6.1.4.1.26138.2.119.2.2.1.6.1	Integer	active (1)
ibICLoghostIpAddressPort.1	.1.3.6.1.4.1.26138.2.119.2.2.1.7.1	Gauge	514
ibICLoghostTAddress.1	.1.3.6.1.4.1.26138.2.119.2.2.1.8.1	OctetString	0A-64-1A-8D-02-02
ibICDirectionName.1	.1.3.6.1.4.1.26138.2.119.3.1.1.2.1	OctetString	Console
ibICDirectionName.2	.1.3.6.1.4.1.26138.2.119.3.1.1.2.2	OctetString	Monitor
ibICDirectionName.3	.1.3.6.1.4.1.26138.2.119.3.1.1.2.3	OctetString	Log buffer
ibICDirectionName.4	.1.3.6.1.4.1.26138.2.119.3.1.1.2.4	OctetString	Log host
ibICDirectionName.5	.1.3.6.1.4.1.26138.2.119.3.1.1.2.5	OctetString	Log file
ibICDirectionName.6	.1.3.6.1.4.1.26138.2.119.3.1.1.2.6	OctetString	Diagnostic log file
ibICDirectionName.7	.1.3.6.1.4.1.26138.2.119.3.1.1.2.7	OctetString	Security log file
ibICDirectionName.9	.1.3.6.1.4.1.26138.2.119.3.1.1.2.9	OctetString	Trap
ibICDirectionState.1	.1.3.6.1.4.1.26138.2.119.3.1.1.3.1	Integer	true (1)
ibICDirectionState.2	.1.3.6.1.4.1.26138.2.119.3.1.1.3.2	Integer	true (1)
ibICDirectionState.3	.1.3.6.1.4.1.26138.2.119.3.1.1.3.3	Integer	true (1)
ibICDirectionState.4	.1.3.6.1.4.1.26138.2.119.3.1.1.3.4	Integer	true (1)
ibICDirectionState.5	.1.3.6.1.4.1.26138.2.119.3.1.1.3.5	Integer	true (1)
ibICDirectionState.6	.1.3.6.1.4.1.26138.2.119.3.1.1.3.6	Integer	true (1)
ibICDirectionState.7	.1.3.6.1.4.1.26138.2.119.3.1.1.3.7	Integer	false (2)

Name	OID	Value Type	Value Example
ibICDirectionState.9	.1.3.6.1.4.1.26138.2.119.3.1.1.3.9	Integer	true (1)
ibICModuleName.65.67.76	.1.3.6.1.4.1.26138.2.119.4.1.1.1.65.67.76	OctetString	ACL
ibICModuleName.65.80.82	.1.3.6.1.4.1.26138.2.119.4.1.1.1.65.80.82	OctetString	APR
ibICModuleName.65.82.80	.1.3.6.1.4.1.26138.2.119.4.1.1.1.65.82.80	OctetString	ARP
ibICModule-Name.67.70.71.77.65.78	.1.3.6.1.4.1.26138.2.119.4.1.1.1.67.70.71.77.65.78	OctetString	CFGMAN
ibICModule-Name.67.77.68.69.86.77.79.78	.1.3.6.1.4.1.26138.2.119.4.1.1.1.67.77.68.69.86.77.79.78	OctetString	CMDEVMON
ibICModule-Name.67.77.84.78.76.77.71.82	.1.3.6.1.4.1.26138.2.119.4.1.1.1.67.77.84.78.76.77.71.82	OctetString	CMTNLMGR
ibICModuleName.68.66.77	.1.3.6.1.4.1.26138.2.119.4.1.1.1.68.66.77	OctetString	DBM
ibICModuleName.68.67.66.88	.1.3.6.1.4.1.26138.2.119.4.1.1.1.68.67.66.88	OctetString	DCBX
ibICModuleName.68.69.86	.1.3.6.1.4.1.26138.2.119.4.1.1.1.68.69.86	OctetString	DEV
ibICModuleName.68.72.67.80	.1.3.6.1.4.1.26138.2.119.4.1.1.1.68.72.67.80	OctetString	DHCP
ibICModule-Name.68.72.67.80.67	.1.3.6.1.4.1.26138.2.119.4.1.1.1.68.72.67.80.67	OctetString	DHCPC
ibICModule-Name.68.72.67.80.76.73.66	.1.3.6.1.4.1.26138.2.119.4.1.1.1.68.72.67.80.76.73.66	OctetString	DHCPLIB
ibICModule-Name.68.72.67.80.82	.1.3.6.1.4.1.26138.2.119.4.1.1.1.68.72.67.80.82	OctetString	DHCPR
ibICModule-Name.68.72.67.80.83	.1.3.6.1.4.1.26138.2.119.4.1.1.1.68.72.67.80.83	OctetString	DHCPS
ibICModuleName.68.78.83	.1.3.6.1.4.1.26138.2.119.4.1.1.1.68.78.83	OctetString	DNS
ibICModule-Name.68.87.95.73.78.70.79	.1.3.6.1.4.1.26138.2.119.4.1.1.1.68.87.95.73.78.70.79	OctetString	DW_INFO
ibICModuleName.69.68.69.88	.1.3.6.1.4.1.26138.2.119.4.1.1.1.69.68.69.88	OctetString	EDEV
ibICModuleName.70.73.66	.1.3.6.1.4.1.26138.2.119.4.1.1.1.70.73.66	OctetString	FIB
ibICModuleName.72.84.84.80	.1.3.6.1.4.1.26138.2.119.4.1.1.1.72.84.84.80	OctetString	HTTP
ibICModule-Name.72.84.84.80.82.69.68.82	.1.3.6.1.4.1.26138.2.119.4.1.1.1.72.84.84.80.82.69.68.82	OctetString	HTTPREDR
ibICModule-Name.73.70.78.69.84	.1.3.6.1.4.1.26138.2.119.4.1.1.1.73.70.78.69.84	OctetString	IFNET
ibICModule-Name.73.80.65.68.68.82	.1.3.6.1.4.1.26138.2.119.4.1.1.1.73.80.65.68.68.82	OctetString	IPADDR
ibICModuleName.73.80.83.71	.1.3.6.1.4.1.26138.2.119.4.1.1.1.73.80.83.71	OctetString	IPSG
ibICModuleName.73.82.68.80	.1.3.6.1.4.1.26138.2.119.4.1.1.1.73.82.68.80	OctetString	IRDP
ibICModuleName.76.65.71.71	.1.3.6.1.4.1.26138.2.119.4.1.1.1.76.65.71.71	OctetString	LAGG
ibICModuleName.76.68.65.80	.1.3.6.1.4.1.26138.2.119.4.1.1.1.76.68.65.80	OctetString	LDAP
ibICModuleName.76.76.68.80	.1.3.6.1.4.1.26138.2.119.4.1.1.1.76.76.68.80	OctetString	LLDP
ibICModule-Name.77.71.82.79.85.80	.1.3.6.1.4.1.26138.2.119.4.1.1.1.77.71.82.79.85.80	OctetString	MGROUP
ibICModule-Name.78.69.84.67.79.78.70	.1.3.6.1.4.1.26138.2.119.4.1.1.1.78.69.84.67.79.78.70	OctetString	NETCONF
ibICModuleName.78.84.80	.1.3.6.1.4.1.26138.2.119.4.1.1.1.78.84.80	OctetString	NTP
ibICModule-Name.79.80.84.77.79.68	.1.3.6.1.4.1.26138.2.119.4.1.1.1.79.80.84.77.79.68	OctetString	OPTMOD

Name	OID	Value Type	Value Example
ibICModule-Name.80.70.73.76.84.69.82	.1.3.6.1.4.1.26138.2.119.4.1.1.1.80.70.73.76.84.69.82	String	PFILTER
ibICModuleName.80.73.78.77.83.61.4.1.26138.2.119.4.1.1.1.80.73.78.77.83	.1.3.6.1.4.1.26138.2.119.4.1.1.1.80.73.78.77.83	OctetString	PING
ibICModuleName.80.75.71	.1.3.6.1.4.1.26138.2.119.4.1.1.1.80.75	OctetString	PKG
ibICModuleName.80.79.69	.1.3.6.1.4.1.26138.2.119.4.1.1.1.80.79	OctetString	POE
ibICModuleName.81.79.83	.1.3.6.1.4.1.26138.2.119.4.1.1.1.81.79	OctetString	QOS
ibICModule-Name.82.65.68.73.85.83	.1.3.6.1.4.1.26138.2.119.4.1.1.1.82.65.68.73.85.83	OctetString	RADIUS
ibICModuleName.82.66.65.67.83.61.4.1.26138.2.119.4.1.1.1.82.66.65.67.83	.1.3.6.1.4.1.26138.2.119.4.1.1.1.82.66.65.67.83	OctetString	RBAC
ibICModule-Name.82.69.83.77.79.78	.1.3.6.1.4.1.26138.2.119.4.1.1.1.82.69.83.77.79.78	OctetString	RESMON
ibICModuleName.82.77	.1.3.6.1.4.1.26138.2.119.4.1.1.1.82.77	OctetString	RM
ibICModuleName.83.67.77.68.3.61.4.1.26138.2.119.4.1.1.1.83.67.77.68	.1.3.6.1.4.1.26138.2.119.4.1.1.1.83.67.77.68	OctetString	SCMD
ibICModule-Name.83.72.69.76.76	.1.3.6.1.4.1.26138.2.119.4.1.1.1.83.72.69.76.76	OctetString	SHELL
ibICModuleName.83.78.77.80.3.61.4.1.26138.2.119.4.1.1.1.83.78.77.80	.1.3.6.1.4.1.26138.2.119.4.1.1.1.83.78.77.80	OctetString	SNMP
ibICModuleName.83.79.65.80.3.61.4.1.26138.2.119.4.1.1.1.83.79.65.80	.1.3.6.1.4.1.26138.2.119.4.1.1.1.83.79.65.80	OctetString	SOAP
ibICModuleName.83.83.72.83.3.61.4.1.26138.2.119.4.1.1.1.83.83.72.83	.1.3.6.1.4.1.26138.2.119.4.1.1.1.83.83.72.83	OctetString	SSHS
ibICModuleName.83.84.73	.1.3.6.1.4.1.26138.2.119.4.1.1.1.83.84.73	OctetString	STI
ibICModuleName.83.84.77	.1.3.6.1.4.1.26138.2.119.4.1.1.1.83.84.77	OctetString	STM
ibICModuleName.83.84.80	.1.3.6.1.4.1.26138.2.119.4.1.1.1.83.84.80	OctetString	STP
ibICModule-Name.83.89.83.76.79.71	.1.3.6.1.4.1.26138.2.119.4.1.1.1.83.89.83.76.79.71	OctetString	SYSLOG
ibICModule-Name.84.65.67.65.67.83	.1.3.6.1.4.1.26138.2.119.4.1.1.1.84.65.67.65.67.83	OctetString	TACACS
ibICModuleName.84.65.69	.1.3.6.1.4.1.26138.2.119.4.1.1.1.84.65.69	OctetString	TAE
ibICModule-Name.84.69.76.78.69.84.68	.1.3.6.1.4.1.26138.2.119.4.1.1.1.84.69.76.78.69.84.68	OctetString	TELNETD
ibICModule-Name.84.82.65.78.71.69	.1.3.6.1.4.1.26138.2.119.4.1.1.1.84.82.65.78.71.69	OctetString	TRANGE
ibICModuleName.86.76.65.78.3.61.4.1.26138.2.119.4.1.1.1.86.76.65.78	.1.3.6.1.4.1.26138.2.119.4.1.1.1.86.76.65.78	OctetString	VLAN
ibICModuleName.87.69.66	.1.3.6.1.4.1.26138.2.119.4.1.1.1.87.69.66	OctetString	WEB
ibICModuleName.87.83.65.78.3.61.4.1.26138.2.119.4.1.1.1.87.83.65.78	.1.3.6.1.4.1.26138.2.119.4.1.1.1.87.83.65.78	OctetString	WSAL
ibICModuleName.88.67.77.80.3.61.4.1.26138.2.119.4.1.1.1.88.67.77.80	.1.3.6.1.4.1.26138.2.119.4.1.1.1.88.67.77.80	OctetString	XCMP
ibICModule-Name.88.77.76.65.71.69.78.84	.1.3.6.1.4.1.26138.2.119.4.1.1.1.88.77.76.65.71.69.78.84	OctetString	XMLAGENT
ibICModule-Name.88.77.76.67.70.71	.1.3.6.1.4.1.26138.2.119.4.1.1.1.88.77.76.67.70.71	OctetString	XMLCFG
ibICModule-Name.88.77.76.83.79.65.80	.1.3.6.1.4.1.26138.2.119.4.1.1.1.88.77.76.83.79.65.80	OctetString	XMLSOAP
ibICLogGlobalState.0	.1.3.6.1.4.1.26138.2.119.5.1.1.0	Integer	true (1)
ibICLogTimestampType.0	.1.3.6.1.4.1.26138.2.119.5.1.2.0	Integer	date (0)
ibICLogLevel.1.100.103.102.97.2673808.1195.2.1.1.1.100.101.102.97.103.102.97.2673808.1195	.1.3.6.1.4.1.26138.2.119.5.2.1.1.1.100.101.102.97.103.102.97.2673808.1195	Integer	debug (7)
ibICLogLevel.2.100.103.102.97.2673808.1195.2.1.1.2.100.101.102.97.103.102.97.2673808.1195	.1.3.6.1.4.1.26138.2.119.5.2.1.1.2.100.101.102.97.103.102.97.2673808.1195	Integer	debug (7)
ibICLogLevel.3.100.103.102.97.2673808.1195.2.1.1.3.100.101.102.97.103.102.97.2673808.1195	.1.3.6.1.4.1.26138.2.119.5.2.1.1.3.100.101.102.97.103.102.97.2673808.1195	Integer	informational (6)
ibICLogLevel.4.100.103.102.97.2673808.1195.2.1.1.4.100.101.102.97.103.102.97.2673808.1195	.1.3.6.1.4.1.26138.2.119.5.2.1.1.4.100.101.102.97.103.102.97.2673808.1195	Integer	informational (6)

Name	OID	Value Type	Value Example
ibCLogLevel.5.100.103.1.02497.26	1.3.6.1.4.1.22978.1.1.5.2.1.1.5.100.101.102.97	Integer	informational (6)
ibCLogLevel.9.100.103.1.02497.26	1.3.6.1.4.1.22978.1.1.5.2.1.1.9.100.101.102.97	Integer	debug (7)
ibCLogRowStatus.11196.104.1.02497.26	1.3.6.1.4.1.22978.1.1.195.2.16.2.1.100.101.102.97	Integer	active (1)
ibCLogRowStatus.21196.104.1.02497.26	1.3.6.1.4.1.22978.1.1.195.2.16.2.2.100.101.102.97	Integer	active (1)
ibCLogRowStatus.31196.104.1.02497.26	1.3.6.1.4.1.22978.1.1.195.2.16.2.3.100.101.102.97	Integer	active (1)
ibCLogRowStatus.41196.104.1.02497.26	1.3.6.1.4.1.22978.1.1.195.2.16.2.4.100.101.102.97	Integer	active (1)
ibCLogRowStatus.51196.104.1.02497.26	1.3.6.1.4.1.22978.1.1.195.2.16.2.5.100.101.102.97	Integer	active (1)
ibCLogRowStatus.91196.104.1.02497.26	1.3.6.1.4.1.22978.1.1.195.2.16.2.9.100.101.102.97	Integer	active (1)
ibDhcpServer2Enabled.0	.1.3.6.1.4.1.26138.2.122.1.1.1.0	Integer	true (1)
ibDhcpServer2AlwaysBroadcast.0	.1.3.6.1.4.1.26138.2.122.1.1.2.0	Integer	false (2)
ibDhcpServer2IgnoreBootp.0	.1.3.6.1.4.1.26138.2.122.1.1.3.0	Integer	false (2)
ibDhcpServer2BootpReplyRfc1048.0	.1.3.6.1.4.1.26138.2.122.1.1.4.0	Integer	false (2)
ibDhcpServer2Opt82Enabled.0	.1.3.6.1.4.1.26138.2.122.1.1.5.0	Integer	true (1)
ibDhcpServer2PingNumber.0	.1.3.6.1.4.1.26138.2.122.1.1.6.0	Gauge	1
ibDhcpServer2PingTimeout.0	.1.3.6.1.4.1.26138.2.122.1.1.7.0	Gauge	500
ibDhcpServer2TotalPoolUsage.0	.1.3.6.1.4.1.26138.2.122.1.2.12.0	Gauge	0
ibDhcpServer2PoolNumber.0	.1.3.6.1.4.1.26138.2.122.1.2.13.0	Gauge	0
ibDhcpServer2ConflictNum.0	.1.3.6.1.4.1.26138.2.122.1.2.14.0	Gauge	0
ibDhcpServer2AutoBindNum.0	.1.3.6.1.4.1.26138.2.122.1.2.15.0	Gauge	0
ibDhcpServer2ManualBindNum.0	.1.3.6.1.4.1.26138.2.122.1.2.16.0	Gauge	0
ibDhcpServer2ExpiredBindNum.0	.1.3.6.1.4.1.26138.2.122.1.2.17.0	Gauge	0
ibDhcpServer2IfApplyPoolName.634	1.3.6.1.4.1.26138.2.122.2.2.1.1.634	OctetString	
ibDhcpRelay2UserInfoRecord.0	.1.3.6.1.4.1.26138.2.122.3.1.1.0	Integer	false (2)
ibDhcpRelay2UserInfoRefresh.0	.1.3.6.1.4.1.26138.2.122.3.1.2.0	Integer	true (1)
ibDhcpRelay2UserInfoFlushTime.0	.1.3.6.1.4.1.26138.2.122.3.1.3.0	Gauge	0
ibDhcpRelay2ReleaseAddr.0	.1.3.6.1.4.1.26138.2.122.3.1.4.0	OctetString	
ibDhcpRelay2IfSelectRelay.634	1.3.6.1.4.1.26138.2.122.4.1.1.1.634	Integer	false (2)
ibDhcpRelay2IfCheckMac.634	1.3.6.1.4.1.26138.2.122.4.1.1.2.634	Integer	false (2)
ibDhcpRelay2IfOpt82Enable.634	1.3.6.1.4.1.26138.2.122.4.1.1.3.634	Integer	false (2)
ibDhcpRelay2IfOpt82Strategy.634	1.3.6.1.4.1.26138.2.122.4.1.1.4.634	Integer	replace (3)
ibDhcpRelay2IfOpt82CIDMode.634	1.3.6.1.4.1.26138.2.122.4.1.1.5.634	Integer	normal (1)
ibDhcpRelay2IfOpt82CIDNodeType.634	1.3.6.1.4.1.26138.2.122.4.1.1.6.634	Integer	invalid (1)
ibDhcpRelay2IfOpt82CIDNodeStr.634	1.3.6.1.4.1.26138.2.122.4.1.1.7.634	OctetString	



Name	OID	Value Type	Value Example
ibDhcpRelay2IfOpt82-CIDStr.634	.1.3.6.1.4.1.26138.2.122.4.1.1.8.634	OctetString	
ibDhcpRelay2IfOpt82CIDFormat.634	.1.3.6.1.4.1.26138.2.122.4.1.1.9.634	Integer	hex (1)
ibDhcpRelay2IfOpt82RID-Mode.634	.1.3.6.1.4.1.26138.2.122.4.1.1.10.634	Integer	normal (1)
ibDhcpRelay2IfOpt82-RIDStr.634	.1.3.6.1.4.1.26138.2.122.4.1.1.11.634	OctetString	
ibDhcpRelay2IfOpt82RIDFormat.634	.1.3.6.1.4.1.26138.2.122.4.1.1.12.634	Integer	hex (1)
ibDhcpSnoop2Enabled.0	.1.3.6.1.4.1.26138.2.124.1.1.1.0	Integer	true (1)
ibDhcpSnoop2BindDbName.0	.1.3.6.1.4.1.26138.2.124.1.1.2.0	OctetString	
ibDhcpSnoop2BindRefreshIntvl.0	.1.3.6.1.4.1.26138.2.124.1.1.3.0	Gauge	300
ibDhcpSnoop2BindRefresh.0	.1.3.6.1.4.1.26138.2.124.1.1.4.0	Integer	on (1)
ibDhcpSnoop2IfTrustStatus.1	.1.3.6.1.4.1.26138.2.124.2.2.1.1.1	Integer	trusted (1)
ibDhcpSnoop2IfTrustStatus.2	.1.3.6.1.4.1.26138.2.124.2.2.1.1.2	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.3	.1.3.6.1.4.1.26138.2.124.2.2.1.1.3	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.4	.1.3.6.1.4.1.26138.2.124.2.2.1.1.4	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.5	.1.3.6.1.4.1.26138.2.124.2.2.1.1.5	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.6	.1.3.6.1.4.1.26138.2.124.2.2.1.1.6	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.7	.1.3.6.1.4.1.26138.2.124.2.2.1.1.7	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.8	.1.3.6.1.4.1.26138.2.124.2.2.1.1.8	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.9	.1.3.6.1.4.1.26138.2.124.2.2.1.1.9	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.10	.1.3.6.1.4.1.26138.2.124.2.2.1.1.10	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.11	.1.3.6.1.4.1.26138.2.124.2.2.1.1.11	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.12	.1.3.6.1.4.1.26138.2.124.2.2.1.1.12	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.13	.1.3.6.1.4.1.26138.2.124.2.2.1.1.13	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.14	.1.3.6.1.4.1.26138.2.124.2.2.1.1.14	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.15	.1.3.6.1.4.1.26138.2.124.2.2.1.1.15	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.16	.1.3.6.1.4.1.26138.2.124.2.2.1.1.16	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.17	.1.3.6.1.4.1.26138.2.124.2.2.1.1.17	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.18	.1.3.6.1.4.1.26138.2.124.2.2.1.1.18	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.19	.1.3.6.1.4.1.26138.2.124.2.2.1.1.19	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.20	.1.3.6.1.4.1.26138.2.124.2.2.1.1.20	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.21	.1.3.6.1.4.1.26138.2.124.2.2.1.1.21	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.22	.1.3.6.1.4.1.26138.2.124.2.2.1.1.22	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.23	.1.3.6.1.4.1.26138.2.124.2.2.1.1.23	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.24	.1.3.6.1.4.1.26138.2.124.2.2.1.1.24	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.25	.1.3.6.1.4.1.26138.2.124.2.2.1.1.25	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.26	.1.3.6.1.4.1.26138.2.124.2.2.1.1.26	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.27	.1.3.6.1.4.1.26138.2.124.2.2.1.1.27	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.28	.1.3.6.1.4.1.26138.2.124.2.2.1.1.28	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.29	.1.3.6.1.4.1.26138.2.124.2.2.1.1.29	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.30	.1.3.6.1.4.1.26138.2.124.2.2.1.1.30	Integer	untrusted (0)

Name	OID	Value Type	Value Example
ibDhcpSnoop2IfTrustStatus.31	.1.3.6.1.4.1.26138.2.124.2.2.1.1.31	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.32	.1.3.6.1.4.1.26138.2.124.2.2.1.1.32	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.33	.1.3.6.1.4.1.26138.2.124.2.2.1.1.33	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.34	.1.3.6.1.4.1.26138.2.124.2.2.1.1.34	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.35	.1.3.6.1.4.1.26138.2.124.2.2.1.1.35	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.36	.1.3.6.1.4.1.26138.2.124.2.2.1.1.36	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.37	.1.3.6.1.4.1.26138.2.124.2.2.1.1.37	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.38	.1.3.6.1.4.1.26138.2.124.2.2.1.1.38	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.39	.1.3.6.1.4.1.26138.2.124.2.2.1.1.39	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.40	.1.3.6.1.4.1.26138.2.124.2.2.1.1.40	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.41	.1.3.6.1.4.1.26138.2.124.2.2.1.1.41	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.42	.1.3.6.1.4.1.26138.2.124.2.2.1.1.42	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.43	.1.3.6.1.4.1.26138.2.124.2.2.1.1.43	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.44	.1.3.6.1.4.1.26138.2.124.2.2.1.1.44	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.45	.1.3.6.1.4.1.26138.2.124.2.2.1.1.45	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.46	.1.3.6.1.4.1.26138.2.124.2.2.1.1.46	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.47	.1.3.6.1.4.1.26138.2.124.2.2.1.1.47	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.48	.1.3.6.1.4.1.26138.2.124.2.2.1.1.48	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.49	.1.3.6.1.4.1.26138.2.124.2.2.1.1.49	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.50	.1.3.6.1.4.1.26138.2.124.2.2.1.1.50	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.51	.1.3.6.1.4.1.26138.2.124.2.2.1.1.51	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.52	.1.3.6.1.4.1.26138.2.124.2.2.1.1.52	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.53	.1.3.6.1.4.1.26138.2.124.2.2.1.1.53	Integer	untrusted (0)
ibDhcpSnoop2IfTrustStatus.54	.1.3.6.1.4.1.26138.2.124.2.2.1.1.54	Integer	untrusted (0)
ibDhcpSnoop2IfCheckMac.1	.1.3.6.1.4.1.26138.2.124.2.2.1.2.1	Integer	false (2)
ibDhcpSnoop2IfCheckMac.2	.1.3.6.1.4.1.26138.2.124.2.2.1.2.2	Integer	false (2)
ibDhcpSnoop2IfCheckMac.3	.1.3.6.1.4.1.26138.2.124.2.2.1.2.3	Integer	false (2)
ibDhcpSnoop2IfCheckMac.4	.1.3.6.1.4.1.26138.2.124.2.2.1.2.4	Integer	false (2)
ibDhcpSnoop2IfCheckMac.5	.1.3.6.1.4.1.26138.2.124.2.2.1.2.5	Integer	false (2)
ibDhcpSnoop2IfCheckMac.6	.1.3.6.1.4.1.26138.2.124.2.2.1.2.6	Integer	false (2)
ibDhcpSnoop2IfCheckMac.7	.1.3.6.1.4.1.26138.2.124.2.2.1.2.7	Integer	false (2)
ibDhcpSnoop2IfCheckMac.8	.1.3.6.1.4.1.26138.2.124.2.2.1.2.8	Integer	false (2)
ibDhcpSnoop2IfCheckMac.9	.1.3.6.1.4.1.26138.2.124.2.2.1.2.9	Integer	false (2)
ibDhcpSnoop2IfCheckMac.10	.1.3.6.1.4.1.26138.2.124.2.2.1.2.10	Integer	false (2)
ibDhcpSnoop2IfCheckMac.11	.1.3.6.1.4.1.26138.2.124.2.2.1.2.11	Integer	false (2)
ibDhcpSnoop2IfCheckMac.12	.1.3.6.1.4.1.26138.2.124.2.2.1.2.12	Integer	false (2)
ibDhcpSnoop2IfCheckMac.13	.1.3.6.1.4.1.26138.2.124.2.2.1.2.13	Integer	false (2)
ibDhcpSnoop2IfCheckMac.14	.1.3.6.1.4.1.26138.2.124.2.2.1.2.14	Integer	false (2)
ibDhcpSnoop2IfCheckMac.15	.1.3.6.1.4.1.26138.2.124.2.2.1.2.15	Integer	false (2)
ibDhcpSnoop2IfCheckMac.16	.1.3.6.1.4.1.26138.2.124.2.2.1.2.16	Integer	false (2)
ibDhcpSnoop2IfCheckMac.17	.1.3.6.1.4.1.26138.2.124.2.2.1.2.17	Integer	false (2)
ibDhcpSnoop2IfCheckMac.18	.1.3.6.1.4.1.26138.2.124.2.2.1.2.18	Integer	false (2)
ibDhcpSnoop2IfCheckMac.19	.1.3.6.1.4.1.26138.2.124.2.2.1.2.19	Integer	false (2)

Name	OID	Value Type	Value Example
ibDhcpSnoop2IfCheckMac.20	.1.3.6.1.4.1.26138.2.124.2.2.1.2.20	Integer	false (2)
ibDhcpSnoop2IfCheckMac.21	.1.3.6.1.4.1.26138.2.124.2.2.1.2.21	Integer	false (2)
ibDhcpSnoop2IfCheckMac.22	.1.3.6.1.4.1.26138.2.124.2.2.1.2.22	Integer	false (2)
ibDhcpSnoop2IfCheckMac.23	.1.3.6.1.4.1.26138.2.124.2.2.1.2.23	Integer	false (2)
ibDhcpSnoop2IfCheckMac.24	.1.3.6.1.4.1.26138.2.124.2.2.1.2.24	Integer	false (2)
ibDhcpSnoop2IfCheckMac.25	.1.3.6.1.4.1.26138.2.124.2.2.1.2.25	Integer	false (2)
ibDhcpSnoop2IfCheckMac.26	.1.3.6.1.4.1.26138.2.124.2.2.1.2.26	Integer	false (2)
ibDhcpSnoop2IfCheckMac.27	.1.3.6.1.4.1.26138.2.124.2.2.1.2.27	Integer	false (2)
ibDhcpSnoop2IfCheckMac.28	.1.3.6.1.4.1.26138.2.124.2.2.1.2.28	Integer	false (2)
ibDhcpSnoop2IfCheckMac.29	.1.3.6.1.4.1.26138.2.124.2.2.1.2.29	Integer	false (2)
ibDhcpSnoop2IfCheckMac.30	.1.3.6.1.4.1.26138.2.124.2.2.1.2.30	Integer	false (2)
ibDhcpSnoop2IfCheckMac.31	.1.3.6.1.4.1.26138.2.124.2.2.1.2.31	Integer	false (2)
ibDhcpSnoop2IfCheckMac.32	.1.3.6.1.4.1.26138.2.124.2.2.1.2.32	Integer	false (2)
ibDhcpSnoop2IfCheckMac.33	.1.3.6.1.4.1.26138.2.124.2.2.1.2.33	Integer	false (2)
ibDhcpSnoop2IfCheckMac.34	.1.3.6.1.4.1.26138.2.124.2.2.1.2.34	Integer	false (2)
ibDhcpSnoop2IfCheckMac.35	.1.3.6.1.4.1.26138.2.124.2.2.1.2.35	Integer	false (2)
ibDhcpSnoop2IfCheckMac.36	.1.3.6.1.4.1.26138.2.124.2.2.1.2.36	Integer	false (2)
ibDhcpSnoop2IfCheckMac.37	.1.3.6.1.4.1.26138.2.124.2.2.1.2.37	Integer	false (2)
ibDhcpSnoop2IfCheckMac.38	.1.3.6.1.4.1.26138.2.124.2.2.1.2.38	Integer	false (2)
ibDhcpSnoop2IfCheckMac.39	.1.3.6.1.4.1.26138.2.124.2.2.1.2.39	Integer	false (2)
ibDhcpSnoop2IfCheckMac.40	.1.3.6.1.4.1.26138.2.124.2.2.1.2.40	Integer	false (2)
ibDhcpSnoop2IfCheckMac.41	.1.3.6.1.4.1.26138.2.124.2.2.1.2.41	Integer	false (2)
ibDhcpSnoop2IfCheckMac.42	.1.3.6.1.4.1.26138.2.124.2.2.1.2.42	Integer	false (2)
ibDhcpSnoop2IfCheckMac.43	.1.3.6.1.4.1.26138.2.124.2.2.1.2.43	Integer	false (2)
ibDhcpSnoop2IfCheckMac.44	.1.3.6.1.4.1.26138.2.124.2.2.1.2.44	Integer	false (2)
ibDhcpSnoop2IfCheckMac.45	.1.3.6.1.4.1.26138.2.124.2.2.1.2.45	Integer	false (2)
ibDhcpSnoop2IfCheckMac.46	.1.3.6.1.4.1.26138.2.124.2.2.1.2.46	Integer	false (2)
ibDhcpSnoop2IfCheckMac.47	.1.3.6.1.4.1.26138.2.124.2.2.1.2.47	Integer	false (2)
ibDhcpSnoop2IfCheckMac.48	.1.3.6.1.4.1.26138.2.124.2.2.1.2.48	Integer	false (2)
ibDhcpSnoop2IfCheckMac.49	.1.3.6.1.4.1.26138.2.124.2.2.1.2.49	Integer	false (2)
ibDhcpSnoop2IfCheckMac.50	.1.3.6.1.4.1.26138.2.124.2.2.1.2.50	Integer	false (2)
ibDhcpSnoop2IfCheckMac.51	.1.3.6.1.4.1.26138.2.124.2.2.1.2.51	Integer	false (2)
ibDhcpSnoop2IfCheckMac.52	.1.3.6.1.4.1.26138.2.124.2.2.1.2.52	Integer	false (2)
ibDhcpSnoop2IfCheckMac.53	.1.3.6.1.4.1.26138.2.124.2.2.1.2.53	Integer	false (2)
ibDhcpSnoop2IfCheckMac.54	.1.3.6.1.4.1.26138.2.124.2.2.1.2.54	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.1	.1.3.6.1.4.1.26138.2.124.2.2.1.3.1	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.2	.1.3.6.1.4.1.26138.2.124.2.2.1.3.2	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.3	.1.3.6.1.4.1.26138.2.124.2.2.1.3.3	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.4	.1.3.6.1.4.1.26138.2.124.2.2.1.3.4	Integer	false (2)

Name	OID	Value Type	Value Example
ibDhcpSnoop2IfCheckRequest.5	.1.3.6.1.4.1.26138.2.124.2.2.1.3.5	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.6	.1.3.6.1.4.1.26138.2.124.2.2.1.3.6	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.7	.1.3.6.1.4.1.26138.2.124.2.2.1.3.7	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.8	.1.3.6.1.4.1.26138.2.124.2.2.1.3.8	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.9	.1.3.6.1.4.1.26138.2.124.2.2.1.3.9	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.10	.1.3.6.1.4.1.26138.2.124.2.2.1.3.10	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.11	.1.3.6.1.4.1.26138.2.124.2.2.1.3.11	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.12	.1.3.6.1.4.1.26138.2.124.2.2.1.3.12	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.13	.1.3.6.1.4.1.26138.2.124.2.2.1.3.13	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.14	.1.3.6.1.4.1.26138.2.124.2.2.1.3.14	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.15	.1.3.6.1.4.1.26138.2.124.2.2.1.3.15	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.16	.1.3.6.1.4.1.26138.2.124.2.2.1.3.16	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.17	.1.3.6.1.4.1.26138.2.124.2.2.1.3.17	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.18	.1.3.6.1.4.1.26138.2.124.2.2.1.3.18	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.19	.1.3.6.1.4.1.26138.2.124.2.2.1.3.19	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.20	.1.3.6.1.4.1.26138.2.124.2.2.1.3.20	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.21	.1.3.6.1.4.1.26138.2.124.2.2.1.3.21	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.22	.1.3.6.1.4.1.26138.2.124.2.2.1.3.22	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.23	.1.3.6.1.4.1.26138.2.124.2.2.1.3.23	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.24	.1.3.6.1.4.1.26138.2.124.2.2.1.3.24	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.25	.1.3.6.1.4.1.26138.2.124.2.2.1.3.25	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.26	.1.3.6.1.4.1.26138.2.124.2.2.1.3.26	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.27	.1.3.6.1.4.1.26138.2.124.2.2.1.3.27	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.28	.1.3.6.1.4.1.26138.2.124.2.2.1.3.28	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.29	.1.3.6.1.4.1.26138.2.124.2.2.1.3.29	Integer	false (2)

Name	OID	Value Type	Value Example
ibDhcpSnoop2IfCheckRequest.30	.1.3.6.1.4.1.26138.2.124.2.2.1.3.30	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.31	.1.3.6.1.4.1.26138.2.124.2.2.1.3.31	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.32	.1.3.6.1.4.1.26138.2.124.2.2.1.3.32	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.33	.1.3.6.1.4.1.26138.2.124.2.2.1.3.33	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.34	.1.3.6.1.4.1.26138.2.124.2.2.1.3.34	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.35	.1.3.6.1.4.1.26138.2.124.2.2.1.3.35	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.36	.1.3.6.1.4.1.26138.2.124.2.2.1.3.36	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.37	.1.3.6.1.4.1.26138.2.124.2.2.1.3.37	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.38	.1.3.6.1.4.1.26138.2.124.2.2.1.3.38	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.39	.1.3.6.1.4.1.26138.2.124.2.2.1.3.39	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.40	.1.3.6.1.4.1.26138.2.124.2.2.1.3.40	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.41	.1.3.6.1.4.1.26138.2.124.2.2.1.3.41	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.42	.1.3.6.1.4.1.26138.2.124.2.2.1.3.42	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.43	.1.3.6.1.4.1.26138.2.124.2.2.1.3.43	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.44	.1.3.6.1.4.1.26138.2.124.2.2.1.3.44	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.45	.1.3.6.1.4.1.26138.2.124.2.2.1.3.45	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.46	.1.3.6.1.4.1.26138.2.124.2.2.1.3.46	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.47	.1.3.6.1.4.1.26138.2.124.2.2.1.3.47	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.48	.1.3.6.1.4.1.26138.2.124.2.2.1.3.48	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.49	.1.3.6.1.4.1.26138.2.124.2.2.1.3.49	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.50	.1.3.6.1.4.1.26138.2.124.2.2.1.3.50	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.51	.1.3.6.1.4.1.26138.2.124.2.2.1.3.51	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.52	.1.3.6.1.4.1.26138.2.124.2.2.1.3.52	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.53	.1.3.6.1.4.1.26138.2.124.2.2.1.3.53	Integer	false (2)
ibDhcpSnoop2IfCheckRequest.54	.1.3.6.1.4.1.26138.2.124.2.2.1.3.54	Integer	false (2)
ibDhcpSnoop2IfRateLimit.1	.1.3.6.1.4.1.26138.2.124.2.2.1.4.1	Gauge	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ibDhcpSnoop2IfRateLimit.2	.1.3.6.1.4.1.26138.2.124.2.2.1.4.2	Gauge	0
ibDhcpSnoop2IfRateLimit.3	.1.3.6.1.4.1.26138.2.124.2.2.1.4.3	Gauge	0
ibDhcpSnoop2IfRateLimit.4	.1.3.6.1.4.1.26138.2.124.2.2.1.4.4	Gauge	0
ibDhcpSnoop2IfRateLimit.5	.1.3.6.1.4.1.26138.2.124.2.2.1.4.5	Gauge	0
ibDhcpSnoop2IfRateLimit.6	.1.3.6.1.4.1.26138.2.124.2.2.1.4.6	Gauge	0
ibDhcpSnoop2IfRateLimit.7	.1.3.6.1.4.1.26138.2.124.2.2.1.4.7	Gauge	0
ibDhcpSnoop2IfRateLimit.8	.1.3.6.1.4.1.26138.2.124.2.2.1.4.8	Gauge	0
ibDhcpSnoop2IfRateLimit.9	.1.3.6.1.4.1.26138.2.124.2.2.1.4.9	Gauge	0
ibDhcpSnoop2IfRateLimit.10	.1.3.6.1.4.1.26138.2.124.2.2.1.4.10	Gauge	0
ibDhcpSnoop2IfRateLimit.11	.1.3.6.1.4.1.26138.2.124.2.2.1.4.11	Gauge	0
ibDhcpSnoop2IfRateLimit.12	.1.3.6.1.4.1.26138.2.124.2.2.1.4.12	Gauge	0
ibDhcpSnoop2IfRateLimit.13	.1.3.6.1.4.1.26138.2.124.2.2.1.4.13	Gauge	0
ibDhcpSnoop2IfRateLimit.14	.1.3.6.1.4.1.26138.2.124.2.2.1.4.14	Gauge	0
ibDhcpSnoop2IfRateLimit.15	.1.3.6.1.4.1.26138.2.124.2.2.1.4.15	Gauge	0
ibDhcpSnoop2IfRateLimit.16	.1.3.6.1.4.1.26138.2.124.2.2.1.4.16	Gauge	0
ibDhcpSnoop2IfRateLimit.17	.1.3.6.1.4.1.26138.2.124.2.2.1.4.17	Gauge	0
ibDhcpSnoop2IfRateLimit.18	.1.3.6.1.4.1.26138.2.124.2.2.1.4.18	Gauge	0
ibDhcpSnoop2IfRateLimit.19	.1.3.6.1.4.1.26138.2.124.2.2.1.4.19	Gauge	0
ibDhcpSnoop2IfRateLimit.20	.1.3.6.1.4.1.26138.2.124.2.2.1.4.20	Gauge	0
ibDhcpSnoop2IfRateLimit.21	.1.3.6.1.4.1.26138.2.124.2.2.1.4.21	Gauge	0
ibDhcpSnoop2IfRateLimit.22	.1.3.6.1.4.1.26138.2.124.2.2.1.4.22	Gauge	0
ibDhcpSnoop2IfRateLimit.23	.1.3.6.1.4.1.26138.2.124.2.2.1.4.23	Gauge	0
ibDhcpSnoop2IfRateLimit.24	.1.3.6.1.4.1.26138.2.124.2.2.1.4.24	Gauge	0
ibDhcpSnoop2IfRateLimit.25	.1.3.6.1.4.1.26138.2.124.2.2.1.4.25	Gauge	0
ibDhcpSnoop2IfRateLimit.26	.1.3.6.1.4.1.26138.2.124.2.2.1.4.26	Gauge	0
ibDhcpSnoop2IfRateLimit.27	.1.3.6.1.4.1.26138.2.124.2.2.1.4.27	Gauge	0
ibDhcpSnoop2IfRateLimit.28	.1.3.6.1.4.1.26138.2.124.2.2.1.4.28	Gauge	0
ibDhcpSnoop2IfRateLimit.29	.1.3.6.1.4.1.26138.2.124.2.2.1.4.29	Gauge	0
ibDhcpSnoop2IfRateLimit.30	.1.3.6.1.4.1.26138.2.124.2.2.1.4.30	Gauge	0
ibDhcpSnoop2IfRateLimit.31	.1.3.6.1.4.1.26138.2.124.2.2.1.4.31	Gauge	0
ibDhcpSnoop2IfRateLimit.32	.1.3.6.1.4.1.26138.2.124.2.2.1.4.32	Gauge	0
ibDhcpSnoop2IfRateLimit.33	.1.3.6.1.4.1.26138.2.124.2.2.1.4.33	Gauge	0
ibDhcpSnoop2IfRateLimit.34	.1.3.6.1.4.1.26138.2.124.2.2.1.4.34	Gauge	0
ibDhcpSnoop2IfRateLimit.35	.1.3.6.1.4.1.26138.2.124.2.2.1.4.35	Gauge	0
ibDhcpSnoop2IfRateLimit.36	.1.3.6.1.4.1.26138.2.124.2.2.1.4.36	Gauge	0
ibDhcpSnoop2IfRateLimit.37	.1.3.6.1.4.1.26138.2.124.2.2.1.4.37	Gauge	0
ibDhcpSnoop2IfRateLimit.38	.1.3.6.1.4.1.26138.2.124.2.2.1.4.38	Gauge	0
ibDhcpSnoop2IfRateLimit.39	.1.3.6.1.4.1.26138.2.124.2.2.1.4.39	Gauge	0
ibDhcpSnoop2IfRateLimit.40	.1.3.6.1.4.1.26138.2.124.2.2.1.4.40	Gauge	0
ibDhcpSnoop2IfRateLimit.41	.1.3.6.1.4.1.26138.2.124.2.2.1.4.41	Gauge	0
ibDhcpSnoop2IfRateLimit.42	.1.3.6.1.4.1.26138.2.124.2.2.1.4.42	Gauge	0
ibDhcpSnoop2IfRateLimit.43	.1.3.6.1.4.1.26138.2.124.2.2.1.4.43	Gauge	0
ibDhcpSnoop2IfRateLimit.44	.1.3.6.1.4.1.26138.2.124.2.2.1.4.44	Gauge	0

Name	OID	Value Type	Value Example
ibDhcpSnoop2IfRateLimit.45	.1.3.6.1.4.1.26138.2.124.2.2.1.4.45	Gauge	0
ibDhcpSnoop2IfRateLimit.46	.1.3.6.1.4.1.26138.2.124.2.2.1.4.46	Gauge	0
ibDhcpSnoop2IfRateLimit.47	.1.3.6.1.4.1.26138.2.124.2.2.1.4.47	Gauge	0
ibDhcpSnoop2IfRateLimit.48	.1.3.6.1.4.1.26138.2.124.2.2.1.4.48	Gauge	0
ibDhcpSnoop2IfRateLimit.49	.1.3.6.1.4.1.26138.2.124.2.2.1.4.49	Gauge	0
ibDhcpSnoop2IfRateLimit.50	.1.3.6.1.4.1.26138.2.124.2.2.1.4.50	Gauge	0
ibDhcpSnoop2IfRateLimit.51	.1.3.6.1.4.1.26138.2.124.2.2.1.4.51	Gauge	0
ibDhcpSnoop2IfRateLimit.52	.1.3.6.1.4.1.26138.2.124.2.2.1.4.52	Gauge	0
ibDhcpSnoop2IfRateLimit.53	.1.3.6.1.4.1.26138.2.124.2.2.1.4.53	Gauge	0
ibDhcpSnoop2IfRateLimit.54	.1.3.6.1.4.1.26138.2.124.2.2.1.4.54	Gauge	0
ibDhcpSnoop2IfRecordBind.1	.1.3.6.1.4.1.26138.2.124.2.2.1.5.1	Integer	false (2)
ibDhcpSnoop2IfRecordBind.2	.1.3.6.1.4.1.26138.2.124.2.2.1.5.2	Integer	false (2)
ibDhcpSnoop2IfRecordBind.3	.1.3.6.1.4.1.26138.2.124.2.2.1.5.3	Integer	false (2)
ibDhcpSnoop2IfRecordBind.4	.1.3.6.1.4.1.26138.2.124.2.2.1.5.4	Integer	false (2)
ibDhcpSnoop2IfRecordBind.5	.1.3.6.1.4.1.26138.2.124.2.2.1.5.5	Integer	false (2)
ibDhcpSnoop2IfRecordBind.6	.1.3.6.1.4.1.26138.2.124.2.2.1.5.6	Integer	false (2)
ibDhcpSnoop2IfRecordBind.7	.1.3.6.1.4.1.26138.2.124.2.2.1.5.7	Integer	false (2)
ibDhcpSnoop2IfRecordBind.8	.1.3.6.1.4.1.26138.2.124.2.2.1.5.8	Integer	false (2)
ibDhcpSnoop2IfRecordBind.9	.1.3.6.1.4.1.26138.2.124.2.2.1.5.9	Integer	false (2)
ibDhcpSnoop2IfRecordBind.10	.1.3.6.1.4.1.26138.2.124.2.2.1.5.10	Integer	false (2)
ibDhcpSnoop2IfRecordBind.11	.1.3.6.1.4.1.26138.2.124.2.2.1.5.11	Integer	false (2)
ibDhcpSnoop2IfRecordBind.12	.1.3.6.1.4.1.26138.2.124.2.2.1.5.12	Integer	false (2)
ibDhcpSnoop2IfRecordBind.13	.1.3.6.1.4.1.26138.2.124.2.2.1.5.13	Integer	false (2)
ibDhcpSnoop2IfRecordBind.14	.1.3.6.1.4.1.26138.2.124.2.2.1.5.14	Integer	false (2)
ibDhcpSnoop2IfRecordBind.15	.1.3.6.1.4.1.26138.2.124.2.2.1.5.15	Integer	false (2)
ibDhcpSnoop2IfRecordBind.16	.1.3.6.1.4.1.26138.2.124.2.2.1.5.16	Integer	false (2)
ibDhcpSnoop2IfRecordBind.17	.1.3.6.1.4.1.26138.2.124.2.2.1.5.17	Integer	false (2)
ibDhcpSnoop2IfRecordBind.18	.1.3.6.1.4.1.26138.2.124.2.2.1.5.18	Integer	false (2)
ibDhcpSnoop2IfRecordBind.19	.1.3.6.1.4.1.26138.2.124.2.2.1.5.19	Integer	false (2)
ibDhcpSnoop2IfRecordBind.20	.1.3.6.1.4.1.26138.2.124.2.2.1.5.20	Integer	false (2)
ibDhcpSnoop2IfRecordBind.21	.1.3.6.1.4.1.26138.2.124.2.2.1.5.21	Integer	false (2)
ibDhcpSnoop2IfRecordBind.22	.1.3.6.1.4.1.26138.2.124.2.2.1.5.22	Integer	false (2)
ibDhcpSnoop2IfRecordBind.23	.1.3.6.1.4.1.26138.2.124.2.2.1.5.23	Integer	false (2)
ibDhcpSnoop2IfRecordBind.24	.1.3.6.1.4.1.26138.2.124.2.2.1.5.24	Integer	false (2)
ibDhcpSnoop2IfRecordBind.25	.1.3.6.1.4.1.26138.2.124.2.2.1.5.25	Integer	false (2)
ibDhcpSnoop2IfRecordBind.26	.1.3.6.1.4.1.26138.2.124.2.2.1.5.26	Integer	false (2)
ibDhcpSnoop2IfRecordBind.27	.1.3.6.1.4.1.26138.2.124.2.2.1.5.27	Integer	false (2)
ibDhcpSnoop2IfRecordBind.28	.1.3.6.1.4.1.26138.2.124.2.2.1.5.28	Integer	false (2)
ibDhcpSnoop2IfRecordBind.29	.1.3.6.1.4.1.26138.2.124.2.2.1.5.29	Integer	false (2)
ibDhcpSnoop2IfRecordBind.30	.1.3.6.1.4.1.26138.2.124.2.2.1.5.30	Integer	false (2)
ibDhcpSnoop2IfRecordBind.31	.1.3.6.1.4.1.26138.2.124.2.2.1.5.31	Integer	false (2)
ibDhcpSnoop2IfRecordBind.32	.1.3.6.1.4.1.26138.2.124.2.2.1.5.32	Integer	false (2)
ibDhcpSnoop2IfRecordBind.33	.1.3.6.1.4.1.26138.2.124.2.2.1.5.33	Integer	false (2)



Name	OID	Value Type	Value Example
ibDhcpSnoop2IfRecordBind.34	.1.3.6.1.4.1.26138.2.124.2.2.1.5.34	Integer	false (2)
ibDhcpSnoop2IfRecordBind.35	.1.3.6.1.4.1.26138.2.124.2.2.1.5.35	Integer	false (2)
ibDhcpSnoop2IfRecordBind.36	.1.3.6.1.4.1.26138.2.124.2.2.1.5.36	Integer	false (2)
ibDhcpSnoop2IfRecordBind.37	.1.3.6.1.4.1.26138.2.124.2.2.1.5.37	Integer	false (2)
ibDhcpSnoop2IfRecordBind.38	.1.3.6.1.4.1.26138.2.124.2.2.1.5.38	Integer	false (2)
ibDhcpSnoop2IfRecordBind.39	.1.3.6.1.4.1.26138.2.124.2.2.1.5.39	Integer	false (2)
ibDhcpSnoop2IfRecordBind.40	.1.3.6.1.4.1.26138.2.124.2.2.1.5.40	Integer	false (2)
ibDhcpSnoop2IfRecordBind.41	.1.3.6.1.4.1.26138.2.124.2.2.1.5.41	Integer	false (2)
ibDhcpSnoop2IfRecordBind.42	.1.3.6.1.4.1.26138.2.124.2.2.1.5.42	Integer	false (2)
ibDhcpSnoop2IfRecordBind.43	.1.3.6.1.4.1.26138.2.124.2.2.1.5.43	Integer	false (2)
ibDhcpSnoop2IfRecordBind.44	.1.3.6.1.4.1.26138.2.124.2.2.1.5.44	Integer	false (2)
ibDhcpSnoop2IfRecordBind.45	.1.3.6.1.4.1.26138.2.124.2.2.1.5.45	Integer	false (2)
ibDhcpSnoop2IfRecordBind.46	.1.3.6.1.4.1.26138.2.124.2.2.1.5.46	Integer	false (2)
ibDhcpSnoop2IfRecordBind.47	.1.3.6.1.4.1.26138.2.124.2.2.1.5.47	Integer	false (2)
ibDhcpSnoop2IfRecordBind.48	.1.3.6.1.4.1.26138.2.124.2.2.1.5.48	Integer	false (2)
ibDhcpSnoop2IfRecordBind.49	.1.3.6.1.4.1.26138.2.124.2.2.1.5.49	Integer	false (2)
ibDhcpSnoop2IfRecordBind.50	.1.3.6.1.4.1.26138.2.124.2.2.1.5.50	Integer	false (2)
ibDhcpSnoop2IfRecordBind.51	.1.3.6.1.4.1.26138.2.124.2.2.1.5.51	Integer	false (2)
ibDhcpSnoop2IfRecordBind.52	.1.3.6.1.4.1.26138.2.124.2.2.1.5.52	Integer	false (2)
ibDhcpSnoop2IfRecordBind.53	.1.3.6.1.4.1.26138.2.124.2.2.1.5.53	Integer	false (2)
ibDhcpSnoop2IfRecordBind.54	.1.3.6.1.4.1.26138.2.124.2.2.1.5.54	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.1	.1.3.6.1.4.1.26138.2.124.2.2.1.7.1	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.2	.1.3.6.1.4.1.26138.2.124.2.2.1.7.2	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.3	.1.3.6.1.4.1.26138.2.124.2.2.1.7.3	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.4	.1.3.6.1.4.1.26138.2.124.2.2.1.7.4	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.5	.1.3.6.1.4.1.26138.2.124.2.2.1.7.5	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.6	.1.3.6.1.4.1.26138.2.124.2.2.1.7.6	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.7	.1.3.6.1.4.1.26138.2.124.2.2.1.7.7	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.8	.1.3.6.1.4.1.26138.2.124.2.2.1.7.8	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.9	.1.3.6.1.4.1.26138.2.124.2.2.1.7.9	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.10	.1.3.6.1.4.1.26138.2.124.2.2.1.7.10	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.11	.1.3.6.1.4.1.26138.2.124.2.2.1.7.11	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.12	.1.3.6.1.4.1.26138.2.124.2.2.1.7.12	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.13	.1.3.6.1.4.1.26138.2.124.2.2.1.7.13	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.14	.1.3.6.1.4.1.26138.2.124.2.2.1.7.14	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.15	.1.3.6.1.4.1.26138.2.124.2.2.1.7.15	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.16	.1.3.6.1.4.1.26138.2.124.2.2.1.7.16	Integer	false (2)

Name	OID	Value Type	Value Example
ibDhcpSnoop2IfOpt82Enable.17	.1.3.6.1.4.1.26138.2.124.2.2.1.7.17	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.18	.1.3.6.1.4.1.26138.2.124.2.2.1.7.18	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.19	.1.3.6.1.4.1.26138.2.124.2.2.1.7.19	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.20	.1.3.6.1.4.1.26138.2.124.2.2.1.7.20	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.21	.1.3.6.1.4.1.26138.2.124.2.2.1.7.21	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.22	.1.3.6.1.4.1.26138.2.124.2.2.1.7.22	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.23	.1.3.6.1.4.1.26138.2.124.2.2.1.7.23	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.24	.1.3.6.1.4.1.26138.2.124.2.2.1.7.24	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.25	.1.3.6.1.4.1.26138.2.124.2.2.1.7.25	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.26	.1.3.6.1.4.1.26138.2.124.2.2.1.7.26	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.27	.1.3.6.1.4.1.26138.2.124.2.2.1.7.27	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.28	.1.3.6.1.4.1.26138.2.124.2.2.1.7.28	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.29	.1.3.6.1.4.1.26138.2.124.2.2.1.7.29	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.30	.1.3.6.1.4.1.26138.2.124.2.2.1.7.30	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.31	.1.3.6.1.4.1.26138.2.124.2.2.1.7.31	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.32	.1.3.6.1.4.1.26138.2.124.2.2.1.7.32	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.33	.1.3.6.1.4.1.26138.2.124.2.2.1.7.33	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.34	.1.3.6.1.4.1.26138.2.124.2.2.1.7.34	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.35	.1.3.6.1.4.1.26138.2.124.2.2.1.7.35	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.36	.1.3.6.1.4.1.26138.2.124.2.2.1.7.36	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.37	.1.3.6.1.4.1.26138.2.124.2.2.1.7.37	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.38	.1.3.6.1.4.1.26138.2.124.2.2.1.7.38	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.39	.1.3.6.1.4.1.26138.2.124.2.2.1.7.39	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.40	.1.3.6.1.4.1.26138.2.124.2.2.1.7.40	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.41	.1.3.6.1.4.1.26138.2.124.2.2.1.7.41	Integer	false (2)

Name	OID	Value Type	Value Example
ibDhcpSnoop2IfOpt82Enable.42	.1.3.6.1.4.1.26138.2.124.2.2.1.7.42	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.43	.1.3.6.1.4.1.26138.2.124.2.2.1.7.43	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.44	.1.3.6.1.4.1.26138.2.124.2.2.1.7.44	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.45	.1.3.6.1.4.1.26138.2.124.2.2.1.7.45	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.46	.1.3.6.1.4.1.26138.2.124.2.2.1.7.46	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.47	.1.3.6.1.4.1.26138.2.124.2.2.1.7.47	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.48	.1.3.6.1.4.1.26138.2.124.2.2.1.7.48	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.49	.1.3.6.1.4.1.26138.2.124.2.2.1.7.49	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.50	.1.3.6.1.4.1.26138.2.124.2.2.1.7.50	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.51	.1.3.6.1.4.1.26138.2.124.2.2.1.7.51	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.52	.1.3.6.1.4.1.26138.2.124.2.2.1.7.52	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.53	.1.3.6.1.4.1.26138.2.124.2.2.1.7.53	Integer	false (2)
ibDhcpSnoop2IfOpt82Enable.54	.1.3.6.1.4.1.26138.2.124.2.2.1.7.54	Integer	false (2)
ibDhcpSnoop2IfOpt82Strategy.1	.1.3.6.1.4.1.26138.2.124.2.2.1.8.1	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.2	.1.3.6.1.4.1.26138.2.124.2.2.1.8.2	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.3	.1.3.6.1.4.1.26138.2.124.2.2.1.8.3	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.4	.1.3.6.1.4.1.26138.2.124.2.2.1.8.4	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.5	.1.3.6.1.4.1.26138.2.124.2.2.1.8.5	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.6	.1.3.6.1.4.1.26138.2.124.2.2.1.8.6	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.7	.1.3.6.1.4.1.26138.2.124.2.2.1.8.7	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.8	.1.3.6.1.4.1.26138.2.124.2.2.1.8.8	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.9	.1.3.6.1.4.1.26138.2.124.2.2.1.8.9	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.10	.1.3.6.1.4.1.26138.2.124.2.2.1.8.10	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.11	.1.3.6.1.4.1.26138.2.124.2.2.1.8.11	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.12	.1.3.6.1.4.1.26138.2.124.2.2.1.8.12	Integer	replace (3)

Name	OID	Value Type	Value Example
ibDhcpSnoop2IfOpt82Strategy.13	.1.3.6.1.4.1.26138.2.124.2.2.1.8.13	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.14	.1.3.6.1.4.1.26138.2.124.2.2.1.8.14	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.15	.1.3.6.1.4.1.26138.2.124.2.2.1.8.15	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.16	.1.3.6.1.4.1.26138.2.124.2.2.1.8.16	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.17	.1.3.6.1.4.1.26138.2.124.2.2.1.8.17	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.18	.1.3.6.1.4.1.26138.2.124.2.2.1.8.18	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.19	.1.3.6.1.4.1.26138.2.124.2.2.1.8.19	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.20	.1.3.6.1.4.1.26138.2.124.2.2.1.8.20	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.21	.1.3.6.1.4.1.26138.2.124.2.2.1.8.21	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.22	.1.3.6.1.4.1.26138.2.124.2.2.1.8.22	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.23	.1.3.6.1.4.1.26138.2.124.2.2.1.8.23	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.24	.1.3.6.1.4.1.26138.2.124.2.2.1.8.24	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.25	.1.3.6.1.4.1.26138.2.124.2.2.1.8.25	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.26	.1.3.6.1.4.1.26138.2.124.2.2.1.8.26	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.27	.1.3.6.1.4.1.26138.2.124.2.2.1.8.27	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.28	.1.3.6.1.4.1.26138.2.124.2.2.1.8.28	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.29	.1.3.6.1.4.1.26138.2.124.2.2.1.8.29	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.30	.1.3.6.1.4.1.26138.2.124.2.2.1.8.30	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.31	.1.3.6.1.4.1.26138.2.124.2.2.1.8.31	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.32	.1.3.6.1.4.1.26138.2.124.2.2.1.8.32	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.33	.1.3.6.1.4.1.26138.2.124.2.2.1.8.33	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.34	.1.3.6.1.4.1.26138.2.124.2.2.1.8.34	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.35	.1.3.6.1.4.1.26138.2.124.2.2.1.8.35	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.36	.1.3.6.1.4.1.26138.2.124.2.2.1.8.36	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.37	.1.3.6.1.4.1.26138.2.124.2.2.1.8.37	Integer	replace (3)

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ibDhcpSnoop2IfOpt82Strategy.38	.1.3.6.1.4.1.26138.2.124.2.2.1.8.38	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.39	.1.3.6.1.4.1.26138.2.124.2.2.1.8.39	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.40	.1.3.6.1.4.1.26138.2.124.2.2.1.8.40	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.41	.1.3.6.1.4.1.26138.2.124.2.2.1.8.41	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.42	.1.3.6.1.4.1.26138.2.124.2.2.1.8.42	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.43	.1.3.6.1.4.1.26138.2.124.2.2.1.8.43	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.44	.1.3.6.1.4.1.26138.2.124.2.2.1.8.44	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.45	.1.3.6.1.4.1.26138.2.124.2.2.1.8.45	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.46	.1.3.6.1.4.1.26138.2.124.2.2.1.8.46	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.47	.1.3.6.1.4.1.26138.2.124.2.2.1.8.47	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.48	.1.3.6.1.4.1.26138.2.124.2.2.1.8.48	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.49	.1.3.6.1.4.1.26138.2.124.2.2.1.8.49	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.50	.1.3.6.1.4.1.26138.2.124.2.2.1.8.50	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.51	.1.3.6.1.4.1.26138.2.124.2.2.1.8.51	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.52	.1.3.6.1.4.1.26138.2.124.2.2.1.8.52	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.53	.1.3.6.1.4.1.26138.2.124.2.2.1.8.53	Integer	replace (3)
ibDhcpSnoop2IfOpt82Strategy.54	.1.3.6.1.4.1.26138.2.124.2.2.1.8.54	Integer	replace (3)
ibDhcpSnoop2IfOpt82CID-Mode.1	.1.3.6.1.4.1.26138.2.124.2.2.1.9.1	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.2	.1.3.6.1.4.1.26138.2.124.2.2.1.9.2	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.3	.1.3.6.1.4.1.26138.2.124.2.2.1.9.3	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.4	.1.3.6.1.4.1.26138.2.124.2.2.1.9.4	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.5	.1.3.6.1.4.1.26138.2.124.2.2.1.9.5	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.6	.1.3.6.1.4.1.26138.2.124.2.2.1.9.6	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.7	.1.3.6.1.4.1.26138.2.124.2.2.1.9.7	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.8	.1.3.6.1.4.1.26138.2.124.2.2.1.9.8	Integer	normal (1)

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ibDhcpSnoop2fOpt82CID-Mode.9	.1.3.6.1.4.1.26138.2.124.2.2.1.9.9	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.10	.1.3.6.1.4.1.26138.2.124.2.2.1.9.10	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.11	.1.3.6.1.4.1.26138.2.124.2.2.1.9.11	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.12	.1.3.6.1.4.1.26138.2.124.2.2.1.9.12	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.13	.1.3.6.1.4.1.26138.2.124.2.2.1.9.13	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.14	.1.3.6.1.4.1.26138.2.124.2.2.1.9.14	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.15	.1.3.6.1.4.1.26138.2.124.2.2.1.9.15	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.16	.1.3.6.1.4.1.26138.2.124.2.2.1.9.16	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.17	.1.3.6.1.4.1.26138.2.124.2.2.1.9.17	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.18	.1.3.6.1.4.1.26138.2.124.2.2.1.9.18	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.19	.1.3.6.1.4.1.26138.2.124.2.2.1.9.19	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.20	.1.3.6.1.4.1.26138.2.124.2.2.1.9.20	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.21	.1.3.6.1.4.1.26138.2.124.2.2.1.9.21	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.22	.1.3.6.1.4.1.26138.2.124.2.2.1.9.22	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.23	.1.3.6.1.4.1.26138.2.124.2.2.1.9.23	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.24	.1.3.6.1.4.1.26138.2.124.2.2.1.9.24	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.25	.1.3.6.1.4.1.26138.2.124.2.2.1.9.25	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.26	.1.3.6.1.4.1.26138.2.124.2.2.1.9.26	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.27	.1.3.6.1.4.1.26138.2.124.2.2.1.9.27	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.28	.1.3.6.1.4.1.26138.2.124.2.2.1.9.28	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.29	.1.3.6.1.4.1.26138.2.124.2.2.1.9.29	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.30	.1.3.6.1.4.1.26138.2.124.2.2.1.9.30	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.31	.1.3.6.1.4.1.26138.2.124.2.2.1.9.31	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.32	.1.3.6.1.4.1.26138.2.124.2.2.1.9.32	Integer	normal (1)
ibDhcpSnoop2fOpt82CID-Mode.33	.1.3.6.1.4.1.26138.2.124.2.2.1.9.33	Integer	normal (1)

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ibDhcpSnoop2IfOpt82CID-Mode.34	.1.3.6.1.4.1.26138.2.124.2.2.1.9.34	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.35	.1.3.6.1.4.1.26138.2.124.2.2.1.9.35	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.36	.1.3.6.1.4.1.26138.2.124.2.2.1.9.36	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.37	.1.3.6.1.4.1.26138.2.124.2.2.1.9.37	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.38	.1.3.6.1.4.1.26138.2.124.2.2.1.9.38	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.39	.1.3.6.1.4.1.26138.2.124.2.2.1.9.39	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.40	.1.3.6.1.4.1.26138.2.124.2.2.1.9.40	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.41	.1.3.6.1.4.1.26138.2.124.2.2.1.9.41	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.42	.1.3.6.1.4.1.26138.2.124.2.2.1.9.42	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.43	.1.3.6.1.4.1.26138.2.124.2.2.1.9.43	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.44	.1.3.6.1.4.1.26138.2.124.2.2.1.9.44	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.45	.1.3.6.1.4.1.26138.2.124.2.2.1.9.45	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.46	.1.3.6.1.4.1.26138.2.124.2.2.1.9.46	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.47	.1.3.6.1.4.1.26138.2.124.2.2.1.9.47	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.48	.1.3.6.1.4.1.26138.2.124.2.2.1.9.48	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.49	.1.3.6.1.4.1.26138.2.124.2.2.1.9.49	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.50	.1.3.6.1.4.1.26138.2.124.2.2.1.9.50	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.51	.1.3.6.1.4.1.26138.2.124.2.2.1.9.51	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.52	.1.3.6.1.4.1.26138.2.124.2.2.1.9.52	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.53	.1.3.6.1.4.1.26138.2.124.2.2.1.9.53	Integer	normal (1)
ibDhcpSnoop2IfOpt82CID-Mode.54	.1.3.6.1.4.1.26138.2.124.2.2.1.9.54	Integer	normal (1)
ibDhcpSnoop2IfOpt82CIDNodeType.1	.1.3.6.1.4.1.26138.2.124.2.2.1.10.1	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.2	.1.3.6.1.4.1.26138.2.124.2.2.1.10.2	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.3	.1.3.6.1.4.1.26138.2.124.2.2.1.10.3	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.4	.1.3.6.1.4.1.26138.2.124.2.2.1.10.4	Integer	invalid (1)



Name	OID	Value Type	Value Example
ibDhcpSnoop2IfOpt82CIDNodeType.5	.1.3.6.1.4.1.26138.2.124.2.2.1.10.5	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.6	.1.3.6.1.4.1.26138.2.124.2.2.1.10.6	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.7	.1.3.6.1.4.1.26138.2.124.2.2.1.10.7	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.8	.1.3.6.1.4.1.26138.2.124.2.2.1.10.8	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.9	.1.3.6.1.4.1.26138.2.124.2.2.1.10.9	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.10	.1.3.6.1.4.1.26138.2.124.2.2.1.10.10	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.11	.1.3.6.1.4.1.26138.2.124.2.2.1.10.11	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.12	.1.3.6.1.4.1.26138.2.124.2.2.1.10.12	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.13	.1.3.6.1.4.1.26138.2.124.2.2.1.10.13	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.14	.1.3.6.1.4.1.26138.2.124.2.2.1.10.14	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.15	.1.3.6.1.4.1.26138.2.124.2.2.1.10.15	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.16	.1.3.6.1.4.1.26138.2.124.2.2.1.10.16	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.17	.1.3.6.1.4.1.26138.2.124.2.2.1.10.17	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.18	.1.3.6.1.4.1.26138.2.124.2.2.1.10.18	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.19	.1.3.6.1.4.1.26138.2.124.2.2.1.10.19	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.20	.1.3.6.1.4.1.26138.2.124.2.2.1.10.20	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.21	.1.3.6.1.4.1.26138.2.124.2.2.1.10.21	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.22	.1.3.6.1.4.1.26138.2.124.2.2.1.10.22	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.23	.1.3.6.1.4.1.26138.2.124.2.2.1.10.23	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.24	.1.3.6.1.4.1.26138.2.124.2.2.1.10.24	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.25	.1.3.6.1.4.1.26138.2.124.2.2.1.10.25	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.26	.1.3.6.1.4.1.26138.2.124.2.2.1.10.26	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.27	.1.3.6.1.4.1.26138.2.124.2.2.1.10.27	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.28	.1.3.6.1.4.1.26138.2.124.2.2.1.10.28	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.29	.1.3.6.1.4.1.26138.2.124.2.2.1.10.29	Integer	invalid (1)

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ibDhcpSnoop2IfOpt82CIDNodeType.30	1.3.6.1.4.1.26138.2.124.2.2.1.10.30	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.31	1.3.6.1.4.1.26138.2.124.2.2.1.10.31	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.32	1.3.6.1.4.1.26138.2.124.2.2.1.10.32	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.33	1.3.6.1.4.1.26138.2.124.2.2.1.10.33	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.34	1.3.6.1.4.1.26138.2.124.2.2.1.10.34	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.35	1.3.6.1.4.1.26138.2.124.2.2.1.10.35	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.36	1.3.6.1.4.1.26138.2.124.2.2.1.10.36	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.37	1.3.6.1.4.1.26138.2.124.2.2.1.10.37	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.38	1.3.6.1.4.1.26138.2.124.2.2.1.10.38	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.39	1.3.6.1.4.1.26138.2.124.2.2.1.10.39	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.40	1.3.6.1.4.1.26138.2.124.2.2.1.10.40	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.41	1.3.6.1.4.1.26138.2.124.2.2.1.10.41	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.42	1.3.6.1.4.1.26138.2.124.2.2.1.10.42	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.43	1.3.6.1.4.1.26138.2.124.2.2.1.10.43	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.44	1.3.6.1.4.1.26138.2.124.2.2.1.10.44	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.45	1.3.6.1.4.1.26138.2.124.2.2.1.10.45	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.46	1.3.6.1.4.1.26138.2.124.2.2.1.10.46	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.47	1.3.6.1.4.1.26138.2.124.2.2.1.10.47	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.48	1.3.6.1.4.1.26138.2.124.2.2.1.10.48	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.49	1.3.6.1.4.1.26138.2.124.2.2.1.10.49	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.50	1.3.6.1.4.1.26138.2.124.2.2.1.10.50	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.51	1.3.6.1.4.1.26138.2.124.2.2.1.10.51	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.52	1.3.6.1.4.1.26138.2.124.2.2.1.10.52	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.53	1.3.6.1.4.1.26138.2.124.2.2.1.10.53	Integer	invalid (1)
ibDhcpSnoop2IfOpt82CIDNodeType.54	1.3.6.1.4.1.26138.2.124.2.2.1.10.54	Integer	invalid (1)

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ibDhcpSnoop2IfOpt82CIDNodeStr.1	.1.3.6.1.4.1.26138.2.124.2.2.1.11.1	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.2	.1.3.6.1.4.1.26138.2.124.2.2.1.11.2	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.3	.1.3.6.1.4.1.26138.2.124.2.2.1.11.3	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.4	.1.3.6.1.4.1.26138.2.124.2.2.1.11.4	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.5	.1.3.6.1.4.1.26138.2.124.2.2.1.11.5	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.6	.1.3.6.1.4.1.26138.2.124.2.2.1.11.6	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.7	.1.3.6.1.4.1.26138.2.124.2.2.1.11.7	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.8	.1.3.6.1.4.1.26138.2.124.2.2.1.11.8	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.9	.1.3.6.1.4.1.26138.2.124.2.2.1.11.9	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.10	.1.3.6.1.4.1.26138.2.124.2.2.1.11.10	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.11	.1.3.6.1.4.1.26138.2.124.2.2.1.11.11	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.12	.1.3.6.1.4.1.26138.2.124.2.2.1.11.12	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.13	.1.3.6.1.4.1.26138.2.124.2.2.1.11.13	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.14	.1.3.6.1.4.1.26138.2.124.2.2.1.11.14	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.15	.1.3.6.1.4.1.26138.2.124.2.2.1.11.15	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.16	.1.3.6.1.4.1.26138.2.124.2.2.1.11.16	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.17	.1.3.6.1.4.1.26138.2.124.2.2.1.11.17	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.18	.1.3.6.1.4.1.26138.2.124.2.2.1.11.18	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.19	.1.3.6.1.4.1.26138.2.124.2.2.1.11.19	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.20	.1.3.6.1.4.1.26138.2.124.2.2.1.11.20	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.21	.1.3.6.1.4.1.26138.2.124.2.2.1.11.21	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.22	.1.3.6.1.4.1.26138.2.124.2.2.1.11.22	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.23	.1.3.6.1.4.1.26138.2.124.2.2.1.11.23	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.24	.1.3.6.1.4.1.26138.2.124.2.2.1.11.24	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.25	.1.3.6.1.4.1.26138.2.124.2.2.1.11.25	OctetString	

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ibDhcpSnoop2IfOpt82CIDNodeStr.26	1.3.6.1.4.1.26138.2.124.2.2.1.11.26	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.27	1.3.6.1.4.1.26138.2.124.2.2.1.11.27	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.28	1.3.6.1.4.1.26138.2.124.2.2.1.11.28	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.29	1.3.6.1.4.1.26138.2.124.2.2.1.11.29	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.30	1.3.6.1.4.1.26138.2.124.2.2.1.11.30	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.31	1.3.6.1.4.1.26138.2.124.2.2.1.11.31	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.32	1.3.6.1.4.1.26138.2.124.2.2.1.11.32	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.33	1.3.6.1.4.1.26138.2.124.2.2.1.11.33	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.34	1.3.6.1.4.1.26138.2.124.2.2.1.11.34	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.35	1.3.6.1.4.1.26138.2.124.2.2.1.11.35	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.36	1.3.6.1.4.1.26138.2.124.2.2.1.11.36	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.37	1.3.6.1.4.1.26138.2.124.2.2.1.11.37	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.38	1.3.6.1.4.1.26138.2.124.2.2.1.11.38	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.39	1.3.6.1.4.1.26138.2.124.2.2.1.11.39	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.40	1.3.6.1.4.1.26138.2.124.2.2.1.11.40	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.41	1.3.6.1.4.1.26138.2.124.2.2.1.11.41	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.42	1.3.6.1.4.1.26138.2.124.2.2.1.11.42	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.43	1.3.6.1.4.1.26138.2.124.2.2.1.11.43	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.44	1.3.6.1.4.1.26138.2.124.2.2.1.11.44	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.45	1.3.6.1.4.1.26138.2.124.2.2.1.11.45	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.46	1.3.6.1.4.1.26138.2.124.2.2.1.11.46	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.47	1.3.6.1.4.1.26138.2.124.2.2.1.11.47	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.48	1.3.6.1.4.1.26138.2.124.2.2.1.11.48	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.49	1.3.6.1.4.1.26138.2.124.2.2.1.11.49	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.50	1.3.6.1.4.1.26138.2.124.2.2.1.11.50	OctetString	

Name	OID	Value Type	Value Example
ibDhcpSnoop2IfOpt82CIDNodeStr.51	.1.3.6.1.4.1.26138.2.124.2.2.1.11.51	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.52	.1.3.6.1.4.1.26138.2.124.2.2.1.11.52	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.53	.1.3.6.1.4.1.26138.2.124.2.2.1.11.53	OctetString	
ibDhcpSnoop2IfOpt82CIDNodeStr.54	.1.3.6.1.4.1.26138.2.124.2.2.1.11.54	OctetString	
ibDhcpSnoop2IfOpt82CIDStr.1	.1.3.6.1.4.1.26138.2.124.2.2.1.12.1	OctetString	
ibDhcpSnoop2IfOpt82CIDStr.2	.1.3.6.1.4.1.26138.2.124.2.2.1.12.2	OctetString	
ibDhcpSnoop2IfOpt82CIDStr.3	.1.3.6.1.4.1.26138.2.124.2.2.1.12.3	OctetString	
ibDhcpSnoop2IfOpt82CIDStr.4	.1.3.6.1.4.1.26138.2.124.2.2.1.12.4	OctetString	
ibDhcpSnoop2IfOpt82CIDStr.5	.1.3.6.1.4.1.26138.2.124.2.2.1.12.5	OctetString	
ibDhcpSnoop2IfOpt82CIDStr.6	.1.3.6.1.4.1.26138.2.124.2.2.1.12.6	OctetString	
ibDhcpSnoop2IfOpt82CIDStr.7	.1.3.6.1.4.1.26138.2.124.2.2.1.12.7	OctetString	
ibDhcpSnoop2IfOpt82CIDStr.8	.1.3.6.1.4.1.26138.2.124.2.2.1.12.8	OctetString	
ibDhcpSnoop2IfOpt82CIDStr.9	.1.3.6.1.4.1.26138.2.124.2.2.1.12.9	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.10	.1.3.6.1.4.1.26138.2.124.2.2.1.12.10	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.11	.1.3.6.1.4.1.26138.2.124.2.2.1.12.11	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.12	.1.3.6.1.4.1.26138.2.124.2.2.1.12.12	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.13	.1.3.6.1.4.1.26138.2.124.2.2.1.12.13	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.14	.1.3.6.1.4.1.26138.2.124.2.2.1.12.14	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.15	.1.3.6.1.4.1.26138.2.124.2.2.1.12.15	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.16	.1.3.6.1.4.1.26138.2.124.2.2.1.12.16	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.17	.1.3.6.1.4.1.26138.2.124.2.2.1.12.17	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.18	.1.3.6.1.4.1.26138.2.124.2.2.1.12.18	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.19	.1.3.6.1.4.1.26138.2.124.2.2.1.12.19	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.20	.1.3.6.1.4.1.26138.2.124.2.2.1.12.20	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.21	.1.3.6.1.4.1.26138.2.124.2.2.1.12.21	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.22	.1.3.6.1.4.1.26138.2.124.2.2.1.12.22	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.23	.1.3.6.1.4.1.26138.2.124.2.2.1.12.23	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.24	.1.3.6.1.4.1.26138.2.124.2.2.1.12.24	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.25	.1.3.6.1.4.1.26138.2.124.2.2.1.12.25	OctetString	

Name	OID	Value Type	Value Example
ibDhcpSnoop2IfOpt82-CIDStr.26	1.3.6.1.4.1.26138.2.124.2.2.1.12.26	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.27	1.3.6.1.4.1.26138.2.124.2.2.1.12.27	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.28	1.3.6.1.4.1.26138.2.124.2.2.1.12.28	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.29	1.3.6.1.4.1.26138.2.124.2.2.1.12.29	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.30	1.3.6.1.4.1.26138.2.124.2.2.1.12.30	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.31	1.3.6.1.4.1.26138.2.124.2.2.1.12.31	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.32	1.3.6.1.4.1.26138.2.124.2.2.1.12.32	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.33	1.3.6.1.4.1.26138.2.124.2.2.1.12.33	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.34	1.3.6.1.4.1.26138.2.124.2.2.1.12.34	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.35	1.3.6.1.4.1.26138.2.124.2.2.1.12.35	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.36	1.3.6.1.4.1.26138.2.124.2.2.1.12.36	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.37	1.3.6.1.4.1.26138.2.124.2.2.1.12.37	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.38	1.3.6.1.4.1.26138.2.124.2.2.1.12.38	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.39	1.3.6.1.4.1.26138.2.124.2.2.1.12.39	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.40	1.3.6.1.4.1.26138.2.124.2.2.1.12.40	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.41	1.3.6.1.4.1.26138.2.124.2.2.1.12.41	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.42	1.3.6.1.4.1.26138.2.124.2.2.1.12.42	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.43	1.3.6.1.4.1.26138.2.124.2.2.1.12.43	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.44	1.3.6.1.4.1.26138.2.124.2.2.1.12.44	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.45	1.3.6.1.4.1.26138.2.124.2.2.1.12.45	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.46	1.3.6.1.4.1.26138.2.124.2.2.1.12.46	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.47	1.3.6.1.4.1.26138.2.124.2.2.1.12.47	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.48	1.3.6.1.4.1.26138.2.124.2.2.1.12.48	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.49	1.3.6.1.4.1.26138.2.124.2.2.1.12.49	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.50	1.3.6.1.4.1.26138.2.124.2.2.1.12.50	OctetString	

Name	OID	Value Type	Value Example
ibDhcpSnoop2IfOpt82-CIDStr.51	.1.3.6.1.4.1.26138.2.124.2.2.1.12.51	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.52	.1.3.6.1.4.1.26138.2.124.2.2.1.12.52	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.53	.1.3.6.1.4.1.26138.2.124.2.2.1.12.53	OctetString	
ibDhcpSnoop2IfOpt82-CIDStr.54	.1.3.6.1.4.1.26138.2.124.2.2.1.12.54	OctetString	
ibDhcpSnoop2IfOpt82CIDFormat.1	.1.3.6.1.4.1.26138.2.124.2.2.1.13.1	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.2	.1.3.6.1.4.1.26138.2.124.2.2.1.13.2	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.3	.1.3.6.1.4.1.26138.2.124.2.2.1.13.3	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.4	.1.3.6.1.4.1.26138.2.124.2.2.1.13.4	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.5	.1.3.6.1.4.1.26138.2.124.2.2.1.13.5	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.6	.1.3.6.1.4.1.26138.2.124.2.2.1.13.6	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.7	.1.3.6.1.4.1.26138.2.124.2.2.1.13.7	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.8	.1.3.6.1.4.1.26138.2.124.2.2.1.13.8	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.9	.1.3.6.1.4.1.26138.2.124.2.2.1.13.9	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.10	.1.3.6.1.4.1.26138.2.124.2.2.1.13.10	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.11	.1.3.6.1.4.1.26138.2.124.2.2.1.13.11	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.12	.1.3.6.1.4.1.26138.2.124.2.2.1.13.12	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.13	.1.3.6.1.4.1.26138.2.124.2.2.1.13.13	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.14	.1.3.6.1.4.1.26138.2.124.2.2.1.13.14	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.15	.1.3.6.1.4.1.26138.2.124.2.2.1.13.15	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.16	.1.3.6.1.4.1.26138.2.124.2.2.1.13.16	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.17	.1.3.6.1.4.1.26138.2.124.2.2.1.13.17	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.18	.1.3.6.1.4.1.26138.2.124.2.2.1.13.18	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.19	.1.3.6.1.4.1.26138.2.124.2.2.1.13.19	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.20	.1.3.6.1.4.1.26138.2.124.2.2.1.13.20	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.21	.1.3.6.1.4.1.26138.2.124.2.2.1.13.21	Integer	hex (1)



Name	OID	Value Type	Value Example
ibDhcpSnoop2IfOpt82CIDFormat.22	1.3.6.1.4.1.26138.2.124.2.2.1.13.22	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.23	1.3.6.1.4.1.26138.2.124.2.2.1.13.23	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.24	1.3.6.1.4.1.26138.2.124.2.2.1.13.24	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.25	1.3.6.1.4.1.26138.2.124.2.2.1.13.25	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.26	1.3.6.1.4.1.26138.2.124.2.2.1.13.26	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.27	1.3.6.1.4.1.26138.2.124.2.2.1.13.27	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.28	1.3.6.1.4.1.26138.2.124.2.2.1.13.28	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.29	1.3.6.1.4.1.26138.2.124.2.2.1.13.29	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.30	1.3.6.1.4.1.26138.2.124.2.2.1.13.30	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.31	1.3.6.1.4.1.26138.2.124.2.2.1.13.31	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.32	1.3.6.1.4.1.26138.2.124.2.2.1.13.32	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.33	1.3.6.1.4.1.26138.2.124.2.2.1.13.33	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.34	1.3.6.1.4.1.26138.2.124.2.2.1.13.34	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.35	1.3.6.1.4.1.26138.2.124.2.2.1.13.35	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.36	1.3.6.1.4.1.26138.2.124.2.2.1.13.36	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.37	1.3.6.1.4.1.26138.2.124.2.2.1.13.37	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.38	1.3.6.1.4.1.26138.2.124.2.2.1.13.38	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.39	1.3.6.1.4.1.26138.2.124.2.2.1.13.39	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.40	1.3.6.1.4.1.26138.2.124.2.2.1.13.40	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.41	1.3.6.1.4.1.26138.2.124.2.2.1.13.41	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.42	1.3.6.1.4.1.26138.2.124.2.2.1.13.42	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.43	1.3.6.1.4.1.26138.2.124.2.2.1.13.43	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.44	1.3.6.1.4.1.26138.2.124.2.2.1.13.44	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.45	1.3.6.1.4.1.26138.2.124.2.2.1.13.45	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.46	1.3.6.1.4.1.26138.2.124.2.2.1.13.46	Integer	hex (1)

Name	OID	Value Type	Value Example
ibDhcpSnoop2IfOpt82CIDFormat.47	.1.3.6.1.4.1.26138.2.124.2.2.1.13.47	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.48	.1.3.6.1.4.1.26138.2.124.2.2.1.13.48	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.49	.1.3.6.1.4.1.26138.2.124.2.2.1.13.49	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.50	.1.3.6.1.4.1.26138.2.124.2.2.1.13.50	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.51	.1.3.6.1.4.1.26138.2.124.2.2.1.13.51	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.52	.1.3.6.1.4.1.26138.2.124.2.2.1.13.52	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.53	.1.3.6.1.4.1.26138.2.124.2.2.1.13.53	Integer	hex (1)
ibDhcpSnoop2IfOpt82CIDFormat.54	.1.3.6.1.4.1.26138.2.124.2.2.1.13.54	Integer	hex (1)
ibDhcpSnoop2IfOpt82RID-Mode.1	.1.3.6.1.4.1.26138.2.124.2.2.1.14.1	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.2	.1.3.6.1.4.1.26138.2.124.2.2.1.14.2	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.3	.1.3.6.1.4.1.26138.2.124.2.2.1.14.3	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.4	.1.3.6.1.4.1.26138.2.124.2.2.1.14.4	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.5	.1.3.6.1.4.1.26138.2.124.2.2.1.14.5	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.6	.1.3.6.1.4.1.26138.2.124.2.2.1.14.6	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.7	.1.3.6.1.4.1.26138.2.124.2.2.1.14.7	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.8	.1.3.6.1.4.1.26138.2.124.2.2.1.14.8	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.9	.1.3.6.1.4.1.26138.2.124.2.2.1.14.9	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.10	.1.3.6.1.4.1.26138.2.124.2.2.1.14.10	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.11	.1.3.6.1.4.1.26138.2.124.2.2.1.14.11	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.12	.1.3.6.1.4.1.26138.2.124.2.2.1.14.12	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.13	.1.3.6.1.4.1.26138.2.124.2.2.1.14.13	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.14	.1.3.6.1.4.1.26138.2.124.2.2.1.14.14	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.15	.1.3.6.1.4.1.26138.2.124.2.2.1.14.15	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.16	.1.3.6.1.4.1.26138.2.124.2.2.1.14.16	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.17	.1.3.6.1.4.1.26138.2.124.2.2.1.14.17	Integer	normal (1)

Name	OID	Value Type	Value Example
ibDhcpSnoop2IfOpt82RID-Mode.18	1.3.6.1.4.1.26138.2.124.2.2.1.14.18	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.19	1.3.6.1.4.1.26138.2.124.2.2.1.14.19	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.20	1.3.6.1.4.1.26138.2.124.2.2.1.14.20	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.21	1.3.6.1.4.1.26138.2.124.2.2.1.14.21	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.22	1.3.6.1.4.1.26138.2.124.2.2.1.14.22	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.23	1.3.6.1.4.1.26138.2.124.2.2.1.14.23	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.24	1.3.6.1.4.1.26138.2.124.2.2.1.14.24	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.25	1.3.6.1.4.1.26138.2.124.2.2.1.14.25	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.26	1.3.6.1.4.1.26138.2.124.2.2.1.14.26	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.27	1.3.6.1.4.1.26138.2.124.2.2.1.14.27	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.28	1.3.6.1.4.1.26138.2.124.2.2.1.14.28	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.29	1.3.6.1.4.1.26138.2.124.2.2.1.14.29	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.30	1.3.6.1.4.1.26138.2.124.2.2.1.14.30	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.31	1.3.6.1.4.1.26138.2.124.2.2.1.14.31	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.32	1.3.6.1.4.1.26138.2.124.2.2.1.14.32	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.33	1.3.6.1.4.1.26138.2.124.2.2.1.14.33	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.34	1.3.6.1.4.1.26138.2.124.2.2.1.14.34	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.35	1.3.6.1.4.1.26138.2.124.2.2.1.14.35	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.36	1.3.6.1.4.1.26138.2.124.2.2.1.14.36	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.37	1.3.6.1.4.1.26138.2.124.2.2.1.14.37	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.38	1.3.6.1.4.1.26138.2.124.2.2.1.14.38	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.39	1.3.6.1.4.1.26138.2.124.2.2.1.14.39	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.40	1.3.6.1.4.1.26138.2.124.2.2.1.14.40	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.41	1.3.6.1.4.1.26138.2.124.2.2.1.14.41	Integer	normal (1)
ibDhcpSnoop2IfOpt82RID-Mode.42	1.3.6.1.4.1.26138.2.124.2.2.1.14.42	Integer	normal (1)

Name	OID	Value Type	Value Example
ibDhcpSnoop2fOpt82RID-Mode.43	.1.3.6.1.4.1.26138.2.124.2.2.1.14.43	Integer	normal (1)
ibDhcpSnoop2fOpt82RID-Mode.44	.1.3.6.1.4.1.26138.2.124.2.2.1.14.44	Integer	normal (1)
ibDhcpSnoop2fOpt82RID-Mode.45	.1.3.6.1.4.1.26138.2.124.2.2.1.14.45	Integer	normal (1)
ibDhcpSnoop2fOpt82RID-Mode.46	.1.3.6.1.4.1.26138.2.124.2.2.1.14.46	Integer	normal (1)
ibDhcpSnoop2fOpt82RID-Mode.47	.1.3.6.1.4.1.26138.2.124.2.2.1.14.47	Integer	normal (1)
ibDhcpSnoop2fOpt82RID-Mode.48	.1.3.6.1.4.1.26138.2.124.2.2.1.14.48	Integer	normal (1)
ibDhcpSnoop2fOpt82RID-Mode.49	.1.3.6.1.4.1.26138.2.124.2.2.1.14.49	Integer	normal (1)
ibDhcpSnoop2fOpt82RID-Mode.50	.1.3.6.1.4.1.26138.2.124.2.2.1.14.50	Integer	normal (1)
ibDhcpSnoop2fOpt82RID-Mode.51	.1.3.6.1.4.1.26138.2.124.2.2.1.14.51	Integer	normal (1)
ibDhcpSnoop2fOpt82RID-Mode.52	.1.3.6.1.4.1.26138.2.124.2.2.1.14.52	Integer	normal (1)
ibDhcpSnoop2fOpt82RID-Mode.53	.1.3.6.1.4.1.26138.2.124.2.2.1.14.53	Integer	normal (1)
ibDhcpSnoop2fOpt82RID-Mode.54	.1.3.6.1.4.1.26138.2.124.2.2.1.14.54	Integer	normal (1)
ibDhcpSnoop2fOpt82RIDStr.1	.1.3.6.1.4.1.26138.2.124.2.2.1.15.1	OctetString	
ibDhcpSnoop2fOpt82RIDStr.2	.1.3.6.1.4.1.26138.2.124.2.2.1.15.2	OctetString	
ibDhcpSnoop2fOpt82RIDStr.3	.1.3.6.1.4.1.26138.2.124.2.2.1.15.3	OctetString	
ibDhcpSnoop2fOpt82RIDStr.4	.1.3.6.1.4.1.26138.2.124.2.2.1.15.4	OctetString	
ibDhcpSnoop2fOpt82RIDStr.5	.1.3.6.1.4.1.26138.2.124.2.2.1.15.5	OctetString	
ibDhcpSnoop2fOpt82RIDStr.6	.1.3.6.1.4.1.26138.2.124.2.2.1.15.6	OctetString	
ibDhcpSnoop2fOpt82RIDStr.7	.1.3.6.1.4.1.26138.2.124.2.2.1.15.7	OctetString	
ibDhcpSnoop2fOpt82RIDStr.8	.1.3.6.1.4.1.26138.2.124.2.2.1.15.8	OctetString	
ibDhcpSnoop2fOpt82RIDStr.9	.1.3.6.1.4.1.26138.2.124.2.2.1.15.9	OctetString	
ibDhcpSnoop2fOpt82-RIDStr.10	.1.3.6.1.4.1.26138.2.124.2.2.1.15.10	OctetString	
ibDhcpSnoop2fOpt82-RIDStr.11	.1.3.6.1.4.1.26138.2.124.2.2.1.15.11	OctetString	
ibDhcpSnoop2fOpt82-RIDStr.12	.1.3.6.1.4.1.26138.2.124.2.2.1.15.12	OctetString	
ibDhcpSnoop2fOpt82-RIDStr.13	.1.3.6.1.4.1.26138.2.124.2.2.1.15.13	OctetString	
ibDhcpSnoop2fOpt82-RIDStr.14	.1.3.6.1.4.1.26138.2.124.2.2.1.15.14	OctetString	
ibDhcpSnoop2fOpt82-RIDStr.15	.1.3.6.1.4.1.26138.2.124.2.2.1.15.15	OctetString	
ibDhcpSnoop2fOpt82-RIDStr.16	.1.3.6.1.4.1.26138.2.124.2.2.1.15.16	OctetString	
ibDhcpSnoop2fOpt82-RIDStr.17	.1.3.6.1.4.1.26138.2.124.2.2.1.15.17	OctetString	

Name	OID	Value Type	Value Example
ibDhcpSnoop2IfOpt82-RIDStr.18	1.3.6.1.4.1.26138.2.124.2.2.1.15.18	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.19	1.3.6.1.4.1.26138.2.124.2.2.1.15.19	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.20	1.3.6.1.4.1.26138.2.124.2.2.1.15.20	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.21	1.3.6.1.4.1.26138.2.124.2.2.1.15.21	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.22	1.3.6.1.4.1.26138.2.124.2.2.1.15.22	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.23	1.3.6.1.4.1.26138.2.124.2.2.1.15.23	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.24	1.3.6.1.4.1.26138.2.124.2.2.1.15.24	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.25	1.3.6.1.4.1.26138.2.124.2.2.1.15.25	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.26	1.3.6.1.4.1.26138.2.124.2.2.1.15.26	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.27	1.3.6.1.4.1.26138.2.124.2.2.1.15.27	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.28	1.3.6.1.4.1.26138.2.124.2.2.1.15.28	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.29	1.3.6.1.4.1.26138.2.124.2.2.1.15.29	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.30	1.3.6.1.4.1.26138.2.124.2.2.1.15.30	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.31	1.3.6.1.4.1.26138.2.124.2.2.1.15.31	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.32	1.3.6.1.4.1.26138.2.124.2.2.1.15.32	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.33	1.3.6.1.4.1.26138.2.124.2.2.1.15.33	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.34	1.3.6.1.4.1.26138.2.124.2.2.1.15.34	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.35	1.3.6.1.4.1.26138.2.124.2.2.1.15.35	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.36	1.3.6.1.4.1.26138.2.124.2.2.1.15.36	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.37	1.3.6.1.4.1.26138.2.124.2.2.1.15.37	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.38	1.3.6.1.4.1.26138.2.124.2.2.1.15.38	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.39	1.3.6.1.4.1.26138.2.124.2.2.1.15.39	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.40	1.3.6.1.4.1.26138.2.124.2.2.1.15.40	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.41	1.3.6.1.4.1.26138.2.124.2.2.1.15.41	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.42	1.3.6.1.4.1.26138.2.124.2.2.1.15.42	OctetString	

Name	OID	Value Type	Value Example
ibDhcpSnoop2IfOpt82-RIDStr.43	.1.3.6.1.4.1.26138.2.124.2.2.1.15.43	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.44	.1.3.6.1.4.1.26138.2.124.2.2.1.15.44	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.45	.1.3.6.1.4.1.26138.2.124.2.2.1.15.45	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.46	.1.3.6.1.4.1.26138.2.124.2.2.1.15.46	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.47	.1.3.6.1.4.1.26138.2.124.2.2.1.15.47	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.48	.1.3.6.1.4.1.26138.2.124.2.2.1.15.48	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.49	.1.3.6.1.4.1.26138.2.124.2.2.1.15.49	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.50	.1.3.6.1.4.1.26138.2.124.2.2.1.15.50	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.51	.1.3.6.1.4.1.26138.2.124.2.2.1.15.51	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.52	.1.3.6.1.4.1.26138.2.124.2.2.1.15.52	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.53	.1.3.6.1.4.1.26138.2.124.2.2.1.15.53	OctetString	
ibDhcpSnoop2IfOpt82-RIDStr.54	.1.3.6.1.4.1.26138.2.124.2.2.1.15.54	OctetString	
ibDhcpSnoop2IfOpt82RIDFormat.1	.1.3.6.1.4.1.26138.2.124.2.2.1.16.1	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.2	.1.3.6.1.4.1.26138.2.124.2.2.1.16.2	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.3	.1.3.6.1.4.1.26138.2.124.2.2.1.16.3	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.4	.1.3.6.1.4.1.26138.2.124.2.2.1.16.4	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.5	.1.3.6.1.4.1.26138.2.124.2.2.1.16.5	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.6	.1.3.6.1.4.1.26138.2.124.2.2.1.16.6	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.7	.1.3.6.1.4.1.26138.2.124.2.2.1.16.7	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.8	.1.3.6.1.4.1.26138.2.124.2.2.1.16.8	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.9	.1.3.6.1.4.1.26138.2.124.2.2.1.16.9	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.10	.1.3.6.1.4.1.26138.2.124.2.2.1.16.10	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.11	.1.3.6.1.4.1.26138.2.124.2.2.1.16.11	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.12	.1.3.6.1.4.1.26138.2.124.2.2.1.16.12	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.13	.1.3.6.1.4.1.26138.2.124.2.2.1.16.13	Integer	hex (1)

Name	OID	Value Type	Value Example
ibDhcpSnoop2IfOpt82RIDFormat.14	1.3.6.1.4.1.26138.2.124.2.2.1.16.14	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.15	1.3.6.1.4.1.26138.2.124.2.2.1.16.15	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.16	1.3.6.1.4.1.26138.2.124.2.2.1.16.16	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.17	1.3.6.1.4.1.26138.2.124.2.2.1.16.17	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.18	1.3.6.1.4.1.26138.2.124.2.2.1.16.18	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.19	1.3.6.1.4.1.26138.2.124.2.2.1.16.19	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.20	1.3.6.1.4.1.26138.2.124.2.2.1.16.20	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.21	1.3.6.1.4.1.26138.2.124.2.2.1.16.21	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.22	1.3.6.1.4.1.26138.2.124.2.2.1.16.22	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.23	1.3.6.1.4.1.26138.2.124.2.2.1.16.23	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.24	1.3.6.1.4.1.26138.2.124.2.2.1.16.24	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.25	1.3.6.1.4.1.26138.2.124.2.2.1.16.25	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.26	1.3.6.1.4.1.26138.2.124.2.2.1.16.26	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.27	1.3.6.1.4.1.26138.2.124.2.2.1.16.27	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.28	1.3.6.1.4.1.26138.2.124.2.2.1.16.28	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.29	1.3.6.1.4.1.26138.2.124.2.2.1.16.29	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.30	1.3.6.1.4.1.26138.2.124.2.2.1.16.30	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.31	1.3.6.1.4.1.26138.2.124.2.2.1.16.31	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.32	1.3.6.1.4.1.26138.2.124.2.2.1.16.32	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.33	1.3.6.1.4.1.26138.2.124.2.2.1.16.33	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.34	1.3.6.1.4.1.26138.2.124.2.2.1.16.34	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.35	1.3.6.1.4.1.26138.2.124.2.2.1.16.35	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.36	1.3.6.1.4.1.26138.2.124.2.2.1.16.36	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.37	1.3.6.1.4.1.26138.2.124.2.2.1.16.37	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.38	1.3.6.1.4.1.26138.2.124.2.2.1.16.38	Integer	hex (1)



Name	OID	Value Type	Value Example
ibDhcpSnoop2IfOpt82RIDFormat.39	.1.3.6.1.4.1.26138.2.124.2.2.1.16.39	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.40	.1.3.6.1.4.1.26138.2.124.2.2.1.16.40	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.41	.1.3.6.1.4.1.26138.2.124.2.2.1.16.41	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.42	.1.3.6.1.4.1.26138.2.124.2.2.1.16.42	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.43	.1.3.6.1.4.1.26138.2.124.2.2.1.16.43	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.44	.1.3.6.1.4.1.26138.2.124.2.2.1.16.44	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.45	.1.3.6.1.4.1.26138.2.124.2.2.1.16.45	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.46	.1.3.6.1.4.1.26138.2.124.2.2.1.16.46	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.47	.1.3.6.1.4.1.26138.2.124.2.2.1.16.47	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.48	.1.3.6.1.4.1.26138.2.124.2.2.1.16.48	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.49	.1.3.6.1.4.1.26138.2.124.2.2.1.16.49	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.50	.1.3.6.1.4.1.26138.2.124.2.2.1.16.50	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.51	.1.3.6.1.4.1.26138.2.124.2.2.1.16.51	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.52	.1.3.6.1.4.1.26138.2.124.2.2.1.16.52	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.53	.1.3.6.1.4.1.26138.2.124.2.2.1.16.53	Integer	hex (1)
ibDhcpSnoop2IfOpt82RIDFormat.54	.1.3.6.1.4.1.26138.2.124.2.2.1.16.54	Integer	hex (1)
ibQinQv2ServiceTPID.0	.1.3.6.1.4.1.26138.2.137.1.1.1.0	Integer	33024
ibQinQv2CustomerTPID.0	.1.3.6.1.4.1.26138.2.137.1.1.2.0	Integer	33024
ibQinQv2IfState.1	.1.3.6.1.4.1.26138.2.137.1.2.1.1.1	Integer	false (2)
ibQinQv2IfState.2	.1.3.6.1.4.1.26138.2.137.1.2.1.1.2	Integer	false (2)
ibQinQv2IfState.3	.1.3.6.1.4.1.26138.2.137.1.2.1.1.3	Integer	false (2)
ibQinQv2IfState.4	.1.3.6.1.4.1.26138.2.137.1.2.1.1.4	Integer	false (2)
ibQinQv2IfState.5	.1.3.6.1.4.1.26138.2.137.1.2.1.1.5	Integer	false (2)
ibQinQv2IfState.6	.1.3.6.1.4.1.26138.2.137.1.2.1.1.6	Integer	false (2)
ibQinQv2IfState.7	.1.3.6.1.4.1.26138.2.137.1.2.1.1.7	Integer	false (2)
ibQinQv2IfState.8	.1.3.6.1.4.1.26138.2.137.1.2.1.1.8	Integer	false (2)
ibQinQv2IfState.9	.1.3.6.1.4.1.26138.2.137.1.2.1.1.9	Integer	false (2)
ibQinQv2IfState.10	.1.3.6.1.4.1.26138.2.137.1.2.1.1.10	Integer	false (2)
ibQinQv2IfState.11	.1.3.6.1.4.1.26138.2.137.1.2.1.1.11	Integer	false (2)
ibQinQv2IfState.12	.1.3.6.1.4.1.26138.2.137.1.2.1.1.12	Integer	false (2)
ibQinQv2IfState.13	.1.3.6.1.4.1.26138.2.137.1.2.1.1.13	Integer	false (2)
ibQinQv2IfState.14	.1.3.6.1.4.1.26138.2.137.1.2.1.1.14	Integer	false (2)

Name	OID	Value Type	Value Example
ibQinQv2IfState.15	.1.3.6.1.4.1.26138.2.137.1.2.1.1.15	Integer	false (2)
ibQinQv2IfState.16	.1.3.6.1.4.1.26138.2.137.1.2.1.1.16	Integer	false (2)
ibQinQv2IfState.17	.1.3.6.1.4.1.26138.2.137.1.2.1.1.17	Integer	false (2)
ibQinQv2IfState.18	.1.3.6.1.4.1.26138.2.137.1.2.1.1.18	Integer	false (2)
ibQinQv2IfState.19	.1.3.6.1.4.1.26138.2.137.1.2.1.1.19	Integer	false (2)
ibQinQv2IfState.20	.1.3.6.1.4.1.26138.2.137.1.2.1.1.20	Integer	false (2)
ibQinQv2IfState.21	.1.3.6.1.4.1.26138.2.137.1.2.1.1.21	Integer	false (2)
ibQinQv2IfState.22	.1.3.6.1.4.1.26138.2.137.1.2.1.1.22	Integer	false (2)
ibQinQv2IfState.23	.1.3.6.1.4.1.26138.2.137.1.2.1.1.23	Integer	false (2)
ibQinQv2IfState.24	.1.3.6.1.4.1.26138.2.137.1.2.1.1.24	Integer	false (2)
ibQinQv2IfState.25	.1.3.6.1.4.1.26138.2.137.1.2.1.1.25	Integer	false (2)
ibQinQv2IfState.26	.1.3.6.1.4.1.26138.2.137.1.2.1.1.26	Integer	false (2)
ibQinQv2IfState.27	.1.3.6.1.4.1.26138.2.137.1.2.1.1.27	Integer	false (2)
ibQinQv2IfState.28	.1.3.6.1.4.1.26138.2.137.1.2.1.1.28	Integer	false (2)
ibQinQv2IfState.29	.1.3.6.1.4.1.26138.2.137.1.2.1.1.29	Integer	false (2)
ibQinQv2IfState.30	.1.3.6.1.4.1.26138.2.137.1.2.1.1.30	Integer	false (2)
ibQinQv2IfState.31	.1.3.6.1.4.1.26138.2.137.1.2.1.1.31	Integer	false (2)
ibQinQv2IfState.32	.1.3.6.1.4.1.26138.2.137.1.2.1.1.32	Integer	false (2)
ibQinQv2IfState.33	.1.3.6.1.4.1.26138.2.137.1.2.1.1.33	Integer	false (2)
ibQinQv2IfState.34	.1.3.6.1.4.1.26138.2.137.1.2.1.1.34	Integer	false (2)
ibQinQv2IfState.35	.1.3.6.1.4.1.26138.2.137.1.2.1.1.35	Integer	false (2)
ibQinQv2IfState.36	.1.3.6.1.4.1.26138.2.137.1.2.1.1.36	Integer	false (2)
ibQinQv2IfState.37	.1.3.6.1.4.1.26138.2.137.1.2.1.1.37	Integer	false (2)
ibQinQv2IfState.38	.1.3.6.1.4.1.26138.2.137.1.2.1.1.38	Integer	false (2)
ibQinQv2IfState.39	.1.3.6.1.4.1.26138.2.137.1.2.1.1.39	Integer	false (2)
ibQinQv2IfState.40	.1.3.6.1.4.1.26138.2.137.1.2.1.1.40	Integer	false (2)
ibQinQv2IfState.41	.1.3.6.1.4.1.26138.2.137.1.2.1.1.41	Integer	false (2)
ibQinQv2IfState.42	.1.3.6.1.4.1.26138.2.137.1.2.1.1.42	Integer	false (2)
ibQinQv2IfState.43	.1.3.6.1.4.1.26138.2.137.1.2.1.1.43	Integer	false (2)
ibQinQv2IfState.44	.1.3.6.1.4.1.26138.2.137.1.2.1.1.44	Integer	false (2)
ibQinQv2IfState.45	.1.3.6.1.4.1.26138.2.137.1.2.1.1.45	Integer	false (2)
ibQinQv2IfState.46	.1.3.6.1.4.1.26138.2.137.1.2.1.1.46	Integer	false (2)
ibQinQv2IfState.47	.1.3.6.1.4.1.26138.2.137.1.2.1.1.47	Integer	false (2)
ibQinQv2IfState.48	.1.3.6.1.4.1.26138.2.137.1.2.1.1.48	Integer	false (2)
ibQinQv2IfState.49	.1.3.6.1.4.1.26138.2.137.1.2.1.1.49	Integer	false (2)
ibQinQv2IfState.50	.1.3.6.1.4.1.26138.2.137.1.2.1.1.50	Integer	false (2)
ibQinQv2IfState.51	.1.3.6.1.4.1.26138.2.137.1.2.1.1.51	Integer	false (2)
ibQinQv2IfState.52	.1.3.6.1.4.1.26138.2.137.1.2.1.1.52	Integer	false (2)
ibQinQv2IfState.53	.1.3.6.1.4.1.26138.2.137.1.2.1.1.53	Integer	false (2)
ibQinQv2IfState.54	.1.3.6.1.4.1.26138.2.137.1.2.1.1.54	Integer	false (2)
ibQinQv2IfServiceTPID.1	.1.3.6.1.4.1.26138.2.137.1.2.1.2.1	Integer	33024
ibQinQv2IfServiceTPID.2	.1.3.6.1.4.1.26138.2.137.1.2.1.2.2	Integer	33024
ibQinQv2IfServiceTPID.3	.1.3.6.1.4.1.26138.2.137.1.2.1.2.3	Integer	33024

Name	OID	Value Type	Value Example
ibQinQv2IfServiceTPID.4	.1.3.6.1.4.1.26138.2.137.1.2.1.2.4	Integer	33024
ibQinQv2IfServiceTPID.5	.1.3.6.1.4.1.26138.2.137.1.2.1.2.5	Integer	33024
ibQinQv2IfServiceTPID.6	.1.3.6.1.4.1.26138.2.137.1.2.1.2.6	Integer	33024
ibQinQv2IfServiceTPID.7	.1.3.6.1.4.1.26138.2.137.1.2.1.2.7	Integer	33024
ibQinQv2IfServiceTPID.8	.1.3.6.1.4.1.26138.2.137.1.2.1.2.8	Integer	33024
ibQinQv2IfServiceTPID.9	.1.3.6.1.4.1.26138.2.137.1.2.1.2.9	Integer	33024
ibQinQv2IfServiceTPID.10	.1.3.6.1.4.1.26138.2.137.1.2.1.2.10	Integer	33024
ibQinQv2IfServiceTPID.11	.1.3.6.1.4.1.26138.2.137.1.2.1.2.11	Integer	33024
ibQinQv2IfServiceTPID.12	.1.3.6.1.4.1.26138.2.137.1.2.1.2.12	Integer	33024
ibQinQv2IfServiceTPID.13	.1.3.6.1.4.1.26138.2.137.1.2.1.2.13	Integer	33024
ibQinQv2IfServiceTPID.14	.1.3.6.1.4.1.26138.2.137.1.2.1.2.14	Integer	33024
ibQinQv2IfServiceTPID.15	.1.3.6.1.4.1.26138.2.137.1.2.1.2.15	Integer	33024
ibQinQv2IfServiceTPID.16	.1.3.6.1.4.1.26138.2.137.1.2.1.2.16	Integer	33024
ibQinQv2IfServiceTPID.17	.1.3.6.1.4.1.26138.2.137.1.2.1.2.17	Integer	33024
ibQinQv2IfServiceTPID.18	.1.3.6.1.4.1.26138.2.137.1.2.1.2.18	Integer	33024
ibQinQv2IfServiceTPID.19	.1.3.6.1.4.1.26138.2.137.1.2.1.2.19	Integer	33024
ibQinQv2IfServiceTPID.20	.1.3.6.1.4.1.26138.2.137.1.2.1.2.20	Integer	33024
ibQinQv2IfServiceTPID.21	.1.3.6.1.4.1.26138.2.137.1.2.1.2.21	Integer	33024
ibQinQv2IfServiceTPID.22	.1.3.6.1.4.1.26138.2.137.1.2.1.2.22	Integer	33024
ibQinQv2IfServiceTPID.23	.1.3.6.1.4.1.26138.2.137.1.2.1.2.23	Integer	33024
ibQinQv2IfServiceTPID.24	.1.3.6.1.4.1.26138.2.137.1.2.1.2.24	Integer	33024
ibQinQv2IfServiceTPID.25	.1.3.6.1.4.1.26138.2.137.1.2.1.2.25	Integer	33024
ibQinQv2IfServiceTPID.26	.1.3.6.1.4.1.26138.2.137.1.2.1.2.26	Integer	33024
ibQinQv2IfServiceTPID.27	.1.3.6.1.4.1.26138.2.137.1.2.1.2.27	Integer	33024
ibQinQv2IfServiceTPID.28	.1.3.6.1.4.1.26138.2.137.1.2.1.2.28	Integer	33024
ibQinQv2IfServiceTPID.29	.1.3.6.1.4.1.26138.2.137.1.2.1.2.29	Integer	33024
ibQinQv2IfServiceTPID.30	.1.3.6.1.4.1.26138.2.137.1.2.1.2.30	Integer	33024
ibQinQv2IfServiceTPID.31	.1.3.6.1.4.1.26138.2.137.1.2.1.2.31	Integer	33024
ibQinQv2IfServiceTPID.32	.1.3.6.1.4.1.26138.2.137.1.2.1.2.32	Integer	33024
ibQinQv2IfServiceTPID.33	.1.3.6.1.4.1.26138.2.137.1.2.1.2.33	Integer	33024
ibQinQv2IfServiceTPID.34	.1.3.6.1.4.1.26138.2.137.1.2.1.2.34	Integer	33024
ibQinQv2IfServiceTPID.35	.1.3.6.1.4.1.26138.2.137.1.2.1.2.35	Integer	33024
ibQinQv2IfServiceTPID.36	.1.3.6.1.4.1.26138.2.137.1.2.1.2.36	Integer	33024
ibQinQv2IfServiceTPID.37	.1.3.6.1.4.1.26138.2.137.1.2.1.2.37	Integer	33024
ibQinQv2IfServiceTPID.38	.1.3.6.1.4.1.26138.2.137.1.2.1.2.38	Integer	33024
ibQinQv2IfServiceTPID.39	.1.3.6.1.4.1.26138.2.137.1.2.1.2.39	Integer	33024
ibQinQv2IfServiceTPID.40	.1.3.6.1.4.1.26138.2.137.1.2.1.2.40	Integer	33024
ibQinQv2IfServiceTPID.41	.1.3.6.1.4.1.26138.2.137.1.2.1.2.41	Integer	33024
ibQinQv2IfServiceTPID.42	.1.3.6.1.4.1.26138.2.137.1.2.1.2.42	Integer	33024
ibQinQv2IfServiceTPID.43	.1.3.6.1.4.1.26138.2.137.1.2.1.2.43	Integer	33024
ibQinQv2IfServiceTPID.44	.1.3.6.1.4.1.26138.2.137.1.2.1.2.44	Integer	33024
ibQinQv2IfServiceTPID.45	.1.3.6.1.4.1.26138.2.137.1.2.1.2.45	Integer	33024
ibQinQv2IfServiceTPID.46	.1.3.6.1.4.1.26138.2.137.1.2.1.2.46	Integer	33024

Name	OID	Value Type	Value Example
ibQinQv2IfServiceTPID.47	.1.3.6.1.4.1.26138.2.137.1.2.1.2.47	Integer	33024
ibQinQv2IfServiceTPID.48	.1.3.6.1.4.1.26138.2.137.1.2.1.2.48	Integer	33024
ibQinQv2IfServiceTPID.49	.1.3.6.1.4.1.26138.2.137.1.2.1.2.49	Integer	33024
ibQinQv2IfServiceTPID.50	.1.3.6.1.4.1.26138.2.137.1.2.1.2.50	Integer	33024
ibQinQv2IfServiceTPID.51	.1.3.6.1.4.1.26138.2.137.1.2.1.2.51	Integer	33024
ibQinQv2IfServiceTPID.52	.1.3.6.1.4.1.26138.2.137.1.2.1.2.52	Integer	33024
ibQinQv2IfServiceTPID.53	.1.3.6.1.4.1.26138.2.137.1.2.1.2.53	Integer	33024
ibQinQv2IfServiceTPID.54	.1.3.6.1.4.1.26138.2.137.1.2.1.2.54	Integer	33024
ibQinQv2IfCustomerTPID.1	.1.3.6.1.4.1.26138.2.137.1.2.1.3.1	Integer	33024
ibQinQv2IfCustomerTPID.2	.1.3.6.1.4.1.26138.2.137.1.2.1.3.2	Integer	33024
ibQinQv2IfCustomerTPID.3	.1.3.6.1.4.1.26138.2.137.1.2.1.3.3	Integer	33024
ibQinQv2IfCustomerTPID.4	.1.3.6.1.4.1.26138.2.137.1.2.1.3.4	Integer	33024
ibQinQv2IfCustomerTPID.5	.1.3.6.1.4.1.26138.2.137.1.2.1.3.5	Integer	33024
ibQinQv2IfCustomerTPID.6	.1.3.6.1.4.1.26138.2.137.1.2.1.3.6	Integer	33024
ibQinQv2IfCustomerTPID.7	.1.3.6.1.4.1.26138.2.137.1.2.1.3.7	Integer	33024
ibQinQv2IfCustomerTPID.8	.1.3.6.1.4.1.26138.2.137.1.2.1.3.8	Integer	33024
ibQinQv2IfCustomerTPID.9	.1.3.6.1.4.1.26138.2.137.1.2.1.3.9	Integer	33024
ibQinQv2IfCustomerTPID.10	.1.3.6.1.4.1.26138.2.137.1.2.1.3.10	Integer	33024
ibQinQv2IfCustomerTPID.11	.1.3.6.1.4.1.26138.2.137.1.2.1.3.11	Integer	33024
ibQinQv2IfCustomerTPID.12	.1.3.6.1.4.1.26138.2.137.1.2.1.3.12	Integer	33024
ibQinQv2IfCustomerTPID.13	.1.3.6.1.4.1.26138.2.137.1.2.1.3.13	Integer	33024
ibQinQv2IfCustomerTPID.14	.1.3.6.1.4.1.26138.2.137.1.2.1.3.14	Integer	33024
ibQinQv2IfCustomerTPID.15	.1.3.6.1.4.1.26138.2.137.1.2.1.3.15	Integer	33024
ibQinQv2IfCustomerTPID.16	.1.3.6.1.4.1.26138.2.137.1.2.1.3.16	Integer	33024
ibQinQv2IfCustomerTPID.17	.1.3.6.1.4.1.26138.2.137.1.2.1.3.17	Integer	33024
ibQinQv2IfCustomerTPID.18	.1.3.6.1.4.1.26138.2.137.1.2.1.3.18	Integer	33024
ibQinQv2IfCustomerTPID.19	.1.3.6.1.4.1.26138.2.137.1.2.1.3.19	Integer	33024
ibQinQv2IfCustomerTPID.20	.1.3.6.1.4.1.26138.2.137.1.2.1.3.20	Integer	33024
ibQinQv2IfCustomerTPID.21	.1.3.6.1.4.1.26138.2.137.1.2.1.3.21	Integer	33024
ibQinQv2IfCustomerTPID.22	.1.3.6.1.4.1.26138.2.137.1.2.1.3.22	Integer	33024
ibQinQv2IfCustomerTPID.23	.1.3.6.1.4.1.26138.2.137.1.2.1.3.23	Integer	33024
ibQinQv2IfCustomerTPID.24	.1.3.6.1.4.1.26138.2.137.1.2.1.3.24	Integer	33024
ibQinQv2IfCustomerTPID.25	.1.3.6.1.4.1.26138.2.137.1.2.1.3.25	Integer	33024
ibQinQv2IfCustomerTPID.26	.1.3.6.1.4.1.26138.2.137.1.2.1.3.26	Integer	33024
ibQinQv2IfCustomerTPID.27	.1.3.6.1.4.1.26138.2.137.1.2.1.3.27	Integer	33024
ibQinQv2IfCustomerTPID.28	.1.3.6.1.4.1.26138.2.137.1.2.1.3.28	Integer	33024
ibQinQv2IfCustomerTPID.29	.1.3.6.1.4.1.26138.2.137.1.2.1.3.29	Integer	33024
ibQinQv2IfCustomerTPID.30	.1.3.6.1.4.1.26138.2.137.1.2.1.3.30	Integer	33024
ibQinQv2IfCustomerTPID.31	.1.3.6.1.4.1.26138.2.137.1.2.1.3.31	Integer	33024
ibQinQv2IfCustomerTPID.32	.1.3.6.1.4.1.26138.2.137.1.2.1.3.32	Integer	33024
ibQinQv2IfCustomerTPID.33	.1.3.6.1.4.1.26138.2.137.1.2.1.3.33	Integer	33024
ibQinQv2IfCustomerTPID.34	.1.3.6.1.4.1.26138.2.137.1.2.1.3.34	Integer	33024
ibQinQv2IfCustomerTPID.35	.1.3.6.1.4.1.26138.2.137.1.2.1.3.35	Integer	33024

Name	OID	Value Type	Value Example
ibQinQv2IfCustomerTPID.36	.1.3.6.1.4.1.26138.2.137.1.2.1.3.36	Integer	33024
ibQinQv2IfCustomerTPID.37	.1.3.6.1.4.1.26138.2.137.1.2.1.3.37	Integer	33024
ibQinQv2IfCustomerTPID.38	.1.3.6.1.4.1.26138.2.137.1.2.1.3.38	Integer	33024
ibQinQv2IfCustomerTPID.39	.1.3.6.1.4.1.26138.2.137.1.2.1.3.39	Integer	33024
ibQinQv2IfCustomerTPID.40	.1.3.6.1.4.1.26138.2.137.1.2.1.3.40	Integer	33024
ibQinQv2IfCustomerTPID.41	.1.3.6.1.4.1.26138.2.137.1.2.1.3.41	Integer	33024
ibQinQv2IfCustomerTPID.42	.1.3.6.1.4.1.26138.2.137.1.2.1.3.42	Integer	33024
ibQinQv2IfCustomerTPID.43	.1.3.6.1.4.1.26138.2.137.1.2.1.3.43	Integer	33024
ibQinQv2IfCustomerTPID.44	.1.3.6.1.4.1.26138.2.137.1.2.1.3.44	Integer	33024
ibQinQv2IfCustomerTPID.45	.1.3.6.1.4.1.26138.2.137.1.2.1.3.45	Integer	33024
ibQinQv2IfCustomerTPID.46	.1.3.6.1.4.1.26138.2.137.1.2.1.3.46	Integer	33024
ibQinQv2IfCustomerTPID.47	.1.3.6.1.4.1.26138.2.137.1.2.1.3.47	Integer	33024
ibQinQv2IfCustomerTPID.48	.1.3.6.1.4.1.26138.2.137.1.2.1.3.48	Integer	33024
ibQinQv2IfCustomerTPID.49	.1.3.6.1.4.1.26138.2.137.1.2.1.3.49	Integer	33024
ibQinQv2IfCustomerTPID.50	.1.3.6.1.4.1.26138.2.137.1.2.1.3.50	Integer	33024
ibQinQv2IfCustomerTPID.51	.1.3.6.1.4.1.26138.2.137.1.2.1.3.51	Integer	33024
ibQinQv2IfCustomerTPID.52	.1.3.6.1.4.1.26138.2.137.1.2.1.3.52	Integer	33024
ibQinQv2IfCustomerTPID.53	.1.3.6.1.4.1.26138.2.137.1.2.1.3.53	Integer	33024
ibQinQv2IfCustomerTPID.54	.1.3.6.1.4.1.26138.2.137.1.2.1.3.54	Integer	33024
ibQinQv2IfTransVlanList.1	.1.3.6.1.4.1.26138.2.137.1.2.1.4.1	OctetString	0x00 00

Name	OID	Value Type	Value Example
			00 00
ibQinQv2IfTransVlanList.2	.1.3.6.1.4.1.26138.2.137.1.2.1.4.2	OctetString	0x00 00















Name	OID	Value Type	Value Example
			00 00
ibQinQv2IfTransVlanList.10	.1.3.6.1.4.1.26138.2.137.1.2.1.4.10	OctetString	0x00 00
ibQinQv2IfTransVlanList.11	.1.3.6.1.4.1.26138.2.137.1.2.1.4.11	OctetString	0x00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00













Name	OID	Value Type	Value Example
			00 00
ibQinQv2IfTransVlanList.17	.1.3.6.1.4.1.26138.2.137.1.2.1.4.17	OctetString	0x00 00
ibQinQv2IfTransVlanList.18	.1.3.6.1.4.1.26138.2.137.1.2.1.4.18	OctetString	0x00 00













Name	OID	Value Type	Value Example
			00 00
ibQinQv2IfTransVlanList.24	.1.3.6.1.4.1.26138.2.137.1.2.1.4.24	OctetString	0x00 00
ibQinQv2IfTransVlanList.25	.1.3.6.1.4.1.26138.2.137.1.2.1.4.25	OctetString	0x00 00









Name	OID	Value Type	Value Example
			00 00
ibQinQv2IfTransVlanList.29	.1.3.6.1.4.1.26138.2.137.1.2.1.4.29	OctetString	0x00 00

Name	OID	Value Type	Value Example
			<pre> 00           </pre>
ibQinQv2IfTransVlanList.30	.1.3.6.1.4.1.26138.2.137.1.2.1.4.30	OctetString	<pre> 0x00           </pre>











Name	OID	Value Type	Value Example
			00 00
ibQinQv2IfTransVlanList.37	.1.3.6.1.4.1.26138.2.137.1.2.1.4.37	OctetString	0x00 00













Name	OID	Value Type	Value Example
			00 00
ibQinQv2IfTransVlanList.44	.1.3.6.1.4.1.26138.2.137.1.2.1.4.44	OctetString	0x00 00
ibQinQv2IfTransVlanList.45	.1.3.6.1.4.1.26138.2.137.1.2.1.4.45	OctetString	0x00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00













Name	OID	Value Type	Value Example
			00 00
ibQinQv2IfTransVlanList.51	.1.3.6.1.4.1.26138.2.137.1.2.1.4.51	OctetString	0x00 00
ibQinQv2IfTransVlanList.52	.1.3.6.1.4.1.26138.2.137.1.2.1.4.52	OctetString	0x00 00





Name	OID	Value Type	Value Example
			00 00
ibVMAPNNIState.1	.1.3.6.1.4.1.26138.2.138.1.1.1.1	Integer	false (2)
ibVMAPNNIState.2	.1.3.6.1.4.1.26138.2.138.1.1.1.2	Integer	false (2)
ibVMAPNNIState.3	.1.3.6.1.4.1.26138.2.138.1.1.1.3	Integer	false (2)
ibVMAPNNIState.4	.1.3.6.1.4.1.26138.2.138.1.1.1.4	Integer	false (2)
ibVMAPNNIState.5	.1.3.6.1.4.1.26138.2.138.1.1.1.5	Integer	false (2)
ibVMAPNNIState.6	.1.3.6.1.4.1.26138.2.138.1.1.1.6	Integer	false (2)
ibVMAPNNIState.7	.1.3.6.1.4.1.26138.2.138.1.1.1.7	Integer	false (2)
ibVMAPNNIState.8	.1.3.6.1.4.1.26138.2.138.1.1.1.8	Integer	false (2)
ibVMAPNNIState.9	.1.3.6.1.4.1.26138.2.138.1.1.1.9	Integer	false (2)
ibVMAPNNIState.10	.1.3.6.1.4.1.26138.2.138.1.1.1.10	Integer	false (2)
ibVMAPNNIState.11	.1.3.6.1.4.1.26138.2.138.1.1.1.11	Integer	false (2)
ibVMAPNNIState.12	.1.3.6.1.4.1.26138.2.138.1.1.1.12	Integer	false (2)
ibVMAPNNIState.13	.1.3.6.1.4.1.26138.2.138.1.1.1.13	Integer	false (2)
ibVMAPNNIState.14	.1.3.6.1.4.1.26138.2.138.1.1.1.14	Integer	false (2)
ibVMAPNNIState.15	.1.3.6.1.4.1.26138.2.138.1.1.1.15	Integer	false (2)
ibVMAPNNIState.16	.1.3.6.1.4.1.26138.2.138.1.1.1.16	Integer	false (2)
ibVMAPNNIState.17	.1.3.6.1.4.1.26138.2.138.1.1.1.17	Integer	false (2)
ibVMAPNNIState.18	.1.3.6.1.4.1.26138.2.138.1.1.1.18	Integer	false (2)
ibVMAPNNIState.19	.1.3.6.1.4.1.26138.2.138.1.1.1.19	Integer	false (2)
ibVMAPNNIState.20	.1.3.6.1.4.1.26138.2.138.1.1.1.20	Integer	false (2)
ibVMAPNNIState.21	.1.3.6.1.4.1.26138.2.138.1.1.1.21	Integer	false (2)
ibVMAPNNIState.22	.1.3.6.1.4.1.26138.2.138.1.1.1.22	Integer	false (2)

Name	OID	Value Type	Value Example
ibVMAPNNIState.23	.1.3.6.1.4.1.26138.2.138.1.1.1.23	Integer	false (2)
ibVMAPNNIState.24	.1.3.6.1.4.1.26138.2.138.1.1.1.24	Integer	false (2)
ibVMAPNNIState.25	.1.3.6.1.4.1.26138.2.138.1.1.1.25	Integer	false (2)
ibVMAPNNIState.26	.1.3.6.1.4.1.26138.2.138.1.1.1.26	Integer	false (2)
ibVMAPNNIState.27	.1.3.6.1.4.1.26138.2.138.1.1.1.27	Integer	false (2)
ibVMAPNNIState.28	.1.3.6.1.4.1.26138.2.138.1.1.1.28	Integer	false (2)
ibVMAPNNIState.29	.1.3.6.1.4.1.26138.2.138.1.1.1.29	Integer	false (2)
ibVMAPNNIState.30	.1.3.6.1.4.1.26138.2.138.1.1.1.30	Integer	false (2)
ibVMAPNNIState.31	.1.3.6.1.4.1.26138.2.138.1.1.1.31	Integer	false (2)
ibVMAPNNIState.32	.1.3.6.1.4.1.26138.2.138.1.1.1.32	Integer	false (2)
ibVMAPNNIState.33	.1.3.6.1.4.1.26138.2.138.1.1.1.33	Integer	false (2)
ibVMAPNNIState.34	.1.3.6.1.4.1.26138.2.138.1.1.1.34	Integer	false (2)
ibVMAPNNIState.35	.1.3.6.1.4.1.26138.2.138.1.1.1.35	Integer	false (2)
ibVMAPNNIState.36	.1.3.6.1.4.1.26138.2.138.1.1.1.36	Integer	false (2)
ibVMAPNNIState.37	.1.3.6.1.4.1.26138.2.138.1.1.1.37	Integer	false (2)
ibVMAPNNIState.38	.1.3.6.1.4.1.26138.2.138.1.1.1.38	Integer	false (2)
ibVMAPNNIState.39	.1.3.6.1.4.1.26138.2.138.1.1.1.39	Integer	false (2)
ibVMAPNNIState.40	.1.3.6.1.4.1.26138.2.138.1.1.1.40	Integer	false (2)
ibVMAPNNIState.41	.1.3.6.1.4.1.26138.2.138.1.1.1.41	Integer	false (2)
ibVMAPNNIState.42	.1.3.6.1.4.1.26138.2.138.1.1.1.42	Integer	false (2)
ibVMAPNNIState.43	.1.3.6.1.4.1.26138.2.138.1.1.1.43	Integer	false (2)
ibVMAPNNIState.44	.1.3.6.1.4.1.26138.2.138.1.1.1.44	Integer	false (2)
ibVMAPNNIState.45	.1.3.6.1.4.1.26138.2.138.1.1.1.45	Integer	false (2)
ibVMAPNNIState.46	.1.3.6.1.4.1.26138.2.138.1.1.1.46	Integer	false (2)
ibVMAPNNIState.47	.1.3.6.1.4.1.26138.2.138.1.1.1.47	Integer	false (2)
ibVMAPNNIState.48	.1.3.6.1.4.1.26138.2.138.1.1.1.48	Integer	false (2)
ibVMAPNNIState.49	.1.3.6.1.4.1.26138.2.138.1.1.1.49	Integer	false (2)
ibVMAPNNIState.50	.1.3.6.1.4.1.26138.2.138.1.1.1.50	Integer	false (2)
ibVMAPNNIState.51	.1.3.6.1.4.1.26138.2.138.1.1.1.51	Integer	false (2)
ibVMAPNNIState.52	.1.3.6.1.4.1.26138.2.138.1.1.1.52	Integer	false (2)
ibVMAPNNIState.53	.1.3.6.1.4.1.26138.2.138.1.1.1.53	Integer	false (2)
ibVMAPNNIState.54	.1.3.6.1.4.1.26138.2.138.1.1.1.54	Integer	false (2)
ibRbacFeatureDescription.2.110.100	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.2.110.100	OctetString	ND protocol related commands
ibRbacFeatureDescription.3.97.97.97	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.97.97.97	OctetString	AAA related commands
ibRbacFeatureDescription.3.97.99.108	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.97.99.108	OctetString	ACL related commands
ibRbacFeatureDescription.3.97.112.114	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.97.112.114	OctetString	Application Recognition related commands
ibRbacFeatureDescription.3.97.114.112	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.97.114.112	OctetString	ARP related commands
ibRbacFeatureDescription.3.97.116.107	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.97.116.107	OctetString	Attack Defence related commands



Name	OID	Value Type	Value Example
ibRbacFeatureDescription.3.98.102.100	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.98.102.100	OctetString	Bidirectional Forwarding Detection related commands
ibRbacFeatureDescription.3.98.103.112	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.98.103.112	OctetString	Border Gateway Protocol related commands
ibRbacFeatureDescription.3.99.99.102	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.99.99.102	OctetString	CCF related commands
ibRbacFeatureDescription.3.99.102.109	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.99.102.109	OctetString	CFM related commands
ibRbacFeatureDescription.3.101.112.97	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.101.112.97	OctetString	EPA related commands
ibRbacFeatureDescription.3.105.107.101	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.105.107.101	OctetString	IKE related commands
ibRbacFeatureDescription.3.105.114.102	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.105.114.102	OctetString	IRF related commands
ibRbacFeatureDescription.3.109.108.100	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.109.108.100	OctetString	Multicast Listener Discovery related commands
ibRbacFeatureDescription.3.109.116.112	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.109.116.112	OctetString	maintenance probe related commands
ibRbacFeatureDescription.3.110.113.97	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.110.113.97	OctetString	NQA related commands
ibRbacFeatureDescription.3.110.116.112	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.110.116.112	OctetString	NTP related commands
ibRbacFeatureDescription.3.112.98.114	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.112.98.114	OctetString	PBR related commands
ibRbacFeatureDescription.3.112.105.109	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.112.105.109	OctetString	Protocol Independent Multicast related commands
ibRbacFeatureDescription.3.112.111.101	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.112.111.101	OctetString	PoE related commands
ibRbacFeatureDescription.3.113.111.115	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.113.111.115	OctetString	QoS related commands
ibRbacFeatureDescription.3.114.105.112	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.114.105.112	OctetString	Routing Information Protocol related commands
ibRbacFeatureDescription.3.115.115.104	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.115.115.104	OctetString	SSH related commands
ibRbacFeatureDescription.3.115.116.112	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.115.116.112	OctetString	STP related commands
ibRbacFeatureDescription.3.118.98.114	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.118.98.114	OctetString	VBR related commands
ibRbacFeatureDescription.3.118.99.102	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.118.99.102	OctetString	VCF related commands
ibRbacFeatureDescription.3.119.101.98	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.3.119.101.98	OctetString	Web related commands
ibRbacFeatureDescription.4.98.121.111.100	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.4.98.121.111.100	OctetString	BYOD related commands
ibRbacFeatureDescription.4.99.119.109.112	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.4.99.119.109.112	OctetString	CWMP related commands
ibRbacFeatureDescription.4.100.100.110.115	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.4.100.100.110.115	OctetString	DDNS related commands
ibRbacFeatureDescription.4.100.104.99.112	.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.4.100.104.99.112	OctetString	DHCPv4 & DHCPv6 protocol stack related commands

Name	OID	Value Type	Value Example
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.100.108.100.112		OctetString	DLDP related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.101.111.97.109		OctetString	EOAM related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.101.114.102.115		OctetString	ERPS related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.102.105.102.115		OctetString	FIPS related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.103.114.072.99		OctetString	gRPC related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.105.103.109.112		OctetString	Internet Group Management Protocol related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.105.115.105.115		OctetString	ISIS protocol related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.108.50.102.116		OctetString	L2PT related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.108.97.99.112		OctetString	LACP related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.108.100.97.112		OctetString	LDAP related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.108.105.105.112		OctetString	LISP protocol related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.108.108.100.112		OctetString	LLDP related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.109.115.100.112		OctetString	Multicast Source Discovery Protocol related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.109.118.104.112		OctetString	MVRP related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.111.115.102.102		OctetString	Open Shortest Path First protocol related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.112.105.100.103		OctetString	PING related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.114.109.101.110		OctetString	Rmon related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.114.114.102.112		OctetString	RRPP related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.115.110.100.112		OctetString	SNMP related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.115.110.106.112		OctetString	SNTP related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.118.108.97.110		OctetString	Virtual LAN related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.118.114.104.112		OctetString	VRRP related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.118.115.104.112		OctetString	VSRP related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.4.119.115.97.108		OctetString	WSAL related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.2.5.104.116.116.112.100		OctetString	HTTPD related commands

Name	OID	Value Type	Value Example
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.5.105.112.102.105.98		OctetString	IP Forwarding Information Base related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.5.105.112.115.101.99		OctetString	IPsec related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.5.105.112.118.102.114		OctetString	IPVFR related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.5.108.50.109.97.100		OctetString	L2mad related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.5.108.51.118.112.110		OctetString	Layer 3 Virtual Private Network related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.5.114.111.117.116.101		OctetString	Route management related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.5.115.102.108.111.119		OctetString	SFlow related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.5.115.104.101.108.108		OctetString	Shell setting related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.5.116.114.97.99.107		OctetString	TRACK related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.5.118.120.108.97.110		OctetString	VXLAN related commands
ibRbacFeatureDescription.3.6.1.4.1.26138.2.158.1.1.1.1.2.6.99.114.121.112.116.111		OctetString	Crypto related commands
ibRbacFeatureDescription.3.6.1.4.1.26138.2.158.1.1.1.1.2.6.100.101.118.105.99.101		OctetString	Device configuration related commands
ibRbacFeatureDescription.3.6.1.4.1.26138.2.158.1.1.1.1.2.6.100.111.116.49.120.99		OctetString	Dot1x client related commands
ibRbacFeatureDescription.6.164.102.138.12.5.98.8.101.1.2.6.100.114.105.106.105.114		OctetString	Driver related commands
ibRbacFeatureDescription.6.164.102.138.12.5.98.4.111.1.2.6.109.105.114.106.105.114		OctetString	Mirror related commands
ibRbacFeatureDescription.3.6.1.4.1.26138.2.158.1.1.1.1.2.6.112.111.114.116.97.108		OctetString	Portal related commands
ibRbacFeatureDescription.6.164.102.138.12.5.98.1.101.1.2.6.112.112.112.106.105.114		OctetString	PPPoE Relay related commands
ibRbacFeatureDescription.3.6.1.4.1.26138.2.158.1.1.1.1.2.6.114.97.100.105.117.115		OctetString	RADIUS related commands
ibRbacFeatureDescription.6.164.102.138.12.5.98.9.111.1.2.6.114.101.115.106.105.114		OctetString	ResMon related commands
ibRbacFeatureDescription.6.164.102.138.12.5.98.8.111.1.2.6.115.121.115.106.105.114		OctetString	Syslog related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.1.1.1.2.6.116.97.99.97.99.115		OctetString	TACACS related commands
ibRbacFeatureDescription.6.164.102.138.12.5.98.0.101.1.2.6.116.101.108.106.105.114		OctetString	Telnet related commands
ibRbacFeatureDescription.6.164.102.138.12.0.98.0.101.1.2.6.116.117.110.106.105.114		OctetString	Tunnel related commands
ibRbacFeatureDescription.6.164.102.138.2.158.1.6.97.107.105.110.115.116.97.108.108		OctetString	Software install related commands
ibRbacFeatureDescription.7.1.26138.2.158.1.16.97.99.107.105.112.115.116.97.99.107		OctetString	IPv4 & IPv6 protocol stack related commands
ibRbacFeatureDescription.6.164.102.138.2.95.8.1.1.101.12.5.108.105.99.101.106.105.114		OctetString	License related commands
ibRbacFeatureDescription.6.164.102.138.2.158.9.1.111.12.0.102.101.116.99.106.105.114		OctetString	NETCONF related commands
ibRbacFeatureDescription.6.164.102.138.2.158.9.1.011.12.5.112.114.111.99.106.105.114		OctetString	Process related commands
ibRbacFeatureDescription.7.1.26138.2.158.1.16.102.17.1.108.01.115.116.97.108.108		OctetString	RESTful related commands
ibRbacFeatureDescription.7.1.26138.2.158.1.16.102.19.1.099.109.146.110.108.109.103.114		OctetString	cmtnlmgr related commands

Name	OID	Value Type	Value Example
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	Http-redirect related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	Keychain related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	Unicast static route related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	Terminal setting related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	Custom log related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	Event Management Information Base
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	Interface related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	Multicast related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	RADIUS-server-management related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	Scheduler related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	File system related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	IPCIM related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	Smart-link related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	Time range related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	UDPH related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	5MAC-Address related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	DMDEVMONITOR related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	MIB-Snooping related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	Monitor-link related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	Routing Policy related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	Profile related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	MIBSnooping related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	ETH related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	Loopback-detection related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	IPsec security related commands
ibRbacFeatureDescription.1.3.6.1.4.1.26138.2.158.1.112.1.212.104.10051116.112.104.105.1109.114		OctetString	OpenPlatform related commands
ibRbacRoleDefaultEnable.0	.1.3.6.1.4.1.26138.2.158.1.2.1.0	Integer	false (2)
ibRbacRoleDescription.1.3.6.1.4.1.26138.2.158.1.2.1.1		OctetString	Predefined level-0 role
ibRbacRoleDescription.1.3.6.1.4.1.26138.2.158.1.2.1.2		OctetString	Predefined level-1 role
ibRbacRoleDescription.1.3.6.1.4.1.26138.2.158.1.2.1.3		OctetString	Predefined level-2 role
ibRbacRoleDescription.1.3.6.1.4.1.26138.2.158.1.2.1.4		OctetString	Predefined level-3 role
ibRbacRoleDescription.1.3.6.1.4.1.26138.2.158.1.2.1.5		OctetString	Predefined level-4 role
ibRbacRoleDescription.1.3.6.1.4.1.26138.2.158.1.2.1.6		OctetString	Predefined level-5 role





Name	OID	Value Type	Value Example
ibRbacRoleStorageType67.108.2613812.168.108345.47.108.101.118.10110845.51		Integer	permanent (4)
ibRbacRoleStorageType67.108.2613812.168.108345.47.108.101.118.10110845.52		Integer	permanent (4)
ibRbacRoleStorageType67.108.2613812.168.108345.47.108.101.118.10110845.53		Integer	permanent (4)
ibRbacRoleStorageType67.108.2613812.168.108345.47.108.101.118.10110845.54		Integer	permanent (4)
ibRbacRoleStorageType67.108.2613812.168.108345.47.108.101.118.10110845.55		Integer	permanent (4)
ibRbacRoleStorageType67.108.2613812.168.108345.47.108.101.118.10110845.56		Integer	permanent (4)
ibRbacRoleStorageType67.108.2613812.168.108345.47.108.101.118.10110845.57		Integer	permanent (4)
ibRbacRoleStorageType681028103812.8501.208.148.89.08.101.118.101110845.49.48		Integer	permanent (4)
ibRbacRoleStorageType681028103812.8501.208.148.89.09.101.118.101110845.49.49		Integer	permanent (4)
ibRbacRoleStorageType681028103812.8501.208.148.89.08.101.118.101110845.49.50		Integer	permanent (4)
ibRbacRoleStorageType681028103812.8501.208.148.89.08.101.118.101110845.49.51		Integer	permanent (4)
ibRbacRoleStorageType681028103812.8501.208.148.89.08.101.118.101110845.49.52		Integer	permanent (4)
ibRbacRoleStorageType681028103812.8501.208.148.89.08.101.118.101110845.49.53		Integer	readOnly (5)
ibRbacRoleStorageType682.3583.217.10411816081614510091975.110.93.1081097110497.103.101.114		Integer	readOnly (5)
ibRbacRoleStorageType682.35810.201114.63.19.0.10.1.14.6.0.7.9.5.97.100.100.105.110		Integer	readOnly (5)
ibRbacRoleStorageType682.35811.2.301.499.4.175.10.109.118.124.465.97.101.100.105.116		Integer	readOnly (5)
ibRbacRoleStorageType682.35810.201114.63.19.0.10.1.14.6.0.7.9.5.97.100.100.105.110		Integer	readOnly (5)
ibRbacRoleRowStat67108.1026138.2015808245.45.7.108.101.118.10110845.48		Integer	active (1)
ibRbacRoleRowStat67108.1026138.2015808245.45.7.108.101.118.10110845.49		Integer	active (1)
ibRbacRoleRowStat67108.1026138.2015808245.55.7.108.101.118.10110845.50		Integer	active (1)
ibRbacRoleRowStat67108.1026138.2015808245.55.7.108.101.118.10110845.51		Integer	active (1)
ibRbacRoleRowStat67108.1026138.2015808245.55.7.108.101.118.10110845.52		Integer	active (1)
ibRbacRoleRowStat67108.1026138.2015808245.53.7.108.101.118.10110845.53		Integer	active (1)
ibRbacRoleRowStat67108.1026138.2015808245.54.7.108.101.118.10110845.54		Integer	active (1)
ibRbacRoleRowStat67108.1026138.2015808245.55.7.108.101.118.10110845.55		Integer	active (1)
ibRbacRoleRowStat67108.1026138.2015808245.55.7.108.101.118.10110845.56		Integer	active (1)
ibRbacRoleRowStat67108.1026138.2015808245.55.7.108.101.118.10110845.57		Integer	active (1)
ibRbacRoleRowStat681148.261382.168.108345.498408.101.118.101110845.49.48		Integer	active (1)
ibRbacRoleRowStat681148.261382.168.108345.498408.101.118.101110845.49.49		Integer	active (1)
ibRbacRoleRowStat681148.261382.168.108345.498508.101.118.101110845.49.50		Integer	active (1)
ibRbacRoleRowStat681148.261382.168.108345.498508.101.118.101110845.49.51		Integer	active (1)
ibRbacRoleRowStat681148.261382.168.108345.498508.101.118.101110845.49.52		Integer	active (1)
ibRbacRoleRowStat681148.261382.168.108345.498508.101.118.101110845.49.53		Integer	active (1)
ibRbacRoleRowStat682.35811.2.301.499.4.175.10.109.118.124.465.97.101.100.105.116		Integer	active (1)
ibRbacRoleRowStat682.35811.2.301.499.4.175.10.109.118.124.465.97.101.100.105.116		Integer	active (1)
ibRbacRuleAction.173.68.101.2683802.168.452481137.108.101.118.101110845.48.1.1		Integer	permit (1)
ibRbacRuleAction.173.68.101.2683802.168.452481137.108.101.118.101110845.48.1.2		Integer	permit (1)
ibRbacRuleAction.173.68.101.2683802.168.452481137.108.101.118.101110845.48.1.3		Integer	permit (1)
ibRbacRuleAction.173.68.101.2683802.168.452481137.108.101.118.101110845.48.1.4		Integer	permit (1)
ibRbacRuleAction.173.68.101.2683802.168.452481137.108.101.118.101110845.48.1.5		Integer	permit (1)
ibRbacRuleAction.173.68.101.2683802.168.452481137.108.101.118.101110845.48.1.6		Integer	permit (1)











Name	OID	Value Type	Value Example
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.101118.101	10844549153.1.9	{}
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.10110118.101	10844549153.1.10	{}
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.1011118.101	10844549153.1.11	{}
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.1012118.101	10844549153.1.12	{}
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.1013118.101	10844549153.1.13	{}
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.1014118.101	10844549153.1.14	{}
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.1015118.101	10844549153.1.15	{}
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.1016118.101	10844549153.1.16	{}
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.1017118.101	10844549153.1.17	{}
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.1018118.101	10844549153.1.18	{}
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.1019118.101	10844549153.1.19	{}
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.1020118.101	10844549153.1.20	{}
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.1021118.101	10844549153.1.21	{}
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.1022118.101	10844549153.1.22	{}
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.1023118.101	10844549153.1.23	{}
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.1024118.101	10844549153.1.24	{}
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.1025118.101	10844549153.1.25	{}
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.1026118.101	10844549153.1.26	{}
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.1027118.101	10844549153.1.27	{}
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.1028118.101	10844549153.1.28	{}
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.1029118.101	10844549153.1.29	{}
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.1030118.101	10844549153.1.30	{}
ibRbacRuleOperator136.184.10261038	2.85801.208145.89.68.1031118.101	10844549153.1.31	{}
ibRbacRuleOperator136.23158312.7.104.113.503.6.145.1109.97511106945109071109171	103.101.114.1.1{exec, read, write}		
ibRbacRuleOperator136.23158312.7.104.113.503.6.145.1109.97511106945109071109171	103.101.114.1.2{exec, read, write}		
ibRbacRuleOperator136.23158312.7.104.113.503.6.145.1109.97511106945109071109171	103.101.114.1.3{exec, read, write}		
ibRbacRuleOperator136.23158312.7.104.113.503.6.145.1109.97511106945109071109171	103.101.114.1.4{exec, read, write}		
ibRbacRuleOperator136.23158312.7.104.113.503.6.145.1109.97511106945109071109171	103.101.114.1.5{exec, read, write}		
ibRbacRuleOperator136.23158312.7.104.113.503.6.145.1109.97511106945109071109171	103.101.114.1.6{exec, read, write}		
ibRbacRuleOperator136.23158312.7.104.113.503.6.145.1109.97511106945109071109171	103.101.114.1.7{exec, read, write}		
ibRbacRuleOperator136.23158312.7.104.113.503.6.145.1109.97511106945109071109171	103.101.114.1.8 {exec}		
ibRbacRuleOperator136.23158312.7.104.113.503.6.145.1109.97511106945109071109171	103.101.114.1.9{exec, read, write}		
ibRbacRuleOperator136.23580.204.11.461319101101141607195197.104.109469971109	109.105.110.1.10 {}		
ibRbacRuleOperator136.23580.204.11.461319101101141607195197.104.109469971109	109.105.110.1.1 {}		
ibRbacRuleOperator136.23580.204.11.461319101101141607195197.104.109469971109	209.105.110.1.2{exec, read, write}		
ibRbacRuleOperator136.23580.204.11.461319101101141607195197.104.109469971109	309.105.110.1.3{exec, read, write}		
ibRbacRuleOperator136.23580.204.11.461319101101141607195197.104.109469971109	409.105.110.1.4 {}		
ibRbacRuleOperator136.23580.204.11.461319101101141607195197.104.109469971109	509.105.110.1.5 {}		
ibRbacRuleOperator136.23580.204.11.461319101101141607195197.104.109469971109	609.105.110.1.6 {}		
ibRbacRuleOperator136.23580.204.11.461319101101141607195197.104.109469971109	709.105.110.1.7 {}		
ibRbacRuleOperator136.23580.204.11.461319101101141607195197.104.109469971109	809.105.110.1.8 {read, write}		
ibRbacRuleOperator136.188152.101.99.4.117.5.141095.1116.11244597.167.10041971187	11.00.105.116.1.1 {}		
ibRbacRuleOperator136.188152.101.99.4.117.5.141095.1116.11244597.167.10041971187	11.00.105.116.1.2 {}		





Name	OID	Value Type	Value Example
ibRbacRuleDefn158.113.401	1.109.116.124.46597161	2005195.116.100105.116.1.46	{}
ibRbacRuleDefn158.113.401	1.109.116.124.46597161	2005195.116.100105.116.1.47	{}
ibRbacRuleDefn158.113.401	1.109.116.124.46597161	2005195.116.100105.116.1.48	{}
ibRbacRuleDefn158.113.401	1.109.116.124.46597161	2005195.116.100105.116.1.49	{}
ibRbacRuleDefn158.113.401	1.109.116.124.46597161	2005195.116.100105.116.1.50	{}
ibRbacRuleDefn158.113.401	1.109.116.124.46597161	2005195.116.100105.116.1.51	{}
ibRbacRuleDefn158.113.401	1.109.116.124.46597161	2005195.116.100105.116.1.52	{}
ibRbacRuleDefn158.113.401	1.109.116.124.46597161	2005195.116.100105.116.1.53	{}
1.3cRbacRuleDefn118.4.1104106	1.116.109.116.119.107.4541107145	10c145901g164197.16.111.114.1.1	{}
1.3cRbacRuleDefn118.4.1104106	1.116.109.116.119.107.4541107145	10c145901g164197.16.112.114.1.2	{}
1.3cRbacRuleDefn118.4.1104106	1.116.109.116.119.107.4541107145	10c145901g164197.16.113.114.1.3	{}
1.3cRbacRuleDefn118.4.1104106	1.116.109.116.119.107.4541107145	10c145901g164197.16.114.114.1.4	{}
1.3cRbacRuleDefn118.4.1104106	1.116.109.116.119.107.4541107145	10c145901g164197.16.115.114.1.5	{}
1.3cRbacRuleDefn118.4.1104106	1.116.109.116.119.107.4541107145	10c145901g164197.16.116.114.1.6	{}
1.3cRbacRuleDefn118.4.1104106	1.116.109.116.119.107.4541107145	10c145901g164197.16.117.114.1.7	{}
1.3cRbacRuleDefn118.4.1104106	1.116.109.116.119.107.4541107145	10c145901g164197.16.118.114.1.8	{}
1.3cRbacRuleDefn118.4.1104106	1.116.109.116.119.107.4541107145	10c145901g164197.16.119.114.1.9	{}
1.3i5RbacRuleDefn1264.1.0.106	1.11061019116111941107145.1107.4521	10c145901g164197.16.111.14.1.10	{}
1.3i5RbacRuleDefn1264.1.0.106	1.11061019116111941107145.1107.4521	10c145901g164197.16.111.11.14.1.11	{}
1.3i5RbacRuleDefn1264.1.0.106	1.11061019116111941107145.1107.4521	10c145901g164197.16.111.12.14.1.12	{}
1.3i5RbacRuleDefn1264.1.0.106	1.11061019116111941107145.1107.4521	10c145901g164197.16.111.13.14.1.13	{}
1.3i5RbacRuleDefn1264.1.0.106	1.11061019116111941107145.1107.4521	10c145901g164197.16.111.14.14.1.14	{}
1.3i5RbacRuleDefn1264.1.0.106	1.11061019116111941107145.1107.4521	10c145901g164197.16.111.15.14.1.15	{}
1.3i5RbacRuleDefn1264.1.0.106	1.11061019116111941107145.1107.4521	10c145901g164197.16.111.16.14.1.16	{read}
1.3i5RbacRuleDefn1264.1.0.106	1.11061019116111941107145.1107.4521	10c145901g164197.16.111.17.14.1.17	{read, write}
1.3i5RbacRuleDefn1264.1.0.106	1.11061019116111941107145.1107.4521	10c145901g164197.16.111.18.14.1.18	{read}
1.3i5RbacRuleDefn1264.1.0.106	1.11061019116111941107145.1107.4521	10c145901g164197.16.111.19.14.1.19	{exec}
1.3i5RbacRuleDefn1264.1.0.106	1.11061019116111941107145.1107.4521	10c145901g164197.16.111.20.14.1.20	{exec}
1.3i5RbacRuleDefn1264.1.0.106	1.11061019116111941107145.1107.4521	10c145901g164197.16.111.21.14.1.21	{}
1.3i5RbacRuleDefn1264.1.0.106	1.11061019116111941107145.1107.4521	10c145901g164197.16.111.22.14.1.22	{}
1.3i5RbacRuleDefn1264.1.0.106	1.11061019116111941107145.1107.4521	10c145901g164197.16.111.23.14.1.23	{}
1.3i5RbacRuleDefn1264.1.0.106	1.11061019116111941107145.1107.4521	10c145901g164197.16.111.24.14.1.24	{}
1.3i5RbacRuleDefn1264.1.0.106	1.11061019116111941107145.1107.4521	10c145901g164197.16.111.25.14.1.25	{}
1.3i5RbacRuleDefn1264.1.0.106	1.11061019116111941107145.1107.4521	10c145901g164197.16.111.26.14.1.26	{}
1.3i5RbacRuleDefn1264.1.0.106	1.11061019116111941107145.1107.4521	10c145901g164197.16.111.27.14.1.27	{read}
1.3i5RbacRuleDefn1264.1.0.106	1.11061019116111941107145.1107.4521	10c145901g164197.16.111.28.14.1.28	{}
1.3i5RbacRuleDefn1264.1.0.106	1.11061019116111941107145.1107.4521	10c145901g164197.16.111.29.14.1.29	{}
1.3i5RbacRuleDefn1264.1.0.106	1.11061019116111941107145.1107.4521	10c145901g164197.16.111.30.14.1.30	{}
ibRbacRuleEntityType671408.26138.2.168.108445.587.1108.101.118.10	1110845.48.1.1	command (2)	
ibRbacRuleEntityType671408.26138.2.168.108445.587.1108.101.118.10	1110845.48.1.2	command (2)	
ibRbacRuleEntityType671408.26138.2.168.108445.587.1108.101.118.10	1110845.48.1.3	command (2)	
ibRbacRuleEntityType671408.26138.2.168.108445.587.1108.101.118.10	1110845.48.1.4	command (2)	
ibRbacRuleEntityType671408.26138.2.168.108445.587.1108.101.118.10	1110845.48.1.5	command (2)	

Name	OID	Value Type	Value Example
ibRbacRuleEntity.Type671408.26138.2.168.10845.57.1.08.101.118.101	110845.48.1.6	command (2)	
ibRbacRuleEntity.Type671408.26138.2.168.10845.57.1.08.101.118.101	110845.49.1.1	command (2)	
ibRbacRuleEntity.Type671408.26138.2.168.10845.57.1.08.101.118.101	110845.49.1.2	command (2)	
ibRbacRuleEntity.Type671408.26138.2.168.10845.57.1.08.101.118.101	110845.49.1.3	command (2)	
ibRbacRuleEntity.Type671408.26138.2.168.10845.57.1.08.101.118.101	110845.49.1.4	command (2)	
ibRbacRuleEntity.Type671408.26138.2.168.10845.57.1.08.101.118.101	110845.49.1.5	command (2)	
ibRbacRuleEntity.Type671408.26138.2.168.10845.57.1.08.101.118.101	110845.49.1.6	command (2)	
ibRbacRuleEntity.Type671408.26138.2.168.10845.57.1.08.101.118.101	110845.49.1.7	command (2)	
ibRbacRuleEntity.Type671408.26138.2.168.10845.57.1.08.101.118.101	110845.49.1.8	command (2)	
ibRbacRuleEntity.Type671408.26138.2.168.10845.57.1.08.101.118.101	110845.57.1.1	feature (3)	
ibRbacRuleEntity.Type671408.26138.2.168.10845.57.1.08.101.118.101	110845.57.1.2	feature (3)	
ibRbacRuleEntity.Type671408.26138.2.168.10845.57.1.08.101.118.101	110845.57.1.3	feature (3)	
ibRbacRuleEntity.Type671408.26138.2.168.10845.57.1.08.101.118.101	110845.57.1.4	command (2)	
ibRbacRuleEntity.Type671408.26138.2.168.10845.57.1.08.101.118.101	110845.57.1.5	command (2)	
ibRbacRuleEntity.Type18410261038128581.208.45.89158.101.118.101	1084549.53.1.1	command (2)	
ibRbacRuleEntity.Type18410261038128581.208.45.89158.102.118.101	1084549.53.1.2	webmenu (5)	
ibRbacRuleEntity.Type18410261038128581.208.45.89158.103.118.101	1084549.53.1.3	xmlelement (6)	
ibRbacRuleEntity.Type18410261038128581.208.45.89158.104.118.101	1084549.53.1.4	command (2)	
ibRbacRuleEntity.Type18410261038128581.208.45.89158.105.118.101	1084549.53.1.5	command (2)	
ibRbacRuleEntity.Type18410261038128581.208.45.89158.106.118.101	1084549.53.1.6	command (2)	
ibRbacRuleEntity.Type18410261038128581.208.45.89158.107.118.101	1084549.53.1.7	command (2)	
ibRbacRuleEntity.Type18410261038128581.208.45.89158.108.118.101	1084549.53.1.8	oid (7)	
ibRbacRuleEntity.Type18410261038128581.208.45.89158.109.118.101	1084549.53.1.9	command (2)	
ibRbacRuleEntity.Type648.102610382185801.208145.89158.11010118.101	1084549.53.1.10	command (2)	
ibRbacRuleEntity.Type648.102610382185801.208145.89158.11011118.101	1084549.53.1.11	command (2)	
ibRbacRuleEntity.Type648.102610382185801.208145.89158.11012118.101	1084549.53.1.12	command (2)	
ibRbacRuleEntity.Type648.102610382185801.208145.89158.11013118.101	1084549.53.1.13	command (2)	
ibRbacRuleEntity.Type648.102610382185801.208145.89158.11014118.101	1084549.53.1.14	command (2)	
ibRbacRuleEntity.Type648.102610382185801.208145.89158.11015118.101	1084549.53.1.15	command (2)	
ibRbacRuleEntity.Type648.102610382185801.208145.89158.11016118.101	1084549.53.1.16	command (2)	
ibRbacRuleEntity.Type648.102610382185801.208145.89158.11017118.101	1084549.53.1.17	command (2)	
ibRbacRuleEntity.Type648.102610382185801.208145.89158.11018118.101	1084549.53.1.18	command (2)	
ibRbacRuleEntity.Type648.102610382185801.208145.89158.11019118.101	1084549.53.1.19	command (2)	
ibRbacRuleEntity.Type648.102610382185801.208145.89158.11020118.101	1084549.53.1.20	command (2)	
ibRbacRuleEntity.Type648.102610382185801.208145.89158.11021118.101	1084549.53.1.21	command (2)	
ibRbacRuleEntity.Type648.102610382185801.208145.89158.11022118.101	1084549.53.1.22	command (2)	
ibRbacRuleEntity.Type648.102610382185801.208145.89158.11023118.101	1084549.53.1.23	command (2)	
ibRbacRuleEntity.Type648.102610382185801.208145.89158.11024118.101	1084549.53.1.24	command (2)	
ibRbacRuleEntity.Type648.102610382185801.208145.89158.11025118.101	1084549.53.1.25	command (2)	
ibRbacRuleEntity.Type648.102610382185801.208145.89158.11026118.101	1084549.53.1.26	command (2)	
ibRbacRuleEntity.Type648.102610382185801.208145.89158.11027118.101	1084549.53.1.27	command (2)	
ibRbacRuleEntity.Type648.102610382185801.208145.89158.11028118.101	1084549.53.1.28	command (2)	
ibRbacRuleEntity.Type648.102610382185801.208145.89158.11029118.101	1084549.53.1.29	command (2)	

Name	OID	Value Type	Value Example
ibRbacRuleEntityByPId.8.10261038	2185801.2.08145.8.9.58.11030118.101	1084549.53.1.30	command (2)
ibRbacRuleEntityByPId.8.10261038	2185801.2.08145.8.9.58.11031118.101	1084549.53.1.31	command (2)
ibRbacRuleEntityByPId.2.31583.1214.10511815081614510091915.11106945.11031003110497.1103.101	114.1.1	xmlelement (6)	
ibRbacRuleEntityByPId.2.31583.1214.10511815081614510091915.11106945.11031003110497.2103.101	114.1.2	xmlelement (6)	
ibRbacRuleEntityByPId.2.31583.1214.10511815081614510091915.11106945.11031003110497.3103.101	114.1.3	xmlelement (6)	
ibRbacRuleEntityByPId.2.31583.1214.10511815081614510091915.11106945.11031003110497.4103.101	114.1.4	xmlelement (6)	
ibRbacRuleEntityByPId.2.31583.1214.10511815081614510091915.11106945.11031003110497.5103.101	114.1.5	xmlelement (6)	
ibRbacRuleEntityByPId.2.31583.1214.10511815081614510091915.11106945.11031003110497.6103.101	114.1.6	xmlelement (6)	
ibRbacRuleEntityByPId.2.31583.1214.10511815081614510091915.11106945.11031003110497.7103.101	114.1.7	xmlelement (6)	
ibRbacRuleEntityByPId.2.31583.1214.10511815081614510091915.11106945.11031003110497.8103.101	114.1.8	xmlelement (6)	
ibRbacRuleEntityByPId.2.31583.1214.10511815081614510091915.11106945.11031003110497.9103.101	114.1.9	xmlelement (6)	
ibRbacRuleEntityByPId.2.3580.3.210115.113.1153.116.451009.95.116.95.103.110497.103.101	114.1.10	command (2)	
ibRbacRuleEntityByPId.2.3580.0.204115.6.3.119.0.1101.114.6.07.95.97.100.109.109.105.110.1.1	command (2)		
ibRbacRuleEntityByPId.2.3580.0.204115.6.3.119.0.1101.114.6.07.95.97.100.109.109.105.110.1.2	webmenu (5)		
ibRbacRuleEntityByPId.2.3580.0.204115.6.3.119.0.1101.114.6.07.95.97.100.109.109.105.110.1.3	xmlelement (6)		
ibRbacRuleEntityByPId.2.3580.0.204115.6.3.119.0.1101.114.6.07.95.97.100.109.109.105.110.1.4	command (2)		
ibRbacRuleEntityByPId.2.3580.0.204115.6.3.119.0.1101.114.6.07.95.97.100.109.109.105.110.1.5	command (2)		
ibRbacRuleEntityByPId.2.3580.0.204115.6.3.119.0.1101.114.6.07.95.97.100.109.109.105.110.1.6	command (2)		
ibRbacRuleEntityByPId.2.3580.0.204115.6.3.119.0.1101.114.6.07.95.97.100.109.109.105.110.1.7	command (2)		
ibRbacRuleEntityByPId.2.3580.0.204115.6.3.119.0.1101.114.6.07.95.97.100.109.109.105.110.1.8	oid (7)		
ibRbacRuleEntityByPId.198115.401594.175.10109.116.124.4597.116.71109597.116.100.105.116.1.1	command (2)		
ibRbacRuleEntityByPId.198115.401594.175.10109.116.124.4597.116.71109597.116.100.105.116.1.2	command (2)		
ibRbacRuleEntityByPId.198115.401594.175.10109.116.124.4597.116.71109597.116.100.105.116.1.3	command (2)		
ibRbacRuleEntityByPId.198115.401594.175.10109.116.124.4597.116.71109597.116.100.105.116.1.4	command (2)		
ibRbacRuleEntityByPId.198115.401594.175.10109.116.124.4597.116.71109597.116.100.105.116.1.5	command (2)		
ibRbacRuleEntityByPId.198115.401594.175.10109.116.124.4597.116.71109597.116.100.105.116.1.6	command (2)		
ibRbacRuleEntityByPId.198115.401594.175.10109.116.124.4597.116.71109597.116.100.105.116.1.7	command (2)		
ibRbacRuleEntityByPId.198115.401594.175.10109.116.124.4597.116.71109597.116.100.105.116.1.8	command (2)		
ibRbacRuleEntityByPId.198115.401594.175.10109.116.124.4597.116.71109597.116.100.105.116.1.9	command (2)		
ibRbacRuleEntityByPId.58.1125.4.05994117511041995.11175.1124.43597161721109597.11175.1100105.116.1.10	command (2)		
ibRbacRuleEntityByPId.58.1125.4.05994117511041995.11175.1124.43597161721109597.11175.11001105.116.1.11	command (2)		
ibRbacRuleEntityByPId.58.1125.4.05994117511041995.11175.1124.43597161721109597.11175.11002105.116.1.12	command (2)		
ibRbacRuleEntityByPId.58.1125.4.05994117511041995.11175.1124.43597161721109597.11175.11003105.116.1.13	command (2)		
ibRbacRuleEntityByPId.58.1125.4.05994117511041995.11175.1124.43597161721109597.11175.11004105.116.1.14	command (2)		
ibRbacRuleEntityByPId.58.1125.4.05994117511041995.11175.1124.43597161721109597.11175.11005105.116.1.15	command (2)		
ibRbacRuleEntityByPId.58.1125.4.05994117511041995.11175.1124.43597161721109597.11175.11006105.116.1.16	command (2)		
ibRbacRuleEntityByPId.58.1125.4.05994117511041995.11175.1124.43597161721109597.11175.11007105.116.1.17	command (2)		
ibRbacRuleEntityByPId.58.1125.4.05994117511041995.11175.1124.43597161721109597.11175.11008105.116.1.18	command (2)		
ibRbacRuleEntityByPId.58.1125.4.05994117511041995.11175.1124.43597161721109597.11175.11009105.116.1.19	command (2)		
ibRbacRuleEntityByPId.58.1125.4.05994117511041995.11175.1124.43597161721109597.11175.11020105.116.1.20	command (2)		
ibRbacRuleEntityByPId.58.1125.4.05994117511041995.11175.1124.43597161721109597.11175.11021105.116.1.21	command (2)		
ibRbacRuleEntityByPId.58.1125.4.05994117511041995.11175.1124.43597161721109597.11175.11022105.116.1.22	command (2)		
ibRbacRuleEntityByPId.58.1125.4.05994117511041995.11175.1124.43597161721109597.11175.11023105.116.1.23	command (2)		









Name	OID	Value Type	Value Example
ibRbacRuleEntity.3.608.4.0126138.211588145.49.531108.101.118.101.108.4549.53.1.6			system-view ; info-center security-logfile directory *
ibRbacRuleEntity.3.608.4.0126138.211588145.49.531108.101.118.101.108.4549.53.1.7			security-logfile save
ibRbacRuleEntity.3.608.4.0126138.211588145.49.531108.101.118.101.108.4549.53.1.8			1
ibRbacRuleEntity.3.608.4.0126138.211588145.49.531108.101.118.101.108.4549.53.1.9			display smartmc *
ibRbacRuleEntity.3.60841026138.211588.25449.53.108.101.118.101.108.4549.53.1.10			debugging smartmc *
ibRbacRuleEntity.3.60841026138.211588.25449.53.108.101.118.101.108.4549.53.1.11			undo debugging smartmc *
ibRbacRuleEntity.3.60841026138.211588.25449.53.108.101.118.101.108.4549.53.1.12			system-view ; smartmc *
ibRbacRuleEntity.3.60841026138.211588.25449.53.108.101.118.101.108.4549.53.1.13			system-view ; undo smartmc *
ibRbacRuleEntity.3.60841026138.211588.25449.53.108.101.118.101.108.4549.53.1.14			system-view ; interface * ; smartmc *
ibRbacRuleEntity.3.60841026138.211588.25449.53.108.101.118.101.108.4549.53.1.15			system-view ; interface * ; undo smartmc *
ibRbacRuleEntity.3.60841026138.211588.25449.53.108.101.118.101.108.4549.53.1.16			display qzts *
ibRbacRuleEntity.3.60841026138.211588.25449.53.108.101.118.101.108.4549.53.1.17			debugging qzts *
ibRbacRuleEntity.3.60841026138.211588.25449.53.108.101.118.101.108.4549.53.1.18			undo debugging qzts *
ibRbacRuleEntity.3.60841026138.211588.25449.53.108.101.118.101.108.4549.53.1.19			system-view ; qzts *
ibRbacRuleEntity.3.60841026138.211588.25449.53.108.101.118.101.108.4549.53.1.20			system-view ; undo qzts *
ibRbacRuleEntity.3.60841026138.211588.25449.53.108.101.118.101.108.4549.53.1.21			system-view ; interface * ; qzts *
ibRbacRuleEntity.3.60841026138.211588.25449.53.108.101.118.101.108.4549.53.1.22			system-view ; interface * ; undo qzts *
ibRbacRuleEntity.3.60841026138.211588.25449.53.108.101.118.101.108.4549.53.1.23			display winet *
ibRbacRuleEntity.3.60841026138.211588.25449.53.108.101.118.101.108.4549.53.1.24			debugging winet *
ibRbacRuleEntity.3.60841026138.211588.25449.53.108.101.118.101.108.4549.53.1.25			undo debugging winet *
ibRbacRuleEntity.3.60841026138.211588.25449.53.108.101.118.101.108.4549.53.1.26			system-view ; winet *
ibRbacRuleEntity.3.60841026138.211588.25449.53.108.101.118.101.108.4549.53.1.27			system-view ; undo winet *
ibRbacRuleEntity.3.60841026138.211588.25449.53.108.101.118.101.108.4549.53.1.28			system-view ; interface * ; winet *
ibRbacRuleEntity.3.60841026138.211588.25449.53.108.101.118.101.108.4549.53.1.29			system-view ; interface * ; undo winet *
ibRbacRuleEntity.3.60841026138.211588.25449.53.108.101.118.101.108.4549.53.1.30			create batch-file *
ibRbacRuleEntity.3.60841026138.211588.25449.53.108.101.118.101.108.4549.53.1.31			smartmc *
ibRbacRuleEntity.61380315871124.116.136.03.109.907110597160351009074150.97.103.101.114.1.1			useraccounts/approveguest/
ibRbacRuleEntity.61380315871124.116.136.03.109.907110597160351009074150.97.103.101.114.1.2			useraccounts/exportguestaccount/
ibRbacRuleEntity.61380315871124.116.136.03.109.907110597160351009074150.97.103.101.114.1.3			useraccounts/generateguestaccount/
ibRbacRuleEntity.61380315871124.116.136.03.109.907110597160351009074150.97.103.101.114.1.4			useraccounts/guest/
ibRbacRuleEntity.61380315871124.116.136.03.109.907110597160351009074150.97.103.101.114.1.5			useraccounts/guestconfigure/
ibRbacRuleEntity.61380315871124.116.136.03.109.907110597160351009074150.97.103.101.114.1.6			useraccounts/importguestaccount/
ibRbacRuleEntity.61380315871124.116.136.03.109.907110597160351009074150.97.103.101.114.1.7			useraccounts/exportguesttemplate/
ibRbacRuleEntity.61380315871124.116.136.03.109.907110597160351009074150.97.103.101.114.1.8			useraccounts/changemypassword
ibRbacRuleEntity.61380315871124.116.136.03.109.907110597160351009074150.97.103.101.114.1.9			rpc/

Name	OID	Value Type	Value Example
ibRbacRuleEntry	1.38.2.0.3.5.8.1.204.1.691B110D140107145197.100..109.1105.104.103.101	String	114.1.10 *
ibRbacRuleEntry	1.38.2.0.58.1.1.216.1.691B110D140107145197.100..109.1105.104.103.101	String	109.105.110.1.1 *
ibRbacRuleEntry	1.38.2.0.58.1.1.216.1.691B110D140107145197.100..109.1105.104.103.101	String	109.105.110.1.2
ibRbacRuleEntry	1.38.2.0.58.1.1.216.1.691B110D140107145197.100..109.1105.104.103.101	String	109.105.110.1.3
ibRbacRuleEntry	1.38.2.0.58.1.1.216.1.691B110D140107145197.100..109.1105.104.103.101	String	display security-logfile summary
ibRbacRuleEntry	1.38.2.0.58.1.1.216.1.691B110D140107145197.100..109.1105.104.103.101	String	display security-logfile buffer
ibRbacRuleEntry	1.38.2.0.58.1.1.216.1.691B110D140107145197.100..109.1105.104.103.101	String	system-view ; info-center security-logfile directory *
ibRbacRuleEntry	1.38.2.0.58.1.1.216.1.691B110D140107145197.100..109.1105.104.103.101	String	110.1 security-logfile save
ibRbacRuleEntry	1.38.2.0.58.1.1.216.1.691B110D140107145197.100..109.1105.104.103.101	String	110.1.8 1
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.1 *
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	display.2 security-logfile summary
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	display.3 security-logfile buffer
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	system-view ; info-center security-logfile directory *
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.3 security-logfile save
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.6 cd *
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.7 copy *
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.8 delete *
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.9 dir *
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.10 mkdir *
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.11 more *
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.12 move *
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.13 rmdir *
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.14 pwd
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.15 rename *
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.16 undelete *
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.17 ftp *
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.18 sftp *
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.19 virtual-ftp-append
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.20 virtual-ftp-ascii
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.21 virtual-ftp-binary
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.22 virtual-ftp-bye
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.23 virtual-ftp-cd
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.24 virtual-ftp-cdup
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.25 virtual-ftp-close
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.26 virtual-ftp-delete
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.27 virtual-ftp-debug
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.28 virtual-ftp-dir
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.29 virtual-ftp-disconnect
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.30 virtual-ftp-get
ibRbacRuleEntry	3.8.2.1.58.0.1299.1.671414150E0199121745197105711601204499.ing	String	7.100.105.116.1.31 virtual-ftp-help

Name	OID	Value Type	Value Example
ibRba6RuleE2603842115810.2.991	3.74.145.06.1.96.127.45.4705.7.160	204896.hg2	100.105.116.1.32virtual-ftp-lcd
ibRba6RuleE2603842115810.2.991	3.74.145.06.1.96.127.45.4705.7.160	204896.hg3	100.105.116.1.33virtual-ftp-ls
ibRba6RuleE2603842115810.2.991	3.74.145.06.1.96.127.45.4705.7.160	204896.hg4	100.105.116.1.34rtual-ftp-mkdir
ibRba6RuleE2603842115810.2.991	3.74.145.06.1.96.127.45.4705.7.160	204896.hg5	100.105.116.1.35rtual-ftp-newer
ibRba6RuleE2603842115810.2.991	3.74.145.06.1.96.127.45.4705.7.160	204896.hg6	100.105.116.1.36rtual-ftp-open
ibRba6RuleE2603842115810.2.991	3.74.145.06.1.96.127.45.4705.7.160	204896.hg7	100.105.116.1.37rtual-ftp-passive
ibRba6RuleE2603842115810.2.991	3.74.145.06.1.96.127.45.4705.7.160	204896.hg8	100.105.116.1.38irtual-ftp-put
ibRba6RuleE2603842115810.2.991	3.74.145.06.1.96.127.45.4705.7.160	204896.hg9	100.105.116.1.39irtual-ftp-pwd
ibRba6RuleE2603842115810.2.991	3.74.145.06.1.96.127.45.4705.7.160	204896.hg0	100.105.116.1.40irtual-ftp-quit
ibRba6RuleE2603842115810.2.991	3.74.145.06.1.96.127.45.4705.7.160	204896.hg1	100.105.116.1.41rtual-ftp-reget
ibRba6RuleE2603842115810.2.991	3.74.145.06.1.96.127.45.4705.7.160	204896.hg2	100.105.116.1.42rtual-ftp-rstatus
ibRba6RuleE2603842115810.2.991	3.74.145.06.1.96.127.45.4705.7.160	204896.hg3	100.105.116.1.43rtual-ftp-rhelp
ibRba6RuleE2603842115810.2.991	3.74.145.06.1.96.127.45.4705.7.160	204896.hg4	100.105.116.1.44rtual-ftp-rename
ibRba6RuleE2603842115810.2.991	3.74.145.06.1.96.127.45.4705.7.160	204896.hg5	100.105.116.1.45rtual-ftp-reset
ibRba6RuleE2603842115810.2.991	3.74.145.06.1.96.127.45.4705.7.160	204896.hg6	100.105.116.1.46rtual-ftp-restart
ibRba6RuleE2603842115810.2.991	3.74.145.06.1.96.127.45.4705.7.160	204896.hg7	100.105.116.1.47rtual-ftp-rmdir
ibRba6RuleE2603842115810.2.991	3.74.145.06.1.96.127.45.4705.7.160	204896.hg8	100.105.116.1.48rtual-ftp-status
ibRba6RuleE2603842115810.2.991	3.74.145.06.1.96.127.45.4705.7.160	204896.hg9	100.105.116.1.49rtual-ftp-system
ibRba6RuleE2603842115810.2.991	3.74.145.06.1.96.127.45.4705.7.160	204896.hg0	100.105.116.1.50rtual-ftp-user
ibRba6RuleE2603842115810.2.991	3.74.145.06.1.96.127.45.4705.7.160	204896.hg1	100.105.116.1.51rtual-ftp-verbose
ibRba6RuleE2603842115810.2.991	3.74.145.06.1.96.127.45.4705.7.160	204896.hg2	100.105.116.1.52rtual-ftp-remove
ibRba6RuleE2603842115810.2.991	3.74.145.06.1.96.127.45.4705.7.160	204896.hg3	100.105.116.1.53rtual-ftp-exit
1.3cRbacRuleE8811.0.401.8.16	119.101.116.109.45.11.114.107.05.1	10.975.1061	14.97.116.111.114.1display *
1.3cRbacRuleE8811.0.401.8.16	119.101.116.109.45.11.114.107.05.1	10.975.1061	14.97.126.111.114.1.2xml
1.3cRbacRuleE8811.0.401.8.16	119.101.116.109.45.11.114.107.05.1	10.975.1061	14.97.1system-view3 probe ; display *
1.3cRbacRuleE8811.0.401.8.16	119.101.116.109.45.11.114.107.05.1	10.975.1061	14.97.13display history-command all
1.3cRbacRuleE8811.0.401.8.16	119.101.116.109.45.11.114.107.05.1	10.975.1061	14.97.15.111display exception *
1.3cRbacRuleE8811.0.401.8.16	119.101.116.109.45.11.114.107.05.1	10.975.1061	14.97.16display 14plus usage configura-tion *
1.3cRbacRuleE8811.0.401.8.16	119.101.116.109.45.11.114.107.05.1	10.975.1061	14.97.17. display kernel exception *
1.3cRbacRuleE8811.0.401.8.16	119.101.116.109.45.11.114.107.05.1	10.975.1061	14.97.18. display kernel deadlock *
1.3cRbacRuleE8811.0.401.8.16	119.101.116.109.45.11.114.107.05.1	10.975.1061	14.97.19. display kernel starvation *
1.3i5Rba4R264B8zyl 58.112.4.0.16116	1109.1011.1164.1109.451.1114.1102.1451.1	10.922.5061	114.197.11601 display kernel reboot *
1.3i5Rba4R264B8zyl 58.112.4.0.16116	1109.1011.1164.1109.451.1114.1102.1451.1	10.922.5061	114.197.11621 display memory trace *
1.3i5Rba4R264B8zyl 58.112.4.0.16116	1109.1011.1164.1109.451.1114.1102.1451.1	10.922.5061	114.197.11621 display kernel memory *
1.3i5Rba4R264B8zyl 58.112.4.0.16116	1109.1011.1164.1109.451.1114.1102.1451.1	10.922.5061	114.197.11631 system-view4 ; local-user *
1.3i5Rba4R264B8zyl 58.112.4.0.16116	1109.1011.1164.1109.451.1114.1102.1451.1	10.922.5061	114.197.11641 system-view4 switchto mdc *
1.3i5Rba4R264B8zyl 58.112.4.0.16116	1109.1011.1164.1109.451.1114.1102.1451.1	10.922.5061	114.197.11651 system-view5 switchto context *
1.3i5Rba4R264B8zyl 58.112.4.0.16116	1109.1011.1164.1109.451.1114.1102.1451.1	10.922.5061	114.197.11661 11.114.1.16
1.3i5Rba4R264B8zyl 58.112.4.0.16116	1109.1011.1164.1109.451.1114.1102.1451.1	10.922.5061	114.197.11671 _device/m1_maintenance/m_-change password
1.3i5Rba4R264B8zyl 58.112.4.0.16116	1109.1011.1164.1109.451.1114.1102.1451.1	10.922.5061	114.197.11681 11.114.1.18













Name	OID	Value Type	Value Example
ibRbacFeatureInGroupRowStatus.2.76.50.3.115.116.112	2.6138.2.158.1.2.7.1.2.2.76.50.3.115.116.112	Integer12	active (1)
ibRbacFeatureInGroupRowStatus.2.76.50.4.100.108.100.112	2.6138.2.158.1.2.7.1.2.2.76.50.4.100.108.100.112	Integer112	active (1)
ibRbacFeatureInGroupRowStatus.2.76.50.4.101.111.97.109	2.6138.2.158.1.2.7.1.2.2.76.50.4.101.111.97.109	Integer109	active (1)
ibRbacFeatureInGroupRowStatus.2.76.50.4.101.114.112.115	2.6138.2.158.1.2.7.1.2.2.76.50.4.101.114.112.115	Integer115	active (1)
ibRbacFeatureInGroupRowStatus.2.76.50.4.108.50.112.116	2.6138.2.158.1.2.7.1.2.2.76.50.4.108.50.112.116	Integer116	active (1)
ibRbacFeatureInGroupRowStatus.2.76.50.4.108.97.99.112	2.6138.2.158.1.2.7.1.2.2.76.50.4.108.97.99.112	Integer112	active (1)
ibRbacFeatureInGroupRowStatus.2.76.50.4.108.108.100.112	2.6138.2.158.1.2.7.1.2.2.76.50.4.108.108.100.112	Integer112	active (1)
ibRbacFeatureInGroupRowStatus.2.76.50.4.109.118.114.112	2.6138.2.158.1.2.7.1.2.2.76.50.4.109.118.114.112	Integer112	active (1)
ibRbacFeatureInGroupRowStatus.2.76.50.4.114.114.112.112	2.6138.2.158.1.2.7.1.2.2.76.50.4.114.114.112.112	Integer112	active (1)
ibRbacFeatureInGroupRowStatus.2.76.50.4.118.108.97.110	2.6138.2.158.1.2.7.1.2.2.76.50.4.118.108.97.110	Integer110	active (1)
ibRbacFeatureInGroupRowStatus.2.76.50.120.120.120.99	2.6138.2.158.1.2.7.1.2.2.76.50.120.120.120.99	Integer120.99	active (1)
ibRbacFeatureInGroupRowStatus.2.76.50.126.159.109.95.109.97.8.45.108.65.08.005710.107	2.76.50.126.159.109.95.109.97.8.45.108.65.08.005710.107	Integer107	active (1)
ibRbacFeatureInGroupRowStatus.2.76.50.021.209.08.08.000451515	2.76.50.021.209.08.08.000451515	Integer11111212050510100803	active (1)
ibRbacFeatureInGroupRowStatus.2.76.50.021.209.09.11110100505151	2.76.50.021.209.09.11110100505151	Integer45450808050510100707	active (1)
ibRbacFeatureInGroupRowStatus.2.76.50.13.105.103.109.112.45.11	2.76.50.13.105.103.109.112.45.11	Integer11.111.112.105.110.103	active (1)
ibRbacFeatureInGroupRowStatus.2.76.50.13.108.111.11.11.12.288.00745300.001.163.00.999.166	2.76.50.13.108.111.11.11.12.288.00745300.001.163.00.999.166	Integer166	active (1)
ibRbacFeatureInGroupRowStatus.2.76.50.13.112.111.11.11.14.116.45.11	2.76.50.13.112.111.11.11.14.116.45.11	Integer117.1114.1105.1116.1221	active (1)
ibRbacFeatureInGroupRowStatus.2.76.51.3.98.103.112	2.6138.2.158.1.2.7.1.2.2.76.51.3.98.103.112	Integer12	active (1)
ibRbacFeatureInGroupRowStatus.2.76.51.3.109.108.100	2.6138.2.158.1.2.7.1.2.2.76.51.3.109.108.100	Integer100	active (1)
ibRbacFeatureInGroupRowStatus.2.76.51.3.112.105.109	2.6138.2.158.1.2.7.1.2.2.76.51.3.112.105.109	Integer109	active (1)
ibRbacFeatureInGroupRowStatus.2.76.51.3.114.105.112	2.6138.2.158.1.2.7.1.2.2.76.51.3.114.105.112	Integer12	active (1)
ibRbacFeatureInGroupRowStatus.2.76.51.4.105.103.109.112	2.6138.2.158.1.2.7.1.2.2.76.51.4.105.103.109.112	Integer112	active (1)
ibRbacFeatureInGroupRowStatus.2.76.51.4.105.115.105.115	2.6138.2.158.1.2.7.1.2.2.76.51.4.105.115.105.115	Integer115	active (1)
ibRbacFeatureInGroupRowStatus.2.76.51.4.108.105.115.112	2.6138.2.158.1.2.7.1.2.2.76.51.4.108.105.115.112	Integer112	active (1)
ibRbacFeatureInGroupRowStatus.2.76.51.4.109.115.100.112	2.6138.2.158.1.2.7.1.2.2.76.51.4.109.115.100.112	Integer112	active (1)
ibRbacFeatureInGroupRowStatus.2.76.51.4.111.115.112.102	2.6138.2.158.1.2.7.1.2.2.76.51.4.111.115.112.102	Integer102	active (1)
ibRbacFeatureInGroupRowStatus.2.76.51.5.128.512.86.52.5108.51	2.76.51.5.128.512.86.52.5108.51	Integer12.110	active (1)
ibRbacFeatureInGroupRowStatus.2.76.58.5.217.1.2.1276.516.104.11	2.76.58.5.217.1.2.1276.516.104.11	Integer16.101	active (1)
ibRbacFeatureInGroupRowStatus.2.76.5.17.8.218.76.5.9.8.116.105.99	2.76.5.17.8.218.76.5.9.8.116.105.99	Integer99.99.114.116	active (1)
ibRbacFeatureInGroupRowStatus.2.76.51.9.205.179.089.167.0689.167899.99.115.116	2.76.51.9.205.179.089.167.0689.167899.99.115.116	Integer99.116	active (1)

Name	OID	Value Type	Value Example
ibRbacFeatureGroupProvsStatus	.1.3.6.1.4.1.26138.2.14.1.11.7.17.6.16.10.14.2.11.108.085.09.92.121	Integer	active (1)
ibResMonMinorResendEnable.0	.1.3.6.1.4.1.26138.2.169.1.1.0	Integer	true (1)
ibResMonOutputEnable.0	.1.3.6.1.4.1.26138.2.169.1.2.0	OctetString	{syslog, snmpNotification, net-confEvent}
ibReboot.0	.1.3.6.1.4.1.26138.6.7.0	Integer	normal (0)
ibSysBootTest.0	.1.3.6.1.4.1.26138.6.10.0	Integer	warmStart (2)
ibSysBannerMOTD.0	.1.3.6.1.4.1.26138.6.11.11.0	OctetString	
ibQoSsCapCharacteristicsValue.1.1	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.1	Gauge	1
ibQoSsCapCharacteristicsValue.1.2	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.2	Gauge	3
ibQoSsCapCharacteristicsValue.1.3	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.3	Gauge	1
ibQoSsCapCharacteristicsValue.1.4	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.4	Gauge	3
ibQoSsCapCharacteristicsValue.1.5	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.5	Gauge	0
ibQoSsCapCharacteristicsValue.1.6	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.6	Gauge	7
ibQoSsCapCharacteristicsValue.1.7	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.7	Gauge	7
ibQoSsCapCharacteristicsValue.1.8	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.8	Gauge	7
ibQoSsCapCharacteristicsValue.1.9	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.9	Gauge	0
ibQoSsCapCharacteristicsValue.1.10	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.10	Gauge	790
ibQoSsCapCharacteristicsValue.1.11	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.11	Gauge	790
ibQoSsCapCharacteristicsValue.1.12	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.12	Gauge	790
ibQoSsCapCharacteristicsValue.1.13	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.13	Gauge	22
ibQoSsCapCharacteristicsValue.1.14	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.14	Gauge	22
ibQoSsCapCharacteristicsValue.1.15	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.15	Gauge	22
ibQoSsCapCharacteristicsValue.1.16	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.16	Gauge	0
ibQoSsCapCharacteristicsValue.1.17	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.17	Gauge	0
ibQoSsCapCharacteristicsValue.1.18	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.18	Gauge	0
ibQoSsCapCharacteristicsValue.1.19	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.19	Gauge	16
ibQoSsCapCharacteristicsValue.1.20	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.20	Gauge	16000000
ibQoSsCapCharacteristicsValue.1.21	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.21	Gauge	16

Name	OID	Value Type	Value Example
ibQoSsSysCapCharacteristicsValue.1.22	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.22	Gauge	16
ibQoSsSysCapCharacteristicsValue.1.23	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.23	Gauge	160000000
ibQoSsSysCapCharacteristicsValue.1.24	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.24	Gauge	16
ibQoSsSysCapCharacteristicsValue.1.25	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.25	Gauge	128
ibQoSsSysCapCharacteristicsValue.1.26	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.26	Gauge	256000000
ibQoSsSysCapCharacteristicsValue.1.27	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.27	Gauge	128
ibQoSsSysCapCharacteristicsValue.1.28	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.28	Gauge	0
ibQoSsSysCapCharacteristicsValue.1.29	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.29	Gauge	0
ibQoSsSysCapCharacteristicsValue.1.30	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.30	Gauge	256000000
ibQoSsSysCapCharacteristicsValue.1.31	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.31	Gauge	128
ibQoSsSysCapCharacteristicsValue.1.32	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.32	Gauge	128
ibQoSsSysCapCharacteristicsValue.1.33	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.33	Gauge	3
ibQoSsSysCapCharacteristicsValue.1.34	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.34	Gauge	3
ibQoSsSysCapCharacteristicsValue.1.35	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.35	Gauge	0
ibQoSsSysCapCharacteristicsValue.1.36	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.36	Gauge	0
ibQoSsSysCapCharacteristicsValue.1.37	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.37	Gauge	0
ibQoSsSysCapCharacteristicsValue.1.38	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.38	Gauge	0
ibQoSsSysCapCharacteristicsValue.1.39	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.39	Gauge	0
ibQoSsSysCapCharacteristicsValue.1.40	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.40	Gauge	0
ibQoSsSysCapCharacteristicsValue.1.41	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.41	Gauge	0
ibQoSsSysCapCharacteristicsValue.1.42	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.42	Gauge	0
ibQoSsSysCapCharacteristicsValue.1.43	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.43	Gauge	0
ibQoSsSysCapCharacteristicsValue.1.44	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.44	Gauge	0
ibQoSsSysCapCharacteristicsValue.1.45	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.1.45	Gauge	0
ibQoSsSysCapCharacteristicsValue.2.1	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.1	Gauge	1

Name	OID	Value Type	Value Example
ibQoSsSysCapCharacteristicsValue.2.2	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.2	Gauge	8
ibQoSsSysCapCharacteristicsValue.2.3	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.3	Gauge	1
ibQoSsSysCapCharacteristicsValue.2.4	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.4	Gauge	0
ibQoSsSysCapCharacteristicsValue.2.5	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.5	Gauge	0
ibQoSsSysCapCharacteristicsValue.2.6	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.6	Gauge	8
ibQoSsSysCapCharacteristicsValue.2.7	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.7	Gauge	0
ibQoSsSysCapCharacteristicsValue.2.8	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.8	Gauge	0
ibQoSsSysCapCharacteristicsValue.2.9	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.9	Gauge	0
ibQoSsSysCapCharacteristicsValue.2.10	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.10	Gauge	500
ibQoSsSysCapCharacteristicsValue.2.11	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.11	Gauge	50000
ibQoSsSysCapCharacteristicsValue.2.12	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.12	Gauge	1000
ibQoSsSysCapCharacteristicsValue.2.13	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.13	Gauge	0
ibQoSsSysCapCharacteristicsValue.2.14	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.14	Gauge	0
ibQoSsSysCapCharacteristicsValue.2.15	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.15	Gauge	0
ibQoSsSysCapCharacteristicsValue.2.16	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.16	Gauge	500
ibQoSsSysCapCharacteristicsValue.2.17	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.17	Gauge	50000
ibQoSsSysCapCharacteristicsValue.2.18	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.18	Gauge	1000
ibQoSsSysCapCharacteristicsValue.2.19	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.19	Gauge	0
ibQoSsSysCapCharacteristicsValue.2.20	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.20	Gauge	0
ibQoSsSysCapCharacteristicsValue.2.21	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.21	Gauge	0
ibQoSsSysCapCharacteristicsValue.2.22	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.22	Gauge	0
ibQoSsSysCapCharacteristicsValue.2.23	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.23	Gauge	0
ibQoSsSysCapCharacteristicsValue.2.24	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.24	Gauge	0
ibQoSsSysCapCharacteristicsValue.2.25	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.25	Gauge	0
ibQoSsSysCapCharacteristicsValue.2.26	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.26	Gauge	0

Name	OID	Value Type	Value Example
ibQoSsSysCapCharacteristicsValue.2.27	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.27	Gauge	0
ibQoSsSysCapCharacteristicsValue.2.28	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.2.28	Gauge	0
ibQoSsSysCapCharacteristicsValue.3.1	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.3.1	Gauge	1
ibQoSsSysCapCharacteristicsValue.3.2	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.3.2	Gauge	1
ibQoSsSysCapCharacteristicsValue.3.3	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.3.3	Gauge	3
ibQoSsSysCapCharacteristicsValue.3.4	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.3.4	Gauge	0
ibQoSsSysCapCharacteristicsValue.3.5	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.3.5	Gauge	0
ibQoSsSysCapCharacteristicsValue.3.6	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.3.6	Gauge	0
ibQoSsSysCapCharacteristicsValue.3.7	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.3.7	Gauge	0
ibQoSsSysCapCharacteristicsValue.4.1	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.1	Gauge	1
ibQoSsSysCapCharacteristicsValue.4.2	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.2	Gauge	3
ibQoSsSysCapCharacteristicsValue.4.3	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.3	Gauge	3
ibQoSsSysCapCharacteristicsValue.4.4	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.4	Gauge	3
ibQoSsSysCapCharacteristicsValue.4.5	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.5	Gauge	1
ibQoSsSysCapCharacteristicsValue.4.6	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.6	Gauge	3
ibQoSsSysCapCharacteristicsValue.4.7	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.7	Gauge	1
ibQoSsSysCapCharacteristicsValue.4.8	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.8	Gauge	15
ibQoSsSysCapCharacteristicsValue.4.9	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.9	Gauge	1
ibQoSsSysCapCharacteristicsValue.4.10	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.10	Gauge	15
ibQoSsSysCapCharacteristicsValue.4.11	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.11	Gauge	1
ibQoSsSysCapCharacteristicsValue.4.12	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.12	Gauge	3
ibQoSsSysCapCharacteristicsValue.4.13	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.13	Gauge	1
ibQoSsSysCapCharacteristicsValue.4.14	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.14	Gauge	15
ibQoSsSysCapCharacteristicsValue.4.15	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.15	Gauge	1
ibQoSsSysCapCharacteristicsValue.4.16	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.16	Gauge	15

Name	OID	Value Type	Value Example
ibQoS SysCapCharacteristicsValue.4.17	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.17	Gauge	16
ibQoS SysCapCharacteristicsValue.4.18	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.18	Gauge	0
ibQoS SysCapCharacteristicsValue.4.19	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.19	Gauge	7
ibQoS SysCapCharacteristicsValue.4.20	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.20	Gauge	1
ibQoS SysCapCharacteristicsValue.4.21	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.21	Gauge	8
ibQoS SysCapCharacteristicsValue.4.22	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.22	Gauge	0
ibQoS SysCapCharacteristicsValue.4.23	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.23	Gauge	0
ibQoS SysCapCharacteristicsValue.4.24	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.24	Gauge	0
ibQoS SysCapCharacteristicsValue.4.25	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.25	Gauge	0
ibQoS SysCapCharacteristicsValue.4.26	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.26	Gauge	0
ibQoS SysCapCharacteristicsValue.4.27	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.27	Gauge	0
ibQoS SysCapCharacteristicsValue.4.28	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.4.28	Gauge	0
ibQoS SysCapCharacteristicsValue.5.1	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.1	Gauge	0
ibQoS SysCapCharacteristicsValue.5.2	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.2	Gauge	0
ibQoS SysCapCharacteristicsValue.5.3	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.3	Gauge	0
ibQoS SysCapCharacteristicsValue.5.4	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.4	Gauge	0
ibQoS SysCapCharacteristicsValue.5.5	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.5	Gauge	0
ibQoS SysCapCharacteristicsValue.5.6	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.6	Gauge	0
ibQoS SysCapCharacteristicsValue.5.7	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.7	Gauge	0
ibQoS SysCapCharacteristicsValue.5.8	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.8	Gauge	0
ibQoS SysCapCharacteristicsValue.5.9	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.9	Gauge	0
ibQoS SysCapCharacteristicsValue.5.10	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.10	Gauge	0
ibQoS SysCapCharacteristicsValue.5.11	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.11	Gauge	0
ibQoS SysCapCharacteristicsValue.5.12	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.12	Gauge	0
ibQoS SysCapCharacteristicsValue.5.13	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.13	Gauge	0

Name	OID	Value Type	Value Example
ibQoSsSysCapCharacteristicsValue.5.14	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.14	Gauge	0
ibQoSsSysCapCharacteristicsValue.5.15	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.15	Gauge	0
ibQoSsSysCapCharacteristicsValue.5.16	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.16	Gauge	0
ibQoSsSysCapCharacteristicsValue.5.17	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.17	Gauge	0
ibQoSsSysCapCharacteristicsValue.5.18	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.18	Gauge	0
ibQoSsSysCapCharacteristicsValue.5.19	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.19	Gauge	0
ibQoSsSysCapCharacteristicsValue.5.20	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.20	Gauge	0
ibQoSsSysCapCharacteristicsValue.5.21	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.21	Gauge	0
ibQoSsSysCapCharacteristicsValue.5.22	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.22	Gauge	0
ibQoSsSysCapCharacteristicsValue.5.23	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.5.23	Gauge	0
ibQoSsSysCapCharacteristicsValue.6.1	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.6.1	Gauge	1
ibQoSsSysCapCharacteristicsValue.6.2	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.6.2	Gauge	0
ibQoSsSysCapCharacteristicsValue.6.3	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.6.3	Gauge	3
ibQoSsSysCapCharacteristicsValue.6.4	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.6.4	Gauge	1
ibQoSsSysCapCharacteristicsValue.6.5	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.6.5	Gauge	7
ibQoSsSysCapCharacteristicsValue.6.6	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.6.6	Gauge	8
ibQoSsSysCapCharacteristicsValue.6.7	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.6.7	Gauge	0
ibQoSsSysCapCharacteristicsValue.6.8	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.6.8	Gauge	0
ibQoSsSysCapCharacteristicsValue.6.9	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.6.9	Gauge	5840
ibQoSsSysCapCharacteristicsValue.6.10	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.6.10	Gauge	5840
ibQoSsSysCapCharacteristicsValue.6.11	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.6.11	Gauge	0
ibQoSsSysCapCharacteristicsValue.6.12	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.6.12	Gauge	15
ibQoSsSysCapCharacteristicsValue.6.13	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.6.13	Gauge	0
ibQoSsSysCapCharacteristicsValue.6.14	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.6.14	Gauge	100
ibQoSsSysCapCharacteristicsValue.6.15	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.6.15	Gauge	1



Name	OID	Value Type	Value Example
ibQoS SysCapCharacteristicsValue.6.16	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.6.16	Gauge	0
ibQoS SysCapCharacteristicsValue.6.17	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.6.17	Gauge	0
ibQoS SysCapCharacteristicsValue.7.1	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.1	Gauge	1
ibQoS SysCapCharacteristicsValue.7.2	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.2	Gauge	1
ibQoS SysCapCharacteristicsValue.7.3	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.3	Gauge	1
ibQoS SysCapCharacteristicsValue.7.4	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.4	Gauge	0
ibQoS SysCapCharacteristicsValue.7.5	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.5	Gauge	0
ibQoS SysCapCharacteristicsValue.7.6	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.6	Gauge	1
ibQoS SysCapCharacteristicsValue.7.7	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.7	Gauge	1
ibQoS SysCapCharacteristicsValue.7.8	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.8	Gauge	1
ibQoS SysCapCharacteristicsValue.7.9	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.9	Gauge	0
ibQoS SysCapCharacteristicsValue.7.10	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.10	Gauge	1
ibQoS SysCapCharacteristicsValue.7.11	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.11	Gauge	0
ibQoS SysCapCharacteristicsValue.7.12	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.12	Gauge	0
ibQoS SysCapCharacteristicsValue.7.13	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.13	Gauge	1
ibQoS SysCapCharacteristicsValue.7.14	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.14	Gauge	0
ibQoS SysCapCharacteristicsValue.7.15	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.15	Gauge	0
ibQoS SysCapCharacteristicsValue.7.16	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.16	Gauge	0
ibQoS SysCapCharacteristicsValue.7.17	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.17	Gauge	0
ibQoS SysCapCharacteristicsValue.7.18	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.18	Gauge	0
ibQoS SysCapCharacteristicsValue.7.19	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.19	Gauge	0
ibQoS SysCapCharacteristicsValue.7.20	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.20	Gauge	0
ibQoS SysCapCharacteristicsValue.7.21	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.21	Gauge	0
ibQoS SysCapCharacteristicsValue.7.22	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.22	Gauge	0
ibQoS SysCapCharacteristicsValue.7.23	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.23	Gauge	0

Name	OID	Value Type	Value Example
ibQoSsSysCapCharacteristicsValue.7.24	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.24	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.25	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.25	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.26	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.26	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.27	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.27	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.28	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.28	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.29	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.29	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.30	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.30	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.31	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.31	Gauge	1
ibQoSsSysCapCharacteristicsValue.7.32	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.32	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.33	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.33	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.34	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.34	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.35	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.35	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.36	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.36	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.37	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.37	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.38	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.38	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.39	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.39	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.40	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.40	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.41	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.41	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.42	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.42	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.43	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.43	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.44	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.44	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.45	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.45	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.46	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.46	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.47	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.47	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.48	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.48	Gauge	0

Name	OID	Value Type	Value Example
ibQoSsSysCapCharacteristicsValue.7.49	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.49	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.50	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.50	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.51	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.51	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.52	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.52	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.53	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.53	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.54	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.54	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.55	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.55	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.56	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.56	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.57	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.57	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.58	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.58	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.59	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.59	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.60	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.60	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.61	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.61	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.62	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.62	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.63	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.63	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.64	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.64	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.65	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.65	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.66	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.66	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.67	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.67	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.68	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.68	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.69	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.69	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.70	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.70	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.71	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.71	Gauge	0
ibQoSsSysCapCharacteristicsValue.7.72	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.7.72	Gauge	0
ibQoSsSysCapCharacteristicsValue.8.1	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.8.1	Gauge	1

Name	OID	Value Type	Value Example
ibQoSsSysCapCharacteristicsValue.8.2	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.8.2	Gauge	9
ibQoSsSysCapCharacteristicsValue.8.3	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.8.3	Gauge	6
ibQoSsSysCapCharacteristicsValue.8.4	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.8.4	Gauge	0
ibQoSsSysCapCharacteristicsValue.8.5	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.8.5	Gauge	3
ibQoSsSysCapCharacteristicsValue.9.1	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.9.1	Gauge	1
ibQoSsSysCapCharacteristicsValue.9.2	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.9.2	Gauge	1
ibQoSsSysCapCharacteristicsValue.9.3	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.9.3	Gauge	0
ibQoSsSysCapCharacteristicsValue.9.4	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.9.4	Gauge	4129
ibQoSsSysCapCharacteristicsValue.9.5	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.9.5	Gauge	1
ibQoSsSysCapCharacteristicsValue.9.6	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.9.6	Gauge	0
ibQoSsSysCapCharacteristicsValue.9.7	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.9.7	Gauge	0
ibQoSsSysCapCharacteristicsValue.9.8	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.9.8	Gauge	4129
ibQoSsSysCapCharacteristicsValue.9.9	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.9.9	Gauge	0
ibQoSsSysCapCharacteristicsValue.10.1	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.1	Gauge	1
ibQoSsSysCapCharacteristicsValue.10.2	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.2	Gauge	3
ibQoSsSysCapCharacteristicsValue.10.3	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.3	Gauge	3
ibQoSsSysCapCharacteristicsValue.10.4	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.4	Gauge	3
ibQoSsSysCapCharacteristicsValue.10.5	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.5	Gauge	1
ibQoSsSysCapCharacteristicsValue.10.6	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.6	Gauge	24
ibQoSsSysCapCharacteristicsValue.10.7	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.7	Gauge	0
ibQoSsSysCapCharacteristicsValue.10.8	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.8	Gauge	0
ibQoSsSysCapCharacteristicsValue.10.9	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.9	Gauge	0
ibQoSsSysCapCharacteristicsValue.10.10	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.10	Gauge	0
ibQoSsSysCapCharacteristicsValue.10.11	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.11	Gauge	0
ibQoSsSysCapCharacteristicsValue.10.12	.1.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.12	Gauge	1

Name	OID	Value Type	Value Example
ibQoSsSysCapCharacteristicsValue.10.13	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.13	Gauge	55
ibQoSsSysCapCharacteristicsValue.10.14	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.14	Gauge	1
ibQoSsSysCapCharacteristicsValue.10.15	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.15	Gauge	3
ibQoSsSysCapCharacteristicsValue.10.16	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.16	Gauge	3
ibQoSsSysCapCharacteristicsValue.10.17	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.17	Gauge	1
ibQoSsSysCapCharacteristicsValue.10.18	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.18	Gauge	1
ibQoSsSysCapCharacteristicsValue.10.19	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.19	Gauge	1
ibQoSsSysCapCharacteristicsValue.10.20	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.20	Gauge	1
ibQoSsSysCapCharacteristicsValue.10.21	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.21	Gauge	3
ibQoSsSysCapCharacteristicsValue.10.22	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.22	Gauge	1
ibQoSsSysCapCharacteristicsValue.10.23	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.23	Gauge	1
ibQoSsSysCapCharacteristicsValue.10.24	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.24	Gauge	63
ibQoSsSysCapCharacteristicsValue.10.25	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.25	Gauge	0
ibQoSsSysCapCharacteristicsValue.10.26	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.26	Gauge	0
ibQoSsSysCapCharacteristicsValue.10.27	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.27	Gauge	0
ibQoSsSysCapCharacteristicsValue.10.28	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.28	Gauge	0
ibQoSsSysCapCharacteristicsValue.10.29	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.29	Gauge	0
ibQoSsSysCapCharacteristicsValue.10.30	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.30	Gauge	0
ibQoSsSysCapCharacteristicsValue.10.31	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.31	Gauge	0
ibQoSsSysCapCharacteristicsValue.10.32	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.32	Gauge	0
ibQoSsSysCapCharacteristicsValue.10.33	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.33	Gauge	0
ibQoSsSysCapCharacteristicsValue.10.34	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.34	Gauge	0
ibQoSsSysCapCharacteristicsValue.10.35	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.35	Gauge	0
ibQoSsSysCapCharacteristicsValue.10.36	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.36	Gauge	0
ibQoSsSysCapCharacteristicsValue.10.37	.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.37	Gauge	2

Name	OID	Value Type	Value Example
ibQoSsSysCapCharacteristicsValue.10.38	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.38	Gauge	1
ibQoSsSysCapCharacteristicsValue.10.39	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.39	Gauge	1
ibQoSsSysCapCharacteristicsValue.10.40	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.40	Gauge	1019
ibQoSsSysCapCharacteristicsValue.10.41	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.41	Gauge	41
ibQoSsSysCapCharacteristicsValue.10.42	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.42	Gauge	41
ibQoSsSysCapCharacteristicsValue.10.43	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.43	Gauge	41
ibQoSsSysCapCharacteristicsValue.10.44	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.44	Gauge	0
ibQoSsSysCapCharacteristicsValue.10.45	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.45	Gauge	16
ibQoSsSysCapCharacteristicsValue.10.46	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.10.46	Gauge	0
ibQoSsSysCapCharacteristicsValue.11.1	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.11.1	Gauge	1
ibQoSsSysCapCharacteristicsValue.11.2	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.11.2	Gauge	0
ibQoSsSysCapCharacteristicsValue.11.3	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.11.3	Gauge	1
ibQoSsSysCapCharacteristicsValue.11.4	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.11.4	Gauge	0
ibQoSsSysCapCharacteristicsValue.11.5	1.3.6.1.4.1.26138.7.1.1.1.2.1.3.11.5	Gauge	0
ibQoSIfCapCharacteristicsValue.1.2.1	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.1.2.2	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.1.2.3	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.1.2.4	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.1.2.5	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.1.2.6	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.1.2.7	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.1.3.1	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.1.3.2	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.1.3.3	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.1.3.4	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.3.4	Gauge	16

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.1.3.5	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.1.3.6	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.1.3.7	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.1.4.1	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.1.4.2	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.1.4.3	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.1.4.4	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.1.4.5	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.1.4.6	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.1.8.1	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.1.8.2	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.1.8.3	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.1.8.4	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.1.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.2.2.1	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.2.2.2	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.2.2.3	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.2.2.4	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.2.2.5	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.2.2.6	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.2.2.7	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.2.3.1	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.2.3.2	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.2.3.3	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.2.3.4	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.2.3.5	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.3.5	Gauge	512



Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.2.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.2.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.2.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.2.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.2.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.2.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.2.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.2.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.2.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.2.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.2.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.2.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.2.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.3.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.3.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.3.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.3.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.3.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.3.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.3.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.3.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.3.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.3.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.3.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.3.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.3.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.3.6	Gauge	134217728

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.3.3.7	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.3.4.1	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.3.4.2	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.3.4.3	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.3.4.4	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.3.4.5	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.3.4.6	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.3.8.1	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.3.8.2	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.3.8.3	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.3.8.4	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.3.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.4.2.1	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.4.2.2	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.4.2.3	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.4.2.4	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.4.2.5	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.4.2.6	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.4.2.7	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.4.3.1	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.4.3.2	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.4.3.3	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.4.3.4	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.4.3.5	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.4.3.6	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.4.3.7	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.3.7	Gauge	512

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.4.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.4.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.4.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.4.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.4.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.4.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.4.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.4.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.4.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.4.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.4.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.5.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.5.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.5.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.5.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.5.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.5.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.5.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.5.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.5.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.5.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.5.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.5.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.5.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.5.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.5.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.4.1	Gauge	1

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.5.4.2	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.5.4.3	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.5.4.4	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.5.4.5	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.5.4.6	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.5.8.1	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.5.8.2	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.5.8.3	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.5.8.4	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.5.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.6.2.1	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.6.2.2	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.6.2.3	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.6.2.4	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.6.2.5	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.6.2.6	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.6.2.7	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.6.3.1	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.6.3.2	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.6.3.3	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.6.3.4	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.6.3.5	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.6.3.6	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.6.3.7	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.6.4.1	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.6.4.2	1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.4.2	Gauge	2

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.6.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.6.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.6.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.6.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.6.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.6.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.6.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.6.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.6.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.7.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.7.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.7.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.7.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.7.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.7.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.7.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.7.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.7.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.7.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.7.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.7.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.7.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.7.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.7.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.7.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.7.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.4.3	Gauge	7

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.7.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.7.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.7.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.7.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.7.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.7.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.7.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.7.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.8.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.8.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.8.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.8.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.8.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.8.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.8.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.8.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.8.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.8.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.8.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.8.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.8.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.8.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.8.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.8.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.8.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.8.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.4.4	Gauge	1

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.8.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.8.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.8.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.8.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.8.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.8.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.8.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.9.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.9.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.9.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.9.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.9.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.9.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.9.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.9.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.9.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.9.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.9.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.9.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.9.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.9.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.9.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.9.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.9.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.9.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.9.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.4.5	Gauge	2



Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.9.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.9.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.9.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.9.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.9.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.9.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.10.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.10.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.10.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.10.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.10.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.10.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.10.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.10.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.10.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.10.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.10.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.10.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.10.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.10.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.10.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.10.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.10.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.10.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.10.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.10.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.4.6	Gauge	8

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.10.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.8.1	1Gauge	1
ibQoSIfCapCharacteristicsValue.10.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.8.2	2Gauge	9
ibQoSIfCapCharacteristicsValue.10.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.8.3	3Gauge	7
ibQoSIfCapCharacteristicsValue.10.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.10.8.4	4Gauge	1
ibQoSIfCapCharacteristicsValue.11.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.2.1	1Gauge	1
ibQoSIfCapCharacteristicsValue.11.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.2.2	2Gauge	16
ibQoSIfCapCharacteristicsValue.11.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.2.3	3Gauge	16777200
ibQoSIfCapCharacteristicsValue.11.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.2.4	4Gauge	16
ibQoSIfCapCharacteristicsValue.11.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.2.5	5Gauge	1536
ibQoSIfCapCharacteristicsValue.11.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.2.6	6Gauge	65535
ibQoSIfCapCharacteristicsValue.11.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.2.7	7Gauge	512
ibQoSIfCapCharacteristicsValue.11.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.3.1	1Gauge	1
ibQoSIfCapCharacteristicsValue.11.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.3.2	2Gauge	16
ibQoSIfCapCharacteristicsValue.11.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.3.3	3Gauge	1048576
ibQoSIfCapCharacteristicsValue.11.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.3.4	4Gauge	16
ibQoSIfCapCharacteristicsValue.11.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.3.5	5Gauge	512
ibQoSIfCapCharacteristicsValue.11.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.3.6	6Gauge	134217728
ibQoSIfCapCharacteristicsValue.11.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.3.7	7Gauge	512
ibQoSIfCapCharacteristicsValue.11.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.4.1	1Gauge	1
ibQoSIfCapCharacteristicsValue.11.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.4.2	2Gauge	2
ibQoSIfCapCharacteristicsValue.11.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.4.3	3Gauge	7
ibQoSIfCapCharacteristicsValue.11.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.4.4	4Gauge	1
ibQoSIfCapCharacteristicsValue.11.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.4.5	5Gauge	2
ibQoSIfCapCharacteristicsValue.11.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.4.6	6Gauge	8
ibQoSIfCapCharacteristicsValue.11.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.8.1	1Gauge	1

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.11.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.11.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.11.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.11.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.12.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.12.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.12.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.12.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.12.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.12.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.12.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.12.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.12.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.12.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.12.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.12.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.12.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.12.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.12.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.12.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.12.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.12.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.12.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.12.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.12.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.12.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.8.2	Gauge	9

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.12.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.12.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.12.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.13.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.13.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.13.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.13.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.13.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.13.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.13.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.13.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.13.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.13.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.13.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.13.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.13.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.13.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.13.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.13.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.13.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.13.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.13.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.13.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.13.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.13.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.13.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.8.3	Gauge	7

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.13.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.13.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.14.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.14.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.14.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.14.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.14.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.14.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.14.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.14.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.14.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.14.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.14.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.14.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.14.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.14.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.14.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.14.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.14.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.14.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.14.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.14.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.14.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.14.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.14.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.14.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.14.8.4	Gauge	1

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.15.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.15.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.15.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.15.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.15.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.15.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.15.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.15.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.15.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.15.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.15.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.15.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.15.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.15.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.15.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.15.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.15.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.15.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.15.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.15.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.15.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.15.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.15.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.15.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.15.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.16.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.2.1	Gauge	1

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.16.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.16.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.16.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.16.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.16.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.16.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.16.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.16.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.16.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.16.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.16.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.16.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.16.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.16.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.16.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.16.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.16.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.16.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.16.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.16.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.16.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.16.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.16.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.16.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.17.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.17.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.2.2	Gauge	16



Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.17.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.17.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.17.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.17.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.17.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.17.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.17.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.17.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.17.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.17.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.17.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.17.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.17.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.17.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.17.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.17.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.17.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.17.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.17.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.17.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.17.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.17.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.17.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.18.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.18.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.18.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.2.3	Gauge	16777200

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.18.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.18.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.18.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.18.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.18.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.18.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.18.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.18.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.18.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.18.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.18.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.18.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.18.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.18.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.18.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.18.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.18.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.18.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.18.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.18.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.18.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.18.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.19.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.19.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.19.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.19.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.2.4	Gauge	16

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.19.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.19.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.19.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.19.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.19.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.19.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.19.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.19.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.19.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.19.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.19.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.19.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.19.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.19.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.19.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.19.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.19.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.19.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.19.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.19.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.19.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.20.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.20.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.20.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.20.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.20.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.2.5	Gauge	1536

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.20.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.20.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.20.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.20.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.20.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.20.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.20.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.20.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.20.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.20.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.20.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.20.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.20.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.20.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.20.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.20.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.20.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.20.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.20.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.20.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.21.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.21.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.21.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.21.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.21.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.21.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.2.6	Gauge	65535

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.21.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.21.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.21.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.21.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.21.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.21.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.21.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.21.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.21.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.21.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.21.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.21.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.21.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.21.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.21.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.21.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.21.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.21.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.21.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.22.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.22.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.22.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.22.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.22.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.22.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.22.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.2.7	Gauge	512

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.22.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.22.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.22.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.22.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.22.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.22.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.22.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.22.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.22.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.22.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.22.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.22.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.22.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.22.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.22.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.22.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.22.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.22.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.23.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.23.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.23.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.23.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.23.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.23.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.23.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.23.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.3.1	Gauge	1

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.23.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.23.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.23.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.23.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.23.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.23.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.23.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.23.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.23.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.23.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.23.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.23.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.23.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.23.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.23.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.23.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.23.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.24.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.24.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.24.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.24.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.24.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.24.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.24.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.24.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.24.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.3.2	Gauge	16



Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.24.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.24.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.24.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.24.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.24.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.24.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.24.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.24.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.24.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.24.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.24.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.24.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.24.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.24.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.24.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.24.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.25.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.25.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.25.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.25.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.25.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.25.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.25.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.25.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.25.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.25.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.3.3	Gauge	1048576

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.25.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.25.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.25.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.25.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.25.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.25.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.25.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.25.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.25.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.25.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.25.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.25.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.25.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.25.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.25.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.26.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.26.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.26.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.26.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.26.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.26.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.26.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.26.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.26.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.26.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.26.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.3.4	Gauge	16

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.26.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.26.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.26.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.26.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.26.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.26.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.26.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.26.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.26.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.26.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.26.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.26.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.26.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.26.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.27.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.27.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.27.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.27.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.27.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.27.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.27.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.27.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.27.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.27.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.27.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.27.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.3.5	Gauge	512

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.27.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.27.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.27.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.27.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.27.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.27.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.27.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.27.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.27.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.27.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.27.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.27.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.27.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.28.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.28.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.28.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.28.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.28.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.28.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.28.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.28.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.28.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.28.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.28.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.28.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.28.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.3.6	Gauge	134217728

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.28.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.28.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.28.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.28.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.28.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.28.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.28.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.28.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.28.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.28.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.28.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.28.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.29.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.29.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.29.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.29.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.29.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.29.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.29.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.29.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.29.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.29.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.29.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.29.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.29.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.29.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.3.7	Gauge	512

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.29.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.29.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.29.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.29.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.29.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.29.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.29.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.29.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.29.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.29.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.29.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.30.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.30.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.30.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.30.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.30.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.30.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.30.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.30.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.30.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.30.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.30.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.30.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.30.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.30.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.30.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.4.1	Gauge	1

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.30.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.4.2	2Gauge	2
ibQoSIfCapCharacteristicsValue.30.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.4.3	3Gauge	7
ibQoSIfCapCharacteristicsValue.30.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.4.4	4Gauge	1
ibQoSIfCapCharacteristicsValue.30.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.4.5	5Gauge	2
ibQoSIfCapCharacteristicsValue.30.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.4.6	6Gauge	8
ibQoSIfCapCharacteristicsValue.30.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.8.1	1Gauge	1
ibQoSIfCapCharacteristicsValue.30.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.8.2	2Gauge	9
ibQoSIfCapCharacteristicsValue.30.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.8.3	3Gauge	7
ibQoSIfCapCharacteristicsValue.30.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.30.8.4	4Gauge	1
ibQoSIfCapCharacteristicsValue.31.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.2.1	1Gauge	1
ibQoSIfCapCharacteristicsValue.31.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.2.2	2Gauge	16
ibQoSIfCapCharacteristicsValue.31.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.2.3	3Gauge	16777200
ibQoSIfCapCharacteristicsValue.31.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.2.4	4Gauge	16
ibQoSIfCapCharacteristicsValue.31.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.2.5	5Gauge	1536
ibQoSIfCapCharacteristicsValue.31.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.2.6	6Gauge	65535
ibQoSIfCapCharacteristicsValue.31.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.2.7	7Gauge	512
ibQoSIfCapCharacteristicsValue.31.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.3.1	1Gauge	1
ibQoSIfCapCharacteristicsValue.31.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.3.2	2Gauge	16
ibQoSIfCapCharacteristicsValue.31.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.3.3	3Gauge	1048576
ibQoSIfCapCharacteristicsValue.31.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.3.4	4Gauge	16
ibQoSIfCapCharacteristicsValue.31.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.3.5	5Gauge	512
ibQoSIfCapCharacteristicsValue.31.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.3.6	6Gauge	134217728
ibQoSIfCapCharacteristicsValue.31.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.3.7	7Gauge	512
ibQoSIfCapCharacteristicsValue.31.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.4.1	1Gauge	1
ibQoSIfCapCharacteristicsValue.31.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.4.2	2Gauge	2



Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.31.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.4.3	3Gauge	7
ibQoSIfCapCharacteristicsValue.31.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.4.4	4Gauge	1
ibQoSIfCapCharacteristicsValue.31.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.4.5	5Gauge	2
ibQoSIfCapCharacteristicsValue.31.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.4.6	6Gauge	8
ibQoSIfCapCharacteristicsValue.31.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.8.1	1Gauge	1
ibQoSIfCapCharacteristicsValue.31.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.8.2	2Gauge	9
ibQoSIfCapCharacteristicsValue.31.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.8.3	3Gauge	7
ibQoSIfCapCharacteristicsValue.31.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.31.8.4	4Gauge	1
ibQoSIfCapCharacteristicsValue.32.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.2.1	1Gauge	1
ibQoSIfCapCharacteristicsValue.32.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.2.2	2Gauge	16
ibQoSIfCapCharacteristicsValue.32.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.2.3	3Gauge	16777200
ibQoSIfCapCharacteristicsValue.32.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.2.4	4Gauge	16
ibQoSIfCapCharacteristicsValue.32.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.2.5	5Gauge	1536
ibQoSIfCapCharacteristicsValue.32.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.2.6	6Gauge	65535
ibQoSIfCapCharacteristicsValue.32.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.2.7	7Gauge	512
ibQoSIfCapCharacteristicsValue.32.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.3.1	1Gauge	1
ibQoSIfCapCharacteristicsValue.32.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.3.2	2Gauge	16
ibQoSIfCapCharacteristicsValue.32.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.3.3	3Gauge	1048576
ibQoSIfCapCharacteristicsValue.32.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.3.4	4Gauge	16
ibQoSIfCapCharacteristicsValue.32.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.3.5	5Gauge	512
ibQoSIfCapCharacteristicsValue.32.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.3.6	6Gauge	134217728
ibQoSIfCapCharacteristicsValue.32.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.3.7	7Gauge	512
ibQoSIfCapCharacteristicsValue.32.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.4.1	1Gauge	1
ibQoSIfCapCharacteristicsValue.32.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.4.2	2Gauge	2
ibQoSIfCapCharacteristicsValue.32.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.4.3	3Gauge	7

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.32.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.32.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.32.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.32.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.32.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.32.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.32.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.32.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.33.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.33.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.33.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.33.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.33.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.33.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.33.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.33.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.33.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.33.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.33.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.33.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.33.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.33.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.33.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.33.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.33.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.33.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.4.4	Gauge	1

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.33.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.33.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.33.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.33.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.33.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.33.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.33.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.34.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.34.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.34.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.34.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.34.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.34.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.34.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.34.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.34.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.34.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.34.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.34.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.34.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.34.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.34.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.34.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.34.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.34.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.34.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.4.5	Gauge	2

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.34.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.34.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.34.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.34.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.34.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.34.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.35.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.35.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.35.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.35.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.35.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.35.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.35.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.35.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.35.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.35.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.35.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.35.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.35.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.35.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.35.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.35.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.35.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.35.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.35.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.35.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.4.6	Gauge	8

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.35.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.35.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.35.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.35.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.35.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.36.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.36.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.36.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.36.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.36.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.36.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.36.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.36.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.36.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.36.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.36.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.36.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.36.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.36.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.36.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.36.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.36.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.36.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.36.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.36.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.36.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.8.1	Gauge	1

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.36.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.36.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.36.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.36.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.37.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.37.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.37.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.37.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.37.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.37.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.37.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.37.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.37.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.37.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.37.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.37.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.37.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.37.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.37.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.37.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.37.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.37.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.37.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.37.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.37.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.37.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.8.2	Gauge	9

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.37.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.37.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.37.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.38.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.38.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.38.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.38.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.38.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.38.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.38.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.38.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.38.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.38.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.38.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.38.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.38.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.38.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.38.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.38.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.38.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.38.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.38.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.38.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.38.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.38.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.38.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.8.3	Gauge	7

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.38.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.38.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.39.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.39.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.39.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.39.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.39.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.39.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.39.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.39.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.39.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.39.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.39.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.39.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.39.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.39.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.39.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.39.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.39.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.39.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.39.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.39.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.39.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.39.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.39.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.39.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.39.8.4	Gauge	1



Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.40.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.40.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.40.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.40.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.40.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.40.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.40.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.40.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.40.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.40.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.40.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.40.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.40.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.40.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.40.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.40.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.40.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.40.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.40.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.40.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.40.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.40.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.40.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.40.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.40.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.41.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.2.1	Gauge	1

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.41.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.41.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.41.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.41.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.41.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.41.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.41.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.41.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.41.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.41.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.41.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.41.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.41.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.41.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.41.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.41.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.41.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.41.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.41.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.41.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.41.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.41.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.41.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.41.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.42.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.42.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.2.2	Gauge	16

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.42.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.42.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.42.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.42.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.42.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.42.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.42.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.42.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.42.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.42.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.42.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.42.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.42.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.42.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.42.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.42.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.42.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.42.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.42.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.42.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.42.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.42.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.42.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.43.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.43.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.43.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.2.3	Gauge	16777200

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.43.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.43.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.43.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.43.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.43.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.43.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.43.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.43.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.43.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.43.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.43.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.43.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.43.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.43.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.43.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.43.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.43.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.43.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.43.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.43.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.43.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.43.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.44.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.44.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.44.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.44.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.2.4	Gauge	16

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.44.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.44.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.44.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.44.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.44.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.44.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.44.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.44.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.44.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.44.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.44.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.44.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.44.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.44.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.44.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.44.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.44.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.44.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.44.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.44.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.44.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.45.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.45.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.45.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.45.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.45.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.2.5	Gauge	1536

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.45.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.45.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.45.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.45.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.45.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.45.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.45.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.45.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.45.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.45.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.45.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.45.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.45.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.45.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.45.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.45.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.45.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.45.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.45.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.45.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.46.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.46.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.46.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.46.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.46.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.46.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.2.6	Gauge	65535

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.46.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.46.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.46.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.46.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.46.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.46.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.46.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.46.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.46.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.46.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.46.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.46.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.46.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.46.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.46.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.46.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.46.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.46.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.46.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.47.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.47.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.47.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.47.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.47.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.47.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.47.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.2.7	Gauge	512

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.47.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.47.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.47.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.47.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.47.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.47.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.47.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.47.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.47.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.47.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.47.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.47.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.47.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.47.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.47.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.47.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.47.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.47.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.48.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.48.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.48.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.2.3	Gauge	16777200
ibQoSIfCapCharacteristicsValue.48.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.48.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.48.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.48.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.48.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.3.1	Gauge	1



Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.48.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.48.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.3.3	Gauge	1048576
ibQoSIfCapCharacteristicsValue.48.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.48.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.48.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.48.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.48.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.48.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.48.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.48.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.48.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.48.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.48.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.48.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.48.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.48.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.48.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.49.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.49.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.49.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.2.3	Gauge	10485760
ibQoSIfCapCharacteristicsValue.49.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.49.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.49.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.49.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.49.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.49.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.3.2	Gauge	16

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.49.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.3.3	Gauge	10485760
ibQoSIfCapCharacteristicsValue.49.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.49.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.49.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.49.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.49.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.49.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.49.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.49.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.49.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.49.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.49.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.49.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.49.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.49.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.49.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.50.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.50.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.50.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.2.3	Gauge	10485760
ibQoSIfCapCharacteristicsValue.50.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.50.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.50.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.50.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.50.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.50.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.50.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.3.3	Gauge	10485760

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.50.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.50.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.50.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.50.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.50.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.50.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.50.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.50.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.50.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.50.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.50.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.50.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.50.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.50.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.50.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.51.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.51.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.51.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.2.3	Gauge	10485760
ibQoSIfCapCharacteristicsValue.51.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.51.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.51.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.51.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.51.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.51.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.51.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.3.3	Gauge	10485760
ibQoSIfCapCharacteristicsValue.51.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.3.4	Gauge	16

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.51.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.51.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.51.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.51.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.51.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.51.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.51.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.51.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.51.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.51.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.51.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.51.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.51.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.51.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.52.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.52.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.52.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.2.3	Gauge	10485760
ibQoSIfCapCharacteristicsValue.52.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.52.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.52.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.52.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.52.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.52.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.52.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.3.3	Gauge	10485760
ibQoSIfCapCharacteristicsValue.52.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.52.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.3.5	Gauge	512

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.52.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.52.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.52.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.52.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.52.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.52.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.52.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.52.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.52.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.52.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.52.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.52.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.52.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.53.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.53.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.53.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.2.3	Gauge	10485760
ibQoSIfCapCharacteristicsValue.53.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.53.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.53.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.53.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.53.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.53.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.53.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.3.3	Gauge	10485760
ibQoSIfCapCharacteristicsValue.53.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.53.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.53.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.3.6	Gauge	134217728

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.53.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.3.7	Gauge	512
ibQoSIfCapCharacteristicsValue.53.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.53.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.53.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.53.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.53.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.53.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.53.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.53.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.53.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.53.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.53.8.4	Gauge	1
ibQoSIfCapCharacteristicsValue.54.2.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.2.1	Gauge	1
ibQoSIfCapCharacteristicsValue.54.2.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.2.2	Gauge	16
ibQoSIfCapCharacteristicsValue.54.2.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.2.3	Gauge	10485760
ibQoSIfCapCharacteristicsValue.54.2.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.2.4	Gauge	16
ibQoSIfCapCharacteristicsValue.54.2.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.2.5	Gauge	1536
ibQoSIfCapCharacteristicsValue.54.2.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.2.6	Gauge	65535
ibQoSIfCapCharacteristicsValue.54.2.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.2.7	Gauge	512
ibQoSIfCapCharacteristicsValue.54.3.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.3.1	Gauge	1
ibQoSIfCapCharacteristicsValue.54.3.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.3.2	Gauge	16
ibQoSIfCapCharacteristicsValue.54.3.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.3.3	Gauge	10485760
ibQoSIfCapCharacteristicsValue.54.3.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.3.4	Gauge	16
ibQoSIfCapCharacteristicsValue.54.3.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.3.5	Gauge	512
ibQoSIfCapCharacteristicsValue.54.3.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.3.6	Gauge	134217728
ibQoSIfCapCharacteristicsValue.54.3.7	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.3.7	Gauge	512

Name	OID	Value Type	Value Example
ibQoSIfCapCharacteristicsValue.54.4.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.4.1	Gauge	1
ibQoSIfCapCharacteristicsValue.54.4.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.4.2	Gauge	2
ibQoSIfCapCharacteristicsValue.54.4.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.4.3	Gauge	7
ibQoSIfCapCharacteristicsValue.54.4.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.4.4	Gauge	1
ibQoSIfCapCharacteristicsValue.54.4.5	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.4.5	Gauge	2
ibQoSIfCapCharacteristicsValue.54.4.6	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.4.6	Gauge	8
ibQoSIfCapCharacteristicsValue.54.8.1	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.8.1	Gauge	1
ibQoSIfCapCharacteristicsValue.54.8.2	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.8.2	Gauge	9
ibQoSIfCapCharacteristicsValue.54.8.3	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.8.3	Gauge	7
ibQoSIfCapCharacteristicsValue.54.8.4	.1.3.6.1.4.1.26138.7.1.1.1.3.1.4.54.8.4	Gauge	1
ibNqaMIBVersion.0	.1.3.6.1.4.1.26138.8.3.1.1.0	OctetString	1.0.0: Initial Ping MIB
ibNqaStatsMaxGroupNumber.0	.1.3.6.1.4.1.26138.8.3.1.9.0	Integer	100
ibNTPSysLeap.0	.1.3.6.1.4.1.26138.8.22.1.1.1.0	Integer	noWarning (0)
ibNTPSysStratum.0	.1.3.6.1.4.1.26138.8.22.1.1.2.0	Integer	2
ibNTPSysPrecision.0	.1.3.6.1.4.1.26138.8.22.1.1.3.0	Integer	-18
ibNTPSysRootdelay.0	.1.3.6.1.4.1.26138.8.22.1.1.4.0	OctetString	18.06641 ms
ibNTPSysRootdispersion.0	.1.3.6.1.4.1.26138.8.22.1.1.5.0	OctetString	19.72961 ms
ibNTPSysRefid.0	.1.3.6.1.4.1.26138.8.22.1.1.6.0	OctetString	200.160.7.186
ibNTPSysReftime.0	.1.3.6.1.4.1.26138.8.22.1.1.7.0	OctetString	ea7cb6ea.e8bb3766 Fri, Aug 30 2024 18:23:54.909
ibNTPSysPoll.0	.1.3.6.1.4.1.26138.8.22.1.1.8.0	Integer	6
ibNTPSysPeer.0	.1.3.6.1.4.1.26138.8.22.1.1.9.0	Integer	1330528850
ibNTPSysState.0	.1.3.6.1.4.1.26138.8.22.1.1.10.0	Integer	clockBySyns (4)
ibNTPSysOffset.0	.1.3.6.1.4.1.26138.8.22.1.1.11.0	OctetString	-14.93835 ms
ibNTPSysDrift.0	.1.3.6.1.4.1.26138.8.22.1.1.12.0	OctetString	0.00000
ibNTPSysCompliance.0	.1.3.6.1.4.1.26138.8.22.1.1.13.0	OctetString	1.19019 ms
ibNTPSysClock.0	.1.3.6.1.4.1.26138.8.22.1.1.14.0	OctetString	ea7cb6f9.24182565 Fri, Aug 30 2024 18:24:09.140
ibNTPSysStabil.0	.1.3.6.1.4.1.26138.8.22.1.1.15.0	OctetString	0.000 pps
ibNTPSysAuthenticate.0	.1.3.6.1.4.1.26138.8.22.1.1.16.0	Integer	noAuthenticate (0)
ibNTPSysPollSec.0	.1.3.6.1.4.1.26138.8.22.1.1.17.0	Integer	64
ibNTPSysClockSec.0	.1.3.6.1.4.1.26138.8.22.1.1.18.0	Integer	1725053049
ibNTPServerIP.0	.1.3.6.1.4.1.26138.8.22.1.1.19.0	IpAddress	200.160.7.186
ibNTPSysSrcPeer.0	.1.3.6.1.4.1.26138.8.22.1.1.20.0	Gauge	1330528850
ibNTPPeerConfig.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.1.200.160.7.186.3	Integer	true (1)

Name	OID	Value Type	Value Example
ibNTPPeerAuthenable.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.2.200.160.7.186.3	Integer	false (2)
ibNTPPeerAuthentic.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.3.200.160.7.186.3	Integer	false (2)
ibNTPPeerRemPort.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.5.200.160.7.186.3	Integer	123
ibNTPPeerLocAdr.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.6.200.160.7.186.3	IpAddress	0.0.0.0
ibNTPPeerLocPort.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.7.200.160.7.186.3	Integer	123
ibNTPPeerLeap.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.8.200.160.7.186.3	Integer	noWarning (0)
ibNTPPeerStratum.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.10.200.160.7.186.3	Integer	1
ibNTPPeerP-Poll.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.11.200.160.7.186.3	Integer	6
ibNTPPeerH-Poll.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.12.200.160.7.186.3	Integer	6
ibNTPPeerPrecision.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.13.200.160.7.186.3	Integer	-20
ibNTPPeerRootDelay.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.14.200.160.7.186.3	OctetString	0.00000 ms
ibNTPPeerRootDispersion.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.15.200.160.7.186.3	OctetString	1.11389 ms
ibNTPPeerReflid.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.16.200.160.7.186.3	OctetString	ONBR
ibNTPPeerRefTime.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.17.200.160.7.186.3	OctetString	ea7cb6e2.dbbe68c1 Fri, Aug 30 2024 18:23:46.858
ibNTPPeerOrg.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.18.200.160.7.186.3	OctetString	ea7cb6ea.e407df63 Fri, Aug 30 2024 18:23:54.890
ibNTPPeerRec.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.19.200.160.7.186.3	OctetString	ea7cb6ea.e289bc0b Fri, Aug 30 2024 18:23:54.884
ibNTPPeerXmt.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.20.200.160.7.186.3	OctetString	ea7cb6ea.e289bc0b Fri, Aug 30 2024 18:23:54.884
ibNTPPeerReach.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.21.200.160.7.186.3	Integer	255
ibNTPPeerValid.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.22.200.160.7.186.3	Integer	7
ibNTPPeerTimer.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.23.200.160.7.186.3	Integer	52
ibNTPPeerDelay.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.24.200.160.7.186.3	OctetString	18.06641 ms
ibNTPPeerOffset.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.25.200.160.7.186.3	OctetString	-14.951989 ms
ibNTPPeerJitter.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.26.200.160.7.186.3	OctetString	0.36621
ibNTPPeerDispersion.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.27.200.160.7.186.3	OctetString	3.08228 ms
ibNTPPeerKeyld.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.28.200.160.7.186.3	Integer	0



Name	OID	Value Type	Value Example
ibNTPPeerFilterDelay.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.1.29.200.160.7.186.3	ObjectString	18.34ms 18.06ms 18.47ms 18.47ms 18.64ms 18.34ms 20.33ms 18.09ms
ibNTPPeerFilterOffset.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.1.30.200.160.7.186.3	ObjectString	-15.02ms -14.95ms -14.72ms -14.74ms -14.95ms -14.61ms -15.79ms -14.72ms
ibNTPPeerFilterError.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.1.31.200.160.7.186.3	ObjectString	0.000ms 1.022ms 2.014ms 3.021ms 4.013ms 5.035ms 6.073ms 7.064ms
ibNTPPeerPMode.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.1.32.200.160.7.186.3	Integer	server (4)
ibNTPPeerReceived.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.1.33.200.160.7.186.3	Counter32	35
ibNTPPeerSent.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.1.34.200.160.7.186.3	Counter32	53
ibNTPPeerFlash.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.1.35.200.160.7.186.3	ObjectString	{}
ibNTPPeerRowStatus.200.160.7.186.3	.1.3.6.1.4.1.26138.8.22.2.1.1.1.36.200.160.7.186.3	Integer	active (1)
ibAggPortNotAttachedReason.1	.1.3.6.1.4.1.26138.8.25.1.2.1.2.1	Integer	7
ibAggPortNotAttachedReason.2	.1.3.6.1.4.1.26138.8.25.1.2.1.2.2	Integer	7
ibAggPortNotAttachedReason.3	.1.3.6.1.4.1.26138.8.25.1.2.1.2.3	Integer	7
ibAggPortNotAttachedReason.4	.1.3.6.1.4.1.26138.8.25.1.2.1.2.4	Integer	7
ibAggPortNotAttachedReason.5	.1.3.6.1.4.1.26138.8.25.1.2.1.2.5	Integer	7
ibAggPortNotAttachedReason.6	.1.3.6.1.4.1.26138.8.25.1.2.1.2.6	Integer	7
ibAggPortNotAttachedReason.7	.1.3.6.1.4.1.26138.8.25.1.2.1.2.7	Integer	7
ibAggPortNotAttachedReason.8	.1.3.6.1.4.1.26138.8.25.1.2.1.2.8	Integer	7
ibAggPortNotAttachedReason.9	.1.3.6.1.4.1.26138.8.25.1.2.1.2.9	Integer	7
ibAggPortNotAttachedReason.10	.1.3.6.1.4.1.26138.8.25.1.2.1.2.10	Integer	7
ibAggPortNotAttachedReason.11	.1.3.6.1.4.1.26138.8.25.1.2.1.2.11	Integer	7
ibAggPortNotAttachedReason.12	.1.3.6.1.4.1.26138.8.25.1.2.1.2.12	Integer	7
ibAggPortNotAttachedReason.13	.1.3.6.1.4.1.26138.8.25.1.2.1.2.13	Integer	7
ibAggPortNotAttachedReason.14	.1.3.6.1.4.1.26138.8.25.1.2.1.2.14	Integer	7
ibAggPortNotAttachedReason.15	.1.3.6.1.4.1.26138.8.25.1.2.1.2.15	Integer	7
ibAggPortNotAttachedReason.16	.1.3.6.1.4.1.26138.8.25.1.2.1.2.16	Integer	7

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ibAggPortNotAttachedReason.17	.1.3.6.1.4.1.26138.8.25.1.2.1.2.17	Integer	7
ibAggPortNotAttachedReason.18	.1.3.6.1.4.1.26138.8.25.1.2.1.2.18	Integer	7
ibAggPortNotAttachedReason.19	.1.3.6.1.4.1.26138.8.25.1.2.1.2.19	Integer	7
ibAggPortNotAttachedReason.20	.1.3.6.1.4.1.26138.8.25.1.2.1.2.20	Integer	7
ibAggPortNotAttachedReason.21	.1.3.6.1.4.1.26138.8.25.1.2.1.2.21	Integer	7
ibAggPortNotAttachedReason.22	.1.3.6.1.4.1.26138.8.25.1.2.1.2.22	Integer	7
ibAggPortNotAttachedReason.23	.1.3.6.1.4.1.26138.8.25.1.2.1.2.23	Integer	7
ibAggPortNotAttachedReason.24	.1.3.6.1.4.1.26138.8.25.1.2.1.2.24	Integer	7
ibAggPortNotAttachedReason.25	.1.3.6.1.4.1.26138.8.25.1.2.1.2.25	Integer	7
ibAggPortNotAttachedReason.26	.1.3.6.1.4.1.26138.8.25.1.2.1.2.26	Integer	7
ibAggPortNotAttachedReason.27	.1.3.6.1.4.1.26138.8.25.1.2.1.2.27	Integer	7
ibAggPortNotAttachedReason.28	.1.3.6.1.4.1.26138.8.25.1.2.1.2.28	Integer	7
ibAggPortNotAttachedReason.29	.1.3.6.1.4.1.26138.8.25.1.2.1.2.29	Integer	7
ibAggPortNotAttachedReason.30	.1.3.6.1.4.1.26138.8.25.1.2.1.2.30	Integer	7
ibAggPortNotAttachedReason.31	.1.3.6.1.4.1.26138.8.25.1.2.1.2.31	Integer	7
ibAggPortNotAttachedReason.32	.1.3.6.1.4.1.26138.8.25.1.2.1.2.32	Integer	7
ibAggPortNotAttachedReason.33	.1.3.6.1.4.1.26138.8.25.1.2.1.2.33	Integer	7
ibAggPortNotAttachedReason.34	.1.3.6.1.4.1.26138.8.25.1.2.1.2.34	Integer	7
ibAggPortNotAttachedReason.35	.1.3.6.1.4.1.26138.8.25.1.2.1.2.35	Integer	7
ibAggPortNotAttachedReason.36	.1.3.6.1.4.1.26138.8.25.1.2.1.2.36	Integer	7
ibAggPortNotAttachedReason.37	.1.3.6.1.4.1.26138.8.25.1.2.1.2.37	Integer	7
ibAggPortNotAttachedReason.38	.1.3.6.1.4.1.26138.8.25.1.2.1.2.38	Integer	7
ibAggPortNotAttachedReason.39	.1.3.6.1.4.1.26138.8.25.1.2.1.2.39	Integer	7
ibAggPortNotAttachedReason.40	.1.3.6.1.4.1.26138.8.25.1.2.1.2.40	Integer	7
ibAggPortNotAttachedReason.41	.1.3.6.1.4.1.26138.8.25.1.2.1.2.41	Integer	7

Name	OID	Value Type	Value Example
ibAggPortNotAttachedReason.42	.1.3.6.1.4.1.26138.8.25.1.2.1.2.42	Integer	7
ibAggPortNotAttachedReason.43	.1.3.6.1.4.1.26138.8.25.1.2.1.2.43	Integer	7
ibAggPortNotAttachedReason.44	.1.3.6.1.4.1.26138.8.25.1.2.1.2.44	Integer	7
ibAggPortNotAttachedReason.45	.1.3.6.1.4.1.26138.8.25.1.2.1.2.45	Integer	7
ibAggPortNotAttachedReason.46	.1.3.6.1.4.1.26138.8.25.1.2.1.2.46	Integer	7
ibAggPortNotAttachedReason.47	.1.3.6.1.4.1.26138.8.25.1.2.1.2.47	Integer	7
ibAggPortNotAttachedReason.48	.1.3.6.1.4.1.26138.8.25.1.2.1.2.48	Integer	7
ibAggPortNotAttachedReason.49	.1.3.6.1.4.1.26138.8.25.1.2.1.2.49	Integer	7
ibAggPortNotAttachedReason.50	.1.3.6.1.4.1.26138.8.25.1.2.1.2.50	Integer	7
ibAggPortNotAttachedReason.51	.1.3.6.1.4.1.26138.8.25.1.2.1.2.51	Integer	7
ibAggPortNotAttachedReason.52	.1.3.6.1.4.1.26138.8.25.1.2.1.2.52	Integer	7
ibAggPortNotAttachedReason.53	.1.3.6.1.4.1.26138.8.25.1.2.1.2.53	Integer	7
ibAggPortNotAttachedReason.54	.1.3.6.1.4.1.26138.8.25.1.2.1.2.54	Integer	7
ibAggPortLacpState.1	.1.3.6.1.4.1.26138.8.25.1.2.1.3.1	Integer	false (2)
ibAggPortLacpState.2	.1.3.6.1.4.1.26138.8.25.1.2.1.3.2	Integer	false (2)
ibAggPortLacpState.3	.1.3.6.1.4.1.26138.8.25.1.2.1.3.3	Integer	false (2)
ibAggPortLacpState.4	.1.3.6.1.4.1.26138.8.25.1.2.1.3.4	Integer	false (2)
ibAggPortLacpState.5	.1.3.6.1.4.1.26138.8.25.1.2.1.3.5	Integer	false (2)
ibAggPortLacpState.6	.1.3.6.1.4.1.26138.8.25.1.2.1.3.6	Integer	false (2)
ibAggPortLacpState.7	.1.3.6.1.4.1.26138.8.25.1.2.1.3.7	Integer	false (2)
ibAggPortLacpState.8	.1.3.6.1.4.1.26138.8.25.1.2.1.3.8	Integer	false (2)
ibAggPortLacpState.9	.1.3.6.1.4.1.26138.8.25.1.2.1.3.9	Integer	false (2)
ibAggPortLacpState.10	.1.3.6.1.4.1.26138.8.25.1.2.1.3.10	Integer	false (2)
ibAggPortLacpState.11	.1.3.6.1.4.1.26138.8.25.1.2.1.3.11	Integer	false (2)
ibAggPortLacpState.12	.1.3.6.1.4.1.26138.8.25.1.2.1.3.12	Integer	false (2)
ibAggPortLacpState.13	.1.3.6.1.4.1.26138.8.25.1.2.1.3.13	Integer	false (2)
ibAggPortLacpState.14	.1.3.6.1.4.1.26138.8.25.1.2.1.3.14	Integer	false (2)
ibAggPortLacpState.15	.1.3.6.1.4.1.26138.8.25.1.2.1.3.15	Integer	false (2)
ibAggPortLacpState.16	.1.3.6.1.4.1.26138.8.25.1.2.1.3.16	Integer	false (2)
ibAggPortLacpState.17	.1.3.6.1.4.1.26138.8.25.1.2.1.3.17	Integer	false (2)
ibAggPortLacpState.18	.1.3.6.1.4.1.26138.8.25.1.2.1.3.18	Integer	false (2)
ibAggPortLacpState.19	.1.3.6.1.4.1.26138.8.25.1.2.1.3.19	Integer	false (2)
ibAggPortLacpState.20	.1.3.6.1.4.1.26138.8.25.1.2.1.3.20	Integer	false (2)
ibAggPortLacpState.21	.1.3.6.1.4.1.26138.8.25.1.2.1.3.21	Integer	false (2)

Name	OID	Value Type	Value Example
ibAggPortLacpState.22	.1.3.6.1.4.1.26138.8.25.1.2.1.3.22	Integer	false (2)
ibAggPortLacpState.23	.1.3.6.1.4.1.26138.8.25.1.2.1.3.23	Integer	false (2)
ibAggPortLacpState.24	.1.3.6.1.4.1.26138.8.25.1.2.1.3.24	Integer	false (2)
ibAggPortLacpState.25	.1.3.6.1.4.1.26138.8.25.1.2.1.3.25	Integer	false (2)
ibAggPortLacpState.26	.1.3.6.1.4.1.26138.8.25.1.2.1.3.26	Integer	false (2)
ibAggPortLacpState.27	.1.3.6.1.4.1.26138.8.25.1.2.1.3.27	Integer	false (2)
ibAggPortLacpState.28	.1.3.6.1.4.1.26138.8.25.1.2.1.3.28	Integer	false (2)
ibAggPortLacpState.29	.1.3.6.1.4.1.26138.8.25.1.2.1.3.29	Integer	false (2)
ibAggPortLacpState.30	.1.3.6.1.4.1.26138.8.25.1.2.1.3.30	Integer	false (2)
ibAggPortLacpState.31	.1.3.6.1.4.1.26138.8.25.1.2.1.3.31	Integer	false (2)
ibAggPortLacpState.32	.1.3.6.1.4.1.26138.8.25.1.2.1.3.32	Integer	false (2)
ibAggPortLacpState.33	.1.3.6.1.4.1.26138.8.25.1.2.1.3.33	Integer	false (2)
ibAggPortLacpState.34	.1.3.6.1.4.1.26138.8.25.1.2.1.3.34	Integer	false (2)
ibAggPortLacpState.35	.1.3.6.1.4.1.26138.8.25.1.2.1.3.35	Integer	false (2)
ibAggPortLacpState.36	.1.3.6.1.4.1.26138.8.25.1.2.1.3.36	Integer	false (2)
ibAggPortLacpState.37	.1.3.6.1.4.1.26138.8.25.1.2.1.3.37	Integer	false (2)
ibAggPortLacpState.38	.1.3.6.1.4.1.26138.8.25.1.2.1.3.38	Integer	false (2)
ibAggPortLacpState.39	.1.3.6.1.4.1.26138.8.25.1.2.1.3.39	Integer	false (2)
ibAggPortLacpState.40	.1.3.6.1.4.1.26138.8.25.1.2.1.3.40	Integer	false (2)
ibAggPortLacpState.41	.1.3.6.1.4.1.26138.8.25.1.2.1.3.41	Integer	false (2)
ibAggPortLacpState.42	.1.3.6.1.4.1.26138.8.25.1.2.1.3.42	Integer	false (2)
ibAggPortLacpState.43	.1.3.6.1.4.1.26138.8.25.1.2.1.3.43	Integer	false (2)
ibAggPortLacpState.44	.1.3.6.1.4.1.26138.8.25.1.2.1.3.44	Integer	false (2)
ibAggPortLacpState.45	.1.3.6.1.4.1.26138.8.25.1.2.1.3.45	Integer	false (2)
ibAggPortLacpState.46	.1.3.6.1.4.1.26138.8.25.1.2.1.3.46	Integer	false (2)
ibAggPortLacpState.47	.1.3.6.1.4.1.26138.8.25.1.2.1.3.47	Integer	false (2)
ibAggPortLacpState.48	.1.3.6.1.4.1.26138.8.25.1.2.1.3.48	Integer	false (2)
ibAggPortLacpState.49	.1.3.6.1.4.1.26138.8.25.1.2.1.3.49	Integer	false (2)
ibAggPortLacpState.50	.1.3.6.1.4.1.26138.8.25.1.2.1.3.50	Integer	false (2)
ibAggPortLacpState.51	.1.3.6.1.4.1.26138.8.25.1.2.1.3.51	Integer	false (2)
ibAggPortLacpState.52	.1.3.6.1.4.1.26138.8.25.1.2.1.3.52	Integer	false (2)
ibAggPortLacpState.53	.1.3.6.1.4.1.26138.8.25.1.2.1.3.53	Integer	false (2)
ibAggPortLacpState.54	.1.3.6.1.4.1.26138.8.25.1.2.1.3.54	Integer	false (2)
ibAggPortNotAttachedString.1	.1.3.6.1.4.1.26138.8.25.1.2.1.4.1	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.2	.1.3.6.1.4.1.26138.8.25.1.2.1.4.2	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.3	.1.3.6.1.4.1.26138.8.25.1.2.1.4.3	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.4	.1.3.6.1.4.1.26138.8.25.1.2.1.4.4	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.5	.1.3.6.1.4.1.26138.8.25.1.2.1.4.5	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.6	.1.3.6.1.4.1.26138.8.25.1.2.1.4.6	OctetString	The port is not selected for an aggregator.

Name	OID	Value Type	Value Example
ibAggPortNotAttachedString.7	.1.3.6.1.4.1.26138.8.25.1.2.1.4.7	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.8	.1.3.6.1.4.1.26138.8.25.1.2.1.4.8	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.9	.1.3.6.1.4.1.26138.8.25.1.2.1.4.9	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.10	.1.3.6.1.4.1.26138.8.25.1.2.1.4.10	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.11	.1.3.6.1.4.1.26138.8.25.1.2.1.4.11	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.12	.1.3.6.1.4.1.26138.8.25.1.2.1.4.12	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.13	.1.3.6.1.4.1.26138.8.25.1.2.1.4.13	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.14	.1.3.6.1.4.1.26138.8.25.1.2.1.4.14	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.15	.1.3.6.1.4.1.26138.8.25.1.2.1.4.15	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.16	.1.3.6.1.4.1.26138.8.25.1.2.1.4.16	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.17	.1.3.6.1.4.1.26138.8.25.1.2.1.4.17	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.18	.1.3.6.1.4.1.26138.8.25.1.2.1.4.18	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.19	.1.3.6.1.4.1.26138.8.25.1.2.1.4.19	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.20	.1.3.6.1.4.1.26138.8.25.1.2.1.4.20	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.21	.1.3.6.1.4.1.26138.8.25.1.2.1.4.21	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.22	.1.3.6.1.4.1.26138.8.25.1.2.1.4.22	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.23	.1.3.6.1.4.1.26138.8.25.1.2.1.4.23	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.24	.1.3.6.1.4.1.26138.8.25.1.2.1.4.24	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.25	.1.3.6.1.4.1.26138.8.25.1.2.1.4.25	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.26	.1.3.6.1.4.1.26138.8.25.1.2.1.4.26	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.27	.1.3.6.1.4.1.26138.8.25.1.2.1.4.27	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.28	.1.3.6.1.4.1.26138.8.25.1.2.1.4.28	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.29	.1.3.6.1.4.1.26138.8.25.1.2.1.4.29	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.30	.1.3.6.1.4.1.26138.8.25.1.2.1.4.30	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.31	.1.3.6.1.4.1.26138.8.25.1.2.1.4.31	OctetString	The port is not selected for an aggregator.

Name	OID	Value Type	Value Example
ibAggPortNotAttachedString.32	.1.3.6.1.4.1.26138.8.25.1.2.1.4.32	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.33	.1.3.6.1.4.1.26138.8.25.1.2.1.4.33	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.34	.1.3.6.1.4.1.26138.8.25.1.2.1.4.34	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.35	.1.3.6.1.4.1.26138.8.25.1.2.1.4.35	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.36	.1.3.6.1.4.1.26138.8.25.1.2.1.4.36	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.37	.1.3.6.1.4.1.26138.8.25.1.2.1.4.37	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.38	.1.3.6.1.4.1.26138.8.25.1.2.1.4.38	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.39	.1.3.6.1.4.1.26138.8.25.1.2.1.4.39	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.40	.1.3.6.1.4.1.26138.8.25.1.2.1.4.40	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.41	.1.3.6.1.4.1.26138.8.25.1.2.1.4.41	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.42	.1.3.6.1.4.1.26138.8.25.1.2.1.4.42	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.43	.1.3.6.1.4.1.26138.8.25.1.2.1.4.43	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.44	.1.3.6.1.4.1.26138.8.25.1.2.1.4.44	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.45	.1.3.6.1.4.1.26138.8.25.1.2.1.4.45	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.46	.1.3.6.1.4.1.26138.8.25.1.2.1.4.46	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.47	.1.3.6.1.4.1.26138.8.25.1.2.1.4.47	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.48	.1.3.6.1.4.1.26138.8.25.1.2.1.4.48	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.49	.1.3.6.1.4.1.26138.8.25.1.2.1.4.49	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.50	.1.3.6.1.4.1.26138.8.25.1.2.1.4.50	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.51	.1.3.6.1.4.1.26138.8.25.1.2.1.4.51	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.52	.1.3.6.1.4.1.26138.8.25.1.2.1.4.52	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.53	.1.3.6.1.4.1.26138.8.25.1.2.1.4.53	OctetString	The port is not selected for an aggregator.
ibAggPortNotAttachedString.54	.1.3.6.1.4.1.26138.8.25.1.2.1.4.54	OctetString	The port is not selected for an aggregator.
ibAggResourceAllocationValue.0	.1.3.6.1.4.1.26138.8.25.1.3.0	OctetString	0x01 03 00 00
ibifMirrorPort.1	.1.3.6.1.4.1.26138.8.35.1.1.1.4.1	Integer	false (2)
ibifMirrorPort.2	.1.3.6.1.4.1.26138.8.35.1.1.1.4.2	Integer	false (2)

Name	OID	Value Type	Value Example
ibifMirrorPort.3	.1.3.6.1.4.1.26138.8.35.1.1.1.4.3	Integer	false (2)
ibifMirrorPort.4	.1.3.6.1.4.1.26138.8.35.1.1.1.4.4	Integer	false (2)
ibifMirrorPort.5	.1.3.6.1.4.1.26138.8.35.1.1.1.4.5	Integer	false (2)
ibifMirrorPort.6	.1.3.6.1.4.1.26138.8.35.1.1.1.4.6	Integer	false (2)
ibifMirrorPort.7	.1.3.6.1.4.1.26138.8.35.1.1.1.4.7	Integer	false (2)
ibifMirrorPort.8	.1.3.6.1.4.1.26138.8.35.1.1.1.4.8	Integer	false (2)
ibifMirrorPort.9	.1.3.6.1.4.1.26138.8.35.1.1.1.4.9	Integer	false (2)
ibifMirrorPort.10	.1.3.6.1.4.1.26138.8.35.1.1.1.4.10	Integer	false (2)
ibifMirrorPort.11	.1.3.6.1.4.1.26138.8.35.1.1.1.4.11	Integer	false (2)
ibifMirrorPort.12	.1.3.6.1.4.1.26138.8.35.1.1.1.4.12	Integer	false (2)
ibifMirrorPort.13	.1.3.6.1.4.1.26138.8.35.1.1.1.4.13	Integer	false (2)
ibifMirrorPort.14	.1.3.6.1.4.1.26138.8.35.1.1.1.4.14	Integer	false (2)
ibifMirrorPort.15	.1.3.6.1.4.1.26138.8.35.1.1.1.4.15	Integer	false (2)
ibifMirrorPort.16	.1.3.6.1.4.1.26138.8.35.1.1.1.4.16	Integer	false (2)
ibifMirrorPort.17	.1.3.6.1.4.1.26138.8.35.1.1.1.4.17	Integer	false (2)
ibifMirrorPort.18	.1.3.6.1.4.1.26138.8.35.1.1.1.4.18	Integer	false (2)
ibifMirrorPort.19	.1.3.6.1.4.1.26138.8.35.1.1.1.4.19	Integer	false (2)
ibifMirrorPort.20	.1.3.6.1.4.1.26138.8.35.1.1.1.4.20	Integer	false (2)
ibifMirrorPort.21	.1.3.6.1.4.1.26138.8.35.1.1.1.4.21	Integer	false (2)
ibifMirrorPort.22	.1.3.6.1.4.1.26138.8.35.1.1.1.4.22	Integer	false (2)
ibifMirrorPort.23	.1.3.6.1.4.1.26138.8.35.1.1.1.4.23	Integer	false (2)
ibifMirrorPort.24	.1.3.6.1.4.1.26138.8.35.1.1.1.4.24	Integer	false (2)
ibifMirrorPort.25	.1.3.6.1.4.1.26138.8.35.1.1.1.4.25	Integer	false (2)
ibifMirrorPort.26	.1.3.6.1.4.1.26138.8.35.1.1.1.4.26	Integer	false (2)
ibifMirrorPort.27	.1.3.6.1.4.1.26138.8.35.1.1.1.4.27	Integer	false (2)
ibifMirrorPort.28	.1.3.6.1.4.1.26138.8.35.1.1.1.4.28	Integer	false (2)
ibifMirrorPort.29	.1.3.6.1.4.1.26138.8.35.1.1.1.4.29	Integer	false (2)
ibifMirrorPort.30	.1.3.6.1.4.1.26138.8.35.1.1.1.4.30	Integer	false (2)
ibifMirrorPort.31	.1.3.6.1.4.1.26138.8.35.1.1.1.4.31	Integer	false (2)
ibifMirrorPort.32	.1.3.6.1.4.1.26138.8.35.1.1.1.4.32	Integer	false (2)
ibifMirrorPort.33	.1.3.6.1.4.1.26138.8.35.1.1.1.4.33	Integer	false (2)
ibifMirrorPort.34	.1.3.6.1.4.1.26138.8.35.1.1.1.4.34	Integer	false (2)
ibifMirrorPort.35	.1.3.6.1.4.1.26138.8.35.1.1.1.4.35	Integer	false (2)
ibifMirrorPort.36	.1.3.6.1.4.1.26138.8.35.1.1.1.4.36	Integer	false (2)
ibifMirrorPort.37	.1.3.6.1.4.1.26138.8.35.1.1.1.4.37	Integer	false (2)
ibifMirrorPort.38	.1.3.6.1.4.1.26138.8.35.1.1.1.4.38	Integer	false (2)
ibifMirrorPort.39	.1.3.6.1.4.1.26138.8.35.1.1.1.4.39	Integer	false (2)
ibifMirrorPort.40	.1.3.6.1.4.1.26138.8.35.1.1.1.4.40	Integer	false (2)
ibifMirrorPort.41	.1.3.6.1.4.1.26138.8.35.1.1.1.4.41	Integer	false (2)
ibifMirrorPort.42	.1.3.6.1.4.1.26138.8.35.1.1.1.4.42	Integer	false (2)
ibifMirrorPort.43	.1.3.6.1.4.1.26138.8.35.1.1.1.4.43	Integer	false (2)
ibifMirrorPort.44	.1.3.6.1.4.1.26138.8.35.1.1.1.4.44	Integer	false (2)
ibifMirrorPort.45	.1.3.6.1.4.1.26138.8.35.1.1.1.4.45	Integer	false (2)



Name	OID	Value Type	Value Example
ibifMirrorPort.46	.1.3.6.1.4.1.26138.8.35.1.1.1.4.46	Integer	false (2)
ibifMirrorPort.47	.1.3.6.1.4.1.26138.8.35.1.1.1.4.47	Integer	false (2)
ibifMirrorPort.48	.1.3.6.1.4.1.26138.8.35.1.1.1.4.48	Integer	false (2)
ibifMirrorPort.49	.1.3.6.1.4.1.26138.8.35.1.1.1.4.49	Integer	false (2)
ibifMirrorPort.50	.1.3.6.1.4.1.26138.8.35.1.1.1.4.50	Integer	false (2)
ibifMirrorPort.51	.1.3.6.1.4.1.26138.8.35.1.1.1.4.51	Integer	false (2)
ibifMirrorPort.52	.1.3.6.1.4.1.26138.8.35.1.1.1.4.52	Integer	false (2)
ibifMirrorPort.53	.1.3.6.1.4.1.26138.8.35.1.1.1.4.53	Integer	false (2)
ibifMirrorPort.54	.1.3.6.1.4.1.26138.8.35.1.1.1.4.54	Integer	false (2)
ibifVLANType.1	.1.3.6.1.4.1.26138.8.35.1.1.1.5.1	Integer	access (2)
ibifVLANType.2	.1.3.6.1.4.1.26138.8.35.1.1.1.5.2	Integer	access (2)
ibifVLANType.3	.1.3.6.1.4.1.26138.8.35.1.1.1.5.3	Integer	access (2)
ibifVLANType.4	.1.3.6.1.4.1.26138.8.35.1.1.1.5.4	Integer	access (2)
ibifVLANType.5	.1.3.6.1.4.1.26138.8.35.1.1.1.5.5	Integer	access (2)
ibifVLANType.6	.1.3.6.1.4.1.26138.8.35.1.1.1.5.6	Integer	access (2)
ibifVLANType.7	.1.3.6.1.4.1.26138.8.35.1.1.1.5.7	Integer	access (2)
ibifVLANType.8	.1.3.6.1.4.1.26138.8.35.1.1.1.5.8	Integer	access (2)
ibifVLANType.9	.1.3.6.1.4.1.26138.8.35.1.1.1.5.9	Integer	access (2)
ibifVLANType.10	.1.3.6.1.4.1.26138.8.35.1.1.1.5.10	Integer	access (2)
ibifVLANType.11	.1.3.6.1.4.1.26138.8.35.1.1.1.5.11	Integer	access (2)
ibifVLANType.12	.1.3.6.1.4.1.26138.8.35.1.1.1.5.12	Integer	access (2)
ibifVLANType.13	.1.3.6.1.4.1.26138.8.35.1.1.1.5.13	Integer	access (2)
ibifVLANType.14	.1.3.6.1.4.1.26138.8.35.1.1.1.5.14	Integer	access (2)
ibifVLANType.15	.1.3.6.1.4.1.26138.8.35.1.1.1.5.15	Integer	access (2)
ibifVLANType.16	.1.3.6.1.4.1.26138.8.35.1.1.1.5.16	Integer	access (2)
ibifVLANType.17	.1.3.6.1.4.1.26138.8.35.1.1.1.5.17	Integer	access (2)
ibifVLANType.18	.1.3.6.1.4.1.26138.8.35.1.1.1.5.18	Integer	access (2)
ibifVLANType.19	.1.3.6.1.4.1.26138.8.35.1.1.1.5.19	Integer	access (2)
ibifVLANType.20	.1.3.6.1.4.1.26138.8.35.1.1.1.5.20	Integer	access (2)
ibifVLANType.21	.1.3.6.1.4.1.26138.8.35.1.1.1.5.21	Integer	access (2)
ibifVLANType.22	.1.3.6.1.4.1.26138.8.35.1.1.1.5.22	Integer	access (2)
ibifVLANType.23	.1.3.6.1.4.1.26138.8.35.1.1.1.5.23	Integer	access (2)
ibifVLANType.24	.1.3.6.1.4.1.26138.8.35.1.1.1.5.24	Integer	access (2)
ibifVLANType.25	.1.3.6.1.4.1.26138.8.35.1.1.1.5.25	Integer	access (2)
ibifVLANType.26	.1.3.6.1.4.1.26138.8.35.1.1.1.5.26	Integer	access (2)
ibifVLANType.27	.1.3.6.1.4.1.26138.8.35.1.1.1.5.27	Integer	access (2)
ibifVLANType.28	.1.3.6.1.4.1.26138.8.35.1.1.1.5.28	Integer	access (2)
ibifVLANType.29	.1.3.6.1.4.1.26138.8.35.1.1.1.5.29	Integer	access (2)
ibifVLANType.30	.1.3.6.1.4.1.26138.8.35.1.1.1.5.30	Integer	hybrid (3)
ibifVLANType.31	.1.3.6.1.4.1.26138.8.35.1.1.1.5.31	Integer	access (2)
ibifVLANType.32	.1.3.6.1.4.1.26138.8.35.1.1.1.5.32	Integer	access (2)
ibifVLANType.33	.1.3.6.1.4.1.26138.8.35.1.1.1.5.33	Integer	access (2)
ibifVLANType.34	.1.3.6.1.4.1.26138.8.35.1.1.1.5.34	Integer	access (2)



Name	OID	Value Type	Value Example
ibifVLANType.35	.1.3.6.1.4.1.26138.8.35.1.1.1.5.35	Integer	access (2)
ibifVLANType.36	.1.3.6.1.4.1.26138.8.35.1.1.1.5.36	Integer	access (2)
ibifVLANType.37	.1.3.6.1.4.1.26138.8.35.1.1.1.5.37	Integer	access (2)
ibifVLANType.38	.1.3.6.1.4.1.26138.8.35.1.1.1.5.38	Integer	access (2)
ibifVLANType.39	.1.3.6.1.4.1.26138.8.35.1.1.1.5.39	Integer	access (2)
ibifVLANType.40	.1.3.6.1.4.1.26138.8.35.1.1.1.5.40	Integer	access (2)
ibifVLANType.41	.1.3.6.1.4.1.26138.8.35.1.1.1.5.41	Integer	access (2)
ibifVLANType.42	.1.3.6.1.4.1.26138.8.35.1.1.1.5.42	Integer	access (2)
ibifVLANType.43	.1.3.6.1.4.1.26138.8.35.1.1.1.5.43	Integer	access (2)
ibifVLANType.44	.1.3.6.1.4.1.26138.8.35.1.1.1.5.44	Integer	access (2)
ibifVLANType.45	.1.3.6.1.4.1.26138.8.35.1.1.1.5.45	Integer	access (2)
ibifVLANType.46	.1.3.6.1.4.1.26138.8.35.1.1.1.5.46	Integer	access (2)
ibifVLANType.47	.1.3.6.1.4.1.26138.8.35.1.1.1.5.47	Integer	access (2)
ibifVLANType.48	.1.3.6.1.4.1.26138.8.35.1.1.1.5.48	Integer	access (2)
ibifVLANType.49	.1.3.6.1.4.1.26138.8.35.1.1.1.5.49	Integer	access (2)
ibifVLANType.50	.1.3.6.1.4.1.26138.8.35.1.1.1.5.50	Integer	access (2)
ibifVLANType.51	.1.3.6.1.4.1.26138.8.35.1.1.1.5.51	Integer	access (2)
ibifVLANType.52	.1.3.6.1.4.1.26138.8.35.1.1.1.5.52	Integer	access (2)
ibifVLANType.53	.1.3.6.1.4.1.26138.8.35.1.1.1.5.53	Integer	access (2)
ibifVLANType.54	.1.3.6.1.4.1.26138.8.35.1.1.1.5.54	Integer	access (2)
ibifMcastControl.1	.1.3.6.1.4.1.26138.8.35.1.1.1.6.1	Integer	100
ibifMcastControl.2	.1.3.6.1.4.1.26138.8.35.1.1.1.6.2	Integer	100
ibifMcastControl.3	.1.3.6.1.4.1.26138.8.35.1.1.1.6.3	Integer	100
ibifMcastControl.4	.1.3.6.1.4.1.26138.8.35.1.1.1.6.4	Integer	100
ibifMcastControl.5	.1.3.6.1.4.1.26138.8.35.1.1.1.6.5	Integer	100
ibifMcastControl.6	.1.3.6.1.4.1.26138.8.35.1.1.1.6.6	Integer	100
ibifMcastControl.7	.1.3.6.1.4.1.26138.8.35.1.1.1.6.7	Integer	100
ibifMcastControl.8	.1.3.6.1.4.1.26138.8.35.1.1.1.6.8	Integer	100
ibifMcastControl.9	.1.3.6.1.4.1.26138.8.35.1.1.1.6.9	Integer	100
ibifMcastControl.10	.1.3.6.1.4.1.26138.8.35.1.1.1.6.10	Integer	100
ibifMcastControl.11	.1.3.6.1.4.1.26138.8.35.1.1.1.6.11	Integer	100
ibifMcastControl.12	.1.3.6.1.4.1.26138.8.35.1.1.1.6.12	Integer	100
ibifMcastControl.13	.1.3.6.1.4.1.26138.8.35.1.1.1.6.13	Integer	100
ibifMcastControl.14	.1.3.6.1.4.1.26138.8.35.1.1.1.6.14	Integer	100
ibifMcastControl.15	.1.3.6.1.4.1.26138.8.35.1.1.1.6.15	Integer	100
ibifMcastControl.16	.1.3.6.1.4.1.26138.8.35.1.1.1.6.16	Integer	100
ibifMcastControl.17	.1.3.6.1.4.1.26138.8.35.1.1.1.6.17	Integer	100
ibifMcastControl.18	.1.3.6.1.4.1.26138.8.35.1.1.1.6.18	Integer	100
ibifMcastControl.19	.1.3.6.1.4.1.26138.8.35.1.1.1.6.19	Integer	100
ibifMcastControl.20	.1.3.6.1.4.1.26138.8.35.1.1.1.6.20	Integer	100
ibifMcastControl.21	.1.3.6.1.4.1.26138.8.35.1.1.1.6.21	Integer	100
ibifMcastControl.22	.1.3.6.1.4.1.26138.8.35.1.1.1.6.22	Integer	100
ibifMcastControl.23	.1.3.6.1.4.1.26138.8.35.1.1.1.6.23	Integer	100

Name	OID	Value Type	Value Example
ibifMcastControl.24	.1.3.6.1.4.1.26138.8.35.1.1.1.6.24	Integer	100
ibifMcastControl.25	.1.3.6.1.4.1.26138.8.35.1.1.1.6.25	Integer	100
ibifMcastControl.26	.1.3.6.1.4.1.26138.8.35.1.1.1.6.26	Integer	100
ibifMcastControl.27	.1.3.6.1.4.1.26138.8.35.1.1.1.6.27	Integer	100
ibifMcastControl.28	.1.3.6.1.4.1.26138.8.35.1.1.1.6.28	Integer	100
ibifMcastControl.29	.1.3.6.1.4.1.26138.8.35.1.1.1.6.29	Integer	100
ibifMcastControl.30	.1.3.6.1.4.1.26138.8.35.1.1.1.6.30	Integer	100
ibifMcastControl.31	.1.3.6.1.4.1.26138.8.35.1.1.1.6.31	Integer	100
ibifMcastControl.32	.1.3.6.1.4.1.26138.8.35.1.1.1.6.32	Integer	100
ibifMcastControl.33	.1.3.6.1.4.1.26138.8.35.1.1.1.6.33	Integer	100
ibifMcastControl.34	.1.3.6.1.4.1.26138.8.35.1.1.1.6.34	Integer	100
ibifMcastControl.35	.1.3.6.1.4.1.26138.8.35.1.1.1.6.35	Integer	100
ibifMcastControl.36	.1.3.6.1.4.1.26138.8.35.1.1.1.6.36	Integer	100
ibifMcastControl.37	.1.3.6.1.4.1.26138.8.35.1.1.1.6.37	Integer	100
ibifMcastControl.38	.1.3.6.1.4.1.26138.8.35.1.1.1.6.38	Integer	100
ibifMcastControl.39	.1.3.6.1.4.1.26138.8.35.1.1.1.6.39	Integer	100
ibifMcastControl.40	.1.3.6.1.4.1.26138.8.35.1.1.1.6.40	Integer	100
ibifMcastControl.41	.1.3.6.1.4.1.26138.8.35.1.1.1.6.41	Integer	100
ibifMcastControl.42	.1.3.6.1.4.1.26138.8.35.1.1.1.6.42	Integer	100
ibifMcastControl.43	.1.3.6.1.4.1.26138.8.35.1.1.1.6.43	Integer	100
ibifMcastControl.44	.1.3.6.1.4.1.26138.8.35.1.1.1.6.44	Integer	100
ibifMcastControl.45	.1.3.6.1.4.1.26138.8.35.1.1.1.6.45	Integer	100
ibifMcastControl.46	.1.3.6.1.4.1.26138.8.35.1.1.1.6.46	Integer	100
ibifMcastControl.47	.1.3.6.1.4.1.26138.8.35.1.1.1.6.47	Integer	100
ibifMcastControl.48	.1.3.6.1.4.1.26138.8.35.1.1.1.6.48	Integer	100
ibifMcastControl.49	.1.3.6.1.4.1.26138.8.35.1.1.1.6.49	Integer	100
ibifMcastControl.50	.1.3.6.1.4.1.26138.8.35.1.1.1.6.50	Integer	100
ibifMcastControl.51	.1.3.6.1.4.1.26138.8.35.1.1.1.6.51	Integer	100
ibifMcastControl.52	.1.3.6.1.4.1.26138.8.35.1.1.1.6.52	Integer	100
ibifMcastControl.53	.1.3.6.1.4.1.26138.8.35.1.1.1.6.53	Integer	100
ibifMcastControl.54	.1.3.6.1.4.1.26138.8.35.1.1.1.6.54	Integer	100
ibifFlowControl.1	.1.3.6.1.4.1.26138.8.35.1.1.1.7.1	Integer	false (2)
ibifFlowControl.2	.1.3.6.1.4.1.26138.8.35.1.1.1.7.2	Integer	false (2)
ibifFlowControl.3	.1.3.6.1.4.1.26138.8.35.1.1.1.7.3	Integer	false (2)
ibifFlowControl.4	.1.3.6.1.4.1.26138.8.35.1.1.1.7.4	Integer	false (2)
ibifFlowControl.5	.1.3.6.1.4.1.26138.8.35.1.1.1.7.5	Integer	false (2)
ibifFlowControl.6	.1.3.6.1.4.1.26138.8.35.1.1.1.7.6	Integer	false (2)
ibifFlowControl.7	.1.3.6.1.4.1.26138.8.35.1.1.1.7.7	Integer	false (2)
ibifFlowControl.8	.1.3.6.1.4.1.26138.8.35.1.1.1.7.8	Integer	false (2)
ibifFlowControl.9	.1.3.6.1.4.1.26138.8.35.1.1.1.7.9	Integer	false (2)
ibifFlowControl.10	.1.3.6.1.4.1.26138.8.35.1.1.1.7.10	Integer	false (2)
ibifFlowControl.11	.1.3.6.1.4.1.26138.8.35.1.1.1.7.11	Integer	false (2)
ibifFlowControl.12	.1.3.6.1.4.1.26138.8.35.1.1.1.7.12	Integer	false (2)

Name	OID	Value Type	Value Example
ibifFlowControl.13	.1.3.6.1.4.1.26138.8.35.1.1.1.7.13	Integer	false (2)
ibifFlowControl.14	.1.3.6.1.4.1.26138.8.35.1.1.1.7.14	Integer	false (2)
ibifFlowControl.15	.1.3.6.1.4.1.26138.8.35.1.1.1.7.15	Integer	false (2)
ibifFlowControl.16	.1.3.6.1.4.1.26138.8.35.1.1.1.7.16	Integer	false (2)
ibifFlowControl.17	.1.3.6.1.4.1.26138.8.35.1.1.1.7.17	Integer	false (2)
ibifFlowControl.18	.1.3.6.1.4.1.26138.8.35.1.1.1.7.18	Integer	false (2)
ibifFlowControl.19	.1.3.6.1.4.1.26138.8.35.1.1.1.7.19	Integer	false (2)
ibifFlowControl.20	.1.3.6.1.4.1.26138.8.35.1.1.1.7.20	Integer	false (2)
ibifFlowControl.21	.1.3.6.1.4.1.26138.8.35.1.1.1.7.21	Integer	false (2)
ibifFlowControl.22	.1.3.6.1.4.1.26138.8.35.1.1.1.7.22	Integer	false (2)
ibifFlowControl.23	.1.3.6.1.4.1.26138.8.35.1.1.1.7.23	Integer	false (2)
ibifFlowControl.24	.1.3.6.1.4.1.26138.8.35.1.1.1.7.24	Integer	false (2)
ibifFlowControl.25	.1.3.6.1.4.1.26138.8.35.1.1.1.7.25	Integer	false (2)
ibifFlowControl.26	.1.3.6.1.4.1.26138.8.35.1.1.1.7.26	Integer	false (2)
ibifFlowControl.27	.1.3.6.1.4.1.26138.8.35.1.1.1.7.27	Integer	false (2)
ibifFlowControl.28	.1.3.6.1.4.1.26138.8.35.1.1.1.7.28	Integer	false (2)
ibifFlowControl.29	.1.3.6.1.4.1.26138.8.35.1.1.1.7.29	Integer	false (2)
ibifFlowControl.30	.1.3.6.1.4.1.26138.8.35.1.1.1.7.30	Integer	false (2)
ibifFlowControl.31	.1.3.6.1.4.1.26138.8.35.1.1.1.7.31	Integer	false (2)
ibifFlowControl.32	.1.3.6.1.4.1.26138.8.35.1.1.1.7.32	Integer	false (2)
ibifFlowControl.33	.1.3.6.1.4.1.26138.8.35.1.1.1.7.33	Integer	false (2)
ibifFlowControl.34	.1.3.6.1.4.1.26138.8.35.1.1.1.7.34	Integer	false (2)
ibifFlowControl.35	.1.3.6.1.4.1.26138.8.35.1.1.1.7.35	Integer	false (2)
ibifFlowControl.36	.1.3.6.1.4.1.26138.8.35.1.1.1.7.36	Integer	false (2)
ibifFlowControl.37	.1.3.6.1.4.1.26138.8.35.1.1.1.7.37	Integer	false (2)
ibifFlowControl.38	.1.3.6.1.4.1.26138.8.35.1.1.1.7.38	Integer	false (2)
ibifFlowControl.39	.1.3.6.1.4.1.26138.8.35.1.1.1.7.39	Integer	false (2)
ibifFlowControl.40	.1.3.6.1.4.1.26138.8.35.1.1.1.7.40	Integer	false (2)
ibifFlowControl.41	.1.3.6.1.4.1.26138.8.35.1.1.1.7.41	Integer	false (2)
ibifFlowControl.42	.1.3.6.1.4.1.26138.8.35.1.1.1.7.42	Integer	false (2)
ibifFlowControl.43	.1.3.6.1.4.1.26138.8.35.1.1.1.7.43	Integer	false (2)
ibifFlowControl.44	.1.3.6.1.4.1.26138.8.35.1.1.1.7.44	Integer	false (2)
ibifFlowControl.45	.1.3.6.1.4.1.26138.8.35.1.1.1.7.45	Integer	false (2)
ibifFlowControl.46	.1.3.6.1.4.1.26138.8.35.1.1.1.7.46	Integer	false (2)
ibifFlowControl.47	.1.3.6.1.4.1.26138.8.35.1.1.1.7.47	Integer	false (2)
ibifFlowControl.48	.1.3.6.1.4.1.26138.8.35.1.1.1.7.48	Integer	false (2)
ibifFlowControl.49	.1.3.6.1.4.1.26138.8.35.1.1.1.7.49	Integer	false (2)
ibifFlowControl.50	.1.3.6.1.4.1.26138.8.35.1.1.1.7.50	Integer	false (2)
ibifFlowControl.51	.1.3.6.1.4.1.26138.8.35.1.1.1.7.51	Integer	false (2)
ibifFlowControl.52	.1.3.6.1.4.1.26138.8.35.1.1.1.7.52	Integer	false (2)
ibifFlowControl.53	.1.3.6.1.4.1.26138.8.35.1.1.1.7.53	Integer	false (2)
ibifFlowControl.54	.1.3.6.1.4.1.26138.8.35.1.1.1.7.54	Integer	false (2)
ibifXXBasePortIndex.1	.1.3.6.1.4.1.26138.8.35.1.1.1.10.1	Integer	1

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ibifXXBasePortIndex.2	.1.3.6.1.4.1.26138.8.35.1.1.1.10.2	Integer	2
ibifXXBasePortIndex.3	.1.3.6.1.4.1.26138.8.35.1.1.1.10.3	Integer	3
ibifXXBasePortIndex.4	.1.3.6.1.4.1.26138.8.35.1.1.1.10.4	Integer	4
ibifXXBasePortIndex.5	.1.3.6.1.4.1.26138.8.35.1.1.1.10.5	Integer	5
ibifXXBasePortIndex.6	.1.3.6.1.4.1.26138.8.35.1.1.1.10.6	Integer	6
ibifXXBasePortIndex.7	.1.3.6.1.4.1.26138.8.35.1.1.1.10.7	Integer	7
ibifXXBasePortIndex.8	.1.3.6.1.4.1.26138.8.35.1.1.1.10.8	Integer	8
ibifXXBasePortIndex.9	.1.3.6.1.4.1.26138.8.35.1.1.1.10.9	Integer	9
ibifXXBasePortIndex.10	.1.3.6.1.4.1.26138.8.35.1.1.1.10.10	Integer	10
ibifXXBasePortIndex.11	.1.3.6.1.4.1.26138.8.35.1.1.1.10.11	Integer	11
ibifXXBasePortIndex.12	.1.3.6.1.4.1.26138.8.35.1.1.1.10.12	Integer	12
ibifXXBasePortIndex.13	.1.3.6.1.4.1.26138.8.35.1.1.1.10.13	Integer	13
ibifXXBasePortIndex.14	.1.3.6.1.4.1.26138.8.35.1.1.1.10.14	Integer	14
ibifXXBasePortIndex.15	.1.3.6.1.4.1.26138.8.35.1.1.1.10.15	Integer	15
ibifXXBasePortIndex.16	.1.3.6.1.4.1.26138.8.35.1.1.1.10.16	Integer	16
ibifXXBasePortIndex.17	.1.3.6.1.4.1.26138.8.35.1.1.1.10.17	Integer	17
ibifXXBasePortIndex.18	.1.3.6.1.4.1.26138.8.35.1.1.1.10.18	Integer	18
ibifXXBasePortIndex.19	.1.3.6.1.4.1.26138.8.35.1.1.1.10.19	Integer	19
ibifXXBasePortIndex.20	.1.3.6.1.4.1.26138.8.35.1.1.1.10.20	Integer	20
ibifXXBasePortIndex.21	.1.3.6.1.4.1.26138.8.35.1.1.1.10.21	Integer	21
ibifXXBasePortIndex.22	.1.3.6.1.4.1.26138.8.35.1.1.1.10.22	Integer	22
ibifXXBasePortIndex.23	.1.3.6.1.4.1.26138.8.35.1.1.1.10.23	Integer	23
ibifXXBasePortIndex.24	.1.3.6.1.4.1.26138.8.35.1.1.1.10.24	Integer	24
ibifXXBasePortIndex.25	.1.3.6.1.4.1.26138.8.35.1.1.1.10.25	Integer	25
ibifXXBasePortIndex.26	.1.3.6.1.4.1.26138.8.35.1.1.1.10.26	Integer	26
ibifXXBasePortIndex.27	.1.3.6.1.4.1.26138.8.35.1.1.1.10.27	Integer	27
ibifXXBasePortIndex.28	.1.3.6.1.4.1.26138.8.35.1.1.1.10.28	Integer	28
ibifXXBasePortIndex.29	.1.3.6.1.4.1.26138.8.35.1.1.1.10.29	Integer	29
ibifXXBasePortIndex.30	.1.3.6.1.4.1.26138.8.35.1.1.1.10.30	Integer	30
ibifXXBasePortIndex.31	.1.3.6.1.4.1.26138.8.35.1.1.1.10.31	Integer	31
ibifXXBasePortIndex.32	.1.3.6.1.4.1.26138.8.35.1.1.1.10.32	Integer	32
ibifXXBasePortIndex.33	.1.3.6.1.4.1.26138.8.35.1.1.1.10.33	Integer	33
ibifXXBasePortIndex.34	.1.3.6.1.4.1.26138.8.35.1.1.1.10.34	Integer	34
ibifXXBasePortIndex.35	.1.3.6.1.4.1.26138.8.35.1.1.1.10.35	Integer	35
ibifXXBasePortIndex.36	.1.3.6.1.4.1.26138.8.35.1.1.1.10.36	Integer	36
ibifXXBasePortIndex.37	.1.3.6.1.4.1.26138.8.35.1.1.1.10.37	Integer	37
ibifXXBasePortIndex.38	.1.3.6.1.4.1.26138.8.35.1.1.1.10.38	Integer	38
ibifXXBasePortIndex.39	.1.3.6.1.4.1.26138.8.35.1.1.1.10.39	Integer	39
ibifXXBasePortIndex.40	.1.3.6.1.4.1.26138.8.35.1.1.1.10.40	Integer	40
ibifXXBasePortIndex.41	.1.3.6.1.4.1.26138.8.35.1.1.1.10.41	Integer	41
ibifXXBasePortIndex.42	.1.3.6.1.4.1.26138.8.35.1.1.1.10.42	Integer	42
ibifXXBasePortIndex.43	.1.3.6.1.4.1.26138.8.35.1.1.1.10.43	Integer	43
ibifXXBasePortIndex.44	.1.3.6.1.4.1.26138.8.35.1.1.1.10.44	Integer	44

Name	OID	Value Type	Value Example
ibifXXBasePortIndex.45	.1.3.6.1.4.1.26138.8.35.1.1.1.10.45	Integer	45
ibifXXBasePortIndex.46	.1.3.6.1.4.1.26138.8.35.1.1.1.10.46	Integer	46
ibifXXBasePortIndex.47	.1.3.6.1.4.1.26138.8.35.1.1.1.10.47	Integer	47
ibifXXBasePortIndex.48	.1.3.6.1.4.1.26138.8.35.1.1.1.10.48	Integer	48
ibifXXBasePortIndex.49	.1.3.6.1.4.1.26138.8.35.1.1.1.10.49	Integer	49
ibifXXBasePortIndex.50	.1.3.6.1.4.1.26138.8.35.1.1.1.10.50	Integer	50
ibifXXBasePortIndex.51	.1.3.6.1.4.1.26138.8.35.1.1.1.10.51	Integer	51
ibifXXBasePortIndex.52	.1.3.6.1.4.1.26138.8.35.1.1.1.10.52	Integer	52
ibifXXBasePortIndex.53	.1.3.6.1.4.1.26138.8.35.1.1.1.10.53	Integer	53
ibifXXBasePortIndex.54	.1.3.6.1.4.1.26138.8.35.1.1.1.10.54	Integer	54
ibifXXDevPortIndex.1	.1.3.6.1.4.1.26138.8.35.1.1.1.11.1	Integer	1
ibifXXDevPortIndex.2	.1.3.6.1.4.1.26138.8.35.1.1.1.11.2	Integer	2
ibifXXDevPortIndex.3	.1.3.6.1.4.1.26138.8.35.1.1.1.11.3	Integer	3
ibifXXDevPortIndex.4	.1.3.6.1.4.1.26138.8.35.1.1.1.11.4	Integer	4
ibifXXDevPortIndex.5	.1.3.6.1.4.1.26138.8.35.1.1.1.11.5	Integer	5
ibifXXDevPortIndex.6	.1.3.6.1.4.1.26138.8.35.1.1.1.11.6	Integer	6
ibifXXDevPortIndex.7	.1.3.6.1.4.1.26138.8.35.1.1.1.11.7	Integer	7
ibifXXDevPortIndex.8	.1.3.6.1.4.1.26138.8.35.1.1.1.11.8	Integer	8
ibifXXDevPortIndex.9	.1.3.6.1.4.1.26138.8.35.1.1.1.11.9	Integer	9
ibifXXDevPortIndex.10	.1.3.6.1.4.1.26138.8.35.1.1.1.11.10	Integer	10
ibifXXDevPortIndex.11	.1.3.6.1.4.1.26138.8.35.1.1.1.11.11	Integer	11
ibifXXDevPortIndex.12	.1.3.6.1.4.1.26138.8.35.1.1.1.11.12	Integer	12
ibifXXDevPortIndex.13	.1.3.6.1.4.1.26138.8.35.1.1.1.11.13	Integer	13
ibifXXDevPortIndex.14	.1.3.6.1.4.1.26138.8.35.1.1.1.11.14	Integer	14
ibifXXDevPortIndex.15	.1.3.6.1.4.1.26138.8.35.1.1.1.11.15	Integer	15
ibifXXDevPortIndex.16	.1.3.6.1.4.1.26138.8.35.1.1.1.11.16	Integer	16
ibifXXDevPortIndex.17	.1.3.6.1.4.1.26138.8.35.1.1.1.11.17	Integer	17
ibifXXDevPortIndex.18	.1.3.6.1.4.1.26138.8.35.1.1.1.11.18	Integer	18
ibifXXDevPortIndex.19	.1.3.6.1.4.1.26138.8.35.1.1.1.11.19	Integer	19
ibifXXDevPortIndex.20	.1.3.6.1.4.1.26138.8.35.1.1.1.11.20	Integer	20
ibifXXDevPortIndex.21	.1.3.6.1.4.1.26138.8.35.1.1.1.11.21	Integer	21
ibifXXDevPortIndex.22	.1.3.6.1.4.1.26138.8.35.1.1.1.11.22	Integer	22
ibifXXDevPortIndex.23	.1.3.6.1.4.1.26138.8.35.1.1.1.11.23	Integer	23
ibifXXDevPortIndex.24	.1.3.6.1.4.1.26138.8.35.1.1.1.11.24	Integer	24
ibifXXDevPortIndex.25	.1.3.6.1.4.1.26138.8.35.1.1.1.11.25	Integer	25
ibifXXDevPortIndex.26	.1.3.6.1.4.1.26138.8.35.1.1.1.11.26	Integer	26
ibifXXDevPortIndex.27	.1.3.6.1.4.1.26138.8.35.1.1.1.11.27	Integer	27
ibifXXDevPortIndex.28	.1.3.6.1.4.1.26138.8.35.1.1.1.11.28	Integer	28
ibifXXDevPortIndex.29	.1.3.6.1.4.1.26138.8.35.1.1.1.11.29	Integer	29
ibifXXDevPortIndex.30	.1.3.6.1.4.1.26138.8.35.1.1.1.11.30	Integer	30
ibifXXDevPortIndex.31	.1.3.6.1.4.1.26138.8.35.1.1.1.11.31	Integer	31
ibifXXDevPortIndex.32	.1.3.6.1.4.1.26138.8.35.1.1.1.11.32	Integer	32
ibifXXDevPortIndex.33	.1.3.6.1.4.1.26138.8.35.1.1.1.11.33	Integer	33

Name	OID	Value Type	Value Example
ibifXXDevPortIndex.34	.1.3.6.1.4.1.26138.8.35.1.1.1.11.34	Integer	34
ibifXXDevPortIndex.35	.1.3.6.1.4.1.26138.8.35.1.1.1.11.35	Integer	35
ibifXXDevPortIndex.36	.1.3.6.1.4.1.26138.8.35.1.1.1.11.36	Integer	36
ibifXXDevPortIndex.37	.1.3.6.1.4.1.26138.8.35.1.1.1.11.37	Integer	37
ibifXXDevPortIndex.38	.1.3.6.1.4.1.26138.8.35.1.1.1.11.38	Integer	38
ibifXXDevPortIndex.39	.1.3.6.1.4.1.26138.8.35.1.1.1.11.39	Integer	39
ibifXXDevPortIndex.40	.1.3.6.1.4.1.26138.8.35.1.1.1.11.40	Integer	40
ibifXXDevPortIndex.41	.1.3.6.1.4.1.26138.8.35.1.1.1.11.41	Integer	41
ibifXXDevPortIndex.42	.1.3.6.1.4.1.26138.8.35.1.1.1.11.42	Integer	42
ibifXXDevPortIndex.43	.1.3.6.1.4.1.26138.8.35.1.1.1.11.43	Integer	43
ibifXXDevPortIndex.44	.1.3.6.1.4.1.26138.8.35.1.1.1.11.44	Integer	44
ibifXXDevPortIndex.45	.1.3.6.1.4.1.26138.8.35.1.1.1.11.45	Integer	45
ibifXXDevPortIndex.46	.1.3.6.1.4.1.26138.8.35.1.1.1.11.46	Integer	46
ibifXXDevPortIndex.47	.1.3.6.1.4.1.26138.8.35.1.1.1.11.47	Integer	47
ibifXXDevPortIndex.48	.1.3.6.1.4.1.26138.8.35.1.1.1.11.48	Integer	48
ibifXXDevPortIndex.49	.1.3.6.1.4.1.26138.8.35.1.1.1.11.49	Integer	49
ibifXXDevPortIndex.50	.1.3.6.1.4.1.26138.8.35.1.1.1.11.50	Integer	50
ibifXXDevPortIndex.51	.1.3.6.1.4.1.26138.8.35.1.1.1.11.51	Integer	51
ibifXXDevPortIndex.52	.1.3.6.1.4.1.26138.8.35.1.1.1.11.52	Integer	52
ibifXXDevPortIndex.53	.1.3.6.1.4.1.26138.8.35.1.1.1.11.53	Integer	53
ibifXXDevPortIndex.54	.1.3.6.1.4.1.26138.8.35.1.1.1.11.54	Integer	54
ibifPpsMcastControl.1	.1.3.6.1.4.1.26138.8.35.1.1.1.12.1	Integer	1488100
ibifPpsMcastControl.2	.1.3.6.1.4.1.26138.8.35.1.1.1.12.2	Integer	1488100
ibifPpsMcastControl.3	.1.3.6.1.4.1.26138.8.35.1.1.1.12.3	Integer	1488100
ibifPpsMcastControl.4	.1.3.6.1.4.1.26138.8.35.1.1.1.12.4	Integer	1488100
ibifPpsMcastControl.5	.1.3.6.1.4.1.26138.8.35.1.1.1.12.5	Integer	1488100
ibifPpsMcastControl.6	.1.3.6.1.4.1.26138.8.35.1.1.1.12.6	Integer	1488100
ibifPpsMcastControl.7	.1.3.6.1.4.1.26138.8.35.1.1.1.12.7	Integer	1488100
ibifPpsMcastControl.8	.1.3.6.1.4.1.26138.8.35.1.1.1.12.8	Integer	1488100
ibifPpsMcastControl.9	.1.3.6.1.4.1.26138.8.35.1.1.1.12.9	Integer	1488100
ibifPpsMcastControl.10	.1.3.6.1.4.1.26138.8.35.1.1.1.12.10	Integer	1488100
ibifPpsMcastControl.11	.1.3.6.1.4.1.26138.8.35.1.1.1.12.11	Integer	1488100
ibifPpsMcastControl.12	.1.3.6.1.4.1.26138.8.35.1.1.1.12.12	Integer	1488100
ibifPpsMcastControl.13	.1.3.6.1.4.1.26138.8.35.1.1.1.12.13	Integer	1488100
ibifPpsMcastControl.14	.1.3.6.1.4.1.26138.8.35.1.1.1.12.14	Integer	1488100
ibifPpsMcastControl.15	.1.3.6.1.4.1.26138.8.35.1.1.1.12.15	Integer	1488100
ibifPpsMcastControl.16	.1.3.6.1.4.1.26138.8.35.1.1.1.12.16	Integer	1488100
ibifPpsMcastControl.17	.1.3.6.1.4.1.26138.8.35.1.1.1.12.17	Integer	1488100
ibifPpsMcastControl.18	.1.3.6.1.4.1.26138.8.35.1.1.1.12.18	Integer	1488100
ibifPpsMcastControl.19	.1.3.6.1.4.1.26138.8.35.1.1.1.12.19	Integer	1488100
ibifPpsMcastControl.20	.1.3.6.1.4.1.26138.8.35.1.1.1.12.20	Integer	1488100
ibifPpsMcastControl.21	.1.3.6.1.4.1.26138.8.35.1.1.1.12.21	Integer	1488100
ibifPpsMcastControl.22	.1.3.6.1.4.1.26138.8.35.1.1.1.12.22	Integer	1488100

Name	OID	Value Type	Value Example
ibifPpsMcastControl.23	.1.3.6.1.4.1.26138.8.35.1.1.1.12.23	Integer	1488100
ibifPpsMcastControl.24	.1.3.6.1.4.1.26138.8.35.1.1.1.12.24	Integer	1488100
ibifPpsMcastControl.25	.1.3.6.1.4.1.26138.8.35.1.1.1.12.25	Integer	1488100
ibifPpsMcastControl.26	.1.3.6.1.4.1.26138.8.35.1.1.1.12.26	Integer	1488100
ibifPpsMcastControl.27	.1.3.6.1.4.1.26138.8.35.1.1.1.12.27	Integer	1488100
ibifPpsMcastControl.28	.1.3.6.1.4.1.26138.8.35.1.1.1.12.28	Integer	1488100
ibifPpsMcastControl.29	.1.3.6.1.4.1.26138.8.35.1.1.1.12.29	Integer	1488100
ibifPpsMcastControl.30	.1.3.6.1.4.1.26138.8.35.1.1.1.12.30	Integer	1488100
ibifPpsMcastControl.31	.1.3.6.1.4.1.26138.8.35.1.1.1.12.31	Integer	1488100
ibifPpsMcastControl.32	.1.3.6.1.4.1.26138.8.35.1.1.1.12.32	Integer	1488100
ibifPpsMcastControl.33	.1.3.6.1.4.1.26138.8.35.1.1.1.12.33	Integer	1488100
ibifPpsMcastControl.34	.1.3.6.1.4.1.26138.8.35.1.1.1.12.34	Integer	1488100
ibifPpsMcastControl.35	.1.3.6.1.4.1.26138.8.35.1.1.1.12.35	Integer	1488100
ibifPpsMcastControl.36	.1.3.6.1.4.1.26138.8.35.1.1.1.12.36	Integer	1488100
ibifPpsMcastControl.37	.1.3.6.1.4.1.26138.8.35.1.1.1.12.37	Integer	1488100
ibifPpsMcastControl.38	.1.3.6.1.4.1.26138.8.35.1.1.1.12.38	Integer	1488100
ibifPpsMcastControl.39	.1.3.6.1.4.1.26138.8.35.1.1.1.12.39	Integer	1488100
ibifPpsMcastControl.40	.1.3.6.1.4.1.26138.8.35.1.1.1.12.40	Integer	1488100
ibifPpsMcastControl.41	.1.3.6.1.4.1.26138.8.35.1.1.1.12.41	Integer	1488100
ibifPpsMcastControl.42	.1.3.6.1.4.1.26138.8.35.1.1.1.12.42	Integer	1488100
ibifPpsMcastControl.43	.1.3.6.1.4.1.26138.8.35.1.1.1.12.43	Integer	1488100
ibifPpsMcastControl.44	.1.3.6.1.4.1.26138.8.35.1.1.1.12.44	Integer	1488100
ibifPpsMcastControl.45	.1.3.6.1.4.1.26138.8.35.1.1.1.12.45	Integer	1488100
ibifPpsMcastControl.46	.1.3.6.1.4.1.26138.8.35.1.1.1.12.46	Integer	1488100
ibifPpsMcastControl.47	.1.3.6.1.4.1.26138.8.35.1.1.1.12.47	Integer	1488100
ibifPpsMcastControl.48	.1.3.6.1.4.1.26138.8.35.1.1.1.12.48	Integer	1488100
ibifPpsMcastControl.49	.1.3.6.1.4.1.26138.8.35.1.1.1.12.49	Integer	14881000
ibifPpsMcastControl.50	.1.3.6.1.4.1.26138.8.35.1.1.1.12.50	Integer	14881000
ibifPpsMcastControl.51	.1.3.6.1.4.1.26138.8.35.1.1.1.12.51	Integer	14881000
ibifPpsMcastControl.52	.1.3.6.1.4.1.26138.8.35.1.1.1.12.52	Integer	14881000
ibifPpsMcastControl.53	.1.3.6.1.4.1.26138.8.35.1.1.1.12.53	Integer	14881000
ibifPpsMcastControl.54	.1.3.6.1.4.1.26138.8.35.1.1.1.12.54	Integer	14881000
ibifUniSuppression.1	.1.3.6.1.4.1.26138.8.35.1.1.1.18.1	Integer	100
ibifUniSuppression.2	.1.3.6.1.4.1.26138.8.35.1.1.1.18.2	Integer	100
ibifUniSuppression.3	.1.3.6.1.4.1.26138.8.35.1.1.1.18.3	Integer	100
ibifUniSuppression.4	.1.3.6.1.4.1.26138.8.35.1.1.1.18.4	Integer	100
ibifUniSuppression.5	.1.3.6.1.4.1.26138.8.35.1.1.1.18.5	Integer	100
ibifUniSuppression.6	.1.3.6.1.4.1.26138.8.35.1.1.1.18.6	Integer	100
ibifUniSuppression.7	.1.3.6.1.4.1.26138.8.35.1.1.1.18.7	Integer	100
ibifUniSuppression.8	.1.3.6.1.4.1.26138.8.35.1.1.1.18.8	Integer	100
ibifUniSuppression.9	.1.3.6.1.4.1.26138.8.35.1.1.1.18.9	Integer	100
ibifUniSuppression.10	.1.3.6.1.4.1.26138.8.35.1.1.1.18.10	Integer	100
ibifUniSuppression.11	.1.3.6.1.4.1.26138.8.35.1.1.1.18.11	Integer	100



Name	OID	Value Type	Value Example
ibifUniSuppression.12	.1.3.6.1.4.1.26138.8.35.1.1.1.18.12	Integer	100
ibifUniSuppression.13	.1.3.6.1.4.1.26138.8.35.1.1.1.18.13	Integer	100
ibifUniSuppression.14	.1.3.6.1.4.1.26138.8.35.1.1.1.18.14	Integer	100
ibifUniSuppression.15	.1.3.6.1.4.1.26138.8.35.1.1.1.18.15	Integer	100
ibifUniSuppression.16	.1.3.6.1.4.1.26138.8.35.1.1.1.18.16	Integer	100
ibifUniSuppression.17	.1.3.6.1.4.1.26138.8.35.1.1.1.18.17	Integer	100
ibifUniSuppression.18	.1.3.6.1.4.1.26138.8.35.1.1.1.18.18	Integer	100
ibifUniSuppression.19	.1.3.6.1.4.1.26138.8.35.1.1.1.18.19	Integer	100
ibifUniSuppression.20	.1.3.6.1.4.1.26138.8.35.1.1.1.18.20	Integer	100
ibifUniSuppression.21	.1.3.6.1.4.1.26138.8.35.1.1.1.18.21	Integer	100
ibifUniSuppression.22	.1.3.6.1.4.1.26138.8.35.1.1.1.18.22	Integer	100
ibifUniSuppression.23	.1.3.6.1.4.1.26138.8.35.1.1.1.18.23	Integer	100
ibifUniSuppression.24	.1.3.6.1.4.1.26138.8.35.1.1.1.18.24	Integer	100
ibifUniSuppression.25	.1.3.6.1.4.1.26138.8.35.1.1.1.18.25	Integer	100
ibifUniSuppression.26	.1.3.6.1.4.1.26138.8.35.1.1.1.18.26	Integer	100
ibifUniSuppression.27	.1.3.6.1.4.1.26138.8.35.1.1.1.18.27	Integer	100
ibifUniSuppression.28	.1.3.6.1.4.1.26138.8.35.1.1.1.18.28	Integer	100
ibifUniSuppression.29	.1.3.6.1.4.1.26138.8.35.1.1.1.18.29	Integer	100
ibifUniSuppression.30	.1.3.6.1.4.1.26138.8.35.1.1.1.18.30	Integer	100
ibifUniSuppression.31	.1.3.6.1.4.1.26138.8.35.1.1.1.18.31	Integer	100
ibifUniSuppression.32	.1.3.6.1.4.1.26138.8.35.1.1.1.18.32	Integer	100
ibifUniSuppression.33	.1.3.6.1.4.1.26138.8.35.1.1.1.18.33	Integer	100
ibifUniSuppression.34	.1.3.6.1.4.1.26138.8.35.1.1.1.18.34	Integer	100
ibifUniSuppression.35	.1.3.6.1.4.1.26138.8.35.1.1.1.18.35	Integer	100
ibifUniSuppression.36	.1.3.6.1.4.1.26138.8.35.1.1.1.18.36	Integer	100
ibifUniSuppression.37	.1.3.6.1.4.1.26138.8.35.1.1.1.18.37	Integer	100
ibifUniSuppression.38	.1.3.6.1.4.1.26138.8.35.1.1.1.18.38	Integer	100
ibifUniSuppression.39	.1.3.6.1.4.1.26138.8.35.1.1.1.18.39	Integer	100
ibifUniSuppression.40	.1.3.6.1.4.1.26138.8.35.1.1.1.18.40	Integer	100
ibifUniSuppression.41	.1.3.6.1.4.1.26138.8.35.1.1.1.18.41	Integer	100
ibifUniSuppression.42	.1.3.6.1.4.1.26138.8.35.1.1.1.18.42	Integer	100
ibifUniSuppression.43	.1.3.6.1.4.1.26138.8.35.1.1.1.18.43	Integer	100
ibifUniSuppression.44	.1.3.6.1.4.1.26138.8.35.1.1.1.18.44	Integer	100
ibifUniSuppression.45	.1.3.6.1.4.1.26138.8.35.1.1.1.18.45	Integer	100
ibifUniSuppression.46	.1.3.6.1.4.1.26138.8.35.1.1.1.18.46	Integer	100
ibifUniSuppression.47	.1.3.6.1.4.1.26138.8.35.1.1.1.18.47	Integer	100
ibifUniSuppression.48	.1.3.6.1.4.1.26138.8.35.1.1.1.18.48	Integer	100
ibifUniSuppression.49	.1.3.6.1.4.1.26138.8.35.1.1.1.18.49	Integer	100
ibifUniSuppression.50	.1.3.6.1.4.1.26138.8.35.1.1.1.18.50	Integer	100
ibifUniSuppression.51	.1.3.6.1.4.1.26138.8.35.1.1.1.18.51	Integer	100
ibifUniSuppression.52	.1.3.6.1.4.1.26138.8.35.1.1.1.18.52	Integer	100
ibifUniSuppression.53	.1.3.6.1.4.1.26138.8.35.1.1.1.18.53	Integer	100
ibifUniSuppression.54	.1.3.6.1.4.1.26138.8.35.1.1.1.18.54	Integer	100



<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ibifPpsUniSuppression.1	.1.3.6.1.4.1.26138.8.35.1.1.1.19.1	Integer	1488100
ibifPpsUniSuppression.2	.1.3.6.1.4.1.26138.8.35.1.1.1.19.2	Integer	1488100
ibifPpsUniSuppression.3	.1.3.6.1.4.1.26138.8.35.1.1.1.19.3	Integer	1488100
ibifPpsUniSuppression.4	.1.3.6.1.4.1.26138.8.35.1.1.1.19.4	Integer	1488100
ibifPpsUniSuppression.5	.1.3.6.1.4.1.26138.8.35.1.1.1.19.5	Integer	1488100
ibifPpsUniSuppression.6	.1.3.6.1.4.1.26138.8.35.1.1.1.19.6	Integer	1488100
ibifPpsUniSuppression.7	.1.3.6.1.4.1.26138.8.35.1.1.1.19.7	Integer	1488100
ibifPpsUniSuppression.8	.1.3.6.1.4.1.26138.8.35.1.1.1.19.8	Integer	1488100
ibifPpsUniSuppression.9	.1.3.6.1.4.1.26138.8.35.1.1.1.19.9	Integer	1488100
ibifPpsUniSuppression.10	.1.3.6.1.4.1.26138.8.35.1.1.1.19.10	Integer	1488100
ibifPpsUniSuppression.11	.1.3.6.1.4.1.26138.8.35.1.1.1.19.11	Integer	1488100
ibifPpsUniSuppression.12	.1.3.6.1.4.1.26138.8.35.1.1.1.19.12	Integer	1488100
ibifPpsUniSuppression.13	.1.3.6.1.4.1.26138.8.35.1.1.1.19.13	Integer	1488100
ibifPpsUniSuppression.14	.1.3.6.1.4.1.26138.8.35.1.1.1.19.14	Integer	1488100
ibifPpsUniSuppression.15	.1.3.6.1.4.1.26138.8.35.1.1.1.19.15	Integer	1488100
ibifPpsUniSuppression.16	.1.3.6.1.4.1.26138.8.35.1.1.1.19.16	Integer	1488100
ibifPpsUniSuppression.17	.1.3.6.1.4.1.26138.8.35.1.1.1.19.17	Integer	1488100
ibifPpsUniSuppression.18	.1.3.6.1.4.1.26138.8.35.1.1.1.19.18	Integer	1488100
ibifPpsUniSuppression.19	.1.3.6.1.4.1.26138.8.35.1.1.1.19.19	Integer	1488100
ibifPpsUniSuppression.20	.1.3.6.1.4.1.26138.8.35.1.1.1.19.20	Integer	1488100
ibifPpsUniSuppression.21	.1.3.6.1.4.1.26138.8.35.1.1.1.19.21	Integer	1488100
ibifPpsUniSuppression.22	.1.3.6.1.4.1.26138.8.35.1.1.1.19.22	Integer	1488100
ibifPpsUniSuppression.23	.1.3.6.1.4.1.26138.8.35.1.1.1.19.23	Integer	1488100
ibifPpsUniSuppression.24	.1.3.6.1.4.1.26138.8.35.1.1.1.19.24	Integer	1488100
ibifPpsUniSuppression.25	.1.3.6.1.4.1.26138.8.35.1.1.1.19.25	Integer	1488100
ibifPpsUniSuppression.26	.1.3.6.1.4.1.26138.8.35.1.1.1.19.26	Integer	1488100
ibifPpsUniSuppression.27	.1.3.6.1.4.1.26138.8.35.1.1.1.19.27	Integer	1488100
ibifPpsUniSuppression.28	.1.3.6.1.4.1.26138.8.35.1.1.1.19.28	Integer	1488100
ibifPpsUniSuppression.29	.1.3.6.1.4.1.26138.8.35.1.1.1.19.29	Integer	1488100
ibifPpsUniSuppression.30	.1.3.6.1.4.1.26138.8.35.1.1.1.19.30	Integer	1488100
ibifPpsUniSuppression.31	.1.3.6.1.4.1.26138.8.35.1.1.1.19.31	Integer	1488100
ibifPpsUniSuppression.32	.1.3.6.1.4.1.26138.8.35.1.1.1.19.32	Integer	1488100
ibifPpsUniSuppression.33	.1.3.6.1.4.1.26138.8.35.1.1.1.19.33	Integer	1488100
ibifPpsUniSuppression.34	.1.3.6.1.4.1.26138.8.35.1.1.1.19.34	Integer	1488100
ibifPpsUniSuppression.35	.1.3.6.1.4.1.26138.8.35.1.1.1.19.35	Integer	1488100
ibifPpsUniSuppression.36	.1.3.6.1.4.1.26138.8.35.1.1.1.19.36	Integer	1488100
ibifPpsUniSuppression.37	.1.3.6.1.4.1.26138.8.35.1.1.1.19.37	Integer	1488100
ibifPpsUniSuppression.38	.1.3.6.1.4.1.26138.8.35.1.1.1.19.38	Integer	1488100
ibifPpsUniSuppression.39	.1.3.6.1.4.1.26138.8.35.1.1.1.19.39	Integer	1488100
ibifPpsUniSuppression.40	.1.3.6.1.4.1.26138.8.35.1.1.1.19.40	Integer	1488100
ibifPpsUniSuppression.41	.1.3.6.1.4.1.26138.8.35.1.1.1.19.41	Integer	1488100
ibifPpsUniSuppression.42	.1.3.6.1.4.1.26138.8.35.1.1.1.19.42	Integer	1488100
ibifPpsUniSuppression.43	.1.3.6.1.4.1.26138.8.35.1.1.1.19.43	Integer	1488100

Name	OID	Value Type	Value Example
ibifPpsUniSuppression.44	.1.3.6.1.4.1.26138.8.35.1.1.1.19.44	Integer	1488100
ibifPpsUniSuppression.45	.1.3.6.1.4.1.26138.8.35.1.1.1.19.45	Integer	1488100
ibifPpsUniSuppression.46	.1.3.6.1.4.1.26138.8.35.1.1.1.19.46	Integer	1488100
ibifPpsUniSuppression.47	.1.3.6.1.4.1.26138.8.35.1.1.1.19.47	Integer	1488100
ibifPpsUniSuppression.48	.1.3.6.1.4.1.26138.8.35.1.1.1.19.48	Integer	1488100
ibifPpsUniSuppression.49	.1.3.6.1.4.1.26138.8.35.1.1.1.19.49	Integer	14881000
ibifPpsUniSuppression.50	.1.3.6.1.4.1.26138.8.35.1.1.1.19.50	Integer	14881000
ibifPpsUniSuppression.51	.1.3.6.1.4.1.26138.8.35.1.1.1.19.51	Integer	14881000
ibifPpsUniSuppression.52	.1.3.6.1.4.1.26138.8.35.1.1.1.19.52	Integer	14881000
ibifPpsUniSuppression.53	.1.3.6.1.4.1.26138.8.35.1.1.1.19.53	Integer	14881000
ibifPpsUniSuppression.54	.1.3.6.1.4.1.26138.8.35.1.1.1.19.54	Integer	14881000
ibifMulSuppression.1	.1.3.6.1.4.1.26138.8.35.1.1.1.20.1	Integer	100
ibifMulSuppression.2	.1.3.6.1.4.1.26138.8.35.1.1.1.20.2	Integer	100
ibifMulSuppression.3	.1.3.6.1.4.1.26138.8.35.1.1.1.20.3	Integer	100
ibifMulSuppression.4	.1.3.6.1.4.1.26138.8.35.1.1.1.20.4	Integer	100
ibifMulSuppression.5	.1.3.6.1.4.1.26138.8.35.1.1.1.20.5	Integer	100
ibifMulSuppression.6	.1.3.6.1.4.1.26138.8.35.1.1.1.20.6	Integer	100
ibifMulSuppression.7	.1.3.6.1.4.1.26138.8.35.1.1.1.20.7	Integer	100
ibifMulSuppression.8	.1.3.6.1.4.1.26138.8.35.1.1.1.20.8	Integer	100
ibifMulSuppression.9	.1.3.6.1.4.1.26138.8.35.1.1.1.20.9	Integer	100
ibifMulSuppression.10	.1.3.6.1.4.1.26138.8.35.1.1.1.20.10	Integer	100
ibifMulSuppression.11	.1.3.6.1.4.1.26138.8.35.1.1.1.20.11	Integer	100
ibifMulSuppression.12	.1.3.6.1.4.1.26138.8.35.1.1.1.20.12	Integer	100
ibifMulSuppression.13	.1.3.6.1.4.1.26138.8.35.1.1.1.20.13	Integer	100
ibifMulSuppression.14	.1.3.6.1.4.1.26138.8.35.1.1.1.20.14	Integer	100
ibifMulSuppression.15	.1.3.6.1.4.1.26138.8.35.1.1.1.20.15	Integer	100
ibifMulSuppression.16	.1.3.6.1.4.1.26138.8.35.1.1.1.20.16	Integer	100
ibifMulSuppression.17	.1.3.6.1.4.1.26138.8.35.1.1.1.20.17	Integer	100
ibifMulSuppression.18	.1.3.6.1.4.1.26138.8.35.1.1.1.20.18	Integer	100
ibifMulSuppression.19	.1.3.6.1.4.1.26138.8.35.1.1.1.20.19	Integer	100
ibifMulSuppression.20	.1.3.6.1.4.1.26138.8.35.1.1.1.20.20	Integer	100
ibifMulSuppression.21	.1.3.6.1.4.1.26138.8.35.1.1.1.20.21	Integer	100
ibifMulSuppression.22	.1.3.6.1.4.1.26138.8.35.1.1.1.20.22	Integer	100
ibifMulSuppression.23	.1.3.6.1.4.1.26138.8.35.1.1.1.20.23	Integer	100
ibifMulSuppression.24	.1.3.6.1.4.1.26138.8.35.1.1.1.20.24	Integer	100
ibifMulSuppression.25	.1.3.6.1.4.1.26138.8.35.1.1.1.20.25	Integer	100
ibifMulSuppression.26	.1.3.6.1.4.1.26138.8.35.1.1.1.20.26	Integer	100
ibifMulSuppression.27	.1.3.6.1.4.1.26138.8.35.1.1.1.20.27	Integer	100
ibifMulSuppression.28	.1.3.6.1.4.1.26138.8.35.1.1.1.20.28	Integer	100
ibifMulSuppression.29	.1.3.6.1.4.1.26138.8.35.1.1.1.20.29	Integer	100
ibifMulSuppression.30	.1.3.6.1.4.1.26138.8.35.1.1.1.20.30	Integer	100
ibifMulSuppression.31	.1.3.6.1.4.1.26138.8.35.1.1.1.20.31	Integer	100
ibifMulSuppression.32	.1.3.6.1.4.1.26138.8.35.1.1.1.20.32	Integer	100

Name	OID	Value Type	Value Example
ibifMulSuppression.33	.1.3.6.1.4.1.26138.8.35.1.1.1.20.33	Integer	100
ibifMulSuppression.34	.1.3.6.1.4.1.26138.8.35.1.1.1.20.34	Integer	100
ibifMulSuppression.35	.1.3.6.1.4.1.26138.8.35.1.1.1.20.35	Integer	100
ibifMulSuppression.36	.1.3.6.1.4.1.26138.8.35.1.1.1.20.36	Integer	100
ibifMulSuppression.37	.1.3.6.1.4.1.26138.8.35.1.1.1.20.37	Integer	100
ibifMulSuppression.38	.1.3.6.1.4.1.26138.8.35.1.1.1.20.38	Integer	100
ibifMulSuppression.39	.1.3.6.1.4.1.26138.8.35.1.1.1.20.39	Integer	100
ibifMulSuppression.40	.1.3.6.1.4.1.26138.8.35.1.1.1.20.40	Integer	100
ibifMulSuppression.41	.1.3.6.1.4.1.26138.8.35.1.1.1.20.41	Integer	100
ibifMulSuppression.42	.1.3.6.1.4.1.26138.8.35.1.1.1.20.42	Integer	100
ibifMulSuppression.43	.1.3.6.1.4.1.26138.8.35.1.1.1.20.43	Integer	100
ibifMulSuppression.44	.1.3.6.1.4.1.26138.8.35.1.1.1.20.44	Integer	100
ibifMulSuppression.45	.1.3.6.1.4.1.26138.8.35.1.1.1.20.45	Integer	100
ibifMulSuppression.46	.1.3.6.1.4.1.26138.8.35.1.1.1.20.46	Integer	100
ibifMulSuppression.47	.1.3.6.1.4.1.26138.8.35.1.1.1.20.47	Integer	100
ibifMulSuppression.48	.1.3.6.1.4.1.26138.8.35.1.1.1.20.48	Integer	100
ibifMulSuppression.49	.1.3.6.1.4.1.26138.8.35.1.1.1.20.49	Integer	100
ibifMulSuppression.50	.1.3.6.1.4.1.26138.8.35.1.1.1.20.50	Integer	100
ibifMulSuppression.51	.1.3.6.1.4.1.26138.8.35.1.1.1.20.51	Integer	100
ibifMulSuppression.52	.1.3.6.1.4.1.26138.8.35.1.1.1.20.52	Integer	100
ibifMulSuppression.53	.1.3.6.1.4.1.26138.8.35.1.1.1.20.53	Integer	100
ibifMulSuppression.54	.1.3.6.1.4.1.26138.8.35.1.1.1.20.54	Integer	100
ibifPpsMulSuppression.1	.1.3.6.1.4.1.26138.8.35.1.1.1.21.1	Integer	1488100
ibifPpsMulSuppression.2	.1.3.6.1.4.1.26138.8.35.1.1.1.21.2	Integer	1488100
ibifPpsMulSuppression.3	.1.3.6.1.4.1.26138.8.35.1.1.1.21.3	Integer	1488100
ibifPpsMulSuppression.4	.1.3.6.1.4.1.26138.8.35.1.1.1.21.4	Integer	1488100
ibifPpsMulSuppression.5	.1.3.6.1.4.1.26138.8.35.1.1.1.21.5	Integer	1488100
ibifPpsMulSuppression.6	.1.3.6.1.4.1.26138.8.35.1.1.1.21.6	Integer	1488100
ibifPpsMulSuppression.7	.1.3.6.1.4.1.26138.8.35.1.1.1.21.7	Integer	1488100
ibifPpsMulSuppression.8	.1.3.6.1.4.1.26138.8.35.1.1.1.21.8	Integer	1488100
ibifPpsMulSuppression.9	.1.3.6.1.4.1.26138.8.35.1.1.1.21.9	Integer	1488100
ibifPpsMulSuppression.10	.1.3.6.1.4.1.26138.8.35.1.1.1.21.10	Integer	1488100
ibifPpsMulSuppression.11	.1.3.6.1.4.1.26138.8.35.1.1.1.21.11	Integer	1488100
ibifPpsMulSuppression.12	.1.3.6.1.4.1.26138.8.35.1.1.1.21.12	Integer	1488100
ibifPpsMulSuppression.13	.1.3.6.1.4.1.26138.8.35.1.1.1.21.13	Integer	1488100
ibifPpsMulSuppression.14	.1.3.6.1.4.1.26138.8.35.1.1.1.21.14	Integer	1488100
ibifPpsMulSuppression.15	.1.3.6.1.4.1.26138.8.35.1.1.1.21.15	Integer	1488100
ibifPpsMulSuppression.16	.1.3.6.1.4.1.26138.8.35.1.1.1.21.16	Integer	1488100
ibifPpsMulSuppression.17	.1.3.6.1.4.1.26138.8.35.1.1.1.21.17	Integer	1488100
ibifPpsMulSuppression.18	.1.3.6.1.4.1.26138.8.35.1.1.1.21.18	Integer	1488100
ibifPpsMulSuppression.19	.1.3.6.1.4.1.26138.8.35.1.1.1.21.19	Integer	1488100
ibifPpsMulSuppression.20	.1.3.6.1.4.1.26138.8.35.1.1.1.21.20	Integer	1488100
ibifPpsMulSuppression.21	.1.3.6.1.4.1.26138.8.35.1.1.1.21.21	Integer	1488100

Name	OID	Value Type	Value Example
ibifPpsMulSuppression.22	.1.3.6.1.4.1.26138.8.35.1.1.1.21.22	Integer	1488100
ibifPpsMulSuppression.23	.1.3.6.1.4.1.26138.8.35.1.1.1.21.23	Integer	1488100
ibifPpsMulSuppression.24	.1.3.6.1.4.1.26138.8.35.1.1.1.21.24	Integer	1488100
ibifPpsMulSuppression.25	.1.3.6.1.4.1.26138.8.35.1.1.1.21.25	Integer	1488100
ibifPpsMulSuppression.26	.1.3.6.1.4.1.26138.8.35.1.1.1.21.26	Integer	1488100
ibifPpsMulSuppression.27	.1.3.6.1.4.1.26138.8.35.1.1.1.21.27	Integer	1488100
ibifPpsMulSuppression.28	.1.3.6.1.4.1.26138.8.35.1.1.1.21.28	Integer	1488100
ibifPpsMulSuppression.29	.1.3.6.1.4.1.26138.8.35.1.1.1.21.29	Integer	1488100
ibifPpsMulSuppression.30	.1.3.6.1.4.1.26138.8.35.1.1.1.21.30	Integer	1488100
ibifPpsMulSuppression.31	.1.3.6.1.4.1.26138.8.35.1.1.1.21.31	Integer	1488100
ibifPpsMulSuppression.32	.1.3.6.1.4.1.26138.8.35.1.1.1.21.32	Integer	1488100
ibifPpsMulSuppression.33	.1.3.6.1.4.1.26138.8.35.1.1.1.21.33	Integer	1488100
ibifPpsMulSuppression.34	.1.3.6.1.4.1.26138.8.35.1.1.1.21.34	Integer	1488100
ibifPpsMulSuppression.35	.1.3.6.1.4.1.26138.8.35.1.1.1.21.35	Integer	1488100
ibifPpsMulSuppression.36	.1.3.6.1.4.1.26138.8.35.1.1.1.21.36	Integer	1488100
ibifPpsMulSuppression.37	.1.3.6.1.4.1.26138.8.35.1.1.1.21.37	Integer	1488100
ibifPpsMulSuppression.38	.1.3.6.1.4.1.26138.8.35.1.1.1.21.38	Integer	1488100
ibifPpsMulSuppression.39	.1.3.6.1.4.1.26138.8.35.1.1.1.21.39	Integer	1488100
ibifPpsMulSuppression.40	.1.3.6.1.4.1.26138.8.35.1.1.1.21.40	Integer	1488100
ibifPpsMulSuppression.41	.1.3.6.1.4.1.26138.8.35.1.1.1.21.41	Integer	1488100
ibifPpsMulSuppression.42	.1.3.6.1.4.1.26138.8.35.1.1.1.21.42	Integer	1488100
ibifPpsMulSuppression.43	.1.3.6.1.4.1.26138.8.35.1.1.1.21.43	Integer	1488100
ibifPpsMulSuppression.44	.1.3.6.1.4.1.26138.8.35.1.1.1.21.44	Integer	1488100
ibifPpsMulSuppression.45	.1.3.6.1.4.1.26138.8.35.1.1.1.21.45	Integer	1488100
ibifPpsMulSuppression.46	.1.3.6.1.4.1.26138.8.35.1.1.1.21.46	Integer	1488100
ibifPpsMulSuppression.47	.1.3.6.1.4.1.26138.8.35.1.1.1.21.47	Integer	1488100
ibifPpsMulSuppression.48	.1.3.6.1.4.1.26138.8.35.1.1.1.21.48	Integer	1488100
ibifPpsMulSuppression.49	.1.3.6.1.4.1.26138.8.35.1.1.1.21.49	Integer	14881000
ibifPpsMulSuppression.50	.1.3.6.1.4.1.26138.8.35.1.1.1.21.50	Integer	14881000
ibifPpsMulSuppression.51	.1.3.6.1.4.1.26138.8.35.1.1.1.21.51	Integer	14881000
ibifPpsMulSuppression.52	.1.3.6.1.4.1.26138.8.35.1.1.1.21.52	Integer	14881000
ibifPpsMulSuppression.53	.1.3.6.1.4.1.26138.8.35.1.1.1.21.53	Integer	14881000
ibifPpsMulSuppression.54	.1.3.6.1.4.1.26138.8.35.1.1.1.21.54	Integer	14881000
ibifMulSuppressionFlag.1	.1.3.6.1.4.1.26138.8.35.1.1.1.41.1	Integer	all (1)
ibifMulSuppressionFlag.2	.1.3.6.1.4.1.26138.8.35.1.1.1.41.2	Integer	all (1)
ibifMulSuppressionFlag.3	.1.3.6.1.4.1.26138.8.35.1.1.1.41.3	Integer	all (1)
ibifMulSuppressionFlag.4	.1.3.6.1.4.1.26138.8.35.1.1.1.41.4	Integer	all (1)
ibifMulSuppressionFlag.5	.1.3.6.1.4.1.26138.8.35.1.1.1.41.5	Integer	all (1)
ibifMulSuppressionFlag.6	.1.3.6.1.4.1.26138.8.35.1.1.1.41.6	Integer	all (1)
ibifMulSuppressionFlag.7	.1.3.6.1.4.1.26138.8.35.1.1.1.41.7	Integer	all (1)
ibifMulSuppressionFlag.8	.1.3.6.1.4.1.26138.8.35.1.1.1.41.8	Integer	all (1)
ibifMulSuppressionFlag.9	.1.3.6.1.4.1.26138.8.35.1.1.1.41.9	Integer	all (1)
ibifMulSuppressionFlag.10	.1.3.6.1.4.1.26138.8.35.1.1.1.41.10	Integer	all (1)





Name	OID	Value Type	Value Example
			00 00
ibifHybridUntaggedVlan-ListHigh.30	.1.3.6.1.4.1.26138.8.35.1.3.1.5.30	OctetString	0x00 00
ibdot1qVlanIndex.1	.1.3.6.1.4.1.26138.8.35.2.1.1.1.1.1	Integer	1
ibdot1qVlanName.1	.1.3.6.1.4.1.26138.8.35.2.1.1.1.2.1	OctetString	VLAN 0001
ibdot1qVlanPorts.1	.1.3.6.1.4.1.26138.8.35.2.1.1.1.3.1	OctetString	0xFF FF FF FF FF FF 3F
ibdot1qVlanType.1	.1.3.6.1.4.1.26138.8.35.2.1.1.1.4.1	Integer	common-vlan (2)
ibdot1qVlanMacFilter.1	.1.3.6.1.4.1.26138.8.35.2.1.1.1.5.1	Integer	false (2)
ibdot1qVlanMcastUnknown-Protos.1	.1.3.6.1.4.1.26138.8.35.2.1.1.1.6.1	Integer	false (2)
ibExistInterface.1	.1.3.6.1.4.1.26138.8.35.2.1.1.1.7.1	Integer	true (1)
ibVlanInterfaceIndex.1	.1.3.6.1.4.1.26138.8.35.2.1.1.1.8.1	Integer	1
ibdot1qVlanMacLearn.1	.1.3.6.1.4.1.26138.8.35.2.1.1.1.9.1	Integer	false (2)
ibdot1qVlanStatus.1	1.3.6.1.4.1.26138.8.35.2.1.1.1.10.1	Integer	static (2)

Name	OID	Value Type	Value Example
ibdot1qVlanCreationTime.1	1.3.6.1.4.1.26138.8.35.2.1.1.1.11.1	TimeTicks	2 minutes 4.22 seconds (12422)
ibdot1qVlanPriority.1	1.3.6.1.4.1.26138.8.35.2.1.1.1.12.1	Integer	0
ibdot1qVlanRowStatus.1	1.3.6.1.4.1.26138.8.35.2.1.1.1.13.1	Integer	active (1)
ibdot1qVlanBroadcastSuppression.1	1.3.6.1.4.1.26138.8.35.2.1.1.1.14.1	Integer	100
ibdot1qVlanTaggedPorts.1	1.3.6.1.4.1.26138.8.35.2.1.1.1.17.1	OctetString	0x00 00 00 00 00 00 00
ibdot1qVlanUntaggedPorts.1	1.3.6.1.4.1.26138.8.35.2.1.1.1.18.1	OctetString	0xFF FF FF FF FF FF 3F
ibdot1qVlanPortIndexs.1	1.3.6.1.4.1.26138.8.35.2.1.1.1.19.1	Integer	1,2,3,4,5,6,7,8,9,10,11,12,13,14,15,16,17,18,19,20,21,22,23,24,25,26,27,28,29,30,31,32,33,34,35,36,37,38,39,40
ibVlanInterfaceID.1	.1.3.6.1.4.1.26138.8.35.2.1.2.1.1.1	Integer	1
ibdot1qVlanID.1	.1.3.6.1.4.1.26138.8.35.2.1.2.1.2.1	Integer	1
ibdot1qVlanIpAddress.1	.1.3.6.1.4.1.26138.8.35.2.1.2.1.3.1	IpAddress	10.100.65.116
ibdot1qVlanIpAddressMask.1	.1.3.6.1.4.1.26138.8.35.2.1.2.1.4.1	IpAddress	255.255.255.0
ibVlanInterfaceAdminStatus.1	.1.3.6.1.4.1.26138.8.35.2.1.2.1.5.1	Integer	up (1)
ibVlanInterfaceFrameType.1	.1.3.6.1.4.1.26138.8.35.2.1.2.1.6.1	Integer	ethernet-ii (1)
ibInterfaceRowStatus.1	.1.3.6.1.4.1.26138.8.35.2.1.2.1.7.1	Integer	active (1)
ibVlanInterfaceIpMethod.1	.1.3.6.1.4.1.26138.8.35.2.1.2.1.8.1	Integer	assigned-ip (1)
ibVlanInterfaceIfIndex.1	.1.3.6.1.4.1.26138.8.35.2.1.2.1.9.1	Integer	634
ibVlanInterfaceIpIfIndex.634.10.100.65.116	.1.3.6.1.4.1.26138.8.35.2.1.5.1.1.634.10.100.65.116	Integer	634
ibVlanInterfaceIpAddr.634.10.100.65.116	.1.3.6.1.4.1.26138.8.35.2.1.5.1.2.634.10.100.65.116	IpAddress	10.100.65.116
ibVlanInterfaceIpMask.634.10.100.65.116	.1.3.6.1.4.1.26138.8.35.2.1.5.1.3.634.10.100.65.116	IpAddress	255.255.255.0
ibVlanInterfaceIpType.634.10.100.65.116	.1.3.6.1.4.1.26138.8.35.2.1.5.1.4.634.10.100.65.116	Integer	primary (1)
ibVlanInterfaceIpRowStatus.634.10.100.65.116	.1.3.6.1.4.1.26138.8.35.2.1.5.1.5.634.10.100.65.116	Integer	active (1)
ibdot1qTpFdbSet-Port.1.0.0.252.0.154.226	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.0.0.252.0.154.226	Integer	1
ibdot1qTpFdbSet-Port.1.0.0.252.0.226.205	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.0.0.252.0.226.205	Integer	1
ibdot1qTpFdbSet-Port.1.0.9.15.9.30.10	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.0.9.15.9.30.10	Integer	1
ibdot1qTpFdbSet-Port.1.20.132.119.131.177.43	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.20.132.119.131.177.43	Integer	1
ibdot1qTpFdbSet-Port.1.20.132.119.131.177.75	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.20.132.119.131.177.75	Integer	1
ibdot1qTpFdbSet-Port.1.20.132.119.133.162.7	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.20.132.119.133.162.7	Integer	1
ibdot1qTpFdbSet-Port.1.20.132.119.140.199.125	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.20.132.119.140.199.125	Integer	1
ibdot1qTpFdbSet-Port.1.20.132.119.148.243.61	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.20.132.119.148.243.61	Integer	1
ibdot1qTpFdbSet-Port.1.20.132.119.207.154.109	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.20.132.119.207.154.109	Integer	1
ibdot1qTpFdbSet-Port.1.20.132.119.227.65.73	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.20.132.119.227.65.73	Integer	1



Name	OID	Value Type	Value Example
ibdot1qTpFdbSet-Port.1.20.132.119.237.167.7	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.20.132.119.237.167.7	Integer	1
ibdot1qTpFdbSet-Port.1.24.13.44.1.27.19	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.24.13.44.1.27.19	Integer	1
ibdot1qTpFdbSet-Port.1.40.0.175.181.178.120	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.40.0.175.181.178.120	Integer	1
ibdot1qTpFdbSet-Port.1.40.228.36.177.38.160	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.40.228.36.177.38.160	Integer	1
ibdot1qTpFdbSet-Port.1.84.198.255.75.170.192	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.84.198.255.75.170.192	Integer	1
ibdot1qTpFdbSet-Port.1.84.198.255.233.172.102	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.84.198.255.233.172.102	Integer	1
ibdot1qTpFdbSet-Port.1.88.202.172.149.241.128	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.88.202.172.149.241.128	Integer	1
ibdot1qTpFdbSet-Port.1.108.135.32.59.168.224	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.108.135.32.59.168.224	Integer	1
ibdot1qTpFdbSet-Port.1.124.122.60.21.14.31	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.124.122.60.21.14.31	Integer	1
ibdot1qTpFdbSet-Port.1.128.97.108.85.113.128	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.128.97.108.85.113.128	Integer	1
ibdot1qTpFdbSet-Port.1.128.133.68.8.106.232	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.128.133.68.8.106.232	Integer	1
ibdot1qTpFdbSet-Port.1.128.133.68.8.166.184	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.128.133.68.8.166.184	Integer	1
ibdot1qTpFdbSetPort.1.144.247.178.221.144.247.178.221	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.144.247.178.221.144.247.178.221	Integer	1
ibdot1qTpFdbSet-Port.1.180.215.219.190.84.96	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.180.215.219.190.84.96	Integer	1
ibdot1qTpFdbSet-Port.1.188.208.235.253.94.59	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.188.208.235.253.94.59	Integer	1
ibdot1qTpFdbSet-Port.1.228.96.23.236.123.216	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.228.96.23.236.123.216	Integer	1
ibdot1qTpFdbSet-Port.1.232.120.238.229.211.7	.1.3.6.1.4.1.26138.8.35.3.2.1.2.1.232.120.238.229.211.7	Integer	1
ibdot1qTpFdbSetStatus.1.0.0.252.0.154.226	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.0.0.252.0.154.226	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.0.0.252.0.226.205	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.0.0.252.0.226.205	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.0.9.15.9.30.10	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.0.9.15.9.30.10	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.20.132.119.131.177.43	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.20.132.119.131.177.43	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.20.132.119.131.177.75	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.20.132.119.131.177.75	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.20.132.119.133.162.7	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.20.132.119.133.162.7	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.20.132.119.140.199.125	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.20.132.119.140.199.125	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.20.132.119.148.243.61	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.20.132.119.148.243.61	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.20.132.119.207.154.109	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.20.132.119.207.154.109	Integer	learned (3)

Name	OID	Value Type	Value Example
ibdot1qTpFdbSetStatus.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.20.132.119.227.65.73	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.20.132.119.227.65.73	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.20.132.119.237.167.7	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.20.132.119.237.167.7	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.24.13.44.1.27.19	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.24.13.44.1.27.19	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.40.0.175.181.178.120	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.40.0.175.181.178.120	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.40.228.36.177.38.160	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.40.228.36.177.38.160	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.84.198.255.75.170.192	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.84.198.255.75.170.192	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.84.198.255.233.172.102	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.84.198.255.233.172.102	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.88.202.172.149.241.128	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.88.202.172.149.241.128	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.108.135.32.59.168.224	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.108.135.32.59.168.224	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.124.122.60.21.14.31	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.124.122.60.21.14.31	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.128.97.108.85.113.128	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.128.97.108.85.113.128	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.128.133.68.8.106.232	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.128.133.68.8.106.232	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.128.133.68.8.166.184	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.128.133.68.8.166.184	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.144.247.178.221.115.231	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.144.247.178.221.115.231	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.180.215.219.190.84.96	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.180.215.219.190.84.96	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.188.208.235.253.94.59	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.188.208.235.253.94.59	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.228.96.23.236.123.216	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.228.96.23.236.123.216	Integer	learned (3)
ibdot1qTpFdbSetStatus.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.232.120.238.228.229.211.7	.1.3.6.1.4.1.26138.8.35.3.2.1.3.1.232.120.238.228.229.211.7	Integer	learned (3)
ibSlotPortMax.0	.1.3.6.1.4.1.26138.8.35.5.1.1.0	Integer	63
ibSwitchPortMax.0	.1.3.6.1.4.1.26138.8.35.5.1.2.0	Integer	630
ibifEthernetDuplex.1	.1.3.6.1.4.1.26138.8.35.5.1.4.1.3.1	Integer	auto (3)
ibifEthernetDuplex.2	.1.3.6.1.4.1.26138.8.35.5.1.4.1.3.2	Integer	auto (3)
ibifEthernetDuplex.3	.1.3.6.1.4.1.26138.8.35.5.1.4.1.3.3	Integer	auto (3)
ibifEthernetDuplex.4	.1.3.6.1.4.1.26138.8.35.5.1.4.1.3.4	Integer	auto (3)
ibifEthernetDuplex.5	.1.3.6.1.4.1.26138.8.35.5.1.4.1.3.5	Integer	auto (3)
ibifEthernetDuplex.6	.1.3.6.1.4.1.26138.8.35.5.1.4.1.3.6	Integer	auto (3)
ibifEthernetDuplex.7	.1.3.6.1.4.1.26138.8.35.5.1.4.1.3.7	Integer	auto (3)
ibifEthernetDuplex.8	.1.3.6.1.4.1.26138.8.35.5.1.4.1.3.8	Integer	auto (3)
ibifEthernetDuplex.9	.1.3.6.1.4.1.26138.8.35.5.1.4.1.3.9	Integer	auto (3)
ibifEthernetDuplex.10	.1.3.6.1.4.1.26138.8.35.5.1.4.1.3.10	Integer	auto (3)

Name	OID	Value Type	Value Example
ibifEthernetDuplex.11	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.11	Integer	auto (3)
ibifEthernetDuplex.12	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.12	Integer	auto (3)
ibifEthernetDuplex.13	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.13	Integer	auto (3)
ibifEthernetDuplex.14	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.14	Integer	auto (3)
ibifEthernetDuplex.15	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.15	Integer	auto (3)
ibifEthernetDuplex.16	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.16	Integer	auto (3)
ibifEthernetDuplex.17	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.17	Integer	auto (3)
ibifEthernetDuplex.18	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.18	Integer	auto (3)
ibifEthernetDuplex.19	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.19	Integer	auto (3)
ibifEthernetDuplex.20	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.20	Integer	auto (3)
ibifEthernetDuplex.21	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.21	Integer	auto (3)
ibifEthernetDuplex.22	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.22	Integer	auto (3)
ibifEthernetDuplex.23	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.23	Integer	auto (3)
ibifEthernetDuplex.24	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.24	Integer	auto (3)
ibifEthernetDuplex.25	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.25	Integer	auto (3)
ibifEthernetDuplex.26	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.26	Integer	auto (3)
ibifEthernetDuplex.27	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.27	Integer	auto (3)
ibifEthernetDuplex.28	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.28	Integer	auto (3)
ibifEthernetDuplex.29	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.29	Integer	auto (3)
ibifEthernetDuplex.30	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.30	Integer	auto (3)
ibifEthernetDuplex.31	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.31	Integer	auto (3)
ibifEthernetDuplex.32	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.32	Integer	auto (3)
ibifEthernetDuplex.33	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.33	Integer	auto (3)
ibifEthernetDuplex.34	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.34	Integer	auto (3)
ibifEthernetDuplex.35	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.35	Integer	auto (3)
ibifEthernetDuplex.36	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.36	Integer	auto (3)
ibifEthernetDuplex.37	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.37	Integer	auto (3)
ibifEthernetDuplex.38	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.38	Integer	auto (3)
ibifEthernetDuplex.39	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.39	Integer	auto (3)
ibifEthernetDuplex.40	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.40	Integer	auto (3)
ibifEthernetDuplex.41	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.41	Integer	auto (3)
ibifEthernetDuplex.42	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.42	Integer	auto (3)
ibifEthernetDuplex.43	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.43	Integer	auto (3)
ibifEthernetDuplex.44	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.44	Integer	auto (3)
ibifEthernetDuplex.45	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.45	Integer	auto (3)
ibifEthernetDuplex.46	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.46	Integer	auto (3)
ibifEthernetDuplex.47	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.47	Integer	auto (3)
ibifEthernetDuplex.48	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.48	Integer	auto (3)
ibifEthernetDuplex.49	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.49	Integer	auto (3)
ibifEthernetDuplex.50	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.50	Integer	auto (3)
ibifEthernetDuplex.51	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.51	Integer	auto (3)
ibifEthernetDuplex.52	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.52	Integer	auto (3)
ibifEthernetDuplex.53	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.53	Integer	auto (3)

Name	OID	Value Type	Value Example
ibifEthernetDuplex.54	1.3.6.1.4.1.26138.8.35.5.1.4.1.3.54	Integer	auto (3)
ibifEthernetMTU.1	.1.3.6.1.4.1.26138.8.35.5.1.4.1.4.1	Integer	12288
ibifEthernetMTU.2	.1.3.6.1.4.1.26138.8.35.5.1.4.1.4.2	Integer	12288
ibifEthernetMTU.3	.1.3.6.1.4.1.26138.8.35.5.1.4.1.4.3	Integer	12288
ibifEthernetMTU.4	.1.3.6.1.4.1.26138.8.35.5.1.4.1.4.4	Integer	12288
ibifEthernetMTU.5	.1.3.6.1.4.1.26138.8.35.5.1.4.1.4.5	Integer	12288
ibifEthernetMTU.6	.1.3.6.1.4.1.26138.8.35.5.1.4.1.4.6	Integer	12288
ibifEthernetMTU.7	.1.3.6.1.4.1.26138.8.35.5.1.4.1.4.7	Integer	12288
ibifEthernetMTU.8	.1.3.6.1.4.1.26138.8.35.5.1.4.1.4.8	Integer	12288
ibifEthernetMTU.9	.1.3.6.1.4.1.26138.8.35.5.1.4.1.4.9	Integer	12288
ibifEthernetMTU.10	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.10	Integer	12288
ibifEthernetMTU.11	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.11	Integer	12288
ibifEthernetMTU.12	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.12	Integer	12288
ibifEthernetMTU.13	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.13	Integer	12288
ibifEthernetMTU.14	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.14	Integer	12288
ibifEthernetMTU.15	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.15	Integer	12288
ibifEthernetMTU.16	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.16	Integer	12288
ibifEthernetMTU.17	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.17	Integer	12288
ibifEthernetMTU.18	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.18	Integer	12288
ibifEthernetMTU.19	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.19	Integer	12288
ibifEthernetMTU.20	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.20	Integer	12288
ibifEthernetMTU.21	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.21	Integer	12288
ibifEthernetMTU.22	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.22	Integer	12288
ibifEthernetMTU.23	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.23	Integer	12288
ibifEthernetMTU.24	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.24	Integer	12288
ibifEthernetMTU.25	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.25	Integer	12288
ibifEthernetMTU.26	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.26	Integer	12288
ibifEthernetMTU.27	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.27	Integer	12288
ibifEthernetMTU.28	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.28	Integer	12288
ibifEthernetMTU.29	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.29	Integer	12288
ibifEthernetMTU.30	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.30	Integer	12288
ibifEthernetMTU.31	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.31	Integer	12288
ibifEthernetMTU.32	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.32	Integer	12288
ibifEthernetMTU.33	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.33	Integer	12288
ibifEthernetMTU.34	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.34	Integer	12288
ibifEthernetMTU.35	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.35	Integer	12288
ibifEthernetMTU.36	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.36	Integer	12288
ibifEthernetMTU.37	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.37	Integer	12288
ibifEthernetMTU.38	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.38	Integer	12288
ibifEthernetMTU.39	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.39	Integer	12288
ibifEthernetMTU.40	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.40	Integer	12288
ibifEthernetMTU.41	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.41	Integer	12288
ibifEthernetMTU.42	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.42	Integer	12288

Name	OID	Value Type	Value Example
ibifEthernetMTU.43	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.43	Integer	12288
ibifEthernetMTU.44	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.44	Integer	12288
ibifEthernetMTU.45	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.45	Integer	12288
ibifEthernetMTU.46	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.46	Integer	12288
ibifEthernetMTU.47	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.47	Integer	12288
ibifEthernetMTU.48	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.48	Integer	12288
ibifEthernetMTU.49	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.49	Integer	12288
ibifEthernetMTU.50	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.50	Integer	12288
ibifEthernetMTU.51	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.51	Integer	12288
ibifEthernetMTU.52	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.52	Integer	12288
ibifEthernetMTU.53	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.53	Integer	12288
ibifEthernetMTU.54	1.3.6.1.4.1.26138.8.35.5.1.4.1.4.54	Integer	12288
ibifEthernetSpeed.1	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.1	Integer	auto (0)
ibifEthernetSpeed.2	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.2	Integer	auto (0)
ibifEthernetSpeed.3	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.3	Integer	auto (0)
ibifEthernetSpeed.4	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.4	Integer	auto (0)
ibifEthernetSpeed.5	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.5	Integer	auto (0)
ibifEthernetSpeed.6	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.6	Integer	auto (0)
ibifEthernetSpeed.7	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.7	Integer	auto (0)
ibifEthernetSpeed.8	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.8	Integer	auto (0)
ibifEthernetSpeed.9	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.9	Integer	auto (0)
ibifEthernetSpeed.10	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.10	Integer	auto (0)
ibifEthernetSpeed.11	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.11	Integer	auto (0)
ibifEthernetSpeed.12	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.12	Integer	auto (0)
ibifEthernetSpeed.13	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.13	Integer	auto (0)
ibifEthernetSpeed.14	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.14	Integer	auto (0)
ibifEthernetSpeed.15	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.15	Integer	auto (0)
ibifEthernetSpeed.16	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.16	Integer	auto (0)
ibifEthernetSpeed.17	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.17	Integer	auto (0)
ibifEthernetSpeed.18	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.18	Integer	auto (0)
ibifEthernetSpeed.19	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.19	Integer	auto (0)
ibifEthernetSpeed.20	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.20	Integer	auto (0)
ibifEthernetSpeed.21	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.21	Integer	auto (0)
ibifEthernetSpeed.22	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.22	Integer	auto (0)
ibifEthernetSpeed.23	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.23	Integer	auto (0)
ibifEthernetSpeed.24	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.24	Integer	auto (0)
ibifEthernetSpeed.25	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.25	Integer	auto (0)
ibifEthernetSpeed.26	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.26	Integer	auto (0)
ibifEthernetSpeed.27	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.27	Integer	auto (0)
ibifEthernetSpeed.28	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.28	Integer	auto (0)
ibifEthernetSpeed.29	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.29	Integer	auto (0)
ibifEthernetSpeed.30	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.30	Integer	auto (0)
ibifEthernetSpeed.31	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.31	Integer	auto (0)

Name	OID	Value Type	Value Example
ibifEthernetSpeed.32	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.32	Integer	auto (0)
ibifEthernetSpeed.33	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.33	Integer	auto (0)
ibifEthernetSpeed.34	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.34	Integer	auto (0)
ibifEthernetSpeed.35	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.35	Integer	auto (0)
ibifEthernetSpeed.36	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.36	Integer	auto (0)
ibifEthernetSpeed.37	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.37	Integer	auto (0)
ibifEthernetSpeed.38	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.38	Integer	auto (0)
ibifEthernetSpeed.39	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.39	Integer	auto (0)
ibifEthernetSpeed.40	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.40	Integer	auto (0)
ibifEthernetSpeed.41	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.41	Integer	auto (0)
ibifEthernetSpeed.42	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.42	Integer	auto (0)
ibifEthernetSpeed.43	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.43	Integer	auto (0)
ibifEthernetSpeed.44	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.44	Integer	auto (0)
ibifEthernetSpeed.45	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.45	Integer	auto (0)
ibifEthernetSpeed.46	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.46	Integer	auto (0)
ibifEthernetSpeed.47	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.47	Integer	auto (0)
ibifEthernetSpeed.48	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.48	Integer	auto (0)
ibifEthernetSpeed.49	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.49	Integer	auto (0)
ibifEthernetSpeed.50	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.50	Integer	auto (0)
ibifEthernetSpeed.51	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.51	Integer	auto (0)
ibifEthernetSpeed.52	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.52	Integer	auto (0)
ibifEthernetSpeed.53	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.53	Integer	auto (0)
ibifEthernetSpeed.54	1.3.6.1.4.1.26138.8.35.5.1.4.1.5.54	Integer	auto (0)
ibifEthernetMdi.1	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.1	Integer	mdi-auto (3)
ibifEthernetMdi.2	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.2	Integer	mdi-auto (3)
ibifEthernetMdi.3	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.3	Integer	mdi-auto (3)
ibifEthernetMdi.4	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.4	Integer	mdi-auto (3)
ibifEthernetMdi.5	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.5	Integer	mdi-auto (3)
ibifEthernetMdi.6	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.6	Integer	mdi-auto (3)
ibifEthernetMdi.7	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.7	Integer	mdi-auto (3)
ibifEthernetMdi.8	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.8	Integer	mdi-auto (3)
ibifEthernetMdi.9	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.9	Integer	mdi-auto (3)
ibifEthernetMdi.10	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.10	Integer	mdi-auto (3)
ibifEthernetMdi.11	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.11	Integer	mdi-auto (3)
ibifEthernetMdi.12	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.12	Integer	mdi-auto (3)
ibifEthernetMdi.13	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.13	Integer	mdi-auto (3)
ibifEthernetMdi.14	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.14	Integer	mdi-auto (3)
ibifEthernetMdi.15	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.15	Integer	mdi-auto (3)
ibifEthernetMdi.16	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.16	Integer	mdi-auto (3)
ibifEthernetMdi.17	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.17	Integer	mdi-auto (3)
ibifEthernetMdi.18	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.18	Integer	mdi-auto (3)
ibifEthernetMdi.19	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.19	Integer	mdi-auto (3)
ibifEthernetMdi.20	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.20	Integer	mdi-auto (3)

Name	OID	Value Type	Value Example
ibifEthernetMdi.21	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.21	Integer	mdi-auto (3)
ibifEthernetMdi.22	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.22	Integer	mdi-auto (3)
ibifEthernetMdi.23	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.23	Integer	mdi-auto (3)
ibifEthernetMdi.24	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.24	Integer	mdi-auto (3)
ibifEthernetMdi.25	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.25	Integer	mdi-auto (3)
ibifEthernetMdi.26	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.26	Integer	mdi-auto (3)
ibifEthernetMdi.27	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.27	Integer	mdi-auto (3)
ibifEthernetMdi.28	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.28	Integer	mdi-auto (3)
ibifEthernetMdi.29	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.29	Integer	mdi-auto (3)
ibifEthernetMdi.30	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.30	Integer	mdi-auto (3)
ibifEthernetMdi.31	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.31	Integer	mdi-auto (3)
ibifEthernetMdi.32	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.32	Integer	mdi-auto (3)
ibifEthernetMdi.33	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.33	Integer	mdi-auto (3)
ibifEthernetMdi.34	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.34	Integer	mdi-auto (3)
ibifEthernetMdi.35	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.35	Integer	mdi-auto (3)
ibifEthernetMdi.36	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.36	Integer	mdi-auto (3)
ibifEthernetMdi.37	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.37	Integer	mdi-auto (3)
ibifEthernetMdi.38	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.38	Integer	mdi-auto (3)
ibifEthernetMdi.39	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.39	Integer	mdi-auto (3)
ibifEthernetMdi.40	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.40	Integer	mdi-auto (3)
ibifEthernetMdi.41	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.41	Integer	mdi-auto (3)
ibifEthernetMdi.42	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.42	Integer	mdi-auto (3)
ibifEthernetMdi.43	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.43	Integer	mdi-auto (3)
ibifEthernetMdi.44	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.44	Integer	mdi-auto (3)
ibifEthernetMdi.45	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.45	Integer	mdi-auto (3)
ibifEthernetMdi.46	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.46	Integer	mdi-auto (3)
ibifEthernetMdi.47	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.47	Integer	mdi-auto (3)
ibifEthernetMdi.48	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.48	Integer	mdi-auto (3)
ibifEthernetMdi.49	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.49	Integer	mdi-auto (3)
ibifEthernetMdi.50	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.50	Integer	mdi-auto (3)
ibifEthernetMdi.51	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.51	Integer	mdi-auto (3)
ibifEthernetMdi.52	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.52	Integer	mdi-auto (3)
ibifEthernetMdi.53	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.53	Integer	mdi-auto (3)
ibifEthernetMdi.54	1.3.6.1.4.1.26138.8.35.5.1.4.1.7.54	Integer	mdi-auto (3)
ibMaxMacLearn.1	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.1	Integer	-1
ibMaxMacLearn.2	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.2	Integer	-1
ibMaxMacLearn.3	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.3	Integer	-1
ibMaxMacLearn.4	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.4	Integer	-1
ibMaxMacLearn.5	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.5	Integer	-1
ibMaxMacLearn.6	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.6	Integer	-1
ibMaxMacLearn.7	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.7	Integer	-1
ibMaxMacLearn.8	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.8	Integer	-1
ibMaxMacLearn.9	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.9	Integer	-1



Name	OID	Value Type	Value Example
ibMaxMacLearn.10	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.10	Integer	-1
ibMaxMacLearn.11	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.11	Integer	-1
ibMaxMacLearn.12	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.12	Integer	-1
ibMaxMacLearn.13	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.13	Integer	-1
ibMaxMacLearn.14	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.14	Integer	-1
ibMaxMacLearn.15	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.15	Integer	-1
ibMaxMacLearn.16	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.16	Integer	-1
ibMaxMacLearn.17	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.17	Integer	-1
ibMaxMacLearn.18	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.18	Integer	-1
ibMaxMacLearn.19	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.19	Integer	-1
ibMaxMacLearn.20	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.20	Integer	-1
ibMaxMacLearn.21	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.21	Integer	-1
ibMaxMacLearn.22	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.22	Integer	-1
ibMaxMacLearn.23	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.23	Integer	-1
ibMaxMacLearn.24	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.24	Integer	-1
ibMaxMacLearn.25	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.25	Integer	-1
ibMaxMacLearn.26	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.26	Integer	-1
ibMaxMacLearn.27	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.27	Integer	-1
ibMaxMacLearn.28	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.28	Integer	-1
ibMaxMacLearn.29	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.29	Integer	-1
ibMaxMacLearn.30	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.30	Integer	-1
ibMaxMacLearn.31	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.31	Integer	-1
ibMaxMacLearn.32	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.32	Integer	-1
ibMaxMacLearn.33	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.33	Integer	-1
ibMaxMacLearn.34	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.34	Integer	-1
ibMaxMacLearn.35	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.35	Integer	-1
ibMaxMacLearn.36	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.36	Integer	-1
ibMaxMacLearn.37	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.37	Integer	-1
ibMaxMacLearn.38	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.38	Integer	-1
ibMaxMacLearn.39	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.39	Integer	-1
ibMaxMacLearn.40	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.40	Integer	-1
ibMaxMacLearn.41	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.41	Integer	-1
ibMaxMacLearn.42	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.42	Integer	-1
ibMaxMacLearn.43	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.43	Integer	-1
ibMaxMacLearn.44	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.44	Integer	-1
ibMaxMacLearn.45	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.45	Integer	-1
ibMaxMacLearn.46	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.46	Integer	-1
ibMaxMacLearn.47	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.47	Integer	-1
ibMaxMacLearn.48	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.48	Integer	-1
ibMaxMacLearn.49	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.49	Integer	-1
ibMaxMacLearn.50	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.50	Integer	-1
ibMaxMacLearn.51	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.51	Integer	-1
ibMaxMacLearn.52	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.52	Integer	-1



Name	OID	Value Type	Value Example
ibMaxMacLearn.53	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.53	Integer	-1
ibMaxMacLearn.54	1.3.6.1.4.1.26138.8.35.5.1.4.1.8.54	Integer	-1
ibifMacAddressLearn.1	.1.3.6.1.4.1.26138.8.35.5.1.4.1.9.1	Integer	enabled (1)
ibifMacAddressLearn.2	.1.3.6.1.4.1.26138.8.35.5.1.4.1.9.2	Integer	enabled (1)
ibifMacAddressLearn.3	.1.3.6.1.4.1.26138.8.35.5.1.4.1.9.3	Integer	enabled (1)
ibifMacAddressLearn.4	.1.3.6.1.4.1.26138.8.35.5.1.4.1.9.4	Integer	enabled (1)
ibifMacAddressLearn.5	.1.3.6.1.4.1.26138.8.35.5.1.4.1.9.5	Integer	enabled (1)
ibifMacAddressLearn.6	.1.3.6.1.4.1.26138.8.35.5.1.4.1.9.6	Integer	enabled (1)
ibifMacAddressLearn.7	.1.3.6.1.4.1.26138.8.35.5.1.4.1.9.7	Integer	enabled (1)
ibifMacAddressLearn.8	.1.3.6.1.4.1.26138.8.35.5.1.4.1.9.8	Integer	enabled (1)
ibifMacAddressLearn.9	.1.3.6.1.4.1.26138.8.35.5.1.4.1.9.9	Integer	enabled (1)
ibifMacAddressLearn.10	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.10	Integer	enabled (1)
ibifMacAddressLearn.11	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.11	Integer	enabled (1)
ibifMacAddressLearn.12	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.12	Integer	enabled (1)
ibifMacAddressLearn.13	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.13	Integer	enabled (1)
ibifMacAddressLearn.14	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.14	Integer	enabled (1)
ibifMacAddressLearn.15	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.15	Integer	enabled (1)
ibifMacAddressLearn.16	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.16	Integer	enabled (1)
ibifMacAddressLearn.17	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.17	Integer	enabled (1)
ibifMacAddressLearn.18	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.18	Integer	enabled (1)
ibifMacAddressLearn.19	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.19	Integer	enabled (1)
ibifMacAddressLearn.20	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.20	Integer	enabled (1)
ibifMacAddressLearn.21	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.21	Integer	enabled (1)
ibifMacAddressLearn.22	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.22	Integer	enabled (1)
ibifMacAddressLearn.23	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.23	Integer	enabled (1)
ibifMacAddressLearn.24	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.24	Integer	enabled (1)
ibifMacAddressLearn.25	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.25	Integer	enabled (1)
ibifMacAddressLearn.26	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.26	Integer	enabled (1)
ibifMacAddressLearn.27	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.27	Integer	enabled (1)
ibifMacAddressLearn.28	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.28	Integer	enabled (1)
ibifMacAddressLearn.29	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.29	Integer	enabled (1)
ibifMacAddressLearn.30	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.30	Integer	enabled (1)
ibifMacAddressLearn.31	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.31	Integer	enabled (1)
ibifMacAddressLearn.32	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.32	Integer	enabled (1)
ibifMacAddressLearn.33	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.33	Integer	enabled (1)
ibifMacAddressLearn.34	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.34	Integer	enabled (1)
ibifMacAddressLearn.35	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.35	Integer	enabled (1)
ibifMacAddressLearn.36	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.36	Integer	enabled (1)
ibifMacAddressLearn.37	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.37	Integer	enabled (1)
ibifMacAddressLearn.38	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.38	Integer	enabled (1)
ibifMacAddressLearn.39	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.39	Integer	enabled (1)
ibifMacAddressLearn.40	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.40	Integer	enabled (1)
ibifMacAddressLearn.41	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.41	Integer	enabled (1)

Name	OID	Value Type	Value Example
ibifMacAddressLearn.42	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.42	Integer	enabled (1)
ibifMacAddressLearn.43	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.43	Integer	enabled (1)
ibifMacAddressLearn.44	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.44	Integer	enabled (1)
ibifMacAddressLearn.45	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.45	Integer	enabled (1)
ibifMacAddressLearn.46	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.46	Integer	enabled (1)
ibifMacAddressLearn.47	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.47	Integer	enabled (1)
ibifMacAddressLearn.48	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.48	Integer	enabled (1)
ibifMacAddressLearn.49	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.49	Integer	enabled (1)
ibifMacAddressLearn.50	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.50	Integer	enabled (1)
ibifMacAddressLearn.51	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.51	Integer	enabled (1)
ibifMacAddressLearn.52	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.52	Integer	enabled (1)
ibifMacAddressLearn.53	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.53	Integer	enabled (1)
ibifMacAddressLearn.54	1.3.6.1.4.1.26138.8.35.5.1.4.1.9.54	Integer	enabled (1)
ibifEthernetFlowInterval.1	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.1	Integer	300
ibifEthernetFlowInterval.2	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.2	Integer	300
ibifEthernetFlowInterval.3	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.3	Integer	300
ibifEthernetFlowInterval.4	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.4	Integer	300
ibifEthernetFlowInterval.5	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.5	Integer	300
ibifEthernetFlowInterval.6	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.6	Integer	300
ibifEthernetFlowInterval.7	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.7	Integer	300
ibifEthernetFlowInterval.8	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.8	Integer	300
ibifEthernetFlowInterval.9	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.9	Integer	300
ibifEthernetFlowInterval.10	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.10	Integer	300
ibifEthernetFlowInterval.11	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.11	Integer	300
ibifEthernetFlowInterval.12	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.12	Integer	300
ibifEthernetFlowInterval.13	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.13	Integer	300
ibifEthernetFlowInterval.14	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.14	Integer	300
ibifEthernetFlowInterval.15	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.15	Integer	300
ibifEthernetFlowInterval.16	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.16	Integer	300
ibifEthernetFlowInterval.17	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.17	Integer	300
ibifEthernetFlowInterval.18	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.18	Integer	300
ibifEthernetFlowInterval.19	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.19	Integer	300
ibifEthernetFlowInterval.20	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.20	Integer	300
ibifEthernetFlowInterval.21	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.21	Integer	300
ibifEthernetFlowInterval.22	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.22	Integer	300
ibifEthernetFlowInterval.23	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.23	Integer	300
ibifEthernetFlowInterval.24	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.24	Integer	300
ibifEthernetFlowInterval.25	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.25	Integer	300
ibifEthernetFlowInterval.26	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.26	Integer	300
ibifEthernetFlowInterval.27	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.27	Integer	300
ibifEthernetFlowInterval.28	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.28	Integer	300
ibifEthernetFlowInterval.29	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.29	Integer	300
ibifEthernetFlowInterval.30	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.30	Integer	300

Name	OID	Value Type	Value Example
ibifEthernetFlowInterval.31	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.31	Integer	300
ibifEthernetFlowInterval.32	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.32	Integer	300
ibifEthernetFlowInterval.33	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.33	Integer	300
ibifEthernetFlowInterval.34	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.34	Integer	300
ibifEthernetFlowInterval.35	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.35	Integer	300
ibifEthernetFlowInterval.36	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.36	Integer	300
ibifEthernetFlowInterval.37	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.37	Integer	300
ibifEthernetFlowInterval.38	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.38	Integer	300
ibifEthernetFlowInterval.39	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.39	Integer	300
ibifEthernetFlowInterval.40	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.40	Integer	300
ibifEthernetFlowInterval.41	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.41	Integer	300
ibifEthernetFlowInterval.42	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.42	Integer	300
ibifEthernetFlowInterval.43	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.43	Integer	300
ibifEthernetFlowInterval.44	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.44	Integer	300
ibifEthernetFlowInterval.45	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.45	Integer	300
ibifEthernetFlowInterval.46	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.46	Integer	300
ibifEthernetFlowInterval.47	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.47	Integer	300
ibifEthernetFlowInterval.48	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.48	Integer	300
ibifEthernetFlowInterval.49	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.49	Integer	300
ibifEthernetFlowInterval.50	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.50	Integer	300
ibifEthernetFlowInterval.51	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.51	Integer	300
ibifEthernetFlowInterval.52	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.52	Integer	300
ibifEthernetFlowInterval.53	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.53	Integer	300
ibifEthernetFlowInterval.54	1.3.6.1.4.1.26138.8.35.5.1.4.1.12.54	Integer	300
ibifIsolateGroupID.1	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.1	Integer	0
ibifIsolateGroupID.2	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.2	Integer	0
ibifIsolateGroupID.3	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.3	Integer	0
ibifIsolateGroupID.4	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.4	Integer	0
ibifIsolateGroupID.5	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.5	Integer	0
ibifIsolateGroupID.6	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.6	Integer	0
ibifIsolateGroupID.7	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.7	Integer	0
ibifIsolateGroupID.8	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.8	Integer	0
ibifIsolateGroupID.9	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.9	Integer	0
ibifIsolateGroupID.10	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.10	Integer	0
ibifIsolateGroupID.11	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.11	Integer	0
ibifIsolateGroupID.12	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.12	Integer	0
ibifIsolateGroupID.13	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.13	Integer	0
ibifIsolateGroupID.14	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.14	Integer	0
ibifIsolateGroupID.15	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.15	Integer	0
ibifIsolateGroupID.16	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.16	Integer	0
ibifIsolateGroupID.17	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.17	Integer	0
ibifIsolateGroupID.18	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.18	Integer	0
ibifIsolateGroupID.19	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.19	Integer	0

Name	OID	Value Type	Value Example
ibifIsolateGroupID.20	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.20	Integer	0
ibifIsolateGroupID.21	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.21	Integer	0
ibifIsolateGroupID.22	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.22	Integer	0
ibifIsolateGroupID.23	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.23	Integer	0
ibifIsolateGroupID.24	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.24	Integer	0
ibifIsolateGroupID.25	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.25	Integer	0
ibifIsolateGroupID.26	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.26	Integer	0
ibifIsolateGroupID.27	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.27	Integer	0
ibifIsolateGroupID.28	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.28	Integer	0
ibifIsolateGroupID.29	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.29	Integer	0
ibifIsolateGroupID.30	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.30	Integer	0
ibifIsolateGroupID.31	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.31	Integer	0
ibifIsolateGroupID.32	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.32	Integer	0
ibifIsolateGroupID.33	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.33	Integer	0
ibifIsolateGroupID.34	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.34	Integer	0
ibifIsolateGroupID.35	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.35	Integer	0
ibifIsolateGroupID.36	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.36	Integer	0
ibifIsolateGroupID.37	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.37	Integer	0
ibifIsolateGroupID.38	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.38	Integer	0
ibifIsolateGroupID.39	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.39	Integer	0
ibifIsolateGroupID.40	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.40	Integer	0
ibifIsolateGroupID.41	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.41	Integer	0
ibifIsolateGroupID.42	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.42	Integer	0
ibifIsolateGroupID.43	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.43	Integer	0
ibifIsolateGroupID.44	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.44	Integer	0
ibifIsolateGroupID.45	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.45	Integer	0
ibifIsolateGroupID.46	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.46	Integer	0
ibifIsolateGroupID.47	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.47	Integer	0
ibifIsolateGroupID.48	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.48	Integer	0
ibifIsolateGroupID.49	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.49	Integer	0
ibifIsolateGroupID.50	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.50	Integer	0
ibifIsolateGroupID.51	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.51	Integer	0
ibifIsolateGroupID.52	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.52	Integer	0
ibifIsolateGroupID.53	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.53	Integer	0
ibifIsolateGroupID.54	1.3.6.1.4.1.26138.8.35.5.1.4.1.17.54	Integer	0
ibifEthernetAutoSpeedMask.1	1.3.6.1.4.1.26138.8.35.5.1.4.1.19.1	OctetString	{s10M, s100M, s1000M}
ibifEthernetAutoSpeedMask.2	1.3.6.1.4.1.26138.8.35.5.1.4.1.19.2	OctetString	{s10M, s100M, s1000M}
ibifEthernetAutoSpeedMask.3	1.3.6.1.4.1.26138.8.35.5.1.4.1.19.3	OctetString	{s10M, s100M, s1000M}
ibifEthernetAutoSpeedMask.4	1.3.6.1.4.1.26138.8.35.5.1.4.1.19.4	OctetString	{s10M, s100M, s1000M}
ibifEthernetAutoSpeedMask.5	1.3.6.1.4.1.26138.8.35.5.1.4.1.19.5	OctetString	{s10M, s100M, s1000M}
ibifEthernetAutoSpeedMask.6	1.3.6.1.4.1.26138.8.35.5.1.4.1.19.6	OctetString	{s10M, s100M, s1000M}
ibifEthernetAutoSpeedMask.7	1.3.6.1.4.1.26138.8.35.5.1.4.1.19.7	OctetString	{s10M, s100M, s1000M}
ibifEthernetAutoSpeedMask.8	1.3.6.1.4.1.26138.8.35.5.1.4.1.19.8	OctetString	{s10M, s100M, s1000M}



Name	OID	Value Type	Value Example
ibifEthernetAutoSpeedMask.52	1.3.6.1.4.1.26138.8.35.5.1.4.1.19.52	OctetString	{}
ibifEthernetAutoSpeedMask.53	1.3.6.1.4.1.26138.8.35.5.1.4.1.19.53	OctetString	{}
ibifEthernetAutoSpeedMask.54	1.3.6.1.4.1.26138.8.35.5.1.4.1.19.54	OctetString	{}
ibifEthernetAutoSpeed.1	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.1	OctetString	{}
ibifEthernetAutoSpeed.2	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.2	OctetString	{}
ibifEthernetAutoSpeed.3	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.3	OctetString	{}
ibifEthernetAutoSpeed.4	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.4	OctetString	{}
ibifEthernetAutoSpeed.5	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.5	OctetString	{}
ibifEthernetAutoSpeed.6	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.6	OctetString	{}
ibifEthernetAutoSpeed.7	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.7	OctetString	{}
ibifEthernetAutoSpeed.8	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.8	OctetString	{}
ibifEthernetAutoSpeed.9	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.9	OctetString	{}
ibifEthernetAutoSpeed.10	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.10	OctetString	{}
ibifEthernetAutoSpeed.11	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.11	OctetString	{}
ibifEthernetAutoSpeed.12	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.12	OctetString	{}
ibifEthernetAutoSpeed.13	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.13	OctetString	{}
ibifEthernetAutoSpeed.14	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.14	OctetString	{}
ibifEthernetAutoSpeed.15	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.15	OctetString	{}
ibifEthernetAutoSpeed.16	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.16	OctetString	{}
ibifEthernetAutoSpeed.17	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.17	OctetString	{}
ibifEthernetAutoSpeed.18	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.18	OctetString	{}
ibifEthernetAutoSpeed.19	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.19	OctetString	{}
ibifEthernetAutoSpeed.20	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.20	OctetString	{}
ibifEthernetAutoSpeed.21	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.21	OctetString	{}
ibifEthernetAutoSpeed.22	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.22	OctetString	{}
ibifEthernetAutoSpeed.23	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.23	OctetString	{}
ibifEthernetAutoSpeed.24	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.24	OctetString	{}
ibifEthernetAutoSpeed.25	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.25	OctetString	{}
ibifEthernetAutoSpeed.26	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.26	OctetString	{}
ibifEthernetAutoSpeed.27	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.27	OctetString	{}
ibifEthernetAutoSpeed.28	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.28	OctetString	{}
ibifEthernetAutoSpeed.29	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.29	OctetString	{}
ibifEthernetAutoSpeed.30	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.30	OctetString	{}
ibifEthernetAutoSpeed.31	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.31	OctetString	{}
ibifEthernetAutoSpeed.32	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.32	OctetString	{}
ibifEthernetAutoSpeed.33	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.33	OctetString	{}
ibifEthernetAutoSpeed.34	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.34	OctetString	{}
ibifEthernetAutoSpeed.35	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.35	OctetString	{}
ibifEthernetAutoSpeed.36	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.36	OctetString	{}
ibifEthernetAutoSpeed.37	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.37	OctetString	{}
ibifEthernetAutoSpeed.38	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.38	OctetString	{}
ibifEthernetAutoSpeed.39	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.39	OctetString	{}
ibifEthernetAutoSpeed.40	1.3.6.1.4.1.26138.8.35.5.1.4.1.20.40	OctetString	{}



Name	OID	Value Type	Value Example
ibifEthernetAutoSpeed.41	.1.3.6.1.4.1.26138.8.35.5.1.4.1.20.41	OctetString	{}
ibifEthernetAutoSpeed.42	.1.3.6.1.4.1.26138.8.35.5.1.4.1.20.42	OctetString	{}
ibifEthernetAutoSpeed.43	.1.3.6.1.4.1.26138.8.35.5.1.4.1.20.43	OctetString	{}
ibifEthernetAutoSpeed.44	.1.3.6.1.4.1.26138.8.35.5.1.4.1.20.44	OctetString	{}
ibifEthernetAutoSpeed.45	.1.3.6.1.4.1.26138.8.35.5.1.4.1.20.45	OctetString	{}
ibifEthernetAutoSpeed.46	.1.3.6.1.4.1.26138.8.35.5.1.4.1.20.46	OctetString	{}
ibifEthernetAutoSpeed.47	.1.3.6.1.4.1.26138.8.35.5.1.4.1.20.47	OctetString	{}
ibifEthernetAutoSpeed.48	.1.3.6.1.4.1.26138.8.35.5.1.4.1.20.48	OctetString	{}
ibifEthernetAutoSpeed.49	.1.3.6.1.4.1.26138.8.35.5.1.4.1.20.49	OctetString	{}
ibifEthernetAutoSpeed.50	.1.3.6.1.4.1.26138.8.35.5.1.4.1.20.50	OctetString	{}
ibifEthernetAutoSpeed.51	.1.3.6.1.4.1.26138.8.35.5.1.4.1.20.51	OctetString	{}
ibifEthernetAutoSpeed.52	.1.3.6.1.4.1.26138.8.35.5.1.4.1.20.52	OctetString	{}
ibifEthernetAutoSpeed.53	.1.3.6.1.4.1.26138.8.35.5.1.4.1.20.53	OctetString	{}
ibifEthernetAutoSpeed.54	.1.3.6.1.4.1.26138.8.35.5.1.4.1.20.54	OctetString	{}
ibIsolateGroupMax.0	.1.3.6.1.4.1.26138.8.35.5.1.5.0	Integer	8
ibMaxMacLearnRange.0	.1.3.6.1.4.1.26138.8.35.5.1.12.0	Integer	4096
ibDevMFanNum.1	.1.3.6.1.4.1.26138.8.35.9.1.1.1.1	Integer	1
ibDevMFanStatus.1	.1.3.6.1.4.1.26138.8.35.9.1.1.1.2.1	Integer	active (1)
ibDevMFanPosFrame.1	.1.3.6.1.4.1.26138.8.35.9.1.1.1.3.1	Integer	0
ibDevMFanPosSlot.1	.1.3.6.1.4.1.26138.8.35.9.1.1.1.4.1	Integer	1
ibDevMFanPosIndex.1	.1.3.6.1.4.1.26138.8.35.9.1.1.1.5.1	Integer	1
ibDevMFanMaxSpeed.1	.1.3.6.1.4.1.26138.8.35.9.1.1.1.6.1	Integer	0
ibDevMFanCurrentSpeed.1	.1.3.6.1.4.1.26138.8.35.9.1.1.1.7.1	Integer	0
ibDevMPowerNum.1	.1.3.6.1.4.1.26138.8.35.9.1.2.1.1.1	Integer	1
ibDevMPowerNum.2	.1.3.6.1.4.1.26138.8.35.9.1.2.1.1.2	Integer	2
ibDevMPowerStatus.1	.1.3.6.1.4.1.26138.8.35.9.1.2.1.2.1	Integer	active (1)
ibDevMPowerStatus.2	.1.3.6.1.4.1.26138.8.35.9.1.2.1.2.2	Integer	not-install (3)
ibDevMPowerEntIndex.1	.1.3.6.1.4.1.26138.8.35.9.1.2.1.3.1	Integer	1
ibDevMPowerEntIndex.2	.1.3.6.1.4.1.26138.8.35.9.1.2.1.3.2	Integer	3
ibDevMSlotEnvironmentValue.0.1.1	.1.3.6.1.4.1.26138.8.35.9.1.3.1.3.0.1	Integer	34
ibdot1qTpFdbLearnStatus.0	.1.3.6.1.4.1.26138.8.35.9.1.10.0	Integer	enabled (1)
ibdot1sStpStatus.0	.1.3.6.1.4.1.26138.8.35.14.1.0	Integer	enabled (1)
ibdot1sStpForceVersion.0	.1.3.6.1.4.1.26138.8.35.14.2.0	Integer	mstp (3)
ibdot1sStpDiameter.0	.1.3.6.1.4.1.26138.8.35.14.3.0	Integer	7
ibdot1sMstBridgeMaxHops.0	.1.3.6.1.4.1.26138.8.35.14.4.0	Integer	20
ibdot1sMstMasterBridgeID.0	.1.3.6.1.4.1.26138.8.35.14.5.0	OctetString	80-00-14-84-77-95-1D-B0
ibdot1sMstMasterPathCost.0	.1.3.6.1.4.1.26138.8.35.14.6.0	Integer	0
ibdot1sMstBpduGuard.0	.1.3.6.1.4.1.26138.8.35.14.7.0	Integer	disabled (2)
ibdot1sMstAdminFormatSelector.0	.1.3.6.1.4.1.26138.8.35.14.8.0	Integer	0
ibdot1sMstAdminRegion-Name.0	.1.3.6.1.4.1.26138.8.35.14.9.0	OctetString	148477951db0

Name	OID	Value Type	Value Example
ibdot1sMstAdminRevisionLevel.0	.1.3.6.1.4.1.26138.8.35.14.10.0	Integer	0
ibdot1sMstOperFormatSelector.0	.1.3.6.1.4.1.26138.8.35.14.11.0	Integer	0
ibdot1sMstOperRegionName.0	.1.3.6.1.4.1.26138.8.35.14.12.0	OctetString	148477951db0
ibdot1sMstOperRevisionLevel.0	.1.3.6.1.4.1.26138.8.35.14.13.0	Integer	0
ibdot1sMstOperConfigDigest.0	.1.3.6.1.4.1.26138.8.35.14.14.0	OctetString	0xAC 36 17 7F 50 28 3C D4 B8 38 21 D8 AB 26 DE 62
ibdot1sMstRegionConfActive.0	.1.3.6.1.4.1.26138.8.35.14.15.0	Integer	enable (1)
ibdot1sMstDefaultVlanAllo.0	.1.3.6.1.4.1.26138.8.35.14.16.0	Integer	unused (65535)
ibdot1sMstDefaultRegionName.0	.1.3.6.1.4.1.26138.8.35.14.17.0	Integer	unused (65535)
ibdot1sMstVID.1	.1.3.6.1.4.1.26138.8.35.14.18.1.1	Integer	1
ibdot1sMstVID.2	.1.3.6.1.4.1.26138.8.35.14.18.1.2	Integer	2
ibdot1sMstVID.3	.1.3.6.1.4.1.26138.8.35.14.18.1.3	Integer	3
ibdot1sMstVID.4	.1.3.6.1.4.1.26138.8.35.14.18.1.4	Integer	4
ibdot1sMstVID.5	.1.3.6.1.4.1.26138.8.35.14.18.1.5	Integer	5
ibdot1sMstVID.6	.1.3.6.1.4.1.26138.8.35.14.18.1.6	Integer	6
ibdot1sMstVID.7	.1.3.6.1.4.1.26138.8.35.14.18.1.7	Integer	7
ibdot1sMstVID.8	.1.3.6.1.4.1.26138.8.35.14.18.1.8	Integer	8
ibdot1sMstVID.9	.1.3.6.1.4.1.26138.8.35.14.18.1.9	Integer	9
ibdot1sMstVID.10	.1.3.6.1.4.1.26138.8.35.14.18.1.10	Integer	10
ibdot1sMstVID.11	.1.3.6.1.4.1.26138.8.35.14.18.1.11	Integer	11
ibdot1sMstVID.12	.1.3.6.1.4.1.26138.8.35.14.18.1.12	Integer	12
ibdot1sMstVID.13	.1.3.6.1.4.1.26138.8.35.14.18.1.13	Integer	13
ibdot1sMstVID.14	.1.3.6.1.4.1.26138.8.35.14.18.1.14	Integer	14
ibdot1sMstVID.15	.1.3.6.1.4.1.26138.8.35.14.18.1.15	Integer	15
ibdot1sMstVID.16	.1.3.6.1.4.1.26138.8.35.14.18.1.16	Integer	16
ibdot1sMstVID.17	.1.3.6.1.4.1.26138.8.35.14.18.1.17	Integer	17
ibdot1sMstVID.18	.1.3.6.1.4.1.26138.8.35.14.18.1.18	Integer	18
ibdot1sMstVID.19	.1.3.6.1.4.1.26138.8.35.14.18.1.19	Integer	19
ibdot1sMstVID.20	.1.3.6.1.4.1.26138.8.35.14.18.1.20	Integer	20
ibdot1sMstVID.21	.1.3.6.1.4.1.26138.8.35.14.18.1.21	Integer	21
ibdot1sMstVID.22	.1.3.6.1.4.1.26138.8.35.14.18.1.22	Integer	22
ibdot1sMstVID.23	.1.3.6.1.4.1.26138.8.35.14.18.1.23	Integer	23
ibdot1sMstVID.24	.1.3.6.1.4.1.26138.8.35.14.18.1.24	Integer	24
ibdot1sMstVID.25	.1.3.6.1.4.1.26138.8.35.14.18.1.25	Integer	25
ibdot1sMstVID.26	.1.3.6.1.4.1.26138.8.35.14.18.1.26	Integer	26
ibdot1sMstVID.27	.1.3.6.1.4.1.26138.8.35.14.18.1.27	Integer	27
ibdot1sMstVID.28	.1.3.6.1.4.1.26138.8.35.14.18.1.28	Integer	28
ibdot1sMstVID.29	.1.3.6.1.4.1.26138.8.35.14.18.1.29	Integer	29
ibdot1sMstVID.30	.1.3.6.1.4.1.26138.8.35.14.18.1.30	Integer	30
ibdot1sMstVID.31	.1.3.6.1.4.1.26138.8.35.14.18.1.31	Integer	31



Name	OID	Value Type	Value Example
ibdot1sMstVID.32	1.3.6.1.4.1.26138.8.35.14.18.1.1.32	Integer	32
ibdot1sMstVID.33	1.3.6.1.4.1.26138.8.35.14.18.1.1.33	Integer	33
ibdot1sMstVID.34	1.3.6.1.4.1.26138.8.35.14.18.1.1.34	Integer	34
ibdot1sMstVID.35	1.3.6.1.4.1.26138.8.35.14.18.1.1.35	Integer	35
ibdot1sMstVID.36	1.3.6.1.4.1.26138.8.35.14.18.1.1.36	Integer	36
ibdot1sMstVID.37	1.3.6.1.4.1.26138.8.35.14.18.1.1.37	Integer	37
ibdot1sMstVID.38	1.3.6.1.4.1.26138.8.35.14.18.1.1.38	Integer	38
ibdot1sMstVID.39	1.3.6.1.4.1.26138.8.35.14.18.1.1.39	Integer	39
ibdot1sMstVID.40	1.3.6.1.4.1.26138.8.35.14.18.1.1.40	Integer	40
ibdot1sMstVID.41	1.3.6.1.4.1.26138.8.35.14.18.1.1.41	Integer	41
ibdot1sMstVID.42	1.3.6.1.4.1.26138.8.35.14.18.1.1.42	Integer	42
ibdot1sMstVID.43	1.3.6.1.4.1.26138.8.35.14.18.1.1.43	Integer	43
ibdot1sMstVID.44	1.3.6.1.4.1.26138.8.35.14.18.1.1.44	Integer	44
ibdot1sMstVID.45	1.3.6.1.4.1.26138.8.35.14.18.1.1.45	Integer	45
ibdot1sMstVID.46	1.3.6.1.4.1.26138.8.35.14.18.1.1.46	Integer	46
ibdot1sMstVID.47	1.3.6.1.4.1.26138.8.35.14.18.1.1.47	Integer	47
ibdot1sMstVID.48	1.3.6.1.4.1.26138.8.35.14.18.1.1.48	Integer	48
ibdot1sMstVID.49	1.3.6.1.4.1.26138.8.35.14.18.1.1.49	Integer	49
ibdot1sMstVID.50	1.3.6.1.4.1.26138.8.35.14.18.1.1.50	Integer	50
ibdot1sMstVID.51	1.3.6.1.4.1.26138.8.35.14.18.1.1.51	Integer	51
ibdot1sMstVID.52	1.3.6.1.4.1.26138.8.35.14.18.1.1.52	Integer	52
ibdot1sMstVID.53	1.3.6.1.4.1.26138.8.35.14.18.1.1.53	Integer	53
ibdot1sMstVID.54	1.3.6.1.4.1.26138.8.35.14.18.1.1.54	Integer	54
ibdot1sMstVID.55	1.3.6.1.4.1.26138.8.35.14.18.1.1.55	Integer	55
ibdot1sMstVID.56	1.3.6.1.4.1.26138.8.35.14.18.1.1.56	Integer	56
ibdot1sMstVID.57	1.3.6.1.4.1.26138.8.35.14.18.1.1.57	Integer	57
ibdot1sMstVID.58	1.3.6.1.4.1.26138.8.35.14.18.1.1.58	Integer	58
ibdot1sMstVID.59	1.3.6.1.4.1.26138.8.35.14.18.1.1.59	Integer	59
ibdot1sMstVID.60	1.3.6.1.4.1.26138.8.35.14.18.1.1.60	Integer	60
ibdot1sMstVID.61	1.3.6.1.4.1.26138.8.35.14.18.1.1.61	Integer	61
ibdot1sMstVID.62	1.3.6.1.4.1.26138.8.35.14.18.1.1.62	Integer	62
ibdot1sMstVID.63	1.3.6.1.4.1.26138.8.35.14.18.1.1.63	Integer	63
ibdot1sMstVID.64	1.3.6.1.4.1.26138.8.35.14.18.1.1.64	Integer	64
ibdot1sMstVID.65	1.3.6.1.4.1.26138.8.35.14.18.1.1.65	Integer	65
ibdot1sMstVID.66	1.3.6.1.4.1.26138.8.35.14.18.1.1.66	Integer	66
ibdot1sMstVID.67	1.3.6.1.4.1.26138.8.35.14.18.1.1.67	Integer	67
ibdot1sMstVID.68	1.3.6.1.4.1.26138.8.35.14.18.1.1.68	Integer	68
ibdot1sMstVID.69	1.3.6.1.4.1.26138.8.35.14.18.1.1.69	Integer	69
ibdot1sMstVID.70	1.3.6.1.4.1.26138.8.35.14.18.1.1.70	Integer	70
ibdot1sMstVID.71	1.3.6.1.4.1.26138.8.35.14.18.1.1.71	Integer	71
ibdot1sMstVID.72	1.3.6.1.4.1.26138.8.35.14.18.1.1.72	Integer	72
ibdot1sMstVID.73	1.3.6.1.4.1.26138.8.35.14.18.1.1.73	Integer	73
ibdot1sMstVID.74	1.3.6.1.4.1.26138.8.35.14.18.1.1.74	Integer	74

Name	OID	Value Type	Value Example
ibdot1sMstVID.75	1.3.6.1.4.1.26138.8.35.14.18.1.1.75	Integer	75
ibdot1sMstVID.76	1.3.6.1.4.1.26138.8.35.14.18.1.1.76	Integer	76
ibdot1sMstVID.77	1.3.6.1.4.1.26138.8.35.14.18.1.1.77	Integer	77
ibdot1sMstVID.78	1.3.6.1.4.1.26138.8.35.14.18.1.1.78	Integer	78
ibdot1sMstVID.79	1.3.6.1.4.1.26138.8.35.14.18.1.1.79	Integer	79
ibdot1sMstVID.80	1.3.6.1.4.1.26138.8.35.14.18.1.1.80	Integer	80
ibdot1sMstVID.81	1.3.6.1.4.1.26138.8.35.14.18.1.1.81	Integer	81
ibdot1sMstVID.82	1.3.6.1.4.1.26138.8.35.14.18.1.1.82	Integer	82
ibdot1sMstVID.83	1.3.6.1.4.1.26138.8.35.14.18.1.1.83	Integer	83
ibdot1sMstVID.84	1.3.6.1.4.1.26138.8.35.14.18.1.1.84	Integer	84
ibdot1sMstVID.85	1.3.6.1.4.1.26138.8.35.14.18.1.1.85	Integer	85
ibdot1sMstVID.86	1.3.6.1.4.1.26138.8.35.14.18.1.1.86	Integer	86
ibdot1sMstVID.87	1.3.6.1.4.1.26138.8.35.14.18.1.1.87	Integer	87
ibdot1sMstVID.88	1.3.6.1.4.1.26138.8.35.14.18.1.1.88	Integer	88
ibdot1sMstVID.89	1.3.6.1.4.1.26138.8.35.14.18.1.1.89	Integer	89
ibdot1sMstVID.90	1.3.6.1.4.1.26138.8.35.14.18.1.1.90	Integer	90
ibdot1sMstVID.91	1.3.6.1.4.1.26138.8.35.14.18.1.1.91	Integer	91
ibdot1sMstVID.92	1.3.6.1.4.1.26138.8.35.14.18.1.1.92	Integer	92
ibdot1sMstVID.93	1.3.6.1.4.1.26138.8.35.14.18.1.1.93	Integer	93
ibdot1sMstVID.94	1.3.6.1.4.1.26138.8.35.14.18.1.1.94	Integer	94
ibdot1sMstVID.95	1.3.6.1.4.1.26138.8.35.14.18.1.1.95	Integer	95
ibdot1sMstVID.96	1.3.6.1.4.1.26138.8.35.14.18.1.1.96	Integer	96
ibdot1sMstVID.97	1.3.6.1.4.1.26138.8.35.14.18.1.1.97	Integer	97
ibdot1sMstVID.98	1.3.6.1.4.1.26138.8.35.14.18.1.1.98	Integer	98
ibdot1sMstVID.99	1.3.6.1.4.1.26138.8.35.14.18.1.1.99	Integer	99
ibdot1sMstVID.100	1.3.6.1.4.1.26138.8.35.14.18.1.1.100	Integer	100
ibdot1sMstVID.101	1.3.6.1.4.1.26138.8.35.14.18.1.1.101	Integer	101
ibdot1sMstVID.102	1.3.6.1.4.1.26138.8.35.14.18.1.1.102	Integer	102
ibdot1sMstVID.103	1.3.6.1.4.1.26138.8.35.14.18.1.1.103	Integer	103
ibdot1sMstVID.104	1.3.6.1.4.1.26138.8.35.14.18.1.1.104	Integer	104
ibdot1sMstVID.105	1.3.6.1.4.1.26138.8.35.14.18.1.1.105	Integer	105
ibdot1sMstVID.106	1.3.6.1.4.1.26138.8.35.14.18.1.1.106	Integer	106
ibdot1sMstVID.107	1.3.6.1.4.1.26138.8.35.14.18.1.1.107	Integer	107
ibdot1sMstVID.108	1.3.6.1.4.1.26138.8.35.14.18.1.1.108	Integer	108
ibdot1sMstVID.109	1.3.6.1.4.1.26138.8.35.14.18.1.1.109	Integer	109
ibdot1sMstVID.110	1.3.6.1.4.1.26138.8.35.14.18.1.1.110	Integer	110
ibdot1sMstVID.111	1.3.6.1.4.1.26138.8.35.14.18.1.1.111	Integer	111
ibdot1sMstVID.112	1.3.6.1.4.1.26138.8.35.14.18.1.1.112	Integer	112
ibdot1sMstVID.113	1.3.6.1.4.1.26138.8.35.14.18.1.1.113	Integer	113
ibdot1sMstVID.114	1.3.6.1.4.1.26138.8.35.14.18.1.1.114	Integer	114
ibdot1sMstVID.115	1.3.6.1.4.1.26138.8.35.14.18.1.1.115	Integer	115
ibdot1sMstVID.116	1.3.6.1.4.1.26138.8.35.14.18.1.1.116	Integer	116
ibdot1sMstVID.117	1.3.6.1.4.1.26138.8.35.14.18.1.1.117	Integer	117

Name	OID	Value Type	Value Example
ibdot1sMstVID.118	.3.6.1.4.1.26138.8.35.14.18.1.1.118	Integer	118
ibdot1sMstVID.119	.3.6.1.4.1.26138.8.35.14.18.1.1.119	Integer	119
ibdot1sMstVID.120	.3.6.1.4.1.26138.8.35.14.18.1.1.120	Integer	120
ibdot1sMstVID.121	.3.6.1.4.1.26138.8.35.14.18.1.1.121	Integer	121
ibdot1sMstVID.122	.3.6.1.4.1.26138.8.35.14.18.1.1.122	Integer	122
ibdot1sMstVID.123	.3.6.1.4.1.26138.8.35.14.18.1.1.123	Integer	123
ibdot1sMstVID.124	.3.6.1.4.1.26138.8.35.14.18.1.1.124	Integer	124
ibdot1sMstVID.125	.3.6.1.4.1.26138.8.35.14.18.1.1.125	Integer	125
ibdot1sMstVID.126	.3.6.1.4.1.26138.8.35.14.18.1.1.126	Integer	126
ibdot1sMstVID.127	.3.6.1.4.1.26138.8.35.14.18.1.1.127	Integer	127
ibdot1sMstVID.128	.3.6.1.4.1.26138.8.35.14.18.1.1.128	Integer	128
ibdot1sMstVID.129	.3.6.1.4.1.26138.8.35.14.18.1.1.129	Integer	129
ibdot1sMstVID.130	.3.6.1.4.1.26138.8.35.14.18.1.1.130	Integer	130
ibdot1sMstVID.131	.3.6.1.4.1.26138.8.35.14.18.1.1.131	Integer	131
ibdot1sMstVID.132	.3.6.1.4.1.26138.8.35.14.18.1.1.132	Integer	132
ibdot1sMstVID.133	.3.6.1.4.1.26138.8.35.14.18.1.1.133	Integer	133
ibdot1sMstVID.134	.3.6.1.4.1.26138.8.35.14.18.1.1.134	Integer	134
ibdot1sMstVID.135	.3.6.1.4.1.26138.8.35.14.18.1.1.135	Integer	135
ibdot1sMstVID.136	.3.6.1.4.1.26138.8.35.14.18.1.1.136	Integer	136
ibdot1sMstVID.137	.3.6.1.4.1.26138.8.35.14.18.1.1.137	Integer	137
ibdot1sMstVID.138	.3.6.1.4.1.26138.8.35.14.18.1.1.138	Integer	138
ibdot1sMstVID.139	.3.6.1.4.1.26138.8.35.14.18.1.1.139	Integer	139
ibdot1sMstVID.140	.3.6.1.4.1.26138.8.35.14.18.1.1.140	Integer	140
ibdot1sMstVID.141	.3.6.1.4.1.26138.8.35.14.18.1.1.141	Integer	141
ibdot1sMstVID.142	.3.6.1.4.1.26138.8.35.14.18.1.1.142	Integer	142
ibdot1sMstVID.143	.3.6.1.4.1.26138.8.35.14.18.1.1.143	Integer	143
ibdot1sMstVID.144	.3.6.1.4.1.26138.8.35.14.18.1.1.144	Integer	144
ibdot1sMstVID.145	.3.6.1.4.1.26138.8.35.14.18.1.1.145	Integer	145
ibdot1sMstVID.146	.3.6.1.4.1.26138.8.35.14.18.1.1.146	Integer	146
ibdot1sMstVID.147	.3.6.1.4.1.26138.8.35.14.18.1.1.147	Integer	147
ibdot1sMstVID.148	.3.6.1.4.1.26138.8.35.14.18.1.1.148	Integer	148
ibdot1sMstVID.149	.3.6.1.4.1.26138.8.35.14.18.1.1.149	Integer	149
ibdot1sMstVID.150	.3.6.1.4.1.26138.8.35.14.18.1.1.150	Integer	150
ibdot1sMstVID.151	.3.6.1.4.1.26138.8.35.14.18.1.1.151	Integer	151
ibdot1sMstVID.152	.3.6.1.4.1.26138.8.35.14.18.1.1.152	Integer	152
ibdot1sMstVID.153	.3.6.1.4.1.26138.8.35.14.18.1.1.153	Integer	153
ibdot1sMstVID.154	.3.6.1.4.1.26138.8.35.14.18.1.1.154	Integer	154
ibdot1sMstVID.155	.3.6.1.4.1.26138.8.35.14.18.1.1.155	Integer	155
ibdot1sMstVID.156	.3.6.1.4.1.26138.8.35.14.18.1.1.156	Integer	156
ibdot1sMstVID.157	.3.6.1.4.1.26138.8.35.14.18.1.1.157	Integer	157
ibdot1sMstVID.158	.3.6.1.4.1.26138.8.35.14.18.1.1.158	Integer	158
ibdot1sMstVID.159	.3.6.1.4.1.26138.8.35.14.18.1.1.159	Integer	159
ibdot1sMstVID.160	.3.6.1.4.1.26138.8.35.14.18.1.1.160	Integer	160

Name	OID	Value Type	Value Example
ibdot1sMstVID.161	.3.6.1.4.1.26138.8.35.14.18.1.1.161	Integer	161
ibdot1sMstVID.162	.3.6.1.4.1.26138.8.35.14.18.1.1.162	Integer	162
ibdot1sMstVID.163	.3.6.1.4.1.26138.8.35.14.18.1.1.163	Integer	163
ibdot1sMstVID.164	.3.6.1.4.1.26138.8.35.14.18.1.1.164	Integer	164
ibdot1sMstVID.165	.3.6.1.4.1.26138.8.35.14.18.1.1.165	Integer	165
ibdot1sMstVID.166	.3.6.1.4.1.26138.8.35.14.18.1.1.166	Integer	166
ibdot1sMstVID.167	.3.6.1.4.1.26138.8.35.14.18.1.1.167	Integer	167
ibdot1sMstVID.168	.3.6.1.4.1.26138.8.35.14.18.1.1.168	Integer	168
ibdot1sMstVID.169	.3.6.1.4.1.26138.8.35.14.18.1.1.169	Integer	169
ibdot1sMstVID.170	.3.6.1.4.1.26138.8.35.14.18.1.1.170	Integer	170
ibdot1sMstVID.171	.3.6.1.4.1.26138.8.35.14.18.1.1.171	Integer	171
ibdot1sMstVID.172	.3.6.1.4.1.26138.8.35.14.18.1.1.172	Integer	172
ibdot1sMstVID.173	.3.6.1.4.1.26138.8.35.14.18.1.1.173	Integer	173
ibdot1sMstVID.174	.3.6.1.4.1.26138.8.35.14.18.1.1.174	Integer	174
ibdot1sMstVID.175	.3.6.1.4.1.26138.8.35.14.18.1.1.175	Integer	175
ibdot1sMstVID.176	.3.6.1.4.1.26138.8.35.14.18.1.1.176	Integer	176
ibdot1sMstVID.177	.3.6.1.4.1.26138.8.35.14.18.1.1.177	Integer	177
ibdot1sMstVID.178	.3.6.1.4.1.26138.8.35.14.18.1.1.178	Integer	178
ibdot1sMstVID.179	.3.6.1.4.1.26138.8.35.14.18.1.1.179	Integer	179
ibdot1sMstVID.180	.3.6.1.4.1.26138.8.35.14.18.1.1.180	Integer	180
ibdot1sMstVID.181	.3.6.1.4.1.26138.8.35.14.18.1.1.181	Integer	181
ibdot1sMstVID.182	.3.6.1.4.1.26138.8.35.14.18.1.1.182	Integer	182
ibdot1sMstVID.183	.3.6.1.4.1.26138.8.35.14.18.1.1.183	Integer	183
ibdot1sMstVID.184	.3.6.1.4.1.26138.8.35.14.18.1.1.184	Integer	184
ibdot1sMstVID.185	.3.6.1.4.1.26138.8.35.14.18.1.1.185	Integer	185
ibdot1sMstVID.186	.3.6.1.4.1.26138.8.35.14.18.1.1.186	Integer	186
ibdot1sMstVID.187	.3.6.1.4.1.26138.8.35.14.18.1.1.187	Integer	187
ibdot1sMstVID.188	.3.6.1.4.1.26138.8.35.14.18.1.1.188	Integer	188
ibdot1sMstVID.189	.3.6.1.4.1.26138.8.35.14.18.1.1.189	Integer	189
ibdot1sMstVID.190	.3.6.1.4.1.26138.8.35.14.18.1.1.190	Integer	190
ibdot1sMstVID.191	.3.6.1.4.1.26138.8.35.14.18.1.1.191	Integer	191
ibdot1sMstVID.192	.3.6.1.4.1.26138.8.35.14.18.1.1.192	Integer	192
ibdot1sMstVID.193	.3.6.1.4.1.26138.8.35.14.18.1.1.193	Integer	193
ibdot1sMstVID.194	.3.6.1.4.1.26138.8.35.14.18.1.1.194	Integer	194
ibdot1sMstVID.195	.3.6.1.4.1.26138.8.35.14.18.1.1.195	Integer	195
ibdot1sMstVID.196	.3.6.1.4.1.26138.8.35.14.18.1.1.196	Integer	196
ibdot1sMstVID.197	.3.6.1.4.1.26138.8.35.14.18.1.1.197	Integer	197
ibdot1sMstVID.198	.3.6.1.4.1.26138.8.35.14.18.1.1.198	Integer	198
ibdot1sMstVID.199	.3.6.1.4.1.26138.8.35.14.18.1.1.199	Integer	199
ibdot1sMstVID.200	.3.6.1.4.1.26138.8.35.14.18.1.1.200	Integer	200
ibdot1sMstVID.201	.3.6.1.4.1.26138.8.35.14.18.1.1.201	Integer	201
ibdot1sMstVID.202	.3.6.1.4.1.26138.8.35.14.18.1.1.202	Integer	202
ibdot1sMstVID.203	.3.6.1.4.1.26138.8.35.14.18.1.1.203	Integer	203

Name	OID	Value Type	Value Example
ibdot1sMstVID.204	.3.6.1.4.1.26138.8.35.14.18.1.1.204	Integer	204
ibdot1sMstVID.205	.3.6.1.4.1.26138.8.35.14.18.1.1.205	Integer	205
ibdot1sMstVID.206	.3.6.1.4.1.26138.8.35.14.18.1.1.206	Integer	206
ibdot1sMstVID.207	.3.6.1.4.1.26138.8.35.14.18.1.1.207	Integer	207
ibdot1sMstVID.208	.3.6.1.4.1.26138.8.35.14.18.1.1.208	Integer	208
ibdot1sMstVID.209	.3.6.1.4.1.26138.8.35.14.18.1.1.209	Integer	209
ibdot1sMstVID.210	.3.6.1.4.1.26138.8.35.14.18.1.1.210	Integer	210
ibdot1sMstVID.211	.3.6.1.4.1.26138.8.35.14.18.1.1.211	Integer	211
ibdot1sMstVID.212	.3.6.1.4.1.26138.8.35.14.18.1.1.212	Integer	212
ibdot1sMstVID.213	.3.6.1.4.1.26138.8.35.14.18.1.1.213	Integer	213
ibdot1sMstVID.214	.3.6.1.4.1.26138.8.35.14.18.1.1.214	Integer	214
ibdot1sMstVID.215	.3.6.1.4.1.26138.8.35.14.18.1.1.215	Integer	215
ibdot1sMstVID.216	.3.6.1.4.1.26138.8.35.14.18.1.1.216	Integer	216
ibdot1sMstVID.217	.3.6.1.4.1.26138.8.35.14.18.1.1.217	Integer	217
ibdot1sMstVID.218	.3.6.1.4.1.26138.8.35.14.18.1.1.218	Integer	218
ibdot1sMstVID.219	.3.6.1.4.1.26138.8.35.14.18.1.1.219	Integer	219
ibdot1sMstVID.220	.3.6.1.4.1.26138.8.35.14.18.1.1.220	Integer	220
ibdot1sMstVID.221	.3.6.1.4.1.26138.8.35.14.18.1.1.221	Integer	221
ibdot1sMstVID.222	.3.6.1.4.1.26138.8.35.14.18.1.1.222	Integer	222
ibdot1sMstVID.223	.3.6.1.4.1.26138.8.35.14.18.1.1.223	Integer	223
ibdot1sMstVID.224	.3.6.1.4.1.26138.8.35.14.18.1.1.224	Integer	224
ibdot1sMstVID.225	.3.6.1.4.1.26138.8.35.14.18.1.1.225	Integer	225
ibdot1sMstVID.226	.3.6.1.4.1.26138.8.35.14.18.1.1.226	Integer	226
ibdot1sMstVID.227	.3.6.1.4.1.26138.8.35.14.18.1.1.227	Integer	227
ibdot1sMstVID.228	.3.6.1.4.1.26138.8.35.14.18.1.1.228	Integer	228
ibdot1sMstVID.229	.3.6.1.4.1.26138.8.35.14.18.1.1.229	Integer	229
ibdot1sMstVID.230	.3.6.1.4.1.26138.8.35.14.18.1.1.230	Integer	230
ibdot1sMstVID.231	.3.6.1.4.1.26138.8.35.14.18.1.1.231	Integer	231
ibdot1sMstVID.232	.3.6.1.4.1.26138.8.35.14.18.1.1.232	Integer	232
ibdot1sMstVID.233	.3.6.1.4.1.26138.8.35.14.18.1.1.233	Integer	233
ibdot1sMstVID.234	.3.6.1.4.1.26138.8.35.14.18.1.1.234	Integer	234
ibdot1sMstVID.235	.3.6.1.4.1.26138.8.35.14.18.1.1.235	Integer	235
ibdot1sMstVID.236	.3.6.1.4.1.26138.8.35.14.18.1.1.236	Integer	236
ibdot1sMstVID.237	.3.6.1.4.1.26138.8.35.14.18.1.1.237	Integer	237
ibdot1sMstVID.238	.3.6.1.4.1.26138.8.35.14.18.1.1.238	Integer	238
ibdot1sMstVID.239	.3.6.1.4.1.26138.8.35.14.18.1.1.239	Integer	239
ibdot1sMstVID.240	.3.6.1.4.1.26138.8.35.14.18.1.1.240	Integer	240
ibdot1sMstVID.241	.3.6.1.4.1.26138.8.35.14.18.1.1.241	Integer	241
ibdot1sMstVID.242	.3.6.1.4.1.26138.8.35.14.18.1.1.242	Integer	242
ibdot1sMstVID.243	.3.6.1.4.1.26138.8.35.14.18.1.1.243	Integer	243
ibdot1sMstVID.244	.3.6.1.4.1.26138.8.35.14.18.1.1.244	Integer	244
ibdot1sMstVID.245	.3.6.1.4.1.26138.8.35.14.18.1.1.245	Integer	245
ibdot1sMstVID.246	.3.6.1.4.1.26138.8.35.14.18.1.1.246	Integer	246

Name	OID	Value Type	Value Example
ibdot1sMstVID.247	.3.6.1.4.1.26138.8.35.14.18.1.1.247	Integer	247
ibdot1sMstVID.248	.3.6.1.4.1.26138.8.35.14.18.1.1.248	Integer	248
ibdot1sMstVID.249	.3.6.1.4.1.26138.8.35.14.18.1.1.249	Integer	249
ibdot1sMstVID.250	.3.6.1.4.1.26138.8.35.14.18.1.1.250	Integer	250
ibdot1sMstVID.251	.3.6.1.4.1.26138.8.35.14.18.1.1.251	Integer	251
ibdot1sMstVID.252	.3.6.1.4.1.26138.8.35.14.18.1.1.252	Integer	252
ibdot1sMstVID.253	.3.6.1.4.1.26138.8.35.14.18.1.1.253	Integer	253
ibdot1sMstVID.254	.3.6.1.4.1.26138.8.35.14.18.1.1.254	Integer	254
ibdot1sMstVID.255	.3.6.1.4.1.26138.8.35.14.18.1.1.255	Integer	255
ibdot1sMstVID.256	.3.6.1.4.1.26138.8.35.14.18.1.1.256	Integer	256
ibdot1sMstVID.257	.3.6.1.4.1.26138.8.35.14.18.1.1.257	Integer	257
ibdot1sMstVID.258	.3.6.1.4.1.26138.8.35.14.18.1.1.258	Integer	258
ibdot1sMstVID.259	.3.6.1.4.1.26138.8.35.14.18.1.1.259	Integer	259
ibdot1sMstVID.260	.3.6.1.4.1.26138.8.35.14.18.1.1.260	Integer	260
ibdot1sMstVID.261	.3.6.1.4.1.26138.8.35.14.18.1.1.261	Integer	261
ibdot1sMstVID.262	.3.6.1.4.1.26138.8.35.14.18.1.1.262	Integer	262
ibdot1sMstVID.263	.3.6.1.4.1.26138.8.35.14.18.1.1.263	Integer	263
ibdot1sMstVID.264	.3.6.1.4.1.26138.8.35.14.18.1.1.264	Integer	264
ibdot1sMstVID.265	.3.6.1.4.1.26138.8.35.14.18.1.1.265	Integer	265
ibdot1sMstVID.266	.3.6.1.4.1.26138.8.35.14.18.1.1.266	Integer	266
ibdot1sMstVID.267	.3.6.1.4.1.26138.8.35.14.18.1.1.267	Integer	267
ibdot1sMstVID.268	.3.6.1.4.1.26138.8.35.14.18.1.1.268	Integer	268
ibdot1sMstVID.269	.3.6.1.4.1.26138.8.35.14.18.1.1.269	Integer	269
ibdot1sMstVID.270	.3.6.1.4.1.26138.8.35.14.18.1.1.270	Integer	270
ibdot1sMstVID.271	.3.6.1.4.1.26138.8.35.14.18.1.1.271	Integer	271
ibdot1sMstVID.272	.3.6.1.4.1.26138.8.35.14.18.1.1.272	Integer	272
ibdot1sMstVID.273	.3.6.1.4.1.26138.8.35.14.18.1.1.273	Integer	273
ibdot1sMstVID.274	.3.6.1.4.1.26138.8.35.14.18.1.1.274	Integer	274
ibdot1sMstVID.275	.3.6.1.4.1.26138.8.35.14.18.1.1.275	Integer	275
ibdot1sMstVID.276	.3.6.1.4.1.26138.8.35.14.18.1.1.276	Integer	276
ibdot1sMstVID.277	.3.6.1.4.1.26138.8.35.14.18.1.1.277	Integer	277
ibdot1sMstVID.278	.3.6.1.4.1.26138.8.35.14.18.1.1.278	Integer	278
ibdot1sMstVID.279	.3.6.1.4.1.26138.8.35.14.18.1.1.279	Integer	279
ibdot1sMstVID.280	.3.6.1.4.1.26138.8.35.14.18.1.1.280	Integer	280
ibdot1sMstVID.281	.3.6.1.4.1.26138.8.35.14.18.1.1.281	Integer	281
ibdot1sMstVID.282	.3.6.1.4.1.26138.8.35.14.18.1.1.282	Integer	282
ibdot1sMstVID.283	.3.6.1.4.1.26138.8.35.14.18.1.1.283	Integer	283
ibdot1sMstVID.284	.3.6.1.4.1.26138.8.35.14.18.1.1.284	Integer	284
ibdot1sMstVID.285	.3.6.1.4.1.26138.8.35.14.18.1.1.285	Integer	285
ibdot1sMstVID.286	.3.6.1.4.1.26138.8.35.14.18.1.1.286	Integer	286
ibdot1sMstVID.287	.3.6.1.4.1.26138.8.35.14.18.1.1.287	Integer	287
ibdot1sMstVID.288	.3.6.1.4.1.26138.8.35.14.18.1.1.288	Integer	288
ibdot1sMstVID.289	.3.6.1.4.1.26138.8.35.14.18.1.1.289	Integer	289

Name	OID	Value Type	Value Example
ibdot1sMstVID.290	.3.6.1.4.1.26138.8.35.14.18.1.1.290	Integer	290
ibdot1sMstVID.291	.3.6.1.4.1.26138.8.35.14.18.1.1.291	Integer	291
ibdot1sMstVID.292	.3.6.1.4.1.26138.8.35.14.18.1.1.292	Integer	292
ibdot1sMstVID.293	.3.6.1.4.1.26138.8.35.14.18.1.1.293	Integer	293
ibdot1sMstVID.294	.3.6.1.4.1.26138.8.35.14.18.1.1.294	Integer	294
ibdot1sMstVID.295	.3.6.1.4.1.26138.8.35.14.18.1.1.295	Integer	295
ibdot1sMstVID.296	.3.6.1.4.1.26138.8.35.14.18.1.1.296	Integer	296
ibdot1sMstVID.297	.3.6.1.4.1.26138.8.35.14.18.1.1.297	Integer	297
ibdot1sMstVID.298	.3.6.1.4.1.26138.8.35.14.18.1.1.298	Integer	298
ibdot1sMstVID.299	.3.6.1.4.1.26138.8.35.14.18.1.1.299	Integer	299
ibdot1sMstVID.300	.3.6.1.4.1.26138.8.35.14.18.1.1.300	Integer	300
ibdot1sMstVID.301	.3.6.1.4.1.26138.8.35.14.18.1.1.301	Integer	301
ibdot1sMstVID.302	.3.6.1.4.1.26138.8.35.14.18.1.1.302	Integer	302
ibdot1sMstVID.303	.3.6.1.4.1.26138.8.35.14.18.1.1.303	Integer	303
ibdot1sMstVID.304	.3.6.1.4.1.26138.8.35.14.18.1.1.304	Integer	304
ibdot1sMstVID.305	.3.6.1.4.1.26138.8.35.14.18.1.1.305	Integer	305
ibdot1sMstVID.306	.3.6.1.4.1.26138.8.35.14.18.1.1.306	Integer	306
ibdot1sMstVID.307	.3.6.1.4.1.26138.8.35.14.18.1.1.307	Integer	307
ibdot1sMstVID.308	.3.6.1.4.1.26138.8.35.14.18.1.1.308	Integer	308
ibdot1sMstVID.309	.3.6.1.4.1.26138.8.35.14.18.1.1.309	Integer	309
ibdot1sMstVID.310	.3.6.1.4.1.26138.8.35.14.18.1.1.310	Integer	310
ibdot1sMstVID.311	.3.6.1.4.1.26138.8.35.14.18.1.1.311	Integer	311
ibdot1sMstVID.312	.3.6.1.4.1.26138.8.35.14.18.1.1.312	Integer	312
ibdot1sMstVID.313	.3.6.1.4.1.26138.8.35.14.18.1.1.313	Integer	313
ibdot1sMstVID.314	.3.6.1.4.1.26138.8.35.14.18.1.1.314	Integer	314
ibdot1sMstVID.315	.3.6.1.4.1.26138.8.35.14.18.1.1.315	Integer	315
ibdot1sMstVID.316	.3.6.1.4.1.26138.8.35.14.18.1.1.316	Integer	316
ibdot1sMstVID.317	.3.6.1.4.1.26138.8.35.14.18.1.1.317	Integer	317
ibdot1sMstVID.318	.3.6.1.4.1.26138.8.35.14.18.1.1.318	Integer	318
ibdot1sMstVID.319	.3.6.1.4.1.26138.8.35.14.18.1.1.319	Integer	319
ibdot1sMstVID.320	.3.6.1.4.1.26138.8.35.14.18.1.1.320	Integer	320
ibdot1sMstVID.321	.3.6.1.4.1.26138.8.35.14.18.1.1.321	Integer	321
ibdot1sMstVID.322	.3.6.1.4.1.26138.8.35.14.18.1.1.322	Integer	322
ibdot1sMstVID.323	.3.6.1.4.1.26138.8.35.14.18.1.1.323	Integer	323
ibdot1sMstVID.324	.3.6.1.4.1.26138.8.35.14.18.1.1.324	Integer	324
ibdot1sMstVID.325	.3.6.1.4.1.26138.8.35.14.18.1.1.325	Integer	325
ibdot1sMstVID.326	.3.6.1.4.1.26138.8.35.14.18.1.1.326	Integer	326
ibdot1sMstVID.327	.3.6.1.4.1.26138.8.35.14.18.1.1.327	Integer	327
ibdot1sMstVID.328	.3.6.1.4.1.26138.8.35.14.18.1.1.328	Integer	328
ibdot1sMstVID.329	.3.6.1.4.1.26138.8.35.14.18.1.1.329	Integer	329
ibdot1sMstVID.330	.3.6.1.4.1.26138.8.35.14.18.1.1.330	Integer	330
ibdot1sMstVID.331	.3.6.1.4.1.26138.8.35.14.18.1.1.331	Integer	331
ibdot1sMstVID.332	.3.6.1.4.1.26138.8.35.14.18.1.1.332	Integer	332



Name	OID	Value Type	Value Example
ibdot1sMstVID.333	.3.6.1.4.1.26138.8.35.14.18.1.1.333	Integer	333
ibdot1sMstVID.334	.3.6.1.4.1.26138.8.35.14.18.1.1.334	Integer	334
ibdot1sMstVID.335	.3.6.1.4.1.26138.8.35.14.18.1.1.335	Integer	335
ibdot1sMstVID.336	.3.6.1.4.1.26138.8.35.14.18.1.1.336	Integer	336
ibdot1sMstVID.337	.3.6.1.4.1.26138.8.35.14.18.1.1.337	Integer	337
ibdot1sMstVID.338	.3.6.1.4.1.26138.8.35.14.18.1.1.338	Integer	338
ibdot1sMstVID.339	.3.6.1.4.1.26138.8.35.14.18.1.1.339	Integer	339
ibdot1sMstVID.340	.3.6.1.4.1.26138.8.35.14.18.1.1.340	Integer	340
ibdot1sMstVID.341	.3.6.1.4.1.26138.8.35.14.18.1.1.341	Integer	341
ibdot1sMstVID.342	.3.6.1.4.1.26138.8.35.14.18.1.1.342	Integer	342
ibdot1sMstVID.343	.3.6.1.4.1.26138.8.35.14.18.1.1.343	Integer	343
ibdot1sMstVID.344	.3.6.1.4.1.26138.8.35.14.18.1.1.344	Integer	344
ibdot1sMstVID.345	.3.6.1.4.1.26138.8.35.14.18.1.1.345	Integer	345
ibdot1sMstVID.346	.3.6.1.4.1.26138.8.35.14.18.1.1.346	Integer	346
ibdot1sMstVID.347	.3.6.1.4.1.26138.8.35.14.18.1.1.347	Integer	347
ibdot1sMstVID.348	.3.6.1.4.1.26138.8.35.14.18.1.1.348	Integer	348
ibdot1sMstVID.349	.3.6.1.4.1.26138.8.35.14.18.1.1.349	Integer	349
ibdot1sMstVID.350	.3.6.1.4.1.26138.8.35.14.18.1.1.350	Integer	350
ibdot1sMstVID.351	.3.6.1.4.1.26138.8.35.14.18.1.1.351	Integer	351
ibdot1sMstVID.352	.3.6.1.4.1.26138.8.35.14.18.1.1.352	Integer	352
ibdot1sMstVID.353	.3.6.1.4.1.26138.8.35.14.18.1.1.353	Integer	353
ibdot1sMstVID.354	.3.6.1.4.1.26138.8.35.14.18.1.1.354	Integer	354
ibdot1sMstVID.355	.3.6.1.4.1.26138.8.35.14.18.1.1.355	Integer	355
ibdot1sMstVID.356	.3.6.1.4.1.26138.8.35.14.18.1.1.356	Integer	356
ibdot1sMstVID.357	.3.6.1.4.1.26138.8.35.14.18.1.1.357	Integer	357
ibdot1sMstVID.358	.3.6.1.4.1.26138.8.35.14.18.1.1.358	Integer	358
ibdot1sMstVID.359	.3.6.1.4.1.26138.8.35.14.18.1.1.359	Integer	359
ibdot1sMstVID.360	.3.6.1.4.1.26138.8.35.14.18.1.1.360	Integer	360
ibdot1sMstVID.361	.3.6.1.4.1.26138.8.35.14.18.1.1.361	Integer	361
ibdot1sMstVID.362	.3.6.1.4.1.26138.8.35.14.18.1.1.362	Integer	362
ibdot1sMstVID.363	.3.6.1.4.1.26138.8.35.14.18.1.1.363	Integer	363
ibdot1sMstVID.364	.3.6.1.4.1.26138.8.35.14.18.1.1.364	Integer	364
ibdot1sMstVID.365	.3.6.1.4.1.26138.8.35.14.18.1.1.365	Integer	365
ibdot1sMstVID.366	.3.6.1.4.1.26138.8.35.14.18.1.1.366	Integer	366
ibdot1sMstVID.367	.3.6.1.4.1.26138.8.35.14.18.1.1.367	Integer	367
ibdot1sMstVID.368	.3.6.1.4.1.26138.8.35.14.18.1.1.368	Integer	368
ibdot1sMstVID.369	.3.6.1.4.1.26138.8.35.14.18.1.1.369	Integer	369
ibdot1sMstVID.370	.3.6.1.4.1.26138.8.35.14.18.1.1.370	Integer	370
ibdot1sMstVID.371	.3.6.1.4.1.26138.8.35.14.18.1.1.371	Integer	371
ibdot1sMstVID.372	.3.6.1.4.1.26138.8.35.14.18.1.1.372	Integer	372
ibdot1sMstVID.373	.3.6.1.4.1.26138.8.35.14.18.1.1.373	Integer	373
ibdot1sMstVID.374	.3.6.1.4.1.26138.8.35.14.18.1.1.374	Integer	374
ibdot1sMstVID.375	.3.6.1.4.1.26138.8.35.14.18.1.1.375	Integer	375



Name	OID	Value Type	Value Example
ibdot1sMstVID.376	.3.6.1.4.1.26138.8.35.14.18.1.1.376	Integer	376
ibdot1sMstVID.377	.3.6.1.4.1.26138.8.35.14.18.1.1.377	Integer	377
ibdot1sMstVID.378	.3.6.1.4.1.26138.8.35.14.18.1.1.378	Integer	378
ibdot1sMstVID.379	.3.6.1.4.1.26138.8.35.14.18.1.1.379	Integer	379
ibdot1sMstVID.380	.3.6.1.4.1.26138.8.35.14.18.1.1.380	Integer	380
ibdot1sMstVID.381	.3.6.1.4.1.26138.8.35.14.18.1.1.381	Integer	381
ibdot1sMstVID.382	.3.6.1.4.1.26138.8.35.14.18.1.1.382	Integer	382
ibdot1sMstVID.383	.3.6.1.4.1.26138.8.35.14.18.1.1.383	Integer	383
ibdot1sMstVID.384	.3.6.1.4.1.26138.8.35.14.18.1.1.384	Integer	384
ibdot1sMstVID.385	.3.6.1.4.1.26138.8.35.14.18.1.1.385	Integer	385
ibdot1sMstVID.386	.3.6.1.4.1.26138.8.35.14.18.1.1.386	Integer	386
ibdot1sMstVID.387	.3.6.1.4.1.26138.8.35.14.18.1.1.387	Integer	387
ibdot1sMstVID.388	.3.6.1.4.1.26138.8.35.14.18.1.1.388	Integer	388
ibdot1sMstVID.389	.3.6.1.4.1.26138.8.35.14.18.1.1.389	Integer	389
ibdot1sMstVID.390	.3.6.1.4.1.26138.8.35.14.18.1.1.390	Integer	390
ibdot1sMstVID.391	.3.6.1.4.1.26138.8.35.14.18.1.1.391	Integer	391
ibdot1sMstVID.392	.3.6.1.4.1.26138.8.35.14.18.1.1.392	Integer	392
ibdot1sMstVID.393	.3.6.1.4.1.26138.8.35.14.18.1.1.393	Integer	393
ibdot1sMstVID.394	.3.6.1.4.1.26138.8.35.14.18.1.1.394	Integer	394
ibdot1sMstVID.395	.3.6.1.4.1.26138.8.35.14.18.1.1.395	Integer	395
ibdot1sMstVID.396	.3.6.1.4.1.26138.8.35.14.18.1.1.396	Integer	396
ibdot1sMstVID.397	.3.6.1.4.1.26138.8.35.14.18.1.1.397	Integer	397
ibdot1sMstVID.398	.3.6.1.4.1.26138.8.35.14.18.1.1.398	Integer	398
ibdot1sMstVID.399	.3.6.1.4.1.26138.8.35.14.18.1.1.399	Integer	399
ibdot1sMstVID.400	.3.6.1.4.1.26138.8.35.14.18.1.1.400	Integer	400
ibdot1sMstVID.401	.3.6.1.4.1.26138.8.35.14.18.1.1.401	Integer	401
ibdot1sMstVID.402	.3.6.1.4.1.26138.8.35.14.18.1.1.402	Integer	402
ibdot1sMstVID.403	.3.6.1.4.1.26138.8.35.14.18.1.1.403	Integer	403
ibdot1sMstVID.404	.3.6.1.4.1.26138.8.35.14.18.1.1.404	Integer	404
ibdot1sMstVID.405	.3.6.1.4.1.26138.8.35.14.18.1.1.405	Integer	405
ibdot1sMstVID.406	.3.6.1.4.1.26138.8.35.14.18.1.1.406	Integer	406
ibdot1sMstVID.407	.3.6.1.4.1.26138.8.35.14.18.1.1.407	Integer	407
ibdot1sMstVID.408	.3.6.1.4.1.26138.8.35.14.18.1.1.408	Integer	408
ibdot1sMstVID.409	.3.6.1.4.1.26138.8.35.14.18.1.1.409	Integer	409
ibdot1sMstVID.410	.3.6.1.4.1.26138.8.35.14.18.1.1.410	Integer	410
ibdot1sMstVID.411	.3.6.1.4.1.26138.8.35.14.18.1.1.411	Integer	411
ibdot1sMstVID.412	.3.6.1.4.1.26138.8.35.14.18.1.1.412	Integer	412
ibdot1sMstVID.413	.3.6.1.4.1.26138.8.35.14.18.1.1.413	Integer	413
ibdot1sMstVID.414	.3.6.1.4.1.26138.8.35.14.18.1.1.414	Integer	414
ibdot1sMstVID.415	.3.6.1.4.1.26138.8.35.14.18.1.1.415	Integer	415
ibdot1sMstVID.416	.3.6.1.4.1.26138.8.35.14.18.1.1.416	Integer	416
ibdot1sMstVID.417	.3.6.1.4.1.26138.8.35.14.18.1.1.417	Integer	417
ibdot1sMstVID.418	.3.6.1.4.1.26138.8.35.14.18.1.1.418	Integer	418

Name	OID	Value Type	Value Example
ibdot1sMstVID.419	.3.6.1.4.1.26138.8.35.14.18.1.1.419	Integer	419
ibdot1sMstVID.420	.3.6.1.4.1.26138.8.35.14.18.1.1.420	Integer	420
ibdot1sMstVID.421	.3.6.1.4.1.26138.8.35.14.18.1.1.421	Integer	421
ibdot1sMstVID.422	.3.6.1.4.1.26138.8.35.14.18.1.1.422	Integer	422
ibdot1sMstVID.423	.3.6.1.4.1.26138.8.35.14.18.1.1.423	Integer	423
ibdot1sMstVID.424	.3.6.1.4.1.26138.8.35.14.18.1.1.424	Integer	424
ibdot1sMstVID.425	.3.6.1.4.1.26138.8.35.14.18.1.1.425	Integer	425
ibdot1sMstVID.426	.3.6.1.4.1.26138.8.35.14.18.1.1.426	Integer	426
ibdot1sMstVID.427	.3.6.1.4.1.26138.8.35.14.18.1.1.427	Integer	427
ibdot1sMstVID.428	.3.6.1.4.1.26138.8.35.14.18.1.1.428	Integer	428
ibdot1sMstVID.429	.3.6.1.4.1.26138.8.35.14.18.1.1.429	Integer	429
ibdot1sMstVID.430	.3.6.1.4.1.26138.8.35.14.18.1.1.430	Integer	430
ibdot1sMstVID.431	.3.6.1.4.1.26138.8.35.14.18.1.1.431	Integer	431
ibdot1sMstVID.432	.3.6.1.4.1.26138.8.35.14.18.1.1.432	Integer	432
ibdot1sMstVID.433	.3.6.1.4.1.26138.8.35.14.18.1.1.433	Integer	433
ibdot1sMstVID.434	.3.6.1.4.1.26138.8.35.14.18.1.1.434	Integer	434
ibdot1sMstVID.435	.3.6.1.4.1.26138.8.35.14.18.1.1.435	Integer	435
ibdot1sMstVID.436	.3.6.1.4.1.26138.8.35.14.18.1.1.436	Integer	436
ibdot1sMstVID.437	.3.6.1.4.1.26138.8.35.14.18.1.1.437	Integer	437
ibdot1sMstVID.438	.3.6.1.4.1.26138.8.35.14.18.1.1.438	Integer	438
ibdot1sMstVID.439	.3.6.1.4.1.26138.8.35.14.18.1.1.439	Integer	439
ibdot1sMstVID.440	.3.6.1.4.1.26138.8.35.14.18.1.1.440	Integer	440
ibdot1sMstVID.441	.3.6.1.4.1.26138.8.35.14.18.1.1.441	Integer	441
ibdot1sMstVID.442	.3.6.1.4.1.26138.8.35.14.18.1.1.442	Integer	442
ibdot1sMstVID.443	.3.6.1.4.1.26138.8.35.14.18.1.1.443	Integer	443
ibdot1sMstVID.444	.3.6.1.4.1.26138.8.35.14.18.1.1.444	Integer	444
ibdot1sMstVID.445	.3.6.1.4.1.26138.8.35.14.18.1.1.445	Integer	445
ibdot1sMstVID.446	.3.6.1.4.1.26138.8.35.14.18.1.1.446	Integer	446
ibdot1sMstVID.447	.3.6.1.4.1.26138.8.35.14.18.1.1.447	Integer	447
ibdot1sMstVID.448	.3.6.1.4.1.26138.8.35.14.18.1.1.448	Integer	448
ibdot1sMstVID.449	.3.6.1.4.1.26138.8.35.14.18.1.1.449	Integer	449
ibdot1sMstVID.450	.3.6.1.4.1.26138.8.35.14.18.1.1.450	Integer	450
ibdot1sMstVID.451	.3.6.1.4.1.26138.8.35.14.18.1.1.451	Integer	451
ibdot1sMstVID.452	.3.6.1.4.1.26138.8.35.14.18.1.1.452	Integer	452
ibdot1sMstVID.453	.3.6.1.4.1.26138.8.35.14.18.1.1.453	Integer	453
ibdot1sMstVID.454	.3.6.1.4.1.26138.8.35.14.18.1.1.454	Integer	454
ibdot1sMstVID.455	.3.6.1.4.1.26138.8.35.14.18.1.1.455	Integer	455
ibdot1sMstVID.456	.3.6.1.4.1.26138.8.35.14.18.1.1.456	Integer	456
ibdot1sMstVID.457	.3.6.1.4.1.26138.8.35.14.18.1.1.457	Integer	457
ibdot1sMstVID.458	.3.6.1.4.1.26138.8.35.14.18.1.1.458	Integer	458
ibdot1sMstVID.459	.3.6.1.4.1.26138.8.35.14.18.1.1.459	Integer	459
ibdot1sMstVID.460	.3.6.1.4.1.26138.8.35.14.18.1.1.460	Integer	460
ibdot1sMstVID.461	.3.6.1.4.1.26138.8.35.14.18.1.1.461	Integer	461

Name	OID	Value Type	Value Example
ibdot1sMstVID.462	.3.6.1.4.1.26138.8.35.14.18.1.1.462	Integer	462
ibdot1sMstVID.463	.3.6.1.4.1.26138.8.35.14.18.1.1.463	Integer	463
ibdot1sMstVID.464	.3.6.1.4.1.26138.8.35.14.18.1.1.464	Integer	464
ibdot1sMstVID.465	.3.6.1.4.1.26138.8.35.14.18.1.1.465	Integer	465
ibdot1sMstVID.466	.3.6.1.4.1.26138.8.35.14.18.1.1.466	Integer	466
ibdot1sMstVID.467	.3.6.1.4.1.26138.8.35.14.18.1.1.467	Integer	467
ibdot1sMstVID.468	.3.6.1.4.1.26138.8.35.14.18.1.1.468	Integer	468
ibdot1sMstVID.469	.3.6.1.4.1.26138.8.35.14.18.1.1.469	Integer	469
ibdot1sMstVID.470	.3.6.1.4.1.26138.8.35.14.18.1.1.470	Integer	470
ibdot1sMstVID.471	.3.6.1.4.1.26138.8.35.14.18.1.1.471	Integer	471
ibdot1sMstVID.472	.3.6.1.4.1.26138.8.35.14.18.1.1.472	Integer	472
ibdot1sMstVID.473	.3.6.1.4.1.26138.8.35.14.18.1.1.473	Integer	473
ibdot1sMstVID.474	.3.6.1.4.1.26138.8.35.14.18.1.1.474	Integer	474
ibdot1sMstVID.475	.3.6.1.4.1.26138.8.35.14.18.1.1.475	Integer	475
ibdot1sMstVID.476	.3.6.1.4.1.26138.8.35.14.18.1.1.476	Integer	476
ibdot1sMstVID.477	.3.6.1.4.1.26138.8.35.14.18.1.1.477	Integer	477
ibdot1sMstVID.478	.3.6.1.4.1.26138.8.35.14.18.1.1.478	Integer	478
ibdot1sMstVID.479	.3.6.1.4.1.26138.8.35.14.18.1.1.479	Integer	479
ibdot1sMstVID.480	.3.6.1.4.1.26138.8.35.14.18.1.1.480	Integer	480
ibdot1sMstVID.481	.3.6.1.4.1.26138.8.35.14.18.1.1.481	Integer	481
ibdot1sMstVID.482	.3.6.1.4.1.26138.8.35.14.18.1.1.482	Integer	482
ibdot1sMstVID.483	.3.6.1.4.1.26138.8.35.14.18.1.1.483	Integer	483
ibdot1sMstVID.484	.3.6.1.4.1.26138.8.35.14.18.1.1.484	Integer	484
ibdot1sMstVID.485	.3.6.1.4.1.26138.8.35.14.18.1.1.485	Integer	485
ibdot1sMstVID.486	.3.6.1.4.1.26138.8.35.14.18.1.1.486	Integer	486
ibdot1sMstVID.487	.3.6.1.4.1.26138.8.35.14.18.1.1.487	Integer	487
ibdot1sMstVID.488	.3.6.1.4.1.26138.8.35.14.18.1.1.488	Integer	488
ibdot1sMstVID.489	.3.6.1.4.1.26138.8.35.14.18.1.1.489	Integer	489
ibdot1sMstVID.490	.3.6.1.4.1.26138.8.35.14.18.1.1.490	Integer	490
ibdot1sMstVID.491	.3.6.1.4.1.26138.8.35.14.18.1.1.491	Integer	491
ibdot1sMstVID.492	.3.6.1.4.1.26138.8.35.14.18.1.1.492	Integer	492
ibdot1sMstVID.493	.3.6.1.4.1.26138.8.35.14.18.1.1.493	Integer	493
ibdot1sMstVID.494	.3.6.1.4.1.26138.8.35.14.18.1.1.494	Integer	494
ibdot1sMstVID.495	.3.6.1.4.1.26138.8.35.14.18.1.1.495	Integer	495
ibdot1sMstVID.496	.3.6.1.4.1.26138.8.35.14.18.1.1.496	Integer	496
ibdot1sMstVID.497	.3.6.1.4.1.26138.8.35.14.18.1.1.497	Integer	497
ibdot1sMstVID.498	.3.6.1.4.1.26138.8.35.14.18.1.1.498	Integer	498
ibdot1sMstVID.499	.3.6.1.4.1.26138.8.35.14.18.1.1.499	Integer	499
ibdot1sMstVID.500	.3.6.1.4.1.26138.8.35.14.18.1.1.500	Integer	500
ibdot1sMstVID.501	.3.6.1.4.1.26138.8.35.14.18.1.1.501	Integer	501
ibdot1sMstVID.502	.3.6.1.4.1.26138.8.35.14.18.1.1.502	Integer	502
ibdot1sMstVID.503	.3.6.1.4.1.26138.8.35.14.18.1.1.503	Integer	503
ibdot1sMstVID.504	.3.6.1.4.1.26138.8.35.14.18.1.1.504	Integer	504

Name	OID	Value Type	Value Example
ibdot1sMstVID.505	.3.6.1.4.1.26138.8.35.14.18.1.1.505	Integer	505
ibdot1sMstVID.506	.3.6.1.4.1.26138.8.35.14.18.1.1.506	Integer	506
ibdot1sMstVID.507	.3.6.1.4.1.26138.8.35.14.18.1.1.507	Integer	507
ibdot1sMstVID.508	.3.6.1.4.1.26138.8.35.14.18.1.1.508	Integer	508
ibdot1sMstVID.509	.3.6.1.4.1.26138.8.35.14.18.1.1.509	Integer	509
ibdot1sMstVID.510	.3.6.1.4.1.26138.8.35.14.18.1.1.510	Integer	510
ibdot1sMstVID.511	.3.6.1.4.1.26138.8.35.14.18.1.1.511	Integer	511
ibdot1sMstVID.512	.3.6.1.4.1.26138.8.35.14.18.1.1.512	Integer	512
ibdot1sMstVID.513	.3.6.1.4.1.26138.8.35.14.18.1.1.513	Integer	513
ibdot1sMstVID.514	.3.6.1.4.1.26138.8.35.14.18.1.1.514	Integer	514
ibdot1sMstVID.515	.3.6.1.4.1.26138.8.35.14.18.1.1.515	Integer	515
ibdot1sMstVID.516	.3.6.1.4.1.26138.8.35.14.18.1.1.516	Integer	516
ibdot1sMstVID.517	.3.6.1.4.1.26138.8.35.14.18.1.1.517	Integer	517
ibdot1sMstVID.518	.3.6.1.4.1.26138.8.35.14.18.1.1.518	Integer	518
ibdot1sMstVID.519	.3.6.1.4.1.26138.8.35.14.18.1.1.519	Integer	519
ibdot1sMstVID.520	.3.6.1.4.1.26138.8.35.14.18.1.1.520	Integer	520
ibdot1sMstVID.521	.3.6.1.4.1.26138.8.35.14.18.1.1.521	Integer	521
ibdot1sMstVID.522	.3.6.1.4.1.26138.8.35.14.18.1.1.522	Integer	522
ibdot1sMstVID.523	.3.6.1.4.1.26138.8.35.14.18.1.1.523	Integer	523
ibdot1sMstVID.524	.3.6.1.4.1.26138.8.35.14.18.1.1.524	Integer	524
ibdot1sMstVID.525	.3.6.1.4.1.26138.8.35.14.18.1.1.525	Integer	525
ibdot1sMstVID.526	.3.6.1.4.1.26138.8.35.14.18.1.1.526	Integer	526
ibdot1sMstVID.527	.3.6.1.4.1.26138.8.35.14.18.1.1.527	Integer	527
ibdot1sMstVID.528	.3.6.1.4.1.26138.8.35.14.18.1.1.528	Integer	528
ibdot1sMstVID.529	.3.6.1.4.1.26138.8.35.14.18.1.1.529	Integer	529
ibdot1sMstVID.530	.3.6.1.4.1.26138.8.35.14.18.1.1.530	Integer	530
ibdot1sMstVID.531	.3.6.1.4.1.26138.8.35.14.18.1.1.531	Integer	531
ibdot1sMstVID.532	.3.6.1.4.1.26138.8.35.14.18.1.1.532	Integer	532
ibdot1sMstVID.533	.3.6.1.4.1.26138.8.35.14.18.1.1.533	Integer	533
ibdot1sMstVID.534	.3.6.1.4.1.26138.8.35.14.18.1.1.534	Integer	534
ibdot1sMstVID.535	.3.6.1.4.1.26138.8.35.14.18.1.1.535	Integer	535
ibdot1sMstVID.536	.3.6.1.4.1.26138.8.35.14.18.1.1.536	Integer	536
ibdot1sMstVID.537	.3.6.1.4.1.26138.8.35.14.18.1.1.537	Integer	537
ibdot1sMstVID.538	.3.6.1.4.1.26138.8.35.14.18.1.1.538	Integer	538
ibdot1sMstVID.539	.3.6.1.4.1.26138.8.35.14.18.1.1.539	Integer	539
ibdot1sMstVID.540	.3.6.1.4.1.26138.8.35.14.18.1.1.540	Integer	540
ibdot1sMstVID.541	.3.6.1.4.1.26138.8.35.14.18.1.1.541	Integer	541
ibdot1sMstVID.542	.3.6.1.4.1.26138.8.35.14.18.1.1.542	Integer	542
ibdot1sMstVID.543	.3.6.1.4.1.26138.8.35.14.18.1.1.543	Integer	543
ibdot1sMstVID.544	.3.6.1.4.1.26138.8.35.14.18.1.1.544	Integer	544
ibdot1sMstVID.545	.3.6.1.4.1.26138.8.35.14.18.1.1.545	Integer	545
ibdot1sMstVID.546	.3.6.1.4.1.26138.8.35.14.18.1.1.546	Integer	546
ibdot1sMstVID.547	.3.6.1.4.1.26138.8.35.14.18.1.1.547	Integer	547

Name	OID	Value Type	Value Example
ibdot1sMstVID.548	.3.6.1.4.1.26138.8.35.14.18.1.1.548	Integer	548
ibdot1sMstVID.549	.3.6.1.4.1.26138.8.35.14.18.1.1.549	Integer	549
ibdot1sMstVID.550	.3.6.1.4.1.26138.8.35.14.18.1.1.550	Integer	550
ibdot1sMstVID.551	.3.6.1.4.1.26138.8.35.14.18.1.1.551	Integer	551
ibdot1sMstVID.552	.3.6.1.4.1.26138.8.35.14.18.1.1.552	Integer	552
ibdot1sMstVID.553	.3.6.1.4.1.26138.8.35.14.18.1.1.553	Integer	553
ibdot1sMstVID.554	.3.6.1.4.1.26138.8.35.14.18.1.1.554	Integer	554
ibdot1sMstVID.555	.3.6.1.4.1.26138.8.35.14.18.1.1.555	Integer	555
ibdot1sMstVID.556	.3.6.1.4.1.26138.8.35.14.18.1.1.556	Integer	556
ibdot1sMstVID.557	.3.6.1.4.1.26138.8.35.14.18.1.1.557	Integer	557
ibdot1sMstVID.558	.3.6.1.4.1.26138.8.35.14.18.1.1.558	Integer	558
ibdot1sMstVID.559	.3.6.1.4.1.26138.8.35.14.18.1.1.559	Integer	559
ibdot1sMstVID.560	.3.6.1.4.1.26138.8.35.14.18.1.1.560	Integer	560
ibdot1sMstVID.561	.3.6.1.4.1.26138.8.35.14.18.1.1.561	Integer	561
ibdot1sMstVID.562	.3.6.1.4.1.26138.8.35.14.18.1.1.562	Integer	562
ibdot1sMstVID.563	.3.6.1.4.1.26138.8.35.14.18.1.1.563	Integer	563
ibdot1sMstVID.564	.3.6.1.4.1.26138.8.35.14.18.1.1.564	Integer	564
ibdot1sMstVID.565	.3.6.1.4.1.26138.8.35.14.18.1.1.565	Integer	565
ibdot1sMstVID.566	.3.6.1.4.1.26138.8.35.14.18.1.1.566	Integer	566
ibdot1sMstVID.567	.3.6.1.4.1.26138.8.35.14.18.1.1.567	Integer	567
ibdot1sMstVID.568	.3.6.1.4.1.26138.8.35.14.18.1.1.568	Integer	568
ibdot1sMstVID.569	.3.6.1.4.1.26138.8.35.14.18.1.1.569	Integer	569
ibdot1sMstVID.570	.3.6.1.4.1.26138.8.35.14.18.1.1.570	Integer	570
ibdot1sMstVID.571	.3.6.1.4.1.26138.8.35.14.18.1.1.571	Integer	571
ibdot1sMstVID.572	.3.6.1.4.1.26138.8.35.14.18.1.1.572	Integer	572
ibdot1sMstVID.573	.3.6.1.4.1.26138.8.35.14.18.1.1.573	Integer	573
ibdot1sMstVID.574	.3.6.1.4.1.26138.8.35.14.18.1.1.574	Integer	574
ibdot1sMstVID.575	.3.6.1.4.1.26138.8.35.14.18.1.1.575	Integer	575
ibdot1sMstVID.576	.3.6.1.4.1.26138.8.35.14.18.1.1.576	Integer	576
ibdot1sMstVID.577	.3.6.1.4.1.26138.8.35.14.18.1.1.577	Integer	577
ibdot1sMstVID.578	.3.6.1.4.1.26138.8.35.14.18.1.1.578	Integer	578
ibdot1sMstVID.579	.3.6.1.4.1.26138.8.35.14.18.1.1.579	Integer	579
ibdot1sMstVID.580	.3.6.1.4.1.26138.8.35.14.18.1.1.580	Integer	580
ibdot1sMstVID.581	.3.6.1.4.1.26138.8.35.14.18.1.1.581	Integer	581
ibdot1sMstVID.582	.3.6.1.4.1.26138.8.35.14.18.1.1.582	Integer	582
ibdot1sMstVID.583	.3.6.1.4.1.26138.8.35.14.18.1.1.583	Integer	583
ibdot1sMstVID.584	.3.6.1.4.1.26138.8.35.14.18.1.1.584	Integer	584
ibdot1sMstVID.585	.3.6.1.4.1.26138.8.35.14.18.1.1.585	Integer	585
ibdot1sMstVID.586	.3.6.1.4.1.26138.8.35.14.18.1.1.586	Integer	586
ibdot1sMstVID.587	.3.6.1.4.1.26138.8.35.14.18.1.1.587	Integer	587
ibdot1sMstVID.588	.3.6.1.4.1.26138.8.35.14.18.1.1.588	Integer	588
ibdot1sMstVID.589	.3.6.1.4.1.26138.8.35.14.18.1.1.589	Integer	589
ibdot1sMstVID.590	.3.6.1.4.1.26138.8.35.14.18.1.1.590	Integer	590

Name	OID	Value Type	Value Example
ibdot1sMstVID.591	.3.6.1.4.1.26138.8.35.14.18.1.1.591	Integer	591
ibdot1sMstVID.592	.3.6.1.4.1.26138.8.35.14.18.1.1.592	Integer	592
ibdot1sMstVID.593	.3.6.1.4.1.26138.8.35.14.18.1.1.593	Integer	593
ibdot1sMstVID.594	.3.6.1.4.1.26138.8.35.14.18.1.1.594	Integer	594
ibdot1sMstVID.595	.3.6.1.4.1.26138.8.35.14.18.1.1.595	Integer	595
ibdot1sMstVID.596	.3.6.1.4.1.26138.8.35.14.18.1.1.596	Integer	596
ibdot1sMstVID.597	.3.6.1.4.1.26138.8.35.14.18.1.1.597	Integer	597
ibdot1sMstVID.598	.3.6.1.4.1.26138.8.35.14.18.1.1.598	Integer	598
ibdot1sMstVID.599	.3.6.1.4.1.26138.8.35.14.18.1.1.599	Integer	599
ibdot1sMstVID.600	.3.6.1.4.1.26138.8.35.14.18.1.1.600	Integer	600
ibdot1sMstVID.601	.3.6.1.4.1.26138.8.35.14.18.1.1.601	Integer	601
ibdot1sMstVID.602	.3.6.1.4.1.26138.8.35.14.18.1.1.602	Integer	602
ibdot1sMstVID.603	.3.6.1.4.1.26138.8.35.14.18.1.1.603	Integer	603
ibdot1sMstVID.604	.3.6.1.4.1.26138.8.35.14.18.1.1.604	Integer	604
ibdot1sMstVID.605	.3.6.1.4.1.26138.8.35.14.18.1.1.605	Integer	605
ibdot1sMstVID.606	.3.6.1.4.1.26138.8.35.14.18.1.1.606	Integer	606
ibdot1sMstVID.607	.3.6.1.4.1.26138.8.35.14.18.1.1.607	Integer	607
ibdot1sMstVID.608	.3.6.1.4.1.26138.8.35.14.18.1.1.608	Integer	608
ibdot1sMstVID.609	.3.6.1.4.1.26138.8.35.14.18.1.1.609	Integer	609
ibdot1sMstVID.610	.3.6.1.4.1.26138.8.35.14.18.1.1.610	Integer	610
ibdot1sMstVID.611	.3.6.1.4.1.26138.8.35.14.18.1.1.611	Integer	611
ibdot1sMstVID.612	.3.6.1.4.1.26138.8.35.14.18.1.1.612	Integer	612
ibdot1sMstVID.613	.3.6.1.4.1.26138.8.35.14.18.1.1.613	Integer	613
ibdot1sMstVID.614	.3.6.1.4.1.26138.8.35.14.18.1.1.614	Integer	614
ibdot1sMstVID.615	.3.6.1.4.1.26138.8.35.14.18.1.1.615	Integer	615
ibdot1sMstVID.616	.3.6.1.4.1.26138.8.35.14.18.1.1.616	Integer	616
ibdot1sMstVID.617	.3.6.1.4.1.26138.8.35.14.18.1.1.617	Integer	617
ibdot1sMstVID.618	.3.6.1.4.1.26138.8.35.14.18.1.1.618	Integer	618
ibdot1sMstVID.619	.3.6.1.4.1.26138.8.35.14.18.1.1.619	Integer	619
ibdot1sMstVID.620	.3.6.1.4.1.26138.8.35.14.18.1.1.620	Integer	620
ibdot1sMstVID.621	.3.6.1.4.1.26138.8.35.14.18.1.1.621	Integer	621
ibdot1sMstVID.622	.3.6.1.4.1.26138.8.35.14.18.1.1.622	Integer	622
ibdot1sMstVID.623	.3.6.1.4.1.26138.8.35.14.18.1.1.623	Integer	623
ibdot1sMstVID.624	.3.6.1.4.1.26138.8.35.14.18.1.1.624	Integer	624
ibdot1sMstVID.625	.3.6.1.4.1.26138.8.35.14.18.1.1.625	Integer	625
ibdot1sMstVID.626	.3.6.1.4.1.26138.8.35.14.18.1.1.626	Integer	626
ibdot1sMstVID.627	.3.6.1.4.1.26138.8.35.14.18.1.1.627	Integer	627
ibdot1sMstVID.628	.3.6.1.4.1.26138.8.35.14.18.1.1.628	Integer	628
ibdot1sMstVID.629	.3.6.1.4.1.26138.8.35.14.18.1.1.629	Integer	629
ibdot1sMstVID.630	.3.6.1.4.1.26138.8.35.14.18.1.1.630	Integer	630
ibdot1sMstVID.631	.3.6.1.4.1.26138.8.35.14.18.1.1.631	Integer	631
ibdot1sMstVID.632	.3.6.1.4.1.26138.8.35.14.18.1.1.632	Integer	632
ibdot1sMstVID.633	.3.6.1.4.1.26138.8.35.14.18.1.1.633	Integer	633

Name	OID	Value Type	Value Example
ibdot1sMstVID.634	.3.6.1.4.1.26138.8.35.14.18.1.1.634	Integer	634
ibdot1sMstVID.635	.3.6.1.4.1.26138.8.35.14.18.1.1.635	Integer	635
ibdot1sMstVID.636	.3.6.1.4.1.26138.8.35.14.18.1.1.636	Integer	636
ibdot1sMstVID.637	.3.6.1.4.1.26138.8.35.14.18.1.1.637	Integer	637
ibdot1sMstVID.638	.3.6.1.4.1.26138.8.35.14.18.1.1.638	Integer	638
ibdot1sMstVID.639	.3.6.1.4.1.26138.8.35.14.18.1.1.639	Integer	639
ibdot1sMstVID.640	.3.6.1.4.1.26138.8.35.14.18.1.1.640	Integer	640
ibdot1sMstVID.641	.3.6.1.4.1.26138.8.35.14.18.1.1.641	Integer	641
ibdot1sMstVID.642	.3.6.1.4.1.26138.8.35.14.18.1.1.642	Integer	642
ibdot1sMstVID.643	.3.6.1.4.1.26138.8.35.14.18.1.1.643	Integer	643
ibdot1sMstVID.644	.3.6.1.4.1.26138.8.35.14.18.1.1.644	Integer	644
ibdot1sMstVID.645	.3.6.1.4.1.26138.8.35.14.18.1.1.645	Integer	645
ibdot1sMstVID.646	.3.6.1.4.1.26138.8.35.14.18.1.1.646	Integer	646
ibdot1sMstVID.647	.3.6.1.4.1.26138.8.35.14.18.1.1.647	Integer	647
ibdot1sMstVID.648	.3.6.1.4.1.26138.8.35.14.18.1.1.648	Integer	648
ibdot1sMstVID.649	.3.6.1.4.1.26138.8.35.14.18.1.1.649	Integer	649
ibdot1sMstVID.650	.3.6.1.4.1.26138.8.35.14.18.1.1.650	Integer	650
ibdot1sMstVID.651	.3.6.1.4.1.26138.8.35.14.18.1.1.651	Integer	651
ibdot1sMstVID.652	.3.6.1.4.1.26138.8.35.14.18.1.1.652	Integer	652
ibdot1sMstVID.653	.3.6.1.4.1.26138.8.35.14.18.1.1.653	Integer	653
ibdot1sMstVID.654	.3.6.1.4.1.26138.8.35.14.18.1.1.654	Integer	654
ibdot1sMstVID.655	.3.6.1.4.1.26138.8.35.14.18.1.1.655	Integer	655
ibdot1sMstVID.656	.3.6.1.4.1.26138.8.35.14.18.1.1.656	Integer	656
ibdot1sMstVID.657	.3.6.1.4.1.26138.8.35.14.18.1.1.657	Integer	657
ibdot1sMstVID.658	.3.6.1.4.1.26138.8.35.14.18.1.1.658	Integer	658
ibdot1sMstVID.659	.3.6.1.4.1.26138.8.35.14.18.1.1.659	Integer	659
ibdot1sMstVID.660	.3.6.1.4.1.26138.8.35.14.18.1.1.660	Integer	660
ibdot1sMstVID.661	.3.6.1.4.1.26138.8.35.14.18.1.1.661	Integer	661
ibdot1sMstVID.662	.3.6.1.4.1.26138.8.35.14.18.1.1.662	Integer	662
ibdot1sMstVID.663	.3.6.1.4.1.26138.8.35.14.18.1.1.663	Integer	663
ibdot1sMstVID.664	.3.6.1.4.1.26138.8.35.14.18.1.1.664	Integer	664
ibdot1sMstVID.665	.3.6.1.4.1.26138.8.35.14.18.1.1.665	Integer	665
ibdot1sMstVID.666	.3.6.1.4.1.26138.8.35.14.18.1.1.666	Integer	666
ibdot1sMstVID.667	.3.6.1.4.1.26138.8.35.14.18.1.1.667	Integer	667
ibdot1sMstVID.668	.3.6.1.4.1.26138.8.35.14.18.1.1.668	Integer	668
ibdot1sMstVID.669	.3.6.1.4.1.26138.8.35.14.18.1.1.669	Integer	669
ibdot1sMstVID.670	.3.6.1.4.1.26138.8.35.14.18.1.1.670	Integer	670
ibdot1sMstVID.671	.3.6.1.4.1.26138.8.35.14.18.1.1.671	Integer	671
ibdot1sMstVID.672	.3.6.1.4.1.26138.8.35.14.18.1.1.672	Integer	672
ibdot1sMstVID.673	.3.6.1.4.1.26138.8.35.14.18.1.1.673	Integer	673
ibdot1sMstVID.674	.3.6.1.4.1.26138.8.35.14.18.1.1.674	Integer	674
ibdot1sMstVID.675	.3.6.1.4.1.26138.8.35.14.18.1.1.675	Integer	675
ibdot1sMstVID.676	.3.6.1.4.1.26138.8.35.14.18.1.1.676	Integer	676



Name	OID	Value Type	Value Example
ibdot1sMstVID.677	.3.6.1.4.1.26138.8.35.14.18.1.1.677	Integer	677
ibdot1sMstVID.678	.3.6.1.4.1.26138.8.35.14.18.1.1.678	Integer	678
ibdot1sMstVID.679	.3.6.1.4.1.26138.8.35.14.18.1.1.679	Integer	679
ibdot1sMstVID.680	.3.6.1.4.1.26138.8.35.14.18.1.1.680	Integer	680
ibdot1sMstVID.681	.3.6.1.4.1.26138.8.35.14.18.1.1.681	Integer	681
ibdot1sMstVID.682	.3.6.1.4.1.26138.8.35.14.18.1.1.682	Integer	682
ibdot1sMstVID.683	.3.6.1.4.1.26138.8.35.14.18.1.1.683	Integer	683
ibdot1sMstVID.684	.3.6.1.4.1.26138.8.35.14.18.1.1.684	Integer	684
ibdot1sMstVID.685	.3.6.1.4.1.26138.8.35.14.18.1.1.685	Integer	685
ibdot1sMstVID.686	.3.6.1.4.1.26138.8.35.14.18.1.1.686	Integer	686
ibdot1sMstVID.687	.3.6.1.4.1.26138.8.35.14.18.1.1.687	Integer	687
ibdot1sMstVID.688	.3.6.1.4.1.26138.8.35.14.18.1.1.688	Integer	688
ibdot1sMstVID.689	.3.6.1.4.1.26138.8.35.14.18.1.1.689	Integer	689
ibdot1sMstVID.690	.3.6.1.4.1.26138.8.35.14.18.1.1.690	Integer	690
ibdot1sMstVID.691	.3.6.1.4.1.26138.8.35.14.18.1.1.691	Integer	691
ibdot1sMstVID.692	.3.6.1.4.1.26138.8.35.14.18.1.1.692	Integer	692
ibdot1sMstVID.693	.3.6.1.4.1.26138.8.35.14.18.1.1.693	Integer	693
ibdot1sMstVID.694	.3.6.1.4.1.26138.8.35.14.18.1.1.694	Integer	694
ibdot1sMstVID.695	.3.6.1.4.1.26138.8.35.14.18.1.1.695	Integer	695
ibdot1sMstVID.696	.3.6.1.4.1.26138.8.35.14.18.1.1.696	Integer	696
ibdot1sMstVID.697	.3.6.1.4.1.26138.8.35.14.18.1.1.697	Integer	697
ibdot1sMstVID.698	.3.6.1.4.1.26138.8.35.14.18.1.1.698	Integer	698
ibdot1sMstVID.699	.3.6.1.4.1.26138.8.35.14.18.1.1.699	Integer	699
ibdot1sMstVID.700	.3.6.1.4.1.26138.8.35.14.18.1.1.700	Integer	700
ibdot1sMstVID.701	.3.6.1.4.1.26138.8.35.14.18.1.1.701	Integer	701
ibdot1sMstVID.702	.3.6.1.4.1.26138.8.35.14.18.1.1.702	Integer	702
ibdot1sMstVID.703	.3.6.1.4.1.26138.8.35.14.18.1.1.703	Integer	703
ibdot1sMstVID.704	.3.6.1.4.1.26138.8.35.14.18.1.1.704	Integer	704
ibdot1sMstVID.705	.3.6.1.4.1.26138.8.35.14.18.1.1.705	Integer	705
ibdot1sMstVID.706	.3.6.1.4.1.26138.8.35.14.18.1.1.706	Integer	706
ibdot1sMstVID.707	.3.6.1.4.1.26138.8.35.14.18.1.1.707	Integer	707
ibdot1sMstVID.708	.3.6.1.4.1.26138.8.35.14.18.1.1.708	Integer	708
ibdot1sMstVID.709	.3.6.1.4.1.26138.8.35.14.18.1.1.709	Integer	709
ibdot1sMstVID.710	.3.6.1.4.1.26138.8.35.14.18.1.1.710	Integer	710
ibdot1sMstVID.711	.3.6.1.4.1.26138.8.35.14.18.1.1.711	Integer	711
ibdot1sMstVID.712	.3.6.1.4.1.26138.8.35.14.18.1.1.712	Integer	712
ibdot1sMstVID.713	.3.6.1.4.1.26138.8.35.14.18.1.1.713	Integer	713
ibdot1sMstVID.714	.3.6.1.4.1.26138.8.35.14.18.1.1.714	Integer	714
ibdot1sMstVID.715	.3.6.1.4.1.26138.8.35.14.18.1.1.715	Integer	715
ibdot1sMstVID.716	.3.6.1.4.1.26138.8.35.14.18.1.1.716	Integer	716
ibdot1sMstVID.717	.3.6.1.4.1.26138.8.35.14.18.1.1.717	Integer	717
ibdot1sMstVID.718	.3.6.1.4.1.26138.8.35.14.18.1.1.718	Integer	718
ibdot1sMstVID.719	.3.6.1.4.1.26138.8.35.14.18.1.1.719	Integer	719



Name	OID	Value Type	Value Example
ibdot1sMstVID.720	.3.6.1.4.1.26138.8.35.14.18.1.1.720	Integer	720
ibdot1sMstVID.721	.3.6.1.4.1.26138.8.35.14.18.1.1.721	Integer	721
ibdot1sMstVID.722	.3.6.1.4.1.26138.8.35.14.18.1.1.722	Integer	722
ibdot1sMstVID.723	.3.6.1.4.1.26138.8.35.14.18.1.1.723	Integer	723
ibdot1sMstVID.724	.3.6.1.4.1.26138.8.35.14.18.1.1.724	Integer	724
ibdot1sMstVID.725	.3.6.1.4.1.26138.8.35.14.18.1.1.725	Integer	725
ibdot1sMstVID.726	.3.6.1.4.1.26138.8.35.14.18.1.1.726	Integer	726
ibdot1sMstVID.727	.3.6.1.4.1.26138.8.35.14.18.1.1.727	Integer	727
ibdot1sMstVID.728	.3.6.1.4.1.26138.8.35.14.18.1.1.728	Integer	728
ibdot1sMstVID.729	.3.6.1.4.1.26138.8.35.14.18.1.1.729	Integer	729
ibdot1sMstVID.730	.3.6.1.4.1.26138.8.35.14.18.1.1.730	Integer	730
ibdot1sMstVID.731	.3.6.1.4.1.26138.8.35.14.18.1.1.731	Integer	731
ibdot1sMstVID.732	.3.6.1.4.1.26138.8.35.14.18.1.1.732	Integer	732
ibdot1sMstVID.733	.3.6.1.4.1.26138.8.35.14.18.1.1.733	Integer	733
ibdot1sMstVID.734	.3.6.1.4.1.26138.8.35.14.18.1.1.734	Integer	734
ibdot1sMstVID.735	.3.6.1.4.1.26138.8.35.14.18.1.1.735	Integer	735
ibdot1sMstVID.736	.3.6.1.4.1.26138.8.35.14.18.1.1.736	Integer	736
ibdot1sMstVID.737	.3.6.1.4.1.26138.8.35.14.18.1.1.737	Integer	737
ibdot1sMstVID.738	.3.6.1.4.1.26138.8.35.14.18.1.1.738	Integer	738
ibdot1sMstVID.739	.3.6.1.4.1.26138.8.35.14.18.1.1.739	Integer	739
ibdot1sMstVID.740	.3.6.1.4.1.26138.8.35.14.18.1.1.740	Integer	740
ibdot1sMstVID.741	.3.6.1.4.1.26138.8.35.14.18.1.1.741	Integer	741
ibdot1sMstVID.742	.3.6.1.4.1.26138.8.35.14.18.1.1.742	Integer	742
ibdot1sMstVID.743	.3.6.1.4.1.26138.8.35.14.18.1.1.743	Integer	743
ibdot1sMstVID.744	.3.6.1.4.1.26138.8.35.14.18.1.1.744	Integer	744
ibdot1sMstVID.745	.3.6.1.4.1.26138.8.35.14.18.1.1.745	Integer	745
ibdot1sMstVID.746	.3.6.1.4.1.26138.8.35.14.18.1.1.746	Integer	746
ibdot1sMstVID.747	.3.6.1.4.1.26138.8.35.14.18.1.1.747	Integer	747
ibdot1sMstVID.748	.3.6.1.4.1.26138.8.35.14.18.1.1.748	Integer	748
ibdot1sMstVID.749	.3.6.1.4.1.26138.8.35.14.18.1.1.749	Integer	749
ibdot1sMstVID.750	.3.6.1.4.1.26138.8.35.14.18.1.1.750	Integer	750
ibdot1sMstVID.751	.3.6.1.4.1.26138.8.35.14.18.1.1.751	Integer	751
ibdot1sMstVID.752	.3.6.1.4.1.26138.8.35.14.18.1.1.752	Integer	752
ibdot1sMstVID.753	.3.6.1.4.1.26138.8.35.14.18.1.1.753	Integer	753
ibdot1sMstVID.754	.3.6.1.4.1.26138.8.35.14.18.1.1.754	Integer	754
ibdot1sMstVID.755	.3.6.1.4.1.26138.8.35.14.18.1.1.755	Integer	755
ibdot1sMstVID.756	.3.6.1.4.1.26138.8.35.14.18.1.1.756	Integer	756
ibdot1sMstVID.757	.3.6.1.4.1.26138.8.35.14.18.1.1.757	Integer	757
ibdot1sMstVID.758	.3.6.1.4.1.26138.8.35.14.18.1.1.758	Integer	758
ibdot1sMstVID.759	.3.6.1.4.1.26138.8.35.14.18.1.1.759	Integer	759
ibdot1sMstVID.760	.3.6.1.4.1.26138.8.35.14.18.1.1.760	Integer	760
ibdot1sMstVID.761	.3.6.1.4.1.26138.8.35.14.18.1.1.761	Integer	761
ibdot1sMstVID.762	.3.6.1.4.1.26138.8.35.14.18.1.1.762	Integer	762

Name	OID	Value Type	Value Example
ibdot1sMstVID.763	.3.6.1.4.1.26138.8.35.14.18.1.1.763	Integer	763
ibdot1sMstVID.764	.3.6.1.4.1.26138.8.35.14.18.1.1.764	Integer	764
ibdot1sMstVID.765	.3.6.1.4.1.26138.8.35.14.18.1.1.765	Integer	765
ibdot1sMstVID.766	.3.6.1.4.1.26138.8.35.14.18.1.1.766	Integer	766
ibdot1sMstVID.767	.3.6.1.4.1.26138.8.35.14.18.1.1.767	Integer	767
ibdot1sMstVID.768	.3.6.1.4.1.26138.8.35.14.18.1.1.768	Integer	768
ibdot1sMstVID.769	.3.6.1.4.1.26138.8.35.14.18.1.1.769	Integer	769
ibdot1sMstVID.770	.3.6.1.4.1.26138.8.35.14.18.1.1.770	Integer	770
ibdot1sMstVID.771	.3.6.1.4.1.26138.8.35.14.18.1.1.771	Integer	771
ibdot1sMstVID.772	.3.6.1.4.1.26138.8.35.14.18.1.1.772	Integer	772
ibdot1sMstVID.773	.3.6.1.4.1.26138.8.35.14.18.1.1.773	Integer	773
ibdot1sMstVID.774	.3.6.1.4.1.26138.8.35.14.18.1.1.774	Integer	774
ibdot1sMstVID.775	.3.6.1.4.1.26138.8.35.14.18.1.1.775	Integer	775
ibdot1sMstVID.776	.3.6.1.4.1.26138.8.35.14.18.1.1.776	Integer	776
ibdot1sMstVID.777	.3.6.1.4.1.26138.8.35.14.18.1.1.777	Integer	777
ibdot1sMstVID.778	.3.6.1.4.1.26138.8.35.14.18.1.1.778	Integer	778
ibdot1sMstVID.779	.3.6.1.4.1.26138.8.35.14.18.1.1.779	Integer	779
ibdot1sMstVID.780	.3.6.1.4.1.26138.8.35.14.18.1.1.780	Integer	780
ibdot1sMstVID.781	.3.6.1.4.1.26138.8.35.14.18.1.1.781	Integer	781
ibdot1sMstVID.782	.3.6.1.4.1.26138.8.35.14.18.1.1.782	Integer	782
ibdot1sMstVID.783	.3.6.1.4.1.26138.8.35.14.18.1.1.783	Integer	783
ibdot1sMstVID.784	.3.6.1.4.1.26138.8.35.14.18.1.1.784	Integer	784
ibdot1sMstVID.785	.3.6.1.4.1.26138.8.35.14.18.1.1.785	Integer	785
ibdot1sMstVID.786	.3.6.1.4.1.26138.8.35.14.18.1.1.786	Integer	786
ibdot1sMstVID.787	.3.6.1.4.1.26138.8.35.14.18.1.1.787	Integer	787
ibdot1sMstVID.788	.3.6.1.4.1.26138.8.35.14.18.1.1.788	Integer	788
ibdot1sMstVID.789	.3.6.1.4.1.26138.8.35.14.18.1.1.789	Integer	789
ibdot1sMstVID.790	.3.6.1.4.1.26138.8.35.14.18.1.1.790	Integer	790
ibdot1sMstVID.791	.3.6.1.4.1.26138.8.35.14.18.1.1.791	Integer	791
ibdot1sMstVID.792	.3.6.1.4.1.26138.8.35.14.18.1.1.792	Integer	792
ibdot1sMstVID.793	.3.6.1.4.1.26138.8.35.14.18.1.1.793	Integer	793
ibdot1sMstVID.794	.3.6.1.4.1.26138.8.35.14.18.1.1.794	Integer	794
ibdot1sMstVID.795	.3.6.1.4.1.26138.8.35.14.18.1.1.795	Integer	795
ibdot1sMstVID.796	.3.6.1.4.1.26138.8.35.14.18.1.1.796	Integer	796
ibdot1sMstVID.797	.3.6.1.4.1.26138.8.35.14.18.1.1.797	Integer	797
ibdot1sMstVID.798	.3.6.1.4.1.26138.8.35.14.18.1.1.798	Integer	798
ibdot1sMstVID.799	.3.6.1.4.1.26138.8.35.14.18.1.1.799	Integer	799
ibdot1sMstVID.800	.3.6.1.4.1.26138.8.35.14.18.1.1.800	Integer	800
ibdot1sMstVID.801	.3.6.1.4.1.26138.8.35.14.18.1.1.801	Integer	801
ibdot1sMstVID.802	.3.6.1.4.1.26138.8.35.14.18.1.1.802	Integer	802
ibdot1sMstVID.803	.3.6.1.4.1.26138.8.35.14.18.1.1.803	Integer	803
ibdot1sMstVID.804	.3.6.1.4.1.26138.8.35.14.18.1.1.804	Integer	804
ibdot1sMstVID.805	.3.6.1.4.1.26138.8.35.14.18.1.1.805	Integer	805

Name	OID	Value Type	Value Example
ibdot1sMstVID.806	.3.6.1.4.1.26138.8.35.14.18.1.1.806	Integer	806
ibdot1sMstVID.807	.3.6.1.4.1.26138.8.35.14.18.1.1.807	Integer	807
ibdot1sMstVID.808	.3.6.1.4.1.26138.8.35.14.18.1.1.808	Integer	808
ibdot1sMstVID.809	.3.6.1.4.1.26138.8.35.14.18.1.1.809	Integer	809
ibdot1sMstVID.810	.3.6.1.4.1.26138.8.35.14.18.1.1.810	Integer	810
ibdot1sMstVID.811	.3.6.1.4.1.26138.8.35.14.18.1.1.811	Integer	811
ibdot1sMstVID.812	.3.6.1.4.1.26138.8.35.14.18.1.1.812	Integer	812
ibdot1sMstVID.813	.3.6.1.4.1.26138.8.35.14.18.1.1.813	Integer	813
ibdot1sMstVID.814	.3.6.1.4.1.26138.8.35.14.18.1.1.814	Integer	814
ibdot1sMstVID.815	.3.6.1.4.1.26138.8.35.14.18.1.1.815	Integer	815
ibdot1sMstVID.816	.3.6.1.4.1.26138.8.35.14.18.1.1.816	Integer	816
ibdot1sMstVID.817	.3.6.1.4.1.26138.8.35.14.18.1.1.817	Integer	817
ibdot1sMstVID.818	.3.6.1.4.1.26138.8.35.14.18.1.1.818	Integer	818
ibdot1sMstVID.819	.3.6.1.4.1.26138.8.35.14.18.1.1.819	Integer	819
ibdot1sMstVID.820	.3.6.1.4.1.26138.8.35.14.18.1.1.820	Integer	820
ibdot1sMstVID.821	.3.6.1.4.1.26138.8.35.14.18.1.1.821	Integer	821
ibdot1sMstVID.822	.3.6.1.4.1.26138.8.35.14.18.1.1.822	Integer	822
ibdot1sMstVID.823	.3.6.1.4.1.26138.8.35.14.18.1.1.823	Integer	823
ibdot1sMstVID.824	.3.6.1.4.1.26138.8.35.14.18.1.1.824	Integer	824
ibdot1sMstVID.825	.3.6.1.4.1.26138.8.35.14.18.1.1.825	Integer	825
ibdot1sMstVID.826	.3.6.1.4.1.26138.8.35.14.18.1.1.826	Integer	826
ibdot1sMstVID.827	.3.6.1.4.1.26138.8.35.14.18.1.1.827	Integer	827
ibdot1sMstVID.828	.3.6.1.4.1.26138.8.35.14.18.1.1.828	Integer	828
ibdot1sMstVID.829	.3.6.1.4.1.26138.8.35.14.18.1.1.829	Integer	829
ibdot1sMstVID.830	.3.6.1.4.1.26138.8.35.14.18.1.1.830	Integer	830
ibdot1sMstVID.831	.3.6.1.4.1.26138.8.35.14.18.1.1.831	Integer	831
ibdot1sMstVID.832	.3.6.1.4.1.26138.8.35.14.18.1.1.832	Integer	832
ibdot1sMstVID.833	.3.6.1.4.1.26138.8.35.14.18.1.1.833	Integer	833
ibdot1sMstVID.834	.3.6.1.4.1.26138.8.35.14.18.1.1.834	Integer	834
ibdot1sMstVID.835	.3.6.1.4.1.26138.8.35.14.18.1.1.835	Integer	835
ibdot1sMstVID.836	.3.6.1.4.1.26138.8.35.14.18.1.1.836	Integer	836
ibdot1sMstVID.837	.3.6.1.4.1.26138.8.35.14.18.1.1.837	Integer	837
ibdot1sMstVID.838	.3.6.1.4.1.26138.8.35.14.18.1.1.838	Integer	838
ibdot1sMstVID.839	.3.6.1.4.1.26138.8.35.14.18.1.1.839	Integer	839
ibdot1sMstVID.840	.3.6.1.4.1.26138.8.35.14.18.1.1.840	Integer	840
ibdot1sMstVID.841	.3.6.1.4.1.26138.8.35.14.18.1.1.841	Integer	841
ibdot1sMstVID.842	.3.6.1.4.1.26138.8.35.14.18.1.1.842	Integer	842
ibdot1sMstVID.843	.3.6.1.4.1.26138.8.35.14.18.1.1.843	Integer	843
ibdot1sMstVID.844	.3.6.1.4.1.26138.8.35.14.18.1.1.844	Integer	844
ibdot1sMstVID.845	.3.6.1.4.1.26138.8.35.14.18.1.1.845	Integer	845
ibdot1sMstVID.846	.3.6.1.4.1.26138.8.35.14.18.1.1.846	Integer	846
ibdot1sMstVID.847	.3.6.1.4.1.26138.8.35.14.18.1.1.847	Integer	847
ibdot1sMstVID.848	.3.6.1.4.1.26138.8.35.14.18.1.1.848	Integer	848

Name	OID	Value Type	Value Example
ibdot1sMstVID.849	.3.6.1.4.1.26138.8.35.14.18.1.1.849	Integer	849
ibdot1sMstVID.850	.3.6.1.4.1.26138.8.35.14.18.1.1.850	Integer	850
ibdot1sMstVID.851	.3.6.1.4.1.26138.8.35.14.18.1.1.851	Integer	851
ibdot1sMstVID.852	.3.6.1.4.1.26138.8.35.14.18.1.1.852	Integer	852
ibdot1sMstVID.853	.3.6.1.4.1.26138.8.35.14.18.1.1.853	Integer	853
ibdot1sMstVID.854	.3.6.1.4.1.26138.8.35.14.18.1.1.854	Integer	854
ibdot1sMstVID.855	.3.6.1.4.1.26138.8.35.14.18.1.1.855	Integer	855
ibdot1sMstVID.856	.3.6.1.4.1.26138.8.35.14.18.1.1.856	Integer	856
ibdot1sMstVID.857	.3.6.1.4.1.26138.8.35.14.18.1.1.857	Integer	857
ibdot1sMstVID.858	.3.6.1.4.1.26138.8.35.14.18.1.1.858	Integer	858
ibdot1sMstVID.859	.3.6.1.4.1.26138.8.35.14.18.1.1.859	Integer	859
ibdot1sMstVID.860	.3.6.1.4.1.26138.8.35.14.18.1.1.860	Integer	860
ibdot1sMstVID.861	.3.6.1.4.1.26138.8.35.14.18.1.1.861	Integer	861
ibdot1sMstVID.862	.3.6.1.4.1.26138.8.35.14.18.1.1.862	Integer	862
ibdot1sMstVID.863	.3.6.1.4.1.26138.8.35.14.18.1.1.863	Integer	863
ibdot1sMstVID.864	.3.6.1.4.1.26138.8.35.14.18.1.1.864	Integer	864
ibdot1sMstVID.865	.3.6.1.4.1.26138.8.35.14.18.1.1.865	Integer	865
ibdot1sMstVID.866	.3.6.1.4.1.26138.8.35.14.18.1.1.866	Integer	866
ibdot1sMstVID.867	.3.6.1.4.1.26138.8.35.14.18.1.1.867	Integer	867
ibdot1sMstVID.868	.3.6.1.4.1.26138.8.35.14.18.1.1.868	Integer	868
ibdot1sMstVID.869	.3.6.1.4.1.26138.8.35.14.18.1.1.869	Integer	869
ibdot1sMstVID.870	.3.6.1.4.1.26138.8.35.14.18.1.1.870	Integer	870
ibdot1sMstVID.871	.3.6.1.4.1.26138.8.35.14.18.1.1.871	Integer	871
ibdot1sMstVID.872	.3.6.1.4.1.26138.8.35.14.18.1.1.872	Integer	872
ibdot1sMstVID.873	.3.6.1.4.1.26138.8.35.14.18.1.1.873	Integer	873
ibdot1sMstVID.874	.3.6.1.4.1.26138.8.35.14.18.1.1.874	Integer	874
ibdot1sMstVID.875	.3.6.1.4.1.26138.8.35.14.18.1.1.875	Integer	875
ibdot1sMstVID.876	.3.6.1.4.1.26138.8.35.14.18.1.1.876	Integer	876
ibdot1sMstVID.877	.3.6.1.4.1.26138.8.35.14.18.1.1.877	Integer	877
ibdot1sMstVID.878	.3.6.1.4.1.26138.8.35.14.18.1.1.878	Integer	878
ibdot1sMstVID.879	.3.6.1.4.1.26138.8.35.14.18.1.1.879	Integer	879
ibdot1sMstVID.880	.3.6.1.4.1.26138.8.35.14.18.1.1.880	Integer	880
ibdot1sMstVID.881	.3.6.1.4.1.26138.8.35.14.18.1.1.881	Integer	881
ibdot1sMstVID.882	.3.6.1.4.1.26138.8.35.14.18.1.1.882	Integer	882
ibdot1sMstVID.883	.3.6.1.4.1.26138.8.35.14.18.1.1.883	Integer	883
ibdot1sMstVID.884	.3.6.1.4.1.26138.8.35.14.18.1.1.884	Integer	884
ibdot1sMstVID.885	.3.6.1.4.1.26138.8.35.14.18.1.1.885	Integer	885
ibdot1sMstVID.886	.3.6.1.4.1.26138.8.35.14.18.1.1.886	Integer	886
ibdot1sMstVID.887	.3.6.1.4.1.26138.8.35.14.18.1.1.887	Integer	887
ibdot1sMstVID.888	.3.6.1.4.1.26138.8.35.14.18.1.1.888	Integer	888
ibdot1sMstVID.889	.3.6.1.4.1.26138.8.35.14.18.1.1.889	Integer	889
ibdot1sMstVID.890	.3.6.1.4.1.26138.8.35.14.18.1.1.890	Integer	890
ibdot1sMstVID.891	.3.6.1.4.1.26138.8.35.14.18.1.1.891	Integer	891

Name	OID	Value Type	Value Example
ibdot1sMstVID.892	.3.6.1.4.1.26138.8.35.14.18.1.1.892	Integer	892
ibdot1sMstVID.893	.3.6.1.4.1.26138.8.35.14.18.1.1.893	Integer	893
ibdot1sMstVID.894	.3.6.1.4.1.26138.8.35.14.18.1.1.894	Integer	894
ibdot1sMstVID.895	.3.6.1.4.1.26138.8.35.14.18.1.1.895	Integer	895
ibdot1sMstVID.896	.3.6.1.4.1.26138.8.35.14.18.1.1.896	Integer	896
ibdot1sMstVID.897	.3.6.1.4.1.26138.8.35.14.18.1.1.897	Integer	897
ibdot1sMstVID.898	.3.6.1.4.1.26138.8.35.14.18.1.1.898	Integer	898
ibdot1sMstVID.899	.3.6.1.4.1.26138.8.35.14.18.1.1.899	Integer	899
ibdot1sMstVID.900	.3.6.1.4.1.26138.8.35.14.18.1.1.900	Integer	900
ibdot1sMstVID.901	.3.6.1.4.1.26138.8.35.14.18.1.1.901	Integer	901
ibdot1sMstVID.902	.3.6.1.4.1.26138.8.35.14.18.1.1.902	Integer	902
ibdot1sMstVID.903	.3.6.1.4.1.26138.8.35.14.18.1.1.903	Integer	903
ibdot1sMstVID.904	.3.6.1.4.1.26138.8.35.14.18.1.1.904	Integer	904
ibdot1sMstVID.905	.3.6.1.4.1.26138.8.35.14.18.1.1.905	Integer	905
ibdot1sMstVID.906	.3.6.1.4.1.26138.8.35.14.18.1.1.906	Integer	906
ibdot1sMstVID.907	.3.6.1.4.1.26138.8.35.14.18.1.1.907	Integer	907
ibdot1sMstVID.908	.3.6.1.4.1.26138.8.35.14.18.1.1.908	Integer	908
ibdot1sMstVID.909	.3.6.1.4.1.26138.8.35.14.18.1.1.909	Integer	909
ibdot1sMstVID.910	.3.6.1.4.1.26138.8.35.14.18.1.1.910	Integer	910
ibdot1sMstVID.911	.3.6.1.4.1.26138.8.35.14.18.1.1.911	Integer	911
ibdot1sMstVID.912	.3.6.1.4.1.26138.8.35.14.18.1.1.912	Integer	912
ibdot1sMstVID.913	.3.6.1.4.1.26138.8.35.14.18.1.1.913	Integer	913
ibdot1sMstVID.914	.3.6.1.4.1.26138.8.35.14.18.1.1.914	Integer	914
ibdot1sMstVID.915	.3.6.1.4.1.26138.8.35.14.18.1.1.915	Integer	915
ibdot1sMstVID.916	.3.6.1.4.1.26138.8.35.14.18.1.1.916	Integer	916
ibdot1sMstVID.917	.3.6.1.4.1.26138.8.35.14.18.1.1.917	Integer	917
ibdot1sMstVID.918	.3.6.1.4.1.26138.8.35.14.18.1.1.918	Integer	918
ibdot1sMstVID.919	.3.6.1.4.1.26138.8.35.14.18.1.1.919	Integer	919
ibdot1sMstVID.920	.3.6.1.4.1.26138.8.35.14.18.1.1.920	Integer	920
ibdot1sMstVID.921	.3.6.1.4.1.26138.8.35.14.18.1.1.921	Integer	921
ibdot1sMstVID.922	.3.6.1.4.1.26138.8.35.14.18.1.1.922	Integer	922
ibdot1sMstVID.923	.3.6.1.4.1.26138.8.35.14.18.1.1.923	Integer	923
ibdot1sMstVID.924	.3.6.1.4.1.26138.8.35.14.18.1.1.924	Integer	924
ibdot1sMstVID.925	.3.6.1.4.1.26138.8.35.14.18.1.1.925	Integer	925
ibdot1sMstVID.926	.3.6.1.4.1.26138.8.35.14.18.1.1.926	Integer	926
ibdot1sMstVID.927	.3.6.1.4.1.26138.8.35.14.18.1.1.927	Integer	927
ibdot1sMstVID.928	.3.6.1.4.1.26138.8.35.14.18.1.1.928	Integer	928
ibdot1sMstVID.929	.3.6.1.4.1.26138.8.35.14.18.1.1.929	Integer	929
ibdot1sMstVID.930	.3.6.1.4.1.26138.8.35.14.18.1.1.930	Integer	930
ibdot1sMstVID.931	.3.6.1.4.1.26138.8.35.14.18.1.1.931	Integer	931
ibdot1sMstVID.932	.3.6.1.4.1.26138.8.35.14.18.1.1.932	Integer	932
ibdot1sMstVID.933	.3.6.1.4.1.26138.8.35.14.18.1.1.933	Integer	933
ibdot1sMstVID.934	.3.6.1.4.1.26138.8.35.14.18.1.1.934	Integer	934

Name	OID	Value Type	Value Example
ibdot1sMstVID.935	.3.6.1.4.1.26138.8.35.14.18.1.1.935	Integer	935
ibdot1sMstVID.936	.3.6.1.4.1.26138.8.35.14.18.1.1.936	Integer	936
ibdot1sMstVID.937	.3.6.1.4.1.26138.8.35.14.18.1.1.937	Integer	937
ibdot1sMstVID.938	.3.6.1.4.1.26138.8.35.14.18.1.1.938	Integer	938
ibdot1sMstVID.939	.3.6.1.4.1.26138.8.35.14.18.1.1.939	Integer	939
ibdot1sMstVID.940	.3.6.1.4.1.26138.8.35.14.18.1.1.940	Integer	940
ibdot1sMstVID.941	.3.6.1.4.1.26138.8.35.14.18.1.1.941	Integer	941
ibdot1sMstVID.942	.3.6.1.4.1.26138.8.35.14.18.1.1.942	Integer	942
ibdot1sMstVID.943	.3.6.1.4.1.26138.8.35.14.18.1.1.943	Integer	943
ibdot1sMstVID.944	.3.6.1.4.1.26138.8.35.14.18.1.1.944	Integer	944
ibdot1sMstVID.945	.3.6.1.4.1.26138.8.35.14.18.1.1.945	Integer	945
ibdot1sMstVID.946	.3.6.1.4.1.26138.8.35.14.18.1.1.946	Integer	946
ibdot1sMstVID.947	.3.6.1.4.1.26138.8.35.14.18.1.1.947	Integer	947
ibdot1sMstVID.948	.3.6.1.4.1.26138.8.35.14.18.1.1.948	Integer	948
ibdot1sMstVID.949	.3.6.1.4.1.26138.8.35.14.18.1.1.949	Integer	949
ibdot1sMstVID.950	.3.6.1.4.1.26138.8.35.14.18.1.1.950	Integer	950
ibdot1sMstVID.951	.3.6.1.4.1.26138.8.35.14.18.1.1.951	Integer	951
ibdot1sMstVID.952	.3.6.1.4.1.26138.8.35.14.18.1.1.952	Integer	952
ibdot1sMstVID.953	.3.6.1.4.1.26138.8.35.14.18.1.1.953	Integer	953
ibdot1sMstVID.954	.3.6.1.4.1.26138.8.35.14.18.1.1.954	Integer	954
ibdot1sMstVID.955	.3.6.1.4.1.26138.8.35.14.18.1.1.955	Integer	955
ibdot1sMstVID.956	.3.6.1.4.1.26138.8.35.14.18.1.1.956	Integer	956
ibdot1sMstVID.957	.3.6.1.4.1.26138.8.35.14.18.1.1.957	Integer	957
ibdot1sMstVID.958	.3.6.1.4.1.26138.8.35.14.18.1.1.958	Integer	958
ibdot1sMstVID.959	.3.6.1.4.1.26138.8.35.14.18.1.1.959	Integer	959
ibdot1sMstVID.960	.3.6.1.4.1.26138.8.35.14.18.1.1.960	Integer	960
ibdot1sMstVID.961	.3.6.1.4.1.26138.8.35.14.18.1.1.961	Integer	961
ibdot1sMstVID.962	.3.6.1.4.1.26138.8.35.14.18.1.1.962	Integer	962
ibdot1sMstVID.963	.3.6.1.4.1.26138.8.35.14.18.1.1.963	Integer	963
ibdot1sMstVID.964	.3.6.1.4.1.26138.8.35.14.18.1.1.964	Integer	964
ibdot1sMstVID.965	.3.6.1.4.1.26138.8.35.14.18.1.1.965	Integer	965
ibdot1sMstVID.966	.3.6.1.4.1.26138.8.35.14.18.1.1.966	Integer	966
ibdot1sMstVID.967	.3.6.1.4.1.26138.8.35.14.18.1.1.967	Integer	967
ibdot1sMstVID.968	.3.6.1.4.1.26138.8.35.14.18.1.1.968	Integer	968
ibdot1sMstVID.969	.3.6.1.4.1.26138.8.35.14.18.1.1.969	Integer	969
ibdot1sMstVID.970	.3.6.1.4.1.26138.8.35.14.18.1.1.970	Integer	970
ibdot1sMstVID.971	.3.6.1.4.1.26138.8.35.14.18.1.1.971	Integer	971
ibdot1sMstVID.972	.3.6.1.4.1.26138.8.35.14.18.1.1.972	Integer	972
ibdot1sMstVID.973	.3.6.1.4.1.26138.8.35.14.18.1.1.973	Integer	973
ibdot1sMstVID.974	.3.6.1.4.1.26138.8.35.14.18.1.1.974	Integer	974
ibdot1sMstVID.975	.3.6.1.4.1.26138.8.35.14.18.1.1.975	Integer	975
ibdot1sMstVID.976	.3.6.1.4.1.26138.8.35.14.18.1.1.976	Integer	976
ibdot1sMstVID.977	.3.6.1.4.1.26138.8.35.14.18.1.1.977	Integer	977

Name	OID	Value Type	Value Example
ibdot1sMstVID.978	.1.3.6.1.4.1.26138.8.35.14.18.1.1.978	Integer	978
ibdot1sMstVID.979	.1.3.6.1.4.1.26138.8.35.14.18.1.1.979	Integer	979
ibdot1sMstVID.980	.1.3.6.1.4.1.26138.8.35.14.18.1.1.980	Integer	980
ibdot1sMstVID.981	.1.3.6.1.4.1.26138.8.35.14.18.1.1.981	Integer	981
ibdot1sMstVID.982	.1.3.6.1.4.1.26138.8.35.14.18.1.1.982	Integer	982
ibdot1sMstVID.983	.1.3.6.1.4.1.26138.8.35.14.18.1.1.983	Integer	983
ibdot1sMstVID.984	.1.3.6.1.4.1.26138.8.35.14.18.1.1.984	Integer	984
ibdot1sMstVID.985	.1.3.6.1.4.1.26138.8.35.14.18.1.1.985	Integer	985
ibdot1sMstVID.986	.1.3.6.1.4.1.26138.8.35.14.18.1.1.986	Integer	986
ibdot1sMstVID.987	.1.3.6.1.4.1.26138.8.35.14.18.1.1.987	Integer	987
ibdot1sMstVID.988	.1.3.6.1.4.1.26138.8.35.14.18.1.1.988	Integer	988
ibdot1sMstVID.989	.1.3.6.1.4.1.26138.8.35.14.18.1.1.989	Integer	989
ibdot1sMstVID.990	.1.3.6.1.4.1.26138.8.35.14.18.1.1.990	Integer	990
ibdot1sMstVID.991	.1.3.6.1.4.1.26138.8.35.14.18.1.1.991	Integer	991
ibdot1sMstVID.992	.1.3.6.1.4.1.26138.8.35.14.18.1.1.992	Integer	992
ibdot1sMstVID.993	.1.3.6.1.4.1.26138.8.35.14.18.1.1.993	Integer	993
ibdot1sMstVID.994	.1.3.6.1.4.1.26138.8.35.14.18.1.1.994	Integer	994
ibdot1sMstVID.995	.1.3.6.1.4.1.26138.8.35.14.18.1.1.995	Integer	995
ibdot1sMstVID.996	.1.3.6.1.4.1.26138.8.35.14.18.1.1.996	Integer	996
ibdot1sMstVID.997	.1.3.6.1.4.1.26138.8.35.14.18.1.1.997	Integer	997
ibdot1sMstVID.998	.1.3.6.1.4.1.26138.8.35.14.18.1.1.998	Integer	998
ibdot1sMstVID.999	.1.3.6.1.4.1.26138.8.35.14.18.1.1.999	Integer	999
ibdot1sMstVID.1000	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1000	Integer	1000
ibdot1sMstVID.1001	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1001	Integer	1001
ibdot1sMstVID.1002	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1002	Integer	1002
ibdot1sMstVID.1003	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1003	Integer	1003
ibdot1sMstVID.1004	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1004	Integer	1004
ibdot1sMstVID.1005	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1005	Integer	1005
ibdot1sMstVID.1006	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1006	Integer	1006
ibdot1sMstVID.1007	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1007	Integer	1007
ibdot1sMstVID.1008	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1008	Integer	1008
ibdot1sMstVID.1009	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1009	Integer	1009
ibdot1sMstVID.1010	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1010	Integer	1010
ibdot1sMstVID.1011	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1011	Integer	1011
ibdot1sMstVID.1012	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1012	Integer	1012
ibdot1sMstVID.1013	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1013	Integer	1013
ibdot1sMstVID.1014	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1014	Integer	1014
ibdot1sMstVID.1015	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1015	Integer	1015
ibdot1sMstVID.1016	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1016	Integer	1016
ibdot1sMstVID.1017	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1017	Integer	1017
ibdot1sMstVID.1018	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1018	Integer	1018
ibdot1sMstVID.1019	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1019	Integer	1019
ibdot1sMstVID.1020	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1020	Integer	1020



Name	OID	Value Type	Value Example
ibdot1sMstVID.1021	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1021	Integer	1021
ibdot1sMstVID.1022	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1022	Integer	1022
ibdot1sMstVID.1023	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1023	Integer	1023
ibdot1sMstVID.1024	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1024	Integer	1024
ibdot1sMstVID.1025	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1025	Integer	1025
ibdot1sMstVID.1026	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1026	Integer	1026
ibdot1sMstVID.1027	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1027	Integer	1027
ibdot1sMstVID.1028	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1028	Integer	1028
ibdot1sMstVID.1029	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1029	Integer	1029
ibdot1sMstVID.1030	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1030	Integer	1030
ibdot1sMstVID.1031	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1031	Integer	1031
ibdot1sMstVID.1032	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1032	Integer	1032
ibdot1sMstVID.1033	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1033	Integer	1033
ibdot1sMstVID.1034	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1034	Integer	1034
ibdot1sMstVID.1035	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1035	Integer	1035
ibdot1sMstVID.1036	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1036	Integer	1036
ibdot1sMstVID.1037	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1037	Integer	1037
ibdot1sMstVID.1038	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1038	Integer	1038
ibdot1sMstVID.1039	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1039	Integer	1039
ibdot1sMstVID.1040	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1040	Integer	1040
ibdot1sMstVID.1041	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1041	Integer	1041
ibdot1sMstVID.1042	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1042	Integer	1042
ibdot1sMstVID.1043	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1043	Integer	1043
ibdot1sMstVID.1044	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1044	Integer	1044
ibdot1sMstVID.1045	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1045	Integer	1045
ibdot1sMstVID.1046	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1046	Integer	1046
ibdot1sMstVID.1047	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1047	Integer	1047
ibdot1sMstVID.1048	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1048	Integer	1048
ibdot1sMstVID.1049	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1049	Integer	1049
ibdot1sMstVID.1050	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1050	Integer	1050
ibdot1sMstVID.1051	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1051	Integer	1051
ibdot1sMstVID.1052	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1052	Integer	1052
ibdot1sMstVID.1053	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1053	Integer	1053
ibdot1sMstVID.1054	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1054	Integer	1054
ibdot1sMstVID.1055	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1055	Integer	1055
ibdot1sMstVID.1056	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1056	Integer	1056
ibdot1sMstVID.1057	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1057	Integer	1057
ibdot1sMstVID.1058	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1058	Integer	1058
ibdot1sMstVID.1059	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1059	Integer	1059
ibdot1sMstVID.1060	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1060	Integer	1060
ibdot1sMstVID.1061	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1061	Integer	1061
ibdot1sMstVID.1062	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1062	Integer	1062
ibdot1sMstVID.1063	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1063	Integer	1063



Name	OID	Value Type	Value Example
ibdot1sMstVID.1064	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1064	Integer	1064
ibdot1sMstVID.1065	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1065	Integer	1065
ibdot1sMstVID.1066	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1066	Integer	1066
ibdot1sMstVID.1067	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1067	Integer	1067
ibdot1sMstVID.1068	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1068	Integer	1068
ibdot1sMstVID.1069	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1069	Integer	1069
ibdot1sMstVID.1070	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1070	Integer	1070
ibdot1sMstVID.1071	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1071	Integer	1071
ibdot1sMstVID.1072	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1072	Integer	1072
ibdot1sMstVID.1073	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1073	Integer	1073
ibdot1sMstVID.1074	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1074	Integer	1074
ibdot1sMstVID.1075	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1075	Integer	1075
ibdot1sMstVID.1076	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1076	Integer	1076
ibdot1sMstVID.1077	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1077	Integer	1077
ibdot1sMstVID.1078	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1078	Integer	1078
ibdot1sMstVID.1079	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1079	Integer	1079
ibdot1sMstVID.1080	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1080	Integer	1080
ibdot1sMstVID.1081	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1081	Integer	1081
ibdot1sMstVID.1082	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1082	Integer	1082
ibdot1sMstVID.1083	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1083	Integer	1083
ibdot1sMstVID.1084	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1084	Integer	1084
ibdot1sMstVID.1085	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1085	Integer	1085
ibdot1sMstVID.1086	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1086	Integer	1086
ibdot1sMstVID.1087	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1087	Integer	1087
ibdot1sMstVID.1088	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1088	Integer	1088
ibdot1sMstVID.1089	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1089	Integer	1089
ibdot1sMstVID.1090	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1090	Integer	1090
ibdot1sMstVID.1091	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1091	Integer	1091
ibdot1sMstVID.1092	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1092	Integer	1092
ibdot1sMstVID.1093	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1093	Integer	1093
ibdot1sMstVID.1094	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1094	Integer	1094
ibdot1sMstVID.1095	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1095	Integer	1095
ibdot1sMstVID.1096	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1096	Integer	1096
ibdot1sMstVID.1097	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1097	Integer	1097
ibdot1sMstVID.1098	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1098	Integer	1098
ibdot1sMstVID.1099	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1099	Integer	1099
ibdot1sMstVID.1100	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1100	Integer	1100
ibdot1sMstVID.1101	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1101	Integer	1101
ibdot1sMstVID.1102	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1102	Integer	1102
ibdot1sMstVID.1103	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1103	Integer	1103
ibdot1sMstVID.1104	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1104	Integer	1104
ibdot1sMstVID.1105	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1105	Integer	1105
ibdot1sMstVID.1106	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1106	Integer	1106

Name	OID	Value Type	Value Example
ibdot1sMstVID.1107	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1107	Integer	1107
ibdot1sMstVID.1108	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1108	Integer	1108
ibdot1sMstVID.1109	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1109	Integer	1109
ibdot1sMstVID.1110	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1110	Integer	1110
ibdot1sMstVID.1111	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1111	Integer	1111
ibdot1sMstVID.1112	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1112	Integer	1112
ibdot1sMstVID.1113	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1113	Integer	1113
ibdot1sMstVID.1114	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1114	Integer	1114
ibdot1sMstVID.1115	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1115	Integer	1115
ibdot1sMstVID.1116	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1116	Integer	1116
ibdot1sMstVID.1117	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1117	Integer	1117
ibdot1sMstVID.1118	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1118	Integer	1118
ibdot1sMstVID.1119	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1119	Integer	1119
ibdot1sMstVID.1120	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1120	Integer	1120
ibdot1sMstVID.1121	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1121	Integer	1121
ibdot1sMstVID.1122	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1122	Integer	1122
ibdot1sMstVID.1123	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1123	Integer	1123
ibdot1sMstVID.1124	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1124	Integer	1124
ibdot1sMstVID.1125	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1125	Integer	1125
ibdot1sMstVID.1126	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1126	Integer	1126
ibdot1sMstVID.1127	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1127	Integer	1127
ibdot1sMstVID.1128	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1128	Integer	1128
ibdot1sMstVID.1129	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1129	Integer	1129
ibdot1sMstVID.1130	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1130	Integer	1130
ibdot1sMstVID.1131	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1131	Integer	1131
ibdot1sMstVID.1132	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1132	Integer	1132
ibdot1sMstVID.1133	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1133	Integer	1133
ibdot1sMstVID.1134	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1134	Integer	1134
ibdot1sMstVID.1135	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1135	Integer	1135
ibdot1sMstVID.1136	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1136	Integer	1136
ibdot1sMstVID.1137	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1137	Integer	1137
ibdot1sMstVID.1138	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1138	Integer	1138
ibdot1sMstVID.1139	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1139	Integer	1139
ibdot1sMstVID.1140	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1140	Integer	1140
ibdot1sMstVID.1141	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1141	Integer	1141
ibdot1sMstVID.1142	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1142	Integer	1142
ibdot1sMstVID.1143	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1143	Integer	1143
ibdot1sMstVID.1144	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1144	Integer	1144
ibdot1sMstVID.1145	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1145	Integer	1145
ibdot1sMstVID.1146	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1146	Integer	1146
ibdot1sMstVID.1147	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1147	Integer	1147
ibdot1sMstVID.1148	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1148	Integer	1148
ibdot1sMstVID.1149	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1149	Integer	1149

Name	OID	Value Type	Value Example
ibdot1sMstVID.1150	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1150	Integer	1150
ibdot1sMstVID.1151	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1151	Integer	1151
ibdot1sMstVID.1152	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1152	Integer	1152
ibdot1sMstVID.1153	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1153	Integer	1153
ibdot1sMstVID.1154	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1154	Integer	1154
ibdot1sMstVID.1155	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1155	Integer	1155
ibdot1sMstVID.1156	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1156	Integer	1156
ibdot1sMstVID.1157	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1157	Integer	1157
ibdot1sMstVID.1158	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1158	Integer	1158
ibdot1sMstVID.1159	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1159	Integer	1159
ibdot1sMstVID.1160	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1160	Integer	1160
ibdot1sMstVID.1161	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1161	Integer	1161
ibdot1sMstVID.1162	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1162	Integer	1162
ibdot1sMstVID.1163	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1163	Integer	1163
ibdot1sMstVID.1164	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1164	Integer	1164
ibdot1sMstVID.1165	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1165	Integer	1165
ibdot1sMstVID.1166	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1166	Integer	1166
ibdot1sMstVID.1167	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1167	Integer	1167
ibdot1sMstVID.1168	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1168	Integer	1168
ibdot1sMstVID.1169	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1169	Integer	1169
ibdot1sMstVID.1170	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1170	Integer	1170
ibdot1sMstVID.1171	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1171	Integer	1171
ibdot1sMstVID.1172	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1172	Integer	1172
ibdot1sMstVID.1173	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1173	Integer	1173
ibdot1sMstVID.1174	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1174	Integer	1174
ibdot1sMstVID.1175	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1175	Integer	1175
ibdot1sMstVID.1176	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1176	Integer	1176
ibdot1sMstVID.1177	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1177	Integer	1177
ibdot1sMstVID.1178	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1178	Integer	1178
ibdot1sMstVID.1179	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1179	Integer	1179
ibdot1sMstVID.1180	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1180	Integer	1180
ibdot1sMstVID.1181	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1181	Integer	1181
ibdot1sMstVID.1182	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1182	Integer	1182
ibdot1sMstVID.1183	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1183	Integer	1183
ibdot1sMstVID.1184	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1184	Integer	1184
ibdot1sMstVID.1185	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1185	Integer	1185
ibdot1sMstVID.1186	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1186	Integer	1186
ibdot1sMstVID.1187	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1187	Integer	1187
ibdot1sMstVID.1188	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1188	Integer	1188
ibdot1sMstVID.1189	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1189	Integer	1189
ibdot1sMstVID.1190	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1190	Integer	1190
ibdot1sMstVID.1191	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1191	Integer	1191
ibdot1sMstVID.1192	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1192	Integer	1192

Name	OID	Value Type	Value Example
ibdot1sMstVID.1193	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1193	Integer	1193
ibdot1sMstVID.1194	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1194	Integer	1194
ibdot1sMstVID.1195	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1195	Integer	1195
ibdot1sMstVID.1196	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1196	Integer	1196
ibdot1sMstVID.1197	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1197	Integer	1197
ibdot1sMstVID.1198	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1198	Integer	1198
ibdot1sMstVID.1199	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1199	Integer	1199
ibdot1sMstVID.1200	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1200	Integer	1200
ibdot1sMstVID.1201	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1201	Integer	1201
ibdot1sMstVID.1202	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1202	Integer	1202
ibdot1sMstVID.1203	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1203	Integer	1203
ibdot1sMstVID.1204	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1204	Integer	1204
ibdot1sMstVID.1205	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1205	Integer	1205
ibdot1sMstVID.1206	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1206	Integer	1206
ibdot1sMstVID.1207	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1207	Integer	1207
ibdot1sMstVID.1208	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1208	Integer	1208
ibdot1sMstVID.1209	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1209	Integer	1209
ibdot1sMstVID.1210	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1210	Integer	1210
ibdot1sMstVID.1211	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1211	Integer	1211
ibdot1sMstVID.1212	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1212	Integer	1212
ibdot1sMstVID.1213	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1213	Integer	1213
ibdot1sMstVID.1214	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1214	Integer	1214
ibdot1sMstVID.1215	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1215	Integer	1215
ibdot1sMstVID.1216	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1216	Integer	1216
ibdot1sMstVID.1217	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1217	Integer	1217
ibdot1sMstVID.1218	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1218	Integer	1218
ibdot1sMstVID.1219	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1219	Integer	1219
ibdot1sMstVID.1220	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1220	Integer	1220
ibdot1sMstVID.1221	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1221	Integer	1221
ibdot1sMstVID.1222	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1222	Integer	1222
ibdot1sMstVID.1223	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1223	Integer	1223
ibdot1sMstVID.1224	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1224	Integer	1224
ibdot1sMstVID.1225	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1225	Integer	1225
ibdot1sMstVID.1226	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1226	Integer	1226
ibdot1sMstVID.1227	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1227	Integer	1227
ibdot1sMstVID.1228	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1228	Integer	1228
ibdot1sMstVID.1229	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1229	Integer	1229
ibdot1sMstVID.1230	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1230	Integer	1230
ibdot1sMstVID.1231	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1231	Integer	1231
ibdot1sMstVID.1232	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1232	Integer	1232
ibdot1sMstVID.1233	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1233	Integer	1233
ibdot1sMstVID.1234	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1234	Integer	1234
ibdot1sMstVID.1235	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1235	Integer	1235

Name	OID	Value Type	Value Example
ibdot1sMstVID.1236	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1236	Integer	1236
ibdot1sMstVID.1237	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1237	Integer	1237
ibdot1sMstVID.1238	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1238	Integer	1238
ibdot1sMstVID.1239	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1239	Integer	1239
ibdot1sMstVID.1240	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1240	Integer	1240
ibdot1sMstVID.1241	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1241	Integer	1241
ibdot1sMstVID.1242	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1242	Integer	1242
ibdot1sMstVID.1243	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1243	Integer	1243
ibdot1sMstVID.1244	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1244	Integer	1244
ibdot1sMstVID.1245	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1245	Integer	1245
ibdot1sMstVID.1246	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1246	Integer	1246
ibdot1sMstVID.1247	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1247	Integer	1247
ibdot1sMstVID.1248	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1248	Integer	1248
ibdot1sMstVID.1249	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1249	Integer	1249
ibdot1sMstVID.1250	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1250	Integer	1250
ibdot1sMstVID.1251	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1251	Integer	1251
ibdot1sMstVID.1252	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1252	Integer	1252
ibdot1sMstVID.1253	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1253	Integer	1253
ibdot1sMstVID.1254	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1254	Integer	1254
ibdot1sMstVID.1255	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1255	Integer	1255
ibdot1sMstVID.1256	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1256	Integer	1256
ibdot1sMstVID.1257	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1257	Integer	1257
ibdot1sMstVID.1258	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1258	Integer	1258
ibdot1sMstVID.1259	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1259	Integer	1259
ibdot1sMstVID.1260	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1260	Integer	1260
ibdot1sMstVID.1261	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1261	Integer	1261
ibdot1sMstVID.1262	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1262	Integer	1262
ibdot1sMstVID.1263	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1263	Integer	1263
ibdot1sMstVID.1264	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1264	Integer	1264
ibdot1sMstVID.1265	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1265	Integer	1265
ibdot1sMstVID.1266	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1266	Integer	1266
ibdot1sMstVID.1267	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1267	Integer	1267
ibdot1sMstVID.1268	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1268	Integer	1268
ibdot1sMstVID.1269	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1269	Integer	1269
ibdot1sMstVID.1270	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1270	Integer	1270
ibdot1sMstVID.1271	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1271	Integer	1271
ibdot1sMstVID.1272	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1272	Integer	1272
ibdot1sMstVID.1273	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1273	Integer	1273
ibdot1sMstVID.1274	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1274	Integer	1274
ibdot1sMstVID.1275	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1275	Integer	1275
ibdot1sMstVID.1276	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1276	Integer	1276
ibdot1sMstVID.1277	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1277	Integer	1277
ibdot1sMstVID.1278	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1278	Integer	1278

Name	OID	Value Type	Value Example
ibdot1sMstVID.1279	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1279	Integer	1279
ibdot1sMstVID.1280	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1280	Integer	1280
ibdot1sMstVID.1281	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1281	Integer	1281
ibdot1sMstVID.1282	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1282	Integer	1282
ibdot1sMstVID.1283	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1283	Integer	1283
ibdot1sMstVID.1284	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1284	Integer	1284
ibdot1sMstVID.1285	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1285	Integer	1285
ibdot1sMstVID.1286	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1286	Integer	1286
ibdot1sMstVID.1287	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1287	Integer	1287
ibdot1sMstVID.1288	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1288	Integer	1288
ibdot1sMstVID.1289	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1289	Integer	1289
ibdot1sMstVID.1290	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1290	Integer	1290
ibdot1sMstVID.1291	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1291	Integer	1291
ibdot1sMstVID.1292	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1292	Integer	1292
ibdot1sMstVID.1293	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1293	Integer	1293
ibdot1sMstVID.1294	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1294	Integer	1294
ibdot1sMstVID.1295	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1295	Integer	1295
ibdot1sMstVID.1296	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1296	Integer	1296
ibdot1sMstVID.1297	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1297	Integer	1297
ibdot1sMstVID.1298	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1298	Integer	1298
ibdot1sMstVID.1299	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1299	Integer	1299
ibdot1sMstVID.1300	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1300	Integer	1300
ibdot1sMstVID.1301	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1301	Integer	1301
ibdot1sMstVID.1302	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1302	Integer	1302
ibdot1sMstVID.1303	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1303	Integer	1303
ibdot1sMstVID.1304	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1304	Integer	1304
ibdot1sMstVID.1305	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1305	Integer	1305
ibdot1sMstVID.1306	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1306	Integer	1306
ibdot1sMstVID.1307	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1307	Integer	1307
ibdot1sMstVID.1308	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1308	Integer	1308
ibdot1sMstVID.1309	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1309	Integer	1309
ibdot1sMstVID.1310	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1310	Integer	1310
ibdot1sMstVID.1311	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1311	Integer	1311
ibdot1sMstVID.1312	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1312	Integer	1312
ibdot1sMstVID.1313	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1313	Integer	1313
ibdot1sMstVID.1314	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1314	Integer	1314
ibdot1sMstVID.1315	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1315	Integer	1315
ibdot1sMstVID.1316	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1316	Integer	1316
ibdot1sMstVID.1317	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1317	Integer	1317
ibdot1sMstVID.1318	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1318	Integer	1318
ibdot1sMstVID.1319	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1319	Integer	1319
ibdot1sMstVID.1320	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1320	Integer	1320
ibdot1sMstVID.1321	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1321	Integer	1321

Name	OID	Value Type	Value Example
ibdot1sMstVID.1322	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1322	Integer	1322
ibdot1sMstVID.1323	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1323	Integer	1323
ibdot1sMstVID.1324	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1324	Integer	1324
ibdot1sMstVID.1325	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1325	Integer	1325
ibdot1sMstVID.1326	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1326	Integer	1326
ibdot1sMstVID.1327	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1327	Integer	1327
ibdot1sMstVID.1328	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1328	Integer	1328
ibdot1sMstVID.1329	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1329	Integer	1329
ibdot1sMstVID.1330	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1330	Integer	1330
ibdot1sMstVID.1331	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1331	Integer	1331
ibdot1sMstVID.1332	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1332	Integer	1332
ibdot1sMstVID.1333	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1333	Integer	1333
ibdot1sMstVID.1334	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1334	Integer	1334
ibdot1sMstVID.1335	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1335	Integer	1335
ibdot1sMstVID.1336	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1336	Integer	1336
ibdot1sMstVID.1337	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1337	Integer	1337
ibdot1sMstVID.1338	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1338	Integer	1338
ibdot1sMstVID.1339	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1339	Integer	1339
ibdot1sMstVID.1340	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1340	Integer	1340
ibdot1sMstVID.1341	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1341	Integer	1341
ibdot1sMstVID.1342	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1342	Integer	1342
ibdot1sMstVID.1343	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1343	Integer	1343
ibdot1sMstVID.1344	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1344	Integer	1344
ibdot1sMstVID.1345	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1345	Integer	1345
ibdot1sMstVID.1346	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1346	Integer	1346
ibdot1sMstVID.1347	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1347	Integer	1347
ibdot1sMstVID.1348	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1348	Integer	1348
ibdot1sMstVID.1349	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1349	Integer	1349
ibdot1sMstVID.1350	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1350	Integer	1350
ibdot1sMstVID.1351	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1351	Integer	1351
ibdot1sMstVID.1352	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1352	Integer	1352
ibdot1sMstVID.1353	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1353	Integer	1353
ibdot1sMstVID.1354	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1354	Integer	1354
ibdot1sMstVID.1355	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1355	Integer	1355
ibdot1sMstVID.1356	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1356	Integer	1356
ibdot1sMstVID.1357	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1357	Integer	1357
ibdot1sMstVID.1358	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1358	Integer	1358
ibdot1sMstVID.1359	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1359	Integer	1359
ibdot1sMstVID.1360	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1360	Integer	1360
ibdot1sMstVID.1361	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1361	Integer	1361
ibdot1sMstVID.1362	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1362	Integer	1362
ibdot1sMstVID.1363	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1363	Integer	1363
ibdot1sMstVID.1364	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1364	Integer	1364



Name	OID	Value Type	Value Example
ibdot1sMstVID.1365	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1365	Integer	1365
ibdot1sMstVID.1366	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1366	Integer	1366
ibdot1sMstVID.1367	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1367	Integer	1367
ibdot1sMstVID.1368	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1368	Integer	1368
ibdot1sMstVID.1369	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1369	Integer	1369
ibdot1sMstVID.1370	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1370	Integer	1370
ibdot1sMstVID.1371	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1371	Integer	1371
ibdot1sMstVID.1372	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1372	Integer	1372
ibdot1sMstVID.1373	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1373	Integer	1373
ibdot1sMstVID.1374	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1374	Integer	1374
ibdot1sMstVID.1375	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1375	Integer	1375
ibdot1sMstVID.1376	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1376	Integer	1376
ibdot1sMstVID.1377	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1377	Integer	1377
ibdot1sMstVID.1378	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1378	Integer	1378
ibdot1sMstVID.1379	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1379	Integer	1379
ibdot1sMstVID.1380	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1380	Integer	1380
ibdot1sMstVID.1381	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1381	Integer	1381
ibdot1sMstVID.1382	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1382	Integer	1382
ibdot1sMstVID.1383	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1383	Integer	1383
ibdot1sMstVID.1384	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1384	Integer	1384
ibdot1sMstVID.1385	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1385	Integer	1385
ibdot1sMstVID.1386	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1386	Integer	1386
ibdot1sMstVID.1387	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1387	Integer	1387
ibdot1sMstVID.1388	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1388	Integer	1388
ibdot1sMstVID.1389	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1389	Integer	1389
ibdot1sMstVID.1390	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1390	Integer	1390
ibdot1sMstVID.1391	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1391	Integer	1391
ibdot1sMstVID.1392	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1392	Integer	1392
ibdot1sMstVID.1393	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1393	Integer	1393
ibdot1sMstVID.1394	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1394	Integer	1394
ibdot1sMstVID.1395	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1395	Integer	1395
ibdot1sMstVID.1396	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1396	Integer	1396
ibdot1sMstVID.1397	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1397	Integer	1397
ibdot1sMstVID.1398	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1398	Integer	1398
ibdot1sMstVID.1399	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1399	Integer	1399
ibdot1sMstVID.1400	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1400	Integer	1400
ibdot1sMstVID.1401	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1401	Integer	1401
ibdot1sMstVID.1402	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1402	Integer	1402
ibdot1sMstVID.1403	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1403	Integer	1403
ibdot1sMstVID.1404	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1404	Integer	1404
ibdot1sMstVID.1405	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1405	Integer	1405
ibdot1sMstVID.1406	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1406	Integer	1406
ibdot1sMstVID.1407	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1407	Integer	1407



Name	OID	Value Type	Value Example
ibdot1sMstVID.1408	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1408	Integer	1408
ibdot1sMstVID.1409	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1409	Integer	1409
ibdot1sMstVID.1410	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1410	Integer	1410
ibdot1sMstVID.1411	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1411	Integer	1411
ibdot1sMstVID.1412	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1412	Integer	1412
ibdot1sMstVID.1413	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1413	Integer	1413
ibdot1sMstVID.1414	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1414	Integer	1414
ibdot1sMstVID.1415	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1415	Integer	1415
ibdot1sMstVID.1416	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1416	Integer	1416
ibdot1sMstVID.1417	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1417	Integer	1417
ibdot1sMstVID.1418	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1418	Integer	1418
ibdot1sMstVID.1419	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1419	Integer	1419
ibdot1sMstVID.1420	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1420	Integer	1420
ibdot1sMstVID.1421	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1421	Integer	1421
ibdot1sMstVID.1422	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1422	Integer	1422
ibdot1sMstVID.1423	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1423	Integer	1423
ibdot1sMstVID.1424	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1424	Integer	1424
ibdot1sMstVID.1425	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1425	Integer	1425
ibdot1sMstVID.1426	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1426	Integer	1426
ibdot1sMstVID.1427	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1427	Integer	1427
ibdot1sMstVID.1428	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1428	Integer	1428
ibdot1sMstVID.1429	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1429	Integer	1429
ibdot1sMstVID.1430	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1430	Integer	1430
ibdot1sMstVID.1431	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1431	Integer	1431
ibdot1sMstVID.1432	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1432	Integer	1432
ibdot1sMstVID.1433	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1433	Integer	1433
ibdot1sMstVID.1434	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1434	Integer	1434
ibdot1sMstVID.1435	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1435	Integer	1435
ibdot1sMstVID.1436	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1436	Integer	1436
ibdot1sMstVID.1437	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1437	Integer	1437
ibdot1sMstVID.1438	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1438	Integer	1438
ibdot1sMstVID.1439	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1439	Integer	1439
ibdot1sMstVID.1440	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1440	Integer	1440
ibdot1sMstVID.1441	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1441	Integer	1441
ibdot1sMstVID.1442	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1442	Integer	1442
ibdot1sMstVID.1443	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1443	Integer	1443
ibdot1sMstVID.1444	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1444	Integer	1444
ibdot1sMstVID.1445	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1445	Integer	1445
ibdot1sMstVID.1446	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1446	Integer	1446
ibdot1sMstVID.1447	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1447	Integer	1447
ibdot1sMstVID.1448	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1448	Integer	1448
ibdot1sMstVID.1449	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1449	Integer	1449
ibdot1sMstVID.1450	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1450	Integer	1450

Name	OID	Value Type	Value Example
ibdot1sMstVID.1451	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1451	Integer	1451
ibdot1sMstVID.1452	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1452	Integer	1452
ibdot1sMstVID.1453	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1453	Integer	1453
ibdot1sMstVID.1454	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1454	Integer	1454
ibdot1sMstVID.1455	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1455	Integer	1455
ibdot1sMstVID.1456	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1456	Integer	1456
ibdot1sMstVID.1457	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1457	Integer	1457
ibdot1sMstVID.1458	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1458	Integer	1458
ibdot1sMstVID.1459	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1459	Integer	1459
ibdot1sMstVID.1460	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1460	Integer	1460
ibdot1sMstVID.1461	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1461	Integer	1461
ibdot1sMstVID.1462	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1462	Integer	1462
ibdot1sMstVID.1463	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1463	Integer	1463
ibdot1sMstVID.1464	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1464	Integer	1464
ibdot1sMstVID.1465	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1465	Integer	1465
ibdot1sMstVID.1466	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1466	Integer	1466
ibdot1sMstVID.1467	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1467	Integer	1467
ibdot1sMstVID.1468	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1468	Integer	1468
ibdot1sMstVID.1469	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1469	Integer	1469
ibdot1sMstVID.1470	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1470	Integer	1470
ibdot1sMstVID.1471	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1471	Integer	1471
ibdot1sMstVID.1472	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1472	Integer	1472
ibdot1sMstVID.1473	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1473	Integer	1473
ibdot1sMstVID.1474	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1474	Integer	1474
ibdot1sMstVID.1475	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1475	Integer	1475
ibdot1sMstVID.1476	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1476	Integer	1476
ibdot1sMstVID.1477	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1477	Integer	1477
ibdot1sMstVID.1478	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1478	Integer	1478
ibdot1sMstVID.1479	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1479	Integer	1479
ibdot1sMstVID.1480	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1480	Integer	1480
ibdot1sMstVID.1481	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1481	Integer	1481
ibdot1sMstVID.1482	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1482	Integer	1482
ibdot1sMstVID.1483	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1483	Integer	1483
ibdot1sMstVID.1484	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1484	Integer	1484
ibdot1sMstVID.1485	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1485	Integer	1485
ibdot1sMstVID.1486	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1486	Integer	1486
ibdot1sMstVID.1487	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1487	Integer	1487
ibdot1sMstVID.1488	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1488	Integer	1488
ibdot1sMstVID.1489	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1489	Integer	1489
ibdot1sMstVID.1490	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1490	Integer	1490
ibdot1sMstVID.1491	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1491	Integer	1491
ibdot1sMstVID.1492	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1492	Integer	1492
ibdot1sMstVID.1493	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1493	Integer	1493

Name	OID	Value Type	Value Example
ibdot1sMstVID.1494	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1494	Integer	1494
ibdot1sMstVID.1495	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1495	Integer	1495
ibdot1sMstVID.1496	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1496	Integer	1496
ibdot1sMstVID.1497	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1497	Integer	1497
ibdot1sMstVID.1498	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1498	Integer	1498
ibdot1sMstVID.1499	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1499	Integer	1499
ibdot1sMstVID.1500	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1500	Integer	1500
ibdot1sMstVID.1501	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1501	Integer	1501
ibdot1sMstVID.1502	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1502	Integer	1502
ibdot1sMstVID.1503	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1503	Integer	1503
ibdot1sMstVID.1504	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1504	Integer	1504
ibdot1sMstVID.1505	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1505	Integer	1505
ibdot1sMstVID.1506	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1506	Integer	1506
ibdot1sMstVID.1507	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1507	Integer	1507
ibdot1sMstVID.1508	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1508	Integer	1508
ibdot1sMstVID.1509	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1509	Integer	1509
ibdot1sMstVID.1510	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1510	Integer	1510
ibdot1sMstVID.1511	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1511	Integer	1511
ibdot1sMstVID.1512	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1512	Integer	1512
ibdot1sMstVID.1513	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1513	Integer	1513
ibdot1sMstVID.1514	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1514	Integer	1514
ibdot1sMstVID.1515	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1515	Integer	1515
ibdot1sMstVID.1516	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1516	Integer	1516
ibdot1sMstVID.1517	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1517	Integer	1517
ibdot1sMstVID.1518	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1518	Integer	1518
ibdot1sMstVID.1519	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1519	Integer	1519
ibdot1sMstVID.1520	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1520	Integer	1520
ibdot1sMstVID.1521	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1521	Integer	1521
ibdot1sMstVID.1522	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1522	Integer	1522
ibdot1sMstVID.1523	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1523	Integer	1523
ibdot1sMstVID.1524	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1524	Integer	1524
ibdot1sMstVID.1525	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1525	Integer	1525
ibdot1sMstVID.1526	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1526	Integer	1526
ibdot1sMstVID.1527	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1527	Integer	1527
ibdot1sMstVID.1528	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1528	Integer	1528
ibdot1sMstVID.1529	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1529	Integer	1529
ibdot1sMstVID.1530	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1530	Integer	1530
ibdot1sMstVID.1531	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1531	Integer	1531
ibdot1sMstVID.1532	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1532	Integer	1532
ibdot1sMstVID.1533	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1533	Integer	1533
ibdot1sMstVID.1534	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1534	Integer	1534
ibdot1sMstVID.1535	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1535	Integer	1535
ibdot1sMstVID.1536	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1536	Integer	1536

Name	OID	Value Type	Value Example
ibdot1sMstVID.1537	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1537	Integer	1537
ibdot1sMstVID.1538	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1538	Integer	1538
ibdot1sMstVID.1539	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1539	Integer	1539
ibdot1sMstVID.1540	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1540	Integer	1540
ibdot1sMstVID.1541	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1541	Integer	1541
ibdot1sMstVID.1542	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1542	Integer	1542
ibdot1sMstVID.1543	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1543	Integer	1543
ibdot1sMstVID.1544	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1544	Integer	1544
ibdot1sMstVID.1545	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1545	Integer	1545
ibdot1sMstVID.1546	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1546	Integer	1546
ibdot1sMstVID.1547	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1547	Integer	1547
ibdot1sMstVID.1548	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1548	Integer	1548
ibdot1sMstVID.1549	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1549	Integer	1549
ibdot1sMstVID.1550	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1550	Integer	1550
ibdot1sMstVID.1551	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1551	Integer	1551
ibdot1sMstVID.1552	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1552	Integer	1552
ibdot1sMstVID.1553	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1553	Integer	1553
ibdot1sMstVID.1554	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1554	Integer	1554
ibdot1sMstVID.1555	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1555	Integer	1555
ibdot1sMstVID.1556	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1556	Integer	1556
ibdot1sMstVID.1557	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1557	Integer	1557
ibdot1sMstVID.1558	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1558	Integer	1558
ibdot1sMstVID.1559	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1559	Integer	1559
ibdot1sMstVID.1560	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1560	Integer	1560
ibdot1sMstVID.1561	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1561	Integer	1561
ibdot1sMstVID.1562	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1562	Integer	1562
ibdot1sMstVID.1563	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1563	Integer	1563
ibdot1sMstVID.1564	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1564	Integer	1564
ibdot1sMstVID.1565	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1565	Integer	1565
ibdot1sMstVID.1566	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1566	Integer	1566
ibdot1sMstVID.1567	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1567	Integer	1567
ibdot1sMstVID.1568	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1568	Integer	1568
ibdot1sMstVID.1569	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1569	Integer	1569
ibdot1sMstVID.1570	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1570	Integer	1570
ibdot1sMstVID.1571	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1571	Integer	1571
ibdot1sMstVID.1572	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1572	Integer	1572
ibdot1sMstVID.1573	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1573	Integer	1573
ibdot1sMstVID.1574	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1574	Integer	1574
ibdot1sMstVID.1575	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1575	Integer	1575
ibdot1sMstVID.1576	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1576	Integer	1576
ibdot1sMstVID.1577	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1577	Integer	1577
ibdot1sMstVID.1578	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1578	Integer	1578
ibdot1sMstVID.1579	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1579	Integer	1579

Name	OID	Value Type	Value Example
ibdot1sMstVID.1580	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1580	Integer	1580
ibdot1sMstVID.1581	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1581	Integer	1581
ibdot1sMstVID.1582	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1582	Integer	1582
ibdot1sMstVID.1583	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1583	Integer	1583
ibdot1sMstVID.1584	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1584	Integer	1584
ibdot1sMstVID.1585	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1585	Integer	1585
ibdot1sMstVID.1586	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1586	Integer	1586
ibdot1sMstVID.1587	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1587	Integer	1587
ibdot1sMstVID.1588	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1588	Integer	1588
ibdot1sMstVID.1589	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1589	Integer	1589
ibdot1sMstVID.1590	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1590	Integer	1590
ibdot1sMstVID.1591	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1591	Integer	1591
ibdot1sMstVID.1592	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1592	Integer	1592
ibdot1sMstVID.1593	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1593	Integer	1593
ibdot1sMstVID.1594	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1594	Integer	1594
ibdot1sMstVID.1595	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1595	Integer	1595
ibdot1sMstVID.1596	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1596	Integer	1596
ibdot1sMstVID.1597	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1597	Integer	1597
ibdot1sMstVID.1598	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1598	Integer	1598
ibdot1sMstVID.1599	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1599	Integer	1599
ibdot1sMstVID.1600	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1600	Integer	1600
ibdot1sMstVID.1601	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1601	Integer	1601
ibdot1sMstVID.1602	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1602	Integer	1602
ibdot1sMstVID.1603	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1603	Integer	1603
ibdot1sMstVID.1604	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1604	Integer	1604
ibdot1sMstVID.1605	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1605	Integer	1605
ibdot1sMstVID.1606	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1606	Integer	1606
ibdot1sMstVID.1607	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1607	Integer	1607
ibdot1sMstVID.1608	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1608	Integer	1608
ibdot1sMstVID.1609	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1609	Integer	1609
ibdot1sMstVID.1610	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1610	Integer	1610
ibdot1sMstVID.1611	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1611	Integer	1611
ibdot1sMstVID.1612	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1612	Integer	1612
ibdot1sMstVID.1613	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1613	Integer	1613
ibdot1sMstVID.1614	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1614	Integer	1614
ibdot1sMstVID.1615	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1615	Integer	1615
ibdot1sMstVID.1616	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1616	Integer	1616
ibdot1sMstVID.1617	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1617	Integer	1617
ibdot1sMstVID.1618	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1618	Integer	1618
ibdot1sMstVID.1619	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1619	Integer	1619
ibdot1sMstVID.1620	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1620	Integer	1620
ibdot1sMstVID.1621	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1621	Integer	1621
ibdot1sMstVID.1622	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1622	Integer	1622

Name	OID	Value Type	Value Example
ibdot1sMstVID.1623	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1623	Integer	1623
ibdot1sMstVID.1624	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1624	Integer	1624
ibdot1sMstVID.1625	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1625	Integer	1625
ibdot1sMstVID.1626	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1626	Integer	1626
ibdot1sMstVID.1627	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1627	Integer	1627
ibdot1sMstVID.1628	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1628	Integer	1628
ibdot1sMstVID.1629	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1629	Integer	1629
ibdot1sMstVID.1630	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1630	Integer	1630
ibdot1sMstVID.1631	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1631	Integer	1631
ibdot1sMstVID.1632	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1632	Integer	1632
ibdot1sMstVID.1633	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1633	Integer	1633
ibdot1sMstVID.1634	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1634	Integer	1634
ibdot1sMstVID.1635	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1635	Integer	1635
ibdot1sMstVID.1636	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1636	Integer	1636
ibdot1sMstVID.1637	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1637	Integer	1637
ibdot1sMstVID.1638	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1638	Integer	1638
ibdot1sMstVID.1639	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1639	Integer	1639
ibdot1sMstVID.1640	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1640	Integer	1640
ibdot1sMstVID.1641	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1641	Integer	1641
ibdot1sMstVID.1642	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1642	Integer	1642
ibdot1sMstVID.1643	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1643	Integer	1643
ibdot1sMstVID.1644	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1644	Integer	1644
ibdot1sMstVID.1645	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1645	Integer	1645
ibdot1sMstVID.1646	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1646	Integer	1646
ibdot1sMstVID.1647	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1647	Integer	1647
ibdot1sMstVID.1648	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1648	Integer	1648
ibdot1sMstVID.1649	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1649	Integer	1649
ibdot1sMstVID.1650	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1650	Integer	1650
ibdot1sMstVID.1651	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1651	Integer	1651
ibdot1sMstVID.1652	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1652	Integer	1652
ibdot1sMstVID.1653	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1653	Integer	1653
ibdot1sMstVID.1654	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1654	Integer	1654
ibdot1sMstVID.1655	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1655	Integer	1655
ibdot1sMstVID.1656	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1656	Integer	1656
ibdot1sMstVID.1657	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1657	Integer	1657
ibdot1sMstVID.1658	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1658	Integer	1658
ibdot1sMstVID.1659	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1659	Integer	1659
ibdot1sMstVID.1660	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1660	Integer	1660
ibdot1sMstVID.1661	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1661	Integer	1661
ibdot1sMstVID.1662	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1662	Integer	1662
ibdot1sMstVID.1663	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1663	Integer	1663
ibdot1sMstVID.1664	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1664	Integer	1664
ibdot1sMstVID.1665	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1665	Integer	1665

Name	OID	Value Type	Value Example
ibdot1sMstVID.1666	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1666	Integer	1666
ibdot1sMstVID.1667	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1667	Integer	1667
ibdot1sMstVID.1668	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1668	Integer	1668
ibdot1sMstVID.1669	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1669	Integer	1669
ibdot1sMstVID.1670	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1670	Integer	1670
ibdot1sMstVID.1671	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1671	Integer	1671
ibdot1sMstVID.1672	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1672	Integer	1672
ibdot1sMstVID.1673	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1673	Integer	1673
ibdot1sMstVID.1674	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1674	Integer	1674
ibdot1sMstVID.1675	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1675	Integer	1675
ibdot1sMstVID.1676	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1676	Integer	1676
ibdot1sMstVID.1677	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1677	Integer	1677
ibdot1sMstVID.1678	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1678	Integer	1678
ibdot1sMstVID.1679	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1679	Integer	1679
ibdot1sMstVID.1680	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1680	Integer	1680
ibdot1sMstVID.1681	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1681	Integer	1681
ibdot1sMstVID.1682	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1682	Integer	1682
ibdot1sMstVID.1683	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1683	Integer	1683
ibdot1sMstVID.1684	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1684	Integer	1684
ibdot1sMstVID.1685	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1685	Integer	1685
ibdot1sMstVID.1686	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1686	Integer	1686
ibdot1sMstVID.1687	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1687	Integer	1687
ibdot1sMstVID.1688	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1688	Integer	1688
ibdot1sMstVID.1689	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1689	Integer	1689
ibdot1sMstVID.1690	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1690	Integer	1690
ibdot1sMstVID.1691	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1691	Integer	1691
ibdot1sMstVID.1692	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1692	Integer	1692
ibdot1sMstVID.1693	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1693	Integer	1693
ibdot1sMstVID.1694	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1694	Integer	1694
ibdot1sMstVID.1695	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1695	Integer	1695
ibdot1sMstVID.1696	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1696	Integer	1696
ibdot1sMstVID.1697	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1697	Integer	1697
ibdot1sMstVID.1698	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1698	Integer	1698
ibdot1sMstVID.1699	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1699	Integer	1699
ibdot1sMstVID.1700	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1700	Integer	1700
ibdot1sMstVID.1701	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1701	Integer	1701
ibdot1sMstVID.1702	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1702	Integer	1702
ibdot1sMstVID.1703	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1703	Integer	1703
ibdot1sMstVID.1704	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1704	Integer	1704
ibdot1sMstVID.1705	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1705	Integer	1705
ibdot1sMstVID.1706	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1706	Integer	1706
ibdot1sMstVID.1707	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1707	Integer	1707
ibdot1sMstVID.1708	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1708	Integer	1708



Name	OID	Value Type	Value Example
ibdot1sMstVID.1709	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1709	Integer	1709
ibdot1sMstVID.1710	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1710	Integer	1710
ibdot1sMstVID.1711	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1711	Integer	1711
ibdot1sMstVID.1712	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1712	Integer	1712
ibdot1sMstVID.1713	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1713	Integer	1713
ibdot1sMstVID.1714	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1714	Integer	1714
ibdot1sMstVID.1715	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1715	Integer	1715
ibdot1sMstVID.1716	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1716	Integer	1716
ibdot1sMstVID.1717	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1717	Integer	1717
ibdot1sMstVID.1718	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1718	Integer	1718
ibdot1sMstVID.1719	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1719	Integer	1719
ibdot1sMstVID.1720	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1720	Integer	1720
ibdot1sMstVID.1721	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1721	Integer	1721
ibdot1sMstVID.1722	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1722	Integer	1722
ibdot1sMstVID.1723	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1723	Integer	1723
ibdot1sMstVID.1724	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1724	Integer	1724
ibdot1sMstVID.1725	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1725	Integer	1725
ibdot1sMstVID.1726	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1726	Integer	1726
ibdot1sMstVID.1727	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1727	Integer	1727
ibdot1sMstVID.1728	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1728	Integer	1728
ibdot1sMstVID.1729	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1729	Integer	1729
ibdot1sMstVID.1730	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1730	Integer	1730
ibdot1sMstVID.1731	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1731	Integer	1731
ibdot1sMstVID.1732	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1732	Integer	1732
ibdot1sMstVID.1733	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1733	Integer	1733
ibdot1sMstVID.1734	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1734	Integer	1734
ibdot1sMstVID.1735	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1735	Integer	1735
ibdot1sMstVID.1736	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1736	Integer	1736
ibdot1sMstVID.1737	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1737	Integer	1737
ibdot1sMstVID.1738	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1738	Integer	1738
ibdot1sMstVID.1739	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1739	Integer	1739
ibdot1sMstVID.1740	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1740	Integer	1740
ibdot1sMstVID.1741	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1741	Integer	1741
ibdot1sMstVID.1742	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1742	Integer	1742
ibdot1sMstVID.1743	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1743	Integer	1743
ibdot1sMstVID.1744	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1744	Integer	1744
ibdot1sMstVID.1745	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1745	Integer	1745
ibdot1sMstVID.1746	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1746	Integer	1746
ibdot1sMstVID.1747	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1747	Integer	1747
ibdot1sMstVID.1748	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1748	Integer	1748
ibdot1sMstVID.1749	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1749	Integer	1749
ibdot1sMstVID.1750	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1750	Integer	1750
ibdot1sMstVID.1751	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1751	Integer	1751



Name	OID	Value Type	Value Example
ibdot1sMstVID.1752	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1752	Integer	1752
ibdot1sMstVID.1753	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1753	Integer	1753
ibdot1sMstVID.1754	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1754	Integer	1754
ibdot1sMstVID.1755	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1755	Integer	1755
ibdot1sMstVID.1756	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1756	Integer	1756
ibdot1sMstVID.1757	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1757	Integer	1757
ibdot1sMstVID.1758	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1758	Integer	1758
ibdot1sMstVID.1759	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1759	Integer	1759
ibdot1sMstVID.1760	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1760	Integer	1760
ibdot1sMstVID.1761	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1761	Integer	1761
ibdot1sMstVID.1762	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1762	Integer	1762
ibdot1sMstVID.1763	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1763	Integer	1763
ibdot1sMstVID.1764	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1764	Integer	1764
ibdot1sMstVID.1765	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1765	Integer	1765
ibdot1sMstVID.1766	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1766	Integer	1766
ibdot1sMstVID.1767	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1767	Integer	1767
ibdot1sMstVID.1768	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1768	Integer	1768
ibdot1sMstVID.1769	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1769	Integer	1769
ibdot1sMstVID.1770	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1770	Integer	1770
ibdot1sMstVID.1771	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1771	Integer	1771
ibdot1sMstVID.1772	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1772	Integer	1772
ibdot1sMstVID.1773	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1773	Integer	1773
ibdot1sMstVID.1774	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1774	Integer	1774
ibdot1sMstVID.1775	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1775	Integer	1775
ibdot1sMstVID.1776	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1776	Integer	1776
ibdot1sMstVID.1777	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1777	Integer	1777
ibdot1sMstVID.1778	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1778	Integer	1778
ibdot1sMstVID.1779	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1779	Integer	1779
ibdot1sMstVID.1780	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1780	Integer	1780
ibdot1sMstVID.1781	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1781	Integer	1781
ibdot1sMstVID.1782	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1782	Integer	1782
ibdot1sMstVID.1783	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1783	Integer	1783
ibdot1sMstVID.1784	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1784	Integer	1784
ibdot1sMstVID.1785	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1785	Integer	1785
ibdot1sMstVID.1786	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1786	Integer	1786
ibdot1sMstVID.1787	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1787	Integer	1787
ibdot1sMstVID.1788	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1788	Integer	1788
ibdot1sMstVID.1789	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1789	Integer	1789
ibdot1sMstVID.1790	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1790	Integer	1790
ibdot1sMstVID.1791	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1791	Integer	1791
ibdot1sMstVID.1792	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1792	Integer	1792
ibdot1sMstVID.1793	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1793	Integer	1793
ibdot1sMstVID.1794	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1794	Integer	1794

Name	OID	Value Type	Value Example
ibdot1sMstVID.1795	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1795	Integer	1795
ibdot1sMstVID.1796	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1796	Integer	1796
ibdot1sMstVID.1797	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1797	Integer	1797
ibdot1sMstVID.1798	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1798	Integer	1798
ibdot1sMstVID.1799	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1799	Integer	1799
ibdot1sMstVID.1800	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1800	Integer	1800
ibdot1sMstVID.1801	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1801	Integer	1801
ibdot1sMstVID.1802	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1802	Integer	1802
ibdot1sMstVID.1803	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1803	Integer	1803
ibdot1sMstVID.1804	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1804	Integer	1804
ibdot1sMstVID.1805	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1805	Integer	1805
ibdot1sMstVID.1806	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1806	Integer	1806
ibdot1sMstVID.1807	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1807	Integer	1807
ibdot1sMstVID.1808	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1808	Integer	1808
ibdot1sMstVID.1809	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1809	Integer	1809
ibdot1sMstVID.1810	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1810	Integer	1810
ibdot1sMstVID.1811	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1811	Integer	1811
ibdot1sMstVID.1812	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1812	Integer	1812
ibdot1sMstVID.1813	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1813	Integer	1813
ibdot1sMstVID.1814	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1814	Integer	1814
ibdot1sMstVID.1815	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1815	Integer	1815
ibdot1sMstVID.1816	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1816	Integer	1816
ibdot1sMstVID.1817	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1817	Integer	1817
ibdot1sMstVID.1818	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1818	Integer	1818
ibdot1sMstVID.1819	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1819	Integer	1819
ibdot1sMstVID.1820	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1820	Integer	1820
ibdot1sMstVID.1821	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1821	Integer	1821
ibdot1sMstVID.1822	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1822	Integer	1822
ibdot1sMstVID.1823	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1823	Integer	1823
ibdot1sMstVID.1824	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1824	Integer	1824
ibdot1sMstVID.1825	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1825	Integer	1825
ibdot1sMstVID.1826	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1826	Integer	1826
ibdot1sMstVID.1827	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1827	Integer	1827
ibdot1sMstVID.1828	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1828	Integer	1828
ibdot1sMstVID.1829	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1829	Integer	1829
ibdot1sMstVID.1830	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1830	Integer	1830
ibdot1sMstVID.1831	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1831	Integer	1831
ibdot1sMstVID.1832	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1832	Integer	1832
ibdot1sMstVID.1833	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1833	Integer	1833
ibdot1sMstVID.1834	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1834	Integer	1834
ibdot1sMstVID.1835	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1835	Integer	1835
ibdot1sMstVID.1836	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1836	Integer	1836
ibdot1sMstVID.1837	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1837	Integer	1837

Name	OID	Value Type	Value Example
ibdot1sMstVID.1838	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1838	Integer	1838
ibdot1sMstVID.1839	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1839	Integer	1839
ibdot1sMstVID.1840	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1840	Integer	1840
ibdot1sMstVID.1841	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1841	Integer	1841
ibdot1sMstVID.1842	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1842	Integer	1842
ibdot1sMstVID.1843	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1843	Integer	1843
ibdot1sMstVID.1844	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1844	Integer	1844
ibdot1sMstVID.1845	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1845	Integer	1845
ibdot1sMstVID.1846	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1846	Integer	1846
ibdot1sMstVID.1847	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1847	Integer	1847
ibdot1sMstVID.1848	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1848	Integer	1848
ibdot1sMstVID.1849	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1849	Integer	1849
ibdot1sMstVID.1850	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1850	Integer	1850
ibdot1sMstVID.1851	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1851	Integer	1851
ibdot1sMstVID.1852	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1852	Integer	1852
ibdot1sMstVID.1853	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1853	Integer	1853
ibdot1sMstVID.1854	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1854	Integer	1854
ibdot1sMstVID.1855	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1855	Integer	1855
ibdot1sMstVID.1856	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1856	Integer	1856
ibdot1sMstVID.1857	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1857	Integer	1857
ibdot1sMstVID.1858	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1858	Integer	1858
ibdot1sMstVID.1859	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1859	Integer	1859
ibdot1sMstVID.1860	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1860	Integer	1860
ibdot1sMstVID.1861	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1861	Integer	1861
ibdot1sMstVID.1862	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1862	Integer	1862
ibdot1sMstVID.1863	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1863	Integer	1863
ibdot1sMstVID.1864	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1864	Integer	1864
ibdot1sMstVID.1865	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1865	Integer	1865
ibdot1sMstVID.1866	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1866	Integer	1866
ibdot1sMstVID.1867	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1867	Integer	1867
ibdot1sMstVID.1868	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1868	Integer	1868
ibdot1sMstVID.1869	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1869	Integer	1869
ibdot1sMstVID.1870	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1870	Integer	1870
ibdot1sMstVID.1871	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1871	Integer	1871
ibdot1sMstVID.1872	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1872	Integer	1872
ibdot1sMstVID.1873	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1873	Integer	1873
ibdot1sMstVID.1874	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1874	Integer	1874
ibdot1sMstVID.1875	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1875	Integer	1875
ibdot1sMstVID.1876	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1876	Integer	1876
ibdot1sMstVID.1877	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1877	Integer	1877
ibdot1sMstVID.1878	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1878	Integer	1878
ibdot1sMstVID.1879	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1879	Integer	1879
ibdot1sMstVID.1880	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1880	Integer	1880

Name	OID	Value Type	Value Example
ibdot1sMstVID.1881	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1881	Integer	1881
ibdot1sMstVID.1882	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1882	Integer	1882
ibdot1sMstVID.1883	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1883	Integer	1883
ibdot1sMstVID.1884	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1884	Integer	1884
ibdot1sMstVID.1885	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1885	Integer	1885
ibdot1sMstVID.1886	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1886	Integer	1886
ibdot1sMstVID.1887	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1887	Integer	1887
ibdot1sMstVID.1888	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1888	Integer	1888
ibdot1sMstVID.1889	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1889	Integer	1889
ibdot1sMstVID.1890	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1890	Integer	1890
ibdot1sMstVID.1891	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1891	Integer	1891
ibdot1sMstVID.1892	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1892	Integer	1892
ibdot1sMstVID.1893	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1893	Integer	1893
ibdot1sMstVID.1894	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1894	Integer	1894
ibdot1sMstVID.1895	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1895	Integer	1895
ibdot1sMstVID.1896	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1896	Integer	1896
ibdot1sMstVID.1897	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1897	Integer	1897
ibdot1sMstVID.1898	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1898	Integer	1898
ibdot1sMstVID.1899	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1899	Integer	1899
ibdot1sMstVID.1900	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1900	Integer	1900
ibdot1sMstVID.1901	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1901	Integer	1901
ibdot1sMstVID.1902	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1902	Integer	1902
ibdot1sMstVID.1903	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1903	Integer	1903
ibdot1sMstVID.1904	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1904	Integer	1904
ibdot1sMstVID.1905	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1905	Integer	1905
ibdot1sMstVID.1906	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1906	Integer	1906
ibdot1sMstVID.1907	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1907	Integer	1907
ibdot1sMstVID.1908	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1908	Integer	1908
ibdot1sMstVID.1909	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1909	Integer	1909
ibdot1sMstVID.1910	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1910	Integer	1910
ibdot1sMstVID.1911	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1911	Integer	1911
ibdot1sMstVID.1912	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1912	Integer	1912
ibdot1sMstVID.1913	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1913	Integer	1913
ibdot1sMstVID.1914	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1914	Integer	1914
ibdot1sMstVID.1915	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1915	Integer	1915
ibdot1sMstVID.1916	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1916	Integer	1916
ibdot1sMstVID.1917	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1917	Integer	1917
ibdot1sMstVID.1918	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1918	Integer	1918
ibdot1sMstVID.1919	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1919	Integer	1919
ibdot1sMstVID.1920	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1920	Integer	1920
ibdot1sMstVID.1921	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1921	Integer	1921
ibdot1sMstVID.1922	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1922	Integer	1922
ibdot1sMstVID.1923	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1923	Integer	1923

Name	OID	Value Type	Value Example
ibdot1sMstVID.1924	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1924	Integer	1924
ibdot1sMstVID.1925	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1925	Integer	1925
ibdot1sMstVID.1926	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1926	Integer	1926
ibdot1sMstVID.1927	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1927	Integer	1927
ibdot1sMstVID.1928	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1928	Integer	1928
ibdot1sMstVID.1929	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1929	Integer	1929
ibdot1sMstVID.1930	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1930	Integer	1930
ibdot1sMstVID.1931	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1931	Integer	1931
ibdot1sMstVID.1932	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1932	Integer	1932
ibdot1sMstVID.1933	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1933	Integer	1933
ibdot1sMstVID.1934	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1934	Integer	1934
ibdot1sMstVID.1935	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1935	Integer	1935
ibdot1sMstVID.1936	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1936	Integer	1936
ibdot1sMstVID.1937	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1937	Integer	1937
ibdot1sMstVID.1938	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1938	Integer	1938
ibdot1sMstVID.1939	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1939	Integer	1939
ibdot1sMstVID.1940	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1940	Integer	1940
ibdot1sMstVID.1941	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1941	Integer	1941
ibdot1sMstVID.1942	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1942	Integer	1942
ibdot1sMstVID.1943	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1943	Integer	1943
ibdot1sMstVID.1944	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1944	Integer	1944
ibdot1sMstVID.1945	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1945	Integer	1945
ibdot1sMstVID.1946	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1946	Integer	1946
ibdot1sMstVID.1947	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1947	Integer	1947
ibdot1sMstVID.1948	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1948	Integer	1948
ibdot1sMstVID.1949	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1949	Integer	1949
ibdot1sMstVID.1950	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1950	Integer	1950
ibdot1sMstVID.1951	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1951	Integer	1951
ibdot1sMstVID.1952	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1952	Integer	1952
ibdot1sMstVID.1953	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1953	Integer	1953
ibdot1sMstVID.1954	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1954	Integer	1954
ibdot1sMstVID.1955	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1955	Integer	1955
ibdot1sMstVID.1956	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1956	Integer	1956
ibdot1sMstVID.1957	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1957	Integer	1957
ibdot1sMstVID.1958	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1958	Integer	1958
ibdot1sMstVID.1959	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1959	Integer	1959
ibdot1sMstVID.1960	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1960	Integer	1960
ibdot1sMstVID.1961	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1961	Integer	1961
ibdot1sMstVID.1962	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1962	Integer	1962
ibdot1sMstVID.1963	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1963	Integer	1963
ibdot1sMstVID.1964	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1964	Integer	1964
ibdot1sMstVID.1965	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1965	Integer	1965
ibdot1sMstVID.1966	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1966	Integer	1966

Name	OID	Value Type	Value Example
ibdot1sMstVID.1967	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1967	Integer	1967
ibdot1sMstVID.1968	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1968	Integer	1968
ibdot1sMstVID.1969	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1969	Integer	1969
ibdot1sMstVID.1970	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1970	Integer	1970
ibdot1sMstVID.1971	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1971	Integer	1971
ibdot1sMstVID.1972	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1972	Integer	1972
ibdot1sMstVID.1973	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1973	Integer	1973
ibdot1sMstVID.1974	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1974	Integer	1974
ibdot1sMstVID.1975	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1975	Integer	1975
ibdot1sMstVID.1976	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1976	Integer	1976
ibdot1sMstVID.1977	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1977	Integer	1977
ibdot1sMstVID.1978	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1978	Integer	1978
ibdot1sMstVID.1979	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1979	Integer	1979
ibdot1sMstVID.1980	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1980	Integer	1980
ibdot1sMstVID.1981	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1981	Integer	1981
ibdot1sMstVID.1982	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1982	Integer	1982
ibdot1sMstVID.1983	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1983	Integer	1983
ibdot1sMstVID.1984	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1984	Integer	1984
ibdot1sMstVID.1985	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1985	Integer	1985
ibdot1sMstVID.1986	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1986	Integer	1986
ibdot1sMstVID.1987	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1987	Integer	1987
ibdot1sMstVID.1988	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1988	Integer	1988
ibdot1sMstVID.1989	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1989	Integer	1989
ibdot1sMstVID.1990	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1990	Integer	1990
ibdot1sMstVID.1991	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1991	Integer	1991
ibdot1sMstVID.1992	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1992	Integer	1992
ibdot1sMstVID.1993	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1993	Integer	1993
ibdot1sMstVID.1994	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1994	Integer	1994
ibdot1sMstVID.1995	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1995	Integer	1995
ibdot1sMstVID.1996	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1996	Integer	1996
ibdot1sMstVID.1997	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1997	Integer	1997
ibdot1sMstVID.1998	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1998	Integer	1998
ibdot1sMstVID.1999	.1.3.6.1.4.1.26138.8.35.14.18.1.1.1999	Integer	1999
ibdot1sMstVID.2000	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2000	Integer	2000
ibdot1sMstVID.2001	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2001	Integer	2001
ibdot1sMstVID.2002	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2002	Integer	2002
ibdot1sMstVID.2003	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2003	Integer	2003
ibdot1sMstVID.2004	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2004	Integer	2004
ibdot1sMstVID.2005	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2005	Integer	2005
ibdot1sMstVID.2006	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2006	Integer	2006
ibdot1sMstVID.2007	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2007	Integer	2007
ibdot1sMstVID.2008	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2008	Integer	2008
ibdot1sMstVID.2009	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2009	Integer	2009

Name	OID	Value Type	Value Example
ibdot1sMstVID.2010	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2010	Integer	2010
ibdot1sMstVID.2011	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2011	Integer	2011
ibdot1sMstVID.2012	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2012	Integer	2012
ibdot1sMstVID.2013	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2013	Integer	2013
ibdot1sMstVID.2014	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2014	Integer	2014
ibdot1sMstVID.2015	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2015	Integer	2015
ibdot1sMstVID.2016	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2016	Integer	2016
ibdot1sMstVID.2017	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2017	Integer	2017
ibdot1sMstVID.2018	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2018	Integer	2018
ibdot1sMstVID.2019	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2019	Integer	2019
ibdot1sMstVID.2020	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2020	Integer	2020
ibdot1sMstVID.2021	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2021	Integer	2021
ibdot1sMstVID.2022	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2022	Integer	2022
ibdot1sMstVID.2023	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2023	Integer	2023
ibdot1sMstVID.2024	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2024	Integer	2024
ibdot1sMstVID.2025	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2025	Integer	2025
ibdot1sMstVID.2026	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2026	Integer	2026
ibdot1sMstVID.2027	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2027	Integer	2027
ibdot1sMstVID.2028	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2028	Integer	2028
ibdot1sMstVID.2029	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2029	Integer	2029
ibdot1sMstVID.2030	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2030	Integer	2030
ibdot1sMstVID.2031	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2031	Integer	2031
ibdot1sMstVID.2032	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2032	Integer	2032
ibdot1sMstVID.2033	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2033	Integer	2033
ibdot1sMstVID.2034	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2034	Integer	2034
ibdot1sMstVID.2035	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2035	Integer	2035
ibdot1sMstVID.2036	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2036	Integer	2036
ibdot1sMstVID.2037	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2037	Integer	2037
ibdot1sMstVID.2038	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2038	Integer	2038
ibdot1sMstVID.2039	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2039	Integer	2039
ibdot1sMstVID.2040	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2040	Integer	2040
ibdot1sMstVID.2041	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2041	Integer	2041
ibdot1sMstVID.2042	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2042	Integer	2042
ibdot1sMstVID.2043	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2043	Integer	2043
ibdot1sMstVID.2044	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2044	Integer	2044
ibdot1sMstVID.2045	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2045	Integer	2045
ibdot1sMstVID.2046	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2046	Integer	2046
ibdot1sMstVID.2047	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2047	Integer	2047
ibdot1sMstVID.2048	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2048	Integer	2048
ibdot1sMstVID.2049	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2049	Integer	2049
ibdot1sMstVID.2050	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2050	Integer	2050
ibdot1sMstVID.2051	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2051	Integer	2051
ibdot1sMstVID.2052	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2052	Integer	2052



Name	OID	Value Type	Value Example
ibdot1sMstVID.2053	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2053	Integer	2053
ibdot1sMstVID.2054	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2054	Integer	2054
ibdot1sMstVID.2055	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2055	Integer	2055
ibdot1sMstVID.2056	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2056	Integer	2056
ibdot1sMstVID.2057	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2057	Integer	2057
ibdot1sMstVID.2058	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2058	Integer	2058
ibdot1sMstVID.2059	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2059	Integer	2059
ibdot1sMstVID.2060	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2060	Integer	2060
ibdot1sMstVID.2061	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2061	Integer	2061
ibdot1sMstVID.2062	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2062	Integer	2062
ibdot1sMstVID.2063	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2063	Integer	2063
ibdot1sMstVID.2064	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2064	Integer	2064
ibdot1sMstVID.2065	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2065	Integer	2065
ibdot1sMstVID.2066	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2066	Integer	2066
ibdot1sMstVID.2067	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2067	Integer	2067
ibdot1sMstVID.2068	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2068	Integer	2068
ibdot1sMstVID.2069	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2069	Integer	2069
ibdot1sMstVID.2070	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2070	Integer	2070
ibdot1sMstVID.2071	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2071	Integer	2071
ibdot1sMstVID.2072	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2072	Integer	2072
ibdot1sMstVID.2073	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2073	Integer	2073
ibdot1sMstVID.2074	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2074	Integer	2074
ibdot1sMstVID.2075	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2075	Integer	2075
ibdot1sMstVID.2076	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2076	Integer	2076
ibdot1sMstVID.2077	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2077	Integer	2077
ibdot1sMstVID.2078	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2078	Integer	2078
ibdot1sMstVID.2079	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2079	Integer	2079
ibdot1sMstVID.2080	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2080	Integer	2080
ibdot1sMstVID.2081	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2081	Integer	2081
ibdot1sMstVID.2082	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2082	Integer	2082
ibdot1sMstVID.2083	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2083	Integer	2083
ibdot1sMstVID.2084	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2084	Integer	2084
ibdot1sMstVID.2085	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2085	Integer	2085
ibdot1sMstVID.2086	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2086	Integer	2086
ibdot1sMstVID.2087	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2087	Integer	2087
ibdot1sMstVID.2088	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2088	Integer	2088
ibdot1sMstVID.2089	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2089	Integer	2089
ibdot1sMstVID.2090	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2090	Integer	2090
ibdot1sMstVID.2091	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2091	Integer	2091
ibdot1sMstVID.2092	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2092	Integer	2092
ibdot1sMstVID.2093	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2093	Integer	2093
ibdot1sMstVID.2094	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2094	Integer	2094
ibdot1sMstVID.2095	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2095	Integer	2095

Name	OID	Value Type	Value Example
ibdot1sMstVID.2096	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2096	Integer	2096
ibdot1sMstVID.2097	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2097	Integer	2097
ibdot1sMstVID.2098	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2098	Integer	2098
ibdot1sMstVID.2099	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2099	Integer	2099
ibdot1sMstVID.2100	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2100	Integer	2100
ibdot1sMstVID.2101	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2101	Integer	2101
ibdot1sMstVID.2102	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2102	Integer	2102
ibdot1sMstVID.2103	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2103	Integer	2103
ibdot1sMstVID.2104	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2104	Integer	2104
ibdot1sMstVID.2105	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2105	Integer	2105
ibdot1sMstVID.2106	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2106	Integer	2106
ibdot1sMstVID.2107	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2107	Integer	2107
ibdot1sMstVID.2108	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2108	Integer	2108
ibdot1sMstVID.2109	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2109	Integer	2109
ibdot1sMstVID.2110	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2110	Integer	2110
ibdot1sMstVID.2111	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2111	Integer	2111
ibdot1sMstVID.2112	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2112	Integer	2112
ibdot1sMstVID.2113	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2113	Integer	2113
ibdot1sMstVID.2114	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2114	Integer	2114
ibdot1sMstVID.2115	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2115	Integer	2115
ibdot1sMstVID.2116	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2116	Integer	2116
ibdot1sMstVID.2117	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2117	Integer	2117
ibdot1sMstVID.2118	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2118	Integer	2118
ibdot1sMstVID.2119	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2119	Integer	2119
ibdot1sMstVID.2120	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2120	Integer	2120
ibdot1sMstVID.2121	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2121	Integer	2121
ibdot1sMstVID.2122	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2122	Integer	2122
ibdot1sMstVID.2123	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2123	Integer	2123
ibdot1sMstVID.2124	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2124	Integer	2124
ibdot1sMstVID.2125	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2125	Integer	2125
ibdot1sMstVID.2126	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2126	Integer	2126
ibdot1sMstVID.2127	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2127	Integer	2127
ibdot1sMstVID.2128	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2128	Integer	2128
ibdot1sMstVID.2129	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2129	Integer	2129
ibdot1sMstVID.2130	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2130	Integer	2130
ibdot1sMstVID.2131	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2131	Integer	2131
ibdot1sMstVID.2132	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2132	Integer	2132
ibdot1sMstVID.2133	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2133	Integer	2133
ibdot1sMstVID.2134	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2134	Integer	2134
ibdot1sMstVID.2135	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2135	Integer	2135
ibdot1sMstVID.2136	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2136	Integer	2136
ibdot1sMstVID.2137	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2137	Integer	2137
ibdot1sMstVID.2138	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2138	Integer	2138

Name	OID	Value Type	Value Example
ibdot1sMstVID.2139	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2139	Integer	2139
ibdot1sMstVID.2140	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2140	Integer	2140
ibdot1sMstVID.2141	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2141	Integer	2141
ibdot1sMstVID.2142	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2142	Integer	2142
ibdot1sMstVID.2143	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2143	Integer	2143
ibdot1sMstVID.2144	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2144	Integer	2144
ibdot1sMstVID.2145	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2145	Integer	2145
ibdot1sMstVID.2146	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2146	Integer	2146
ibdot1sMstVID.2147	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2147	Integer	2147
ibdot1sMstVID.2148	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2148	Integer	2148
ibdot1sMstVID.2149	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2149	Integer	2149
ibdot1sMstVID.2150	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2150	Integer	2150
ibdot1sMstVID.2151	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2151	Integer	2151
ibdot1sMstVID.2152	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2152	Integer	2152
ibdot1sMstVID.2153	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2153	Integer	2153
ibdot1sMstVID.2154	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2154	Integer	2154
ibdot1sMstVID.2155	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2155	Integer	2155
ibdot1sMstVID.2156	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2156	Integer	2156
ibdot1sMstVID.2157	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2157	Integer	2157
ibdot1sMstVID.2158	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2158	Integer	2158
ibdot1sMstVID.2159	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2159	Integer	2159
ibdot1sMstVID.2160	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2160	Integer	2160
ibdot1sMstVID.2161	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2161	Integer	2161
ibdot1sMstVID.2162	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2162	Integer	2162
ibdot1sMstVID.2163	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2163	Integer	2163
ibdot1sMstVID.2164	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2164	Integer	2164
ibdot1sMstVID.2165	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2165	Integer	2165
ibdot1sMstVID.2166	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2166	Integer	2166
ibdot1sMstVID.2167	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2167	Integer	2167
ibdot1sMstVID.2168	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2168	Integer	2168
ibdot1sMstVID.2169	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2169	Integer	2169
ibdot1sMstVID.2170	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2170	Integer	2170
ibdot1sMstVID.2171	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2171	Integer	2171
ibdot1sMstVID.2172	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2172	Integer	2172
ibdot1sMstVID.2173	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2173	Integer	2173
ibdot1sMstVID.2174	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2174	Integer	2174
ibdot1sMstVID.2175	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2175	Integer	2175
ibdot1sMstVID.2176	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2176	Integer	2176
ibdot1sMstVID.2177	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2177	Integer	2177
ibdot1sMstVID.2178	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2178	Integer	2178
ibdot1sMstVID.2179	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2179	Integer	2179
ibdot1sMstVID.2180	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2180	Integer	2180
ibdot1sMstVID.2181	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2181	Integer	2181

Name	OID	Value Type	Value Example
ibdot1sMstVID.2182	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2182	Integer	2182
ibdot1sMstVID.2183	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2183	Integer	2183
ibdot1sMstVID.2184	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2184	Integer	2184
ibdot1sMstVID.2185	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2185	Integer	2185
ibdot1sMstVID.2186	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2186	Integer	2186
ibdot1sMstVID.2187	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2187	Integer	2187
ibdot1sMstVID.2188	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2188	Integer	2188
ibdot1sMstVID.2189	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2189	Integer	2189
ibdot1sMstVID.2190	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2190	Integer	2190
ibdot1sMstVID.2191	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2191	Integer	2191
ibdot1sMstVID.2192	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2192	Integer	2192
ibdot1sMstVID.2193	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2193	Integer	2193
ibdot1sMstVID.2194	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2194	Integer	2194
ibdot1sMstVID.2195	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2195	Integer	2195
ibdot1sMstVID.2196	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2196	Integer	2196
ibdot1sMstVID.2197	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2197	Integer	2197
ibdot1sMstVID.2198	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2198	Integer	2198
ibdot1sMstVID.2199	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2199	Integer	2199
ibdot1sMstVID.2200	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2200	Integer	2200
ibdot1sMstVID.2201	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2201	Integer	2201
ibdot1sMstVID.2202	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2202	Integer	2202
ibdot1sMstVID.2203	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2203	Integer	2203
ibdot1sMstVID.2204	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2204	Integer	2204
ibdot1sMstVID.2205	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2205	Integer	2205
ibdot1sMstVID.2206	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2206	Integer	2206
ibdot1sMstVID.2207	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2207	Integer	2207
ibdot1sMstVID.2208	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2208	Integer	2208
ibdot1sMstVID.2209	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2209	Integer	2209
ibdot1sMstVID.2210	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2210	Integer	2210
ibdot1sMstVID.2211	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2211	Integer	2211
ibdot1sMstVID.2212	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2212	Integer	2212
ibdot1sMstVID.2213	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2213	Integer	2213
ibdot1sMstVID.2214	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2214	Integer	2214
ibdot1sMstVID.2215	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2215	Integer	2215
ibdot1sMstVID.2216	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2216	Integer	2216
ibdot1sMstVID.2217	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2217	Integer	2217
ibdot1sMstVID.2218	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2218	Integer	2218
ibdot1sMstVID.2219	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2219	Integer	2219
ibdot1sMstVID.2220	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2220	Integer	2220
ibdot1sMstVID.2221	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2221	Integer	2221
ibdot1sMstVID.2222	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2222	Integer	2222
ibdot1sMstVID.2223	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2223	Integer	2223
ibdot1sMstVID.2224	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2224	Integer	2224

Name	OID	Value Type	Value Example
ibdot1sMstVID.2225	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2225	Integer	2225
ibdot1sMstVID.2226	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2226	Integer	2226
ibdot1sMstVID.2227	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2227	Integer	2227
ibdot1sMstVID.2228	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2228	Integer	2228
ibdot1sMstVID.2229	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2229	Integer	2229
ibdot1sMstVID.2230	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2230	Integer	2230
ibdot1sMstVID.2231	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2231	Integer	2231
ibdot1sMstVID.2232	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2232	Integer	2232
ibdot1sMstVID.2233	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2233	Integer	2233
ibdot1sMstVID.2234	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2234	Integer	2234
ibdot1sMstVID.2235	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2235	Integer	2235
ibdot1sMstVID.2236	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2236	Integer	2236
ibdot1sMstVID.2237	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2237	Integer	2237
ibdot1sMstVID.2238	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2238	Integer	2238
ibdot1sMstVID.2239	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2239	Integer	2239
ibdot1sMstVID.2240	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2240	Integer	2240
ibdot1sMstVID.2241	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2241	Integer	2241
ibdot1sMstVID.2242	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2242	Integer	2242
ibdot1sMstVID.2243	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2243	Integer	2243
ibdot1sMstVID.2244	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2244	Integer	2244
ibdot1sMstVID.2245	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2245	Integer	2245
ibdot1sMstVID.2246	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2246	Integer	2246
ibdot1sMstVID.2247	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2247	Integer	2247
ibdot1sMstVID.2248	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2248	Integer	2248
ibdot1sMstVID.2249	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2249	Integer	2249
ibdot1sMstVID.2250	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2250	Integer	2250
ibdot1sMstVID.2251	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2251	Integer	2251
ibdot1sMstVID.2252	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2252	Integer	2252
ibdot1sMstVID.2253	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2253	Integer	2253
ibdot1sMstVID.2254	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2254	Integer	2254
ibdot1sMstVID.2255	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2255	Integer	2255
ibdot1sMstVID.2256	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2256	Integer	2256
ibdot1sMstVID.2257	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2257	Integer	2257
ibdot1sMstVID.2258	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2258	Integer	2258
ibdot1sMstVID.2259	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2259	Integer	2259
ibdot1sMstVID.2260	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2260	Integer	2260
ibdot1sMstVID.2261	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2261	Integer	2261
ibdot1sMstVID.2262	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2262	Integer	2262
ibdot1sMstVID.2263	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2263	Integer	2263
ibdot1sMstVID.2264	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2264	Integer	2264
ibdot1sMstVID.2265	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2265	Integer	2265
ibdot1sMstVID.2266	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2266	Integer	2266
ibdot1sMstVID.2267	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2267	Integer	2267

Name	OID	Value Type	Value Example
ibdot1sMstVID.2268	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2268	Integer	2268
ibdot1sMstVID.2269	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2269	Integer	2269
ibdot1sMstVID.2270	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2270	Integer	2270
ibdot1sMstVID.2271	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2271	Integer	2271
ibdot1sMstVID.2272	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2272	Integer	2272
ibdot1sMstVID.2273	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2273	Integer	2273
ibdot1sMstVID.2274	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2274	Integer	2274
ibdot1sMstVID.2275	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2275	Integer	2275
ibdot1sMstVID.2276	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2276	Integer	2276
ibdot1sMstVID.2277	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2277	Integer	2277
ibdot1sMstVID.2278	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2278	Integer	2278
ibdot1sMstVID.2279	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2279	Integer	2279
ibdot1sMstVID.2280	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2280	Integer	2280
ibdot1sMstVID.2281	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2281	Integer	2281
ibdot1sMstVID.2282	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2282	Integer	2282
ibdot1sMstVID.2283	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2283	Integer	2283
ibdot1sMstVID.2284	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2284	Integer	2284
ibdot1sMstVID.2285	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2285	Integer	2285
ibdot1sMstVID.2286	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2286	Integer	2286
ibdot1sMstVID.2287	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2287	Integer	2287
ibdot1sMstVID.2288	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2288	Integer	2288
ibdot1sMstVID.2289	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2289	Integer	2289
ibdot1sMstVID.2290	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2290	Integer	2290
ibdot1sMstVID.2291	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2291	Integer	2291
ibdot1sMstVID.2292	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2292	Integer	2292
ibdot1sMstVID.2293	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2293	Integer	2293
ibdot1sMstVID.2294	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2294	Integer	2294
ibdot1sMstVID.2295	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2295	Integer	2295
ibdot1sMstVID.2296	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2296	Integer	2296
ibdot1sMstVID.2297	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2297	Integer	2297
ibdot1sMstVID.2298	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2298	Integer	2298
ibdot1sMstVID.2299	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2299	Integer	2299
ibdot1sMstVID.2300	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2300	Integer	2300
ibdot1sMstVID.2301	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2301	Integer	2301
ibdot1sMstVID.2302	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2302	Integer	2302
ibdot1sMstVID.2303	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2303	Integer	2303
ibdot1sMstVID.2304	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2304	Integer	2304
ibdot1sMstVID.2305	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2305	Integer	2305
ibdot1sMstVID.2306	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2306	Integer	2306
ibdot1sMstVID.2307	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2307	Integer	2307
ibdot1sMstVID.2308	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2308	Integer	2308
ibdot1sMstVID.2309	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2309	Integer	2309
ibdot1sMstVID.2310	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2310	Integer	2310

Name	OID	Value Type	Value Example
ibdot1sMstVID.2311	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2311	Integer	2311
ibdot1sMstVID.2312	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2312	Integer	2312
ibdot1sMstVID.2313	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2313	Integer	2313
ibdot1sMstVID.2314	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2314	Integer	2314
ibdot1sMstVID.2315	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2315	Integer	2315
ibdot1sMstVID.2316	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2316	Integer	2316
ibdot1sMstVID.2317	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2317	Integer	2317
ibdot1sMstVID.2318	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2318	Integer	2318
ibdot1sMstVID.2319	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2319	Integer	2319
ibdot1sMstVID.2320	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2320	Integer	2320
ibdot1sMstVID.2321	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2321	Integer	2321
ibdot1sMstVID.2322	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2322	Integer	2322
ibdot1sMstVID.2323	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2323	Integer	2323
ibdot1sMstVID.2324	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2324	Integer	2324
ibdot1sMstVID.2325	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2325	Integer	2325
ibdot1sMstVID.2326	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2326	Integer	2326
ibdot1sMstVID.2327	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2327	Integer	2327
ibdot1sMstVID.2328	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2328	Integer	2328
ibdot1sMstVID.2329	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2329	Integer	2329
ibdot1sMstVID.2330	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2330	Integer	2330
ibdot1sMstVID.2331	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2331	Integer	2331
ibdot1sMstVID.2332	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2332	Integer	2332
ibdot1sMstVID.2333	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2333	Integer	2333
ibdot1sMstVID.2334	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2334	Integer	2334
ibdot1sMstVID.2335	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2335	Integer	2335
ibdot1sMstVID.2336	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2336	Integer	2336
ibdot1sMstVID.2337	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2337	Integer	2337
ibdot1sMstVID.2338	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2338	Integer	2338
ibdot1sMstVID.2339	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2339	Integer	2339
ibdot1sMstVID.2340	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2340	Integer	2340
ibdot1sMstVID.2341	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2341	Integer	2341
ibdot1sMstVID.2342	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2342	Integer	2342
ibdot1sMstVID.2343	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2343	Integer	2343
ibdot1sMstVID.2344	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2344	Integer	2344
ibdot1sMstVID.2345	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2345	Integer	2345
ibdot1sMstVID.2346	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2346	Integer	2346
ibdot1sMstVID.2347	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2347	Integer	2347
ibdot1sMstVID.2348	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2348	Integer	2348
ibdot1sMstVID.2349	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2349	Integer	2349
ibdot1sMstVID.2350	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2350	Integer	2350
ibdot1sMstVID.2351	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2351	Integer	2351
ibdot1sMstVID.2352	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2352	Integer	2352
ibdot1sMstVID.2353	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2353	Integer	2353



Name	OID	Value Type	Value Example
ibdot1sMstVID.2354	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2354	Integer	2354
ibdot1sMstVID.2355	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2355	Integer	2355
ibdot1sMstVID.2356	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2356	Integer	2356
ibdot1sMstVID.2357	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2357	Integer	2357
ibdot1sMstVID.2358	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2358	Integer	2358
ibdot1sMstVID.2359	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2359	Integer	2359
ibdot1sMstVID.2360	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2360	Integer	2360
ibdot1sMstVID.2361	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2361	Integer	2361
ibdot1sMstVID.2362	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2362	Integer	2362
ibdot1sMstVID.2363	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2363	Integer	2363
ibdot1sMstVID.2364	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2364	Integer	2364
ibdot1sMstVID.2365	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2365	Integer	2365
ibdot1sMstVID.2366	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2366	Integer	2366
ibdot1sMstVID.2367	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2367	Integer	2367
ibdot1sMstVID.2368	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2368	Integer	2368
ibdot1sMstVID.2369	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2369	Integer	2369
ibdot1sMstVID.2370	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2370	Integer	2370
ibdot1sMstVID.2371	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2371	Integer	2371
ibdot1sMstVID.2372	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2372	Integer	2372
ibdot1sMstVID.2373	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2373	Integer	2373
ibdot1sMstVID.2374	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2374	Integer	2374
ibdot1sMstVID.2375	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2375	Integer	2375
ibdot1sMstVID.2376	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2376	Integer	2376
ibdot1sMstVID.2377	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2377	Integer	2377
ibdot1sMstVID.2378	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2378	Integer	2378
ibdot1sMstVID.2379	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2379	Integer	2379
ibdot1sMstVID.2380	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2380	Integer	2380
ibdot1sMstVID.2381	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2381	Integer	2381
ibdot1sMstVID.2382	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2382	Integer	2382
ibdot1sMstVID.2383	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2383	Integer	2383
ibdot1sMstVID.2384	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2384	Integer	2384
ibdot1sMstVID.2385	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2385	Integer	2385
ibdot1sMstVID.2386	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2386	Integer	2386
ibdot1sMstVID.2387	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2387	Integer	2387
ibdot1sMstVID.2388	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2388	Integer	2388
ibdot1sMstVID.2389	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2389	Integer	2389
ibdot1sMstVID.2390	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2390	Integer	2390
ibdot1sMstVID.2391	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2391	Integer	2391
ibdot1sMstVID.2392	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2392	Integer	2392
ibdot1sMstVID.2393	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2393	Integer	2393
ibdot1sMstVID.2394	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2394	Integer	2394
ibdot1sMstVID.2395	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2395	Integer	2395
ibdot1sMstVID.2396	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2396	Integer	2396

Name	OID	Value Type	Value Example
ibdot1sMstVID.2397	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2397	Integer	2397
ibdot1sMstVID.2398	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2398	Integer	2398
ibdot1sMstVID.2399	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2399	Integer	2399
ibdot1sMstVID.2400	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2400	Integer	2400
ibdot1sMstVID.2401	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2401	Integer	2401
ibdot1sMstVID.2402	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2402	Integer	2402
ibdot1sMstVID.2403	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2403	Integer	2403
ibdot1sMstVID.2404	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2404	Integer	2404
ibdot1sMstVID.2405	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2405	Integer	2405
ibdot1sMstVID.2406	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2406	Integer	2406
ibdot1sMstVID.2407	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2407	Integer	2407
ibdot1sMstVID.2408	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2408	Integer	2408
ibdot1sMstVID.2409	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2409	Integer	2409
ibdot1sMstVID.2410	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2410	Integer	2410
ibdot1sMstVID.2411	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2411	Integer	2411
ibdot1sMstVID.2412	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2412	Integer	2412
ibdot1sMstVID.2413	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2413	Integer	2413
ibdot1sMstVID.2414	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2414	Integer	2414
ibdot1sMstVID.2415	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2415	Integer	2415
ibdot1sMstVID.2416	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2416	Integer	2416
ibdot1sMstVID.2417	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2417	Integer	2417
ibdot1sMstVID.2418	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2418	Integer	2418
ibdot1sMstVID.2419	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2419	Integer	2419
ibdot1sMstVID.2420	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2420	Integer	2420
ibdot1sMstVID.2421	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2421	Integer	2421
ibdot1sMstVID.2422	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2422	Integer	2422
ibdot1sMstVID.2423	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2423	Integer	2423
ibdot1sMstVID.2424	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2424	Integer	2424
ibdot1sMstVID.2425	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2425	Integer	2425
ibdot1sMstVID.2426	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2426	Integer	2426
ibdot1sMstVID.2427	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2427	Integer	2427
ibdot1sMstVID.2428	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2428	Integer	2428
ibdot1sMstVID.2429	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2429	Integer	2429
ibdot1sMstVID.2430	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2430	Integer	2430
ibdot1sMstVID.2431	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2431	Integer	2431
ibdot1sMstVID.2432	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2432	Integer	2432
ibdot1sMstVID.2433	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2433	Integer	2433
ibdot1sMstVID.2434	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2434	Integer	2434
ibdot1sMstVID.2435	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2435	Integer	2435
ibdot1sMstVID.2436	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2436	Integer	2436
ibdot1sMstVID.2437	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2437	Integer	2437
ibdot1sMstVID.2438	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2438	Integer	2438
ibdot1sMstVID.2439	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2439	Integer	2439

Name	OID	Value Type	Value Example
ibdot1sMstVID.2440	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2440	Integer	2440
ibdot1sMstVID.2441	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2441	Integer	2441
ibdot1sMstVID.2442	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2442	Integer	2442
ibdot1sMstVID.2443	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2443	Integer	2443
ibdot1sMstVID.2444	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2444	Integer	2444
ibdot1sMstVID.2445	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2445	Integer	2445
ibdot1sMstVID.2446	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2446	Integer	2446
ibdot1sMstVID.2447	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2447	Integer	2447
ibdot1sMstVID.2448	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2448	Integer	2448
ibdot1sMstVID.2449	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2449	Integer	2449
ibdot1sMstVID.2450	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2450	Integer	2450
ibdot1sMstVID.2451	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2451	Integer	2451
ibdot1sMstVID.2452	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2452	Integer	2452
ibdot1sMstVID.2453	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2453	Integer	2453
ibdot1sMstVID.2454	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2454	Integer	2454
ibdot1sMstVID.2455	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2455	Integer	2455
ibdot1sMstVID.2456	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2456	Integer	2456
ibdot1sMstVID.2457	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2457	Integer	2457
ibdot1sMstVID.2458	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2458	Integer	2458
ibdot1sMstVID.2459	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2459	Integer	2459
ibdot1sMstVID.2460	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2460	Integer	2460
ibdot1sMstVID.2461	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2461	Integer	2461
ibdot1sMstVID.2462	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2462	Integer	2462
ibdot1sMstVID.2463	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2463	Integer	2463
ibdot1sMstVID.2464	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2464	Integer	2464
ibdot1sMstVID.2465	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2465	Integer	2465
ibdot1sMstVID.2466	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2466	Integer	2466
ibdot1sMstVID.2467	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2467	Integer	2467
ibdot1sMstVID.2468	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2468	Integer	2468
ibdot1sMstVID.2469	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2469	Integer	2469
ibdot1sMstVID.2470	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2470	Integer	2470
ibdot1sMstVID.2471	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2471	Integer	2471
ibdot1sMstVID.2472	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2472	Integer	2472
ibdot1sMstVID.2473	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2473	Integer	2473
ibdot1sMstVID.2474	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2474	Integer	2474
ibdot1sMstVID.2475	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2475	Integer	2475
ibdot1sMstVID.2476	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2476	Integer	2476
ibdot1sMstVID.2477	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2477	Integer	2477
ibdot1sMstVID.2478	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2478	Integer	2478
ibdot1sMstVID.2479	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2479	Integer	2479
ibdot1sMstVID.2480	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2480	Integer	2480
ibdot1sMstVID.2481	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2481	Integer	2481
ibdot1sMstVID.2482	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2482	Integer	2482

Name	OID	Value Type	Value Example
ibdot1sMstVID.2483	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2483	Integer	2483
ibdot1sMstVID.2484	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2484	Integer	2484
ibdot1sMstVID.2485	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2485	Integer	2485
ibdot1sMstVID.2486	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2486	Integer	2486
ibdot1sMstVID.2487	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2487	Integer	2487
ibdot1sMstVID.2488	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2488	Integer	2488
ibdot1sMstVID.2489	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2489	Integer	2489
ibdot1sMstVID.2490	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2490	Integer	2490
ibdot1sMstVID.2491	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2491	Integer	2491
ibdot1sMstVID.2492	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2492	Integer	2492
ibdot1sMstVID.2493	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2493	Integer	2493
ibdot1sMstVID.2494	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2494	Integer	2494
ibdot1sMstVID.2495	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2495	Integer	2495
ibdot1sMstVID.2496	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2496	Integer	2496
ibdot1sMstVID.2497	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2497	Integer	2497
ibdot1sMstVID.2498	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2498	Integer	2498
ibdot1sMstVID.2499	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2499	Integer	2499
ibdot1sMstVID.2500	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2500	Integer	2500
ibdot1sMstVID.2501	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2501	Integer	2501
ibdot1sMstVID.2502	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2502	Integer	2502
ibdot1sMstVID.2503	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2503	Integer	2503
ibdot1sMstVID.2504	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2504	Integer	2504
ibdot1sMstVID.2505	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2505	Integer	2505
ibdot1sMstVID.2506	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2506	Integer	2506
ibdot1sMstVID.2507	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2507	Integer	2507
ibdot1sMstVID.2508	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2508	Integer	2508
ibdot1sMstVID.2509	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2509	Integer	2509
ibdot1sMstVID.2510	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2510	Integer	2510
ibdot1sMstVID.2511	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2511	Integer	2511
ibdot1sMstVID.2512	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2512	Integer	2512
ibdot1sMstVID.2513	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2513	Integer	2513
ibdot1sMstVID.2514	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2514	Integer	2514
ibdot1sMstVID.2515	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2515	Integer	2515
ibdot1sMstVID.2516	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2516	Integer	2516
ibdot1sMstVID.2517	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2517	Integer	2517
ibdot1sMstVID.2518	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2518	Integer	2518
ibdot1sMstVID.2519	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2519	Integer	2519
ibdot1sMstVID.2520	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2520	Integer	2520
ibdot1sMstVID.2521	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2521	Integer	2521
ibdot1sMstVID.2522	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2522	Integer	2522
ibdot1sMstVID.2523	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2523	Integer	2523
ibdot1sMstVID.2524	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2524	Integer	2524
ibdot1sMstVID.2525	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2525	Integer	2525

Name	OID	Value Type	Value Example
ibdot1sMstVID.2526	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2526	Integer	2526
ibdot1sMstVID.2527	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2527	Integer	2527
ibdot1sMstVID.2528	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2528	Integer	2528
ibdot1sMstVID.2529	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2529	Integer	2529
ibdot1sMstVID.2530	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2530	Integer	2530
ibdot1sMstVID.2531	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2531	Integer	2531
ibdot1sMstVID.2532	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2532	Integer	2532
ibdot1sMstVID.2533	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2533	Integer	2533
ibdot1sMstVID.2534	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2534	Integer	2534
ibdot1sMstVID.2535	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2535	Integer	2535
ibdot1sMstVID.2536	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2536	Integer	2536
ibdot1sMstVID.2537	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2537	Integer	2537
ibdot1sMstVID.2538	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2538	Integer	2538
ibdot1sMstVID.2539	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2539	Integer	2539
ibdot1sMstVID.2540	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2540	Integer	2540
ibdot1sMstVID.2541	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2541	Integer	2541
ibdot1sMstVID.2542	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2542	Integer	2542
ibdot1sMstVID.2543	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2543	Integer	2543
ibdot1sMstVID.2544	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2544	Integer	2544
ibdot1sMstVID.2545	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2545	Integer	2545
ibdot1sMstVID.2546	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2546	Integer	2546
ibdot1sMstVID.2547	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2547	Integer	2547
ibdot1sMstVID.2548	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2548	Integer	2548
ibdot1sMstVID.2549	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2549	Integer	2549
ibdot1sMstVID.2550	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2550	Integer	2550
ibdot1sMstVID.2551	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2551	Integer	2551
ibdot1sMstVID.2552	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2552	Integer	2552
ibdot1sMstVID.2553	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2553	Integer	2553
ibdot1sMstVID.2554	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2554	Integer	2554
ibdot1sMstVID.2555	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2555	Integer	2555
ibdot1sMstVID.2556	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2556	Integer	2556
ibdot1sMstVID.2557	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2557	Integer	2557
ibdot1sMstVID.2558	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2558	Integer	2558
ibdot1sMstVID.2559	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2559	Integer	2559
ibdot1sMstVID.2560	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2560	Integer	2560
ibdot1sMstVID.2561	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2561	Integer	2561
ibdot1sMstVID.2562	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2562	Integer	2562
ibdot1sMstVID.2563	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2563	Integer	2563
ibdot1sMstVID.2564	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2564	Integer	2564
ibdot1sMstVID.2565	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2565	Integer	2565
ibdot1sMstVID.2566	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2566	Integer	2566
ibdot1sMstVID.2567	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2567	Integer	2567
ibdot1sMstVID.2568	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2568	Integer	2568

Name	OID	Value Type	Value Example
ibdot1sMstVID.2569	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2569	Integer	2569
ibdot1sMstVID.2570	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2570	Integer	2570
ibdot1sMstVID.2571	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2571	Integer	2571
ibdot1sMstVID.2572	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2572	Integer	2572
ibdot1sMstVID.2573	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2573	Integer	2573
ibdot1sMstVID.2574	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2574	Integer	2574
ibdot1sMstVID.2575	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2575	Integer	2575
ibdot1sMstVID.2576	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2576	Integer	2576
ibdot1sMstVID.2577	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2577	Integer	2577
ibdot1sMstVID.2578	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2578	Integer	2578
ibdot1sMstVID.2579	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2579	Integer	2579
ibdot1sMstVID.2580	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2580	Integer	2580
ibdot1sMstVID.2581	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2581	Integer	2581
ibdot1sMstVID.2582	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2582	Integer	2582
ibdot1sMstVID.2583	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2583	Integer	2583
ibdot1sMstVID.2584	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2584	Integer	2584
ibdot1sMstVID.2585	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2585	Integer	2585
ibdot1sMstVID.2586	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2586	Integer	2586
ibdot1sMstVID.2587	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2587	Integer	2587
ibdot1sMstVID.2588	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2588	Integer	2588
ibdot1sMstVID.2589	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2589	Integer	2589
ibdot1sMstVID.2590	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2590	Integer	2590
ibdot1sMstVID.2591	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2591	Integer	2591
ibdot1sMstVID.2592	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2592	Integer	2592
ibdot1sMstVID.2593	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2593	Integer	2593
ibdot1sMstVID.2594	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2594	Integer	2594
ibdot1sMstVID.2595	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2595	Integer	2595
ibdot1sMstVID.2596	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2596	Integer	2596
ibdot1sMstVID.2597	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2597	Integer	2597
ibdot1sMstVID.2598	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2598	Integer	2598
ibdot1sMstVID.2599	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2599	Integer	2599
ibdot1sMstVID.2600	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2600	Integer	2600
ibdot1sMstVID.2601	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2601	Integer	2601
ibdot1sMstVID.2602	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2602	Integer	2602
ibdot1sMstVID.2603	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2603	Integer	2603
ibdot1sMstVID.2604	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2604	Integer	2604
ibdot1sMstVID.2605	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2605	Integer	2605
ibdot1sMstVID.2606	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2606	Integer	2606
ibdot1sMstVID.2607	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2607	Integer	2607
ibdot1sMstVID.2608	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2608	Integer	2608
ibdot1sMstVID.2609	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2609	Integer	2609
ibdot1sMstVID.2610	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2610	Integer	2610
ibdot1sMstVID.2611	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2611	Integer	2611

Name	OID	Value Type	Value Example
ibdot1sMstVID.2612	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2612	Integer	2612
ibdot1sMstVID.2613	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2613	Integer	2613
ibdot1sMstVID.2614	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2614	Integer	2614
ibdot1sMstVID.2615	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2615	Integer	2615
ibdot1sMstVID.2616	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2616	Integer	2616
ibdot1sMstVID.2617	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2617	Integer	2617
ibdot1sMstVID.2618	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2618	Integer	2618
ibdot1sMstVID.2619	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2619	Integer	2619
ibdot1sMstVID.2620	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2620	Integer	2620
ibdot1sMstVID.2621	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2621	Integer	2621
ibdot1sMstVID.2622	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2622	Integer	2622
ibdot1sMstVID.2623	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2623	Integer	2623
ibdot1sMstVID.2624	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2624	Integer	2624
ibdot1sMstVID.2625	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2625	Integer	2625
ibdot1sMstVID.2626	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2626	Integer	2626
ibdot1sMstVID.2627	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2627	Integer	2627
ibdot1sMstVID.2628	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2628	Integer	2628
ibdot1sMstVID.2629	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2629	Integer	2629
ibdot1sMstVID.2630	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2630	Integer	2630
ibdot1sMstVID.2631	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2631	Integer	2631
ibdot1sMstVID.2632	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2632	Integer	2632
ibdot1sMstVID.2633	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2633	Integer	2633
ibdot1sMstVID.2634	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2634	Integer	2634
ibdot1sMstVID.2635	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2635	Integer	2635
ibdot1sMstVID.2636	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2636	Integer	2636
ibdot1sMstVID.2637	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2637	Integer	2637
ibdot1sMstVID.2638	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2638	Integer	2638
ibdot1sMstVID.2639	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2639	Integer	2639
ibdot1sMstVID.2640	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2640	Integer	2640
ibdot1sMstVID.2641	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2641	Integer	2641
ibdot1sMstVID.2642	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2642	Integer	2642
ibdot1sMstVID.2643	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2643	Integer	2643
ibdot1sMstVID.2644	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2644	Integer	2644
ibdot1sMstVID.2645	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2645	Integer	2645
ibdot1sMstVID.2646	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2646	Integer	2646
ibdot1sMstVID.2647	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2647	Integer	2647
ibdot1sMstVID.2648	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2648	Integer	2648
ibdot1sMstVID.2649	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2649	Integer	2649
ibdot1sMstVID.2650	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2650	Integer	2650
ibdot1sMstVID.2651	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2651	Integer	2651
ibdot1sMstVID.2652	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2652	Integer	2652
ibdot1sMstVID.2653	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2653	Integer	2653
ibdot1sMstVID.2654	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2654	Integer	2654



Name	OID	Value Type	Value Example
ibdot1sMstVID.2655	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2655	Integer	2655
ibdot1sMstVID.2656	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2656	Integer	2656
ibdot1sMstVID.2657	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2657	Integer	2657
ibdot1sMstVID.2658	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2658	Integer	2658
ibdot1sMstVID.2659	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2659	Integer	2659
ibdot1sMstVID.2660	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2660	Integer	2660
ibdot1sMstVID.2661	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2661	Integer	2661
ibdot1sMstVID.2662	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2662	Integer	2662
ibdot1sMstVID.2663	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2663	Integer	2663
ibdot1sMstVID.2664	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2664	Integer	2664
ibdot1sMstVID.2665	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2665	Integer	2665
ibdot1sMstVID.2666	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2666	Integer	2666
ibdot1sMstVID.2667	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2667	Integer	2667
ibdot1sMstVID.2668	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2668	Integer	2668
ibdot1sMstVID.2669	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2669	Integer	2669
ibdot1sMstVID.2670	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2670	Integer	2670
ibdot1sMstVID.2671	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2671	Integer	2671
ibdot1sMstVID.2672	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2672	Integer	2672
ibdot1sMstVID.2673	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2673	Integer	2673
ibdot1sMstVID.2674	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2674	Integer	2674
ibdot1sMstVID.2675	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2675	Integer	2675
ibdot1sMstVID.2676	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2676	Integer	2676
ibdot1sMstVID.2677	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2677	Integer	2677
ibdot1sMstVID.2678	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2678	Integer	2678
ibdot1sMstVID.2679	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2679	Integer	2679
ibdot1sMstVID.2680	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2680	Integer	2680
ibdot1sMstVID.2681	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2681	Integer	2681
ibdot1sMstVID.2682	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2682	Integer	2682
ibdot1sMstVID.2683	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2683	Integer	2683
ibdot1sMstVID.2684	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2684	Integer	2684
ibdot1sMstVID.2685	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2685	Integer	2685
ibdot1sMstVID.2686	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2686	Integer	2686
ibdot1sMstVID.2687	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2687	Integer	2687
ibdot1sMstVID.2688	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2688	Integer	2688
ibdot1sMstVID.2689	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2689	Integer	2689
ibdot1sMstVID.2690	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2690	Integer	2690
ibdot1sMstVID.2691	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2691	Integer	2691
ibdot1sMstVID.2692	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2692	Integer	2692
ibdot1sMstVID.2693	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2693	Integer	2693
ibdot1sMstVID.2694	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2694	Integer	2694
ibdot1sMstVID.2695	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2695	Integer	2695
ibdot1sMstVID.2696	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2696	Integer	2696
ibdot1sMstVID.2697	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2697	Integer	2697

Name	OID	Value Type	Value Example
ibdot1sMstVID.2698	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2698	Integer	2698
ibdot1sMstVID.2699	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2699	Integer	2699
ibdot1sMstVID.2700	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2700	Integer	2700
ibdot1sMstVID.2701	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2701	Integer	2701
ibdot1sMstVID.2702	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2702	Integer	2702
ibdot1sMstVID.2703	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2703	Integer	2703
ibdot1sMstVID.2704	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2704	Integer	2704
ibdot1sMstVID.2705	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2705	Integer	2705
ibdot1sMstVID.2706	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2706	Integer	2706
ibdot1sMstVID.2707	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2707	Integer	2707
ibdot1sMstVID.2708	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2708	Integer	2708
ibdot1sMstVID.2709	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2709	Integer	2709
ibdot1sMstVID.2710	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2710	Integer	2710
ibdot1sMstVID.2711	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2711	Integer	2711
ibdot1sMstVID.2712	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2712	Integer	2712
ibdot1sMstVID.2713	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2713	Integer	2713
ibdot1sMstVID.2714	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2714	Integer	2714
ibdot1sMstVID.2715	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2715	Integer	2715
ibdot1sMstVID.2716	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2716	Integer	2716
ibdot1sMstVID.2717	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2717	Integer	2717
ibdot1sMstVID.2718	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2718	Integer	2718
ibdot1sMstVID.2719	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2719	Integer	2719
ibdot1sMstVID.2720	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2720	Integer	2720
ibdot1sMstVID.2721	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2721	Integer	2721
ibdot1sMstVID.2722	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2722	Integer	2722
ibdot1sMstVID.2723	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2723	Integer	2723
ibdot1sMstVID.2724	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2724	Integer	2724
ibdot1sMstVID.2725	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2725	Integer	2725
ibdot1sMstVID.2726	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2726	Integer	2726
ibdot1sMstVID.2727	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2727	Integer	2727
ibdot1sMstVID.2728	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2728	Integer	2728
ibdot1sMstVID.2729	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2729	Integer	2729
ibdot1sMstVID.2730	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2730	Integer	2730
ibdot1sMstVID.2731	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2731	Integer	2731
ibdot1sMstVID.2732	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2732	Integer	2732
ibdot1sMstVID.2733	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2733	Integer	2733
ibdot1sMstVID.2734	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2734	Integer	2734
ibdot1sMstVID.2735	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2735	Integer	2735
ibdot1sMstVID.2736	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2736	Integer	2736
ibdot1sMstVID.2737	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2737	Integer	2737
ibdot1sMstVID.2738	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2738	Integer	2738
ibdot1sMstVID.2739	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2739	Integer	2739
ibdot1sMstVID.2740	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2740	Integer	2740

Name	OID	Value Type	Value Example
ibdot1sMstVID.2741	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2741	Integer	2741
ibdot1sMstVID.2742	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2742	Integer	2742
ibdot1sMstVID.2743	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2743	Integer	2743
ibdot1sMstVID.2744	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2744	Integer	2744
ibdot1sMstVID.2745	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2745	Integer	2745
ibdot1sMstVID.2746	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2746	Integer	2746
ibdot1sMstVID.2747	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2747	Integer	2747
ibdot1sMstVID.2748	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2748	Integer	2748
ibdot1sMstVID.2749	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2749	Integer	2749
ibdot1sMstVID.2750	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2750	Integer	2750
ibdot1sMstVID.2751	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2751	Integer	2751
ibdot1sMstVID.2752	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2752	Integer	2752
ibdot1sMstVID.2753	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2753	Integer	2753
ibdot1sMstVID.2754	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2754	Integer	2754
ibdot1sMstVID.2755	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2755	Integer	2755
ibdot1sMstVID.2756	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2756	Integer	2756
ibdot1sMstVID.2757	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2757	Integer	2757
ibdot1sMstVID.2758	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2758	Integer	2758
ibdot1sMstVID.2759	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2759	Integer	2759
ibdot1sMstVID.2760	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2760	Integer	2760
ibdot1sMstVID.2761	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2761	Integer	2761
ibdot1sMstVID.2762	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2762	Integer	2762
ibdot1sMstVID.2763	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2763	Integer	2763
ibdot1sMstVID.2764	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2764	Integer	2764
ibdot1sMstVID.2765	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2765	Integer	2765
ibdot1sMstVID.2766	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2766	Integer	2766
ibdot1sMstVID.2767	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2767	Integer	2767
ibdot1sMstVID.2768	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2768	Integer	2768
ibdot1sMstVID.2769	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2769	Integer	2769
ibdot1sMstVID.2770	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2770	Integer	2770
ibdot1sMstVID.2771	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2771	Integer	2771
ibdot1sMstVID.2772	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2772	Integer	2772
ibdot1sMstVID.2773	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2773	Integer	2773
ibdot1sMstVID.2774	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2774	Integer	2774
ibdot1sMstVID.2775	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2775	Integer	2775
ibdot1sMstVID.2776	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2776	Integer	2776
ibdot1sMstVID.2777	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2777	Integer	2777
ibdot1sMstVID.2778	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2778	Integer	2778
ibdot1sMstVID.2779	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2779	Integer	2779
ibdot1sMstVID.2780	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2780	Integer	2780
ibdot1sMstVID.2781	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2781	Integer	2781
ibdot1sMstVID.2782	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2782	Integer	2782
ibdot1sMstVID.2783	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2783	Integer	2783

Name	OID	Value Type	Value Example
ibdot1sMstVID.2784	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2784	Integer	2784
ibdot1sMstVID.2785	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2785	Integer	2785
ibdot1sMstVID.2786	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2786	Integer	2786
ibdot1sMstVID.2787	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2787	Integer	2787
ibdot1sMstVID.2788	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2788	Integer	2788
ibdot1sMstVID.2789	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2789	Integer	2789
ibdot1sMstVID.2790	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2790	Integer	2790
ibdot1sMstVID.2791	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2791	Integer	2791
ibdot1sMstVID.2792	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2792	Integer	2792
ibdot1sMstVID.2793	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2793	Integer	2793
ibdot1sMstVID.2794	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2794	Integer	2794
ibdot1sMstVID.2795	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2795	Integer	2795
ibdot1sMstVID.2796	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2796	Integer	2796
ibdot1sMstVID.2797	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2797	Integer	2797
ibdot1sMstVID.2798	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2798	Integer	2798
ibdot1sMstVID.2799	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2799	Integer	2799
ibdot1sMstVID.2800	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2800	Integer	2800
ibdot1sMstVID.2801	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2801	Integer	2801
ibdot1sMstVID.2802	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2802	Integer	2802
ibdot1sMstVID.2803	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2803	Integer	2803
ibdot1sMstVID.2804	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2804	Integer	2804
ibdot1sMstVID.2805	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2805	Integer	2805
ibdot1sMstVID.2806	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2806	Integer	2806
ibdot1sMstVID.2807	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2807	Integer	2807
ibdot1sMstVID.2808	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2808	Integer	2808
ibdot1sMstVID.2809	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2809	Integer	2809
ibdot1sMstVID.2810	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2810	Integer	2810
ibdot1sMstVID.2811	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2811	Integer	2811
ibdot1sMstVID.2812	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2812	Integer	2812
ibdot1sMstVID.2813	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2813	Integer	2813
ibdot1sMstVID.2814	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2814	Integer	2814
ibdot1sMstVID.2815	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2815	Integer	2815
ibdot1sMstVID.2816	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2816	Integer	2816
ibdot1sMstVID.2817	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2817	Integer	2817
ibdot1sMstVID.2818	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2818	Integer	2818
ibdot1sMstVID.2819	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2819	Integer	2819
ibdot1sMstVID.2820	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2820	Integer	2820
ibdot1sMstVID.2821	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2821	Integer	2821
ibdot1sMstVID.2822	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2822	Integer	2822
ibdot1sMstVID.2823	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2823	Integer	2823
ibdot1sMstVID.2824	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2824	Integer	2824
ibdot1sMstVID.2825	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2825	Integer	2825
ibdot1sMstVID.2826	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2826	Integer	2826

Name	OID	Value Type	Value Example
ibdot1sMstVID.2827	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2827	Integer	2827
ibdot1sMstVID.2828	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2828	Integer	2828
ibdot1sMstVID.2829	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2829	Integer	2829
ibdot1sMstVID.2830	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2830	Integer	2830
ibdot1sMstVID.2831	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2831	Integer	2831
ibdot1sMstVID.2832	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2832	Integer	2832
ibdot1sMstVID.2833	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2833	Integer	2833
ibdot1sMstVID.2834	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2834	Integer	2834
ibdot1sMstVID.2835	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2835	Integer	2835
ibdot1sMstVID.2836	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2836	Integer	2836
ibdot1sMstVID.2837	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2837	Integer	2837
ibdot1sMstVID.2838	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2838	Integer	2838
ibdot1sMstVID.2839	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2839	Integer	2839
ibdot1sMstVID.2840	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2840	Integer	2840
ibdot1sMstVID.2841	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2841	Integer	2841
ibdot1sMstVID.2842	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2842	Integer	2842
ibdot1sMstVID.2843	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2843	Integer	2843
ibdot1sMstVID.2844	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2844	Integer	2844
ibdot1sMstVID.2845	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2845	Integer	2845
ibdot1sMstVID.2846	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2846	Integer	2846
ibdot1sMstVID.2847	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2847	Integer	2847
ibdot1sMstVID.2848	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2848	Integer	2848
ibdot1sMstVID.2849	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2849	Integer	2849
ibdot1sMstVID.2850	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2850	Integer	2850
ibdot1sMstVID.2851	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2851	Integer	2851
ibdot1sMstVID.2852	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2852	Integer	2852
ibdot1sMstVID.2853	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2853	Integer	2853
ibdot1sMstVID.2854	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2854	Integer	2854
ibdot1sMstVID.2855	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2855	Integer	2855
ibdot1sMstVID.2856	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2856	Integer	2856
ibdot1sMstVID.2857	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2857	Integer	2857
ibdot1sMstVID.2858	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2858	Integer	2858
ibdot1sMstVID.2859	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2859	Integer	2859
ibdot1sMstVID.2860	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2860	Integer	2860
ibdot1sMstVID.2861	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2861	Integer	2861
ibdot1sMstVID.2862	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2862	Integer	2862
ibdot1sMstVID.2863	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2863	Integer	2863
ibdot1sMstVID.2864	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2864	Integer	2864
ibdot1sMstVID.2865	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2865	Integer	2865
ibdot1sMstVID.2866	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2866	Integer	2866
ibdot1sMstVID.2867	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2867	Integer	2867
ibdot1sMstVID.2868	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2868	Integer	2868
ibdot1sMstVID.2869	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2869	Integer	2869

Name	OID	Value Type	Value Example
ibdot1sMstVID.2870	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2870	Integer	2870
ibdot1sMstVID.2871	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2871	Integer	2871
ibdot1sMstVID.2872	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2872	Integer	2872
ibdot1sMstVID.2873	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2873	Integer	2873
ibdot1sMstVID.2874	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2874	Integer	2874
ibdot1sMstVID.2875	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2875	Integer	2875
ibdot1sMstVID.2876	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2876	Integer	2876
ibdot1sMstVID.2877	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2877	Integer	2877
ibdot1sMstVID.2878	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2878	Integer	2878
ibdot1sMstVID.2879	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2879	Integer	2879
ibdot1sMstVID.2880	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2880	Integer	2880
ibdot1sMstVID.2881	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2881	Integer	2881
ibdot1sMstVID.2882	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2882	Integer	2882
ibdot1sMstVID.2883	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2883	Integer	2883
ibdot1sMstVID.2884	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2884	Integer	2884
ibdot1sMstVID.2885	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2885	Integer	2885
ibdot1sMstVID.2886	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2886	Integer	2886
ibdot1sMstVID.2887	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2887	Integer	2887
ibdot1sMstVID.2888	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2888	Integer	2888
ibdot1sMstVID.2889	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2889	Integer	2889
ibdot1sMstVID.2890	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2890	Integer	2890
ibdot1sMstVID.2891	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2891	Integer	2891
ibdot1sMstVID.2892	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2892	Integer	2892
ibdot1sMstVID.2893	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2893	Integer	2893
ibdot1sMstVID.2894	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2894	Integer	2894
ibdot1sMstVID.2895	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2895	Integer	2895
ibdot1sMstVID.2896	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2896	Integer	2896
ibdot1sMstVID.2897	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2897	Integer	2897
ibdot1sMstVID.2898	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2898	Integer	2898
ibdot1sMstVID.2899	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2899	Integer	2899
ibdot1sMstVID.2900	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2900	Integer	2900
ibdot1sMstVID.2901	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2901	Integer	2901
ibdot1sMstVID.2902	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2902	Integer	2902
ibdot1sMstVID.2903	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2903	Integer	2903
ibdot1sMstVID.2904	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2904	Integer	2904
ibdot1sMstVID.2905	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2905	Integer	2905
ibdot1sMstVID.2906	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2906	Integer	2906
ibdot1sMstVID.2907	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2907	Integer	2907
ibdot1sMstVID.2908	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2908	Integer	2908
ibdot1sMstVID.2909	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2909	Integer	2909
ibdot1sMstVID.2910	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2910	Integer	2910
ibdot1sMstVID.2911	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2911	Integer	2911
ibdot1sMstVID.2912	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2912	Integer	2912

Name	OID	Value Type	Value Example
ibdot1sMstVID.2913	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2913	Integer	2913
ibdot1sMstVID.2914	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2914	Integer	2914
ibdot1sMstVID.2915	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2915	Integer	2915
ibdot1sMstVID.2916	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2916	Integer	2916
ibdot1sMstVID.2917	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2917	Integer	2917
ibdot1sMstVID.2918	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2918	Integer	2918
ibdot1sMstVID.2919	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2919	Integer	2919
ibdot1sMstVID.2920	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2920	Integer	2920
ibdot1sMstVID.2921	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2921	Integer	2921
ibdot1sMstVID.2922	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2922	Integer	2922
ibdot1sMstVID.2923	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2923	Integer	2923
ibdot1sMstVID.2924	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2924	Integer	2924
ibdot1sMstVID.2925	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2925	Integer	2925
ibdot1sMstVID.2926	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2926	Integer	2926
ibdot1sMstVID.2927	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2927	Integer	2927
ibdot1sMstVID.2928	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2928	Integer	2928
ibdot1sMstVID.2929	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2929	Integer	2929
ibdot1sMstVID.2930	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2930	Integer	2930
ibdot1sMstVID.2931	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2931	Integer	2931
ibdot1sMstVID.2932	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2932	Integer	2932
ibdot1sMstVID.2933	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2933	Integer	2933
ibdot1sMstVID.2934	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2934	Integer	2934
ibdot1sMstVID.2935	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2935	Integer	2935
ibdot1sMstVID.2936	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2936	Integer	2936
ibdot1sMstVID.2937	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2937	Integer	2937
ibdot1sMstVID.2938	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2938	Integer	2938
ibdot1sMstVID.2939	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2939	Integer	2939
ibdot1sMstVID.2940	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2940	Integer	2940
ibdot1sMstVID.2941	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2941	Integer	2941
ibdot1sMstVID.2942	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2942	Integer	2942
ibdot1sMstVID.2943	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2943	Integer	2943
ibdot1sMstVID.2944	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2944	Integer	2944
ibdot1sMstVID.2945	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2945	Integer	2945
ibdot1sMstVID.2946	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2946	Integer	2946
ibdot1sMstVID.2947	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2947	Integer	2947
ibdot1sMstVID.2948	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2948	Integer	2948
ibdot1sMstVID.2949	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2949	Integer	2949
ibdot1sMstVID.2950	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2950	Integer	2950
ibdot1sMstVID.2951	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2951	Integer	2951
ibdot1sMstVID.2952	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2952	Integer	2952
ibdot1sMstVID.2953	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2953	Integer	2953
ibdot1sMstVID.2954	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2954	Integer	2954
ibdot1sMstVID.2955	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2955	Integer	2955



Name	OID	Value Type	Value Example
ibdot1sMstVID.2956	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2956	Integer	2956
ibdot1sMstVID.2957	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2957	Integer	2957
ibdot1sMstVID.2958	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2958	Integer	2958
ibdot1sMstVID.2959	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2959	Integer	2959
ibdot1sMstVID.2960	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2960	Integer	2960
ibdot1sMstVID.2961	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2961	Integer	2961
ibdot1sMstVID.2962	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2962	Integer	2962
ibdot1sMstVID.2963	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2963	Integer	2963
ibdot1sMstVID.2964	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2964	Integer	2964
ibdot1sMstVID.2965	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2965	Integer	2965
ibdot1sMstVID.2966	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2966	Integer	2966
ibdot1sMstVID.2967	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2967	Integer	2967
ibdot1sMstVID.2968	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2968	Integer	2968
ibdot1sMstVID.2969	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2969	Integer	2969
ibdot1sMstVID.2970	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2970	Integer	2970
ibdot1sMstVID.2971	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2971	Integer	2971
ibdot1sMstVID.2972	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2972	Integer	2972
ibdot1sMstVID.2973	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2973	Integer	2973
ibdot1sMstVID.2974	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2974	Integer	2974
ibdot1sMstVID.2975	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2975	Integer	2975
ibdot1sMstVID.2976	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2976	Integer	2976
ibdot1sMstVID.2977	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2977	Integer	2977
ibdot1sMstVID.2978	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2978	Integer	2978
ibdot1sMstVID.2979	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2979	Integer	2979
ibdot1sMstVID.2980	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2980	Integer	2980
ibdot1sMstVID.2981	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2981	Integer	2981
ibdot1sMstVID.2982	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2982	Integer	2982
ibdot1sMstVID.2983	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2983	Integer	2983
ibdot1sMstVID.2984	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2984	Integer	2984
ibdot1sMstVID.2985	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2985	Integer	2985
ibdot1sMstVID.2986	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2986	Integer	2986
ibdot1sMstVID.2987	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2987	Integer	2987
ibdot1sMstVID.2988	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2988	Integer	2988
ibdot1sMstVID.2989	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2989	Integer	2989
ibdot1sMstVID.2990	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2990	Integer	2990
ibdot1sMstVID.2991	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2991	Integer	2991
ibdot1sMstVID.2992	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2992	Integer	2992
ibdot1sMstVID.2993	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2993	Integer	2993
ibdot1sMstVID.2994	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2994	Integer	2994
ibdot1sMstVID.2995	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2995	Integer	2995
ibdot1sMstVID.2996	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2996	Integer	2996
ibdot1sMstVID.2997	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2997	Integer	2997
ibdot1sMstVID.2998	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2998	Integer	2998

Name	OID	Value Type	Value Example
ibdot1sMstVID.2999	.1.3.6.1.4.1.26138.8.35.14.18.1.1.2999	Integer	2999
ibdot1sMstVID.3000	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3000	Integer	3000
ibdot1sMstVID.3001	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3001	Integer	3001
ibdot1sMstVID.3002	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3002	Integer	3002
ibdot1sMstVID.3003	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3003	Integer	3003
ibdot1sMstVID.3004	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3004	Integer	3004
ibdot1sMstVID.3005	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3005	Integer	3005
ibdot1sMstVID.3006	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3006	Integer	3006
ibdot1sMstVID.3007	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3007	Integer	3007
ibdot1sMstVID.3008	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3008	Integer	3008
ibdot1sMstVID.3009	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3009	Integer	3009
ibdot1sMstVID.3010	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3010	Integer	3010
ibdot1sMstVID.3011	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3011	Integer	3011
ibdot1sMstVID.3012	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3012	Integer	3012
ibdot1sMstVID.3013	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3013	Integer	3013
ibdot1sMstVID.3014	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3014	Integer	3014
ibdot1sMstVID.3015	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3015	Integer	3015
ibdot1sMstVID.3016	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3016	Integer	3016
ibdot1sMstVID.3017	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3017	Integer	3017
ibdot1sMstVID.3018	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3018	Integer	3018
ibdot1sMstVID.3019	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3019	Integer	3019
ibdot1sMstVID.3020	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3020	Integer	3020
ibdot1sMstVID.3021	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3021	Integer	3021
ibdot1sMstVID.3022	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3022	Integer	3022
ibdot1sMstVID.3023	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3023	Integer	3023
ibdot1sMstVID.3024	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3024	Integer	3024
ibdot1sMstVID.3025	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3025	Integer	3025
ibdot1sMstVID.3026	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3026	Integer	3026
ibdot1sMstVID.3027	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3027	Integer	3027
ibdot1sMstVID.3028	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3028	Integer	3028
ibdot1sMstVID.3029	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3029	Integer	3029
ibdot1sMstVID.3030	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3030	Integer	3030
ibdot1sMstVID.3031	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3031	Integer	3031
ibdot1sMstVID.3032	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3032	Integer	3032
ibdot1sMstVID.3033	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3033	Integer	3033
ibdot1sMstVID.3034	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3034	Integer	3034
ibdot1sMstVID.3035	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3035	Integer	3035
ibdot1sMstVID.3036	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3036	Integer	3036
ibdot1sMstVID.3037	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3037	Integer	3037
ibdot1sMstVID.3038	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3038	Integer	3038
ibdot1sMstVID.3039	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3039	Integer	3039
ibdot1sMstVID.3040	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3040	Integer	3040
ibdot1sMstVID.3041	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3041	Integer	3041

Name	OID	Value Type	Value Example
ibdot1sMstVID.3042	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3042	Integer	3042
ibdot1sMstVID.3043	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3043	Integer	3043
ibdot1sMstVID.3044	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3044	Integer	3044
ibdot1sMstVID.3045	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3045	Integer	3045
ibdot1sMstVID.3046	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3046	Integer	3046
ibdot1sMstVID.3047	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3047	Integer	3047
ibdot1sMstVID.3048	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3048	Integer	3048
ibdot1sMstVID.3049	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3049	Integer	3049
ibdot1sMstVID.3050	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3050	Integer	3050
ibdot1sMstVID.3051	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3051	Integer	3051
ibdot1sMstVID.3052	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3052	Integer	3052
ibdot1sMstVID.3053	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3053	Integer	3053
ibdot1sMstVID.3054	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3054	Integer	3054
ibdot1sMstVID.3055	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3055	Integer	3055
ibdot1sMstVID.3056	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3056	Integer	3056
ibdot1sMstVID.3057	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3057	Integer	3057
ibdot1sMstVID.3058	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3058	Integer	3058
ibdot1sMstVID.3059	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3059	Integer	3059
ibdot1sMstVID.3060	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3060	Integer	3060
ibdot1sMstVID.3061	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3061	Integer	3061
ibdot1sMstVID.3062	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3062	Integer	3062
ibdot1sMstVID.3063	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3063	Integer	3063
ibdot1sMstVID.3064	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3064	Integer	3064
ibdot1sMstVID.3065	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3065	Integer	3065
ibdot1sMstVID.3066	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3066	Integer	3066
ibdot1sMstVID.3067	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3067	Integer	3067
ibdot1sMstVID.3068	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3068	Integer	3068
ibdot1sMstVID.3069	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3069	Integer	3069
ibdot1sMstVID.3070	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3070	Integer	3070
ibdot1sMstVID.3071	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3071	Integer	3071
ibdot1sMstVID.3072	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3072	Integer	3072
ibdot1sMstVID.3073	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3073	Integer	3073
ibdot1sMstVID.3074	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3074	Integer	3074
ibdot1sMstVID.3075	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3075	Integer	3075
ibdot1sMstVID.3076	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3076	Integer	3076
ibdot1sMstVID.3077	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3077	Integer	3077
ibdot1sMstVID.3078	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3078	Integer	3078
ibdot1sMstVID.3079	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3079	Integer	3079
ibdot1sMstVID.3080	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3080	Integer	3080
ibdot1sMstVID.3081	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3081	Integer	3081
ibdot1sMstVID.3082	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3082	Integer	3082
ibdot1sMstVID.3083	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3083	Integer	3083
ibdot1sMstVID.3084	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3084	Integer	3084

Name	OID	Value Type	Value Example
ibdot1sMstVID.3085	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3085	Integer	3085
ibdot1sMstVID.3086	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3086	Integer	3086
ibdot1sMstVID.3087	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3087	Integer	3087
ibdot1sMstVID.3088	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3088	Integer	3088
ibdot1sMstVID.3089	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3089	Integer	3089
ibdot1sMstVID.3090	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3090	Integer	3090
ibdot1sMstVID.3091	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3091	Integer	3091
ibdot1sMstVID.3092	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3092	Integer	3092
ibdot1sMstVID.3093	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3093	Integer	3093
ibdot1sMstVID.3094	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3094	Integer	3094
ibdot1sMstVID.3095	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3095	Integer	3095
ibdot1sMstVID.3096	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3096	Integer	3096
ibdot1sMstVID.3097	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3097	Integer	3097
ibdot1sMstVID.3098	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3098	Integer	3098
ibdot1sMstVID.3099	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3099	Integer	3099
ibdot1sMstVID.3100	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3100	Integer	3100
ibdot1sMstVID.3101	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3101	Integer	3101
ibdot1sMstVID.3102	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3102	Integer	3102
ibdot1sMstVID.3103	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3103	Integer	3103
ibdot1sMstVID.3104	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3104	Integer	3104
ibdot1sMstVID.3105	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3105	Integer	3105
ibdot1sMstVID.3106	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3106	Integer	3106
ibdot1sMstVID.3107	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3107	Integer	3107
ibdot1sMstVID.3108	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3108	Integer	3108
ibdot1sMstVID.3109	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3109	Integer	3109
ibdot1sMstVID.3110	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3110	Integer	3110
ibdot1sMstVID.3111	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3111	Integer	3111
ibdot1sMstVID.3112	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3112	Integer	3112
ibdot1sMstVID.3113	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3113	Integer	3113
ibdot1sMstVID.3114	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3114	Integer	3114
ibdot1sMstVID.3115	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3115	Integer	3115
ibdot1sMstVID.3116	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3116	Integer	3116
ibdot1sMstVID.3117	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3117	Integer	3117
ibdot1sMstVID.3118	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3118	Integer	3118
ibdot1sMstVID.3119	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3119	Integer	3119
ibdot1sMstVID.3120	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3120	Integer	3120
ibdot1sMstVID.3121	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3121	Integer	3121
ibdot1sMstVID.3122	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3122	Integer	3122
ibdot1sMstVID.3123	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3123	Integer	3123
ibdot1sMstVID.3124	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3124	Integer	3124
ibdot1sMstVID.3125	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3125	Integer	3125
ibdot1sMstVID.3126	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3126	Integer	3126
ibdot1sMstVID.3127	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3127	Integer	3127

Name	OID	Value Type	Value Example
ibdot1sMstVID.3128	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3128	Integer	3128
ibdot1sMstVID.3129	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3129	Integer	3129
ibdot1sMstVID.3130	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3130	Integer	3130
ibdot1sMstVID.3131	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3131	Integer	3131
ibdot1sMstVID.3132	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3132	Integer	3132
ibdot1sMstVID.3133	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3133	Integer	3133
ibdot1sMstVID.3134	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3134	Integer	3134
ibdot1sMstVID.3135	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3135	Integer	3135
ibdot1sMstVID.3136	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3136	Integer	3136
ibdot1sMstVID.3137	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3137	Integer	3137
ibdot1sMstVID.3138	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3138	Integer	3138
ibdot1sMstVID.3139	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3139	Integer	3139
ibdot1sMstVID.3140	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3140	Integer	3140
ibdot1sMstVID.3141	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3141	Integer	3141
ibdot1sMstVID.3142	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3142	Integer	3142
ibdot1sMstVID.3143	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3143	Integer	3143
ibdot1sMstVID.3144	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3144	Integer	3144
ibdot1sMstVID.3145	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3145	Integer	3145
ibdot1sMstVID.3146	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3146	Integer	3146
ibdot1sMstVID.3147	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3147	Integer	3147
ibdot1sMstVID.3148	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3148	Integer	3148
ibdot1sMstVID.3149	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3149	Integer	3149
ibdot1sMstVID.3150	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3150	Integer	3150
ibdot1sMstVID.3151	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3151	Integer	3151
ibdot1sMstVID.3152	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3152	Integer	3152
ibdot1sMstVID.3153	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3153	Integer	3153
ibdot1sMstVID.3154	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3154	Integer	3154
ibdot1sMstVID.3155	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3155	Integer	3155
ibdot1sMstVID.3156	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3156	Integer	3156
ibdot1sMstVID.3157	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3157	Integer	3157
ibdot1sMstVID.3158	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3158	Integer	3158
ibdot1sMstVID.3159	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3159	Integer	3159
ibdot1sMstVID.3160	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3160	Integer	3160
ibdot1sMstVID.3161	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3161	Integer	3161
ibdot1sMstVID.3162	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3162	Integer	3162
ibdot1sMstVID.3163	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3163	Integer	3163
ibdot1sMstVID.3164	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3164	Integer	3164
ibdot1sMstVID.3165	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3165	Integer	3165
ibdot1sMstVID.3166	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3166	Integer	3166
ibdot1sMstVID.3167	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3167	Integer	3167
ibdot1sMstVID.3168	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3168	Integer	3168
ibdot1sMstVID.3169	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3169	Integer	3169
ibdot1sMstVID.3170	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3170	Integer	3170

Name	OID	Value Type	Value Example
ibdot1sMstVID.3171	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3171	Integer	3171
ibdot1sMstVID.3172	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3172	Integer	3172
ibdot1sMstVID.3173	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3173	Integer	3173
ibdot1sMstVID.3174	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3174	Integer	3174
ibdot1sMstVID.3175	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3175	Integer	3175
ibdot1sMstVID.3176	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3176	Integer	3176
ibdot1sMstVID.3177	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3177	Integer	3177
ibdot1sMstVID.3178	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3178	Integer	3178
ibdot1sMstVID.3179	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3179	Integer	3179
ibdot1sMstVID.3180	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3180	Integer	3180
ibdot1sMstVID.3181	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3181	Integer	3181
ibdot1sMstVID.3182	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3182	Integer	3182
ibdot1sMstVID.3183	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3183	Integer	3183
ibdot1sMstVID.3184	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3184	Integer	3184
ibdot1sMstVID.3185	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3185	Integer	3185
ibdot1sMstVID.3186	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3186	Integer	3186
ibdot1sMstVID.3187	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3187	Integer	3187
ibdot1sMstVID.3188	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3188	Integer	3188
ibdot1sMstVID.3189	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3189	Integer	3189
ibdot1sMstVID.3190	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3190	Integer	3190
ibdot1sMstVID.3191	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3191	Integer	3191
ibdot1sMstVID.3192	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3192	Integer	3192
ibdot1sMstVID.3193	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3193	Integer	3193
ibdot1sMstVID.3194	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3194	Integer	3194
ibdot1sMstVID.3195	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3195	Integer	3195
ibdot1sMstVID.3196	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3196	Integer	3196
ibdot1sMstVID.3197	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3197	Integer	3197
ibdot1sMstVID.3198	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3198	Integer	3198
ibdot1sMstVID.3199	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3199	Integer	3199
ibdot1sMstVID.3200	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3200	Integer	3200
ibdot1sMstVID.3201	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3201	Integer	3201
ibdot1sMstVID.3202	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3202	Integer	3202
ibdot1sMstVID.3203	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3203	Integer	3203
ibdot1sMstVID.3204	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3204	Integer	3204
ibdot1sMstVID.3205	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3205	Integer	3205
ibdot1sMstVID.3206	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3206	Integer	3206
ibdot1sMstVID.3207	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3207	Integer	3207
ibdot1sMstVID.3208	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3208	Integer	3208
ibdot1sMstVID.3209	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3209	Integer	3209
ibdot1sMstVID.3210	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3210	Integer	3210
ibdot1sMstVID.3211	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3211	Integer	3211
ibdot1sMstVID.3212	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3212	Integer	3212
ibdot1sMstVID.3213	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3213	Integer	3213

Name	OID	Value Type	Value Example
ibdot1sMstVID.3214	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3214	Integer	3214
ibdot1sMstVID.3215	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3215	Integer	3215
ibdot1sMstVID.3216	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3216	Integer	3216
ibdot1sMstVID.3217	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3217	Integer	3217
ibdot1sMstVID.3218	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3218	Integer	3218
ibdot1sMstVID.3219	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3219	Integer	3219
ibdot1sMstVID.3220	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3220	Integer	3220
ibdot1sMstVID.3221	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3221	Integer	3221
ibdot1sMstVID.3222	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3222	Integer	3222
ibdot1sMstVID.3223	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3223	Integer	3223
ibdot1sMstVID.3224	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3224	Integer	3224
ibdot1sMstVID.3225	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3225	Integer	3225
ibdot1sMstVID.3226	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3226	Integer	3226
ibdot1sMstVID.3227	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3227	Integer	3227
ibdot1sMstVID.3228	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3228	Integer	3228
ibdot1sMstVID.3229	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3229	Integer	3229
ibdot1sMstVID.3230	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3230	Integer	3230
ibdot1sMstVID.3231	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3231	Integer	3231
ibdot1sMstVID.3232	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3232	Integer	3232
ibdot1sMstVID.3233	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3233	Integer	3233
ibdot1sMstVID.3234	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3234	Integer	3234
ibdot1sMstVID.3235	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3235	Integer	3235
ibdot1sMstVID.3236	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3236	Integer	3236
ibdot1sMstVID.3237	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3237	Integer	3237
ibdot1sMstVID.3238	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3238	Integer	3238
ibdot1sMstVID.3239	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3239	Integer	3239
ibdot1sMstVID.3240	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3240	Integer	3240
ibdot1sMstVID.3241	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3241	Integer	3241
ibdot1sMstVID.3242	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3242	Integer	3242
ibdot1sMstVID.3243	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3243	Integer	3243
ibdot1sMstVID.3244	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3244	Integer	3244
ibdot1sMstVID.3245	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3245	Integer	3245
ibdot1sMstVID.3246	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3246	Integer	3246
ibdot1sMstVID.3247	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3247	Integer	3247
ibdot1sMstVID.3248	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3248	Integer	3248
ibdot1sMstVID.3249	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3249	Integer	3249
ibdot1sMstVID.3250	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3250	Integer	3250
ibdot1sMstVID.3251	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3251	Integer	3251
ibdot1sMstVID.3252	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3252	Integer	3252
ibdot1sMstVID.3253	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3253	Integer	3253
ibdot1sMstVID.3254	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3254	Integer	3254
ibdot1sMstVID.3255	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3255	Integer	3255
ibdot1sMstVID.3256	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3256	Integer	3256



Name	OID	Value Type	Value Example
ibdot1sMstVID.3257	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3257	Integer	3257
ibdot1sMstVID.3258	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3258	Integer	3258
ibdot1sMstVID.3259	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3259	Integer	3259
ibdot1sMstVID.3260	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3260	Integer	3260
ibdot1sMstVID.3261	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3261	Integer	3261
ibdot1sMstVID.3262	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3262	Integer	3262
ibdot1sMstVID.3263	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3263	Integer	3263
ibdot1sMstVID.3264	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3264	Integer	3264
ibdot1sMstVID.3265	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3265	Integer	3265
ibdot1sMstVID.3266	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3266	Integer	3266
ibdot1sMstVID.3267	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3267	Integer	3267
ibdot1sMstVID.3268	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3268	Integer	3268
ibdot1sMstVID.3269	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3269	Integer	3269
ibdot1sMstVID.3270	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3270	Integer	3270
ibdot1sMstVID.3271	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3271	Integer	3271
ibdot1sMstVID.3272	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3272	Integer	3272
ibdot1sMstVID.3273	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3273	Integer	3273
ibdot1sMstVID.3274	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3274	Integer	3274
ibdot1sMstVID.3275	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3275	Integer	3275
ibdot1sMstVID.3276	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3276	Integer	3276
ibdot1sMstVID.3277	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3277	Integer	3277
ibdot1sMstVID.3278	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3278	Integer	3278
ibdot1sMstVID.3279	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3279	Integer	3279
ibdot1sMstVID.3280	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3280	Integer	3280
ibdot1sMstVID.3281	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3281	Integer	3281
ibdot1sMstVID.3282	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3282	Integer	3282
ibdot1sMstVID.3283	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3283	Integer	3283
ibdot1sMstVID.3284	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3284	Integer	3284
ibdot1sMstVID.3285	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3285	Integer	3285
ibdot1sMstVID.3286	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3286	Integer	3286
ibdot1sMstVID.3287	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3287	Integer	3287
ibdot1sMstVID.3288	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3288	Integer	3288
ibdot1sMstVID.3289	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3289	Integer	3289
ibdot1sMstVID.3290	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3290	Integer	3290
ibdot1sMstVID.3291	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3291	Integer	3291
ibdot1sMstVID.3292	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3292	Integer	3292
ibdot1sMstVID.3293	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3293	Integer	3293
ibdot1sMstVID.3294	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3294	Integer	3294
ibdot1sMstVID.3295	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3295	Integer	3295
ibdot1sMstVID.3296	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3296	Integer	3296
ibdot1sMstVID.3297	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3297	Integer	3297
ibdot1sMstVID.3298	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3298	Integer	3298
ibdot1sMstVID.3299	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3299	Integer	3299

Name	OID	Value Type	Value Example
ibdot1sMstVID.3300	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3300	Integer	3300
ibdot1sMstVID.3301	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3301	Integer	3301
ibdot1sMstVID.3302	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3302	Integer	3302
ibdot1sMstVID.3303	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3303	Integer	3303
ibdot1sMstVID.3304	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3304	Integer	3304
ibdot1sMstVID.3305	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3305	Integer	3305
ibdot1sMstVID.3306	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3306	Integer	3306
ibdot1sMstVID.3307	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3307	Integer	3307
ibdot1sMstVID.3308	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3308	Integer	3308
ibdot1sMstVID.3309	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3309	Integer	3309
ibdot1sMstVID.3310	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3310	Integer	3310
ibdot1sMstVID.3311	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3311	Integer	3311
ibdot1sMstVID.3312	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3312	Integer	3312
ibdot1sMstVID.3313	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3313	Integer	3313
ibdot1sMstVID.3314	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3314	Integer	3314
ibdot1sMstVID.3315	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3315	Integer	3315
ibdot1sMstVID.3316	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3316	Integer	3316
ibdot1sMstVID.3317	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3317	Integer	3317
ibdot1sMstVID.3318	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3318	Integer	3318
ibdot1sMstVID.3319	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3319	Integer	3319
ibdot1sMstVID.3320	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3320	Integer	3320
ibdot1sMstVID.3321	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3321	Integer	3321
ibdot1sMstVID.3322	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3322	Integer	3322
ibdot1sMstVID.3323	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3323	Integer	3323
ibdot1sMstVID.3324	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3324	Integer	3324
ibdot1sMstVID.3325	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3325	Integer	3325
ibdot1sMstVID.3326	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3326	Integer	3326
ibdot1sMstVID.3327	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3327	Integer	3327
ibdot1sMstVID.3328	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3328	Integer	3328
ibdot1sMstVID.3329	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3329	Integer	3329
ibdot1sMstVID.3330	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3330	Integer	3330
ibdot1sMstVID.3331	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3331	Integer	3331
ibdot1sMstVID.3332	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3332	Integer	3332
ibdot1sMstVID.3333	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3333	Integer	3333
ibdot1sMstVID.3334	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3334	Integer	3334
ibdot1sMstVID.3335	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3335	Integer	3335
ibdot1sMstVID.3336	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3336	Integer	3336
ibdot1sMstVID.3337	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3337	Integer	3337
ibdot1sMstVID.3338	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3338	Integer	3338
ibdot1sMstVID.3339	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3339	Integer	3339
ibdot1sMstVID.3340	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3340	Integer	3340
ibdot1sMstVID.3341	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3341	Integer	3341
ibdot1sMstVID.3342	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3342	Integer	3342

Name	OID	Value Type	Value Example
ibdot1sMstVID.3343	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3343	Integer	3343
ibdot1sMstVID.3344	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3344	Integer	3344
ibdot1sMstVID.3345	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3345	Integer	3345
ibdot1sMstVID.3346	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3346	Integer	3346
ibdot1sMstVID.3347	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3347	Integer	3347
ibdot1sMstVID.3348	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3348	Integer	3348
ibdot1sMstVID.3349	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3349	Integer	3349
ibdot1sMstVID.3350	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3350	Integer	3350
ibdot1sMstVID.3351	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3351	Integer	3351
ibdot1sMstVID.3352	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3352	Integer	3352
ibdot1sMstVID.3353	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3353	Integer	3353
ibdot1sMstVID.3354	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3354	Integer	3354
ibdot1sMstVID.3355	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3355	Integer	3355
ibdot1sMstVID.3356	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3356	Integer	3356
ibdot1sMstVID.3357	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3357	Integer	3357
ibdot1sMstVID.3358	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3358	Integer	3358
ibdot1sMstVID.3359	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3359	Integer	3359
ibdot1sMstVID.3360	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3360	Integer	3360
ibdot1sMstVID.3361	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3361	Integer	3361
ibdot1sMstVID.3362	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3362	Integer	3362
ibdot1sMstVID.3363	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3363	Integer	3363
ibdot1sMstVID.3364	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3364	Integer	3364
ibdot1sMstVID.3365	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3365	Integer	3365
ibdot1sMstVID.3366	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3366	Integer	3366
ibdot1sMstVID.3367	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3367	Integer	3367
ibdot1sMstVID.3368	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3368	Integer	3368
ibdot1sMstVID.3369	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3369	Integer	3369
ibdot1sMstVID.3370	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3370	Integer	3370
ibdot1sMstVID.3371	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3371	Integer	3371
ibdot1sMstVID.3372	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3372	Integer	3372
ibdot1sMstVID.3373	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3373	Integer	3373
ibdot1sMstVID.3374	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3374	Integer	3374
ibdot1sMstVID.3375	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3375	Integer	3375
ibdot1sMstVID.3376	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3376	Integer	3376
ibdot1sMstVID.3377	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3377	Integer	3377
ibdot1sMstVID.3378	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3378	Integer	3378
ibdot1sMstVID.3379	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3379	Integer	3379
ibdot1sMstVID.3380	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3380	Integer	3380
ibdot1sMstVID.3381	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3381	Integer	3381
ibdot1sMstVID.3382	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3382	Integer	3382
ibdot1sMstVID.3383	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3383	Integer	3383
ibdot1sMstVID.3384	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3384	Integer	3384
ibdot1sMstVID.3385	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3385	Integer	3385

Name	OID	Value Type	Value Example
ibdot1sMstVID.3386	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3386	Integer	3386
ibdot1sMstVID.3387	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3387	Integer	3387
ibdot1sMstVID.3388	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3388	Integer	3388
ibdot1sMstVID.3389	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3389	Integer	3389
ibdot1sMstVID.3390	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3390	Integer	3390
ibdot1sMstVID.3391	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3391	Integer	3391
ibdot1sMstVID.3392	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3392	Integer	3392
ibdot1sMstVID.3393	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3393	Integer	3393
ibdot1sMstVID.3394	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3394	Integer	3394
ibdot1sMstVID.3395	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3395	Integer	3395
ibdot1sMstVID.3396	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3396	Integer	3396
ibdot1sMstVID.3397	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3397	Integer	3397
ibdot1sMstVID.3398	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3398	Integer	3398
ibdot1sMstVID.3399	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3399	Integer	3399
ibdot1sMstVID.3400	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3400	Integer	3400
ibdot1sMstVID.3401	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3401	Integer	3401
ibdot1sMstVID.3402	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3402	Integer	3402
ibdot1sMstVID.3403	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3403	Integer	3403
ibdot1sMstVID.3404	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3404	Integer	3404
ibdot1sMstVID.3405	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3405	Integer	3405
ibdot1sMstVID.3406	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3406	Integer	3406
ibdot1sMstVID.3407	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3407	Integer	3407
ibdot1sMstVID.3408	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3408	Integer	3408
ibdot1sMstVID.3409	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3409	Integer	3409
ibdot1sMstVID.3410	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3410	Integer	3410
ibdot1sMstVID.3411	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3411	Integer	3411
ibdot1sMstVID.3412	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3412	Integer	3412
ibdot1sMstVID.3413	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3413	Integer	3413
ibdot1sMstVID.3414	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3414	Integer	3414
ibdot1sMstVID.3415	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3415	Integer	3415
ibdot1sMstVID.3416	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3416	Integer	3416
ibdot1sMstVID.3417	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3417	Integer	3417
ibdot1sMstVID.3418	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3418	Integer	3418
ibdot1sMstVID.3419	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3419	Integer	3419
ibdot1sMstVID.3420	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3420	Integer	3420
ibdot1sMstVID.3421	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3421	Integer	3421
ibdot1sMstVID.3422	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3422	Integer	3422
ibdot1sMstVID.3423	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3423	Integer	3423
ibdot1sMstVID.3424	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3424	Integer	3424
ibdot1sMstVID.3425	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3425	Integer	3425
ibdot1sMstVID.3426	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3426	Integer	3426
ibdot1sMstVID.3427	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3427	Integer	3427
ibdot1sMstVID.3428	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3428	Integer	3428

Name	OID	Value Type	Value Example
ibdot1sMstVID.3429	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3429	Integer	3429
ibdot1sMstVID.3430	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3430	Integer	3430
ibdot1sMstVID.3431	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3431	Integer	3431
ibdot1sMstVID.3432	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3432	Integer	3432
ibdot1sMstVID.3433	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3433	Integer	3433
ibdot1sMstVID.3434	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3434	Integer	3434
ibdot1sMstVID.3435	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3435	Integer	3435
ibdot1sMstVID.3436	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3436	Integer	3436
ibdot1sMstVID.3437	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3437	Integer	3437
ibdot1sMstVID.3438	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3438	Integer	3438
ibdot1sMstVID.3439	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3439	Integer	3439
ibdot1sMstVID.3440	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3440	Integer	3440
ibdot1sMstVID.3441	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3441	Integer	3441
ibdot1sMstVID.3442	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3442	Integer	3442
ibdot1sMstVID.3443	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3443	Integer	3443
ibdot1sMstVID.3444	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3444	Integer	3444
ibdot1sMstVID.3445	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3445	Integer	3445
ibdot1sMstVID.3446	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3446	Integer	3446
ibdot1sMstVID.3447	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3447	Integer	3447
ibdot1sMstVID.3448	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3448	Integer	3448
ibdot1sMstVID.3449	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3449	Integer	3449
ibdot1sMstVID.3450	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3450	Integer	3450
ibdot1sMstVID.3451	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3451	Integer	3451
ibdot1sMstVID.3452	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3452	Integer	3452
ibdot1sMstVID.3453	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3453	Integer	3453
ibdot1sMstVID.3454	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3454	Integer	3454
ibdot1sMstVID.3455	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3455	Integer	3455
ibdot1sMstVID.3456	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3456	Integer	3456
ibdot1sMstVID.3457	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3457	Integer	3457
ibdot1sMstVID.3458	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3458	Integer	3458
ibdot1sMstVID.3459	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3459	Integer	3459
ibdot1sMstVID.3460	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3460	Integer	3460
ibdot1sMstVID.3461	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3461	Integer	3461
ibdot1sMstVID.3462	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3462	Integer	3462
ibdot1sMstVID.3463	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3463	Integer	3463
ibdot1sMstVID.3464	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3464	Integer	3464
ibdot1sMstVID.3465	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3465	Integer	3465
ibdot1sMstVID.3466	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3466	Integer	3466
ibdot1sMstVID.3467	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3467	Integer	3467
ibdot1sMstVID.3468	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3468	Integer	3468
ibdot1sMstVID.3469	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3469	Integer	3469
ibdot1sMstVID.3470	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3470	Integer	3470
ibdot1sMstVID.3471	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3471	Integer	3471

Name	OID	Value Type	Value Example
ibdot1sMstVID.3472	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3472	Integer	3472
ibdot1sMstVID.3473	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3473	Integer	3473
ibdot1sMstVID.3474	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3474	Integer	3474
ibdot1sMstVID.3475	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3475	Integer	3475
ibdot1sMstVID.3476	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3476	Integer	3476
ibdot1sMstVID.3477	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3477	Integer	3477
ibdot1sMstVID.3478	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3478	Integer	3478
ibdot1sMstVID.3479	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3479	Integer	3479
ibdot1sMstVID.3480	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3480	Integer	3480
ibdot1sMstVID.3481	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3481	Integer	3481
ibdot1sMstVID.3482	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3482	Integer	3482
ibdot1sMstVID.3483	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3483	Integer	3483
ibdot1sMstVID.3484	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3484	Integer	3484
ibdot1sMstVID.3485	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3485	Integer	3485
ibdot1sMstVID.3486	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3486	Integer	3486
ibdot1sMstVID.3487	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3487	Integer	3487
ibdot1sMstVID.3488	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3488	Integer	3488
ibdot1sMstVID.3489	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3489	Integer	3489
ibdot1sMstVID.3490	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3490	Integer	3490
ibdot1sMstVID.3491	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3491	Integer	3491
ibdot1sMstVID.3492	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3492	Integer	3492
ibdot1sMstVID.3493	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3493	Integer	3493
ibdot1sMstVID.3494	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3494	Integer	3494
ibdot1sMstVID.3495	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3495	Integer	3495
ibdot1sMstVID.3496	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3496	Integer	3496
ibdot1sMstVID.3497	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3497	Integer	3497
ibdot1sMstVID.3498	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3498	Integer	3498
ibdot1sMstVID.3499	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3499	Integer	3499
ibdot1sMstVID.3500	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3500	Integer	3500
ibdot1sMstVID.3501	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3501	Integer	3501
ibdot1sMstVID.3502	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3502	Integer	3502
ibdot1sMstVID.3503	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3503	Integer	3503
ibdot1sMstVID.3504	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3504	Integer	3504
ibdot1sMstVID.3505	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3505	Integer	3505
ibdot1sMstVID.3506	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3506	Integer	3506
ibdot1sMstVID.3507	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3507	Integer	3507
ibdot1sMstVID.3508	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3508	Integer	3508
ibdot1sMstVID.3509	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3509	Integer	3509
ibdot1sMstVID.3510	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3510	Integer	3510
ibdot1sMstVID.3511	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3511	Integer	3511
ibdot1sMstVID.3512	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3512	Integer	3512
ibdot1sMstVID.3513	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3513	Integer	3513
ibdot1sMstVID.3514	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3514	Integer	3514

Name	OID	Value Type	Value Example
ibdot1sMstVID.3515	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3515	Integer	3515
ibdot1sMstVID.3516	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3516	Integer	3516
ibdot1sMstVID.3517	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3517	Integer	3517
ibdot1sMstVID.3518	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3518	Integer	3518
ibdot1sMstVID.3519	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3519	Integer	3519
ibdot1sMstVID.3520	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3520	Integer	3520
ibdot1sMstVID.3521	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3521	Integer	3521
ibdot1sMstVID.3522	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3522	Integer	3522
ibdot1sMstVID.3523	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3523	Integer	3523
ibdot1sMstVID.3524	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3524	Integer	3524
ibdot1sMstVID.3525	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3525	Integer	3525
ibdot1sMstVID.3526	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3526	Integer	3526
ibdot1sMstVID.3527	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3527	Integer	3527
ibdot1sMstVID.3528	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3528	Integer	3528
ibdot1sMstVID.3529	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3529	Integer	3529
ibdot1sMstVID.3530	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3530	Integer	3530
ibdot1sMstVID.3531	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3531	Integer	3531
ibdot1sMstVID.3532	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3532	Integer	3532
ibdot1sMstVID.3533	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3533	Integer	3533
ibdot1sMstVID.3534	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3534	Integer	3534
ibdot1sMstVID.3535	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3535	Integer	3535
ibdot1sMstVID.3536	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3536	Integer	3536
ibdot1sMstVID.3537	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3537	Integer	3537
ibdot1sMstVID.3538	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3538	Integer	3538
ibdot1sMstVID.3539	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3539	Integer	3539
ibdot1sMstVID.3540	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3540	Integer	3540
ibdot1sMstVID.3541	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3541	Integer	3541
ibdot1sMstVID.3542	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3542	Integer	3542
ibdot1sMstVID.3543	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3543	Integer	3543
ibdot1sMstVID.3544	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3544	Integer	3544
ibdot1sMstVID.3545	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3545	Integer	3545
ibdot1sMstVID.3546	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3546	Integer	3546
ibdot1sMstVID.3547	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3547	Integer	3547
ibdot1sMstVID.3548	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3548	Integer	3548
ibdot1sMstVID.3549	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3549	Integer	3549
ibdot1sMstVID.3550	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3550	Integer	3550
ibdot1sMstVID.3551	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3551	Integer	3551
ibdot1sMstVID.3552	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3552	Integer	3552
ibdot1sMstVID.3553	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3553	Integer	3553
ibdot1sMstVID.3554	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3554	Integer	3554
ibdot1sMstVID.3555	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3555	Integer	3555
ibdot1sMstVID.3556	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3556	Integer	3556
ibdot1sMstVID.3557	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3557	Integer	3557



Name	OID	Value Type	Value Example
ibdot1sMstVID.3558	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3558	Integer	3558
ibdot1sMstVID.3559	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3559	Integer	3559
ibdot1sMstVID.3560	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3560	Integer	3560
ibdot1sMstVID.3561	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3561	Integer	3561
ibdot1sMstVID.3562	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3562	Integer	3562
ibdot1sMstVID.3563	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3563	Integer	3563
ibdot1sMstVID.3564	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3564	Integer	3564
ibdot1sMstVID.3565	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3565	Integer	3565
ibdot1sMstVID.3566	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3566	Integer	3566
ibdot1sMstVID.3567	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3567	Integer	3567
ibdot1sMstVID.3568	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3568	Integer	3568
ibdot1sMstVID.3569	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3569	Integer	3569
ibdot1sMstVID.3570	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3570	Integer	3570
ibdot1sMstVID.3571	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3571	Integer	3571
ibdot1sMstVID.3572	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3572	Integer	3572
ibdot1sMstVID.3573	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3573	Integer	3573
ibdot1sMstVID.3574	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3574	Integer	3574
ibdot1sMstVID.3575	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3575	Integer	3575
ibdot1sMstVID.3576	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3576	Integer	3576
ibdot1sMstVID.3577	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3577	Integer	3577
ibdot1sMstVID.3578	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3578	Integer	3578
ibdot1sMstVID.3579	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3579	Integer	3579
ibdot1sMstVID.3580	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3580	Integer	3580
ibdot1sMstVID.3581	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3581	Integer	3581
ibdot1sMstVID.3582	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3582	Integer	3582
ibdot1sMstVID.3583	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3583	Integer	3583
ibdot1sMstVID.3584	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3584	Integer	3584
ibdot1sMstVID.3585	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3585	Integer	3585
ibdot1sMstVID.3586	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3586	Integer	3586
ibdot1sMstVID.3587	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3587	Integer	3587
ibdot1sMstVID.3588	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3588	Integer	3588
ibdot1sMstVID.3589	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3589	Integer	3589
ibdot1sMstVID.3590	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3590	Integer	3590
ibdot1sMstVID.3591	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3591	Integer	3591
ibdot1sMstVID.3592	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3592	Integer	3592
ibdot1sMstVID.3593	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3593	Integer	3593
ibdot1sMstVID.3594	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3594	Integer	3594
ibdot1sMstVID.3595	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3595	Integer	3595
ibdot1sMstVID.3596	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3596	Integer	3596
ibdot1sMstVID.3597	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3597	Integer	3597
ibdot1sMstVID.3598	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3598	Integer	3598
ibdot1sMstVID.3599	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3599	Integer	3599
ibdot1sMstVID.3600	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3600	Integer	3600

Name	OID	Value Type	Value Example
ibdot1sMstVID.3601	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3601	Integer	3601
ibdot1sMstVID.3602	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3602	Integer	3602
ibdot1sMstVID.3603	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3603	Integer	3603
ibdot1sMstVID.3604	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3604	Integer	3604
ibdot1sMstVID.3605	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3605	Integer	3605
ibdot1sMstVID.3606	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3606	Integer	3606
ibdot1sMstVID.3607	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3607	Integer	3607
ibdot1sMstVID.3608	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3608	Integer	3608
ibdot1sMstVID.3609	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3609	Integer	3609
ibdot1sMstVID.3610	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3610	Integer	3610
ibdot1sMstVID.3611	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3611	Integer	3611
ibdot1sMstVID.3612	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3612	Integer	3612
ibdot1sMstVID.3613	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3613	Integer	3613
ibdot1sMstVID.3614	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3614	Integer	3614
ibdot1sMstVID.3615	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3615	Integer	3615
ibdot1sMstVID.3616	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3616	Integer	3616
ibdot1sMstVID.3617	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3617	Integer	3617
ibdot1sMstVID.3618	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3618	Integer	3618
ibdot1sMstVID.3619	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3619	Integer	3619
ibdot1sMstVID.3620	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3620	Integer	3620
ibdot1sMstVID.3621	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3621	Integer	3621
ibdot1sMstVID.3622	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3622	Integer	3622
ibdot1sMstVID.3623	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3623	Integer	3623
ibdot1sMstVID.3624	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3624	Integer	3624
ibdot1sMstVID.3625	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3625	Integer	3625
ibdot1sMstVID.3626	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3626	Integer	3626
ibdot1sMstVID.3627	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3627	Integer	3627
ibdot1sMstVID.3628	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3628	Integer	3628
ibdot1sMstVID.3629	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3629	Integer	3629
ibdot1sMstVID.3630	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3630	Integer	3630
ibdot1sMstVID.3631	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3631	Integer	3631
ibdot1sMstVID.3632	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3632	Integer	3632
ibdot1sMstVID.3633	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3633	Integer	3633
ibdot1sMstVID.3634	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3634	Integer	3634
ibdot1sMstVID.3635	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3635	Integer	3635
ibdot1sMstVID.3636	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3636	Integer	3636
ibdot1sMstVID.3637	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3637	Integer	3637
ibdot1sMstVID.3638	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3638	Integer	3638
ibdot1sMstVID.3639	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3639	Integer	3639
ibdot1sMstVID.3640	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3640	Integer	3640
ibdot1sMstVID.3641	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3641	Integer	3641
ibdot1sMstVID.3642	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3642	Integer	3642
ibdot1sMstVID.3643	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3643	Integer	3643

Name	OID	Value Type	Value Example
ibdot1sMstVID.3644	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3644	Integer	3644
ibdot1sMstVID.3645	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3645	Integer	3645
ibdot1sMstVID.3646	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3646	Integer	3646
ibdot1sMstVID.3647	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3647	Integer	3647
ibdot1sMstVID.3648	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3648	Integer	3648
ibdot1sMstVID.3649	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3649	Integer	3649
ibdot1sMstVID.3650	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3650	Integer	3650
ibdot1sMstVID.3651	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3651	Integer	3651
ibdot1sMstVID.3652	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3652	Integer	3652
ibdot1sMstVID.3653	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3653	Integer	3653
ibdot1sMstVID.3654	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3654	Integer	3654
ibdot1sMstVID.3655	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3655	Integer	3655
ibdot1sMstVID.3656	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3656	Integer	3656
ibdot1sMstVID.3657	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3657	Integer	3657
ibdot1sMstVID.3658	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3658	Integer	3658
ibdot1sMstVID.3659	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3659	Integer	3659
ibdot1sMstVID.3660	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3660	Integer	3660
ibdot1sMstVID.3661	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3661	Integer	3661
ibdot1sMstVID.3662	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3662	Integer	3662
ibdot1sMstVID.3663	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3663	Integer	3663
ibdot1sMstVID.3664	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3664	Integer	3664
ibdot1sMstVID.3665	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3665	Integer	3665
ibdot1sMstVID.3666	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3666	Integer	3666
ibdot1sMstVID.3667	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3667	Integer	3667
ibdot1sMstVID.3668	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3668	Integer	3668
ibdot1sMstVID.3669	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3669	Integer	3669
ibdot1sMstVID.3670	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3670	Integer	3670
ibdot1sMstVID.3671	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3671	Integer	3671
ibdot1sMstVID.3672	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3672	Integer	3672
ibdot1sMstVID.3673	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3673	Integer	3673
ibdot1sMstVID.3674	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3674	Integer	3674
ibdot1sMstVID.3675	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3675	Integer	3675
ibdot1sMstVID.3676	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3676	Integer	3676
ibdot1sMstVID.3677	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3677	Integer	3677
ibdot1sMstVID.3678	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3678	Integer	3678
ibdot1sMstVID.3679	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3679	Integer	3679
ibdot1sMstVID.3680	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3680	Integer	3680
ibdot1sMstVID.3681	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3681	Integer	3681
ibdot1sMstVID.3682	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3682	Integer	3682
ibdot1sMstVID.3683	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3683	Integer	3683
ibdot1sMstVID.3684	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3684	Integer	3684
ibdot1sMstVID.3685	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3685	Integer	3685
ibdot1sMstVID.3686	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3686	Integer	3686

Name	OID	Value Type	Value Example
ibdot1sMstVID.3687	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3687	Integer	3687
ibdot1sMstVID.3688	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3688	Integer	3688
ibdot1sMstVID.3689	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3689	Integer	3689
ibdot1sMstVID.3690	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3690	Integer	3690
ibdot1sMstVID.3691	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3691	Integer	3691
ibdot1sMstVID.3692	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3692	Integer	3692
ibdot1sMstVID.3693	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3693	Integer	3693
ibdot1sMstVID.3694	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3694	Integer	3694
ibdot1sMstVID.3695	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3695	Integer	3695
ibdot1sMstVID.3696	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3696	Integer	3696
ibdot1sMstVID.3697	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3697	Integer	3697
ibdot1sMstVID.3698	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3698	Integer	3698
ibdot1sMstVID.3699	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3699	Integer	3699
ibdot1sMstVID.3700	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3700	Integer	3700
ibdot1sMstVID.3701	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3701	Integer	3701
ibdot1sMstVID.3702	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3702	Integer	3702
ibdot1sMstVID.3703	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3703	Integer	3703
ibdot1sMstVID.3704	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3704	Integer	3704
ibdot1sMstVID.3705	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3705	Integer	3705
ibdot1sMstVID.3706	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3706	Integer	3706
ibdot1sMstVID.3707	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3707	Integer	3707
ibdot1sMstVID.3708	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3708	Integer	3708
ibdot1sMstVID.3709	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3709	Integer	3709
ibdot1sMstVID.3710	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3710	Integer	3710
ibdot1sMstVID.3711	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3711	Integer	3711
ibdot1sMstVID.3712	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3712	Integer	3712
ibdot1sMstVID.3713	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3713	Integer	3713
ibdot1sMstVID.3714	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3714	Integer	3714
ibdot1sMstVID.3715	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3715	Integer	3715
ibdot1sMstVID.3716	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3716	Integer	3716
ibdot1sMstVID.3717	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3717	Integer	3717
ibdot1sMstVID.3718	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3718	Integer	3718
ibdot1sMstVID.3719	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3719	Integer	3719
ibdot1sMstVID.3720	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3720	Integer	3720
ibdot1sMstVID.3721	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3721	Integer	3721
ibdot1sMstVID.3722	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3722	Integer	3722
ibdot1sMstVID.3723	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3723	Integer	3723
ibdot1sMstVID.3724	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3724	Integer	3724
ibdot1sMstVID.3725	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3725	Integer	3725
ibdot1sMstVID.3726	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3726	Integer	3726
ibdot1sMstVID.3727	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3727	Integer	3727
ibdot1sMstVID.3728	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3728	Integer	3728
ibdot1sMstVID.3729	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3729	Integer	3729

Name	OID	Value Type	Value Example
ibdot1sMstVID.3730	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3730	Integer	3730
ibdot1sMstVID.3731	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3731	Integer	3731
ibdot1sMstVID.3732	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3732	Integer	3732
ibdot1sMstVID.3733	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3733	Integer	3733
ibdot1sMstVID.3734	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3734	Integer	3734
ibdot1sMstVID.3735	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3735	Integer	3735
ibdot1sMstVID.3736	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3736	Integer	3736
ibdot1sMstVID.3737	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3737	Integer	3737
ibdot1sMstVID.3738	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3738	Integer	3738
ibdot1sMstVID.3739	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3739	Integer	3739
ibdot1sMstVID.3740	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3740	Integer	3740
ibdot1sMstVID.3741	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3741	Integer	3741
ibdot1sMstVID.3742	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3742	Integer	3742
ibdot1sMstVID.3743	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3743	Integer	3743
ibdot1sMstVID.3744	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3744	Integer	3744
ibdot1sMstVID.3745	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3745	Integer	3745
ibdot1sMstVID.3746	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3746	Integer	3746
ibdot1sMstVID.3747	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3747	Integer	3747
ibdot1sMstVID.3748	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3748	Integer	3748
ibdot1sMstVID.3749	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3749	Integer	3749
ibdot1sMstVID.3750	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3750	Integer	3750
ibdot1sMstVID.3751	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3751	Integer	3751
ibdot1sMstVID.3752	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3752	Integer	3752
ibdot1sMstVID.3753	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3753	Integer	3753
ibdot1sMstVID.3754	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3754	Integer	3754
ibdot1sMstVID.3755	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3755	Integer	3755
ibdot1sMstVID.3756	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3756	Integer	3756
ibdot1sMstVID.3757	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3757	Integer	3757
ibdot1sMstVID.3758	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3758	Integer	3758
ibdot1sMstVID.3759	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3759	Integer	3759
ibdot1sMstVID.3760	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3760	Integer	3760
ibdot1sMstVID.3761	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3761	Integer	3761
ibdot1sMstVID.3762	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3762	Integer	3762
ibdot1sMstVID.3763	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3763	Integer	3763
ibdot1sMstVID.3764	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3764	Integer	3764
ibdot1sMstVID.3765	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3765	Integer	3765
ibdot1sMstVID.3766	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3766	Integer	3766
ibdot1sMstVID.3767	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3767	Integer	3767
ibdot1sMstVID.3768	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3768	Integer	3768
ibdot1sMstVID.3769	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3769	Integer	3769
ibdot1sMstVID.3770	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3770	Integer	3770
ibdot1sMstVID.3771	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3771	Integer	3771
ibdot1sMstVID.3772	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3772	Integer	3772

Name	OID	Value Type	Value Example
ibdot1sMstVID.3773	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3773	Integer	3773
ibdot1sMstVID.3774	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3774	Integer	3774
ibdot1sMstVID.3775	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3775	Integer	3775
ibdot1sMstVID.3776	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3776	Integer	3776
ibdot1sMstVID.3777	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3777	Integer	3777
ibdot1sMstVID.3778	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3778	Integer	3778
ibdot1sMstVID.3779	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3779	Integer	3779
ibdot1sMstVID.3780	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3780	Integer	3780
ibdot1sMstVID.3781	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3781	Integer	3781
ibdot1sMstVID.3782	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3782	Integer	3782
ibdot1sMstVID.3783	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3783	Integer	3783
ibdot1sMstVID.3784	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3784	Integer	3784
ibdot1sMstVID.3785	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3785	Integer	3785
ibdot1sMstVID.3786	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3786	Integer	3786
ibdot1sMstVID.3787	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3787	Integer	3787
ibdot1sMstVID.3788	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3788	Integer	3788
ibdot1sMstVID.3789	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3789	Integer	3789
ibdot1sMstVID.3790	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3790	Integer	3790
ibdot1sMstVID.3791	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3791	Integer	3791
ibdot1sMstVID.3792	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3792	Integer	3792
ibdot1sMstVID.3793	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3793	Integer	3793
ibdot1sMstVID.3794	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3794	Integer	3794
ibdot1sMstVID.3795	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3795	Integer	3795
ibdot1sMstVID.3796	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3796	Integer	3796
ibdot1sMstVID.3797	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3797	Integer	3797
ibdot1sMstVID.3798	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3798	Integer	3798
ibdot1sMstVID.3799	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3799	Integer	3799
ibdot1sMstVID.3800	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3800	Integer	3800
ibdot1sMstVID.3801	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3801	Integer	3801
ibdot1sMstVID.3802	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3802	Integer	3802
ibdot1sMstVID.3803	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3803	Integer	3803
ibdot1sMstVID.3804	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3804	Integer	3804
ibdot1sMstVID.3805	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3805	Integer	3805
ibdot1sMstVID.3806	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3806	Integer	3806
ibdot1sMstVID.3807	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3807	Integer	3807
ibdot1sMstVID.3808	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3808	Integer	3808
ibdot1sMstVID.3809	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3809	Integer	3809
ibdot1sMstVID.3810	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3810	Integer	3810
ibdot1sMstVID.3811	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3811	Integer	3811
ibdot1sMstVID.3812	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3812	Integer	3812
ibdot1sMstVID.3813	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3813	Integer	3813
ibdot1sMstVID.3814	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3814	Integer	3814
ibdot1sMstVID.3815	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3815	Integer	3815

Name	OID	Value Type	Value Example
ibdot1sMstVID.3816	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3816	Integer	3816
ibdot1sMstVID.3817	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3817	Integer	3817
ibdot1sMstVID.3818	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3818	Integer	3818
ibdot1sMstVID.3819	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3819	Integer	3819
ibdot1sMstVID.3820	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3820	Integer	3820
ibdot1sMstVID.3821	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3821	Integer	3821
ibdot1sMstVID.3822	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3822	Integer	3822
ibdot1sMstVID.3823	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3823	Integer	3823
ibdot1sMstVID.3824	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3824	Integer	3824
ibdot1sMstVID.3825	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3825	Integer	3825
ibdot1sMstVID.3826	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3826	Integer	3826
ibdot1sMstVID.3827	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3827	Integer	3827
ibdot1sMstVID.3828	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3828	Integer	3828
ibdot1sMstVID.3829	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3829	Integer	3829
ibdot1sMstVID.3830	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3830	Integer	3830
ibdot1sMstVID.3831	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3831	Integer	3831
ibdot1sMstVID.3832	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3832	Integer	3832
ibdot1sMstVID.3833	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3833	Integer	3833
ibdot1sMstVID.3834	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3834	Integer	3834
ibdot1sMstVID.3835	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3835	Integer	3835
ibdot1sMstVID.3836	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3836	Integer	3836
ibdot1sMstVID.3837	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3837	Integer	3837
ibdot1sMstVID.3838	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3838	Integer	3838
ibdot1sMstVID.3839	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3839	Integer	3839
ibdot1sMstVID.3840	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3840	Integer	3840
ibdot1sMstVID.3841	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3841	Integer	3841
ibdot1sMstVID.3842	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3842	Integer	3842
ibdot1sMstVID.3843	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3843	Integer	3843
ibdot1sMstVID.3844	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3844	Integer	3844
ibdot1sMstVID.3845	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3845	Integer	3845
ibdot1sMstVID.3846	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3846	Integer	3846
ibdot1sMstVID.3847	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3847	Integer	3847
ibdot1sMstVID.3848	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3848	Integer	3848
ibdot1sMstVID.3849	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3849	Integer	3849
ibdot1sMstVID.3850	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3850	Integer	3850
ibdot1sMstVID.3851	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3851	Integer	3851
ibdot1sMstVID.3852	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3852	Integer	3852
ibdot1sMstVID.3853	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3853	Integer	3853
ibdot1sMstVID.3854	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3854	Integer	3854
ibdot1sMstVID.3855	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3855	Integer	3855
ibdot1sMstVID.3856	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3856	Integer	3856
ibdot1sMstVID.3857	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3857	Integer	3857
ibdot1sMstVID.3858	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3858	Integer	3858



Name	OID	Value Type	Value Example
ibdot1sMstVID.3859	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3859	Integer	3859
ibdot1sMstVID.3860	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3860	Integer	3860
ibdot1sMstVID.3861	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3861	Integer	3861
ibdot1sMstVID.3862	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3862	Integer	3862
ibdot1sMstVID.3863	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3863	Integer	3863
ibdot1sMstVID.3864	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3864	Integer	3864
ibdot1sMstVID.3865	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3865	Integer	3865
ibdot1sMstVID.3866	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3866	Integer	3866
ibdot1sMstVID.3867	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3867	Integer	3867
ibdot1sMstVID.3868	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3868	Integer	3868
ibdot1sMstVID.3869	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3869	Integer	3869
ibdot1sMstVID.3870	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3870	Integer	3870
ibdot1sMstVID.3871	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3871	Integer	3871
ibdot1sMstVID.3872	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3872	Integer	3872
ibdot1sMstVID.3873	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3873	Integer	3873
ibdot1sMstVID.3874	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3874	Integer	3874
ibdot1sMstVID.3875	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3875	Integer	3875
ibdot1sMstVID.3876	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3876	Integer	3876
ibdot1sMstVID.3877	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3877	Integer	3877
ibdot1sMstVID.3878	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3878	Integer	3878
ibdot1sMstVID.3879	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3879	Integer	3879
ibdot1sMstVID.3880	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3880	Integer	3880
ibdot1sMstVID.3881	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3881	Integer	3881
ibdot1sMstVID.3882	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3882	Integer	3882
ibdot1sMstVID.3883	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3883	Integer	3883
ibdot1sMstVID.3884	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3884	Integer	3884
ibdot1sMstVID.3885	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3885	Integer	3885
ibdot1sMstVID.3886	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3886	Integer	3886
ibdot1sMstVID.3887	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3887	Integer	3887
ibdot1sMstVID.3888	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3888	Integer	3888
ibdot1sMstVID.3889	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3889	Integer	3889
ibdot1sMstVID.3890	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3890	Integer	3890
ibdot1sMstVID.3891	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3891	Integer	3891
ibdot1sMstVID.3892	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3892	Integer	3892
ibdot1sMstVID.3893	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3893	Integer	3893
ibdot1sMstVID.3894	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3894	Integer	3894
ibdot1sMstVID.3895	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3895	Integer	3895
ibdot1sMstVID.3896	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3896	Integer	3896
ibdot1sMstVID.3897	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3897	Integer	3897
ibdot1sMstVID.3898	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3898	Integer	3898
ibdot1sMstVID.3899	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3899	Integer	3899
ibdot1sMstVID.3900	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3900	Integer	3900
ibdot1sMstVID.3901	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3901	Integer	3901

Name	OID	Value Type	Value Example
ibdot1sMstVID.3902	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3902	Integer	3902
ibdot1sMstVID.3903	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3903	Integer	3903
ibdot1sMstVID.3904	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3904	Integer	3904
ibdot1sMstVID.3905	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3905	Integer	3905
ibdot1sMstVID.3906	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3906	Integer	3906
ibdot1sMstVID.3907	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3907	Integer	3907
ibdot1sMstVID.3908	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3908	Integer	3908
ibdot1sMstVID.3909	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3909	Integer	3909
ibdot1sMstVID.3910	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3910	Integer	3910
ibdot1sMstVID.3911	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3911	Integer	3911
ibdot1sMstVID.3912	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3912	Integer	3912
ibdot1sMstVID.3913	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3913	Integer	3913
ibdot1sMstVID.3914	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3914	Integer	3914
ibdot1sMstVID.3915	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3915	Integer	3915
ibdot1sMstVID.3916	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3916	Integer	3916
ibdot1sMstVID.3917	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3917	Integer	3917
ibdot1sMstVID.3918	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3918	Integer	3918
ibdot1sMstVID.3919	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3919	Integer	3919
ibdot1sMstVID.3920	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3920	Integer	3920
ibdot1sMstVID.3921	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3921	Integer	3921
ibdot1sMstVID.3922	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3922	Integer	3922
ibdot1sMstVID.3923	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3923	Integer	3923
ibdot1sMstVID.3924	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3924	Integer	3924
ibdot1sMstVID.3925	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3925	Integer	3925
ibdot1sMstVID.3926	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3926	Integer	3926
ibdot1sMstVID.3927	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3927	Integer	3927
ibdot1sMstVID.3928	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3928	Integer	3928
ibdot1sMstVID.3929	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3929	Integer	3929
ibdot1sMstVID.3930	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3930	Integer	3930
ibdot1sMstVID.3931	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3931	Integer	3931
ibdot1sMstVID.3932	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3932	Integer	3932
ibdot1sMstVID.3933	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3933	Integer	3933
ibdot1sMstVID.3934	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3934	Integer	3934
ibdot1sMstVID.3935	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3935	Integer	3935
ibdot1sMstVID.3936	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3936	Integer	3936
ibdot1sMstVID.3937	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3937	Integer	3937
ibdot1sMstVID.3938	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3938	Integer	3938
ibdot1sMstVID.3939	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3939	Integer	3939
ibdot1sMstVID.3940	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3940	Integer	3940
ibdot1sMstVID.3941	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3941	Integer	3941
ibdot1sMstVID.3942	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3942	Integer	3942
ibdot1sMstVID.3943	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3943	Integer	3943
ibdot1sMstVID.3944	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3944	Integer	3944

Name	OID	Value Type	Value Example
ibdot1sMstVID.3945	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3945	Integer	3945
ibdot1sMstVID.3946	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3946	Integer	3946
ibdot1sMstVID.3947	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3947	Integer	3947
ibdot1sMstVID.3948	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3948	Integer	3948
ibdot1sMstVID.3949	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3949	Integer	3949
ibdot1sMstVID.3950	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3950	Integer	3950
ibdot1sMstVID.3951	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3951	Integer	3951
ibdot1sMstVID.3952	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3952	Integer	3952
ibdot1sMstVID.3953	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3953	Integer	3953
ibdot1sMstVID.3954	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3954	Integer	3954
ibdot1sMstVID.3955	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3955	Integer	3955
ibdot1sMstVID.3956	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3956	Integer	3956
ibdot1sMstVID.3957	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3957	Integer	3957
ibdot1sMstVID.3958	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3958	Integer	3958
ibdot1sMstVID.3959	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3959	Integer	3959
ibdot1sMstVID.3960	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3960	Integer	3960
ibdot1sMstVID.3961	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3961	Integer	3961
ibdot1sMstVID.3962	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3962	Integer	3962
ibdot1sMstVID.3963	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3963	Integer	3963
ibdot1sMstVID.3964	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3964	Integer	3964
ibdot1sMstVID.3965	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3965	Integer	3965
ibdot1sMstVID.3966	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3966	Integer	3966
ibdot1sMstVID.3967	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3967	Integer	3967
ibdot1sMstVID.3968	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3968	Integer	3968
ibdot1sMstVID.3969	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3969	Integer	3969
ibdot1sMstVID.3970	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3970	Integer	3970
ibdot1sMstVID.3971	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3971	Integer	3971
ibdot1sMstVID.3972	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3972	Integer	3972
ibdot1sMstVID.3973	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3973	Integer	3973
ibdot1sMstVID.3974	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3974	Integer	3974
ibdot1sMstVID.3975	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3975	Integer	3975
ibdot1sMstVID.3976	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3976	Integer	3976
ibdot1sMstVID.3977	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3977	Integer	3977
ibdot1sMstVID.3978	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3978	Integer	3978
ibdot1sMstVID.3979	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3979	Integer	3979
ibdot1sMstVID.3980	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3980	Integer	3980
ibdot1sMstVID.3981	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3981	Integer	3981
ibdot1sMstVID.3982	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3982	Integer	3982
ibdot1sMstVID.3983	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3983	Integer	3983
ibdot1sMstVID.3984	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3984	Integer	3984
ibdot1sMstVID.3985	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3985	Integer	3985
ibdot1sMstVID.3986	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3986	Integer	3986
ibdot1sMstVID.3987	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3987	Integer	3987

Name	OID	Value Type	Value Example
ibdot1sMstVID.3988	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3988	Integer	3988
ibdot1sMstVID.3989	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3989	Integer	3989
ibdot1sMstVID.3990	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3990	Integer	3990
ibdot1sMstVID.3991	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3991	Integer	3991
ibdot1sMstVID.3992	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3992	Integer	3992
ibdot1sMstVID.3993	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3993	Integer	3993
ibdot1sMstVID.3994	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3994	Integer	3994
ibdot1sMstVID.3995	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3995	Integer	3995
ibdot1sMstVID.3996	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3996	Integer	3996
ibdot1sMstVID.3997	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3997	Integer	3997
ibdot1sMstVID.3998	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3998	Integer	3998
ibdot1sMstVID.3999	.1.3.6.1.4.1.26138.8.35.14.18.1.1.3999	Integer	3999
ibdot1sMstVID.4000	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4000	Integer	4000
ibdot1sMstVID.4001	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4001	Integer	4001
ibdot1sMstVID.4002	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4002	Integer	4002
ibdot1sMstVID.4003	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4003	Integer	4003
ibdot1sMstVID.4004	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4004	Integer	4004
ibdot1sMstVID.4005	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4005	Integer	4005
ibdot1sMstVID.4006	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4006	Integer	4006
ibdot1sMstVID.4007	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4007	Integer	4007
ibdot1sMstVID.4008	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4008	Integer	4008
ibdot1sMstVID.4009	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4009	Integer	4009
ibdot1sMstVID.4010	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4010	Integer	4010
ibdot1sMstVID.4011	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4011	Integer	4011
ibdot1sMstVID.4012	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4012	Integer	4012
ibdot1sMstVID.4013	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4013	Integer	4013
ibdot1sMstVID.4014	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4014	Integer	4014
ibdot1sMstVID.4015	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4015	Integer	4015
ibdot1sMstVID.4016	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4016	Integer	4016
ibdot1sMstVID.4017	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4017	Integer	4017
ibdot1sMstVID.4018	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4018	Integer	4018
ibdot1sMstVID.4019	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4019	Integer	4019
ibdot1sMstVID.4020	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4020	Integer	4020
ibdot1sMstVID.4021	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4021	Integer	4021
ibdot1sMstVID.4022	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4022	Integer	4022
ibdot1sMstVID.4023	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4023	Integer	4023
ibdot1sMstVID.4024	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4024	Integer	4024
ibdot1sMstVID.4025	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4025	Integer	4025
ibdot1sMstVID.4026	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4026	Integer	4026
ibdot1sMstVID.4027	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4027	Integer	4027
ibdot1sMstVID.4028	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4028	Integer	4028
ibdot1sMstVID.4029	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4029	Integer	4029
ibdot1sMstVID.4030	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4030	Integer	4030

Name	OID	Value Type	Value Example
ibdot1sMstVID.4031	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4031	Integer	4031
ibdot1sMstVID.4032	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4032	Integer	4032
ibdot1sMstVID.4033	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4033	Integer	4033
ibdot1sMstVID.4034	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4034	Integer	4034
ibdot1sMstVID.4035	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4035	Integer	4035
ibdot1sMstVID.4036	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4036	Integer	4036
ibdot1sMstVID.4037	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4037	Integer	4037
ibdot1sMstVID.4038	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4038	Integer	4038
ibdot1sMstVID.4039	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4039	Integer	4039
ibdot1sMstVID.4040	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4040	Integer	4040
ibdot1sMstVID.4041	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4041	Integer	4041
ibdot1sMstVID.4042	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4042	Integer	4042
ibdot1sMstVID.4043	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4043	Integer	4043
ibdot1sMstVID.4044	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4044	Integer	4044
ibdot1sMstVID.4045	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4045	Integer	4045
ibdot1sMstVID.4046	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4046	Integer	4046
ibdot1sMstVID.4047	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4047	Integer	4047
ibdot1sMstVID.4048	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4048	Integer	4048
ibdot1sMstVID.4049	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4049	Integer	4049
ibdot1sMstVID.4050	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4050	Integer	4050
ibdot1sMstVID.4051	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4051	Integer	4051
ibdot1sMstVID.4052	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4052	Integer	4052
ibdot1sMstVID.4053	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4053	Integer	4053
ibdot1sMstVID.4054	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4054	Integer	4054
ibdot1sMstVID.4055	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4055	Integer	4055
ibdot1sMstVID.4056	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4056	Integer	4056
ibdot1sMstVID.4057	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4057	Integer	4057
ibdot1sMstVID.4058	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4058	Integer	4058
ibdot1sMstVID.4059	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4059	Integer	4059
ibdot1sMstVID.4060	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4060	Integer	4060
ibdot1sMstVID.4061	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4061	Integer	4061
ibdot1sMstVID.4062	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4062	Integer	4062
ibdot1sMstVID.4063	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4063	Integer	4063
ibdot1sMstVID.4064	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4064	Integer	4064
ibdot1sMstVID.4065	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4065	Integer	4065
ibdot1sMstVID.4066	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4066	Integer	4066
ibdot1sMstVID.4067	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4067	Integer	4067
ibdot1sMstVID.4068	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4068	Integer	4068
ibdot1sMstVID.4069	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4069	Integer	4069
ibdot1sMstVID.4070	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4070	Integer	4070
ibdot1sMstVID.4071	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4071	Integer	4071
ibdot1sMstVID.4072	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4072	Integer	4072
ibdot1sMstVID.4073	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4073	Integer	4073

Name	OID	Value Type	Value Example
ibdot1sMstVID.4074	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4074	Integer	4074
ibdot1sMstVID.4075	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4075	Integer	4075
ibdot1sMstVID.4076	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4076	Integer	4076
ibdot1sMstVID.4077	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4077	Integer	4077
ibdot1sMstVID.4078	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4078	Integer	4078
ibdot1sMstVID.4079	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4079	Integer	4079
ibdot1sMstVID.4080	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4080	Integer	4080
ibdot1sMstVID.4081	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4081	Integer	4081
ibdot1sMstVID.4082	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4082	Integer	4082
ibdot1sMstVID.4083	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4083	Integer	4083
ibdot1sMstVID.4084	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4084	Integer	4084
ibdot1sMstVID.4085	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4085	Integer	4085
ibdot1sMstVID.4086	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4086	Integer	4086
ibdot1sMstVID.4087	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4087	Integer	4087
ibdot1sMstVID.4088	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4088	Integer	4088
ibdot1sMstVID.4089	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4089	Integer	4089
ibdot1sMstVID.4090	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4090	Integer	4090
ibdot1sMstVID.4091	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4091	Integer	4091
ibdot1sMstVID.4092	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4092	Integer	4092
ibdot1sMstVID.4093	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4093	Integer	4093
ibdot1sMstVID.4094	.1.3.6.1.4.1.26138.8.35.14.18.1.1.4094	Integer	4094
ibdot1sAdminMstID.1	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1	Integer	0
ibdot1sAdminMstID.2	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2	Integer	0
ibdot1sAdminMstID.3	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3	Integer	0
ibdot1sAdminMstID.4	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4	Integer	0
ibdot1sAdminMstID.5	.1.3.6.1.4.1.26138.8.35.14.18.1.2.5	Integer	0
ibdot1sAdminMstID.6	.1.3.6.1.4.1.26138.8.35.14.18.1.2.6	Integer	0
ibdot1sAdminMstID.7	.1.3.6.1.4.1.26138.8.35.14.18.1.2.7	Integer	0
ibdot1sAdminMstID.8	.1.3.6.1.4.1.26138.8.35.14.18.1.2.8	Integer	0
ibdot1sAdminMstID.9	.1.3.6.1.4.1.26138.8.35.14.18.1.2.9	Integer	0
ibdot1sAdminMstID.10	.1.3.6.1.4.1.26138.8.35.14.18.1.2.10	Integer	0
ibdot1sAdminMstID.11	.1.3.6.1.4.1.26138.8.35.14.18.1.2.11	Integer	0
ibdot1sAdminMstID.12	.1.3.6.1.4.1.26138.8.35.14.18.1.2.12	Integer	0
ibdot1sAdminMstID.13	.1.3.6.1.4.1.26138.8.35.14.18.1.2.13	Integer	0
ibdot1sAdminMstID.14	.1.3.6.1.4.1.26138.8.35.14.18.1.2.14	Integer	0
ibdot1sAdminMstID.15	.1.3.6.1.4.1.26138.8.35.14.18.1.2.15	Integer	0
ibdot1sAdminMstID.16	.1.3.6.1.4.1.26138.8.35.14.18.1.2.16	Integer	0
ibdot1sAdminMstID.17	.1.3.6.1.4.1.26138.8.35.14.18.1.2.17	Integer	0
ibdot1sAdminMstID.18	.1.3.6.1.4.1.26138.8.35.14.18.1.2.18	Integer	0
ibdot1sAdminMstID.19	.1.3.6.1.4.1.26138.8.35.14.18.1.2.19	Integer	0
ibdot1sAdminMstID.20	.1.3.6.1.4.1.26138.8.35.14.18.1.2.20	Integer	0
ibdot1sAdminMstID.21	.1.3.6.1.4.1.26138.8.35.14.18.1.2.21	Integer	0
ibdot1sAdminMstID.22	.1.3.6.1.4.1.26138.8.35.14.18.1.2.22	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.23	1.3.6.1.4.1.26138.8.35.14.18.1.2.23	Integer	0
ibdot1sAdminMstID.24	1.3.6.1.4.1.26138.8.35.14.18.1.2.24	Integer	0
ibdot1sAdminMstID.25	1.3.6.1.4.1.26138.8.35.14.18.1.2.25	Integer	0
ibdot1sAdminMstID.26	1.3.6.1.4.1.26138.8.35.14.18.1.2.26	Integer	0
ibdot1sAdminMstID.27	1.3.6.1.4.1.26138.8.35.14.18.1.2.27	Integer	0
ibdot1sAdminMstID.28	1.3.6.1.4.1.26138.8.35.14.18.1.2.28	Integer	0
ibdot1sAdminMstID.29	1.3.6.1.4.1.26138.8.35.14.18.1.2.29	Integer	0
ibdot1sAdminMstID.30	1.3.6.1.4.1.26138.8.35.14.18.1.2.30	Integer	0
ibdot1sAdminMstID.31	1.3.6.1.4.1.26138.8.35.14.18.1.2.31	Integer	0
ibdot1sAdminMstID.32	1.3.6.1.4.1.26138.8.35.14.18.1.2.32	Integer	0
ibdot1sAdminMstID.33	1.3.6.1.4.1.26138.8.35.14.18.1.2.33	Integer	0
ibdot1sAdminMstID.34	1.3.6.1.4.1.26138.8.35.14.18.1.2.34	Integer	0
ibdot1sAdminMstID.35	1.3.6.1.4.1.26138.8.35.14.18.1.2.35	Integer	0
ibdot1sAdminMstID.36	1.3.6.1.4.1.26138.8.35.14.18.1.2.36	Integer	0
ibdot1sAdminMstID.37	1.3.6.1.4.1.26138.8.35.14.18.1.2.37	Integer	0
ibdot1sAdminMstID.38	1.3.6.1.4.1.26138.8.35.14.18.1.2.38	Integer	0
ibdot1sAdminMstID.39	1.3.6.1.4.1.26138.8.35.14.18.1.2.39	Integer	0
ibdot1sAdminMstID.40	1.3.6.1.4.1.26138.8.35.14.18.1.2.40	Integer	0
ibdot1sAdminMstID.41	1.3.6.1.4.1.26138.8.35.14.18.1.2.41	Integer	0
ibdot1sAdminMstID.42	1.3.6.1.4.1.26138.8.35.14.18.1.2.42	Integer	0
ibdot1sAdminMstID.43	1.3.6.1.4.1.26138.8.35.14.18.1.2.43	Integer	0
ibdot1sAdminMstID.44	1.3.6.1.4.1.26138.8.35.14.18.1.2.44	Integer	0
ibdot1sAdminMstID.45	1.3.6.1.4.1.26138.8.35.14.18.1.2.45	Integer	0
ibdot1sAdminMstID.46	1.3.6.1.4.1.26138.8.35.14.18.1.2.46	Integer	0
ibdot1sAdminMstID.47	1.3.6.1.4.1.26138.8.35.14.18.1.2.47	Integer	0
ibdot1sAdminMstID.48	1.3.6.1.4.1.26138.8.35.14.18.1.2.48	Integer	0
ibdot1sAdminMstID.49	1.3.6.1.4.1.26138.8.35.14.18.1.2.49	Integer	0
ibdot1sAdminMstID.50	1.3.6.1.4.1.26138.8.35.14.18.1.2.50	Integer	0
ibdot1sAdminMstID.51	1.3.6.1.4.1.26138.8.35.14.18.1.2.51	Integer	0
ibdot1sAdminMstID.52	1.3.6.1.4.1.26138.8.35.14.18.1.2.52	Integer	0
ibdot1sAdminMstID.53	1.3.6.1.4.1.26138.8.35.14.18.1.2.53	Integer	0
ibdot1sAdminMstID.54	1.3.6.1.4.1.26138.8.35.14.18.1.2.54	Integer	0
ibdot1sAdminMstID.55	1.3.6.1.4.1.26138.8.35.14.18.1.2.55	Integer	0
ibdot1sAdminMstID.56	1.3.6.1.4.1.26138.8.35.14.18.1.2.56	Integer	0
ibdot1sAdminMstID.57	1.3.6.1.4.1.26138.8.35.14.18.1.2.57	Integer	0
ibdot1sAdminMstID.58	1.3.6.1.4.1.26138.8.35.14.18.1.2.58	Integer	0
ibdot1sAdminMstID.59	1.3.6.1.4.1.26138.8.35.14.18.1.2.59	Integer	0
ibdot1sAdminMstID.60	1.3.6.1.4.1.26138.8.35.14.18.1.2.60	Integer	0
ibdot1sAdminMstID.61	1.3.6.1.4.1.26138.8.35.14.18.1.2.61	Integer	0
ibdot1sAdminMstID.62	1.3.6.1.4.1.26138.8.35.14.18.1.2.62	Integer	0
ibdot1sAdminMstID.63	1.3.6.1.4.1.26138.8.35.14.18.1.2.63	Integer	0
ibdot1sAdminMstID.64	1.3.6.1.4.1.26138.8.35.14.18.1.2.64	Integer	0
ibdot1sAdminMstID.65	1.3.6.1.4.1.26138.8.35.14.18.1.2.65	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.66	.1.3.6.1.4.1.26138.8.35.14.18.1.2.66	Integer	0
ibdot1sAdminMstID.67	.1.3.6.1.4.1.26138.8.35.14.18.1.2.67	Integer	0
ibdot1sAdminMstID.68	.1.3.6.1.4.1.26138.8.35.14.18.1.2.68	Integer	0
ibdot1sAdminMstID.69	.1.3.6.1.4.1.26138.8.35.14.18.1.2.69	Integer	0
ibdot1sAdminMstID.70	.1.3.6.1.4.1.26138.8.35.14.18.1.2.70	Integer	0
ibdot1sAdminMstID.71	.1.3.6.1.4.1.26138.8.35.14.18.1.2.71	Integer	0
ibdot1sAdminMstID.72	.1.3.6.1.4.1.26138.8.35.14.18.1.2.72	Integer	0
ibdot1sAdminMstID.73	.1.3.6.1.4.1.26138.8.35.14.18.1.2.73	Integer	0
ibdot1sAdminMstID.74	.1.3.6.1.4.1.26138.8.35.14.18.1.2.74	Integer	0
ibdot1sAdminMstID.75	.1.3.6.1.4.1.26138.8.35.14.18.1.2.75	Integer	0
ibdot1sAdminMstID.76	.1.3.6.1.4.1.26138.8.35.14.18.1.2.76	Integer	0
ibdot1sAdminMstID.77	.1.3.6.1.4.1.26138.8.35.14.18.1.2.77	Integer	0
ibdot1sAdminMstID.78	.1.3.6.1.4.1.26138.8.35.14.18.1.2.78	Integer	0
ibdot1sAdminMstID.79	.1.3.6.1.4.1.26138.8.35.14.18.1.2.79	Integer	0
ibdot1sAdminMstID.80	.1.3.6.1.4.1.26138.8.35.14.18.1.2.80	Integer	0
ibdot1sAdminMstID.81	.1.3.6.1.4.1.26138.8.35.14.18.1.2.81	Integer	0
ibdot1sAdminMstID.82	.1.3.6.1.4.1.26138.8.35.14.18.1.2.82	Integer	0
ibdot1sAdminMstID.83	.1.3.6.1.4.1.26138.8.35.14.18.1.2.83	Integer	0
ibdot1sAdminMstID.84	.1.3.6.1.4.1.26138.8.35.14.18.1.2.84	Integer	0
ibdot1sAdminMstID.85	.1.3.6.1.4.1.26138.8.35.14.18.1.2.85	Integer	0
ibdot1sAdminMstID.86	.1.3.6.1.4.1.26138.8.35.14.18.1.2.86	Integer	0
ibdot1sAdminMstID.87	.1.3.6.1.4.1.26138.8.35.14.18.1.2.87	Integer	0
ibdot1sAdminMstID.88	.1.3.6.1.4.1.26138.8.35.14.18.1.2.88	Integer	0
ibdot1sAdminMstID.89	.1.3.6.1.4.1.26138.8.35.14.18.1.2.89	Integer	0
ibdot1sAdminMstID.90	.1.3.6.1.4.1.26138.8.35.14.18.1.2.90	Integer	0
ibdot1sAdminMstID.91	.1.3.6.1.4.1.26138.8.35.14.18.1.2.91	Integer	0
ibdot1sAdminMstID.92	.1.3.6.1.4.1.26138.8.35.14.18.1.2.92	Integer	0
ibdot1sAdminMstID.93	.1.3.6.1.4.1.26138.8.35.14.18.1.2.93	Integer	0
ibdot1sAdminMstID.94	.1.3.6.1.4.1.26138.8.35.14.18.1.2.94	Integer	0
ibdot1sAdminMstID.95	.1.3.6.1.4.1.26138.8.35.14.18.1.2.95	Integer	0
ibdot1sAdminMstID.96	.1.3.6.1.4.1.26138.8.35.14.18.1.2.96	Integer	0
ibdot1sAdminMstID.97	.1.3.6.1.4.1.26138.8.35.14.18.1.2.97	Integer	0
ibdot1sAdminMstID.98	.1.3.6.1.4.1.26138.8.35.14.18.1.2.98	Integer	0
ibdot1sAdminMstID.99	.1.3.6.1.4.1.26138.8.35.14.18.1.2.99	Integer	0
ibdot1sAdminMstID.100	.1.3.6.1.4.1.26138.8.35.14.18.1.2.100	Integer	0
ibdot1sAdminMstID.101	.1.3.6.1.4.1.26138.8.35.14.18.1.2.101	Integer	0
ibdot1sAdminMstID.102	.1.3.6.1.4.1.26138.8.35.14.18.1.2.102	Integer	0
ibdot1sAdminMstID.103	.1.3.6.1.4.1.26138.8.35.14.18.1.2.103	Integer	0
ibdot1sAdminMstID.104	.1.3.6.1.4.1.26138.8.35.14.18.1.2.104	Integer	0
ibdot1sAdminMstID.105	.1.3.6.1.4.1.26138.8.35.14.18.1.2.105	Integer	0
ibdot1sAdminMstID.106	.1.3.6.1.4.1.26138.8.35.14.18.1.2.106	Integer	0
ibdot1sAdminMstID.107	.1.3.6.1.4.1.26138.8.35.14.18.1.2.107	Integer	0
ibdot1sAdminMstID.108	.1.3.6.1.4.1.26138.8.35.14.18.1.2.108	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.109	.3.6.1.4.1.26138.8.35.14.18.1.2.109	Integer	0
ibdot1sAdminMstID.110	.3.6.1.4.1.26138.8.35.14.18.1.2.110	Integer	0
ibdot1sAdminMstID.111	.3.6.1.4.1.26138.8.35.14.18.1.2.111	Integer	0
ibdot1sAdminMstID.112	.3.6.1.4.1.26138.8.35.14.18.1.2.112	Integer	0
ibdot1sAdminMstID.113	.3.6.1.4.1.26138.8.35.14.18.1.2.113	Integer	0
ibdot1sAdminMstID.114	.3.6.1.4.1.26138.8.35.14.18.1.2.114	Integer	0
ibdot1sAdminMstID.115	.3.6.1.4.1.26138.8.35.14.18.1.2.115	Integer	0
ibdot1sAdminMstID.116	.3.6.1.4.1.26138.8.35.14.18.1.2.116	Integer	0
ibdot1sAdminMstID.117	.3.6.1.4.1.26138.8.35.14.18.1.2.117	Integer	0
ibdot1sAdminMstID.118	.3.6.1.4.1.26138.8.35.14.18.1.2.118	Integer	0
ibdot1sAdminMstID.119	.3.6.1.4.1.26138.8.35.14.18.1.2.119	Integer	0
ibdot1sAdminMstID.120	.3.6.1.4.1.26138.8.35.14.18.1.2.120	Integer	0
ibdot1sAdminMstID.121	.3.6.1.4.1.26138.8.35.14.18.1.2.121	Integer	0
ibdot1sAdminMstID.122	.3.6.1.4.1.26138.8.35.14.18.1.2.122	Integer	0
ibdot1sAdminMstID.123	.3.6.1.4.1.26138.8.35.14.18.1.2.123	Integer	0
ibdot1sAdminMstID.124	.3.6.1.4.1.26138.8.35.14.18.1.2.124	Integer	0
ibdot1sAdminMstID.125	.3.6.1.4.1.26138.8.35.14.18.1.2.125	Integer	0
ibdot1sAdminMstID.126	.3.6.1.4.1.26138.8.35.14.18.1.2.126	Integer	0
ibdot1sAdminMstID.127	.3.6.1.4.1.26138.8.35.14.18.1.2.127	Integer	0
ibdot1sAdminMstID.128	.3.6.1.4.1.26138.8.35.14.18.1.2.128	Integer	0
ibdot1sAdminMstID.129	.3.6.1.4.1.26138.8.35.14.18.1.2.129	Integer	0
ibdot1sAdminMstID.130	.3.6.1.4.1.26138.8.35.14.18.1.2.130	Integer	0
ibdot1sAdminMstID.131	.3.6.1.4.1.26138.8.35.14.18.1.2.131	Integer	0
ibdot1sAdminMstID.132	.3.6.1.4.1.26138.8.35.14.18.1.2.132	Integer	0
ibdot1sAdminMstID.133	.3.6.1.4.1.26138.8.35.14.18.1.2.133	Integer	0
ibdot1sAdminMstID.134	.3.6.1.4.1.26138.8.35.14.18.1.2.134	Integer	0
ibdot1sAdminMstID.135	.3.6.1.4.1.26138.8.35.14.18.1.2.135	Integer	0
ibdot1sAdminMstID.136	.3.6.1.4.1.26138.8.35.14.18.1.2.136	Integer	0
ibdot1sAdminMstID.137	.3.6.1.4.1.26138.8.35.14.18.1.2.137	Integer	0
ibdot1sAdminMstID.138	.3.6.1.4.1.26138.8.35.14.18.1.2.138	Integer	0
ibdot1sAdminMstID.139	.3.6.1.4.1.26138.8.35.14.18.1.2.139	Integer	0
ibdot1sAdminMstID.140	.3.6.1.4.1.26138.8.35.14.18.1.2.140	Integer	0
ibdot1sAdminMstID.141	.3.6.1.4.1.26138.8.35.14.18.1.2.141	Integer	0
ibdot1sAdminMstID.142	.3.6.1.4.1.26138.8.35.14.18.1.2.142	Integer	0
ibdot1sAdminMstID.143	.3.6.1.4.1.26138.8.35.14.18.1.2.143	Integer	0
ibdot1sAdminMstID.144	.3.6.1.4.1.26138.8.35.14.18.1.2.144	Integer	0
ibdot1sAdminMstID.145	.3.6.1.4.1.26138.8.35.14.18.1.2.145	Integer	0
ibdot1sAdminMstID.146	.3.6.1.4.1.26138.8.35.14.18.1.2.146	Integer	0
ibdot1sAdminMstID.147	.3.6.1.4.1.26138.8.35.14.18.1.2.147	Integer	0
ibdot1sAdminMstID.148	.3.6.1.4.1.26138.8.35.14.18.1.2.148	Integer	0
ibdot1sAdminMstID.149	.3.6.1.4.1.26138.8.35.14.18.1.2.149	Integer	0
ibdot1sAdminMstID.150	.3.6.1.4.1.26138.8.35.14.18.1.2.150	Integer	0
ibdot1sAdminMstID.151	.3.6.1.4.1.26138.8.35.14.18.1.2.151	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.152	.3.6.1.4.1.26138.8.35.14.18.1.2.152	Integer	0
ibdot1sAdminMstID.153	.3.6.1.4.1.26138.8.35.14.18.1.2.153	Integer	0
ibdot1sAdminMstID.154	.3.6.1.4.1.26138.8.35.14.18.1.2.154	Integer	0
ibdot1sAdminMstID.155	.3.6.1.4.1.26138.8.35.14.18.1.2.155	Integer	0
ibdot1sAdminMstID.156	.3.6.1.4.1.26138.8.35.14.18.1.2.156	Integer	0
ibdot1sAdminMstID.157	.3.6.1.4.1.26138.8.35.14.18.1.2.157	Integer	0
ibdot1sAdminMstID.158	.3.6.1.4.1.26138.8.35.14.18.1.2.158	Integer	0
ibdot1sAdminMstID.159	.3.6.1.4.1.26138.8.35.14.18.1.2.159	Integer	0
ibdot1sAdminMstID.160	.3.6.1.4.1.26138.8.35.14.18.1.2.160	Integer	0
ibdot1sAdminMstID.161	.3.6.1.4.1.26138.8.35.14.18.1.2.161	Integer	0
ibdot1sAdminMstID.162	.3.6.1.4.1.26138.8.35.14.18.1.2.162	Integer	0
ibdot1sAdminMstID.163	.3.6.1.4.1.26138.8.35.14.18.1.2.163	Integer	0
ibdot1sAdminMstID.164	.3.6.1.4.1.26138.8.35.14.18.1.2.164	Integer	0
ibdot1sAdminMstID.165	.3.6.1.4.1.26138.8.35.14.18.1.2.165	Integer	0
ibdot1sAdminMstID.166	.3.6.1.4.1.26138.8.35.14.18.1.2.166	Integer	0
ibdot1sAdminMstID.167	.3.6.1.4.1.26138.8.35.14.18.1.2.167	Integer	0
ibdot1sAdminMstID.168	.3.6.1.4.1.26138.8.35.14.18.1.2.168	Integer	0
ibdot1sAdminMstID.169	.3.6.1.4.1.26138.8.35.14.18.1.2.169	Integer	0
ibdot1sAdminMstID.170	.3.6.1.4.1.26138.8.35.14.18.1.2.170	Integer	0
ibdot1sAdminMstID.171	.3.6.1.4.1.26138.8.35.14.18.1.2.171	Integer	0
ibdot1sAdminMstID.172	.3.6.1.4.1.26138.8.35.14.18.1.2.172	Integer	0
ibdot1sAdminMstID.173	.3.6.1.4.1.26138.8.35.14.18.1.2.173	Integer	0
ibdot1sAdminMstID.174	.3.6.1.4.1.26138.8.35.14.18.1.2.174	Integer	0
ibdot1sAdminMstID.175	.3.6.1.4.1.26138.8.35.14.18.1.2.175	Integer	0
ibdot1sAdminMstID.176	.3.6.1.4.1.26138.8.35.14.18.1.2.176	Integer	0
ibdot1sAdminMstID.177	.3.6.1.4.1.26138.8.35.14.18.1.2.177	Integer	0
ibdot1sAdminMstID.178	.3.6.1.4.1.26138.8.35.14.18.1.2.178	Integer	0
ibdot1sAdminMstID.179	.3.6.1.4.1.26138.8.35.14.18.1.2.179	Integer	0
ibdot1sAdminMstID.180	.3.6.1.4.1.26138.8.35.14.18.1.2.180	Integer	0
ibdot1sAdminMstID.181	.3.6.1.4.1.26138.8.35.14.18.1.2.181	Integer	0
ibdot1sAdminMstID.182	.3.6.1.4.1.26138.8.35.14.18.1.2.182	Integer	0
ibdot1sAdminMstID.183	.3.6.1.4.1.26138.8.35.14.18.1.2.183	Integer	0
ibdot1sAdminMstID.184	.3.6.1.4.1.26138.8.35.14.18.1.2.184	Integer	0
ibdot1sAdminMstID.185	.3.6.1.4.1.26138.8.35.14.18.1.2.185	Integer	0
ibdot1sAdminMstID.186	.3.6.1.4.1.26138.8.35.14.18.1.2.186	Integer	0
ibdot1sAdminMstID.187	.3.6.1.4.1.26138.8.35.14.18.1.2.187	Integer	0
ibdot1sAdminMstID.188	.3.6.1.4.1.26138.8.35.14.18.1.2.188	Integer	0
ibdot1sAdminMstID.189	.3.6.1.4.1.26138.8.35.14.18.1.2.189	Integer	0
ibdot1sAdminMstID.190	.3.6.1.4.1.26138.8.35.14.18.1.2.190	Integer	0
ibdot1sAdminMstID.191	.3.6.1.4.1.26138.8.35.14.18.1.2.191	Integer	0
ibdot1sAdminMstID.192	.3.6.1.4.1.26138.8.35.14.18.1.2.192	Integer	0
ibdot1sAdminMstID.193	.3.6.1.4.1.26138.8.35.14.18.1.2.193	Integer	0
ibdot1sAdminMstID.194	.3.6.1.4.1.26138.8.35.14.18.1.2.194	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.195	.3.6.1.4.1.26138.8.35.14.18.1.2.195	Integer	0
ibdot1sAdminMstID.196	.3.6.1.4.1.26138.8.35.14.18.1.2.196	Integer	0
ibdot1sAdminMstID.197	.3.6.1.4.1.26138.8.35.14.18.1.2.197	Integer	0
ibdot1sAdminMstID.198	.3.6.1.4.1.26138.8.35.14.18.1.2.198	Integer	0
ibdot1sAdminMstID.199	.3.6.1.4.1.26138.8.35.14.18.1.2.199	Integer	0
ibdot1sAdminMstID.200	.3.6.1.4.1.26138.8.35.14.18.1.2.200	Integer	0
ibdot1sAdminMstID.201	.3.6.1.4.1.26138.8.35.14.18.1.2.201	Integer	0
ibdot1sAdminMstID.202	.3.6.1.4.1.26138.8.35.14.18.1.2.202	Integer	0
ibdot1sAdminMstID.203	.3.6.1.4.1.26138.8.35.14.18.1.2.203	Integer	0
ibdot1sAdminMstID.204	.3.6.1.4.1.26138.8.35.14.18.1.2.204	Integer	0
ibdot1sAdminMstID.205	.3.6.1.4.1.26138.8.35.14.18.1.2.205	Integer	0
ibdot1sAdminMstID.206	.3.6.1.4.1.26138.8.35.14.18.1.2.206	Integer	0
ibdot1sAdminMstID.207	.3.6.1.4.1.26138.8.35.14.18.1.2.207	Integer	0
ibdot1sAdminMstID.208	.3.6.1.4.1.26138.8.35.14.18.1.2.208	Integer	0
ibdot1sAdminMstID.209	.3.6.1.4.1.26138.8.35.14.18.1.2.209	Integer	0
ibdot1sAdminMstID.210	.3.6.1.4.1.26138.8.35.14.18.1.2.210	Integer	0
ibdot1sAdminMstID.211	.3.6.1.4.1.26138.8.35.14.18.1.2.211	Integer	0
ibdot1sAdminMstID.212	.3.6.1.4.1.26138.8.35.14.18.1.2.212	Integer	0
ibdot1sAdminMstID.213	.3.6.1.4.1.26138.8.35.14.18.1.2.213	Integer	0
ibdot1sAdminMstID.214	.3.6.1.4.1.26138.8.35.14.18.1.2.214	Integer	0
ibdot1sAdminMstID.215	.3.6.1.4.1.26138.8.35.14.18.1.2.215	Integer	0
ibdot1sAdminMstID.216	.3.6.1.4.1.26138.8.35.14.18.1.2.216	Integer	0
ibdot1sAdminMstID.217	.3.6.1.4.1.26138.8.35.14.18.1.2.217	Integer	0
ibdot1sAdminMstID.218	.3.6.1.4.1.26138.8.35.14.18.1.2.218	Integer	0
ibdot1sAdminMstID.219	.3.6.1.4.1.26138.8.35.14.18.1.2.219	Integer	0
ibdot1sAdminMstID.220	.3.6.1.4.1.26138.8.35.14.18.1.2.220	Integer	0
ibdot1sAdminMstID.221	.3.6.1.4.1.26138.8.35.14.18.1.2.221	Integer	0
ibdot1sAdminMstID.222	.3.6.1.4.1.26138.8.35.14.18.1.2.222	Integer	0
ibdot1sAdminMstID.223	.3.6.1.4.1.26138.8.35.14.18.1.2.223	Integer	0
ibdot1sAdminMstID.224	.3.6.1.4.1.26138.8.35.14.18.1.2.224	Integer	0
ibdot1sAdminMstID.225	.3.6.1.4.1.26138.8.35.14.18.1.2.225	Integer	0
ibdot1sAdminMstID.226	.3.6.1.4.1.26138.8.35.14.18.1.2.226	Integer	0
ibdot1sAdminMstID.227	.3.6.1.4.1.26138.8.35.14.18.1.2.227	Integer	0
ibdot1sAdminMstID.228	.3.6.1.4.1.26138.8.35.14.18.1.2.228	Integer	0
ibdot1sAdminMstID.229	.3.6.1.4.1.26138.8.35.14.18.1.2.229	Integer	0
ibdot1sAdminMstID.230	.3.6.1.4.1.26138.8.35.14.18.1.2.230	Integer	0
ibdot1sAdminMstID.231	.3.6.1.4.1.26138.8.35.14.18.1.2.231	Integer	0
ibdot1sAdminMstID.232	.3.6.1.4.1.26138.8.35.14.18.1.2.232	Integer	0
ibdot1sAdminMstID.233	.3.6.1.4.1.26138.8.35.14.18.1.2.233	Integer	0
ibdot1sAdminMstID.234	.3.6.1.4.1.26138.8.35.14.18.1.2.234	Integer	0
ibdot1sAdminMstID.235	.3.6.1.4.1.26138.8.35.14.18.1.2.235	Integer	0
ibdot1sAdminMstID.236	.3.6.1.4.1.26138.8.35.14.18.1.2.236	Integer	0
ibdot1sAdminMstID.237	.3.6.1.4.1.26138.8.35.14.18.1.2.237	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.238	.3.6.1.4.1.26138.8.35.14.18.1.2.238	Integer	0
ibdot1sAdminMstID.239	.3.6.1.4.1.26138.8.35.14.18.1.2.239	Integer	0
ibdot1sAdminMstID.240	.3.6.1.4.1.26138.8.35.14.18.1.2.240	Integer	0
ibdot1sAdminMstID.241	.3.6.1.4.1.26138.8.35.14.18.1.2.241	Integer	0
ibdot1sAdminMstID.242	.3.6.1.4.1.26138.8.35.14.18.1.2.242	Integer	0
ibdot1sAdminMstID.243	.3.6.1.4.1.26138.8.35.14.18.1.2.243	Integer	0
ibdot1sAdminMstID.244	.3.6.1.4.1.26138.8.35.14.18.1.2.244	Integer	0
ibdot1sAdminMstID.245	.3.6.1.4.1.26138.8.35.14.18.1.2.245	Integer	0
ibdot1sAdminMstID.246	.3.6.1.4.1.26138.8.35.14.18.1.2.246	Integer	0
ibdot1sAdminMstID.247	.3.6.1.4.1.26138.8.35.14.18.1.2.247	Integer	0
ibdot1sAdminMstID.248	.3.6.1.4.1.26138.8.35.14.18.1.2.248	Integer	0
ibdot1sAdminMstID.249	.3.6.1.4.1.26138.8.35.14.18.1.2.249	Integer	0
ibdot1sAdminMstID.250	.3.6.1.4.1.26138.8.35.14.18.1.2.250	Integer	0
ibdot1sAdminMstID.251	.3.6.1.4.1.26138.8.35.14.18.1.2.251	Integer	0
ibdot1sAdminMstID.252	.3.6.1.4.1.26138.8.35.14.18.1.2.252	Integer	0
ibdot1sAdminMstID.253	.3.6.1.4.1.26138.8.35.14.18.1.2.253	Integer	0
ibdot1sAdminMstID.254	.3.6.1.4.1.26138.8.35.14.18.1.2.254	Integer	0
ibdot1sAdminMstID.255	.3.6.1.4.1.26138.8.35.14.18.1.2.255	Integer	0
ibdot1sAdminMstID.256	.3.6.1.4.1.26138.8.35.14.18.1.2.256	Integer	0
ibdot1sAdminMstID.257	.3.6.1.4.1.26138.8.35.14.18.1.2.257	Integer	0
ibdot1sAdminMstID.258	.3.6.1.4.1.26138.8.35.14.18.1.2.258	Integer	0
ibdot1sAdminMstID.259	.3.6.1.4.1.26138.8.35.14.18.1.2.259	Integer	0
ibdot1sAdminMstID.260	.3.6.1.4.1.26138.8.35.14.18.1.2.260	Integer	0
ibdot1sAdminMstID.261	.3.6.1.4.1.26138.8.35.14.18.1.2.261	Integer	0
ibdot1sAdminMstID.262	.3.6.1.4.1.26138.8.35.14.18.1.2.262	Integer	0
ibdot1sAdminMstID.263	.3.6.1.4.1.26138.8.35.14.18.1.2.263	Integer	0
ibdot1sAdminMstID.264	.3.6.1.4.1.26138.8.35.14.18.1.2.264	Integer	0
ibdot1sAdminMstID.265	.3.6.1.4.1.26138.8.35.14.18.1.2.265	Integer	0
ibdot1sAdminMstID.266	.3.6.1.4.1.26138.8.35.14.18.1.2.266	Integer	0
ibdot1sAdminMstID.267	.3.6.1.4.1.26138.8.35.14.18.1.2.267	Integer	0
ibdot1sAdminMstID.268	.3.6.1.4.1.26138.8.35.14.18.1.2.268	Integer	0
ibdot1sAdminMstID.269	.3.6.1.4.1.26138.8.35.14.18.1.2.269	Integer	0
ibdot1sAdminMstID.270	.3.6.1.4.1.26138.8.35.14.18.1.2.270	Integer	0
ibdot1sAdminMstID.271	.3.6.1.4.1.26138.8.35.14.18.1.2.271	Integer	0
ibdot1sAdminMstID.272	.3.6.1.4.1.26138.8.35.14.18.1.2.272	Integer	0
ibdot1sAdminMstID.273	.3.6.1.4.1.26138.8.35.14.18.1.2.273	Integer	0
ibdot1sAdminMstID.274	.3.6.1.4.1.26138.8.35.14.18.1.2.274	Integer	0
ibdot1sAdminMstID.275	.3.6.1.4.1.26138.8.35.14.18.1.2.275	Integer	0
ibdot1sAdminMstID.276	.3.6.1.4.1.26138.8.35.14.18.1.2.276	Integer	0
ibdot1sAdminMstID.277	.3.6.1.4.1.26138.8.35.14.18.1.2.277	Integer	0
ibdot1sAdminMstID.278	.3.6.1.4.1.26138.8.35.14.18.1.2.278	Integer	0
ibdot1sAdminMstID.279	.3.6.1.4.1.26138.8.35.14.18.1.2.279	Integer	0
ibdot1sAdminMstID.280	.3.6.1.4.1.26138.8.35.14.18.1.2.280	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.281	.3.6.1.4.1.26138.8.35.14.18.1.2.281	Integer	0
ibdot1sAdminMstID.282	.3.6.1.4.1.26138.8.35.14.18.1.2.282	Integer	0
ibdot1sAdminMstID.283	.3.6.1.4.1.26138.8.35.14.18.1.2.283	Integer	0
ibdot1sAdminMstID.284	.3.6.1.4.1.26138.8.35.14.18.1.2.284	Integer	0
ibdot1sAdminMstID.285	.3.6.1.4.1.26138.8.35.14.18.1.2.285	Integer	0
ibdot1sAdminMstID.286	.3.6.1.4.1.26138.8.35.14.18.1.2.286	Integer	0
ibdot1sAdminMstID.287	.3.6.1.4.1.26138.8.35.14.18.1.2.287	Integer	0
ibdot1sAdminMstID.288	.3.6.1.4.1.26138.8.35.14.18.1.2.288	Integer	0
ibdot1sAdminMstID.289	.3.6.1.4.1.26138.8.35.14.18.1.2.289	Integer	0
ibdot1sAdminMstID.290	.3.6.1.4.1.26138.8.35.14.18.1.2.290	Integer	0
ibdot1sAdminMstID.291	.3.6.1.4.1.26138.8.35.14.18.1.2.291	Integer	0
ibdot1sAdminMstID.292	.3.6.1.4.1.26138.8.35.14.18.1.2.292	Integer	0
ibdot1sAdminMstID.293	.3.6.1.4.1.26138.8.35.14.18.1.2.293	Integer	0
ibdot1sAdminMstID.294	.3.6.1.4.1.26138.8.35.14.18.1.2.294	Integer	0
ibdot1sAdminMstID.295	.3.6.1.4.1.26138.8.35.14.18.1.2.295	Integer	0
ibdot1sAdminMstID.296	.3.6.1.4.1.26138.8.35.14.18.1.2.296	Integer	0
ibdot1sAdminMstID.297	.3.6.1.4.1.26138.8.35.14.18.1.2.297	Integer	0
ibdot1sAdminMstID.298	.3.6.1.4.1.26138.8.35.14.18.1.2.298	Integer	0
ibdot1sAdminMstID.299	.3.6.1.4.1.26138.8.35.14.18.1.2.299	Integer	0
ibdot1sAdminMstID.300	.3.6.1.4.1.26138.8.35.14.18.1.2.300	Integer	0
ibdot1sAdminMstID.301	.3.6.1.4.1.26138.8.35.14.18.1.2.301	Integer	0
ibdot1sAdminMstID.302	.3.6.1.4.1.26138.8.35.14.18.1.2.302	Integer	0
ibdot1sAdminMstID.303	.3.6.1.4.1.26138.8.35.14.18.1.2.303	Integer	0
ibdot1sAdminMstID.304	.3.6.1.4.1.26138.8.35.14.18.1.2.304	Integer	0
ibdot1sAdminMstID.305	.3.6.1.4.1.26138.8.35.14.18.1.2.305	Integer	0
ibdot1sAdminMstID.306	.3.6.1.4.1.26138.8.35.14.18.1.2.306	Integer	0
ibdot1sAdminMstID.307	.3.6.1.4.1.26138.8.35.14.18.1.2.307	Integer	0
ibdot1sAdminMstID.308	.3.6.1.4.1.26138.8.35.14.18.1.2.308	Integer	0
ibdot1sAdminMstID.309	.3.6.1.4.1.26138.8.35.14.18.1.2.309	Integer	0
ibdot1sAdminMstID.310	.3.6.1.4.1.26138.8.35.14.18.1.2.310	Integer	0
ibdot1sAdminMstID.311	.3.6.1.4.1.26138.8.35.14.18.1.2.311	Integer	0
ibdot1sAdminMstID.312	.3.6.1.4.1.26138.8.35.14.18.1.2.312	Integer	0
ibdot1sAdminMstID.313	.3.6.1.4.1.26138.8.35.14.18.1.2.313	Integer	0
ibdot1sAdminMstID.314	.3.6.1.4.1.26138.8.35.14.18.1.2.314	Integer	0
ibdot1sAdminMstID.315	.3.6.1.4.1.26138.8.35.14.18.1.2.315	Integer	0
ibdot1sAdminMstID.316	.3.6.1.4.1.26138.8.35.14.18.1.2.316	Integer	0
ibdot1sAdminMstID.317	.3.6.1.4.1.26138.8.35.14.18.1.2.317	Integer	0
ibdot1sAdminMstID.318	.3.6.1.4.1.26138.8.35.14.18.1.2.318	Integer	0
ibdot1sAdminMstID.319	.3.6.1.4.1.26138.8.35.14.18.1.2.319	Integer	0
ibdot1sAdminMstID.320	.3.6.1.4.1.26138.8.35.14.18.1.2.320	Integer	0
ibdot1sAdminMstID.321	.3.6.1.4.1.26138.8.35.14.18.1.2.321	Integer	0
ibdot1sAdminMstID.322	.3.6.1.4.1.26138.8.35.14.18.1.2.322	Integer	0
ibdot1sAdminMstID.323	.3.6.1.4.1.26138.8.35.14.18.1.2.323	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.324	.3.6.1.4.1.26138.8.35.14.18.1.2.324	Integer	0
ibdot1sAdminMstID.325	.3.6.1.4.1.26138.8.35.14.18.1.2.325	Integer	0
ibdot1sAdminMstID.326	.3.6.1.4.1.26138.8.35.14.18.1.2.326	Integer	0
ibdot1sAdminMstID.327	.3.6.1.4.1.26138.8.35.14.18.1.2.327	Integer	0
ibdot1sAdminMstID.328	.3.6.1.4.1.26138.8.35.14.18.1.2.328	Integer	0
ibdot1sAdminMstID.329	.3.6.1.4.1.26138.8.35.14.18.1.2.329	Integer	0
ibdot1sAdminMstID.330	.3.6.1.4.1.26138.8.35.14.18.1.2.330	Integer	0
ibdot1sAdminMstID.331	.3.6.1.4.1.26138.8.35.14.18.1.2.331	Integer	0
ibdot1sAdminMstID.332	.3.6.1.4.1.26138.8.35.14.18.1.2.332	Integer	0
ibdot1sAdminMstID.333	.3.6.1.4.1.26138.8.35.14.18.1.2.333	Integer	0
ibdot1sAdminMstID.334	.3.6.1.4.1.26138.8.35.14.18.1.2.334	Integer	0
ibdot1sAdminMstID.335	.3.6.1.4.1.26138.8.35.14.18.1.2.335	Integer	0
ibdot1sAdminMstID.336	.3.6.1.4.1.26138.8.35.14.18.1.2.336	Integer	0
ibdot1sAdminMstID.337	.3.6.1.4.1.26138.8.35.14.18.1.2.337	Integer	0
ibdot1sAdminMstID.338	.3.6.1.4.1.26138.8.35.14.18.1.2.338	Integer	0
ibdot1sAdminMstID.339	.3.6.1.4.1.26138.8.35.14.18.1.2.339	Integer	0
ibdot1sAdminMstID.340	.3.6.1.4.1.26138.8.35.14.18.1.2.340	Integer	0
ibdot1sAdminMstID.341	.3.6.1.4.1.26138.8.35.14.18.1.2.341	Integer	0
ibdot1sAdminMstID.342	.3.6.1.4.1.26138.8.35.14.18.1.2.342	Integer	0
ibdot1sAdminMstID.343	.3.6.1.4.1.26138.8.35.14.18.1.2.343	Integer	0
ibdot1sAdminMstID.344	.3.6.1.4.1.26138.8.35.14.18.1.2.344	Integer	0
ibdot1sAdminMstID.345	.3.6.1.4.1.26138.8.35.14.18.1.2.345	Integer	0
ibdot1sAdminMstID.346	.3.6.1.4.1.26138.8.35.14.18.1.2.346	Integer	0
ibdot1sAdminMstID.347	.3.6.1.4.1.26138.8.35.14.18.1.2.347	Integer	0
ibdot1sAdminMstID.348	.3.6.1.4.1.26138.8.35.14.18.1.2.348	Integer	0
ibdot1sAdminMstID.349	.3.6.1.4.1.26138.8.35.14.18.1.2.349	Integer	0
ibdot1sAdminMstID.350	.3.6.1.4.1.26138.8.35.14.18.1.2.350	Integer	0
ibdot1sAdminMstID.351	.3.6.1.4.1.26138.8.35.14.18.1.2.351	Integer	0
ibdot1sAdminMstID.352	.3.6.1.4.1.26138.8.35.14.18.1.2.352	Integer	0
ibdot1sAdminMstID.353	.3.6.1.4.1.26138.8.35.14.18.1.2.353	Integer	0
ibdot1sAdminMstID.354	.3.6.1.4.1.26138.8.35.14.18.1.2.354	Integer	0
ibdot1sAdminMstID.355	.3.6.1.4.1.26138.8.35.14.18.1.2.355	Integer	0
ibdot1sAdminMstID.356	.3.6.1.4.1.26138.8.35.14.18.1.2.356	Integer	0
ibdot1sAdminMstID.357	.3.6.1.4.1.26138.8.35.14.18.1.2.357	Integer	0
ibdot1sAdminMstID.358	.3.6.1.4.1.26138.8.35.14.18.1.2.358	Integer	0
ibdot1sAdminMstID.359	.3.6.1.4.1.26138.8.35.14.18.1.2.359	Integer	0
ibdot1sAdminMstID.360	.3.6.1.4.1.26138.8.35.14.18.1.2.360	Integer	0
ibdot1sAdminMstID.361	.3.6.1.4.1.26138.8.35.14.18.1.2.361	Integer	0
ibdot1sAdminMstID.362	.3.6.1.4.1.26138.8.35.14.18.1.2.362	Integer	0
ibdot1sAdminMstID.363	.3.6.1.4.1.26138.8.35.14.18.1.2.363	Integer	0
ibdot1sAdminMstID.364	.3.6.1.4.1.26138.8.35.14.18.1.2.364	Integer	0
ibdot1sAdminMstID.365	.3.6.1.4.1.26138.8.35.14.18.1.2.365	Integer	0
ibdot1sAdminMstID.366	.3.6.1.4.1.26138.8.35.14.18.1.2.366	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.367	.3.6.1.4.1.26138.8.35.14.18.1.2.367	Integer	0
ibdot1sAdminMstID.368	.3.6.1.4.1.26138.8.35.14.18.1.2.368	Integer	0
ibdot1sAdminMstID.369	.3.6.1.4.1.26138.8.35.14.18.1.2.369	Integer	0
ibdot1sAdminMstID.370	.3.6.1.4.1.26138.8.35.14.18.1.2.370	Integer	0
ibdot1sAdminMstID.371	.3.6.1.4.1.26138.8.35.14.18.1.2.371	Integer	0
ibdot1sAdminMstID.372	.3.6.1.4.1.26138.8.35.14.18.1.2.372	Integer	0
ibdot1sAdminMstID.373	.3.6.1.4.1.26138.8.35.14.18.1.2.373	Integer	0
ibdot1sAdminMstID.374	.3.6.1.4.1.26138.8.35.14.18.1.2.374	Integer	0
ibdot1sAdminMstID.375	.3.6.1.4.1.26138.8.35.14.18.1.2.375	Integer	0
ibdot1sAdminMstID.376	.3.6.1.4.1.26138.8.35.14.18.1.2.376	Integer	0
ibdot1sAdminMstID.377	.3.6.1.4.1.26138.8.35.14.18.1.2.377	Integer	0
ibdot1sAdminMstID.378	.3.6.1.4.1.26138.8.35.14.18.1.2.378	Integer	0
ibdot1sAdminMstID.379	.3.6.1.4.1.26138.8.35.14.18.1.2.379	Integer	0
ibdot1sAdminMstID.380	.3.6.1.4.1.26138.8.35.14.18.1.2.380	Integer	0
ibdot1sAdminMstID.381	.3.6.1.4.1.26138.8.35.14.18.1.2.381	Integer	0
ibdot1sAdminMstID.382	.3.6.1.4.1.26138.8.35.14.18.1.2.382	Integer	0
ibdot1sAdminMstID.383	.3.6.1.4.1.26138.8.35.14.18.1.2.383	Integer	0
ibdot1sAdminMstID.384	.3.6.1.4.1.26138.8.35.14.18.1.2.384	Integer	0
ibdot1sAdminMstID.385	.3.6.1.4.1.26138.8.35.14.18.1.2.385	Integer	0
ibdot1sAdminMstID.386	.3.6.1.4.1.26138.8.35.14.18.1.2.386	Integer	0
ibdot1sAdminMstID.387	.3.6.1.4.1.26138.8.35.14.18.1.2.387	Integer	0
ibdot1sAdminMstID.388	.3.6.1.4.1.26138.8.35.14.18.1.2.388	Integer	0
ibdot1sAdminMstID.389	.3.6.1.4.1.26138.8.35.14.18.1.2.389	Integer	0
ibdot1sAdminMstID.390	.3.6.1.4.1.26138.8.35.14.18.1.2.390	Integer	0
ibdot1sAdminMstID.391	.3.6.1.4.1.26138.8.35.14.18.1.2.391	Integer	0
ibdot1sAdminMstID.392	.3.6.1.4.1.26138.8.35.14.18.1.2.392	Integer	0
ibdot1sAdminMstID.393	.3.6.1.4.1.26138.8.35.14.18.1.2.393	Integer	0
ibdot1sAdminMstID.394	.3.6.1.4.1.26138.8.35.14.18.1.2.394	Integer	0
ibdot1sAdminMstID.395	.3.6.1.4.1.26138.8.35.14.18.1.2.395	Integer	0
ibdot1sAdminMstID.396	.3.6.1.4.1.26138.8.35.14.18.1.2.396	Integer	0
ibdot1sAdminMstID.397	.3.6.1.4.1.26138.8.35.14.18.1.2.397	Integer	0
ibdot1sAdminMstID.398	.3.6.1.4.1.26138.8.35.14.18.1.2.398	Integer	0
ibdot1sAdminMstID.399	.3.6.1.4.1.26138.8.35.14.18.1.2.399	Integer	0
ibdot1sAdminMstID.400	.3.6.1.4.1.26138.8.35.14.18.1.2.400	Integer	0
ibdot1sAdminMstID.401	.3.6.1.4.1.26138.8.35.14.18.1.2.401	Integer	0
ibdot1sAdminMstID.402	.3.6.1.4.1.26138.8.35.14.18.1.2.402	Integer	0
ibdot1sAdminMstID.403	.3.6.1.4.1.26138.8.35.14.18.1.2.403	Integer	0
ibdot1sAdminMstID.404	.3.6.1.4.1.26138.8.35.14.18.1.2.404	Integer	0
ibdot1sAdminMstID.405	.3.6.1.4.1.26138.8.35.14.18.1.2.405	Integer	0
ibdot1sAdminMstID.406	.3.6.1.4.1.26138.8.35.14.18.1.2.406	Integer	0
ibdot1sAdminMstID.407	.3.6.1.4.1.26138.8.35.14.18.1.2.407	Integer	0
ibdot1sAdminMstID.408	.3.6.1.4.1.26138.8.35.14.18.1.2.408	Integer	0
ibdot1sAdminMstID.409	.3.6.1.4.1.26138.8.35.14.18.1.2.409	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.410	.3.6.1.4.1.26138.8.35.14.18.1.2.410	Integer	0
ibdot1sAdminMstID.411	.3.6.1.4.1.26138.8.35.14.18.1.2.411	Integer	0
ibdot1sAdminMstID.412	.3.6.1.4.1.26138.8.35.14.18.1.2.412	Integer	0
ibdot1sAdminMstID.413	.3.6.1.4.1.26138.8.35.14.18.1.2.413	Integer	0
ibdot1sAdminMstID.414	.3.6.1.4.1.26138.8.35.14.18.1.2.414	Integer	0
ibdot1sAdminMstID.415	.3.6.1.4.1.26138.8.35.14.18.1.2.415	Integer	0
ibdot1sAdminMstID.416	.3.6.1.4.1.26138.8.35.14.18.1.2.416	Integer	0
ibdot1sAdminMstID.417	.3.6.1.4.1.26138.8.35.14.18.1.2.417	Integer	0
ibdot1sAdminMstID.418	.3.6.1.4.1.26138.8.35.14.18.1.2.418	Integer	0
ibdot1sAdminMstID.419	.3.6.1.4.1.26138.8.35.14.18.1.2.419	Integer	0
ibdot1sAdminMstID.420	.3.6.1.4.1.26138.8.35.14.18.1.2.420	Integer	0
ibdot1sAdminMstID.421	.3.6.1.4.1.26138.8.35.14.18.1.2.421	Integer	0
ibdot1sAdminMstID.422	.3.6.1.4.1.26138.8.35.14.18.1.2.422	Integer	0
ibdot1sAdminMstID.423	.3.6.1.4.1.26138.8.35.14.18.1.2.423	Integer	0
ibdot1sAdminMstID.424	.3.6.1.4.1.26138.8.35.14.18.1.2.424	Integer	0
ibdot1sAdminMstID.425	.3.6.1.4.1.26138.8.35.14.18.1.2.425	Integer	0
ibdot1sAdminMstID.426	.3.6.1.4.1.26138.8.35.14.18.1.2.426	Integer	0
ibdot1sAdminMstID.427	.3.6.1.4.1.26138.8.35.14.18.1.2.427	Integer	0
ibdot1sAdminMstID.428	.3.6.1.4.1.26138.8.35.14.18.1.2.428	Integer	0
ibdot1sAdminMstID.429	.3.6.1.4.1.26138.8.35.14.18.1.2.429	Integer	0
ibdot1sAdminMstID.430	.3.6.1.4.1.26138.8.35.14.18.1.2.430	Integer	0
ibdot1sAdminMstID.431	.3.6.1.4.1.26138.8.35.14.18.1.2.431	Integer	0
ibdot1sAdminMstID.432	.3.6.1.4.1.26138.8.35.14.18.1.2.432	Integer	0
ibdot1sAdminMstID.433	.3.6.1.4.1.26138.8.35.14.18.1.2.433	Integer	0
ibdot1sAdminMstID.434	.3.6.1.4.1.26138.8.35.14.18.1.2.434	Integer	0
ibdot1sAdminMstID.435	.3.6.1.4.1.26138.8.35.14.18.1.2.435	Integer	0
ibdot1sAdminMstID.436	.3.6.1.4.1.26138.8.35.14.18.1.2.436	Integer	0
ibdot1sAdminMstID.437	.3.6.1.4.1.26138.8.35.14.18.1.2.437	Integer	0
ibdot1sAdminMstID.438	.3.6.1.4.1.26138.8.35.14.18.1.2.438	Integer	0
ibdot1sAdminMstID.439	.3.6.1.4.1.26138.8.35.14.18.1.2.439	Integer	0
ibdot1sAdminMstID.440	.3.6.1.4.1.26138.8.35.14.18.1.2.440	Integer	0
ibdot1sAdminMstID.441	.3.6.1.4.1.26138.8.35.14.18.1.2.441	Integer	0
ibdot1sAdminMstID.442	.3.6.1.4.1.26138.8.35.14.18.1.2.442	Integer	0
ibdot1sAdminMstID.443	.3.6.1.4.1.26138.8.35.14.18.1.2.443	Integer	0
ibdot1sAdminMstID.444	.3.6.1.4.1.26138.8.35.14.18.1.2.444	Integer	0
ibdot1sAdminMstID.445	.3.6.1.4.1.26138.8.35.14.18.1.2.445	Integer	0
ibdot1sAdminMstID.446	.3.6.1.4.1.26138.8.35.14.18.1.2.446	Integer	0
ibdot1sAdminMstID.447	.3.6.1.4.1.26138.8.35.14.18.1.2.447	Integer	0
ibdot1sAdminMstID.448	.3.6.1.4.1.26138.8.35.14.18.1.2.448	Integer	0
ibdot1sAdminMstID.449	.3.6.1.4.1.26138.8.35.14.18.1.2.449	Integer	0
ibdot1sAdminMstID.450	.3.6.1.4.1.26138.8.35.14.18.1.2.450	Integer	0
ibdot1sAdminMstID.451	.3.6.1.4.1.26138.8.35.14.18.1.2.451	Integer	0
ibdot1sAdminMstID.452	.3.6.1.4.1.26138.8.35.14.18.1.2.452	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.453	.3.6.1.4.1.26138.8.35.14.18.1.2.453	Integer	0
ibdot1sAdminMstID.454	.3.6.1.4.1.26138.8.35.14.18.1.2.454	Integer	0
ibdot1sAdminMstID.455	.3.6.1.4.1.26138.8.35.14.18.1.2.455	Integer	0
ibdot1sAdminMstID.456	.3.6.1.4.1.26138.8.35.14.18.1.2.456	Integer	0
ibdot1sAdminMstID.457	.3.6.1.4.1.26138.8.35.14.18.1.2.457	Integer	0
ibdot1sAdminMstID.458	.3.6.1.4.1.26138.8.35.14.18.1.2.458	Integer	0
ibdot1sAdminMstID.459	.3.6.1.4.1.26138.8.35.14.18.1.2.459	Integer	0
ibdot1sAdminMstID.460	.3.6.1.4.1.26138.8.35.14.18.1.2.460	Integer	0
ibdot1sAdminMstID.461	.3.6.1.4.1.26138.8.35.14.18.1.2.461	Integer	0
ibdot1sAdminMstID.462	.3.6.1.4.1.26138.8.35.14.18.1.2.462	Integer	0
ibdot1sAdminMstID.463	.3.6.1.4.1.26138.8.35.14.18.1.2.463	Integer	0
ibdot1sAdminMstID.464	.3.6.1.4.1.26138.8.35.14.18.1.2.464	Integer	0
ibdot1sAdminMstID.465	.3.6.1.4.1.26138.8.35.14.18.1.2.465	Integer	0
ibdot1sAdminMstID.466	.3.6.1.4.1.26138.8.35.14.18.1.2.466	Integer	0
ibdot1sAdminMstID.467	.3.6.1.4.1.26138.8.35.14.18.1.2.467	Integer	0
ibdot1sAdminMstID.468	.3.6.1.4.1.26138.8.35.14.18.1.2.468	Integer	0
ibdot1sAdminMstID.469	.3.6.1.4.1.26138.8.35.14.18.1.2.469	Integer	0
ibdot1sAdminMstID.470	.3.6.1.4.1.26138.8.35.14.18.1.2.470	Integer	0
ibdot1sAdminMstID.471	.3.6.1.4.1.26138.8.35.14.18.1.2.471	Integer	0
ibdot1sAdminMstID.472	.3.6.1.4.1.26138.8.35.14.18.1.2.472	Integer	0
ibdot1sAdminMstID.473	.3.6.1.4.1.26138.8.35.14.18.1.2.473	Integer	0
ibdot1sAdminMstID.474	.3.6.1.4.1.26138.8.35.14.18.1.2.474	Integer	0
ibdot1sAdminMstID.475	.3.6.1.4.1.26138.8.35.14.18.1.2.475	Integer	0
ibdot1sAdminMstID.476	.3.6.1.4.1.26138.8.35.14.18.1.2.476	Integer	0
ibdot1sAdminMstID.477	.3.6.1.4.1.26138.8.35.14.18.1.2.477	Integer	0
ibdot1sAdminMstID.478	.3.6.1.4.1.26138.8.35.14.18.1.2.478	Integer	0
ibdot1sAdminMstID.479	.3.6.1.4.1.26138.8.35.14.18.1.2.479	Integer	0
ibdot1sAdminMstID.480	.3.6.1.4.1.26138.8.35.14.18.1.2.480	Integer	0
ibdot1sAdminMstID.481	.3.6.1.4.1.26138.8.35.14.18.1.2.481	Integer	0
ibdot1sAdminMstID.482	.3.6.1.4.1.26138.8.35.14.18.1.2.482	Integer	0
ibdot1sAdminMstID.483	.3.6.1.4.1.26138.8.35.14.18.1.2.483	Integer	0
ibdot1sAdminMstID.484	.3.6.1.4.1.26138.8.35.14.18.1.2.484	Integer	0
ibdot1sAdminMstID.485	.3.6.1.4.1.26138.8.35.14.18.1.2.485	Integer	0
ibdot1sAdminMstID.486	.3.6.1.4.1.26138.8.35.14.18.1.2.486	Integer	0
ibdot1sAdminMstID.487	.3.6.1.4.1.26138.8.35.14.18.1.2.487	Integer	0
ibdot1sAdminMstID.488	.3.6.1.4.1.26138.8.35.14.18.1.2.488	Integer	0
ibdot1sAdminMstID.489	.3.6.1.4.1.26138.8.35.14.18.1.2.489	Integer	0
ibdot1sAdminMstID.490	.3.6.1.4.1.26138.8.35.14.18.1.2.490	Integer	0
ibdot1sAdminMstID.491	.3.6.1.4.1.26138.8.35.14.18.1.2.491	Integer	0
ibdot1sAdminMstID.492	.3.6.1.4.1.26138.8.35.14.18.1.2.492	Integer	0
ibdot1sAdminMstID.493	.3.6.1.4.1.26138.8.35.14.18.1.2.493	Integer	0
ibdot1sAdminMstID.494	.3.6.1.4.1.26138.8.35.14.18.1.2.494	Integer	0
ibdot1sAdminMstID.495	.3.6.1.4.1.26138.8.35.14.18.1.2.495	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.496	.3.6.1.4.1.26138.8.35.14.18.1.2.496	Integer	0
ibdot1sAdminMstID.497	.3.6.1.4.1.26138.8.35.14.18.1.2.497	Integer	0
ibdot1sAdminMstID.498	.3.6.1.4.1.26138.8.35.14.18.1.2.498	Integer	0
ibdot1sAdminMstID.499	.3.6.1.4.1.26138.8.35.14.18.1.2.499	Integer	0
ibdot1sAdminMstID.500	.3.6.1.4.1.26138.8.35.14.18.1.2.500	Integer	0
ibdot1sAdminMstID.501	.3.6.1.4.1.26138.8.35.14.18.1.2.501	Integer	0
ibdot1sAdminMstID.502	.3.6.1.4.1.26138.8.35.14.18.1.2.502	Integer	0
ibdot1sAdminMstID.503	.3.6.1.4.1.26138.8.35.14.18.1.2.503	Integer	0
ibdot1sAdminMstID.504	.3.6.1.4.1.26138.8.35.14.18.1.2.504	Integer	0
ibdot1sAdminMstID.505	.3.6.1.4.1.26138.8.35.14.18.1.2.505	Integer	0
ibdot1sAdminMstID.506	.3.6.1.4.1.26138.8.35.14.18.1.2.506	Integer	0
ibdot1sAdminMstID.507	.3.6.1.4.1.26138.8.35.14.18.1.2.507	Integer	0
ibdot1sAdminMstID.508	.3.6.1.4.1.26138.8.35.14.18.1.2.508	Integer	0
ibdot1sAdminMstID.509	.3.6.1.4.1.26138.8.35.14.18.1.2.509	Integer	0
ibdot1sAdminMstID.510	.3.6.1.4.1.26138.8.35.14.18.1.2.510	Integer	0
ibdot1sAdminMstID.511	.3.6.1.4.1.26138.8.35.14.18.1.2.511	Integer	0
ibdot1sAdminMstID.512	.3.6.1.4.1.26138.8.35.14.18.1.2.512	Integer	0
ibdot1sAdminMstID.513	.3.6.1.4.1.26138.8.35.14.18.1.2.513	Integer	0
ibdot1sAdminMstID.514	.3.6.1.4.1.26138.8.35.14.18.1.2.514	Integer	0
ibdot1sAdminMstID.515	.3.6.1.4.1.26138.8.35.14.18.1.2.515	Integer	0
ibdot1sAdminMstID.516	.3.6.1.4.1.26138.8.35.14.18.1.2.516	Integer	0
ibdot1sAdminMstID.517	.3.6.1.4.1.26138.8.35.14.18.1.2.517	Integer	0
ibdot1sAdminMstID.518	.3.6.1.4.1.26138.8.35.14.18.1.2.518	Integer	0
ibdot1sAdminMstID.519	.3.6.1.4.1.26138.8.35.14.18.1.2.519	Integer	0
ibdot1sAdminMstID.520	.3.6.1.4.1.26138.8.35.14.18.1.2.520	Integer	0
ibdot1sAdminMstID.521	.3.6.1.4.1.26138.8.35.14.18.1.2.521	Integer	0
ibdot1sAdminMstID.522	.3.6.1.4.1.26138.8.35.14.18.1.2.522	Integer	0
ibdot1sAdminMstID.523	.3.6.1.4.1.26138.8.35.14.18.1.2.523	Integer	0
ibdot1sAdminMstID.524	.3.6.1.4.1.26138.8.35.14.18.1.2.524	Integer	0
ibdot1sAdminMstID.525	.3.6.1.4.1.26138.8.35.14.18.1.2.525	Integer	0
ibdot1sAdminMstID.526	.3.6.1.4.1.26138.8.35.14.18.1.2.526	Integer	0
ibdot1sAdminMstID.527	.3.6.1.4.1.26138.8.35.14.18.1.2.527	Integer	0
ibdot1sAdminMstID.528	.3.6.1.4.1.26138.8.35.14.18.1.2.528	Integer	0
ibdot1sAdminMstID.529	.3.6.1.4.1.26138.8.35.14.18.1.2.529	Integer	0
ibdot1sAdminMstID.530	.3.6.1.4.1.26138.8.35.14.18.1.2.530	Integer	0
ibdot1sAdminMstID.531	.3.6.1.4.1.26138.8.35.14.18.1.2.531	Integer	0
ibdot1sAdminMstID.532	.3.6.1.4.1.26138.8.35.14.18.1.2.532	Integer	0
ibdot1sAdminMstID.533	.3.6.1.4.1.26138.8.35.14.18.1.2.533	Integer	0
ibdot1sAdminMstID.534	.3.6.1.4.1.26138.8.35.14.18.1.2.534	Integer	0
ibdot1sAdminMstID.535	.3.6.1.4.1.26138.8.35.14.18.1.2.535	Integer	0
ibdot1sAdminMstID.536	.3.6.1.4.1.26138.8.35.14.18.1.2.536	Integer	0
ibdot1sAdminMstID.537	.3.6.1.4.1.26138.8.35.14.18.1.2.537	Integer	0
ibdot1sAdminMstID.538	.3.6.1.4.1.26138.8.35.14.18.1.2.538	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.539	.3.6.1.4.1.26138.8.35.14.18.1.2.539	Integer	0
ibdot1sAdminMstID.540	.3.6.1.4.1.26138.8.35.14.18.1.2.540	Integer	0
ibdot1sAdminMstID.541	.3.6.1.4.1.26138.8.35.14.18.1.2.541	Integer	0
ibdot1sAdminMstID.542	.3.6.1.4.1.26138.8.35.14.18.1.2.542	Integer	0
ibdot1sAdminMstID.543	.3.6.1.4.1.26138.8.35.14.18.1.2.543	Integer	0
ibdot1sAdminMstID.544	.3.6.1.4.1.26138.8.35.14.18.1.2.544	Integer	0
ibdot1sAdminMstID.545	.3.6.1.4.1.26138.8.35.14.18.1.2.545	Integer	0
ibdot1sAdminMstID.546	.3.6.1.4.1.26138.8.35.14.18.1.2.546	Integer	0
ibdot1sAdminMstID.547	.3.6.1.4.1.26138.8.35.14.18.1.2.547	Integer	0
ibdot1sAdminMstID.548	.3.6.1.4.1.26138.8.35.14.18.1.2.548	Integer	0
ibdot1sAdminMstID.549	.3.6.1.4.1.26138.8.35.14.18.1.2.549	Integer	0
ibdot1sAdminMstID.550	.3.6.1.4.1.26138.8.35.14.18.1.2.550	Integer	0
ibdot1sAdminMstID.551	.3.6.1.4.1.26138.8.35.14.18.1.2.551	Integer	0
ibdot1sAdminMstID.552	.3.6.1.4.1.26138.8.35.14.18.1.2.552	Integer	0
ibdot1sAdminMstID.553	.3.6.1.4.1.26138.8.35.14.18.1.2.553	Integer	0
ibdot1sAdminMstID.554	.3.6.1.4.1.26138.8.35.14.18.1.2.554	Integer	0
ibdot1sAdminMstID.555	.3.6.1.4.1.26138.8.35.14.18.1.2.555	Integer	0
ibdot1sAdminMstID.556	.3.6.1.4.1.26138.8.35.14.18.1.2.556	Integer	0
ibdot1sAdminMstID.557	.3.6.1.4.1.26138.8.35.14.18.1.2.557	Integer	0
ibdot1sAdminMstID.558	.3.6.1.4.1.26138.8.35.14.18.1.2.558	Integer	0
ibdot1sAdminMstID.559	.3.6.1.4.1.26138.8.35.14.18.1.2.559	Integer	0
ibdot1sAdminMstID.560	.3.6.1.4.1.26138.8.35.14.18.1.2.560	Integer	0
ibdot1sAdminMstID.561	.3.6.1.4.1.26138.8.35.14.18.1.2.561	Integer	0
ibdot1sAdminMstID.562	.3.6.1.4.1.26138.8.35.14.18.1.2.562	Integer	0
ibdot1sAdminMstID.563	.3.6.1.4.1.26138.8.35.14.18.1.2.563	Integer	0
ibdot1sAdminMstID.564	.3.6.1.4.1.26138.8.35.14.18.1.2.564	Integer	0
ibdot1sAdminMstID.565	.3.6.1.4.1.26138.8.35.14.18.1.2.565	Integer	0
ibdot1sAdminMstID.566	.3.6.1.4.1.26138.8.35.14.18.1.2.566	Integer	0
ibdot1sAdminMstID.567	.3.6.1.4.1.26138.8.35.14.18.1.2.567	Integer	0
ibdot1sAdminMstID.568	.3.6.1.4.1.26138.8.35.14.18.1.2.568	Integer	0
ibdot1sAdminMstID.569	.3.6.1.4.1.26138.8.35.14.18.1.2.569	Integer	0
ibdot1sAdminMstID.570	.3.6.1.4.1.26138.8.35.14.18.1.2.570	Integer	0
ibdot1sAdminMstID.571	.3.6.1.4.1.26138.8.35.14.18.1.2.571	Integer	0
ibdot1sAdminMstID.572	.3.6.1.4.1.26138.8.35.14.18.1.2.572	Integer	0
ibdot1sAdminMstID.573	.3.6.1.4.1.26138.8.35.14.18.1.2.573	Integer	0
ibdot1sAdminMstID.574	.3.6.1.4.1.26138.8.35.14.18.1.2.574	Integer	0
ibdot1sAdminMstID.575	.3.6.1.4.1.26138.8.35.14.18.1.2.575	Integer	0
ibdot1sAdminMstID.576	.3.6.1.4.1.26138.8.35.14.18.1.2.576	Integer	0
ibdot1sAdminMstID.577	.3.6.1.4.1.26138.8.35.14.18.1.2.577	Integer	0
ibdot1sAdminMstID.578	.3.6.1.4.1.26138.8.35.14.18.1.2.578	Integer	0
ibdot1sAdminMstID.579	.3.6.1.4.1.26138.8.35.14.18.1.2.579	Integer	0
ibdot1sAdminMstID.580	.3.6.1.4.1.26138.8.35.14.18.1.2.580	Integer	0
ibdot1sAdminMstID.581	.3.6.1.4.1.26138.8.35.14.18.1.2.581	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.582	.3.6.1.4.1.26138.8.35.14.18.1.2.582	Integer	0
ibdot1sAdminMstID.583	.3.6.1.4.1.26138.8.35.14.18.1.2.583	Integer	0
ibdot1sAdminMstID.584	.3.6.1.4.1.26138.8.35.14.18.1.2.584	Integer	0
ibdot1sAdminMstID.585	.3.6.1.4.1.26138.8.35.14.18.1.2.585	Integer	0
ibdot1sAdminMstID.586	.3.6.1.4.1.26138.8.35.14.18.1.2.586	Integer	0
ibdot1sAdminMstID.587	.3.6.1.4.1.26138.8.35.14.18.1.2.587	Integer	0
ibdot1sAdminMstID.588	.3.6.1.4.1.26138.8.35.14.18.1.2.588	Integer	0
ibdot1sAdminMstID.589	.3.6.1.4.1.26138.8.35.14.18.1.2.589	Integer	0
ibdot1sAdminMstID.590	.3.6.1.4.1.26138.8.35.14.18.1.2.590	Integer	0
ibdot1sAdminMstID.591	.3.6.1.4.1.26138.8.35.14.18.1.2.591	Integer	0
ibdot1sAdminMstID.592	.3.6.1.4.1.26138.8.35.14.18.1.2.592	Integer	0
ibdot1sAdminMstID.593	.3.6.1.4.1.26138.8.35.14.18.1.2.593	Integer	0
ibdot1sAdminMstID.594	.3.6.1.4.1.26138.8.35.14.18.1.2.594	Integer	0
ibdot1sAdminMstID.595	.3.6.1.4.1.26138.8.35.14.18.1.2.595	Integer	0
ibdot1sAdminMstID.596	.3.6.1.4.1.26138.8.35.14.18.1.2.596	Integer	0
ibdot1sAdminMstID.597	.3.6.1.4.1.26138.8.35.14.18.1.2.597	Integer	0
ibdot1sAdminMstID.598	.3.6.1.4.1.26138.8.35.14.18.1.2.598	Integer	0
ibdot1sAdminMstID.599	.3.6.1.4.1.26138.8.35.14.18.1.2.599	Integer	0
ibdot1sAdminMstID.600	.3.6.1.4.1.26138.8.35.14.18.1.2.600	Integer	0
ibdot1sAdminMstID.601	.3.6.1.4.1.26138.8.35.14.18.1.2.601	Integer	0
ibdot1sAdminMstID.602	.3.6.1.4.1.26138.8.35.14.18.1.2.602	Integer	0
ibdot1sAdminMstID.603	.3.6.1.4.1.26138.8.35.14.18.1.2.603	Integer	0
ibdot1sAdminMstID.604	.3.6.1.4.1.26138.8.35.14.18.1.2.604	Integer	0
ibdot1sAdminMstID.605	.3.6.1.4.1.26138.8.35.14.18.1.2.605	Integer	0
ibdot1sAdminMstID.606	.3.6.1.4.1.26138.8.35.14.18.1.2.606	Integer	0
ibdot1sAdminMstID.607	.3.6.1.4.1.26138.8.35.14.18.1.2.607	Integer	0
ibdot1sAdminMstID.608	.3.6.1.4.1.26138.8.35.14.18.1.2.608	Integer	0
ibdot1sAdminMstID.609	.3.6.1.4.1.26138.8.35.14.18.1.2.609	Integer	0
ibdot1sAdminMstID.610	.3.6.1.4.1.26138.8.35.14.18.1.2.610	Integer	0
ibdot1sAdminMstID.611	.3.6.1.4.1.26138.8.35.14.18.1.2.611	Integer	0
ibdot1sAdminMstID.612	.3.6.1.4.1.26138.8.35.14.18.1.2.612	Integer	0
ibdot1sAdminMstID.613	.3.6.1.4.1.26138.8.35.14.18.1.2.613	Integer	0
ibdot1sAdminMstID.614	.3.6.1.4.1.26138.8.35.14.18.1.2.614	Integer	0
ibdot1sAdminMstID.615	.3.6.1.4.1.26138.8.35.14.18.1.2.615	Integer	0
ibdot1sAdminMstID.616	.3.6.1.4.1.26138.8.35.14.18.1.2.616	Integer	0
ibdot1sAdminMstID.617	.3.6.1.4.1.26138.8.35.14.18.1.2.617	Integer	0
ibdot1sAdminMstID.618	.3.6.1.4.1.26138.8.35.14.18.1.2.618	Integer	0
ibdot1sAdminMstID.619	.3.6.1.4.1.26138.8.35.14.18.1.2.619	Integer	0
ibdot1sAdminMstID.620	.3.6.1.4.1.26138.8.35.14.18.1.2.620	Integer	0
ibdot1sAdminMstID.621	.3.6.1.4.1.26138.8.35.14.18.1.2.621	Integer	0
ibdot1sAdminMstID.622	.3.6.1.4.1.26138.8.35.14.18.1.2.622	Integer	0
ibdot1sAdminMstID.623	.3.6.1.4.1.26138.8.35.14.18.1.2.623	Integer	0
ibdot1sAdminMstID.624	.3.6.1.4.1.26138.8.35.14.18.1.2.624	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.625	.3.6.1.4.1.26138.8.35.14.18.1.2.625	Integer	0
ibdot1sAdminMstID.626	.3.6.1.4.1.26138.8.35.14.18.1.2.626	Integer	0
ibdot1sAdminMstID.627	.3.6.1.4.1.26138.8.35.14.18.1.2.627	Integer	0
ibdot1sAdminMstID.628	.3.6.1.4.1.26138.8.35.14.18.1.2.628	Integer	0
ibdot1sAdminMstID.629	.3.6.1.4.1.26138.8.35.14.18.1.2.629	Integer	0
ibdot1sAdminMstID.630	.3.6.1.4.1.26138.8.35.14.18.1.2.630	Integer	0
ibdot1sAdminMstID.631	.3.6.1.4.1.26138.8.35.14.18.1.2.631	Integer	0
ibdot1sAdminMstID.632	.3.6.1.4.1.26138.8.35.14.18.1.2.632	Integer	0
ibdot1sAdminMstID.633	.3.6.1.4.1.26138.8.35.14.18.1.2.633	Integer	0
ibdot1sAdminMstID.634	.3.6.1.4.1.26138.8.35.14.18.1.2.634	Integer	0
ibdot1sAdminMstID.635	.3.6.1.4.1.26138.8.35.14.18.1.2.635	Integer	0
ibdot1sAdminMstID.636	.3.6.1.4.1.26138.8.35.14.18.1.2.636	Integer	0
ibdot1sAdminMstID.637	.3.6.1.4.1.26138.8.35.14.18.1.2.637	Integer	0
ibdot1sAdminMstID.638	.3.6.1.4.1.26138.8.35.14.18.1.2.638	Integer	0
ibdot1sAdminMstID.639	.3.6.1.4.1.26138.8.35.14.18.1.2.639	Integer	0
ibdot1sAdminMstID.640	.3.6.1.4.1.26138.8.35.14.18.1.2.640	Integer	0
ibdot1sAdminMstID.641	.3.6.1.4.1.26138.8.35.14.18.1.2.641	Integer	0
ibdot1sAdminMstID.642	.3.6.1.4.1.26138.8.35.14.18.1.2.642	Integer	0
ibdot1sAdminMstID.643	.3.6.1.4.1.26138.8.35.14.18.1.2.643	Integer	0
ibdot1sAdminMstID.644	.3.6.1.4.1.26138.8.35.14.18.1.2.644	Integer	0
ibdot1sAdminMstID.645	.3.6.1.4.1.26138.8.35.14.18.1.2.645	Integer	0
ibdot1sAdminMstID.646	.3.6.1.4.1.26138.8.35.14.18.1.2.646	Integer	0
ibdot1sAdminMstID.647	.3.6.1.4.1.26138.8.35.14.18.1.2.647	Integer	0
ibdot1sAdminMstID.648	.3.6.1.4.1.26138.8.35.14.18.1.2.648	Integer	0
ibdot1sAdminMstID.649	.3.6.1.4.1.26138.8.35.14.18.1.2.649	Integer	0
ibdot1sAdminMstID.650	.3.6.1.4.1.26138.8.35.14.18.1.2.650	Integer	0
ibdot1sAdminMstID.651	.3.6.1.4.1.26138.8.35.14.18.1.2.651	Integer	0
ibdot1sAdminMstID.652	.3.6.1.4.1.26138.8.35.14.18.1.2.652	Integer	0
ibdot1sAdminMstID.653	.3.6.1.4.1.26138.8.35.14.18.1.2.653	Integer	0
ibdot1sAdminMstID.654	.3.6.1.4.1.26138.8.35.14.18.1.2.654	Integer	0
ibdot1sAdminMstID.655	.3.6.1.4.1.26138.8.35.14.18.1.2.655	Integer	0
ibdot1sAdminMstID.656	.3.6.1.4.1.26138.8.35.14.18.1.2.656	Integer	0
ibdot1sAdminMstID.657	.3.6.1.4.1.26138.8.35.14.18.1.2.657	Integer	0
ibdot1sAdminMstID.658	.3.6.1.4.1.26138.8.35.14.18.1.2.658	Integer	0
ibdot1sAdminMstID.659	.3.6.1.4.1.26138.8.35.14.18.1.2.659	Integer	0
ibdot1sAdminMstID.660	.3.6.1.4.1.26138.8.35.14.18.1.2.660	Integer	0
ibdot1sAdminMstID.661	.3.6.1.4.1.26138.8.35.14.18.1.2.661	Integer	0
ibdot1sAdminMstID.662	.3.6.1.4.1.26138.8.35.14.18.1.2.662	Integer	0
ibdot1sAdminMstID.663	.3.6.1.4.1.26138.8.35.14.18.1.2.663	Integer	0
ibdot1sAdminMstID.664	.3.6.1.4.1.26138.8.35.14.18.1.2.664	Integer	0
ibdot1sAdminMstID.665	.3.6.1.4.1.26138.8.35.14.18.1.2.665	Integer	0
ibdot1sAdminMstID.666	.3.6.1.4.1.26138.8.35.14.18.1.2.666	Integer	0
ibdot1sAdminMstID.667	.3.6.1.4.1.26138.8.35.14.18.1.2.667	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.668	.3.6.1.4.1.26138.8.35.14.18.1.2.668	Integer	0
ibdot1sAdminMstID.669	.3.6.1.4.1.26138.8.35.14.18.1.2.669	Integer	0
ibdot1sAdminMstID.670	.3.6.1.4.1.26138.8.35.14.18.1.2.670	Integer	0
ibdot1sAdminMstID.671	.3.6.1.4.1.26138.8.35.14.18.1.2.671	Integer	0
ibdot1sAdminMstID.672	.3.6.1.4.1.26138.8.35.14.18.1.2.672	Integer	0
ibdot1sAdminMstID.673	.3.6.1.4.1.26138.8.35.14.18.1.2.673	Integer	0
ibdot1sAdminMstID.674	.3.6.1.4.1.26138.8.35.14.18.1.2.674	Integer	0
ibdot1sAdminMstID.675	.3.6.1.4.1.26138.8.35.14.18.1.2.675	Integer	0
ibdot1sAdminMstID.676	.3.6.1.4.1.26138.8.35.14.18.1.2.676	Integer	0
ibdot1sAdminMstID.677	.3.6.1.4.1.26138.8.35.14.18.1.2.677	Integer	0
ibdot1sAdminMstID.678	.3.6.1.4.1.26138.8.35.14.18.1.2.678	Integer	0
ibdot1sAdminMstID.679	.3.6.1.4.1.26138.8.35.14.18.1.2.679	Integer	0
ibdot1sAdminMstID.680	.3.6.1.4.1.26138.8.35.14.18.1.2.680	Integer	0
ibdot1sAdminMstID.681	.3.6.1.4.1.26138.8.35.14.18.1.2.681	Integer	0
ibdot1sAdminMstID.682	.3.6.1.4.1.26138.8.35.14.18.1.2.682	Integer	0
ibdot1sAdminMstID.683	.3.6.1.4.1.26138.8.35.14.18.1.2.683	Integer	0
ibdot1sAdminMstID.684	.3.6.1.4.1.26138.8.35.14.18.1.2.684	Integer	0
ibdot1sAdminMstID.685	.3.6.1.4.1.26138.8.35.14.18.1.2.685	Integer	0
ibdot1sAdminMstID.686	.3.6.1.4.1.26138.8.35.14.18.1.2.686	Integer	0
ibdot1sAdminMstID.687	.3.6.1.4.1.26138.8.35.14.18.1.2.687	Integer	0
ibdot1sAdminMstID.688	.3.6.1.4.1.26138.8.35.14.18.1.2.688	Integer	0
ibdot1sAdminMstID.689	.3.6.1.4.1.26138.8.35.14.18.1.2.689	Integer	0
ibdot1sAdminMstID.690	.3.6.1.4.1.26138.8.35.14.18.1.2.690	Integer	0
ibdot1sAdminMstID.691	.3.6.1.4.1.26138.8.35.14.18.1.2.691	Integer	0
ibdot1sAdminMstID.692	.3.6.1.4.1.26138.8.35.14.18.1.2.692	Integer	0
ibdot1sAdminMstID.693	.3.6.1.4.1.26138.8.35.14.18.1.2.693	Integer	0
ibdot1sAdminMstID.694	.3.6.1.4.1.26138.8.35.14.18.1.2.694	Integer	0
ibdot1sAdminMstID.695	.3.6.1.4.1.26138.8.35.14.18.1.2.695	Integer	0
ibdot1sAdminMstID.696	.3.6.1.4.1.26138.8.35.14.18.1.2.696	Integer	0
ibdot1sAdminMstID.697	.3.6.1.4.1.26138.8.35.14.18.1.2.697	Integer	0
ibdot1sAdminMstID.698	.3.6.1.4.1.26138.8.35.14.18.1.2.698	Integer	0
ibdot1sAdminMstID.699	.3.6.1.4.1.26138.8.35.14.18.1.2.699	Integer	0
ibdot1sAdminMstID.700	.3.6.1.4.1.26138.8.35.14.18.1.2.700	Integer	0
ibdot1sAdminMstID.701	.3.6.1.4.1.26138.8.35.14.18.1.2.701	Integer	0
ibdot1sAdminMstID.702	.3.6.1.4.1.26138.8.35.14.18.1.2.702	Integer	0
ibdot1sAdminMstID.703	.3.6.1.4.1.26138.8.35.14.18.1.2.703	Integer	0
ibdot1sAdminMstID.704	.3.6.1.4.1.26138.8.35.14.18.1.2.704	Integer	0
ibdot1sAdminMstID.705	.3.6.1.4.1.26138.8.35.14.18.1.2.705	Integer	0
ibdot1sAdminMstID.706	.3.6.1.4.1.26138.8.35.14.18.1.2.706	Integer	0
ibdot1sAdminMstID.707	.3.6.1.4.1.26138.8.35.14.18.1.2.707	Integer	0
ibdot1sAdminMstID.708	.3.6.1.4.1.26138.8.35.14.18.1.2.708	Integer	0
ibdot1sAdminMstID.709	.3.6.1.4.1.26138.8.35.14.18.1.2.709	Integer	0
ibdot1sAdminMstID.710	.3.6.1.4.1.26138.8.35.14.18.1.2.710	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.711	.3.6.1.4.1.26138.8.35.14.18.1.2.711	Integer	0
ibdot1sAdminMstID.712	.3.6.1.4.1.26138.8.35.14.18.1.2.712	Integer	0
ibdot1sAdminMstID.713	.3.6.1.4.1.26138.8.35.14.18.1.2.713	Integer	0
ibdot1sAdminMstID.714	.3.6.1.4.1.26138.8.35.14.18.1.2.714	Integer	0
ibdot1sAdminMstID.715	.3.6.1.4.1.26138.8.35.14.18.1.2.715	Integer	0
ibdot1sAdminMstID.716	.3.6.1.4.1.26138.8.35.14.18.1.2.716	Integer	0
ibdot1sAdminMstID.717	.3.6.1.4.1.26138.8.35.14.18.1.2.717	Integer	0
ibdot1sAdminMstID.718	.3.6.1.4.1.26138.8.35.14.18.1.2.718	Integer	0
ibdot1sAdminMstID.719	.3.6.1.4.1.26138.8.35.14.18.1.2.719	Integer	0
ibdot1sAdminMstID.720	.3.6.1.4.1.26138.8.35.14.18.1.2.720	Integer	0
ibdot1sAdminMstID.721	.3.6.1.4.1.26138.8.35.14.18.1.2.721	Integer	0
ibdot1sAdminMstID.722	.3.6.1.4.1.26138.8.35.14.18.1.2.722	Integer	0
ibdot1sAdminMstID.723	.3.6.1.4.1.26138.8.35.14.18.1.2.723	Integer	0
ibdot1sAdminMstID.724	.3.6.1.4.1.26138.8.35.14.18.1.2.724	Integer	0
ibdot1sAdminMstID.725	.3.6.1.4.1.26138.8.35.14.18.1.2.725	Integer	0
ibdot1sAdminMstID.726	.3.6.1.4.1.26138.8.35.14.18.1.2.726	Integer	0
ibdot1sAdminMstID.727	.3.6.1.4.1.26138.8.35.14.18.1.2.727	Integer	0
ibdot1sAdminMstID.728	.3.6.1.4.1.26138.8.35.14.18.1.2.728	Integer	0
ibdot1sAdminMstID.729	.3.6.1.4.1.26138.8.35.14.18.1.2.729	Integer	0
ibdot1sAdminMstID.730	.3.6.1.4.1.26138.8.35.14.18.1.2.730	Integer	0
ibdot1sAdminMstID.731	.3.6.1.4.1.26138.8.35.14.18.1.2.731	Integer	0
ibdot1sAdminMstID.732	.3.6.1.4.1.26138.8.35.14.18.1.2.732	Integer	0
ibdot1sAdminMstID.733	.3.6.1.4.1.26138.8.35.14.18.1.2.733	Integer	0
ibdot1sAdminMstID.734	.3.6.1.4.1.26138.8.35.14.18.1.2.734	Integer	0
ibdot1sAdminMstID.735	.3.6.1.4.1.26138.8.35.14.18.1.2.735	Integer	0
ibdot1sAdminMstID.736	.3.6.1.4.1.26138.8.35.14.18.1.2.736	Integer	0
ibdot1sAdminMstID.737	.3.6.1.4.1.26138.8.35.14.18.1.2.737	Integer	0
ibdot1sAdminMstID.738	.3.6.1.4.1.26138.8.35.14.18.1.2.738	Integer	0
ibdot1sAdminMstID.739	.3.6.1.4.1.26138.8.35.14.18.1.2.739	Integer	0
ibdot1sAdminMstID.740	.3.6.1.4.1.26138.8.35.14.18.1.2.740	Integer	0
ibdot1sAdminMstID.741	.3.6.1.4.1.26138.8.35.14.18.1.2.741	Integer	0
ibdot1sAdminMstID.742	.3.6.1.4.1.26138.8.35.14.18.1.2.742	Integer	0
ibdot1sAdminMstID.743	.3.6.1.4.1.26138.8.35.14.18.1.2.743	Integer	0
ibdot1sAdminMstID.744	.3.6.1.4.1.26138.8.35.14.18.1.2.744	Integer	0
ibdot1sAdminMstID.745	.3.6.1.4.1.26138.8.35.14.18.1.2.745	Integer	0
ibdot1sAdminMstID.746	.3.6.1.4.1.26138.8.35.14.18.1.2.746	Integer	0
ibdot1sAdminMstID.747	.3.6.1.4.1.26138.8.35.14.18.1.2.747	Integer	0
ibdot1sAdminMstID.748	.3.6.1.4.1.26138.8.35.14.18.1.2.748	Integer	0
ibdot1sAdminMstID.749	.3.6.1.4.1.26138.8.35.14.18.1.2.749	Integer	0
ibdot1sAdminMstID.750	.3.6.1.4.1.26138.8.35.14.18.1.2.750	Integer	0
ibdot1sAdminMstID.751	.3.6.1.4.1.26138.8.35.14.18.1.2.751	Integer	0
ibdot1sAdminMstID.752	.3.6.1.4.1.26138.8.35.14.18.1.2.752	Integer	0
ibdot1sAdminMstID.753	.3.6.1.4.1.26138.8.35.14.18.1.2.753	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.754	.3.6.1.4.1.26138.8.35.14.18.1.2.754	Integer	0
ibdot1sAdminMstID.755	.3.6.1.4.1.26138.8.35.14.18.1.2.755	Integer	0
ibdot1sAdminMstID.756	.3.6.1.4.1.26138.8.35.14.18.1.2.756	Integer	0
ibdot1sAdminMstID.757	.3.6.1.4.1.26138.8.35.14.18.1.2.757	Integer	0
ibdot1sAdminMstID.758	.3.6.1.4.1.26138.8.35.14.18.1.2.758	Integer	0
ibdot1sAdminMstID.759	.3.6.1.4.1.26138.8.35.14.18.1.2.759	Integer	0
ibdot1sAdminMstID.760	.3.6.1.4.1.26138.8.35.14.18.1.2.760	Integer	0
ibdot1sAdminMstID.761	.3.6.1.4.1.26138.8.35.14.18.1.2.761	Integer	0
ibdot1sAdminMstID.762	.3.6.1.4.1.26138.8.35.14.18.1.2.762	Integer	0
ibdot1sAdminMstID.763	.3.6.1.4.1.26138.8.35.14.18.1.2.763	Integer	0
ibdot1sAdminMstID.764	.3.6.1.4.1.26138.8.35.14.18.1.2.764	Integer	0
ibdot1sAdminMstID.765	.3.6.1.4.1.26138.8.35.14.18.1.2.765	Integer	0
ibdot1sAdminMstID.766	.3.6.1.4.1.26138.8.35.14.18.1.2.766	Integer	0
ibdot1sAdminMstID.767	.3.6.1.4.1.26138.8.35.14.18.1.2.767	Integer	0
ibdot1sAdminMstID.768	.3.6.1.4.1.26138.8.35.14.18.1.2.768	Integer	0
ibdot1sAdminMstID.769	.3.6.1.4.1.26138.8.35.14.18.1.2.769	Integer	0
ibdot1sAdminMstID.770	.3.6.1.4.1.26138.8.35.14.18.1.2.770	Integer	0
ibdot1sAdminMstID.771	.3.6.1.4.1.26138.8.35.14.18.1.2.771	Integer	0
ibdot1sAdminMstID.772	.3.6.1.4.1.26138.8.35.14.18.1.2.772	Integer	0
ibdot1sAdminMstID.773	.3.6.1.4.1.26138.8.35.14.18.1.2.773	Integer	0
ibdot1sAdminMstID.774	.3.6.1.4.1.26138.8.35.14.18.1.2.774	Integer	0
ibdot1sAdminMstID.775	.3.6.1.4.1.26138.8.35.14.18.1.2.775	Integer	0
ibdot1sAdminMstID.776	.3.6.1.4.1.26138.8.35.14.18.1.2.776	Integer	0
ibdot1sAdminMstID.777	.3.6.1.4.1.26138.8.35.14.18.1.2.777	Integer	0
ibdot1sAdminMstID.778	.3.6.1.4.1.26138.8.35.14.18.1.2.778	Integer	0
ibdot1sAdminMstID.779	.3.6.1.4.1.26138.8.35.14.18.1.2.779	Integer	0
ibdot1sAdminMstID.780	.3.6.1.4.1.26138.8.35.14.18.1.2.780	Integer	0
ibdot1sAdminMstID.781	.3.6.1.4.1.26138.8.35.14.18.1.2.781	Integer	0
ibdot1sAdminMstID.782	.3.6.1.4.1.26138.8.35.14.18.1.2.782	Integer	0
ibdot1sAdminMstID.783	.3.6.1.4.1.26138.8.35.14.18.1.2.783	Integer	0
ibdot1sAdminMstID.784	.3.6.1.4.1.26138.8.35.14.18.1.2.784	Integer	0
ibdot1sAdminMstID.785	.3.6.1.4.1.26138.8.35.14.18.1.2.785	Integer	0
ibdot1sAdminMstID.786	.3.6.1.4.1.26138.8.35.14.18.1.2.786	Integer	0
ibdot1sAdminMstID.787	.3.6.1.4.1.26138.8.35.14.18.1.2.787	Integer	0
ibdot1sAdminMstID.788	.3.6.1.4.1.26138.8.35.14.18.1.2.788	Integer	0
ibdot1sAdminMstID.789	.3.6.1.4.1.26138.8.35.14.18.1.2.789	Integer	0
ibdot1sAdminMstID.790	.3.6.1.4.1.26138.8.35.14.18.1.2.790	Integer	0
ibdot1sAdminMstID.791	.3.6.1.4.1.26138.8.35.14.18.1.2.791	Integer	0
ibdot1sAdminMstID.792	.3.6.1.4.1.26138.8.35.14.18.1.2.792	Integer	0
ibdot1sAdminMstID.793	.3.6.1.4.1.26138.8.35.14.18.1.2.793	Integer	0
ibdot1sAdminMstID.794	.3.6.1.4.1.26138.8.35.14.18.1.2.794	Integer	0
ibdot1sAdminMstID.795	.3.6.1.4.1.26138.8.35.14.18.1.2.795	Integer	0
ibdot1sAdminMstID.796	.3.6.1.4.1.26138.8.35.14.18.1.2.796	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.797	.3.6.1.4.1.26138.8.35.14.18.1.2.797	Integer	0
ibdot1sAdminMstID.798	.3.6.1.4.1.26138.8.35.14.18.1.2.798	Integer	0
ibdot1sAdminMstID.799	.3.6.1.4.1.26138.8.35.14.18.1.2.799	Integer	0
ibdot1sAdminMstID.800	.3.6.1.4.1.26138.8.35.14.18.1.2.800	Integer	0
ibdot1sAdminMstID.801	.3.6.1.4.1.26138.8.35.14.18.1.2.801	Integer	0
ibdot1sAdminMstID.802	.3.6.1.4.1.26138.8.35.14.18.1.2.802	Integer	0
ibdot1sAdminMstID.803	.3.6.1.4.1.26138.8.35.14.18.1.2.803	Integer	0
ibdot1sAdminMstID.804	.3.6.1.4.1.26138.8.35.14.18.1.2.804	Integer	0
ibdot1sAdminMstID.805	.3.6.1.4.1.26138.8.35.14.18.1.2.805	Integer	0
ibdot1sAdminMstID.806	.3.6.1.4.1.26138.8.35.14.18.1.2.806	Integer	0
ibdot1sAdminMstID.807	.3.6.1.4.1.26138.8.35.14.18.1.2.807	Integer	0
ibdot1sAdminMstID.808	.3.6.1.4.1.26138.8.35.14.18.1.2.808	Integer	0
ibdot1sAdminMstID.809	.3.6.1.4.1.26138.8.35.14.18.1.2.809	Integer	0
ibdot1sAdminMstID.810	.3.6.1.4.1.26138.8.35.14.18.1.2.810	Integer	0
ibdot1sAdminMstID.811	.3.6.1.4.1.26138.8.35.14.18.1.2.811	Integer	0
ibdot1sAdminMstID.812	.3.6.1.4.1.26138.8.35.14.18.1.2.812	Integer	0
ibdot1sAdminMstID.813	.3.6.1.4.1.26138.8.35.14.18.1.2.813	Integer	0
ibdot1sAdminMstID.814	.3.6.1.4.1.26138.8.35.14.18.1.2.814	Integer	0
ibdot1sAdminMstID.815	.3.6.1.4.1.26138.8.35.14.18.1.2.815	Integer	0
ibdot1sAdminMstID.816	.3.6.1.4.1.26138.8.35.14.18.1.2.816	Integer	0
ibdot1sAdminMstID.817	.3.6.1.4.1.26138.8.35.14.18.1.2.817	Integer	0
ibdot1sAdminMstID.818	.3.6.1.4.1.26138.8.35.14.18.1.2.818	Integer	0
ibdot1sAdminMstID.819	.3.6.1.4.1.26138.8.35.14.18.1.2.819	Integer	0
ibdot1sAdminMstID.820	.3.6.1.4.1.26138.8.35.14.18.1.2.820	Integer	0
ibdot1sAdminMstID.821	.3.6.1.4.1.26138.8.35.14.18.1.2.821	Integer	0
ibdot1sAdminMstID.822	.3.6.1.4.1.26138.8.35.14.18.1.2.822	Integer	0
ibdot1sAdminMstID.823	.3.6.1.4.1.26138.8.35.14.18.1.2.823	Integer	0
ibdot1sAdminMstID.824	.3.6.1.4.1.26138.8.35.14.18.1.2.824	Integer	0
ibdot1sAdminMstID.825	.3.6.1.4.1.26138.8.35.14.18.1.2.825	Integer	0
ibdot1sAdminMstID.826	.3.6.1.4.1.26138.8.35.14.18.1.2.826	Integer	0
ibdot1sAdminMstID.827	.3.6.1.4.1.26138.8.35.14.18.1.2.827	Integer	0
ibdot1sAdminMstID.828	.3.6.1.4.1.26138.8.35.14.18.1.2.828	Integer	0
ibdot1sAdminMstID.829	.3.6.1.4.1.26138.8.35.14.18.1.2.829	Integer	0
ibdot1sAdminMstID.830	.3.6.1.4.1.26138.8.35.14.18.1.2.830	Integer	0
ibdot1sAdminMstID.831	.3.6.1.4.1.26138.8.35.14.18.1.2.831	Integer	0
ibdot1sAdminMstID.832	.3.6.1.4.1.26138.8.35.14.18.1.2.832	Integer	0
ibdot1sAdminMstID.833	.3.6.1.4.1.26138.8.35.14.18.1.2.833	Integer	0
ibdot1sAdminMstID.834	.3.6.1.4.1.26138.8.35.14.18.1.2.834	Integer	0
ibdot1sAdminMstID.835	.3.6.1.4.1.26138.8.35.14.18.1.2.835	Integer	0
ibdot1sAdminMstID.836	.3.6.1.4.1.26138.8.35.14.18.1.2.836	Integer	0
ibdot1sAdminMstID.837	.3.6.1.4.1.26138.8.35.14.18.1.2.837	Integer	0
ibdot1sAdminMstID.838	.3.6.1.4.1.26138.8.35.14.18.1.2.838	Integer	0
ibdot1sAdminMstID.839	.3.6.1.4.1.26138.8.35.14.18.1.2.839	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.840	.3.6.1.4.1.26138.8.35.14.18.1.2.840	Integer	0
ibdot1sAdminMstID.841	.3.6.1.4.1.26138.8.35.14.18.1.2.841	Integer	0
ibdot1sAdminMstID.842	.3.6.1.4.1.26138.8.35.14.18.1.2.842	Integer	0
ibdot1sAdminMstID.843	.3.6.1.4.1.26138.8.35.14.18.1.2.843	Integer	0
ibdot1sAdminMstID.844	.3.6.1.4.1.26138.8.35.14.18.1.2.844	Integer	0
ibdot1sAdminMstID.845	.3.6.1.4.1.26138.8.35.14.18.1.2.845	Integer	0
ibdot1sAdminMstID.846	.3.6.1.4.1.26138.8.35.14.18.1.2.846	Integer	0
ibdot1sAdminMstID.847	.3.6.1.4.1.26138.8.35.14.18.1.2.847	Integer	0
ibdot1sAdminMstID.848	.3.6.1.4.1.26138.8.35.14.18.1.2.848	Integer	0
ibdot1sAdminMstID.849	.3.6.1.4.1.26138.8.35.14.18.1.2.849	Integer	0
ibdot1sAdminMstID.850	.3.6.1.4.1.26138.8.35.14.18.1.2.850	Integer	0
ibdot1sAdminMstID.851	.3.6.1.4.1.26138.8.35.14.18.1.2.851	Integer	0
ibdot1sAdminMstID.852	.3.6.1.4.1.26138.8.35.14.18.1.2.852	Integer	0
ibdot1sAdminMstID.853	.3.6.1.4.1.26138.8.35.14.18.1.2.853	Integer	0
ibdot1sAdminMstID.854	.3.6.1.4.1.26138.8.35.14.18.1.2.854	Integer	0
ibdot1sAdminMstID.855	.3.6.1.4.1.26138.8.35.14.18.1.2.855	Integer	0
ibdot1sAdminMstID.856	.3.6.1.4.1.26138.8.35.14.18.1.2.856	Integer	0
ibdot1sAdminMstID.857	.3.6.1.4.1.26138.8.35.14.18.1.2.857	Integer	0
ibdot1sAdminMstID.858	.3.6.1.4.1.26138.8.35.14.18.1.2.858	Integer	0
ibdot1sAdminMstID.859	.3.6.1.4.1.26138.8.35.14.18.1.2.859	Integer	0
ibdot1sAdminMstID.860	.3.6.1.4.1.26138.8.35.14.18.1.2.860	Integer	0
ibdot1sAdminMstID.861	.3.6.1.4.1.26138.8.35.14.18.1.2.861	Integer	0
ibdot1sAdminMstID.862	.3.6.1.4.1.26138.8.35.14.18.1.2.862	Integer	0
ibdot1sAdminMstID.863	.3.6.1.4.1.26138.8.35.14.18.1.2.863	Integer	0
ibdot1sAdminMstID.864	.3.6.1.4.1.26138.8.35.14.18.1.2.864	Integer	0
ibdot1sAdminMstID.865	.3.6.1.4.1.26138.8.35.14.18.1.2.865	Integer	0
ibdot1sAdminMstID.866	.3.6.1.4.1.26138.8.35.14.18.1.2.866	Integer	0
ibdot1sAdminMstID.867	.3.6.1.4.1.26138.8.35.14.18.1.2.867	Integer	0
ibdot1sAdminMstID.868	.3.6.1.4.1.26138.8.35.14.18.1.2.868	Integer	0
ibdot1sAdminMstID.869	.3.6.1.4.1.26138.8.35.14.18.1.2.869	Integer	0
ibdot1sAdminMstID.870	.3.6.1.4.1.26138.8.35.14.18.1.2.870	Integer	0
ibdot1sAdminMstID.871	.3.6.1.4.1.26138.8.35.14.18.1.2.871	Integer	0
ibdot1sAdminMstID.872	.3.6.1.4.1.26138.8.35.14.18.1.2.872	Integer	0
ibdot1sAdminMstID.873	.3.6.1.4.1.26138.8.35.14.18.1.2.873	Integer	0
ibdot1sAdminMstID.874	.3.6.1.4.1.26138.8.35.14.18.1.2.874	Integer	0
ibdot1sAdminMstID.875	.3.6.1.4.1.26138.8.35.14.18.1.2.875	Integer	0
ibdot1sAdminMstID.876	.3.6.1.4.1.26138.8.35.14.18.1.2.876	Integer	0
ibdot1sAdminMstID.877	.3.6.1.4.1.26138.8.35.14.18.1.2.877	Integer	0
ibdot1sAdminMstID.878	.3.6.1.4.1.26138.8.35.14.18.1.2.878	Integer	0
ibdot1sAdminMstID.879	.3.6.1.4.1.26138.8.35.14.18.1.2.879	Integer	0
ibdot1sAdminMstID.880	.3.6.1.4.1.26138.8.35.14.18.1.2.880	Integer	0
ibdot1sAdminMstID.881	.3.6.1.4.1.26138.8.35.14.18.1.2.881	Integer	0
ibdot1sAdminMstID.882	.3.6.1.4.1.26138.8.35.14.18.1.2.882	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.883	.3.6.1.4.1.26138.8.35.14.18.1.2.883	Integer	0
ibdot1sAdminMstID.884	.3.6.1.4.1.26138.8.35.14.18.1.2.884	Integer	0
ibdot1sAdminMstID.885	.3.6.1.4.1.26138.8.35.14.18.1.2.885	Integer	0
ibdot1sAdminMstID.886	.3.6.1.4.1.26138.8.35.14.18.1.2.886	Integer	0
ibdot1sAdminMstID.887	.3.6.1.4.1.26138.8.35.14.18.1.2.887	Integer	0
ibdot1sAdminMstID.888	.3.6.1.4.1.26138.8.35.14.18.1.2.888	Integer	0
ibdot1sAdminMstID.889	.3.6.1.4.1.26138.8.35.14.18.1.2.889	Integer	0
ibdot1sAdminMstID.890	.3.6.1.4.1.26138.8.35.14.18.1.2.890	Integer	0
ibdot1sAdminMstID.891	.3.6.1.4.1.26138.8.35.14.18.1.2.891	Integer	0
ibdot1sAdminMstID.892	.3.6.1.4.1.26138.8.35.14.18.1.2.892	Integer	0
ibdot1sAdminMstID.893	.3.6.1.4.1.26138.8.35.14.18.1.2.893	Integer	0
ibdot1sAdminMstID.894	.3.6.1.4.1.26138.8.35.14.18.1.2.894	Integer	0
ibdot1sAdminMstID.895	.3.6.1.4.1.26138.8.35.14.18.1.2.895	Integer	0
ibdot1sAdminMstID.896	.3.6.1.4.1.26138.8.35.14.18.1.2.896	Integer	0
ibdot1sAdminMstID.897	.3.6.1.4.1.26138.8.35.14.18.1.2.897	Integer	0
ibdot1sAdminMstID.898	.3.6.1.4.1.26138.8.35.14.18.1.2.898	Integer	0
ibdot1sAdminMstID.899	.3.6.1.4.1.26138.8.35.14.18.1.2.899	Integer	0
ibdot1sAdminMstID.900	.3.6.1.4.1.26138.8.35.14.18.1.2.900	Integer	0
ibdot1sAdminMstID.901	.3.6.1.4.1.26138.8.35.14.18.1.2.901	Integer	0
ibdot1sAdminMstID.902	.3.6.1.4.1.26138.8.35.14.18.1.2.902	Integer	0
ibdot1sAdminMstID.903	.3.6.1.4.1.26138.8.35.14.18.1.2.903	Integer	0
ibdot1sAdminMstID.904	.3.6.1.4.1.26138.8.35.14.18.1.2.904	Integer	0
ibdot1sAdminMstID.905	.3.6.1.4.1.26138.8.35.14.18.1.2.905	Integer	0
ibdot1sAdminMstID.906	.3.6.1.4.1.26138.8.35.14.18.1.2.906	Integer	0
ibdot1sAdminMstID.907	.3.6.1.4.1.26138.8.35.14.18.1.2.907	Integer	0
ibdot1sAdminMstID.908	.3.6.1.4.1.26138.8.35.14.18.1.2.908	Integer	0
ibdot1sAdminMstID.909	.3.6.1.4.1.26138.8.35.14.18.1.2.909	Integer	0
ibdot1sAdminMstID.910	.3.6.1.4.1.26138.8.35.14.18.1.2.910	Integer	0
ibdot1sAdminMstID.911	.3.6.1.4.1.26138.8.35.14.18.1.2.911	Integer	0
ibdot1sAdminMstID.912	.3.6.1.4.1.26138.8.35.14.18.1.2.912	Integer	0
ibdot1sAdminMstID.913	.3.6.1.4.1.26138.8.35.14.18.1.2.913	Integer	0
ibdot1sAdminMstID.914	.3.6.1.4.1.26138.8.35.14.18.1.2.914	Integer	0
ibdot1sAdminMstID.915	.3.6.1.4.1.26138.8.35.14.18.1.2.915	Integer	0
ibdot1sAdminMstID.916	.3.6.1.4.1.26138.8.35.14.18.1.2.916	Integer	0
ibdot1sAdminMstID.917	.3.6.1.4.1.26138.8.35.14.18.1.2.917	Integer	0
ibdot1sAdminMstID.918	.3.6.1.4.1.26138.8.35.14.18.1.2.918	Integer	0
ibdot1sAdminMstID.919	.3.6.1.4.1.26138.8.35.14.18.1.2.919	Integer	0
ibdot1sAdminMstID.920	.3.6.1.4.1.26138.8.35.14.18.1.2.920	Integer	0
ibdot1sAdminMstID.921	.3.6.1.4.1.26138.8.35.14.18.1.2.921	Integer	0
ibdot1sAdminMstID.922	.3.6.1.4.1.26138.8.35.14.18.1.2.922	Integer	0
ibdot1sAdminMstID.923	.3.6.1.4.1.26138.8.35.14.18.1.2.923	Integer	0
ibdot1sAdminMstID.924	.3.6.1.4.1.26138.8.35.14.18.1.2.924	Integer	0
ibdot1sAdminMstID.925	.3.6.1.4.1.26138.8.35.14.18.1.2.925	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.926	.3.6.1.4.1.26138.8.35.14.18.1.2.926	Integer	0
ibdot1sAdminMstID.927	.3.6.1.4.1.26138.8.35.14.18.1.2.927	Integer	0
ibdot1sAdminMstID.928	.3.6.1.4.1.26138.8.35.14.18.1.2.928	Integer	0
ibdot1sAdminMstID.929	.3.6.1.4.1.26138.8.35.14.18.1.2.929	Integer	0
ibdot1sAdminMstID.930	.3.6.1.4.1.26138.8.35.14.18.1.2.930	Integer	0
ibdot1sAdminMstID.931	.3.6.1.4.1.26138.8.35.14.18.1.2.931	Integer	0
ibdot1sAdminMstID.932	.3.6.1.4.1.26138.8.35.14.18.1.2.932	Integer	0
ibdot1sAdminMstID.933	.3.6.1.4.1.26138.8.35.14.18.1.2.933	Integer	0
ibdot1sAdminMstID.934	.3.6.1.4.1.26138.8.35.14.18.1.2.934	Integer	0
ibdot1sAdminMstID.935	.3.6.1.4.1.26138.8.35.14.18.1.2.935	Integer	0
ibdot1sAdminMstID.936	.3.6.1.4.1.26138.8.35.14.18.1.2.936	Integer	0
ibdot1sAdminMstID.937	.3.6.1.4.1.26138.8.35.14.18.1.2.937	Integer	0
ibdot1sAdminMstID.938	.3.6.1.4.1.26138.8.35.14.18.1.2.938	Integer	0
ibdot1sAdminMstID.939	.3.6.1.4.1.26138.8.35.14.18.1.2.939	Integer	0
ibdot1sAdminMstID.940	.3.6.1.4.1.26138.8.35.14.18.1.2.940	Integer	0
ibdot1sAdminMstID.941	.3.6.1.4.1.26138.8.35.14.18.1.2.941	Integer	0
ibdot1sAdminMstID.942	.3.6.1.4.1.26138.8.35.14.18.1.2.942	Integer	0
ibdot1sAdminMstID.943	.3.6.1.4.1.26138.8.35.14.18.1.2.943	Integer	0
ibdot1sAdminMstID.944	.3.6.1.4.1.26138.8.35.14.18.1.2.944	Integer	0
ibdot1sAdminMstID.945	.3.6.1.4.1.26138.8.35.14.18.1.2.945	Integer	0
ibdot1sAdminMstID.946	.3.6.1.4.1.26138.8.35.14.18.1.2.946	Integer	0
ibdot1sAdminMstID.947	.3.6.1.4.1.26138.8.35.14.18.1.2.947	Integer	0
ibdot1sAdminMstID.948	.3.6.1.4.1.26138.8.35.14.18.1.2.948	Integer	0
ibdot1sAdminMstID.949	.3.6.1.4.1.26138.8.35.14.18.1.2.949	Integer	0
ibdot1sAdminMstID.950	.3.6.1.4.1.26138.8.35.14.18.1.2.950	Integer	0
ibdot1sAdminMstID.951	.3.6.1.4.1.26138.8.35.14.18.1.2.951	Integer	0
ibdot1sAdminMstID.952	.3.6.1.4.1.26138.8.35.14.18.1.2.952	Integer	0
ibdot1sAdminMstID.953	.3.6.1.4.1.26138.8.35.14.18.1.2.953	Integer	0
ibdot1sAdminMstID.954	.3.6.1.4.1.26138.8.35.14.18.1.2.954	Integer	0
ibdot1sAdminMstID.955	.3.6.1.4.1.26138.8.35.14.18.1.2.955	Integer	0
ibdot1sAdminMstID.956	.3.6.1.4.1.26138.8.35.14.18.1.2.956	Integer	0
ibdot1sAdminMstID.957	.3.6.1.4.1.26138.8.35.14.18.1.2.957	Integer	0
ibdot1sAdminMstID.958	.3.6.1.4.1.26138.8.35.14.18.1.2.958	Integer	0
ibdot1sAdminMstID.959	.3.6.1.4.1.26138.8.35.14.18.1.2.959	Integer	0
ibdot1sAdminMstID.960	.3.6.1.4.1.26138.8.35.14.18.1.2.960	Integer	0
ibdot1sAdminMstID.961	.3.6.1.4.1.26138.8.35.14.18.1.2.961	Integer	0
ibdot1sAdminMstID.962	.3.6.1.4.1.26138.8.35.14.18.1.2.962	Integer	0
ibdot1sAdminMstID.963	.3.6.1.4.1.26138.8.35.14.18.1.2.963	Integer	0
ibdot1sAdminMstID.964	.3.6.1.4.1.26138.8.35.14.18.1.2.964	Integer	0
ibdot1sAdminMstID.965	.3.6.1.4.1.26138.8.35.14.18.1.2.965	Integer	0
ibdot1sAdminMstID.966	.3.6.1.4.1.26138.8.35.14.18.1.2.966	Integer	0
ibdot1sAdminMstID.967	.3.6.1.4.1.26138.8.35.14.18.1.2.967	Integer	0
ibdot1sAdminMstID.968	.3.6.1.4.1.26138.8.35.14.18.1.2.968	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.969	.1.3.6.1.4.1.26138.8.35.14.18.1.2.969	Integer	0
ibdot1sAdminMstID.970	.1.3.6.1.4.1.26138.8.35.14.18.1.2.970	Integer	0
ibdot1sAdminMstID.971	.1.3.6.1.4.1.26138.8.35.14.18.1.2.971	Integer	0
ibdot1sAdminMstID.972	.1.3.6.1.4.1.26138.8.35.14.18.1.2.972	Integer	0
ibdot1sAdminMstID.973	.1.3.6.1.4.1.26138.8.35.14.18.1.2.973	Integer	0
ibdot1sAdminMstID.974	.1.3.6.1.4.1.26138.8.35.14.18.1.2.974	Integer	0
ibdot1sAdminMstID.975	.1.3.6.1.4.1.26138.8.35.14.18.1.2.975	Integer	0
ibdot1sAdminMstID.976	.1.3.6.1.4.1.26138.8.35.14.18.1.2.976	Integer	0
ibdot1sAdminMstID.977	.1.3.6.1.4.1.26138.8.35.14.18.1.2.977	Integer	0
ibdot1sAdminMstID.978	.1.3.6.1.4.1.26138.8.35.14.18.1.2.978	Integer	0
ibdot1sAdminMstID.979	.1.3.6.1.4.1.26138.8.35.14.18.1.2.979	Integer	0
ibdot1sAdminMstID.980	.1.3.6.1.4.1.26138.8.35.14.18.1.2.980	Integer	0
ibdot1sAdminMstID.981	.1.3.6.1.4.1.26138.8.35.14.18.1.2.981	Integer	0
ibdot1sAdminMstID.982	.1.3.6.1.4.1.26138.8.35.14.18.1.2.982	Integer	0
ibdot1sAdminMstID.983	.1.3.6.1.4.1.26138.8.35.14.18.1.2.983	Integer	0
ibdot1sAdminMstID.984	.1.3.6.1.4.1.26138.8.35.14.18.1.2.984	Integer	0
ibdot1sAdminMstID.985	.1.3.6.1.4.1.26138.8.35.14.18.1.2.985	Integer	0
ibdot1sAdminMstID.986	.1.3.6.1.4.1.26138.8.35.14.18.1.2.986	Integer	0
ibdot1sAdminMstID.987	.1.3.6.1.4.1.26138.8.35.14.18.1.2.987	Integer	0
ibdot1sAdminMstID.988	.1.3.6.1.4.1.26138.8.35.14.18.1.2.988	Integer	0
ibdot1sAdminMstID.989	.1.3.6.1.4.1.26138.8.35.14.18.1.2.989	Integer	0
ibdot1sAdminMstID.990	.1.3.6.1.4.1.26138.8.35.14.18.1.2.990	Integer	0
ibdot1sAdminMstID.991	.1.3.6.1.4.1.26138.8.35.14.18.1.2.991	Integer	0
ibdot1sAdminMstID.992	.1.3.6.1.4.1.26138.8.35.14.18.1.2.992	Integer	0
ibdot1sAdminMstID.993	.1.3.6.1.4.1.26138.8.35.14.18.1.2.993	Integer	0
ibdot1sAdminMstID.994	.1.3.6.1.4.1.26138.8.35.14.18.1.2.994	Integer	0
ibdot1sAdminMstID.995	.1.3.6.1.4.1.26138.8.35.14.18.1.2.995	Integer	0
ibdot1sAdminMstID.996	.1.3.6.1.4.1.26138.8.35.14.18.1.2.996	Integer	0
ibdot1sAdminMstID.997	.1.3.6.1.4.1.26138.8.35.14.18.1.2.997	Integer	0
ibdot1sAdminMstID.998	.1.3.6.1.4.1.26138.8.35.14.18.1.2.998	Integer	0
ibdot1sAdminMstID.999	.1.3.6.1.4.1.26138.8.35.14.18.1.2.999	Integer	0
ibdot1sAdminMstID.1000	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1000	Integer	0
ibdot1sAdminMstID.1001	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1001	Integer	0
ibdot1sAdminMstID.1002	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1002	Integer	0
ibdot1sAdminMstID.1003	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1003	Integer	0
ibdot1sAdminMstID.1004	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1004	Integer	0
ibdot1sAdminMstID.1005	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1005	Integer	0
ibdot1sAdminMstID.1006	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1006	Integer	0
ibdot1sAdminMstID.1007	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1007	Integer	0
ibdot1sAdminMstID.1008	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1008	Integer	0
ibdot1sAdminMstID.1009	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1009	Integer	0
ibdot1sAdminMstID.1010	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1010	Integer	0
ibdot1sAdminMstID.1011	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1011	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1012	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1012	Integer	0
ibdot1sAdminMstID.1013	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1013	Integer	0
ibdot1sAdminMstID.1014	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1014	Integer	0
ibdot1sAdminMstID.1015	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1015	Integer	0
ibdot1sAdminMstID.1016	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1016	Integer	0
ibdot1sAdminMstID.1017	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1017	Integer	0
ibdot1sAdminMstID.1018	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1018	Integer	0
ibdot1sAdminMstID.1019	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1019	Integer	0
ibdot1sAdminMstID.1020	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1020	Integer	0
ibdot1sAdminMstID.1021	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1021	Integer	0
ibdot1sAdminMstID.1022	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1022	Integer	0
ibdot1sAdminMstID.1023	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1023	Integer	0
ibdot1sAdminMstID.1024	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1024	Integer	0
ibdot1sAdminMstID.1025	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1025	Integer	0
ibdot1sAdminMstID.1026	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1026	Integer	0
ibdot1sAdminMstID.1027	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1027	Integer	0
ibdot1sAdminMstID.1028	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1028	Integer	0
ibdot1sAdminMstID.1029	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1029	Integer	0
ibdot1sAdminMstID.1030	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1030	Integer	0
ibdot1sAdminMstID.1031	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1031	Integer	0
ibdot1sAdminMstID.1032	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1032	Integer	0
ibdot1sAdminMstID.1033	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1033	Integer	0
ibdot1sAdminMstID.1034	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1034	Integer	0
ibdot1sAdminMstID.1035	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1035	Integer	0
ibdot1sAdminMstID.1036	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1036	Integer	0
ibdot1sAdminMstID.1037	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1037	Integer	0
ibdot1sAdminMstID.1038	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1038	Integer	0
ibdot1sAdminMstID.1039	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1039	Integer	0
ibdot1sAdminMstID.1040	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1040	Integer	0
ibdot1sAdminMstID.1041	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1041	Integer	0
ibdot1sAdminMstID.1042	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1042	Integer	0
ibdot1sAdminMstID.1043	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1043	Integer	0
ibdot1sAdminMstID.1044	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1044	Integer	0
ibdot1sAdminMstID.1045	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1045	Integer	0
ibdot1sAdminMstID.1046	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1046	Integer	0
ibdot1sAdminMstID.1047	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1047	Integer	0
ibdot1sAdminMstID.1048	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1048	Integer	0
ibdot1sAdminMstID.1049	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1049	Integer	0
ibdot1sAdminMstID.1050	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1050	Integer	0
ibdot1sAdminMstID.1051	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1051	Integer	0
ibdot1sAdminMstID.1052	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1052	Integer	0
ibdot1sAdminMstID.1053	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1053	Integer	0
ibdot1sAdminMstID.1054	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1054	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1055	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1055	Integer	0
ibdot1sAdminMstID.1056	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1056	Integer	0
ibdot1sAdminMstID.1057	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1057	Integer	0
ibdot1sAdminMstID.1058	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1058	Integer	0
ibdot1sAdminMstID.1059	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1059	Integer	0
ibdot1sAdminMstID.1060	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1060	Integer	0
ibdot1sAdminMstID.1061	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1061	Integer	0
ibdot1sAdminMstID.1062	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1062	Integer	0
ibdot1sAdminMstID.1063	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1063	Integer	0
ibdot1sAdminMstID.1064	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1064	Integer	0
ibdot1sAdminMstID.1065	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1065	Integer	0
ibdot1sAdminMstID.1066	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1066	Integer	0
ibdot1sAdminMstID.1067	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1067	Integer	0
ibdot1sAdminMstID.1068	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1068	Integer	0
ibdot1sAdminMstID.1069	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1069	Integer	0
ibdot1sAdminMstID.1070	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1070	Integer	0
ibdot1sAdminMstID.1071	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1071	Integer	0
ibdot1sAdminMstID.1072	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1072	Integer	0
ibdot1sAdminMstID.1073	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1073	Integer	0
ibdot1sAdminMstID.1074	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1074	Integer	0
ibdot1sAdminMstID.1075	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1075	Integer	0
ibdot1sAdminMstID.1076	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1076	Integer	0
ibdot1sAdminMstID.1077	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1077	Integer	0
ibdot1sAdminMstID.1078	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1078	Integer	0
ibdot1sAdminMstID.1079	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1079	Integer	0
ibdot1sAdminMstID.1080	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1080	Integer	0
ibdot1sAdminMstID.1081	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1081	Integer	0
ibdot1sAdminMstID.1082	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1082	Integer	0
ibdot1sAdminMstID.1083	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1083	Integer	0
ibdot1sAdminMstID.1084	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1084	Integer	0
ibdot1sAdminMstID.1085	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1085	Integer	0
ibdot1sAdminMstID.1086	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1086	Integer	0
ibdot1sAdminMstID.1087	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1087	Integer	0
ibdot1sAdminMstID.1088	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1088	Integer	0
ibdot1sAdminMstID.1089	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1089	Integer	0
ibdot1sAdminMstID.1090	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1090	Integer	0
ibdot1sAdminMstID.1091	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1091	Integer	0
ibdot1sAdminMstID.1092	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1092	Integer	0
ibdot1sAdminMstID.1093	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1093	Integer	0
ibdot1sAdminMstID.1094	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1094	Integer	0
ibdot1sAdminMstID.1095	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1095	Integer	0
ibdot1sAdminMstID.1096	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1096	Integer	0
ibdot1sAdminMstID.1097	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1097	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1098	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1098	Integer	0
ibdot1sAdminMstID.1099	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1099	Integer	0
ibdot1sAdminMstID.1100	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1100	Integer	0
ibdot1sAdminMstID.1101	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1101	Integer	0
ibdot1sAdminMstID.1102	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1102	Integer	0
ibdot1sAdminMstID.1103	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1103	Integer	0
ibdot1sAdminMstID.1104	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1104	Integer	0
ibdot1sAdminMstID.1105	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1105	Integer	0
ibdot1sAdminMstID.1106	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1106	Integer	0
ibdot1sAdminMstID.1107	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1107	Integer	0
ibdot1sAdminMstID.1108	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1108	Integer	0
ibdot1sAdminMstID.1109	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1109	Integer	0
ibdot1sAdminMstID.1110	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1110	Integer	0
ibdot1sAdminMstID.1111	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1111	Integer	0
ibdot1sAdminMstID.1112	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1112	Integer	0
ibdot1sAdminMstID.1113	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1113	Integer	0
ibdot1sAdminMstID.1114	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1114	Integer	0
ibdot1sAdminMstID.1115	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1115	Integer	0
ibdot1sAdminMstID.1116	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1116	Integer	0
ibdot1sAdminMstID.1117	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1117	Integer	0
ibdot1sAdminMstID.1118	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1118	Integer	0
ibdot1sAdminMstID.1119	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1119	Integer	0
ibdot1sAdminMstID.1120	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1120	Integer	0
ibdot1sAdminMstID.1121	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1121	Integer	0
ibdot1sAdminMstID.1122	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1122	Integer	0
ibdot1sAdminMstID.1123	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1123	Integer	0
ibdot1sAdminMstID.1124	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1124	Integer	0
ibdot1sAdminMstID.1125	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1125	Integer	0
ibdot1sAdminMstID.1126	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1126	Integer	0
ibdot1sAdminMstID.1127	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1127	Integer	0
ibdot1sAdminMstID.1128	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1128	Integer	0
ibdot1sAdminMstID.1129	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1129	Integer	0
ibdot1sAdminMstID.1130	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1130	Integer	0
ibdot1sAdminMstID.1131	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1131	Integer	0
ibdot1sAdminMstID.1132	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1132	Integer	0
ibdot1sAdminMstID.1133	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1133	Integer	0
ibdot1sAdminMstID.1134	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1134	Integer	0
ibdot1sAdminMstID.1135	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1135	Integer	0
ibdot1sAdminMstID.1136	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1136	Integer	0
ibdot1sAdminMstID.1137	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1137	Integer	0
ibdot1sAdminMstID.1138	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1138	Integer	0
ibdot1sAdminMstID.1139	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1139	Integer	0
ibdot1sAdminMstID.1140	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1140	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1141	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1141	Integer	0
ibdot1sAdminMstID.1142	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1142	Integer	0
ibdot1sAdminMstID.1143	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1143	Integer	0
ibdot1sAdminMstID.1144	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1144	Integer	0
ibdot1sAdminMstID.1145	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1145	Integer	0
ibdot1sAdminMstID.1146	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1146	Integer	0
ibdot1sAdminMstID.1147	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1147	Integer	0
ibdot1sAdminMstID.1148	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1148	Integer	0
ibdot1sAdminMstID.1149	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1149	Integer	0
ibdot1sAdminMstID.1150	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1150	Integer	0
ibdot1sAdminMstID.1151	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1151	Integer	0
ibdot1sAdminMstID.1152	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1152	Integer	0
ibdot1sAdminMstID.1153	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1153	Integer	0
ibdot1sAdminMstID.1154	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1154	Integer	0
ibdot1sAdminMstID.1155	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1155	Integer	0
ibdot1sAdminMstID.1156	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1156	Integer	0
ibdot1sAdminMstID.1157	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1157	Integer	0
ibdot1sAdminMstID.1158	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1158	Integer	0
ibdot1sAdminMstID.1159	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1159	Integer	0
ibdot1sAdminMstID.1160	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1160	Integer	0
ibdot1sAdminMstID.1161	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1161	Integer	0
ibdot1sAdminMstID.1162	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1162	Integer	0
ibdot1sAdminMstID.1163	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1163	Integer	0
ibdot1sAdminMstID.1164	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1164	Integer	0
ibdot1sAdminMstID.1165	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1165	Integer	0
ibdot1sAdminMstID.1166	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1166	Integer	0
ibdot1sAdminMstID.1167	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1167	Integer	0
ibdot1sAdminMstID.1168	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1168	Integer	0
ibdot1sAdminMstID.1169	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1169	Integer	0
ibdot1sAdminMstID.1170	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1170	Integer	0
ibdot1sAdminMstID.1171	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1171	Integer	0
ibdot1sAdminMstID.1172	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1172	Integer	0
ibdot1sAdminMstID.1173	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1173	Integer	0
ibdot1sAdminMstID.1174	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1174	Integer	0
ibdot1sAdminMstID.1175	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1175	Integer	0
ibdot1sAdminMstID.1176	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1176	Integer	0
ibdot1sAdminMstID.1177	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1177	Integer	0
ibdot1sAdminMstID.1178	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1178	Integer	0
ibdot1sAdminMstID.1179	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1179	Integer	0
ibdot1sAdminMstID.1180	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1180	Integer	0
ibdot1sAdminMstID.1181	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1181	Integer	0
ibdot1sAdminMstID.1182	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1182	Integer	0
ibdot1sAdminMstID.1183	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1183	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1184	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1184	Integer	0
ibdot1sAdminMstID.1185	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1185	Integer	0
ibdot1sAdminMstID.1186	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1186	Integer	0
ibdot1sAdminMstID.1187	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1187	Integer	0
ibdot1sAdminMstID.1188	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1188	Integer	0
ibdot1sAdminMstID.1189	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1189	Integer	0
ibdot1sAdminMstID.1190	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1190	Integer	0
ibdot1sAdminMstID.1191	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1191	Integer	0
ibdot1sAdminMstID.1192	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1192	Integer	0
ibdot1sAdminMstID.1193	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1193	Integer	0
ibdot1sAdminMstID.1194	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1194	Integer	0
ibdot1sAdminMstID.1195	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1195	Integer	0
ibdot1sAdminMstID.1196	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1196	Integer	0
ibdot1sAdminMstID.1197	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1197	Integer	0
ibdot1sAdminMstID.1198	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1198	Integer	0
ibdot1sAdminMstID.1199	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1199	Integer	0
ibdot1sAdminMstID.1200	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1200	Integer	0
ibdot1sAdminMstID.1201	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1201	Integer	0
ibdot1sAdminMstID.1202	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1202	Integer	0
ibdot1sAdminMstID.1203	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1203	Integer	0
ibdot1sAdminMstID.1204	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1204	Integer	0
ibdot1sAdminMstID.1205	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1205	Integer	0
ibdot1sAdminMstID.1206	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1206	Integer	0
ibdot1sAdminMstID.1207	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1207	Integer	0
ibdot1sAdminMstID.1208	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1208	Integer	0
ibdot1sAdminMstID.1209	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1209	Integer	0
ibdot1sAdminMstID.1210	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1210	Integer	0
ibdot1sAdminMstID.1211	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1211	Integer	0
ibdot1sAdminMstID.1212	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1212	Integer	0
ibdot1sAdminMstID.1213	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1213	Integer	0
ibdot1sAdminMstID.1214	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1214	Integer	0
ibdot1sAdminMstID.1215	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1215	Integer	0
ibdot1sAdminMstID.1216	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1216	Integer	0
ibdot1sAdminMstID.1217	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1217	Integer	0
ibdot1sAdminMstID.1218	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1218	Integer	0
ibdot1sAdminMstID.1219	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1219	Integer	0
ibdot1sAdminMstID.1220	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1220	Integer	0
ibdot1sAdminMstID.1221	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1221	Integer	0
ibdot1sAdminMstID.1222	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1222	Integer	0
ibdot1sAdminMstID.1223	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1223	Integer	0
ibdot1sAdminMstID.1224	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1224	Integer	0
ibdot1sAdminMstID.1225	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1225	Integer	0
ibdot1sAdminMstID.1226	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1226	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1227	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1227	Integer	0
ibdot1sAdminMstID.1228	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1228	Integer	0
ibdot1sAdminMstID.1229	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1229	Integer	0
ibdot1sAdminMstID.1230	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1230	Integer	0
ibdot1sAdminMstID.1231	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1231	Integer	0
ibdot1sAdminMstID.1232	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1232	Integer	0
ibdot1sAdminMstID.1233	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1233	Integer	0
ibdot1sAdminMstID.1234	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1234	Integer	0
ibdot1sAdminMstID.1235	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1235	Integer	0
ibdot1sAdminMstID.1236	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1236	Integer	0
ibdot1sAdminMstID.1237	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1237	Integer	0
ibdot1sAdminMstID.1238	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1238	Integer	0
ibdot1sAdminMstID.1239	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1239	Integer	0
ibdot1sAdminMstID.1240	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1240	Integer	0
ibdot1sAdminMstID.1241	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1241	Integer	0
ibdot1sAdminMstID.1242	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1242	Integer	0
ibdot1sAdminMstID.1243	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1243	Integer	0
ibdot1sAdminMstID.1244	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1244	Integer	0
ibdot1sAdminMstID.1245	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1245	Integer	0
ibdot1sAdminMstID.1246	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1246	Integer	0
ibdot1sAdminMstID.1247	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1247	Integer	0
ibdot1sAdminMstID.1248	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1248	Integer	0
ibdot1sAdminMstID.1249	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1249	Integer	0
ibdot1sAdminMstID.1250	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1250	Integer	0
ibdot1sAdminMstID.1251	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1251	Integer	0
ibdot1sAdminMstID.1252	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1252	Integer	0
ibdot1sAdminMstID.1253	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1253	Integer	0
ibdot1sAdminMstID.1254	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1254	Integer	0
ibdot1sAdminMstID.1255	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1255	Integer	0
ibdot1sAdminMstID.1256	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1256	Integer	0
ibdot1sAdminMstID.1257	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1257	Integer	0
ibdot1sAdminMstID.1258	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1258	Integer	0
ibdot1sAdminMstID.1259	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1259	Integer	0
ibdot1sAdminMstID.1260	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1260	Integer	0
ibdot1sAdminMstID.1261	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1261	Integer	0
ibdot1sAdminMstID.1262	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1262	Integer	0
ibdot1sAdminMstID.1263	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1263	Integer	0
ibdot1sAdminMstID.1264	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1264	Integer	0
ibdot1sAdminMstID.1265	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1265	Integer	0
ibdot1sAdminMstID.1266	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1266	Integer	0
ibdot1sAdminMstID.1267	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1267	Integer	0
ibdot1sAdminMstID.1268	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1268	Integer	0
ibdot1sAdminMstID.1269	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1269	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1270	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1270	Integer	0
ibdot1sAdminMstID.1271	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1271	Integer	0
ibdot1sAdminMstID.1272	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1272	Integer	0
ibdot1sAdminMstID.1273	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1273	Integer	0
ibdot1sAdminMstID.1274	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1274	Integer	0
ibdot1sAdminMstID.1275	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1275	Integer	0
ibdot1sAdminMstID.1276	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1276	Integer	0
ibdot1sAdminMstID.1277	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1277	Integer	0
ibdot1sAdminMstID.1278	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1278	Integer	0
ibdot1sAdminMstID.1279	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1279	Integer	0
ibdot1sAdminMstID.1280	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1280	Integer	0
ibdot1sAdminMstID.1281	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1281	Integer	0
ibdot1sAdminMstID.1282	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1282	Integer	0
ibdot1sAdminMstID.1283	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1283	Integer	0
ibdot1sAdminMstID.1284	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1284	Integer	0
ibdot1sAdminMstID.1285	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1285	Integer	0
ibdot1sAdminMstID.1286	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1286	Integer	0
ibdot1sAdminMstID.1287	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1287	Integer	0
ibdot1sAdminMstID.1288	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1288	Integer	0
ibdot1sAdminMstID.1289	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1289	Integer	0
ibdot1sAdminMstID.1290	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1290	Integer	0
ibdot1sAdminMstID.1291	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1291	Integer	0
ibdot1sAdminMstID.1292	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1292	Integer	0
ibdot1sAdminMstID.1293	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1293	Integer	0
ibdot1sAdminMstID.1294	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1294	Integer	0
ibdot1sAdminMstID.1295	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1295	Integer	0
ibdot1sAdminMstID.1296	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1296	Integer	0
ibdot1sAdminMstID.1297	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1297	Integer	0
ibdot1sAdminMstID.1298	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1298	Integer	0
ibdot1sAdminMstID.1299	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1299	Integer	0
ibdot1sAdminMstID.1300	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1300	Integer	0
ibdot1sAdminMstID.1301	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1301	Integer	0
ibdot1sAdminMstID.1302	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1302	Integer	0
ibdot1sAdminMstID.1303	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1303	Integer	0
ibdot1sAdminMstID.1304	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1304	Integer	0
ibdot1sAdminMstID.1305	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1305	Integer	0
ibdot1sAdminMstID.1306	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1306	Integer	0
ibdot1sAdminMstID.1307	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1307	Integer	0
ibdot1sAdminMstID.1308	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1308	Integer	0
ibdot1sAdminMstID.1309	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1309	Integer	0
ibdot1sAdminMstID.1310	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1310	Integer	0
ibdot1sAdminMstID.1311	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1311	Integer	0
ibdot1sAdminMstID.1312	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1312	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1313	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1313	Integer	0
ibdot1sAdminMstID.1314	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1314	Integer	0
ibdot1sAdminMstID.1315	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1315	Integer	0
ibdot1sAdminMstID.1316	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1316	Integer	0
ibdot1sAdminMstID.1317	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1317	Integer	0
ibdot1sAdminMstID.1318	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1318	Integer	0
ibdot1sAdminMstID.1319	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1319	Integer	0
ibdot1sAdminMstID.1320	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1320	Integer	0
ibdot1sAdminMstID.1321	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1321	Integer	0
ibdot1sAdminMstID.1322	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1322	Integer	0
ibdot1sAdminMstID.1323	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1323	Integer	0
ibdot1sAdminMstID.1324	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1324	Integer	0
ibdot1sAdminMstID.1325	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1325	Integer	0
ibdot1sAdminMstID.1326	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1326	Integer	0
ibdot1sAdminMstID.1327	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1327	Integer	0
ibdot1sAdminMstID.1328	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1328	Integer	0
ibdot1sAdminMstID.1329	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1329	Integer	0
ibdot1sAdminMstID.1330	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1330	Integer	0
ibdot1sAdminMstID.1331	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1331	Integer	0
ibdot1sAdminMstID.1332	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1332	Integer	0
ibdot1sAdminMstID.1333	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1333	Integer	0
ibdot1sAdminMstID.1334	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1334	Integer	0
ibdot1sAdminMstID.1335	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1335	Integer	0
ibdot1sAdminMstID.1336	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1336	Integer	0
ibdot1sAdminMstID.1337	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1337	Integer	0
ibdot1sAdminMstID.1338	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1338	Integer	0
ibdot1sAdminMstID.1339	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1339	Integer	0
ibdot1sAdminMstID.1340	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1340	Integer	0
ibdot1sAdminMstID.1341	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1341	Integer	0
ibdot1sAdminMstID.1342	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1342	Integer	0
ibdot1sAdminMstID.1343	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1343	Integer	0
ibdot1sAdminMstID.1344	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1344	Integer	0
ibdot1sAdminMstID.1345	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1345	Integer	0
ibdot1sAdminMstID.1346	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1346	Integer	0
ibdot1sAdminMstID.1347	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1347	Integer	0
ibdot1sAdminMstID.1348	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1348	Integer	0
ibdot1sAdminMstID.1349	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1349	Integer	0
ibdot1sAdminMstID.1350	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1350	Integer	0
ibdot1sAdminMstID.1351	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1351	Integer	0
ibdot1sAdminMstID.1352	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1352	Integer	0
ibdot1sAdminMstID.1353	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1353	Integer	0
ibdot1sAdminMstID.1354	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1354	Integer	0
ibdot1sAdminMstID.1355	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1355	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1356	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1356	Integer	0
ibdot1sAdminMstID.1357	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1357	Integer	0
ibdot1sAdminMstID.1358	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1358	Integer	0
ibdot1sAdminMstID.1359	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1359	Integer	0
ibdot1sAdminMstID.1360	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1360	Integer	0
ibdot1sAdminMstID.1361	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1361	Integer	0
ibdot1sAdminMstID.1362	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1362	Integer	0
ibdot1sAdminMstID.1363	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1363	Integer	0
ibdot1sAdminMstID.1364	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1364	Integer	0
ibdot1sAdminMstID.1365	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1365	Integer	0
ibdot1sAdminMstID.1366	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1366	Integer	0
ibdot1sAdminMstID.1367	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1367	Integer	0
ibdot1sAdminMstID.1368	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1368	Integer	0
ibdot1sAdminMstID.1369	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1369	Integer	0
ibdot1sAdminMstID.1370	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1370	Integer	0
ibdot1sAdminMstID.1371	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1371	Integer	0
ibdot1sAdminMstID.1372	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1372	Integer	0
ibdot1sAdminMstID.1373	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1373	Integer	0
ibdot1sAdminMstID.1374	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1374	Integer	0
ibdot1sAdminMstID.1375	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1375	Integer	0
ibdot1sAdminMstID.1376	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1376	Integer	0
ibdot1sAdminMstID.1377	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1377	Integer	0
ibdot1sAdminMstID.1378	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1378	Integer	0
ibdot1sAdminMstID.1379	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1379	Integer	0
ibdot1sAdminMstID.1380	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1380	Integer	0
ibdot1sAdminMstID.1381	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1381	Integer	0
ibdot1sAdminMstID.1382	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1382	Integer	0
ibdot1sAdminMstID.1383	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1383	Integer	0
ibdot1sAdminMstID.1384	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1384	Integer	0
ibdot1sAdminMstID.1385	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1385	Integer	0
ibdot1sAdminMstID.1386	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1386	Integer	0
ibdot1sAdminMstID.1387	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1387	Integer	0
ibdot1sAdminMstID.1388	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1388	Integer	0
ibdot1sAdminMstID.1389	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1389	Integer	0
ibdot1sAdminMstID.1390	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1390	Integer	0
ibdot1sAdminMstID.1391	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1391	Integer	0
ibdot1sAdminMstID.1392	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1392	Integer	0
ibdot1sAdminMstID.1393	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1393	Integer	0
ibdot1sAdminMstID.1394	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1394	Integer	0
ibdot1sAdminMstID.1395	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1395	Integer	0
ibdot1sAdminMstID.1396	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1396	Integer	0
ibdot1sAdminMstID.1397	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1397	Integer	0
ibdot1sAdminMstID.1398	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1398	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1399	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1399	Integer	0
ibdot1sAdminMstID.1400	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1400	Integer	0
ibdot1sAdminMstID.1401	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1401	Integer	0
ibdot1sAdminMstID.1402	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1402	Integer	0
ibdot1sAdminMstID.1403	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1403	Integer	0
ibdot1sAdminMstID.1404	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1404	Integer	0
ibdot1sAdminMstID.1405	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1405	Integer	0
ibdot1sAdminMstID.1406	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1406	Integer	0
ibdot1sAdminMstID.1407	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1407	Integer	0
ibdot1sAdminMstID.1408	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1408	Integer	0
ibdot1sAdminMstID.1409	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1409	Integer	0
ibdot1sAdminMstID.1410	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1410	Integer	0
ibdot1sAdminMstID.1411	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1411	Integer	0
ibdot1sAdminMstID.1412	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1412	Integer	0
ibdot1sAdminMstID.1413	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1413	Integer	0
ibdot1sAdminMstID.1414	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1414	Integer	0
ibdot1sAdminMstID.1415	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1415	Integer	0
ibdot1sAdminMstID.1416	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1416	Integer	0
ibdot1sAdminMstID.1417	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1417	Integer	0
ibdot1sAdminMstID.1418	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1418	Integer	0
ibdot1sAdminMstID.1419	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1419	Integer	0
ibdot1sAdminMstID.1420	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1420	Integer	0
ibdot1sAdminMstID.1421	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1421	Integer	0
ibdot1sAdminMstID.1422	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1422	Integer	0
ibdot1sAdminMstID.1423	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1423	Integer	0
ibdot1sAdminMstID.1424	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1424	Integer	0
ibdot1sAdminMstID.1425	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1425	Integer	0
ibdot1sAdminMstID.1426	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1426	Integer	0
ibdot1sAdminMstID.1427	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1427	Integer	0
ibdot1sAdminMstID.1428	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1428	Integer	0
ibdot1sAdminMstID.1429	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1429	Integer	0
ibdot1sAdminMstID.1430	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1430	Integer	0
ibdot1sAdminMstID.1431	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1431	Integer	0
ibdot1sAdminMstID.1432	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1432	Integer	0
ibdot1sAdminMstID.1433	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1433	Integer	0
ibdot1sAdminMstID.1434	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1434	Integer	0
ibdot1sAdminMstID.1435	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1435	Integer	0
ibdot1sAdminMstID.1436	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1436	Integer	0
ibdot1sAdminMstID.1437	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1437	Integer	0
ibdot1sAdminMstID.1438	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1438	Integer	0
ibdot1sAdminMstID.1439	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1439	Integer	0
ibdot1sAdminMstID.1440	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1440	Integer	0
ibdot1sAdminMstID.1441	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1441	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1442	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1442	Integer	0
ibdot1sAdminMstID.1443	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1443	Integer	0
ibdot1sAdminMstID.1444	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1444	Integer	0
ibdot1sAdminMstID.1445	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1445	Integer	0
ibdot1sAdminMstID.1446	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1446	Integer	0
ibdot1sAdminMstID.1447	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1447	Integer	0
ibdot1sAdminMstID.1448	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1448	Integer	0
ibdot1sAdminMstID.1449	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1449	Integer	0
ibdot1sAdminMstID.1450	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1450	Integer	0
ibdot1sAdminMstID.1451	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1451	Integer	0
ibdot1sAdminMstID.1452	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1452	Integer	0
ibdot1sAdminMstID.1453	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1453	Integer	0
ibdot1sAdminMstID.1454	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1454	Integer	0
ibdot1sAdminMstID.1455	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1455	Integer	0
ibdot1sAdminMstID.1456	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1456	Integer	0
ibdot1sAdminMstID.1457	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1457	Integer	0
ibdot1sAdminMstID.1458	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1458	Integer	0
ibdot1sAdminMstID.1459	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1459	Integer	0
ibdot1sAdminMstID.1460	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1460	Integer	0
ibdot1sAdminMstID.1461	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1461	Integer	0
ibdot1sAdminMstID.1462	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1462	Integer	0
ibdot1sAdminMstID.1463	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1463	Integer	0
ibdot1sAdminMstID.1464	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1464	Integer	0
ibdot1sAdminMstID.1465	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1465	Integer	0
ibdot1sAdminMstID.1466	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1466	Integer	0
ibdot1sAdminMstID.1467	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1467	Integer	0
ibdot1sAdminMstID.1468	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1468	Integer	0
ibdot1sAdminMstID.1469	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1469	Integer	0
ibdot1sAdminMstID.1470	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1470	Integer	0
ibdot1sAdminMstID.1471	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1471	Integer	0
ibdot1sAdminMstID.1472	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1472	Integer	0
ibdot1sAdminMstID.1473	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1473	Integer	0
ibdot1sAdminMstID.1474	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1474	Integer	0
ibdot1sAdminMstID.1475	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1475	Integer	0
ibdot1sAdminMstID.1476	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1476	Integer	0
ibdot1sAdminMstID.1477	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1477	Integer	0
ibdot1sAdminMstID.1478	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1478	Integer	0
ibdot1sAdminMstID.1479	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1479	Integer	0
ibdot1sAdminMstID.1480	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1480	Integer	0
ibdot1sAdminMstID.1481	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1481	Integer	0
ibdot1sAdminMstID.1482	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1482	Integer	0
ibdot1sAdminMstID.1483	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1483	Integer	0
ibdot1sAdminMstID.1484	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1484	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1485	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1485	Integer	0
ibdot1sAdminMstID.1486	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1486	Integer	0
ibdot1sAdminMstID.1487	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1487	Integer	0
ibdot1sAdminMstID.1488	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1488	Integer	0
ibdot1sAdminMstID.1489	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1489	Integer	0
ibdot1sAdminMstID.1490	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1490	Integer	0
ibdot1sAdminMstID.1491	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1491	Integer	0
ibdot1sAdminMstID.1492	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1492	Integer	0
ibdot1sAdminMstID.1493	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1493	Integer	0
ibdot1sAdminMstID.1494	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1494	Integer	0
ibdot1sAdminMstID.1495	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1495	Integer	0
ibdot1sAdminMstID.1496	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1496	Integer	0
ibdot1sAdminMstID.1497	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1497	Integer	0
ibdot1sAdminMstID.1498	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1498	Integer	0
ibdot1sAdminMstID.1499	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1499	Integer	0
ibdot1sAdminMstID.1500	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1500	Integer	0
ibdot1sAdminMstID.1501	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1501	Integer	0
ibdot1sAdminMstID.1502	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1502	Integer	0
ibdot1sAdminMstID.1503	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1503	Integer	0
ibdot1sAdminMstID.1504	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1504	Integer	0
ibdot1sAdminMstID.1505	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1505	Integer	0
ibdot1sAdminMstID.1506	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1506	Integer	0
ibdot1sAdminMstID.1507	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1507	Integer	0
ibdot1sAdminMstID.1508	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1508	Integer	0
ibdot1sAdminMstID.1509	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1509	Integer	0
ibdot1sAdminMstID.1510	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1510	Integer	0
ibdot1sAdminMstID.1511	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1511	Integer	0
ibdot1sAdminMstID.1512	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1512	Integer	0
ibdot1sAdminMstID.1513	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1513	Integer	0
ibdot1sAdminMstID.1514	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1514	Integer	0
ibdot1sAdminMstID.1515	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1515	Integer	0
ibdot1sAdminMstID.1516	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1516	Integer	0
ibdot1sAdminMstID.1517	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1517	Integer	0
ibdot1sAdminMstID.1518	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1518	Integer	0
ibdot1sAdminMstID.1519	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1519	Integer	0
ibdot1sAdminMstID.1520	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1520	Integer	0
ibdot1sAdminMstID.1521	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1521	Integer	0
ibdot1sAdminMstID.1522	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1522	Integer	0
ibdot1sAdminMstID.1523	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1523	Integer	0
ibdot1sAdminMstID.1524	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1524	Integer	0
ibdot1sAdminMstID.1525	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1525	Integer	0
ibdot1sAdminMstID.1526	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1526	Integer	0
ibdot1sAdminMstID.1527	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1527	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1528	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1528	Integer	0
ibdot1sAdminMstID.1529	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1529	Integer	0
ibdot1sAdminMstID.1530	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1530	Integer	0
ibdot1sAdminMstID.1531	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1531	Integer	0
ibdot1sAdminMstID.1532	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1532	Integer	0
ibdot1sAdminMstID.1533	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1533	Integer	0
ibdot1sAdminMstID.1534	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1534	Integer	0
ibdot1sAdminMstID.1535	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1535	Integer	0
ibdot1sAdminMstID.1536	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1536	Integer	0
ibdot1sAdminMstID.1537	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1537	Integer	0
ibdot1sAdminMstID.1538	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1538	Integer	0
ibdot1sAdminMstID.1539	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1539	Integer	0
ibdot1sAdminMstID.1540	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1540	Integer	0
ibdot1sAdminMstID.1541	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1541	Integer	0
ibdot1sAdminMstID.1542	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1542	Integer	0
ibdot1sAdminMstID.1543	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1543	Integer	0
ibdot1sAdminMstID.1544	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1544	Integer	0
ibdot1sAdminMstID.1545	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1545	Integer	0
ibdot1sAdminMstID.1546	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1546	Integer	0
ibdot1sAdminMstID.1547	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1547	Integer	0
ibdot1sAdminMstID.1548	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1548	Integer	0
ibdot1sAdminMstID.1549	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1549	Integer	0
ibdot1sAdminMstID.1550	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1550	Integer	0
ibdot1sAdminMstID.1551	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1551	Integer	0
ibdot1sAdminMstID.1552	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1552	Integer	0
ibdot1sAdminMstID.1553	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1553	Integer	0
ibdot1sAdminMstID.1554	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1554	Integer	0
ibdot1sAdminMstID.1555	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1555	Integer	0
ibdot1sAdminMstID.1556	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1556	Integer	0
ibdot1sAdminMstID.1557	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1557	Integer	0
ibdot1sAdminMstID.1558	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1558	Integer	0
ibdot1sAdminMstID.1559	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1559	Integer	0
ibdot1sAdminMstID.1560	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1560	Integer	0
ibdot1sAdminMstID.1561	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1561	Integer	0
ibdot1sAdminMstID.1562	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1562	Integer	0
ibdot1sAdminMstID.1563	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1563	Integer	0
ibdot1sAdminMstID.1564	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1564	Integer	0
ibdot1sAdminMstID.1565	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1565	Integer	0
ibdot1sAdminMstID.1566	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1566	Integer	0
ibdot1sAdminMstID.1567	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1567	Integer	0
ibdot1sAdminMstID.1568	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1568	Integer	0
ibdot1sAdminMstID.1569	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1569	Integer	0
ibdot1sAdminMstID.1570	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1570	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1571	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1571	Integer	0
ibdot1sAdminMstID.1572	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1572	Integer	0
ibdot1sAdminMstID.1573	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1573	Integer	0
ibdot1sAdminMstID.1574	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1574	Integer	0
ibdot1sAdminMstID.1575	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1575	Integer	0
ibdot1sAdminMstID.1576	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1576	Integer	0
ibdot1sAdminMstID.1577	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1577	Integer	0
ibdot1sAdminMstID.1578	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1578	Integer	0
ibdot1sAdminMstID.1579	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1579	Integer	0
ibdot1sAdminMstID.1580	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1580	Integer	0
ibdot1sAdminMstID.1581	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1581	Integer	0
ibdot1sAdminMstID.1582	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1582	Integer	0
ibdot1sAdminMstID.1583	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1583	Integer	0
ibdot1sAdminMstID.1584	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1584	Integer	0
ibdot1sAdminMstID.1585	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1585	Integer	0
ibdot1sAdminMstID.1586	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1586	Integer	0
ibdot1sAdminMstID.1587	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1587	Integer	0
ibdot1sAdminMstID.1588	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1588	Integer	0
ibdot1sAdminMstID.1589	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1589	Integer	0
ibdot1sAdminMstID.1590	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1590	Integer	0
ibdot1sAdminMstID.1591	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1591	Integer	0
ibdot1sAdminMstID.1592	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1592	Integer	0
ibdot1sAdminMstID.1593	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1593	Integer	0
ibdot1sAdminMstID.1594	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1594	Integer	0
ibdot1sAdminMstID.1595	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1595	Integer	0
ibdot1sAdminMstID.1596	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1596	Integer	0
ibdot1sAdminMstID.1597	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1597	Integer	0
ibdot1sAdminMstID.1598	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1598	Integer	0
ibdot1sAdminMstID.1599	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1599	Integer	0
ibdot1sAdminMstID.1600	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1600	Integer	0
ibdot1sAdminMstID.1601	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1601	Integer	0
ibdot1sAdminMstID.1602	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1602	Integer	0
ibdot1sAdminMstID.1603	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1603	Integer	0
ibdot1sAdminMstID.1604	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1604	Integer	0
ibdot1sAdminMstID.1605	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1605	Integer	0
ibdot1sAdminMstID.1606	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1606	Integer	0
ibdot1sAdminMstID.1607	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1607	Integer	0
ibdot1sAdminMstID.1608	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1608	Integer	0
ibdot1sAdminMstID.1609	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1609	Integer	0
ibdot1sAdminMstID.1610	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1610	Integer	0
ibdot1sAdminMstID.1611	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1611	Integer	0
ibdot1sAdminMstID.1612	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1612	Integer	0
ibdot1sAdminMstID.1613	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1613	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1614	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1614	Integer	0
ibdot1sAdminMstID.1615	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1615	Integer	0
ibdot1sAdminMstID.1616	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1616	Integer	0
ibdot1sAdminMstID.1617	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1617	Integer	0
ibdot1sAdminMstID.1618	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1618	Integer	0
ibdot1sAdminMstID.1619	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1619	Integer	0
ibdot1sAdminMstID.1620	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1620	Integer	0
ibdot1sAdminMstID.1621	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1621	Integer	0
ibdot1sAdminMstID.1622	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1622	Integer	0
ibdot1sAdminMstID.1623	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1623	Integer	0
ibdot1sAdminMstID.1624	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1624	Integer	0
ibdot1sAdminMstID.1625	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1625	Integer	0
ibdot1sAdminMstID.1626	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1626	Integer	0
ibdot1sAdminMstID.1627	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1627	Integer	0
ibdot1sAdminMstID.1628	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1628	Integer	0
ibdot1sAdminMstID.1629	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1629	Integer	0
ibdot1sAdminMstID.1630	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1630	Integer	0
ibdot1sAdminMstID.1631	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1631	Integer	0
ibdot1sAdminMstID.1632	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1632	Integer	0
ibdot1sAdminMstID.1633	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1633	Integer	0
ibdot1sAdminMstID.1634	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1634	Integer	0
ibdot1sAdminMstID.1635	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1635	Integer	0
ibdot1sAdminMstID.1636	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1636	Integer	0
ibdot1sAdminMstID.1637	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1637	Integer	0
ibdot1sAdminMstID.1638	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1638	Integer	0
ibdot1sAdminMstID.1639	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1639	Integer	0
ibdot1sAdminMstID.1640	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1640	Integer	0
ibdot1sAdminMstID.1641	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1641	Integer	0
ibdot1sAdminMstID.1642	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1642	Integer	0
ibdot1sAdminMstID.1643	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1643	Integer	0
ibdot1sAdminMstID.1644	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1644	Integer	0
ibdot1sAdminMstID.1645	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1645	Integer	0
ibdot1sAdminMstID.1646	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1646	Integer	0
ibdot1sAdminMstID.1647	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1647	Integer	0
ibdot1sAdminMstID.1648	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1648	Integer	0
ibdot1sAdminMstID.1649	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1649	Integer	0
ibdot1sAdminMstID.1650	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1650	Integer	0
ibdot1sAdminMstID.1651	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1651	Integer	0
ibdot1sAdminMstID.1652	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1652	Integer	0
ibdot1sAdminMstID.1653	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1653	Integer	0
ibdot1sAdminMstID.1654	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1654	Integer	0
ibdot1sAdminMstID.1655	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1655	Integer	0
ibdot1sAdminMstID.1656	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1656	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1657	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1657	Integer	0
ibdot1sAdminMstID.1658	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1658	Integer	0
ibdot1sAdminMstID.1659	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1659	Integer	0
ibdot1sAdminMstID.1660	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1660	Integer	0
ibdot1sAdminMstID.1661	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1661	Integer	0
ibdot1sAdminMstID.1662	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1662	Integer	0
ibdot1sAdminMstID.1663	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1663	Integer	0
ibdot1sAdminMstID.1664	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1664	Integer	0
ibdot1sAdminMstID.1665	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1665	Integer	0
ibdot1sAdminMstID.1666	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1666	Integer	0
ibdot1sAdminMstID.1667	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1667	Integer	0
ibdot1sAdminMstID.1668	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1668	Integer	0
ibdot1sAdminMstID.1669	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1669	Integer	0
ibdot1sAdminMstID.1670	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1670	Integer	0
ibdot1sAdminMstID.1671	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1671	Integer	0
ibdot1sAdminMstID.1672	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1672	Integer	0
ibdot1sAdminMstID.1673	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1673	Integer	0
ibdot1sAdminMstID.1674	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1674	Integer	0
ibdot1sAdminMstID.1675	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1675	Integer	0
ibdot1sAdminMstID.1676	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1676	Integer	0
ibdot1sAdminMstID.1677	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1677	Integer	0
ibdot1sAdminMstID.1678	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1678	Integer	0
ibdot1sAdminMstID.1679	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1679	Integer	0
ibdot1sAdminMstID.1680	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1680	Integer	0
ibdot1sAdminMstID.1681	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1681	Integer	0
ibdot1sAdminMstID.1682	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1682	Integer	0
ibdot1sAdminMstID.1683	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1683	Integer	0
ibdot1sAdminMstID.1684	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1684	Integer	0
ibdot1sAdminMstID.1685	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1685	Integer	0
ibdot1sAdminMstID.1686	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1686	Integer	0
ibdot1sAdminMstID.1687	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1687	Integer	0
ibdot1sAdminMstID.1688	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1688	Integer	0
ibdot1sAdminMstID.1689	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1689	Integer	0
ibdot1sAdminMstID.1690	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1690	Integer	0
ibdot1sAdminMstID.1691	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1691	Integer	0
ibdot1sAdminMstID.1692	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1692	Integer	0
ibdot1sAdminMstID.1693	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1693	Integer	0
ibdot1sAdminMstID.1694	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1694	Integer	0
ibdot1sAdminMstID.1695	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1695	Integer	0
ibdot1sAdminMstID.1696	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1696	Integer	0
ibdot1sAdminMstID.1697	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1697	Integer	0
ibdot1sAdminMstID.1698	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1698	Integer	0
ibdot1sAdminMstID.1699	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1699	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1700	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1700	Integer	0
ibdot1sAdminMstID.1701	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1701	Integer	0
ibdot1sAdminMstID.1702	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1702	Integer	0
ibdot1sAdminMstID.1703	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1703	Integer	0
ibdot1sAdminMstID.1704	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1704	Integer	0
ibdot1sAdminMstID.1705	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1705	Integer	0
ibdot1sAdminMstID.1706	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1706	Integer	0
ibdot1sAdminMstID.1707	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1707	Integer	0
ibdot1sAdminMstID.1708	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1708	Integer	0
ibdot1sAdminMstID.1709	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1709	Integer	0
ibdot1sAdminMstID.1710	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1710	Integer	0
ibdot1sAdminMstID.1711	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1711	Integer	0
ibdot1sAdminMstID.1712	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1712	Integer	0
ibdot1sAdminMstID.1713	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1713	Integer	0
ibdot1sAdminMstID.1714	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1714	Integer	0
ibdot1sAdminMstID.1715	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1715	Integer	0
ibdot1sAdminMstID.1716	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1716	Integer	0
ibdot1sAdminMstID.1717	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1717	Integer	0
ibdot1sAdminMstID.1718	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1718	Integer	0
ibdot1sAdminMstID.1719	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1719	Integer	0
ibdot1sAdminMstID.1720	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1720	Integer	0
ibdot1sAdminMstID.1721	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1721	Integer	0
ibdot1sAdminMstID.1722	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1722	Integer	0
ibdot1sAdminMstID.1723	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1723	Integer	0
ibdot1sAdminMstID.1724	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1724	Integer	0
ibdot1sAdminMstID.1725	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1725	Integer	0
ibdot1sAdminMstID.1726	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1726	Integer	0
ibdot1sAdminMstID.1727	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1727	Integer	0
ibdot1sAdminMstID.1728	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1728	Integer	0
ibdot1sAdminMstID.1729	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1729	Integer	0
ibdot1sAdminMstID.1730	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1730	Integer	0
ibdot1sAdminMstID.1731	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1731	Integer	0
ibdot1sAdminMstID.1732	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1732	Integer	0
ibdot1sAdminMstID.1733	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1733	Integer	0
ibdot1sAdminMstID.1734	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1734	Integer	0
ibdot1sAdminMstID.1735	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1735	Integer	0
ibdot1sAdminMstID.1736	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1736	Integer	0
ibdot1sAdminMstID.1737	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1737	Integer	0
ibdot1sAdminMstID.1738	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1738	Integer	0
ibdot1sAdminMstID.1739	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1739	Integer	0
ibdot1sAdminMstID.1740	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1740	Integer	0
ibdot1sAdminMstID.1741	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1741	Integer	0
ibdot1sAdminMstID.1742	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1742	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1743	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1743	Integer	0
ibdot1sAdminMstID.1744	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1744	Integer	0
ibdot1sAdminMstID.1745	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1745	Integer	0
ibdot1sAdminMstID.1746	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1746	Integer	0
ibdot1sAdminMstID.1747	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1747	Integer	0
ibdot1sAdminMstID.1748	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1748	Integer	0
ibdot1sAdminMstID.1749	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1749	Integer	0
ibdot1sAdminMstID.1750	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1750	Integer	0
ibdot1sAdminMstID.1751	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1751	Integer	0
ibdot1sAdminMstID.1752	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1752	Integer	0
ibdot1sAdminMstID.1753	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1753	Integer	0
ibdot1sAdminMstID.1754	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1754	Integer	0
ibdot1sAdminMstID.1755	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1755	Integer	0
ibdot1sAdminMstID.1756	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1756	Integer	0
ibdot1sAdminMstID.1757	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1757	Integer	0
ibdot1sAdminMstID.1758	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1758	Integer	0
ibdot1sAdminMstID.1759	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1759	Integer	0
ibdot1sAdminMstID.1760	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1760	Integer	0
ibdot1sAdminMstID.1761	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1761	Integer	0
ibdot1sAdminMstID.1762	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1762	Integer	0
ibdot1sAdminMstID.1763	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1763	Integer	0
ibdot1sAdminMstID.1764	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1764	Integer	0
ibdot1sAdminMstID.1765	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1765	Integer	0
ibdot1sAdminMstID.1766	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1766	Integer	0
ibdot1sAdminMstID.1767	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1767	Integer	0
ibdot1sAdminMstID.1768	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1768	Integer	0
ibdot1sAdminMstID.1769	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1769	Integer	0
ibdot1sAdminMstID.1770	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1770	Integer	0
ibdot1sAdminMstID.1771	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1771	Integer	0
ibdot1sAdminMstID.1772	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1772	Integer	0
ibdot1sAdminMstID.1773	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1773	Integer	0
ibdot1sAdminMstID.1774	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1774	Integer	0
ibdot1sAdminMstID.1775	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1775	Integer	0
ibdot1sAdminMstID.1776	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1776	Integer	0
ibdot1sAdminMstID.1777	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1777	Integer	0
ibdot1sAdminMstID.1778	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1778	Integer	0
ibdot1sAdminMstID.1779	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1779	Integer	0
ibdot1sAdminMstID.1780	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1780	Integer	0
ibdot1sAdminMstID.1781	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1781	Integer	0
ibdot1sAdminMstID.1782	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1782	Integer	0
ibdot1sAdminMstID.1783	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1783	Integer	0
ibdot1sAdminMstID.1784	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1784	Integer	0
ibdot1sAdminMstID.1785	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1785	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1786	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1786	Integer	0
ibdot1sAdminMstID.1787	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1787	Integer	0
ibdot1sAdminMstID.1788	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1788	Integer	0
ibdot1sAdminMstID.1789	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1789	Integer	0
ibdot1sAdminMstID.1790	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1790	Integer	0
ibdot1sAdminMstID.1791	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1791	Integer	0
ibdot1sAdminMstID.1792	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1792	Integer	0
ibdot1sAdminMstID.1793	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1793	Integer	0
ibdot1sAdminMstID.1794	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1794	Integer	0
ibdot1sAdminMstID.1795	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1795	Integer	0
ibdot1sAdminMstID.1796	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1796	Integer	0
ibdot1sAdminMstID.1797	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1797	Integer	0
ibdot1sAdminMstID.1798	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1798	Integer	0
ibdot1sAdminMstID.1799	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1799	Integer	0
ibdot1sAdminMstID.1800	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1800	Integer	0
ibdot1sAdminMstID.1801	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1801	Integer	0
ibdot1sAdminMstID.1802	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1802	Integer	0
ibdot1sAdminMstID.1803	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1803	Integer	0
ibdot1sAdminMstID.1804	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1804	Integer	0
ibdot1sAdminMstID.1805	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1805	Integer	0
ibdot1sAdminMstID.1806	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1806	Integer	0
ibdot1sAdminMstID.1807	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1807	Integer	0
ibdot1sAdminMstID.1808	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1808	Integer	0
ibdot1sAdminMstID.1809	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1809	Integer	0
ibdot1sAdminMstID.1810	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1810	Integer	0
ibdot1sAdminMstID.1811	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1811	Integer	0
ibdot1sAdminMstID.1812	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1812	Integer	0
ibdot1sAdminMstID.1813	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1813	Integer	0
ibdot1sAdminMstID.1814	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1814	Integer	0
ibdot1sAdminMstID.1815	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1815	Integer	0
ibdot1sAdminMstID.1816	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1816	Integer	0
ibdot1sAdminMstID.1817	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1817	Integer	0
ibdot1sAdminMstID.1818	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1818	Integer	0
ibdot1sAdminMstID.1819	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1819	Integer	0
ibdot1sAdminMstID.1820	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1820	Integer	0
ibdot1sAdminMstID.1821	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1821	Integer	0
ibdot1sAdminMstID.1822	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1822	Integer	0
ibdot1sAdminMstID.1823	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1823	Integer	0
ibdot1sAdminMstID.1824	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1824	Integer	0
ibdot1sAdminMstID.1825	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1825	Integer	0
ibdot1sAdminMstID.1826	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1826	Integer	0
ibdot1sAdminMstID.1827	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1827	Integer	0
ibdot1sAdminMstID.1828	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1828	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1829	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1829	Integer	0
ibdot1sAdminMstID.1830	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1830	Integer	0
ibdot1sAdminMstID.1831	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1831	Integer	0
ibdot1sAdminMstID.1832	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1832	Integer	0
ibdot1sAdminMstID.1833	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1833	Integer	0
ibdot1sAdminMstID.1834	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1834	Integer	0
ibdot1sAdminMstID.1835	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1835	Integer	0
ibdot1sAdminMstID.1836	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1836	Integer	0
ibdot1sAdminMstID.1837	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1837	Integer	0
ibdot1sAdminMstID.1838	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1838	Integer	0
ibdot1sAdminMstID.1839	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1839	Integer	0
ibdot1sAdminMstID.1840	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1840	Integer	0
ibdot1sAdminMstID.1841	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1841	Integer	0
ibdot1sAdminMstID.1842	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1842	Integer	0
ibdot1sAdminMstID.1843	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1843	Integer	0
ibdot1sAdminMstID.1844	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1844	Integer	0
ibdot1sAdminMstID.1845	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1845	Integer	0
ibdot1sAdminMstID.1846	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1846	Integer	0
ibdot1sAdminMstID.1847	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1847	Integer	0
ibdot1sAdminMstID.1848	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1848	Integer	0
ibdot1sAdminMstID.1849	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1849	Integer	0
ibdot1sAdminMstID.1850	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1850	Integer	0
ibdot1sAdminMstID.1851	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1851	Integer	0
ibdot1sAdminMstID.1852	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1852	Integer	0
ibdot1sAdminMstID.1853	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1853	Integer	0
ibdot1sAdminMstID.1854	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1854	Integer	0
ibdot1sAdminMstID.1855	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1855	Integer	0
ibdot1sAdminMstID.1856	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1856	Integer	0
ibdot1sAdminMstID.1857	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1857	Integer	0
ibdot1sAdminMstID.1858	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1858	Integer	0
ibdot1sAdminMstID.1859	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1859	Integer	0
ibdot1sAdminMstID.1860	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1860	Integer	0
ibdot1sAdminMstID.1861	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1861	Integer	0
ibdot1sAdminMstID.1862	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1862	Integer	0
ibdot1sAdminMstID.1863	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1863	Integer	0
ibdot1sAdminMstID.1864	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1864	Integer	0
ibdot1sAdminMstID.1865	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1865	Integer	0
ibdot1sAdminMstID.1866	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1866	Integer	0
ibdot1sAdminMstID.1867	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1867	Integer	0
ibdot1sAdminMstID.1868	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1868	Integer	0
ibdot1sAdminMstID.1869	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1869	Integer	0
ibdot1sAdminMstID.1870	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1870	Integer	0
ibdot1sAdminMstID.1871	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1871	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1872	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1872	Integer	0
ibdot1sAdminMstID.1873	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1873	Integer	0
ibdot1sAdminMstID.1874	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1874	Integer	0
ibdot1sAdminMstID.1875	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1875	Integer	0
ibdot1sAdminMstID.1876	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1876	Integer	0
ibdot1sAdminMstID.1877	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1877	Integer	0
ibdot1sAdminMstID.1878	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1878	Integer	0
ibdot1sAdminMstID.1879	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1879	Integer	0
ibdot1sAdminMstID.1880	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1880	Integer	0
ibdot1sAdminMstID.1881	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1881	Integer	0
ibdot1sAdminMstID.1882	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1882	Integer	0
ibdot1sAdminMstID.1883	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1883	Integer	0
ibdot1sAdminMstID.1884	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1884	Integer	0
ibdot1sAdminMstID.1885	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1885	Integer	0
ibdot1sAdminMstID.1886	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1886	Integer	0
ibdot1sAdminMstID.1887	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1887	Integer	0
ibdot1sAdminMstID.1888	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1888	Integer	0
ibdot1sAdminMstID.1889	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1889	Integer	0
ibdot1sAdminMstID.1890	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1890	Integer	0
ibdot1sAdminMstID.1891	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1891	Integer	0
ibdot1sAdminMstID.1892	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1892	Integer	0
ibdot1sAdminMstID.1893	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1893	Integer	0
ibdot1sAdminMstID.1894	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1894	Integer	0
ibdot1sAdminMstID.1895	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1895	Integer	0
ibdot1sAdminMstID.1896	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1896	Integer	0
ibdot1sAdminMstID.1897	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1897	Integer	0
ibdot1sAdminMstID.1898	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1898	Integer	0
ibdot1sAdminMstID.1899	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1899	Integer	0
ibdot1sAdminMstID.1900	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1900	Integer	0
ibdot1sAdminMstID.1901	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1901	Integer	0
ibdot1sAdminMstID.1902	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1902	Integer	0
ibdot1sAdminMstID.1903	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1903	Integer	0
ibdot1sAdminMstID.1904	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1904	Integer	0
ibdot1sAdminMstID.1905	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1905	Integer	0
ibdot1sAdminMstID.1906	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1906	Integer	0
ibdot1sAdminMstID.1907	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1907	Integer	0
ibdot1sAdminMstID.1908	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1908	Integer	0
ibdot1sAdminMstID.1909	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1909	Integer	0
ibdot1sAdminMstID.1910	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1910	Integer	0
ibdot1sAdminMstID.1911	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1911	Integer	0
ibdot1sAdminMstID.1912	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1912	Integer	0
ibdot1sAdminMstID.1913	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1913	Integer	0
ibdot1sAdminMstID.1914	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1914	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1915	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1915	Integer	0
ibdot1sAdminMstID.1916	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1916	Integer	0
ibdot1sAdminMstID.1917	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1917	Integer	0
ibdot1sAdminMstID.1918	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1918	Integer	0
ibdot1sAdminMstID.1919	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1919	Integer	0
ibdot1sAdminMstID.1920	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1920	Integer	0
ibdot1sAdminMstID.1921	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1921	Integer	0
ibdot1sAdminMstID.1922	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1922	Integer	0
ibdot1sAdminMstID.1923	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1923	Integer	0
ibdot1sAdminMstID.1924	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1924	Integer	0
ibdot1sAdminMstID.1925	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1925	Integer	0
ibdot1sAdminMstID.1926	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1926	Integer	0
ibdot1sAdminMstID.1927	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1927	Integer	0
ibdot1sAdminMstID.1928	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1928	Integer	0
ibdot1sAdminMstID.1929	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1929	Integer	0
ibdot1sAdminMstID.1930	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1930	Integer	0
ibdot1sAdminMstID.1931	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1931	Integer	0
ibdot1sAdminMstID.1932	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1932	Integer	0
ibdot1sAdminMstID.1933	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1933	Integer	0
ibdot1sAdminMstID.1934	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1934	Integer	0
ibdot1sAdminMstID.1935	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1935	Integer	0
ibdot1sAdminMstID.1936	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1936	Integer	0
ibdot1sAdminMstID.1937	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1937	Integer	0
ibdot1sAdminMstID.1938	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1938	Integer	0
ibdot1sAdminMstID.1939	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1939	Integer	0
ibdot1sAdminMstID.1940	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1940	Integer	0
ibdot1sAdminMstID.1941	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1941	Integer	0
ibdot1sAdminMstID.1942	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1942	Integer	0
ibdot1sAdminMstID.1943	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1943	Integer	0
ibdot1sAdminMstID.1944	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1944	Integer	0
ibdot1sAdminMstID.1945	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1945	Integer	0
ibdot1sAdminMstID.1946	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1946	Integer	0
ibdot1sAdminMstID.1947	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1947	Integer	0
ibdot1sAdminMstID.1948	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1948	Integer	0
ibdot1sAdminMstID.1949	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1949	Integer	0
ibdot1sAdminMstID.1950	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1950	Integer	0
ibdot1sAdminMstID.1951	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1951	Integer	0
ibdot1sAdminMstID.1952	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1952	Integer	0
ibdot1sAdminMstID.1953	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1953	Integer	0
ibdot1sAdminMstID.1954	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1954	Integer	0
ibdot1sAdminMstID.1955	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1955	Integer	0
ibdot1sAdminMstID.1956	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1956	Integer	0
ibdot1sAdminMstID.1957	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1957	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.1958	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1958	Integer	0
ibdot1sAdminMstID.1959	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1959	Integer	0
ibdot1sAdminMstID.1960	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1960	Integer	0
ibdot1sAdminMstID.1961	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1961	Integer	0
ibdot1sAdminMstID.1962	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1962	Integer	0
ibdot1sAdminMstID.1963	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1963	Integer	0
ibdot1sAdminMstID.1964	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1964	Integer	0
ibdot1sAdminMstID.1965	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1965	Integer	0
ibdot1sAdminMstID.1966	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1966	Integer	0
ibdot1sAdminMstID.1967	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1967	Integer	0
ibdot1sAdminMstID.1968	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1968	Integer	0
ibdot1sAdminMstID.1969	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1969	Integer	0
ibdot1sAdminMstID.1970	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1970	Integer	0
ibdot1sAdminMstID.1971	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1971	Integer	0
ibdot1sAdminMstID.1972	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1972	Integer	0
ibdot1sAdminMstID.1973	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1973	Integer	0
ibdot1sAdminMstID.1974	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1974	Integer	0
ibdot1sAdminMstID.1975	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1975	Integer	0
ibdot1sAdminMstID.1976	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1976	Integer	0
ibdot1sAdminMstID.1977	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1977	Integer	0
ibdot1sAdminMstID.1978	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1978	Integer	0
ibdot1sAdminMstID.1979	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1979	Integer	0
ibdot1sAdminMstID.1980	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1980	Integer	0
ibdot1sAdminMstID.1981	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1981	Integer	0
ibdot1sAdminMstID.1982	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1982	Integer	0
ibdot1sAdminMstID.1983	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1983	Integer	0
ibdot1sAdminMstID.1984	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1984	Integer	0
ibdot1sAdminMstID.1985	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1985	Integer	0
ibdot1sAdminMstID.1986	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1986	Integer	0
ibdot1sAdminMstID.1987	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1987	Integer	0
ibdot1sAdminMstID.1988	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1988	Integer	0
ibdot1sAdminMstID.1989	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1989	Integer	0
ibdot1sAdminMstID.1990	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1990	Integer	0
ibdot1sAdminMstID.1991	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1991	Integer	0
ibdot1sAdminMstID.1992	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1992	Integer	0
ibdot1sAdminMstID.1993	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1993	Integer	0
ibdot1sAdminMstID.1994	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1994	Integer	0
ibdot1sAdminMstID.1995	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1995	Integer	0
ibdot1sAdminMstID.1996	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1996	Integer	0
ibdot1sAdminMstID.1997	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1997	Integer	0
ibdot1sAdminMstID.1998	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1998	Integer	0
ibdot1sAdminMstID.1999	.1.3.6.1.4.1.26138.8.35.14.18.1.2.1999	Integer	0
ibdot1sAdminMstID.2000	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2000	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2001	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2001	Integer	0
ibdot1sAdminMstID.2002	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2002	Integer	0
ibdot1sAdminMstID.2003	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2003	Integer	0
ibdot1sAdminMstID.2004	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2004	Integer	0
ibdot1sAdminMstID.2005	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2005	Integer	0
ibdot1sAdminMstID.2006	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2006	Integer	0
ibdot1sAdminMstID.2007	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2007	Integer	0
ibdot1sAdminMstID.2008	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2008	Integer	0
ibdot1sAdminMstID.2009	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2009	Integer	0
ibdot1sAdminMstID.2010	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2010	Integer	0
ibdot1sAdminMstID.2011	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2011	Integer	0
ibdot1sAdminMstID.2012	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2012	Integer	0
ibdot1sAdminMstID.2013	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2013	Integer	0
ibdot1sAdminMstID.2014	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2014	Integer	0
ibdot1sAdminMstID.2015	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2015	Integer	0
ibdot1sAdminMstID.2016	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2016	Integer	0
ibdot1sAdminMstID.2017	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2017	Integer	0
ibdot1sAdminMstID.2018	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2018	Integer	0
ibdot1sAdminMstID.2019	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2019	Integer	0
ibdot1sAdminMstID.2020	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2020	Integer	0
ibdot1sAdminMstID.2021	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2021	Integer	0
ibdot1sAdminMstID.2022	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2022	Integer	0
ibdot1sAdminMstID.2023	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2023	Integer	0
ibdot1sAdminMstID.2024	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2024	Integer	0
ibdot1sAdminMstID.2025	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2025	Integer	0
ibdot1sAdminMstID.2026	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2026	Integer	0
ibdot1sAdminMstID.2027	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2027	Integer	0
ibdot1sAdminMstID.2028	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2028	Integer	0
ibdot1sAdminMstID.2029	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2029	Integer	0
ibdot1sAdminMstID.2030	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2030	Integer	0
ibdot1sAdminMstID.2031	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2031	Integer	0
ibdot1sAdminMstID.2032	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2032	Integer	0
ibdot1sAdminMstID.2033	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2033	Integer	0
ibdot1sAdminMstID.2034	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2034	Integer	0
ibdot1sAdminMstID.2035	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2035	Integer	0
ibdot1sAdminMstID.2036	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2036	Integer	0
ibdot1sAdminMstID.2037	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2037	Integer	0
ibdot1sAdminMstID.2038	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2038	Integer	0
ibdot1sAdminMstID.2039	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2039	Integer	0
ibdot1sAdminMstID.2040	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2040	Integer	0
ibdot1sAdminMstID.2041	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2041	Integer	0
ibdot1sAdminMstID.2042	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2042	Integer	0
ibdot1sAdminMstID.2043	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2043	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2044	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2044	Integer	0
ibdot1sAdminMstID.2045	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2045	Integer	0
ibdot1sAdminMstID.2046	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2046	Integer	0
ibdot1sAdminMstID.2047	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2047	Integer	0
ibdot1sAdminMstID.2048	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2048	Integer	0
ibdot1sAdminMstID.2049	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2049	Integer	0
ibdot1sAdminMstID.2050	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2050	Integer	0
ibdot1sAdminMstID.2051	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2051	Integer	0
ibdot1sAdminMstID.2052	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2052	Integer	0
ibdot1sAdminMstID.2053	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2053	Integer	0
ibdot1sAdminMstID.2054	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2054	Integer	0
ibdot1sAdminMstID.2055	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2055	Integer	0
ibdot1sAdminMstID.2056	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2056	Integer	0
ibdot1sAdminMstID.2057	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2057	Integer	0
ibdot1sAdminMstID.2058	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2058	Integer	0
ibdot1sAdminMstID.2059	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2059	Integer	0
ibdot1sAdminMstID.2060	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2060	Integer	0
ibdot1sAdminMstID.2061	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2061	Integer	0
ibdot1sAdminMstID.2062	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2062	Integer	0
ibdot1sAdminMstID.2063	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2063	Integer	0
ibdot1sAdminMstID.2064	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2064	Integer	0
ibdot1sAdminMstID.2065	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2065	Integer	0
ibdot1sAdminMstID.2066	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2066	Integer	0
ibdot1sAdminMstID.2067	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2067	Integer	0
ibdot1sAdminMstID.2068	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2068	Integer	0
ibdot1sAdminMstID.2069	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2069	Integer	0
ibdot1sAdminMstID.2070	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2070	Integer	0
ibdot1sAdminMstID.2071	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2071	Integer	0
ibdot1sAdminMstID.2072	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2072	Integer	0
ibdot1sAdminMstID.2073	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2073	Integer	0
ibdot1sAdminMstID.2074	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2074	Integer	0
ibdot1sAdminMstID.2075	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2075	Integer	0
ibdot1sAdminMstID.2076	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2076	Integer	0
ibdot1sAdminMstID.2077	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2077	Integer	0
ibdot1sAdminMstID.2078	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2078	Integer	0
ibdot1sAdminMstID.2079	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2079	Integer	0
ibdot1sAdminMstID.2080	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2080	Integer	0
ibdot1sAdminMstID.2081	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2081	Integer	0
ibdot1sAdminMstID.2082	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2082	Integer	0
ibdot1sAdminMstID.2083	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2083	Integer	0
ibdot1sAdminMstID.2084	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2084	Integer	0
ibdot1sAdminMstID.2085	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2085	Integer	0
ibdot1sAdminMstID.2086	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2086	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2087	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2087	Integer	0
ibdot1sAdminMstID.2088	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2088	Integer	0
ibdot1sAdminMstID.2089	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2089	Integer	0
ibdot1sAdminMstID.2090	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2090	Integer	0
ibdot1sAdminMstID.2091	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2091	Integer	0
ibdot1sAdminMstID.2092	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2092	Integer	0
ibdot1sAdminMstID.2093	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2093	Integer	0
ibdot1sAdminMstID.2094	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2094	Integer	0
ibdot1sAdminMstID.2095	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2095	Integer	0
ibdot1sAdminMstID.2096	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2096	Integer	0
ibdot1sAdminMstID.2097	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2097	Integer	0
ibdot1sAdminMstID.2098	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2098	Integer	0
ibdot1sAdminMstID.2099	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2099	Integer	0
ibdot1sAdminMstID.2100	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2100	Integer	0
ibdot1sAdminMstID.2101	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2101	Integer	0
ibdot1sAdminMstID.2102	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2102	Integer	0
ibdot1sAdminMstID.2103	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2103	Integer	0
ibdot1sAdminMstID.2104	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2104	Integer	0
ibdot1sAdminMstID.2105	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2105	Integer	0
ibdot1sAdminMstID.2106	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2106	Integer	0
ibdot1sAdminMstID.2107	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2107	Integer	0
ibdot1sAdminMstID.2108	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2108	Integer	0
ibdot1sAdminMstID.2109	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2109	Integer	0
ibdot1sAdminMstID.2110	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2110	Integer	0
ibdot1sAdminMstID.2111	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2111	Integer	0
ibdot1sAdminMstID.2112	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2112	Integer	0
ibdot1sAdminMstID.2113	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2113	Integer	0
ibdot1sAdminMstID.2114	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2114	Integer	0
ibdot1sAdminMstID.2115	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2115	Integer	0
ibdot1sAdminMstID.2116	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2116	Integer	0
ibdot1sAdminMstID.2117	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2117	Integer	0
ibdot1sAdminMstID.2118	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2118	Integer	0
ibdot1sAdminMstID.2119	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2119	Integer	0
ibdot1sAdminMstID.2120	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2120	Integer	0
ibdot1sAdminMstID.2121	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2121	Integer	0
ibdot1sAdminMstID.2122	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2122	Integer	0
ibdot1sAdminMstID.2123	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2123	Integer	0
ibdot1sAdminMstID.2124	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2124	Integer	0
ibdot1sAdminMstID.2125	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2125	Integer	0
ibdot1sAdminMstID.2126	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2126	Integer	0
ibdot1sAdminMstID.2127	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2127	Integer	0
ibdot1sAdminMstID.2128	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2128	Integer	0
ibdot1sAdminMstID.2129	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2129	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2130	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2130	Integer	0
ibdot1sAdminMstID.2131	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2131	Integer	0
ibdot1sAdminMstID.2132	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2132	Integer	0
ibdot1sAdminMstID.2133	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2133	Integer	0
ibdot1sAdminMstID.2134	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2134	Integer	0
ibdot1sAdminMstID.2135	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2135	Integer	0
ibdot1sAdminMstID.2136	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2136	Integer	0
ibdot1sAdminMstID.2137	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2137	Integer	0
ibdot1sAdminMstID.2138	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2138	Integer	0
ibdot1sAdminMstID.2139	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2139	Integer	0
ibdot1sAdminMstID.2140	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2140	Integer	0
ibdot1sAdminMstID.2141	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2141	Integer	0
ibdot1sAdminMstID.2142	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2142	Integer	0
ibdot1sAdminMstID.2143	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2143	Integer	0
ibdot1sAdminMstID.2144	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2144	Integer	0
ibdot1sAdminMstID.2145	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2145	Integer	0
ibdot1sAdminMstID.2146	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2146	Integer	0
ibdot1sAdminMstID.2147	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2147	Integer	0
ibdot1sAdminMstID.2148	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2148	Integer	0
ibdot1sAdminMstID.2149	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2149	Integer	0
ibdot1sAdminMstID.2150	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2150	Integer	0
ibdot1sAdminMstID.2151	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2151	Integer	0
ibdot1sAdminMstID.2152	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2152	Integer	0
ibdot1sAdminMstID.2153	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2153	Integer	0
ibdot1sAdminMstID.2154	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2154	Integer	0
ibdot1sAdminMstID.2155	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2155	Integer	0
ibdot1sAdminMstID.2156	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2156	Integer	0
ibdot1sAdminMstID.2157	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2157	Integer	0
ibdot1sAdminMstID.2158	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2158	Integer	0
ibdot1sAdminMstID.2159	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2159	Integer	0
ibdot1sAdminMstID.2160	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2160	Integer	0
ibdot1sAdminMstID.2161	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2161	Integer	0
ibdot1sAdminMstID.2162	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2162	Integer	0
ibdot1sAdminMstID.2163	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2163	Integer	0
ibdot1sAdminMstID.2164	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2164	Integer	0
ibdot1sAdminMstID.2165	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2165	Integer	0
ibdot1sAdminMstID.2166	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2166	Integer	0
ibdot1sAdminMstID.2167	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2167	Integer	0
ibdot1sAdminMstID.2168	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2168	Integer	0
ibdot1sAdminMstID.2169	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2169	Integer	0
ibdot1sAdminMstID.2170	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2170	Integer	0
ibdot1sAdminMstID.2171	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2171	Integer	0
ibdot1sAdminMstID.2172	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2172	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2173	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2173	Integer	0
ibdot1sAdminMstID.2174	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2174	Integer	0
ibdot1sAdminMstID.2175	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2175	Integer	0
ibdot1sAdminMstID.2176	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2176	Integer	0
ibdot1sAdminMstID.2177	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2177	Integer	0
ibdot1sAdminMstID.2178	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2178	Integer	0
ibdot1sAdminMstID.2179	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2179	Integer	0
ibdot1sAdminMstID.2180	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2180	Integer	0
ibdot1sAdminMstID.2181	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2181	Integer	0
ibdot1sAdminMstID.2182	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2182	Integer	0
ibdot1sAdminMstID.2183	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2183	Integer	0
ibdot1sAdminMstID.2184	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2184	Integer	0
ibdot1sAdminMstID.2185	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2185	Integer	0
ibdot1sAdminMstID.2186	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2186	Integer	0
ibdot1sAdminMstID.2187	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2187	Integer	0
ibdot1sAdminMstID.2188	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2188	Integer	0
ibdot1sAdminMstID.2189	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2189	Integer	0
ibdot1sAdminMstID.2190	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2190	Integer	0
ibdot1sAdminMstID.2191	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2191	Integer	0
ibdot1sAdminMstID.2192	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2192	Integer	0
ibdot1sAdminMstID.2193	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2193	Integer	0
ibdot1sAdminMstID.2194	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2194	Integer	0
ibdot1sAdminMstID.2195	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2195	Integer	0
ibdot1sAdminMstID.2196	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2196	Integer	0
ibdot1sAdminMstID.2197	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2197	Integer	0
ibdot1sAdminMstID.2198	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2198	Integer	0
ibdot1sAdminMstID.2199	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2199	Integer	0
ibdot1sAdminMstID.2200	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2200	Integer	0
ibdot1sAdminMstID.2201	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2201	Integer	0
ibdot1sAdminMstID.2202	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2202	Integer	0
ibdot1sAdminMstID.2203	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2203	Integer	0
ibdot1sAdminMstID.2204	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2204	Integer	0
ibdot1sAdminMstID.2205	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2205	Integer	0
ibdot1sAdminMstID.2206	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2206	Integer	0
ibdot1sAdminMstID.2207	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2207	Integer	0
ibdot1sAdminMstID.2208	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2208	Integer	0
ibdot1sAdminMstID.2209	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2209	Integer	0
ibdot1sAdminMstID.2210	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2210	Integer	0
ibdot1sAdminMstID.2211	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2211	Integer	0
ibdot1sAdminMstID.2212	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2212	Integer	0
ibdot1sAdminMstID.2213	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2213	Integer	0
ibdot1sAdminMstID.2214	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2214	Integer	0
ibdot1sAdminMstID.2215	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2215	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2216	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2216	Integer	0
ibdot1sAdminMstID.2217	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2217	Integer	0
ibdot1sAdminMstID.2218	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2218	Integer	0
ibdot1sAdminMstID.2219	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2219	Integer	0
ibdot1sAdminMstID.2220	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2220	Integer	0
ibdot1sAdminMstID.2221	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2221	Integer	0
ibdot1sAdminMstID.2222	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2222	Integer	0
ibdot1sAdminMstID.2223	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2223	Integer	0
ibdot1sAdminMstID.2224	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2224	Integer	0
ibdot1sAdminMstID.2225	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2225	Integer	0
ibdot1sAdminMstID.2226	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2226	Integer	0
ibdot1sAdminMstID.2227	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2227	Integer	0
ibdot1sAdminMstID.2228	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2228	Integer	0
ibdot1sAdminMstID.2229	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2229	Integer	0
ibdot1sAdminMstID.2230	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2230	Integer	0
ibdot1sAdminMstID.2231	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2231	Integer	0
ibdot1sAdminMstID.2232	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2232	Integer	0
ibdot1sAdminMstID.2233	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2233	Integer	0
ibdot1sAdminMstID.2234	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2234	Integer	0
ibdot1sAdminMstID.2235	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2235	Integer	0
ibdot1sAdminMstID.2236	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2236	Integer	0
ibdot1sAdminMstID.2237	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2237	Integer	0
ibdot1sAdminMstID.2238	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2238	Integer	0
ibdot1sAdminMstID.2239	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2239	Integer	0
ibdot1sAdminMstID.2240	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2240	Integer	0
ibdot1sAdminMstID.2241	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2241	Integer	0
ibdot1sAdminMstID.2242	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2242	Integer	0
ibdot1sAdminMstID.2243	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2243	Integer	0
ibdot1sAdminMstID.2244	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2244	Integer	0
ibdot1sAdminMstID.2245	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2245	Integer	0
ibdot1sAdminMstID.2246	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2246	Integer	0
ibdot1sAdminMstID.2247	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2247	Integer	0
ibdot1sAdminMstID.2248	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2248	Integer	0
ibdot1sAdminMstID.2249	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2249	Integer	0
ibdot1sAdminMstID.2250	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2250	Integer	0
ibdot1sAdminMstID.2251	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2251	Integer	0
ibdot1sAdminMstID.2252	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2252	Integer	0
ibdot1sAdminMstID.2253	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2253	Integer	0
ibdot1sAdminMstID.2254	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2254	Integer	0
ibdot1sAdminMstID.2255	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2255	Integer	0
ibdot1sAdminMstID.2256	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2256	Integer	0
ibdot1sAdminMstID.2257	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2257	Integer	0
ibdot1sAdminMstID.2258	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2258	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2259	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2259	Integer	0
ibdot1sAdminMstID.2260	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2260	Integer	0
ibdot1sAdminMstID.2261	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2261	Integer	0
ibdot1sAdminMstID.2262	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2262	Integer	0
ibdot1sAdminMstID.2263	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2263	Integer	0
ibdot1sAdminMstID.2264	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2264	Integer	0
ibdot1sAdminMstID.2265	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2265	Integer	0
ibdot1sAdminMstID.2266	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2266	Integer	0
ibdot1sAdminMstID.2267	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2267	Integer	0
ibdot1sAdminMstID.2268	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2268	Integer	0
ibdot1sAdminMstID.2269	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2269	Integer	0
ibdot1sAdminMstID.2270	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2270	Integer	0
ibdot1sAdminMstID.2271	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2271	Integer	0
ibdot1sAdminMstID.2272	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2272	Integer	0
ibdot1sAdminMstID.2273	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2273	Integer	0
ibdot1sAdminMstID.2274	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2274	Integer	0
ibdot1sAdminMstID.2275	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2275	Integer	0
ibdot1sAdminMstID.2276	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2276	Integer	0
ibdot1sAdminMstID.2277	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2277	Integer	0
ibdot1sAdminMstID.2278	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2278	Integer	0
ibdot1sAdminMstID.2279	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2279	Integer	0
ibdot1sAdminMstID.2280	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2280	Integer	0
ibdot1sAdminMstID.2281	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2281	Integer	0
ibdot1sAdminMstID.2282	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2282	Integer	0
ibdot1sAdminMstID.2283	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2283	Integer	0
ibdot1sAdminMstID.2284	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2284	Integer	0
ibdot1sAdminMstID.2285	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2285	Integer	0
ibdot1sAdminMstID.2286	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2286	Integer	0
ibdot1sAdminMstID.2287	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2287	Integer	0
ibdot1sAdminMstID.2288	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2288	Integer	0
ibdot1sAdminMstID.2289	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2289	Integer	0
ibdot1sAdminMstID.2290	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2290	Integer	0
ibdot1sAdminMstID.2291	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2291	Integer	0
ibdot1sAdminMstID.2292	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2292	Integer	0
ibdot1sAdminMstID.2293	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2293	Integer	0
ibdot1sAdminMstID.2294	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2294	Integer	0
ibdot1sAdminMstID.2295	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2295	Integer	0
ibdot1sAdminMstID.2296	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2296	Integer	0
ibdot1sAdminMstID.2297	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2297	Integer	0
ibdot1sAdminMstID.2298	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2298	Integer	0
ibdot1sAdminMstID.2299	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2299	Integer	0
ibdot1sAdminMstID.2300	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2300	Integer	0
ibdot1sAdminMstID.2301	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2301	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2302	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2302	Integer	0
ibdot1sAdminMstID.2303	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2303	Integer	0
ibdot1sAdminMstID.2304	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2304	Integer	0
ibdot1sAdminMstID.2305	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2305	Integer	0
ibdot1sAdminMstID.2306	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2306	Integer	0
ibdot1sAdminMstID.2307	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2307	Integer	0
ibdot1sAdminMstID.2308	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2308	Integer	0
ibdot1sAdminMstID.2309	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2309	Integer	0
ibdot1sAdminMstID.2310	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2310	Integer	0
ibdot1sAdminMstID.2311	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2311	Integer	0
ibdot1sAdminMstID.2312	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2312	Integer	0
ibdot1sAdminMstID.2313	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2313	Integer	0
ibdot1sAdminMstID.2314	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2314	Integer	0
ibdot1sAdminMstID.2315	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2315	Integer	0
ibdot1sAdminMstID.2316	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2316	Integer	0
ibdot1sAdminMstID.2317	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2317	Integer	0
ibdot1sAdminMstID.2318	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2318	Integer	0
ibdot1sAdminMstID.2319	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2319	Integer	0
ibdot1sAdminMstID.2320	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2320	Integer	0
ibdot1sAdminMstID.2321	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2321	Integer	0
ibdot1sAdminMstID.2322	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2322	Integer	0
ibdot1sAdminMstID.2323	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2323	Integer	0
ibdot1sAdminMstID.2324	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2324	Integer	0
ibdot1sAdminMstID.2325	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2325	Integer	0
ibdot1sAdminMstID.2326	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2326	Integer	0
ibdot1sAdminMstID.2327	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2327	Integer	0
ibdot1sAdminMstID.2328	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2328	Integer	0
ibdot1sAdminMstID.2329	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2329	Integer	0
ibdot1sAdminMstID.2330	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2330	Integer	0
ibdot1sAdminMstID.2331	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2331	Integer	0
ibdot1sAdminMstID.2332	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2332	Integer	0
ibdot1sAdminMstID.2333	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2333	Integer	0
ibdot1sAdminMstID.2334	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2334	Integer	0
ibdot1sAdminMstID.2335	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2335	Integer	0
ibdot1sAdminMstID.2336	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2336	Integer	0
ibdot1sAdminMstID.2337	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2337	Integer	0
ibdot1sAdminMstID.2338	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2338	Integer	0
ibdot1sAdminMstID.2339	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2339	Integer	0
ibdot1sAdminMstID.2340	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2340	Integer	0
ibdot1sAdminMstID.2341	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2341	Integer	0
ibdot1sAdminMstID.2342	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2342	Integer	0
ibdot1sAdminMstID.2343	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2343	Integer	0
ibdot1sAdminMstID.2344	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2344	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2345	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2345	Integer	0
ibdot1sAdminMstID.2346	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2346	Integer	0
ibdot1sAdminMstID.2347	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2347	Integer	0
ibdot1sAdminMstID.2348	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2348	Integer	0
ibdot1sAdminMstID.2349	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2349	Integer	0
ibdot1sAdminMstID.2350	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2350	Integer	0
ibdot1sAdminMstID.2351	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2351	Integer	0
ibdot1sAdminMstID.2352	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2352	Integer	0
ibdot1sAdminMstID.2353	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2353	Integer	0
ibdot1sAdminMstID.2354	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2354	Integer	0
ibdot1sAdminMstID.2355	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2355	Integer	0
ibdot1sAdminMstID.2356	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2356	Integer	0
ibdot1sAdminMstID.2357	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2357	Integer	0
ibdot1sAdminMstID.2358	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2358	Integer	0
ibdot1sAdminMstID.2359	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2359	Integer	0
ibdot1sAdminMstID.2360	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2360	Integer	0
ibdot1sAdminMstID.2361	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2361	Integer	0
ibdot1sAdminMstID.2362	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2362	Integer	0
ibdot1sAdminMstID.2363	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2363	Integer	0
ibdot1sAdminMstID.2364	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2364	Integer	0
ibdot1sAdminMstID.2365	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2365	Integer	0
ibdot1sAdminMstID.2366	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2366	Integer	0
ibdot1sAdminMstID.2367	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2367	Integer	0
ibdot1sAdminMstID.2368	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2368	Integer	0
ibdot1sAdminMstID.2369	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2369	Integer	0
ibdot1sAdminMstID.2370	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2370	Integer	0
ibdot1sAdminMstID.2371	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2371	Integer	0
ibdot1sAdminMstID.2372	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2372	Integer	0
ibdot1sAdminMstID.2373	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2373	Integer	0
ibdot1sAdminMstID.2374	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2374	Integer	0
ibdot1sAdminMstID.2375	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2375	Integer	0
ibdot1sAdminMstID.2376	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2376	Integer	0
ibdot1sAdminMstID.2377	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2377	Integer	0
ibdot1sAdminMstID.2378	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2378	Integer	0
ibdot1sAdminMstID.2379	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2379	Integer	0
ibdot1sAdminMstID.2380	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2380	Integer	0
ibdot1sAdminMstID.2381	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2381	Integer	0
ibdot1sAdminMstID.2382	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2382	Integer	0
ibdot1sAdminMstID.2383	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2383	Integer	0
ibdot1sAdminMstID.2384	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2384	Integer	0
ibdot1sAdminMstID.2385	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2385	Integer	0
ibdot1sAdminMstID.2386	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2386	Integer	0
ibdot1sAdminMstID.2387	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2387	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2388	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2388	Integer	0
ibdot1sAdminMstID.2389	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2389	Integer	0
ibdot1sAdminMstID.2390	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2390	Integer	0
ibdot1sAdminMstID.2391	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2391	Integer	0
ibdot1sAdminMstID.2392	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2392	Integer	0
ibdot1sAdminMstID.2393	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2393	Integer	0
ibdot1sAdminMstID.2394	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2394	Integer	0
ibdot1sAdminMstID.2395	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2395	Integer	0
ibdot1sAdminMstID.2396	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2396	Integer	0
ibdot1sAdminMstID.2397	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2397	Integer	0
ibdot1sAdminMstID.2398	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2398	Integer	0
ibdot1sAdminMstID.2399	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2399	Integer	0
ibdot1sAdminMstID.2400	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2400	Integer	0
ibdot1sAdminMstID.2401	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2401	Integer	0
ibdot1sAdminMstID.2402	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2402	Integer	0
ibdot1sAdminMstID.2403	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2403	Integer	0
ibdot1sAdminMstID.2404	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2404	Integer	0
ibdot1sAdminMstID.2405	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2405	Integer	0
ibdot1sAdminMstID.2406	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2406	Integer	0
ibdot1sAdminMstID.2407	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2407	Integer	0
ibdot1sAdminMstID.2408	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2408	Integer	0
ibdot1sAdminMstID.2409	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2409	Integer	0
ibdot1sAdminMstID.2410	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2410	Integer	0
ibdot1sAdminMstID.2411	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2411	Integer	0
ibdot1sAdminMstID.2412	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2412	Integer	0
ibdot1sAdminMstID.2413	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2413	Integer	0
ibdot1sAdminMstID.2414	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2414	Integer	0
ibdot1sAdminMstID.2415	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2415	Integer	0
ibdot1sAdminMstID.2416	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2416	Integer	0
ibdot1sAdminMstID.2417	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2417	Integer	0
ibdot1sAdminMstID.2418	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2418	Integer	0
ibdot1sAdminMstID.2419	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2419	Integer	0
ibdot1sAdminMstID.2420	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2420	Integer	0
ibdot1sAdminMstID.2421	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2421	Integer	0
ibdot1sAdminMstID.2422	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2422	Integer	0
ibdot1sAdminMstID.2423	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2423	Integer	0
ibdot1sAdminMstID.2424	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2424	Integer	0
ibdot1sAdminMstID.2425	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2425	Integer	0
ibdot1sAdminMstID.2426	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2426	Integer	0
ibdot1sAdminMstID.2427	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2427	Integer	0
ibdot1sAdminMstID.2428	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2428	Integer	0
ibdot1sAdminMstID.2429	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2429	Integer	0
ibdot1sAdminMstID.2430	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2430	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2431	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2431	Integer	0
ibdot1sAdminMstID.2432	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2432	Integer	0
ibdot1sAdminMstID.2433	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2433	Integer	0
ibdot1sAdminMstID.2434	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2434	Integer	0
ibdot1sAdminMstID.2435	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2435	Integer	0
ibdot1sAdminMstID.2436	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2436	Integer	0
ibdot1sAdminMstID.2437	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2437	Integer	0
ibdot1sAdminMstID.2438	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2438	Integer	0
ibdot1sAdminMstID.2439	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2439	Integer	0
ibdot1sAdminMstID.2440	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2440	Integer	0
ibdot1sAdminMstID.2441	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2441	Integer	0
ibdot1sAdminMstID.2442	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2442	Integer	0
ibdot1sAdminMstID.2443	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2443	Integer	0
ibdot1sAdminMstID.2444	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2444	Integer	0
ibdot1sAdminMstID.2445	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2445	Integer	0
ibdot1sAdminMstID.2446	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2446	Integer	0
ibdot1sAdminMstID.2447	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2447	Integer	0
ibdot1sAdminMstID.2448	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2448	Integer	0
ibdot1sAdminMstID.2449	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2449	Integer	0
ibdot1sAdminMstID.2450	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2450	Integer	0
ibdot1sAdminMstID.2451	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2451	Integer	0
ibdot1sAdminMstID.2452	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2452	Integer	0
ibdot1sAdminMstID.2453	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2453	Integer	0
ibdot1sAdminMstID.2454	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2454	Integer	0
ibdot1sAdminMstID.2455	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2455	Integer	0
ibdot1sAdminMstID.2456	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2456	Integer	0
ibdot1sAdminMstID.2457	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2457	Integer	0
ibdot1sAdminMstID.2458	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2458	Integer	0
ibdot1sAdminMstID.2459	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2459	Integer	0
ibdot1sAdminMstID.2460	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2460	Integer	0
ibdot1sAdminMstID.2461	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2461	Integer	0
ibdot1sAdminMstID.2462	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2462	Integer	0
ibdot1sAdminMstID.2463	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2463	Integer	0
ibdot1sAdminMstID.2464	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2464	Integer	0
ibdot1sAdminMstID.2465	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2465	Integer	0
ibdot1sAdminMstID.2466	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2466	Integer	0
ibdot1sAdminMstID.2467	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2467	Integer	0
ibdot1sAdminMstID.2468	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2468	Integer	0
ibdot1sAdminMstID.2469	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2469	Integer	0
ibdot1sAdminMstID.2470	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2470	Integer	0
ibdot1sAdminMstID.2471	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2471	Integer	0
ibdot1sAdminMstID.2472	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2472	Integer	0
ibdot1sAdminMstID.2473	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2473	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2474	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2474	Integer	0
ibdot1sAdminMstID.2475	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2475	Integer	0
ibdot1sAdminMstID.2476	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2476	Integer	0
ibdot1sAdminMstID.2477	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2477	Integer	0
ibdot1sAdminMstID.2478	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2478	Integer	0
ibdot1sAdminMstID.2479	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2479	Integer	0
ibdot1sAdminMstID.2480	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2480	Integer	0
ibdot1sAdminMstID.2481	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2481	Integer	0
ibdot1sAdminMstID.2482	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2482	Integer	0
ibdot1sAdminMstID.2483	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2483	Integer	0
ibdot1sAdminMstID.2484	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2484	Integer	0
ibdot1sAdminMstID.2485	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2485	Integer	0
ibdot1sAdminMstID.2486	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2486	Integer	0
ibdot1sAdminMstID.2487	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2487	Integer	0
ibdot1sAdminMstID.2488	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2488	Integer	0
ibdot1sAdminMstID.2489	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2489	Integer	0
ibdot1sAdminMstID.2490	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2490	Integer	0
ibdot1sAdminMstID.2491	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2491	Integer	0
ibdot1sAdminMstID.2492	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2492	Integer	0
ibdot1sAdminMstID.2493	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2493	Integer	0
ibdot1sAdminMstID.2494	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2494	Integer	0
ibdot1sAdminMstID.2495	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2495	Integer	0
ibdot1sAdminMstID.2496	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2496	Integer	0
ibdot1sAdminMstID.2497	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2497	Integer	0
ibdot1sAdminMstID.2498	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2498	Integer	0
ibdot1sAdminMstID.2499	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2499	Integer	0
ibdot1sAdminMstID.2500	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2500	Integer	0
ibdot1sAdminMstID.2501	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2501	Integer	0
ibdot1sAdminMstID.2502	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2502	Integer	0
ibdot1sAdminMstID.2503	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2503	Integer	0
ibdot1sAdminMstID.2504	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2504	Integer	0
ibdot1sAdminMstID.2505	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2505	Integer	0
ibdot1sAdminMstID.2506	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2506	Integer	0
ibdot1sAdminMstID.2507	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2507	Integer	0
ibdot1sAdminMstID.2508	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2508	Integer	0
ibdot1sAdminMstID.2509	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2509	Integer	0
ibdot1sAdminMstID.2510	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2510	Integer	0
ibdot1sAdminMstID.2511	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2511	Integer	0
ibdot1sAdminMstID.2512	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2512	Integer	0
ibdot1sAdminMstID.2513	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2513	Integer	0
ibdot1sAdminMstID.2514	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2514	Integer	0
ibdot1sAdminMstID.2515	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2515	Integer	0
ibdot1sAdminMstID.2516	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2516	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2517	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2517	Integer	0
ibdot1sAdminMstID.2518	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2518	Integer	0
ibdot1sAdminMstID.2519	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2519	Integer	0
ibdot1sAdminMstID.2520	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2520	Integer	0
ibdot1sAdminMstID.2521	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2521	Integer	0
ibdot1sAdminMstID.2522	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2522	Integer	0
ibdot1sAdminMstID.2523	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2523	Integer	0
ibdot1sAdminMstID.2524	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2524	Integer	0
ibdot1sAdminMstID.2525	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2525	Integer	0
ibdot1sAdminMstID.2526	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2526	Integer	0
ibdot1sAdminMstID.2527	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2527	Integer	0
ibdot1sAdminMstID.2528	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2528	Integer	0
ibdot1sAdminMstID.2529	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2529	Integer	0
ibdot1sAdminMstID.2530	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2530	Integer	0
ibdot1sAdminMstID.2531	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2531	Integer	0
ibdot1sAdminMstID.2532	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2532	Integer	0
ibdot1sAdminMstID.2533	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2533	Integer	0
ibdot1sAdminMstID.2534	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2534	Integer	0
ibdot1sAdminMstID.2535	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2535	Integer	0
ibdot1sAdminMstID.2536	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2536	Integer	0
ibdot1sAdminMstID.2537	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2537	Integer	0
ibdot1sAdminMstID.2538	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2538	Integer	0
ibdot1sAdminMstID.2539	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2539	Integer	0
ibdot1sAdminMstID.2540	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2540	Integer	0
ibdot1sAdminMstID.2541	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2541	Integer	0
ibdot1sAdminMstID.2542	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2542	Integer	0
ibdot1sAdminMstID.2543	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2543	Integer	0
ibdot1sAdminMstID.2544	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2544	Integer	0
ibdot1sAdminMstID.2545	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2545	Integer	0
ibdot1sAdminMstID.2546	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2546	Integer	0
ibdot1sAdminMstID.2547	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2547	Integer	0
ibdot1sAdminMstID.2548	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2548	Integer	0
ibdot1sAdminMstID.2549	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2549	Integer	0
ibdot1sAdminMstID.2550	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2550	Integer	0
ibdot1sAdminMstID.2551	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2551	Integer	0
ibdot1sAdminMstID.2552	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2552	Integer	0
ibdot1sAdminMstID.2553	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2553	Integer	0
ibdot1sAdminMstID.2554	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2554	Integer	0
ibdot1sAdminMstID.2555	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2555	Integer	0
ibdot1sAdminMstID.2556	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2556	Integer	0
ibdot1sAdminMstID.2557	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2557	Integer	0
ibdot1sAdminMstID.2558	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2558	Integer	0
ibdot1sAdminMstID.2559	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2559	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2560	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2560	Integer	0
ibdot1sAdminMstID.2561	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2561	Integer	0
ibdot1sAdminMstID.2562	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2562	Integer	0
ibdot1sAdminMstID.2563	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2563	Integer	0
ibdot1sAdminMstID.2564	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2564	Integer	0
ibdot1sAdminMstID.2565	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2565	Integer	0
ibdot1sAdminMstID.2566	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2566	Integer	0
ibdot1sAdminMstID.2567	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2567	Integer	0
ibdot1sAdminMstID.2568	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2568	Integer	0
ibdot1sAdminMstID.2569	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2569	Integer	0
ibdot1sAdminMstID.2570	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2570	Integer	0
ibdot1sAdminMstID.2571	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2571	Integer	0
ibdot1sAdminMstID.2572	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2572	Integer	0
ibdot1sAdminMstID.2573	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2573	Integer	0
ibdot1sAdminMstID.2574	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2574	Integer	0
ibdot1sAdminMstID.2575	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2575	Integer	0
ibdot1sAdminMstID.2576	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2576	Integer	0
ibdot1sAdminMstID.2577	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2577	Integer	0
ibdot1sAdminMstID.2578	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2578	Integer	0
ibdot1sAdminMstID.2579	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2579	Integer	0
ibdot1sAdminMstID.2580	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2580	Integer	0
ibdot1sAdminMstID.2581	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2581	Integer	0
ibdot1sAdminMstID.2582	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2582	Integer	0
ibdot1sAdminMstID.2583	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2583	Integer	0
ibdot1sAdminMstID.2584	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2584	Integer	0
ibdot1sAdminMstID.2585	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2585	Integer	0
ibdot1sAdminMstID.2586	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2586	Integer	0
ibdot1sAdminMstID.2587	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2587	Integer	0
ibdot1sAdminMstID.2588	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2588	Integer	0
ibdot1sAdminMstID.2589	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2589	Integer	0
ibdot1sAdminMstID.2590	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2590	Integer	0
ibdot1sAdminMstID.2591	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2591	Integer	0
ibdot1sAdminMstID.2592	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2592	Integer	0
ibdot1sAdminMstID.2593	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2593	Integer	0
ibdot1sAdminMstID.2594	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2594	Integer	0
ibdot1sAdminMstID.2595	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2595	Integer	0
ibdot1sAdminMstID.2596	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2596	Integer	0
ibdot1sAdminMstID.2597	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2597	Integer	0
ibdot1sAdminMstID.2598	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2598	Integer	0
ibdot1sAdminMstID.2599	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2599	Integer	0
ibdot1sAdminMstID.2600	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2600	Integer	0
ibdot1sAdminMstID.2601	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2601	Integer	0
ibdot1sAdminMstID.2602	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2602	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2603	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2603	Integer	0
ibdot1sAdminMstID.2604	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2604	Integer	0
ibdot1sAdminMstID.2605	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2605	Integer	0
ibdot1sAdminMstID.2606	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2606	Integer	0
ibdot1sAdminMstID.2607	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2607	Integer	0
ibdot1sAdminMstID.2608	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2608	Integer	0
ibdot1sAdminMstID.2609	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2609	Integer	0
ibdot1sAdminMstID.2610	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2610	Integer	0
ibdot1sAdminMstID.2611	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2611	Integer	0
ibdot1sAdminMstID.2612	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2612	Integer	0
ibdot1sAdminMstID.2613	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2613	Integer	0
ibdot1sAdminMstID.2614	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2614	Integer	0
ibdot1sAdminMstID.2615	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2615	Integer	0
ibdot1sAdminMstID.2616	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2616	Integer	0
ibdot1sAdminMstID.2617	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2617	Integer	0
ibdot1sAdminMstID.2618	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2618	Integer	0
ibdot1sAdminMstID.2619	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2619	Integer	0
ibdot1sAdminMstID.2620	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2620	Integer	0
ibdot1sAdminMstID.2621	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2621	Integer	0
ibdot1sAdminMstID.2622	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2622	Integer	0
ibdot1sAdminMstID.2623	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2623	Integer	0
ibdot1sAdminMstID.2624	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2624	Integer	0
ibdot1sAdminMstID.2625	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2625	Integer	0
ibdot1sAdminMstID.2626	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2626	Integer	0
ibdot1sAdminMstID.2627	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2627	Integer	0
ibdot1sAdminMstID.2628	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2628	Integer	0
ibdot1sAdminMstID.2629	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2629	Integer	0
ibdot1sAdminMstID.2630	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2630	Integer	0
ibdot1sAdminMstID.2631	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2631	Integer	0
ibdot1sAdminMstID.2632	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2632	Integer	0
ibdot1sAdminMstID.2633	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2633	Integer	0
ibdot1sAdminMstID.2634	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2634	Integer	0
ibdot1sAdminMstID.2635	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2635	Integer	0
ibdot1sAdminMstID.2636	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2636	Integer	0
ibdot1sAdminMstID.2637	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2637	Integer	0
ibdot1sAdminMstID.2638	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2638	Integer	0
ibdot1sAdminMstID.2639	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2639	Integer	0
ibdot1sAdminMstID.2640	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2640	Integer	0
ibdot1sAdminMstID.2641	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2641	Integer	0
ibdot1sAdminMstID.2642	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2642	Integer	0
ibdot1sAdminMstID.2643	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2643	Integer	0
ibdot1sAdminMstID.2644	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2644	Integer	0
ibdot1sAdminMstID.2645	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2645	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2646	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2646	Integer	0
ibdot1sAdminMstID.2647	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2647	Integer	0
ibdot1sAdminMstID.2648	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2648	Integer	0
ibdot1sAdminMstID.2649	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2649	Integer	0
ibdot1sAdminMstID.2650	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2650	Integer	0
ibdot1sAdminMstID.2651	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2651	Integer	0
ibdot1sAdminMstID.2652	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2652	Integer	0
ibdot1sAdminMstID.2653	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2653	Integer	0
ibdot1sAdminMstID.2654	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2654	Integer	0
ibdot1sAdminMstID.2655	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2655	Integer	0
ibdot1sAdminMstID.2656	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2656	Integer	0
ibdot1sAdminMstID.2657	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2657	Integer	0
ibdot1sAdminMstID.2658	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2658	Integer	0
ibdot1sAdminMstID.2659	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2659	Integer	0
ibdot1sAdminMstID.2660	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2660	Integer	0
ibdot1sAdminMstID.2661	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2661	Integer	0
ibdot1sAdminMstID.2662	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2662	Integer	0
ibdot1sAdminMstID.2663	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2663	Integer	0
ibdot1sAdminMstID.2664	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2664	Integer	0
ibdot1sAdminMstID.2665	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2665	Integer	0
ibdot1sAdminMstID.2666	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2666	Integer	0
ibdot1sAdminMstID.2667	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2667	Integer	0
ibdot1sAdminMstID.2668	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2668	Integer	0
ibdot1sAdminMstID.2669	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2669	Integer	0
ibdot1sAdminMstID.2670	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2670	Integer	0
ibdot1sAdminMstID.2671	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2671	Integer	0
ibdot1sAdminMstID.2672	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2672	Integer	0
ibdot1sAdminMstID.2673	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2673	Integer	0
ibdot1sAdminMstID.2674	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2674	Integer	0
ibdot1sAdminMstID.2675	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2675	Integer	0
ibdot1sAdminMstID.2676	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2676	Integer	0
ibdot1sAdminMstID.2677	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2677	Integer	0
ibdot1sAdminMstID.2678	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2678	Integer	0
ibdot1sAdminMstID.2679	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2679	Integer	0
ibdot1sAdminMstID.2680	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2680	Integer	0
ibdot1sAdminMstID.2681	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2681	Integer	0
ibdot1sAdminMstID.2682	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2682	Integer	0
ibdot1sAdminMstID.2683	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2683	Integer	0
ibdot1sAdminMstID.2684	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2684	Integer	0
ibdot1sAdminMstID.2685	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2685	Integer	0
ibdot1sAdminMstID.2686	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2686	Integer	0
ibdot1sAdminMstID.2687	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2687	Integer	0
ibdot1sAdminMstID.2688	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2688	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2689	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2689	Integer	0
ibdot1sAdminMstID.2690	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2690	Integer	0
ibdot1sAdminMstID.2691	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2691	Integer	0
ibdot1sAdminMstID.2692	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2692	Integer	0
ibdot1sAdminMstID.2693	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2693	Integer	0
ibdot1sAdminMstID.2694	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2694	Integer	0
ibdot1sAdminMstID.2695	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2695	Integer	0
ibdot1sAdminMstID.2696	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2696	Integer	0
ibdot1sAdminMstID.2697	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2697	Integer	0
ibdot1sAdminMstID.2698	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2698	Integer	0
ibdot1sAdminMstID.2699	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2699	Integer	0
ibdot1sAdminMstID.2700	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2700	Integer	0
ibdot1sAdminMstID.2701	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2701	Integer	0
ibdot1sAdminMstID.2702	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2702	Integer	0
ibdot1sAdminMstID.2703	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2703	Integer	0
ibdot1sAdminMstID.2704	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2704	Integer	0
ibdot1sAdminMstID.2705	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2705	Integer	0
ibdot1sAdminMstID.2706	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2706	Integer	0
ibdot1sAdminMstID.2707	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2707	Integer	0
ibdot1sAdminMstID.2708	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2708	Integer	0
ibdot1sAdminMstID.2709	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2709	Integer	0
ibdot1sAdminMstID.2710	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2710	Integer	0
ibdot1sAdminMstID.2711	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2711	Integer	0
ibdot1sAdminMstID.2712	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2712	Integer	0
ibdot1sAdminMstID.2713	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2713	Integer	0
ibdot1sAdminMstID.2714	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2714	Integer	0
ibdot1sAdminMstID.2715	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2715	Integer	0
ibdot1sAdminMstID.2716	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2716	Integer	0
ibdot1sAdminMstID.2717	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2717	Integer	0
ibdot1sAdminMstID.2718	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2718	Integer	0
ibdot1sAdminMstID.2719	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2719	Integer	0
ibdot1sAdminMstID.2720	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2720	Integer	0
ibdot1sAdminMstID.2721	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2721	Integer	0
ibdot1sAdminMstID.2722	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2722	Integer	0
ibdot1sAdminMstID.2723	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2723	Integer	0
ibdot1sAdminMstID.2724	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2724	Integer	0
ibdot1sAdminMstID.2725	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2725	Integer	0
ibdot1sAdminMstID.2726	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2726	Integer	0
ibdot1sAdminMstID.2727	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2727	Integer	0
ibdot1sAdminMstID.2728	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2728	Integer	0
ibdot1sAdminMstID.2729	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2729	Integer	0
ibdot1sAdminMstID.2730	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2730	Integer	0
ibdot1sAdminMstID.2731	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2731	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2732	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2732	Integer	0
ibdot1sAdminMstID.2733	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2733	Integer	0
ibdot1sAdminMstID.2734	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2734	Integer	0
ibdot1sAdminMstID.2735	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2735	Integer	0
ibdot1sAdminMstID.2736	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2736	Integer	0
ibdot1sAdminMstID.2737	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2737	Integer	0
ibdot1sAdminMstID.2738	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2738	Integer	0
ibdot1sAdminMstID.2739	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2739	Integer	0
ibdot1sAdminMstID.2740	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2740	Integer	0
ibdot1sAdminMstID.2741	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2741	Integer	0
ibdot1sAdminMstID.2742	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2742	Integer	0
ibdot1sAdminMstID.2743	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2743	Integer	0
ibdot1sAdminMstID.2744	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2744	Integer	0
ibdot1sAdminMstID.2745	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2745	Integer	0
ibdot1sAdminMstID.2746	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2746	Integer	0
ibdot1sAdminMstID.2747	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2747	Integer	0
ibdot1sAdminMstID.2748	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2748	Integer	0
ibdot1sAdminMstID.2749	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2749	Integer	0
ibdot1sAdminMstID.2750	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2750	Integer	0
ibdot1sAdminMstID.2751	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2751	Integer	0
ibdot1sAdminMstID.2752	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2752	Integer	0
ibdot1sAdminMstID.2753	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2753	Integer	0
ibdot1sAdminMstID.2754	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2754	Integer	0
ibdot1sAdminMstID.2755	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2755	Integer	0
ibdot1sAdminMstID.2756	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2756	Integer	0
ibdot1sAdminMstID.2757	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2757	Integer	0
ibdot1sAdminMstID.2758	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2758	Integer	0
ibdot1sAdminMstID.2759	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2759	Integer	0
ibdot1sAdminMstID.2760	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2760	Integer	0
ibdot1sAdminMstID.2761	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2761	Integer	0
ibdot1sAdminMstID.2762	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2762	Integer	0
ibdot1sAdminMstID.2763	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2763	Integer	0
ibdot1sAdminMstID.2764	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2764	Integer	0
ibdot1sAdminMstID.2765	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2765	Integer	0
ibdot1sAdminMstID.2766	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2766	Integer	0
ibdot1sAdminMstID.2767	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2767	Integer	0
ibdot1sAdminMstID.2768	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2768	Integer	0
ibdot1sAdminMstID.2769	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2769	Integer	0
ibdot1sAdminMstID.2770	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2770	Integer	0
ibdot1sAdminMstID.2771	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2771	Integer	0
ibdot1sAdminMstID.2772	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2772	Integer	0
ibdot1sAdminMstID.2773	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2773	Integer	0
ibdot1sAdminMstID.2774	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2774	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2775	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2775	Integer	0
ibdot1sAdminMstID.2776	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2776	Integer	0
ibdot1sAdminMstID.2777	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2777	Integer	0
ibdot1sAdminMstID.2778	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2778	Integer	0
ibdot1sAdminMstID.2779	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2779	Integer	0
ibdot1sAdminMstID.2780	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2780	Integer	0
ibdot1sAdminMstID.2781	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2781	Integer	0
ibdot1sAdminMstID.2782	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2782	Integer	0
ibdot1sAdminMstID.2783	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2783	Integer	0
ibdot1sAdminMstID.2784	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2784	Integer	0
ibdot1sAdminMstID.2785	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2785	Integer	0
ibdot1sAdminMstID.2786	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2786	Integer	0
ibdot1sAdminMstID.2787	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2787	Integer	0
ibdot1sAdminMstID.2788	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2788	Integer	0
ibdot1sAdminMstID.2789	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2789	Integer	0
ibdot1sAdminMstID.2790	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2790	Integer	0
ibdot1sAdminMstID.2791	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2791	Integer	0
ibdot1sAdminMstID.2792	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2792	Integer	0
ibdot1sAdminMstID.2793	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2793	Integer	0
ibdot1sAdminMstID.2794	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2794	Integer	0
ibdot1sAdminMstID.2795	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2795	Integer	0
ibdot1sAdminMstID.2796	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2796	Integer	0
ibdot1sAdminMstID.2797	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2797	Integer	0
ibdot1sAdminMstID.2798	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2798	Integer	0
ibdot1sAdminMstID.2799	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2799	Integer	0
ibdot1sAdminMstID.2800	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2800	Integer	0
ibdot1sAdminMstID.2801	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2801	Integer	0
ibdot1sAdminMstID.2802	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2802	Integer	0
ibdot1sAdminMstID.2803	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2803	Integer	0
ibdot1sAdminMstID.2804	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2804	Integer	0
ibdot1sAdminMstID.2805	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2805	Integer	0
ibdot1sAdminMstID.2806	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2806	Integer	0
ibdot1sAdminMstID.2807	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2807	Integer	0
ibdot1sAdminMstID.2808	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2808	Integer	0
ibdot1sAdminMstID.2809	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2809	Integer	0
ibdot1sAdminMstID.2810	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2810	Integer	0
ibdot1sAdminMstID.2811	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2811	Integer	0
ibdot1sAdminMstID.2812	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2812	Integer	0
ibdot1sAdminMstID.2813	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2813	Integer	0
ibdot1sAdminMstID.2814	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2814	Integer	0
ibdot1sAdminMstID.2815	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2815	Integer	0
ibdot1sAdminMstID.2816	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2816	Integer	0
ibdot1sAdminMstID.2817	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2817	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2818	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2818	Integer	0
ibdot1sAdminMstID.2819	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2819	Integer	0
ibdot1sAdminMstID.2820	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2820	Integer	0
ibdot1sAdminMstID.2821	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2821	Integer	0
ibdot1sAdminMstID.2822	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2822	Integer	0
ibdot1sAdminMstID.2823	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2823	Integer	0
ibdot1sAdminMstID.2824	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2824	Integer	0
ibdot1sAdminMstID.2825	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2825	Integer	0
ibdot1sAdminMstID.2826	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2826	Integer	0
ibdot1sAdminMstID.2827	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2827	Integer	0
ibdot1sAdminMstID.2828	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2828	Integer	0
ibdot1sAdminMstID.2829	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2829	Integer	0
ibdot1sAdminMstID.2830	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2830	Integer	0
ibdot1sAdminMstID.2831	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2831	Integer	0
ibdot1sAdminMstID.2832	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2832	Integer	0
ibdot1sAdminMstID.2833	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2833	Integer	0
ibdot1sAdminMstID.2834	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2834	Integer	0
ibdot1sAdminMstID.2835	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2835	Integer	0
ibdot1sAdminMstID.2836	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2836	Integer	0
ibdot1sAdminMstID.2837	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2837	Integer	0
ibdot1sAdminMstID.2838	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2838	Integer	0
ibdot1sAdminMstID.2839	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2839	Integer	0
ibdot1sAdminMstID.2840	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2840	Integer	0
ibdot1sAdminMstID.2841	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2841	Integer	0
ibdot1sAdminMstID.2842	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2842	Integer	0
ibdot1sAdminMstID.2843	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2843	Integer	0
ibdot1sAdminMstID.2844	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2844	Integer	0
ibdot1sAdminMstID.2845	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2845	Integer	0
ibdot1sAdminMstID.2846	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2846	Integer	0
ibdot1sAdminMstID.2847	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2847	Integer	0
ibdot1sAdminMstID.2848	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2848	Integer	0
ibdot1sAdminMstID.2849	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2849	Integer	0
ibdot1sAdminMstID.2850	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2850	Integer	0
ibdot1sAdminMstID.2851	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2851	Integer	0
ibdot1sAdminMstID.2852	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2852	Integer	0
ibdot1sAdminMstID.2853	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2853	Integer	0
ibdot1sAdminMstID.2854	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2854	Integer	0
ibdot1sAdminMstID.2855	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2855	Integer	0
ibdot1sAdminMstID.2856	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2856	Integer	0
ibdot1sAdminMstID.2857	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2857	Integer	0
ibdot1sAdminMstID.2858	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2858	Integer	0
ibdot1sAdminMstID.2859	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2859	Integer	0
ibdot1sAdminMstID.2860	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2860	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2861	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2861	Integer	0
ibdot1sAdminMstID.2862	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2862	Integer	0
ibdot1sAdminMstID.2863	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2863	Integer	0
ibdot1sAdminMstID.2864	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2864	Integer	0
ibdot1sAdminMstID.2865	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2865	Integer	0
ibdot1sAdminMstID.2866	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2866	Integer	0
ibdot1sAdminMstID.2867	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2867	Integer	0
ibdot1sAdminMstID.2868	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2868	Integer	0
ibdot1sAdminMstID.2869	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2869	Integer	0
ibdot1sAdminMstID.2870	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2870	Integer	0
ibdot1sAdminMstID.2871	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2871	Integer	0
ibdot1sAdminMstID.2872	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2872	Integer	0
ibdot1sAdminMstID.2873	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2873	Integer	0
ibdot1sAdminMstID.2874	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2874	Integer	0
ibdot1sAdminMstID.2875	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2875	Integer	0
ibdot1sAdminMstID.2876	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2876	Integer	0
ibdot1sAdminMstID.2877	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2877	Integer	0
ibdot1sAdminMstID.2878	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2878	Integer	0
ibdot1sAdminMstID.2879	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2879	Integer	0
ibdot1sAdminMstID.2880	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2880	Integer	0
ibdot1sAdminMstID.2881	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2881	Integer	0
ibdot1sAdminMstID.2882	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2882	Integer	0
ibdot1sAdminMstID.2883	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2883	Integer	0
ibdot1sAdminMstID.2884	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2884	Integer	0
ibdot1sAdminMstID.2885	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2885	Integer	0
ibdot1sAdminMstID.2886	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2886	Integer	0
ibdot1sAdminMstID.2887	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2887	Integer	0
ibdot1sAdminMstID.2888	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2888	Integer	0
ibdot1sAdminMstID.2889	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2889	Integer	0
ibdot1sAdminMstID.2890	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2890	Integer	0
ibdot1sAdminMstID.2891	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2891	Integer	0
ibdot1sAdminMstID.2892	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2892	Integer	0
ibdot1sAdminMstID.2893	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2893	Integer	0
ibdot1sAdminMstID.2894	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2894	Integer	0
ibdot1sAdminMstID.2895	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2895	Integer	0
ibdot1sAdminMstID.2896	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2896	Integer	0
ibdot1sAdminMstID.2897	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2897	Integer	0
ibdot1sAdminMstID.2898	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2898	Integer	0
ibdot1sAdminMstID.2899	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2899	Integer	0
ibdot1sAdminMstID.2900	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2900	Integer	0
ibdot1sAdminMstID.2901	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2901	Integer	0
ibdot1sAdminMstID.2902	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2902	Integer	0
ibdot1sAdminMstID.2903	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2903	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2904	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2904	Integer	0
ibdot1sAdminMstID.2905	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2905	Integer	0
ibdot1sAdminMstID.2906	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2906	Integer	0
ibdot1sAdminMstID.2907	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2907	Integer	0
ibdot1sAdminMstID.2908	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2908	Integer	0
ibdot1sAdminMstID.2909	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2909	Integer	0
ibdot1sAdminMstID.2910	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2910	Integer	0
ibdot1sAdminMstID.2911	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2911	Integer	0
ibdot1sAdminMstID.2912	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2912	Integer	0
ibdot1sAdminMstID.2913	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2913	Integer	0
ibdot1sAdminMstID.2914	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2914	Integer	0
ibdot1sAdminMstID.2915	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2915	Integer	0
ibdot1sAdminMstID.2916	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2916	Integer	0
ibdot1sAdminMstID.2917	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2917	Integer	0
ibdot1sAdminMstID.2918	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2918	Integer	0
ibdot1sAdminMstID.2919	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2919	Integer	0
ibdot1sAdminMstID.2920	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2920	Integer	0
ibdot1sAdminMstID.2921	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2921	Integer	0
ibdot1sAdminMstID.2922	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2922	Integer	0
ibdot1sAdminMstID.2923	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2923	Integer	0
ibdot1sAdminMstID.2924	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2924	Integer	0
ibdot1sAdminMstID.2925	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2925	Integer	0
ibdot1sAdminMstID.2926	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2926	Integer	0
ibdot1sAdminMstID.2927	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2927	Integer	0
ibdot1sAdminMstID.2928	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2928	Integer	0
ibdot1sAdminMstID.2929	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2929	Integer	0
ibdot1sAdminMstID.2930	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2930	Integer	0
ibdot1sAdminMstID.2931	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2931	Integer	0
ibdot1sAdminMstID.2932	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2932	Integer	0
ibdot1sAdminMstID.2933	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2933	Integer	0
ibdot1sAdminMstID.2934	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2934	Integer	0
ibdot1sAdminMstID.2935	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2935	Integer	0
ibdot1sAdminMstID.2936	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2936	Integer	0
ibdot1sAdminMstID.2937	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2937	Integer	0
ibdot1sAdminMstID.2938	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2938	Integer	0
ibdot1sAdminMstID.2939	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2939	Integer	0
ibdot1sAdminMstID.2940	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2940	Integer	0
ibdot1sAdminMstID.2941	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2941	Integer	0
ibdot1sAdminMstID.2942	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2942	Integer	0
ibdot1sAdminMstID.2943	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2943	Integer	0
ibdot1sAdminMstID.2944	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2944	Integer	0
ibdot1sAdminMstID.2945	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2945	Integer	0
ibdot1sAdminMstID.2946	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2946	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2947	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2947	Integer	0
ibdot1sAdminMstID.2948	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2948	Integer	0
ibdot1sAdminMstID.2949	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2949	Integer	0
ibdot1sAdminMstID.2950	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2950	Integer	0
ibdot1sAdminMstID.2951	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2951	Integer	0
ibdot1sAdminMstID.2952	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2952	Integer	0
ibdot1sAdminMstID.2953	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2953	Integer	0
ibdot1sAdminMstID.2954	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2954	Integer	0
ibdot1sAdminMstID.2955	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2955	Integer	0
ibdot1sAdminMstID.2956	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2956	Integer	0
ibdot1sAdminMstID.2957	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2957	Integer	0
ibdot1sAdminMstID.2958	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2958	Integer	0
ibdot1sAdminMstID.2959	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2959	Integer	0
ibdot1sAdminMstID.2960	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2960	Integer	0
ibdot1sAdminMstID.2961	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2961	Integer	0
ibdot1sAdminMstID.2962	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2962	Integer	0
ibdot1sAdminMstID.2963	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2963	Integer	0
ibdot1sAdminMstID.2964	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2964	Integer	0
ibdot1sAdminMstID.2965	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2965	Integer	0
ibdot1sAdminMstID.2966	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2966	Integer	0
ibdot1sAdminMstID.2967	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2967	Integer	0
ibdot1sAdminMstID.2968	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2968	Integer	0
ibdot1sAdminMstID.2969	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2969	Integer	0
ibdot1sAdminMstID.2970	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2970	Integer	0
ibdot1sAdminMstID.2971	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2971	Integer	0
ibdot1sAdminMstID.2972	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2972	Integer	0
ibdot1sAdminMstID.2973	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2973	Integer	0
ibdot1sAdminMstID.2974	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2974	Integer	0
ibdot1sAdminMstID.2975	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2975	Integer	0
ibdot1sAdminMstID.2976	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2976	Integer	0
ibdot1sAdminMstID.2977	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2977	Integer	0
ibdot1sAdminMstID.2978	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2978	Integer	0
ibdot1sAdminMstID.2979	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2979	Integer	0
ibdot1sAdminMstID.2980	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2980	Integer	0
ibdot1sAdminMstID.2981	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2981	Integer	0
ibdot1sAdminMstID.2982	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2982	Integer	0
ibdot1sAdminMstID.2983	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2983	Integer	0
ibdot1sAdminMstID.2984	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2984	Integer	0
ibdot1sAdminMstID.2985	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2985	Integer	0
ibdot1sAdminMstID.2986	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2986	Integer	0
ibdot1sAdminMstID.2987	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2987	Integer	0
ibdot1sAdminMstID.2988	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2988	Integer	0
ibdot1sAdminMstID.2989	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2989	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.2990	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2990	Integer	0
ibdot1sAdminMstID.2991	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2991	Integer	0
ibdot1sAdminMstID.2992	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2992	Integer	0
ibdot1sAdminMstID.2993	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2993	Integer	0
ibdot1sAdminMstID.2994	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2994	Integer	0
ibdot1sAdminMstID.2995	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2995	Integer	0
ibdot1sAdminMstID.2996	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2996	Integer	0
ibdot1sAdminMstID.2997	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2997	Integer	0
ibdot1sAdminMstID.2998	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2998	Integer	0
ibdot1sAdminMstID.2999	.1.3.6.1.4.1.26138.8.35.14.18.1.2.2999	Integer	0
ibdot1sAdminMstID.3000	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3000	Integer	0
ibdot1sAdminMstID.3001	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3001	Integer	0
ibdot1sAdminMstID.3002	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3002	Integer	0
ibdot1sAdminMstID.3003	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3003	Integer	0
ibdot1sAdminMstID.3004	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3004	Integer	0
ibdot1sAdminMstID.3005	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3005	Integer	0
ibdot1sAdminMstID.3006	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3006	Integer	0
ibdot1sAdminMstID.3007	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3007	Integer	0
ibdot1sAdminMstID.3008	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3008	Integer	0
ibdot1sAdminMstID.3009	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3009	Integer	0
ibdot1sAdminMstID.3010	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3010	Integer	0
ibdot1sAdminMstID.3011	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3011	Integer	0
ibdot1sAdminMstID.3012	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3012	Integer	0
ibdot1sAdminMstID.3013	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3013	Integer	0
ibdot1sAdminMstID.3014	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3014	Integer	0
ibdot1sAdminMstID.3015	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3015	Integer	0
ibdot1sAdminMstID.3016	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3016	Integer	0
ibdot1sAdminMstID.3017	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3017	Integer	0
ibdot1sAdminMstID.3018	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3018	Integer	0
ibdot1sAdminMstID.3019	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3019	Integer	0
ibdot1sAdminMstID.3020	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3020	Integer	0
ibdot1sAdminMstID.3021	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3021	Integer	0
ibdot1sAdminMstID.3022	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3022	Integer	0
ibdot1sAdminMstID.3023	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3023	Integer	0
ibdot1sAdminMstID.3024	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3024	Integer	0
ibdot1sAdminMstID.3025	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3025	Integer	0
ibdot1sAdminMstID.3026	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3026	Integer	0
ibdot1sAdminMstID.3027	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3027	Integer	0
ibdot1sAdminMstID.3028	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3028	Integer	0
ibdot1sAdminMstID.3029	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3029	Integer	0
ibdot1sAdminMstID.3030	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3030	Integer	0
ibdot1sAdminMstID.3031	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3031	Integer	0
ibdot1sAdminMstID.3032	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3032	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3033	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3033	Integer	0
ibdot1sAdminMstID.3034	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3034	Integer	0
ibdot1sAdminMstID.3035	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3035	Integer	0
ibdot1sAdminMstID.3036	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3036	Integer	0
ibdot1sAdminMstID.3037	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3037	Integer	0
ibdot1sAdminMstID.3038	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3038	Integer	0
ibdot1sAdminMstID.3039	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3039	Integer	0
ibdot1sAdminMstID.3040	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3040	Integer	0
ibdot1sAdminMstID.3041	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3041	Integer	0
ibdot1sAdminMstID.3042	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3042	Integer	0
ibdot1sAdminMstID.3043	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3043	Integer	0
ibdot1sAdminMstID.3044	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3044	Integer	0
ibdot1sAdminMstID.3045	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3045	Integer	0
ibdot1sAdminMstID.3046	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3046	Integer	0
ibdot1sAdminMstID.3047	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3047	Integer	0
ibdot1sAdminMstID.3048	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3048	Integer	0
ibdot1sAdminMstID.3049	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3049	Integer	0
ibdot1sAdminMstID.3050	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3050	Integer	0
ibdot1sAdminMstID.3051	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3051	Integer	0
ibdot1sAdminMstID.3052	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3052	Integer	0
ibdot1sAdminMstID.3053	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3053	Integer	0
ibdot1sAdminMstID.3054	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3054	Integer	0
ibdot1sAdminMstID.3055	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3055	Integer	0
ibdot1sAdminMstID.3056	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3056	Integer	0
ibdot1sAdminMstID.3057	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3057	Integer	0
ibdot1sAdminMstID.3058	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3058	Integer	0
ibdot1sAdminMstID.3059	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3059	Integer	0
ibdot1sAdminMstID.3060	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3060	Integer	0
ibdot1sAdminMstID.3061	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3061	Integer	0
ibdot1sAdminMstID.3062	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3062	Integer	0
ibdot1sAdminMstID.3063	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3063	Integer	0
ibdot1sAdminMstID.3064	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3064	Integer	0
ibdot1sAdminMstID.3065	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3065	Integer	0
ibdot1sAdminMstID.3066	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3066	Integer	0
ibdot1sAdminMstID.3067	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3067	Integer	0
ibdot1sAdminMstID.3068	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3068	Integer	0
ibdot1sAdminMstID.3069	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3069	Integer	0
ibdot1sAdminMstID.3070	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3070	Integer	0
ibdot1sAdminMstID.3071	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3071	Integer	0
ibdot1sAdminMstID.3072	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3072	Integer	0
ibdot1sAdminMstID.3073	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3073	Integer	0
ibdot1sAdminMstID.3074	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3074	Integer	0
ibdot1sAdminMstID.3075	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3075	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3076	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3076	Integer	0
ibdot1sAdminMstID.3077	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3077	Integer	0
ibdot1sAdminMstID.3078	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3078	Integer	0
ibdot1sAdminMstID.3079	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3079	Integer	0
ibdot1sAdminMstID.3080	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3080	Integer	0
ibdot1sAdminMstID.3081	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3081	Integer	0
ibdot1sAdminMstID.3082	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3082	Integer	0
ibdot1sAdminMstID.3083	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3083	Integer	0
ibdot1sAdminMstID.3084	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3084	Integer	0
ibdot1sAdminMstID.3085	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3085	Integer	0
ibdot1sAdminMstID.3086	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3086	Integer	0
ibdot1sAdminMstID.3087	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3087	Integer	0
ibdot1sAdminMstID.3088	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3088	Integer	0
ibdot1sAdminMstID.3089	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3089	Integer	0
ibdot1sAdminMstID.3090	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3090	Integer	0
ibdot1sAdminMstID.3091	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3091	Integer	0
ibdot1sAdminMstID.3092	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3092	Integer	0
ibdot1sAdminMstID.3093	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3093	Integer	0
ibdot1sAdminMstID.3094	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3094	Integer	0
ibdot1sAdminMstID.3095	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3095	Integer	0
ibdot1sAdminMstID.3096	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3096	Integer	0
ibdot1sAdminMstID.3097	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3097	Integer	0
ibdot1sAdminMstID.3098	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3098	Integer	0
ibdot1sAdminMstID.3099	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3099	Integer	0
ibdot1sAdminMstID.3100	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3100	Integer	0
ibdot1sAdminMstID.3101	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3101	Integer	0
ibdot1sAdminMstID.3102	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3102	Integer	0
ibdot1sAdminMstID.3103	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3103	Integer	0
ibdot1sAdminMstID.3104	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3104	Integer	0
ibdot1sAdminMstID.3105	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3105	Integer	0
ibdot1sAdminMstID.3106	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3106	Integer	0
ibdot1sAdminMstID.3107	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3107	Integer	0
ibdot1sAdminMstID.3108	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3108	Integer	0
ibdot1sAdminMstID.3109	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3109	Integer	0
ibdot1sAdminMstID.3110	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3110	Integer	0
ibdot1sAdminMstID.3111	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3111	Integer	0
ibdot1sAdminMstID.3112	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3112	Integer	0
ibdot1sAdminMstID.3113	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3113	Integer	0
ibdot1sAdminMstID.3114	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3114	Integer	0
ibdot1sAdminMstID.3115	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3115	Integer	0
ibdot1sAdminMstID.3116	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3116	Integer	0
ibdot1sAdminMstID.3117	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3117	Integer	0
ibdot1sAdminMstID.3118	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3118	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3119	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3119	Integer	0
ibdot1sAdminMstID.3120	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3120	Integer	0
ibdot1sAdminMstID.3121	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3121	Integer	0
ibdot1sAdminMstID.3122	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3122	Integer	0
ibdot1sAdminMstID.3123	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3123	Integer	0
ibdot1sAdminMstID.3124	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3124	Integer	0
ibdot1sAdminMstID.3125	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3125	Integer	0
ibdot1sAdminMstID.3126	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3126	Integer	0
ibdot1sAdminMstID.3127	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3127	Integer	0
ibdot1sAdminMstID.3128	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3128	Integer	0
ibdot1sAdminMstID.3129	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3129	Integer	0
ibdot1sAdminMstID.3130	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3130	Integer	0
ibdot1sAdminMstID.3131	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3131	Integer	0
ibdot1sAdminMstID.3132	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3132	Integer	0
ibdot1sAdminMstID.3133	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3133	Integer	0
ibdot1sAdminMstID.3134	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3134	Integer	0
ibdot1sAdminMstID.3135	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3135	Integer	0
ibdot1sAdminMstID.3136	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3136	Integer	0
ibdot1sAdminMstID.3137	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3137	Integer	0
ibdot1sAdminMstID.3138	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3138	Integer	0
ibdot1sAdminMstID.3139	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3139	Integer	0
ibdot1sAdminMstID.3140	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3140	Integer	0
ibdot1sAdminMstID.3141	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3141	Integer	0
ibdot1sAdminMstID.3142	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3142	Integer	0
ibdot1sAdminMstID.3143	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3143	Integer	0
ibdot1sAdminMstID.3144	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3144	Integer	0
ibdot1sAdminMstID.3145	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3145	Integer	0
ibdot1sAdminMstID.3146	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3146	Integer	0
ibdot1sAdminMstID.3147	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3147	Integer	0
ibdot1sAdminMstID.3148	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3148	Integer	0
ibdot1sAdminMstID.3149	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3149	Integer	0
ibdot1sAdminMstID.3150	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3150	Integer	0
ibdot1sAdminMstID.3151	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3151	Integer	0
ibdot1sAdminMstID.3152	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3152	Integer	0
ibdot1sAdminMstID.3153	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3153	Integer	0
ibdot1sAdminMstID.3154	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3154	Integer	0
ibdot1sAdminMstID.3155	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3155	Integer	0
ibdot1sAdminMstID.3156	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3156	Integer	0
ibdot1sAdminMstID.3157	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3157	Integer	0
ibdot1sAdminMstID.3158	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3158	Integer	0
ibdot1sAdminMstID.3159	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3159	Integer	0
ibdot1sAdminMstID.3160	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3160	Integer	0
ibdot1sAdminMstID.3161	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3161	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3162	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3162	Integer	0
ibdot1sAdminMstID.3163	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3163	Integer	0
ibdot1sAdminMstID.3164	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3164	Integer	0
ibdot1sAdminMstID.3165	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3165	Integer	0
ibdot1sAdminMstID.3166	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3166	Integer	0
ibdot1sAdminMstID.3167	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3167	Integer	0
ibdot1sAdminMstID.3168	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3168	Integer	0
ibdot1sAdminMstID.3169	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3169	Integer	0
ibdot1sAdminMstID.3170	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3170	Integer	0
ibdot1sAdminMstID.3171	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3171	Integer	0
ibdot1sAdminMstID.3172	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3172	Integer	0
ibdot1sAdminMstID.3173	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3173	Integer	0
ibdot1sAdminMstID.3174	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3174	Integer	0
ibdot1sAdminMstID.3175	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3175	Integer	0
ibdot1sAdminMstID.3176	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3176	Integer	0
ibdot1sAdminMstID.3177	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3177	Integer	0
ibdot1sAdminMstID.3178	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3178	Integer	0
ibdot1sAdminMstID.3179	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3179	Integer	0
ibdot1sAdminMstID.3180	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3180	Integer	0
ibdot1sAdminMstID.3181	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3181	Integer	0
ibdot1sAdminMstID.3182	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3182	Integer	0
ibdot1sAdminMstID.3183	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3183	Integer	0
ibdot1sAdminMstID.3184	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3184	Integer	0
ibdot1sAdminMstID.3185	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3185	Integer	0
ibdot1sAdminMstID.3186	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3186	Integer	0
ibdot1sAdminMstID.3187	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3187	Integer	0
ibdot1sAdminMstID.3188	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3188	Integer	0
ibdot1sAdminMstID.3189	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3189	Integer	0
ibdot1sAdminMstID.3190	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3190	Integer	0
ibdot1sAdminMstID.3191	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3191	Integer	0
ibdot1sAdminMstID.3192	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3192	Integer	0
ibdot1sAdminMstID.3193	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3193	Integer	0
ibdot1sAdminMstID.3194	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3194	Integer	0
ibdot1sAdminMstID.3195	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3195	Integer	0
ibdot1sAdminMstID.3196	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3196	Integer	0
ibdot1sAdminMstID.3197	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3197	Integer	0
ibdot1sAdminMstID.3198	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3198	Integer	0
ibdot1sAdminMstID.3199	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3199	Integer	0
ibdot1sAdminMstID.3200	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3200	Integer	0
ibdot1sAdminMstID.3201	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3201	Integer	0
ibdot1sAdminMstID.3202	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3202	Integer	0
ibdot1sAdminMstID.3203	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3203	Integer	0
ibdot1sAdminMstID.3204	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3204	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3205	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3205	Integer	0
ibdot1sAdminMstID.3206	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3206	Integer	0
ibdot1sAdminMstID.3207	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3207	Integer	0
ibdot1sAdminMstID.3208	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3208	Integer	0
ibdot1sAdminMstID.3209	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3209	Integer	0
ibdot1sAdminMstID.3210	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3210	Integer	0
ibdot1sAdminMstID.3211	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3211	Integer	0
ibdot1sAdminMstID.3212	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3212	Integer	0
ibdot1sAdminMstID.3213	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3213	Integer	0
ibdot1sAdminMstID.3214	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3214	Integer	0
ibdot1sAdminMstID.3215	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3215	Integer	0
ibdot1sAdminMstID.3216	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3216	Integer	0
ibdot1sAdminMstID.3217	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3217	Integer	0
ibdot1sAdminMstID.3218	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3218	Integer	0
ibdot1sAdminMstID.3219	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3219	Integer	0
ibdot1sAdminMstID.3220	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3220	Integer	0
ibdot1sAdminMstID.3221	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3221	Integer	0
ibdot1sAdminMstID.3222	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3222	Integer	0
ibdot1sAdminMstID.3223	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3223	Integer	0
ibdot1sAdminMstID.3224	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3224	Integer	0
ibdot1sAdminMstID.3225	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3225	Integer	0
ibdot1sAdminMstID.3226	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3226	Integer	0
ibdot1sAdminMstID.3227	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3227	Integer	0
ibdot1sAdminMstID.3228	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3228	Integer	0
ibdot1sAdminMstID.3229	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3229	Integer	0
ibdot1sAdminMstID.3230	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3230	Integer	0
ibdot1sAdminMstID.3231	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3231	Integer	0
ibdot1sAdminMstID.3232	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3232	Integer	0
ibdot1sAdminMstID.3233	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3233	Integer	0
ibdot1sAdminMstID.3234	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3234	Integer	0
ibdot1sAdminMstID.3235	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3235	Integer	0
ibdot1sAdminMstID.3236	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3236	Integer	0
ibdot1sAdminMstID.3237	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3237	Integer	0
ibdot1sAdminMstID.3238	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3238	Integer	0
ibdot1sAdminMstID.3239	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3239	Integer	0
ibdot1sAdminMstID.3240	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3240	Integer	0
ibdot1sAdminMstID.3241	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3241	Integer	0
ibdot1sAdminMstID.3242	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3242	Integer	0
ibdot1sAdminMstID.3243	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3243	Integer	0
ibdot1sAdminMstID.3244	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3244	Integer	0
ibdot1sAdminMstID.3245	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3245	Integer	0
ibdot1sAdminMstID.3246	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3246	Integer	0
ibdot1sAdminMstID.3247	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3247	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3248	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3248	Integer	0
ibdot1sAdminMstID.3249	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3249	Integer	0
ibdot1sAdminMstID.3250	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3250	Integer	0
ibdot1sAdminMstID.3251	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3251	Integer	0
ibdot1sAdminMstID.3252	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3252	Integer	0
ibdot1sAdminMstID.3253	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3253	Integer	0
ibdot1sAdminMstID.3254	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3254	Integer	0
ibdot1sAdminMstID.3255	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3255	Integer	0
ibdot1sAdminMstID.3256	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3256	Integer	0
ibdot1sAdminMstID.3257	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3257	Integer	0
ibdot1sAdminMstID.3258	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3258	Integer	0
ibdot1sAdminMstID.3259	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3259	Integer	0
ibdot1sAdminMstID.3260	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3260	Integer	0
ibdot1sAdminMstID.3261	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3261	Integer	0
ibdot1sAdminMstID.3262	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3262	Integer	0
ibdot1sAdminMstID.3263	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3263	Integer	0
ibdot1sAdminMstID.3264	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3264	Integer	0
ibdot1sAdminMstID.3265	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3265	Integer	0
ibdot1sAdminMstID.3266	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3266	Integer	0
ibdot1sAdminMstID.3267	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3267	Integer	0
ibdot1sAdminMstID.3268	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3268	Integer	0
ibdot1sAdminMstID.3269	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3269	Integer	0
ibdot1sAdminMstID.3270	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3270	Integer	0
ibdot1sAdminMstID.3271	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3271	Integer	0
ibdot1sAdminMstID.3272	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3272	Integer	0
ibdot1sAdminMstID.3273	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3273	Integer	0
ibdot1sAdminMstID.3274	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3274	Integer	0
ibdot1sAdminMstID.3275	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3275	Integer	0
ibdot1sAdminMstID.3276	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3276	Integer	0
ibdot1sAdminMstID.3277	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3277	Integer	0
ibdot1sAdminMstID.3278	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3278	Integer	0
ibdot1sAdminMstID.3279	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3279	Integer	0
ibdot1sAdminMstID.3280	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3280	Integer	0
ibdot1sAdminMstID.3281	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3281	Integer	0
ibdot1sAdminMstID.3282	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3282	Integer	0
ibdot1sAdminMstID.3283	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3283	Integer	0
ibdot1sAdminMstID.3284	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3284	Integer	0
ibdot1sAdminMstID.3285	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3285	Integer	0
ibdot1sAdminMstID.3286	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3286	Integer	0
ibdot1sAdminMstID.3287	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3287	Integer	0
ibdot1sAdminMstID.3288	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3288	Integer	0
ibdot1sAdminMstID.3289	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3289	Integer	0
ibdot1sAdminMstID.3290	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3290	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3291	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3291	Integer	0
ibdot1sAdminMstID.3292	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3292	Integer	0
ibdot1sAdminMstID.3293	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3293	Integer	0
ibdot1sAdminMstID.3294	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3294	Integer	0
ibdot1sAdminMstID.3295	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3295	Integer	0
ibdot1sAdminMstID.3296	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3296	Integer	0
ibdot1sAdminMstID.3297	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3297	Integer	0
ibdot1sAdminMstID.3298	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3298	Integer	0
ibdot1sAdminMstID.3299	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3299	Integer	0
ibdot1sAdminMstID.3300	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3300	Integer	0
ibdot1sAdminMstID.3301	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3301	Integer	0
ibdot1sAdminMstID.3302	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3302	Integer	0
ibdot1sAdminMstID.3303	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3303	Integer	0
ibdot1sAdminMstID.3304	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3304	Integer	0
ibdot1sAdminMstID.3305	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3305	Integer	0
ibdot1sAdminMstID.3306	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3306	Integer	0
ibdot1sAdminMstID.3307	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3307	Integer	0
ibdot1sAdminMstID.3308	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3308	Integer	0
ibdot1sAdminMstID.3309	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3309	Integer	0
ibdot1sAdminMstID.3310	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3310	Integer	0
ibdot1sAdminMstID.3311	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3311	Integer	0
ibdot1sAdminMstID.3312	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3312	Integer	0
ibdot1sAdminMstID.3313	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3313	Integer	0
ibdot1sAdminMstID.3314	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3314	Integer	0
ibdot1sAdminMstID.3315	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3315	Integer	0
ibdot1sAdminMstID.3316	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3316	Integer	0
ibdot1sAdminMstID.3317	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3317	Integer	0
ibdot1sAdminMstID.3318	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3318	Integer	0
ibdot1sAdminMstID.3319	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3319	Integer	0
ibdot1sAdminMstID.3320	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3320	Integer	0
ibdot1sAdminMstID.3321	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3321	Integer	0
ibdot1sAdminMstID.3322	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3322	Integer	0
ibdot1sAdminMstID.3323	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3323	Integer	0
ibdot1sAdminMstID.3324	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3324	Integer	0
ibdot1sAdminMstID.3325	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3325	Integer	0
ibdot1sAdminMstID.3326	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3326	Integer	0
ibdot1sAdminMstID.3327	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3327	Integer	0
ibdot1sAdminMstID.3328	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3328	Integer	0
ibdot1sAdminMstID.3329	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3329	Integer	0
ibdot1sAdminMstID.3330	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3330	Integer	0
ibdot1sAdminMstID.3331	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3331	Integer	0
ibdot1sAdminMstID.3332	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3332	Integer	0
ibdot1sAdminMstID.3333	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3333	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3334	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3334	Integer	0
ibdot1sAdminMstID.3335	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3335	Integer	0
ibdot1sAdminMstID.3336	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3336	Integer	0
ibdot1sAdminMstID.3337	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3337	Integer	0
ibdot1sAdminMstID.3338	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3338	Integer	0
ibdot1sAdminMstID.3339	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3339	Integer	0
ibdot1sAdminMstID.3340	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3340	Integer	0
ibdot1sAdminMstID.3341	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3341	Integer	0
ibdot1sAdminMstID.3342	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3342	Integer	0
ibdot1sAdminMstID.3343	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3343	Integer	0
ibdot1sAdminMstID.3344	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3344	Integer	0
ibdot1sAdminMstID.3345	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3345	Integer	0
ibdot1sAdminMstID.3346	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3346	Integer	0
ibdot1sAdminMstID.3347	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3347	Integer	0
ibdot1sAdminMstID.3348	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3348	Integer	0
ibdot1sAdminMstID.3349	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3349	Integer	0
ibdot1sAdminMstID.3350	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3350	Integer	0
ibdot1sAdminMstID.3351	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3351	Integer	0
ibdot1sAdminMstID.3352	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3352	Integer	0
ibdot1sAdminMstID.3353	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3353	Integer	0
ibdot1sAdminMstID.3354	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3354	Integer	0
ibdot1sAdminMstID.3355	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3355	Integer	0
ibdot1sAdminMstID.3356	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3356	Integer	0
ibdot1sAdminMstID.3357	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3357	Integer	0
ibdot1sAdminMstID.3358	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3358	Integer	0
ibdot1sAdminMstID.3359	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3359	Integer	0
ibdot1sAdminMstID.3360	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3360	Integer	0
ibdot1sAdminMstID.3361	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3361	Integer	0
ibdot1sAdminMstID.3362	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3362	Integer	0
ibdot1sAdminMstID.3363	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3363	Integer	0
ibdot1sAdminMstID.3364	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3364	Integer	0
ibdot1sAdminMstID.3365	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3365	Integer	0
ibdot1sAdminMstID.3366	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3366	Integer	0
ibdot1sAdminMstID.3367	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3367	Integer	0
ibdot1sAdminMstID.3368	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3368	Integer	0
ibdot1sAdminMstID.3369	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3369	Integer	0
ibdot1sAdminMstID.3370	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3370	Integer	0
ibdot1sAdminMstID.3371	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3371	Integer	0
ibdot1sAdminMstID.3372	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3372	Integer	0
ibdot1sAdminMstID.3373	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3373	Integer	0
ibdot1sAdminMstID.3374	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3374	Integer	0
ibdot1sAdminMstID.3375	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3375	Integer	0
ibdot1sAdminMstID.3376	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3376	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3377	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3377	Integer	0
ibdot1sAdminMstID.3378	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3378	Integer	0
ibdot1sAdminMstID.3379	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3379	Integer	0
ibdot1sAdminMstID.3380	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3380	Integer	0
ibdot1sAdminMstID.3381	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3381	Integer	0
ibdot1sAdminMstID.3382	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3382	Integer	0
ibdot1sAdminMstID.3383	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3383	Integer	0
ibdot1sAdminMstID.3384	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3384	Integer	0
ibdot1sAdminMstID.3385	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3385	Integer	0
ibdot1sAdminMstID.3386	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3386	Integer	0
ibdot1sAdminMstID.3387	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3387	Integer	0
ibdot1sAdminMstID.3388	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3388	Integer	0
ibdot1sAdminMstID.3389	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3389	Integer	0
ibdot1sAdminMstID.3390	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3390	Integer	0
ibdot1sAdminMstID.3391	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3391	Integer	0
ibdot1sAdminMstID.3392	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3392	Integer	0
ibdot1sAdminMstID.3393	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3393	Integer	0
ibdot1sAdminMstID.3394	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3394	Integer	0
ibdot1sAdminMstID.3395	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3395	Integer	0
ibdot1sAdminMstID.3396	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3396	Integer	0
ibdot1sAdminMstID.3397	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3397	Integer	0
ibdot1sAdminMstID.3398	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3398	Integer	0
ibdot1sAdminMstID.3399	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3399	Integer	0
ibdot1sAdminMstID.3400	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3400	Integer	0
ibdot1sAdminMstID.3401	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3401	Integer	0
ibdot1sAdminMstID.3402	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3402	Integer	0
ibdot1sAdminMstID.3403	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3403	Integer	0
ibdot1sAdminMstID.3404	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3404	Integer	0
ibdot1sAdminMstID.3405	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3405	Integer	0
ibdot1sAdminMstID.3406	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3406	Integer	0
ibdot1sAdminMstID.3407	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3407	Integer	0
ibdot1sAdminMstID.3408	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3408	Integer	0
ibdot1sAdminMstID.3409	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3409	Integer	0
ibdot1sAdminMstID.3410	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3410	Integer	0
ibdot1sAdminMstID.3411	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3411	Integer	0
ibdot1sAdminMstID.3412	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3412	Integer	0
ibdot1sAdminMstID.3413	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3413	Integer	0
ibdot1sAdminMstID.3414	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3414	Integer	0
ibdot1sAdminMstID.3415	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3415	Integer	0
ibdot1sAdminMstID.3416	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3416	Integer	0
ibdot1sAdminMstID.3417	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3417	Integer	0
ibdot1sAdminMstID.3418	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3418	Integer	0
ibdot1sAdminMstID.3419	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3419	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3420	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3420	Integer	0
ibdot1sAdminMstID.3421	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3421	Integer	0
ibdot1sAdminMstID.3422	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3422	Integer	0
ibdot1sAdminMstID.3423	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3423	Integer	0
ibdot1sAdminMstID.3424	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3424	Integer	0
ibdot1sAdminMstID.3425	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3425	Integer	0
ibdot1sAdminMstID.3426	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3426	Integer	0
ibdot1sAdminMstID.3427	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3427	Integer	0
ibdot1sAdminMstID.3428	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3428	Integer	0
ibdot1sAdminMstID.3429	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3429	Integer	0
ibdot1sAdminMstID.3430	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3430	Integer	0
ibdot1sAdminMstID.3431	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3431	Integer	0
ibdot1sAdminMstID.3432	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3432	Integer	0
ibdot1sAdminMstID.3433	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3433	Integer	0
ibdot1sAdminMstID.3434	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3434	Integer	0
ibdot1sAdminMstID.3435	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3435	Integer	0
ibdot1sAdminMstID.3436	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3436	Integer	0
ibdot1sAdminMstID.3437	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3437	Integer	0
ibdot1sAdminMstID.3438	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3438	Integer	0
ibdot1sAdminMstID.3439	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3439	Integer	0
ibdot1sAdminMstID.3440	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3440	Integer	0
ibdot1sAdminMstID.3441	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3441	Integer	0
ibdot1sAdminMstID.3442	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3442	Integer	0
ibdot1sAdminMstID.3443	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3443	Integer	0
ibdot1sAdminMstID.3444	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3444	Integer	0
ibdot1sAdminMstID.3445	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3445	Integer	0
ibdot1sAdminMstID.3446	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3446	Integer	0
ibdot1sAdminMstID.3447	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3447	Integer	0
ibdot1sAdminMstID.3448	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3448	Integer	0
ibdot1sAdminMstID.3449	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3449	Integer	0
ibdot1sAdminMstID.3450	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3450	Integer	0
ibdot1sAdminMstID.3451	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3451	Integer	0
ibdot1sAdminMstID.3452	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3452	Integer	0
ibdot1sAdminMstID.3453	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3453	Integer	0
ibdot1sAdminMstID.3454	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3454	Integer	0
ibdot1sAdminMstID.3455	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3455	Integer	0
ibdot1sAdminMstID.3456	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3456	Integer	0
ibdot1sAdminMstID.3457	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3457	Integer	0
ibdot1sAdminMstID.3458	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3458	Integer	0
ibdot1sAdminMstID.3459	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3459	Integer	0
ibdot1sAdminMstID.3460	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3460	Integer	0
ibdot1sAdminMstID.3461	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3461	Integer	0
ibdot1sAdminMstID.3462	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3462	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3463	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3463	Integer	0
ibdot1sAdminMstID.3464	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3464	Integer	0
ibdot1sAdminMstID.3465	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3465	Integer	0
ibdot1sAdminMstID.3466	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3466	Integer	0
ibdot1sAdminMstID.3467	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3467	Integer	0
ibdot1sAdminMstID.3468	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3468	Integer	0
ibdot1sAdminMstID.3469	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3469	Integer	0
ibdot1sAdminMstID.3470	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3470	Integer	0
ibdot1sAdminMstID.3471	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3471	Integer	0
ibdot1sAdminMstID.3472	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3472	Integer	0
ibdot1sAdminMstID.3473	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3473	Integer	0
ibdot1sAdminMstID.3474	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3474	Integer	0
ibdot1sAdminMstID.3475	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3475	Integer	0
ibdot1sAdminMstID.3476	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3476	Integer	0
ibdot1sAdminMstID.3477	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3477	Integer	0
ibdot1sAdminMstID.3478	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3478	Integer	0
ibdot1sAdminMstID.3479	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3479	Integer	0
ibdot1sAdminMstID.3480	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3480	Integer	0
ibdot1sAdminMstID.3481	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3481	Integer	0
ibdot1sAdminMstID.3482	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3482	Integer	0
ibdot1sAdminMstID.3483	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3483	Integer	0
ibdot1sAdminMstID.3484	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3484	Integer	0
ibdot1sAdminMstID.3485	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3485	Integer	0
ibdot1sAdminMstID.3486	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3486	Integer	0
ibdot1sAdminMstID.3487	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3487	Integer	0
ibdot1sAdminMstID.3488	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3488	Integer	0
ibdot1sAdminMstID.3489	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3489	Integer	0
ibdot1sAdminMstID.3490	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3490	Integer	0
ibdot1sAdminMstID.3491	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3491	Integer	0
ibdot1sAdminMstID.3492	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3492	Integer	0
ibdot1sAdminMstID.3493	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3493	Integer	0
ibdot1sAdminMstID.3494	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3494	Integer	0
ibdot1sAdminMstID.3495	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3495	Integer	0
ibdot1sAdminMstID.3496	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3496	Integer	0
ibdot1sAdminMstID.3497	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3497	Integer	0
ibdot1sAdminMstID.3498	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3498	Integer	0
ibdot1sAdminMstID.3499	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3499	Integer	0
ibdot1sAdminMstID.3500	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3500	Integer	0
ibdot1sAdminMstID.3501	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3501	Integer	0
ibdot1sAdminMstID.3502	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3502	Integer	0
ibdot1sAdminMstID.3503	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3503	Integer	0
ibdot1sAdminMstID.3504	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3504	Integer	0
ibdot1sAdminMstID.3505	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3505	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3506	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3506	Integer	0
ibdot1sAdminMstID.3507	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3507	Integer	0
ibdot1sAdminMstID.3508	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3508	Integer	0
ibdot1sAdminMstID.3509	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3509	Integer	0
ibdot1sAdminMstID.3510	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3510	Integer	0
ibdot1sAdminMstID.3511	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3511	Integer	0
ibdot1sAdminMstID.3512	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3512	Integer	0
ibdot1sAdminMstID.3513	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3513	Integer	0
ibdot1sAdminMstID.3514	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3514	Integer	0
ibdot1sAdminMstID.3515	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3515	Integer	0
ibdot1sAdminMstID.3516	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3516	Integer	0
ibdot1sAdminMstID.3517	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3517	Integer	0
ibdot1sAdminMstID.3518	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3518	Integer	0
ibdot1sAdminMstID.3519	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3519	Integer	0
ibdot1sAdminMstID.3520	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3520	Integer	0
ibdot1sAdminMstID.3521	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3521	Integer	0
ibdot1sAdminMstID.3522	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3522	Integer	0
ibdot1sAdminMstID.3523	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3523	Integer	0
ibdot1sAdminMstID.3524	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3524	Integer	0
ibdot1sAdminMstID.3525	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3525	Integer	0
ibdot1sAdminMstID.3526	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3526	Integer	0
ibdot1sAdminMstID.3527	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3527	Integer	0
ibdot1sAdminMstID.3528	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3528	Integer	0
ibdot1sAdminMstID.3529	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3529	Integer	0
ibdot1sAdminMstID.3530	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3530	Integer	0
ibdot1sAdminMstID.3531	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3531	Integer	0
ibdot1sAdminMstID.3532	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3532	Integer	0
ibdot1sAdminMstID.3533	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3533	Integer	0
ibdot1sAdminMstID.3534	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3534	Integer	0
ibdot1sAdminMstID.3535	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3535	Integer	0
ibdot1sAdminMstID.3536	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3536	Integer	0
ibdot1sAdminMstID.3537	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3537	Integer	0
ibdot1sAdminMstID.3538	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3538	Integer	0
ibdot1sAdminMstID.3539	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3539	Integer	0
ibdot1sAdminMstID.3540	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3540	Integer	0
ibdot1sAdminMstID.3541	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3541	Integer	0
ibdot1sAdminMstID.3542	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3542	Integer	0
ibdot1sAdminMstID.3543	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3543	Integer	0
ibdot1sAdminMstID.3544	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3544	Integer	0
ibdot1sAdminMstID.3545	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3545	Integer	0
ibdot1sAdminMstID.3546	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3546	Integer	0
ibdot1sAdminMstID.3547	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3547	Integer	0
ibdot1sAdminMstID.3548	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3548	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3549	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3549	Integer	0
ibdot1sAdminMstID.3550	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3550	Integer	0
ibdot1sAdminMstID.3551	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3551	Integer	0
ibdot1sAdminMstID.3552	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3552	Integer	0
ibdot1sAdminMstID.3553	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3553	Integer	0
ibdot1sAdminMstID.3554	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3554	Integer	0
ibdot1sAdminMstID.3555	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3555	Integer	0
ibdot1sAdminMstID.3556	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3556	Integer	0
ibdot1sAdminMstID.3557	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3557	Integer	0
ibdot1sAdminMstID.3558	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3558	Integer	0
ibdot1sAdminMstID.3559	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3559	Integer	0
ibdot1sAdminMstID.3560	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3560	Integer	0
ibdot1sAdminMstID.3561	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3561	Integer	0
ibdot1sAdminMstID.3562	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3562	Integer	0
ibdot1sAdminMstID.3563	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3563	Integer	0
ibdot1sAdminMstID.3564	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3564	Integer	0
ibdot1sAdminMstID.3565	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3565	Integer	0
ibdot1sAdminMstID.3566	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3566	Integer	0
ibdot1sAdminMstID.3567	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3567	Integer	0
ibdot1sAdminMstID.3568	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3568	Integer	0
ibdot1sAdminMstID.3569	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3569	Integer	0
ibdot1sAdminMstID.3570	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3570	Integer	0
ibdot1sAdminMstID.3571	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3571	Integer	0
ibdot1sAdminMstID.3572	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3572	Integer	0
ibdot1sAdminMstID.3573	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3573	Integer	0
ibdot1sAdminMstID.3574	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3574	Integer	0
ibdot1sAdminMstID.3575	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3575	Integer	0
ibdot1sAdminMstID.3576	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3576	Integer	0
ibdot1sAdminMstID.3577	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3577	Integer	0
ibdot1sAdminMstID.3578	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3578	Integer	0
ibdot1sAdminMstID.3579	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3579	Integer	0
ibdot1sAdminMstID.3580	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3580	Integer	0
ibdot1sAdminMstID.3581	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3581	Integer	0
ibdot1sAdminMstID.3582	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3582	Integer	0
ibdot1sAdminMstID.3583	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3583	Integer	0
ibdot1sAdminMstID.3584	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3584	Integer	0
ibdot1sAdminMstID.3585	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3585	Integer	0
ibdot1sAdminMstID.3586	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3586	Integer	0
ibdot1sAdminMstID.3587	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3587	Integer	0
ibdot1sAdminMstID.3588	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3588	Integer	0
ibdot1sAdminMstID.3589	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3589	Integer	0
ibdot1sAdminMstID.3590	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3590	Integer	0
ibdot1sAdminMstID.3591	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3591	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3592	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3592	Integer	0
ibdot1sAdminMstID.3593	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3593	Integer	0
ibdot1sAdminMstID.3594	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3594	Integer	0
ibdot1sAdminMstID.3595	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3595	Integer	0
ibdot1sAdminMstID.3596	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3596	Integer	0
ibdot1sAdminMstID.3597	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3597	Integer	0
ibdot1sAdminMstID.3598	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3598	Integer	0
ibdot1sAdminMstID.3599	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3599	Integer	0
ibdot1sAdminMstID.3600	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3600	Integer	0
ibdot1sAdminMstID.3601	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3601	Integer	0
ibdot1sAdminMstID.3602	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3602	Integer	0
ibdot1sAdminMstID.3603	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3603	Integer	0
ibdot1sAdminMstID.3604	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3604	Integer	0
ibdot1sAdminMstID.3605	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3605	Integer	0
ibdot1sAdminMstID.3606	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3606	Integer	0
ibdot1sAdminMstID.3607	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3607	Integer	0
ibdot1sAdminMstID.3608	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3608	Integer	0
ibdot1sAdminMstID.3609	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3609	Integer	0
ibdot1sAdminMstID.3610	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3610	Integer	0
ibdot1sAdminMstID.3611	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3611	Integer	0
ibdot1sAdminMstID.3612	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3612	Integer	0
ibdot1sAdminMstID.3613	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3613	Integer	0
ibdot1sAdminMstID.3614	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3614	Integer	0
ibdot1sAdminMstID.3615	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3615	Integer	0
ibdot1sAdminMstID.3616	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3616	Integer	0
ibdot1sAdminMstID.3617	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3617	Integer	0
ibdot1sAdminMstID.3618	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3618	Integer	0
ibdot1sAdminMstID.3619	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3619	Integer	0
ibdot1sAdminMstID.3620	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3620	Integer	0
ibdot1sAdminMstID.3621	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3621	Integer	0
ibdot1sAdminMstID.3622	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3622	Integer	0
ibdot1sAdminMstID.3623	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3623	Integer	0
ibdot1sAdminMstID.3624	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3624	Integer	0
ibdot1sAdminMstID.3625	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3625	Integer	0
ibdot1sAdminMstID.3626	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3626	Integer	0
ibdot1sAdminMstID.3627	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3627	Integer	0
ibdot1sAdminMstID.3628	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3628	Integer	0
ibdot1sAdminMstID.3629	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3629	Integer	0
ibdot1sAdminMstID.3630	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3630	Integer	0
ibdot1sAdminMstID.3631	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3631	Integer	0
ibdot1sAdminMstID.3632	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3632	Integer	0
ibdot1sAdminMstID.3633	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3633	Integer	0
ibdot1sAdminMstID.3634	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3634	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3635	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3635	Integer	0
ibdot1sAdminMstID.3636	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3636	Integer	0
ibdot1sAdminMstID.3637	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3637	Integer	0
ibdot1sAdminMstID.3638	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3638	Integer	0
ibdot1sAdminMstID.3639	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3639	Integer	0
ibdot1sAdminMstID.3640	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3640	Integer	0
ibdot1sAdminMstID.3641	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3641	Integer	0
ibdot1sAdminMstID.3642	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3642	Integer	0
ibdot1sAdminMstID.3643	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3643	Integer	0
ibdot1sAdminMstID.3644	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3644	Integer	0
ibdot1sAdminMstID.3645	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3645	Integer	0
ibdot1sAdminMstID.3646	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3646	Integer	0
ibdot1sAdminMstID.3647	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3647	Integer	0
ibdot1sAdminMstID.3648	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3648	Integer	0
ibdot1sAdminMstID.3649	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3649	Integer	0
ibdot1sAdminMstID.3650	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3650	Integer	0
ibdot1sAdminMstID.3651	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3651	Integer	0
ibdot1sAdminMstID.3652	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3652	Integer	0
ibdot1sAdminMstID.3653	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3653	Integer	0
ibdot1sAdminMstID.3654	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3654	Integer	0
ibdot1sAdminMstID.3655	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3655	Integer	0
ibdot1sAdminMstID.3656	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3656	Integer	0
ibdot1sAdminMstID.3657	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3657	Integer	0
ibdot1sAdminMstID.3658	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3658	Integer	0
ibdot1sAdminMstID.3659	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3659	Integer	0
ibdot1sAdminMstID.3660	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3660	Integer	0
ibdot1sAdminMstID.3661	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3661	Integer	0
ibdot1sAdminMstID.3662	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3662	Integer	0
ibdot1sAdminMstID.3663	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3663	Integer	0
ibdot1sAdminMstID.3664	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3664	Integer	0
ibdot1sAdminMstID.3665	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3665	Integer	0
ibdot1sAdminMstID.3666	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3666	Integer	0
ibdot1sAdminMstID.3667	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3667	Integer	0
ibdot1sAdminMstID.3668	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3668	Integer	0
ibdot1sAdminMstID.3669	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3669	Integer	0
ibdot1sAdminMstID.3670	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3670	Integer	0
ibdot1sAdminMstID.3671	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3671	Integer	0
ibdot1sAdminMstID.3672	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3672	Integer	0
ibdot1sAdminMstID.3673	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3673	Integer	0
ibdot1sAdminMstID.3674	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3674	Integer	0
ibdot1sAdminMstID.3675	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3675	Integer	0
ibdot1sAdminMstID.3676	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3676	Integer	0
ibdot1sAdminMstID.3677	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3677	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3678	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3678	Integer	0
ibdot1sAdminMstID.3679	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3679	Integer	0
ibdot1sAdminMstID.3680	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3680	Integer	0
ibdot1sAdminMstID.3681	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3681	Integer	0
ibdot1sAdminMstID.3682	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3682	Integer	0
ibdot1sAdminMstID.3683	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3683	Integer	0
ibdot1sAdminMstID.3684	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3684	Integer	0
ibdot1sAdminMstID.3685	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3685	Integer	0
ibdot1sAdminMstID.3686	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3686	Integer	0
ibdot1sAdminMstID.3687	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3687	Integer	0
ibdot1sAdminMstID.3688	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3688	Integer	0
ibdot1sAdminMstID.3689	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3689	Integer	0
ibdot1sAdminMstID.3690	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3690	Integer	0
ibdot1sAdminMstID.3691	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3691	Integer	0
ibdot1sAdminMstID.3692	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3692	Integer	0
ibdot1sAdminMstID.3693	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3693	Integer	0
ibdot1sAdminMstID.3694	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3694	Integer	0
ibdot1sAdminMstID.3695	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3695	Integer	0
ibdot1sAdminMstID.3696	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3696	Integer	0
ibdot1sAdminMstID.3697	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3697	Integer	0
ibdot1sAdminMstID.3698	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3698	Integer	0
ibdot1sAdminMstID.3699	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3699	Integer	0
ibdot1sAdminMstID.3700	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3700	Integer	0
ibdot1sAdminMstID.3701	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3701	Integer	0
ibdot1sAdminMstID.3702	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3702	Integer	0
ibdot1sAdminMstID.3703	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3703	Integer	0
ibdot1sAdminMstID.3704	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3704	Integer	0
ibdot1sAdminMstID.3705	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3705	Integer	0
ibdot1sAdminMstID.3706	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3706	Integer	0
ibdot1sAdminMstID.3707	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3707	Integer	0
ibdot1sAdminMstID.3708	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3708	Integer	0
ibdot1sAdminMstID.3709	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3709	Integer	0
ibdot1sAdminMstID.3710	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3710	Integer	0
ibdot1sAdminMstID.3711	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3711	Integer	0
ibdot1sAdminMstID.3712	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3712	Integer	0
ibdot1sAdminMstID.3713	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3713	Integer	0
ibdot1sAdminMstID.3714	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3714	Integer	0
ibdot1sAdminMstID.3715	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3715	Integer	0
ibdot1sAdminMstID.3716	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3716	Integer	0
ibdot1sAdminMstID.3717	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3717	Integer	0
ibdot1sAdminMstID.3718	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3718	Integer	0
ibdot1sAdminMstID.3719	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3719	Integer	0
ibdot1sAdminMstID.3720	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3720	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3721	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3721	Integer	0
ibdot1sAdminMstID.3722	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3722	Integer	0
ibdot1sAdminMstID.3723	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3723	Integer	0
ibdot1sAdminMstID.3724	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3724	Integer	0
ibdot1sAdminMstID.3725	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3725	Integer	0
ibdot1sAdminMstID.3726	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3726	Integer	0
ibdot1sAdminMstID.3727	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3727	Integer	0
ibdot1sAdminMstID.3728	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3728	Integer	0
ibdot1sAdminMstID.3729	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3729	Integer	0
ibdot1sAdminMstID.3730	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3730	Integer	0
ibdot1sAdminMstID.3731	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3731	Integer	0
ibdot1sAdminMstID.3732	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3732	Integer	0
ibdot1sAdminMstID.3733	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3733	Integer	0
ibdot1sAdminMstID.3734	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3734	Integer	0
ibdot1sAdminMstID.3735	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3735	Integer	0
ibdot1sAdminMstID.3736	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3736	Integer	0
ibdot1sAdminMstID.3737	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3737	Integer	0
ibdot1sAdminMstID.3738	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3738	Integer	0
ibdot1sAdminMstID.3739	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3739	Integer	0
ibdot1sAdminMstID.3740	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3740	Integer	0
ibdot1sAdminMstID.3741	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3741	Integer	0
ibdot1sAdminMstID.3742	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3742	Integer	0
ibdot1sAdminMstID.3743	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3743	Integer	0
ibdot1sAdminMstID.3744	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3744	Integer	0
ibdot1sAdminMstID.3745	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3745	Integer	0
ibdot1sAdminMstID.3746	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3746	Integer	0
ibdot1sAdminMstID.3747	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3747	Integer	0
ibdot1sAdminMstID.3748	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3748	Integer	0
ibdot1sAdminMstID.3749	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3749	Integer	0
ibdot1sAdminMstID.3750	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3750	Integer	0
ibdot1sAdminMstID.3751	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3751	Integer	0
ibdot1sAdminMstID.3752	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3752	Integer	0
ibdot1sAdminMstID.3753	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3753	Integer	0
ibdot1sAdminMstID.3754	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3754	Integer	0
ibdot1sAdminMstID.3755	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3755	Integer	0
ibdot1sAdminMstID.3756	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3756	Integer	0
ibdot1sAdminMstID.3757	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3757	Integer	0
ibdot1sAdminMstID.3758	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3758	Integer	0
ibdot1sAdminMstID.3759	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3759	Integer	0
ibdot1sAdminMstID.3760	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3760	Integer	0
ibdot1sAdminMstID.3761	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3761	Integer	0
ibdot1sAdminMstID.3762	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3762	Integer	0
ibdot1sAdminMstID.3763	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3763	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3764	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3764	Integer	0
ibdot1sAdminMstID.3765	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3765	Integer	0
ibdot1sAdminMstID.3766	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3766	Integer	0
ibdot1sAdminMstID.3767	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3767	Integer	0
ibdot1sAdminMstID.3768	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3768	Integer	0
ibdot1sAdminMstID.3769	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3769	Integer	0
ibdot1sAdminMstID.3770	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3770	Integer	0
ibdot1sAdminMstID.3771	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3771	Integer	0
ibdot1sAdminMstID.3772	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3772	Integer	0
ibdot1sAdminMstID.3773	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3773	Integer	0
ibdot1sAdminMstID.3774	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3774	Integer	0
ibdot1sAdminMstID.3775	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3775	Integer	0
ibdot1sAdminMstID.3776	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3776	Integer	0
ibdot1sAdminMstID.3777	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3777	Integer	0
ibdot1sAdminMstID.3778	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3778	Integer	0
ibdot1sAdminMstID.3779	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3779	Integer	0
ibdot1sAdminMstID.3780	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3780	Integer	0
ibdot1sAdminMstID.3781	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3781	Integer	0
ibdot1sAdminMstID.3782	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3782	Integer	0
ibdot1sAdminMstID.3783	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3783	Integer	0
ibdot1sAdminMstID.3784	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3784	Integer	0
ibdot1sAdminMstID.3785	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3785	Integer	0
ibdot1sAdminMstID.3786	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3786	Integer	0
ibdot1sAdminMstID.3787	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3787	Integer	0
ibdot1sAdminMstID.3788	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3788	Integer	0
ibdot1sAdminMstID.3789	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3789	Integer	0
ibdot1sAdminMstID.3790	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3790	Integer	0
ibdot1sAdminMstID.3791	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3791	Integer	0
ibdot1sAdminMstID.3792	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3792	Integer	0
ibdot1sAdminMstID.3793	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3793	Integer	0
ibdot1sAdminMstID.3794	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3794	Integer	0
ibdot1sAdminMstID.3795	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3795	Integer	0
ibdot1sAdminMstID.3796	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3796	Integer	0
ibdot1sAdminMstID.3797	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3797	Integer	0
ibdot1sAdminMstID.3798	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3798	Integer	0
ibdot1sAdminMstID.3799	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3799	Integer	0
ibdot1sAdminMstID.3800	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3800	Integer	0
ibdot1sAdminMstID.3801	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3801	Integer	0
ibdot1sAdminMstID.3802	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3802	Integer	0
ibdot1sAdminMstID.3803	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3803	Integer	0
ibdot1sAdminMstID.3804	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3804	Integer	0
ibdot1sAdminMstID.3805	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3805	Integer	0
ibdot1sAdminMstID.3806	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3806	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3807	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3807	Integer	0
ibdot1sAdminMstID.3808	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3808	Integer	0
ibdot1sAdminMstID.3809	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3809	Integer	0
ibdot1sAdminMstID.3810	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3810	Integer	0
ibdot1sAdminMstID.3811	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3811	Integer	0
ibdot1sAdminMstID.3812	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3812	Integer	0
ibdot1sAdminMstID.3813	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3813	Integer	0
ibdot1sAdminMstID.3814	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3814	Integer	0
ibdot1sAdminMstID.3815	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3815	Integer	0
ibdot1sAdminMstID.3816	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3816	Integer	0
ibdot1sAdminMstID.3817	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3817	Integer	0
ibdot1sAdminMstID.3818	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3818	Integer	0
ibdot1sAdminMstID.3819	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3819	Integer	0
ibdot1sAdminMstID.3820	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3820	Integer	0
ibdot1sAdminMstID.3821	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3821	Integer	0
ibdot1sAdminMstID.3822	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3822	Integer	0
ibdot1sAdminMstID.3823	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3823	Integer	0
ibdot1sAdminMstID.3824	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3824	Integer	0
ibdot1sAdminMstID.3825	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3825	Integer	0
ibdot1sAdminMstID.3826	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3826	Integer	0
ibdot1sAdminMstID.3827	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3827	Integer	0
ibdot1sAdminMstID.3828	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3828	Integer	0
ibdot1sAdminMstID.3829	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3829	Integer	0
ibdot1sAdminMstID.3830	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3830	Integer	0
ibdot1sAdminMstID.3831	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3831	Integer	0
ibdot1sAdminMstID.3832	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3832	Integer	0
ibdot1sAdminMstID.3833	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3833	Integer	0
ibdot1sAdminMstID.3834	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3834	Integer	0
ibdot1sAdminMstID.3835	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3835	Integer	0
ibdot1sAdminMstID.3836	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3836	Integer	0
ibdot1sAdminMstID.3837	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3837	Integer	0
ibdot1sAdminMstID.3838	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3838	Integer	0
ibdot1sAdminMstID.3839	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3839	Integer	0
ibdot1sAdminMstID.3840	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3840	Integer	0
ibdot1sAdminMstID.3841	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3841	Integer	0
ibdot1sAdminMstID.3842	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3842	Integer	0
ibdot1sAdminMstID.3843	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3843	Integer	0
ibdot1sAdminMstID.3844	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3844	Integer	0
ibdot1sAdminMstID.3845	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3845	Integer	0
ibdot1sAdminMstID.3846	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3846	Integer	0
ibdot1sAdminMstID.3847	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3847	Integer	0
ibdot1sAdminMstID.3848	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3848	Integer	0
ibdot1sAdminMstID.3849	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3849	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3850	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3850	Integer	0
ibdot1sAdminMstID.3851	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3851	Integer	0
ibdot1sAdminMstID.3852	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3852	Integer	0
ibdot1sAdminMstID.3853	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3853	Integer	0
ibdot1sAdminMstID.3854	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3854	Integer	0
ibdot1sAdminMstID.3855	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3855	Integer	0
ibdot1sAdminMstID.3856	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3856	Integer	0
ibdot1sAdminMstID.3857	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3857	Integer	0
ibdot1sAdminMstID.3858	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3858	Integer	0
ibdot1sAdminMstID.3859	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3859	Integer	0
ibdot1sAdminMstID.3860	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3860	Integer	0
ibdot1sAdminMstID.3861	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3861	Integer	0
ibdot1sAdminMstID.3862	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3862	Integer	0
ibdot1sAdminMstID.3863	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3863	Integer	0
ibdot1sAdminMstID.3864	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3864	Integer	0
ibdot1sAdminMstID.3865	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3865	Integer	0
ibdot1sAdminMstID.3866	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3866	Integer	0
ibdot1sAdminMstID.3867	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3867	Integer	0
ibdot1sAdminMstID.3868	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3868	Integer	0
ibdot1sAdminMstID.3869	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3869	Integer	0
ibdot1sAdminMstID.3870	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3870	Integer	0
ibdot1sAdminMstID.3871	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3871	Integer	0
ibdot1sAdminMstID.3872	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3872	Integer	0
ibdot1sAdminMstID.3873	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3873	Integer	0
ibdot1sAdminMstID.3874	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3874	Integer	0
ibdot1sAdminMstID.3875	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3875	Integer	0
ibdot1sAdminMstID.3876	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3876	Integer	0
ibdot1sAdminMstID.3877	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3877	Integer	0
ibdot1sAdminMstID.3878	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3878	Integer	0
ibdot1sAdminMstID.3879	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3879	Integer	0
ibdot1sAdminMstID.3880	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3880	Integer	0
ibdot1sAdminMstID.3881	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3881	Integer	0
ibdot1sAdminMstID.3882	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3882	Integer	0
ibdot1sAdminMstID.3883	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3883	Integer	0
ibdot1sAdminMstID.3884	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3884	Integer	0
ibdot1sAdminMstID.3885	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3885	Integer	0
ibdot1sAdminMstID.3886	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3886	Integer	0
ibdot1sAdminMstID.3887	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3887	Integer	0
ibdot1sAdminMstID.3888	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3888	Integer	0
ibdot1sAdminMstID.3889	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3889	Integer	0
ibdot1sAdminMstID.3890	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3890	Integer	0
ibdot1sAdminMstID.3891	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3891	Integer	0
ibdot1sAdminMstID.3892	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3892	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3893	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3893	Integer	0
ibdot1sAdminMstID.3894	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3894	Integer	0
ibdot1sAdminMstID.3895	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3895	Integer	0
ibdot1sAdminMstID.3896	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3896	Integer	0
ibdot1sAdminMstID.3897	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3897	Integer	0
ibdot1sAdminMstID.3898	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3898	Integer	0
ibdot1sAdminMstID.3899	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3899	Integer	0
ibdot1sAdminMstID.3900	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3900	Integer	0
ibdot1sAdminMstID.3901	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3901	Integer	0
ibdot1sAdminMstID.3902	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3902	Integer	0
ibdot1sAdminMstID.3903	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3903	Integer	0
ibdot1sAdminMstID.3904	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3904	Integer	0
ibdot1sAdminMstID.3905	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3905	Integer	0
ibdot1sAdminMstID.3906	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3906	Integer	0
ibdot1sAdminMstID.3907	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3907	Integer	0
ibdot1sAdminMstID.3908	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3908	Integer	0
ibdot1sAdminMstID.3909	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3909	Integer	0
ibdot1sAdminMstID.3910	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3910	Integer	0
ibdot1sAdminMstID.3911	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3911	Integer	0
ibdot1sAdminMstID.3912	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3912	Integer	0
ibdot1sAdminMstID.3913	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3913	Integer	0
ibdot1sAdminMstID.3914	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3914	Integer	0
ibdot1sAdminMstID.3915	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3915	Integer	0
ibdot1sAdminMstID.3916	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3916	Integer	0
ibdot1sAdminMstID.3917	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3917	Integer	0
ibdot1sAdminMstID.3918	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3918	Integer	0
ibdot1sAdminMstID.3919	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3919	Integer	0
ibdot1sAdminMstID.3920	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3920	Integer	0
ibdot1sAdminMstID.3921	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3921	Integer	0
ibdot1sAdminMstID.3922	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3922	Integer	0
ibdot1sAdminMstID.3923	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3923	Integer	0
ibdot1sAdminMstID.3924	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3924	Integer	0
ibdot1sAdminMstID.3925	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3925	Integer	0
ibdot1sAdminMstID.3926	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3926	Integer	0
ibdot1sAdminMstID.3927	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3927	Integer	0
ibdot1sAdminMstID.3928	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3928	Integer	0
ibdot1sAdminMstID.3929	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3929	Integer	0
ibdot1sAdminMstID.3930	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3930	Integer	0
ibdot1sAdminMstID.3931	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3931	Integer	0
ibdot1sAdminMstID.3932	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3932	Integer	0
ibdot1sAdminMstID.3933	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3933	Integer	0
ibdot1sAdminMstID.3934	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3934	Integer	0
ibdot1sAdminMstID.3935	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3935	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3936	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3936	Integer	0
ibdot1sAdminMstID.3937	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3937	Integer	0
ibdot1sAdminMstID.3938	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3938	Integer	0
ibdot1sAdminMstID.3939	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3939	Integer	0
ibdot1sAdminMstID.3940	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3940	Integer	0
ibdot1sAdminMstID.3941	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3941	Integer	0
ibdot1sAdminMstID.3942	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3942	Integer	0
ibdot1sAdminMstID.3943	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3943	Integer	0
ibdot1sAdminMstID.3944	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3944	Integer	0
ibdot1sAdminMstID.3945	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3945	Integer	0
ibdot1sAdminMstID.3946	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3946	Integer	0
ibdot1sAdminMstID.3947	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3947	Integer	0
ibdot1sAdminMstID.3948	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3948	Integer	0
ibdot1sAdminMstID.3949	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3949	Integer	0
ibdot1sAdminMstID.3950	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3950	Integer	0
ibdot1sAdminMstID.3951	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3951	Integer	0
ibdot1sAdminMstID.3952	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3952	Integer	0
ibdot1sAdminMstID.3953	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3953	Integer	0
ibdot1sAdminMstID.3954	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3954	Integer	0
ibdot1sAdminMstID.3955	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3955	Integer	0
ibdot1sAdminMstID.3956	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3956	Integer	0
ibdot1sAdminMstID.3957	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3957	Integer	0
ibdot1sAdminMstID.3958	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3958	Integer	0
ibdot1sAdminMstID.3959	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3959	Integer	0
ibdot1sAdminMstID.3960	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3960	Integer	0
ibdot1sAdminMstID.3961	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3961	Integer	0
ibdot1sAdminMstID.3962	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3962	Integer	0
ibdot1sAdminMstID.3963	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3963	Integer	0
ibdot1sAdminMstID.3964	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3964	Integer	0
ibdot1sAdminMstID.3965	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3965	Integer	0
ibdot1sAdminMstID.3966	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3966	Integer	0
ibdot1sAdminMstID.3967	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3967	Integer	0
ibdot1sAdminMstID.3968	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3968	Integer	0
ibdot1sAdminMstID.3969	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3969	Integer	0
ibdot1sAdminMstID.3970	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3970	Integer	0
ibdot1sAdminMstID.3971	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3971	Integer	0
ibdot1sAdminMstID.3972	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3972	Integer	0
ibdot1sAdminMstID.3973	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3973	Integer	0
ibdot1sAdminMstID.3974	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3974	Integer	0
ibdot1sAdminMstID.3975	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3975	Integer	0
ibdot1sAdminMstID.3976	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3976	Integer	0
ibdot1sAdminMstID.3977	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3977	Integer	0
ibdot1sAdminMstID.3978	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3978	Integer	0



Name	OID	Value Type	Value Example
ibdot1sAdminMstID.3979	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3979	Integer	0
ibdot1sAdminMstID.3980	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3980	Integer	0
ibdot1sAdminMstID.3981	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3981	Integer	0
ibdot1sAdminMstID.3982	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3982	Integer	0
ibdot1sAdminMstID.3983	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3983	Integer	0
ibdot1sAdminMstID.3984	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3984	Integer	0
ibdot1sAdminMstID.3985	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3985	Integer	0
ibdot1sAdminMstID.3986	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3986	Integer	0
ibdot1sAdminMstID.3987	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3987	Integer	0
ibdot1sAdminMstID.3988	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3988	Integer	0
ibdot1sAdminMstID.3989	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3989	Integer	0
ibdot1sAdminMstID.3990	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3990	Integer	0
ibdot1sAdminMstID.3991	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3991	Integer	0
ibdot1sAdminMstID.3992	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3992	Integer	0
ibdot1sAdminMstID.3993	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3993	Integer	0
ibdot1sAdminMstID.3994	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3994	Integer	0
ibdot1sAdminMstID.3995	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3995	Integer	0
ibdot1sAdminMstID.3996	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3996	Integer	0
ibdot1sAdminMstID.3997	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3997	Integer	0
ibdot1sAdminMstID.3998	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3998	Integer	0
ibdot1sAdminMstID.3999	.1.3.6.1.4.1.26138.8.35.14.18.1.2.3999	Integer	0
ibdot1sAdminMstID.4000	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4000	Integer	0
ibdot1sAdminMstID.4001	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4001	Integer	0
ibdot1sAdminMstID.4002	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4002	Integer	0
ibdot1sAdminMstID.4003	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4003	Integer	0
ibdot1sAdminMstID.4004	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4004	Integer	0
ibdot1sAdminMstID.4005	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4005	Integer	0
ibdot1sAdminMstID.4006	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4006	Integer	0
ibdot1sAdminMstID.4007	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4007	Integer	0
ibdot1sAdminMstID.4008	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4008	Integer	0
ibdot1sAdminMstID.4009	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4009	Integer	0
ibdot1sAdminMstID.4010	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4010	Integer	0
ibdot1sAdminMstID.4011	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4011	Integer	0
ibdot1sAdminMstID.4012	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4012	Integer	0
ibdot1sAdminMstID.4013	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4013	Integer	0
ibdot1sAdminMstID.4014	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4014	Integer	0
ibdot1sAdminMstID.4015	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4015	Integer	0
ibdot1sAdminMstID.4016	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4016	Integer	0
ibdot1sAdminMstID.4017	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4017	Integer	0
ibdot1sAdminMstID.4018	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4018	Integer	0
ibdot1sAdminMstID.4019	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4019	Integer	0
ibdot1sAdminMstID.4020	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4020	Integer	0
ibdot1sAdminMstID.4021	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4021	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.4022	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4022	Integer	0
ibdot1sAdminMstID.4023	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4023	Integer	0
ibdot1sAdminMstID.4024	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4024	Integer	0
ibdot1sAdminMstID.4025	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4025	Integer	0
ibdot1sAdminMstID.4026	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4026	Integer	0
ibdot1sAdminMstID.4027	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4027	Integer	0
ibdot1sAdminMstID.4028	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4028	Integer	0
ibdot1sAdminMstID.4029	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4029	Integer	0
ibdot1sAdminMstID.4030	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4030	Integer	0
ibdot1sAdminMstID.4031	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4031	Integer	0
ibdot1sAdminMstID.4032	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4032	Integer	0
ibdot1sAdminMstID.4033	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4033	Integer	0
ibdot1sAdminMstID.4034	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4034	Integer	0
ibdot1sAdminMstID.4035	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4035	Integer	0
ibdot1sAdminMstID.4036	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4036	Integer	0
ibdot1sAdminMstID.4037	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4037	Integer	0
ibdot1sAdminMstID.4038	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4038	Integer	0
ibdot1sAdminMstID.4039	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4039	Integer	0
ibdot1sAdminMstID.4040	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4040	Integer	0
ibdot1sAdminMstID.4041	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4041	Integer	0
ibdot1sAdminMstID.4042	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4042	Integer	0
ibdot1sAdminMstID.4043	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4043	Integer	0
ibdot1sAdminMstID.4044	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4044	Integer	0
ibdot1sAdminMstID.4045	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4045	Integer	0
ibdot1sAdminMstID.4046	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4046	Integer	0
ibdot1sAdminMstID.4047	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4047	Integer	0
ibdot1sAdminMstID.4048	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4048	Integer	0
ibdot1sAdminMstID.4049	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4049	Integer	0
ibdot1sAdminMstID.4050	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4050	Integer	0
ibdot1sAdminMstID.4051	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4051	Integer	0
ibdot1sAdminMstID.4052	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4052	Integer	0
ibdot1sAdminMstID.4053	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4053	Integer	0
ibdot1sAdminMstID.4054	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4054	Integer	0
ibdot1sAdminMstID.4055	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4055	Integer	0
ibdot1sAdminMstID.4056	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4056	Integer	0
ibdot1sAdminMstID.4057	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4057	Integer	0
ibdot1sAdminMstID.4058	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4058	Integer	0
ibdot1sAdminMstID.4059	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4059	Integer	0
ibdot1sAdminMstID.4060	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4060	Integer	0
ibdot1sAdminMstID.4061	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4061	Integer	0
ibdot1sAdminMstID.4062	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4062	Integer	0
ibdot1sAdminMstID.4063	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4063	Integer	0
ibdot1sAdminMstID.4064	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4064	Integer	0

Name	OID	Value Type	Value Example
ibdot1sAdminMstID.4065	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4065	Integer	0
ibdot1sAdminMstID.4066	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4066	Integer	0
ibdot1sAdminMstID.4067	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4067	Integer	0
ibdot1sAdminMstID.4068	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4068	Integer	0
ibdot1sAdminMstID.4069	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4069	Integer	0
ibdot1sAdminMstID.4070	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4070	Integer	0
ibdot1sAdminMstID.4071	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4071	Integer	0
ibdot1sAdminMstID.4072	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4072	Integer	0
ibdot1sAdminMstID.4073	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4073	Integer	0
ibdot1sAdminMstID.4074	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4074	Integer	0
ibdot1sAdminMstID.4075	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4075	Integer	0
ibdot1sAdminMstID.4076	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4076	Integer	0
ibdot1sAdminMstID.4077	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4077	Integer	0
ibdot1sAdminMstID.4078	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4078	Integer	0
ibdot1sAdminMstID.4079	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4079	Integer	0
ibdot1sAdminMstID.4080	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4080	Integer	0
ibdot1sAdminMstID.4081	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4081	Integer	0
ibdot1sAdminMstID.4082	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4082	Integer	0
ibdot1sAdminMstID.4083	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4083	Integer	0
ibdot1sAdminMstID.4084	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4084	Integer	0
ibdot1sAdminMstID.4085	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4085	Integer	0
ibdot1sAdminMstID.4086	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4086	Integer	0
ibdot1sAdminMstID.4087	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4087	Integer	0
ibdot1sAdminMstID.4088	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4088	Integer	0
ibdot1sAdminMstID.4089	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4089	Integer	0
ibdot1sAdminMstID.4090	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4090	Integer	0
ibdot1sAdminMstID.4091	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4091	Integer	0
ibdot1sAdminMstID.4092	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4092	Integer	0
ibdot1sAdminMstID.4093	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4093	Integer	0
ibdot1sAdminMstID.4094	.1.3.6.1.4.1.26138.8.35.14.18.1.2.4094	Integer	0
ibdot1sOperMstID.1	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1	Integer	0
ibdot1sOperMstID.2	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2	Integer	0
ibdot1sOperMstID.3	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3	Integer	0
ibdot1sOperMstID.4	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4	Integer	0
ibdot1sOperMstID.5	.1.3.6.1.4.1.26138.8.35.14.18.1.3.5	Integer	0
ibdot1sOperMstID.6	.1.3.6.1.4.1.26138.8.35.14.18.1.3.6	Integer	0
ibdot1sOperMstID.7	.1.3.6.1.4.1.26138.8.35.14.18.1.3.7	Integer	0
ibdot1sOperMstID.8	.1.3.6.1.4.1.26138.8.35.14.18.1.3.8	Integer	0
ibdot1sOperMstID.9	.1.3.6.1.4.1.26138.8.35.14.18.1.3.9	Integer	0
ibdot1sOperMstID.10	.1.3.6.1.4.1.26138.8.35.14.18.1.3.10	Integer	0
ibdot1sOperMstID.11	.1.3.6.1.4.1.26138.8.35.14.18.1.3.11	Integer	0
ibdot1sOperMstID.12	.1.3.6.1.4.1.26138.8.35.14.18.1.3.12	Integer	0
ibdot1sOperMstID.13	.1.3.6.1.4.1.26138.8.35.14.18.1.3.13	Integer	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
ibdot1sOperMstID.14	1.3.6.1.4.1.26138.8.35.14.18.1.3.14	Integer	0
ibdot1sOperMstID.15	1.3.6.1.4.1.26138.8.35.14.18.1.3.15	Integer	0
ibdot1sOperMstID.16	1.3.6.1.4.1.26138.8.35.14.18.1.3.16	Integer	0
ibdot1sOperMstID.17	1.3.6.1.4.1.26138.8.35.14.18.1.3.17	Integer	0
ibdot1sOperMstID.18	1.3.6.1.4.1.26138.8.35.14.18.1.3.18	Integer	0
ibdot1sOperMstID.19	1.3.6.1.4.1.26138.8.35.14.18.1.3.19	Integer	0
ibdot1sOperMstID.20	1.3.6.1.4.1.26138.8.35.14.18.1.3.20	Integer	0
ibdot1sOperMstID.21	1.3.6.1.4.1.26138.8.35.14.18.1.3.21	Integer	0
ibdot1sOperMstID.22	1.3.6.1.4.1.26138.8.35.14.18.1.3.22	Integer	0
ibdot1sOperMstID.23	1.3.6.1.4.1.26138.8.35.14.18.1.3.23	Integer	0
ibdot1sOperMstID.24	1.3.6.1.4.1.26138.8.35.14.18.1.3.24	Integer	0
ibdot1sOperMstID.25	1.3.6.1.4.1.26138.8.35.14.18.1.3.25	Integer	0
ibdot1sOperMstID.26	1.3.6.1.4.1.26138.8.35.14.18.1.3.26	Integer	0
ibdot1sOperMstID.27	1.3.6.1.4.1.26138.8.35.14.18.1.3.27	Integer	0
ibdot1sOperMstID.28	1.3.6.1.4.1.26138.8.35.14.18.1.3.28	Integer	0
ibdot1sOperMstID.29	1.3.6.1.4.1.26138.8.35.14.18.1.3.29	Integer	0
ibdot1sOperMstID.30	1.3.6.1.4.1.26138.8.35.14.18.1.3.30	Integer	0
ibdot1sOperMstID.31	1.3.6.1.4.1.26138.8.35.14.18.1.3.31	Integer	0
ibdot1sOperMstID.32	1.3.6.1.4.1.26138.8.35.14.18.1.3.32	Integer	0
ibdot1sOperMstID.33	1.3.6.1.4.1.26138.8.35.14.18.1.3.33	Integer	0
ibdot1sOperMstID.34	1.3.6.1.4.1.26138.8.35.14.18.1.3.34	Integer	0
ibdot1sOperMstID.35	1.3.6.1.4.1.26138.8.35.14.18.1.3.35	Integer	0
ibdot1sOperMstID.36	1.3.6.1.4.1.26138.8.35.14.18.1.3.36	Integer	0
ibdot1sOperMstID.37	1.3.6.1.4.1.26138.8.35.14.18.1.3.37	Integer	0
ibdot1sOperMstID.38	1.3.6.1.4.1.26138.8.35.14.18.1.3.38	Integer	0
ibdot1sOperMstID.39	1.3.6.1.4.1.26138.8.35.14.18.1.3.39	Integer	0
ibdot1sOperMstID.40	1.3.6.1.4.1.26138.8.35.14.18.1.3.40	Integer	0
ibdot1sOperMstID.41	1.3.6.1.4.1.26138.8.35.14.18.1.3.41	Integer	0
ibdot1sOperMstID.42	1.3.6.1.4.1.26138.8.35.14.18.1.3.42	Integer	0
ibdot1sOperMstID.43	1.3.6.1.4.1.26138.8.35.14.18.1.3.43	Integer	0
ibdot1sOperMstID.44	1.3.6.1.4.1.26138.8.35.14.18.1.3.44	Integer	0
ibdot1sOperMstID.45	1.3.6.1.4.1.26138.8.35.14.18.1.3.45	Integer	0
ibdot1sOperMstID.46	1.3.6.1.4.1.26138.8.35.14.18.1.3.46	Integer	0
ibdot1sOperMstID.47	1.3.6.1.4.1.26138.8.35.14.18.1.3.47	Integer	0
ibdot1sOperMstID.48	1.3.6.1.4.1.26138.8.35.14.18.1.3.48	Integer	0
ibdot1sOperMstID.49	1.3.6.1.4.1.26138.8.35.14.18.1.3.49	Integer	0
ibdot1sOperMstID.50	1.3.6.1.4.1.26138.8.35.14.18.1.3.50	Integer	0
ibdot1sOperMstID.51	1.3.6.1.4.1.26138.8.35.14.18.1.3.51	Integer	0
ibdot1sOperMstID.52	1.3.6.1.4.1.26138.8.35.14.18.1.3.52	Integer	0
ibdot1sOperMstID.53	1.3.6.1.4.1.26138.8.35.14.18.1.3.53	Integer	0
ibdot1sOperMstID.54	1.3.6.1.4.1.26138.8.35.14.18.1.3.54	Integer	0
ibdot1sOperMstID.55	1.3.6.1.4.1.26138.8.35.14.18.1.3.55	Integer	0
ibdot1sOperMstID.56	1.3.6.1.4.1.26138.8.35.14.18.1.3.56	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.57	1.3.6.1.4.1.26138.8.35.14.18.1.3.57	Integer	0
ibdot1sOperMstID.58	1.3.6.1.4.1.26138.8.35.14.18.1.3.58	Integer	0
ibdot1sOperMstID.59	1.3.6.1.4.1.26138.8.35.14.18.1.3.59	Integer	0
ibdot1sOperMstID.60	1.3.6.1.4.1.26138.8.35.14.18.1.3.60	Integer	0
ibdot1sOperMstID.61	1.3.6.1.4.1.26138.8.35.14.18.1.3.61	Integer	0
ibdot1sOperMstID.62	1.3.6.1.4.1.26138.8.35.14.18.1.3.62	Integer	0
ibdot1sOperMstID.63	1.3.6.1.4.1.26138.8.35.14.18.1.3.63	Integer	0
ibdot1sOperMstID.64	1.3.6.1.4.1.26138.8.35.14.18.1.3.64	Integer	0
ibdot1sOperMstID.65	1.3.6.1.4.1.26138.8.35.14.18.1.3.65	Integer	0
ibdot1sOperMstID.66	1.3.6.1.4.1.26138.8.35.14.18.1.3.66	Integer	0
ibdot1sOperMstID.67	1.3.6.1.4.1.26138.8.35.14.18.1.3.67	Integer	0
ibdot1sOperMstID.68	1.3.6.1.4.1.26138.8.35.14.18.1.3.68	Integer	0
ibdot1sOperMstID.69	1.3.6.1.4.1.26138.8.35.14.18.1.3.69	Integer	0
ibdot1sOperMstID.70	1.3.6.1.4.1.26138.8.35.14.18.1.3.70	Integer	0
ibdot1sOperMstID.71	1.3.6.1.4.1.26138.8.35.14.18.1.3.71	Integer	0
ibdot1sOperMstID.72	1.3.6.1.4.1.26138.8.35.14.18.1.3.72	Integer	0
ibdot1sOperMstID.73	1.3.6.1.4.1.26138.8.35.14.18.1.3.73	Integer	0
ibdot1sOperMstID.74	1.3.6.1.4.1.26138.8.35.14.18.1.3.74	Integer	0
ibdot1sOperMstID.75	1.3.6.1.4.1.26138.8.35.14.18.1.3.75	Integer	0
ibdot1sOperMstID.76	1.3.6.1.4.1.26138.8.35.14.18.1.3.76	Integer	0
ibdot1sOperMstID.77	1.3.6.1.4.1.26138.8.35.14.18.1.3.77	Integer	0
ibdot1sOperMstID.78	1.3.6.1.4.1.26138.8.35.14.18.1.3.78	Integer	0
ibdot1sOperMstID.79	1.3.6.1.4.1.26138.8.35.14.18.1.3.79	Integer	0
ibdot1sOperMstID.80	1.3.6.1.4.1.26138.8.35.14.18.1.3.80	Integer	0
ibdot1sOperMstID.81	1.3.6.1.4.1.26138.8.35.14.18.1.3.81	Integer	0
ibdot1sOperMstID.82	1.3.6.1.4.1.26138.8.35.14.18.1.3.82	Integer	0
ibdot1sOperMstID.83	1.3.6.1.4.1.26138.8.35.14.18.1.3.83	Integer	0
ibdot1sOperMstID.84	1.3.6.1.4.1.26138.8.35.14.18.1.3.84	Integer	0
ibdot1sOperMstID.85	1.3.6.1.4.1.26138.8.35.14.18.1.3.85	Integer	0
ibdot1sOperMstID.86	1.3.6.1.4.1.26138.8.35.14.18.1.3.86	Integer	0
ibdot1sOperMstID.87	1.3.6.1.4.1.26138.8.35.14.18.1.3.87	Integer	0
ibdot1sOperMstID.88	1.3.6.1.4.1.26138.8.35.14.18.1.3.88	Integer	0
ibdot1sOperMstID.89	1.3.6.1.4.1.26138.8.35.14.18.1.3.89	Integer	0
ibdot1sOperMstID.90	1.3.6.1.4.1.26138.8.35.14.18.1.3.90	Integer	0
ibdot1sOperMstID.91	1.3.6.1.4.1.26138.8.35.14.18.1.3.91	Integer	0
ibdot1sOperMstID.92	1.3.6.1.4.1.26138.8.35.14.18.1.3.92	Integer	0
ibdot1sOperMstID.93	1.3.6.1.4.1.26138.8.35.14.18.1.3.93	Integer	0
ibdot1sOperMstID.94	1.3.6.1.4.1.26138.8.35.14.18.1.3.94	Integer	0
ibdot1sOperMstID.95	1.3.6.1.4.1.26138.8.35.14.18.1.3.95	Integer	0
ibdot1sOperMstID.96	1.3.6.1.4.1.26138.8.35.14.18.1.3.96	Integer	0
ibdot1sOperMstID.97	1.3.6.1.4.1.26138.8.35.14.18.1.3.97	Integer	0
ibdot1sOperMstID.98	1.3.6.1.4.1.26138.8.35.14.18.1.3.98	Integer	0
ibdot1sOperMstID.99	1.3.6.1.4.1.26138.8.35.14.18.1.3.99	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.100	.3.6.1.4.1.26138.8.35.14.18.1.3.100	Integer	0
ibdot1sOperMstID.101	.3.6.1.4.1.26138.8.35.14.18.1.3.101	Integer	0
ibdot1sOperMstID.102	.3.6.1.4.1.26138.8.35.14.18.1.3.102	Integer	0
ibdot1sOperMstID.103	.3.6.1.4.1.26138.8.35.14.18.1.3.103	Integer	0
ibdot1sOperMstID.104	.3.6.1.4.1.26138.8.35.14.18.1.3.104	Integer	0
ibdot1sOperMstID.105	.3.6.1.4.1.26138.8.35.14.18.1.3.105	Integer	0
ibdot1sOperMstID.106	.3.6.1.4.1.26138.8.35.14.18.1.3.106	Integer	0
ibdot1sOperMstID.107	.3.6.1.4.1.26138.8.35.14.18.1.3.107	Integer	0
ibdot1sOperMstID.108	.3.6.1.4.1.26138.8.35.14.18.1.3.108	Integer	0
ibdot1sOperMstID.109	.3.6.1.4.1.26138.8.35.14.18.1.3.109	Integer	0
ibdot1sOperMstID.110	.3.6.1.4.1.26138.8.35.14.18.1.3.110	Integer	0
ibdot1sOperMstID.111	.3.6.1.4.1.26138.8.35.14.18.1.3.111	Integer	0
ibdot1sOperMstID.112	.3.6.1.4.1.26138.8.35.14.18.1.3.112	Integer	0
ibdot1sOperMstID.113	.3.6.1.4.1.26138.8.35.14.18.1.3.113	Integer	0
ibdot1sOperMstID.114	.3.6.1.4.1.26138.8.35.14.18.1.3.114	Integer	0
ibdot1sOperMstID.115	.3.6.1.4.1.26138.8.35.14.18.1.3.115	Integer	0
ibdot1sOperMstID.116	.3.6.1.4.1.26138.8.35.14.18.1.3.116	Integer	0
ibdot1sOperMstID.117	.3.6.1.4.1.26138.8.35.14.18.1.3.117	Integer	0
ibdot1sOperMstID.118	.3.6.1.4.1.26138.8.35.14.18.1.3.118	Integer	0
ibdot1sOperMstID.119	.3.6.1.4.1.26138.8.35.14.18.1.3.119	Integer	0
ibdot1sOperMstID.120	.3.6.1.4.1.26138.8.35.14.18.1.3.120	Integer	0
ibdot1sOperMstID.121	.3.6.1.4.1.26138.8.35.14.18.1.3.121	Integer	0
ibdot1sOperMstID.122	.3.6.1.4.1.26138.8.35.14.18.1.3.122	Integer	0
ibdot1sOperMstID.123	.3.6.1.4.1.26138.8.35.14.18.1.3.123	Integer	0
ibdot1sOperMstID.124	.3.6.1.4.1.26138.8.35.14.18.1.3.124	Integer	0
ibdot1sOperMstID.125	.3.6.1.4.1.26138.8.35.14.18.1.3.125	Integer	0
ibdot1sOperMstID.126	.3.6.1.4.1.26138.8.35.14.18.1.3.126	Integer	0
ibdot1sOperMstID.127	.3.6.1.4.1.26138.8.35.14.18.1.3.127	Integer	0
ibdot1sOperMstID.128	.3.6.1.4.1.26138.8.35.14.18.1.3.128	Integer	0
ibdot1sOperMstID.129	.3.6.1.4.1.26138.8.35.14.18.1.3.129	Integer	0
ibdot1sOperMstID.130	.3.6.1.4.1.26138.8.35.14.18.1.3.130	Integer	0
ibdot1sOperMstID.131	.3.6.1.4.1.26138.8.35.14.18.1.3.131	Integer	0
ibdot1sOperMstID.132	.3.6.1.4.1.26138.8.35.14.18.1.3.132	Integer	0
ibdot1sOperMstID.133	.3.6.1.4.1.26138.8.35.14.18.1.3.133	Integer	0
ibdot1sOperMstID.134	.3.6.1.4.1.26138.8.35.14.18.1.3.134	Integer	0
ibdot1sOperMstID.135	.3.6.1.4.1.26138.8.35.14.18.1.3.135	Integer	0
ibdot1sOperMstID.136	.3.6.1.4.1.26138.8.35.14.18.1.3.136	Integer	0
ibdot1sOperMstID.137	.3.6.1.4.1.26138.8.35.14.18.1.3.137	Integer	0
ibdot1sOperMstID.138	.3.6.1.4.1.26138.8.35.14.18.1.3.138	Integer	0
ibdot1sOperMstID.139	.3.6.1.4.1.26138.8.35.14.18.1.3.139	Integer	0
ibdot1sOperMstID.140	.3.6.1.4.1.26138.8.35.14.18.1.3.140	Integer	0
ibdot1sOperMstID.141	.3.6.1.4.1.26138.8.35.14.18.1.3.141	Integer	0
ibdot1sOperMstID.142	.3.6.1.4.1.26138.8.35.14.18.1.3.142	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.143	.3.6.1.4.1.26138.8.35.14.18.1.3.143	Integer	0
ibdot1sOperMstID.144	.3.6.1.4.1.26138.8.35.14.18.1.3.144	Integer	0
ibdot1sOperMstID.145	.3.6.1.4.1.26138.8.35.14.18.1.3.145	Integer	0
ibdot1sOperMstID.146	.3.6.1.4.1.26138.8.35.14.18.1.3.146	Integer	0
ibdot1sOperMstID.147	.3.6.1.4.1.26138.8.35.14.18.1.3.147	Integer	0
ibdot1sOperMstID.148	.3.6.1.4.1.26138.8.35.14.18.1.3.148	Integer	0
ibdot1sOperMstID.149	.3.6.1.4.1.26138.8.35.14.18.1.3.149	Integer	0
ibdot1sOperMstID.150	.3.6.1.4.1.26138.8.35.14.18.1.3.150	Integer	0
ibdot1sOperMstID.151	.3.6.1.4.1.26138.8.35.14.18.1.3.151	Integer	0
ibdot1sOperMstID.152	.3.6.1.4.1.26138.8.35.14.18.1.3.152	Integer	0
ibdot1sOperMstID.153	.3.6.1.4.1.26138.8.35.14.18.1.3.153	Integer	0
ibdot1sOperMstID.154	.3.6.1.4.1.26138.8.35.14.18.1.3.154	Integer	0
ibdot1sOperMstID.155	.3.6.1.4.1.26138.8.35.14.18.1.3.155	Integer	0
ibdot1sOperMstID.156	.3.6.1.4.1.26138.8.35.14.18.1.3.156	Integer	0
ibdot1sOperMstID.157	.3.6.1.4.1.26138.8.35.14.18.1.3.157	Integer	0
ibdot1sOperMstID.158	.3.6.1.4.1.26138.8.35.14.18.1.3.158	Integer	0
ibdot1sOperMstID.159	.3.6.1.4.1.26138.8.35.14.18.1.3.159	Integer	0
ibdot1sOperMstID.160	.3.6.1.4.1.26138.8.35.14.18.1.3.160	Integer	0
ibdot1sOperMstID.161	.3.6.1.4.1.26138.8.35.14.18.1.3.161	Integer	0
ibdot1sOperMstID.162	.3.6.1.4.1.26138.8.35.14.18.1.3.162	Integer	0
ibdot1sOperMstID.163	.3.6.1.4.1.26138.8.35.14.18.1.3.163	Integer	0
ibdot1sOperMstID.164	.3.6.1.4.1.26138.8.35.14.18.1.3.164	Integer	0
ibdot1sOperMstID.165	.3.6.1.4.1.26138.8.35.14.18.1.3.165	Integer	0
ibdot1sOperMstID.166	.3.6.1.4.1.26138.8.35.14.18.1.3.166	Integer	0
ibdot1sOperMstID.167	.3.6.1.4.1.26138.8.35.14.18.1.3.167	Integer	0
ibdot1sOperMstID.168	.3.6.1.4.1.26138.8.35.14.18.1.3.168	Integer	0
ibdot1sOperMstID.169	.3.6.1.4.1.26138.8.35.14.18.1.3.169	Integer	0
ibdot1sOperMstID.170	.3.6.1.4.1.26138.8.35.14.18.1.3.170	Integer	0
ibdot1sOperMstID.171	.3.6.1.4.1.26138.8.35.14.18.1.3.171	Integer	0
ibdot1sOperMstID.172	.3.6.1.4.1.26138.8.35.14.18.1.3.172	Integer	0
ibdot1sOperMstID.173	.3.6.1.4.1.26138.8.35.14.18.1.3.173	Integer	0
ibdot1sOperMstID.174	.3.6.1.4.1.26138.8.35.14.18.1.3.174	Integer	0
ibdot1sOperMstID.175	.3.6.1.4.1.26138.8.35.14.18.1.3.175	Integer	0
ibdot1sOperMstID.176	.3.6.1.4.1.26138.8.35.14.18.1.3.176	Integer	0
ibdot1sOperMstID.177	.3.6.1.4.1.26138.8.35.14.18.1.3.177	Integer	0
ibdot1sOperMstID.178	.3.6.1.4.1.26138.8.35.14.18.1.3.178	Integer	0
ibdot1sOperMstID.179	.3.6.1.4.1.26138.8.35.14.18.1.3.179	Integer	0
ibdot1sOperMstID.180	.3.6.1.4.1.26138.8.35.14.18.1.3.180	Integer	0
ibdot1sOperMstID.181	.3.6.1.4.1.26138.8.35.14.18.1.3.181	Integer	0
ibdot1sOperMstID.182	.3.6.1.4.1.26138.8.35.14.18.1.3.182	Integer	0
ibdot1sOperMstID.183	.3.6.1.4.1.26138.8.35.14.18.1.3.183	Integer	0
ibdot1sOperMstID.184	.3.6.1.4.1.26138.8.35.14.18.1.3.184	Integer	0
ibdot1sOperMstID.185	.3.6.1.4.1.26138.8.35.14.18.1.3.185	Integer	0



Name	OID	Value Type	Value Example
ibdot1sOperMstID.186	.3.6.1.4.1.26138.8.35.14.18.1.3.186	Integer	0
ibdot1sOperMstID.187	.3.6.1.4.1.26138.8.35.14.18.1.3.187	Integer	0
ibdot1sOperMstID.188	.3.6.1.4.1.26138.8.35.14.18.1.3.188	Integer	0
ibdot1sOperMstID.189	.3.6.1.4.1.26138.8.35.14.18.1.3.189	Integer	0
ibdot1sOperMstID.190	.3.6.1.4.1.26138.8.35.14.18.1.3.190	Integer	0
ibdot1sOperMstID.191	.3.6.1.4.1.26138.8.35.14.18.1.3.191	Integer	0
ibdot1sOperMstID.192	.3.6.1.4.1.26138.8.35.14.18.1.3.192	Integer	0
ibdot1sOperMstID.193	.3.6.1.4.1.26138.8.35.14.18.1.3.193	Integer	0
ibdot1sOperMstID.194	.3.6.1.4.1.26138.8.35.14.18.1.3.194	Integer	0
ibdot1sOperMstID.195	.3.6.1.4.1.26138.8.35.14.18.1.3.195	Integer	0
ibdot1sOperMstID.196	.3.6.1.4.1.26138.8.35.14.18.1.3.196	Integer	0
ibdot1sOperMstID.197	.3.6.1.4.1.26138.8.35.14.18.1.3.197	Integer	0
ibdot1sOperMstID.198	.3.6.1.4.1.26138.8.35.14.18.1.3.198	Integer	0
ibdot1sOperMstID.199	.3.6.1.4.1.26138.8.35.14.18.1.3.199	Integer	0
ibdot1sOperMstID.200	.3.6.1.4.1.26138.8.35.14.18.1.3.200	Integer	0
ibdot1sOperMstID.201	.3.6.1.4.1.26138.8.35.14.18.1.3.201	Integer	0
ibdot1sOperMstID.202	.3.6.1.4.1.26138.8.35.14.18.1.3.202	Integer	0
ibdot1sOperMstID.203	.3.6.1.4.1.26138.8.35.14.18.1.3.203	Integer	0
ibdot1sOperMstID.204	.3.6.1.4.1.26138.8.35.14.18.1.3.204	Integer	0
ibdot1sOperMstID.205	.3.6.1.4.1.26138.8.35.14.18.1.3.205	Integer	0
ibdot1sOperMstID.206	.3.6.1.4.1.26138.8.35.14.18.1.3.206	Integer	0
ibdot1sOperMstID.207	.3.6.1.4.1.26138.8.35.14.18.1.3.207	Integer	0
ibdot1sOperMstID.208	.3.6.1.4.1.26138.8.35.14.18.1.3.208	Integer	0
ibdot1sOperMstID.209	.3.6.1.4.1.26138.8.35.14.18.1.3.209	Integer	0
ibdot1sOperMstID.210	.3.6.1.4.1.26138.8.35.14.18.1.3.210	Integer	0
ibdot1sOperMstID.211	.3.6.1.4.1.26138.8.35.14.18.1.3.211	Integer	0
ibdot1sOperMstID.212	.3.6.1.4.1.26138.8.35.14.18.1.3.212	Integer	0
ibdot1sOperMstID.213	.3.6.1.4.1.26138.8.35.14.18.1.3.213	Integer	0
ibdot1sOperMstID.214	.3.6.1.4.1.26138.8.35.14.18.1.3.214	Integer	0
ibdot1sOperMstID.215	.3.6.1.4.1.26138.8.35.14.18.1.3.215	Integer	0
ibdot1sOperMstID.216	.3.6.1.4.1.26138.8.35.14.18.1.3.216	Integer	0
ibdot1sOperMstID.217	.3.6.1.4.1.26138.8.35.14.18.1.3.217	Integer	0
ibdot1sOperMstID.218	.3.6.1.4.1.26138.8.35.14.18.1.3.218	Integer	0
ibdot1sOperMstID.219	.3.6.1.4.1.26138.8.35.14.18.1.3.219	Integer	0
ibdot1sOperMstID.220	.3.6.1.4.1.26138.8.35.14.18.1.3.220	Integer	0
ibdot1sOperMstID.221	.3.6.1.4.1.26138.8.35.14.18.1.3.221	Integer	0
ibdot1sOperMstID.222	.3.6.1.4.1.26138.8.35.14.18.1.3.222	Integer	0
ibdot1sOperMstID.223	.3.6.1.4.1.26138.8.35.14.18.1.3.223	Integer	0
ibdot1sOperMstID.224	.3.6.1.4.1.26138.8.35.14.18.1.3.224	Integer	0
ibdot1sOperMstID.225	.3.6.1.4.1.26138.8.35.14.18.1.3.225	Integer	0
ibdot1sOperMstID.226	.3.6.1.4.1.26138.8.35.14.18.1.3.226	Integer	0
ibdot1sOperMstID.227	.3.6.1.4.1.26138.8.35.14.18.1.3.227	Integer	0
ibdot1sOperMstID.228	.3.6.1.4.1.26138.8.35.14.18.1.3.228	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.229	.3.6.1.4.1.26138.8.35.14.18.1.3.229	Integer	0
ibdot1sOperMstID.230	.3.6.1.4.1.26138.8.35.14.18.1.3.230	Integer	0
ibdot1sOperMstID.231	.3.6.1.4.1.26138.8.35.14.18.1.3.231	Integer	0
ibdot1sOperMstID.232	.3.6.1.4.1.26138.8.35.14.18.1.3.232	Integer	0
ibdot1sOperMstID.233	.3.6.1.4.1.26138.8.35.14.18.1.3.233	Integer	0
ibdot1sOperMstID.234	.3.6.1.4.1.26138.8.35.14.18.1.3.234	Integer	0
ibdot1sOperMstID.235	.3.6.1.4.1.26138.8.35.14.18.1.3.235	Integer	0
ibdot1sOperMstID.236	.3.6.1.4.1.26138.8.35.14.18.1.3.236	Integer	0
ibdot1sOperMstID.237	.3.6.1.4.1.26138.8.35.14.18.1.3.237	Integer	0
ibdot1sOperMstID.238	.3.6.1.4.1.26138.8.35.14.18.1.3.238	Integer	0
ibdot1sOperMstID.239	.3.6.1.4.1.26138.8.35.14.18.1.3.239	Integer	0
ibdot1sOperMstID.240	.3.6.1.4.1.26138.8.35.14.18.1.3.240	Integer	0
ibdot1sOperMstID.241	.3.6.1.4.1.26138.8.35.14.18.1.3.241	Integer	0
ibdot1sOperMstID.242	.3.6.1.4.1.26138.8.35.14.18.1.3.242	Integer	0
ibdot1sOperMstID.243	.3.6.1.4.1.26138.8.35.14.18.1.3.243	Integer	0
ibdot1sOperMstID.244	.3.6.1.4.1.26138.8.35.14.18.1.3.244	Integer	0
ibdot1sOperMstID.245	.3.6.1.4.1.26138.8.35.14.18.1.3.245	Integer	0
ibdot1sOperMstID.246	.3.6.1.4.1.26138.8.35.14.18.1.3.246	Integer	0
ibdot1sOperMstID.247	.3.6.1.4.1.26138.8.35.14.18.1.3.247	Integer	0
ibdot1sOperMstID.248	.3.6.1.4.1.26138.8.35.14.18.1.3.248	Integer	0
ibdot1sOperMstID.249	.3.6.1.4.1.26138.8.35.14.18.1.3.249	Integer	0
ibdot1sOperMstID.250	.3.6.1.4.1.26138.8.35.14.18.1.3.250	Integer	0
ibdot1sOperMstID.251	.3.6.1.4.1.26138.8.35.14.18.1.3.251	Integer	0
ibdot1sOperMstID.252	.3.6.1.4.1.26138.8.35.14.18.1.3.252	Integer	0
ibdot1sOperMstID.253	.3.6.1.4.1.26138.8.35.14.18.1.3.253	Integer	0
ibdot1sOperMstID.254	.3.6.1.4.1.26138.8.35.14.18.1.3.254	Integer	0
ibdot1sOperMstID.255	.3.6.1.4.1.26138.8.35.14.18.1.3.255	Integer	0
ibdot1sOperMstID.256	.3.6.1.4.1.26138.8.35.14.18.1.3.256	Integer	0
ibdot1sOperMstID.257	.3.6.1.4.1.26138.8.35.14.18.1.3.257	Integer	0
ibdot1sOperMstID.258	.3.6.1.4.1.26138.8.35.14.18.1.3.258	Integer	0
ibdot1sOperMstID.259	.3.6.1.4.1.26138.8.35.14.18.1.3.259	Integer	0
ibdot1sOperMstID.260	.3.6.1.4.1.26138.8.35.14.18.1.3.260	Integer	0
ibdot1sOperMstID.261	.3.6.1.4.1.26138.8.35.14.18.1.3.261	Integer	0
ibdot1sOperMstID.262	.3.6.1.4.1.26138.8.35.14.18.1.3.262	Integer	0
ibdot1sOperMstID.263	.3.6.1.4.1.26138.8.35.14.18.1.3.263	Integer	0
ibdot1sOperMstID.264	.3.6.1.4.1.26138.8.35.14.18.1.3.264	Integer	0
ibdot1sOperMstID.265	.3.6.1.4.1.26138.8.35.14.18.1.3.265	Integer	0
ibdot1sOperMstID.266	.3.6.1.4.1.26138.8.35.14.18.1.3.266	Integer	0
ibdot1sOperMstID.267	.3.6.1.4.1.26138.8.35.14.18.1.3.267	Integer	0
ibdot1sOperMstID.268	.3.6.1.4.1.26138.8.35.14.18.1.3.268	Integer	0
ibdot1sOperMstID.269	.3.6.1.4.1.26138.8.35.14.18.1.3.269	Integer	0
ibdot1sOperMstID.270	.3.6.1.4.1.26138.8.35.14.18.1.3.270	Integer	0
ibdot1sOperMstID.271	.3.6.1.4.1.26138.8.35.14.18.1.3.271	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.272	.3.6.1.4.1.26138.8.35.14.18.1.3.272	Integer	0
ibdot1sOperMstID.273	.3.6.1.4.1.26138.8.35.14.18.1.3.273	Integer	0
ibdot1sOperMstID.274	.3.6.1.4.1.26138.8.35.14.18.1.3.274	Integer	0
ibdot1sOperMstID.275	.3.6.1.4.1.26138.8.35.14.18.1.3.275	Integer	0
ibdot1sOperMstID.276	.3.6.1.4.1.26138.8.35.14.18.1.3.276	Integer	0
ibdot1sOperMstID.277	.3.6.1.4.1.26138.8.35.14.18.1.3.277	Integer	0
ibdot1sOperMstID.278	.3.6.1.4.1.26138.8.35.14.18.1.3.278	Integer	0
ibdot1sOperMstID.279	.3.6.1.4.1.26138.8.35.14.18.1.3.279	Integer	0
ibdot1sOperMstID.280	.3.6.1.4.1.26138.8.35.14.18.1.3.280	Integer	0
ibdot1sOperMstID.281	.3.6.1.4.1.26138.8.35.14.18.1.3.281	Integer	0
ibdot1sOperMstID.282	.3.6.1.4.1.26138.8.35.14.18.1.3.282	Integer	0
ibdot1sOperMstID.283	.3.6.1.4.1.26138.8.35.14.18.1.3.283	Integer	0
ibdot1sOperMstID.284	.3.6.1.4.1.26138.8.35.14.18.1.3.284	Integer	0
ibdot1sOperMstID.285	.3.6.1.4.1.26138.8.35.14.18.1.3.285	Integer	0
ibdot1sOperMstID.286	.3.6.1.4.1.26138.8.35.14.18.1.3.286	Integer	0
ibdot1sOperMstID.287	.3.6.1.4.1.26138.8.35.14.18.1.3.287	Integer	0
ibdot1sOperMstID.288	.3.6.1.4.1.26138.8.35.14.18.1.3.288	Integer	0
ibdot1sOperMstID.289	.3.6.1.4.1.26138.8.35.14.18.1.3.289	Integer	0
ibdot1sOperMstID.290	.3.6.1.4.1.26138.8.35.14.18.1.3.290	Integer	0
ibdot1sOperMstID.291	.3.6.1.4.1.26138.8.35.14.18.1.3.291	Integer	0
ibdot1sOperMstID.292	.3.6.1.4.1.26138.8.35.14.18.1.3.292	Integer	0
ibdot1sOperMstID.293	.3.6.1.4.1.26138.8.35.14.18.1.3.293	Integer	0
ibdot1sOperMstID.294	.3.6.1.4.1.26138.8.35.14.18.1.3.294	Integer	0
ibdot1sOperMstID.295	.3.6.1.4.1.26138.8.35.14.18.1.3.295	Integer	0
ibdot1sOperMstID.296	.3.6.1.4.1.26138.8.35.14.18.1.3.296	Integer	0
ibdot1sOperMstID.297	.3.6.1.4.1.26138.8.35.14.18.1.3.297	Integer	0
ibdot1sOperMstID.298	.3.6.1.4.1.26138.8.35.14.18.1.3.298	Integer	0
ibdot1sOperMstID.299	.3.6.1.4.1.26138.8.35.14.18.1.3.299	Integer	0
ibdot1sOperMstID.300	.3.6.1.4.1.26138.8.35.14.18.1.3.300	Integer	0
ibdot1sOperMstID.301	.3.6.1.4.1.26138.8.35.14.18.1.3.301	Integer	0
ibdot1sOperMstID.302	.3.6.1.4.1.26138.8.35.14.18.1.3.302	Integer	0
ibdot1sOperMstID.303	.3.6.1.4.1.26138.8.35.14.18.1.3.303	Integer	0
ibdot1sOperMstID.304	.3.6.1.4.1.26138.8.35.14.18.1.3.304	Integer	0
ibdot1sOperMstID.305	.3.6.1.4.1.26138.8.35.14.18.1.3.305	Integer	0
ibdot1sOperMstID.306	.3.6.1.4.1.26138.8.35.14.18.1.3.306	Integer	0
ibdot1sOperMstID.307	.3.6.1.4.1.26138.8.35.14.18.1.3.307	Integer	0
ibdot1sOperMstID.308	.3.6.1.4.1.26138.8.35.14.18.1.3.308	Integer	0
ibdot1sOperMstID.309	.3.6.1.4.1.26138.8.35.14.18.1.3.309	Integer	0
ibdot1sOperMstID.310	.3.6.1.4.1.26138.8.35.14.18.1.3.310	Integer	0
ibdot1sOperMstID.311	.3.6.1.4.1.26138.8.35.14.18.1.3.311	Integer	0
ibdot1sOperMstID.312	.3.6.1.4.1.26138.8.35.14.18.1.3.312	Integer	0
ibdot1sOperMstID.313	.3.6.1.4.1.26138.8.35.14.18.1.3.313	Integer	0
ibdot1sOperMstID.314	.3.6.1.4.1.26138.8.35.14.18.1.3.314	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.315	.3.6.1.4.1.26138.8.35.14.18.1.3.315	Integer	0
ibdot1sOperMstID.316	.3.6.1.4.1.26138.8.35.14.18.1.3.316	Integer	0
ibdot1sOperMstID.317	.3.6.1.4.1.26138.8.35.14.18.1.3.317	Integer	0
ibdot1sOperMstID.318	.3.6.1.4.1.26138.8.35.14.18.1.3.318	Integer	0
ibdot1sOperMstID.319	.3.6.1.4.1.26138.8.35.14.18.1.3.319	Integer	0
ibdot1sOperMstID.320	.3.6.1.4.1.26138.8.35.14.18.1.3.320	Integer	0
ibdot1sOperMstID.321	.3.6.1.4.1.26138.8.35.14.18.1.3.321	Integer	0
ibdot1sOperMstID.322	.3.6.1.4.1.26138.8.35.14.18.1.3.322	Integer	0
ibdot1sOperMstID.323	.3.6.1.4.1.26138.8.35.14.18.1.3.323	Integer	0
ibdot1sOperMstID.324	.3.6.1.4.1.26138.8.35.14.18.1.3.324	Integer	0
ibdot1sOperMstID.325	.3.6.1.4.1.26138.8.35.14.18.1.3.325	Integer	0
ibdot1sOperMstID.326	.3.6.1.4.1.26138.8.35.14.18.1.3.326	Integer	0
ibdot1sOperMstID.327	.3.6.1.4.1.26138.8.35.14.18.1.3.327	Integer	0
ibdot1sOperMstID.328	.3.6.1.4.1.26138.8.35.14.18.1.3.328	Integer	0
ibdot1sOperMstID.329	.3.6.1.4.1.26138.8.35.14.18.1.3.329	Integer	0
ibdot1sOperMstID.330	.3.6.1.4.1.26138.8.35.14.18.1.3.330	Integer	0
ibdot1sOperMstID.331	.3.6.1.4.1.26138.8.35.14.18.1.3.331	Integer	0
ibdot1sOperMstID.332	.3.6.1.4.1.26138.8.35.14.18.1.3.332	Integer	0
ibdot1sOperMstID.333	.3.6.1.4.1.26138.8.35.14.18.1.3.333	Integer	0
ibdot1sOperMstID.334	.3.6.1.4.1.26138.8.35.14.18.1.3.334	Integer	0
ibdot1sOperMstID.335	.3.6.1.4.1.26138.8.35.14.18.1.3.335	Integer	0
ibdot1sOperMstID.336	.3.6.1.4.1.26138.8.35.14.18.1.3.336	Integer	0
ibdot1sOperMstID.337	.3.6.1.4.1.26138.8.35.14.18.1.3.337	Integer	0
ibdot1sOperMstID.338	.3.6.1.4.1.26138.8.35.14.18.1.3.338	Integer	0
ibdot1sOperMstID.339	.3.6.1.4.1.26138.8.35.14.18.1.3.339	Integer	0
ibdot1sOperMstID.340	.3.6.1.4.1.26138.8.35.14.18.1.3.340	Integer	0
ibdot1sOperMstID.341	.3.6.1.4.1.26138.8.35.14.18.1.3.341	Integer	0
ibdot1sOperMstID.342	.3.6.1.4.1.26138.8.35.14.18.1.3.342	Integer	0
ibdot1sOperMstID.343	.3.6.1.4.1.26138.8.35.14.18.1.3.343	Integer	0
ibdot1sOperMstID.344	.3.6.1.4.1.26138.8.35.14.18.1.3.344	Integer	0
ibdot1sOperMstID.345	.3.6.1.4.1.26138.8.35.14.18.1.3.345	Integer	0
ibdot1sOperMstID.346	.3.6.1.4.1.26138.8.35.14.18.1.3.346	Integer	0
ibdot1sOperMstID.347	.3.6.1.4.1.26138.8.35.14.18.1.3.347	Integer	0
ibdot1sOperMstID.348	.3.6.1.4.1.26138.8.35.14.18.1.3.348	Integer	0
ibdot1sOperMstID.349	.3.6.1.4.1.26138.8.35.14.18.1.3.349	Integer	0
ibdot1sOperMstID.350	.3.6.1.4.1.26138.8.35.14.18.1.3.350	Integer	0
ibdot1sOperMstID.351	.3.6.1.4.1.26138.8.35.14.18.1.3.351	Integer	0
ibdot1sOperMstID.352	.3.6.1.4.1.26138.8.35.14.18.1.3.352	Integer	0
ibdot1sOperMstID.353	.3.6.1.4.1.26138.8.35.14.18.1.3.353	Integer	0
ibdot1sOperMstID.354	.3.6.1.4.1.26138.8.35.14.18.1.3.354	Integer	0
ibdot1sOperMstID.355	.3.6.1.4.1.26138.8.35.14.18.1.3.355	Integer	0
ibdot1sOperMstID.356	.3.6.1.4.1.26138.8.35.14.18.1.3.356	Integer	0
ibdot1sOperMstID.357	.3.6.1.4.1.26138.8.35.14.18.1.3.357	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.358	.3.6.1.4.1.26138.8.35.14.18.1.3.358	Integer	0
ibdot1sOperMstID.359	.3.6.1.4.1.26138.8.35.14.18.1.3.359	Integer	0
ibdot1sOperMstID.360	.3.6.1.4.1.26138.8.35.14.18.1.3.360	Integer	0
ibdot1sOperMstID.361	.3.6.1.4.1.26138.8.35.14.18.1.3.361	Integer	0
ibdot1sOperMstID.362	.3.6.1.4.1.26138.8.35.14.18.1.3.362	Integer	0
ibdot1sOperMstID.363	.3.6.1.4.1.26138.8.35.14.18.1.3.363	Integer	0
ibdot1sOperMstID.364	.3.6.1.4.1.26138.8.35.14.18.1.3.364	Integer	0
ibdot1sOperMstID.365	.3.6.1.4.1.26138.8.35.14.18.1.3.365	Integer	0
ibdot1sOperMstID.366	.3.6.1.4.1.26138.8.35.14.18.1.3.366	Integer	0
ibdot1sOperMstID.367	.3.6.1.4.1.26138.8.35.14.18.1.3.367	Integer	0
ibdot1sOperMstID.368	.3.6.1.4.1.26138.8.35.14.18.1.3.368	Integer	0
ibdot1sOperMstID.369	.3.6.1.4.1.26138.8.35.14.18.1.3.369	Integer	0
ibdot1sOperMstID.370	.3.6.1.4.1.26138.8.35.14.18.1.3.370	Integer	0
ibdot1sOperMstID.371	.3.6.1.4.1.26138.8.35.14.18.1.3.371	Integer	0
ibdot1sOperMstID.372	.3.6.1.4.1.26138.8.35.14.18.1.3.372	Integer	0
ibdot1sOperMstID.373	.3.6.1.4.1.26138.8.35.14.18.1.3.373	Integer	0
ibdot1sOperMstID.374	.3.6.1.4.1.26138.8.35.14.18.1.3.374	Integer	0
ibdot1sOperMstID.375	.3.6.1.4.1.26138.8.35.14.18.1.3.375	Integer	0
ibdot1sOperMstID.376	.3.6.1.4.1.26138.8.35.14.18.1.3.376	Integer	0
ibdot1sOperMstID.377	.3.6.1.4.1.26138.8.35.14.18.1.3.377	Integer	0
ibdot1sOperMstID.378	.3.6.1.4.1.26138.8.35.14.18.1.3.378	Integer	0
ibdot1sOperMstID.379	.3.6.1.4.1.26138.8.35.14.18.1.3.379	Integer	0
ibdot1sOperMstID.380	.3.6.1.4.1.26138.8.35.14.18.1.3.380	Integer	0
ibdot1sOperMstID.381	.3.6.1.4.1.26138.8.35.14.18.1.3.381	Integer	0
ibdot1sOperMstID.382	.3.6.1.4.1.26138.8.35.14.18.1.3.382	Integer	0
ibdot1sOperMstID.383	.3.6.1.4.1.26138.8.35.14.18.1.3.383	Integer	0
ibdot1sOperMstID.384	.3.6.1.4.1.26138.8.35.14.18.1.3.384	Integer	0
ibdot1sOperMstID.385	.3.6.1.4.1.26138.8.35.14.18.1.3.385	Integer	0
ibdot1sOperMstID.386	.3.6.1.4.1.26138.8.35.14.18.1.3.386	Integer	0
ibdot1sOperMstID.387	.3.6.1.4.1.26138.8.35.14.18.1.3.387	Integer	0
ibdot1sOperMstID.388	.3.6.1.4.1.26138.8.35.14.18.1.3.388	Integer	0
ibdot1sOperMstID.389	.3.6.1.4.1.26138.8.35.14.18.1.3.389	Integer	0
ibdot1sOperMstID.390	.3.6.1.4.1.26138.8.35.14.18.1.3.390	Integer	0
ibdot1sOperMstID.391	.3.6.1.4.1.26138.8.35.14.18.1.3.391	Integer	0
ibdot1sOperMstID.392	.3.6.1.4.1.26138.8.35.14.18.1.3.392	Integer	0
ibdot1sOperMstID.393	.3.6.1.4.1.26138.8.35.14.18.1.3.393	Integer	0
ibdot1sOperMstID.394	.3.6.1.4.1.26138.8.35.14.18.1.3.394	Integer	0
ibdot1sOperMstID.395	.3.6.1.4.1.26138.8.35.14.18.1.3.395	Integer	0
ibdot1sOperMstID.396	.3.6.1.4.1.26138.8.35.14.18.1.3.396	Integer	0
ibdot1sOperMstID.397	.3.6.1.4.1.26138.8.35.14.18.1.3.397	Integer	0
ibdot1sOperMstID.398	.3.6.1.4.1.26138.8.35.14.18.1.3.398	Integer	0
ibdot1sOperMstID.399	.3.6.1.4.1.26138.8.35.14.18.1.3.399	Integer	0
ibdot1sOperMstID.400	.3.6.1.4.1.26138.8.35.14.18.1.3.400	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.401	.3.6.1.4.1.26138.8.35.14.18.1.3.401	Integer	0
ibdot1sOperMstID.402	.3.6.1.4.1.26138.8.35.14.18.1.3.402	Integer	0
ibdot1sOperMstID.403	.3.6.1.4.1.26138.8.35.14.18.1.3.403	Integer	0
ibdot1sOperMstID.404	.3.6.1.4.1.26138.8.35.14.18.1.3.404	Integer	0
ibdot1sOperMstID.405	.3.6.1.4.1.26138.8.35.14.18.1.3.405	Integer	0
ibdot1sOperMstID.406	.3.6.1.4.1.26138.8.35.14.18.1.3.406	Integer	0
ibdot1sOperMstID.407	.3.6.1.4.1.26138.8.35.14.18.1.3.407	Integer	0
ibdot1sOperMstID.408	.3.6.1.4.1.26138.8.35.14.18.1.3.408	Integer	0
ibdot1sOperMstID.409	.3.6.1.4.1.26138.8.35.14.18.1.3.409	Integer	0
ibdot1sOperMstID.410	.3.6.1.4.1.26138.8.35.14.18.1.3.410	Integer	0
ibdot1sOperMstID.411	.3.6.1.4.1.26138.8.35.14.18.1.3.411	Integer	0
ibdot1sOperMstID.412	.3.6.1.4.1.26138.8.35.14.18.1.3.412	Integer	0
ibdot1sOperMstID.413	.3.6.1.4.1.26138.8.35.14.18.1.3.413	Integer	0
ibdot1sOperMstID.414	.3.6.1.4.1.26138.8.35.14.18.1.3.414	Integer	0
ibdot1sOperMstID.415	.3.6.1.4.1.26138.8.35.14.18.1.3.415	Integer	0
ibdot1sOperMstID.416	.3.6.1.4.1.26138.8.35.14.18.1.3.416	Integer	0
ibdot1sOperMstID.417	.3.6.1.4.1.26138.8.35.14.18.1.3.417	Integer	0
ibdot1sOperMstID.418	.3.6.1.4.1.26138.8.35.14.18.1.3.418	Integer	0
ibdot1sOperMstID.419	.3.6.1.4.1.26138.8.35.14.18.1.3.419	Integer	0
ibdot1sOperMstID.420	.3.6.1.4.1.26138.8.35.14.18.1.3.420	Integer	0
ibdot1sOperMstID.421	.3.6.1.4.1.26138.8.35.14.18.1.3.421	Integer	0
ibdot1sOperMstID.422	.3.6.1.4.1.26138.8.35.14.18.1.3.422	Integer	0
ibdot1sOperMstID.423	.3.6.1.4.1.26138.8.35.14.18.1.3.423	Integer	0
ibdot1sOperMstID.424	.3.6.1.4.1.26138.8.35.14.18.1.3.424	Integer	0
ibdot1sOperMstID.425	.3.6.1.4.1.26138.8.35.14.18.1.3.425	Integer	0
ibdot1sOperMstID.426	.3.6.1.4.1.26138.8.35.14.18.1.3.426	Integer	0
ibdot1sOperMstID.427	.3.6.1.4.1.26138.8.35.14.18.1.3.427	Integer	0
ibdot1sOperMstID.428	.3.6.1.4.1.26138.8.35.14.18.1.3.428	Integer	0
ibdot1sOperMstID.429	.3.6.1.4.1.26138.8.35.14.18.1.3.429	Integer	0
ibdot1sOperMstID.430	.3.6.1.4.1.26138.8.35.14.18.1.3.430	Integer	0
ibdot1sOperMstID.431	.3.6.1.4.1.26138.8.35.14.18.1.3.431	Integer	0
ibdot1sOperMstID.432	.3.6.1.4.1.26138.8.35.14.18.1.3.432	Integer	0
ibdot1sOperMstID.433	.3.6.1.4.1.26138.8.35.14.18.1.3.433	Integer	0
ibdot1sOperMstID.434	.3.6.1.4.1.26138.8.35.14.18.1.3.434	Integer	0
ibdot1sOperMstID.435	.3.6.1.4.1.26138.8.35.14.18.1.3.435	Integer	0
ibdot1sOperMstID.436	.3.6.1.4.1.26138.8.35.14.18.1.3.436	Integer	0
ibdot1sOperMstID.437	.3.6.1.4.1.26138.8.35.14.18.1.3.437	Integer	0
ibdot1sOperMstID.438	.3.6.1.4.1.26138.8.35.14.18.1.3.438	Integer	0
ibdot1sOperMstID.439	.3.6.1.4.1.26138.8.35.14.18.1.3.439	Integer	0
ibdot1sOperMstID.440	.3.6.1.4.1.26138.8.35.14.18.1.3.440	Integer	0
ibdot1sOperMstID.441	.3.6.1.4.1.26138.8.35.14.18.1.3.441	Integer	0
ibdot1sOperMstID.442	.3.6.1.4.1.26138.8.35.14.18.1.3.442	Integer	0
ibdot1sOperMstID.443	.3.6.1.4.1.26138.8.35.14.18.1.3.443	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.444	.3.6.1.4.1.26138.8.35.14.18.1.3.444	Integer	0
ibdot1sOperMstID.445	.3.6.1.4.1.26138.8.35.14.18.1.3.445	Integer	0
ibdot1sOperMstID.446	.3.6.1.4.1.26138.8.35.14.18.1.3.446	Integer	0
ibdot1sOperMstID.447	.3.6.1.4.1.26138.8.35.14.18.1.3.447	Integer	0
ibdot1sOperMstID.448	.3.6.1.4.1.26138.8.35.14.18.1.3.448	Integer	0
ibdot1sOperMstID.449	.3.6.1.4.1.26138.8.35.14.18.1.3.449	Integer	0
ibdot1sOperMstID.450	.3.6.1.4.1.26138.8.35.14.18.1.3.450	Integer	0
ibdot1sOperMstID.451	.3.6.1.4.1.26138.8.35.14.18.1.3.451	Integer	0
ibdot1sOperMstID.452	.3.6.1.4.1.26138.8.35.14.18.1.3.452	Integer	0
ibdot1sOperMstID.453	.3.6.1.4.1.26138.8.35.14.18.1.3.453	Integer	0
ibdot1sOperMstID.454	.3.6.1.4.1.26138.8.35.14.18.1.3.454	Integer	0
ibdot1sOperMstID.455	.3.6.1.4.1.26138.8.35.14.18.1.3.455	Integer	0
ibdot1sOperMstID.456	.3.6.1.4.1.26138.8.35.14.18.1.3.456	Integer	0
ibdot1sOperMstID.457	.3.6.1.4.1.26138.8.35.14.18.1.3.457	Integer	0
ibdot1sOperMstID.458	.3.6.1.4.1.26138.8.35.14.18.1.3.458	Integer	0
ibdot1sOperMstID.459	.3.6.1.4.1.26138.8.35.14.18.1.3.459	Integer	0
ibdot1sOperMstID.460	.3.6.1.4.1.26138.8.35.14.18.1.3.460	Integer	0
ibdot1sOperMstID.461	.3.6.1.4.1.26138.8.35.14.18.1.3.461	Integer	0
ibdot1sOperMstID.462	.3.6.1.4.1.26138.8.35.14.18.1.3.462	Integer	0
ibdot1sOperMstID.463	.3.6.1.4.1.26138.8.35.14.18.1.3.463	Integer	0
ibdot1sOperMstID.464	.3.6.1.4.1.26138.8.35.14.18.1.3.464	Integer	0
ibdot1sOperMstID.465	.3.6.1.4.1.26138.8.35.14.18.1.3.465	Integer	0
ibdot1sOperMstID.466	.3.6.1.4.1.26138.8.35.14.18.1.3.466	Integer	0
ibdot1sOperMstID.467	.3.6.1.4.1.26138.8.35.14.18.1.3.467	Integer	0
ibdot1sOperMstID.468	.3.6.1.4.1.26138.8.35.14.18.1.3.468	Integer	0
ibdot1sOperMstID.469	.3.6.1.4.1.26138.8.35.14.18.1.3.469	Integer	0
ibdot1sOperMstID.470	.3.6.1.4.1.26138.8.35.14.18.1.3.470	Integer	0
ibdot1sOperMstID.471	.3.6.1.4.1.26138.8.35.14.18.1.3.471	Integer	0
ibdot1sOperMstID.472	.3.6.1.4.1.26138.8.35.14.18.1.3.472	Integer	0
ibdot1sOperMstID.473	.3.6.1.4.1.26138.8.35.14.18.1.3.473	Integer	0
ibdot1sOperMstID.474	.3.6.1.4.1.26138.8.35.14.18.1.3.474	Integer	0
ibdot1sOperMstID.475	.3.6.1.4.1.26138.8.35.14.18.1.3.475	Integer	0
ibdot1sOperMstID.476	.3.6.1.4.1.26138.8.35.14.18.1.3.476	Integer	0
ibdot1sOperMstID.477	.3.6.1.4.1.26138.8.35.14.18.1.3.477	Integer	0
ibdot1sOperMstID.478	.3.6.1.4.1.26138.8.35.14.18.1.3.478	Integer	0
ibdot1sOperMstID.479	.3.6.1.4.1.26138.8.35.14.18.1.3.479	Integer	0
ibdot1sOperMstID.480	.3.6.1.4.1.26138.8.35.14.18.1.3.480	Integer	0
ibdot1sOperMstID.481	.3.6.1.4.1.26138.8.35.14.18.1.3.481	Integer	0
ibdot1sOperMstID.482	.3.6.1.4.1.26138.8.35.14.18.1.3.482	Integer	0
ibdot1sOperMstID.483	.3.6.1.4.1.26138.8.35.14.18.1.3.483	Integer	0
ibdot1sOperMstID.484	.3.6.1.4.1.26138.8.35.14.18.1.3.484	Integer	0
ibdot1sOperMstID.485	.3.6.1.4.1.26138.8.35.14.18.1.3.485	Integer	0
ibdot1sOperMstID.486	.3.6.1.4.1.26138.8.35.14.18.1.3.486	Integer	0



Name	OID	Value Type	Value Example
ibdot1sOperMstID.487	.3.6.1.4.1.26138.8.35.14.18.1.3.487	Integer	0
ibdot1sOperMstID.488	.3.6.1.4.1.26138.8.35.14.18.1.3.488	Integer	0
ibdot1sOperMstID.489	.3.6.1.4.1.26138.8.35.14.18.1.3.489	Integer	0
ibdot1sOperMstID.490	.3.6.1.4.1.26138.8.35.14.18.1.3.490	Integer	0
ibdot1sOperMstID.491	.3.6.1.4.1.26138.8.35.14.18.1.3.491	Integer	0
ibdot1sOperMstID.492	.3.6.1.4.1.26138.8.35.14.18.1.3.492	Integer	0
ibdot1sOperMstID.493	.3.6.1.4.1.26138.8.35.14.18.1.3.493	Integer	0
ibdot1sOperMstID.494	.3.6.1.4.1.26138.8.35.14.18.1.3.494	Integer	0
ibdot1sOperMstID.495	.3.6.1.4.1.26138.8.35.14.18.1.3.495	Integer	0
ibdot1sOperMstID.496	.3.6.1.4.1.26138.8.35.14.18.1.3.496	Integer	0
ibdot1sOperMstID.497	.3.6.1.4.1.26138.8.35.14.18.1.3.497	Integer	0
ibdot1sOperMstID.498	.3.6.1.4.1.26138.8.35.14.18.1.3.498	Integer	0
ibdot1sOperMstID.499	.3.6.1.4.1.26138.8.35.14.18.1.3.499	Integer	0
ibdot1sOperMstID.500	.3.6.1.4.1.26138.8.35.14.18.1.3.500	Integer	0
ibdot1sOperMstID.501	.3.6.1.4.1.26138.8.35.14.18.1.3.501	Integer	0
ibdot1sOperMstID.502	.3.6.1.4.1.26138.8.35.14.18.1.3.502	Integer	0
ibdot1sOperMstID.503	.3.6.1.4.1.26138.8.35.14.18.1.3.503	Integer	0
ibdot1sOperMstID.504	.3.6.1.4.1.26138.8.35.14.18.1.3.504	Integer	0
ibdot1sOperMstID.505	.3.6.1.4.1.26138.8.35.14.18.1.3.505	Integer	0
ibdot1sOperMstID.506	.3.6.1.4.1.26138.8.35.14.18.1.3.506	Integer	0
ibdot1sOperMstID.507	.3.6.1.4.1.26138.8.35.14.18.1.3.507	Integer	0
ibdot1sOperMstID.508	.3.6.1.4.1.26138.8.35.14.18.1.3.508	Integer	0
ibdot1sOperMstID.509	.3.6.1.4.1.26138.8.35.14.18.1.3.509	Integer	0
ibdot1sOperMstID.510	.3.6.1.4.1.26138.8.35.14.18.1.3.510	Integer	0
ibdot1sOperMstID.511	.3.6.1.4.1.26138.8.35.14.18.1.3.511	Integer	0
ibdot1sOperMstID.512	.3.6.1.4.1.26138.8.35.14.18.1.3.512	Integer	0
ibdot1sOperMstID.513	.3.6.1.4.1.26138.8.35.14.18.1.3.513	Integer	0
ibdot1sOperMstID.514	.3.6.1.4.1.26138.8.35.14.18.1.3.514	Integer	0
ibdot1sOperMstID.515	.3.6.1.4.1.26138.8.35.14.18.1.3.515	Integer	0
ibdot1sOperMstID.516	.3.6.1.4.1.26138.8.35.14.18.1.3.516	Integer	0
ibdot1sOperMstID.517	.3.6.1.4.1.26138.8.35.14.18.1.3.517	Integer	0
ibdot1sOperMstID.518	.3.6.1.4.1.26138.8.35.14.18.1.3.518	Integer	0
ibdot1sOperMstID.519	.3.6.1.4.1.26138.8.35.14.18.1.3.519	Integer	0
ibdot1sOperMstID.520	.3.6.1.4.1.26138.8.35.14.18.1.3.520	Integer	0
ibdot1sOperMstID.521	.3.6.1.4.1.26138.8.35.14.18.1.3.521	Integer	0
ibdot1sOperMstID.522	.3.6.1.4.1.26138.8.35.14.18.1.3.522	Integer	0
ibdot1sOperMstID.523	.3.6.1.4.1.26138.8.35.14.18.1.3.523	Integer	0
ibdot1sOperMstID.524	.3.6.1.4.1.26138.8.35.14.18.1.3.524	Integer	0
ibdot1sOperMstID.525	.3.6.1.4.1.26138.8.35.14.18.1.3.525	Integer	0
ibdot1sOperMstID.526	.3.6.1.4.1.26138.8.35.14.18.1.3.526	Integer	0
ibdot1sOperMstID.527	.3.6.1.4.1.26138.8.35.14.18.1.3.527	Integer	0
ibdot1sOperMstID.528	.3.6.1.4.1.26138.8.35.14.18.1.3.528	Integer	0
ibdot1sOperMstID.529	.3.6.1.4.1.26138.8.35.14.18.1.3.529	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.530	.3.6.1.4.1.26138.8.35.14.18.1.3.530	Integer	0
ibdot1sOperMstID.531	.3.6.1.4.1.26138.8.35.14.18.1.3.531	Integer	0
ibdot1sOperMstID.532	.3.6.1.4.1.26138.8.35.14.18.1.3.532	Integer	0
ibdot1sOperMstID.533	.3.6.1.4.1.26138.8.35.14.18.1.3.533	Integer	0
ibdot1sOperMstID.534	.3.6.1.4.1.26138.8.35.14.18.1.3.534	Integer	0
ibdot1sOperMstID.535	.3.6.1.4.1.26138.8.35.14.18.1.3.535	Integer	0
ibdot1sOperMstID.536	.3.6.1.4.1.26138.8.35.14.18.1.3.536	Integer	0
ibdot1sOperMstID.537	.3.6.1.4.1.26138.8.35.14.18.1.3.537	Integer	0
ibdot1sOperMstID.538	.3.6.1.4.1.26138.8.35.14.18.1.3.538	Integer	0
ibdot1sOperMstID.539	.3.6.1.4.1.26138.8.35.14.18.1.3.539	Integer	0
ibdot1sOperMstID.540	.3.6.1.4.1.26138.8.35.14.18.1.3.540	Integer	0
ibdot1sOperMstID.541	.3.6.1.4.1.26138.8.35.14.18.1.3.541	Integer	0
ibdot1sOperMstID.542	.3.6.1.4.1.26138.8.35.14.18.1.3.542	Integer	0
ibdot1sOperMstID.543	.3.6.1.4.1.26138.8.35.14.18.1.3.543	Integer	0
ibdot1sOperMstID.544	.3.6.1.4.1.26138.8.35.14.18.1.3.544	Integer	0
ibdot1sOperMstID.545	.3.6.1.4.1.26138.8.35.14.18.1.3.545	Integer	0
ibdot1sOperMstID.546	.3.6.1.4.1.26138.8.35.14.18.1.3.546	Integer	0
ibdot1sOperMstID.547	.3.6.1.4.1.26138.8.35.14.18.1.3.547	Integer	0
ibdot1sOperMstID.548	.3.6.1.4.1.26138.8.35.14.18.1.3.548	Integer	0
ibdot1sOperMstID.549	.3.6.1.4.1.26138.8.35.14.18.1.3.549	Integer	0
ibdot1sOperMstID.550	.3.6.1.4.1.26138.8.35.14.18.1.3.550	Integer	0
ibdot1sOperMstID.551	.3.6.1.4.1.26138.8.35.14.18.1.3.551	Integer	0
ibdot1sOperMstID.552	.3.6.1.4.1.26138.8.35.14.18.1.3.552	Integer	0
ibdot1sOperMstID.553	.3.6.1.4.1.26138.8.35.14.18.1.3.553	Integer	0
ibdot1sOperMstID.554	.3.6.1.4.1.26138.8.35.14.18.1.3.554	Integer	0
ibdot1sOperMstID.555	.3.6.1.4.1.26138.8.35.14.18.1.3.555	Integer	0
ibdot1sOperMstID.556	.3.6.1.4.1.26138.8.35.14.18.1.3.556	Integer	0
ibdot1sOperMstID.557	.3.6.1.4.1.26138.8.35.14.18.1.3.557	Integer	0
ibdot1sOperMstID.558	.3.6.1.4.1.26138.8.35.14.18.1.3.558	Integer	0
ibdot1sOperMstID.559	.3.6.1.4.1.26138.8.35.14.18.1.3.559	Integer	0
ibdot1sOperMstID.560	.3.6.1.4.1.26138.8.35.14.18.1.3.560	Integer	0
ibdot1sOperMstID.561	.3.6.1.4.1.26138.8.35.14.18.1.3.561	Integer	0
ibdot1sOperMstID.562	.3.6.1.4.1.26138.8.35.14.18.1.3.562	Integer	0
ibdot1sOperMstID.563	.3.6.1.4.1.26138.8.35.14.18.1.3.563	Integer	0
ibdot1sOperMstID.564	.3.6.1.4.1.26138.8.35.14.18.1.3.564	Integer	0
ibdot1sOperMstID.565	.3.6.1.4.1.26138.8.35.14.18.1.3.565	Integer	0
ibdot1sOperMstID.566	.3.6.1.4.1.26138.8.35.14.18.1.3.566	Integer	0
ibdot1sOperMstID.567	.3.6.1.4.1.26138.8.35.14.18.1.3.567	Integer	0
ibdot1sOperMstID.568	.3.6.1.4.1.26138.8.35.14.18.1.3.568	Integer	0
ibdot1sOperMstID.569	.3.6.1.4.1.26138.8.35.14.18.1.3.569	Integer	0
ibdot1sOperMstID.570	.3.6.1.4.1.26138.8.35.14.18.1.3.570	Integer	0
ibdot1sOperMstID.571	.3.6.1.4.1.26138.8.35.14.18.1.3.571	Integer	0
ibdot1sOperMstID.572	.3.6.1.4.1.26138.8.35.14.18.1.3.572	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.573	.3.6.1.4.1.26138.8.35.14.18.1.3.573	Integer	0
ibdot1sOperMstID.574	.3.6.1.4.1.26138.8.35.14.18.1.3.574	Integer	0
ibdot1sOperMstID.575	.3.6.1.4.1.26138.8.35.14.18.1.3.575	Integer	0
ibdot1sOperMstID.576	.3.6.1.4.1.26138.8.35.14.18.1.3.576	Integer	0
ibdot1sOperMstID.577	.3.6.1.4.1.26138.8.35.14.18.1.3.577	Integer	0
ibdot1sOperMstID.578	.3.6.1.4.1.26138.8.35.14.18.1.3.578	Integer	0
ibdot1sOperMstID.579	.3.6.1.4.1.26138.8.35.14.18.1.3.579	Integer	0
ibdot1sOperMstID.580	.3.6.1.4.1.26138.8.35.14.18.1.3.580	Integer	0
ibdot1sOperMstID.581	.3.6.1.4.1.26138.8.35.14.18.1.3.581	Integer	0
ibdot1sOperMstID.582	.3.6.1.4.1.26138.8.35.14.18.1.3.582	Integer	0
ibdot1sOperMstID.583	.3.6.1.4.1.26138.8.35.14.18.1.3.583	Integer	0
ibdot1sOperMstID.584	.3.6.1.4.1.26138.8.35.14.18.1.3.584	Integer	0
ibdot1sOperMstID.585	.3.6.1.4.1.26138.8.35.14.18.1.3.585	Integer	0
ibdot1sOperMstID.586	.3.6.1.4.1.26138.8.35.14.18.1.3.586	Integer	0
ibdot1sOperMstID.587	.3.6.1.4.1.26138.8.35.14.18.1.3.587	Integer	0
ibdot1sOperMstID.588	.3.6.1.4.1.26138.8.35.14.18.1.3.588	Integer	0
ibdot1sOperMstID.589	.3.6.1.4.1.26138.8.35.14.18.1.3.589	Integer	0
ibdot1sOperMstID.590	.3.6.1.4.1.26138.8.35.14.18.1.3.590	Integer	0
ibdot1sOperMstID.591	.3.6.1.4.1.26138.8.35.14.18.1.3.591	Integer	0
ibdot1sOperMstID.592	.3.6.1.4.1.26138.8.35.14.18.1.3.592	Integer	0
ibdot1sOperMstID.593	.3.6.1.4.1.26138.8.35.14.18.1.3.593	Integer	0
ibdot1sOperMstID.594	.3.6.1.4.1.26138.8.35.14.18.1.3.594	Integer	0
ibdot1sOperMstID.595	.3.6.1.4.1.26138.8.35.14.18.1.3.595	Integer	0
ibdot1sOperMstID.596	.3.6.1.4.1.26138.8.35.14.18.1.3.596	Integer	0
ibdot1sOperMstID.597	.3.6.1.4.1.26138.8.35.14.18.1.3.597	Integer	0
ibdot1sOperMstID.598	.3.6.1.4.1.26138.8.35.14.18.1.3.598	Integer	0
ibdot1sOperMstID.599	.3.6.1.4.1.26138.8.35.14.18.1.3.599	Integer	0
ibdot1sOperMstID.600	.3.6.1.4.1.26138.8.35.14.18.1.3.600	Integer	0
ibdot1sOperMstID.601	.3.6.1.4.1.26138.8.35.14.18.1.3.601	Integer	0
ibdot1sOperMstID.602	.3.6.1.4.1.26138.8.35.14.18.1.3.602	Integer	0
ibdot1sOperMstID.603	.3.6.1.4.1.26138.8.35.14.18.1.3.603	Integer	0
ibdot1sOperMstID.604	.3.6.1.4.1.26138.8.35.14.18.1.3.604	Integer	0
ibdot1sOperMstID.605	.3.6.1.4.1.26138.8.35.14.18.1.3.605	Integer	0
ibdot1sOperMstID.606	.3.6.1.4.1.26138.8.35.14.18.1.3.606	Integer	0
ibdot1sOperMstID.607	.3.6.1.4.1.26138.8.35.14.18.1.3.607	Integer	0
ibdot1sOperMstID.608	.3.6.1.4.1.26138.8.35.14.18.1.3.608	Integer	0
ibdot1sOperMstID.609	.3.6.1.4.1.26138.8.35.14.18.1.3.609	Integer	0
ibdot1sOperMstID.610	.3.6.1.4.1.26138.8.35.14.18.1.3.610	Integer	0
ibdot1sOperMstID.611	.3.6.1.4.1.26138.8.35.14.18.1.3.611	Integer	0
ibdot1sOperMstID.612	.3.6.1.4.1.26138.8.35.14.18.1.3.612	Integer	0
ibdot1sOperMstID.613	.3.6.1.4.1.26138.8.35.14.18.1.3.613	Integer	0
ibdot1sOperMstID.614	.3.6.1.4.1.26138.8.35.14.18.1.3.614	Integer	0
ibdot1sOperMstID.615	.3.6.1.4.1.26138.8.35.14.18.1.3.615	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.616	.3.6.1.4.1.26138.8.35.14.18.1.3.616	Integer	0
ibdot1sOperMstID.617	.3.6.1.4.1.26138.8.35.14.18.1.3.617	Integer	0
ibdot1sOperMstID.618	.3.6.1.4.1.26138.8.35.14.18.1.3.618	Integer	0
ibdot1sOperMstID.619	.3.6.1.4.1.26138.8.35.14.18.1.3.619	Integer	0
ibdot1sOperMstID.620	.3.6.1.4.1.26138.8.35.14.18.1.3.620	Integer	0
ibdot1sOperMstID.621	.3.6.1.4.1.26138.8.35.14.18.1.3.621	Integer	0
ibdot1sOperMstID.622	.3.6.1.4.1.26138.8.35.14.18.1.3.622	Integer	0
ibdot1sOperMstID.623	.3.6.1.4.1.26138.8.35.14.18.1.3.623	Integer	0
ibdot1sOperMstID.624	.3.6.1.4.1.26138.8.35.14.18.1.3.624	Integer	0
ibdot1sOperMstID.625	.3.6.1.4.1.26138.8.35.14.18.1.3.625	Integer	0
ibdot1sOperMstID.626	.3.6.1.4.1.26138.8.35.14.18.1.3.626	Integer	0
ibdot1sOperMstID.627	.3.6.1.4.1.26138.8.35.14.18.1.3.627	Integer	0
ibdot1sOperMstID.628	.3.6.1.4.1.26138.8.35.14.18.1.3.628	Integer	0
ibdot1sOperMstID.629	.3.6.1.4.1.26138.8.35.14.18.1.3.629	Integer	0
ibdot1sOperMstID.630	.3.6.1.4.1.26138.8.35.14.18.1.3.630	Integer	0
ibdot1sOperMstID.631	.3.6.1.4.1.26138.8.35.14.18.1.3.631	Integer	0
ibdot1sOperMstID.632	.3.6.1.4.1.26138.8.35.14.18.1.3.632	Integer	0
ibdot1sOperMstID.633	.3.6.1.4.1.26138.8.35.14.18.1.3.633	Integer	0
ibdot1sOperMstID.634	.3.6.1.4.1.26138.8.35.14.18.1.3.634	Integer	0
ibdot1sOperMstID.635	.3.6.1.4.1.26138.8.35.14.18.1.3.635	Integer	0
ibdot1sOperMstID.636	.3.6.1.4.1.26138.8.35.14.18.1.3.636	Integer	0
ibdot1sOperMstID.637	.3.6.1.4.1.26138.8.35.14.18.1.3.637	Integer	0
ibdot1sOperMstID.638	.3.6.1.4.1.26138.8.35.14.18.1.3.638	Integer	0
ibdot1sOperMstID.639	.3.6.1.4.1.26138.8.35.14.18.1.3.639	Integer	0
ibdot1sOperMstID.640	.3.6.1.4.1.26138.8.35.14.18.1.3.640	Integer	0
ibdot1sOperMstID.641	.3.6.1.4.1.26138.8.35.14.18.1.3.641	Integer	0
ibdot1sOperMstID.642	.3.6.1.4.1.26138.8.35.14.18.1.3.642	Integer	0
ibdot1sOperMstID.643	.3.6.1.4.1.26138.8.35.14.18.1.3.643	Integer	0
ibdot1sOperMstID.644	.3.6.1.4.1.26138.8.35.14.18.1.3.644	Integer	0
ibdot1sOperMstID.645	.3.6.1.4.1.26138.8.35.14.18.1.3.645	Integer	0
ibdot1sOperMstID.646	.3.6.1.4.1.26138.8.35.14.18.1.3.646	Integer	0
ibdot1sOperMstID.647	.3.6.1.4.1.26138.8.35.14.18.1.3.647	Integer	0
ibdot1sOperMstID.648	.3.6.1.4.1.26138.8.35.14.18.1.3.648	Integer	0
ibdot1sOperMstID.649	.3.6.1.4.1.26138.8.35.14.18.1.3.649	Integer	0
ibdot1sOperMstID.650	.3.6.1.4.1.26138.8.35.14.18.1.3.650	Integer	0
ibdot1sOperMstID.651	.3.6.1.4.1.26138.8.35.14.18.1.3.651	Integer	0
ibdot1sOperMstID.652	.3.6.1.4.1.26138.8.35.14.18.1.3.652	Integer	0
ibdot1sOperMstID.653	.3.6.1.4.1.26138.8.35.14.18.1.3.653	Integer	0
ibdot1sOperMstID.654	.3.6.1.4.1.26138.8.35.14.18.1.3.654	Integer	0
ibdot1sOperMstID.655	.3.6.1.4.1.26138.8.35.14.18.1.3.655	Integer	0
ibdot1sOperMstID.656	.3.6.1.4.1.26138.8.35.14.18.1.3.656	Integer	0
ibdot1sOperMstID.657	.3.6.1.4.1.26138.8.35.14.18.1.3.657	Integer	0
ibdot1sOperMstID.658	.3.6.1.4.1.26138.8.35.14.18.1.3.658	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.659	.3.6.1.4.1.26138.8.35.14.18.1.3.659	Integer	0
ibdot1sOperMstID.660	.3.6.1.4.1.26138.8.35.14.18.1.3.660	Integer	0
ibdot1sOperMstID.661	.3.6.1.4.1.26138.8.35.14.18.1.3.661	Integer	0
ibdot1sOperMstID.662	.3.6.1.4.1.26138.8.35.14.18.1.3.662	Integer	0
ibdot1sOperMstID.663	.3.6.1.4.1.26138.8.35.14.18.1.3.663	Integer	0
ibdot1sOperMstID.664	.3.6.1.4.1.26138.8.35.14.18.1.3.664	Integer	0
ibdot1sOperMstID.665	.3.6.1.4.1.26138.8.35.14.18.1.3.665	Integer	0
ibdot1sOperMstID.666	.3.6.1.4.1.26138.8.35.14.18.1.3.666	Integer	0
ibdot1sOperMstID.667	.3.6.1.4.1.26138.8.35.14.18.1.3.667	Integer	0
ibdot1sOperMstID.668	.3.6.1.4.1.26138.8.35.14.18.1.3.668	Integer	0
ibdot1sOperMstID.669	.3.6.1.4.1.26138.8.35.14.18.1.3.669	Integer	0
ibdot1sOperMstID.670	.3.6.1.4.1.26138.8.35.14.18.1.3.670	Integer	0
ibdot1sOperMstID.671	.3.6.1.4.1.26138.8.35.14.18.1.3.671	Integer	0
ibdot1sOperMstID.672	.3.6.1.4.1.26138.8.35.14.18.1.3.672	Integer	0
ibdot1sOperMstID.673	.3.6.1.4.1.26138.8.35.14.18.1.3.673	Integer	0
ibdot1sOperMstID.674	.3.6.1.4.1.26138.8.35.14.18.1.3.674	Integer	0
ibdot1sOperMstID.675	.3.6.1.4.1.26138.8.35.14.18.1.3.675	Integer	0
ibdot1sOperMstID.676	.3.6.1.4.1.26138.8.35.14.18.1.3.676	Integer	0
ibdot1sOperMstID.677	.3.6.1.4.1.26138.8.35.14.18.1.3.677	Integer	0
ibdot1sOperMstID.678	.3.6.1.4.1.26138.8.35.14.18.1.3.678	Integer	0
ibdot1sOperMstID.679	.3.6.1.4.1.26138.8.35.14.18.1.3.679	Integer	0
ibdot1sOperMstID.680	.3.6.1.4.1.26138.8.35.14.18.1.3.680	Integer	0
ibdot1sOperMstID.681	.3.6.1.4.1.26138.8.35.14.18.1.3.681	Integer	0
ibdot1sOperMstID.682	.3.6.1.4.1.26138.8.35.14.18.1.3.682	Integer	0
ibdot1sOperMstID.683	.3.6.1.4.1.26138.8.35.14.18.1.3.683	Integer	0
ibdot1sOperMstID.684	.3.6.1.4.1.26138.8.35.14.18.1.3.684	Integer	0
ibdot1sOperMstID.685	.3.6.1.4.1.26138.8.35.14.18.1.3.685	Integer	0
ibdot1sOperMstID.686	.3.6.1.4.1.26138.8.35.14.18.1.3.686	Integer	0
ibdot1sOperMstID.687	.3.6.1.4.1.26138.8.35.14.18.1.3.687	Integer	0
ibdot1sOperMstID.688	.3.6.1.4.1.26138.8.35.14.18.1.3.688	Integer	0
ibdot1sOperMstID.689	.3.6.1.4.1.26138.8.35.14.18.1.3.689	Integer	0
ibdot1sOperMstID.690	.3.6.1.4.1.26138.8.35.14.18.1.3.690	Integer	0
ibdot1sOperMstID.691	.3.6.1.4.1.26138.8.35.14.18.1.3.691	Integer	0
ibdot1sOperMstID.692	.3.6.1.4.1.26138.8.35.14.18.1.3.692	Integer	0
ibdot1sOperMstID.693	.3.6.1.4.1.26138.8.35.14.18.1.3.693	Integer	0
ibdot1sOperMstID.694	.3.6.1.4.1.26138.8.35.14.18.1.3.694	Integer	0
ibdot1sOperMstID.695	.3.6.1.4.1.26138.8.35.14.18.1.3.695	Integer	0
ibdot1sOperMstID.696	.3.6.1.4.1.26138.8.35.14.18.1.3.696	Integer	0
ibdot1sOperMstID.697	.3.6.1.4.1.26138.8.35.14.18.1.3.697	Integer	0
ibdot1sOperMstID.698	.3.6.1.4.1.26138.8.35.14.18.1.3.698	Integer	0
ibdot1sOperMstID.699	.3.6.1.4.1.26138.8.35.14.18.1.3.699	Integer	0
ibdot1sOperMstID.700	.3.6.1.4.1.26138.8.35.14.18.1.3.700	Integer	0
ibdot1sOperMstID.701	.3.6.1.4.1.26138.8.35.14.18.1.3.701	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.702	.3.6.1.4.1.26138.8.35.14.18.1.3.702	Integer	0
ibdot1sOperMstID.703	.3.6.1.4.1.26138.8.35.14.18.1.3.703	Integer	0
ibdot1sOperMstID.704	.3.6.1.4.1.26138.8.35.14.18.1.3.704	Integer	0
ibdot1sOperMstID.705	.3.6.1.4.1.26138.8.35.14.18.1.3.705	Integer	0
ibdot1sOperMstID.706	.3.6.1.4.1.26138.8.35.14.18.1.3.706	Integer	0
ibdot1sOperMstID.707	.3.6.1.4.1.26138.8.35.14.18.1.3.707	Integer	0
ibdot1sOperMstID.708	.3.6.1.4.1.26138.8.35.14.18.1.3.708	Integer	0
ibdot1sOperMstID.709	.3.6.1.4.1.26138.8.35.14.18.1.3.709	Integer	0
ibdot1sOperMstID.710	.3.6.1.4.1.26138.8.35.14.18.1.3.710	Integer	0
ibdot1sOperMstID.711	.3.6.1.4.1.26138.8.35.14.18.1.3.711	Integer	0
ibdot1sOperMstID.712	.3.6.1.4.1.26138.8.35.14.18.1.3.712	Integer	0
ibdot1sOperMstID.713	.3.6.1.4.1.26138.8.35.14.18.1.3.713	Integer	0
ibdot1sOperMstID.714	.3.6.1.4.1.26138.8.35.14.18.1.3.714	Integer	0
ibdot1sOperMstID.715	.3.6.1.4.1.26138.8.35.14.18.1.3.715	Integer	0
ibdot1sOperMstID.716	.3.6.1.4.1.26138.8.35.14.18.1.3.716	Integer	0
ibdot1sOperMstID.717	.3.6.1.4.1.26138.8.35.14.18.1.3.717	Integer	0
ibdot1sOperMstID.718	.3.6.1.4.1.26138.8.35.14.18.1.3.718	Integer	0
ibdot1sOperMstID.719	.3.6.1.4.1.26138.8.35.14.18.1.3.719	Integer	0
ibdot1sOperMstID.720	.3.6.1.4.1.26138.8.35.14.18.1.3.720	Integer	0
ibdot1sOperMstID.721	.3.6.1.4.1.26138.8.35.14.18.1.3.721	Integer	0
ibdot1sOperMstID.722	.3.6.1.4.1.26138.8.35.14.18.1.3.722	Integer	0
ibdot1sOperMstID.723	.3.6.1.4.1.26138.8.35.14.18.1.3.723	Integer	0
ibdot1sOperMstID.724	.3.6.1.4.1.26138.8.35.14.18.1.3.724	Integer	0
ibdot1sOperMstID.725	.3.6.1.4.1.26138.8.35.14.18.1.3.725	Integer	0
ibdot1sOperMstID.726	.3.6.1.4.1.26138.8.35.14.18.1.3.726	Integer	0
ibdot1sOperMstID.727	.3.6.1.4.1.26138.8.35.14.18.1.3.727	Integer	0
ibdot1sOperMstID.728	.3.6.1.4.1.26138.8.35.14.18.1.3.728	Integer	0
ibdot1sOperMstID.729	.3.6.1.4.1.26138.8.35.14.18.1.3.729	Integer	0
ibdot1sOperMstID.730	.3.6.1.4.1.26138.8.35.14.18.1.3.730	Integer	0
ibdot1sOperMstID.731	.3.6.1.4.1.26138.8.35.14.18.1.3.731	Integer	0
ibdot1sOperMstID.732	.3.6.1.4.1.26138.8.35.14.18.1.3.732	Integer	0
ibdot1sOperMstID.733	.3.6.1.4.1.26138.8.35.14.18.1.3.733	Integer	0
ibdot1sOperMstID.734	.3.6.1.4.1.26138.8.35.14.18.1.3.734	Integer	0
ibdot1sOperMstID.735	.3.6.1.4.1.26138.8.35.14.18.1.3.735	Integer	0
ibdot1sOperMstID.736	.3.6.1.4.1.26138.8.35.14.18.1.3.736	Integer	0
ibdot1sOperMstID.737	.3.6.1.4.1.26138.8.35.14.18.1.3.737	Integer	0
ibdot1sOperMstID.738	.3.6.1.4.1.26138.8.35.14.18.1.3.738	Integer	0
ibdot1sOperMstID.739	.3.6.1.4.1.26138.8.35.14.18.1.3.739	Integer	0
ibdot1sOperMstID.740	.3.6.1.4.1.26138.8.35.14.18.1.3.740	Integer	0
ibdot1sOperMstID.741	.3.6.1.4.1.26138.8.35.14.18.1.3.741	Integer	0
ibdot1sOperMstID.742	.3.6.1.4.1.26138.8.35.14.18.1.3.742	Integer	0
ibdot1sOperMstID.743	.3.6.1.4.1.26138.8.35.14.18.1.3.743	Integer	0
ibdot1sOperMstID.744	.3.6.1.4.1.26138.8.35.14.18.1.3.744	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.745	.3.6.1.4.1.26138.8.35.14.18.1.3.745	Integer	0
ibdot1sOperMstID.746	.3.6.1.4.1.26138.8.35.14.18.1.3.746	Integer	0
ibdot1sOperMstID.747	.3.6.1.4.1.26138.8.35.14.18.1.3.747	Integer	0
ibdot1sOperMstID.748	.3.6.1.4.1.26138.8.35.14.18.1.3.748	Integer	0
ibdot1sOperMstID.749	.3.6.1.4.1.26138.8.35.14.18.1.3.749	Integer	0
ibdot1sOperMstID.750	.3.6.1.4.1.26138.8.35.14.18.1.3.750	Integer	0
ibdot1sOperMstID.751	.3.6.1.4.1.26138.8.35.14.18.1.3.751	Integer	0
ibdot1sOperMstID.752	.3.6.1.4.1.26138.8.35.14.18.1.3.752	Integer	0
ibdot1sOperMstID.753	.3.6.1.4.1.26138.8.35.14.18.1.3.753	Integer	0
ibdot1sOperMstID.754	.3.6.1.4.1.26138.8.35.14.18.1.3.754	Integer	0
ibdot1sOperMstID.755	.3.6.1.4.1.26138.8.35.14.18.1.3.755	Integer	0
ibdot1sOperMstID.756	.3.6.1.4.1.26138.8.35.14.18.1.3.756	Integer	0
ibdot1sOperMstID.757	.3.6.1.4.1.26138.8.35.14.18.1.3.757	Integer	0
ibdot1sOperMstID.758	.3.6.1.4.1.26138.8.35.14.18.1.3.758	Integer	0
ibdot1sOperMstID.759	.3.6.1.4.1.26138.8.35.14.18.1.3.759	Integer	0
ibdot1sOperMstID.760	.3.6.1.4.1.26138.8.35.14.18.1.3.760	Integer	0
ibdot1sOperMstID.761	.3.6.1.4.1.26138.8.35.14.18.1.3.761	Integer	0
ibdot1sOperMstID.762	.3.6.1.4.1.26138.8.35.14.18.1.3.762	Integer	0
ibdot1sOperMstID.763	.3.6.1.4.1.26138.8.35.14.18.1.3.763	Integer	0
ibdot1sOperMstID.764	.3.6.1.4.1.26138.8.35.14.18.1.3.764	Integer	0
ibdot1sOperMstID.765	.3.6.1.4.1.26138.8.35.14.18.1.3.765	Integer	0
ibdot1sOperMstID.766	.3.6.1.4.1.26138.8.35.14.18.1.3.766	Integer	0
ibdot1sOperMstID.767	.3.6.1.4.1.26138.8.35.14.18.1.3.767	Integer	0
ibdot1sOperMstID.768	.3.6.1.4.1.26138.8.35.14.18.1.3.768	Integer	0
ibdot1sOperMstID.769	.3.6.1.4.1.26138.8.35.14.18.1.3.769	Integer	0
ibdot1sOperMstID.770	.3.6.1.4.1.26138.8.35.14.18.1.3.770	Integer	0
ibdot1sOperMstID.771	.3.6.1.4.1.26138.8.35.14.18.1.3.771	Integer	0
ibdot1sOperMstID.772	.3.6.1.4.1.26138.8.35.14.18.1.3.772	Integer	0
ibdot1sOperMstID.773	.3.6.1.4.1.26138.8.35.14.18.1.3.773	Integer	0
ibdot1sOperMstID.774	.3.6.1.4.1.26138.8.35.14.18.1.3.774	Integer	0
ibdot1sOperMstID.775	.3.6.1.4.1.26138.8.35.14.18.1.3.775	Integer	0
ibdot1sOperMstID.776	.3.6.1.4.1.26138.8.35.14.18.1.3.776	Integer	0
ibdot1sOperMstID.777	.3.6.1.4.1.26138.8.35.14.18.1.3.777	Integer	0
ibdot1sOperMstID.778	.3.6.1.4.1.26138.8.35.14.18.1.3.778	Integer	0
ibdot1sOperMstID.779	.3.6.1.4.1.26138.8.35.14.18.1.3.779	Integer	0
ibdot1sOperMstID.780	.3.6.1.4.1.26138.8.35.14.18.1.3.780	Integer	0
ibdot1sOperMstID.781	.3.6.1.4.1.26138.8.35.14.18.1.3.781	Integer	0
ibdot1sOperMstID.782	.3.6.1.4.1.26138.8.35.14.18.1.3.782	Integer	0
ibdot1sOperMstID.783	.3.6.1.4.1.26138.8.35.14.18.1.3.783	Integer	0
ibdot1sOperMstID.784	.3.6.1.4.1.26138.8.35.14.18.1.3.784	Integer	0
ibdot1sOperMstID.785	.3.6.1.4.1.26138.8.35.14.18.1.3.785	Integer	0
ibdot1sOperMstID.786	.3.6.1.4.1.26138.8.35.14.18.1.3.786	Integer	0
ibdot1sOperMstID.787	.3.6.1.4.1.26138.8.35.14.18.1.3.787	Integer	0



Name	OID	Value Type	Value Example
ibdot1sOperMstID.788	.3.6.1.4.1.26138.8.35.14.18.1.3.788	Integer	0
ibdot1sOperMstID.789	.3.6.1.4.1.26138.8.35.14.18.1.3.789	Integer	0
ibdot1sOperMstID.790	.3.6.1.4.1.26138.8.35.14.18.1.3.790	Integer	0
ibdot1sOperMstID.791	.3.6.1.4.1.26138.8.35.14.18.1.3.791	Integer	0
ibdot1sOperMstID.792	.3.6.1.4.1.26138.8.35.14.18.1.3.792	Integer	0
ibdot1sOperMstID.793	.3.6.1.4.1.26138.8.35.14.18.1.3.793	Integer	0
ibdot1sOperMstID.794	.3.6.1.4.1.26138.8.35.14.18.1.3.794	Integer	0
ibdot1sOperMstID.795	.3.6.1.4.1.26138.8.35.14.18.1.3.795	Integer	0
ibdot1sOperMstID.796	.3.6.1.4.1.26138.8.35.14.18.1.3.796	Integer	0
ibdot1sOperMstID.797	.3.6.1.4.1.26138.8.35.14.18.1.3.797	Integer	0
ibdot1sOperMstID.798	.3.6.1.4.1.26138.8.35.14.18.1.3.798	Integer	0
ibdot1sOperMstID.799	.3.6.1.4.1.26138.8.35.14.18.1.3.799	Integer	0
ibdot1sOperMstID.800	.3.6.1.4.1.26138.8.35.14.18.1.3.800	Integer	0
ibdot1sOperMstID.801	.3.6.1.4.1.26138.8.35.14.18.1.3.801	Integer	0
ibdot1sOperMstID.802	.3.6.1.4.1.26138.8.35.14.18.1.3.802	Integer	0
ibdot1sOperMstID.803	.3.6.1.4.1.26138.8.35.14.18.1.3.803	Integer	0
ibdot1sOperMstID.804	.3.6.1.4.1.26138.8.35.14.18.1.3.804	Integer	0
ibdot1sOperMstID.805	.3.6.1.4.1.26138.8.35.14.18.1.3.805	Integer	0
ibdot1sOperMstID.806	.3.6.1.4.1.26138.8.35.14.18.1.3.806	Integer	0
ibdot1sOperMstID.807	.3.6.1.4.1.26138.8.35.14.18.1.3.807	Integer	0
ibdot1sOperMstID.808	.3.6.1.4.1.26138.8.35.14.18.1.3.808	Integer	0
ibdot1sOperMstID.809	.3.6.1.4.1.26138.8.35.14.18.1.3.809	Integer	0
ibdot1sOperMstID.810	.3.6.1.4.1.26138.8.35.14.18.1.3.810	Integer	0
ibdot1sOperMstID.811	.3.6.1.4.1.26138.8.35.14.18.1.3.811	Integer	0
ibdot1sOperMstID.812	.3.6.1.4.1.26138.8.35.14.18.1.3.812	Integer	0
ibdot1sOperMstID.813	.3.6.1.4.1.26138.8.35.14.18.1.3.813	Integer	0
ibdot1sOperMstID.814	.3.6.1.4.1.26138.8.35.14.18.1.3.814	Integer	0
ibdot1sOperMstID.815	.3.6.1.4.1.26138.8.35.14.18.1.3.815	Integer	0
ibdot1sOperMstID.816	.3.6.1.4.1.26138.8.35.14.18.1.3.816	Integer	0
ibdot1sOperMstID.817	.3.6.1.4.1.26138.8.35.14.18.1.3.817	Integer	0
ibdot1sOperMstID.818	.3.6.1.4.1.26138.8.35.14.18.1.3.818	Integer	0
ibdot1sOperMstID.819	.3.6.1.4.1.26138.8.35.14.18.1.3.819	Integer	0
ibdot1sOperMstID.820	.3.6.1.4.1.26138.8.35.14.18.1.3.820	Integer	0
ibdot1sOperMstID.821	.3.6.1.4.1.26138.8.35.14.18.1.3.821	Integer	0
ibdot1sOperMstID.822	.3.6.1.4.1.26138.8.35.14.18.1.3.822	Integer	0
ibdot1sOperMstID.823	.3.6.1.4.1.26138.8.35.14.18.1.3.823	Integer	0
ibdot1sOperMstID.824	.3.6.1.4.1.26138.8.35.14.18.1.3.824	Integer	0
ibdot1sOperMstID.825	.3.6.1.4.1.26138.8.35.14.18.1.3.825	Integer	0
ibdot1sOperMstID.826	.3.6.1.4.1.26138.8.35.14.18.1.3.826	Integer	0
ibdot1sOperMstID.827	.3.6.1.4.1.26138.8.35.14.18.1.3.827	Integer	0
ibdot1sOperMstID.828	.3.6.1.4.1.26138.8.35.14.18.1.3.828	Integer	0
ibdot1sOperMstID.829	.3.6.1.4.1.26138.8.35.14.18.1.3.829	Integer	0
ibdot1sOperMstID.830	.3.6.1.4.1.26138.8.35.14.18.1.3.830	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.831	.3.6.1.4.1.26138.8.35.14.18.1.3.831	Integer	0
ibdot1sOperMstID.832	.3.6.1.4.1.26138.8.35.14.18.1.3.832	Integer	0
ibdot1sOperMstID.833	.3.6.1.4.1.26138.8.35.14.18.1.3.833	Integer	0
ibdot1sOperMstID.834	.3.6.1.4.1.26138.8.35.14.18.1.3.834	Integer	0
ibdot1sOperMstID.835	.3.6.1.4.1.26138.8.35.14.18.1.3.835	Integer	0
ibdot1sOperMstID.836	.3.6.1.4.1.26138.8.35.14.18.1.3.836	Integer	0
ibdot1sOperMstID.837	.3.6.1.4.1.26138.8.35.14.18.1.3.837	Integer	0
ibdot1sOperMstID.838	.3.6.1.4.1.26138.8.35.14.18.1.3.838	Integer	0
ibdot1sOperMstID.839	.3.6.1.4.1.26138.8.35.14.18.1.3.839	Integer	0
ibdot1sOperMstID.840	.3.6.1.4.1.26138.8.35.14.18.1.3.840	Integer	0
ibdot1sOperMstID.841	.3.6.1.4.1.26138.8.35.14.18.1.3.841	Integer	0
ibdot1sOperMstID.842	.3.6.1.4.1.26138.8.35.14.18.1.3.842	Integer	0
ibdot1sOperMstID.843	.3.6.1.4.1.26138.8.35.14.18.1.3.843	Integer	0
ibdot1sOperMstID.844	.3.6.1.4.1.26138.8.35.14.18.1.3.844	Integer	0
ibdot1sOperMstID.845	.3.6.1.4.1.26138.8.35.14.18.1.3.845	Integer	0
ibdot1sOperMstID.846	.3.6.1.4.1.26138.8.35.14.18.1.3.846	Integer	0
ibdot1sOperMstID.847	.3.6.1.4.1.26138.8.35.14.18.1.3.847	Integer	0
ibdot1sOperMstID.848	.3.6.1.4.1.26138.8.35.14.18.1.3.848	Integer	0
ibdot1sOperMstID.849	.3.6.1.4.1.26138.8.35.14.18.1.3.849	Integer	0
ibdot1sOperMstID.850	.3.6.1.4.1.26138.8.35.14.18.1.3.850	Integer	0
ibdot1sOperMstID.851	.3.6.1.4.1.26138.8.35.14.18.1.3.851	Integer	0
ibdot1sOperMstID.852	.3.6.1.4.1.26138.8.35.14.18.1.3.852	Integer	0
ibdot1sOperMstID.853	.3.6.1.4.1.26138.8.35.14.18.1.3.853	Integer	0
ibdot1sOperMstID.854	.3.6.1.4.1.26138.8.35.14.18.1.3.854	Integer	0
ibdot1sOperMstID.855	.3.6.1.4.1.26138.8.35.14.18.1.3.855	Integer	0
ibdot1sOperMstID.856	.3.6.1.4.1.26138.8.35.14.18.1.3.856	Integer	0
ibdot1sOperMstID.857	.3.6.1.4.1.26138.8.35.14.18.1.3.857	Integer	0
ibdot1sOperMstID.858	.3.6.1.4.1.26138.8.35.14.18.1.3.858	Integer	0
ibdot1sOperMstID.859	.3.6.1.4.1.26138.8.35.14.18.1.3.859	Integer	0
ibdot1sOperMstID.860	.3.6.1.4.1.26138.8.35.14.18.1.3.860	Integer	0
ibdot1sOperMstID.861	.3.6.1.4.1.26138.8.35.14.18.1.3.861	Integer	0
ibdot1sOperMstID.862	.3.6.1.4.1.26138.8.35.14.18.1.3.862	Integer	0
ibdot1sOperMstID.863	.3.6.1.4.1.26138.8.35.14.18.1.3.863	Integer	0
ibdot1sOperMstID.864	.3.6.1.4.1.26138.8.35.14.18.1.3.864	Integer	0
ibdot1sOperMstID.865	.3.6.1.4.1.26138.8.35.14.18.1.3.865	Integer	0
ibdot1sOperMstID.866	.3.6.1.4.1.26138.8.35.14.18.1.3.866	Integer	0
ibdot1sOperMstID.867	.3.6.1.4.1.26138.8.35.14.18.1.3.867	Integer	0
ibdot1sOperMstID.868	.3.6.1.4.1.26138.8.35.14.18.1.3.868	Integer	0
ibdot1sOperMstID.869	.3.6.1.4.1.26138.8.35.14.18.1.3.869	Integer	0
ibdot1sOperMstID.870	.3.6.1.4.1.26138.8.35.14.18.1.3.870	Integer	0
ibdot1sOperMstID.871	.3.6.1.4.1.26138.8.35.14.18.1.3.871	Integer	0
ibdot1sOperMstID.872	.3.6.1.4.1.26138.8.35.14.18.1.3.872	Integer	0
ibdot1sOperMstID.873	.3.6.1.4.1.26138.8.35.14.18.1.3.873	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.874	.3.6.1.4.1.26138.8.35.14.18.1.3.874	Integer	0
ibdot1sOperMstID.875	.3.6.1.4.1.26138.8.35.14.18.1.3.875	Integer	0
ibdot1sOperMstID.876	.3.6.1.4.1.26138.8.35.14.18.1.3.876	Integer	0
ibdot1sOperMstID.877	.3.6.1.4.1.26138.8.35.14.18.1.3.877	Integer	0
ibdot1sOperMstID.878	.3.6.1.4.1.26138.8.35.14.18.1.3.878	Integer	0
ibdot1sOperMstID.879	.3.6.1.4.1.26138.8.35.14.18.1.3.879	Integer	0
ibdot1sOperMstID.880	.3.6.1.4.1.26138.8.35.14.18.1.3.880	Integer	0
ibdot1sOperMstID.881	.3.6.1.4.1.26138.8.35.14.18.1.3.881	Integer	0
ibdot1sOperMstID.882	.3.6.1.4.1.26138.8.35.14.18.1.3.882	Integer	0
ibdot1sOperMstID.883	.3.6.1.4.1.26138.8.35.14.18.1.3.883	Integer	0
ibdot1sOperMstID.884	.3.6.1.4.1.26138.8.35.14.18.1.3.884	Integer	0
ibdot1sOperMstID.885	.3.6.1.4.1.26138.8.35.14.18.1.3.885	Integer	0
ibdot1sOperMstID.886	.3.6.1.4.1.26138.8.35.14.18.1.3.886	Integer	0
ibdot1sOperMstID.887	.3.6.1.4.1.26138.8.35.14.18.1.3.887	Integer	0
ibdot1sOperMstID.888	.3.6.1.4.1.26138.8.35.14.18.1.3.888	Integer	0
ibdot1sOperMstID.889	.3.6.1.4.1.26138.8.35.14.18.1.3.889	Integer	0
ibdot1sOperMstID.890	.3.6.1.4.1.26138.8.35.14.18.1.3.890	Integer	0
ibdot1sOperMstID.891	.3.6.1.4.1.26138.8.35.14.18.1.3.891	Integer	0
ibdot1sOperMstID.892	.3.6.1.4.1.26138.8.35.14.18.1.3.892	Integer	0
ibdot1sOperMstID.893	.3.6.1.4.1.26138.8.35.14.18.1.3.893	Integer	0
ibdot1sOperMstID.894	.3.6.1.4.1.26138.8.35.14.18.1.3.894	Integer	0
ibdot1sOperMstID.895	.3.6.1.4.1.26138.8.35.14.18.1.3.895	Integer	0
ibdot1sOperMstID.896	.3.6.1.4.1.26138.8.35.14.18.1.3.896	Integer	0
ibdot1sOperMstID.897	.3.6.1.4.1.26138.8.35.14.18.1.3.897	Integer	0
ibdot1sOperMstID.898	.3.6.1.4.1.26138.8.35.14.18.1.3.898	Integer	0
ibdot1sOperMstID.899	.3.6.1.4.1.26138.8.35.14.18.1.3.899	Integer	0
ibdot1sOperMstID.900	.3.6.1.4.1.26138.8.35.14.18.1.3.900	Integer	0
ibdot1sOperMstID.901	.3.6.1.4.1.26138.8.35.14.18.1.3.901	Integer	0
ibdot1sOperMstID.902	.3.6.1.4.1.26138.8.35.14.18.1.3.902	Integer	0
ibdot1sOperMstID.903	.3.6.1.4.1.26138.8.35.14.18.1.3.903	Integer	0
ibdot1sOperMstID.904	.3.6.1.4.1.26138.8.35.14.18.1.3.904	Integer	0
ibdot1sOperMstID.905	.3.6.1.4.1.26138.8.35.14.18.1.3.905	Integer	0
ibdot1sOperMstID.906	.3.6.1.4.1.26138.8.35.14.18.1.3.906	Integer	0
ibdot1sOperMstID.907	.3.6.1.4.1.26138.8.35.14.18.1.3.907	Integer	0
ibdot1sOperMstID.908	.3.6.1.4.1.26138.8.35.14.18.1.3.908	Integer	0
ibdot1sOperMstID.909	.3.6.1.4.1.26138.8.35.14.18.1.3.909	Integer	0
ibdot1sOperMstID.910	.3.6.1.4.1.26138.8.35.14.18.1.3.910	Integer	0
ibdot1sOperMstID.911	.3.6.1.4.1.26138.8.35.14.18.1.3.911	Integer	0
ibdot1sOperMstID.912	.3.6.1.4.1.26138.8.35.14.18.1.3.912	Integer	0
ibdot1sOperMstID.913	.3.6.1.4.1.26138.8.35.14.18.1.3.913	Integer	0
ibdot1sOperMstID.914	.3.6.1.4.1.26138.8.35.14.18.1.3.914	Integer	0
ibdot1sOperMstID.915	.3.6.1.4.1.26138.8.35.14.18.1.3.915	Integer	0
ibdot1sOperMstID.916	.3.6.1.4.1.26138.8.35.14.18.1.3.916	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.917	.3.6.1.4.1.26138.8.35.14.18.1.3.917	Integer	0
ibdot1sOperMstID.918	.3.6.1.4.1.26138.8.35.14.18.1.3.918	Integer	0
ibdot1sOperMstID.919	.3.6.1.4.1.26138.8.35.14.18.1.3.919	Integer	0
ibdot1sOperMstID.920	.3.6.1.4.1.26138.8.35.14.18.1.3.920	Integer	0
ibdot1sOperMstID.921	.3.6.1.4.1.26138.8.35.14.18.1.3.921	Integer	0
ibdot1sOperMstID.922	.3.6.1.4.1.26138.8.35.14.18.1.3.922	Integer	0
ibdot1sOperMstID.923	.3.6.1.4.1.26138.8.35.14.18.1.3.923	Integer	0
ibdot1sOperMstID.924	.3.6.1.4.1.26138.8.35.14.18.1.3.924	Integer	0
ibdot1sOperMstID.925	.3.6.1.4.1.26138.8.35.14.18.1.3.925	Integer	0
ibdot1sOperMstID.926	.3.6.1.4.1.26138.8.35.14.18.1.3.926	Integer	0
ibdot1sOperMstID.927	.3.6.1.4.1.26138.8.35.14.18.1.3.927	Integer	0
ibdot1sOperMstID.928	.3.6.1.4.1.26138.8.35.14.18.1.3.928	Integer	0
ibdot1sOperMstID.929	.3.6.1.4.1.26138.8.35.14.18.1.3.929	Integer	0
ibdot1sOperMstID.930	.3.6.1.4.1.26138.8.35.14.18.1.3.930	Integer	0
ibdot1sOperMstID.931	.3.6.1.4.1.26138.8.35.14.18.1.3.931	Integer	0
ibdot1sOperMstID.932	.3.6.1.4.1.26138.8.35.14.18.1.3.932	Integer	0
ibdot1sOperMstID.933	.3.6.1.4.1.26138.8.35.14.18.1.3.933	Integer	0
ibdot1sOperMstID.934	.3.6.1.4.1.26138.8.35.14.18.1.3.934	Integer	0
ibdot1sOperMstID.935	.3.6.1.4.1.26138.8.35.14.18.1.3.935	Integer	0
ibdot1sOperMstID.936	.3.6.1.4.1.26138.8.35.14.18.1.3.936	Integer	0
ibdot1sOperMstID.937	.3.6.1.4.1.26138.8.35.14.18.1.3.937	Integer	0
ibdot1sOperMstID.938	.3.6.1.4.1.26138.8.35.14.18.1.3.938	Integer	0
ibdot1sOperMstID.939	.3.6.1.4.1.26138.8.35.14.18.1.3.939	Integer	0
ibdot1sOperMstID.940	.3.6.1.4.1.26138.8.35.14.18.1.3.940	Integer	0
ibdot1sOperMstID.941	.3.6.1.4.1.26138.8.35.14.18.1.3.941	Integer	0
ibdot1sOperMstID.942	.3.6.1.4.1.26138.8.35.14.18.1.3.942	Integer	0
ibdot1sOperMstID.943	.3.6.1.4.1.26138.8.35.14.18.1.3.943	Integer	0
ibdot1sOperMstID.944	.3.6.1.4.1.26138.8.35.14.18.1.3.944	Integer	0
ibdot1sOperMstID.945	.3.6.1.4.1.26138.8.35.14.18.1.3.945	Integer	0
ibdot1sOperMstID.946	.3.6.1.4.1.26138.8.35.14.18.1.3.946	Integer	0
ibdot1sOperMstID.947	.3.6.1.4.1.26138.8.35.14.18.1.3.947	Integer	0
ibdot1sOperMstID.948	.3.6.1.4.1.26138.8.35.14.18.1.3.948	Integer	0
ibdot1sOperMstID.949	.3.6.1.4.1.26138.8.35.14.18.1.3.949	Integer	0
ibdot1sOperMstID.950	.3.6.1.4.1.26138.8.35.14.18.1.3.950	Integer	0
ibdot1sOperMstID.951	.3.6.1.4.1.26138.8.35.14.18.1.3.951	Integer	0
ibdot1sOperMstID.952	.3.6.1.4.1.26138.8.35.14.18.1.3.952	Integer	0
ibdot1sOperMstID.953	.3.6.1.4.1.26138.8.35.14.18.1.3.953	Integer	0
ibdot1sOperMstID.954	.3.6.1.4.1.26138.8.35.14.18.1.3.954	Integer	0
ibdot1sOperMstID.955	.3.6.1.4.1.26138.8.35.14.18.1.3.955	Integer	0
ibdot1sOperMstID.956	.3.6.1.4.1.26138.8.35.14.18.1.3.956	Integer	0
ibdot1sOperMstID.957	.3.6.1.4.1.26138.8.35.14.18.1.3.957	Integer	0
ibdot1sOperMstID.958	.3.6.1.4.1.26138.8.35.14.18.1.3.958	Integer	0
ibdot1sOperMstID.959	.3.6.1.4.1.26138.8.35.14.18.1.3.959	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.960	.3.6.1.4.1.26138.8.35.14.18.1.3.960	Integer	0
ibdot1sOperMstID.961	.3.6.1.4.1.26138.8.35.14.18.1.3.961	Integer	0
ibdot1sOperMstID.962	.3.6.1.4.1.26138.8.35.14.18.1.3.962	Integer	0
ibdot1sOperMstID.963	.3.6.1.4.1.26138.8.35.14.18.1.3.963	Integer	0
ibdot1sOperMstID.964	.3.6.1.4.1.26138.8.35.14.18.1.3.964	Integer	0
ibdot1sOperMstID.965	.3.6.1.4.1.26138.8.35.14.18.1.3.965	Integer	0
ibdot1sOperMstID.966	.3.6.1.4.1.26138.8.35.14.18.1.3.966	Integer	0
ibdot1sOperMstID.967	.3.6.1.4.1.26138.8.35.14.18.1.3.967	Integer	0
ibdot1sOperMstID.968	.3.6.1.4.1.26138.8.35.14.18.1.3.968	Integer	0
ibdot1sOperMstID.969	.3.6.1.4.1.26138.8.35.14.18.1.3.969	Integer	0
ibdot1sOperMstID.970	.3.6.1.4.1.26138.8.35.14.18.1.3.970	Integer	0
ibdot1sOperMstID.971	.3.6.1.4.1.26138.8.35.14.18.1.3.971	Integer	0
ibdot1sOperMstID.972	.3.6.1.4.1.26138.8.35.14.18.1.3.972	Integer	0
ibdot1sOperMstID.973	.3.6.1.4.1.26138.8.35.14.18.1.3.973	Integer	0
ibdot1sOperMstID.974	.3.6.1.4.1.26138.8.35.14.18.1.3.974	Integer	0
ibdot1sOperMstID.975	.3.6.1.4.1.26138.8.35.14.18.1.3.975	Integer	0
ibdot1sOperMstID.976	.3.6.1.4.1.26138.8.35.14.18.1.3.976	Integer	0
ibdot1sOperMstID.977	.3.6.1.4.1.26138.8.35.14.18.1.3.977	Integer	0
ibdot1sOperMstID.978	.3.6.1.4.1.26138.8.35.14.18.1.3.978	Integer	0
ibdot1sOperMstID.979	.3.6.1.4.1.26138.8.35.14.18.1.3.979	Integer	0
ibdot1sOperMstID.980	.3.6.1.4.1.26138.8.35.14.18.1.3.980	Integer	0
ibdot1sOperMstID.981	.3.6.1.4.1.26138.8.35.14.18.1.3.981	Integer	0
ibdot1sOperMstID.982	.3.6.1.4.1.26138.8.35.14.18.1.3.982	Integer	0
ibdot1sOperMstID.983	.3.6.1.4.1.26138.8.35.14.18.1.3.983	Integer	0
ibdot1sOperMstID.984	.3.6.1.4.1.26138.8.35.14.18.1.3.984	Integer	0
ibdot1sOperMstID.985	.3.6.1.4.1.26138.8.35.14.18.1.3.985	Integer	0
ibdot1sOperMstID.986	.3.6.1.4.1.26138.8.35.14.18.1.3.986	Integer	0
ibdot1sOperMstID.987	.3.6.1.4.1.26138.8.35.14.18.1.3.987	Integer	0
ibdot1sOperMstID.988	.3.6.1.4.1.26138.8.35.14.18.1.3.988	Integer	0
ibdot1sOperMstID.989	.3.6.1.4.1.26138.8.35.14.18.1.3.989	Integer	0
ibdot1sOperMstID.990	.3.6.1.4.1.26138.8.35.14.18.1.3.990	Integer	0
ibdot1sOperMstID.991	.3.6.1.4.1.26138.8.35.14.18.1.3.991	Integer	0
ibdot1sOperMstID.992	.3.6.1.4.1.26138.8.35.14.18.1.3.992	Integer	0
ibdot1sOperMstID.993	.3.6.1.4.1.26138.8.35.14.18.1.3.993	Integer	0
ibdot1sOperMstID.994	.3.6.1.4.1.26138.8.35.14.18.1.3.994	Integer	0
ibdot1sOperMstID.995	.3.6.1.4.1.26138.8.35.14.18.1.3.995	Integer	0
ibdot1sOperMstID.996	.3.6.1.4.1.26138.8.35.14.18.1.3.996	Integer	0
ibdot1sOperMstID.997	.3.6.1.4.1.26138.8.35.14.18.1.3.997	Integer	0
ibdot1sOperMstID.998	.3.6.1.4.1.26138.8.35.14.18.1.3.998	Integer	0
ibdot1sOperMstID.999	.3.6.1.4.1.26138.8.35.14.18.1.3.999	Integer	0
ibdot1sOperMstID.1000	.3.6.1.4.1.26138.8.35.14.18.1.3.1000	Integer	0
ibdot1sOperMstID.1001	.3.6.1.4.1.26138.8.35.14.18.1.3.1001	Integer	0
ibdot1sOperMstID.1002	.3.6.1.4.1.26138.8.35.14.18.1.3.1002	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.1003	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1003	Integer	0
ibdot1sOperMstID.1004	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1004	Integer	0
ibdot1sOperMstID.1005	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1005	Integer	0
ibdot1sOperMstID.1006	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1006	Integer	0
ibdot1sOperMstID.1007	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1007	Integer	0
ibdot1sOperMstID.1008	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1008	Integer	0
ibdot1sOperMstID.1009	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1009	Integer	0
ibdot1sOperMstID.1010	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1010	Integer	0
ibdot1sOperMstID.1011	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1011	Integer	0
ibdot1sOperMstID.1012	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1012	Integer	0
ibdot1sOperMstID.1013	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1013	Integer	0
ibdot1sOperMstID.1014	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1014	Integer	0
ibdot1sOperMstID.1015	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1015	Integer	0
ibdot1sOperMstID.1016	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1016	Integer	0
ibdot1sOperMstID.1017	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1017	Integer	0
ibdot1sOperMstID.1018	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1018	Integer	0
ibdot1sOperMstID.1019	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1019	Integer	0
ibdot1sOperMstID.1020	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1020	Integer	0
ibdot1sOperMstID.1021	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1021	Integer	0
ibdot1sOperMstID.1022	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1022	Integer	0
ibdot1sOperMstID.1023	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1023	Integer	0
ibdot1sOperMstID.1024	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1024	Integer	0
ibdot1sOperMstID.1025	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1025	Integer	0
ibdot1sOperMstID.1026	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1026	Integer	0
ibdot1sOperMstID.1027	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1027	Integer	0
ibdot1sOperMstID.1028	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1028	Integer	0
ibdot1sOperMstID.1029	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1029	Integer	0
ibdot1sOperMstID.1030	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1030	Integer	0
ibdot1sOperMstID.1031	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1031	Integer	0
ibdot1sOperMstID.1032	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1032	Integer	0
ibdot1sOperMstID.1033	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1033	Integer	0
ibdot1sOperMstID.1034	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1034	Integer	0
ibdot1sOperMstID.1035	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1035	Integer	0
ibdot1sOperMstID.1036	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1036	Integer	0
ibdot1sOperMstID.1037	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1037	Integer	0
ibdot1sOperMstID.1038	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1038	Integer	0
ibdot1sOperMstID.1039	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1039	Integer	0
ibdot1sOperMstID.1040	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1040	Integer	0
ibdot1sOperMstID.1041	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1041	Integer	0
ibdot1sOperMstID.1042	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1042	Integer	0
ibdot1sOperMstID.1043	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1043	Integer	0
ibdot1sOperMstID.1044	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1044	Integer	0
ibdot1sOperMstID.1045	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1045	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.1046	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1046	Integer	0
ibdot1sOperMstID.1047	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1047	Integer	0
ibdot1sOperMstID.1048	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1048	Integer	0
ibdot1sOperMstID.1049	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1049	Integer	0
ibdot1sOperMstID.1050	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1050	Integer	0
ibdot1sOperMstID.1051	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1051	Integer	0
ibdot1sOperMstID.1052	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1052	Integer	0
ibdot1sOperMstID.1053	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1053	Integer	0
ibdot1sOperMstID.1054	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1054	Integer	0
ibdot1sOperMstID.1055	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1055	Integer	0
ibdot1sOperMstID.1056	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1056	Integer	0
ibdot1sOperMstID.1057	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1057	Integer	0
ibdot1sOperMstID.1058	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1058	Integer	0
ibdot1sOperMstID.1059	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1059	Integer	0
ibdot1sOperMstID.1060	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1060	Integer	0
ibdot1sOperMstID.1061	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1061	Integer	0
ibdot1sOperMstID.1062	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1062	Integer	0
ibdot1sOperMstID.1063	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1063	Integer	0
ibdot1sOperMstID.1064	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1064	Integer	0
ibdot1sOperMstID.1065	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1065	Integer	0
ibdot1sOperMstID.1066	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1066	Integer	0
ibdot1sOperMstID.1067	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1067	Integer	0
ibdot1sOperMstID.1068	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1068	Integer	0
ibdot1sOperMstID.1069	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1069	Integer	0
ibdot1sOperMstID.1070	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1070	Integer	0
ibdot1sOperMstID.1071	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1071	Integer	0
ibdot1sOperMstID.1072	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1072	Integer	0
ibdot1sOperMstID.1073	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1073	Integer	0
ibdot1sOperMstID.1074	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1074	Integer	0
ibdot1sOperMstID.1075	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1075	Integer	0
ibdot1sOperMstID.1076	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1076	Integer	0
ibdot1sOperMstID.1077	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1077	Integer	0
ibdot1sOperMstID.1078	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1078	Integer	0
ibdot1sOperMstID.1079	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1079	Integer	0
ibdot1sOperMstID.1080	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1080	Integer	0
ibdot1sOperMstID.1081	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1081	Integer	0
ibdot1sOperMstID.1082	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1082	Integer	0
ibdot1sOperMstID.1083	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1083	Integer	0
ibdot1sOperMstID.1084	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1084	Integer	0
ibdot1sOperMstID.1085	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1085	Integer	0
ibdot1sOperMstID.1086	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1086	Integer	0
ibdot1sOperMstID.1087	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1087	Integer	0
ibdot1sOperMstID.1088	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1088	Integer	0



Name	OID	Value Type	Value Example
ibdot1sOperMstID.1089	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1089	Integer	0
ibdot1sOperMstID.1090	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1090	Integer	0
ibdot1sOperMstID.1091	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1091	Integer	0
ibdot1sOperMstID.1092	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1092	Integer	0
ibdot1sOperMstID.1093	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1093	Integer	0
ibdot1sOperMstID.1094	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1094	Integer	0
ibdot1sOperMstID.1095	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1095	Integer	0
ibdot1sOperMstID.1096	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1096	Integer	0
ibdot1sOperMstID.1097	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1097	Integer	0
ibdot1sOperMstID.1098	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1098	Integer	0
ibdot1sOperMstID.1099	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1099	Integer	0
ibdot1sOperMstID.1100	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1100	Integer	0
ibdot1sOperMstID.1101	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1101	Integer	0
ibdot1sOperMstID.1102	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1102	Integer	0
ibdot1sOperMstID.1103	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1103	Integer	0
ibdot1sOperMstID.1104	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1104	Integer	0
ibdot1sOperMstID.1105	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1105	Integer	0
ibdot1sOperMstID.1106	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1106	Integer	0
ibdot1sOperMstID.1107	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1107	Integer	0
ibdot1sOperMstID.1108	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1108	Integer	0
ibdot1sOperMstID.1109	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1109	Integer	0
ibdot1sOperMstID.1110	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1110	Integer	0
ibdot1sOperMstID.1111	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1111	Integer	0
ibdot1sOperMstID.1112	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1112	Integer	0
ibdot1sOperMstID.1113	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1113	Integer	0
ibdot1sOperMstID.1114	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1114	Integer	0
ibdot1sOperMstID.1115	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1115	Integer	0
ibdot1sOperMstID.1116	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1116	Integer	0
ibdot1sOperMstID.1117	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1117	Integer	0
ibdot1sOperMstID.1118	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1118	Integer	0
ibdot1sOperMstID.1119	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1119	Integer	0
ibdot1sOperMstID.1120	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1120	Integer	0
ibdot1sOperMstID.1121	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1121	Integer	0
ibdot1sOperMstID.1122	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1122	Integer	0
ibdot1sOperMstID.1123	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1123	Integer	0
ibdot1sOperMstID.1124	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1124	Integer	0
ibdot1sOperMstID.1125	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1125	Integer	0
ibdot1sOperMstID.1126	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1126	Integer	0
ibdot1sOperMstID.1127	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1127	Integer	0
ibdot1sOperMstID.1128	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1128	Integer	0
ibdot1sOperMstID.1129	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1129	Integer	0
ibdot1sOperMstID.1130	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1130	Integer	0
ibdot1sOperMstID.1131	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1131	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.1132	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1132	Integer	0
ibdot1sOperMstID.1133	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1133	Integer	0
ibdot1sOperMstID.1134	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1134	Integer	0
ibdot1sOperMstID.1135	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1135	Integer	0
ibdot1sOperMstID.1136	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1136	Integer	0
ibdot1sOperMstID.1137	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1137	Integer	0
ibdot1sOperMstID.1138	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1138	Integer	0
ibdot1sOperMstID.1139	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1139	Integer	0
ibdot1sOperMstID.1140	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1140	Integer	0
ibdot1sOperMstID.1141	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1141	Integer	0
ibdot1sOperMstID.1142	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1142	Integer	0
ibdot1sOperMstID.1143	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1143	Integer	0
ibdot1sOperMstID.1144	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1144	Integer	0
ibdot1sOperMstID.1145	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1145	Integer	0
ibdot1sOperMstID.1146	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1146	Integer	0
ibdot1sOperMstID.1147	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1147	Integer	0
ibdot1sOperMstID.1148	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1148	Integer	0
ibdot1sOperMstID.1149	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1149	Integer	0
ibdot1sOperMstID.1150	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1150	Integer	0
ibdot1sOperMstID.1151	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1151	Integer	0
ibdot1sOperMstID.1152	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1152	Integer	0
ibdot1sOperMstID.1153	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1153	Integer	0
ibdot1sOperMstID.1154	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1154	Integer	0
ibdot1sOperMstID.1155	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1155	Integer	0
ibdot1sOperMstID.1156	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1156	Integer	0
ibdot1sOperMstID.1157	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1157	Integer	0
ibdot1sOperMstID.1158	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1158	Integer	0
ibdot1sOperMstID.1159	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1159	Integer	0
ibdot1sOperMstID.1160	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1160	Integer	0
ibdot1sOperMstID.1161	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1161	Integer	0
ibdot1sOperMstID.1162	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1162	Integer	0
ibdot1sOperMstID.1163	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1163	Integer	0
ibdot1sOperMstID.1164	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1164	Integer	0
ibdot1sOperMstID.1165	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1165	Integer	0
ibdot1sOperMstID.1166	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1166	Integer	0
ibdot1sOperMstID.1167	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1167	Integer	0
ibdot1sOperMstID.1168	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1168	Integer	0
ibdot1sOperMstID.1169	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1169	Integer	0
ibdot1sOperMstID.1170	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1170	Integer	0
ibdot1sOperMstID.1171	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1171	Integer	0
ibdot1sOperMstID.1172	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1172	Integer	0
ibdot1sOperMstID.1173	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1173	Integer	0
ibdot1sOperMstID.1174	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1174	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.1175	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1175	Integer	0
ibdot1sOperMstID.1176	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1176	Integer	0
ibdot1sOperMstID.1177	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1177	Integer	0
ibdot1sOperMstID.1178	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1178	Integer	0
ibdot1sOperMstID.1179	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1179	Integer	0
ibdot1sOperMstID.1180	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1180	Integer	0
ibdot1sOperMstID.1181	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1181	Integer	0
ibdot1sOperMstID.1182	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1182	Integer	0
ibdot1sOperMstID.1183	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1183	Integer	0
ibdot1sOperMstID.1184	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1184	Integer	0
ibdot1sOperMstID.1185	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1185	Integer	0
ibdot1sOperMstID.1186	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1186	Integer	0
ibdot1sOperMstID.1187	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1187	Integer	0
ibdot1sOperMstID.1188	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1188	Integer	0
ibdot1sOperMstID.1189	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1189	Integer	0
ibdot1sOperMstID.1190	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1190	Integer	0
ibdot1sOperMstID.1191	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1191	Integer	0
ibdot1sOperMstID.1192	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1192	Integer	0
ibdot1sOperMstID.1193	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1193	Integer	0
ibdot1sOperMstID.1194	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1194	Integer	0
ibdot1sOperMstID.1195	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1195	Integer	0
ibdot1sOperMstID.1196	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1196	Integer	0
ibdot1sOperMstID.1197	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1197	Integer	0
ibdot1sOperMstID.1198	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1198	Integer	0
ibdot1sOperMstID.1199	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1199	Integer	0
ibdot1sOperMstID.1200	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1200	Integer	0
ibdot1sOperMstID.1201	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1201	Integer	0
ibdot1sOperMstID.1202	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1202	Integer	0
ibdot1sOperMstID.1203	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1203	Integer	0
ibdot1sOperMstID.1204	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1204	Integer	0
ibdot1sOperMstID.1205	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1205	Integer	0
ibdot1sOperMstID.1206	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1206	Integer	0
ibdot1sOperMstID.1207	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1207	Integer	0
ibdot1sOperMstID.1208	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1208	Integer	0
ibdot1sOperMstID.1209	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1209	Integer	0
ibdot1sOperMstID.1210	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1210	Integer	0
ibdot1sOperMstID.1211	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1211	Integer	0
ibdot1sOperMstID.1212	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1212	Integer	0
ibdot1sOperMstID.1213	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1213	Integer	0
ibdot1sOperMstID.1214	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1214	Integer	0
ibdot1sOperMstID.1215	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1215	Integer	0
ibdot1sOperMstID.1216	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1216	Integer	0
ibdot1sOperMstID.1217	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1217	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.1218	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1218	Integer	0
ibdot1sOperMstID.1219	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1219	Integer	0
ibdot1sOperMstID.1220	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1220	Integer	0
ibdot1sOperMstID.1221	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1221	Integer	0
ibdot1sOperMstID.1222	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1222	Integer	0
ibdot1sOperMstID.1223	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1223	Integer	0
ibdot1sOperMstID.1224	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1224	Integer	0
ibdot1sOperMstID.1225	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1225	Integer	0
ibdot1sOperMstID.1226	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1226	Integer	0
ibdot1sOperMstID.1227	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1227	Integer	0
ibdot1sOperMstID.1228	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1228	Integer	0
ibdot1sOperMstID.1229	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1229	Integer	0
ibdot1sOperMstID.1230	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1230	Integer	0
ibdot1sOperMstID.1231	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1231	Integer	0
ibdot1sOperMstID.1232	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1232	Integer	0
ibdot1sOperMstID.1233	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1233	Integer	0
ibdot1sOperMstID.1234	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1234	Integer	0
ibdot1sOperMstID.1235	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1235	Integer	0
ibdot1sOperMstID.1236	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1236	Integer	0
ibdot1sOperMstID.1237	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1237	Integer	0
ibdot1sOperMstID.1238	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1238	Integer	0
ibdot1sOperMstID.1239	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1239	Integer	0
ibdot1sOperMstID.1240	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1240	Integer	0
ibdot1sOperMstID.1241	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1241	Integer	0
ibdot1sOperMstID.1242	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1242	Integer	0
ibdot1sOperMstID.1243	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1243	Integer	0
ibdot1sOperMstID.1244	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1244	Integer	0
ibdot1sOperMstID.1245	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1245	Integer	0
ibdot1sOperMstID.1246	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1246	Integer	0
ibdot1sOperMstID.1247	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1247	Integer	0
ibdot1sOperMstID.1248	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1248	Integer	0
ibdot1sOperMstID.1249	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1249	Integer	0
ibdot1sOperMstID.1250	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1250	Integer	0
ibdot1sOperMstID.1251	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1251	Integer	0
ibdot1sOperMstID.1252	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1252	Integer	0
ibdot1sOperMstID.1253	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1253	Integer	0
ibdot1sOperMstID.1254	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1254	Integer	0
ibdot1sOperMstID.1255	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1255	Integer	0
ibdot1sOperMstID.1256	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1256	Integer	0
ibdot1sOperMstID.1257	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1257	Integer	0
ibdot1sOperMstID.1258	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1258	Integer	0
ibdot1sOperMstID.1259	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1259	Integer	0
ibdot1sOperMstID.1260	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1260	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.1261	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1261	Integer	0
ibdot1sOperMstID.1262	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1262	Integer	0
ibdot1sOperMstID.1263	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1263	Integer	0
ibdot1sOperMstID.1264	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1264	Integer	0
ibdot1sOperMstID.1265	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1265	Integer	0
ibdot1sOperMstID.1266	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1266	Integer	0
ibdot1sOperMstID.1267	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1267	Integer	0
ibdot1sOperMstID.1268	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1268	Integer	0
ibdot1sOperMstID.1269	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1269	Integer	0
ibdot1sOperMstID.1270	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1270	Integer	0
ibdot1sOperMstID.1271	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1271	Integer	0
ibdot1sOperMstID.1272	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1272	Integer	0
ibdot1sOperMstID.1273	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1273	Integer	0
ibdot1sOperMstID.1274	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1274	Integer	0
ibdot1sOperMstID.1275	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1275	Integer	0
ibdot1sOperMstID.1276	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1276	Integer	0
ibdot1sOperMstID.1277	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1277	Integer	0
ibdot1sOperMstID.1278	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1278	Integer	0
ibdot1sOperMstID.1279	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1279	Integer	0
ibdot1sOperMstID.1280	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1280	Integer	0
ibdot1sOperMstID.1281	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1281	Integer	0
ibdot1sOperMstID.1282	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1282	Integer	0
ibdot1sOperMstID.1283	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1283	Integer	0
ibdot1sOperMstID.1284	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1284	Integer	0
ibdot1sOperMstID.1285	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1285	Integer	0
ibdot1sOperMstID.1286	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1286	Integer	0
ibdot1sOperMstID.1287	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1287	Integer	0
ibdot1sOperMstID.1288	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1288	Integer	0
ibdot1sOperMstID.1289	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1289	Integer	0
ibdot1sOperMstID.1290	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1290	Integer	0
ibdot1sOperMstID.1291	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1291	Integer	0
ibdot1sOperMstID.1292	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1292	Integer	0
ibdot1sOperMstID.1293	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1293	Integer	0
ibdot1sOperMstID.1294	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1294	Integer	0
ibdot1sOperMstID.1295	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1295	Integer	0
ibdot1sOperMstID.1296	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1296	Integer	0
ibdot1sOperMstID.1297	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1297	Integer	0
ibdot1sOperMstID.1298	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1298	Integer	0
ibdot1sOperMstID.1299	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1299	Integer	0
ibdot1sOperMstID.1300	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1300	Integer	0
ibdot1sOperMstID.1301	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1301	Integer	0
ibdot1sOperMstID.1302	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1302	Integer	0
ibdot1sOperMstID.1303	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1303	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.1304	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1304	Integer	0
ibdot1sOperMstID.1305	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1305	Integer	0
ibdot1sOperMstID.1306	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1306	Integer	0
ibdot1sOperMstID.1307	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1307	Integer	0
ibdot1sOperMstID.1308	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1308	Integer	0
ibdot1sOperMstID.1309	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1309	Integer	0
ibdot1sOperMstID.1310	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1310	Integer	0
ibdot1sOperMstID.1311	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1311	Integer	0
ibdot1sOperMstID.1312	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1312	Integer	0
ibdot1sOperMstID.1313	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1313	Integer	0
ibdot1sOperMstID.1314	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1314	Integer	0
ibdot1sOperMstID.1315	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1315	Integer	0
ibdot1sOperMstID.1316	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1316	Integer	0
ibdot1sOperMstID.1317	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1317	Integer	0
ibdot1sOperMstID.1318	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1318	Integer	0
ibdot1sOperMstID.1319	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1319	Integer	0
ibdot1sOperMstID.1320	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1320	Integer	0
ibdot1sOperMstID.1321	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1321	Integer	0
ibdot1sOperMstID.1322	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1322	Integer	0
ibdot1sOperMstID.1323	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1323	Integer	0
ibdot1sOperMstID.1324	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1324	Integer	0
ibdot1sOperMstID.1325	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1325	Integer	0
ibdot1sOperMstID.1326	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1326	Integer	0
ibdot1sOperMstID.1327	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1327	Integer	0
ibdot1sOperMstID.1328	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1328	Integer	0
ibdot1sOperMstID.1329	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1329	Integer	0
ibdot1sOperMstID.1330	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1330	Integer	0
ibdot1sOperMstID.1331	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1331	Integer	0
ibdot1sOperMstID.1332	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1332	Integer	0
ibdot1sOperMstID.1333	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1333	Integer	0
ibdot1sOperMstID.1334	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1334	Integer	0
ibdot1sOperMstID.1335	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1335	Integer	0
ibdot1sOperMstID.1336	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1336	Integer	0
ibdot1sOperMstID.1337	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1337	Integer	0
ibdot1sOperMstID.1338	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1338	Integer	0
ibdot1sOperMstID.1339	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1339	Integer	0
ibdot1sOperMstID.1340	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1340	Integer	0
ibdot1sOperMstID.1341	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1341	Integer	0
ibdot1sOperMstID.1342	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1342	Integer	0
ibdot1sOperMstID.1343	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1343	Integer	0
ibdot1sOperMstID.1344	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1344	Integer	0
ibdot1sOperMstID.1345	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1345	Integer	0
ibdot1sOperMstID.1346	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1346	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.1347	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1347	Integer	0
ibdot1sOperMstID.1348	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1348	Integer	0
ibdot1sOperMstID.1349	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1349	Integer	0
ibdot1sOperMstID.1350	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1350	Integer	0
ibdot1sOperMstID.1351	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1351	Integer	0
ibdot1sOperMstID.1352	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1352	Integer	0
ibdot1sOperMstID.1353	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1353	Integer	0
ibdot1sOperMstID.1354	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1354	Integer	0
ibdot1sOperMstID.1355	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1355	Integer	0
ibdot1sOperMstID.1356	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1356	Integer	0
ibdot1sOperMstID.1357	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1357	Integer	0
ibdot1sOperMstID.1358	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1358	Integer	0
ibdot1sOperMstID.1359	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1359	Integer	0
ibdot1sOperMstID.1360	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1360	Integer	0
ibdot1sOperMstID.1361	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1361	Integer	0
ibdot1sOperMstID.1362	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1362	Integer	0
ibdot1sOperMstID.1363	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1363	Integer	0
ibdot1sOperMstID.1364	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1364	Integer	0
ibdot1sOperMstID.1365	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1365	Integer	0
ibdot1sOperMstID.1366	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1366	Integer	0
ibdot1sOperMstID.1367	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1367	Integer	0
ibdot1sOperMstID.1368	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1368	Integer	0
ibdot1sOperMstID.1369	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1369	Integer	0
ibdot1sOperMstID.1370	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1370	Integer	0
ibdot1sOperMstID.1371	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1371	Integer	0
ibdot1sOperMstID.1372	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1372	Integer	0
ibdot1sOperMstID.1373	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1373	Integer	0
ibdot1sOperMstID.1374	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1374	Integer	0
ibdot1sOperMstID.1375	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1375	Integer	0
ibdot1sOperMstID.1376	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1376	Integer	0
ibdot1sOperMstID.1377	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1377	Integer	0
ibdot1sOperMstID.1378	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1378	Integer	0
ibdot1sOperMstID.1379	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1379	Integer	0
ibdot1sOperMstID.1380	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1380	Integer	0
ibdot1sOperMstID.1381	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1381	Integer	0
ibdot1sOperMstID.1382	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1382	Integer	0
ibdot1sOperMstID.1383	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1383	Integer	0
ibdot1sOperMstID.1384	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1384	Integer	0
ibdot1sOperMstID.1385	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1385	Integer	0
ibdot1sOperMstID.1386	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1386	Integer	0
ibdot1sOperMstID.1387	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1387	Integer	0
ibdot1sOperMstID.1388	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1388	Integer	0
ibdot1sOperMstID.1389	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1389	Integer	0



Name	OID	Value Type	Value Example
ibdot1sOperMstID.1390	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1390	Integer	0
ibdot1sOperMstID.1391	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1391	Integer	0
ibdot1sOperMstID.1392	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1392	Integer	0
ibdot1sOperMstID.1393	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1393	Integer	0
ibdot1sOperMstID.1394	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1394	Integer	0
ibdot1sOperMstID.1395	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1395	Integer	0
ibdot1sOperMstID.1396	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1396	Integer	0
ibdot1sOperMstID.1397	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1397	Integer	0
ibdot1sOperMstID.1398	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1398	Integer	0
ibdot1sOperMstID.1399	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1399	Integer	0
ibdot1sOperMstID.1400	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1400	Integer	0
ibdot1sOperMstID.1401	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1401	Integer	0
ibdot1sOperMstID.1402	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1402	Integer	0
ibdot1sOperMstID.1403	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1403	Integer	0
ibdot1sOperMstID.1404	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1404	Integer	0
ibdot1sOperMstID.1405	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1405	Integer	0
ibdot1sOperMstID.1406	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1406	Integer	0
ibdot1sOperMstID.1407	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1407	Integer	0
ibdot1sOperMstID.1408	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1408	Integer	0
ibdot1sOperMstID.1409	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1409	Integer	0
ibdot1sOperMstID.1410	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1410	Integer	0
ibdot1sOperMstID.1411	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1411	Integer	0
ibdot1sOperMstID.1412	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1412	Integer	0
ibdot1sOperMstID.1413	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1413	Integer	0
ibdot1sOperMstID.1414	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1414	Integer	0
ibdot1sOperMstID.1415	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1415	Integer	0
ibdot1sOperMstID.1416	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1416	Integer	0
ibdot1sOperMstID.1417	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1417	Integer	0
ibdot1sOperMstID.1418	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1418	Integer	0
ibdot1sOperMstID.1419	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1419	Integer	0
ibdot1sOperMstID.1420	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1420	Integer	0
ibdot1sOperMstID.1421	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1421	Integer	0
ibdot1sOperMstID.1422	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1422	Integer	0
ibdot1sOperMstID.1423	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1423	Integer	0
ibdot1sOperMstID.1424	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1424	Integer	0
ibdot1sOperMstID.1425	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1425	Integer	0
ibdot1sOperMstID.1426	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1426	Integer	0
ibdot1sOperMstID.1427	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1427	Integer	0
ibdot1sOperMstID.1428	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1428	Integer	0
ibdot1sOperMstID.1429	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1429	Integer	0
ibdot1sOperMstID.1430	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1430	Integer	0
ibdot1sOperMstID.1431	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1431	Integer	0
ibdot1sOperMstID.1432	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1432	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.1433	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1433	Integer	0
ibdot1sOperMstID.1434	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1434	Integer	0
ibdot1sOperMstID.1435	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1435	Integer	0
ibdot1sOperMstID.1436	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1436	Integer	0
ibdot1sOperMstID.1437	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1437	Integer	0
ibdot1sOperMstID.1438	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1438	Integer	0
ibdot1sOperMstID.1439	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1439	Integer	0
ibdot1sOperMstID.1440	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1440	Integer	0
ibdot1sOperMstID.1441	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1441	Integer	0
ibdot1sOperMstID.1442	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1442	Integer	0
ibdot1sOperMstID.1443	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1443	Integer	0
ibdot1sOperMstID.1444	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1444	Integer	0
ibdot1sOperMstID.1445	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1445	Integer	0
ibdot1sOperMstID.1446	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1446	Integer	0
ibdot1sOperMstID.1447	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1447	Integer	0
ibdot1sOperMstID.1448	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1448	Integer	0
ibdot1sOperMstID.1449	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1449	Integer	0
ibdot1sOperMstID.1450	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1450	Integer	0
ibdot1sOperMstID.1451	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1451	Integer	0
ibdot1sOperMstID.1452	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1452	Integer	0
ibdot1sOperMstID.1453	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1453	Integer	0
ibdot1sOperMstID.1454	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1454	Integer	0
ibdot1sOperMstID.1455	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1455	Integer	0
ibdot1sOperMstID.1456	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1456	Integer	0
ibdot1sOperMstID.1457	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1457	Integer	0
ibdot1sOperMstID.1458	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1458	Integer	0
ibdot1sOperMstID.1459	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1459	Integer	0
ibdot1sOperMstID.1460	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1460	Integer	0
ibdot1sOperMstID.1461	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1461	Integer	0
ibdot1sOperMstID.1462	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1462	Integer	0
ibdot1sOperMstID.1463	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1463	Integer	0
ibdot1sOperMstID.1464	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1464	Integer	0
ibdot1sOperMstID.1465	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1465	Integer	0
ibdot1sOperMstID.1466	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1466	Integer	0
ibdot1sOperMstID.1467	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1467	Integer	0
ibdot1sOperMstID.1468	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1468	Integer	0
ibdot1sOperMstID.1469	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1469	Integer	0
ibdot1sOperMstID.1470	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1470	Integer	0
ibdot1sOperMstID.1471	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1471	Integer	0
ibdot1sOperMstID.1472	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1472	Integer	0
ibdot1sOperMstID.1473	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1473	Integer	0
ibdot1sOperMstID.1474	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1474	Integer	0
ibdot1sOperMstID.1475	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1475	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.1476	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1476	Integer	0
ibdot1sOperMstID.1477	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1477	Integer	0
ibdot1sOperMstID.1478	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1478	Integer	0
ibdot1sOperMstID.1479	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1479	Integer	0
ibdot1sOperMstID.1480	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1480	Integer	0
ibdot1sOperMstID.1481	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1481	Integer	0
ibdot1sOperMstID.1482	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1482	Integer	0
ibdot1sOperMstID.1483	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1483	Integer	0
ibdot1sOperMstID.1484	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1484	Integer	0
ibdot1sOperMstID.1485	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1485	Integer	0
ibdot1sOperMstID.1486	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1486	Integer	0
ibdot1sOperMstID.1487	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1487	Integer	0
ibdot1sOperMstID.1488	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1488	Integer	0
ibdot1sOperMstID.1489	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1489	Integer	0
ibdot1sOperMstID.1490	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1490	Integer	0
ibdot1sOperMstID.1491	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1491	Integer	0
ibdot1sOperMstID.1492	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1492	Integer	0
ibdot1sOperMstID.1493	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1493	Integer	0
ibdot1sOperMstID.1494	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1494	Integer	0
ibdot1sOperMstID.1495	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1495	Integer	0
ibdot1sOperMstID.1496	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1496	Integer	0
ibdot1sOperMstID.1497	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1497	Integer	0
ibdot1sOperMstID.1498	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1498	Integer	0
ibdot1sOperMstID.1499	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1499	Integer	0
ibdot1sOperMstID.1500	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1500	Integer	0
ibdot1sOperMstID.1501	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1501	Integer	0
ibdot1sOperMstID.1502	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1502	Integer	0
ibdot1sOperMstID.1503	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1503	Integer	0
ibdot1sOperMstID.1504	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1504	Integer	0
ibdot1sOperMstID.1505	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1505	Integer	0
ibdot1sOperMstID.1506	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1506	Integer	0
ibdot1sOperMstID.1507	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1507	Integer	0
ibdot1sOperMstID.1508	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1508	Integer	0
ibdot1sOperMstID.1509	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1509	Integer	0
ibdot1sOperMstID.1510	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1510	Integer	0
ibdot1sOperMstID.1511	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1511	Integer	0
ibdot1sOperMstID.1512	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1512	Integer	0
ibdot1sOperMstID.1513	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1513	Integer	0
ibdot1sOperMstID.1514	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1514	Integer	0
ibdot1sOperMstID.1515	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1515	Integer	0
ibdot1sOperMstID.1516	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1516	Integer	0
ibdot1sOperMstID.1517	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1517	Integer	0
ibdot1sOperMstID.1518	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1518	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.1519	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1519	Integer	0
ibdot1sOperMstID.1520	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1520	Integer	0
ibdot1sOperMstID.1521	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1521	Integer	0
ibdot1sOperMstID.1522	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1522	Integer	0
ibdot1sOperMstID.1523	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1523	Integer	0
ibdot1sOperMstID.1524	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1524	Integer	0
ibdot1sOperMstID.1525	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1525	Integer	0
ibdot1sOperMstID.1526	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1526	Integer	0
ibdot1sOperMstID.1527	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1527	Integer	0
ibdot1sOperMstID.1528	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1528	Integer	0
ibdot1sOperMstID.1529	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1529	Integer	0
ibdot1sOperMstID.1530	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1530	Integer	0
ibdot1sOperMstID.1531	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1531	Integer	0
ibdot1sOperMstID.1532	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1532	Integer	0
ibdot1sOperMstID.1533	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1533	Integer	0
ibdot1sOperMstID.1534	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1534	Integer	0
ibdot1sOperMstID.1535	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1535	Integer	0
ibdot1sOperMstID.1536	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1536	Integer	0
ibdot1sOperMstID.1537	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1537	Integer	0
ibdot1sOperMstID.1538	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1538	Integer	0
ibdot1sOperMstID.1539	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1539	Integer	0
ibdot1sOperMstID.1540	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1540	Integer	0
ibdot1sOperMstID.1541	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1541	Integer	0
ibdot1sOperMstID.1542	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1542	Integer	0
ibdot1sOperMstID.1543	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1543	Integer	0
ibdot1sOperMstID.1544	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1544	Integer	0
ibdot1sOperMstID.1545	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1545	Integer	0
ibdot1sOperMstID.1546	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1546	Integer	0
ibdot1sOperMstID.1547	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1547	Integer	0
ibdot1sOperMstID.1548	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1548	Integer	0
ibdot1sOperMstID.1549	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1549	Integer	0
ibdot1sOperMstID.1550	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1550	Integer	0
ibdot1sOperMstID.1551	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1551	Integer	0
ibdot1sOperMstID.1552	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1552	Integer	0
ibdot1sOperMstID.1553	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1553	Integer	0
ibdot1sOperMstID.1554	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1554	Integer	0
ibdot1sOperMstID.1555	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1555	Integer	0
ibdot1sOperMstID.1556	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1556	Integer	0
ibdot1sOperMstID.1557	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1557	Integer	0
ibdot1sOperMstID.1558	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1558	Integer	0
ibdot1sOperMstID.1559	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1559	Integer	0
ibdot1sOperMstID.1560	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1560	Integer	0
ibdot1sOperMstID.1561	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1561	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.1562	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1562	Integer	0
ibdot1sOperMstID.1563	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1563	Integer	0
ibdot1sOperMstID.1564	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1564	Integer	0
ibdot1sOperMstID.1565	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1565	Integer	0
ibdot1sOperMstID.1566	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1566	Integer	0
ibdot1sOperMstID.1567	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1567	Integer	0
ibdot1sOperMstID.1568	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1568	Integer	0
ibdot1sOperMstID.1569	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1569	Integer	0
ibdot1sOperMstID.1570	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1570	Integer	0
ibdot1sOperMstID.1571	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1571	Integer	0
ibdot1sOperMstID.1572	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1572	Integer	0
ibdot1sOperMstID.1573	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1573	Integer	0
ibdot1sOperMstID.1574	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1574	Integer	0
ibdot1sOperMstID.1575	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1575	Integer	0
ibdot1sOperMstID.1576	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1576	Integer	0
ibdot1sOperMstID.1577	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1577	Integer	0
ibdot1sOperMstID.1578	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1578	Integer	0
ibdot1sOperMstID.1579	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1579	Integer	0
ibdot1sOperMstID.1580	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1580	Integer	0
ibdot1sOperMstID.1581	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1581	Integer	0
ibdot1sOperMstID.1582	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1582	Integer	0
ibdot1sOperMstID.1583	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1583	Integer	0
ibdot1sOperMstID.1584	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1584	Integer	0
ibdot1sOperMstID.1585	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1585	Integer	0
ibdot1sOperMstID.1586	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1586	Integer	0
ibdot1sOperMstID.1587	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1587	Integer	0
ibdot1sOperMstID.1588	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1588	Integer	0
ibdot1sOperMstID.1589	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1589	Integer	0
ibdot1sOperMstID.1590	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1590	Integer	0
ibdot1sOperMstID.1591	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1591	Integer	0
ibdot1sOperMstID.1592	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1592	Integer	0
ibdot1sOperMstID.1593	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1593	Integer	0
ibdot1sOperMstID.1594	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1594	Integer	0
ibdot1sOperMstID.1595	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1595	Integer	0
ibdot1sOperMstID.1596	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1596	Integer	0
ibdot1sOperMstID.1597	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1597	Integer	0
ibdot1sOperMstID.1598	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1598	Integer	0
ibdot1sOperMstID.1599	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1599	Integer	0
ibdot1sOperMstID.1600	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1600	Integer	0
ibdot1sOperMstID.1601	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1601	Integer	0
ibdot1sOperMstID.1602	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1602	Integer	0
ibdot1sOperMstID.1603	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1603	Integer	0
ibdot1sOperMstID.1604	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1604	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.1605	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1605	Integer	0
ibdot1sOperMstID.1606	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1606	Integer	0
ibdot1sOperMstID.1607	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1607	Integer	0
ibdot1sOperMstID.1608	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1608	Integer	0
ibdot1sOperMstID.1609	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1609	Integer	0
ibdot1sOperMstID.1610	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1610	Integer	0
ibdot1sOperMstID.1611	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1611	Integer	0
ibdot1sOperMstID.1612	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1612	Integer	0
ibdot1sOperMstID.1613	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1613	Integer	0
ibdot1sOperMstID.1614	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1614	Integer	0
ibdot1sOperMstID.1615	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1615	Integer	0
ibdot1sOperMstID.1616	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1616	Integer	0
ibdot1sOperMstID.1617	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1617	Integer	0
ibdot1sOperMstID.1618	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1618	Integer	0
ibdot1sOperMstID.1619	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1619	Integer	0
ibdot1sOperMstID.1620	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1620	Integer	0
ibdot1sOperMstID.1621	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1621	Integer	0
ibdot1sOperMstID.1622	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1622	Integer	0
ibdot1sOperMstID.1623	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1623	Integer	0
ibdot1sOperMstID.1624	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1624	Integer	0
ibdot1sOperMstID.1625	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1625	Integer	0
ibdot1sOperMstID.1626	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1626	Integer	0
ibdot1sOperMstID.1627	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1627	Integer	0
ibdot1sOperMstID.1628	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1628	Integer	0
ibdot1sOperMstID.1629	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1629	Integer	0
ibdot1sOperMstID.1630	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1630	Integer	0
ibdot1sOperMstID.1631	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1631	Integer	0
ibdot1sOperMstID.1632	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1632	Integer	0
ibdot1sOperMstID.1633	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1633	Integer	0
ibdot1sOperMstID.1634	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1634	Integer	0
ibdot1sOperMstID.1635	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1635	Integer	0
ibdot1sOperMstID.1636	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1636	Integer	0
ibdot1sOperMstID.1637	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1637	Integer	0
ibdot1sOperMstID.1638	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1638	Integer	0
ibdot1sOperMstID.1639	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1639	Integer	0
ibdot1sOperMstID.1640	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1640	Integer	0
ibdot1sOperMstID.1641	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1641	Integer	0
ibdot1sOperMstID.1642	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1642	Integer	0
ibdot1sOperMstID.1643	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1643	Integer	0
ibdot1sOperMstID.1644	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1644	Integer	0
ibdot1sOperMstID.1645	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1645	Integer	0
ibdot1sOperMstID.1646	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1646	Integer	0
ibdot1sOperMstID.1647	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1647	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.1648	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1648	Integer	0
ibdot1sOperMstID.1649	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1649	Integer	0
ibdot1sOperMstID.1650	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1650	Integer	0
ibdot1sOperMstID.1651	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1651	Integer	0
ibdot1sOperMstID.1652	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1652	Integer	0
ibdot1sOperMstID.1653	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1653	Integer	0
ibdot1sOperMstID.1654	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1654	Integer	0
ibdot1sOperMstID.1655	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1655	Integer	0
ibdot1sOperMstID.1656	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1656	Integer	0
ibdot1sOperMstID.1657	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1657	Integer	0
ibdot1sOperMstID.1658	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1658	Integer	0
ibdot1sOperMstID.1659	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1659	Integer	0
ibdot1sOperMstID.1660	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1660	Integer	0
ibdot1sOperMstID.1661	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1661	Integer	0
ibdot1sOperMstID.1662	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1662	Integer	0
ibdot1sOperMstID.1663	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1663	Integer	0
ibdot1sOperMstID.1664	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1664	Integer	0
ibdot1sOperMstID.1665	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1665	Integer	0
ibdot1sOperMstID.1666	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1666	Integer	0
ibdot1sOperMstID.1667	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1667	Integer	0
ibdot1sOperMstID.1668	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1668	Integer	0
ibdot1sOperMstID.1669	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1669	Integer	0
ibdot1sOperMstID.1670	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1670	Integer	0
ibdot1sOperMstID.1671	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1671	Integer	0
ibdot1sOperMstID.1672	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1672	Integer	0
ibdot1sOperMstID.1673	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1673	Integer	0
ibdot1sOperMstID.1674	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1674	Integer	0
ibdot1sOperMstID.1675	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1675	Integer	0
ibdot1sOperMstID.1676	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1676	Integer	0
ibdot1sOperMstID.1677	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1677	Integer	0
ibdot1sOperMstID.1678	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1678	Integer	0
ibdot1sOperMstID.1679	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1679	Integer	0
ibdot1sOperMstID.1680	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1680	Integer	0
ibdot1sOperMstID.1681	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1681	Integer	0
ibdot1sOperMstID.1682	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1682	Integer	0
ibdot1sOperMstID.1683	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1683	Integer	0
ibdot1sOperMstID.1684	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1684	Integer	0
ibdot1sOperMstID.1685	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1685	Integer	0
ibdot1sOperMstID.1686	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1686	Integer	0
ibdot1sOperMstID.1687	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1687	Integer	0
ibdot1sOperMstID.1688	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1688	Integer	0
ibdot1sOperMstID.1689	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1689	Integer	0
ibdot1sOperMstID.1690	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1690	Integer	0



Name	OID	Value Type	Value Example
ibdot1sOperMstID.1691	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1691	Integer	0
ibdot1sOperMstID.1692	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1692	Integer	0
ibdot1sOperMstID.1693	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1693	Integer	0
ibdot1sOperMstID.1694	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1694	Integer	0
ibdot1sOperMstID.1695	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1695	Integer	0
ibdot1sOperMstID.1696	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1696	Integer	0
ibdot1sOperMstID.1697	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1697	Integer	0
ibdot1sOperMstID.1698	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1698	Integer	0
ibdot1sOperMstID.1699	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1699	Integer	0
ibdot1sOperMstID.1700	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1700	Integer	0
ibdot1sOperMstID.1701	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1701	Integer	0
ibdot1sOperMstID.1702	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1702	Integer	0
ibdot1sOperMstID.1703	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1703	Integer	0
ibdot1sOperMstID.1704	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1704	Integer	0
ibdot1sOperMstID.1705	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1705	Integer	0
ibdot1sOperMstID.1706	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1706	Integer	0
ibdot1sOperMstID.1707	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1707	Integer	0
ibdot1sOperMstID.1708	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1708	Integer	0
ibdot1sOperMstID.1709	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1709	Integer	0
ibdot1sOperMstID.1710	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1710	Integer	0
ibdot1sOperMstID.1711	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1711	Integer	0
ibdot1sOperMstID.1712	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1712	Integer	0
ibdot1sOperMstID.1713	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1713	Integer	0
ibdot1sOperMstID.1714	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1714	Integer	0
ibdot1sOperMstID.1715	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1715	Integer	0
ibdot1sOperMstID.1716	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1716	Integer	0
ibdot1sOperMstID.1717	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1717	Integer	0
ibdot1sOperMstID.1718	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1718	Integer	0
ibdot1sOperMstID.1719	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1719	Integer	0
ibdot1sOperMstID.1720	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1720	Integer	0
ibdot1sOperMstID.1721	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1721	Integer	0
ibdot1sOperMstID.1722	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1722	Integer	0
ibdot1sOperMstID.1723	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1723	Integer	0
ibdot1sOperMstID.1724	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1724	Integer	0
ibdot1sOperMstID.1725	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1725	Integer	0
ibdot1sOperMstID.1726	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1726	Integer	0
ibdot1sOperMstID.1727	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1727	Integer	0
ibdot1sOperMstID.1728	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1728	Integer	0
ibdot1sOperMstID.1729	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1729	Integer	0
ibdot1sOperMstID.1730	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1730	Integer	0
ibdot1sOperMstID.1731	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1731	Integer	0
ibdot1sOperMstID.1732	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1732	Integer	0
ibdot1sOperMstID.1733	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1733	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.1734	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1734	Integer	0
ibdot1sOperMstID.1735	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1735	Integer	0
ibdot1sOperMstID.1736	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1736	Integer	0
ibdot1sOperMstID.1737	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1737	Integer	0
ibdot1sOperMstID.1738	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1738	Integer	0
ibdot1sOperMstID.1739	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1739	Integer	0
ibdot1sOperMstID.1740	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1740	Integer	0
ibdot1sOperMstID.1741	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1741	Integer	0
ibdot1sOperMstID.1742	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1742	Integer	0
ibdot1sOperMstID.1743	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1743	Integer	0
ibdot1sOperMstID.1744	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1744	Integer	0
ibdot1sOperMstID.1745	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1745	Integer	0
ibdot1sOperMstID.1746	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1746	Integer	0
ibdot1sOperMstID.1747	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1747	Integer	0
ibdot1sOperMstID.1748	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1748	Integer	0
ibdot1sOperMstID.1749	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1749	Integer	0
ibdot1sOperMstID.1750	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1750	Integer	0
ibdot1sOperMstID.1751	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1751	Integer	0
ibdot1sOperMstID.1752	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1752	Integer	0
ibdot1sOperMstID.1753	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1753	Integer	0
ibdot1sOperMstID.1754	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1754	Integer	0
ibdot1sOperMstID.1755	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1755	Integer	0
ibdot1sOperMstID.1756	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1756	Integer	0
ibdot1sOperMstID.1757	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1757	Integer	0
ibdot1sOperMstID.1758	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1758	Integer	0
ibdot1sOperMstID.1759	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1759	Integer	0
ibdot1sOperMstID.1760	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1760	Integer	0
ibdot1sOperMstID.1761	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1761	Integer	0
ibdot1sOperMstID.1762	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1762	Integer	0
ibdot1sOperMstID.1763	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1763	Integer	0
ibdot1sOperMstID.1764	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1764	Integer	0
ibdot1sOperMstID.1765	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1765	Integer	0
ibdot1sOperMstID.1766	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1766	Integer	0
ibdot1sOperMstID.1767	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1767	Integer	0
ibdot1sOperMstID.1768	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1768	Integer	0
ibdot1sOperMstID.1769	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1769	Integer	0
ibdot1sOperMstID.1770	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1770	Integer	0
ibdot1sOperMstID.1771	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1771	Integer	0
ibdot1sOperMstID.1772	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1772	Integer	0
ibdot1sOperMstID.1773	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1773	Integer	0
ibdot1sOperMstID.1774	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1774	Integer	0
ibdot1sOperMstID.1775	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1775	Integer	0
ibdot1sOperMstID.1776	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1776	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.1777	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1777	Integer	0
ibdot1sOperMstID.1778	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1778	Integer	0
ibdot1sOperMstID.1779	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1779	Integer	0
ibdot1sOperMstID.1780	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1780	Integer	0
ibdot1sOperMstID.1781	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1781	Integer	0
ibdot1sOperMstID.1782	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1782	Integer	0
ibdot1sOperMstID.1783	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1783	Integer	0
ibdot1sOperMstID.1784	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1784	Integer	0
ibdot1sOperMstID.1785	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1785	Integer	0
ibdot1sOperMstID.1786	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1786	Integer	0
ibdot1sOperMstID.1787	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1787	Integer	0
ibdot1sOperMstID.1788	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1788	Integer	0
ibdot1sOperMstID.1789	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1789	Integer	0
ibdot1sOperMstID.1790	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1790	Integer	0
ibdot1sOperMstID.1791	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1791	Integer	0
ibdot1sOperMstID.1792	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1792	Integer	0
ibdot1sOperMstID.1793	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1793	Integer	0
ibdot1sOperMstID.1794	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1794	Integer	0
ibdot1sOperMstID.1795	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1795	Integer	0
ibdot1sOperMstID.1796	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1796	Integer	0
ibdot1sOperMstID.1797	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1797	Integer	0
ibdot1sOperMstID.1798	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1798	Integer	0
ibdot1sOperMstID.1799	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1799	Integer	0
ibdot1sOperMstID.1800	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1800	Integer	0
ibdot1sOperMstID.1801	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1801	Integer	0
ibdot1sOperMstID.1802	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1802	Integer	0
ibdot1sOperMstID.1803	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1803	Integer	0
ibdot1sOperMstID.1804	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1804	Integer	0
ibdot1sOperMstID.1805	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1805	Integer	0
ibdot1sOperMstID.1806	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1806	Integer	0
ibdot1sOperMstID.1807	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1807	Integer	0
ibdot1sOperMstID.1808	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1808	Integer	0
ibdot1sOperMstID.1809	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1809	Integer	0
ibdot1sOperMstID.1810	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1810	Integer	0
ibdot1sOperMstID.1811	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1811	Integer	0
ibdot1sOperMstID.1812	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1812	Integer	0
ibdot1sOperMstID.1813	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1813	Integer	0
ibdot1sOperMstID.1814	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1814	Integer	0
ibdot1sOperMstID.1815	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1815	Integer	0
ibdot1sOperMstID.1816	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1816	Integer	0
ibdot1sOperMstID.1817	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1817	Integer	0
ibdot1sOperMstID.1818	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1818	Integer	0
ibdot1sOperMstID.1819	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1819	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.1820	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1820	Integer	0
ibdot1sOperMstID.1821	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1821	Integer	0
ibdot1sOperMstID.1822	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1822	Integer	0
ibdot1sOperMstID.1823	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1823	Integer	0
ibdot1sOperMstID.1824	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1824	Integer	0
ibdot1sOperMstID.1825	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1825	Integer	0
ibdot1sOperMstID.1826	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1826	Integer	0
ibdot1sOperMstID.1827	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1827	Integer	0
ibdot1sOperMstID.1828	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1828	Integer	0
ibdot1sOperMstID.1829	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1829	Integer	0
ibdot1sOperMstID.1830	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1830	Integer	0
ibdot1sOperMstID.1831	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1831	Integer	0
ibdot1sOperMstID.1832	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1832	Integer	0
ibdot1sOperMstID.1833	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1833	Integer	0
ibdot1sOperMstID.1834	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1834	Integer	0
ibdot1sOperMstID.1835	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1835	Integer	0
ibdot1sOperMstID.1836	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1836	Integer	0
ibdot1sOperMstID.1837	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1837	Integer	0
ibdot1sOperMstID.1838	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1838	Integer	0
ibdot1sOperMstID.1839	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1839	Integer	0
ibdot1sOperMstID.1840	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1840	Integer	0
ibdot1sOperMstID.1841	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1841	Integer	0
ibdot1sOperMstID.1842	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1842	Integer	0
ibdot1sOperMstID.1843	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1843	Integer	0
ibdot1sOperMstID.1844	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1844	Integer	0
ibdot1sOperMstID.1845	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1845	Integer	0
ibdot1sOperMstID.1846	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1846	Integer	0
ibdot1sOperMstID.1847	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1847	Integer	0
ibdot1sOperMstID.1848	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1848	Integer	0
ibdot1sOperMstID.1849	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1849	Integer	0
ibdot1sOperMstID.1850	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1850	Integer	0
ibdot1sOperMstID.1851	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1851	Integer	0
ibdot1sOperMstID.1852	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1852	Integer	0
ibdot1sOperMstID.1853	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1853	Integer	0
ibdot1sOperMstID.1854	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1854	Integer	0
ibdot1sOperMstID.1855	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1855	Integer	0
ibdot1sOperMstID.1856	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1856	Integer	0
ibdot1sOperMstID.1857	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1857	Integer	0
ibdot1sOperMstID.1858	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1858	Integer	0
ibdot1sOperMstID.1859	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1859	Integer	0
ibdot1sOperMstID.1860	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1860	Integer	0
ibdot1sOperMstID.1861	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1861	Integer	0
ibdot1sOperMstID.1862	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1862	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.1863	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1863	Integer	0
ibdot1sOperMstID.1864	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1864	Integer	0
ibdot1sOperMstID.1865	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1865	Integer	0
ibdot1sOperMstID.1866	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1866	Integer	0
ibdot1sOperMstID.1867	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1867	Integer	0
ibdot1sOperMstID.1868	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1868	Integer	0
ibdot1sOperMstID.1869	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1869	Integer	0
ibdot1sOperMstID.1870	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1870	Integer	0
ibdot1sOperMstID.1871	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1871	Integer	0
ibdot1sOperMstID.1872	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1872	Integer	0
ibdot1sOperMstID.1873	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1873	Integer	0
ibdot1sOperMstID.1874	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1874	Integer	0
ibdot1sOperMstID.1875	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1875	Integer	0
ibdot1sOperMstID.1876	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1876	Integer	0
ibdot1sOperMstID.1877	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1877	Integer	0
ibdot1sOperMstID.1878	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1878	Integer	0
ibdot1sOperMstID.1879	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1879	Integer	0
ibdot1sOperMstID.1880	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1880	Integer	0
ibdot1sOperMstID.1881	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1881	Integer	0
ibdot1sOperMstID.1882	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1882	Integer	0
ibdot1sOperMstID.1883	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1883	Integer	0
ibdot1sOperMstID.1884	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1884	Integer	0
ibdot1sOperMstID.1885	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1885	Integer	0
ibdot1sOperMstID.1886	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1886	Integer	0
ibdot1sOperMstID.1887	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1887	Integer	0
ibdot1sOperMstID.1888	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1888	Integer	0
ibdot1sOperMstID.1889	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1889	Integer	0
ibdot1sOperMstID.1890	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1890	Integer	0
ibdot1sOperMstID.1891	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1891	Integer	0
ibdot1sOperMstID.1892	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1892	Integer	0
ibdot1sOperMstID.1893	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1893	Integer	0
ibdot1sOperMstID.1894	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1894	Integer	0
ibdot1sOperMstID.1895	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1895	Integer	0
ibdot1sOperMstID.1896	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1896	Integer	0
ibdot1sOperMstID.1897	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1897	Integer	0
ibdot1sOperMstID.1898	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1898	Integer	0
ibdot1sOperMstID.1899	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1899	Integer	0
ibdot1sOperMstID.1900	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1900	Integer	0
ibdot1sOperMstID.1901	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1901	Integer	0
ibdot1sOperMstID.1902	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1902	Integer	0
ibdot1sOperMstID.1903	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1903	Integer	0
ibdot1sOperMstID.1904	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1904	Integer	0
ibdot1sOperMstID.1905	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1905	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.1906	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1906	Integer	0
ibdot1sOperMstID.1907	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1907	Integer	0
ibdot1sOperMstID.1908	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1908	Integer	0
ibdot1sOperMstID.1909	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1909	Integer	0
ibdot1sOperMstID.1910	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1910	Integer	0
ibdot1sOperMstID.1911	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1911	Integer	0
ibdot1sOperMstID.1912	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1912	Integer	0
ibdot1sOperMstID.1913	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1913	Integer	0
ibdot1sOperMstID.1914	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1914	Integer	0
ibdot1sOperMstID.1915	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1915	Integer	0
ibdot1sOperMstID.1916	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1916	Integer	0
ibdot1sOperMstID.1917	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1917	Integer	0
ibdot1sOperMstID.1918	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1918	Integer	0
ibdot1sOperMstID.1919	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1919	Integer	0
ibdot1sOperMstID.1920	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1920	Integer	0
ibdot1sOperMstID.1921	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1921	Integer	0
ibdot1sOperMstID.1922	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1922	Integer	0
ibdot1sOperMstID.1923	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1923	Integer	0
ibdot1sOperMstID.1924	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1924	Integer	0
ibdot1sOperMstID.1925	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1925	Integer	0
ibdot1sOperMstID.1926	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1926	Integer	0
ibdot1sOperMstID.1927	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1927	Integer	0
ibdot1sOperMstID.1928	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1928	Integer	0
ibdot1sOperMstID.1929	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1929	Integer	0
ibdot1sOperMstID.1930	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1930	Integer	0
ibdot1sOperMstID.1931	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1931	Integer	0
ibdot1sOperMstID.1932	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1932	Integer	0
ibdot1sOperMstID.1933	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1933	Integer	0
ibdot1sOperMstID.1934	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1934	Integer	0
ibdot1sOperMstID.1935	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1935	Integer	0
ibdot1sOperMstID.1936	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1936	Integer	0
ibdot1sOperMstID.1937	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1937	Integer	0
ibdot1sOperMstID.1938	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1938	Integer	0
ibdot1sOperMstID.1939	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1939	Integer	0
ibdot1sOperMstID.1940	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1940	Integer	0
ibdot1sOperMstID.1941	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1941	Integer	0
ibdot1sOperMstID.1942	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1942	Integer	0
ibdot1sOperMstID.1943	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1943	Integer	0
ibdot1sOperMstID.1944	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1944	Integer	0
ibdot1sOperMstID.1945	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1945	Integer	0
ibdot1sOperMstID.1946	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1946	Integer	0
ibdot1sOperMstID.1947	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1947	Integer	0
ibdot1sOperMstID.1948	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1948	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.1949	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1949	Integer	0
ibdot1sOperMstID.1950	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1950	Integer	0
ibdot1sOperMstID.1951	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1951	Integer	0
ibdot1sOperMstID.1952	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1952	Integer	0
ibdot1sOperMstID.1953	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1953	Integer	0
ibdot1sOperMstID.1954	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1954	Integer	0
ibdot1sOperMstID.1955	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1955	Integer	0
ibdot1sOperMstID.1956	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1956	Integer	0
ibdot1sOperMstID.1957	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1957	Integer	0
ibdot1sOperMstID.1958	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1958	Integer	0
ibdot1sOperMstID.1959	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1959	Integer	0
ibdot1sOperMstID.1960	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1960	Integer	0
ibdot1sOperMstID.1961	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1961	Integer	0
ibdot1sOperMstID.1962	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1962	Integer	0
ibdot1sOperMstID.1963	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1963	Integer	0
ibdot1sOperMstID.1964	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1964	Integer	0
ibdot1sOperMstID.1965	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1965	Integer	0
ibdot1sOperMstID.1966	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1966	Integer	0
ibdot1sOperMstID.1967	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1967	Integer	0
ibdot1sOperMstID.1968	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1968	Integer	0
ibdot1sOperMstID.1969	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1969	Integer	0
ibdot1sOperMstID.1970	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1970	Integer	0
ibdot1sOperMstID.1971	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1971	Integer	0
ibdot1sOperMstID.1972	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1972	Integer	0
ibdot1sOperMstID.1973	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1973	Integer	0
ibdot1sOperMstID.1974	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1974	Integer	0
ibdot1sOperMstID.1975	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1975	Integer	0
ibdot1sOperMstID.1976	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1976	Integer	0
ibdot1sOperMstID.1977	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1977	Integer	0
ibdot1sOperMstID.1978	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1978	Integer	0
ibdot1sOperMstID.1979	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1979	Integer	0
ibdot1sOperMstID.1980	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1980	Integer	0
ibdot1sOperMstID.1981	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1981	Integer	0
ibdot1sOperMstID.1982	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1982	Integer	0
ibdot1sOperMstID.1983	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1983	Integer	0
ibdot1sOperMstID.1984	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1984	Integer	0
ibdot1sOperMstID.1985	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1985	Integer	0
ibdot1sOperMstID.1986	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1986	Integer	0
ibdot1sOperMstID.1987	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1987	Integer	0
ibdot1sOperMstID.1988	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1988	Integer	0
ibdot1sOperMstID.1989	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1989	Integer	0
ibdot1sOperMstID.1990	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1990	Integer	0
ibdot1sOperMstID.1991	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1991	Integer	0



Name	OID	Value Type	Value Example
ibdot1sOperMstID.1992	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1992	Integer	0
ibdot1sOperMstID.1993	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1993	Integer	0
ibdot1sOperMstID.1994	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1994	Integer	0
ibdot1sOperMstID.1995	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1995	Integer	0
ibdot1sOperMstID.1996	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1996	Integer	0
ibdot1sOperMstID.1997	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1997	Integer	0
ibdot1sOperMstID.1998	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1998	Integer	0
ibdot1sOperMstID.1999	.1.3.6.1.4.1.26138.8.35.14.18.1.3.1999	Integer	0
ibdot1sOperMstID.2000	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2000	Integer	0
ibdot1sOperMstID.2001	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2001	Integer	0
ibdot1sOperMstID.2002	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2002	Integer	0
ibdot1sOperMstID.2003	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2003	Integer	0
ibdot1sOperMstID.2004	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2004	Integer	0
ibdot1sOperMstID.2005	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2005	Integer	0
ibdot1sOperMstID.2006	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2006	Integer	0
ibdot1sOperMstID.2007	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2007	Integer	0
ibdot1sOperMstID.2008	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2008	Integer	0
ibdot1sOperMstID.2009	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2009	Integer	0
ibdot1sOperMstID.2010	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2010	Integer	0
ibdot1sOperMstID.2011	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2011	Integer	0
ibdot1sOperMstID.2012	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2012	Integer	0
ibdot1sOperMstID.2013	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2013	Integer	0
ibdot1sOperMstID.2014	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2014	Integer	0
ibdot1sOperMstID.2015	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2015	Integer	0
ibdot1sOperMstID.2016	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2016	Integer	0
ibdot1sOperMstID.2017	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2017	Integer	0
ibdot1sOperMstID.2018	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2018	Integer	0
ibdot1sOperMstID.2019	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2019	Integer	0
ibdot1sOperMstID.2020	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2020	Integer	0
ibdot1sOperMstID.2021	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2021	Integer	0
ibdot1sOperMstID.2022	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2022	Integer	0
ibdot1sOperMstID.2023	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2023	Integer	0
ibdot1sOperMstID.2024	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2024	Integer	0
ibdot1sOperMstID.2025	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2025	Integer	0
ibdot1sOperMstID.2026	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2026	Integer	0
ibdot1sOperMstID.2027	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2027	Integer	0
ibdot1sOperMstID.2028	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2028	Integer	0
ibdot1sOperMstID.2029	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2029	Integer	0
ibdot1sOperMstID.2030	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2030	Integer	0
ibdot1sOperMstID.2031	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2031	Integer	0
ibdot1sOperMstID.2032	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2032	Integer	0
ibdot1sOperMstID.2033	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2033	Integer	0
ibdot1sOperMstID.2034	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2034	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.2035	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2035	Integer	0
ibdot1sOperMstID.2036	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2036	Integer	0
ibdot1sOperMstID.2037	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2037	Integer	0
ibdot1sOperMstID.2038	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2038	Integer	0
ibdot1sOperMstID.2039	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2039	Integer	0
ibdot1sOperMstID.2040	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2040	Integer	0
ibdot1sOperMstID.2041	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2041	Integer	0
ibdot1sOperMstID.2042	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2042	Integer	0
ibdot1sOperMstID.2043	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2043	Integer	0
ibdot1sOperMstID.2044	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2044	Integer	0
ibdot1sOperMstID.2045	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2045	Integer	0
ibdot1sOperMstID.2046	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2046	Integer	0
ibdot1sOperMstID.2047	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2047	Integer	0
ibdot1sOperMstID.2048	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2048	Integer	0
ibdot1sOperMstID.2049	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2049	Integer	0
ibdot1sOperMstID.2050	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2050	Integer	0
ibdot1sOperMstID.2051	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2051	Integer	0
ibdot1sOperMstID.2052	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2052	Integer	0
ibdot1sOperMstID.2053	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2053	Integer	0
ibdot1sOperMstID.2054	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2054	Integer	0
ibdot1sOperMstID.2055	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2055	Integer	0
ibdot1sOperMstID.2056	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2056	Integer	0
ibdot1sOperMstID.2057	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2057	Integer	0
ibdot1sOperMstID.2058	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2058	Integer	0
ibdot1sOperMstID.2059	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2059	Integer	0
ibdot1sOperMstID.2060	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2060	Integer	0
ibdot1sOperMstID.2061	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2061	Integer	0
ibdot1sOperMstID.2062	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2062	Integer	0
ibdot1sOperMstID.2063	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2063	Integer	0
ibdot1sOperMstID.2064	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2064	Integer	0
ibdot1sOperMstID.2065	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2065	Integer	0
ibdot1sOperMstID.2066	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2066	Integer	0
ibdot1sOperMstID.2067	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2067	Integer	0
ibdot1sOperMstID.2068	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2068	Integer	0
ibdot1sOperMstID.2069	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2069	Integer	0
ibdot1sOperMstID.2070	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2070	Integer	0
ibdot1sOperMstID.2071	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2071	Integer	0
ibdot1sOperMstID.2072	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2072	Integer	0
ibdot1sOperMstID.2073	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2073	Integer	0
ibdot1sOperMstID.2074	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2074	Integer	0
ibdot1sOperMstID.2075	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2075	Integer	0
ibdot1sOperMstID.2076	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2076	Integer	0
ibdot1sOperMstID.2077	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2077	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.2078	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2078	Integer	0
ibdot1sOperMstID.2079	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2079	Integer	0
ibdot1sOperMstID.2080	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2080	Integer	0
ibdot1sOperMstID.2081	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2081	Integer	0
ibdot1sOperMstID.2082	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2082	Integer	0
ibdot1sOperMstID.2083	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2083	Integer	0
ibdot1sOperMstID.2084	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2084	Integer	0
ibdot1sOperMstID.2085	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2085	Integer	0
ibdot1sOperMstID.2086	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2086	Integer	0
ibdot1sOperMstID.2087	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2087	Integer	0
ibdot1sOperMstID.2088	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2088	Integer	0
ibdot1sOperMstID.2089	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2089	Integer	0
ibdot1sOperMstID.2090	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2090	Integer	0
ibdot1sOperMstID.2091	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2091	Integer	0
ibdot1sOperMstID.2092	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2092	Integer	0
ibdot1sOperMstID.2093	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2093	Integer	0
ibdot1sOperMstID.2094	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2094	Integer	0
ibdot1sOperMstID.2095	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2095	Integer	0
ibdot1sOperMstID.2096	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2096	Integer	0
ibdot1sOperMstID.2097	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2097	Integer	0
ibdot1sOperMstID.2098	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2098	Integer	0
ibdot1sOperMstID.2099	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2099	Integer	0
ibdot1sOperMstID.2100	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2100	Integer	0
ibdot1sOperMstID.2101	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2101	Integer	0
ibdot1sOperMstID.2102	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2102	Integer	0
ibdot1sOperMstID.2103	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2103	Integer	0
ibdot1sOperMstID.2104	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2104	Integer	0
ibdot1sOperMstID.2105	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2105	Integer	0
ibdot1sOperMstID.2106	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2106	Integer	0
ibdot1sOperMstID.2107	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2107	Integer	0
ibdot1sOperMstID.2108	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2108	Integer	0
ibdot1sOperMstID.2109	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2109	Integer	0
ibdot1sOperMstID.2110	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2110	Integer	0
ibdot1sOperMstID.2111	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2111	Integer	0
ibdot1sOperMstID.2112	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2112	Integer	0
ibdot1sOperMstID.2113	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2113	Integer	0
ibdot1sOperMstID.2114	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2114	Integer	0
ibdot1sOperMstID.2115	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2115	Integer	0
ibdot1sOperMstID.2116	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2116	Integer	0
ibdot1sOperMstID.2117	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2117	Integer	0
ibdot1sOperMstID.2118	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2118	Integer	0
ibdot1sOperMstID.2119	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2119	Integer	0
ibdot1sOperMstID.2120	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2120	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.2121	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2121	Integer	0
ibdot1sOperMstID.2122	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2122	Integer	0
ibdot1sOperMstID.2123	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2123	Integer	0
ibdot1sOperMstID.2124	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2124	Integer	0
ibdot1sOperMstID.2125	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2125	Integer	0
ibdot1sOperMstID.2126	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2126	Integer	0
ibdot1sOperMstID.2127	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2127	Integer	0
ibdot1sOperMstID.2128	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2128	Integer	0
ibdot1sOperMstID.2129	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2129	Integer	0
ibdot1sOperMstID.2130	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2130	Integer	0
ibdot1sOperMstID.2131	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2131	Integer	0
ibdot1sOperMstID.2132	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2132	Integer	0
ibdot1sOperMstID.2133	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2133	Integer	0
ibdot1sOperMstID.2134	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2134	Integer	0
ibdot1sOperMstID.2135	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2135	Integer	0
ibdot1sOperMstID.2136	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2136	Integer	0
ibdot1sOperMstID.2137	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2137	Integer	0
ibdot1sOperMstID.2138	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2138	Integer	0
ibdot1sOperMstID.2139	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2139	Integer	0
ibdot1sOperMstID.2140	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2140	Integer	0
ibdot1sOperMstID.2141	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2141	Integer	0
ibdot1sOperMstID.2142	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2142	Integer	0
ibdot1sOperMstID.2143	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2143	Integer	0
ibdot1sOperMstID.2144	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2144	Integer	0
ibdot1sOperMstID.2145	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2145	Integer	0
ibdot1sOperMstID.2146	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2146	Integer	0
ibdot1sOperMstID.2147	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2147	Integer	0
ibdot1sOperMstID.2148	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2148	Integer	0
ibdot1sOperMstID.2149	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2149	Integer	0
ibdot1sOperMstID.2150	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2150	Integer	0
ibdot1sOperMstID.2151	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2151	Integer	0
ibdot1sOperMstID.2152	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2152	Integer	0
ibdot1sOperMstID.2153	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2153	Integer	0
ibdot1sOperMstID.2154	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2154	Integer	0
ibdot1sOperMstID.2155	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2155	Integer	0
ibdot1sOperMstID.2156	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2156	Integer	0
ibdot1sOperMstID.2157	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2157	Integer	0
ibdot1sOperMstID.2158	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2158	Integer	0
ibdot1sOperMstID.2159	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2159	Integer	0
ibdot1sOperMstID.2160	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2160	Integer	0
ibdot1sOperMstID.2161	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2161	Integer	0
ibdot1sOperMstID.2162	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2162	Integer	0
ibdot1sOperMstID.2163	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2163	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.2164	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2164	Integer	0
ibdot1sOperMstID.2165	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2165	Integer	0
ibdot1sOperMstID.2166	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2166	Integer	0
ibdot1sOperMstID.2167	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2167	Integer	0
ibdot1sOperMstID.2168	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2168	Integer	0
ibdot1sOperMstID.2169	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2169	Integer	0
ibdot1sOperMstID.2170	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2170	Integer	0
ibdot1sOperMstID.2171	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2171	Integer	0
ibdot1sOperMstID.2172	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2172	Integer	0
ibdot1sOperMstID.2173	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2173	Integer	0
ibdot1sOperMstID.2174	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2174	Integer	0
ibdot1sOperMstID.2175	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2175	Integer	0
ibdot1sOperMstID.2176	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2176	Integer	0
ibdot1sOperMstID.2177	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2177	Integer	0
ibdot1sOperMstID.2178	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2178	Integer	0
ibdot1sOperMstID.2179	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2179	Integer	0
ibdot1sOperMstID.2180	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2180	Integer	0
ibdot1sOperMstID.2181	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2181	Integer	0
ibdot1sOperMstID.2182	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2182	Integer	0
ibdot1sOperMstID.2183	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2183	Integer	0
ibdot1sOperMstID.2184	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2184	Integer	0
ibdot1sOperMstID.2185	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2185	Integer	0
ibdot1sOperMstID.2186	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2186	Integer	0
ibdot1sOperMstID.2187	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2187	Integer	0
ibdot1sOperMstID.2188	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2188	Integer	0
ibdot1sOperMstID.2189	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2189	Integer	0
ibdot1sOperMstID.2190	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2190	Integer	0
ibdot1sOperMstID.2191	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2191	Integer	0
ibdot1sOperMstID.2192	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2192	Integer	0
ibdot1sOperMstID.2193	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2193	Integer	0
ibdot1sOperMstID.2194	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2194	Integer	0
ibdot1sOperMstID.2195	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2195	Integer	0
ibdot1sOperMstID.2196	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2196	Integer	0
ibdot1sOperMstID.2197	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2197	Integer	0
ibdot1sOperMstID.2198	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2198	Integer	0
ibdot1sOperMstID.2199	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2199	Integer	0
ibdot1sOperMstID.2200	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2200	Integer	0
ibdot1sOperMstID.2201	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2201	Integer	0
ibdot1sOperMstID.2202	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2202	Integer	0
ibdot1sOperMstID.2203	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2203	Integer	0
ibdot1sOperMstID.2204	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2204	Integer	0
ibdot1sOperMstID.2205	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2205	Integer	0
ibdot1sOperMstID.2206	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2206	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.2207	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2207	Integer	0
ibdot1sOperMstID.2208	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2208	Integer	0
ibdot1sOperMstID.2209	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2209	Integer	0
ibdot1sOperMstID.2210	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2210	Integer	0
ibdot1sOperMstID.2211	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2211	Integer	0
ibdot1sOperMstID.2212	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2212	Integer	0
ibdot1sOperMstID.2213	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2213	Integer	0
ibdot1sOperMstID.2214	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2214	Integer	0
ibdot1sOperMstID.2215	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2215	Integer	0
ibdot1sOperMstID.2216	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2216	Integer	0
ibdot1sOperMstID.2217	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2217	Integer	0
ibdot1sOperMstID.2218	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2218	Integer	0
ibdot1sOperMstID.2219	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2219	Integer	0
ibdot1sOperMstID.2220	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2220	Integer	0
ibdot1sOperMstID.2221	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2221	Integer	0
ibdot1sOperMstID.2222	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2222	Integer	0
ibdot1sOperMstID.2223	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2223	Integer	0
ibdot1sOperMstID.2224	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2224	Integer	0
ibdot1sOperMstID.2225	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2225	Integer	0
ibdot1sOperMstID.2226	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2226	Integer	0
ibdot1sOperMstID.2227	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2227	Integer	0
ibdot1sOperMstID.2228	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2228	Integer	0
ibdot1sOperMstID.2229	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2229	Integer	0
ibdot1sOperMstID.2230	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2230	Integer	0
ibdot1sOperMstID.2231	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2231	Integer	0
ibdot1sOperMstID.2232	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2232	Integer	0
ibdot1sOperMstID.2233	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2233	Integer	0
ibdot1sOperMstID.2234	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2234	Integer	0
ibdot1sOperMstID.2235	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2235	Integer	0
ibdot1sOperMstID.2236	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2236	Integer	0
ibdot1sOperMstID.2237	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2237	Integer	0
ibdot1sOperMstID.2238	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2238	Integer	0
ibdot1sOperMstID.2239	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2239	Integer	0
ibdot1sOperMstID.2240	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2240	Integer	0
ibdot1sOperMstID.2241	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2241	Integer	0
ibdot1sOperMstID.2242	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2242	Integer	0
ibdot1sOperMstID.2243	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2243	Integer	0
ibdot1sOperMstID.2244	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2244	Integer	0
ibdot1sOperMstID.2245	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2245	Integer	0
ibdot1sOperMstID.2246	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2246	Integer	0
ibdot1sOperMstID.2247	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2247	Integer	0
ibdot1sOperMstID.2248	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2248	Integer	0
ibdot1sOperMstID.2249	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2249	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.2250	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2250	Integer	0
ibdot1sOperMstID.2251	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2251	Integer	0
ibdot1sOperMstID.2252	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2252	Integer	0
ibdot1sOperMstID.2253	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2253	Integer	0
ibdot1sOperMstID.2254	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2254	Integer	0
ibdot1sOperMstID.2255	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2255	Integer	0
ibdot1sOperMstID.2256	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2256	Integer	0
ibdot1sOperMstID.2257	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2257	Integer	0
ibdot1sOperMstID.2258	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2258	Integer	0
ibdot1sOperMstID.2259	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2259	Integer	0
ibdot1sOperMstID.2260	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2260	Integer	0
ibdot1sOperMstID.2261	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2261	Integer	0
ibdot1sOperMstID.2262	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2262	Integer	0
ibdot1sOperMstID.2263	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2263	Integer	0
ibdot1sOperMstID.2264	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2264	Integer	0
ibdot1sOperMstID.2265	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2265	Integer	0
ibdot1sOperMstID.2266	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2266	Integer	0
ibdot1sOperMstID.2267	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2267	Integer	0
ibdot1sOperMstID.2268	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2268	Integer	0
ibdot1sOperMstID.2269	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2269	Integer	0
ibdot1sOperMstID.2270	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2270	Integer	0
ibdot1sOperMstID.2271	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2271	Integer	0
ibdot1sOperMstID.2272	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2272	Integer	0
ibdot1sOperMstID.2273	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2273	Integer	0
ibdot1sOperMstID.2274	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2274	Integer	0
ibdot1sOperMstID.2275	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2275	Integer	0
ibdot1sOperMstID.2276	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2276	Integer	0
ibdot1sOperMstID.2277	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2277	Integer	0
ibdot1sOperMstID.2278	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2278	Integer	0
ibdot1sOperMstID.2279	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2279	Integer	0
ibdot1sOperMstID.2280	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2280	Integer	0
ibdot1sOperMstID.2281	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2281	Integer	0
ibdot1sOperMstID.2282	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2282	Integer	0
ibdot1sOperMstID.2283	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2283	Integer	0
ibdot1sOperMstID.2284	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2284	Integer	0
ibdot1sOperMstID.2285	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2285	Integer	0
ibdot1sOperMstID.2286	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2286	Integer	0
ibdot1sOperMstID.2287	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2287	Integer	0
ibdot1sOperMstID.2288	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2288	Integer	0
ibdot1sOperMstID.2289	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2289	Integer	0
ibdot1sOperMstID.2290	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2290	Integer	0
ibdot1sOperMstID.2291	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2291	Integer	0
ibdot1sOperMstID.2292	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2292	Integer	0



Name	OID	Value Type	Value Example
ibdot1sOperMstID.2293	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2293	Integer	0
ibdot1sOperMstID.2294	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2294	Integer	0
ibdot1sOperMstID.2295	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2295	Integer	0
ibdot1sOperMstID.2296	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2296	Integer	0
ibdot1sOperMstID.2297	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2297	Integer	0
ibdot1sOperMstID.2298	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2298	Integer	0
ibdot1sOperMstID.2299	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2299	Integer	0
ibdot1sOperMstID.2300	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2300	Integer	0
ibdot1sOperMstID.2301	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2301	Integer	0
ibdot1sOperMstID.2302	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2302	Integer	0
ibdot1sOperMstID.2303	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2303	Integer	0
ibdot1sOperMstID.2304	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2304	Integer	0
ibdot1sOperMstID.2305	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2305	Integer	0
ibdot1sOperMstID.2306	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2306	Integer	0
ibdot1sOperMstID.2307	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2307	Integer	0
ibdot1sOperMstID.2308	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2308	Integer	0
ibdot1sOperMstID.2309	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2309	Integer	0
ibdot1sOperMstID.2310	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2310	Integer	0
ibdot1sOperMstID.2311	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2311	Integer	0
ibdot1sOperMstID.2312	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2312	Integer	0
ibdot1sOperMstID.2313	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2313	Integer	0
ibdot1sOperMstID.2314	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2314	Integer	0
ibdot1sOperMstID.2315	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2315	Integer	0
ibdot1sOperMstID.2316	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2316	Integer	0
ibdot1sOperMstID.2317	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2317	Integer	0
ibdot1sOperMstID.2318	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2318	Integer	0
ibdot1sOperMstID.2319	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2319	Integer	0
ibdot1sOperMstID.2320	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2320	Integer	0
ibdot1sOperMstID.2321	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2321	Integer	0
ibdot1sOperMstID.2322	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2322	Integer	0
ibdot1sOperMstID.2323	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2323	Integer	0
ibdot1sOperMstID.2324	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2324	Integer	0
ibdot1sOperMstID.2325	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2325	Integer	0
ibdot1sOperMstID.2326	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2326	Integer	0
ibdot1sOperMstID.2327	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2327	Integer	0
ibdot1sOperMstID.2328	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2328	Integer	0
ibdot1sOperMstID.2329	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2329	Integer	0
ibdot1sOperMstID.2330	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2330	Integer	0
ibdot1sOperMstID.2331	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2331	Integer	0
ibdot1sOperMstID.2332	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2332	Integer	0
ibdot1sOperMstID.2333	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2333	Integer	0
ibdot1sOperMstID.2334	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2334	Integer	0
ibdot1sOperMstID.2335	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2335	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.2336	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2336	Integer	0
ibdot1sOperMstID.2337	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2337	Integer	0
ibdot1sOperMstID.2338	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2338	Integer	0
ibdot1sOperMstID.2339	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2339	Integer	0
ibdot1sOperMstID.2340	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2340	Integer	0
ibdot1sOperMstID.2341	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2341	Integer	0
ibdot1sOperMstID.2342	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2342	Integer	0
ibdot1sOperMstID.2343	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2343	Integer	0
ibdot1sOperMstID.2344	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2344	Integer	0
ibdot1sOperMstID.2345	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2345	Integer	0
ibdot1sOperMstID.2346	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2346	Integer	0
ibdot1sOperMstID.2347	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2347	Integer	0
ibdot1sOperMstID.2348	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2348	Integer	0
ibdot1sOperMstID.2349	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2349	Integer	0
ibdot1sOperMstID.2350	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2350	Integer	0
ibdot1sOperMstID.2351	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2351	Integer	0
ibdot1sOperMstID.2352	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2352	Integer	0
ibdot1sOperMstID.2353	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2353	Integer	0
ibdot1sOperMstID.2354	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2354	Integer	0
ibdot1sOperMstID.2355	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2355	Integer	0
ibdot1sOperMstID.2356	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2356	Integer	0
ibdot1sOperMstID.2357	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2357	Integer	0
ibdot1sOperMstID.2358	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2358	Integer	0
ibdot1sOperMstID.2359	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2359	Integer	0
ibdot1sOperMstID.2360	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2360	Integer	0
ibdot1sOperMstID.2361	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2361	Integer	0
ibdot1sOperMstID.2362	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2362	Integer	0
ibdot1sOperMstID.2363	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2363	Integer	0
ibdot1sOperMstID.2364	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2364	Integer	0
ibdot1sOperMstID.2365	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2365	Integer	0
ibdot1sOperMstID.2366	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2366	Integer	0
ibdot1sOperMstID.2367	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2367	Integer	0
ibdot1sOperMstID.2368	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2368	Integer	0
ibdot1sOperMstID.2369	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2369	Integer	0
ibdot1sOperMstID.2370	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2370	Integer	0
ibdot1sOperMstID.2371	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2371	Integer	0
ibdot1sOperMstID.2372	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2372	Integer	0
ibdot1sOperMstID.2373	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2373	Integer	0
ibdot1sOperMstID.2374	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2374	Integer	0
ibdot1sOperMstID.2375	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2375	Integer	0
ibdot1sOperMstID.2376	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2376	Integer	0
ibdot1sOperMstID.2377	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2377	Integer	0
ibdot1sOperMstID.2378	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2378	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.2379	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2379	Integer	0
ibdot1sOperMstID.2380	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2380	Integer	0
ibdot1sOperMstID.2381	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2381	Integer	0
ibdot1sOperMstID.2382	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2382	Integer	0
ibdot1sOperMstID.2383	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2383	Integer	0
ibdot1sOperMstID.2384	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2384	Integer	0
ibdot1sOperMstID.2385	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2385	Integer	0
ibdot1sOperMstID.2386	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2386	Integer	0
ibdot1sOperMstID.2387	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2387	Integer	0
ibdot1sOperMstID.2388	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2388	Integer	0
ibdot1sOperMstID.2389	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2389	Integer	0
ibdot1sOperMstID.2390	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2390	Integer	0
ibdot1sOperMstID.2391	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2391	Integer	0
ibdot1sOperMstID.2392	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2392	Integer	0
ibdot1sOperMstID.2393	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2393	Integer	0
ibdot1sOperMstID.2394	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2394	Integer	0
ibdot1sOperMstID.2395	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2395	Integer	0
ibdot1sOperMstID.2396	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2396	Integer	0
ibdot1sOperMstID.2397	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2397	Integer	0
ibdot1sOperMstID.2398	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2398	Integer	0
ibdot1sOperMstID.2399	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2399	Integer	0
ibdot1sOperMstID.2400	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2400	Integer	0
ibdot1sOperMstID.2401	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2401	Integer	0
ibdot1sOperMstID.2402	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2402	Integer	0
ibdot1sOperMstID.2403	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2403	Integer	0
ibdot1sOperMstID.2404	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2404	Integer	0
ibdot1sOperMstID.2405	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2405	Integer	0
ibdot1sOperMstID.2406	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2406	Integer	0
ibdot1sOperMstID.2407	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2407	Integer	0
ibdot1sOperMstID.2408	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2408	Integer	0
ibdot1sOperMstID.2409	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2409	Integer	0
ibdot1sOperMstID.2410	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2410	Integer	0
ibdot1sOperMstID.2411	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2411	Integer	0
ibdot1sOperMstID.2412	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2412	Integer	0
ibdot1sOperMstID.2413	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2413	Integer	0
ibdot1sOperMstID.2414	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2414	Integer	0
ibdot1sOperMstID.2415	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2415	Integer	0
ibdot1sOperMstID.2416	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2416	Integer	0
ibdot1sOperMstID.2417	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2417	Integer	0
ibdot1sOperMstID.2418	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2418	Integer	0
ibdot1sOperMstID.2419	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2419	Integer	0
ibdot1sOperMstID.2420	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2420	Integer	0
ibdot1sOperMstID.2421	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2421	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.2422	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2422	Integer	0
ibdot1sOperMstID.2423	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2423	Integer	0
ibdot1sOperMstID.2424	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2424	Integer	0
ibdot1sOperMstID.2425	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2425	Integer	0
ibdot1sOperMstID.2426	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2426	Integer	0
ibdot1sOperMstID.2427	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2427	Integer	0
ibdot1sOperMstID.2428	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2428	Integer	0
ibdot1sOperMstID.2429	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2429	Integer	0
ibdot1sOperMstID.2430	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2430	Integer	0
ibdot1sOperMstID.2431	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2431	Integer	0
ibdot1sOperMstID.2432	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2432	Integer	0
ibdot1sOperMstID.2433	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2433	Integer	0
ibdot1sOperMstID.2434	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2434	Integer	0
ibdot1sOperMstID.2435	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2435	Integer	0
ibdot1sOperMstID.2436	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2436	Integer	0
ibdot1sOperMstID.2437	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2437	Integer	0
ibdot1sOperMstID.2438	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2438	Integer	0
ibdot1sOperMstID.2439	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2439	Integer	0
ibdot1sOperMstID.2440	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2440	Integer	0
ibdot1sOperMstID.2441	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2441	Integer	0
ibdot1sOperMstID.2442	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2442	Integer	0
ibdot1sOperMstID.2443	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2443	Integer	0
ibdot1sOperMstID.2444	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2444	Integer	0
ibdot1sOperMstID.2445	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2445	Integer	0
ibdot1sOperMstID.2446	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2446	Integer	0
ibdot1sOperMstID.2447	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2447	Integer	0
ibdot1sOperMstID.2448	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2448	Integer	0
ibdot1sOperMstID.2449	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2449	Integer	0
ibdot1sOperMstID.2450	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2450	Integer	0
ibdot1sOperMstID.2451	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2451	Integer	0
ibdot1sOperMstID.2452	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2452	Integer	0
ibdot1sOperMstID.2453	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2453	Integer	0
ibdot1sOperMstID.2454	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2454	Integer	0
ibdot1sOperMstID.2455	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2455	Integer	0
ibdot1sOperMstID.2456	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2456	Integer	0
ibdot1sOperMstID.2457	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2457	Integer	0
ibdot1sOperMstID.2458	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2458	Integer	0
ibdot1sOperMstID.2459	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2459	Integer	0
ibdot1sOperMstID.2460	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2460	Integer	0
ibdot1sOperMstID.2461	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2461	Integer	0
ibdot1sOperMstID.2462	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2462	Integer	0
ibdot1sOperMstID.2463	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2463	Integer	0
ibdot1sOperMstID.2464	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2464	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.2465	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2465	Integer	0
ibdot1sOperMstID.2466	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2466	Integer	0
ibdot1sOperMstID.2467	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2467	Integer	0
ibdot1sOperMstID.2468	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2468	Integer	0
ibdot1sOperMstID.2469	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2469	Integer	0
ibdot1sOperMstID.2470	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2470	Integer	0
ibdot1sOperMstID.2471	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2471	Integer	0
ibdot1sOperMstID.2472	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2472	Integer	0
ibdot1sOperMstID.2473	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2473	Integer	0
ibdot1sOperMstID.2474	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2474	Integer	0
ibdot1sOperMstID.2475	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2475	Integer	0
ibdot1sOperMstID.2476	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2476	Integer	0
ibdot1sOperMstID.2477	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2477	Integer	0
ibdot1sOperMstID.2478	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2478	Integer	0
ibdot1sOperMstID.2479	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2479	Integer	0
ibdot1sOperMstID.2480	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2480	Integer	0
ibdot1sOperMstID.2481	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2481	Integer	0
ibdot1sOperMstID.2482	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2482	Integer	0
ibdot1sOperMstID.2483	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2483	Integer	0
ibdot1sOperMstID.2484	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2484	Integer	0
ibdot1sOperMstID.2485	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2485	Integer	0
ibdot1sOperMstID.2486	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2486	Integer	0
ibdot1sOperMstID.2487	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2487	Integer	0
ibdot1sOperMstID.2488	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2488	Integer	0
ibdot1sOperMstID.2489	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2489	Integer	0
ibdot1sOperMstID.2490	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2490	Integer	0
ibdot1sOperMstID.2491	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2491	Integer	0
ibdot1sOperMstID.2492	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2492	Integer	0
ibdot1sOperMstID.2493	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2493	Integer	0
ibdot1sOperMstID.2494	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2494	Integer	0
ibdot1sOperMstID.2495	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2495	Integer	0
ibdot1sOperMstID.2496	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2496	Integer	0
ibdot1sOperMstID.2497	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2497	Integer	0
ibdot1sOperMstID.2498	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2498	Integer	0
ibdot1sOperMstID.2499	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2499	Integer	0
ibdot1sOperMstID.2500	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2500	Integer	0
ibdot1sOperMstID.2501	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2501	Integer	0
ibdot1sOperMstID.2502	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2502	Integer	0
ibdot1sOperMstID.2503	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2503	Integer	0
ibdot1sOperMstID.2504	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2504	Integer	0
ibdot1sOperMstID.2505	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2505	Integer	0
ibdot1sOperMstID.2506	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2506	Integer	0
ibdot1sOperMstID.2507	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2507	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.2508	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2508	Integer	0
ibdot1sOperMstID.2509	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2509	Integer	0
ibdot1sOperMstID.2510	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2510	Integer	0
ibdot1sOperMstID.2511	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2511	Integer	0
ibdot1sOperMstID.2512	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2512	Integer	0
ibdot1sOperMstID.2513	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2513	Integer	0
ibdot1sOperMstID.2514	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2514	Integer	0
ibdot1sOperMstID.2515	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2515	Integer	0
ibdot1sOperMstID.2516	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2516	Integer	0
ibdot1sOperMstID.2517	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2517	Integer	0
ibdot1sOperMstID.2518	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2518	Integer	0
ibdot1sOperMstID.2519	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2519	Integer	0
ibdot1sOperMstID.2520	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2520	Integer	0
ibdot1sOperMstID.2521	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2521	Integer	0
ibdot1sOperMstID.2522	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2522	Integer	0
ibdot1sOperMstID.2523	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2523	Integer	0
ibdot1sOperMstID.2524	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2524	Integer	0
ibdot1sOperMstID.2525	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2525	Integer	0
ibdot1sOperMstID.2526	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2526	Integer	0
ibdot1sOperMstID.2527	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2527	Integer	0
ibdot1sOperMstID.2528	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2528	Integer	0
ibdot1sOperMstID.2529	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2529	Integer	0
ibdot1sOperMstID.2530	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2530	Integer	0
ibdot1sOperMstID.2531	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2531	Integer	0
ibdot1sOperMstID.2532	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2532	Integer	0
ibdot1sOperMstID.2533	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2533	Integer	0
ibdot1sOperMstID.2534	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2534	Integer	0
ibdot1sOperMstID.2535	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2535	Integer	0
ibdot1sOperMstID.2536	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2536	Integer	0
ibdot1sOperMstID.2537	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2537	Integer	0
ibdot1sOperMstID.2538	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2538	Integer	0
ibdot1sOperMstID.2539	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2539	Integer	0
ibdot1sOperMstID.2540	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2540	Integer	0
ibdot1sOperMstID.2541	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2541	Integer	0
ibdot1sOperMstID.2542	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2542	Integer	0
ibdot1sOperMstID.2543	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2543	Integer	0
ibdot1sOperMstID.2544	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2544	Integer	0
ibdot1sOperMstID.2545	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2545	Integer	0
ibdot1sOperMstID.2546	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2546	Integer	0
ibdot1sOperMstID.2547	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2547	Integer	0
ibdot1sOperMstID.2548	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2548	Integer	0
ibdot1sOperMstID.2549	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2549	Integer	0
ibdot1sOperMstID.2550	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2550	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.2551	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2551	Integer	0
ibdot1sOperMstID.2552	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2552	Integer	0
ibdot1sOperMstID.2553	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2553	Integer	0
ibdot1sOperMstID.2554	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2554	Integer	0
ibdot1sOperMstID.2555	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2555	Integer	0
ibdot1sOperMstID.2556	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2556	Integer	0
ibdot1sOperMstID.2557	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2557	Integer	0
ibdot1sOperMstID.2558	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2558	Integer	0
ibdot1sOperMstID.2559	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2559	Integer	0
ibdot1sOperMstID.2560	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2560	Integer	0
ibdot1sOperMstID.2561	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2561	Integer	0
ibdot1sOperMstID.2562	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2562	Integer	0
ibdot1sOperMstID.2563	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2563	Integer	0
ibdot1sOperMstID.2564	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2564	Integer	0
ibdot1sOperMstID.2565	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2565	Integer	0
ibdot1sOperMstID.2566	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2566	Integer	0
ibdot1sOperMstID.2567	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2567	Integer	0
ibdot1sOperMstID.2568	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2568	Integer	0
ibdot1sOperMstID.2569	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2569	Integer	0
ibdot1sOperMstID.2570	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2570	Integer	0
ibdot1sOperMstID.2571	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2571	Integer	0
ibdot1sOperMstID.2572	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2572	Integer	0
ibdot1sOperMstID.2573	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2573	Integer	0
ibdot1sOperMstID.2574	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2574	Integer	0
ibdot1sOperMstID.2575	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2575	Integer	0
ibdot1sOperMstID.2576	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2576	Integer	0
ibdot1sOperMstID.2577	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2577	Integer	0
ibdot1sOperMstID.2578	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2578	Integer	0
ibdot1sOperMstID.2579	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2579	Integer	0
ibdot1sOperMstID.2580	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2580	Integer	0
ibdot1sOperMstID.2581	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2581	Integer	0
ibdot1sOperMstID.2582	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2582	Integer	0
ibdot1sOperMstID.2583	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2583	Integer	0
ibdot1sOperMstID.2584	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2584	Integer	0
ibdot1sOperMstID.2585	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2585	Integer	0
ibdot1sOperMstID.2586	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2586	Integer	0
ibdot1sOperMstID.2587	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2587	Integer	0
ibdot1sOperMstID.2588	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2588	Integer	0
ibdot1sOperMstID.2589	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2589	Integer	0
ibdot1sOperMstID.2590	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2590	Integer	0
ibdot1sOperMstID.2591	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2591	Integer	0
ibdot1sOperMstID.2592	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2592	Integer	0
ibdot1sOperMstID.2593	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2593	Integer	0



Name	OID	Value Type	Value Example
ibdot1sOperMstID.2594	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2594	Integer	0
ibdot1sOperMstID.2595	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2595	Integer	0
ibdot1sOperMstID.2596	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2596	Integer	0
ibdot1sOperMstID.2597	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2597	Integer	0
ibdot1sOperMstID.2598	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2598	Integer	0
ibdot1sOperMstID.2599	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2599	Integer	0
ibdot1sOperMstID.2600	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2600	Integer	0
ibdot1sOperMstID.2601	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2601	Integer	0
ibdot1sOperMstID.2602	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2602	Integer	0
ibdot1sOperMstID.2603	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2603	Integer	0
ibdot1sOperMstID.2604	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2604	Integer	0
ibdot1sOperMstID.2605	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2605	Integer	0
ibdot1sOperMstID.2606	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2606	Integer	0
ibdot1sOperMstID.2607	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2607	Integer	0
ibdot1sOperMstID.2608	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2608	Integer	0
ibdot1sOperMstID.2609	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2609	Integer	0
ibdot1sOperMstID.2610	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2610	Integer	0
ibdot1sOperMstID.2611	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2611	Integer	0
ibdot1sOperMstID.2612	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2612	Integer	0
ibdot1sOperMstID.2613	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2613	Integer	0
ibdot1sOperMstID.2614	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2614	Integer	0
ibdot1sOperMstID.2615	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2615	Integer	0
ibdot1sOperMstID.2616	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2616	Integer	0
ibdot1sOperMstID.2617	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2617	Integer	0
ibdot1sOperMstID.2618	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2618	Integer	0
ibdot1sOperMstID.2619	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2619	Integer	0
ibdot1sOperMstID.2620	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2620	Integer	0
ibdot1sOperMstID.2621	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2621	Integer	0
ibdot1sOperMstID.2622	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2622	Integer	0
ibdot1sOperMstID.2623	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2623	Integer	0
ibdot1sOperMstID.2624	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2624	Integer	0
ibdot1sOperMstID.2625	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2625	Integer	0
ibdot1sOperMstID.2626	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2626	Integer	0
ibdot1sOperMstID.2627	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2627	Integer	0
ibdot1sOperMstID.2628	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2628	Integer	0
ibdot1sOperMstID.2629	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2629	Integer	0
ibdot1sOperMstID.2630	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2630	Integer	0
ibdot1sOperMstID.2631	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2631	Integer	0
ibdot1sOperMstID.2632	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2632	Integer	0
ibdot1sOperMstID.2633	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2633	Integer	0
ibdot1sOperMstID.2634	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2634	Integer	0
ibdot1sOperMstID.2635	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2635	Integer	0
ibdot1sOperMstID.2636	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2636	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.2637	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2637	Integer	0
ibdot1sOperMstID.2638	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2638	Integer	0
ibdot1sOperMstID.2639	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2639	Integer	0
ibdot1sOperMstID.2640	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2640	Integer	0
ibdot1sOperMstID.2641	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2641	Integer	0
ibdot1sOperMstID.2642	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2642	Integer	0
ibdot1sOperMstID.2643	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2643	Integer	0
ibdot1sOperMstID.2644	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2644	Integer	0
ibdot1sOperMstID.2645	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2645	Integer	0
ibdot1sOperMstID.2646	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2646	Integer	0
ibdot1sOperMstID.2647	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2647	Integer	0
ibdot1sOperMstID.2648	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2648	Integer	0
ibdot1sOperMstID.2649	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2649	Integer	0
ibdot1sOperMstID.2650	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2650	Integer	0
ibdot1sOperMstID.2651	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2651	Integer	0
ibdot1sOperMstID.2652	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2652	Integer	0
ibdot1sOperMstID.2653	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2653	Integer	0
ibdot1sOperMstID.2654	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2654	Integer	0
ibdot1sOperMstID.2655	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2655	Integer	0
ibdot1sOperMstID.2656	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2656	Integer	0
ibdot1sOperMstID.2657	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2657	Integer	0
ibdot1sOperMstID.2658	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2658	Integer	0
ibdot1sOperMstID.2659	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2659	Integer	0
ibdot1sOperMstID.2660	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2660	Integer	0
ibdot1sOperMstID.2661	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2661	Integer	0
ibdot1sOperMstID.2662	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2662	Integer	0
ibdot1sOperMstID.2663	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2663	Integer	0
ibdot1sOperMstID.2664	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2664	Integer	0
ibdot1sOperMstID.2665	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2665	Integer	0
ibdot1sOperMstID.2666	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2666	Integer	0
ibdot1sOperMstID.2667	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2667	Integer	0
ibdot1sOperMstID.2668	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2668	Integer	0
ibdot1sOperMstID.2669	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2669	Integer	0
ibdot1sOperMstID.2670	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2670	Integer	0
ibdot1sOperMstID.2671	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2671	Integer	0
ibdot1sOperMstID.2672	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2672	Integer	0
ibdot1sOperMstID.2673	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2673	Integer	0
ibdot1sOperMstID.2674	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2674	Integer	0
ibdot1sOperMstID.2675	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2675	Integer	0
ibdot1sOperMstID.2676	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2676	Integer	0
ibdot1sOperMstID.2677	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2677	Integer	0
ibdot1sOperMstID.2678	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2678	Integer	0
ibdot1sOperMstID.2679	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2679	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.2680	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2680	Integer	0
ibdot1sOperMstID.2681	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2681	Integer	0
ibdot1sOperMstID.2682	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2682	Integer	0
ibdot1sOperMstID.2683	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2683	Integer	0
ibdot1sOperMstID.2684	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2684	Integer	0
ibdot1sOperMstID.2685	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2685	Integer	0
ibdot1sOperMstID.2686	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2686	Integer	0
ibdot1sOperMstID.2687	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2687	Integer	0
ibdot1sOperMstID.2688	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2688	Integer	0
ibdot1sOperMstID.2689	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2689	Integer	0
ibdot1sOperMstID.2690	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2690	Integer	0
ibdot1sOperMstID.2691	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2691	Integer	0
ibdot1sOperMstID.2692	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2692	Integer	0
ibdot1sOperMstID.2693	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2693	Integer	0
ibdot1sOperMstID.2694	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2694	Integer	0
ibdot1sOperMstID.2695	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2695	Integer	0
ibdot1sOperMstID.2696	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2696	Integer	0
ibdot1sOperMstID.2697	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2697	Integer	0
ibdot1sOperMstID.2698	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2698	Integer	0
ibdot1sOperMstID.2699	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2699	Integer	0
ibdot1sOperMstID.2700	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2700	Integer	0
ibdot1sOperMstID.2701	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2701	Integer	0
ibdot1sOperMstID.2702	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2702	Integer	0
ibdot1sOperMstID.2703	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2703	Integer	0
ibdot1sOperMstID.2704	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2704	Integer	0
ibdot1sOperMstID.2705	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2705	Integer	0
ibdot1sOperMstID.2706	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2706	Integer	0
ibdot1sOperMstID.2707	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2707	Integer	0
ibdot1sOperMstID.2708	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2708	Integer	0
ibdot1sOperMstID.2709	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2709	Integer	0
ibdot1sOperMstID.2710	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2710	Integer	0
ibdot1sOperMstID.2711	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2711	Integer	0
ibdot1sOperMstID.2712	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2712	Integer	0
ibdot1sOperMstID.2713	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2713	Integer	0
ibdot1sOperMstID.2714	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2714	Integer	0
ibdot1sOperMstID.2715	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2715	Integer	0
ibdot1sOperMstID.2716	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2716	Integer	0
ibdot1sOperMstID.2717	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2717	Integer	0
ibdot1sOperMstID.2718	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2718	Integer	0
ibdot1sOperMstID.2719	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2719	Integer	0
ibdot1sOperMstID.2720	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2720	Integer	0
ibdot1sOperMstID.2721	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2721	Integer	0
ibdot1sOperMstID.2722	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2722	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.2723	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2723	Integer	0
ibdot1sOperMstID.2724	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2724	Integer	0
ibdot1sOperMstID.2725	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2725	Integer	0
ibdot1sOperMstID.2726	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2726	Integer	0
ibdot1sOperMstID.2727	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2727	Integer	0
ibdot1sOperMstID.2728	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2728	Integer	0
ibdot1sOperMstID.2729	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2729	Integer	0
ibdot1sOperMstID.2730	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2730	Integer	0
ibdot1sOperMstID.2731	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2731	Integer	0
ibdot1sOperMstID.2732	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2732	Integer	0
ibdot1sOperMstID.2733	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2733	Integer	0
ibdot1sOperMstID.2734	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2734	Integer	0
ibdot1sOperMstID.2735	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2735	Integer	0
ibdot1sOperMstID.2736	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2736	Integer	0
ibdot1sOperMstID.2737	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2737	Integer	0
ibdot1sOperMstID.2738	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2738	Integer	0
ibdot1sOperMstID.2739	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2739	Integer	0
ibdot1sOperMstID.2740	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2740	Integer	0
ibdot1sOperMstID.2741	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2741	Integer	0
ibdot1sOperMstID.2742	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2742	Integer	0
ibdot1sOperMstID.2743	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2743	Integer	0
ibdot1sOperMstID.2744	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2744	Integer	0
ibdot1sOperMstID.2745	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2745	Integer	0
ibdot1sOperMstID.2746	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2746	Integer	0
ibdot1sOperMstID.2747	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2747	Integer	0
ibdot1sOperMstID.2748	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2748	Integer	0
ibdot1sOperMstID.2749	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2749	Integer	0
ibdot1sOperMstID.2750	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2750	Integer	0
ibdot1sOperMstID.2751	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2751	Integer	0
ibdot1sOperMstID.2752	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2752	Integer	0
ibdot1sOperMstID.2753	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2753	Integer	0
ibdot1sOperMstID.2754	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2754	Integer	0
ibdot1sOperMstID.2755	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2755	Integer	0
ibdot1sOperMstID.2756	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2756	Integer	0
ibdot1sOperMstID.2757	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2757	Integer	0
ibdot1sOperMstID.2758	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2758	Integer	0
ibdot1sOperMstID.2759	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2759	Integer	0
ibdot1sOperMstID.2760	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2760	Integer	0
ibdot1sOperMstID.2761	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2761	Integer	0
ibdot1sOperMstID.2762	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2762	Integer	0
ibdot1sOperMstID.2763	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2763	Integer	0
ibdot1sOperMstID.2764	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2764	Integer	0
ibdot1sOperMstID.2765	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2765	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.2766	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2766	Integer	0
ibdot1sOperMstID.2767	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2767	Integer	0
ibdot1sOperMstID.2768	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2768	Integer	0
ibdot1sOperMstID.2769	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2769	Integer	0
ibdot1sOperMstID.2770	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2770	Integer	0
ibdot1sOperMstID.2771	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2771	Integer	0
ibdot1sOperMstID.2772	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2772	Integer	0
ibdot1sOperMstID.2773	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2773	Integer	0
ibdot1sOperMstID.2774	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2774	Integer	0
ibdot1sOperMstID.2775	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2775	Integer	0
ibdot1sOperMstID.2776	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2776	Integer	0
ibdot1sOperMstID.2777	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2777	Integer	0
ibdot1sOperMstID.2778	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2778	Integer	0
ibdot1sOperMstID.2779	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2779	Integer	0
ibdot1sOperMstID.2780	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2780	Integer	0
ibdot1sOperMstID.2781	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2781	Integer	0
ibdot1sOperMstID.2782	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2782	Integer	0
ibdot1sOperMstID.2783	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2783	Integer	0
ibdot1sOperMstID.2784	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2784	Integer	0
ibdot1sOperMstID.2785	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2785	Integer	0
ibdot1sOperMstID.2786	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2786	Integer	0
ibdot1sOperMstID.2787	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2787	Integer	0
ibdot1sOperMstID.2788	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2788	Integer	0
ibdot1sOperMstID.2789	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2789	Integer	0
ibdot1sOperMstID.2790	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2790	Integer	0
ibdot1sOperMstID.2791	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2791	Integer	0
ibdot1sOperMstID.2792	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2792	Integer	0
ibdot1sOperMstID.2793	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2793	Integer	0
ibdot1sOperMstID.2794	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2794	Integer	0
ibdot1sOperMstID.2795	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2795	Integer	0
ibdot1sOperMstID.2796	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2796	Integer	0
ibdot1sOperMstID.2797	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2797	Integer	0
ibdot1sOperMstID.2798	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2798	Integer	0
ibdot1sOperMstID.2799	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2799	Integer	0
ibdot1sOperMstID.2800	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2800	Integer	0
ibdot1sOperMstID.2801	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2801	Integer	0
ibdot1sOperMstID.2802	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2802	Integer	0
ibdot1sOperMstID.2803	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2803	Integer	0
ibdot1sOperMstID.2804	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2804	Integer	0
ibdot1sOperMstID.2805	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2805	Integer	0
ibdot1sOperMstID.2806	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2806	Integer	0
ibdot1sOperMstID.2807	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2807	Integer	0
ibdot1sOperMstID.2808	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2808	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.2809	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2809	Integer	0
ibdot1sOperMstID.2810	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2810	Integer	0
ibdot1sOperMstID.2811	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2811	Integer	0
ibdot1sOperMstID.2812	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2812	Integer	0
ibdot1sOperMstID.2813	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2813	Integer	0
ibdot1sOperMstID.2814	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2814	Integer	0
ibdot1sOperMstID.2815	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2815	Integer	0
ibdot1sOperMstID.2816	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2816	Integer	0
ibdot1sOperMstID.2817	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2817	Integer	0
ibdot1sOperMstID.2818	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2818	Integer	0
ibdot1sOperMstID.2819	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2819	Integer	0
ibdot1sOperMstID.2820	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2820	Integer	0
ibdot1sOperMstID.2821	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2821	Integer	0
ibdot1sOperMstID.2822	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2822	Integer	0
ibdot1sOperMstID.2823	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2823	Integer	0
ibdot1sOperMstID.2824	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2824	Integer	0
ibdot1sOperMstID.2825	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2825	Integer	0
ibdot1sOperMstID.2826	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2826	Integer	0
ibdot1sOperMstID.2827	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2827	Integer	0
ibdot1sOperMstID.2828	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2828	Integer	0
ibdot1sOperMstID.2829	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2829	Integer	0
ibdot1sOperMstID.2830	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2830	Integer	0
ibdot1sOperMstID.2831	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2831	Integer	0
ibdot1sOperMstID.2832	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2832	Integer	0
ibdot1sOperMstID.2833	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2833	Integer	0
ibdot1sOperMstID.2834	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2834	Integer	0
ibdot1sOperMstID.2835	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2835	Integer	0
ibdot1sOperMstID.2836	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2836	Integer	0
ibdot1sOperMstID.2837	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2837	Integer	0
ibdot1sOperMstID.2838	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2838	Integer	0
ibdot1sOperMstID.2839	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2839	Integer	0
ibdot1sOperMstID.2840	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2840	Integer	0
ibdot1sOperMstID.2841	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2841	Integer	0
ibdot1sOperMstID.2842	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2842	Integer	0
ibdot1sOperMstID.2843	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2843	Integer	0
ibdot1sOperMstID.2844	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2844	Integer	0
ibdot1sOperMstID.2845	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2845	Integer	0
ibdot1sOperMstID.2846	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2846	Integer	0
ibdot1sOperMstID.2847	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2847	Integer	0
ibdot1sOperMstID.2848	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2848	Integer	0
ibdot1sOperMstID.2849	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2849	Integer	0
ibdot1sOperMstID.2850	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2850	Integer	0
ibdot1sOperMstID.2851	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2851	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.2852	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2852	Integer	0
ibdot1sOperMstID.2853	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2853	Integer	0
ibdot1sOperMstID.2854	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2854	Integer	0
ibdot1sOperMstID.2855	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2855	Integer	0
ibdot1sOperMstID.2856	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2856	Integer	0
ibdot1sOperMstID.2857	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2857	Integer	0
ibdot1sOperMstID.2858	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2858	Integer	0
ibdot1sOperMstID.2859	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2859	Integer	0
ibdot1sOperMstID.2860	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2860	Integer	0
ibdot1sOperMstID.2861	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2861	Integer	0
ibdot1sOperMstID.2862	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2862	Integer	0
ibdot1sOperMstID.2863	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2863	Integer	0
ibdot1sOperMstID.2864	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2864	Integer	0
ibdot1sOperMstID.2865	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2865	Integer	0
ibdot1sOperMstID.2866	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2866	Integer	0
ibdot1sOperMstID.2867	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2867	Integer	0
ibdot1sOperMstID.2868	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2868	Integer	0
ibdot1sOperMstID.2869	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2869	Integer	0
ibdot1sOperMstID.2870	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2870	Integer	0
ibdot1sOperMstID.2871	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2871	Integer	0
ibdot1sOperMstID.2872	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2872	Integer	0
ibdot1sOperMstID.2873	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2873	Integer	0
ibdot1sOperMstID.2874	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2874	Integer	0
ibdot1sOperMstID.2875	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2875	Integer	0
ibdot1sOperMstID.2876	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2876	Integer	0
ibdot1sOperMstID.2877	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2877	Integer	0
ibdot1sOperMstID.2878	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2878	Integer	0
ibdot1sOperMstID.2879	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2879	Integer	0
ibdot1sOperMstID.2880	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2880	Integer	0
ibdot1sOperMstID.2881	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2881	Integer	0
ibdot1sOperMstID.2882	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2882	Integer	0
ibdot1sOperMstID.2883	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2883	Integer	0
ibdot1sOperMstID.2884	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2884	Integer	0
ibdot1sOperMstID.2885	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2885	Integer	0
ibdot1sOperMstID.2886	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2886	Integer	0
ibdot1sOperMstID.2887	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2887	Integer	0
ibdot1sOperMstID.2888	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2888	Integer	0
ibdot1sOperMstID.2889	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2889	Integer	0
ibdot1sOperMstID.2890	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2890	Integer	0
ibdot1sOperMstID.2891	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2891	Integer	0
ibdot1sOperMstID.2892	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2892	Integer	0
ibdot1sOperMstID.2893	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2893	Integer	0
ibdot1sOperMstID.2894	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2894	Integer	0



Name	OID	Value Type	Value Example
ibdot1sOperMstID.2895	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2895	Integer	0
ibdot1sOperMstID.2896	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2896	Integer	0
ibdot1sOperMstID.2897	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2897	Integer	0
ibdot1sOperMstID.2898	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2898	Integer	0
ibdot1sOperMstID.2899	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2899	Integer	0
ibdot1sOperMstID.2900	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2900	Integer	0
ibdot1sOperMstID.2901	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2901	Integer	0
ibdot1sOperMstID.2902	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2902	Integer	0
ibdot1sOperMstID.2903	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2903	Integer	0
ibdot1sOperMstID.2904	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2904	Integer	0
ibdot1sOperMstID.2905	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2905	Integer	0
ibdot1sOperMstID.2906	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2906	Integer	0
ibdot1sOperMstID.2907	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2907	Integer	0
ibdot1sOperMstID.2908	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2908	Integer	0
ibdot1sOperMstID.2909	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2909	Integer	0
ibdot1sOperMstID.2910	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2910	Integer	0
ibdot1sOperMstID.2911	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2911	Integer	0
ibdot1sOperMstID.2912	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2912	Integer	0
ibdot1sOperMstID.2913	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2913	Integer	0
ibdot1sOperMstID.2914	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2914	Integer	0
ibdot1sOperMstID.2915	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2915	Integer	0
ibdot1sOperMstID.2916	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2916	Integer	0
ibdot1sOperMstID.2917	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2917	Integer	0
ibdot1sOperMstID.2918	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2918	Integer	0
ibdot1sOperMstID.2919	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2919	Integer	0
ibdot1sOperMstID.2920	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2920	Integer	0
ibdot1sOperMstID.2921	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2921	Integer	0
ibdot1sOperMstID.2922	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2922	Integer	0
ibdot1sOperMstID.2923	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2923	Integer	0
ibdot1sOperMstID.2924	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2924	Integer	0
ibdot1sOperMstID.2925	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2925	Integer	0
ibdot1sOperMstID.2926	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2926	Integer	0
ibdot1sOperMstID.2927	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2927	Integer	0
ibdot1sOperMstID.2928	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2928	Integer	0
ibdot1sOperMstID.2929	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2929	Integer	0
ibdot1sOperMstID.2930	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2930	Integer	0
ibdot1sOperMstID.2931	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2931	Integer	0
ibdot1sOperMstID.2932	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2932	Integer	0
ibdot1sOperMstID.2933	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2933	Integer	0
ibdot1sOperMstID.2934	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2934	Integer	0
ibdot1sOperMstID.2935	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2935	Integer	0
ibdot1sOperMstID.2936	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2936	Integer	0
ibdot1sOperMstID.2937	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2937	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.2938	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2938	Integer	0
ibdot1sOperMstID.2939	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2939	Integer	0
ibdot1sOperMstID.2940	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2940	Integer	0
ibdot1sOperMstID.2941	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2941	Integer	0
ibdot1sOperMstID.2942	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2942	Integer	0
ibdot1sOperMstID.2943	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2943	Integer	0
ibdot1sOperMstID.2944	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2944	Integer	0
ibdot1sOperMstID.2945	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2945	Integer	0
ibdot1sOperMstID.2946	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2946	Integer	0
ibdot1sOperMstID.2947	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2947	Integer	0
ibdot1sOperMstID.2948	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2948	Integer	0
ibdot1sOperMstID.2949	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2949	Integer	0
ibdot1sOperMstID.2950	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2950	Integer	0
ibdot1sOperMstID.2951	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2951	Integer	0
ibdot1sOperMstID.2952	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2952	Integer	0
ibdot1sOperMstID.2953	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2953	Integer	0
ibdot1sOperMstID.2954	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2954	Integer	0
ibdot1sOperMstID.2955	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2955	Integer	0
ibdot1sOperMstID.2956	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2956	Integer	0
ibdot1sOperMstID.2957	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2957	Integer	0
ibdot1sOperMstID.2958	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2958	Integer	0
ibdot1sOperMstID.2959	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2959	Integer	0
ibdot1sOperMstID.2960	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2960	Integer	0
ibdot1sOperMstID.2961	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2961	Integer	0
ibdot1sOperMstID.2962	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2962	Integer	0
ibdot1sOperMstID.2963	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2963	Integer	0
ibdot1sOperMstID.2964	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2964	Integer	0
ibdot1sOperMstID.2965	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2965	Integer	0
ibdot1sOperMstID.2966	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2966	Integer	0
ibdot1sOperMstID.2967	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2967	Integer	0
ibdot1sOperMstID.2968	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2968	Integer	0
ibdot1sOperMstID.2969	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2969	Integer	0
ibdot1sOperMstID.2970	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2970	Integer	0
ibdot1sOperMstID.2971	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2971	Integer	0
ibdot1sOperMstID.2972	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2972	Integer	0
ibdot1sOperMstID.2973	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2973	Integer	0
ibdot1sOperMstID.2974	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2974	Integer	0
ibdot1sOperMstID.2975	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2975	Integer	0
ibdot1sOperMstID.2976	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2976	Integer	0
ibdot1sOperMstID.2977	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2977	Integer	0
ibdot1sOperMstID.2978	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2978	Integer	0
ibdot1sOperMstID.2979	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2979	Integer	0
ibdot1sOperMstID.2980	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2980	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.2981	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2981	Integer	0
ibdot1sOperMstID.2982	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2982	Integer	0
ibdot1sOperMstID.2983	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2983	Integer	0
ibdot1sOperMstID.2984	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2984	Integer	0
ibdot1sOperMstID.2985	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2985	Integer	0
ibdot1sOperMstID.2986	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2986	Integer	0
ibdot1sOperMstID.2987	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2987	Integer	0
ibdot1sOperMstID.2988	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2988	Integer	0
ibdot1sOperMstID.2989	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2989	Integer	0
ibdot1sOperMstID.2990	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2990	Integer	0
ibdot1sOperMstID.2991	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2991	Integer	0
ibdot1sOperMstID.2992	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2992	Integer	0
ibdot1sOperMstID.2993	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2993	Integer	0
ibdot1sOperMstID.2994	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2994	Integer	0
ibdot1sOperMstID.2995	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2995	Integer	0
ibdot1sOperMstID.2996	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2996	Integer	0
ibdot1sOperMstID.2997	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2997	Integer	0
ibdot1sOperMstID.2998	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2998	Integer	0
ibdot1sOperMstID.2999	.1.3.6.1.4.1.26138.8.35.14.18.1.3.2999	Integer	0
ibdot1sOperMstID.3000	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3000	Integer	0
ibdot1sOperMstID.3001	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3001	Integer	0
ibdot1sOperMstID.3002	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3002	Integer	0
ibdot1sOperMstID.3003	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3003	Integer	0
ibdot1sOperMstID.3004	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3004	Integer	0
ibdot1sOperMstID.3005	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3005	Integer	0
ibdot1sOperMstID.3006	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3006	Integer	0
ibdot1sOperMstID.3007	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3007	Integer	0
ibdot1sOperMstID.3008	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3008	Integer	0
ibdot1sOperMstID.3009	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3009	Integer	0
ibdot1sOperMstID.3010	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3010	Integer	0
ibdot1sOperMstID.3011	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3011	Integer	0
ibdot1sOperMstID.3012	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3012	Integer	0
ibdot1sOperMstID.3013	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3013	Integer	0
ibdot1sOperMstID.3014	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3014	Integer	0
ibdot1sOperMstID.3015	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3015	Integer	0
ibdot1sOperMstID.3016	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3016	Integer	0
ibdot1sOperMstID.3017	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3017	Integer	0
ibdot1sOperMstID.3018	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3018	Integer	0
ibdot1sOperMstID.3019	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3019	Integer	0
ibdot1sOperMstID.3020	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3020	Integer	0
ibdot1sOperMstID.3021	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3021	Integer	0
ibdot1sOperMstID.3022	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3022	Integer	0
ibdot1sOperMstID.3023	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3023	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.3024	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3024	Integer	0
ibdot1sOperMstID.3025	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3025	Integer	0
ibdot1sOperMstID.3026	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3026	Integer	0
ibdot1sOperMstID.3027	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3027	Integer	0
ibdot1sOperMstID.3028	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3028	Integer	0
ibdot1sOperMstID.3029	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3029	Integer	0
ibdot1sOperMstID.3030	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3030	Integer	0
ibdot1sOperMstID.3031	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3031	Integer	0
ibdot1sOperMstID.3032	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3032	Integer	0
ibdot1sOperMstID.3033	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3033	Integer	0
ibdot1sOperMstID.3034	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3034	Integer	0
ibdot1sOperMstID.3035	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3035	Integer	0
ibdot1sOperMstID.3036	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3036	Integer	0
ibdot1sOperMstID.3037	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3037	Integer	0
ibdot1sOperMstID.3038	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3038	Integer	0
ibdot1sOperMstID.3039	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3039	Integer	0
ibdot1sOperMstID.3040	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3040	Integer	0
ibdot1sOperMstID.3041	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3041	Integer	0
ibdot1sOperMstID.3042	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3042	Integer	0
ibdot1sOperMstID.3043	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3043	Integer	0
ibdot1sOperMstID.3044	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3044	Integer	0
ibdot1sOperMstID.3045	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3045	Integer	0
ibdot1sOperMstID.3046	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3046	Integer	0
ibdot1sOperMstID.3047	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3047	Integer	0
ibdot1sOperMstID.3048	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3048	Integer	0
ibdot1sOperMstID.3049	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3049	Integer	0
ibdot1sOperMstID.3050	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3050	Integer	0
ibdot1sOperMstID.3051	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3051	Integer	0
ibdot1sOperMstID.3052	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3052	Integer	0
ibdot1sOperMstID.3053	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3053	Integer	0
ibdot1sOperMstID.3054	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3054	Integer	0
ibdot1sOperMstID.3055	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3055	Integer	0
ibdot1sOperMstID.3056	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3056	Integer	0
ibdot1sOperMstID.3057	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3057	Integer	0
ibdot1sOperMstID.3058	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3058	Integer	0
ibdot1sOperMstID.3059	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3059	Integer	0
ibdot1sOperMstID.3060	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3060	Integer	0
ibdot1sOperMstID.3061	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3061	Integer	0
ibdot1sOperMstID.3062	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3062	Integer	0
ibdot1sOperMstID.3063	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3063	Integer	0
ibdot1sOperMstID.3064	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3064	Integer	0
ibdot1sOperMstID.3065	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3065	Integer	0
ibdot1sOperMstID.3066	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3066	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.3067	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3067	Integer	0
ibdot1sOperMstID.3068	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3068	Integer	0
ibdot1sOperMstID.3069	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3069	Integer	0
ibdot1sOperMstID.3070	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3070	Integer	0
ibdot1sOperMstID.3071	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3071	Integer	0
ibdot1sOperMstID.3072	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3072	Integer	0
ibdot1sOperMstID.3073	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3073	Integer	0
ibdot1sOperMstID.3074	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3074	Integer	0
ibdot1sOperMstID.3075	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3075	Integer	0
ibdot1sOperMstID.3076	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3076	Integer	0
ibdot1sOperMstID.3077	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3077	Integer	0
ibdot1sOperMstID.3078	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3078	Integer	0
ibdot1sOperMstID.3079	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3079	Integer	0
ibdot1sOperMstID.3080	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3080	Integer	0
ibdot1sOperMstID.3081	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3081	Integer	0
ibdot1sOperMstID.3082	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3082	Integer	0
ibdot1sOperMstID.3083	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3083	Integer	0
ibdot1sOperMstID.3084	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3084	Integer	0
ibdot1sOperMstID.3085	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3085	Integer	0
ibdot1sOperMstID.3086	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3086	Integer	0
ibdot1sOperMstID.3087	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3087	Integer	0
ibdot1sOperMstID.3088	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3088	Integer	0
ibdot1sOperMstID.3089	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3089	Integer	0
ibdot1sOperMstID.3090	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3090	Integer	0
ibdot1sOperMstID.3091	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3091	Integer	0
ibdot1sOperMstID.3092	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3092	Integer	0
ibdot1sOperMstID.3093	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3093	Integer	0
ibdot1sOperMstID.3094	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3094	Integer	0
ibdot1sOperMstID.3095	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3095	Integer	0
ibdot1sOperMstID.3096	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3096	Integer	0
ibdot1sOperMstID.3097	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3097	Integer	0
ibdot1sOperMstID.3098	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3098	Integer	0
ibdot1sOperMstID.3099	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3099	Integer	0
ibdot1sOperMstID.3100	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3100	Integer	0
ibdot1sOperMstID.3101	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3101	Integer	0
ibdot1sOperMstID.3102	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3102	Integer	0
ibdot1sOperMstID.3103	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3103	Integer	0
ibdot1sOperMstID.3104	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3104	Integer	0
ibdot1sOperMstID.3105	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3105	Integer	0
ibdot1sOperMstID.3106	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3106	Integer	0
ibdot1sOperMstID.3107	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3107	Integer	0
ibdot1sOperMstID.3108	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3108	Integer	0
ibdot1sOperMstID.3109	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3109	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.3110	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3110	Integer	0
ibdot1sOperMstID.3111	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3111	Integer	0
ibdot1sOperMstID.3112	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3112	Integer	0
ibdot1sOperMstID.3113	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3113	Integer	0
ibdot1sOperMstID.3114	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3114	Integer	0
ibdot1sOperMstID.3115	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3115	Integer	0
ibdot1sOperMstID.3116	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3116	Integer	0
ibdot1sOperMstID.3117	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3117	Integer	0
ibdot1sOperMstID.3118	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3118	Integer	0
ibdot1sOperMstID.3119	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3119	Integer	0
ibdot1sOperMstID.3120	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3120	Integer	0
ibdot1sOperMstID.3121	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3121	Integer	0
ibdot1sOperMstID.3122	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3122	Integer	0
ibdot1sOperMstID.3123	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3123	Integer	0
ibdot1sOperMstID.3124	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3124	Integer	0
ibdot1sOperMstID.3125	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3125	Integer	0
ibdot1sOperMstID.3126	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3126	Integer	0
ibdot1sOperMstID.3127	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3127	Integer	0
ibdot1sOperMstID.3128	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3128	Integer	0
ibdot1sOperMstID.3129	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3129	Integer	0
ibdot1sOperMstID.3130	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3130	Integer	0
ibdot1sOperMstID.3131	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3131	Integer	0
ibdot1sOperMstID.3132	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3132	Integer	0
ibdot1sOperMstID.3133	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3133	Integer	0
ibdot1sOperMstID.3134	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3134	Integer	0
ibdot1sOperMstID.3135	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3135	Integer	0
ibdot1sOperMstID.3136	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3136	Integer	0
ibdot1sOperMstID.3137	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3137	Integer	0
ibdot1sOperMstID.3138	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3138	Integer	0
ibdot1sOperMstID.3139	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3139	Integer	0
ibdot1sOperMstID.3140	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3140	Integer	0
ibdot1sOperMstID.3141	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3141	Integer	0
ibdot1sOperMstID.3142	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3142	Integer	0
ibdot1sOperMstID.3143	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3143	Integer	0
ibdot1sOperMstID.3144	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3144	Integer	0
ibdot1sOperMstID.3145	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3145	Integer	0
ibdot1sOperMstID.3146	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3146	Integer	0
ibdot1sOperMstID.3147	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3147	Integer	0
ibdot1sOperMstID.3148	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3148	Integer	0
ibdot1sOperMstID.3149	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3149	Integer	0
ibdot1sOperMstID.3150	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3150	Integer	0
ibdot1sOperMstID.3151	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3151	Integer	0
ibdot1sOperMstID.3152	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3152	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.3153	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3153	Integer	0
ibdot1sOperMstID.3154	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3154	Integer	0
ibdot1sOperMstID.3155	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3155	Integer	0
ibdot1sOperMstID.3156	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3156	Integer	0
ibdot1sOperMstID.3157	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3157	Integer	0
ibdot1sOperMstID.3158	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3158	Integer	0
ibdot1sOperMstID.3159	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3159	Integer	0
ibdot1sOperMstID.3160	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3160	Integer	0
ibdot1sOperMstID.3161	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3161	Integer	0
ibdot1sOperMstID.3162	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3162	Integer	0
ibdot1sOperMstID.3163	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3163	Integer	0
ibdot1sOperMstID.3164	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3164	Integer	0
ibdot1sOperMstID.3165	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3165	Integer	0
ibdot1sOperMstID.3166	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3166	Integer	0
ibdot1sOperMstID.3167	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3167	Integer	0
ibdot1sOperMstID.3168	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3168	Integer	0
ibdot1sOperMstID.3169	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3169	Integer	0
ibdot1sOperMstID.3170	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3170	Integer	0
ibdot1sOperMstID.3171	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3171	Integer	0
ibdot1sOperMstID.3172	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3172	Integer	0
ibdot1sOperMstID.3173	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3173	Integer	0
ibdot1sOperMstID.3174	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3174	Integer	0
ibdot1sOperMstID.3175	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3175	Integer	0
ibdot1sOperMstID.3176	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3176	Integer	0
ibdot1sOperMstID.3177	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3177	Integer	0
ibdot1sOperMstID.3178	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3178	Integer	0
ibdot1sOperMstID.3179	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3179	Integer	0
ibdot1sOperMstID.3180	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3180	Integer	0
ibdot1sOperMstID.3181	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3181	Integer	0
ibdot1sOperMstID.3182	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3182	Integer	0
ibdot1sOperMstID.3183	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3183	Integer	0
ibdot1sOperMstID.3184	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3184	Integer	0
ibdot1sOperMstID.3185	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3185	Integer	0
ibdot1sOperMstID.3186	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3186	Integer	0
ibdot1sOperMstID.3187	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3187	Integer	0
ibdot1sOperMstID.3188	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3188	Integer	0
ibdot1sOperMstID.3189	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3189	Integer	0
ibdot1sOperMstID.3190	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3190	Integer	0
ibdot1sOperMstID.3191	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3191	Integer	0
ibdot1sOperMstID.3192	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3192	Integer	0
ibdot1sOperMstID.3193	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3193	Integer	0
ibdot1sOperMstID.3194	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3194	Integer	0
ibdot1sOperMstID.3195	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3195	Integer	0



Name	OID	Value Type	Value Example
ibdot1sOperMstID.3196	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3196	Integer	0
ibdot1sOperMstID.3197	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3197	Integer	0
ibdot1sOperMstID.3198	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3198	Integer	0
ibdot1sOperMstID.3199	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3199	Integer	0
ibdot1sOperMstID.3200	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3200	Integer	0
ibdot1sOperMstID.3201	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3201	Integer	0
ibdot1sOperMstID.3202	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3202	Integer	0
ibdot1sOperMstID.3203	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3203	Integer	0
ibdot1sOperMstID.3204	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3204	Integer	0
ibdot1sOperMstID.3205	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3205	Integer	0
ibdot1sOperMstID.3206	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3206	Integer	0
ibdot1sOperMstID.3207	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3207	Integer	0
ibdot1sOperMstID.3208	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3208	Integer	0
ibdot1sOperMstID.3209	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3209	Integer	0
ibdot1sOperMstID.3210	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3210	Integer	0
ibdot1sOperMstID.3211	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3211	Integer	0
ibdot1sOperMstID.3212	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3212	Integer	0
ibdot1sOperMstID.3213	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3213	Integer	0
ibdot1sOperMstID.3214	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3214	Integer	0
ibdot1sOperMstID.3215	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3215	Integer	0
ibdot1sOperMstID.3216	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3216	Integer	0
ibdot1sOperMstID.3217	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3217	Integer	0
ibdot1sOperMstID.3218	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3218	Integer	0
ibdot1sOperMstID.3219	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3219	Integer	0
ibdot1sOperMstID.3220	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3220	Integer	0
ibdot1sOperMstID.3221	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3221	Integer	0
ibdot1sOperMstID.3222	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3222	Integer	0
ibdot1sOperMstID.3223	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3223	Integer	0
ibdot1sOperMstID.3224	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3224	Integer	0
ibdot1sOperMstID.3225	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3225	Integer	0
ibdot1sOperMstID.3226	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3226	Integer	0
ibdot1sOperMstID.3227	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3227	Integer	0
ibdot1sOperMstID.3228	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3228	Integer	0
ibdot1sOperMstID.3229	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3229	Integer	0
ibdot1sOperMstID.3230	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3230	Integer	0
ibdot1sOperMstID.3231	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3231	Integer	0
ibdot1sOperMstID.3232	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3232	Integer	0
ibdot1sOperMstID.3233	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3233	Integer	0
ibdot1sOperMstID.3234	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3234	Integer	0
ibdot1sOperMstID.3235	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3235	Integer	0
ibdot1sOperMstID.3236	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3236	Integer	0
ibdot1sOperMstID.3237	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3237	Integer	0
ibdot1sOperMstID.3238	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3238	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.3239	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3239	Integer	0
ibdot1sOperMstID.3240	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3240	Integer	0
ibdot1sOperMstID.3241	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3241	Integer	0
ibdot1sOperMstID.3242	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3242	Integer	0
ibdot1sOperMstID.3243	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3243	Integer	0
ibdot1sOperMstID.3244	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3244	Integer	0
ibdot1sOperMstID.3245	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3245	Integer	0
ibdot1sOperMstID.3246	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3246	Integer	0
ibdot1sOperMstID.3247	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3247	Integer	0
ibdot1sOperMstID.3248	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3248	Integer	0
ibdot1sOperMstID.3249	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3249	Integer	0
ibdot1sOperMstID.3250	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3250	Integer	0
ibdot1sOperMstID.3251	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3251	Integer	0
ibdot1sOperMstID.3252	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3252	Integer	0
ibdot1sOperMstID.3253	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3253	Integer	0
ibdot1sOperMstID.3254	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3254	Integer	0
ibdot1sOperMstID.3255	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3255	Integer	0
ibdot1sOperMstID.3256	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3256	Integer	0
ibdot1sOperMstID.3257	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3257	Integer	0
ibdot1sOperMstID.3258	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3258	Integer	0
ibdot1sOperMstID.3259	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3259	Integer	0
ibdot1sOperMstID.3260	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3260	Integer	0
ibdot1sOperMstID.3261	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3261	Integer	0
ibdot1sOperMstID.3262	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3262	Integer	0
ibdot1sOperMstID.3263	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3263	Integer	0
ibdot1sOperMstID.3264	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3264	Integer	0
ibdot1sOperMstID.3265	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3265	Integer	0
ibdot1sOperMstID.3266	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3266	Integer	0
ibdot1sOperMstID.3267	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3267	Integer	0
ibdot1sOperMstID.3268	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3268	Integer	0
ibdot1sOperMstID.3269	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3269	Integer	0
ibdot1sOperMstID.3270	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3270	Integer	0
ibdot1sOperMstID.3271	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3271	Integer	0
ibdot1sOperMstID.3272	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3272	Integer	0
ibdot1sOperMstID.3273	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3273	Integer	0
ibdot1sOperMstID.3274	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3274	Integer	0
ibdot1sOperMstID.3275	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3275	Integer	0
ibdot1sOperMstID.3276	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3276	Integer	0
ibdot1sOperMstID.3277	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3277	Integer	0
ibdot1sOperMstID.3278	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3278	Integer	0
ibdot1sOperMstID.3279	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3279	Integer	0
ibdot1sOperMstID.3280	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3280	Integer	0
ibdot1sOperMstID.3281	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3281	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.3282	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3282	Integer	0
ibdot1sOperMstID.3283	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3283	Integer	0
ibdot1sOperMstID.3284	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3284	Integer	0
ibdot1sOperMstID.3285	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3285	Integer	0
ibdot1sOperMstID.3286	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3286	Integer	0
ibdot1sOperMstID.3287	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3287	Integer	0
ibdot1sOperMstID.3288	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3288	Integer	0
ibdot1sOperMstID.3289	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3289	Integer	0
ibdot1sOperMstID.3290	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3290	Integer	0
ibdot1sOperMstID.3291	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3291	Integer	0
ibdot1sOperMstID.3292	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3292	Integer	0
ibdot1sOperMstID.3293	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3293	Integer	0
ibdot1sOperMstID.3294	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3294	Integer	0
ibdot1sOperMstID.3295	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3295	Integer	0
ibdot1sOperMstID.3296	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3296	Integer	0
ibdot1sOperMstID.3297	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3297	Integer	0
ibdot1sOperMstID.3298	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3298	Integer	0
ibdot1sOperMstID.3299	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3299	Integer	0
ibdot1sOperMstID.3300	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3300	Integer	0
ibdot1sOperMstID.3301	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3301	Integer	0
ibdot1sOperMstID.3302	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3302	Integer	0
ibdot1sOperMstID.3303	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3303	Integer	0
ibdot1sOperMstID.3304	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3304	Integer	0
ibdot1sOperMstID.3305	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3305	Integer	0
ibdot1sOperMstID.3306	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3306	Integer	0
ibdot1sOperMstID.3307	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3307	Integer	0
ibdot1sOperMstID.3308	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3308	Integer	0
ibdot1sOperMstID.3309	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3309	Integer	0
ibdot1sOperMstID.3310	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3310	Integer	0
ibdot1sOperMstID.3311	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3311	Integer	0
ibdot1sOperMstID.3312	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3312	Integer	0
ibdot1sOperMstID.3313	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3313	Integer	0
ibdot1sOperMstID.3314	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3314	Integer	0
ibdot1sOperMstID.3315	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3315	Integer	0
ibdot1sOperMstID.3316	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3316	Integer	0
ibdot1sOperMstID.3317	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3317	Integer	0
ibdot1sOperMstID.3318	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3318	Integer	0
ibdot1sOperMstID.3319	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3319	Integer	0
ibdot1sOperMstID.3320	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3320	Integer	0
ibdot1sOperMstID.3321	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3321	Integer	0
ibdot1sOperMstID.3322	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3322	Integer	0
ibdot1sOperMstID.3323	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3323	Integer	0
ibdot1sOperMstID.3324	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3324	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.3325	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3325	Integer	0
ibdot1sOperMstID.3326	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3326	Integer	0
ibdot1sOperMstID.3327	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3327	Integer	0
ibdot1sOperMstID.3328	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3328	Integer	0
ibdot1sOperMstID.3329	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3329	Integer	0
ibdot1sOperMstID.3330	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3330	Integer	0
ibdot1sOperMstID.3331	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3331	Integer	0
ibdot1sOperMstID.3332	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3332	Integer	0
ibdot1sOperMstID.3333	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3333	Integer	0
ibdot1sOperMstID.3334	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3334	Integer	0
ibdot1sOperMstID.3335	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3335	Integer	0
ibdot1sOperMstID.3336	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3336	Integer	0
ibdot1sOperMstID.3337	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3337	Integer	0
ibdot1sOperMstID.3338	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3338	Integer	0
ibdot1sOperMstID.3339	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3339	Integer	0
ibdot1sOperMstID.3340	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3340	Integer	0
ibdot1sOperMstID.3341	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3341	Integer	0
ibdot1sOperMstID.3342	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3342	Integer	0
ibdot1sOperMstID.3343	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3343	Integer	0
ibdot1sOperMstID.3344	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3344	Integer	0
ibdot1sOperMstID.3345	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3345	Integer	0
ibdot1sOperMstID.3346	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3346	Integer	0
ibdot1sOperMstID.3347	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3347	Integer	0
ibdot1sOperMstID.3348	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3348	Integer	0
ibdot1sOperMstID.3349	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3349	Integer	0
ibdot1sOperMstID.3350	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3350	Integer	0
ibdot1sOperMstID.3351	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3351	Integer	0
ibdot1sOperMstID.3352	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3352	Integer	0
ibdot1sOperMstID.3353	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3353	Integer	0
ibdot1sOperMstID.3354	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3354	Integer	0
ibdot1sOperMstID.3355	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3355	Integer	0
ibdot1sOperMstID.3356	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3356	Integer	0
ibdot1sOperMstID.3357	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3357	Integer	0
ibdot1sOperMstID.3358	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3358	Integer	0
ibdot1sOperMstID.3359	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3359	Integer	0
ibdot1sOperMstID.3360	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3360	Integer	0
ibdot1sOperMstID.3361	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3361	Integer	0
ibdot1sOperMstID.3362	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3362	Integer	0
ibdot1sOperMstID.3363	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3363	Integer	0
ibdot1sOperMstID.3364	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3364	Integer	0
ibdot1sOperMstID.3365	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3365	Integer	0
ibdot1sOperMstID.3366	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3366	Integer	0
ibdot1sOperMstID.3367	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3367	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.3368	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3368	Integer	0
ibdot1sOperMstID.3369	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3369	Integer	0
ibdot1sOperMstID.3370	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3370	Integer	0
ibdot1sOperMstID.3371	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3371	Integer	0
ibdot1sOperMstID.3372	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3372	Integer	0
ibdot1sOperMstID.3373	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3373	Integer	0
ibdot1sOperMstID.3374	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3374	Integer	0
ibdot1sOperMstID.3375	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3375	Integer	0
ibdot1sOperMstID.3376	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3376	Integer	0
ibdot1sOperMstID.3377	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3377	Integer	0
ibdot1sOperMstID.3378	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3378	Integer	0
ibdot1sOperMstID.3379	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3379	Integer	0
ibdot1sOperMstID.3380	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3380	Integer	0
ibdot1sOperMstID.3381	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3381	Integer	0
ibdot1sOperMstID.3382	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3382	Integer	0
ibdot1sOperMstID.3383	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3383	Integer	0
ibdot1sOperMstID.3384	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3384	Integer	0
ibdot1sOperMstID.3385	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3385	Integer	0
ibdot1sOperMstID.3386	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3386	Integer	0
ibdot1sOperMstID.3387	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3387	Integer	0
ibdot1sOperMstID.3388	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3388	Integer	0
ibdot1sOperMstID.3389	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3389	Integer	0
ibdot1sOperMstID.3390	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3390	Integer	0
ibdot1sOperMstID.3391	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3391	Integer	0
ibdot1sOperMstID.3392	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3392	Integer	0
ibdot1sOperMstID.3393	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3393	Integer	0
ibdot1sOperMstID.3394	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3394	Integer	0
ibdot1sOperMstID.3395	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3395	Integer	0
ibdot1sOperMstID.3396	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3396	Integer	0
ibdot1sOperMstID.3397	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3397	Integer	0
ibdot1sOperMstID.3398	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3398	Integer	0
ibdot1sOperMstID.3399	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3399	Integer	0
ibdot1sOperMstID.3400	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3400	Integer	0
ibdot1sOperMstID.3401	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3401	Integer	0
ibdot1sOperMstID.3402	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3402	Integer	0
ibdot1sOperMstID.3403	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3403	Integer	0
ibdot1sOperMstID.3404	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3404	Integer	0
ibdot1sOperMstID.3405	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3405	Integer	0
ibdot1sOperMstID.3406	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3406	Integer	0
ibdot1sOperMstID.3407	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3407	Integer	0
ibdot1sOperMstID.3408	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3408	Integer	0
ibdot1sOperMstID.3409	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3409	Integer	0
ibdot1sOperMstID.3410	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3410	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.3411	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3411	Integer	0
ibdot1sOperMstID.3412	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3412	Integer	0
ibdot1sOperMstID.3413	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3413	Integer	0
ibdot1sOperMstID.3414	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3414	Integer	0
ibdot1sOperMstID.3415	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3415	Integer	0
ibdot1sOperMstID.3416	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3416	Integer	0
ibdot1sOperMstID.3417	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3417	Integer	0
ibdot1sOperMstID.3418	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3418	Integer	0
ibdot1sOperMstID.3419	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3419	Integer	0
ibdot1sOperMstID.3420	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3420	Integer	0
ibdot1sOperMstID.3421	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3421	Integer	0
ibdot1sOperMstID.3422	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3422	Integer	0
ibdot1sOperMstID.3423	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3423	Integer	0
ibdot1sOperMstID.3424	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3424	Integer	0
ibdot1sOperMstID.3425	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3425	Integer	0
ibdot1sOperMstID.3426	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3426	Integer	0
ibdot1sOperMstID.3427	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3427	Integer	0
ibdot1sOperMstID.3428	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3428	Integer	0
ibdot1sOperMstID.3429	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3429	Integer	0
ibdot1sOperMstID.3430	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3430	Integer	0
ibdot1sOperMstID.3431	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3431	Integer	0
ibdot1sOperMstID.3432	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3432	Integer	0
ibdot1sOperMstID.3433	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3433	Integer	0
ibdot1sOperMstID.3434	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3434	Integer	0
ibdot1sOperMstID.3435	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3435	Integer	0
ibdot1sOperMstID.3436	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3436	Integer	0
ibdot1sOperMstID.3437	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3437	Integer	0
ibdot1sOperMstID.3438	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3438	Integer	0
ibdot1sOperMstID.3439	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3439	Integer	0
ibdot1sOperMstID.3440	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3440	Integer	0
ibdot1sOperMstID.3441	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3441	Integer	0
ibdot1sOperMstID.3442	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3442	Integer	0
ibdot1sOperMstID.3443	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3443	Integer	0
ibdot1sOperMstID.3444	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3444	Integer	0
ibdot1sOperMstID.3445	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3445	Integer	0
ibdot1sOperMstID.3446	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3446	Integer	0
ibdot1sOperMstID.3447	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3447	Integer	0
ibdot1sOperMstID.3448	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3448	Integer	0
ibdot1sOperMstID.3449	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3449	Integer	0
ibdot1sOperMstID.3450	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3450	Integer	0
ibdot1sOperMstID.3451	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3451	Integer	0
ibdot1sOperMstID.3452	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3452	Integer	0
ibdot1sOperMstID.3453	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3453	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.3454	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3454	Integer	0
ibdot1sOperMstID.3455	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3455	Integer	0
ibdot1sOperMstID.3456	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3456	Integer	0
ibdot1sOperMstID.3457	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3457	Integer	0
ibdot1sOperMstID.3458	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3458	Integer	0
ibdot1sOperMstID.3459	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3459	Integer	0
ibdot1sOperMstID.3460	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3460	Integer	0
ibdot1sOperMstID.3461	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3461	Integer	0
ibdot1sOperMstID.3462	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3462	Integer	0
ibdot1sOperMstID.3463	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3463	Integer	0
ibdot1sOperMstID.3464	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3464	Integer	0
ibdot1sOperMstID.3465	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3465	Integer	0
ibdot1sOperMstID.3466	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3466	Integer	0
ibdot1sOperMstID.3467	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3467	Integer	0
ibdot1sOperMstID.3468	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3468	Integer	0
ibdot1sOperMstID.3469	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3469	Integer	0
ibdot1sOperMstID.3470	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3470	Integer	0
ibdot1sOperMstID.3471	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3471	Integer	0
ibdot1sOperMstID.3472	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3472	Integer	0
ibdot1sOperMstID.3473	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3473	Integer	0
ibdot1sOperMstID.3474	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3474	Integer	0
ibdot1sOperMstID.3475	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3475	Integer	0
ibdot1sOperMstID.3476	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3476	Integer	0
ibdot1sOperMstID.3477	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3477	Integer	0
ibdot1sOperMstID.3478	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3478	Integer	0
ibdot1sOperMstID.3479	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3479	Integer	0
ibdot1sOperMstID.3480	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3480	Integer	0
ibdot1sOperMstID.3481	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3481	Integer	0
ibdot1sOperMstID.3482	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3482	Integer	0
ibdot1sOperMstID.3483	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3483	Integer	0
ibdot1sOperMstID.3484	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3484	Integer	0
ibdot1sOperMstID.3485	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3485	Integer	0
ibdot1sOperMstID.3486	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3486	Integer	0
ibdot1sOperMstID.3487	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3487	Integer	0
ibdot1sOperMstID.3488	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3488	Integer	0
ibdot1sOperMstID.3489	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3489	Integer	0
ibdot1sOperMstID.3490	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3490	Integer	0
ibdot1sOperMstID.3491	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3491	Integer	0
ibdot1sOperMstID.3492	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3492	Integer	0
ibdot1sOperMstID.3493	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3493	Integer	0
ibdot1sOperMstID.3494	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3494	Integer	0
ibdot1sOperMstID.3495	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3495	Integer	0
ibdot1sOperMstID.3496	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3496	Integer	0



Name	OID	Value Type	Value Example
ibdot1sOperMstID.3497	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3497	Integer	0
ibdot1sOperMstID.3498	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3498	Integer	0
ibdot1sOperMstID.3499	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3499	Integer	0
ibdot1sOperMstID.3500	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3500	Integer	0
ibdot1sOperMstID.3501	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3501	Integer	0
ibdot1sOperMstID.3502	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3502	Integer	0
ibdot1sOperMstID.3503	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3503	Integer	0
ibdot1sOperMstID.3504	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3504	Integer	0
ibdot1sOperMstID.3505	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3505	Integer	0
ibdot1sOperMstID.3506	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3506	Integer	0
ibdot1sOperMstID.3507	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3507	Integer	0
ibdot1sOperMstID.3508	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3508	Integer	0
ibdot1sOperMstID.3509	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3509	Integer	0
ibdot1sOperMstID.3510	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3510	Integer	0
ibdot1sOperMstID.3511	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3511	Integer	0
ibdot1sOperMstID.3512	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3512	Integer	0
ibdot1sOperMstID.3513	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3513	Integer	0
ibdot1sOperMstID.3514	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3514	Integer	0
ibdot1sOperMstID.3515	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3515	Integer	0
ibdot1sOperMstID.3516	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3516	Integer	0
ibdot1sOperMstID.3517	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3517	Integer	0
ibdot1sOperMstID.3518	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3518	Integer	0
ibdot1sOperMstID.3519	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3519	Integer	0
ibdot1sOperMstID.3520	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3520	Integer	0
ibdot1sOperMstID.3521	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3521	Integer	0
ibdot1sOperMstID.3522	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3522	Integer	0
ibdot1sOperMstID.3523	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3523	Integer	0
ibdot1sOperMstID.3524	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3524	Integer	0
ibdot1sOperMstID.3525	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3525	Integer	0
ibdot1sOperMstID.3526	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3526	Integer	0
ibdot1sOperMstID.3527	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3527	Integer	0
ibdot1sOperMstID.3528	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3528	Integer	0
ibdot1sOperMstID.3529	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3529	Integer	0
ibdot1sOperMstID.3530	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3530	Integer	0
ibdot1sOperMstID.3531	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3531	Integer	0
ibdot1sOperMstID.3532	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3532	Integer	0
ibdot1sOperMstID.3533	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3533	Integer	0
ibdot1sOperMstID.3534	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3534	Integer	0
ibdot1sOperMstID.3535	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3535	Integer	0
ibdot1sOperMstID.3536	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3536	Integer	0
ibdot1sOperMstID.3537	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3537	Integer	0
ibdot1sOperMstID.3538	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3538	Integer	0
ibdot1sOperMstID.3539	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3539	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.3540	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3540	Integer	0
ibdot1sOperMstID.3541	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3541	Integer	0
ibdot1sOperMstID.3542	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3542	Integer	0
ibdot1sOperMstID.3543	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3543	Integer	0
ibdot1sOperMstID.3544	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3544	Integer	0
ibdot1sOperMstID.3545	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3545	Integer	0
ibdot1sOperMstID.3546	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3546	Integer	0
ibdot1sOperMstID.3547	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3547	Integer	0
ibdot1sOperMstID.3548	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3548	Integer	0
ibdot1sOperMstID.3549	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3549	Integer	0
ibdot1sOperMstID.3550	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3550	Integer	0
ibdot1sOperMstID.3551	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3551	Integer	0
ibdot1sOperMstID.3552	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3552	Integer	0
ibdot1sOperMstID.3553	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3553	Integer	0
ibdot1sOperMstID.3554	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3554	Integer	0
ibdot1sOperMstID.3555	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3555	Integer	0
ibdot1sOperMstID.3556	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3556	Integer	0
ibdot1sOperMstID.3557	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3557	Integer	0
ibdot1sOperMstID.3558	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3558	Integer	0
ibdot1sOperMstID.3559	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3559	Integer	0
ibdot1sOperMstID.3560	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3560	Integer	0
ibdot1sOperMstID.3561	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3561	Integer	0
ibdot1sOperMstID.3562	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3562	Integer	0
ibdot1sOperMstID.3563	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3563	Integer	0
ibdot1sOperMstID.3564	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3564	Integer	0
ibdot1sOperMstID.3565	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3565	Integer	0
ibdot1sOperMstID.3566	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3566	Integer	0
ibdot1sOperMstID.3567	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3567	Integer	0
ibdot1sOperMstID.3568	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3568	Integer	0
ibdot1sOperMstID.3569	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3569	Integer	0
ibdot1sOperMstID.3570	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3570	Integer	0
ibdot1sOperMstID.3571	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3571	Integer	0
ibdot1sOperMstID.3572	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3572	Integer	0
ibdot1sOperMstID.3573	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3573	Integer	0
ibdot1sOperMstID.3574	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3574	Integer	0
ibdot1sOperMstID.3575	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3575	Integer	0
ibdot1sOperMstID.3576	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3576	Integer	0
ibdot1sOperMstID.3577	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3577	Integer	0
ibdot1sOperMstID.3578	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3578	Integer	0
ibdot1sOperMstID.3579	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3579	Integer	0
ibdot1sOperMstID.3580	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3580	Integer	0
ibdot1sOperMstID.3581	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3581	Integer	0
ibdot1sOperMstID.3582	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3582	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.3583	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3583	Integer	0
ibdot1sOperMstID.3584	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3584	Integer	0
ibdot1sOperMstID.3585	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3585	Integer	0
ibdot1sOperMstID.3586	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3586	Integer	0
ibdot1sOperMstID.3587	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3587	Integer	0
ibdot1sOperMstID.3588	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3588	Integer	0
ibdot1sOperMstID.3589	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3589	Integer	0
ibdot1sOperMstID.3590	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3590	Integer	0
ibdot1sOperMstID.3591	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3591	Integer	0
ibdot1sOperMstID.3592	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3592	Integer	0
ibdot1sOperMstID.3593	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3593	Integer	0
ibdot1sOperMstID.3594	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3594	Integer	0
ibdot1sOperMstID.3595	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3595	Integer	0
ibdot1sOperMstID.3596	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3596	Integer	0
ibdot1sOperMstID.3597	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3597	Integer	0
ibdot1sOperMstID.3598	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3598	Integer	0
ibdot1sOperMstID.3599	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3599	Integer	0
ibdot1sOperMstID.3600	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3600	Integer	0
ibdot1sOperMstID.3601	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3601	Integer	0
ibdot1sOperMstID.3602	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3602	Integer	0
ibdot1sOperMstID.3603	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3603	Integer	0
ibdot1sOperMstID.3604	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3604	Integer	0
ibdot1sOperMstID.3605	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3605	Integer	0
ibdot1sOperMstID.3606	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3606	Integer	0
ibdot1sOperMstID.3607	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3607	Integer	0
ibdot1sOperMstID.3608	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3608	Integer	0
ibdot1sOperMstID.3609	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3609	Integer	0
ibdot1sOperMstID.3610	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3610	Integer	0
ibdot1sOperMstID.3611	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3611	Integer	0
ibdot1sOperMstID.3612	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3612	Integer	0
ibdot1sOperMstID.3613	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3613	Integer	0
ibdot1sOperMstID.3614	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3614	Integer	0
ibdot1sOperMstID.3615	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3615	Integer	0
ibdot1sOperMstID.3616	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3616	Integer	0
ibdot1sOperMstID.3617	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3617	Integer	0
ibdot1sOperMstID.3618	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3618	Integer	0
ibdot1sOperMstID.3619	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3619	Integer	0
ibdot1sOperMstID.3620	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3620	Integer	0
ibdot1sOperMstID.3621	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3621	Integer	0
ibdot1sOperMstID.3622	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3622	Integer	0
ibdot1sOperMstID.3623	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3623	Integer	0
ibdot1sOperMstID.3624	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3624	Integer	0
ibdot1sOperMstID.3625	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3625	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.3626	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3626	Integer	0
ibdot1sOperMstID.3627	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3627	Integer	0
ibdot1sOperMstID.3628	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3628	Integer	0
ibdot1sOperMstID.3629	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3629	Integer	0
ibdot1sOperMstID.3630	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3630	Integer	0
ibdot1sOperMstID.3631	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3631	Integer	0
ibdot1sOperMstID.3632	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3632	Integer	0
ibdot1sOperMstID.3633	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3633	Integer	0
ibdot1sOperMstID.3634	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3634	Integer	0
ibdot1sOperMstID.3635	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3635	Integer	0
ibdot1sOperMstID.3636	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3636	Integer	0
ibdot1sOperMstID.3637	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3637	Integer	0
ibdot1sOperMstID.3638	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3638	Integer	0
ibdot1sOperMstID.3639	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3639	Integer	0
ibdot1sOperMstID.3640	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3640	Integer	0
ibdot1sOperMstID.3641	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3641	Integer	0
ibdot1sOperMstID.3642	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3642	Integer	0
ibdot1sOperMstID.3643	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3643	Integer	0
ibdot1sOperMstID.3644	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3644	Integer	0
ibdot1sOperMstID.3645	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3645	Integer	0
ibdot1sOperMstID.3646	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3646	Integer	0
ibdot1sOperMstID.3647	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3647	Integer	0
ibdot1sOperMstID.3648	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3648	Integer	0
ibdot1sOperMstID.3649	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3649	Integer	0
ibdot1sOperMstID.3650	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3650	Integer	0
ibdot1sOperMstID.3651	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3651	Integer	0
ibdot1sOperMstID.3652	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3652	Integer	0
ibdot1sOperMstID.3653	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3653	Integer	0
ibdot1sOperMstID.3654	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3654	Integer	0
ibdot1sOperMstID.3655	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3655	Integer	0
ibdot1sOperMstID.3656	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3656	Integer	0
ibdot1sOperMstID.3657	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3657	Integer	0
ibdot1sOperMstID.3658	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3658	Integer	0
ibdot1sOperMstID.3659	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3659	Integer	0
ibdot1sOperMstID.3660	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3660	Integer	0
ibdot1sOperMstID.3661	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3661	Integer	0
ibdot1sOperMstID.3662	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3662	Integer	0
ibdot1sOperMstID.3663	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3663	Integer	0
ibdot1sOperMstID.3664	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3664	Integer	0
ibdot1sOperMstID.3665	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3665	Integer	0
ibdot1sOperMstID.3666	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3666	Integer	0
ibdot1sOperMstID.3667	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3667	Integer	0
ibdot1sOperMstID.3668	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3668	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.3669	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3669	Integer	0
ibdot1sOperMstID.3670	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3670	Integer	0
ibdot1sOperMstID.3671	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3671	Integer	0
ibdot1sOperMstID.3672	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3672	Integer	0
ibdot1sOperMstID.3673	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3673	Integer	0
ibdot1sOperMstID.3674	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3674	Integer	0
ibdot1sOperMstID.3675	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3675	Integer	0
ibdot1sOperMstID.3676	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3676	Integer	0
ibdot1sOperMstID.3677	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3677	Integer	0
ibdot1sOperMstID.3678	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3678	Integer	0
ibdot1sOperMstID.3679	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3679	Integer	0
ibdot1sOperMstID.3680	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3680	Integer	0
ibdot1sOperMstID.3681	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3681	Integer	0
ibdot1sOperMstID.3682	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3682	Integer	0
ibdot1sOperMstID.3683	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3683	Integer	0
ibdot1sOperMstID.3684	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3684	Integer	0
ibdot1sOperMstID.3685	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3685	Integer	0
ibdot1sOperMstID.3686	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3686	Integer	0
ibdot1sOperMstID.3687	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3687	Integer	0
ibdot1sOperMstID.3688	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3688	Integer	0
ibdot1sOperMstID.3689	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3689	Integer	0
ibdot1sOperMstID.3690	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3690	Integer	0
ibdot1sOperMstID.3691	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3691	Integer	0
ibdot1sOperMstID.3692	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3692	Integer	0
ibdot1sOperMstID.3693	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3693	Integer	0
ibdot1sOperMstID.3694	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3694	Integer	0
ibdot1sOperMstID.3695	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3695	Integer	0
ibdot1sOperMstID.3696	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3696	Integer	0
ibdot1sOperMstID.3697	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3697	Integer	0
ibdot1sOperMstID.3698	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3698	Integer	0
ibdot1sOperMstID.3699	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3699	Integer	0
ibdot1sOperMstID.3700	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3700	Integer	0
ibdot1sOperMstID.3701	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3701	Integer	0
ibdot1sOperMstID.3702	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3702	Integer	0
ibdot1sOperMstID.3703	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3703	Integer	0
ibdot1sOperMstID.3704	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3704	Integer	0
ibdot1sOperMstID.3705	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3705	Integer	0
ibdot1sOperMstID.3706	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3706	Integer	0
ibdot1sOperMstID.3707	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3707	Integer	0
ibdot1sOperMstID.3708	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3708	Integer	0
ibdot1sOperMstID.3709	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3709	Integer	0
ibdot1sOperMstID.3710	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3710	Integer	0
ibdot1sOperMstID.3711	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3711	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.3712	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3712	Integer	0
ibdot1sOperMstID.3713	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3713	Integer	0
ibdot1sOperMstID.3714	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3714	Integer	0
ibdot1sOperMstID.3715	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3715	Integer	0
ibdot1sOperMstID.3716	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3716	Integer	0
ibdot1sOperMstID.3717	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3717	Integer	0
ibdot1sOperMstID.3718	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3718	Integer	0
ibdot1sOperMstID.3719	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3719	Integer	0
ibdot1sOperMstID.3720	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3720	Integer	0
ibdot1sOperMstID.3721	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3721	Integer	0
ibdot1sOperMstID.3722	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3722	Integer	0
ibdot1sOperMstID.3723	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3723	Integer	0
ibdot1sOperMstID.3724	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3724	Integer	0
ibdot1sOperMstID.3725	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3725	Integer	0
ibdot1sOperMstID.3726	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3726	Integer	0
ibdot1sOperMstID.3727	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3727	Integer	0
ibdot1sOperMstID.3728	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3728	Integer	0
ibdot1sOperMstID.3729	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3729	Integer	0
ibdot1sOperMstID.3730	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3730	Integer	0
ibdot1sOperMstID.3731	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3731	Integer	0
ibdot1sOperMstID.3732	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3732	Integer	0
ibdot1sOperMstID.3733	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3733	Integer	0
ibdot1sOperMstID.3734	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3734	Integer	0
ibdot1sOperMstID.3735	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3735	Integer	0
ibdot1sOperMstID.3736	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3736	Integer	0
ibdot1sOperMstID.3737	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3737	Integer	0
ibdot1sOperMstID.3738	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3738	Integer	0
ibdot1sOperMstID.3739	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3739	Integer	0
ibdot1sOperMstID.3740	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3740	Integer	0
ibdot1sOperMstID.3741	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3741	Integer	0
ibdot1sOperMstID.3742	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3742	Integer	0
ibdot1sOperMstID.3743	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3743	Integer	0
ibdot1sOperMstID.3744	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3744	Integer	0
ibdot1sOperMstID.3745	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3745	Integer	0
ibdot1sOperMstID.3746	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3746	Integer	0
ibdot1sOperMstID.3747	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3747	Integer	0
ibdot1sOperMstID.3748	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3748	Integer	0
ibdot1sOperMstID.3749	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3749	Integer	0
ibdot1sOperMstID.3750	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3750	Integer	0
ibdot1sOperMstID.3751	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3751	Integer	0
ibdot1sOperMstID.3752	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3752	Integer	0
ibdot1sOperMstID.3753	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3753	Integer	0
ibdot1sOperMstID.3754	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3754	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.3755	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3755	Integer	0
ibdot1sOperMstID.3756	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3756	Integer	0
ibdot1sOperMstID.3757	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3757	Integer	0
ibdot1sOperMstID.3758	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3758	Integer	0
ibdot1sOperMstID.3759	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3759	Integer	0
ibdot1sOperMstID.3760	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3760	Integer	0
ibdot1sOperMstID.3761	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3761	Integer	0
ibdot1sOperMstID.3762	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3762	Integer	0
ibdot1sOperMstID.3763	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3763	Integer	0
ibdot1sOperMstID.3764	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3764	Integer	0
ibdot1sOperMstID.3765	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3765	Integer	0
ibdot1sOperMstID.3766	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3766	Integer	0
ibdot1sOperMstID.3767	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3767	Integer	0
ibdot1sOperMstID.3768	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3768	Integer	0
ibdot1sOperMstID.3769	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3769	Integer	0
ibdot1sOperMstID.3770	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3770	Integer	0
ibdot1sOperMstID.3771	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3771	Integer	0
ibdot1sOperMstID.3772	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3772	Integer	0
ibdot1sOperMstID.3773	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3773	Integer	0
ibdot1sOperMstID.3774	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3774	Integer	0
ibdot1sOperMstID.3775	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3775	Integer	0
ibdot1sOperMstID.3776	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3776	Integer	0
ibdot1sOperMstID.3777	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3777	Integer	0
ibdot1sOperMstID.3778	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3778	Integer	0
ibdot1sOperMstID.3779	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3779	Integer	0
ibdot1sOperMstID.3780	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3780	Integer	0
ibdot1sOperMstID.3781	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3781	Integer	0
ibdot1sOperMstID.3782	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3782	Integer	0
ibdot1sOperMstID.3783	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3783	Integer	0
ibdot1sOperMstID.3784	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3784	Integer	0
ibdot1sOperMstID.3785	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3785	Integer	0
ibdot1sOperMstID.3786	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3786	Integer	0
ibdot1sOperMstID.3787	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3787	Integer	0
ibdot1sOperMstID.3788	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3788	Integer	0
ibdot1sOperMstID.3789	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3789	Integer	0
ibdot1sOperMstID.3790	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3790	Integer	0
ibdot1sOperMstID.3791	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3791	Integer	0
ibdot1sOperMstID.3792	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3792	Integer	0
ibdot1sOperMstID.3793	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3793	Integer	0
ibdot1sOperMstID.3794	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3794	Integer	0
ibdot1sOperMstID.3795	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3795	Integer	0
ibdot1sOperMstID.3796	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3796	Integer	0
ibdot1sOperMstID.3797	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3797	Integer	0



Name	OID	Value Type	Value Example
ibdot1sOperMstID.3798	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3798	Integer	0
ibdot1sOperMstID.3799	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3799	Integer	0
ibdot1sOperMstID.3800	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3800	Integer	0
ibdot1sOperMstID.3801	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3801	Integer	0
ibdot1sOperMstID.3802	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3802	Integer	0
ibdot1sOperMstID.3803	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3803	Integer	0
ibdot1sOperMstID.3804	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3804	Integer	0
ibdot1sOperMstID.3805	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3805	Integer	0
ibdot1sOperMstID.3806	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3806	Integer	0
ibdot1sOperMstID.3807	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3807	Integer	0
ibdot1sOperMstID.3808	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3808	Integer	0
ibdot1sOperMstID.3809	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3809	Integer	0
ibdot1sOperMstID.3810	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3810	Integer	0
ibdot1sOperMstID.3811	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3811	Integer	0
ibdot1sOperMstID.3812	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3812	Integer	0
ibdot1sOperMstID.3813	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3813	Integer	0
ibdot1sOperMstID.3814	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3814	Integer	0
ibdot1sOperMstID.3815	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3815	Integer	0
ibdot1sOperMstID.3816	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3816	Integer	0
ibdot1sOperMstID.3817	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3817	Integer	0
ibdot1sOperMstID.3818	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3818	Integer	0
ibdot1sOperMstID.3819	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3819	Integer	0
ibdot1sOperMstID.3820	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3820	Integer	0
ibdot1sOperMstID.3821	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3821	Integer	0
ibdot1sOperMstID.3822	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3822	Integer	0
ibdot1sOperMstID.3823	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3823	Integer	0
ibdot1sOperMstID.3824	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3824	Integer	0
ibdot1sOperMstID.3825	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3825	Integer	0
ibdot1sOperMstID.3826	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3826	Integer	0
ibdot1sOperMstID.3827	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3827	Integer	0
ibdot1sOperMstID.3828	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3828	Integer	0
ibdot1sOperMstID.3829	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3829	Integer	0
ibdot1sOperMstID.3830	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3830	Integer	0
ibdot1sOperMstID.3831	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3831	Integer	0
ibdot1sOperMstID.3832	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3832	Integer	0
ibdot1sOperMstID.3833	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3833	Integer	0
ibdot1sOperMstID.3834	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3834	Integer	0
ibdot1sOperMstID.3835	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3835	Integer	0
ibdot1sOperMstID.3836	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3836	Integer	0
ibdot1sOperMstID.3837	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3837	Integer	0
ibdot1sOperMstID.3838	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3838	Integer	0
ibdot1sOperMstID.3839	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3839	Integer	0
ibdot1sOperMstID.3840	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3840	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.3841	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3841	Integer	0
ibdot1sOperMstID.3842	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3842	Integer	0
ibdot1sOperMstID.3843	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3843	Integer	0
ibdot1sOperMstID.3844	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3844	Integer	0
ibdot1sOperMstID.3845	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3845	Integer	0
ibdot1sOperMstID.3846	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3846	Integer	0
ibdot1sOperMstID.3847	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3847	Integer	0
ibdot1sOperMstID.3848	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3848	Integer	0
ibdot1sOperMstID.3849	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3849	Integer	0
ibdot1sOperMstID.3850	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3850	Integer	0
ibdot1sOperMstID.3851	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3851	Integer	0
ibdot1sOperMstID.3852	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3852	Integer	0
ibdot1sOperMstID.3853	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3853	Integer	0
ibdot1sOperMstID.3854	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3854	Integer	0
ibdot1sOperMstID.3855	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3855	Integer	0
ibdot1sOperMstID.3856	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3856	Integer	0
ibdot1sOperMstID.3857	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3857	Integer	0
ibdot1sOperMstID.3858	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3858	Integer	0
ibdot1sOperMstID.3859	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3859	Integer	0
ibdot1sOperMstID.3860	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3860	Integer	0
ibdot1sOperMstID.3861	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3861	Integer	0
ibdot1sOperMstID.3862	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3862	Integer	0
ibdot1sOperMstID.3863	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3863	Integer	0
ibdot1sOperMstID.3864	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3864	Integer	0
ibdot1sOperMstID.3865	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3865	Integer	0
ibdot1sOperMstID.3866	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3866	Integer	0
ibdot1sOperMstID.3867	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3867	Integer	0
ibdot1sOperMstID.3868	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3868	Integer	0
ibdot1sOperMstID.3869	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3869	Integer	0
ibdot1sOperMstID.3870	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3870	Integer	0
ibdot1sOperMstID.3871	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3871	Integer	0
ibdot1sOperMstID.3872	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3872	Integer	0
ibdot1sOperMstID.3873	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3873	Integer	0
ibdot1sOperMstID.3874	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3874	Integer	0
ibdot1sOperMstID.3875	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3875	Integer	0
ibdot1sOperMstID.3876	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3876	Integer	0
ibdot1sOperMstID.3877	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3877	Integer	0
ibdot1sOperMstID.3878	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3878	Integer	0
ibdot1sOperMstID.3879	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3879	Integer	0
ibdot1sOperMstID.3880	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3880	Integer	0
ibdot1sOperMstID.3881	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3881	Integer	0
ibdot1sOperMstID.3882	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3882	Integer	0
ibdot1sOperMstID.3883	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3883	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.3884	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3884	Integer	0
ibdot1sOperMstID.3885	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3885	Integer	0
ibdot1sOperMstID.3886	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3886	Integer	0
ibdot1sOperMstID.3887	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3887	Integer	0
ibdot1sOperMstID.3888	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3888	Integer	0
ibdot1sOperMstID.3889	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3889	Integer	0
ibdot1sOperMstID.3890	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3890	Integer	0
ibdot1sOperMstID.3891	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3891	Integer	0
ibdot1sOperMstID.3892	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3892	Integer	0
ibdot1sOperMstID.3893	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3893	Integer	0
ibdot1sOperMstID.3894	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3894	Integer	0
ibdot1sOperMstID.3895	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3895	Integer	0
ibdot1sOperMstID.3896	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3896	Integer	0
ibdot1sOperMstID.3897	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3897	Integer	0
ibdot1sOperMstID.3898	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3898	Integer	0
ibdot1sOperMstID.3899	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3899	Integer	0
ibdot1sOperMstID.3900	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3900	Integer	0
ibdot1sOperMstID.3901	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3901	Integer	0
ibdot1sOperMstID.3902	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3902	Integer	0
ibdot1sOperMstID.3903	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3903	Integer	0
ibdot1sOperMstID.3904	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3904	Integer	0
ibdot1sOperMstID.3905	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3905	Integer	0
ibdot1sOperMstID.3906	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3906	Integer	0
ibdot1sOperMstID.3907	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3907	Integer	0
ibdot1sOperMstID.3908	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3908	Integer	0
ibdot1sOperMstID.3909	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3909	Integer	0
ibdot1sOperMstID.3910	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3910	Integer	0
ibdot1sOperMstID.3911	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3911	Integer	0
ibdot1sOperMstID.3912	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3912	Integer	0
ibdot1sOperMstID.3913	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3913	Integer	0
ibdot1sOperMstID.3914	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3914	Integer	0
ibdot1sOperMstID.3915	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3915	Integer	0
ibdot1sOperMstID.3916	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3916	Integer	0
ibdot1sOperMstID.3917	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3917	Integer	0
ibdot1sOperMstID.3918	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3918	Integer	0
ibdot1sOperMstID.3919	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3919	Integer	0
ibdot1sOperMstID.3920	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3920	Integer	0
ibdot1sOperMstID.3921	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3921	Integer	0
ibdot1sOperMstID.3922	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3922	Integer	0
ibdot1sOperMstID.3923	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3923	Integer	0
ibdot1sOperMstID.3924	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3924	Integer	0
ibdot1sOperMstID.3925	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3925	Integer	0
ibdot1sOperMstID.3926	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3926	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.3927	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3927	Integer	0
ibdot1sOperMstID.3928	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3928	Integer	0
ibdot1sOperMstID.3929	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3929	Integer	0
ibdot1sOperMstID.3930	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3930	Integer	0
ibdot1sOperMstID.3931	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3931	Integer	0
ibdot1sOperMstID.3932	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3932	Integer	0
ibdot1sOperMstID.3933	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3933	Integer	0
ibdot1sOperMstID.3934	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3934	Integer	0
ibdot1sOperMstID.3935	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3935	Integer	0
ibdot1sOperMstID.3936	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3936	Integer	0
ibdot1sOperMstID.3937	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3937	Integer	0
ibdot1sOperMstID.3938	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3938	Integer	0
ibdot1sOperMstID.3939	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3939	Integer	0
ibdot1sOperMstID.3940	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3940	Integer	0
ibdot1sOperMstID.3941	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3941	Integer	0
ibdot1sOperMstID.3942	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3942	Integer	0
ibdot1sOperMstID.3943	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3943	Integer	0
ibdot1sOperMstID.3944	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3944	Integer	0
ibdot1sOperMstID.3945	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3945	Integer	0
ibdot1sOperMstID.3946	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3946	Integer	0
ibdot1sOperMstID.3947	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3947	Integer	0
ibdot1sOperMstID.3948	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3948	Integer	0
ibdot1sOperMstID.3949	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3949	Integer	0
ibdot1sOperMstID.3950	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3950	Integer	0
ibdot1sOperMstID.3951	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3951	Integer	0
ibdot1sOperMstID.3952	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3952	Integer	0
ibdot1sOperMstID.3953	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3953	Integer	0
ibdot1sOperMstID.3954	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3954	Integer	0
ibdot1sOperMstID.3955	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3955	Integer	0
ibdot1sOperMstID.3956	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3956	Integer	0
ibdot1sOperMstID.3957	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3957	Integer	0
ibdot1sOperMstID.3958	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3958	Integer	0
ibdot1sOperMstID.3959	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3959	Integer	0
ibdot1sOperMstID.3960	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3960	Integer	0
ibdot1sOperMstID.3961	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3961	Integer	0
ibdot1sOperMstID.3962	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3962	Integer	0
ibdot1sOperMstID.3963	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3963	Integer	0
ibdot1sOperMstID.3964	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3964	Integer	0
ibdot1sOperMstID.3965	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3965	Integer	0
ibdot1sOperMstID.3966	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3966	Integer	0
ibdot1sOperMstID.3967	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3967	Integer	0
ibdot1sOperMstID.3968	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3968	Integer	0
ibdot1sOperMstID.3969	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3969	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.3970	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3970	Integer	0
ibdot1sOperMstID.3971	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3971	Integer	0
ibdot1sOperMstID.3972	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3972	Integer	0
ibdot1sOperMstID.3973	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3973	Integer	0
ibdot1sOperMstID.3974	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3974	Integer	0
ibdot1sOperMstID.3975	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3975	Integer	0
ibdot1sOperMstID.3976	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3976	Integer	0
ibdot1sOperMstID.3977	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3977	Integer	0
ibdot1sOperMstID.3978	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3978	Integer	0
ibdot1sOperMstID.3979	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3979	Integer	0
ibdot1sOperMstID.3980	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3980	Integer	0
ibdot1sOperMstID.3981	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3981	Integer	0
ibdot1sOperMstID.3982	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3982	Integer	0
ibdot1sOperMstID.3983	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3983	Integer	0
ibdot1sOperMstID.3984	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3984	Integer	0
ibdot1sOperMstID.3985	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3985	Integer	0
ibdot1sOperMstID.3986	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3986	Integer	0
ibdot1sOperMstID.3987	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3987	Integer	0
ibdot1sOperMstID.3988	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3988	Integer	0
ibdot1sOperMstID.3989	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3989	Integer	0
ibdot1sOperMstID.3990	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3990	Integer	0
ibdot1sOperMstID.3991	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3991	Integer	0
ibdot1sOperMstID.3992	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3992	Integer	0
ibdot1sOperMstID.3993	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3993	Integer	0
ibdot1sOperMstID.3994	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3994	Integer	0
ibdot1sOperMstID.3995	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3995	Integer	0
ibdot1sOperMstID.3996	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3996	Integer	0
ibdot1sOperMstID.3997	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3997	Integer	0
ibdot1sOperMstID.3998	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3998	Integer	0
ibdot1sOperMstID.3999	.1.3.6.1.4.1.26138.8.35.14.18.1.3.3999	Integer	0
ibdot1sOperMstID.4000	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4000	Integer	0
ibdot1sOperMstID.4001	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4001	Integer	0
ibdot1sOperMstID.4002	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4002	Integer	0
ibdot1sOperMstID.4003	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4003	Integer	0
ibdot1sOperMstID.4004	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4004	Integer	0
ibdot1sOperMstID.4005	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4005	Integer	0
ibdot1sOperMstID.4006	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4006	Integer	0
ibdot1sOperMstID.4007	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4007	Integer	0
ibdot1sOperMstID.4008	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4008	Integer	0
ibdot1sOperMstID.4009	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4009	Integer	0
ibdot1sOperMstID.4010	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4010	Integer	0
ibdot1sOperMstID.4011	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4011	Integer	0
ibdot1sOperMstID.4012	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4012	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.4013	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4013	Integer	0
ibdot1sOperMstID.4014	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4014	Integer	0
ibdot1sOperMstID.4015	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4015	Integer	0
ibdot1sOperMstID.4016	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4016	Integer	0
ibdot1sOperMstID.4017	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4017	Integer	0
ibdot1sOperMstID.4018	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4018	Integer	0
ibdot1sOperMstID.4019	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4019	Integer	0
ibdot1sOperMstID.4020	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4020	Integer	0
ibdot1sOperMstID.4021	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4021	Integer	0
ibdot1sOperMstID.4022	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4022	Integer	0
ibdot1sOperMstID.4023	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4023	Integer	0
ibdot1sOperMstID.4024	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4024	Integer	0
ibdot1sOperMstID.4025	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4025	Integer	0
ibdot1sOperMstID.4026	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4026	Integer	0
ibdot1sOperMstID.4027	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4027	Integer	0
ibdot1sOperMstID.4028	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4028	Integer	0
ibdot1sOperMstID.4029	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4029	Integer	0
ibdot1sOperMstID.4030	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4030	Integer	0
ibdot1sOperMstID.4031	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4031	Integer	0
ibdot1sOperMstID.4032	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4032	Integer	0
ibdot1sOperMstID.4033	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4033	Integer	0
ibdot1sOperMstID.4034	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4034	Integer	0
ibdot1sOperMstID.4035	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4035	Integer	0
ibdot1sOperMstID.4036	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4036	Integer	0
ibdot1sOperMstID.4037	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4037	Integer	0
ibdot1sOperMstID.4038	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4038	Integer	0
ibdot1sOperMstID.4039	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4039	Integer	0
ibdot1sOperMstID.4040	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4040	Integer	0
ibdot1sOperMstID.4041	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4041	Integer	0
ibdot1sOperMstID.4042	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4042	Integer	0
ibdot1sOperMstID.4043	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4043	Integer	0
ibdot1sOperMstID.4044	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4044	Integer	0
ibdot1sOperMstID.4045	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4045	Integer	0
ibdot1sOperMstID.4046	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4046	Integer	0
ibdot1sOperMstID.4047	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4047	Integer	0
ibdot1sOperMstID.4048	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4048	Integer	0
ibdot1sOperMstID.4049	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4049	Integer	0
ibdot1sOperMstID.4050	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4050	Integer	0
ibdot1sOperMstID.4051	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4051	Integer	0
ibdot1sOperMstID.4052	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4052	Integer	0
ibdot1sOperMstID.4053	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4053	Integer	0
ibdot1sOperMstID.4054	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4054	Integer	0
ibdot1sOperMstID.4055	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4055	Integer	0

Name	OID	Value Type	Value Example
ibdot1sOperMstID.4056	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4056	Integer	0
ibdot1sOperMstID.4057	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4057	Integer	0
ibdot1sOperMstID.4058	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4058	Integer	0
ibdot1sOperMstID.4059	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4059	Integer	0
ibdot1sOperMstID.4060	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4060	Integer	0
ibdot1sOperMstID.4061	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4061	Integer	0
ibdot1sOperMstID.4062	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4062	Integer	0
ibdot1sOperMstID.4063	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4063	Integer	0
ibdot1sOperMstID.4064	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4064	Integer	0
ibdot1sOperMstID.4065	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4065	Integer	0
ibdot1sOperMstID.4066	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4066	Integer	0
ibdot1sOperMstID.4067	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4067	Integer	0
ibdot1sOperMstID.4068	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4068	Integer	0
ibdot1sOperMstID.4069	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4069	Integer	0
ibdot1sOperMstID.4070	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4070	Integer	0
ibdot1sOperMstID.4071	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4071	Integer	0
ibdot1sOperMstID.4072	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4072	Integer	0
ibdot1sOperMstID.4073	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4073	Integer	0
ibdot1sOperMstID.4074	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4074	Integer	0
ibdot1sOperMstID.4075	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4075	Integer	0
ibdot1sOperMstID.4076	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4076	Integer	0
ibdot1sOperMstID.4077	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4077	Integer	0
ibdot1sOperMstID.4078	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4078	Integer	0
ibdot1sOperMstID.4079	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4079	Integer	0
ibdot1sOperMstID.4080	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4080	Integer	0
ibdot1sOperMstID.4081	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4081	Integer	0
ibdot1sOperMstID.4082	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4082	Integer	0
ibdot1sOperMstID.4083	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4083	Integer	0
ibdot1sOperMstID.4084	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4084	Integer	0
ibdot1sOperMstID.4085	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4085	Integer	0
ibdot1sOperMstID.4086	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4086	Integer	0
ibdot1sOperMstID.4087	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4087	Integer	0
ibdot1sOperMstID.4088	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4088	Integer	0
ibdot1sOperMstID.4089	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4089	Integer	0
ibdot1sOperMstID.4090	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4090	Integer	0
ibdot1sOperMstID.4091	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4091	Integer	0
ibdot1sOperMstID.4092	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4092	Integer	0
ibdot1sOperMstID.4093	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4093	Integer	0
ibdot1sOperMstID.4094	.1.3.6.1.4.1.26138.8.35.14.18.1.3.4094	Integer	0
ibdot1sInstanceID.0	.1.3.6.1.4.1.26138.8.35.14.19.1.1.0	Integer	0
ibdot1sMstiBridgeID.0	.1.3.6.1.4.1.26138.8.35.14.19.1.2.0	OctetString	80-00-14-84-77-95-1D-B0
ibdot1sMstiBridgePriority.0	.1.3.6.1.4.1.26138.8.35.14.19.1.3.0	Integer	32768
ibdot1sMstiDesignedRoot.0	.1.3.6.1.4.1.26138.8.35.14.19.1.4.0	OctetString	40-00-E4-F0-04-73-89-88



Name	OID	Value Type	Value Example
ibdot1sMstiRootPathCost.0	.1.3.6.1.4.1.26138.8.35.14.19.1.5.0	Integer	20080
ibdot1sMstiRootPort.0	.1.3.6.1.4.1.26138.8.35.14.19.1.6.0	Integer	1
ibdot1sMstiRootType.0	.1.3.6.1.4.1.26138.8.35.14.19.1.7.0	Integer	normal (0)
ibdot1sMstiRemainingHops.0	.1.3.6.1.4.1.26138.8.35.14.19.1.8.0	Integer	20
ibdot1sMstiAdminMapped-VlanListLow.0	.1.3.6.1.4.1.26138.8.35.14.19.1.9.0	OctetString	0xFF FF
ibdot1sMstiAdminMapped-VlanListHigh.0	.1.3.6.1.4.1.26138.8.35.14.19.1.10.0	OctetString	0xFF FF
ibdot1sMstiOperMappedVlanListLow.0	.1.3.6.1.4.1.26138.8.35.14.19.1.11.0	OctetString	0xFF FF

Name	OID	Value Type	Value Example
			FF FF
ibdot1sMstiOperMappedVlan-ListHigh.0	1.3.6.1.4.1.26138.8.35.14.19.1.12.0	OctetString	0xFF 3F
ibdot1sMstiPortIndex.0.1	1.3.6.1.4.1.26138.8.35.14.20.1.1.0	Integer	1
ibdot1sMstiState.0.1	1.3.6.1.4.1.26138.8.35.14.20.1.2.0	Integer	forwarding (5)
ibdot1sMstiPortPriority.0.1	1.3.6.1.4.1.26138.8.35.14.20.1.3.0	Integer	128
ibdot1sMstiPathCost.0.1	1.3.6.1.4.1.26138.8.35.14.20.1.4.0	Integer	20
ibdot1sMstiDesignatedRoot.0.1	1.3.6.1.4.1.26138.8.35.14.20.1.5.0	OctetString	40-00-E4-F0-04-73-89-88
ibdot1sMstiDesignatedCost.0.1	1.3.6.1.4.1.26138.8.35.14.20.1.6.0	Integer	20060
ibdot1sMstiDesignatedBridge.0.1	1.3.6.1.4.1.26138.8.35.14.20.1.7.0	OctetString	80-00-14-84-77-83-B1-20
ibdot1sMstiDesignatedPort.0.1	1.3.6.1.4.1.26138.8.35.14.20.1.8.0	OctetString	0x80 02
ibdot1sMstiMasterBridgeID.0.1	1.3.6.1.4.1.26138.8.35.14.20.1.9.0	OctetString	80-00-14-84-77-95-1D-B0
ibdot1sMstiMasterPortCost.0.1	1.3.6.1.4.1.26138.8.35.14.20.1.10.0	Integer	0
ibdot1sMstiStpPortEdge-port.0.1	1.3.6.1.4.1.26138.8.35.14.20.1.11.0	Integer	disabled (2)

Name	OID	Value Type	Value Example
ibdot1sMstiStpPortPointTo-Point.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.12.0	Integer	auto (3)
ibdot1sMstiStpMcheck.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.13.0	Integer	unused (65535)
ibdot1sMstiStpTransLimit.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.14.0	Integer	10
ibdot1sMstiStpRXStpBPDU.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.15.0	Counter32	0
ibdot1sMstiStpTXStpBPDU.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.16.0	Counter32	0
ibdot1sMstiStpRXTCNBPDU.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.17.0	Counter32	0
ibdot1sMstiStpTXTCNBPDU.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.18.0	Counter32	0
ibdot1sMstiStpRXRSTPBPDU.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.19.0	Counter32	0
ibdot1sMstiStpTXRSTPBPDU.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.20.0	Counter32	0
ibdot1sMstiStpRXMSTPBPDU.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.21.0	Counter32	1162
ibdot1sMstiStpTXMSTPBPDU.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.22.0	Counter32	3
ibdot1sMstiStpClearStatistics.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.23.0	Integer	unused (65535)
ibdot1sMstiStpDefaultPortCost.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.24.0	Integer	unused (65535)
ibdot1sMstiStpStatus.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.25.0	Integer	enabled (1)
ibdot1sMstiPortRootGuard.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.26.0	Integer	disabled (2)
ibdot1sMstiPortLoopGuard.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.27.0	Integer	disabled (2)
ibdot1sMstiStpPortSendingBPDUType.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.28.0	Integer	mstp (3)
ibdot1sMstiStpOperPortPointToPoint.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.29.0	Integer	true (1)
ibdot1sMstiStpPortAdminBPDUFmt.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.30.0	Integer	auto (3)
ibdot1sMstiStpPortOperBPDUFmt.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.31.0	Integer	dot1s (2)
ibdot1sMstiStpPortRoleRestriction.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.32.0	Integer	disabled (2)
ibdot1sMstiStpPortTcRestriction.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.33.0	Integer	disabled (2)
ibdot1sMstiStpPortDisputed.0.1	.1.3.6.1.4.1.26138.8.35.14.20.1.34.0	Integer	false (2)
ibdot1sStpPathCostStandard.0	.1.3.6.1.4.1.26138.8.35.14.21.0	Integer	legacy (0)
ibLswLastSwitchDate.0	.1.3.6.1.4.1.26138.8.35.17.1.0	Integer	0
ibLswLastSwitchTime.0	.1.3.6.1.4.1.26138.8.35.17.2.0	Integer	0
ibLswMpuSwitchsNum.0	.1.3.6.1.4.1.26138.8.35.17.3.0	Integer	0
ibLswMainCardBoardStatus.0.1	1.3.6.1.4.1.26138.8.35.17.5.1.1.0.1	Integer	master (1)
ibLswMainCardBoardStatus.0.2	1.3.6.1.4.1.26138.8.35.17.5.1.1.0.2	Integer	process (3)
ibLswMainCardBoardStatus.0.3	1.3.6.1.4.1.26138.8.35.17.5.1.1.0.3	Integer	process (3)

Name	OID	Value Type	Value Example
ibLswMainCardBoardStatus.0.4	1.3.6.1.4.1.26138.8.35.17.5.1.1.0.4	Integer	process (3)
ibLswMainCardBoardStatus.0.5	1.3.6.1.4.1.26138.8.35.17.5.1.1.0.5	Integer	process (3)
ibLswMainCardBoardStatus.0.6	1.3.6.1.4.1.26138.8.35.17.5.1.1.0.6	Integer	process (3)
ibLswMainCardBoardStatus.0.7	1.3.6.1.4.1.26138.8.35.17.5.1.1.0.7	Integer	process (3)
ibLswMainCardBoardStatus.0.8	1.3.6.1.4.1.26138.8.35.17.5.1.1.0.8	Integer	process (3)
ibLswMainCardBoardStatus.0.9	1.3.6.1.4.1.26138.8.35.17.5.1.1.0.9	Integer	process (3)
ibLswMainCardBoardStatus.0.10	1.3.6.1.4.1.26138.8.35.17.5.1.1.0.10	Integer	process (3)
ibLswSysIpAddr.0	.1.3.6.1.4.1.26138.8.35.18.1.1.0	IpAddress	10.100.65.116
ibLswSysIpMask.0	.1.3.6.1.4.1.26138.8.35.18.1.2.0	IpAddress	255.255.255.0
ibLswSysCpuRatio.0	.1.3.6.1.4.1.26138.8.35.18.1.3.0	Integer	16
ibLswSysVersion.0	.1.3.6.1.4.1.26138.8.35.18.1.4.0	OctetString	7.1.070
ibLswSysTime.0	.1.3.6.1.4.1.26138.8.35.18.1.5.0	OctetString	2024-8-30,18:27:11.7,-3:0
ibLswSysPhyMemory.0	.1.3.6.1.4.1.26138.8.35.18.1.13.0	Gauge	1073741824
ibLswSysMemory.0	.1.3.6.1.4.1.26138.8.35.18.1.14.0	Gauge	1015533568
ibLswSysMemoryUsed.0	.1.3.6.1.4.1.26138.8.35.18.1.15.0	Gauge	463859712
ibLswSysMemoryRatio.0	.1.3.6.1.4.1.26138.8.35.18.1.16.0	Gauge	44
ibSysProductName.0	.1.3.6.1.4.1.26138.8.35.18.1.23.0	OctetString	INTELBRAS SC 3570-48GP-6X
ibSysProductVersion.0	.1.3.6.1.4.1.26138.8.35.18.1.24.0	OctetString	R1124
ibLswFrameIndex.0	1.3.6.1.4.1.26138.8.35.18.4.2.1.1.0	Integer	0
ibLswFrameType.0	1.3.6.1.4.1.26138.8.35.18.4.2.1.2.0	Integer	0
ibLswFrameDesc.0	1.3.6.1.4.1.26138.8.35.18.4.2.1.3.0	OctetString	Normal
ibLswSlotNumber.0	1.3.6.1.4.1.26138.8.35.18.4.2.1.4.0	Integer	10
ibLswFrameAdminStatus.0	1.3.6.1.4.1.26138.8.35.18.4.2.1.5.0	Integer	normal (1)
ibLswSlotIndex.0.1	.1.3.6.1.4.1.26138.8.35.18.4.3.1.1.0.1	Integer	1
ibLswSlotType.0.1	.1.3.6.1.4.1.26138.8.35.18.4.3.1.2.0.1	Integer	type-1000BASE-TX (4)
ibLswSlotDesc.0.1	.1.3.6.1.4.1.26138.8.35.18.4.3.1.3.0.1	OctetString	MODULE LEVEL1
ibLswSlotCpuRatio.0.1	.1.3.6.1.4.1.26138.8.35.18.4.3.1.4.0.1	Integer	16
ibLswSlotPcbVersion.0.1	.1.3.6.1.4.1.26138.8.35.18.4.3.1.5.0.1	OctetString	Ver.
ibLswSlotSoftwareVersion.0.1	.1.3.6.1.4.1.26138.8.35.18.4.3.1.6.0.1	OctetString	V900R001B01D094
ibLswSubslotNumber.0.1	.1.3.6.1.4.1.26138.8.35.18.4.3.1.7.0.1	Integer	1
ibLswSlotAdminStatus.0.1	.1.3.6.1.4.1.26138.8.35.18.4.3.1.8.0.1	Integer	normal (2)
ibLswSlotOperStatus.0.1	.1.3.6.1.4.1.26138.8.35.18.4.3.1.9.0.1	Integer	enable (2)
ibLswSlotPhyMemory.0.1	.1.3.6.1.4.1.26138.8.35.18.4.3.1.10.0.1	Gauge	1073741824
ibLswSlotMemory.0.1	.1.3.6.1.4.1.26138.8.35.18.4.3.1.11.0.1	Gauge	1015533568
ibLswSlotMemoryUsed.0.1	.1.3.6.1.4.1.26138.8.35.18.4.3.1.12.0.1	Gauge	463859712
ibLswSlotMemoryRatio.0.1	.1.3.6.1.4.1.26138.8.35.18.4.3.1.13.0.1	Gauge	44
ibLswSlotPktBufFree.0.1	.1.3.6.1.4.1.26138.8.35.18.4.3.1.15.0.1	Integer	5825
ibLswSlotPktBufInited.0.1	.1.3.6.1.4.1.26138.8.35.18.4.3.1.16.0.1	Integer	15

Name	OID	Value Type	Value Example
ibLswSlotPktBufMin.0.1	.1.3.6.1.4.1.26138.8.35.18.4.3.1.17.0	Integer	15
ibLswSlotRunTime.0.1	.1.3.6.1.4.1.26138.8.35.18.4.3.1.19.0	OctetString	0 weeks, 0 days, 0 hours, 59 minutes
ibLswSlotModelDesc.0.1	.1.3.6.1.4.1.26138.8.35.18.4.3.1.23.0	OctetString	
ibLswSlotSerialNumber.0.1	.1.3.6.1.4.1.26138.8.35.18.4.3.1.25.0	OctetString	219801A3PQP23400006H
ibLswSubslotIndex.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.4.1.1.0.1	Integer	0
ibLswSubslotType.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.4.1.2.0.1	Integer	type-1000BASE-TX (4)
ibLswSubslotPortNum.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.4.1.3.0.1	Integer	54
ibLswSubslotAdminStatus.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.4.1.4.0.1	Integer	normal (2)
ibLswSubslotFirstIfIndex.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.4.1.5.0.1	Integer	1
ibLswSubslotSerialNumber.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.4.1.6.0.1	OctetString	
ibLswPortIndex.0.1.0.1	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	1
ibLswPortIndex.0.1.0.2	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	2
ibLswPortIndex.0.1.0.3	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	3
ibLswPortIndex.0.1.0.4	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	4
ibLswPortIndex.0.1.0.5	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	5
ibLswPortIndex.0.1.0.6	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	6
ibLswPortIndex.0.1.0.7	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	7
ibLswPortIndex.0.1.0.8	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	8
ibLswPortIndex.0.1.0.9	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	9
ibLswPortIndex.0.1.0.10	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	10
ibLswPortIndex.0.1.0.11	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	11
ibLswPortIndex.0.1.0.12	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	12
ibLswPortIndex.0.1.0.13	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	13
ibLswPortIndex.0.1.0.14	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	14
ibLswPortIndex.0.1.0.15	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	15
ibLswPortIndex.0.1.0.16	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	16
ibLswPortIndex.0.1.0.17	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	17
ibLswPortIndex.0.1.0.18	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	18
ibLswPortIndex.0.1.0.19	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	19
ibLswPortIndex.0.1.0.20	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	20
ibLswPortIndex.0.1.0.21	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	21
ibLswPortIndex.0.1.0.22	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	22
ibLswPortIndex.0.1.0.23	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	23
ibLswPortIndex.0.1.0.24	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	24
ibLswPortIndex.0.1.0.25	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	25
ibLswPortIndex.0.1.0.26	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	26
ibLswPortIndex.0.1.0.27	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	27
ibLswPortIndex.0.1.0.28	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	28
ibLswPortIndex.0.1.0.29	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	29
ibLswPortIndex.0.1.0.30	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	30
ibLswPortIndex.0.1.0.31	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1	Integer	31

Name	OID	Value Type	Value Example
ibLswPortIndex.0.1.0.32	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.32	Integer	32
ibLswPortIndex.0.1.0.33	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.33	Integer	33
ibLswPortIndex.0.1.0.34	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.34	Integer	34
ibLswPortIndex.0.1.0.35	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.35	Integer	35
ibLswPortIndex.0.1.0.36	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.36	Integer	36
ibLswPortIndex.0.1.0.37	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.37	Integer	37
ibLswPortIndex.0.1.0.38	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.38	Integer	38
ibLswPortIndex.0.1.0.39	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.39	Integer	39
ibLswPortIndex.0.1.0.40	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.40	Integer	40
ibLswPortIndex.0.1.0.41	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.41	Integer	41
ibLswPortIndex.0.1.0.42	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.42	Integer	42
ibLswPortIndex.0.1.0.43	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.43	Integer	43
ibLswPortIndex.0.1.0.44	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.44	Integer	44
ibLswPortIndex.0.1.0.45	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.45	Integer	45
ibLswPortIndex.0.1.0.46	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.46	Integer	46
ibLswPortIndex.0.1.0.47	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.47	Integer	47
ibLswPortIndex.0.1.0.48	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.48	Integer	48
ibLswPortIndex.0.1.0.49	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.49	Integer	49
ibLswPortIndex.0.1.0.50	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.50	Integer	50
ibLswPortIndex.0.1.0.51	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.51	Integer	51
ibLswPortIndex.0.1.0.52	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.52	Integer	52
ibLswPortIndex.0.1.0.53	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.53	Integer	53
ibLswPortIndex.0.1.0.54	.1.3.6.1.4.1.26138.8.35.18.4.5.1.1.0.1.0.54	Integer	54
ibLswCpuEntityIndex.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.10.1.2.0.1.0	Integer	212
ibLswCpuRatio.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.10.1.3.0.1.0	Gauge	16
ibLswCpuSoftwareVersion.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.10.1.4.0.1.0	OctetString	V900R001B01D094
ibLswCpuAdminStatus.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.10.1.5.0.1.0	Integer	normal (2)
ibLswCpuOperStatus.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.10.1.6.0.1.0	Integer	enable (2)
ibLswCpuMemoryRatio.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.10.1.10.0.1.0	Gauge	44
ibLswCpuUsageMinorThreshold.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.10.1.11.0.1.0	Gauge	80
ibLswCpuUsageSevereThreshold.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.10.1.12.0.1.0	Gauge	99
ibLswCpuUsageRecoverThreshold.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.10.1.13.0.1.0	Gauge	60
ibLswCpuMemoryFreeRatio.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.10.1.15.0.1.0	Gauge	55
ibLswCpuMemoryThresholdUnit.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.10.1.25.0.1.0	Integer	inMB (1)
ibLswCpuMemorySecureThreshold.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.10.1.26.0.1.0	Gauge	128
ibLswCpuMemoryEarlyWarningThreshold.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.10.1.27.0.1.0	Gauge	112
ibLswCpuMemoryNormalThreshold.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.10.1.28.0.1.0	Gauge	96

Name	OID	Value Type	Value Example
ibLswCpuMemoryMinorThreshold.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.10.1.29.0	Gauge	80
ibLswCpuMemorySevereThreshold.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.10.1.30.0	Gauge	64
ibLswCpuMemoryCriticalThreshold.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.10.1.31.0	Gauge	48
ibLswCpuMemoryCurrentState.0.1.0	.1.3.6.1.4.1.26138.8.35.18.4.10.1.32.0	Integer	secure (1)
ibLswPowerIndex.0.1.1	.1.3.6.1.4.1.26138.8.35.18.4.11.1.1.0	Integer	1
ibLswPowerSerialNumber.0.1.1	.1.3.6.1.4.1.26138.8.35.18.4.11.1.2.0	OctetString	219803A05N6233V001F2
ibLswFanIndex.0.1.1	.1.3.6.1.4.1.26138.8.35.18.4.12.1.1.0	Integer	1
ibLswFanSerialNumber.0.1.1	.1.3.6.1.4.1.26138.8.35.18.4.12.1.2.0	OctetString	
snmpSetSerialNo.0	.1.3.6.1.6.3.1.1.6.1.0	Integer	0
snmpEngineID.0	.1.3.6.1.6.3.10.2.1.1.0	OctetString	0x80 00 66 1A 80 14 84 77 95 1D DA 00 00 00 01
snmpEngineBoots.0	.1.3.6.1.6.3.10.2.1.2.0	Integer	15
snmpEngineTime.0	.1.3.6.1.6.3.10.2.1.3.0	Integer	3343
snmpEngineMaxMessageSize.0	.1.3.6.1.6.3.10.2.1.4.0	Integer	1500
snmpUnknownSecurityModels.0	.1.3.6.1.6.3.11.2.1.1.0	Counter32	0
snmpInvalidMsgs.0	.1.3.6.1.6.3.11.2.1.2.0	Counter32	0
snmpUnknownPDUHandlers.0	.1.3.6.1.6.3.11.2.1.3.0	Counter32	0
snmpTargetSpinLock.0	.1.3.6.1.6.3.12.1.1.0	Integer	0
1.3.6.1.6.3.12.1.2.1.2	1.3.6.1.4.1.26138.8.35.18.4.13.1.1.1.0	Integer	0
1.3.6.1.6.3.12.1.2.1.2	1.3.6.1.4.1.26138.8.35.18.4.13.1.1.2.0	OctetString	
1.3.6.1.6.3.12.1.2.1.2	1.3.6.1.4.1.26138.8.35.18.4.13.1.1.3.0	Integer	0
1.3.6.1.6.3.12.1.2.1.3	1.3.6.1.4.1.26138.8.35.18.4.13.1.1.4.0	Integer	0
1.3.6.1.6.3.12.1.2.1.3	1.3.6.1.4.1.26138.8.35.18.4.13.1.1.5.0	Integer	0
1.3.6.1.6.3.12.1.2.1.3	1.3.6.1.4.1.26138.8.35.18.4.13.1.1.6.0	Integer	0
1.3.6.1.6.3.12.1.2.1.3	1.3.6.1.4.1.26138.8.35.18.4.13.1.1.7.0	Integer	0
1.3.6.1.6.3.12.1.2.1.4	1.3.6.1.4.1.26138.8.35.18.4.13.1.1.8.0	Integer	0
1.3.6.1.6.3.12.1.2.1.4	1.3.6.1.4.1.26138.8.35.18.4.13.1.1.9.0	Integer	0
1.3.6.1.6.3.12.1.2.1.4	1.3.6.1.4.1.26138.8.35.18.4.13.1.1.10.0	Integer	0
1.3.6.1.6.3.12.1.2.1.5	1.3.6.1.4.1.26138.8.35.18.4.13.1.1.11.0	Integer	0
1.3.6.1.6.3.12.1.2.1.5	1.3.6.1.4.1.26138.8.35.18.4.13.1.1.12.0	Integer	0
1.3.6.1.6.3.12.1.2.1.5	1.3.6.1.4.1.26138.8.35.18.4.13.1.1.13.0	Integer	0
1.3.6.1.6.3.12.1.2.1.6	1.3.6.1.4.1.26138.8.35.18.4.13.1.1.14.0	Integer	0
1.3.6.1.6.3.12.1.2.1.6	1.3.6.1.4.1.26138.8.35.18.4.13.1.1.15.0	Integer	0
1.3.6.1.6.3.12.1.2.1.6	1.3.6.1.4.1.26138.8.35.18.4.13.1.1.16.0	Integer	0
1.3.6.1.6.3.12.1.2.1.7	1.3.6.1.4.1.26138.8.35.18.4.13.1.1.17.0	Integer	0
1.3.6.1.6.3.12.1.2.1.7	1.3.6.1.4.1.26138.8.35.18.4.13.1.1.18.0	Integer	0
1.3.6.1.6.3.12.1.2.1.7	1.3.6.1.4.1.26138.8.35.18.4.13.1.1.19.0	Integer	0
1.3.6.1.6.3.12.1.2.1.8	1.3.6.1.4.1.26138.8.35.18.4.13.1.1.20.0	Integer	0



Name	OID	Value Type	Value Example
.1.3.6.1.6.3.12.1.2.1.8	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
.1.3.6.1.6.3.12.1.2.1.8	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
.1.3.6.1.6.3.12.1.2.1.9	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
.1.3.6.1.6.3.12.1.2.1.9	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
.1.3.6.1.6.3.12.1.2.1.9	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
.1.3.6.1.6.3.12.1.3.1.2	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
.1.3.6.1.6.3.12.1.3.1.2	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
.1.3.6.1.6.3.12.1.3.1.2	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
.1.3.6.1.6.3.12.1.3.1.3	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
.1.3.6.1.6.3.12.1.3.1.3	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
.1.3.6.1.6.3.12.1.3.1.3	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
.1.3.6.1.6.3.12.1.3.1.4	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
.1.3.6.1.6.3.12.1.3.1.4	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
.1.3.6.1.6.3.12.1.3.1.4	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
.1.3.6.1.6.3.12.1.3.1.5	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
.1.3.6.1.6.3.12.1.3.1.5	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
.1.3.6.1.6.3.12.1.3.1.5	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
.1.3.6.1.6.3.12.1.3.1.6	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
.1.3.6.1.6.3.12.1.3.1.6	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
.1.3.6.1.6.3.12.1.3.1.6	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
.1.3.6.1.6.3.12.1.3.1.7	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
.1.3.6.1.6.3.12.1.3.1.7	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
.1.3.6.1.6.3.12.1.3.1.7	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer32	98461499781485384649548546.49.48.48.46.50
snmpUnavailableContexts.0	.1.3.6.1.6.3.12.1.4.0	Counter32	0
snmpUnknownContexts.0	.1.3.6.1.6.3.12.1.5.0	Counter32	0
snmpNotifyTag.73.114.1109.72.1110.1102.1116.114.109.72	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	OctetString	InformHost
snmpNotifyTag.84.114.97.112.72.1111.1115.11284.114.97.112.72.111	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	OctetString	TrapHost
snmpNotifyType.73.114.1109.72.1110.1102.1116.114.109.72	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer5.116	inform (2)
snmpNotifyType.84.114.97.112.72.1111.1115.11284.114.97.112.72.111	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer6	trap (1)
snmpNotifyStorageType.6.73.114.1109.72.1110.1102.1116.114.109.72	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer5.116	nonVolatile (3)
snmpNotifyStorageType.84.114.97.112.72.1111.1115.11284.114.97.112.72.111	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer6	nonVolatile (3)
snmpNotifyRowStatus.73.114.1109.72.1110.1102.1116.114.109.72	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer5.116	active (1)
snmpNotifyRowStatus.84.114.97.112.72.1111.1115.11284.114.97.112.72.111	1.105.97.0.12.60.0.1.1108.98.1116.46.105.49.50.51.1106.408	Integer6	active (1)
usmStatsUnsupportedSecLevels.0	.1.3.6.1.6.3.15.1.1.0	Counter32	0
usmStatsNotInTimeWindows.0	.1.3.6.1.6.3.15.1.1.2.0	Counter32	0
usmStatsUnknownUserNames.0	.1.3.6.1.6.3.15.1.1.3.0	Counter32	0
usmStatsUnknownEngineIDs.0	.1.3.6.1.6.3.15.1.1.4.0	Counter32	0
usmStatsWrongDigests.0	.1.3.6.1.6.3.15.1.1.5.0	Counter32	0
usmStatsDecryptionErrors.0	.1.3.6.1.6.3.15.1.1.6.0	Counter32	0

Name	OID	Value Type	Value Example
usmUserSpinLock.0	.1.3.6.1.6.3.15.1.2.1.0	Integer	0
vacmGroupName.6.1.2.3.5.6.1.2.113.1.102.1105.98.0.14.07.015.09.98.514.07.15.49.50.51	.1.3.6.1.4.1.113.1.102.1105.98.0.14.07.015.09.98.514.07.15.49.50.51	String	intelbras123
vacmGroupName.8.1.2.3.5.6.1.2.113.2.102.1105.98.0.14.07.015.09.98.514.07.15.49.50.51	.1.3.6.1.4.1.113.2.102.1105.98.0.14.07.015.09.98.514.07.15.49.50.51	String	intelbras123
vacmSecurityTypeGroupStorageType.4.1.112.1105.1110.1116.1101.1108.98.114.07.15.49.50.51	.1.3.6.1.4.1.112.1105.1110.1116.1101.1108.98.114.07.15.49.50.51	String	nonVolatile (3)
vacmSecurityTypeGroupStorageType.4.2.112.1105.1110.1116.1101.1108.98.114.07.15.49.50.51	.1.3.6.1.4.1.112.1105.1110.1116.1101.1108.98.114.07.15.49.50.51	String	nonVolatile (3)
vacmSecurityTypeGroupStorageType.1.2.2.505.102.005.6.1101.1168.098.108.98.114.07.15.49.50.51	.1.3.6.1.4.1.112.1105.1110.1116.1101.1108.98.114.07.15.49.50.51	String	active (1)
vacmSecurityTypeGroupStorageType.2.2.2.505.102.005.6.1101.1168.098.108.98.114.07.15.49.50.51	.1.3.6.1.4.1.112.1105.1110.1116.1101.1108.98.114.07.15.49.50.51	String	active (1)
vacmAccessControlName.1.421145.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.4511145.1.1	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.4511145.1.1	String	exact (1)
vacmAccessControlName.1.421145.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.45121145.2.1	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.45121145.2.1	String	exact (1)
vacmAccessReadViewName.4.1125103.109.116.106.108.988198.974197.405605101511145.1.1	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.4511145.1.1	String	ViewDefault
vacmAccessReadViewName.4.1125103.109.116.106.108.988198.974197.40560510151245.2.1	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.451245.2.1	String	ViewDefault
vacmAccessWriteViewName.4.125105.1105.1116.1103.1108.988198.974197.40560510151145.1.1	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.451145.1.1	String	ViewDefault
vacmAccessWriteViewName.4.125105.1105.1116.1103.1108.988198.974197.40560510151245.2.1	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.451245.2.1	String	ViewDefault
vacmAccessNotifyViewName.11.210510501.10611611008198.984197.97510913055015145.1.1	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.45145.1.1	String	ViewDefault
vacmAccessNotifyViewName.11.210510501.10611611008198.984197.97510913055015145.2.1	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.45145.2.1	String	ViewDefault
vacmAccessStorageType.6.124108.12010561.1011168198.108.98.118.97.505698.55111.45.1.1	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.45111.45.1.1	String	nonVolatile (3)
vacmAccessStorageType.6.124108.12010561.1011168198.108.98.118.97.505698.55111.45.2.1	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.45111.45.2.1	String	nonVolatile (3)
vacmAccessStorageType.6.2.11651140.9162100510809816110971085949150.57.115698.50.51.1.45.1.1	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.451.1.45.1.1	String	active (1)
vacmAccessStorageType.6.2.11651140.9162100510809816110971085949150.57.115698.50.51.1.45.2.1	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.451.1.45.2.1	String	active (1)
vacmViewSpinLock.0	.1.3.6.1.6.3.16.1.5.1.0	Integer	0
vacmViewTreeFamilyMask.11.52105.11088.1958001.11908870117028016751089.16.1.1	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.4516.1.1	String	ViewDefault
vacmViewTreeFamilyMask.2.11386185.1105.1109.168168.1102.902197.11081066181615.3.6.3.63.15	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.453.6.3.63.15	String	ViewDefault
vacmViewTreeFamilyMask.2.11386185.1105.1109.168168.1102.902197.11081066181615.3.6.3.63.16	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.453.6.3.63.16	String	ViewDefault
vacmViewTreeFamilyMask.2.11386185.1105.1109.168168.1102.902197.11081066181615.3.6.3.63.18	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.453.6.3.63.18	String	ViewDefault
vacmViewTreeFamilyType.4.1.861108.10.86.1905800.1119258701710291107.108.116.1.1	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.45108.116.1.1	String	included (1)
vacmViewTreeFamilyType.5.211.861185.105.109.689168.102.902197.10811062116376136631163.15	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.4511062116376136631163.15	String	excluded (2)
vacmViewTreeFamilyType.5.211.861185.105.109.689168.102.902197.10811062116376136631163.16	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.4511062116376136631163.16	String	excluded (2)
vacmViewTreeFamilyType.5.211.861185.105.109.689168.102.902197.10811062116376136631163.18	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.4511062116376136631163.18	String	excluded (2)
vacmViewTreeFamilyStorageType.115.86865051.0119.68.88.100202.971108.98.517.6.3.6.3.6.3.15	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.45108.98.517.6.3.6.3.6.3.15	String	nonVolatile (3)
vacmViewTreeFamilyStorageType.115.86865051.0119.68.88.100202.971108.98.517.6.3.6.3.6.3.16	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.45108.98.517.6.3.6.3.6.3.16	String	nonVolatile (3)
vacmViewTreeFamilyStorageType.115.86865051.0119.68.88.100202.971108.98.517.6.3.6.3.6.3.18	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.45108.98.517.6.3.6.3.6.3.18	String	nonVolatile (3)
vacmViewTreeFamilyStatus.1.15861169.186.105.88.1019.68.9701.102961169.108.116.1.1	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.45108.116.1.1	String	active (1)
vacmViewTreeFamilyStatus.2.116.86.869.05.1019.68.88.1002.92.97.7.108108.9761731631661363.15	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.45108.9761731631661363.15	String	active (1)
vacmViewTreeFamilyStatus.2.116.86.869.05.1019.68.88.1002.92.97.7.108108.9761731631661363.16	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.45108.9761731631661363.16	String	active (1)
vacmViewTreeFamilyStatus.2.116.86.869.05.1019.68.88.1002.92.97.7.108108.9761731631661363.18	.1.3.6.1.4.1.114.1105.2.105.16.0.01.6.08.08.08.98.7.14.97.91.56.98.50.45108.9761731631661363.18	String	active (1)
lldpV2MessageTxInterval.0	.1.3.111.2.802.1.1.13.1.1.1.0	Gauge	30
lldpV2MessageTxHoldMultiplier.0	.1.3.111.2.802.1.1.13.1.1.2.0	Gauge	4
lldpV2ReinitDelay.0	.1.3.111.2.802.1.1.13.1.1.3.0	Gauge	2
lldpV2NotificationInterval.0	.1.3.111.2.802.1.1.13.1.1.4.0	Gauge	30
lldpV2TxCreditMax.0	.1.3.111.2.802.1.1.13.1.1.5.0	Gauge	5
lldpV2MessageFastTx.0	.1.3.111.2.802.1.1.13.1.1.6.0	Gauge	1

Name	OID	Value Type	Value Example
IldpV2TxFastInit.0	.1.3.111.2.802.1.1.13.1.1.7.0	Gauge	4
IldpV2PortConfigAdminStatus.1.1	.1.3.111.2.802.1.1.13.1.1.8.1.3.1.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.1.2	.1.3.111.2.802.1.1.13.1.1.8.1.3.1.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.1.3	.1.3.111.2.802.1.1.13.1.1.8.1.3.1.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.2.1	.1.3.111.2.802.1.1.13.1.1.8.1.3.2.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.2.2	.1.3.111.2.802.1.1.13.1.1.8.1.3.2.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.2.3	.1.3.111.2.802.1.1.13.1.1.8.1.3.2.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.3.1	.1.3.111.2.802.1.1.13.1.1.8.1.3.3.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.3.2	.1.3.111.2.802.1.1.13.1.1.8.1.3.3.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.3.3	.1.3.111.2.802.1.1.13.1.1.8.1.3.3.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.4.1	.1.3.111.2.802.1.1.13.1.1.8.1.3.4.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.4.2	.1.3.111.2.802.1.1.13.1.1.8.1.3.4.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.4.3	.1.3.111.2.802.1.1.13.1.1.8.1.3.4.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.5.1	.1.3.111.2.802.1.1.13.1.1.8.1.3.5.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.5.2	.1.3.111.2.802.1.1.13.1.1.8.1.3.5.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.5.3	.1.3.111.2.802.1.1.13.1.1.8.1.3.5.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.6.1	.1.3.111.2.802.1.1.13.1.1.8.1.3.6.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.6.2	.1.3.111.2.802.1.1.13.1.1.8.1.3.6.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.6.3	.1.3.111.2.802.1.1.13.1.1.8.1.3.6.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.7.1	.1.3.111.2.802.1.1.13.1.1.8.1.3.7.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.7.2	.1.3.111.2.802.1.1.13.1.1.8.1.3.7.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.7.3	.1.3.111.2.802.1.1.13.1.1.8.1.3.7.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.8.1	.1.3.111.2.802.1.1.13.1.1.8.1.3.8.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.8.2	.1.3.111.2.802.1.1.13.1.1.8.1.3.8.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.8.3	.1.3.111.2.802.1.1.13.1.1.8.1.3.8.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.9.1	.1.3.111.2.802.1.1.13.1.1.8.1.3.9.1	Integer	txAndRx (3)

Name	OID	Value Type	Value Example
IldpV2PortConfigAdminStatus.9.2	.1.3.111.2.802.1.1.13.1.1.8.1.3.9.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.9.3	.1.3.111.2.802.1.1.13.1.1.8.1.3.9.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.10.1	1.3.111.2.802.1.1.13.1.1.8.1.3.10.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.10.2	1.3.111.2.802.1.1.13.1.1.8.1.3.10.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.10.3	1.3.111.2.802.1.1.13.1.1.8.1.3.10.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.11.1	1.3.111.2.802.1.1.13.1.1.8.1.3.11.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.11.2	1.3.111.2.802.1.1.13.1.1.8.1.3.11.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.11.3	1.3.111.2.802.1.1.13.1.1.8.1.3.11.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.12.1	1.3.111.2.802.1.1.13.1.1.8.1.3.12.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.12.2	1.3.111.2.802.1.1.13.1.1.8.1.3.12.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.12.3	1.3.111.2.802.1.1.13.1.1.8.1.3.12.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.13.1	1.3.111.2.802.1.1.13.1.1.8.1.3.13.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.13.2	1.3.111.2.802.1.1.13.1.1.8.1.3.13.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.13.3	1.3.111.2.802.1.1.13.1.1.8.1.3.13.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.14.1	1.3.111.2.802.1.1.13.1.1.8.1.3.14.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.14.2	1.3.111.2.802.1.1.13.1.1.8.1.3.14.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.14.3	1.3.111.2.802.1.1.13.1.1.8.1.3.14.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.15.1	1.3.111.2.802.1.1.13.1.1.8.1.3.15.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.15.2	1.3.111.2.802.1.1.13.1.1.8.1.3.15.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.15.3	1.3.111.2.802.1.1.13.1.1.8.1.3.15.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.16.1	1.3.111.2.802.1.1.13.1.1.8.1.3.16.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.16.2	1.3.111.2.802.1.1.13.1.1.8.1.3.16.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.16.3	1.3.111.2.802.1.1.13.1.1.8.1.3.16.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.17.1	1.3.111.2.802.1.1.13.1.1.8.1.3.17.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.17.2	1.3.111.2.802.1.1.13.1.1.8.1.3.17.2	Integer	disabled (4)

Name	OID	Value Type	Value Example
IldpV2PortConfigAdminStatus.17.3	1.3.111.2.802.1.1.13.1.1.8.1.3.17.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.18.1	1.3.111.2.802.1.1.13.1.1.8.1.3.18.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.18.2	1.3.111.2.802.1.1.13.1.1.8.1.3.18.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.18.3	1.3.111.2.802.1.1.13.1.1.8.1.3.18.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.19.1	1.3.111.2.802.1.1.13.1.1.8.1.3.19.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.19.2	1.3.111.2.802.1.1.13.1.1.8.1.3.19.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.19.3	1.3.111.2.802.1.1.13.1.1.8.1.3.19.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.20.1	1.3.111.2.802.1.1.13.1.1.8.1.3.20.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.20.2	1.3.111.2.802.1.1.13.1.1.8.1.3.20.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.20.3	1.3.111.2.802.1.1.13.1.1.8.1.3.20.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.21.1	1.3.111.2.802.1.1.13.1.1.8.1.3.21.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.21.2	1.3.111.2.802.1.1.13.1.1.8.1.3.21.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.21.3	1.3.111.2.802.1.1.13.1.1.8.1.3.21.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.22.1	1.3.111.2.802.1.1.13.1.1.8.1.3.22.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.22.2	1.3.111.2.802.1.1.13.1.1.8.1.3.22.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.22.3	1.3.111.2.802.1.1.13.1.1.8.1.3.22.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.23.1	1.3.111.2.802.1.1.13.1.1.8.1.3.23.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.23.2	1.3.111.2.802.1.1.13.1.1.8.1.3.23.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.23.3	1.3.111.2.802.1.1.13.1.1.8.1.3.23.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.24.1	1.3.111.2.802.1.1.13.1.1.8.1.3.24.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.24.2	1.3.111.2.802.1.1.13.1.1.8.1.3.24.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.24.3	1.3.111.2.802.1.1.13.1.1.8.1.3.24.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.25.1	1.3.111.2.802.1.1.13.1.1.8.1.3.25.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.25.2	1.3.111.2.802.1.1.13.1.1.8.1.3.25.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.25.3	1.3.111.2.802.1.1.13.1.1.8.1.3.25.3	Integer	disabled (4)

Name	OID	Value Type	Value Example
IldpV2PortConfigAdminStatus.26.1	1.3.111.2.802.1.1.13.1.1.8.1.3.26.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.26.2	1.3.111.2.802.1.1.13.1.1.8.1.3.26.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.26.3	1.3.111.2.802.1.1.13.1.1.8.1.3.26.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.27.1	1.3.111.2.802.1.1.13.1.1.8.1.3.27.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.27.2	1.3.111.2.802.1.1.13.1.1.8.1.3.27.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.27.3	1.3.111.2.802.1.1.13.1.1.8.1.3.27.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.28.1	1.3.111.2.802.1.1.13.1.1.8.1.3.28.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.28.2	1.3.111.2.802.1.1.13.1.1.8.1.3.28.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.28.3	1.3.111.2.802.1.1.13.1.1.8.1.3.28.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.29.1	1.3.111.2.802.1.1.13.1.1.8.1.3.29.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.29.2	1.3.111.2.802.1.1.13.1.1.8.1.3.29.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.29.3	1.3.111.2.802.1.1.13.1.1.8.1.3.29.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.30.1	1.3.111.2.802.1.1.13.1.1.8.1.3.30.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.30.2	1.3.111.2.802.1.1.13.1.1.8.1.3.30.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.30.3	1.3.111.2.802.1.1.13.1.1.8.1.3.30.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.31.1	1.3.111.2.802.1.1.13.1.1.8.1.3.31.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.31.2	1.3.111.2.802.1.1.13.1.1.8.1.3.31.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.31.3	1.3.111.2.802.1.1.13.1.1.8.1.3.31.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.32.1	1.3.111.2.802.1.1.13.1.1.8.1.3.32.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.32.2	1.3.111.2.802.1.1.13.1.1.8.1.3.32.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.32.3	1.3.111.2.802.1.1.13.1.1.8.1.3.32.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.33.1	1.3.111.2.802.1.1.13.1.1.8.1.3.33.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.33.2	1.3.111.2.802.1.1.13.1.1.8.1.3.33.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.33.3	1.3.111.2.802.1.1.13.1.1.8.1.3.33.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.34.1	1.3.111.2.802.1.1.13.1.1.8.1.3.34.1	Integer	txAndRx (3)



Name	OID	Value Type	Value Example
IldpV2PortConfigAdminStatus.34.2	1.3.111.2.802.1.1.13.1.1.8.1.3.34.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.34.3	1.3.111.2.802.1.1.13.1.1.8.1.3.34.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.35.1	1.3.111.2.802.1.1.13.1.1.8.1.3.35.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.35.2	1.3.111.2.802.1.1.13.1.1.8.1.3.35.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.35.3	1.3.111.2.802.1.1.13.1.1.8.1.3.35.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.36.1	1.3.111.2.802.1.1.13.1.1.8.1.3.36.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.36.2	1.3.111.2.802.1.1.13.1.1.8.1.3.36.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.36.3	1.3.111.2.802.1.1.13.1.1.8.1.3.36.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.37.1	1.3.111.2.802.1.1.13.1.1.8.1.3.37.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.37.2	1.3.111.2.802.1.1.13.1.1.8.1.3.37.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.37.3	1.3.111.2.802.1.1.13.1.1.8.1.3.37.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.38.1	1.3.111.2.802.1.1.13.1.1.8.1.3.38.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.38.2	1.3.111.2.802.1.1.13.1.1.8.1.3.38.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.38.3	1.3.111.2.802.1.1.13.1.1.8.1.3.38.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.39.1	1.3.111.2.802.1.1.13.1.1.8.1.3.39.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.39.2	1.3.111.2.802.1.1.13.1.1.8.1.3.39.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.39.3	1.3.111.2.802.1.1.13.1.1.8.1.3.39.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.40.1	1.3.111.2.802.1.1.13.1.1.8.1.3.40.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.40.2	1.3.111.2.802.1.1.13.1.1.8.1.3.40.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.40.3	1.3.111.2.802.1.1.13.1.1.8.1.3.40.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.41.1	1.3.111.2.802.1.1.13.1.1.8.1.3.41.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.41.2	1.3.111.2.802.1.1.13.1.1.8.1.3.41.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.41.3	1.3.111.2.802.1.1.13.1.1.8.1.3.41.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.42.1	1.3.111.2.802.1.1.13.1.1.8.1.3.42.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.42.2	1.3.111.2.802.1.1.13.1.1.8.1.3.42.2	Integer	disabled (4)



Name	OID	Value Type	Value Example
IldpV2PortConfigAdminStatus.42.3	1.3.111.2.802.1.1.13.1.1.8.1.3.42.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.43.1	1.3.111.2.802.1.1.13.1.1.8.1.3.43.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.43.2	1.3.111.2.802.1.1.13.1.1.8.1.3.43.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.43.3	1.3.111.2.802.1.1.13.1.1.8.1.3.43.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.44.1	1.3.111.2.802.1.1.13.1.1.8.1.3.44.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.44.2	1.3.111.2.802.1.1.13.1.1.8.1.3.44.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.44.3	1.3.111.2.802.1.1.13.1.1.8.1.3.44.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.45.1	1.3.111.2.802.1.1.13.1.1.8.1.3.45.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.45.2	1.3.111.2.802.1.1.13.1.1.8.1.3.45.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.45.3	1.3.111.2.802.1.1.13.1.1.8.1.3.45.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.46.1	1.3.111.2.802.1.1.13.1.1.8.1.3.46.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.46.2	1.3.111.2.802.1.1.13.1.1.8.1.3.46.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.46.3	1.3.111.2.802.1.1.13.1.1.8.1.3.46.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.47.1	1.3.111.2.802.1.1.13.1.1.8.1.3.47.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.47.2	1.3.111.2.802.1.1.13.1.1.8.1.3.47.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.47.3	1.3.111.2.802.1.1.13.1.1.8.1.3.47.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.48.1	1.3.111.2.802.1.1.13.1.1.8.1.3.48.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.48.2	1.3.111.2.802.1.1.13.1.1.8.1.3.48.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.48.3	1.3.111.2.802.1.1.13.1.1.8.1.3.48.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.49.1	1.3.111.2.802.1.1.13.1.1.8.1.3.49.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.49.2	1.3.111.2.802.1.1.13.1.1.8.1.3.49.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.49.3	1.3.111.2.802.1.1.13.1.1.8.1.3.49.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.50.1	1.3.111.2.802.1.1.13.1.1.8.1.3.50.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.50.2	1.3.111.2.802.1.1.13.1.1.8.1.3.50.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.50.3	1.3.111.2.802.1.1.13.1.1.8.1.3.50.3	Integer	disabled (4)

Name	OID	Value Type	Value Example
IldpV2PortConfigAdminStatus.51.1	1.3.111.2.802.1.1.13.1.1.8.1.3.51.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.51.2	1.3.111.2.802.1.1.13.1.1.8.1.3.51.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.51.3	1.3.111.2.802.1.1.13.1.1.8.1.3.51.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.52.1	1.3.111.2.802.1.1.13.1.1.8.1.3.52.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.52.2	1.3.111.2.802.1.1.13.1.1.8.1.3.52.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.52.3	1.3.111.2.802.1.1.13.1.1.8.1.3.52.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.53.1	1.3.111.2.802.1.1.13.1.1.8.1.3.53.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.53.2	1.3.111.2.802.1.1.13.1.1.8.1.3.53.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.53.3	1.3.111.2.802.1.1.13.1.1.8.1.3.53.3	Integer	disabled (4)
IldpV2PortConfigAdminStatus.54.1	1.3.111.2.802.1.1.13.1.1.8.1.3.54.1	Integer	txAndRx (3)
IldpV2PortConfigAdminStatus.54.2	1.3.111.2.802.1.1.13.1.1.8.1.3.54.2	Integer	disabled (4)
IldpV2PortConfigAdminStatus.54.3	1.3.111.2.802.1.1.13.1.1.8.1.3.54.3	Integer	disabled (4)
IldpV2PortConfigNotificationEnable.1.1	.1.3.111.2.802.1.1.13.1.1.8.1.4.1.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.1.2	.1.3.111.2.802.1.1.13.1.1.8.1.4.1.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.1.3	.1.3.111.2.802.1.1.13.1.1.8.1.4.1.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.2.1	.1.3.111.2.802.1.1.13.1.1.8.1.4.2.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.2.2	.1.3.111.2.802.1.1.13.1.1.8.1.4.2.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.2.3	.1.3.111.2.802.1.1.13.1.1.8.1.4.2.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.3.1	.1.3.111.2.802.1.1.13.1.1.8.1.4.3.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.3.2	.1.3.111.2.802.1.1.13.1.1.8.1.4.3.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.3.3	.1.3.111.2.802.1.1.13.1.1.8.1.4.3.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.4.1	.1.3.111.2.802.1.1.13.1.1.8.1.4.4.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.4.2	.1.3.111.2.802.1.1.13.1.1.8.1.4.4.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.4.3	.1.3.111.2.802.1.1.13.1.1.8.1.4.4.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.5.1	.1.3.111.2.802.1.1.13.1.1.8.1.4.5.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2PortConfigNotificationEnable.5.2	.1.3.111.2.802.1.1.13.1.1.8.1.4.5.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.5.3	.1.3.111.2.802.1.1.13.1.1.8.1.4.5.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.6.1	.1.3.111.2.802.1.1.13.1.1.8.1.4.6.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.6.2	.1.3.111.2.802.1.1.13.1.1.8.1.4.6.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.6.3	.1.3.111.2.802.1.1.13.1.1.8.1.4.6.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.7.1	.1.3.111.2.802.1.1.13.1.1.8.1.4.7.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.7.2	.1.3.111.2.802.1.1.13.1.1.8.1.4.7.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.7.3	.1.3.111.2.802.1.1.13.1.1.8.1.4.7.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.8.1	.1.3.111.2.802.1.1.13.1.1.8.1.4.8.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.8.2	.1.3.111.2.802.1.1.13.1.1.8.1.4.8.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.8.3	.1.3.111.2.802.1.1.13.1.1.8.1.4.8.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.9.1	.1.3.111.2.802.1.1.13.1.1.8.1.4.9.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.9.2	.1.3.111.2.802.1.1.13.1.1.8.1.4.9.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.9.3	.1.3.111.2.802.1.1.13.1.1.8.1.4.9.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.10.1	1.3.111.2.802.1.1.13.1.1.8.1.4.10.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.10.2	1.3.111.2.802.1.1.13.1.1.8.1.4.10.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.10.3	1.3.111.2.802.1.1.13.1.1.8.1.4.10.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.11.1	1.3.111.2.802.1.1.13.1.1.8.1.4.11.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.11.2	1.3.111.2.802.1.1.13.1.1.8.1.4.11.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.11.3	1.3.111.2.802.1.1.13.1.1.8.1.4.11.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.12.1	1.3.111.2.802.1.1.13.1.1.8.1.4.12.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.12.2	1.3.111.2.802.1.1.13.1.1.8.1.4.12.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.12.3	1.3.111.2.802.1.1.13.1.1.8.1.4.12.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.13.1	1.3.111.2.802.1.1.13.1.1.8.1.4.13.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.13.2	1.3.111.2.802.1.1.13.1.1.8.1.4.13.2	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2PortConfigNotificationEnable.13.3	1.3.111.2.802.1.1.13.1.1.8.1.4.13.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.14.1	1.3.111.2.802.1.1.13.1.1.8.1.4.14.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.14.2	1.3.111.2.802.1.1.13.1.1.8.1.4.14.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.14.3	1.3.111.2.802.1.1.13.1.1.8.1.4.14.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.15.1	1.3.111.2.802.1.1.13.1.1.8.1.4.15.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.15.2	1.3.111.2.802.1.1.13.1.1.8.1.4.15.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.15.3	1.3.111.2.802.1.1.13.1.1.8.1.4.15.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.16.1	1.3.111.2.802.1.1.13.1.1.8.1.4.16.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.16.2	1.3.111.2.802.1.1.13.1.1.8.1.4.16.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.16.3	1.3.111.2.802.1.1.13.1.1.8.1.4.16.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.17.1	1.3.111.2.802.1.1.13.1.1.8.1.4.17.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.17.2	1.3.111.2.802.1.1.13.1.1.8.1.4.17.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.17.3	1.3.111.2.802.1.1.13.1.1.8.1.4.17.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.18.1	1.3.111.2.802.1.1.13.1.1.8.1.4.18.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.18.2	1.3.111.2.802.1.1.13.1.1.8.1.4.18.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.18.3	1.3.111.2.802.1.1.13.1.1.8.1.4.18.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.19.1	1.3.111.2.802.1.1.13.1.1.8.1.4.19.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.19.2	1.3.111.2.802.1.1.13.1.1.8.1.4.19.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.19.3	1.3.111.2.802.1.1.13.1.1.8.1.4.19.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.20.1	1.3.111.2.802.1.1.13.1.1.8.1.4.20.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.20.2	1.3.111.2.802.1.1.13.1.1.8.1.4.20.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.20.3	1.3.111.2.802.1.1.13.1.1.8.1.4.20.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.21.1	1.3.111.2.802.1.1.13.1.1.8.1.4.21.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.21.2	1.3.111.2.802.1.1.13.1.1.8.1.4.21.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.21.3	1.3.111.2.802.1.1.13.1.1.8.1.4.21.3	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2PortConfigNotificationEnable.22.1	1.3.111.2.802.1.1.13.1.1.8.1.4.22.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.22.2	1.3.111.2.802.1.1.13.1.1.8.1.4.22.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.22.3	1.3.111.2.802.1.1.13.1.1.8.1.4.22.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.23.1	1.3.111.2.802.1.1.13.1.1.8.1.4.23.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.23.2	1.3.111.2.802.1.1.13.1.1.8.1.4.23.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.23.3	1.3.111.2.802.1.1.13.1.1.8.1.4.23.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.24.1	1.3.111.2.802.1.1.13.1.1.8.1.4.24.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.24.2	1.3.111.2.802.1.1.13.1.1.8.1.4.24.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.24.3	1.3.111.2.802.1.1.13.1.1.8.1.4.24.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.25.1	1.3.111.2.802.1.1.13.1.1.8.1.4.25.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.25.2	1.3.111.2.802.1.1.13.1.1.8.1.4.25.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.25.3	1.3.111.2.802.1.1.13.1.1.8.1.4.25.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.26.1	1.3.111.2.802.1.1.13.1.1.8.1.4.26.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.26.2	1.3.111.2.802.1.1.13.1.1.8.1.4.26.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.26.3	1.3.111.2.802.1.1.13.1.1.8.1.4.26.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.27.1	1.3.111.2.802.1.1.13.1.1.8.1.4.27.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.27.2	1.3.111.2.802.1.1.13.1.1.8.1.4.27.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.27.3	1.3.111.2.802.1.1.13.1.1.8.1.4.27.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.28.1	1.3.111.2.802.1.1.13.1.1.8.1.4.28.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.28.2	1.3.111.2.802.1.1.13.1.1.8.1.4.28.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.28.3	1.3.111.2.802.1.1.13.1.1.8.1.4.28.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.29.1	1.3.111.2.802.1.1.13.1.1.8.1.4.29.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.29.2	1.3.111.2.802.1.1.13.1.1.8.1.4.29.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.29.3	1.3.111.2.802.1.1.13.1.1.8.1.4.29.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.30.1	1.3.111.2.802.1.1.13.1.1.8.1.4.30.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2PortConfigNotificationEnable.30.2	1.3.111.2.802.1.1.13.1.1.8.1.4.30.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.30.3	1.3.111.2.802.1.1.13.1.1.8.1.4.30.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.31.1	1.3.111.2.802.1.1.13.1.1.8.1.4.31.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.31.2	1.3.111.2.802.1.1.13.1.1.8.1.4.31.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.31.3	1.3.111.2.802.1.1.13.1.1.8.1.4.31.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.32.1	1.3.111.2.802.1.1.13.1.1.8.1.4.32.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.32.2	1.3.111.2.802.1.1.13.1.1.8.1.4.32.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.32.3	1.3.111.2.802.1.1.13.1.1.8.1.4.32.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.33.1	1.3.111.2.802.1.1.13.1.1.8.1.4.33.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.33.2	1.3.111.2.802.1.1.13.1.1.8.1.4.33.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.33.3	1.3.111.2.802.1.1.13.1.1.8.1.4.33.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.34.1	1.3.111.2.802.1.1.13.1.1.8.1.4.34.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.34.2	1.3.111.2.802.1.1.13.1.1.8.1.4.34.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.34.3	1.3.111.2.802.1.1.13.1.1.8.1.4.34.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.35.1	1.3.111.2.802.1.1.13.1.1.8.1.4.35.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.35.2	1.3.111.2.802.1.1.13.1.1.8.1.4.35.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.35.3	1.3.111.2.802.1.1.13.1.1.8.1.4.35.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.36.1	1.3.111.2.802.1.1.13.1.1.8.1.4.36.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.36.2	1.3.111.2.802.1.1.13.1.1.8.1.4.36.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.36.3	1.3.111.2.802.1.1.13.1.1.8.1.4.36.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.37.1	1.3.111.2.802.1.1.13.1.1.8.1.4.37.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.37.2	1.3.111.2.802.1.1.13.1.1.8.1.4.37.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.37.3	1.3.111.2.802.1.1.13.1.1.8.1.4.37.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.38.1	1.3.111.2.802.1.1.13.1.1.8.1.4.38.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.38.2	1.3.111.2.802.1.1.13.1.1.8.1.4.38.2	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2PortConfigNotificationEnable.38.3	1.3.111.2.802.1.1.13.1.1.8.1.4.38.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.39.1	1.3.111.2.802.1.1.13.1.1.8.1.4.39.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.39.2	1.3.111.2.802.1.1.13.1.1.8.1.4.39.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.39.3	1.3.111.2.802.1.1.13.1.1.8.1.4.39.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.40.1	1.3.111.2.802.1.1.13.1.1.8.1.4.40.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.40.2	1.3.111.2.802.1.1.13.1.1.8.1.4.40.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.40.3	1.3.111.2.802.1.1.13.1.1.8.1.4.40.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.41.1	1.3.111.2.802.1.1.13.1.1.8.1.4.41.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.41.2	1.3.111.2.802.1.1.13.1.1.8.1.4.41.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.41.3	1.3.111.2.802.1.1.13.1.1.8.1.4.41.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.42.1	1.3.111.2.802.1.1.13.1.1.8.1.4.42.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.42.2	1.3.111.2.802.1.1.13.1.1.8.1.4.42.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.42.3	1.3.111.2.802.1.1.13.1.1.8.1.4.42.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.43.1	1.3.111.2.802.1.1.13.1.1.8.1.4.43.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.43.2	1.3.111.2.802.1.1.13.1.1.8.1.4.43.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.43.3	1.3.111.2.802.1.1.13.1.1.8.1.4.43.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.44.1	1.3.111.2.802.1.1.13.1.1.8.1.4.44.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.44.2	1.3.111.2.802.1.1.13.1.1.8.1.4.44.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.44.3	1.3.111.2.802.1.1.13.1.1.8.1.4.44.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.45.1	1.3.111.2.802.1.1.13.1.1.8.1.4.45.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.45.2	1.3.111.2.802.1.1.13.1.1.8.1.4.45.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.45.3	1.3.111.2.802.1.1.13.1.1.8.1.4.45.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.46.1	1.3.111.2.802.1.1.13.1.1.8.1.4.46.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.46.2	1.3.111.2.802.1.1.13.1.1.8.1.4.46.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.46.3	1.3.111.2.802.1.1.13.1.1.8.1.4.46.3	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2PortConfigNotificationEnable.47.1	1.3.111.2.802.1.1.13.1.1.8.1.4.47.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.47.2	1.3.111.2.802.1.1.13.1.1.8.1.4.47.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.47.3	1.3.111.2.802.1.1.13.1.1.8.1.4.47.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.48.1	1.3.111.2.802.1.1.13.1.1.8.1.4.48.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.48.2	1.3.111.2.802.1.1.13.1.1.8.1.4.48.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.48.3	1.3.111.2.802.1.1.13.1.1.8.1.4.48.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.49.1	1.3.111.2.802.1.1.13.1.1.8.1.4.49.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.49.2	1.3.111.2.802.1.1.13.1.1.8.1.4.49.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.49.3	1.3.111.2.802.1.1.13.1.1.8.1.4.49.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.50.1	1.3.111.2.802.1.1.13.1.1.8.1.4.50.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.50.2	1.3.111.2.802.1.1.13.1.1.8.1.4.50.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.50.3	1.3.111.2.802.1.1.13.1.1.8.1.4.50.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.51.1	1.3.111.2.802.1.1.13.1.1.8.1.4.51.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.51.2	1.3.111.2.802.1.1.13.1.1.8.1.4.51.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.51.3	1.3.111.2.802.1.1.13.1.1.8.1.4.51.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.52.1	1.3.111.2.802.1.1.13.1.1.8.1.4.52.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.52.2	1.3.111.2.802.1.1.13.1.1.8.1.4.52.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.52.3	1.3.111.2.802.1.1.13.1.1.8.1.4.52.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.53.1	1.3.111.2.802.1.1.13.1.1.8.1.4.53.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.53.2	1.3.111.2.802.1.1.13.1.1.8.1.4.53.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.53.3	1.3.111.2.802.1.1.13.1.1.8.1.4.53.3	Integer	false (2)
IldpV2PortConfigNotificationEnable.54.1	1.3.111.2.802.1.1.13.1.1.8.1.4.54.1	Integer	false (2)
IldpV2PortConfigNotificationEnable.54.2	1.3.111.2.802.1.1.13.1.1.8.1.4.54.2	Integer	false (2)
IldpV2PortConfigNotificationEnable.54.3	1.3.111.2.802.1.1.13.1.1.8.1.4.54.3	Integer	false (2)
IldpV2PortConfigTLVsTxEnable.1.1	1.3.111.2.802.1.1.13.1.1.8.1.5.1.1	OctetString	{portDesc, sysName, sysDesc, sysCap}

Name	OID	Value Type	Value Example
IldpV2PortConfigTLVsTxEnable.1.2	.1.3.111.2.802.1.1.13.1.1.8.1.5.1.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.1.3	.1.3.111.2.802.1.1.13.1.1.8.1.5.1.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.2.1	.1.3.111.2.802.1.1.13.1.1.8.1.5.2.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.2.2	.1.3.111.2.802.1.1.13.1.1.8.1.5.2.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.2.3	.1.3.111.2.802.1.1.13.1.1.8.1.5.2.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.3.1	.1.3.111.2.802.1.1.13.1.1.8.1.5.3.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.3.2	.1.3.111.2.802.1.1.13.1.1.8.1.5.3.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.3.3	.1.3.111.2.802.1.1.13.1.1.8.1.5.3.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.4.1	.1.3.111.2.802.1.1.13.1.1.8.1.5.4.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.4.2	.1.3.111.2.802.1.1.13.1.1.8.1.5.4.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.4.3	.1.3.111.2.802.1.1.13.1.1.8.1.5.4.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.5.1	.1.3.111.2.802.1.1.13.1.1.8.1.5.5.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.5.2	.1.3.111.2.802.1.1.13.1.1.8.1.5.5.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.5.3	.1.3.111.2.802.1.1.13.1.1.8.1.5.5.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.6.1	.1.3.111.2.802.1.1.13.1.1.8.1.5.6.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.6.2	.1.3.111.2.802.1.1.13.1.1.8.1.5.6.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.6.3	.1.3.111.2.802.1.1.13.1.1.8.1.5.6.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.7.1	.1.3.111.2.802.1.1.13.1.1.8.1.5.7.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.7.2	.1.3.111.2.802.1.1.13.1.1.8.1.5.7.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.7.3	.1.3.111.2.802.1.1.13.1.1.8.1.5.7.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.8.1	.1.3.111.2.802.1.1.13.1.1.8.1.5.8.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.8.2	.1.3.111.2.802.1.1.13.1.1.8.1.5.8.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.8.3	.1.3.111.2.802.1.1.13.1.1.8.1.5.8.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.9.1	.1.3.111.2.802.1.1.13.1.1.8.1.5.9.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.9.2	.1.3.111.2.802.1.1.13.1.1.8.1.5.9.2	OctetString	{}

Name	OID	Value Type	Value Example
IldpV2PortConfigTLVsTxEnable.9.3	.1.3.111.2.802.1.1.13.1.1.8.1.5.9.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.10.1	1.3.111.2.802.1.1.13.1.1.8.1.5.10.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.10.2	1.3.111.2.802.1.1.13.1.1.8.1.5.10.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.10.3	1.3.111.2.802.1.1.13.1.1.8.1.5.10.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.11.1	1.3.111.2.802.1.1.13.1.1.8.1.5.11.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.11.2	1.3.111.2.802.1.1.13.1.1.8.1.5.11.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.11.3	1.3.111.2.802.1.1.13.1.1.8.1.5.11.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.12.1	1.3.111.2.802.1.1.13.1.1.8.1.5.12.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.12.2	1.3.111.2.802.1.1.13.1.1.8.1.5.12.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.12.3	1.3.111.2.802.1.1.13.1.1.8.1.5.12.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.13.1	1.3.111.2.802.1.1.13.1.1.8.1.5.13.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.13.2	1.3.111.2.802.1.1.13.1.1.8.1.5.13.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.13.3	1.3.111.2.802.1.1.13.1.1.8.1.5.13.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.14.1	1.3.111.2.802.1.1.13.1.1.8.1.5.14.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.14.2	1.3.111.2.802.1.1.13.1.1.8.1.5.14.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.14.3	1.3.111.2.802.1.1.13.1.1.8.1.5.14.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.15.1	1.3.111.2.802.1.1.13.1.1.8.1.5.15.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.15.2	1.3.111.2.802.1.1.13.1.1.8.1.5.15.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.15.3	1.3.111.2.802.1.1.13.1.1.8.1.5.15.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.16.1	1.3.111.2.802.1.1.13.1.1.8.1.5.16.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.16.2	1.3.111.2.802.1.1.13.1.1.8.1.5.16.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.16.3	1.3.111.2.802.1.1.13.1.1.8.1.5.16.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.17.1	1.3.111.2.802.1.1.13.1.1.8.1.5.17.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.17.2	1.3.111.2.802.1.1.13.1.1.8.1.5.17.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.17.3	1.3.111.2.802.1.1.13.1.1.8.1.5.17.3	OctetString	{portDesc, sysName, sysDesc, sysCap}

Name	OID	Value Type	Value Example
IldpV2PortConfigTLVsTxEnable.18.1	1.3.111.2.802.1.1.13.1.1.8.1.5.18.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.18.2	1.3.111.2.802.1.1.13.1.1.8.1.5.18.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.18.3	1.3.111.2.802.1.1.13.1.1.8.1.5.18.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.19.1	1.3.111.2.802.1.1.13.1.1.8.1.5.19.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.19.2	1.3.111.2.802.1.1.13.1.1.8.1.5.19.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.19.3	1.3.111.2.802.1.1.13.1.1.8.1.5.19.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.20.1	1.3.111.2.802.1.1.13.1.1.8.1.5.20.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.20.2	1.3.111.2.802.1.1.13.1.1.8.1.5.20.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.20.3	1.3.111.2.802.1.1.13.1.1.8.1.5.20.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.21.1	1.3.111.2.802.1.1.13.1.1.8.1.5.21.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.21.2	1.3.111.2.802.1.1.13.1.1.8.1.5.21.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.21.3	1.3.111.2.802.1.1.13.1.1.8.1.5.21.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.22.1	1.3.111.2.802.1.1.13.1.1.8.1.5.22.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.22.2	1.3.111.2.802.1.1.13.1.1.8.1.5.22.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.22.3	1.3.111.2.802.1.1.13.1.1.8.1.5.22.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.23.1	1.3.111.2.802.1.1.13.1.1.8.1.5.23.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.23.2	1.3.111.2.802.1.1.13.1.1.8.1.5.23.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.23.3	1.3.111.2.802.1.1.13.1.1.8.1.5.23.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.24.1	1.3.111.2.802.1.1.13.1.1.8.1.5.24.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.24.2	1.3.111.2.802.1.1.13.1.1.8.1.5.24.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.24.3	1.3.111.2.802.1.1.13.1.1.8.1.5.24.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.25.1	1.3.111.2.802.1.1.13.1.1.8.1.5.25.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.25.2	1.3.111.2.802.1.1.13.1.1.8.1.5.25.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.25.3	1.3.111.2.802.1.1.13.1.1.8.1.5.25.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.26.1	1.3.111.2.802.1.1.13.1.1.8.1.5.26.1	OctetString	{portDesc, sysName, sysDesc, sysCap}

Name	OID	Value Type	Value Example
IldpV2PortConfigTLVsTxEnable.26.2	1.3.111.2.802.1.1.13.1.1.8.1.5.26.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.26.3	1.3.111.2.802.1.1.13.1.1.8.1.5.26.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.27.1	1.3.111.2.802.1.1.13.1.1.8.1.5.27.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.27.2	1.3.111.2.802.1.1.13.1.1.8.1.5.27.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.27.3	1.3.111.2.802.1.1.13.1.1.8.1.5.27.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.28.1	1.3.111.2.802.1.1.13.1.1.8.1.5.28.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.28.2	1.3.111.2.802.1.1.13.1.1.8.1.5.28.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.28.3	1.3.111.2.802.1.1.13.1.1.8.1.5.28.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.29.1	1.3.111.2.802.1.1.13.1.1.8.1.5.29.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.29.2	1.3.111.2.802.1.1.13.1.1.8.1.5.29.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.29.3	1.3.111.2.802.1.1.13.1.1.8.1.5.29.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.30.1	1.3.111.2.802.1.1.13.1.1.8.1.5.30.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.30.2	1.3.111.2.802.1.1.13.1.1.8.1.5.30.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.30.3	1.3.111.2.802.1.1.13.1.1.8.1.5.30.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.31.1	1.3.111.2.802.1.1.13.1.1.8.1.5.31.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.31.2	1.3.111.2.802.1.1.13.1.1.8.1.5.31.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.31.3	1.3.111.2.802.1.1.13.1.1.8.1.5.31.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.32.1	1.3.111.2.802.1.1.13.1.1.8.1.5.32.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.32.2	1.3.111.2.802.1.1.13.1.1.8.1.5.32.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.32.3	1.3.111.2.802.1.1.13.1.1.8.1.5.32.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.33.1	1.3.111.2.802.1.1.13.1.1.8.1.5.33.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.33.2	1.3.111.2.802.1.1.13.1.1.8.1.5.33.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.33.3	1.3.111.2.802.1.1.13.1.1.8.1.5.33.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.34.1	1.3.111.2.802.1.1.13.1.1.8.1.5.34.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.34.2	1.3.111.2.802.1.1.13.1.1.8.1.5.34.2	OctetString	{}

Name	OID	Value Type	Value Example
IldpV2PortConfigTLVsTxEnable.34.3	1.3.111.2.802.1.1.13.1.1.8.1.5.34.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.35.1	1.3.111.2.802.1.1.13.1.1.8.1.5.35.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.35.2	1.3.111.2.802.1.1.13.1.1.8.1.5.35.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.35.3	1.3.111.2.802.1.1.13.1.1.8.1.5.35.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.36.1	1.3.111.2.802.1.1.13.1.1.8.1.5.36.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.36.2	1.3.111.2.802.1.1.13.1.1.8.1.5.36.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.36.3	1.3.111.2.802.1.1.13.1.1.8.1.5.36.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.37.1	1.3.111.2.802.1.1.13.1.1.8.1.5.37.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.37.2	1.3.111.2.802.1.1.13.1.1.8.1.5.37.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.37.3	1.3.111.2.802.1.1.13.1.1.8.1.5.37.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.38.1	1.3.111.2.802.1.1.13.1.1.8.1.5.38.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.38.2	1.3.111.2.802.1.1.13.1.1.8.1.5.38.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.38.3	1.3.111.2.802.1.1.13.1.1.8.1.5.38.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.39.1	1.3.111.2.802.1.1.13.1.1.8.1.5.39.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.39.2	1.3.111.2.802.1.1.13.1.1.8.1.5.39.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.39.3	1.3.111.2.802.1.1.13.1.1.8.1.5.39.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.40.1	1.3.111.2.802.1.1.13.1.1.8.1.5.40.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.40.2	1.3.111.2.802.1.1.13.1.1.8.1.5.40.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.40.3	1.3.111.2.802.1.1.13.1.1.8.1.5.40.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.41.1	1.3.111.2.802.1.1.13.1.1.8.1.5.41.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.41.2	1.3.111.2.802.1.1.13.1.1.8.1.5.41.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.41.3	1.3.111.2.802.1.1.13.1.1.8.1.5.41.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.42.1	1.3.111.2.802.1.1.13.1.1.8.1.5.42.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.42.2	1.3.111.2.802.1.1.13.1.1.8.1.5.42.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.42.3	1.3.111.2.802.1.1.13.1.1.8.1.5.42.3	OctetString	{portDesc, sysName, sysDesc, sysCap}

Name	OID	Value Type	Value Example
IldpV2PortConfigTLVsTxEnable.43.1	1.3.111.2.802.1.1.13.1.1.8.1.5.43.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.43.2	1.3.111.2.802.1.1.13.1.1.8.1.5.43.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.43.3	1.3.111.2.802.1.1.13.1.1.8.1.5.43.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.44.1	1.3.111.2.802.1.1.13.1.1.8.1.5.44.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.44.2	1.3.111.2.802.1.1.13.1.1.8.1.5.44.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.44.3	1.3.111.2.802.1.1.13.1.1.8.1.5.44.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.45.1	1.3.111.2.802.1.1.13.1.1.8.1.5.45.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.45.2	1.3.111.2.802.1.1.13.1.1.8.1.5.45.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.45.3	1.3.111.2.802.1.1.13.1.1.8.1.5.45.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.46.1	1.3.111.2.802.1.1.13.1.1.8.1.5.46.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.46.2	1.3.111.2.802.1.1.13.1.1.8.1.5.46.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.46.3	1.3.111.2.802.1.1.13.1.1.8.1.5.46.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.47.1	1.3.111.2.802.1.1.13.1.1.8.1.5.47.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.47.2	1.3.111.2.802.1.1.13.1.1.8.1.5.47.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.47.3	1.3.111.2.802.1.1.13.1.1.8.1.5.47.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.48.1	1.3.111.2.802.1.1.13.1.1.8.1.5.48.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.48.2	1.3.111.2.802.1.1.13.1.1.8.1.5.48.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.48.3	1.3.111.2.802.1.1.13.1.1.8.1.5.48.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.49.1	1.3.111.2.802.1.1.13.1.1.8.1.5.49.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.49.2	1.3.111.2.802.1.1.13.1.1.8.1.5.49.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.49.3	1.3.111.2.802.1.1.13.1.1.8.1.5.49.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.50.1	1.3.111.2.802.1.1.13.1.1.8.1.5.50.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.50.2	1.3.111.2.802.1.1.13.1.1.8.1.5.50.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.50.3	1.3.111.2.802.1.1.13.1.1.8.1.5.50.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.51.1	1.3.111.2.802.1.1.13.1.1.8.1.5.51.1	OctetString	{portDesc, sysName, sysDesc, sysCap}



Name	OID	Value Type	Value Example
IldpV2PortConfigTLVsTxEnable.51.2	1.3.111.2.802.1.1.13.1.1.8.1.5.51.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.51.3	1.3.111.2.802.1.1.13.1.1.8.1.5.51.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.52.1	1.3.111.2.802.1.1.13.1.1.8.1.5.52.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.52.2	1.3.111.2.802.1.1.13.1.1.8.1.5.52.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.52.3	1.3.111.2.802.1.1.13.1.1.8.1.5.52.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.53.1	1.3.111.2.802.1.1.13.1.1.8.1.5.53.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.53.2	1.3.111.2.802.1.1.13.1.1.8.1.5.53.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.53.3	1.3.111.2.802.1.1.13.1.1.8.1.5.53.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.54.1	1.3.111.2.802.1.1.13.1.1.8.1.5.54.1	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2PortConfigTLVsTxEnable.54.2	1.3.111.2.802.1.1.13.1.1.8.1.5.54.2	OctetString	{}
IldpV2PortConfigTLVsTxEnable.54.3	1.3.111.2.802.1.1.13.1.1.8.1.5.54.3	OctetString	{portDesc, sysName, sysDesc, sysCap}
IldpV2DestMacAddress.1	.1.3.111.2.802.1.1.13.1.1.9.1.2.1	OctetString	01-80-C2-00-00-0E
IldpV2DestMacAddress.2	.1.3.111.2.802.1.1.13.1.1.9.1.2.2	OctetString	01-80-C2-00-00-03
IldpV2DestMacAddress.3	.1.3.111.2.802.1.1.13.1.1.9.1.2.3	OctetString	01-80-C2-00-00-00
IldpV2ManAddrConfigTxEnable.1.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.1.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.1.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.1.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.1.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.1.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.1.2.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.2.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.1.2.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.2.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.1.2.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.2.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.1.3.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.3.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.1.3.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.3.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.1.3.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.3.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.1.4.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.4.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.1.4.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.4.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.1.4.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.4.3.1.4.0.0.0.0	Integer	true (1)

Name	OID	Value Type	Value Example
IldpV2ManAddrConfigTxEnable.5.1.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.5.1.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.5.2.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.5.2.1.4.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.5.3.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.5.3.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.6.1.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.6.1.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.6.2.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.6.2.1.4.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.6.3.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.6.3.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.7.1.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.7.1.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.7.2.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.7.2.1.4.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.7.3.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.7.3.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.8.1.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.8.1.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.8.2.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.8.2.1.4.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.8.3.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.8.3.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.9.1.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.9.1.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.9.2.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.9.2.1.4.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.9.3.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.9.3.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.10.1.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.10.1.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.10.2.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.10.2.1.4.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.10.3.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.10.3.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.11.1.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.11.1.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.11.2.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.11.2.1.4.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.11.3.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.11.3.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.12.1.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.12.1.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.12.2.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.12.2.1.4.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.12.3.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.12.3.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.13.1.1.4.0.0.0	1.2.802.1.1.13.1.1.10.1.5.13.1.1.4.0.0.0	Integer	true (1)

Name	OID	Value Type	Value Example
IldpV2ManAddrConfigTxEnable.13.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.13.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.13.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.13.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.14.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.14.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.14.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.14.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.14.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.14.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.15.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.15.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.15.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.15.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.15.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.15.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.16.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.16.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.16.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.16.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.16.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.16.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.17.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.17.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.17.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.17.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.17.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.17.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.18.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.18.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.18.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.18.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.18.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.18.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.19.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.19.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.19.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.19.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.19.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.19.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.20.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.20.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.20.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.20.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.20.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.20.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.21.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.21.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.21.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.21.2.1.4.0.0.0.0	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2ManAddrConfigTxEnable.21.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.21.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.22.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.22.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.22.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.22.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.22.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.22.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.23.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.23.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.23.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.23.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.23.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.23.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.24.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.24.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.24.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.24.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.24.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.24.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.25.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.25.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.25.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.25.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.25.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.25.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.26.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.26.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.26.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.26.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.26.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.26.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.27.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.27.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.27.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.27.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.27.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.27.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.28.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.28.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.28.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.28.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.28.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.28.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.29.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.29.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.29.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.29.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.29.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.29.3.1.4.0.0.0.0	Integer	true (1)

Name	OID	Value Type	Value Example
IldpV2ManAddrConfigTxEnable.3.11ble.30.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.30.1.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.11ble.30.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.30.2.1.4.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.3.11ble.30.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.30.3.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.11ble.31.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.31.1.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.11ble.31.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.31.2.1.4.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.3.11ble.31.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.31.3.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.11ble.32.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.32.1.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.11ble.32.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.32.2.1.4.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.3.11ble.32.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.32.3.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.11ble.33.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.33.1.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.11ble.33.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.33.2.1.4.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.3.11ble.33.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.33.3.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.11ble.34.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.34.1.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.11ble.34.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.34.2.1.4.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.3.11ble.34.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.34.3.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.11ble.35.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.35.1.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.11ble.35.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.35.2.1.4.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.3.11ble.35.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.35.3.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.11ble.36.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.36.1.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.11ble.36.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.36.2.1.4.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.3.11ble.36.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.36.3.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.11ble.37.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.37.1.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.11ble.37.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.37.2.1.4.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.3.11ble.37.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.37.3.1.4.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.11ble.38.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.38.1.1.4.0.0.0	Integer	true (1)

Name	OID	Value Type	Value Example
IldpV2ManAddrConfigTxEnable.3.111.38.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.38.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.3.111.38.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.38.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.111.39.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.39.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.111.39.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.39.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.3.111.39.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.39.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.111.40.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.40.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.111.40.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.40.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.3.111.40.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.40.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.111.41.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.41.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.111.41.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.41.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.3.111.41.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.41.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.111.42.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.42.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.111.42.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.42.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.3.111.42.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.42.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.111.43.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.43.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.111.43.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.43.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.3.111.43.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.43.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.111.44.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.44.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.111.44.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.44.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.3.111.44.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.44.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.111.45.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.45.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.111.45.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.45.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.3.111.45.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.45.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.111.46.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.46.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.3.111.46.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.46.2.1.4.0.0.0.0	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2ManAddrConfigTxEnable.46.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.46.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.47.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.47.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.47.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.47.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.47.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.47.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.48.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.48.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.48.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.48.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.48.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.48.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.49.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.49.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.49.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.49.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.49.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.49.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.50.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.50.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.50.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.50.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.50.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.50.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.51.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.51.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.51.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.51.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.51.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.51.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.52.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.52.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.52.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.52.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.52.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.52.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.53.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.53.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.53.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.53.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.53.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.53.3.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.54.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.54.1.1.4.0.0.0.0	Integer	true (1)
IldpV2ManAddrConfigTxEnable.54.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.54.2.1.4.0.0.0.0	Integer	false (2)
IldpV2ManAddrConfigTxEnable.54.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.5.54.3.1.4.0.0.0.0	Integer	true (1)



Name	OID	Value Type	Value Example
IldpV2ManAddrConfigRowStatus.1.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.1.1.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.1.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.1.2.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.1.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.1.3.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.2.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.2.1.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.2.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.2.2.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.2.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.2.3.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.3.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.3.1.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.3.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.3.2.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.3.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.3.3.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.4.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.4.1.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.4.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.4.2.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.4.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.4.3.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.5.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.5.1.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.5.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.5.2.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.5.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.5.3.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.6.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.6.1.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.6.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.6.2.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.6.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.6.3.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.7.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.7.1.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.7.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.7.2.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.7.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.7.3.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.8.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.8.1.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.8.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.8.2.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.8.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.8.3.1.4.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.9.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.9.1.1.4.0.0	Integer	active (1)

Name	OID	Value Type	Value Example
IldpV2ManAddrConfigRowStatus.9.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.9.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.9.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.9.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.10.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.10.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.10.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.10.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.10.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.10.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.11.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.11.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.11.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.11.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.11.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.11.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.12.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.12.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.12.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.12.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.12.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.12.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.13.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.13.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.13.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.13.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.13.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.13.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.14.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.14.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.14.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.14.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.14.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.14.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.15.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.15.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.15.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.15.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.15.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.15.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.16.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.16.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.16.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.16.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.16.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.16.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.17.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.17.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.17.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.17.2.1.4.0.0.0.0	Integer	active (1)

Name	OID	Value Type	Value Example
IldpV2ManAddrConfigRowStatus.17.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.17.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.18.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.18.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.18.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.18.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.18.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.18.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.19.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.19.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.19.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.19.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.19.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.19.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.20.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.20.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.20.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.20.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.20.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.20.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.21.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.21.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.21.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.21.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.21.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.21.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.22.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.22.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.22.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.22.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.22.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.22.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.23.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.23.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.23.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.23.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.23.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.23.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.24.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.24.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.24.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.24.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.24.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.24.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.25.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.25.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.25.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.25.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.25.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.25.3.1.4.0.0.0.0	Integer	active (1)

Name	OID	Value Type	Value Example
IldpV2ManAddrConfigRowStatus.26.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.26.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.26.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.26.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.26.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.26.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.27.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.27.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.27.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.27.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.27.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.27.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.28.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.28.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.28.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.28.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.28.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.28.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.29.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.29.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.29.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.29.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.29.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.29.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.30.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.30.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.30.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.30.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.30.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.30.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.31.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.31.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.31.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.31.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.31.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.31.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.32.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.32.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.32.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.32.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.32.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.32.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.33.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.33.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.33.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.33.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.33.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.33.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.34.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.34.1.1.4.0.0.0.0	Integer	active (1)

Name	OID	Value Type	Value Example
IldpV2ManAddrConfigRowStatus.34.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.34.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.34.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.34.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.35.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.35.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.35.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.35.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.35.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.35.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.36.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.36.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.36.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.36.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.36.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.36.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.37.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.37.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.37.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.37.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.37.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.37.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.38.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.38.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.38.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.38.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.38.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.38.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.39.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.39.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.39.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.39.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.39.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.39.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.40.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.40.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.40.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.40.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.40.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.40.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.41.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.41.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.41.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.41.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.41.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.41.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.42.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.42.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.42.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.42.2.1.4.0.0.0.0	Integer	active (1)

Name	OID	Value Type	Value Example
IldpV2ManAddrConfigRowStatus.42.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.42.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.43.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.43.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.43.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.43.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.43.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.43.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.44.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.44.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.44.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.44.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.44.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.44.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.45.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.45.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.45.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.45.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.45.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.45.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.46.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.46.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.46.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.46.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.46.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.46.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.47.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.47.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.47.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.47.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.47.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.47.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.48.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.48.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.48.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.48.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.48.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.48.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.49.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.49.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.49.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.49.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.49.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.49.3.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.50.1.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.50.1.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.50.2.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.50.2.1.4.0.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.50.3.1.4.0.0.0.0	1.2.802.1.1.13.1.1.10.1.6.50.3.1.4.0.0.0.0	Integer	active (1)

Name	OID	Value Type	Value Example
IldpV2ManAddrConfigRowStatus.111.2.802.1.1.13.1.1.10.1.6.51.1.1.4.0.0.0	1.1.2.802.1.1.13.1.1.10.1.6.51.1.1.4.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.111.2.802.1.1.13.1.1.10.1.6.51.2.1.4.0.0.0	1.1.2.802.1.1.13.1.1.10.1.6.51.2.1.4.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.111.2.802.1.1.13.1.1.10.1.6.51.3.1.4.0.0.0	1.1.2.802.1.1.13.1.1.10.1.6.51.3.1.4.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.111.2.802.1.1.13.1.1.10.1.6.52.1.1.4.0.0.0	1.1.2.802.1.1.13.1.1.10.1.6.52.1.1.4.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.111.2.802.1.1.13.1.1.10.1.6.52.2.1.4.0.0.0	1.1.2.802.1.1.13.1.1.10.1.6.52.2.1.4.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.111.2.802.1.1.13.1.1.10.1.6.52.3.1.4.0.0.0	1.1.2.802.1.1.13.1.1.10.1.6.52.3.1.4.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.111.2.802.1.1.13.1.1.10.1.6.53.1.1.4.0.0.0	1.1.2.802.1.1.13.1.1.10.1.6.53.1.1.4.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.111.2.802.1.1.13.1.1.10.1.6.53.2.1.4.0.0.0	1.1.2.802.1.1.13.1.1.10.1.6.53.2.1.4.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.111.2.802.1.1.13.1.1.10.1.6.53.3.1.4.0.0.0	1.1.2.802.1.1.13.1.1.10.1.6.53.3.1.4.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.111.2.802.1.1.13.1.1.10.1.6.54.1.1.4.0.0.0	1.1.2.802.1.1.13.1.1.10.1.6.54.1.1.4.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.111.2.802.1.1.13.1.1.10.1.6.54.2.1.4.0.0.0	1.1.2.802.1.1.13.1.1.10.1.6.54.2.1.4.0.0.0	Integer	active (1)
IldpV2ManAddrConfigRowStatus.111.2.802.1.1.13.1.1.10.1.6.54.3.1.4.0.0.0	1.1.2.802.1.1.13.1.1.10.1.6.54.3.1.4.0.0.0	Integer	active (1)
IldpV2StatsRemTablesLast-ChangeTime.0	.1.3.111.2.802.1.1.13.1.2.1.0	TimeTicks	23 minutes 15.37 seconds (139537)
IldpV2StatsRemTablesInserts.0	.1.3.111.2.802.1.1.13.1.2.2.0	Gauge	2
IldpV2StatsRemTablesDeletes.0	.1.3.111.2.802.1.1.13.1.2.3.0	Gauge	1
IldpV2StatsRemTablesDrops.0	.1.3.111.2.802.1.1.13.1.2.4.0	Gauge	0
IldpV2StatsRemTablesAge-outs.0	.1.3.111.2.802.1.1.13.1.2.5.0	Gauge	0
IldpV2StatsTxPortFramesTotal.1.1	.1.3.111.2.802.1.1.13.1.2.6.1.3.1.1	Counter32	94
IldpV2StatsTxPortFramesTotal.1.2	.1.3.111.2.802.1.1.13.1.2.6.1.3.1.2	Counter32	0
IldpV2StatsTxPortFramesTotal.1.3	.1.3.111.2.802.1.1.13.1.2.6.1.3.1.3	Counter32	0
IldpV2StatsTxPortFramesTotal.2.1	.1.3.111.2.802.1.1.13.1.2.6.1.3.2.1	Counter32	0
IldpV2StatsTxPortFramesTotal.2.2	.1.3.111.2.802.1.1.13.1.2.6.1.3.2.2	Counter32	0
IldpV2StatsTxPortFramesTotal.2.3	.1.3.111.2.802.1.1.13.1.2.6.1.3.2.3	Counter32	0
IldpV2StatsTxPortFramesTotal.3.1	.1.3.111.2.802.1.1.13.1.2.6.1.3.3.1	Counter32	0
IldpV2StatsTxPortFramesTotal.3.2	.1.3.111.2.802.1.1.13.1.2.6.1.3.3.2	Counter32	0
IldpV2StatsTxPortFramesTotal.3.3	.1.3.111.2.802.1.1.13.1.2.6.1.3.3.3	Counter32	0



<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
IldpV2StatsTxPortFramesTotal.4.1	.1.3.111.2.802.1.1.13.1.2.6.1.3.4.1	Counter32	0
IldpV2StatsTxPortFramesTotal.4.2	.1.3.111.2.802.1.1.13.1.2.6.1.3.4.2	Counter32	0
IldpV2StatsTxPortFramesTotal.4.3	.1.3.111.2.802.1.1.13.1.2.6.1.3.4.3	Counter32	0
IldpV2StatsTxPortFramesTotal.5.1	.1.3.111.2.802.1.1.13.1.2.6.1.3.5.1	Counter32	0
IldpV2StatsTxPortFramesTotal.5.2	.1.3.111.2.802.1.1.13.1.2.6.1.3.5.2	Counter32	0
IldpV2StatsTxPortFramesTotal.5.3	.1.3.111.2.802.1.1.13.1.2.6.1.3.5.3	Counter32	0
IldpV2StatsTxPortFramesTotal.6.1	.1.3.111.2.802.1.1.13.1.2.6.1.3.6.1	Counter32	0
IldpV2StatsTxPortFramesTotal.6.2	.1.3.111.2.802.1.1.13.1.2.6.1.3.6.2	Counter32	0
IldpV2StatsTxPortFramesTotal.6.3	.1.3.111.2.802.1.1.13.1.2.6.1.3.6.3	Counter32	0
IldpV2StatsTxPortFramesTotal.7.1	.1.3.111.2.802.1.1.13.1.2.6.1.3.7.1	Counter32	0
IldpV2StatsTxPortFramesTotal.7.2	.1.3.111.2.802.1.1.13.1.2.6.1.3.7.2	Counter32	0
IldpV2StatsTxPortFramesTotal.7.3	.1.3.111.2.802.1.1.13.1.2.6.1.3.7.3	Counter32	0
IldpV2StatsTxPortFramesTotal.8.1	.1.3.111.2.802.1.1.13.1.2.6.1.3.8.1	Counter32	0
IldpV2StatsTxPortFramesTotal.8.2	.1.3.111.2.802.1.1.13.1.2.6.1.3.8.2	Counter32	0
IldpV2StatsTxPortFramesTotal.8.3	.1.3.111.2.802.1.1.13.1.2.6.1.3.8.3	Counter32	0
IldpV2StatsTxPortFramesTotal.9.1	.1.3.111.2.802.1.1.13.1.2.6.1.3.9.1	Counter32	0
IldpV2StatsTxPortFramesTotal.9.2	.1.3.111.2.802.1.1.13.1.2.6.1.3.9.2	Counter32	0
IldpV2StatsTxPortFramesTotal.9.3	.1.3.111.2.802.1.1.13.1.2.6.1.3.9.3	Counter32	0
IldpV2StatsTxPortFramesTotal.10.1	.1.3.111.2.802.1.1.13.1.2.6.1.3.10.1	Counter32	0
IldpV2StatsTxPortFramesTotal.10.2	.1.3.111.2.802.1.1.13.1.2.6.1.3.10.2	Counter32	0
IldpV2StatsTxPortFramesTotal.10.3	.1.3.111.2.802.1.1.13.1.2.6.1.3.10.3	Counter32	0
IldpV2StatsTxPortFramesTotal.11.1	.1.3.111.2.802.1.1.13.1.2.6.1.3.11.1	Counter32	0
IldpV2StatsTxPortFramesTotal.11.2	.1.3.111.2.802.1.1.13.1.2.6.1.3.11.2	Counter32	0
IldpV2StatsTxPortFramesTotal.11.3	.1.3.111.2.802.1.1.13.1.2.6.1.3.11.3	Counter32	0
IldpV2StatsTxPortFramesTotal.12.1	.1.3.111.2.802.1.1.13.1.2.6.1.3.12.1	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsTxPortFramesTotal.12.2	1.3.111.2.802.1.1.13.1.2.6.1.3.12.2	Counter32	0
IldpV2StatsTxPortFramesTotal.12.3	1.3.111.2.802.1.1.13.1.2.6.1.3.12.3	Counter32	0
IldpV2StatsTxPortFramesTotal.13.1	1.3.111.2.802.1.1.13.1.2.6.1.3.13.1	Counter32	0
IldpV2StatsTxPortFramesTotal.13.2	1.3.111.2.802.1.1.13.1.2.6.1.3.13.2	Counter32	0
IldpV2StatsTxPortFramesTotal.13.3	1.3.111.2.802.1.1.13.1.2.6.1.3.13.3	Counter32	0
IldpV2StatsTxPortFramesTotal.14.1	1.3.111.2.802.1.1.13.1.2.6.1.3.14.1	Counter32	0
IldpV2StatsTxPortFramesTotal.14.2	1.3.111.2.802.1.1.13.1.2.6.1.3.14.2	Counter32	0
IldpV2StatsTxPortFramesTotal.14.3	1.3.111.2.802.1.1.13.1.2.6.1.3.14.3	Counter32	0
IldpV2StatsTxPortFramesTotal.15.1	1.3.111.2.802.1.1.13.1.2.6.1.3.15.1	Counter32	0
IldpV2StatsTxPortFramesTotal.15.2	1.3.111.2.802.1.1.13.1.2.6.1.3.15.2	Counter32	0
IldpV2StatsTxPortFramesTotal.15.3	1.3.111.2.802.1.1.13.1.2.6.1.3.15.3	Counter32	0
IldpV2StatsTxPortFramesTotal.16.1	1.3.111.2.802.1.1.13.1.2.6.1.3.16.1	Counter32	0
IldpV2StatsTxPortFramesTotal.16.2	1.3.111.2.802.1.1.13.1.2.6.1.3.16.2	Counter32	0
IldpV2StatsTxPortFramesTotal.16.3	1.3.111.2.802.1.1.13.1.2.6.1.3.16.3	Counter32	0
IldpV2StatsTxPortFramesTotal.17.1	1.3.111.2.802.1.1.13.1.2.6.1.3.17.1	Counter32	0
IldpV2StatsTxPortFramesTotal.17.2	1.3.111.2.802.1.1.13.1.2.6.1.3.17.2	Counter32	0
IldpV2StatsTxPortFramesTotal.17.3	1.3.111.2.802.1.1.13.1.2.6.1.3.17.3	Counter32	0
IldpV2StatsTxPortFramesTotal.18.1	1.3.111.2.802.1.1.13.1.2.6.1.3.18.1	Counter32	0
IldpV2StatsTxPortFramesTotal.18.2	1.3.111.2.802.1.1.13.1.2.6.1.3.18.2	Counter32	0
IldpV2StatsTxPortFramesTotal.18.3	1.3.111.2.802.1.1.13.1.2.6.1.3.18.3	Counter32	0
IldpV2StatsTxPortFramesTotal.19.1	1.3.111.2.802.1.1.13.1.2.6.1.3.19.1	Counter32	0
IldpV2StatsTxPortFramesTotal.19.2	1.3.111.2.802.1.1.13.1.2.6.1.3.19.2	Counter32	0
IldpV2StatsTxPortFramesTotal.19.3	1.3.111.2.802.1.1.13.1.2.6.1.3.19.3	Counter32	0
IldpV2StatsTxPortFramesTotal.20.1	1.3.111.2.802.1.1.13.1.2.6.1.3.20.1	Counter32	0
IldpV2StatsTxPortFramesTotal.20.2	1.3.111.2.802.1.1.13.1.2.6.1.3.20.2	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsTxPortFramesTotal.20.3	1.3.111.2.802.1.1.13.1.2.6.1.3.20.3	Counter32	0
IldpV2StatsTxPortFramesTotal.21.1	1.3.111.2.802.1.1.13.1.2.6.1.3.21.1	Counter32	0
IldpV2StatsTxPortFramesTotal.21.2	1.3.111.2.802.1.1.13.1.2.6.1.3.21.2	Counter32	0
IldpV2StatsTxPortFramesTotal.21.3	1.3.111.2.802.1.1.13.1.2.6.1.3.21.3	Counter32	0
IldpV2StatsTxPortFramesTotal.22.1	1.3.111.2.802.1.1.13.1.2.6.1.3.22.1	Counter32	0
IldpV2StatsTxPortFramesTotal.22.2	1.3.111.2.802.1.1.13.1.2.6.1.3.22.2	Counter32	0
IldpV2StatsTxPortFramesTotal.22.3	1.3.111.2.802.1.1.13.1.2.6.1.3.22.3	Counter32	0
IldpV2StatsTxPortFramesTotal.23.1	1.3.111.2.802.1.1.13.1.2.6.1.3.23.1	Counter32	0
IldpV2StatsTxPortFramesTotal.23.2	1.3.111.2.802.1.1.13.1.2.6.1.3.23.2	Counter32	0
IldpV2StatsTxPortFramesTotal.23.3	1.3.111.2.802.1.1.13.1.2.6.1.3.23.3	Counter32	0
IldpV2StatsTxPortFramesTotal.24.1	1.3.111.2.802.1.1.13.1.2.6.1.3.24.1	Counter32	0
IldpV2StatsTxPortFramesTotal.24.2	1.3.111.2.802.1.1.13.1.2.6.1.3.24.2	Counter32	0
IldpV2StatsTxPortFramesTotal.24.3	1.3.111.2.802.1.1.13.1.2.6.1.3.24.3	Counter32	0
IldpV2StatsTxPortFramesTotal.25.1	1.3.111.2.802.1.1.13.1.2.6.1.3.25.1	Counter32	0
IldpV2StatsTxPortFramesTotal.25.2	1.3.111.2.802.1.1.13.1.2.6.1.3.25.2	Counter32	0
IldpV2StatsTxPortFramesTotal.25.3	1.3.111.2.802.1.1.13.1.2.6.1.3.25.3	Counter32	0
IldpV2StatsTxPortFramesTotal.26.1	1.3.111.2.802.1.1.13.1.2.6.1.3.26.1	Counter32	0
IldpV2StatsTxPortFramesTotal.26.2	1.3.111.2.802.1.1.13.1.2.6.1.3.26.2	Counter32	0
IldpV2StatsTxPortFramesTotal.26.3	1.3.111.2.802.1.1.13.1.2.6.1.3.26.3	Counter32	0
IldpV2StatsTxPortFramesTotal.27.1	1.3.111.2.802.1.1.13.1.2.6.1.3.27.1	Counter32	0
IldpV2StatsTxPortFramesTotal.27.2	1.3.111.2.802.1.1.13.1.2.6.1.3.27.2	Counter32	0
IldpV2StatsTxPortFramesTotal.27.3	1.3.111.2.802.1.1.13.1.2.6.1.3.27.3	Counter32	0
IldpV2StatsTxPortFramesTotal.28.1	1.3.111.2.802.1.1.13.1.2.6.1.3.28.1	Counter32	0
IldpV2StatsTxPortFramesTotal.28.2	1.3.111.2.802.1.1.13.1.2.6.1.3.28.2	Counter32	0
IldpV2StatsTxPortFramesTotal.28.3	1.3.111.2.802.1.1.13.1.2.6.1.3.28.3	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsTxPortFramesTotal.29.1	1.3.111.2.802.1.1.13.1.2.6.1.3.29.1	Counter32	0
IldpV2StatsTxPortFramesTotal.29.2	1.3.111.2.802.1.1.13.1.2.6.1.3.29.2	Counter32	0
IldpV2StatsTxPortFramesTotal.29.3	1.3.111.2.802.1.1.13.1.2.6.1.3.29.3	Counter32	0
IldpV2StatsTxPortFramesTotal.30.1	1.3.111.2.802.1.1.13.1.2.6.1.3.30.1	Counter32	0
IldpV2StatsTxPortFramesTotal.30.2	1.3.111.2.802.1.1.13.1.2.6.1.3.30.2	Counter32	0
IldpV2StatsTxPortFramesTotal.30.3	1.3.111.2.802.1.1.13.1.2.6.1.3.30.3	Counter32	0
IldpV2StatsTxPortFramesTotal.31.1	1.3.111.2.802.1.1.13.1.2.6.1.3.31.1	Counter32	0
IldpV2StatsTxPortFramesTotal.31.2	1.3.111.2.802.1.1.13.1.2.6.1.3.31.2	Counter32	0
IldpV2StatsTxPortFramesTotal.31.3	1.3.111.2.802.1.1.13.1.2.6.1.3.31.3	Counter32	0
IldpV2StatsTxPortFramesTotal.32.1	1.3.111.2.802.1.1.13.1.2.6.1.3.32.1	Counter32	0
IldpV2StatsTxPortFramesTotal.32.2	1.3.111.2.802.1.1.13.1.2.6.1.3.32.2	Counter32	0
IldpV2StatsTxPortFramesTotal.32.3	1.3.111.2.802.1.1.13.1.2.6.1.3.32.3	Counter32	0
IldpV2StatsTxPortFramesTotal.33.1	1.3.111.2.802.1.1.13.1.2.6.1.3.33.1	Counter32	0
IldpV2StatsTxPortFramesTotal.33.2	1.3.111.2.802.1.1.13.1.2.6.1.3.33.2	Counter32	0
IldpV2StatsTxPortFramesTotal.33.3	1.3.111.2.802.1.1.13.1.2.6.1.3.33.3	Counter32	0
IldpV2StatsTxPortFramesTotal.34.1	1.3.111.2.802.1.1.13.1.2.6.1.3.34.1	Counter32	0
IldpV2StatsTxPortFramesTotal.34.2	1.3.111.2.802.1.1.13.1.2.6.1.3.34.2	Counter32	0
IldpV2StatsTxPortFramesTotal.34.3	1.3.111.2.802.1.1.13.1.2.6.1.3.34.3	Counter32	0
IldpV2StatsTxPortFramesTotal.35.1	1.3.111.2.802.1.1.13.1.2.6.1.3.35.1	Counter32	0
IldpV2StatsTxPortFramesTotal.35.2	1.3.111.2.802.1.1.13.1.2.6.1.3.35.2	Counter32	0
IldpV2StatsTxPortFramesTotal.35.3	1.3.111.2.802.1.1.13.1.2.6.1.3.35.3	Counter32	0
IldpV2StatsTxPortFramesTotal.36.1	1.3.111.2.802.1.1.13.1.2.6.1.3.36.1	Counter32	0
IldpV2StatsTxPortFramesTotal.36.2	1.3.111.2.802.1.1.13.1.2.6.1.3.36.2	Counter32	0
IldpV2StatsTxPortFramesTotal.36.3	1.3.111.2.802.1.1.13.1.2.6.1.3.36.3	Counter32	0
IldpV2StatsTxPortFramesTotal.37.1	1.3.111.2.802.1.1.13.1.2.6.1.3.37.1	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsTxPortFramesTotal.37.2	1.3.111.2.802.1.1.13.1.2.6.1.3.37.2	Counter32	0
IldpV2StatsTxPortFramesTotal.37.3	1.3.111.2.802.1.1.13.1.2.6.1.3.37.3	Counter32	0
IldpV2StatsTxPortFramesTotal.38.1	1.3.111.2.802.1.1.13.1.2.6.1.3.38.1	Counter32	0
IldpV2StatsTxPortFramesTotal.38.2	1.3.111.2.802.1.1.13.1.2.6.1.3.38.2	Counter32	0
IldpV2StatsTxPortFramesTotal.38.3	1.3.111.2.802.1.1.13.1.2.6.1.3.38.3	Counter32	0
IldpV2StatsTxPortFramesTotal.39.1	1.3.111.2.802.1.1.13.1.2.6.1.3.39.1	Counter32	0
IldpV2StatsTxPortFramesTotal.39.2	1.3.111.2.802.1.1.13.1.2.6.1.3.39.2	Counter32	0
IldpV2StatsTxPortFramesTotal.39.3	1.3.111.2.802.1.1.13.1.2.6.1.3.39.3	Counter32	0
IldpV2StatsTxPortFramesTotal.40.1	1.3.111.2.802.1.1.13.1.2.6.1.3.40.1	Counter32	0
IldpV2StatsTxPortFramesTotal.40.2	1.3.111.2.802.1.1.13.1.2.6.1.3.40.2	Counter32	0
IldpV2StatsTxPortFramesTotal.40.3	1.3.111.2.802.1.1.13.1.2.6.1.3.40.3	Counter32	0
IldpV2StatsTxPortFramesTotal.41.1	1.3.111.2.802.1.1.13.1.2.6.1.3.41.1	Counter32	0
IldpV2StatsTxPortFramesTotal.41.2	1.3.111.2.802.1.1.13.1.2.6.1.3.41.2	Counter32	0
IldpV2StatsTxPortFramesTotal.41.3	1.3.111.2.802.1.1.13.1.2.6.1.3.41.3	Counter32	0
IldpV2StatsTxPortFramesTotal.42.1	1.3.111.2.802.1.1.13.1.2.6.1.3.42.1	Counter32	0
IldpV2StatsTxPortFramesTotal.42.2	1.3.111.2.802.1.1.13.1.2.6.1.3.42.2	Counter32	0
IldpV2StatsTxPortFramesTotal.42.3	1.3.111.2.802.1.1.13.1.2.6.1.3.42.3	Counter32	0
IldpV2StatsTxPortFramesTotal.43.1	1.3.111.2.802.1.1.13.1.2.6.1.3.43.1	Counter32	0
IldpV2StatsTxPortFramesTotal.43.2	1.3.111.2.802.1.1.13.1.2.6.1.3.43.2	Counter32	0
IldpV2StatsTxPortFramesTotal.43.3	1.3.111.2.802.1.1.13.1.2.6.1.3.43.3	Counter32	0
IldpV2StatsTxPortFramesTotal.44.1	1.3.111.2.802.1.1.13.1.2.6.1.3.44.1	Counter32	0
IldpV2StatsTxPortFramesTotal.44.2	1.3.111.2.802.1.1.13.1.2.6.1.3.44.2	Counter32	0
IldpV2StatsTxPortFramesTotal.44.3	1.3.111.2.802.1.1.13.1.2.6.1.3.44.3	Counter32	0
IldpV2StatsTxPortFramesTotal.45.1	1.3.111.2.802.1.1.13.1.2.6.1.3.45.1	Counter32	0
IldpV2StatsTxPortFramesTotal.45.2	1.3.111.2.802.1.1.13.1.2.6.1.3.45.2	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsTxPortFramesTotal.45.3	1.3.111.2.802.1.1.13.1.2.6.1.3.45.3	Counter32	0
IldpV2StatsTxPortFramesTotal.46.1	1.3.111.2.802.1.1.13.1.2.6.1.3.46.1	Counter32	0
IldpV2StatsTxPortFramesTotal.46.2	1.3.111.2.802.1.1.13.1.2.6.1.3.46.2	Counter32	0
IldpV2StatsTxPortFramesTotal.46.3	1.3.111.2.802.1.1.13.1.2.6.1.3.46.3	Counter32	0
IldpV2StatsTxPortFramesTotal.47.1	1.3.111.2.802.1.1.13.1.2.6.1.3.47.1	Counter32	0
IldpV2StatsTxPortFramesTotal.47.2	1.3.111.2.802.1.1.13.1.2.6.1.3.47.2	Counter32	0
IldpV2StatsTxPortFramesTotal.47.3	1.3.111.2.802.1.1.13.1.2.6.1.3.47.3	Counter32	0
IldpV2StatsTxPortFramesTotal.48.1	1.3.111.2.802.1.1.13.1.2.6.1.3.48.1	Counter32	0
IldpV2StatsTxPortFramesTotal.48.2	1.3.111.2.802.1.1.13.1.2.6.1.3.48.2	Counter32	0
IldpV2StatsTxPortFramesTotal.48.3	1.3.111.2.802.1.1.13.1.2.6.1.3.48.3	Counter32	0
IldpV2StatsTxPortFramesTotal.49.1	1.3.111.2.802.1.1.13.1.2.6.1.3.49.1	Counter32	0
IldpV2StatsTxPortFramesTotal.49.2	1.3.111.2.802.1.1.13.1.2.6.1.3.49.2	Counter32	0
IldpV2StatsTxPortFramesTotal.49.3	1.3.111.2.802.1.1.13.1.2.6.1.3.49.3	Counter32	0
IldpV2StatsTxPortFramesTotal.50.1	1.3.111.2.802.1.1.13.1.2.6.1.3.50.1	Counter32	0
IldpV2StatsTxPortFramesTotal.50.2	1.3.111.2.802.1.1.13.1.2.6.1.3.50.2	Counter32	0
IldpV2StatsTxPortFramesTotal.50.3	1.3.111.2.802.1.1.13.1.2.6.1.3.50.3	Counter32	0
IldpV2StatsTxPortFramesTotal.51.1	1.3.111.2.802.1.1.13.1.2.6.1.3.51.1	Counter32	0
IldpV2StatsTxPortFramesTotal.51.2	1.3.111.2.802.1.1.13.1.2.6.1.3.51.2	Counter32	0
IldpV2StatsTxPortFramesTotal.51.3	1.3.111.2.802.1.1.13.1.2.6.1.3.51.3	Counter32	0
IldpV2StatsTxPortFramesTotal.52.1	1.3.111.2.802.1.1.13.1.2.6.1.3.52.1	Counter32	0
IldpV2StatsTxPortFramesTotal.52.2	1.3.111.2.802.1.1.13.1.2.6.1.3.52.2	Counter32	0
IldpV2StatsTxPortFramesTotal.52.3	1.3.111.2.802.1.1.13.1.2.6.1.3.52.3	Counter32	0
IldpV2StatsTxPortFramesTotal.53.1	1.3.111.2.802.1.1.13.1.2.6.1.3.53.1	Counter32	0
IldpV2StatsTxPortFramesTotal.53.2	1.3.111.2.802.1.1.13.1.2.6.1.3.53.2	Counter32	0
IldpV2StatsTxPortFramesTotal.53.3	1.3.111.2.802.1.1.13.1.2.6.1.3.53.3	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsTxPortFramesTotal.54.1	.1.3.111.2.802.1.1.13.1.2.6.1.3.54.1	Counter32	0
IldpV2StatsTxPortFramesTotal.54.2	.1.3.111.2.802.1.1.13.1.2.6.1.3.54.2	Counter32	0
IldpV2StatsTxPortFramesTotal.54.3	.1.3.111.2.802.1.1.13.1.2.6.1.3.54.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.1.1	.1.3.111.2.802.1.1.13.1.2.6.1.4.1.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.1.2	.1.3.111.2.802.1.1.13.1.2.6.1.4.1.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.1.3	.1.3.111.2.802.1.1.13.1.2.6.1.4.1.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.2.1	.1.3.111.2.802.1.1.13.1.2.6.1.4.2.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.2.2	.1.3.111.2.802.1.1.13.1.2.6.1.4.2.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.2.3	.1.3.111.2.802.1.1.13.1.2.6.1.4.2.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.3.1	.1.3.111.2.802.1.1.13.1.2.6.1.4.3.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.3.2	.1.3.111.2.802.1.1.13.1.2.6.1.4.3.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.3.3	.1.3.111.2.802.1.1.13.1.2.6.1.4.3.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.4.1	.1.3.111.2.802.1.1.13.1.2.6.1.4.4.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.4.2	.1.3.111.2.802.1.1.13.1.2.6.1.4.4.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.4.3	.1.3.111.2.802.1.1.13.1.2.6.1.4.4.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.5.1	.1.3.111.2.802.1.1.13.1.2.6.1.4.5.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.5.2	.1.3.111.2.802.1.1.13.1.2.6.1.4.5.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.5.3	.1.3.111.2.802.1.1.13.1.2.6.1.4.5.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.6.1	.1.3.111.2.802.1.1.13.1.2.6.1.4.6.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.6.2	.1.3.111.2.802.1.1.13.1.2.6.1.4.6.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.6.3	.1.3.111.2.802.1.1.13.1.2.6.1.4.6.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.7.1	.1.3.111.2.802.1.1.13.1.2.6.1.4.7.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.7.2	.1.3.111.2.802.1.1.13.1.2.6.1.4.7.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.7.3	.1.3.111.2.802.1.1.13.1.2.6.1.4.7.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.8.1	.1.3.111.2.802.1.1.13.1.2.6.1.4.8.1	Counter32	0



Name	OID	Value Type	Value Example
IldpV2StatsTxLLDPDU-LengthErrors.8.2	.1.3.111.2.802.1.1.13.1.2.6.1.4.8.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.8.3	.1.3.111.2.802.1.1.13.1.2.6.1.4.8.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.9.1	.1.3.111.2.802.1.1.13.1.2.6.1.4.9.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.9.2	.1.3.111.2.802.1.1.13.1.2.6.1.4.9.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.9.3	.1.3.111.2.802.1.1.13.1.2.6.1.4.9.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.10.1	1.3.111.2.802.1.1.13.1.2.6.1.4.10.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.10.2	1.3.111.2.802.1.1.13.1.2.6.1.4.10.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.10.3	1.3.111.2.802.1.1.13.1.2.6.1.4.10.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.11.1	1.3.111.2.802.1.1.13.1.2.6.1.4.11.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.11.2	1.3.111.2.802.1.1.13.1.2.6.1.4.11.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.11.3	1.3.111.2.802.1.1.13.1.2.6.1.4.11.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.12.1	1.3.111.2.802.1.1.13.1.2.6.1.4.12.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.12.2	1.3.111.2.802.1.1.13.1.2.6.1.4.12.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.12.3	1.3.111.2.802.1.1.13.1.2.6.1.4.12.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.13.1	1.3.111.2.802.1.1.13.1.2.6.1.4.13.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.13.2	1.3.111.2.802.1.1.13.1.2.6.1.4.13.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.13.3	1.3.111.2.802.1.1.13.1.2.6.1.4.13.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.14.1	1.3.111.2.802.1.1.13.1.2.6.1.4.14.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.14.2	1.3.111.2.802.1.1.13.1.2.6.1.4.14.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.14.3	1.3.111.2.802.1.1.13.1.2.6.1.4.14.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.15.1	1.3.111.2.802.1.1.13.1.2.6.1.4.15.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.15.2	1.3.111.2.802.1.1.13.1.2.6.1.4.15.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.15.3	1.3.111.2.802.1.1.13.1.2.6.1.4.15.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.16.1	1.3.111.2.802.1.1.13.1.2.6.1.4.16.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.16.2	1.3.111.2.802.1.1.13.1.2.6.1.4.16.2	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsTxLLDPDU-LengthErrors.16.3	1.3.111.2.802.1.1.13.1.2.6.1.4.16.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.17.1	1.3.111.2.802.1.1.13.1.2.6.1.4.17.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.17.2	1.3.111.2.802.1.1.13.1.2.6.1.4.17.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.17.3	1.3.111.2.802.1.1.13.1.2.6.1.4.17.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.18.1	1.3.111.2.802.1.1.13.1.2.6.1.4.18.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.18.2	1.3.111.2.802.1.1.13.1.2.6.1.4.18.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.18.3	1.3.111.2.802.1.1.13.1.2.6.1.4.18.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.19.1	1.3.111.2.802.1.1.13.1.2.6.1.4.19.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.19.2	1.3.111.2.802.1.1.13.1.2.6.1.4.19.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.19.3	1.3.111.2.802.1.1.13.1.2.6.1.4.19.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.20.1	1.3.111.2.802.1.1.13.1.2.6.1.4.20.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.20.2	1.3.111.2.802.1.1.13.1.2.6.1.4.20.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.20.3	1.3.111.2.802.1.1.13.1.2.6.1.4.20.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.21.1	1.3.111.2.802.1.1.13.1.2.6.1.4.21.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.21.2	1.3.111.2.802.1.1.13.1.2.6.1.4.21.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.21.3	1.3.111.2.802.1.1.13.1.2.6.1.4.21.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.22.1	1.3.111.2.802.1.1.13.1.2.6.1.4.22.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.22.2	1.3.111.2.802.1.1.13.1.2.6.1.4.22.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.22.3	1.3.111.2.802.1.1.13.1.2.6.1.4.22.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.23.1	1.3.111.2.802.1.1.13.1.2.6.1.4.23.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.23.2	1.3.111.2.802.1.1.13.1.2.6.1.4.23.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.23.3	1.3.111.2.802.1.1.13.1.2.6.1.4.23.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.24.1	1.3.111.2.802.1.1.13.1.2.6.1.4.24.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.24.2	1.3.111.2.802.1.1.13.1.2.6.1.4.24.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.24.3	1.3.111.2.802.1.1.13.1.2.6.1.4.24.3	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
IldpV2StatsTxLLDPDU-LengthErrors.25.1	1.3.111.2.802.1.1.13.1.2.6.1.4.25.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.25.2	1.3.111.2.802.1.1.13.1.2.6.1.4.25.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.25.3	1.3.111.2.802.1.1.13.1.2.6.1.4.25.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.26.1	1.3.111.2.802.1.1.13.1.2.6.1.4.26.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.26.2	1.3.111.2.802.1.1.13.1.2.6.1.4.26.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.26.3	1.3.111.2.802.1.1.13.1.2.6.1.4.26.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.27.1	1.3.111.2.802.1.1.13.1.2.6.1.4.27.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.27.2	1.3.111.2.802.1.1.13.1.2.6.1.4.27.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.27.3	1.3.111.2.802.1.1.13.1.2.6.1.4.27.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.28.1	1.3.111.2.802.1.1.13.1.2.6.1.4.28.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.28.2	1.3.111.2.802.1.1.13.1.2.6.1.4.28.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.28.3	1.3.111.2.802.1.1.13.1.2.6.1.4.28.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.29.1	1.3.111.2.802.1.1.13.1.2.6.1.4.29.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.29.2	1.3.111.2.802.1.1.13.1.2.6.1.4.29.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.29.3	1.3.111.2.802.1.1.13.1.2.6.1.4.29.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.30.1	1.3.111.2.802.1.1.13.1.2.6.1.4.30.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.30.2	1.3.111.2.802.1.1.13.1.2.6.1.4.30.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.30.3	1.3.111.2.802.1.1.13.1.2.6.1.4.30.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.31.1	1.3.111.2.802.1.1.13.1.2.6.1.4.31.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.31.2	1.3.111.2.802.1.1.13.1.2.6.1.4.31.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.31.3	1.3.111.2.802.1.1.13.1.2.6.1.4.31.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.32.1	1.3.111.2.802.1.1.13.1.2.6.1.4.32.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.32.2	1.3.111.2.802.1.1.13.1.2.6.1.4.32.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.32.3	1.3.111.2.802.1.1.13.1.2.6.1.4.32.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.33.1	1.3.111.2.802.1.1.13.1.2.6.1.4.33.1	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsTxLLDPDU-LengthErrors.33.2	1.3.111.2.802.1.1.13.1.2.6.1.4.33.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.33.3	1.3.111.2.802.1.1.13.1.2.6.1.4.33.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.34.1	1.3.111.2.802.1.1.13.1.2.6.1.4.34.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.34.2	1.3.111.2.802.1.1.13.1.2.6.1.4.34.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.34.3	1.3.111.2.802.1.1.13.1.2.6.1.4.34.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.35.1	1.3.111.2.802.1.1.13.1.2.6.1.4.35.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.35.2	1.3.111.2.802.1.1.13.1.2.6.1.4.35.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.35.3	1.3.111.2.802.1.1.13.1.2.6.1.4.35.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.36.1	1.3.111.2.802.1.1.13.1.2.6.1.4.36.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.36.2	1.3.111.2.802.1.1.13.1.2.6.1.4.36.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.36.3	1.3.111.2.802.1.1.13.1.2.6.1.4.36.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.37.1	1.3.111.2.802.1.1.13.1.2.6.1.4.37.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.37.2	1.3.111.2.802.1.1.13.1.2.6.1.4.37.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.37.3	1.3.111.2.802.1.1.13.1.2.6.1.4.37.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.38.1	1.3.111.2.802.1.1.13.1.2.6.1.4.38.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.38.2	1.3.111.2.802.1.1.13.1.2.6.1.4.38.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.38.3	1.3.111.2.802.1.1.13.1.2.6.1.4.38.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.39.1	1.3.111.2.802.1.1.13.1.2.6.1.4.39.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.39.2	1.3.111.2.802.1.1.13.1.2.6.1.4.39.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.39.3	1.3.111.2.802.1.1.13.1.2.6.1.4.39.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.40.1	1.3.111.2.802.1.1.13.1.2.6.1.4.40.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.40.2	1.3.111.2.802.1.1.13.1.2.6.1.4.40.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.40.3	1.3.111.2.802.1.1.13.1.2.6.1.4.40.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.41.1	1.3.111.2.802.1.1.13.1.2.6.1.4.41.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.41.2	1.3.111.2.802.1.1.13.1.2.6.1.4.41.2	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsTxLLDPDU-LengthErrors.41.3	1.3.111.2.802.1.1.13.1.2.6.1.4.41.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.42.1	1.3.111.2.802.1.1.13.1.2.6.1.4.42.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.42.2	1.3.111.2.802.1.1.13.1.2.6.1.4.42.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.42.3	1.3.111.2.802.1.1.13.1.2.6.1.4.42.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.43.1	1.3.111.2.802.1.1.13.1.2.6.1.4.43.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.43.2	1.3.111.2.802.1.1.13.1.2.6.1.4.43.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.43.3	1.3.111.2.802.1.1.13.1.2.6.1.4.43.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.44.1	1.3.111.2.802.1.1.13.1.2.6.1.4.44.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.44.2	1.3.111.2.802.1.1.13.1.2.6.1.4.44.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.44.3	1.3.111.2.802.1.1.13.1.2.6.1.4.44.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.45.1	1.3.111.2.802.1.1.13.1.2.6.1.4.45.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.45.2	1.3.111.2.802.1.1.13.1.2.6.1.4.45.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.45.3	1.3.111.2.802.1.1.13.1.2.6.1.4.45.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.46.1	1.3.111.2.802.1.1.13.1.2.6.1.4.46.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.46.2	1.3.111.2.802.1.1.13.1.2.6.1.4.46.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.46.3	1.3.111.2.802.1.1.13.1.2.6.1.4.46.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.47.1	1.3.111.2.802.1.1.13.1.2.6.1.4.47.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.47.2	1.3.111.2.802.1.1.13.1.2.6.1.4.47.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.47.3	1.3.111.2.802.1.1.13.1.2.6.1.4.47.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.48.1	1.3.111.2.802.1.1.13.1.2.6.1.4.48.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.48.2	1.3.111.2.802.1.1.13.1.2.6.1.4.48.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.48.3	1.3.111.2.802.1.1.13.1.2.6.1.4.48.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.49.1	1.3.111.2.802.1.1.13.1.2.6.1.4.49.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.49.2	1.3.111.2.802.1.1.13.1.2.6.1.4.49.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.49.3	1.3.111.2.802.1.1.13.1.2.6.1.4.49.3	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsTxLLDPDU-LengthErrors.50.1	1.3.111.2.802.1.1.13.1.2.6.1.4.50.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.50.2	1.3.111.2.802.1.1.13.1.2.6.1.4.50.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.50.3	1.3.111.2.802.1.1.13.1.2.6.1.4.50.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.51.1	1.3.111.2.802.1.1.13.1.2.6.1.4.51.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.51.2	1.3.111.2.802.1.1.13.1.2.6.1.4.51.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.51.3	1.3.111.2.802.1.1.13.1.2.6.1.4.51.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.52.1	1.3.111.2.802.1.1.13.1.2.6.1.4.52.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.52.2	1.3.111.2.802.1.1.13.1.2.6.1.4.52.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.52.3	1.3.111.2.802.1.1.13.1.2.6.1.4.52.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.53.1	1.3.111.2.802.1.1.13.1.2.6.1.4.53.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.53.2	1.3.111.2.802.1.1.13.1.2.6.1.4.53.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.53.3	1.3.111.2.802.1.1.13.1.2.6.1.4.53.3	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.54.1	1.3.111.2.802.1.1.13.1.2.6.1.4.54.1	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.54.2	1.3.111.2.802.1.1.13.1.2.6.1.4.54.2	Counter32	0
IldpV2StatsTxLLDPDU-LengthErrors.54.3	1.3.111.2.802.1.1.13.1.2.6.1.4.54.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.1.1	1.3.111.2.802.1.1.13.1.2.7.1.3.1.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.1.2	1.3.111.2.802.1.1.13.1.2.7.1.3.1.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.1.3	1.3.111.2.802.1.1.13.1.2.7.1.3.1.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.2.1	1.3.111.2.802.1.1.13.1.2.7.1.3.2.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.2.2	1.3.111.2.802.1.1.13.1.2.7.1.3.2.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.2.3	1.3.111.2.802.1.1.13.1.2.7.1.3.2.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.3.1	1.3.111.2.802.1.1.13.1.2.7.1.3.3.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.3.2	1.3.111.2.802.1.1.13.1.2.7.1.3.3.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.3.3	1.3.111.2.802.1.1.13.1.2.7.1.3.3.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.4.1	1.3.111.2.802.1.1.13.1.2.7.1.3.4.1	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortFramesDiscardedTotal.4.2	.1.3.111.2.802.1.1.13.1.2.7.1.3.4.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.4.3	.1.3.111.2.802.1.1.13.1.2.7.1.3.4.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.5.1	.1.3.111.2.802.1.1.13.1.2.7.1.3.5.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.5.2	.1.3.111.2.802.1.1.13.1.2.7.1.3.5.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.5.3	.1.3.111.2.802.1.1.13.1.2.7.1.3.5.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.6.1	.1.3.111.2.802.1.1.13.1.2.7.1.3.6.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.6.2	.1.3.111.2.802.1.1.13.1.2.7.1.3.6.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.6.3	.1.3.111.2.802.1.1.13.1.2.7.1.3.6.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.7.1	.1.3.111.2.802.1.1.13.1.2.7.1.3.7.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.7.2	.1.3.111.2.802.1.1.13.1.2.7.1.3.7.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.7.3	.1.3.111.2.802.1.1.13.1.2.7.1.3.7.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.8.1	.1.3.111.2.802.1.1.13.1.2.7.1.3.8.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.8.2	.1.3.111.2.802.1.1.13.1.2.7.1.3.8.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.8.3	.1.3.111.2.802.1.1.13.1.2.7.1.3.8.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.9.1	.1.3.111.2.802.1.1.13.1.2.7.1.3.9.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.9.2	.1.3.111.2.802.1.1.13.1.2.7.1.3.9.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.9.3	.1.3.111.2.802.1.1.13.1.2.7.1.3.9.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.10.1	.1.3.111.2.802.1.1.13.1.2.7.1.3.10.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.10.2	.1.3.111.2.802.1.1.13.1.2.7.1.3.10.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.10.3	.1.3.111.2.802.1.1.13.1.2.7.1.3.10.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.11.1	.1.3.111.2.802.1.1.13.1.2.7.1.3.11.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.11.2	.1.3.111.2.802.1.1.13.1.2.7.1.3.11.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.11.3	.1.3.111.2.802.1.1.13.1.2.7.1.3.11.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.12.1	.1.3.111.2.802.1.1.13.1.2.7.1.3.12.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.12.2	.1.3.111.2.802.1.1.13.1.2.7.1.3.12.2	Counter32	0



Name	OID	Value Type	Value Example
IldpV2StatsRxPortFramesDiscardedTotal.12.3	1.3.111.2.802.1.1.13.1.2.7.1.3.12.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.13.1	1.3.111.2.802.1.1.13.1.2.7.1.3.13.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.13.2	1.3.111.2.802.1.1.13.1.2.7.1.3.13.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.13.3	1.3.111.2.802.1.1.13.1.2.7.1.3.13.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.14.1	1.3.111.2.802.1.1.13.1.2.7.1.3.14.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.14.2	1.3.111.2.802.1.1.13.1.2.7.1.3.14.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.14.3	1.3.111.2.802.1.1.13.1.2.7.1.3.14.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.15.1	1.3.111.2.802.1.1.13.1.2.7.1.3.15.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.15.2	1.3.111.2.802.1.1.13.1.2.7.1.3.15.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.15.3	1.3.111.2.802.1.1.13.1.2.7.1.3.15.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.16.1	1.3.111.2.802.1.1.13.1.2.7.1.3.16.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.16.2	1.3.111.2.802.1.1.13.1.2.7.1.3.16.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.16.3	1.3.111.2.802.1.1.13.1.2.7.1.3.16.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.17.1	1.3.111.2.802.1.1.13.1.2.7.1.3.17.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.17.2	1.3.111.2.802.1.1.13.1.2.7.1.3.17.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.17.3	1.3.111.2.802.1.1.13.1.2.7.1.3.17.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.18.1	1.3.111.2.802.1.1.13.1.2.7.1.3.18.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.18.2	1.3.111.2.802.1.1.13.1.2.7.1.3.18.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.18.3	1.3.111.2.802.1.1.13.1.2.7.1.3.18.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.19.1	1.3.111.2.802.1.1.13.1.2.7.1.3.19.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.19.2	1.3.111.2.802.1.1.13.1.2.7.1.3.19.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.19.3	1.3.111.2.802.1.1.13.1.2.7.1.3.19.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.20.1	1.3.111.2.802.1.1.13.1.2.7.1.3.20.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.20.2	1.3.111.2.802.1.1.13.1.2.7.1.3.20.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.20.3	1.3.111.2.802.1.1.13.1.2.7.1.3.20.3	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortFramesDiscardedTotal.21.1	1.3.111.2.802.1.1.13.1.2.7.1.3.21.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.21.2	1.3.111.2.802.1.1.13.1.2.7.1.3.21.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.21.3	1.3.111.2.802.1.1.13.1.2.7.1.3.21.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.22.1	1.3.111.2.802.1.1.13.1.2.7.1.3.22.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.22.2	1.3.111.2.802.1.1.13.1.2.7.1.3.22.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.22.3	1.3.111.2.802.1.1.13.1.2.7.1.3.22.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.23.1	1.3.111.2.802.1.1.13.1.2.7.1.3.23.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.23.2	1.3.111.2.802.1.1.13.1.2.7.1.3.23.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.23.3	1.3.111.2.802.1.1.13.1.2.7.1.3.23.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.24.1	1.3.111.2.802.1.1.13.1.2.7.1.3.24.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.24.2	1.3.111.2.802.1.1.13.1.2.7.1.3.24.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.24.3	1.3.111.2.802.1.1.13.1.2.7.1.3.24.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.25.1	1.3.111.2.802.1.1.13.1.2.7.1.3.25.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.25.2	1.3.111.2.802.1.1.13.1.2.7.1.3.25.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.25.3	1.3.111.2.802.1.1.13.1.2.7.1.3.25.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.26.1	1.3.111.2.802.1.1.13.1.2.7.1.3.26.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.26.2	1.3.111.2.802.1.1.13.1.2.7.1.3.26.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.26.3	1.3.111.2.802.1.1.13.1.2.7.1.3.26.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.27.1	1.3.111.2.802.1.1.13.1.2.7.1.3.27.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.27.2	1.3.111.2.802.1.1.13.1.2.7.1.3.27.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.27.3	1.3.111.2.802.1.1.13.1.2.7.1.3.27.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.28.1	1.3.111.2.802.1.1.13.1.2.7.1.3.28.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.28.2	1.3.111.2.802.1.1.13.1.2.7.1.3.28.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.28.3	1.3.111.2.802.1.1.13.1.2.7.1.3.28.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.29.1	1.3.111.2.802.1.1.13.1.2.7.1.3.29.1	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortFramesDiscardedTotal.29.2	1.3.111.2.802.1.1.13.1.2.7.1.3.29.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.29.3	1.3.111.2.802.1.1.13.1.2.7.1.3.29.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.30.1	1.3.111.2.802.1.1.13.1.2.7.1.3.30.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.30.2	1.3.111.2.802.1.1.13.1.2.7.1.3.30.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.30.3	1.3.111.2.802.1.1.13.1.2.7.1.3.30.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.31.1	1.3.111.2.802.1.1.13.1.2.7.1.3.31.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.31.2	1.3.111.2.802.1.1.13.1.2.7.1.3.31.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.31.3	1.3.111.2.802.1.1.13.1.2.7.1.3.31.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.32.1	1.3.111.2.802.1.1.13.1.2.7.1.3.32.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.32.2	1.3.111.2.802.1.1.13.1.2.7.1.3.32.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.32.3	1.3.111.2.802.1.1.13.1.2.7.1.3.32.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.33.1	1.3.111.2.802.1.1.13.1.2.7.1.3.33.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.33.2	1.3.111.2.802.1.1.13.1.2.7.1.3.33.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.33.3	1.3.111.2.802.1.1.13.1.2.7.1.3.33.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.34.1	1.3.111.2.802.1.1.13.1.2.7.1.3.34.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.34.2	1.3.111.2.802.1.1.13.1.2.7.1.3.34.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.34.3	1.3.111.2.802.1.1.13.1.2.7.1.3.34.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.35.1	1.3.111.2.802.1.1.13.1.2.7.1.3.35.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.35.2	1.3.111.2.802.1.1.13.1.2.7.1.3.35.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.35.3	1.3.111.2.802.1.1.13.1.2.7.1.3.35.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.36.1	1.3.111.2.802.1.1.13.1.2.7.1.3.36.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.36.2	1.3.111.2.802.1.1.13.1.2.7.1.3.36.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.36.3	1.3.111.2.802.1.1.13.1.2.7.1.3.36.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.37.1	1.3.111.2.802.1.1.13.1.2.7.1.3.37.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.37.2	1.3.111.2.802.1.1.13.1.2.7.1.3.37.2	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortFramesDiscardedTotal.37.3	1.3.111.2.802.1.1.13.1.2.7.1.3.37.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.38.1	1.3.111.2.802.1.1.13.1.2.7.1.3.38.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.38.2	1.3.111.2.802.1.1.13.1.2.7.1.3.38.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.38.3	1.3.111.2.802.1.1.13.1.2.7.1.3.38.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.39.1	1.3.111.2.802.1.1.13.1.2.7.1.3.39.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.39.2	1.3.111.2.802.1.1.13.1.2.7.1.3.39.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.39.3	1.3.111.2.802.1.1.13.1.2.7.1.3.39.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.40.1	1.3.111.2.802.1.1.13.1.2.7.1.3.40.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.40.2	1.3.111.2.802.1.1.13.1.2.7.1.3.40.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.40.3	1.3.111.2.802.1.1.13.1.2.7.1.3.40.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.41.1	1.3.111.2.802.1.1.13.1.2.7.1.3.41.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.41.2	1.3.111.2.802.1.1.13.1.2.7.1.3.41.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.41.3	1.3.111.2.802.1.1.13.1.2.7.1.3.41.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.42.1	1.3.111.2.802.1.1.13.1.2.7.1.3.42.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.42.2	1.3.111.2.802.1.1.13.1.2.7.1.3.42.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.42.3	1.3.111.2.802.1.1.13.1.2.7.1.3.42.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.43.1	1.3.111.2.802.1.1.13.1.2.7.1.3.43.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.43.2	1.3.111.2.802.1.1.13.1.2.7.1.3.43.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.43.3	1.3.111.2.802.1.1.13.1.2.7.1.3.43.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.44.1	1.3.111.2.802.1.1.13.1.2.7.1.3.44.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.44.2	1.3.111.2.802.1.1.13.1.2.7.1.3.44.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.44.3	1.3.111.2.802.1.1.13.1.2.7.1.3.44.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.45.1	1.3.111.2.802.1.1.13.1.2.7.1.3.45.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.45.2	1.3.111.2.802.1.1.13.1.2.7.1.3.45.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.45.3	1.3.111.2.802.1.1.13.1.2.7.1.3.45.3	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortFramesDiscardedTotal.46.1	1.3.111.2.802.1.1.13.1.2.7.1.3.46.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.46.2	1.3.111.2.802.1.1.13.1.2.7.1.3.46.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.46.3	1.3.111.2.802.1.1.13.1.2.7.1.3.46.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.47.1	1.3.111.2.802.1.1.13.1.2.7.1.3.47.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.47.2	1.3.111.2.802.1.1.13.1.2.7.1.3.47.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.47.3	1.3.111.2.802.1.1.13.1.2.7.1.3.47.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.48.1	1.3.111.2.802.1.1.13.1.2.7.1.3.48.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.48.2	1.3.111.2.802.1.1.13.1.2.7.1.3.48.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.48.3	1.3.111.2.802.1.1.13.1.2.7.1.3.48.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.49.1	1.3.111.2.802.1.1.13.1.2.7.1.3.49.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.49.2	1.3.111.2.802.1.1.13.1.2.7.1.3.49.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.49.3	1.3.111.2.802.1.1.13.1.2.7.1.3.49.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.50.1	1.3.111.2.802.1.1.13.1.2.7.1.3.50.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.50.2	1.3.111.2.802.1.1.13.1.2.7.1.3.50.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.50.3	1.3.111.2.802.1.1.13.1.2.7.1.3.50.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.51.1	1.3.111.2.802.1.1.13.1.2.7.1.3.51.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.51.2	1.3.111.2.802.1.1.13.1.2.7.1.3.51.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.51.3	1.3.111.2.802.1.1.13.1.2.7.1.3.51.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.52.1	1.3.111.2.802.1.1.13.1.2.7.1.3.52.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.52.2	1.3.111.2.802.1.1.13.1.2.7.1.3.52.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.52.3	1.3.111.2.802.1.1.13.1.2.7.1.3.52.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.53.1	1.3.111.2.802.1.1.13.1.2.7.1.3.53.1	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.53.2	1.3.111.2.802.1.1.13.1.2.7.1.3.53.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.53.3	1.3.111.2.802.1.1.13.1.2.7.1.3.53.3	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.54.1	1.3.111.2.802.1.1.13.1.2.7.1.3.54.1	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortFramesDiscardedTotal.54.2	.1.3.111.2.802.1.1.13.1.2.7.1.3.54.2	Counter32	0
IldpV2StatsRxPortFramesDiscardedTotal.54.3	.1.3.111.2.802.1.1.13.1.2.7.1.3.54.3	Counter32	0
IldpV2StatsRxPortFramesErrors.1.1	.1.3.111.2.802.1.1.13.1.2.7.1.4.1.1	Counter32	0
IldpV2StatsRxPortFramesErrors.1.2	.1.3.111.2.802.1.1.13.1.2.7.1.4.1.2	Counter32	0
IldpV2StatsRxPortFramesErrors.1.3	.1.3.111.2.802.1.1.13.1.2.7.1.4.1.3	Counter32	0
IldpV2StatsRxPortFramesErrors.2.1	.1.3.111.2.802.1.1.13.1.2.7.1.4.2.1	Counter32	0
IldpV2StatsRxPortFramesErrors.2.2	.1.3.111.2.802.1.1.13.1.2.7.1.4.2.2	Counter32	0
IldpV2StatsRxPortFramesErrors.2.3	.1.3.111.2.802.1.1.13.1.2.7.1.4.2.3	Counter32	0
IldpV2StatsRxPortFramesErrors.3.1	.1.3.111.2.802.1.1.13.1.2.7.1.4.3.1	Counter32	0
IldpV2StatsRxPortFramesErrors.3.2	.1.3.111.2.802.1.1.13.1.2.7.1.4.3.2	Counter32	0
IldpV2StatsRxPortFramesErrors.3.3	.1.3.111.2.802.1.1.13.1.2.7.1.4.3.3	Counter32	0
IldpV2StatsRxPortFramesErrors.4.1	.1.3.111.2.802.1.1.13.1.2.7.1.4.4.1	Counter32	0
IldpV2StatsRxPortFramesErrors.4.2	.1.3.111.2.802.1.1.13.1.2.7.1.4.4.2	Counter32	0
IldpV2StatsRxPortFramesErrors.4.3	.1.3.111.2.802.1.1.13.1.2.7.1.4.4.3	Counter32	0
IldpV2StatsRxPortFramesErrors.5.1	.1.3.111.2.802.1.1.13.1.2.7.1.4.5.1	Counter32	0
IldpV2StatsRxPortFramesErrors.5.2	.1.3.111.2.802.1.1.13.1.2.7.1.4.5.2	Counter32	0
IldpV2StatsRxPortFramesErrors.5.3	.1.3.111.2.802.1.1.13.1.2.7.1.4.5.3	Counter32	0
IldpV2StatsRxPortFramesErrors.6.1	.1.3.111.2.802.1.1.13.1.2.7.1.4.6.1	Counter32	0
IldpV2StatsRxPortFramesErrors.6.2	.1.3.111.2.802.1.1.13.1.2.7.1.4.6.2	Counter32	0
IldpV2StatsRxPortFramesErrors.6.3	.1.3.111.2.802.1.1.13.1.2.7.1.4.6.3	Counter32	0
IldpV2StatsRxPortFramesErrors.7.1	.1.3.111.2.802.1.1.13.1.2.7.1.4.7.1	Counter32	0
IldpV2StatsRxPortFramesErrors.7.2	.1.3.111.2.802.1.1.13.1.2.7.1.4.7.2	Counter32	0
IldpV2StatsRxPortFramesErrors.7.3	.1.3.111.2.802.1.1.13.1.2.7.1.4.7.3	Counter32	0
IldpV2StatsRxPortFramesErrors.8.1	.1.3.111.2.802.1.1.13.1.2.7.1.4.8.1	Counter32	0
IldpV2StatsRxPortFramesErrors.8.2	.1.3.111.2.802.1.1.13.1.2.7.1.4.8.2	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortFramesErrors.8.3	.1.3.111.2.802.1.1.13.1.2.7.1.4.8.3	Counter32	0
IldpV2StatsRxPortFramesErrors.9.1	.1.3.111.2.802.1.1.13.1.2.7.1.4.9.1	Counter32	0
IldpV2StatsRxPortFramesErrors.9.2	.1.3.111.2.802.1.1.13.1.2.7.1.4.9.2	Counter32	0
IldpV2StatsRxPortFramesErrors.9.3	.1.3.111.2.802.1.1.13.1.2.7.1.4.9.3	Counter32	0
IldpV2StatsRxPortFramesErrors.10.1	1.3.111.2.802.1.1.13.1.2.7.1.4.10.1	Counter32	0
IldpV2StatsRxPortFramesErrors.10.2	1.3.111.2.802.1.1.13.1.2.7.1.4.10.2	Counter32	0
IldpV2StatsRxPortFramesErrors.10.3	1.3.111.2.802.1.1.13.1.2.7.1.4.10.3	Counter32	0
IldpV2StatsRxPortFramesErrors.11.1	1.3.111.2.802.1.1.13.1.2.7.1.4.11.1	Counter32	0
IldpV2StatsRxPortFramesErrors.11.2	1.3.111.2.802.1.1.13.1.2.7.1.4.11.2	Counter32	0
IldpV2StatsRxPortFramesErrors.11.3	1.3.111.2.802.1.1.13.1.2.7.1.4.11.3	Counter32	0
IldpV2StatsRxPortFramesErrors.12.1	1.3.111.2.802.1.1.13.1.2.7.1.4.12.1	Counter32	0
IldpV2StatsRxPortFramesErrors.12.2	1.3.111.2.802.1.1.13.1.2.7.1.4.12.2	Counter32	0
IldpV2StatsRxPortFramesErrors.12.3	1.3.111.2.802.1.1.13.1.2.7.1.4.12.3	Counter32	0
IldpV2StatsRxPortFramesErrors.13.1	1.3.111.2.802.1.1.13.1.2.7.1.4.13.1	Counter32	0
IldpV2StatsRxPortFramesErrors.13.2	1.3.111.2.802.1.1.13.1.2.7.1.4.13.2	Counter32	0
IldpV2StatsRxPortFramesErrors.13.3	1.3.111.2.802.1.1.13.1.2.7.1.4.13.3	Counter32	0
IldpV2StatsRxPortFramesErrors.14.1	1.3.111.2.802.1.1.13.1.2.7.1.4.14.1	Counter32	0
IldpV2StatsRxPortFramesErrors.14.2	1.3.111.2.802.1.1.13.1.2.7.1.4.14.2	Counter32	0
IldpV2StatsRxPortFramesErrors.14.3	1.3.111.2.802.1.1.13.1.2.7.1.4.14.3	Counter32	0
IldpV2StatsRxPortFramesErrors.15.1	1.3.111.2.802.1.1.13.1.2.7.1.4.15.1	Counter32	0
IldpV2StatsRxPortFramesErrors.15.2	1.3.111.2.802.1.1.13.1.2.7.1.4.15.2	Counter32	0
IldpV2StatsRxPortFramesErrors.15.3	1.3.111.2.802.1.1.13.1.2.7.1.4.15.3	Counter32	0
IldpV2StatsRxPortFramesErrors.16.1	1.3.111.2.802.1.1.13.1.2.7.1.4.16.1	Counter32	0
IldpV2StatsRxPortFramesErrors.16.2	1.3.111.2.802.1.1.13.1.2.7.1.4.16.2	Counter32	0
IldpV2StatsRxPortFramesErrors.16.3	1.3.111.2.802.1.1.13.1.2.7.1.4.16.3	Counter32	0



Name	OID	Value Type	Value Example
IldpV2StatsRxPortFramesErrors.17.1	1.3.111.2.802.1.1.13.1.2.7.1.4.17.1	Counter32	0
IldpV2StatsRxPortFramesErrors.17.2	1.3.111.2.802.1.1.13.1.2.7.1.4.17.2	Counter32	0
IldpV2StatsRxPortFramesErrors.17.3	1.3.111.2.802.1.1.13.1.2.7.1.4.17.3	Counter32	0
IldpV2StatsRxPortFramesErrors.18.1	1.3.111.2.802.1.1.13.1.2.7.1.4.18.1	Counter32	0
IldpV2StatsRxPortFramesErrors.18.2	1.3.111.2.802.1.1.13.1.2.7.1.4.18.2	Counter32	0
IldpV2StatsRxPortFramesErrors.18.3	1.3.111.2.802.1.1.13.1.2.7.1.4.18.3	Counter32	0
IldpV2StatsRxPortFramesErrors.19.1	1.3.111.2.802.1.1.13.1.2.7.1.4.19.1	Counter32	0
IldpV2StatsRxPortFramesErrors.19.2	1.3.111.2.802.1.1.13.1.2.7.1.4.19.2	Counter32	0
IldpV2StatsRxPortFramesErrors.19.3	1.3.111.2.802.1.1.13.1.2.7.1.4.19.3	Counter32	0
IldpV2StatsRxPortFramesErrors.20.1	1.3.111.2.802.1.1.13.1.2.7.1.4.20.1	Counter32	0
IldpV2StatsRxPortFramesErrors.20.2	1.3.111.2.802.1.1.13.1.2.7.1.4.20.2	Counter32	0
IldpV2StatsRxPortFramesErrors.20.3	1.3.111.2.802.1.1.13.1.2.7.1.4.20.3	Counter32	0
IldpV2StatsRxPortFramesErrors.21.1	1.3.111.2.802.1.1.13.1.2.7.1.4.21.1	Counter32	0
IldpV2StatsRxPortFramesErrors.21.2	1.3.111.2.802.1.1.13.1.2.7.1.4.21.2	Counter32	0
IldpV2StatsRxPortFramesErrors.21.3	1.3.111.2.802.1.1.13.1.2.7.1.4.21.3	Counter32	0
IldpV2StatsRxPortFramesErrors.22.1	1.3.111.2.802.1.1.13.1.2.7.1.4.22.1	Counter32	0
IldpV2StatsRxPortFramesErrors.22.2	1.3.111.2.802.1.1.13.1.2.7.1.4.22.2	Counter32	0
IldpV2StatsRxPortFramesErrors.22.3	1.3.111.2.802.1.1.13.1.2.7.1.4.22.3	Counter32	0
IldpV2StatsRxPortFramesErrors.23.1	1.3.111.2.802.1.1.13.1.2.7.1.4.23.1	Counter32	0
IldpV2StatsRxPortFramesErrors.23.2	1.3.111.2.802.1.1.13.1.2.7.1.4.23.2	Counter32	0
IldpV2StatsRxPortFramesErrors.23.3	1.3.111.2.802.1.1.13.1.2.7.1.4.23.3	Counter32	0
IldpV2StatsRxPortFramesErrors.24.1	1.3.111.2.802.1.1.13.1.2.7.1.4.24.1	Counter32	0
IldpV2StatsRxPortFramesErrors.24.2	1.3.111.2.802.1.1.13.1.2.7.1.4.24.2	Counter32	0
IldpV2StatsRxPortFramesErrors.24.3	1.3.111.2.802.1.1.13.1.2.7.1.4.24.3	Counter32	0
IldpV2StatsRxPortFramesErrors.25.1	1.3.111.2.802.1.1.13.1.2.7.1.4.25.1	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortFramesErrors.25.2	1.3.111.2.802.1.1.13.1.2.7.1.4.25.2	Counter32	0
IldpV2StatsRxPortFramesErrors.25.3	1.3.111.2.802.1.1.13.1.2.7.1.4.25.3	Counter32	0
IldpV2StatsRxPortFramesErrors.26.1	1.3.111.2.802.1.1.13.1.2.7.1.4.26.1	Counter32	0
IldpV2StatsRxPortFramesErrors.26.2	1.3.111.2.802.1.1.13.1.2.7.1.4.26.2	Counter32	0
IldpV2StatsRxPortFramesErrors.26.3	1.3.111.2.802.1.1.13.1.2.7.1.4.26.3	Counter32	0
IldpV2StatsRxPortFramesErrors.27.1	1.3.111.2.802.1.1.13.1.2.7.1.4.27.1	Counter32	0
IldpV2StatsRxPortFramesErrors.27.2	1.3.111.2.802.1.1.13.1.2.7.1.4.27.2	Counter32	0
IldpV2StatsRxPortFramesErrors.27.3	1.3.111.2.802.1.1.13.1.2.7.1.4.27.3	Counter32	0
IldpV2StatsRxPortFramesErrors.28.1	1.3.111.2.802.1.1.13.1.2.7.1.4.28.1	Counter32	0
IldpV2StatsRxPortFramesErrors.28.2	1.3.111.2.802.1.1.13.1.2.7.1.4.28.2	Counter32	0
IldpV2StatsRxPortFramesErrors.28.3	1.3.111.2.802.1.1.13.1.2.7.1.4.28.3	Counter32	0
IldpV2StatsRxPortFramesErrors.29.1	1.3.111.2.802.1.1.13.1.2.7.1.4.29.1	Counter32	0
IldpV2StatsRxPortFramesErrors.29.2	1.3.111.2.802.1.1.13.1.2.7.1.4.29.2	Counter32	0
IldpV2StatsRxPortFramesErrors.29.3	1.3.111.2.802.1.1.13.1.2.7.1.4.29.3	Counter32	0
IldpV2StatsRxPortFramesErrors.30.1	1.3.111.2.802.1.1.13.1.2.7.1.4.30.1	Counter32	0
IldpV2StatsRxPortFramesErrors.30.2	1.3.111.2.802.1.1.13.1.2.7.1.4.30.2	Counter32	0
IldpV2StatsRxPortFramesErrors.30.3	1.3.111.2.802.1.1.13.1.2.7.1.4.30.3	Counter32	0
IldpV2StatsRxPortFramesErrors.31.1	1.3.111.2.802.1.1.13.1.2.7.1.4.31.1	Counter32	0
IldpV2StatsRxPortFramesErrors.31.2	1.3.111.2.802.1.1.13.1.2.7.1.4.31.2	Counter32	0
IldpV2StatsRxPortFramesErrors.31.3	1.3.111.2.802.1.1.13.1.2.7.1.4.31.3	Counter32	0
IldpV2StatsRxPortFramesErrors.32.1	1.3.111.2.802.1.1.13.1.2.7.1.4.32.1	Counter32	0
IldpV2StatsRxPortFramesErrors.32.2	1.3.111.2.802.1.1.13.1.2.7.1.4.32.2	Counter32	0
IldpV2StatsRxPortFramesErrors.32.3	1.3.111.2.802.1.1.13.1.2.7.1.4.32.3	Counter32	0
IldpV2StatsRxPortFramesErrors.33.1	1.3.111.2.802.1.1.13.1.2.7.1.4.33.1	Counter32	0
IldpV2StatsRxPortFramesErrors.33.2	1.3.111.2.802.1.1.13.1.2.7.1.4.33.2	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortFramesErrors.33.3	1.3.111.2.802.1.1.13.1.2.7.1.4.33.3	Counter32	0
IldpV2StatsRxPortFramesErrors.34.1	1.3.111.2.802.1.1.13.1.2.7.1.4.34.1	Counter32	0
IldpV2StatsRxPortFramesErrors.34.2	1.3.111.2.802.1.1.13.1.2.7.1.4.34.2	Counter32	0
IldpV2StatsRxPortFramesErrors.34.3	1.3.111.2.802.1.1.13.1.2.7.1.4.34.3	Counter32	0
IldpV2StatsRxPortFramesErrors.35.1	1.3.111.2.802.1.1.13.1.2.7.1.4.35.1	Counter32	0
IldpV2StatsRxPortFramesErrors.35.2	1.3.111.2.802.1.1.13.1.2.7.1.4.35.2	Counter32	0
IldpV2StatsRxPortFramesErrors.35.3	1.3.111.2.802.1.1.13.1.2.7.1.4.35.3	Counter32	0
IldpV2StatsRxPortFramesErrors.36.1	1.3.111.2.802.1.1.13.1.2.7.1.4.36.1	Counter32	0
IldpV2StatsRxPortFramesErrors.36.2	1.3.111.2.802.1.1.13.1.2.7.1.4.36.2	Counter32	0
IldpV2StatsRxPortFramesErrors.36.3	1.3.111.2.802.1.1.13.1.2.7.1.4.36.3	Counter32	0
IldpV2StatsRxPortFramesErrors.37.1	1.3.111.2.802.1.1.13.1.2.7.1.4.37.1	Counter32	0
IldpV2StatsRxPortFramesErrors.37.2	1.3.111.2.802.1.1.13.1.2.7.1.4.37.2	Counter32	0
IldpV2StatsRxPortFramesErrors.37.3	1.3.111.2.802.1.1.13.1.2.7.1.4.37.3	Counter32	0
IldpV2StatsRxPortFramesErrors.38.1	1.3.111.2.802.1.1.13.1.2.7.1.4.38.1	Counter32	0
IldpV2StatsRxPortFramesErrors.38.2	1.3.111.2.802.1.1.13.1.2.7.1.4.38.2	Counter32	0
IldpV2StatsRxPortFramesErrors.38.3	1.3.111.2.802.1.1.13.1.2.7.1.4.38.3	Counter32	0
IldpV2StatsRxPortFramesErrors.39.1	1.3.111.2.802.1.1.13.1.2.7.1.4.39.1	Counter32	0
IldpV2StatsRxPortFramesErrors.39.2	1.3.111.2.802.1.1.13.1.2.7.1.4.39.2	Counter32	0
IldpV2StatsRxPortFramesErrors.39.3	1.3.111.2.802.1.1.13.1.2.7.1.4.39.3	Counter32	0
IldpV2StatsRxPortFramesErrors.40.1	1.3.111.2.802.1.1.13.1.2.7.1.4.40.1	Counter32	0
IldpV2StatsRxPortFramesErrors.40.2	1.3.111.2.802.1.1.13.1.2.7.1.4.40.2	Counter32	0
IldpV2StatsRxPortFramesErrors.40.3	1.3.111.2.802.1.1.13.1.2.7.1.4.40.3	Counter32	0
IldpV2StatsRxPortFramesErrors.41.1	1.3.111.2.802.1.1.13.1.2.7.1.4.41.1	Counter32	0
IldpV2StatsRxPortFramesErrors.41.2	1.3.111.2.802.1.1.13.1.2.7.1.4.41.2	Counter32	0
IldpV2StatsRxPortFramesErrors.41.3	1.3.111.2.802.1.1.13.1.2.7.1.4.41.3	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
IldpV2StatsRxPortFramesErrors.42.1	1.3.111.2.802.1.1.13.1.2.7.1.4.42.1	Counter32	0
IldpV2StatsRxPortFramesErrors.42.2	1.3.111.2.802.1.1.13.1.2.7.1.4.42.2	Counter32	0
IldpV2StatsRxPortFramesErrors.42.3	1.3.111.2.802.1.1.13.1.2.7.1.4.42.3	Counter32	0
IldpV2StatsRxPortFramesErrors.43.1	1.3.111.2.802.1.1.13.1.2.7.1.4.43.1	Counter32	0
IldpV2StatsRxPortFramesErrors.43.2	1.3.111.2.802.1.1.13.1.2.7.1.4.43.2	Counter32	0
IldpV2StatsRxPortFramesErrors.43.3	1.3.111.2.802.1.1.13.1.2.7.1.4.43.3	Counter32	0
IldpV2StatsRxPortFramesErrors.44.1	1.3.111.2.802.1.1.13.1.2.7.1.4.44.1	Counter32	0
IldpV2StatsRxPortFramesErrors.44.2	1.3.111.2.802.1.1.13.1.2.7.1.4.44.2	Counter32	0
IldpV2StatsRxPortFramesErrors.44.3	1.3.111.2.802.1.1.13.1.2.7.1.4.44.3	Counter32	0
IldpV2StatsRxPortFramesErrors.45.1	1.3.111.2.802.1.1.13.1.2.7.1.4.45.1	Counter32	0
IldpV2StatsRxPortFramesErrors.45.2	1.3.111.2.802.1.1.13.1.2.7.1.4.45.2	Counter32	0
IldpV2StatsRxPortFramesErrors.45.3	1.3.111.2.802.1.1.13.1.2.7.1.4.45.3	Counter32	0
IldpV2StatsRxPortFramesErrors.46.1	1.3.111.2.802.1.1.13.1.2.7.1.4.46.1	Counter32	0
IldpV2StatsRxPortFramesErrors.46.2	1.3.111.2.802.1.1.13.1.2.7.1.4.46.2	Counter32	0
IldpV2StatsRxPortFramesErrors.46.3	1.3.111.2.802.1.1.13.1.2.7.1.4.46.3	Counter32	0
IldpV2StatsRxPortFramesErrors.47.1	1.3.111.2.802.1.1.13.1.2.7.1.4.47.1	Counter32	0
IldpV2StatsRxPortFramesErrors.47.2	1.3.111.2.802.1.1.13.1.2.7.1.4.47.2	Counter32	0
IldpV2StatsRxPortFramesErrors.47.3	1.3.111.2.802.1.1.13.1.2.7.1.4.47.3	Counter32	0
IldpV2StatsRxPortFramesErrors.48.1	1.3.111.2.802.1.1.13.1.2.7.1.4.48.1	Counter32	0
IldpV2StatsRxPortFramesErrors.48.2	1.3.111.2.802.1.1.13.1.2.7.1.4.48.2	Counter32	0
IldpV2StatsRxPortFramesErrors.48.3	1.3.111.2.802.1.1.13.1.2.7.1.4.48.3	Counter32	0
IldpV2StatsRxPortFramesErrors.49.1	1.3.111.2.802.1.1.13.1.2.7.1.4.49.1	Counter32	0
IldpV2StatsRxPortFramesErrors.49.2	1.3.111.2.802.1.1.13.1.2.7.1.4.49.2	Counter32	0
IldpV2StatsRxPortFramesErrors.49.3	1.3.111.2.802.1.1.13.1.2.7.1.4.49.3	Counter32	0
IldpV2StatsRxPortFramesErrors.50.1	1.3.111.2.802.1.1.13.1.2.7.1.4.50.1	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortFramesErrors.50.2	1.3.111.2.802.1.1.13.1.2.7.1.4.50.2	Counter32	0
IldpV2StatsRxPortFramesErrors.50.3	1.3.111.2.802.1.1.13.1.2.7.1.4.50.3	Counter32	0
IldpV2StatsRxPortFramesErrors.51.1	1.3.111.2.802.1.1.13.1.2.7.1.4.51.1	Counter32	0
IldpV2StatsRxPortFramesErrors.51.2	1.3.111.2.802.1.1.13.1.2.7.1.4.51.2	Counter32	0
IldpV2StatsRxPortFramesErrors.51.3	1.3.111.2.802.1.1.13.1.2.7.1.4.51.3	Counter32	0
IldpV2StatsRxPortFramesErrors.52.1	1.3.111.2.802.1.1.13.1.2.7.1.4.52.1	Counter32	0
IldpV2StatsRxPortFramesErrors.52.2	1.3.111.2.802.1.1.13.1.2.7.1.4.52.2	Counter32	0
IldpV2StatsRxPortFramesErrors.52.3	1.3.111.2.802.1.1.13.1.2.7.1.4.52.3	Counter32	0
IldpV2StatsRxPortFramesErrors.53.1	1.3.111.2.802.1.1.13.1.2.7.1.4.53.1	Counter32	0
IldpV2StatsRxPortFramesErrors.53.2	1.3.111.2.802.1.1.13.1.2.7.1.4.53.2	Counter32	0
IldpV2StatsRxPortFramesErrors.53.3	1.3.111.2.802.1.1.13.1.2.7.1.4.53.3	Counter32	0
IldpV2StatsRxPortFramesErrors.54.1	1.3.111.2.802.1.1.13.1.2.7.1.4.54.1	Counter32	0
IldpV2StatsRxPortFramesErrors.54.2	1.3.111.2.802.1.1.13.1.2.7.1.4.54.2	Counter32	0
IldpV2StatsRxPortFramesErrors.54.3	1.3.111.2.802.1.1.13.1.2.7.1.4.54.3	Counter32	0
IldpV2StatsRxPortFramesTotal.1.1	1.3.111.2.802.1.1.13.1.2.7.1.5.1.1	Counter32	83
IldpV2StatsRxPortFramesTotal.1.2	1.3.111.2.802.1.1.13.1.2.7.1.5.1.2	Counter32	0
IldpV2StatsRxPortFramesTotal.1.3	1.3.111.2.802.1.1.13.1.2.7.1.5.1.3	Counter32	0
IldpV2StatsRxPortFramesTotal.2.1	1.3.111.2.802.1.1.13.1.2.7.1.5.2.1	Counter32	0
IldpV2StatsRxPortFramesTotal.2.2	1.3.111.2.802.1.1.13.1.2.7.1.5.2.2	Counter32	0
IldpV2StatsRxPortFramesTotal.2.3	1.3.111.2.802.1.1.13.1.2.7.1.5.2.3	Counter32	0
IldpV2StatsRxPortFramesTotal.3.1	1.3.111.2.802.1.1.13.1.2.7.1.5.3.1	Counter32	0
IldpV2StatsRxPortFramesTotal.3.2	1.3.111.2.802.1.1.13.1.2.7.1.5.3.2	Counter32	0
IldpV2StatsRxPortFramesTotal.3.3	1.3.111.2.802.1.1.13.1.2.7.1.5.3.3	Counter32	0
IldpV2StatsRxPortFramesTotal.4.1	1.3.111.2.802.1.1.13.1.2.7.1.5.4.1	Counter32	0
IldpV2StatsRxPortFramesTotal.4.2	1.3.111.2.802.1.1.13.1.2.7.1.5.4.2	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
IldpV2StatsRxPortFramesTotal.4.3	.1.3.111.2.802.1.1.13.1.2.7.1.5.4.3	Counter32	0
IldpV2StatsRxPortFramesTotal.5.1	.1.3.111.2.802.1.1.13.1.2.7.1.5.5.1	Counter32	0
IldpV2StatsRxPortFramesTotal.5.2	.1.3.111.2.802.1.1.13.1.2.7.1.5.5.2	Counter32	0
IldpV2StatsRxPortFramesTotal.5.3	.1.3.111.2.802.1.1.13.1.2.7.1.5.5.3	Counter32	0
IldpV2StatsRxPortFramesTotal.6.1	.1.3.111.2.802.1.1.13.1.2.7.1.5.6.1	Counter32	0
IldpV2StatsRxPortFramesTotal.6.2	.1.3.111.2.802.1.1.13.1.2.7.1.5.6.2	Counter32	0
IldpV2StatsRxPortFramesTotal.6.3	.1.3.111.2.802.1.1.13.1.2.7.1.5.6.3	Counter32	0
IldpV2StatsRxPortFramesTotal.7.1	.1.3.111.2.802.1.1.13.1.2.7.1.5.7.1	Counter32	0
IldpV2StatsRxPortFramesTotal.7.2	.1.3.111.2.802.1.1.13.1.2.7.1.5.7.2	Counter32	0
IldpV2StatsRxPortFramesTotal.7.3	.1.3.111.2.802.1.1.13.1.2.7.1.5.7.3	Counter32	0
IldpV2StatsRxPortFramesTotal.8.1	.1.3.111.2.802.1.1.13.1.2.7.1.5.8.1	Counter32	0
IldpV2StatsRxPortFramesTotal.8.2	.1.3.111.2.802.1.1.13.1.2.7.1.5.8.2	Counter32	0
IldpV2StatsRxPortFramesTotal.8.3	.1.3.111.2.802.1.1.13.1.2.7.1.5.8.3	Counter32	0
IldpV2StatsRxPortFramesTotal.9.1	.1.3.111.2.802.1.1.13.1.2.7.1.5.9.1	Counter32	0
IldpV2StatsRxPortFramesTotal.9.2	.1.3.111.2.802.1.1.13.1.2.7.1.5.9.2	Counter32	0
IldpV2StatsRxPortFramesTotal.9.3	.1.3.111.2.802.1.1.13.1.2.7.1.5.9.3	Counter32	0
IldpV2StatsRxPortFramesTotal.10.1	.1.3.111.2.802.1.1.13.1.2.7.1.5.10.1	Counter32	0
IldpV2StatsRxPortFramesTotal.10.2	.1.3.111.2.802.1.1.13.1.2.7.1.5.10.2	Counter32	0
IldpV2StatsRxPortFramesTotal.10.3	.1.3.111.2.802.1.1.13.1.2.7.1.5.10.3	Counter32	0
IldpV2StatsRxPortFramesTotal.11.1	.1.3.111.2.802.1.1.13.1.2.7.1.5.11.1	Counter32	0
IldpV2StatsRxPortFramesTotal.11.2	.1.3.111.2.802.1.1.13.1.2.7.1.5.11.2	Counter32	0
IldpV2StatsRxPortFramesTotal.11.3	.1.3.111.2.802.1.1.13.1.2.7.1.5.11.3	Counter32	0
IldpV2StatsRxPortFramesTotal.12.1	.1.3.111.2.802.1.1.13.1.2.7.1.5.12.1	Counter32	0
IldpV2StatsRxPortFramesTotal.12.2	.1.3.111.2.802.1.1.13.1.2.7.1.5.12.2	Counter32	0
IldpV2StatsRxPortFramesTotal.12.3	.1.3.111.2.802.1.1.13.1.2.7.1.5.12.3	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortFramesTotal.13.1	1.3.111.2.802.1.1.13.1.2.7.1.5.13.1	Counter32	0
IldpV2StatsRxPortFramesTotal.13.2	1.3.111.2.802.1.1.13.1.2.7.1.5.13.2	Counter32	0
IldpV2StatsRxPortFramesTotal.13.3	1.3.111.2.802.1.1.13.1.2.7.1.5.13.3	Counter32	0
IldpV2StatsRxPortFramesTotal.14.1	1.3.111.2.802.1.1.13.1.2.7.1.5.14.1	Counter32	0
IldpV2StatsRxPortFramesTotal.14.2	1.3.111.2.802.1.1.13.1.2.7.1.5.14.2	Counter32	0
IldpV2StatsRxPortFramesTotal.14.3	1.3.111.2.802.1.1.13.1.2.7.1.5.14.3	Counter32	0
IldpV2StatsRxPortFramesTotal.15.1	1.3.111.2.802.1.1.13.1.2.7.1.5.15.1	Counter32	0
IldpV2StatsRxPortFramesTotal.15.2	1.3.111.2.802.1.1.13.1.2.7.1.5.15.2	Counter32	0
IldpV2StatsRxPortFramesTotal.15.3	1.3.111.2.802.1.1.13.1.2.7.1.5.15.3	Counter32	0
IldpV2StatsRxPortFramesTotal.16.1	1.3.111.2.802.1.1.13.1.2.7.1.5.16.1	Counter32	0
IldpV2StatsRxPortFramesTotal.16.2	1.3.111.2.802.1.1.13.1.2.7.1.5.16.2	Counter32	0
IldpV2StatsRxPortFramesTotal.16.3	1.3.111.2.802.1.1.13.1.2.7.1.5.16.3	Counter32	0
IldpV2StatsRxPortFramesTotal.17.1	1.3.111.2.802.1.1.13.1.2.7.1.5.17.1	Counter32	0
IldpV2StatsRxPortFramesTotal.17.2	1.3.111.2.802.1.1.13.1.2.7.1.5.17.2	Counter32	0
IldpV2StatsRxPortFramesTotal.17.3	1.3.111.2.802.1.1.13.1.2.7.1.5.17.3	Counter32	0
IldpV2StatsRxPortFramesTotal.18.1	1.3.111.2.802.1.1.13.1.2.7.1.5.18.1	Counter32	0
IldpV2StatsRxPortFramesTotal.18.2	1.3.111.2.802.1.1.13.1.2.7.1.5.18.2	Counter32	0
IldpV2StatsRxPortFramesTotal.18.3	1.3.111.2.802.1.1.13.1.2.7.1.5.18.3	Counter32	0
IldpV2StatsRxPortFramesTotal.19.1	1.3.111.2.802.1.1.13.1.2.7.1.5.19.1	Counter32	0
IldpV2StatsRxPortFramesTotal.19.2	1.3.111.2.802.1.1.13.1.2.7.1.5.19.2	Counter32	0
IldpV2StatsRxPortFramesTotal.19.3	1.3.111.2.802.1.1.13.1.2.7.1.5.19.3	Counter32	0
IldpV2StatsRxPortFramesTotal.20.1	1.3.111.2.802.1.1.13.1.2.7.1.5.20.1	Counter32	0
IldpV2StatsRxPortFramesTotal.20.2	1.3.111.2.802.1.1.13.1.2.7.1.5.20.2	Counter32	0
IldpV2StatsRxPortFramesTotal.20.3	1.3.111.2.802.1.1.13.1.2.7.1.5.20.3	Counter32	0
IldpV2StatsRxPortFramesTotal.21.1	1.3.111.2.802.1.1.13.1.2.7.1.5.21.1	Counter32	0



Name	OID	Value Type	Value Example
IldpV2StatsRxPortFramesTotal.21.2	1.3.111.2.802.1.1.13.1.2.7.1.5.21.2	Counter32	0
IldpV2StatsRxPortFramesTotal.21.3	1.3.111.2.802.1.1.13.1.2.7.1.5.21.3	Counter32	0
IldpV2StatsRxPortFramesTotal.22.1	1.3.111.2.802.1.1.13.1.2.7.1.5.22.1	Counter32	0
IldpV2StatsRxPortFramesTotal.22.2	1.3.111.2.802.1.1.13.1.2.7.1.5.22.2	Counter32	0
IldpV2StatsRxPortFramesTotal.22.3	1.3.111.2.802.1.1.13.1.2.7.1.5.22.3	Counter32	0
IldpV2StatsRxPortFramesTotal.23.1	1.3.111.2.802.1.1.13.1.2.7.1.5.23.1	Counter32	0
IldpV2StatsRxPortFramesTotal.23.2	1.3.111.2.802.1.1.13.1.2.7.1.5.23.2	Counter32	0
IldpV2StatsRxPortFramesTotal.23.3	1.3.111.2.802.1.1.13.1.2.7.1.5.23.3	Counter32	0
IldpV2StatsRxPortFramesTotal.24.1	1.3.111.2.802.1.1.13.1.2.7.1.5.24.1	Counter32	0
IldpV2StatsRxPortFramesTotal.24.2	1.3.111.2.802.1.1.13.1.2.7.1.5.24.2	Counter32	0
IldpV2StatsRxPortFramesTotal.24.3	1.3.111.2.802.1.1.13.1.2.7.1.5.24.3	Counter32	0
IldpV2StatsRxPortFramesTotal.25.1	1.3.111.2.802.1.1.13.1.2.7.1.5.25.1	Counter32	0
IldpV2StatsRxPortFramesTotal.25.2	1.3.111.2.802.1.1.13.1.2.7.1.5.25.2	Counter32	0
IldpV2StatsRxPortFramesTotal.25.3	1.3.111.2.802.1.1.13.1.2.7.1.5.25.3	Counter32	0
IldpV2StatsRxPortFramesTotal.26.1	1.3.111.2.802.1.1.13.1.2.7.1.5.26.1	Counter32	0
IldpV2StatsRxPortFramesTotal.26.2	1.3.111.2.802.1.1.13.1.2.7.1.5.26.2	Counter32	0
IldpV2StatsRxPortFramesTotal.26.3	1.3.111.2.802.1.1.13.1.2.7.1.5.26.3	Counter32	0
IldpV2StatsRxPortFramesTotal.27.1	1.3.111.2.802.1.1.13.1.2.7.1.5.27.1	Counter32	0
IldpV2StatsRxPortFramesTotal.27.2	1.3.111.2.802.1.1.13.1.2.7.1.5.27.2	Counter32	0
IldpV2StatsRxPortFramesTotal.27.3	1.3.111.2.802.1.1.13.1.2.7.1.5.27.3	Counter32	0
IldpV2StatsRxPortFramesTotal.28.1	1.3.111.2.802.1.1.13.1.2.7.1.5.28.1	Counter32	0
IldpV2StatsRxPortFramesTotal.28.2	1.3.111.2.802.1.1.13.1.2.7.1.5.28.2	Counter32	0
IldpV2StatsRxPortFramesTotal.28.3	1.3.111.2.802.1.1.13.1.2.7.1.5.28.3	Counter32	0
IldpV2StatsRxPortFramesTotal.29.1	1.3.111.2.802.1.1.13.1.2.7.1.5.29.1	Counter32	0
IldpV2StatsRxPortFramesTotal.29.2	1.3.111.2.802.1.1.13.1.2.7.1.5.29.2	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortFramesTotal.29.3	1.3.111.2.802.1.1.13.1.2.7.1.5.29.3	Counter32	0
IldpV2StatsRxPortFramesTotal.30.1	1.3.111.2.802.1.1.13.1.2.7.1.5.30.1	Counter32	0
IldpV2StatsRxPortFramesTotal.30.2	1.3.111.2.802.1.1.13.1.2.7.1.5.30.2	Counter32	0
IldpV2StatsRxPortFramesTotal.30.3	1.3.111.2.802.1.1.13.1.2.7.1.5.30.3	Counter32	0
IldpV2StatsRxPortFramesTotal.31.1	1.3.111.2.802.1.1.13.1.2.7.1.5.31.1	Counter32	0
IldpV2StatsRxPortFramesTotal.31.2	1.3.111.2.802.1.1.13.1.2.7.1.5.31.2	Counter32	0
IldpV2StatsRxPortFramesTotal.31.3	1.3.111.2.802.1.1.13.1.2.7.1.5.31.3	Counter32	0
IldpV2StatsRxPortFramesTotal.32.1	1.3.111.2.802.1.1.13.1.2.7.1.5.32.1	Counter32	0
IldpV2StatsRxPortFramesTotal.32.2	1.3.111.2.802.1.1.13.1.2.7.1.5.32.2	Counter32	0
IldpV2StatsRxPortFramesTotal.32.3	1.3.111.2.802.1.1.13.1.2.7.1.5.32.3	Counter32	0
IldpV2StatsRxPortFramesTotal.33.1	1.3.111.2.802.1.1.13.1.2.7.1.5.33.1	Counter32	0
IldpV2StatsRxPortFramesTotal.33.2	1.3.111.2.802.1.1.13.1.2.7.1.5.33.2	Counter32	0
IldpV2StatsRxPortFramesTotal.33.3	1.3.111.2.802.1.1.13.1.2.7.1.5.33.3	Counter32	0
IldpV2StatsRxPortFramesTotal.34.1	1.3.111.2.802.1.1.13.1.2.7.1.5.34.1	Counter32	0
IldpV2StatsRxPortFramesTotal.34.2	1.3.111.2.802.1.1.13.1.2.7.1.5.34.2	Counter32	0
IldpV2StatsRxPortFramesTotal.34.3	1.3.111.2.802.1.1.13.1.2.7.1.5.34.3	Counter32	0
IldpV2StatsRxPortFramesTotal.35.1	1.3.111.2.802.1.1.13.1.2.7.1.5.35.1	Counter32	0
IldpV2StatsRxPortFramesTotal.35.2	1.3.111.2.802.1.1.13.1.2.7.1.5.35.2	Counter32	0
IldpV2StatsRxPortFramesTotal.35.3	1.3.111.2.802.1.1.13.1.2.7.1.5.35.3	Counter32	0
IldpV2StatsRxPortFramesTotal.36.1	1.3.111.2.802.1.1.13.1.2.7.1.5.36.1	Counter32	0
IldpV2StatsRxPortFramesTotal.36.2	1.3.111.2.802.1.1.13.1.2.7.1.5.36.2	Counter32	0
IldpV2StatsRxPortFramesTotal.36.3	1.3.111.2.802.1.1.13.1.2.7.1.5.36.3	Counter32	0
IldpV2StatsRxPortFramesTotal.37.1	1.3.111.2.802.1.1.13.1.2.7.1.5.37.1	Counter32	0
IldpV2StatsRxPortFramesTotal.37.2	1.3.111.2.802.1.1.13.1.2.7.1.5.37.2	Counter32	0
IldpV2StatsRxPortFramesTotal.37.3	1.3.111.2.802.1.1.13.1.2.7.1.5.37.3	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
IldpV2StatsRxPortFramesTotal.38.1	1.3.111.2.802.1.1.13.1.2.7.1.5.38.1	Counter32	0
IldpV2StatsRxPortFramesTotal.38.2	1.3.111.2.802.1.1.13.1.2.7.1.5.38.2	Counter32	0
IldpV2StatsRxPortFramesTotal.38.3	1.3.111.2.802.1.1.13.1.2.7.1.5.38.3	Counter32	0
IldpV2StatsRxPortFramesTotal.39.1	1.3.111.2.802.1.1.13.1.2.7.1.5.39.1	Counter32	0
IldpV2StatsRxPortFramesTotal.39.2	1.3.111.2.802.1.1.13.1.2.7.1.5.39.2	Counter32	0
IldpV2StatsRxPortFramesTotal.39.3	1.3.111.2.802.1.1.13.1.2.7.1.5.39.3	Counter32	0
IldpV2StatsRxPortFramesTotal.40.1	1.3.111.2.802.1.1.13.1.2.7.1.5.40.1	Counter32	0
IldpV2StatsRxPortFramesTotal.40.2	1.3.111.2.802.1.1.13.1.2.7.1.5.40.2	Counter32	0
IldpV2StatsRxPortFramesTotal.40.3	1.3.111.2.802.1.1.13.1.2.7.1.5.40.3	Counter32	0
IldpV2StatsRxPortFramesTotal.41.1	1.3.111.2.802.1.1.13.1.2.7.1.5.41.1	Counter32	0
IldpV2StatsRxPortFramesTotal.41.2	1.3.111.2.802.1.1.13.1.2.7.1.5.41.2	Counter32	0
IldpV2StatsRxPortFramesTotal.41.3	1.3.111.2.802.1.1.13.1.2.7.1.5.41.3	Counter32	0
IldpV2StatsRxPortFramesTotal.42.1	1.3.111.2.802.1.1.13.1.2.7.1.5.42.1	Counter32	0
IldpV2StatsRxPortFramesTotal.42.2	1.3.111.2.802.1.1.13.1.2.7.1.5.42.2	Counter32	0
IldpV2StatsRxPortFramesTotal.42.3	1.3.111.2.802.1.1.13.1.2.7.1.5.42.3	Counter32	0
IldpV2StatsRxPortFramesTotal.43.1	1.3.111.2.802.1.1.13.1.2.7.1.5.43.1	Counter32	0
IldpV2StatsRxPortFramesTotal.43.2	1.3.111.2.802.1.1.13.1.2.7.1.5.43.2	Counter32	0
IldpV2StatsRxPortFramesTotal.43.3	1.3.111.2.802.1.1.13.1.2.7.1.5.43.3	Counter32	0
IldpV2StatsRxPortFramesTotal.44.1	1.3.111.2.802.1.1.13.1.2.7.1.5.44.1	Counter32	0
IldpV2StatsRxPortFramesTotal.44.2	1.3.111.2.802.1.1.13.1.2.7.1.5.44.2	Counter32	0
IldpV2StatsRxPortFramesTotal.44.3	1.3.111.2.802.1.1.13.1.2.7.1.5.44.3	Counter32	0
IldpV2StatsRxPortFramesTotal.45.1	1.3.111.2.802.1.1.13.1.2.7.1.5.45.1	Counter32	0
IldpV2StatsRxPortFramesTotal.45.2	1.3.111.2.802.1.1.13.1.2.7.1.5.45.2	Counter32	0
IldpV2StatsRxPortFramesTotal.45.3	1.3.111.2.802.1.1.13.1.2.7.1.5.45.3	Counter32	0
IldpV2StatsRxPortFramesTotal.46.1	1.3.111.2.802.1.1.13.1.2.7.1.5.46.1	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortFramesTotal.46.2	1.3.111.2.802.1.1.13.1.2.7.1.5.46.2	Counter32	0
IldpV2StatsRxPortFramesTotal.46.3	1.3.111.2.802.1.1.13.1.2.7.1.5.46.3	Counter32	0
IldpV2StatsRxPortFramesTotal.47.1	1.3.111.2.802.1.1.13.1.2.7.1.5.47.1	Counter32	0
IldpV2StatsRxPortFramesTotal.47.2	1.3.111.2.802.1.1.13.1.2.7.1.5.47.2	Counter32	0
IldpV2StatsRxPortFramesTotal.47.3	1.3.111.2.802.1.1.13.1.2.7.1.5.47.3	Counter32	0
IldpV2StatsRxPortFramesTotal.48.1	1.3.111.2.802.1.1.13.1.2.7.1.5.48.1	Counter32	0
IldpV2StatsRxPortFramesTotal.48.2	1.3.111.2.802.1.1.13.1.2.7.1.5.48.2	Counter32	0
IldpV2StatsRxPortFramesTotal.48.3	1.3.111.2.802.1.1.13.1.2.7.1.5.48.3	Counter32	0
IldpV2StatsRxPortFramesTotal.49.1	1.3.111.2.802.1.1.13.1.2.7.1.5.49.1	Counter32	0
IldpV2StatsRxPortFramesTotal.49.2	1.3.111.2.802.1.1.13.1.2.7.1.5.49.2	Counter32	0
IldpV2StatsRxPortFramesTotal.49.3	1.3.111.2.802.1.1.13.1.2.7.1.5.49.3	Counter32	0
IldpV2StatsRxPortFramesTotal.50.1	1.3.111.2.802.1.1.13.1.2.7.1.5.50.1	Counter32	0
IldpV2StatsRxPortFramesTotal.50.2	1.3.111.2.802.1.1.13.1.2.7.1.5.50.2	Counter32	0
IldpV2StatsRxPortFramesTotal.50.3	1.3.111.2.802.1.1.13.1.2.7.1.5.50.3	Counter32	0
IldpV2StatsRxPortFramesTotal.51.1	1.3.111.2.802.1.1.13.1.2.7.1.5.51.1	Counter32	0
IldpV2StatsRxPortFramesTotal.51.2	1.3.111.2.802.1.1.13.1.2.7.1.5.51.2	Counter32	0
IldpV2StatsRxPortFramesTotal.51.3	1.3.111.2.802.1.1.13.1.2.7.1.5.51.3	Counter32	0
IldpV2StatsRxPortFramesTotal.52.1	1.3.111.2.802.1.1.13.1.2.7.1.5.52.1	Counter32	0
IldpV2StatsRxPortFramesTotal.52.2	1.3.111.2.802.1.1.13.1.2.7.1.5.52.2	Counter32	0
IldpV2StatsRxPortFramesTotal.52.3	1.3.111.2.802.1.1.13.1.2.7.1.5.52.3	Counter32	0
IldpV2StatsRxPortFramesTotal.53.1	1.3.111.2.802.1.1.13.1.2.7.1.5.53.1	Counter32	0
IldpV2StatsRxPortFramesTotal.53.2	1.3.111.2.802.1.1.13.1.2.7.1.5.53.2	Counter32	0
IldpV2StatsRxPortFramesTotal.53.3	1.3.111.2.802.1.1.13.1.2.7.1.5.53.3	Counter32	0
IldpV2StatsRxPortFramesTotal.54.1	1.3.111.2.802.1.1.13.1.2.7.1.5.54.1	Counter32	0
IldpV2StatsRxPortFramesTotal.54.2	1.3.111.2.802.1.1.13.1.2.7.1.5.54.2	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortFramesTotal.54.3	.1.3.111.2.802.1.1.13.1.2.7.1.5.54.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.1.1	.1.3.111.2.802.1.1.13.1.2.7.1.6.1.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.1.2	.1.3.111.2.802.1.1.13.1.2.7.1.6.1.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.1.3	.1.3.111.2.802.1.1.13.1.2.7.1.6.1.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.2.1	.1.3.111.2.802.1.1.13.1.2.7.1.6.2.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.2.2	.1.3.111.2.802.1.1.13.1.2.7.1.6.2.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.2.3	.1.3.111.2.802.1.1.13.1.2.7.1.6.2.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.3.1	.1.3.111.2.802.1.1.13.1.2.7.1.6.3.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.3.2	.1.3.111.2.802.1.1.13.1.2.7.1.6.3.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.3.3	.1.3.111.2.802.1.1.13.1.2.7.1.6.3.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.4.1	.1.3.111.2.802.1.1.13.1.2.7.1.6.4.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.4.2	.1.3.111.2.802.1.1.13.1.2.7.1.6.4.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.4.3	.1.3.111.2.802.1.1.13.1.2.7.1.6.4.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.5.1	.1.3.111.2.802.1.1.13.1.2.7.1.6.5.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.5.2	.1.3.111.2.802.1.1.13.1.2.7.1.6.5.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.5.3	.1.3.111.2.802.1.1.13.1.2.7.1.6.5.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.6.1	.1.3.111.2.802.1.1.13.1.2.7.1.6.6.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.6.2	.1.3.111.2.802.1.1.13.1.2.7.1.6.6.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.6.3	.1.3.111.2.802.1.1.13.1.2.7.1.6.6.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.7.1	.1.3.111.2.802.1.1.13.1.2.7.1.6.7.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.7.2	.1.3.111.2.802.1.1.13.1.2.7.1.6.7.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.7.3	.1.3.111.2.802.1.1.13.1.2.7.1.6.7.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.8.1	.1.3.111.2.802.1.1.13.1.2.7.1.6.8.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.8.2	.1.3.111.2.802.1.1.13.1.2.7.1.6.8.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.8.3	.1.3.111.2.802.1.1.13.1.2.7.1.6.8.3	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortTLVsDiscardedTotal.9.1	.1.3.111.2.802.1.1.13.1.2.7.1.6.9.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.9.2	.1.3.111.2.802.1.1.13.1.2.7.1.6.9.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.9.3	.1.3.111.2.802.1.1.13.1.2.7.1.6.9.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.10.1	1.3.111.2.802.1.1.13.1.2.7.1.6.10.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.10.2	1.3.111.2.802.1.1.13.1.2.7.1.6.10.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.10.3	1.3.111.2.802.1.1.13.1.2.7.1.6.10.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.11.1	1.3.111.2.802.1.1.13.1.2.7.1.6.11.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.11.2	1.3.111.2.802.1.1.13.1.2.7.1.6.11.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.11.3	1.3.111.2.802.1.1.13.1.2.7.1.6.11.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.12.1	1.3.111.2.802.1.1.13.1.2.7.1.6.12.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.12.2	1.3.111.2.802.1.1.13.1.2.7.1.6.12.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.12.3	1.3.111.2.802.1.1.13.1.2.7.1.6.12.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.13.1	1.3.111.2.802.1.1.13.1.2.7.1.6.13.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.13.2	1.3.111.2.802.1.1.13.1.2.7.1.6.13.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.13.3	1.3.111.2.802.1.1.13.1.2.7.1.6.13.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.14.1	1.3.111.2.802.1.1.13.1.2.7.1.6.14.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.14.2	1.3.111.2.802.1.1.13.1.2.7.1.6.14.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.14.3	1.3.111.2.802.1.1.13.1.2.7.1.6.14.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.15.1	1.3.111.2.802.1.1.13.1.2.7.1.6.15.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.15.2	1.3.111.2.802.1.1.13.1.2.7.1.6.15.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.15.3	1.3.111.2.802.1.1.13.1.2.7.1.6.15.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.16.1	1.3.111.2.802.1.1.13.1.2.7.1.6.16.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.16.2	1.3.111.2.802.1.1.13.1.2.7.1.6.16.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.16.3	1.3.111.2.802.1.1.13.1.2.7.1.6.16.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.17.1	1.3.111.2.802.1.1.13.1.2.7.1.6.17.1	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortTLVsDiscardedTotal.17.2	1.3.111.2.802.1.1.13.1.2.7.1.6.17.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.17.3	1.3.111.2.802.1.1.13.1.2.7.1.6.17.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.18.1	1.3.111.2.802.1.1.13.1.2.7.1.6.18.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.18.2	1.3.111.2.802.1.1.13.1.2.7.1.6.18.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.18.3	1.3.111.2.802.1.1.13.1.2.7.1.6.18.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.19.1	1.3.111.2.802.1.1.13.1.2.7.1.6.19.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.19.2	1.3.111.2.802.1.1.13.1.2.7.1.6.19.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.19.3	1.3.111.2.802.1.1.13.1.2.7.1.6.19.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.20.1	1.3.111.2.802.1.1.13.1.2.7.1.6.20.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.20.2	1.3.111.2.802.1.1.13.1.2.7.1.6.20.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.20.3	1.3.111.2.802.1.1.13.1.2.7.1.6.20.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.21.1	1.3.111.2.802.1.1.13.1.2.7.1.6.21.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.21.2	1.3.111.2.802.1.1.13.1.2.7.1.6.21.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.21.3	1.3.111.2.802.1.1.13.1.2.7.1.6.21.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.22.1	1.3.111.2.802.1.1.13.1.2.7.1.6.22.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.22.2	1.3.111.2.802.1.1.13.1.2.7.1.6.22.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.22.3	1.3.111.2.802.1.1.13.1.2.7.1.6.22.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.23.1	1.3.111.2.802.1.1.13.1.2.7.1.6.23.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.23.2	1.3.111.2.802.1.1.13.1.2.7.1.6.23.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.23.3	1.3.111.2.802.1.1.13.1.2.7.1.6.23.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.24.1	1.3.111.2.802.1.1.13.1.2.7.1.6.24.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.24.2	1.3.111.2.802.1.1.13.1.2.7.1.6.24.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.24.3	1.3.111.2.802.1.1.13.1.2.7.1.6.24.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.25.1	1.3.111.2.802.1.1.13.1.2.7.1.6.25.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.25.2	1.3.111.2.802.1.1.13.1.2.7.1.6.25.2	Counter32	0



Name	OID	Value Type	Value Example
IldpV2StatsRxPortTLVsDiscardedTotal.25.3	1.3.111.2.802.1.1.13.1.2.7.1.6.25.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.26.1	1.3.111.2.802.1.1.13.1.2.7.1.6.26.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.26.2	1.3.111.2.802.1.1.13.1.2.7.1.6.26.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.26.3	1.3.111.2.802.1.1.13.1.2.7.1.6.26.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.27.1	1.3.111.2.802.1.1.13.1.2.7.1.6.27.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.27.2	1.3.111.2.802.1.1.13.1.2.7.1.6.27.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.27.3	1.3.111.2.802.1.1.13.1.2.7.1.6.27.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.28.1	1.3.111.2.802.1.1.13.1.2.7.1.6.28.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.28.2	1.3.111.2.802.1.1.13.1.2.7.1.6.28.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.28.3	1.3.111.2.802.1.1.13.1.2.7.1.6.28.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.29.1	1.3.111.2.802.1.1.13.1.2.7.1.6.29.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.29.2	1.3.111.2.802.1.1.13.1.2.7.1.6.29.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.29.3	1.3.111.2.802.1.1.13.1.2.7.1.6.29.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.30.1	1.3.111.2.802.1.1.13.1.2.7.1.6.30.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.30.2	1.3.111.2.802.1.1.13.1.2.7.1.6.30.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.30.3	1.3.111.2.802.1.1.13.1.2.7.1.6.30.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.31.1	1.3.111.2.802.1.1.13.1.2.7.1.6.31.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.31.2	1.3.111.2.802.1.1.13.1.2.7.1.6.31.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.31.3	1.3.111.2.802.1.1.13.1.2.7.1.6.31.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.32.1	1.3.111.2.802.1.1.13.1.2.7.1.6.32.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.32.2	1.3.111.2.802.1.1.13.1.2.7.1.6.32.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.32.3	1.3.111.2.802.1.1.13.1.2.7.1.6.32.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.33.1	1.3.111.2.802.1.1.13.1.2.7.1.6.33.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.33.2	1.3.111.2.802.1.1.13.1.2.7.1.6.33.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.33.3	1.3.111.2.802.1.1.13.1.2.7.1.6.33.3	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortTLVsDiscardedTotal.34.1	1.3.111.2.802.1.1.13.1.2.7.1.6.34.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.34.2	1.3.111.2.802.1.1.13.1.2.7.1.6.34.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.34.3	1.3.111.2.802.1.1.13.1.2.7.1.6.34.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.35.1	1.3.111.2.802.1.1.13.1.2.7.1.6.35.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.35.2	1.3.111.2.802.1.1.13.1.2.7.1.6.35.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.35.3	1.3.111.2.802.1.1.13.1.2.7.1.6.35.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.36.1	1.3.111.2.802.1.1.13.1.2.7.1.6.36.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.36.2	1.3.111.2.802.1.1.13.1.2.7.1.6.36.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.36.3	1.3.111.2.802.1.1.13.1.2.7.1.6.36.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.37.1	1.3.111.2.802.1.1.13.1.2.7.1.6.37.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.37.2	1.3.111.2.802.1.1.13.1.2.7.1.6.37.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.37.3	1.3.111.2.802.1.1.13.1.2.7.1.6.37.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.38.1	1.3.111.2.802.1.1.13.1.2.7.1.6.38.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.38.2	1.3.111.2.802.1.1.13.1.2.7.1.6.38.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.38.3	1.3.111.2.802.1.1.13.1.2.7.1.6.38.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.39.1	1.3.111.2.802.1.1.13.1.2.7.1.6.39.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.39.2	1.3.111.2.802.1.1.13.1.2.7.1.6.39.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.39.3	1.3.111.2.802.1.1.13.1.2.7.1.6.39.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.40.1	1.3.111.2.802.1.1.13.1.2.7.1.6.40.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.40.2	1.3.111.2.802.1.1.13.1.2.7.1.6.40.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.40.3	1.3.111.2.802.1.1.13.1.2.7.1.6.40.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.41.1	1.3.111.2.802.1.1.13.1.2.7.1.6.41.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.41.2	1.3.111.2.802.1.1.13.1.2.7.1.6.41.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.41.3	1.3.111.2.802.1.1.13.1.2.7.1.6.41.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.42.1	1.3.111.2.802.1.1.13.1.2.7.1.6.42.1	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortTLVsDiscardedTotal.42.2	1.3.111.2.802.1.1.13.1.2.7.1.6.42.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.42.3	1.3.111.2.802.1.1.13.1.2.7.1.6.42.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.43.1	1.3.111.2.802.1.1.13.1.2.7.1.6.43.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.43.2	1.3.111.2.802.1.1.13.1.2.7.1.6.43.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.43.3	1.3.111.2.802.1.1.13.1.2.7.1.6.43.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.44.1	1.3.111.2.802.1.1.13.1.2.7.1.6.44.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.44.2	1.3.111.2.802.1.1.13.1.2.7.1.6.44.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.44.3	1.3.111.2.802.1.1.13.1.2.7.1.6.44.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.45.1	1.3.111.2.802.1.1.13.1.2.7.1.6.45.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.45.2	1.3.111.2.802.1.1.13.1.2.7.1.6.45.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.45.3	1.3.111.2.802.1.1.13.1.2.7.1.6.45.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.46.1	1.3.111.2.802.1.1.13.1.2.7.1.6.46.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.46.2	1.3.111.2.802.1.1.13.1.2.7.1.6.46.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.46.3	1.3.111.2.802.1.1.13.1.2.7.1.6.46.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.47.1	1.3.111.2.802.1.1.13.1.2.7.1.6.47.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.47.2	1.3.111.2.802.1.1.13.1.2.7.1.6.47.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.47.3	1.3.111.2.802.1.1.13.1.2.7.1.6.47.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.48.1	1.3.111.2.802.1.1.13.1.2.7.1.6.48.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.48.2	1.3.111.2.802.1.1.13.1.2.7.1.6.48.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.48.3	1.3.111.2.802.1.1.13.1.2.7.1.6.48.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.49.1	1.3.111.2.802.1.1.13.1.2.7.1.6.49.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.49.2	1.3.111.2.802.1.1.13.1.2.7.1.6.49.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.49.3	1.3.111.2.802.1.1.13.1.2.7.1.6.49.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.50.1	1.3.111.2.802.1.1.13.1.2.7.1.6.50.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.50.2	1.3.111.2.802.1.1.13.1.2.7.1.6.50.2	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortTLVsDiscardedTotal.50.3	1.3.111.2.802.1.1.13.1.2.7.1.6.50.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.51.1	1.3.111.2.802.1.1.13.1.2.7.1.6.51.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.51.2	1.3.111.2.802.1.1.13.1.2.7.1.6.51.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.51.3	1.3.111.2.802.1.1.13.1.2.7.1.6.51.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.52.1	1.3.111.2.802.1.1.13.1.2.7.1.6.52.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.52.2	1.3.111.2.802.1.1.13.1.2.7.1.6.52.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.52.3	1.3.111.2.802.1.1.13.1.2.7.1.6.52.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.53.1	1.3.111.2.802.1.1.13.1.2.7.1.6.53.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.53.2	1.3.111.2.802.1.1.13.1.2.7.1.6.53.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.53.3	1.3.111.2.802.1.1.13.1.2.7.1.6.53.3	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.54.1	1.3.111.2.802.1.1.13.1.2.7.1.6.54.1	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.54.2	1.3.111.2.802.1.1.13.1.2.7.1.6.54.2	Counter32	0
IldpV2StatsRxPortTLVsDiscardedTotal.54.3	1.3.111.2.802.1.1.13.1.2.7.1.6.54.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.1.1	1.3.111.2.802.1.1.13.1.2.7.1.7.1.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.1.2	1.3.111.2.802.1.1.13.1.2.7.1.7.1.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.1.3	1.3.111.2.802.1.1.13.1.2.7.1.7.1.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.2.1	1.3.111.2.802.1.1.13.1.2.7.1.7.2.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.2.2	1.3.111.2.802.1.1.13.1.2.7.1.7.2.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.2.3	1.3.111.2.802.1.1.13.1.2.7.1.7.2.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.3.1	1.3.111.2.802.1.1.13.1.2.7.1.7.3.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.3.2	1.3.111.2.802.1.1.13.1.2.7.1.7.3.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.3.3	1.3.111.2.802.1.1.13.1.2.7.1.7.3.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.4.1	1.3.111.2.802.1.1.13.1.2.7.1.7.4.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.4.2	1.3.111.2.802.1.1.13.1.2.7.1.7.4.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.4.3	1.3.111.2.802.1.1.13.1.2.7.1.7.4.3	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortTLVsUnrecognizedTotal.5.1	.1.3.111.2.802.1.1.13.1.2.7.1.7.5.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.5.2	.1.3.111.2.802.1.1.13.1.2.7.1.7.5.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.5.3	.1.3.111.2.802.1.1.13.1.2.7.1.7.5.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.6.1	.1.3.111.2.802.1.1.13.1.2.7.1.7.6.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.6.2	.1.3.111.2.802.1.1.13.1.2.7.1.7.6.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.6.3	.1.3.111.2.802.1.1.13.1.2.7.1.7.6.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.7.1	.1.3.111.2.802.1.1.13.1.2.7.1.7.7.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.7.2	.1.3.111.2.802.1.1.13.1.2.7.1.7.7.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.7.3	.1.3.111.2.802.1.1.13.1.2.7.1.7.7.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.8.1	.1.3.111.2.802.1.1.13.1.2.7.1.7.8.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.8.2	.1.3.111.2.802.1.1.13.1.2.7.1.7.8.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.8.3	.1.3.111.2.802.1.1.13.1.2.7.1.7.8.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.9.1	.1.3.111.2.802.1.1.13.1.2.7.1.7.9.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.9.2	.1.3.111.2.802.1.1.13.1.2.7.1.7.9.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.9.3	.1.3.111.2.802.1.1.13.1.2.7.1.7.9.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.10.1	1.3.111.2.802.1.1.13.1.2.7.1.7.10.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.10.2	1.3.111.2.802.1.1.13.1.2.7.1.7.10.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.10.3	1.3.111.2.802.1.1.13.1.2.7.1.7.10.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.11.1	1.3.111.2.802.1.1.13.1.2.7.1.7.11.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.11.2	1.3.111.2.802.1.1.13.1.2.7.1.7.11.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.11.3	1.3.111.2.802.1.1.13.1.2.7.1.7.11.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.12.1	1.3.111.2.802.1.1.13.1.2.7.1.7.12.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.12.2	1.3.111.2.802.1.1.13.1.2.7.1.7.12.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.12.3	1.3.111.2.802.1.1.13.1.2.7.1.7.12.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.13.1	1.3.111.2.802.1.1.13.1.2.7.1.7.13.1	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortTLVsUnrecognizedTotal.13.2	1.3.111.2.802.1.1.13.1.2.7.1.7.13.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.13.3	1.3.111.2.802.1.1.13.1.2.7.1.7.13.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.14.1	1.3.111.2.802.1.1.13.1.2.7.1.7.14.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.14.2	1.3.111.2.802.1.1.13.1.2.7.1.7.14.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.14.3	1.3.111.2.802.1.1.13.1.2.7.1.7.14.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.15.1	1.3.111.2.802.1.1.13.1.2.7.1.7.15.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.15.2	1.3.111.2.802.1.1.13.1.2.7.1.7.15.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.15.3	1.3.111.2.802.1.1.13.1.2.7.1.7.15.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.16.1	1.3.111.2.802.1.1.13.1.2.7.1.7.16.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.16.2	1.3.111.2.802.1.1.13.1.2.7.1.7.16.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.16.3	1.3.111.2.802.1.1.13.1.2.7.1.7.16.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.17.1	1.3.111.2.802.1.1.13.1.2.7.1.7.17.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.17.2	1.3.111.2.802.1.1.13.1.2.7.1.7.17.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.17.3	1.3.111.2.802.1.1.13.1.2.7.1.7.17.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.18.1	1.3.111.2.802.1.1.13.1.2.7.1.7.18.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.18.2	1.3.111.2.802.1.1.13.1.2.7.1.7.18.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.18.3	1.3.111.2.802.1.1.13.1.2.7.1.7.18.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.19.1	1.3.111.2.802.1.1.13.1.2.7.1.7.19.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.19.2	1.3.111.2.802.1.1.13.1.2.7.1.7.19.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.19.3	1.3.111.2.802.1.1.13.1.2.7.1.7.19.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.20.1	1.3.111.2.802.1.1.13.1.2.7.1.7.20.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.20.2	1.3.111.2.802.1.1.13.1.2.7.1.7.20.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.20.3	1.3.111.2.802.1.1.13.1.2.7.1.7.20.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.21.1	1.3.111.2.802.1.1.13.1.2.7.1.7.21.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.21.2	1.3.111.2.802.1.1.13.1.2.7.1.7.21.2	Counter32	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
IldpV2StatsRxPortTLVsUnrecognizedTotal.21.3	1.3.111.2.802.1.1.13.1.2.7.1.7.21.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.22.1	1.3.111.2.802.1.1.13.1.2.7.1.7.22.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.22.2	1.3.111.2.802.1.1.13.1.2.7.1.7.22.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.22.3	1.3.111.2.802.1.1.13.1.2.7.1.7.22.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.23.1	1.3.111.2.802.1.1.13.1.2.7.1.7.23.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.23.2	1.3.111.2.802.1.1.13.1.2.7.1.7.23.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.23.3	1.3.111.2.802.1.1.13.1.2.7.1.7.23.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.24.1	1.3.111.2.802.1.1.13.1.2.7.1.7.24.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.24.2	1.3.111.2.802.1.1.13.1.2.7.1.7.24.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.24.3	1.3.111.2.802.1.1.13.1.2.7.1.7.24.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.25.1	1.3.111.2.802.1.1.13.1.2.7.1.7.25.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.25.2	1.3.111.2.802.1.1.13.1.2.7.1.7.25.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.25.3	1.3.111.2.802.1.1.13.1.2.7.1.7.25.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.26.1	1.3.111.2.802.1.1.13.1.2.7.1.7.26.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.26.2	1.3.111.2.802.1.1.13.1.2.7.1.7.26.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.26.3	1.3.111.2.802.1.1.13.1.2.7.1.7.26.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.27.1	1.3.111.2.802.1.1.13.1.2.7.1.7.27.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.27.2	1.3.111.2.802.1.1.13.1.2.7.1.7.27.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.27.3	1.3.111.2.802.1.1.13.1.2.7.1.7.27.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.28.1	1.3.111.2.802.1.1.13.1.2.7.1.7.28.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.28.2	1.3.111.2.802.1.1.13.1.2.7.1.7.28.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.28.3	1.3.111.2.802.1.1.13.1.2.7.1.7.28.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.29.1	1.3.111.2.802.1.1.13.1.2.7.1.7.29.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.29.2	1.3.111.2.802.1.1.13.1.2.7.1.7.29.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.29.3	1.3.111.2.802.1.1.13.1.2.7.1.7.29.3	Counter32	0



Name	OID	Value Type	Value Example
IldpV2StatsRxPortTLVsUnrecognizedTotal.30.1	1.3.111.2.802.1.1.13.1.2.7.1.7.30.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.30.2	1.3.111.2.802.1.1.13.1.2.7.1.7.30.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.30.3	1.3.111.2.802.1.1.13.1.2.7.1.7.30.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.31.1	1.3.111.2.802.1.1.13.1.2.7.1.7.31.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.31.2	1.3.111.2.802.1.1.13.1.2.7.1.7.31.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.31.3	1.3.111.2.802.1.1.13.1.2.7.1.7.31.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.32.1	1.3.111.2.802.1.1.13.1.2.7.1.7.32.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.32.2	1.3.111.2.802.1.1.13.1.2.7.1.7.32.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.32.3	1.3.111.2.802.1.1.13.1.2.7.1.7.32.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.33.1	1.3.111.2.802.1.1.13.1.2.7.1.7.33.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.33.2	1.3.111.2.802.1.1.13.1.2.7.1.7.33.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.33.3	1.3.111.2.802.1.1.13.1.2.7.1.7.33.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.34.1	1.3.111.2.802.1.1.13.1.2.7.1.7.34.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.34.2	1.3.111.2.802.1.1.13.1.2.7.1.7.34.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.34.3	1.3.111.2.802.1.1.13.1.2.7.1.7.34.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.35.1	1.3.111.2.802.1.1.13.1.2.7.1.7.35.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.35.2	1.3.111.2.802.1.1.13.1.2.7.1.7.35.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.35.3	1.3.111.2.802.1.1.13.1.2.7.1.7.35.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.36.1	1.3.111.2.802.1.1.13.1.2.7.1.7.36.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.36.2	1.3.111.2.802.1.1.13.1.2.7.1.7.36.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.36.3	1.3.111.2.802.1.1.13.1.2.7.1.7.36.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.37.1	1.3.111.2.802.1.1.13.1.2.7.1.7.37.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.37.2	1.3.111.2.802.1.1.13.1.2.7.1.7.37.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.37.3	1.3.111.2.802.1.1.13.1.2.7.1.7.37.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.38.1	1.3.111.2.802.1.1.13.1.2.7.1.7.38.1	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortTLVsUnrecognizedTotal.38.2	1.3.111.2.802.1.1.13.1.2.7.1.7.38.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.38.3	1.3.111.2.802.1.1.13.1.2.7.1.7.38.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.39.1	1.3.111.2.802.1.1.13.1.2.7.1.7.39.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.39.2	1.3.111.2.802.1.1.13.1.2.7.1.7.39.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.39.3	1.3.111.2.802.1.1.13.1.2.7.1.7.39.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.40.1	1.3.111.2.802.1.1.13.1.2.7.1.7.40.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.40.2	1.3.111.2.802.1.1.13.1.2.7.1.7.40.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.40.3	1.3.111.2.802.1.1.13.1.2.7.1.7.40.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.41.1	1.3.111.2.802.1.1.13.1.2.7.1.7.41.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.41.2	1.3.111.2.802.1.1.13.1.2.7.1.7.41.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.41.3	1.3.111.2.802.1.1.13.1.2.7.1.7.41.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.42.1	1.3.111.2.802.1.1.13.1.2.7.1.7.42.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.42.2	1.3.111.2.802.1.1.13.1.2.7.1.7.42.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.42.3	1.3.111.2.802.1.1.13.1.2.7.1.7.42.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.43.1	1.3.111.2.802.1.1.13.1.2.7.1.7.43.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.43.2	1.3.111.2.802.1.1.13.1.2.7.1.7.43.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.43.3	1.3.111.2.802.1.1.13.1.2.7.1.7.43.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.44.1	1.3.111.2.802.1.1.13.1.2.7.1.7.44.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.44.2	1.3.111.2.802.1.1.13.1.2.7.1.7.44.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.44.3	1.3.111.2.802.1.1.13.1.2.7.1.7.44.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.45.1	1.3.111.2.802.1.1.13.1.2.7.1.7.45.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.45.2	1.3.111.2.802.1.1.13.1.2.7.1.7.45.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.45.3	1.3.111.2.802.1.1.13.1.2.7.1.7.45.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.46.1	1.3.111.2.802.1.1.13.1.2.7.1.7.46.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.46.2	1.3.111.2.802.1.1.13.1.2.7.1.7.46.2	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortTLVsUnrecognizedTotal.46.3	1.3.111.2.802.1.1.13.1.2.7.1.7.46.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.47.1	1.3.111.2.802.1.1.13.1.2.7.1.7.47.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.47.2	1.3.111.2.802.1.1.13.1.2.7.1.7.47.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.47.3	1.3.111.2.802.1.1.13.1.2.7.1.7.47.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.48.1	1.3.111.2.802.1.1.13.1.2.7.1.7.48.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.48.2	1.3.111.2.802.1.1.13.1.2.7.1.7.48.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.48.3	1.3.111.2.802.1.1.13.1.2.7.1.7.48.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.49.1	1.3.111.2.802.1.1.13.1.2.7.1.7.49.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.49.2	1.3.111.2.802.1.1.13.1.2.7.1.7.49.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.49.3	1.3.111.2.802.1.1.13.1.2.7.1.7.49.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.50.1	1.3.111.2.802.1.1.13.1.2.7.1.7.50.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.50.2	1.3.111.2.802.1.1.13.1.2.7.1.7.50.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.50.3	1.3.111.2.802.1.1.13.1.2.7.1.7.50.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.51.1	1.3.111.2.802.1.1.13.1.2.7.1.7.51.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.51.2	1.3.111.2.802.1.1.13.1.2.7.1.7.51.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.51.3	1.3.111.2.802.1.1.13.1.2.7.1.7.51.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.52.1	1.3.111.2.802.1.1.13.1.2.7.1.7.52.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.52.2	1.3.111.2.802.1.1.13.1.2.7.1.7.52.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.52.3	1.3.111.2.802.1.1.13.1.2.7.1.7.52.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.53.1	1.3.111.2.802.1.1.13.1.2.7.1.7.53.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.53.2	1.3.111.2.802.1.1.13.1.2.7.1.7.53.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.53.3	1.3.111.2.802.1.1.13.1.2.7.1.7.53.3	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.54.1	1.3.111.2.802.1.1.13.1.2.7.1.7.54.1	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.54.2	1.3.111.2.802.1.1.13.1.2.7.1.7.54.2	Counter32	0
IldpV2StatsRxPortTLVsUnrecognizedTotal.54.3	1.3.111.2.802.1.1.13.1.2.7.1.7.54.3	Counter32	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortAgeoutsTotal.1.1	.1.3.111.2.802.1.1.13.1.2.7.1.8.1.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.1.2	.1.3.111.2.802.1.1.13.1.2.7.1.8.1.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.1.3	.1.3.111.2.802.1.1.13.1.2.7.1.8.1.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.2.1	.1.3.111.2.802.1.1.13.1.2.7.1.8.2.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.2.2	.1.3.111.2.802.1.1.13.1.2.7.1.8.2.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.2.3	.1.3.111.2.802.1.1.13.1.2.7.1.8.2.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.3.1	.1.3.111.2.802.1.1.13.1.2.7.1.8.3.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.3.2	.1.3.111.2.802.1.1.13.1.2.7.1.8.3.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.3.3	.1.3.111.2.802.1.1.13.1.2.7.1.8.3.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.4.1	.1.3.111.2.802.1.1.13.1.2.7.1.8.4.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.4.2	.1.3.111.2.802.1.1.13.1.2.7.1.8.4.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.4.3	.1.3.111.2.802.1.1.13.1.2.7.1.8.4.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.5.1	.1.3.111.2.802.1.1.13.1.2.7.1.8.5.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.5.2	.1.3.111.2.802.1.1.13.1.2.7.1.8.5.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.5.3	.1.3.111.2.802.1.1.13.1.2.7.1.8.5.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.6.1	.1.3.111.2.802.1.1.13.1.2.7.1.8.6.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.6.2	.1.3.111.2.802.1.1.13.1.2.7.1.8.6.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.6.3	.1.3.111.2.802.1.1.13.1.2.7.1.8.6.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.7.1	.1.3.111.2.802.1.1.13.1.2.7.1.8.7.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.7.2	.1.3.111.2.802.1.1.13.1.2.7.1.8.7.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.7.3	.1.3.111.2.802.1.1.13.1.2.7.1.8.7.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.8.1	.1.3.111.2.802.1.1.13.1.2.7.1.8.8.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.8.2	.1.3.111.2.802.1.1.13.1.2.7.1.8.8.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.8.3	.1.3.111.2.802.1.1.13.1.2.7.1.8.8.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.9.1	.1.3.111.2.802.1.1.13.1.2.7.1.8.9.1	Gauge	0

<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
IldpV2StatsRxPortAgeoutsTotal.9.2	.1.3.111.2.802.1.1.13.1.2.7.1.8.9.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.9.3	.1.3.111.2.802.1.1.13.1.2.7.1.8.9.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.10.1	1.3.111.2.802.1.1.13.1.2.7.1.8.10.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.10.2	1.3.111.2.802.1.1.13.1.2.7.1.8.10.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.10.3	1.3.111.2.802.1.1.13.1.2.7.1.8.10.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.11.1	1.3.111.2.802.1.1.13.1.2.7.1.8.11.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.11.2	1.3.111.2.802.1.1.13.1.2.7.1.8.11.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.11.3	1.3.111.2.802.1.1.13.1.2.7.1.8.11.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.12.1	1.3.111.2.802.1.1.13.1.2.7.1.8.12.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.12.2	1.3.111.2.802.1.1.13.1.2.7.1.8.12.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.12.3	1.3.111.2.802.1.1.13.1.2.7.1.8.12.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.13.1	1.3.111.2.802.1.1.13.1.2.7.1.8.13.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.13.2	1.3.111.2.802.1.1.13.1.2.7.1.8.13.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.13.3	1.3.111.2.802.1.1.13.1.2.7.1.8.13.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.14.1	1.3.111.2.802.1.1.13.1.2.7.1.8.14.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.14.2	1.3.111.2.802.1.1.13.1.2.7.1.8.14.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.14.3	1.3.111.2.802.1.1.13.1.2.7.1.8.14.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.15.1	1.3.111.2.802.1.1.13.1.2.7.1.8.15.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.15.2	1.3.111.2.802.1.1.13.1.2.7.1.8.15.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.15.3	1.3.111.2.802.1.1.13.1.2.7.1.8.15.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.16.1	1.3.111.2.802.1.1.13.1.2.7.1.8.16.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.16.2	1.3.111.2.802.1.1.13.1.2.7.1.8.16.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.16.3	1.3.111.2.802.1.1.13.1.2.7.1.8.16.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.17.1	1.3.111.2.802.1.1.13.1.2.7.1.8.17.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.17.2	1.3.111.2.802.1.1.13.1.2.7.1.8.17.2	Gauge	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortAgeoutsTotal.17.3	1.3.111.2.802.1.1.13.1.2.7.1.8.17.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.18.1	1.3.111.2.802.1.1.13.1.2.7.1.8.18.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.18.2	1.3.111.2.802.1.1.13.1.2.7.1.8.18.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.18.3	1.3.111.2.802.1.1.13.1.2.7.1.8.18.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.19.1	1.3.111.2.802.1.1.13.1.2.7.1.8.19.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.19.2	1.3.111.2.802.1.1.13.1.2.7.1.8.19.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.19.3	1.3.111.2.802.1.1.13.1.2.7.1.8.19.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.20.1	1.3.111.2.802.1.1.13.1.2.7.1.8.20.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.20.2	1.3.111.2.802.1.1.13.1.2.7.1.8.20.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.20.3	1.3.111.2.802.1.1.13.1.2.7.1.8.20.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.21.1	1.3.111.2.802.1.1.13.1.2.7.1.8.21.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.21.2	1.3.111.2.802.1.1.13.1.2.7.1.8.21.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.21.3	1.3.111.2.802.1.1.13.1.2.7.1.8.21.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.22.1	1.3.111.2.802.1.1.13.1.2.7.1.8.22.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.22.2	1.3.111.2.802.1.1.13.1.2.7.1.8.22.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.22.3	1.3.111.2.802.1.1.13.1.2.7.1.8.22.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.23.1	1.3.111.2.802.1.1.13.1.2.7.1.8.23.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.23.2	1.3.111.2.802.1.1.13.1.2.7.1.8.23.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.23.3	1.3.111.2.802.1.1.13.1.2.7.1.8.23.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.24.1	1.3.111.2.802.1.1.13.1.2.7.1.8.24.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.24.2	1.3.111.2.802.1.1.13.1.2.7.1.8.24.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.24.3	1.3.111.2.802.1.1.13.1.2.7.1.8.24.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.25.1	1.3.111.2.802.1.1.13.1.2.7.1.8.25.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.25.2	1.3.111.2.802.1.1.13.1.2.7.1.8.25.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.25.3	1.3.111.2.802.1.1.13.1.2.7.1.8.25.3	Gauge	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortAgeoutsTotal.26.1	1.3.111.2.802.1.1.13.1.2.7.1.8.26.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.26.2	1.3.111.2.802.1.1.13.1.2.7.1.8.26.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.26.3	1.3.111.2.802.1.1.13.1.2.7.1.8.26.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.27.1	1.3.111.2.802.1.1.13.1.2.7.1.8.27.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.27.2	1.3.111.2.802.1.1.13.1.2.7.1.8.27.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.27.3	1.3.111.2.802.1.1.13.1.2.7.1.8.27.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.28.1	1.3.111.2.802.1.1.13.1.2.7.1.8.28.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.28.2	1.3.111.2.802.1.1.13.1.2.7.1.8.28.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.28.3	1.3.111.2.802.1.1.13.1.2.7.1.8.28.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.29.1	1.3.111.2.802.1.1.13.1.2.7.1.8.29.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.29.2	1.3.111.2.802.1.1.13.1.2.7.1.8.29.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.29.3	1.3.111.2.802.1.1.13.1.2.7.1.8.29.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.30.1	1.3.111.2.802.1.1.13.1.2.7.1.8.30.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.30.2	1.3.111.2.802.1.1.13.1.2.7.1.8.30.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.30.3	1.3.111.2.802.1.1.13.1.2.7.1.8.30.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.31.1	1.3.111.2.802.1.1.13.1.2.7.1.8.31.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.31.2	1.3.111.2.802.1.1.13.1.2.7.1.8.31.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.31.3	1.3.111.2.802.1.1.13.1.2.7.1.8.31.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.32.1	1.3.111.2.802.1.1.13.1.2.7.1.8.32.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.32.2	1.3.111.2.802.1.1.13.1.2.7.1.8.32.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.32.3	1.3.111.2.802.1.1.13.1.2.7.1.8.32.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.33.1	1.3.111.2.802.1.1.13.1.2.7.1.8.33.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.33.2	1.3.111.2.802.1.1.13.1.2.7.1.8.33.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.33.3	1.3.111.2.802.1.1.13.1.2.7.1.8.33.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.34.1	1.3.111.2.802.1.1.13.1.2.7.1.8.34.1	Gauge	0



Name	OID	Value Type	Value Example
IldpV2StatsRxPortAgeoutsTotal.34.2	1.3.111.2.802.1.1.13.1.2.7.1.8.34.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.34.3	1.3.111.2.802.1.1.13.1.2.7.1.8.34.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.35.1	1.3.111.2.802.1.1.13.1.2.7.1.8.35.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.35.2	1.3.111.2.802.1.1.13.1.2.7.1.8.35.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.35.3	1.3.111.2.802.1.1.13.1.2.7.1.8.35.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.36.1	1.3.111.2.802.1.1.13.1.2.7.1.8.36.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.36.2	1.3.111.2.802.1.1.13.1.2.7.1.8.36.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.36.3	1.3.111.2.802.1.1.13.1.2.7.1.8.36.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.37.1	1.3.111.2.802.1.1.13.1.2.7.1.8.37.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.37.2	1.3.111.2.802.1.1.13.1.2.7.1.8.37.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.37.3	1.3.111.2.802.1.1.13.1.2.7.1.8.37.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.38.1	1.3.111.2.802.1.1.13.1.2.7.1.8.38.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.38.2	1.3.111.2.802.1.1.13.1.2.7.1.8.38.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.38.3	1.3.111.2.802.1.1.13.1.2.7.1.8.38.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.39.1	1.3.111.2.802.1.1.13.1.2.7.1.8.39.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.39.2	1.3.111.2.802.1.1.13.1.2.7.1.8.39.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.39.3	1.3.111.2.802.1.1.13.1.2.7.1.8.39.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.40.1	1.3.111.2.802.1.1.13.1.2.7.1.8.40.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.40.2	1.3.111.2.802.1.1.13.1.2.7.1.8.40.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.40.3	1.3.111.2.802.1.1.13.1.2.7.1.8.40.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.41.1	1.3.111.2.802.1.1.13.1.2.7.1.8.41.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.41.2	1.3.111.2.802.1.1.13.1.2.7.1.8.41.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.41.3	1.3.111.2.802.1.1.13.1.2.7.1.8.41.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.42.1	1.3.111.2.802.1.1.13.1.2.7.1.8.42.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.42.2	1.3.111.2.802.1.1.13.1.2.7.1.8.42.2	Gauge	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortAgeoutsTotal.42.3	1.3.111.2.802.1.1.13.1.2.7.1.8.42.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.43.1	1.3.111.2.802.1.1.13.1.2.7.1.8.43.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.43.2	1.3.111.2.802.1.1.13.1.2.7.1.8.43.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.43.3	1.3.111.2.802.1.1.13.1.2.7.1.8.43.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.44.1	1.3.111.2.802.1.1.13.1.2.7.1.8.44.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.44.2	1.3.111.2.802.1.1.13.1.2.7.1.8.44.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.44.3	1.3.111.2.802.1.1.13.1.2.7.1.8.44.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.45.1	1.3.111.2.802.1.1.13.1.2.7.1.8.45.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.45.2	1.3.111.2.802.1.1.13.1.2.7.1.8.45.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.45.3	1.3.111.2.802.1.1.13.1.2.7.1.8.45.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.46.1	1.3.111.2.802.1.1.13.1.2.7.1.8.46.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.46.2	1.3.111.2.802.1.1.13.1.2.7.1.8.46.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.46.3	1.3.111.2.802.1.1.13.1.2.7.1.8.46.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.47.1	1.3.111.2.802.1.1.13.1.2.7.1.8.47.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.47.2	1.3.111.2.802.1.1.13.1.2.7.1.8.47.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.47.3	1.3.111.2.802.1.1.13.1.2.7.1.8.47.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.48.1	1.3.111.2.802.1.1.13.1.2.7.1.8.48.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.48.2	1.3.111.2.802.1.1.13.1.2.7.1.8.48.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.48.3	1.3.111.2.802.1.1.13.1.2.7.1.8.48.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.49.1	1.3.111.2.802.1.1.13.1.2.7.1.8.49.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.49.2	1.3.111.2.802.1.1.13.1.2.7.1.8.49.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.49.3	1.3.111.2.802.1.1.13.1.2.7.1.8.49.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.50.1	1.3.111.2.802.1.1.13.1.2.7.1.8.50.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.50.2	1.3.111.2.802.1.1.13.1.2.7.1.8.50.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.50.3	1.3.111.2.802.1.1.13.1.2.7.1.8.50.3	Gauge	0

Name	OID	Value Type	Value Example
IldpV2StatsRxPortAgeoutsTotal.51.1	1.3.111.2.802.1.1.13.1.2.7.1.8.51.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.51.2	1.3.111.2.802.1.1.13.1.2.7.1.8.51.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.51.3	1.3.111.2.802.1.1.13.1.2.7.1.8.51.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.52.1	1.3.111.2.802.1.1.13.1.2.7.1.8.52.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.52.2	1.3.111.2.802.1.1.13.1.2.7.1.8.52.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.52.3	1.3.111.2.802.1.1.13.1.2.7.1.8.52.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.53.1	1.3.111.2.802.1.1.13.1.2.7.1.8.53.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.53.2	1.3.111.2.802.1.1.13.1.2.7.1.8.53.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.53.3	1.3.111.2.802.1.1.13.1.2.7.1.8.53.3	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.54.1	1.3.111.2.802.1.1.13.1.2.7.1.8.54.1	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.54.2	1.3.111.2.802.1.1.13.1.2.7.1.8.54.2	Gauge	0
IldpV2StatsRxPortAgeoutsTotal.54.3	1.3.111.2.802.1.1.13.1.2.7.1.8.54.3	Gauge	0
IldpV2LocChassisIdSubtype.0	.1.3.111.2.802.1.1.13.1.3.1.0	Integer	macAddress (4)
IldpV2LocChassisId.0	.1.3.111.2.802.1.1.13.1.3.2.0	OctetString	14-84-77-95-1D-B0
IldpV2LocSysName.0	.1.3.111.2.802.1.1.13.1.3.3.0	OctetString	SC 3570-48GP-6X
IldpV2LocSysDesc.0	.1.3.111.2.802.1.1.13.1.3.4.0	OctetString	INTELBRAS Platform Software, Software Version 7.1.070, Release 1124 INTELBRAS SC 3570-48GP-6X Copyright (C) 2023 Intelbras S.A. All rights reserved.
IldpV2LocSysCapSupported.0	.1.3.111.2.802.1.1.13.1.3.5.0	OctetString	{bridge, router, cVLANComponent, sVLANComponent}
IldpV2LocSysCapEnabled.0	.1.3.111.2.802.1.1.13.1.3.6.0	OctetString	{bridge, router, cVLANComponent}
IldpV2LocPortIdSubtype.1	.1.3.111.2.802.1.1.13.1.3.7.1.2.1	Integer	interfaceName (5)
IldpV2LocPortId.1	.1.3.111.2.802.1.1.13.1.3.7.1.3.1	OctetString	GigabitEthernet1/0/1
IldpV2LocPortDesc.1	.1.3.111.2.802.1.1.13.1.3.7.1.4.1	OctetString	UPLINK
IldpV2LocManAddrLen.1.4.10.100.65.116	.1.3.111.2.802.1.1.13.1.3.8.1.3.1.4.10.100.65.116	Gauge	4
IldpV2LocManAddrIfSubtype.1.4.10.100.65.116	.1.3.111.2.802.1.1.13.1.3.8.1.4.1.4.10.100.65.116	Integer	ifIndex (2)
IldpV2LocManAddrIfId.1.4.10.100.65.116	.1.3.111.2.802.1.1.13.1.3.8.1.5.1.4.10.100.65.116	Gauge	634
IldpV2LocManAddrOID.1.4.10.100.65.116	.1.3.111.2.802.1.1.13.1.3.8.1.6.1.4.10.100.65.116	OID	.0.0
IldpV2RemChassisIdSubtype.139537.1.1.1	.1.3.111.2.802.1.1.13.1.4.1.1.5.139537.1.1.1	Integer	macAddress (4)

Name	OID	Value Type	Value Example
IldpV2RemChassisId.139537.1.1.1	.1.3.111.2.802.1.1.13.1.4.1.1.6.139537.1.1.1	OctetString	14-84-77-83-B1-20
IldpV2RemPortId-Subtype.139537.1.1.1	.1.3.111.2.802.1.1.13.1.4.1.1.7.139537.1.1.1	Integer	interfaceName (5)
IldpV2RemPortId.139537.1.1.1.3	.1.3.111.2.802.1.1.13.1.4.1.1.8.139537.1.1.1	OctetString	GigabitEthernet1/0/2
IldpV2RemPort-Desc.139537.1.1.1	.1.3.111.2.802.1.1.13.1.4.1.1.9.139537.1.1.1	OctetString	GigabitEthernet1/0/2 Interface
IldpV2RemSys-Name.139537.1.1.1	.1.3.111.2.802.1.1.13.1.4.1.1.10.139537.1.1.1	OctetString	H3C S5570S-28S-HPWR-EI-A
IldpV2RemSys-Desc.139537.1.1.1	.1.3.111.2.802.1.1.13.1.4.1.1.11.139537.1.1.1	OctetString	H3C Comware Platform Software, Software Version 7.1.070, Release 1115 H3C S5570S-28S-HPWR-EI-A Copyright (c) 2004-2022 New H3C Technologies Co., Ltd. All rights reserved.
IldpV2RemSysCapSupported.139537.1.1.1	.1.3.111.2.802.1.1.13.1.4.1.1.12.139537.1.1.1	OctetString	{bridge, router, cVLANComponent, sVLANComponent}
IldpV2RemSysCapEnabled.139537.1.1.1	.1.3.111.2.802.1.1.13.1.4.1.1.13.139537.1.1.1	OctetString	{bridge, router, cVLANComponent}
IldpV2RemRemoteChanges.139537.1.1.1	.1.3.111.2.802.1.1.13.1.4.1.1.14.139537.1.1.1	Integer	false (2)
IldpV2RemTooManyNeighbors.139537.1.1.1	.1.3.111.2.802.1.1.13.1.4.1.1.15.139537.1.1.1	Integer	false (2)
IldpV2RemManAddrSubtype.139537.1.1.1.3	.1.3.111.2.802.1.1.13.1.4.1.1.16.139537.1.1.1	Integer	ifIndex (2)
IldpV2RemManAddrId.139537.1.1.1.3	.1.3.111.2.802.1.1.13.1.4.1.1.17.139537.1.1.1	Integer	65.67
IldpV2RemManAddrID.139537.1.1.1.3	.1.3.111.2.802.1.1.13.1.4.1.1.18.139537.1.1.1	Integer	634
IldpV2RemManAddrID.139537.1.1.1.3	.1.3.111.2.802.1.1.13.1.4.1.1.19.139537.1.1.1	Integer	.0.0
IldpV2Xdot3PortConfigTLVsT:1.1	.1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.1	OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT:2.1	.1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.2	OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT:3.1	.1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.3	OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT:4.1	.1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.4	OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT:5.1	.1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.5	OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT:6.1	.1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.6	OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT:7.1	.1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.7	OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT:8.1	.1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.8	OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT:9.1	.1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.9	OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT:10.1	.1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.10	OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT:11.1	.1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.11	OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT:12.1	.1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.12	OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}



Name	OID	Value Type	Value Example
IldpV2Xdot3PortConfigTLVsT1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.1.38.1		OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.1.39.1		OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.1.40.1		OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.1.41.1		OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.1.42.1		OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.1.43.1		OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.1.44.1		OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.1.45.1		OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.1.46.1		OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.1.47.1		OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.1.48.1		OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.1.49.1		OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.1.50.1		OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.1.51.1		OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.1.52.1		OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.1.53.1		OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3PortConfigTLVsT1.3.111.2.802.1.1.13.1.5.4623.1.1.1.1.1.54.1		OctetString	{macPhyConfigStatus, powerViaMDI, maxFrameSize}
IldpV2Xdot3LocPortAutoNegSupported.1.3.111.2.802.1.1.13.1.5.4623.1.2.1.1.1		Integer	true (1)
IldpV2Xdot3LocPortAutoNegEnabled.1.3.111.2.802.1.1.13.1.5.4623.1.2.1.1.2		Integer	true (1)
IldpV2Xdot3LocPortAutoNegAdvertisedCap.1.3.111.2.802.1.1.13.1.5.4623.1.2.1.1.3		OctetString	l
IldpV2Xdot3LocPortOperMauType.1.3.111.2.802.1.1.13.1.5.4623.1.2.1.1.4		Gauge	30
IldpV2Xdot3LocPowerPortClass.1.3.111.2.802.1.1.13.1.5.4623.1.2.2.1.1		Integer	pClassPSE (1)
IldpV2Xdot3LocPowerMDISupported.1.3.111.2.802.1.1.13.1.5.4623.1.2.2.1.2		Integer	true (1)
IldpV2Xdot3LocPowerMDIEnabled.1.3.111.2.802.1.1.13.1.5.4623.1.2.2.1.3		Integer	true (1)
IldpV2Xdot3LocPowerPairControllable.1.3.111.2.802.1.1.13.1.5.4623.1.2.2.1.4		Integer	false (2)
IldpV2Xdot3LocPowerPairs.1.3.111.2.802.1.1.13.1.5.4623.1.2.2.1.5		Gauge	1

Name	OID	Value Type	Value Example
IldpV2Xdot3LocPowerClass.1.1.3.111.2.802.1.1.13.1.5.4623.1.2.2.1.6		Gauge	1
IldpV2Xdot3LocMaxFrameSize.1.1.3.111.2.802.1.1.13.1.5.4623.1.2.3.1.1		Gauge	12288
IldpV2Xdot3RemPortAutoNegSupported.139537.1.1.1	1.2.802.1.1.13.1.5.4623.1.3.1.1.1.139537.1.1.1	Boolean	true (1)
IldpV2Xdot3RemPortAutoNegEnabled.139537.1.1.1	1.2.802.1.1.13.1.5.4623.1.3.1.1.2.139537.1.1.1	Boolean	true (1)
IldpV2Xdot3RemPortAutoNegAdvertisedCap.139537.1.1.1	1.2.802.1.1.13.1.5.4623.1.3.1.1.3.139537.1.1.1	OctetString	0x00 00
IldpV2Xdot3RemPortOperMauType.139537.1.1.1	3.111.2.802.1.1.13.1.5.4623.1.3.1.1.4.139537.1.1.1	Gauge	30
IldpV2Xdot3RemPowerPSEClass.139537.1.1.1	1.111.2.802.1.1.13.1.5.4623.1.3.2.1.1.139537.1.1.1	Boolean	pClassPSE (1)
IldpV2Xdot3RemPowerMDESupported.139537.1.1.1	1.111.2.802.1.1.13.1.5.4623.1.3.2.1.2.139537.1.1.1	Boolean	true (1)
IldpV2Xdot3RemPowerMDEEnabled.139537.1.1.1	1.111.2.802.1.1.13.1.5.4623.1.3.2.1.3.139537.1.1.1	Boolean	true (1)
IldpV2Xdot3RemPowerPairControlable.139537.1.1.1	1.111.2.802.1.1.13.1.5.4623.1.3.2.1.4.139537.1.1.1	Boolean	false (2)
IldpV2Xdot3RemPowerPairs.139537.1.1.1	1.111.2.802.1.1.13.1.5.4623.1.3.2.1.5.139537.1.1.1	Gauge	1
IldpV2Xdot3RemPowerClass.139537.1.1.1	1.111.2.802.1.1.13.1.5.4623.1.3.2.1.6.139537.1.1.1	Gauge	1
IldpV2Xdot3RemMaxFrameSize.139537.1.1.1	1.111.2.802.1.1.13.1.5.4623.1.3.3.1.1.139537.1.1.1	Gauge	12288
IldpV2Xdot1ConfigPortVlanTxEnable.1.1	1.111.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.1.2	1.111.2.802.1.1.13.1.5.32962.1.1.1.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.1.3	1.111.2.802.1.1.13.1.5.32962.1.1.1.1.1.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.2.1	1.111.2.802.1.1.13.1.5.32962.1.1.1.1.1.4	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.2.2	1.111.2.802.1.1.13.1.5.32962.1.1.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.2.3	1.111.2.802.1.1.13.1.5.32962.1.1.1.1.1.6	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.3.1	1.111.2.802.1.1.13.1.5.32962.1.1.1.1.1.7	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.3.2	1.111.2.802.1.1.13.1.5.32962.1.1.1.1.1.8	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.3.3	1.111.2.802.1.1.13.1.5.32962.1.1.1.1.1.9	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.4.1	1.111.2.802.1.1.13.1.5.32962.1.1.1.1.1.10	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.4.2	1.111.2.802.1.1.13.1.5.32962.1.1.1.1.1.11	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.4.3	1.111.2.802.1.1.13.1.5.32962.1.1.1.1.1.12	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.5.1	1.111.2.802.1.1.13.1.5.32962.1.1.1.1.1.13	Integer	true (1)



<b>Name</b>	<b>OID</b>	<b>Value Type</b>	<b>Value Example</b>
IldpV2Xdot1ConfigPortVlanTxEnable.5.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.5.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.6.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.6.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.6.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.7.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.7.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.7.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.8.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.8.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.8.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.9.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.9.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.9.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.10.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.10.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.10.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.11.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.11.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.11.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.12.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.12.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.12.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.13.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.13.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigPortVlanTxEnable.13.3	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.13.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.14.1	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.14.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.14.2	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.14.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.14.3	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.14.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.15.1	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.15.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.15.2	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.15.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.15.3	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.15.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.16.1	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.16.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.16.2	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.16.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.16.3	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.16.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.17.1	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.17.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.17.2	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.17.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.17.3	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.17.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.18.1	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.18.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.18.2	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.18.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.18.3	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.18.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.19.1	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.19.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.19.2	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.19.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.19.3	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.19.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.20.1	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.20.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.20.2	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.20.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.20.3	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.20.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.21.1	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.21.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.21.2	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.21.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.21.3	1.2.802.1.1.13.1.5.32962.1.1.1.1.1.21.3	Integer	true (1)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigPortVlanTxEnable.22.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.22	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.22.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.22	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.22.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.22	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.23.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.23	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.23.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.23	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.23.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.23	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.24.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.24	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.24.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.24	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.24.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.24	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.25.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.25	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.25.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.25	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.25.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.25	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.26.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.26	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.26.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.26	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.26.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.26	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.27.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.27	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.27.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.27	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.27.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.27	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.28.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.28	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.28.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.28	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.28.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.28	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.29.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.29	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.29.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.29	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.29.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.29	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.30.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.30	Integer	true (1)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigPortVlanTxEnable.30.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.30.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.30.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.30.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.31.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.31.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.31.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.31.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.31.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.31.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.32.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.32.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.32.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.32.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.32.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.32.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.33.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.33.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.33.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.33.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.33.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.33.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.34.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.34.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.34.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.34.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.34.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.34.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.35.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.35.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.35.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.35.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.35.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.35.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.36.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.36.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.36.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.36.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.36.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.36.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.37.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.37.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.37.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.37.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.37.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.37.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.38.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.38.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.38.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.38.2	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigPortVlanTxEnable.38.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.38.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.39.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.39.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.39.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.39.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.39.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.39.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.40.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.40.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.40.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.40.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.40.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.40.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.41.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.41.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.41.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.41.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.41.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.41.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.42.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.42.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.42.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.42.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.42.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.42.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.43.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.43.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.43.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.43.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.43.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.43.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.44.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.44.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.44.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.44.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.44.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.44.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.45.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.45.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.45.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.45.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.45.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.45.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.46.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.46.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.46.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.46.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.46.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.46.3	Integer	true (1)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigPortVlanTxEnable.47.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.47.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.47.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.47.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.47.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.47.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.48.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.48.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.48.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.48.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.48.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.48.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.49.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.49.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.49.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.49.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.49.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.49.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.50.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.50.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.50.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.50.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.50.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.50.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.51.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.51.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.51.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.51.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.51.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.51.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.52.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.52.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.52.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.52.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.52.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.52.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.53.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.53.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.53.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.53.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.53.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.53.3	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.54.1	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.54.1	Integer	true (1)
IldpV2Xdot1ConfigPortVlanTxEnable.54.2	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.54.2	Integer	false (2)
IldpV2Xdot1ConfigPortVlanTxEnable.54.3	11.2.802.1.1.13.1.5.32962.1.1.1.1.1.54.3	Integer	true (1)
IldpV2Xdot1ConfigVlanNameTxEnable.1.0	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.0	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.1.1	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.2	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.3	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.4	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.5	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.6	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.7	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.8	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.9	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.10	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.11	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.12	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.13	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.14	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.15	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.16	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.17	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.18	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.19	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.20	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.21	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.22	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.23	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.24	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.25	11.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameXEnable.1.26	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.26	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.27	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.27	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.28	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.28	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.29	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.29	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.30	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.30	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.31	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.31	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.32	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.32	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.33	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.33	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.34	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.34	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.35	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.35	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.36	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.36	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.37	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.38	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.38	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.39	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.39	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.40	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.40	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.41	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.41	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.42	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.42	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.43	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.43	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.44	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.44	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.45	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.45	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.46	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.46	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.47	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.47	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.48	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.48	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.49	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.49	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.1.50	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.50	Integer	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameXEnable.1.51	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.52	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.53	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.3	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.54	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.4	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.55	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.5	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.56	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.6	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.57	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.7	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.58	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.8	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.59	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.9	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.60	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.10	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.61	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.11	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.62	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.12	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.63	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.13	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.64	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.14	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.65	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.66	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.67	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.68	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.18	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.69	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.19	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.70	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.20	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.71	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.21	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.72	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.22	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.73	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.23	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.74	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.24	Integer	false (2)
lldpV2Xdot1ConfigVlanNameXEnable.1.75	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.25	Integer	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.76	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.76	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.77	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.77	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.78	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.78	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.79	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.79	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.80	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.80	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.81	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.81	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.82	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.82	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.83	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.83	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.84	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.84	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.85	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.85	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.86	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.86	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.87	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.87	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.88	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.88	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.89	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.89	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.90	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.90	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.91	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.91	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.92	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.92	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.93	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.93	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.94	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.94	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.95	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.95	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.96	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.96	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.97	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.97	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.98	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.98	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.99	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.99	Integer	false (2)
lldpV2Xdot1ConfigVlanNameDot1xEnable.1.100	1.1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.100	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.101	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.102	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.103	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.104	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.105	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.106	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.107	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.108	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.109	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.110	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.111	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.112	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.113	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.114	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.115	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.116	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.117	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.118	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.119	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.120	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.121	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.122	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.123	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.124	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.125	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.126	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.127	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.128	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.129	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.130	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.131	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.132	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.133	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.134	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.135	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.136	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.137	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.138	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.139	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.140	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.141	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.142	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.143	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.144	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.145	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.146	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.147	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.148	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.149	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.150	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.151	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.152	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.153	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.154	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.155	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.156	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.157	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.158	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.159	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.160	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.161	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.162	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.163	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.164	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.165	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.166	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.167	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.168	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.169	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.170	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.171	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.172	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.173	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.174	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.175	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.176	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.176	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.177	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.177	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.178	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.178	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.179	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.179	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.180	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.180	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.181	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.181	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.182	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.182	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.183	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.183	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.184	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.184	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.185	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.185	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.186	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.186	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.187	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.187	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.188	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.188	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.189	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.189	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.190	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.190	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.191	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.191	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.192	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.192	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.193	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.193	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.194	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.194	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.195	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.195	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.196	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.196	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.197	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.197	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.198	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.198	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.199	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.199	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.200	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.200	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.201	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1201	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.202	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1202	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.203	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1203	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.204	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1204	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.205	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1205	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.206	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1206	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.207	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1207	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.208	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1208	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.209	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.210	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1210	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.211	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1211	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.212	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1212	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.213	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1213	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.214	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1214	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.215	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1215	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.216	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1216	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.217	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1217	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.218	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1218	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.219	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1219	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.220	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1220	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.221	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1221	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.222	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1222	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.223	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1223	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.224	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1224	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.225	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1225	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.226	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1226	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.227	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1227	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.228	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1228	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.229	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1229	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.230	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1230	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.231	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1231	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.232	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1232	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.233	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1233	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.234	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1234	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.235	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1235	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.236	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1236	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.237	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1237	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.238	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1238	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.239	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1239	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.240	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1240	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.241	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1241	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.242	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1242	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.243	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1243	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.244	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1244	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.245	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1245	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.246	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1246	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.247	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1247	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.248	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1248	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.249	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1249	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.250	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1250	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.251	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1261	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.252	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1262	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.253	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1263	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.254	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1264	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.255	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1265	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.256	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1266	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.257	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1267	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.258	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1268	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.259	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1269	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.260	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1270	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.261	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1271	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.262	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1272	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.263	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1273	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.264	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1274	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.265	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1275	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.266	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1276	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.267	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1277	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.268	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1278	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.269	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1279	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.270	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1280	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.271	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1281	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.272	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1282	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.273	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1283	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.274	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1284	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.275	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1285	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.276	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.276	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.277	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.277	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.278	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.278	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.279	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.279	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.280	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.280	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.281	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.281	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.282	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.282	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.283	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.283	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.284	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.284	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.285	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.285	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.286	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.286	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.287	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.287	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.288	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.288	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.289	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.289	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.290	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.290	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.291	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.291	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.292	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.292	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.293	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.293	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.294	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.294	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.295	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.295	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.296	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.296	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.297	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.297	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.298	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.298	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.299	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.299	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.300	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.300	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.301	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1301	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.302	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1302	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.303	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1303	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.304	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1304	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.305	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1305	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.306	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1306	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.307	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1307	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.308	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1308	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.309	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1309	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.310	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1310	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.311	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1311	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.312	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1312	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.313	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1313	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.314	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1314	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.315	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1315	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.316	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1316	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.317	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1317	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.318	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1318	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.319	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1319	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.320	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1320	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.321	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1321	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.322	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1322	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.323	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1323	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.324	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1324	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.325	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1325	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.326	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1326	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.327	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1327	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.328	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1328	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.329	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1329	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.330	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1330	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.331	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1331	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.332	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1332	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.333	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1333	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.334	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1334	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.335	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1335	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.336	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1336	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.337	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1337	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.338	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1338	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.339	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1339	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.340	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1340	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.341	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1341	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.342	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1342	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.343	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1343	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.344	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1344	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.345	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1345	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.346	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1346	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.347	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1347	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.348	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1348	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.349	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1349	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.350	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1350	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.351	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1361	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.352	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1362	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.353	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1363	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.354	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1364	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.355	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1365	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.356	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1366	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.357	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1367	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.358	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1368	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.359	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1369	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.360	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1370	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.361	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1371	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.362	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1372	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.363	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1373	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.364	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1374	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.365	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1375	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.366	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1376	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.367	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1377	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.368	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1378	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.369	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1379	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.370	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1380	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.371	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1381	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.372	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1382	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.373	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1383	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.374	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1384	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.375	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1385	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.376	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1376	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.377	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1377	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.378	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1378	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.379	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1379	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.380	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1380	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.381	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1381	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.382	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1382	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.383	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1383	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.384	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1384	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.385	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1385	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.386	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1386	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.387	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1387	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.388	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1388	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.389	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1389	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.390	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1390	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.391	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1391	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.392	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1392	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.393	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1393	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.394	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1394	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.395	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1395	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.396	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1396	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.397	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1397	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.398	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1398	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.399	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1399	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.400	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1400	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.401	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1401	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.402	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1402	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.403	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1403	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.404	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1404	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.405	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1405	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.406	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1406	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.407	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1407	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.408	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1408	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.409	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1409	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.410	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1410	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.411	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1411	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.412	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1412	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.413	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1413	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.414	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1414	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.415	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1415	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.416	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1416	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.417	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1417	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.418	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1418	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.419	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1419	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.420	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1420	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.421	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1421	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.422	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1422	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.423	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1423	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.424	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1424	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.425	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1425	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.426	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.426	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.427	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.427	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.428	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.428	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.429	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.429	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.430	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.430	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.431	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.431	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.432	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.432	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.433	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.433	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.434	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.434	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.435	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.435	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.436	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.436	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.437	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.437	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.438	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.438	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.439	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.439	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.440	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.440	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.441	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.441	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.442	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.442	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.443	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.443	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.444	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.444	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.445	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.445	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.446	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.446	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.447	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.447	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.448	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.448	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.449	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.449	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.450	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.450	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.451	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.451	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.452	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.452	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.453	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.453	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.454	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.454	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.455	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.455	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.456	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.456	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.457	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.457	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.458	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.458	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.459	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.459	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.460	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.460	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.461	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.461	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.462	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.462	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.463	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.463	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.464	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.464	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.465	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.465	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.466	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.466	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.467	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.467	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.468	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.468	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.469	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.469	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.470	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.470	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.471	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.471	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.472	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.472	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.473	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.473	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.474	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.474	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.475	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.475	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.476	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.476	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.477	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.477	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.478	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.478	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.479	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.479	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.480	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.480	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.481	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.481	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.482	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.482	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.483	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.483	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.484	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.484	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.485	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.485	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.486	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.486	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.487	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.487	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.488	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.488	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.489	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.489	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.490	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.490	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.491	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.491	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.492	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.492	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.493	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.493	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.494	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.494	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.495	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.495	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.496	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.496	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.497	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.497	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.498	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.498	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.499	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.499	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.500	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.500	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.501	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1501	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.502	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1502	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.503	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1503	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.504	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1504	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.505	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1505	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.506	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1506	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.507	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1507	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.508	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1508	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.509	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1509	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.510	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.511	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1511	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.512	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1512	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.513	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1513	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.514	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1514	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.515	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1515	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.516	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1516	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.517	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1517	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.518	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1518	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.519	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1519	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.520	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1520	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.521	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1521	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.522	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1522	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.523	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1523	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.524	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1524	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.525	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1525	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.526	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1526	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.527	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1527	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.528	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1528	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.529	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1529	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.530	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1530	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.531	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1531	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.532	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1532	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.533	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1533	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.534	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1534	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.535	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1535	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.536	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1536	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.537	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1537	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.538	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1538	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.539	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1539	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.540	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1540	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.541	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1541	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.542	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1542	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.543	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1543	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.544	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1544	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.545	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1545	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.546	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1546	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.547	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1547	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.548	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1548	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.549	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1549	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.550	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1550	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.551	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.551	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.552	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.552	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.553	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.553	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.554	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.554	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.555	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.555	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.556	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.556	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.557	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.557	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.558	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.558	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.559	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.559	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.560	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.560	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.561	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.561	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.562	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.562	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.563	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.563	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.564	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.564	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.565	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.565	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.566	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.566	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.567	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.567	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.568	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.568	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.569	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.569	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.570	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.570	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.571	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.571	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.572	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.572	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.573	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.573	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.574	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.574	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.575	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.575	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.576	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.576	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.577	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.577	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.578	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.578	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.579	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.579	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.580	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.580	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.581	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.581	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.582	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.582	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.583	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.583	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.584	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.584	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.585	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.585	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.586	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.586	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.587	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.587	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.588	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.588	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.589	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.589	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.590	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.590	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.591	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.591	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.592	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.592	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.593	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.593	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.594	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.594	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.595	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.595	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.596	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.596	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.597	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.597	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.598	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.598	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.599	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.599	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.600	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.600	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.601	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1601	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.602	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1602	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.603	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1603	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.604	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1604	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.605	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1605	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.606	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1606	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.607	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1607	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.608	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1608	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.609	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1609	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.610	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1610	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.611	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1611	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.612	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1612	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.613	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1613	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.614	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1614	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.615	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1615	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.616	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1616	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.617	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1617	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.618	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1618	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.619	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1619	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.620	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1620	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.621	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1621	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.622	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1622	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.623	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1623	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.624	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1624	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.625	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1625	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.1.626	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1606	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.627	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1607	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.628	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1608	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.629	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1609	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.630	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1610	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.631	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1611	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.632	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1612	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.633	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1613	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.634	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1614	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.635	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1615	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.636	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1616	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.637	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1617	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.638	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1618	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.639	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1619	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.640	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1620	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.641	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1621	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.642	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1622	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.643	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1623	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.644	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1624	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.645	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1625	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.646	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1626	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.647	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1627	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.648	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1628	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.649	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1629	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.1.650	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1630	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.651	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.651	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.652	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.652	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.653	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.653	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.654	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.654	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.655	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.655	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.656	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.656	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.657	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.657	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.658	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.658	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.659	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.660	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.660	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.661	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.661	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.662	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.662	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.663	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.663	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.664	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.664	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.665	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.665	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.666	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.666	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.667	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.667	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.668	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.668	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.669	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.669	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.670	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.670	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.671	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.671	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.672	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.672	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.673	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.673	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.674	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.674	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.675	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.675	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.676	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.676	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.677	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.677	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.678	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.678	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.679	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.679	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.680	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.680	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.681	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.681	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.682	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.682	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.683	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.683	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.684	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.684	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.685	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.685	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.686	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.686	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.687	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.687	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.688	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.688	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.689	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.689	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.690	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.690	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.691	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.691	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.692	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.692	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.693	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.693	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.694	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.694	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.695	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.695	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.696	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.696	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.697	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.697	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.698	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.698	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.699	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.699	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.700	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.700	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.701	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.701	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.702	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.702	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.703	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.703	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.704	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.704	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.705	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.705	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.706	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.706	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.707	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.707	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.708	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.708	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.709	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.709	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.710	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.710	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.711	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.711	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.712	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.712	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.713	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.713	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.714	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.714	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.715	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.715	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.716	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.716	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.717	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.717	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.718	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.718	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.719	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.719	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.720	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.720	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.721	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.721	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.722	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.722	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.723	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.723	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.724	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.724	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.725	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.725	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.726	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.727	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.728	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.729	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.730	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.731	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.732	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.733	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.734	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.735	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.736	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.737	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.738	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.739	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.740	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.741	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.742	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.743	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.744	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.745	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.746	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.747	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.748	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.749	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.750	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.751	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.751	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.752	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.752	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.753	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.753	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.754	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.754	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.755	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.755	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.756	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.756	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.757	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.757	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.758	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.758	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.759	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.759	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.760	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.760	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.761	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.761	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.762	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.762	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.763	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.763	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.764	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.764	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.765	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.765	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.766	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.766	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.767	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.767	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.768	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.768	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.769	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.769	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.770	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.770	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.771	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.771	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.772	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.772	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.773	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.773	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.774	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.774	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.775	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.775	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.776	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.776	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.777	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.777	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.778	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.778	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.779	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.779	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.780	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.780	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.781	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.781	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.782	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.782	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.783	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.783	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.784	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.784	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.785	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.785	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.786	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.786	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.787	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.787	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.788	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.788	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.789	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.789	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.790	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.790	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.791	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.791	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.792	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.792	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.793	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.793	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.794	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.794	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.795	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.795	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.796	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.796	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.797	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.797	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.798	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.798	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.799	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.799	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.800	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.800	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.801	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.801	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.802	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.802	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.803	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.803	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.804	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.804	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.805	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.805	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.806	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.806	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.807	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.807	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.808	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.808	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.809	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.809	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.810	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.810	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.811	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.811	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.812	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.812	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.813	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.813	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.814	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.814	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.815	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.815	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.816	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.816	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.817	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.817	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.818	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.818	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.819	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.819	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.820	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.820	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.821	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.821	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.822	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.822	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.823	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.823	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.824	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.824	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.825	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.825	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.826	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1826	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.827	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1827	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.828	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1828	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.829	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1829	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.830	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1830	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.831	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1831	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.832	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1832	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.833	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1833	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.834	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1834	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.835	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1835	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.836	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1836	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.837	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1837	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.838	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1838	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.839	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1839	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.840	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1840	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.841	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1841	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.842	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1842	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.843	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1843	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.844	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1844	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.845	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1845	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.846	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1846	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.847	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1847	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.848	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1848	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.849	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1849	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.850	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1850	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.851	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.851	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.852	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.852	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.853	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.853	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.854	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.854	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.855	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.855	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.856	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.856	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.857	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.857	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.858	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.858	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.859	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.859	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.860	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.860	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.861	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.861	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.862	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.862	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.863	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.863	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.864	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.864	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.865	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.865	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.866	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.866	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.867	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.867	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.868	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.868	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.869	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.869	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.870	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.870	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.871	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.871	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.872	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.872	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.873	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.873	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.874	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.874	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.875	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.875	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.876	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.876	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.877	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.877	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.878	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.878	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.879	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.879	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.880	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.880	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.881	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.881	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.882	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.882	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.883	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.883	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.884	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.884	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.885	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.885	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.886	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.886	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.887	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.887	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.888	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.888	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.889	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.889	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.890	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.890	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.891	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.891	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.892	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.892	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.893	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.893	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.894	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.894	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.895	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.895	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.896	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.896	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.897	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.897	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.898	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.898	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.899	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.899	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.900	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.900	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.901	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.901	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.902	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.902	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.903	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.903	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.904	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.904	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.905	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.905	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.906	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.906	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.907	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.907	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.908	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.908	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.909	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.909	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.910	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.910	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.911	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.911	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.912	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.912	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.913	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.913	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.914	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.914	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.915	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.915	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.916	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.916	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.917	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.917	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.918	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.918	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.919	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.919	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.920	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.920	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.921	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.921	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.922	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.922	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.923	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.923	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.924	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.924	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.925	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.925	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.926	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1926	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.927	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1927	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.928	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1928	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.929	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1929	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.930	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1930	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.931	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1931	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.932	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1932	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.933	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1933	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.934	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1934	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.935	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1935	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.936	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1936	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.937	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1937	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.938	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1938	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.939	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1939	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.940	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1940	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.941	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1941	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.942	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1942	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.943	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1943	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.944	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1944	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.945	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1945	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.946	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1946	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.947	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1947	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.948	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1948	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.949	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1949	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.950	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1950	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.1.951	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.951	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.952	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.952	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.953	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.953	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.954	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.954	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.955	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.955	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.956	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.956	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.957	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.957	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.958	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.958	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.959	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.959	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.960	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.960	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.961	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.961	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.962	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.962	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.963	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.963	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.964	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.964	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.965	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.965	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.966	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.966	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.967	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.967	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.968	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.968	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.969	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.969	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.970	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.970	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.971	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.971	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.972	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.972	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.973	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.973	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.974	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.974	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.1.975	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.975	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.976	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.976	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.977	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.977	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.978	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.978	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.979	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.979	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.980	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.980	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.981	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.981	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.982	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.982	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.983	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.983	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.984	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.984	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.985	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.985	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.986	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.986	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.987	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.987	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.988	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.988	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.989	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.989	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.990	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.990	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.991	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.991	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.992	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.992	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.993	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.993	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.994	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.994	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.995	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.995	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.996	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.996	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.997	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.997	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.998	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.998	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.999	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.999	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1000	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1000	Integer	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.1001	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1001	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1002	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1002	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1003	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1003	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1004	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1004	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1005	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1005	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1006	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1006	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1007	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1007	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1008	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1008	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1009	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1009	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1010	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1010	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1011	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1011	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1012	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1012	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1013	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1013	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1014	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1014	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1015	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1015	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1016	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1016	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1017	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1017	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1018	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1018	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1019	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1019	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1020	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1020	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1021	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1021	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1022	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1022	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1023	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1023	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1024	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1024	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1025	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1025	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1026	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1026	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1027	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1027	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1028	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1028	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1029	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1029	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1030	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1030	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1031	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1031	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1032	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1032	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1033	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1033	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1034	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1034	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1035	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1035	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1036	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1036	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1037	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1037	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1038	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1038	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1039	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1039	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1040	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1040	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1041	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1041	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1042	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1042	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1043	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1043	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1044	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1044	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1045	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1045	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1046	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1046	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1047	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1047	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1048	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1048	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1049	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1049	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1050	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1050	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1051	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1051	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1052	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1052	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1053	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1053	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1054	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1054	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1055	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1055	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1056	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1056	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1057	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1057	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1058	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1058	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1059	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1059	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1060	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1060	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1061	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1061	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1062	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1062	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1063	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1063	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1064	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1064	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1065	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1065	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1066	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1066	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1067	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1067	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1068	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1068	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1069	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1069	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1070	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1070	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1071	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1071	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1072	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1072	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1073	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1073	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1074	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1074	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1075	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.1075	Boolean	false (2)



Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.1076	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1076	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1077	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1077	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1078	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1078	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1079	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1079	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1080	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1080	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1081	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1081	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1082	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1082	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1083	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1083	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1084	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1084	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1085	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1085	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1086	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1086	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1087	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1087	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1088	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1088	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1089	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1089	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1090	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1090	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1091	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1091	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1092	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1092	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1093	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1093	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1094	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1094	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1095	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1095	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1096	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1096	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1097	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1097	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1098	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1098	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1099	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1099	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1100	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1100	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1101	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1102	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1103	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1104	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1105	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1106	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1107	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1108	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1109	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1110	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1111	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1112	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1113	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1114	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1115	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1116	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1117	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1118	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1119	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1120	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1121	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1122	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1123	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1124	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1125	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.1126	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1127	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1128	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1129	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1130	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1131	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1132	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1133	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1134	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1135	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1136	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1137	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1138	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1139	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1140	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1141	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1142	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1143	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1144	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1145	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1146	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1147	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1148	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1149	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1150	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.1151	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1152	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1153	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1154	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1155	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1156	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1157	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1158	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1159	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1160	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1161	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1162	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1163	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1164	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1165	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1166	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1167	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1168	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1169	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1170	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1171	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1172	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1173	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1174	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1175	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.1176	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1177	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1178	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1179	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1180	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1181	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1182	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1183	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1184	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1185	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1186	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1187	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1188	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1189	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1190	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1191	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1192	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1193	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1194	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1195	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1196	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1197	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1198	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1199	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1200	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1201	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1201	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1202	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1202	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1203	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1203	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1204	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1204	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1205	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1205	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1206	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1206	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1207	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1207	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1208	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1208	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1209	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1210	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1210	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1211	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1211	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1212	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1212	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1213	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1213	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1214	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1214	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1215	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1215	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1216	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1216	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1217	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1217	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1218	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1218	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1219	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1219	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1220	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1220	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1221	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1221	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1222	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1222	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1223	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1223	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1224	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1224	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1225	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1225	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1226	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1226	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1227	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1227	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1228	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1228	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1229	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1229	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1230	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1230	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1231	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1231	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1232	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1232	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1233	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1233	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1234	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1234	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1235	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1235	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1236	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1236	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1237	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1237	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1238	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1238	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1239	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1239	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1240	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1240	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1241	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1241	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1242	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1242	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1243	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1243	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1244	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1244	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1245	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1245	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1246	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1246	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1247	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1247	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1248	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1248	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1249	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1249	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1250	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1250	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1251	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1251	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1252	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1252	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1253	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1253	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1254	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1254	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1255	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1255	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1256	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1256	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1257	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1257	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1258	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1258	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1259	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1259	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1260	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1260	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1261	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1261	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1262	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1262	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1263	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1263	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1264	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1264	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1265	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1265	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1266	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1266	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1267	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1267	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1268	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1268	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1269	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1269	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1270	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1270	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1271	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1271	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1272	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1272	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1273	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1273	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1274	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1274	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1275	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1275	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1276	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1276	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1277	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1277	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1278	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1278	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1279	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1279	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1280	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1280	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1281	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1281	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1282	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1282	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1283	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1283	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1284	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1284	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1285	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1285	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1286	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1286	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1287	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1287	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1288	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1288	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1289	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1289	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1290	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1290	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1291	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1291	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1292	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1292	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1293	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1293	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1294	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1294	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1295	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1295	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1296	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1296	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1297	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1297	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1298	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1298	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1299	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1299	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1300	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1300	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1301	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1302	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1303	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1304	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1305	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1306	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1307	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1308	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1309	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1310	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1311	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1312	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1313	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1314	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1315	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1316	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1317	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1318	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1319	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1320	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1321	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1322	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1323	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1324	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1325	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1326	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1326	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1327	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1327	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1328	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1328	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1329	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1329	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1330	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1330	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1331	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1331	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1332	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1332	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1333	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1333	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1334	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1334	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1335	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1335	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1336	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1336	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1337	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1337	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1338	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1338	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1339	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1339	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1340	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1340	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1341	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1341	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1342	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1342	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1343	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1343	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1344	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1344	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1345	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1345	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1346	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1346	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1347	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1347	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1348	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1348	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1349	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1349	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1350	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1350	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1351	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1351	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1352	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1352	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1353	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1353	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1354	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1354	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1355	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1355	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1356	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1356	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1357	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1357	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1358	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1358	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1359	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1359	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1360	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1360	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1361	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1361	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1362	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1362	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1363	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1363	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1364	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1364	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1365	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1365	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1366	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1366	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1367	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1367	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1368	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1368	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1369	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1369	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1370	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1370	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1371	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1371	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1372	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1372	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1373	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1373	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1374	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1374	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1375	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1375	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1376	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1376	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1377	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1377	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1378	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1378	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1379	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1379	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1380	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1380	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1381	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1381	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1382	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1382	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1383	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1383	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1384	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1384	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1385	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1385	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1386	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1386	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1387	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1387	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1388	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1388	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1389	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1389	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1390	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1390	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1391	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1391	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1392	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1392	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1393	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1393	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1394	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1394	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1395	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1395	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1396	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1396	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1397	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1397	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1398	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1398	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1399	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1399	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1400	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1400	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1401	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1402	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1403	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1404	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1405	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1406	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1407	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1408	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1409	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1410	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1411	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1412	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1413	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1414	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1415	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1416	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1417	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1418	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1419	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1420	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1421	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1422	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1423	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1424	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1425	2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1426	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1427	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1428	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1429	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1430	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1431	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1432	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1433	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1434	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1435	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1436	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1437	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1438	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1439	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1440	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1441	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1442	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1443	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1444	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1445	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1446	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1447	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1448	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1449	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1450	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1451	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1451	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1452	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1452	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1453	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1453	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1454	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1454	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1455	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1455	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1456	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1456	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1457	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1457	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1458	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1458	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1459	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1459	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1460	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1460	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1461	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1461	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1462	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1462	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1463	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1463	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1464	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1464	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1465	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1465	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1466	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1466	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1467	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1467	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1468	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1468	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1469	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1469	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1470	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1470	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1471	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1471	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1472	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1472	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1473	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1473	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1474	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1474	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1475	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1475	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1476	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1477	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1478	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1479	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1480	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1481	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1482	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1483	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1484	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1485	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1486	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1487	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1488	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1489	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1490	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1491	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1492	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1493	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1494	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1495	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1496	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1497	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1498	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1499	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1500	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.1501	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11501	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1502	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11502	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1503	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11503	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1504	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11504	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1505	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11505	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1506	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11506	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1507	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11507	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1508	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11508	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1509	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11509	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1510	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11510	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1511	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11511	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1512	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11512	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1513	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11513	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1514	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11514	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1515	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11515	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1516	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11516	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1517	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11517	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1518	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11518	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1519	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11519	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1520	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11520	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1521	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11521	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1522	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11522	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1523	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11523	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1524	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11524	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1525	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11525	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1526	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1526	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1527	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1527	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1528	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1528	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1529	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1529	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1530	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1530	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1531	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1531	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1532	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1532	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1533	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1533	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1534	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1534	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1535	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1535	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1536	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1536	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1537	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1537	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1538	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1538	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1539	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1539	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1540	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1540	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1541	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1541	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1542	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1542	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1543	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1543	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1544	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1544	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1545	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1545	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1546	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1546	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1547	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1547	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1548	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1548	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1549	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1549	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1550	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1550	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1551	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11551	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1552	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11552	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1553	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11553	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1554	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11554	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1555	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11555	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1556	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11556	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1557	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11557	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1558	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11558	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1559	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11559	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1560	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11560	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1561	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11561	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1562	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11562	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1563	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11563	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1564	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11564	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1565	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11565	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1566	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11566	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1567	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11567	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1568	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11568	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1569	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11569	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1570	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11570	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1571	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11571	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1572	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11572	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1573	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11573	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1574	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11574	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1575	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11575	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1576	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1576	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1577	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1577	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1578	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1578	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1579	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1579	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1580	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1580	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1581	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1581	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1582	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1582	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1583	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1583	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1584	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1584	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1585	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1585	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1586	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1586	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1587	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1587	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1588	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1588	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1589	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1589	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1590	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1590	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1591	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1591	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1592	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1592	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1593	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1593	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1594	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1594	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1595	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1595	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1596	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1596	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1597	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1597	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1598	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1598	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1599	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1599	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1600	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1600	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1601	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11601	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1602	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1603	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11603	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1604	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11604	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1605	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11605	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1606	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11606	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1607	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11607	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1608	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11608	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1609	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11609	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1610	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11610	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1611	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11611	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1612	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11612	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1613	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11613	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1614	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11614	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1615	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11615	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1616	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11616	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1617	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11617	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1618	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11618	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1619	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11619	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1620	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11620	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1621	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11621	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1622	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11622	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1623	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11623	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1624	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11624	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1625	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.11625	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1626	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1626	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1627	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1627	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1628	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1628	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1629	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1629	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1630	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1630	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1631	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1631	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1632	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1633	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1633	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1634	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1634	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1635	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1635	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1636	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1636	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1637	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1637	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1638	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1638	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1639	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1639	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1640	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1640	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1641	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1641	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1642	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1642	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1643	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1643	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1644	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1644	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1645	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1645	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1646	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1646	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1647	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1647	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1648	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1648	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1649	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1649	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1650	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1650	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1651	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1651	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1652	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1652	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1653	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1653	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1654	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1654	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1655	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1655	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1656	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1656	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1657	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1657	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1658	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1658	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1659	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1660	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1660	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1661	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1661	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1662	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1662	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1663	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1663	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1664	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1664	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1665	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1665	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1666	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1666	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1667	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1667	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1668	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1668	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1669	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1669	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1670	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1670	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1671	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1671	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1672	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1672	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1673	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1673	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1674	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1674	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1675	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1675	Boolean	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.1676	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1676	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1677	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1677	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1678	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1678	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1679	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1679	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1680	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1680	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1681	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1681	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1682	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1682	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1683	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1683	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1684	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1684	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1685	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1685	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1686	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1686	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1687	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1687	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1688	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1688	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1689	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1689	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1690	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1690	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1691	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1691	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1692	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1692	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1693	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1693	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1694	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1694	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1695	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1695	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1696	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1696	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1697	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1697	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1698	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1698	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1699	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1699	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1700	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1700	boolean	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.1701	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1702	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1703	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1704	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1705	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1706	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1707	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1708	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1709	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1710	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1711	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1712	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1713	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1714	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1715	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1716	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1717	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1718	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1719	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1720	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1721	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1722	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1723	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1724	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1725	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1726	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1727	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1728	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1729	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1730	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1731	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1732	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1733	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1734	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1735	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1736	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1737	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1738	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1739	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1740	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1741	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1742	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1743	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1744	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1745	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1746	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1747	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1748	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1749	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1750	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.1751	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1752	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1753	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1754	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1755	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1756	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1757	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1758	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1759	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1760	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1761	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1762	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1763	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1764	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1765	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1766	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1767	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1768	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1769	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1770	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1771	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1772	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1773	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1774	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1775	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)



Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.1776	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1777	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1778	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1779	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1780	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1781	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1782	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1783	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1784	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1785	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1786	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1787	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1788	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1789	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1790	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1791	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1792	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1793	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1794	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1795	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1796	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1797	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1798	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1799	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1800	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1801	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1801	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1802	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1802	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1803	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1803	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1804	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1804	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1805	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1805	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1806	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1806	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1807	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1807	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1808	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1808	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1809	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1809	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1810	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1810	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1811	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1811	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1812	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1812	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1813	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1813	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1814	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1814	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1815	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1815	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1816	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1816	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1817	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1817	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1818	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1818	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1819	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1819	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1820	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1820	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1821	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1821	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1822	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1822	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1823	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1823	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1824	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1824	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1825	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1825	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1826	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1826	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1827	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1827	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1828	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1828	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1829	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1829	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1830	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1830	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1831	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1831	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1832	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1832	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1833	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1833	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1834	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1834	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1835	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1835	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1836	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1836	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1837	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1837	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1838	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1838	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1839	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1839	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1840	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1840	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1841	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1841	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1842	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1842	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1843	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1843	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1844	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1844	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1845	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1845	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1846	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1846	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1847	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1847	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1848	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1848	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1849	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1849	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1850	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1850	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1851	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1851	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1852	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1852	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1853	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1853	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1854	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1854	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1855	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1855	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1856	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1856	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1857	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1857	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1858	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1858	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1859	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1859	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1860	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1860	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1861	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1861	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1862	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1862	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1863	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1863	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1864	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1864	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1865	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1865	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1866	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1866	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1867	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1867	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1868	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1868	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1869	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1869	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1870	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1870	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1871	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1871	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1872	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1872	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1873	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1873	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1874	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1874	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1875	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1875	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.1876	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1876	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1877	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1877	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1878	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1878	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1879	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1879	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1880	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1880	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1881	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1881	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1882	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1882	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1883	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1883	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1884	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1884	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1885	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1885	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1886	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1886	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1887	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1887	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1888	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1888	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1889	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1889	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1890	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1890	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1891	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1891	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1892	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1892	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1893	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1893	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1894	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1894	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1895	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1895	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1896	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1896	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1897	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1897	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1898	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1898	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1899	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1899	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.1900	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1900	Boolean	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.1901	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1901	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1902	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1902	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1903	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1903	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1904	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1904	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1905	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1905	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1906	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1906	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1907	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1907	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1908	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1908	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1909	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1909	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1910	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1910	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1911	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1911	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1912	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1912	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1913	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1913	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1914	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1914	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1915	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1915	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1916	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1916	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1917	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1917	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1918	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1918	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1919	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1919	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1920	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1920	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1921	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1921	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1922	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1922	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1923	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1923	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1924	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1924	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1925	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1925	boolean	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.1926	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1926	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1927	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1927	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1928	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1928	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1929	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1929	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1930	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1930	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1931	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1931	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1932	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1932	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1933	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1933	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1934	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1934	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1935	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1935	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1936	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1936	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1937	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1937	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1938	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1938	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1939	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1939	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1940	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1940	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1941	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1941	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1942	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1942	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1943	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1943	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1944	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1944	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1945	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1945	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1946	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1946	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1947	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1947	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1948	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1948	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1949	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1949	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1950	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1950	boolean	false (2)



Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.1951	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1951	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1952	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1952	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1953	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1953	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1954	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1954	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1955	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1955	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1956	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1956	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1957	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1957	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1958	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1958	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1959	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1959	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1960	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1960	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1961	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1961	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1962	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1962	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1963	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1963	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1964	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1964	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1965	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1965	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1966	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1966	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1967	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1967	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1968	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1968	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1969	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1969	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1970	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1970	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1971	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1971	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1972	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1972	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1973	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1973	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1974	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1974	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1975	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1975	Boolean	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.1976	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1976	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1977	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1977	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1978	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1978	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1979	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1979	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1980	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1980	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1981	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1981	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1982	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1982	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1983	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1983	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1984	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1984	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1985	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1985	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1986	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1986	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1987	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1987	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1988	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1988	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1989	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1989	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1990	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1990	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1991	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1991	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1992	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1992	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1993	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1993	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1994	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1994	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1995	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1995	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1996	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1996	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1997	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1997	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1998	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1998	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.1999	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1999	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2000	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2000	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2001	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2001	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2002	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2002	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2003	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2003	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2004	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2004	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2005	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2005	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2006	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2006	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2007	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2007	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2008	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2008	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2009	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2009	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2010	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2010	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2011	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2011	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2012	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2012	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2013	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2013	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2014	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2014	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2015	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2015	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2016	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2016	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2017	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2017	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2018	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2018	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2019	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2019	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2020	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2020	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2021	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2021	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2022	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2022	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2023	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2023	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2024	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2024	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2025	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2025	Boolean	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.2026	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2026	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2027	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2027	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2028	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2028	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2029	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2029	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2030	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2030	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2031	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2031	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2032	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2032	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2033	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2033	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2034	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2034	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2035	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2035	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2036	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2036	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2037	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2037	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2038	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2038	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2039	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2039	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2040	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2040	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2041	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2041	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2042	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2042	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2043	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2043	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2044	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2044	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2045	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2045	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2046	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2046	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2047	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2047	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2048	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2048	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2049	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2049	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2050	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2050	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2051	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2051	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2052	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2052	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2053	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2053	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2054	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2054	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2055	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2055	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2056	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2056	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2057	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2057	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2058	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2058	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2059	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2059	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2060	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2060	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2061	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2061	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2062	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2062	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2063	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2063	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2064	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2064	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2065	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2065	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2066	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2066	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2067	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2067	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2068	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2068	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2069	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2069	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2070	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2070	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2071	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2071	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2072	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2072	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2073	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2073	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2074	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2074	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2075	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2075	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2076	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2076	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2077	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2077	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2078	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2078	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2079	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2079	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2080	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2080	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2081	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2081	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2082	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2082	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2083	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2083	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2084	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2084	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2085	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2085	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2086	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2086	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2087	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2087	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2088	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2088	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2089	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2089	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2090	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2090	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2091	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2091	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2092	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2092	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2093	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2093	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2094	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2094	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2095	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2095	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2096	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2096	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2097	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2097	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2098	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2098	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2099	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2099	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2100	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2100	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2101	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2102	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2103	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2104	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2105	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2106	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2107	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2108	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2109	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2110	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2111	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2112	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2113	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2114	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2115	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2116	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2117	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2118	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2119	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2120	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2121	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2122	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2123	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2124	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2125	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2126	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2127	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2128	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2129	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2130	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2131	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2132	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2133	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2134	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2135	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2136	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2137	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2138	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2139	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2140	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2141	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2142	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2143	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2144	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2145	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2146	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2147	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2148	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2149	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2150	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2151	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2152	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2153	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2154	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2155	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2156	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2157	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2158	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2159	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2160	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2161	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2162	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2163	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2164	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2165	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2166	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2167	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2168	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2169	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2170	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2171	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2172	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2173	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2174	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2175	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.2176	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2177	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2178	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2179	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2180	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2181	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2182	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2183	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2184	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2185	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2186	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2187	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2188	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2189	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2190	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2191	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2192	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2193	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2194	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2195	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2196	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2197	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2198	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2199	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2200	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2226	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2226	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2227	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2227	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2228	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2228	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2229	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2229	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2230	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2230	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2231	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2231	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2232	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2232	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2233	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2233	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2234	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2234	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2235	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2235	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2236	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2236	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2237	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2237	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2238	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2238	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2239	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2239	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2240	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2240	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2241	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2241	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2242	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2242	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2243	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2243	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2244	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2244	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2245	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2245	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2246	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2246	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2247	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2247	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2248	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2248	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2249	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2249	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2250	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.2250	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2251	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2251	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2252	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2252	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2253	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2253	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2254	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2254	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2255	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2255	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2256	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2256	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2257	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2257	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2258	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2258	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2259	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2259	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2260	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2260	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2261	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2261	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2262	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2262	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2263	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2263	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2264	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2264	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2265	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2265	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2266	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2266	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2267	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2267	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2268	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2268	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2269	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2269	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2270	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2270	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2271	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2271	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2272	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2272	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2273	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2273	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2274	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2274	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2275	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2275	Integer	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.2276	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2276	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2277	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2277	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2278	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2278	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2279	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2279	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2280	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2280	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2281	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2281	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2282	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2282	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2283	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2283	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2284	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2284	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2285	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2285	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2286	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2286	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2287	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2287	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2288	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2288	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2289	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2289	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2290	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2290	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2291	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2291	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2292	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2292	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2293	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2293	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2294	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2294	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2295	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2295	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2296	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2296	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2297	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2297	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2298	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2298	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2299	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2299	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2300	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2300	boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2301	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2302	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2303	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2304	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2305	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2306	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2307	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2308	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2309	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2310	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2311	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2312	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2313	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2314	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2315	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2316	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2317	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2318	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2319	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2320	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2321	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2322	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2323	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2324	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2325	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2326	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2326	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2327	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2327	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2328	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2328	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2329	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2329	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2330	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2330	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2331	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2331	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2332	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2332	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2333	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2333	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2334	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2334	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2335	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2335	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2336	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2336	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2337	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2337	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2338	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2338	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2339	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2339	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2340	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2340	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2341	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2341	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2342	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2342	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2343	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2343	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2344	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2344	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2345	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2345	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2346	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2346	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2347	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2347	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2348	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2348	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2349	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2349	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2350	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2350	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2351	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2351	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2352	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2352	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2353	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2353	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2354	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2354	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2355	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2355	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2356	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2356	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2357	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2357	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2358	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2358	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2359	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2359	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2360	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2360	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2361	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2361	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2362	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2362	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2363	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2363	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2364	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2364	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2365	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2365	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2366	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2366	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2367	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2367	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2368	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2368	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2369	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2369	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2370	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2370	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2371	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2371	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2372	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2372	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2373	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2373	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2374	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2374	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2375	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2375	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2376	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2376	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2377	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2377	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2378	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2378	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2379	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2379	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2380	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2380	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2381	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2381	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2382	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2382	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2383	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2383	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2384	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2384	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2385	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2385	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2386	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2386	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2387	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2387	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2388	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2388	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2389	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2389	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2390	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2390	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2391	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2391	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2392	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2392	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2393	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2393	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2394	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2394	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2395	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2395	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2396	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2396	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2397	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2397	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2398	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2398	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2399	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2399	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2400	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2400	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2401	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2401	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2402	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2402	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2403	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2403	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2404	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2404	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2405	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2405	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2406	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2406	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2407	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2407	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2408	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2408	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2409	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2409	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2410	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2410	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2411	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2411	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2412	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2412	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2413	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2413	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2414	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2414	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2415	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2415	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2416	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2416	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2417	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2417	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2418	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2418	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2419	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2419	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2420	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2420	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2421	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2421	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2422	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2422	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2423	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2423	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2424	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2424	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2425	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2425	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2426	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2426	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2427	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2427	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2428	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2428	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2429	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2429	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2430	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2430	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2431	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2431	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2432	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2432	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2433	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2433	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2434	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2434	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2435	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2435	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2436	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2436	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2437	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2437	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2438	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2438	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2439	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2439	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2440	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2440	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2441	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2441	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2442	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2442	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2443	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2443	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2444	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2444	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2445	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2445	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2446	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2446	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2447	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2447	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2448	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2448	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2449	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2449	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2450	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2450	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2451	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2451	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2452	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2452	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2453	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2453	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2454	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2454	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2455	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2455	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2456	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2456	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2457	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2457	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2458	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2458	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2459	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2459	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2460	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2460	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2461	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2461	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2462	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2462	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2463	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2463	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2464	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2464	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2465	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2465	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2466	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2466	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2467	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2467	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2468	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2468	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2469	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2469	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2470	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2470	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2471	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2471	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2472	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2472	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2473	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2473	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2474	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2474	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2475	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2475	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2476	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2476	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2477	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2477	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2478	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2478	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2479	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2479	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2480	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2480	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2481	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2481	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2482	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2482	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2483	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2483	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2484	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2484	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2485	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2485	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2486	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2486	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2487	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2487	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2488	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2488	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2489	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2489	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2490	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2490	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2491	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2491	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2492	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2492	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2493	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2493	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2494	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2494	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2495	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2495	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2496	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2496	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2497	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2497	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2498	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2498	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2499	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2499	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2500	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2500	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2501	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2501	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2502	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2502	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2503	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2503	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2504	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2504	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2505	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2505	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2506	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2506	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2507	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2507	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2508	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2508	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2509	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2509	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2510	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2510	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2511	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2511	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2512	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2512	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2513	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2513	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2514	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2514	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2515	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2515	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2516	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2516	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2517	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2517	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2518	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2518	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2519	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2519	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2520	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2520	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2521	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2521	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2522	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2522	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2523	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2523	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2524	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2524	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2525	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2525	Boolean	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.2526	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2526	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2527	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2527	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2528	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2528	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2529	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2529	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2530	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2530	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2531	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2531	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2532	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2532	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2533	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2533	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2534	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2534	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2535	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2535	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2536	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2536	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2537	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2537	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2538	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2538	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2539	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2539	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2540	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2540	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2541	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2541	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2542	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2542	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2543	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2543	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2544	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2544	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2545	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2545	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2546	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2546	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2547	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2547	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2548	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2548	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2549	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2549	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2550	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2550	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2551	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2551	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2552	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2552	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2553	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2553	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2554	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2554	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2555	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2555	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2556	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2556	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2557	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2557	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2558	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2558	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2559	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2559	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2560	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2560	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2561	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2561	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2562	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2562	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2563	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2563	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2564	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2564	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2565	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2565	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2566	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2566	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2567	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2567	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2568	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2568	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2569	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2569	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2570	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2570	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2571	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2571	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2572	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2572	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2573	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2573	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2574	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2574	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2575	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2575	Boolean	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.2576	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2576	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2577	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2577	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2578	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2578	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2579	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2579	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2580	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2580	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2581	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2581	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2582	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2582	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2583	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2583	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2584	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2584	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2585	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2585	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2586	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2586	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2587	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2587	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2588	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2588	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2589	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2589	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2590	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2590	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2591	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2591	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2592	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2592	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2593	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2593	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2594	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2594	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2595	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2595	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2596	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2596	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2597	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2597	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2598	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2598	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2599	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2599	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.2600	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2600	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2601	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2601	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2602	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2602	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2603	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2603	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2604	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2604	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2605	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2605	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2606	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2606	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2607	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2607	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2608	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2608	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2609	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2609	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2610	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2610	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2611	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2611	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2612	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2612	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2613	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2613	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2614	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2614	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2615	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2615	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2616	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2616	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2617	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2617	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2618	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2618	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2619	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2619	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2620	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2620	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2621	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2621	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2622	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2622	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2623	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2623	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2624	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2624	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2625	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2625	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2626	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2626	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2627	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2627	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2628	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2628	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2629	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2629	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2630	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2630	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2631	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2631	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2632	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2633	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2633	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2634	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2634	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2635	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2635	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2636	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2636	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2637	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2637	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2638	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2638	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2639	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2639	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2640	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2640	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2641	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2641	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2642	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2642	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2643	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2643	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2644	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2644	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2645	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2645	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2646	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2646	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2647	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2647	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2648	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2648	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2649	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2649	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2650	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2650	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2651	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2651	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2652	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2652	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2653	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2653	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2654	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2654	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2655	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2655	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2656	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2656	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2657	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2657	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2658	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2658	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2659	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2660	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2660	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2661	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2661	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2662	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2662	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2663	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2663	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2664	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2664	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2665	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2665	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2666	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2666	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2667	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2667	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2668	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2668	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2669	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2669	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2670	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2670	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2671	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2671	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2672	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2672	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2673	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2673	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2674	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2674	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2675	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2675	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2676	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2676	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2677	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2677	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2678	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2678	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2679	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2679	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2680	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2680	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2681	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2681	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2682	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2682	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2683	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2683	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2684	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2684	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2685	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2685	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2686	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2686	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2687	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2687	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2688	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2688	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2689	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2689	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2690	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2690	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2691	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2691	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2692	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2692	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2693	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2693	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2694	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2694	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2695	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2695	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2696	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2696	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2697	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2697	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2698	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2698	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2699	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2699	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2700	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2700	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2701	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2702	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2703	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2704	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2705	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2706	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2707	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2708	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2709	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2710	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2711	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2712	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2713	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2714	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2715	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2716	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2717	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2718	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2719	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2720	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2721	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2722	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2723	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2724	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2725	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2726	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2727	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2728	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2729	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2730	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2731	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2732	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2733	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2734	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2735	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2736	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2737	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2738	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2739	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2740	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2741	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2742	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2743	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2744	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2745	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2746	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2747	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2748	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2749	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2750	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2751	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2751	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2752	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2752	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2753	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2753	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2754	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2754	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2755	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2755	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2756	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2756	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2757	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2757	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2758	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2758	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2759	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2759	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2760	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2760	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2761	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2761	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2762	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2762	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2763	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2763	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2764	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2764	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2765	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2765	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2766	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2766	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2767	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2767	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2768	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2768	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2769	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2769	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2770	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2770	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2771	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2771	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2772	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2772	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2773	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2773	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2774	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2774	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2775	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2775	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2776	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2777	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2778	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2779	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2780	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2781	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2782	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2783	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2784	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2785	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2786	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2787	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2788	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2789	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2790	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2791	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2792	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2793	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2794	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2795	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2796	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2797	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2798	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2799	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2800	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2801	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2801	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2802	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2802	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2803	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2803	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2804	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2804	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2805	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2805	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2806	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2806	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2807	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2807	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2808	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2808	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2809	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2809	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2810	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2810	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2811	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2811	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2812	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2812	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2813	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2813	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2814	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2814	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2815	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2815	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2816	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2816	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2817	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2817	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2818	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2818	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2819	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2819	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2820	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2820	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2821	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2821	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2822	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2822	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2823	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2823	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2824	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2824	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2825	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2825	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2826	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2826	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2827	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2827	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2828	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2828	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2829	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2829	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2830	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2830	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2831	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2831	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2832	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2832	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2833	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2833	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2834	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2834	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2835	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2835	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2836	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2836	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2837	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2837	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2838	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2838	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2839	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2839	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2840	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2840	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2841	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2841	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2842	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2842	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2843	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2843	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2844	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2844	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2845	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2845	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2846	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2846	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2847	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2847	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2848	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2848	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2849	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2849	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2850	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2850	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2851	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2851	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2852	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2852	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2853	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2853	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2854	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2854	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2855	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2855	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2856	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2856	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2857	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2857	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2858	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2858	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2859	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2859	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2860	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2860	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2861	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2861	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2862	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2862	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2863	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2863	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2864	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2864	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2865	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2865	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2866	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2866	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2867	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2867	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2868	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2868	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2869	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2869	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2870	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2870	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2871	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2871	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2872	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2872	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2873	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2873	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2874	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2874	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2875	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2875	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2876	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2876	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2877	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2877	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2878	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2878	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2879	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2879	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2880	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2880	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2881	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2881	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2882	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2882	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2883	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2883	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2884	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2884	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2885	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2885	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2886	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2886	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2887	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2887	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2888	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2888	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2889	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2889	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2890	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2890	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2891	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2891	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2892	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2892	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2893	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2893	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2894	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2894	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2895	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2895	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2896	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2896	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2897	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2897	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2898	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2898	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2899	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2899	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2900	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2900	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2901	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2901	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2902	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2902	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2903	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2903	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2904	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2904	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2905	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2905	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2906	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2906	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2907	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2907	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2908	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2908	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2909	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2909	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2910	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2910	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2911	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2911	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2912	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2912	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2913	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2913	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2914	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2914	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2915	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2915	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2916	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2916	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2917	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2917	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2918	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2918	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2919	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2919	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2920	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2920	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2921	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2921	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2922	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2922	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2923	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2923	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2924	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2924	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2925	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2925	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2926	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2926	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2927	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2927	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2928	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2928	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2929	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2929	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2930	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2930	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2931	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2931	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2932	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2932	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2933	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2933	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2934	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2934	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2935	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2935	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2936	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2936	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2937	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2937	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2938	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2938	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2939	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2939	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2940	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2940	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2941	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2941	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2942	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2942	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2943	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2943	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2944	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2944	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2945	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2945	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2946	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2946	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2947	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2947	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2948	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2948	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2949	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2949	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2950	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2950	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2951	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2951	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2952	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2952	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2953	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2953	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2954	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2954	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2955	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2955	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2956	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2956	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2957	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2957	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2958	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2958	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2959	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2959	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2960	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2960	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2961	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2961	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2962	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2962	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2963	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2963	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2964	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2964	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2965	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2965	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2966	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2966	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2967	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2967	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2968	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2968	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2969	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2969	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2970	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2970	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2971	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2971	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2972	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2972	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2973	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2973	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2974	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2974	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2975	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2975	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.2976	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2976	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2977	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2977	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2978	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2978	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2979	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2979	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2980	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2980	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2981	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2981	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2982	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2982	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2983	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2983	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2984	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2984	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2985	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2985	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2986	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2986	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2987	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2987	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2988	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2988	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2989	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2989	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2990	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2990	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2991	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2991	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2992	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2992	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2993	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2993	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2994	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2994	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2995	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2995	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2996	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2996	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2997	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2997	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2998	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2998	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.2999	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2999	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3000	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3000	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3001	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3001	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3002	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3002	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3003	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3003	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3004	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3004	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3005	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3005	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3006	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3006	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3007	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3007	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3008	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3008	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3009	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3009	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3010	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3010	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3011	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3011	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3012	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3012	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3013	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3013	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3014	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3014	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3015	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3015	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3016	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3016	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3017	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3017	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3018	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3018	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3019	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3019	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3020	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3020	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3021	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3021	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3022	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3022	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3023	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3023	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3024	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3024	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3025	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3025	Boolean	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.3026	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3026	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3027	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3027	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3028	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3028	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3029	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3029	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3030	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3030	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3031	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3031	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3032	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3032	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3033	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3033	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3034	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3034	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3035	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3035	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3036	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3036	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3037	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3037	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3038	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3038	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3039	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3039	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3040	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3040	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3041	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3041	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3042	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3042	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3043	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3043	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3044	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3044	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3045	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3045	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3046	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3046	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3047	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3047	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3048	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3048	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3049	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3049	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3050	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3050	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3051	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3051	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3052	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3052	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3053	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3053	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3054	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3054	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3055	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3055	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3056	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3056	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3057	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3057	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3058	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3058	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3059	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3059	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3060	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3060	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3061	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3061	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3062	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3062	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3063	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3063	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3064	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3064	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3065	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3065	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3066	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3066	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3067	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3067	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3068	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3068	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3069	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3069	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3070	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3070	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3071	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3071	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3072	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3072	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3073	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3073	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3074	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3074	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3075	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3075	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3076	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3076	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3077	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3077	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3078	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3078	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3079	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3079	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3080	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3080	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3081	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3081	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3082	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3082	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3083	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3083	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3084	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3084	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3085	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3085	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3086	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3086	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3087	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3087	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3088	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3088	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3089	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3089	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3090	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3090	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3091	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3091	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3092	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3092	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3093	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3093	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3094	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3094	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3095	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3095	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3096	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3096	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3097	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3097	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3098	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3098	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3099	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3099	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3100	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3100	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3101	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3102	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3103	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3104	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3105	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3106	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3107	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3108	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3109	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3110	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3111	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3112	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3113	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3114	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3115	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3116	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3117	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3118	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3119	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3120	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3121	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3122	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3123	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3124	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3125	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3126	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3127	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3128	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3129	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3130	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3131	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3132	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3133	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3134	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3135	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3136	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3137	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3138	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3139	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3140	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3141	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3142	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3143	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3144	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3145	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3146	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3147	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3148	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3149	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3150	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3151	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3152	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3153	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3154	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3155	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3156	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3157	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3158	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3159	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3160	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3161	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3162	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3163	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3164	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3165	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3166	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3167	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3168	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3169	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3170	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3171	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3172	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3173	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3174	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3175	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3176	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3177	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3178	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3179	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3180	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3181	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3182	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3183	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3184	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3185	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3186	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3187	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3188	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3189	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3190	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3191	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3192	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3193	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3194	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3195	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3196	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3197	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3198	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3199	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3200	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3201	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3201	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3202	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3202	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3203	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3203	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3204	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3204	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3205	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3205	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3206	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3206	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3207	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3207	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3208	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3208	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3209	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3209	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3210	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3210	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3211	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3211	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3212	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3212	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3213	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3213	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3214	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3214	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3215	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3215	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3216	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3216	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3217	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3217	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3218	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3218	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3219	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3219	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3220	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3220	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3221	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3221	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3222	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3222	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3223	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3223	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3224	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3224	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3225	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3225	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3226	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3226	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3227	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3227	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3228	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3228	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3229	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3229	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3230	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3230	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3231	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3231	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3232	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3232	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3233	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3233	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3234	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3234	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3235	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3235	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3236	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3236	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3237	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3237	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3238	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3238	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3239	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3239	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3240	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3240	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3241	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3241	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3242	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3242	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3243	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3243	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3244	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3244	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3245	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3245	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3246	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3246	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3247	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3247	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3248	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3248	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3249	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3249	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3250	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3250	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3251	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3251	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3252	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3252	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3253	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3253	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3254	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3254	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3255	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3255	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3256	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3256	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3257	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3257	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3258	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3258	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3259	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3259	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3260	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3260	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3261	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3261	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3262	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3262	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3263	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3263	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3264	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3264	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3265	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3265	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3266	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3266	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3267	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3267	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3268	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3268	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3269	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3269	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3270	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3270	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3271	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3271	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3272	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3272	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3273	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3273	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3274	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3274	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3275	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3275	Boolean	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.3276	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3276	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3277	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3277	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3278	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3278	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3279	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3279	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3280	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3280	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3281	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3281	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3282	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3282	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3283	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3283	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3284	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3284	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3285	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3285	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3286	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3286	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3287	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3287	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3288	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3288	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3289	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3289	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3290	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3290	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3291	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3291	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3292	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3292	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3293	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3293	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3294	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3294	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3295	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3295	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3296	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3296	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3297	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3297	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3298	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3298	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3299	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3299	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3300	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3300	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3301	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3301	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3302	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3302	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3303	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3303	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3304	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3304	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3305	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3305	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3306	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3306	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3307	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3307	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3308	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3308	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3309	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3309	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3310	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3310	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3311	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3311	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3312	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3312	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3313	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3313	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3314	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3314	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3315	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3315	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3316	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3316	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3317	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3317	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3318	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3318	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3319	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3319	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3320	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3320	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3321	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3321	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3322	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3322	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3323	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3323	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3324	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3324	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3325	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3325	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3326	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3326	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3327	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3327	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3328	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3328	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3329	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3329	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3330	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3330	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3331	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3331	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3332	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3332	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3333	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3333	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3334	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3334	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3335	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3335	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3336	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3336	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3337	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3337	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3338	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3338	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3339	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3339	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3340	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3340	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3341	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3341	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3342	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3342	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3343	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3343	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3344	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3344	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3345	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3345	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3346	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3346	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3347	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3347	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3348	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3348	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3349	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3349	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3350	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3350	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3351	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3351	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3352	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3352	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3353	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3353	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3354	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3354	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3355	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3355	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3356	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3356	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3357	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3357	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3358	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3358	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3359	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3359	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3360	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3360	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3361	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3361	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3362	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3362	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3363	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3363	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3364	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3364	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3365	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3365	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3366	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3366	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3367	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3367	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3368	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3368	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3369	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3369	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3370	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3370	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3371	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3371	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3372	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3372	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3373	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3373	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3374	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3374	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3375	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3375	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3376	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3376	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3377	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3377	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3378	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3378	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3379	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3379	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3380	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3380	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3381	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3381	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3382	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3382	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3383	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3383	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3384	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3384	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3385	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3385	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3386	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3386	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3387	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3387	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3388	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3388	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3389	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3389	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3390	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3390	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3391	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3391	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3392	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3392	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3393	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3393	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3394	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3394	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3395	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3395	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3396	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3396	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3397	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3397	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3398	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3398	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3399	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3399	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3400	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3400	Boolean	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.3401	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3401	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3402	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3402	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3403	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3403	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3404	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3404	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3405	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3405	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3406	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3406	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3407	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3407	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3408	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3408	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3409	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3409	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3410	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3410	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3411	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3411	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3412	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3412	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3413	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3413	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3414	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3414	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3415	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3415	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3416	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3416	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3417	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3417	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3418	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3418	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3419	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3419	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3420	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3420	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3421	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3421	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3422	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3422	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3423	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3423	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3424	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3424	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3425	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3425	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3426	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3426	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3427	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3427	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3428	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3428	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3429	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3429	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3430	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3430	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3431	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3431	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3432	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3432	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3433	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3433	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3434	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3434	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3435	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3435	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3436	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3436	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3437	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3437	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3438	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3438	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3439	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3439	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3440	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3440	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3441	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3441	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3442	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3442	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3443	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3443	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3444	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3444	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3445	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3445	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3446	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3446	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3447	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3447	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3448	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3448	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3449	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3449	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3450	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3450	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3451	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3451	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3452	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3452	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3453	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3453	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3454	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3454	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3455	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3455	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3456	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3456	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3457	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3457	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3458	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3458	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3459	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3459	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3460	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3460	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3461	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3461	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3462	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3462	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3463	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3463	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3464	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3464	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3465	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3465	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3466	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3466	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3467	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3467	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3468	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3468	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3469	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3469	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3470	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3470	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3471	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3471	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3472	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3472	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3473	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3473	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3474	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3474	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3475	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3475	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3476	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3476	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3477	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3477	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3478	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3478	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3479	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3479	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3480	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3480	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3481	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3481	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3482	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3482	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3483	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3483	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3484	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3484	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3485	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3485	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3486	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3486	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3487	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3487	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3488	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3488	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3489	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3489	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3490	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3490	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3491	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3491	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3492	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3492	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3493	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3493	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3494	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3494	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3495	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3495	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3496	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3496	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3497	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3497	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3498	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3498	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3499	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3499	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3500	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3500	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3501	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3501	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3502	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3502	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3503	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3503	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3504	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3504	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3505	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3505	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3506	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3506	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3507	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3507	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3508	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3508	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3509	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3509	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3510	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3510	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3511	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3511	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3512	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3512	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3513	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3513	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3514	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3514	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3515	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3515	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3516	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3516	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3517	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3517	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3518	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3518	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3519	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3519	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3520	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3520	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3521	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3521	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3522	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3522	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3523	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3523	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3524	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3524	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3525	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3525	Boolean	false (2)



Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.3526	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3526	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3527	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3527	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3528	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3528	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3529	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3529	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3530	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3530	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3531	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3531	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3532	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3532	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3533	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3533	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3534	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3534	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3535	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3535	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3536	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3536	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3537	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3537	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3538	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3538	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3539	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3539	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3540	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3540	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3541	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3541	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3542	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3542	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3543	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3543	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3544	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3544	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3545	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3545	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3546	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3546	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3547	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3547	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3548	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3548	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3549	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3549	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3550	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3550	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3551	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3551	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3552	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3552	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3553	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3553	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3554	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3554	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3555	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3555	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3556	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3556	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3557	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3557	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3558	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3558	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3559	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3559	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3560	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3560	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3561	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3561	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3562	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3562	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3563	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3563	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3564	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3564	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3565	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3565	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3566	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3566	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3567	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3567	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3568	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3568	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3569	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3569	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3570	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3570	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3571	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3571	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3572	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3572	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3573	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3573	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3574	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3574	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3575	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3575	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3576	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3576	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3577	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3577	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3578	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3578	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3579	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3579	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3580	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3580	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3581	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3581	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3582	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3582	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3583	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3583	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3584	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3584	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3585	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3585	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3586	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3586	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3587	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3587	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3588	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3588	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3589	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3589	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3590	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3590	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3591	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3591	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3592	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3592	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3593	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3593	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3594	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3594	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3595	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3595	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3596	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3596	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3597	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3597	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3598	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3598	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3599	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3599	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3600	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3600	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3601	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3601	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3602	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3602	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3603	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3603	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3604	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3604	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3605	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3605	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3606	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3606	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3607	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3607	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3608	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3608	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3609	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3609	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3610	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3610	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3611	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3611	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3612	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3612	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3613	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3613	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3614	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3614	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3615	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3615	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3616	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3616	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3617	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3617	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3618	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3618	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3619	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3619	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3620	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3620	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3621	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3621	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3622	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3622	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3623	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3623	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3624	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3624	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3625	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3625	Boolean	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.3626	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3626	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3627	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3627	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3628	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3628	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3629	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3629	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3630	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3630	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3631	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3631	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3632	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3632	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3633	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3633	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3634	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3634	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3635	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3635	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3636	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3636	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3637	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3637	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3638	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3638	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3639	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3639	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3640	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3640	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3641	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3641	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3642	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3642	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3643	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3643	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3644	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3644	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3645	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3645	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3646	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3646	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3647	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3647	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3648	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3648	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3649	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3649	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3650	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3650	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3651	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3651	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3652	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3652	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3653	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3653	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3654	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3654	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3655	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3655	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3656	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3656	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3657	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3657	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3658	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3658	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3659	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3660	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3660	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3661	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3661	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3662	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3662	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3663	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3663	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3664	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3664	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3665	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3665	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3666	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3666	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3667	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3667	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3668	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3668	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3669	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3669	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3670	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3670	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3671	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3671	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3672	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3672	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3673	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3673	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3674	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3674	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3675	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3675	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3676	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3676	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3677	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3677	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3678	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3678	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3679	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3679	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3680	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3680	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3681	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3681	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3682	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3682	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3683	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3683	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3684	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3684	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3685	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3685	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3686	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3686	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3687	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3687	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3688	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3688	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3689	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3689	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3690	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3690	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3691	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3691	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3692	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3692	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3693	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3693	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3694	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3694	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3695	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3695	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3696	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3696	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3697	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3697	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3698	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3698	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3699	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3699	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3700	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3700	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3701	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3702	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3703	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3704	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3705	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3706	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3707	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3708	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3709	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3710	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3711	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3712	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3713	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3714	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3715	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3716	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3717	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3718	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3719	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3720	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3721	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3722	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3723	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3724	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3725	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3726	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3727	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3728	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3729	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3730	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3731	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3732	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3733	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3734	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3735	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3736	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3737	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3738	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3739	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3740	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3741	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3742	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3743	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3744	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3745	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3746	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3747	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3748	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3749	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3750	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.3751	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3752	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3753	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3754	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3755	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3756	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3757	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3758	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3759	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3760	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3761	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3762	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3763	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3764	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3765	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3766	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3767	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3768	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3769	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3770	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3771	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3772	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3773	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3774	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3775	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.1.3776	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3777	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3778	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3779	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3780	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3781	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3782	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3783	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3784	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3785	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3786	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3787	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3788	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3789	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3790	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3791	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3792	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3793	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3794	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3795	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3796	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3797	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3798	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3799	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.1.3800	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3801	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3801	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3802	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3802	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3803	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3803	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3804	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3804	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3805	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3805	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3806	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3806	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3807	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3807	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3808	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3808	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3809	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3809	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3810	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3810	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3811	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3811	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3812	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3812	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3813	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3813	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3814	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3814	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3815	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3815	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3816	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3816	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3817	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3817	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3818	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3818	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3819	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3819	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3820	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3820	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3821	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3821	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3822	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3822	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3823	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3823	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3824	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3824	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3825	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3825	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3826	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3826	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3827	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3827	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3828	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3828	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3829	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3829	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3830	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3830	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3831	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3831	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3832	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3832	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3833	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3833	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3834	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3834	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3835	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3835	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3836	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3836	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3837	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3837	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3838	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3838	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3839	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3839	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3840	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3840	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3841	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3841	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3842	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3842	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3843	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3843	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3844	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3844	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3845	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3845	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3846	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3846	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3847	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3847	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3848	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3848	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3849	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3849	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3850	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3850	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3851	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3851	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3852	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3852	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3853	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3853	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3854	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3854	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3855	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3855	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3856	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3856	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3857	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3857	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3858	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3858	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3859	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3859	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3860	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3860	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3861	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3861	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3862	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3862	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3863	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3863	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3864	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3864	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3865	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3865	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3866	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3866	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3867	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3867	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3868	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3868	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3869	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3869	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3870	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3870	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3871	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3871	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3872	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3872	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3873	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3873	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3874	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3874	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3875	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3875	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3876	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3876	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3877	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3877	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3878	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3878	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3879	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3879	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3880	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3880	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3881	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3881	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3882	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3882	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3883	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3883	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3884	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3884	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3885	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3885	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3886	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3886	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3887	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3887	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3888	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3888	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3889	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3889	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3890	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3890	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3891	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3891	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3892	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3892	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3893	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3893	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3894	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3894	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3895	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3895	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3896	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3896	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3897	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3897	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3898	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3898	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3899	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3899	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3900	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3900	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3901	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3901	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3902	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3902	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3903	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3903	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3904	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3904	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3905	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3905	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3906	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3906	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3907	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3907	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3908	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3908	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3909	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3909	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3910	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3910	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3911	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3911	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3912	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3912	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3913	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3913	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3914	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3914	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3915	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3915	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3916	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3916	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3917	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3917	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3918	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3918	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3919	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3919	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3920	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3920	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3921	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3921	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3922	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3922	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3923	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3923	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3924	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3924	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3925	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3925	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3926	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3926	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3927	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3927	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3928	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3928	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3929	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3929	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3930	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3930	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3931	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3931	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3932	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3932	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3933	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3933	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3934	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3934	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3935	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3935	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3936	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3936	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3937	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3937	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3938	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3938	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3939	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3939	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3940	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3940	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3941	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3941	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3942	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3942	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3943	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3943	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3944	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3944	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3945	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3945	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3946	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3946	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3947	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3947	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3948	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3948	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3949	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3949	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3950	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3950	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3951	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3951	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3952	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3952	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3953	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3953	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3954	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3954	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3955	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3955	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3956	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3956	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3957	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3957	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3958	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3958	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3959	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3959	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3960	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3960	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3961	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3961	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3962	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3962	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3963	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3963	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3964	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3964	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3965	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3965	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3966	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3966	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3967	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3967	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3968	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3968	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3969	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3969	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3970	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3970	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3971	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3971	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3972	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3972	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3973	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3973	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3974	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3974	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3975	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3975	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.3976	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3976	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3977	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3977	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3978	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3978	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3979	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3979	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3980	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3980	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3981	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3981	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3982	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3982	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3983	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3983	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3984	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3984	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3985	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3985	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3986	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3986	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3987	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3987	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3988	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3988	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3989	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3989	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3990	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3990	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3991	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3991	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3992	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3992	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3993	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3993	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3994	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3994	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3995	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3995	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3996	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3996	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3997	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3997	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3998	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3998	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.3999	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.3999	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4000	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4000	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.4001	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4001	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4002	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4002	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4003	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4003	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4004	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4004	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4005	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4005	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4006	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4006	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4007	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4007	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4008	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4008	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4009	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4009	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4010	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4010	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4011	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4011	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4012	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4012	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4013	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4013	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4014	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4014	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4015	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4015	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4016	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4016	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4017	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4017	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4018	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4018	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4019	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4019	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4020	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4020	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4021	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4021	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4022	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4022	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4023	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4023	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4024	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4024	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4025	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4025	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.4026	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4026	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4027	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4027	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4028	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4028	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4029	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4029	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4030	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4030	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4031	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4031	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4032	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4032	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4033	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4033	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4034	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4034	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4035	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4035	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4036	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4036	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4037	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4037	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4038	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4038	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4039	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4040	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4040	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4041	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4041	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4042	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4042	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4043	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4043	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4044	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4044	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4045	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4045	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4046	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4046	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4047	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4047	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4048	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4048	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4049	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4049	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4050	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4050	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.4051	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4051	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4052	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4052	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4053	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4053	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4054	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4054	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4055	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4055	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4056	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4056	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4057	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4057	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4058	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4058	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4059	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4059	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4060	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4060	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4061	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4061	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4062	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4062	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4063	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4063	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4064	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4064	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4065	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4065	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4066	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4066	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4067	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4067	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4068	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4068	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4069	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4069	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4070	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4070	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4071	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4071	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4072	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4072	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4073	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4073	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4074	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4074	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4075	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4075	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.1.4076	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4076	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4077	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4077	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4078	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4078	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4079	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4079	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4080	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4080	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4081	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4081	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4082	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4082	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4083	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4083	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4084	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4084	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4085	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4085	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4086	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4086	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4087	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4087	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4088	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4088	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4089	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4089	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4090	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4090	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4091	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4091	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4092	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4093	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4093	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.1.4094	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4094	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.0	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.0	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.2	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.3	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.3	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.4	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.4	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.5	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.5	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.2.6	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.6	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.7	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.7	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.8	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.8	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.9	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.9	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.10	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.10	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.11	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.11	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.12	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.12	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.13	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.13	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.14	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.14	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.15	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.16	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.17	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.18	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.18	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.19	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.19	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.20	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.20	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.21	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.21	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.22	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.22	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.23	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.23	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.24	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.24	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.25	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.25	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.26	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.26	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.27	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.27	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.28	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.28	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.29	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.29	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.30	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.2.30	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameXEnable.2.31	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.31	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.32	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.32	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.33	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.33	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.34	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.34	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.35	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.35	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.36	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.36	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.37	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.38	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.38	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.39	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.39	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.40	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.40	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.41	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.41	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.42	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.42	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.43	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.43	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.44	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.44	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.45	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.45	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.46	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.46	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.47	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.47	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.48	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.48	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.49	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.49	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.50	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.50	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.51	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.51	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.52	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.52	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.53	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.53	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.54	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.54	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.55	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.55	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameXEnable.2.56	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.56	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.57	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.57	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.58	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.58	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.59	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.59	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.60	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.60	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.61	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.61	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.62	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.62	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.63	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.63	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.64	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.64	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.65	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.65	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.66	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.66	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.67	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.67	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.68	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.68	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.69	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.69	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.70	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.70	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.71	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.71	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.72	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.72	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.73	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.73	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.74	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.74	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.75	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.75	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.76	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.76	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.77	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.77	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.78	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.78	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.79	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.79	Integer	false (2)
IldpV2Xdot1ConfigVlanNameXEnable.2.80	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.80	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.2.81	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.81	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.82	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.82	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.83	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.83	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.84	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.84	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.85	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.85	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.86	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.86	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.87	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.87	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.88	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.88	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.89	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.89	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.90	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.90	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.91	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.91	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.92	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.92	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.93	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.93	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.94	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.94	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.95	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.95	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.96	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.96	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.97	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.97	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.98	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.98	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.99	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.99	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.100	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.100	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.101	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.101	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.102	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.102	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.103	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.103	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.104	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.104	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.2.105	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.105	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.106	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.107	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.108	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.109	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.110	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.111	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.112	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.113	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.114	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.115	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.116	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.117	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.118	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.119	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.120	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.121	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.122	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.123	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.124	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.125	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.126	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.127	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.128	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.129	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.130	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.2.131	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.132	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.133	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.134	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.135	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.136	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.137	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.138	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.139	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.140	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.141	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.142	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.143	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.144	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.145	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.146	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.147	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.148	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.149	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.150	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.151	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.152	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.153	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.154	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.155	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.156	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.157	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.158	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.159	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.160	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.161	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.162	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.163	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.164	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.165	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.166	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.167	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.168	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.169	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.170	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.171	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.172	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.173	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.174	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.175	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.176	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.177	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.178	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.179	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.180	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.2.181	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2181	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.182	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2182	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.183	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2183	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.184	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2184	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.185	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2185	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.186	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2186	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.187	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2187	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.188	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2188	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.189	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2189	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.190	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2190	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.191	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2191	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.192	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2192	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.193	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2193	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.194	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2194	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.195	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2195	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.196	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2196	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.197	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2197	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.198	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2198	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.199	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2199	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.200	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2200	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.201	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2201	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.202	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2202	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.203	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2203	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.204	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2204	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.205	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2205	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.206	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.207	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.208	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.209	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.210	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.211	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.212	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.213	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.214	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.215	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.216	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.217	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.218	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.219	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.220	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.221	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.222	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.223	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.224	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.225	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.226	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.227	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.228	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.229	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.230	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.2.231	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2761	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.232	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2762	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.233	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2763	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.234	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2764	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.235	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2765	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.236	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2766	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.237	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2767	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.238	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2768	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.239	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2769	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.240	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2770	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.241	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2771	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.242	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2772	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.243	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2773	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.244	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2774	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.245	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2775	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.246	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2776	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.247	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2777	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.248	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2778	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.249	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2779	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.250	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2780	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.251	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2781	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.252	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2782	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.253	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2783	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.254	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2784	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.255	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2785	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.256	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.257	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.258	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.259	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.260	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.261	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.262	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.263	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.264	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.265	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.266	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.267	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.268	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.269	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.270	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.271	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.272	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.273	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.274	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.275	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.276	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.277	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.278	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.279	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.280	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.2.281	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2781	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.282	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2782	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.283	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2783	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.284	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2784	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.285	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2785	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.286	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2786	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.287	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2787	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.288	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2788	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.289	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2789	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.290	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2790	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.291	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2791	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.292	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2792	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.293	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2793	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.294	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2794	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.295	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2795	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.296	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2796	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.297	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2797	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.298	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2798	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.299	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2799	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.300	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2800	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.301	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2801	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.302	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2802	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.303	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2803	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.304	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2804	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.305	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2805	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.306	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.306	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.307	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.307	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.308	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.308	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.309	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.309	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.310	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.310	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.311	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.311	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.312	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.312	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.313	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.313	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.314	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.314	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.315	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.315	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.316	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.316	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.317	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.317	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.318	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.318	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.319	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.319	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.320	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.320	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.321	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.321	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.322	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.322	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.323	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.323	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.324	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.324	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.325	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.325	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.326	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.326	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.327	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.327	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.328	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.328	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.329	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.329	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.330	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.330	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.331	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2331	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.332	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2332	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.333	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2333	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.334	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2334	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.335	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2335	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.336	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2336	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.337	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2337	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.338	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2338	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.339	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2339	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.340	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2340	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.341	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2341	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.342	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2342	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.343	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2343	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.344	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2344	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.345	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2345	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.346	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2346	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.347	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2347	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.348	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2348	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.349	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2349	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.350	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2350	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.351	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2351	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.352	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2352	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.353	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2353	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.354	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2354	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.355	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2355	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.356	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.357	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.358	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.359	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.360	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.361	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.362	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.363	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.364	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.365	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.366	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.367	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.368	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.369	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.370	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.371	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.372	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.373	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.374	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.375	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.376	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.377	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.378	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.379	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.380	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.381	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2381	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.382	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2382	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.383	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2383	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.384	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2384	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.385	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2385	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.386	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2386	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.387	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2387	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.388	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2388	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.389	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2389	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.390	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2390	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.391	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2391	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.392	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2392	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.393	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2393	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.394	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2394	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.395	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2395	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.396	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2396	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.397	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2397	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.398	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2398	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.399	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2399	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.400	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2400	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.401	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2401	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.402	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2402	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.403	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2403	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.404	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2404	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.405	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2405	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.2.406	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.407	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.408	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.409	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.410	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.411	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.412	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.413	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.414	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.415	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.416	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.417	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.418	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.419	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.420	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.421	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.422	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.423	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.424	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.425	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.426	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.427	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.428	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.429	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.430	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.431	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.432	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.433	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.434	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.435	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.436	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.437	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.438	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.439	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.440	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.441	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.442	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.443	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.444	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.445	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.446	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.447	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.448	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.449	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.450	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.451	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.452	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.453	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.454	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.455	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.456	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.457	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.458	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.459	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.460	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.461	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.462	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.463	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.464	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.465	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.466	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.467	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.468	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.469	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.470	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.471	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.472	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.473	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.474	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.475	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.476	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.477	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.478	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.479	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.480	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.2.481	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.481	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.482	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.482	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.483	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.483	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.484	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.484	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.485	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.485	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.486	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.486	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.487	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.487	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.488	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.488	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.489	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.489	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.490	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.490	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.491	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.491	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.492	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.492	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.493	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.493	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.494	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.494	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.495	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.495	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.496	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.496	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.497	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.497	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.498	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.498	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.499	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.499	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.500	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.500	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.501	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.501	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.502	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.502	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.503	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.503	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.504	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.504	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.505	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.505	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.506	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.507	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.508	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.509	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.510	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.511	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.512	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.513	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.514	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.515	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.516	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.517	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.518	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.519	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.520	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.521	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.522	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.523	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.524	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.525	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.526	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.527	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.528	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.529	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.530	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.531	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.532	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.533	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.534	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.535	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.536	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.537	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.538	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.539	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.540	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.541	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.542	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.543	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.544	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.545	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.546	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.547	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.548	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.549	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.550	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.551	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.552	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.553	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.554	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.555	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.556	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.557	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.558	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.559	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.560	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.561	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.562	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.563	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.564	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.565	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.566	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.567	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.568	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.569	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.570	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.571	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.572	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.573	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.574	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.575	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.576	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.577	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.578	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.579	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.580	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.581	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2581ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.582	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2582ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.583	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2583ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.584	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2584ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.585	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2585ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.586	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2586ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.587	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2587ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.588	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2588ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.589	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2589ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.590	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2590ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.591	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2591ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.592	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2592ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.593	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2593ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.594	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2594ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.595	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2595ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.596	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2596ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.597	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2597ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.598	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2598ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.599	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2599ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.600	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2600ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.601	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2601ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.602	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2602ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.603	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2603ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.604	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2604ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.605	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2605ger	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.606	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.607	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.608	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.609	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.610	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.611	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.612	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.613	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.614	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.615	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.616	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.617	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.618	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.619	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.620	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.621	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.622	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.623	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.624	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.625	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.626	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.627	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.628	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.629	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.630	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.631	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.632	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.633	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.634	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.635	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.636	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.637	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.638	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.639	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.640	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.641	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.642	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.643	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.644	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.645	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.646	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.647	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.648	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.649	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.650	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.651	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.652	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.653	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.654	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.655	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.656	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.657	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.658	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.659	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.660	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.661	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.662	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.663	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.664	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.665	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.666	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.667	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.668	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.669	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.670	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.671	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.672	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.673	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.674	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.675	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.676	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.677	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.678	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.679	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.680	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.681	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.681ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.682	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.682ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.683	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.683ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.684	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.684ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.685	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.685ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.686	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.686ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.687	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.687ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.688	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.688ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.689	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.689ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.690	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.690ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.691	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.691ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.692	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.692ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.693	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.693ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.694	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.694ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.695	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.695ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.696	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.696ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.697	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.697ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.698	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.698ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.699	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.699ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.700	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.700ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.701	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.701ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.702	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.702ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.703	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.703ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.704	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.704ger	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.705	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	2.705ger	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.706	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.707	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.708	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.709	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.710	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.711	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.712	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.713	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.714	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.715	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.716	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.717	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.718	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.719	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.720	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.721	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.722	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.723	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.724	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.725	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.726	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.727	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.728	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.729	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.730	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.731	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.732	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.733	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.734	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.735	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.736	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.737	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.738	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.739	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.740	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.741	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.742	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.743	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.744	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.745	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.746	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.747	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.748	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.749	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.750	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.751	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.752	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.753	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.754	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.755	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.756	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.757	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.758	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.759	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.760	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.761	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.762	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.763	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.764	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.765	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.766	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.767	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.768	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.769	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.770	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.771	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.772	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.773	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.774	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.775	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.776	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.777	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.778	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.779	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.780	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.2.781	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.782	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.783	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.784	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.785	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.786	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.787	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.788	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.789	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.790	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.791	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.792	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.793	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.794	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.795	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.796	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.797	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.798	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.799	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.800	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.801	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.802	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.803	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.804	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.805	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.2.806	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.806	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.807	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.807	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.808	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.808	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.809	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.809	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.810	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.810	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.811	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.811	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.812	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.812	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.813	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.813	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.814	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.814	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.815	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.815	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.816	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.816	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.817	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.817	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.818	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.818	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.819	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.819	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.820	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.820	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.821	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.821	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.822	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.822	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.823	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.823	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.824	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.824	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.825	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.825	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.826	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.826	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.827	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.827	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.828	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.828	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.829	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.829	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.830	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.830	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.831	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.832	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.833	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.834	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.835	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.836	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.837	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.838	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.839	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.840	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.841	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.842	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.843	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.844	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.845	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.846	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.847	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.848	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.849	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.850	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.851	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.852	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.853	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.854	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.855	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.856	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.857	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.858	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.859	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.860	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.861	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.862	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.863	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.864	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.865	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.866	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.867	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.868	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.869	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.870	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.871	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.872	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.873	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.874	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.875	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.876	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.877	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.878	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.879	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.880	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameB.xEnable.2.881	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.882	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.883	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.884	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.885	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.886	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.887	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.888	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.889	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.890	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.891	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.892	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.893	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.894	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.895	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.896	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.897	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.898	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.899	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.900	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.901	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.902	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.903	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.904	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameB.xEnable.2.905	1.2.802.1.1.13.1.5.32962.1.1.2.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.906	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2906	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.907	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2907	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.908	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2908	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.909	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2909	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.910	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2910	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.911	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2911	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.912	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2912	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.913	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2913	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.914	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2914	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.915	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2915	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.916	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2916	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.917	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2917	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.918	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2918	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.919	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2919	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.920	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2920	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.921	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2921	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.922	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2922	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.923	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2923	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.924	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2924	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.925	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2925	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.926	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2926	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.927	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2927	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.928	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2928	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.929	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2929	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.930	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2930	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.931	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2961	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.932	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2962	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.933	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2963	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.934	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2964	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.935	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2965	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.936	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2966	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.937	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2967	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.938	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2968	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.939	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2969	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.940	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2970	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.941	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2971	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.942	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2972	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.943	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2973	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.944	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2974	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.945	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2975	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.946	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2976	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.947	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2977	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.948	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2978	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.949	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2979	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.950	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2980	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.951	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2981	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.952	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2982	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.953	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2983	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.954	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2984	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.955	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2985	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.956	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.956	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.957	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.957	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.958	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.958	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.959	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.959	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.960	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.960	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.961	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.961	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.962	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.962	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.963	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.963	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.964	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.964	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.965	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.965	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.966	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.966	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.967	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.967	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.968	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.968	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.969	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.969	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.970	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.970	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.971	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.971	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.972	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.972	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.973	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.973	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.974	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.974	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.975	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.975	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.976	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.976	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.977	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.977	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.978	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.978	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.979	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.979	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.980	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.980	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.2.981	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1001	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.982	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1002	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.983	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1003	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.984	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1004	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.985	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1005	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.986	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1006	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.987	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1007	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.988	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1008	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.989	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1009	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.990	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1010	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.991	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1011	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.992	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1012	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.993	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1013	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.994	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1014	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.995	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1015	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.996	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1016	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.997	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1017	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.998	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1018	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.999	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1019	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.1000	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1100	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.1001	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1101	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.1002	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1102	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.1003	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1103	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.1004	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1104	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.2.1005	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1105	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.2.1006	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1006	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1007	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1007	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1008	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1008	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1009	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1009	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1010	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1010	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1011	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1011	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1012	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1012	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1013	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1013	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1014	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1014	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1015	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1015	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1016	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1016	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1017	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1017	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1018	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1018	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1019	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1019	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1020	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1020	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1021	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1021	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1022	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1022	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1023	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1023	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1024	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1024	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1025	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1025	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1026	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1026	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1027	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1027	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1028	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1028	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1029	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1029	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1030	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1030	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.2.1031	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1031	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1032	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1032	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1033	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1033	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1034	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1034	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1035	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1035	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1036	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1036	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1037	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1037	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1038	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1038	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1039	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1039	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1040	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1040	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1041	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1041	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1042	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1042	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1043	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1043	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1044	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1044	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1045	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1045	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1046	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1046	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1047	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1047	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1048	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1048	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1049	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1049	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1050	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1050	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1051	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1051	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1052	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1052	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1053	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1053	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1054	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1054	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1055	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1055	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.2.1056	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1056	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1057	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1057	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1058	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1058	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1059	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1059	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1060	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1060	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1061	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1061	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1062	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1062	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1063	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1063	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1064	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1064	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1065	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1065	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1066	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1066	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1067	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1067	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1068	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1068	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1069	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1069	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1070	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1070	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1071	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1071	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1072	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1072	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1073	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1073	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1074	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1074	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1075	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1075	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1076	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1076	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1077	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1077	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1078	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1078	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1079	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1079	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1080	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1080	Boolean	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.2.1081	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1081	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1082	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1082	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1083	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1083	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1084	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1084	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1085	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1085	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1086	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1086	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1087	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1087	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1088	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1088	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1089	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1089	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1090	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1090	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1091	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1091	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1092	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1092	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1093	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1093	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1094	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1094	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1095	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1095	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1096	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1096	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1097	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1097	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1098	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1098	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1099	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1099	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1100	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1100	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1101	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1101	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1102	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1102	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1103	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1103	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1104	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1104	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1105	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1105	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.2.1106	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1107	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1108	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1109	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1110	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1111	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1112	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1113	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1114	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1115	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1116	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1117	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1118	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1119	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1120	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1121	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1122	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1123	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1124	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1125	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1126	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1127	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1128	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1129	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1130	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.2.1131	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1132	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1133	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1134	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1135	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1136	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1137	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1138	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1139	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1140	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1141	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1142	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1143	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1144	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1145	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1146	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1147	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1148	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1149	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1150	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1151	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1152	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1153	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1154	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1155	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.2.1156	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1157	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1158	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1159	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1160	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1161	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1162	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1163	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1164	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1165	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1166	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1167	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1168	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1169	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1170	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1171	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1172	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1173	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1174	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1175	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1176	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1177	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1178	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1179	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1180	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)



Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.2.1181	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1182	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1183	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1184	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1185	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1186	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1187	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1188	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1189	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1190	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1191	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1192	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1193	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1194	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1195	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1196	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1197	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1198	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1199	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1200	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1201	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1202	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1203	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1204	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.2.1205	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.2.1206	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1206	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1207	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1207	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1208	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1208	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1209	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1210	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1210	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1211	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1211	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1212	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1212	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1213	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1213	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1214	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1214	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1215	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1215	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1216	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1216	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1217	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1217	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1218	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1218	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1219	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1219	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1220	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1220	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1221	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1221	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1222	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1222	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1223	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1223	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1224	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1224	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1225	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1225	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1226	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1226	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1227	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1227	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1228	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1228	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1229	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1229	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1230	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1230	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.2.1231	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1231	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1232	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1232	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1233	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1233	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1234	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1234	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1235	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1235	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1236	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1236	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1237	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1237	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1238	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1238	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1239	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1239	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1240	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1240	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1241	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1241	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1242	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1242	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1243	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1243	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1244	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1244	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1245	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1245	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1246	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1246	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1247	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1247	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1248	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1248	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1249	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1249	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1250	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1250	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1251	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1251	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1252	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1252	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1253	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1253	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1254	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1254	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1255	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1255	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.2.1256	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1256	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1257	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1257	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1258	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1258	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1259	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1259	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1260	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1260	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1261	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1261	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1262	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1262	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1263	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1263	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1264	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1264	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1265	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1265	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1266	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1266	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1267	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1267	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1268	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1268	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1269	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1269	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1270	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1270	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1271	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1271	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1272	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1272	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1273	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1273	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1274	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1274	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1275	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1275	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1276	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1276	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1277	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1277	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1278	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1278	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1279	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1279	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1280	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1280	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.2.1281	.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1281	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1282	.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1282	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1283	.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1283	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1284	.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1284	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1285	.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1285	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1286	.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1286	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1287	.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1287	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1288	.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1288	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1289	.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1289	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.2.1290	.2.802.1.1.13.1.5.32962.1.1.2.1.1.2.1290	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.14.4001	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4001	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.14.4002	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4002	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.14.4003	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4003	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.14.4004	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4004	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.14.4005	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4005	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.14.4006	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4006	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.14.4007	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4007	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.14.4008	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4008	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.14.4009	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4009	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.14.4010	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4010	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.14.4011	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4011	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.14.4012	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4012	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.14.4013	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4013	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.14.4014	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4014	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.14.4015	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4015	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.14.4016	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4016	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4017	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4017	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4018	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4018	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4019	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4019	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4020	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4020	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4021	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4021	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4022	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4022	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4023	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4023	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4024	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4024	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4025	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4025	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4026	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4026	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4027	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4027	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4028	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4028	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4029	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4030	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4030	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4031	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4031	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4032	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4033	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4033	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4034	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4034	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4035	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4035	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4036	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4036	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4037	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4037	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4038	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4038	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4039	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4039	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4040	.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4040	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.14.4041	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4041	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4042	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4042	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4043	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4043	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4044	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4044	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4045	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4045	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4046	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4046	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4047	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4047	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4048	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4048	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4049	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4049	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4050	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4050	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4051	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4051	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4052	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4053	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4053	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4054	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4054	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4055	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4055	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4056	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4056	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4057	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4057	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4058	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4058	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4059	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4059	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4060	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4060	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4061	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4061	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4062	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4062	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4063	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4063	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4064	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4064	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4065	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4065	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.14.4066	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4066	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4067	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4067	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4068	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4068	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4069	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4069	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4070	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4070	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4071	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4071	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4072	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4072	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4073	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4073	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4074	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4074	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4075	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4075	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4076	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4076	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4077	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4077	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4078	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4078	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4079	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4079	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4080	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4080	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4081	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4081	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4082	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4082	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4083	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4083	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4084	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4084	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4085	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4085	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4086	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4086	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4087	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4087	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4088	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4088	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4089	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4089	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4090	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.4.4090	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.14.4091	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4091	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4092	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4093	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4093	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.14.4094	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.14.4094	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.0	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.0	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.4	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.5	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.6	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.6	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.7	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.7	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.8	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.8	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.9	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.9	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.10	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.10	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.11	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.11	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.12	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.12	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.13	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.13	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.14	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.14	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.15	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.16	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.17	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.18	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.18	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.19	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.19	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.20	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.20	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.15.21	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.21	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.22	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.22	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.23	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.23	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.24	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.24	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.25	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.25	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.26	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.26	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.27	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.27	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.28	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.28	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.29	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.29	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.30	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.30	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.31	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.31	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.32	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.32	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.33	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.33	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.34	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.34	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.35	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.35	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.36	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.36	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.37	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.38	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.38	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.39	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.39	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.40	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.40	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.41	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.41	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.42	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.42	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.43	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.43	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.44	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.44	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.45	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.45	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.15.46	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1546	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.47	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1547	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.48	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1548	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.49	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1549	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.50	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1550	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.51	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1551	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.52	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1552	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.53	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1553	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.54	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1554	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.55	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1555	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.56	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1556	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.57	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1557	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.58	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1558	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.59	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1559	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.60	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1560	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.61	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1561	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.62	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1562	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.63	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1563	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.64	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1564	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.65	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1565	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.66	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1566	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.67	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1567	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.68	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1568	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.69	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1569	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.70	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1570	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.15.71	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1571	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.72	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1572	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.73	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1573	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.74	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1574	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.75	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1575	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.76	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1576	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.77	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1577	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.78	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1578	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.79	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1579	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.80	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1580	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.81	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1581	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.82	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1582	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.83	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1583	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.84	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1584	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.85	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1585	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.86	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1586	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.87	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1587	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.88	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1588	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.89	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1589	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.90	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1590	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.91	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1591	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.92	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1592	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.93	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1593	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.94	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1594	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.15.95	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1595	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.96	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.96	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.97	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.97	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.98	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.98	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.99	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.99	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.100	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.100	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.101	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.101	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.102	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.102	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.103	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.103	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.104	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.104	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.105	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.105	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.106	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.106	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.107	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.107	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.108	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.108	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.109	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.109	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.110	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.110	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.111	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.111	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.112	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.112	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.113	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.113	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.114	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.114	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.115	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.115	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.116	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.116	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.117	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.117	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.118	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.118	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.119	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.119	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.120	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.120	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.121	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.122	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.123	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.124	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.125	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.126	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.127	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.128	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.129	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.130	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.131	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.132	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.133	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.134	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.135	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.136	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.137	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.138	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.139	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.140	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.141	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.142	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.143	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.144	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.145	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)



Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.15.146	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.147	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.148	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.149	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.150	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.151	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.152	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.153	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.154	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.155	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.156	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.157	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.158	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.159	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.160	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.161	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.162	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.163	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.164	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.165	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.166	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.167	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.168	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.169	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.170	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.15.171	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.172	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.173	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.174	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.175	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.176	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.177	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.178	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.179	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.180	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.181	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.182	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.183	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.184	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.185	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.186	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.187	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.188	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.189	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.190	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.191	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.192	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.193	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.194	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.195	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.196	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.197	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.198	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.199	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.200	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.201	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.202	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.203	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.204	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.205	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.206	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.207	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.208	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.209	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.210	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.211	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.212	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.213	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.214	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.215	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.216	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.217	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.218	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.219	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.220	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.221	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15221	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.222	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15222	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.223	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15223	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.224	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15224	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.225	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15225	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.226	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15226	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.227	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15227	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.228	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15228	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.229	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15229	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.230	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15230	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.231	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15231	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.232	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15232	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.233	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15233	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.234	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15234	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.235	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15235	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.236	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15236	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.237	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15237	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.238	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15238	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.239	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15239	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.240	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15240	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.241	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15241	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.242	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15242	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.243	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15243	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.244	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15244	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.245	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15245	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.246	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15246	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.247	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15247	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.248	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15248	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.249	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15249	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.250	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15250	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.251	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15251	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.252	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15252	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.253	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15253	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.254	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15254	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.255	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15255	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.256	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15256	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.257	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15257	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.258	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15258	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.259	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15259	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.260	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15260	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.261	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15261	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.262	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15262	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.263	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15263	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.264	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15264	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.265	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15265	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.266	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15266	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.267	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15267	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.268	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15268	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.269	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15269	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.270	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15270	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.271	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15271	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.272	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15272	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.273	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15273	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.274	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15274	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.275	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15275	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.276	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15276	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.277	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15277	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.278	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15278	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.279	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15279	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.280	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15280	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.281	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15281	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.282	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15282	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.283	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15283	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.284	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15284	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.285	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15285	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.286	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15286	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.287	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15287	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.288	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15288	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.289	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15289	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.290	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15290	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.291	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15291	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.292	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15292	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.293	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15293	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.294	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15294	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.295	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15295	Integer	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.15.296	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15296	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.297	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15297	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.298	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15298	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.299	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15299	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.300	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15300	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.301	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15301	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.302	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15302	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.303	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15303	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.304	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15304	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.305	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15305	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.306	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15306	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.307	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15307	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.308	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15308	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.309	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15309	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.310	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15310	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.311	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15311	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.312	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15312	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.313	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15313	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.314	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15314	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.315	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15315	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.316	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15316	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.317	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15317	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.318	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15318	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.319	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15319	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.320	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15320	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.321	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.322	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.323	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.324	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.325	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.326	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.327	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.328	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.329	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.330	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.331	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.332	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.333	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.334	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.335	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.336	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.337	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.338	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.339	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.340	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.341	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.342	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.343	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.344	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.345	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.346	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15346	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.347	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15347	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.348	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15348	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.349	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15349	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.350	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15350	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.351	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15351	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.352	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15352	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.353	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15353	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.354	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15354	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.355	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15355	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.356	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15356	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.357	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15357	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.358	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15358	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.359	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15359	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.360	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15360	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.361	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15361	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.362	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15362	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.363	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15363	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.364	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15364	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.365	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15365	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.366	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15366	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.367	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15367	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.368	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15368	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.369	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15369	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.370	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15370	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.371	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15371	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.372	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15372	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.373	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15373	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.374	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15374	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.375	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15375	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.376	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15376	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.377	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15377	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.378	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15378	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.379	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15379	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.380	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15380	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.381	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15381	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.382	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15382	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.383	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15383	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.384	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15384	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.385	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15385	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.386	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15386	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.387	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15387	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.388	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15388	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.389	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15389	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.390	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15390	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.391	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15391	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.392	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15392	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.393	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15393	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.394	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15394	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.395	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15395	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.396	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.397	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.398	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.399	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.400	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.401	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.402	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.403	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.404	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.405	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.406	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.407	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.408	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.409	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.410	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.411	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.412	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.413	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.414	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.415	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.416	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.417	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.418	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.419	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.420	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.421	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.422	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.423	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.424	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.425	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.426	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.427	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.428	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.429	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.430	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.431	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.432	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.433	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.434	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.435	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.436	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.437	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.438	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.439	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.440	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.441	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.442	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.443	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.444	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.445	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.446	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15446	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.447	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15447	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.448	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15448	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.449	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15449	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.450	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15450	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.451	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15451	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.452	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15452	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.453	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15453	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.454	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15454	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.455	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15455	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.456	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15456	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.457	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15457	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.458	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15458	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.459	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15459	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.460	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15460	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.461	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15461	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.462	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15462	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.463	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15463	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.464	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15464	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.465	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15465	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.466	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15466	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.467	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15467	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.468	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15468	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.469	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15469	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.470	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15470	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.471	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.472	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.473	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.474	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.475	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.476	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.477	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.478	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.479	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.480	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.481	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.482	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.483	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.484	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.485	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.486	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.487	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.488	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.489	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.490	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.491	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.492	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.493	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.494	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.495	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.496	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.497	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.498	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.499	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.500	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.501	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.502	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.503	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.504	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.505	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.506	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.507	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.508	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.509	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.510	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.511	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.512	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.513	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.514	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.515	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.516	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.517	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.518	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.519	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.520	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.521	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.521	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.522	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.522	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.523	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.523	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.524	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.524	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.525	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.525	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.526	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.526	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.527	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.527	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.528	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.528	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.529	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.529	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.530	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.530	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.531	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.531	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.532	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.532	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.533	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.533	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.534	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.534	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.535	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.535	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.536	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.536	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.537	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.537	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.538	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.538	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.539	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.539	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.540	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.540	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.541	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.541	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.542	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.542	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.543	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.543	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.544	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.544	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.545	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.5.545	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.546	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5546	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.547	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5547	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.548	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5548	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.549	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5549	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.550	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5550	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.551	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5551	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.552	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5552	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.553	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5553	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.554	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5554	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.555	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5555	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.556	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5556	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.557	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5557	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.558	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5558	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.559	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5559	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.560	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5560	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.561	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5561	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.562	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5562	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.563	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5563	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.564	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5564	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.565	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5565	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.566	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5566	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.567	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5567	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.568	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5568	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.569	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5569	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.570	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5570	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.571	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15571	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.572	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15572	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.573	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15573	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.574	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15574	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.575	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15575	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.576	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15576	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.577	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15577	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.578	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15578	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.579	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15579	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.580	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15580	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.581	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15581	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.582	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15582	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.583	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15583	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.584	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15584	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.585	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15585	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.586	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15586	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.587	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15587	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.588	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15588	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.589	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15589	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.590	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15590	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.591	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15591	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.592	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15592	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.593	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15593	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.594	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15594	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.595	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15595	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.596	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51600	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.597	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51601	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.598	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51602	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.599	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51603	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.600	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51604	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.601	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51605	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.602	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51606	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.603	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51607	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.604	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51608	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.605	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51609	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.606	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51610	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.607	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51611	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.608	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51612	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.609	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51613	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.610	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51614	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.611	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51615	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.612	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51616	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.613	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51617	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.614	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51618	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.615	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51619	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.616	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51620	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.617	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51621	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.618	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51622	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.619	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51623	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.620	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.51624	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.621	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15621	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.622	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15622	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.623	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15623	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.624	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15624	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.625	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15625	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.626	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15626	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.627	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15627	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.628	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15628	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.629	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15629	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.630	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15630	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.631	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15631	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.632	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15632	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.633	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15633	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.634	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15634	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.635	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15635	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.636	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15636	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.637	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15637	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.638	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15638	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.639	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15639	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.640	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15640	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.641	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15641	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.642	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15642	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.643	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15643	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.644	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15644	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.645	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15645	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.646	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15646	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.647	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15647	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.648	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15648	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.649	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15649	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.650	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15650	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.651	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15651	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.652	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15652	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.653	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15653	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.654	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15654	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.655	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15655	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.656	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15656	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.657	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15657	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.658	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15658	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.659	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.660	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15660	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.661	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15661	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.662	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15662	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.663	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15663	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.664	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15664	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.665	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15665	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.666	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15666	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.667	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15667	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.668	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15668	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.669	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15669	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.670	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15670	Boolean	false (2)



Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.15.671	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15671	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.672	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15672	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.673	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15673	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.674	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15674	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.675	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15675	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.676	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15676	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.677	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15677	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.678	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15678	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.679	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15679	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.680	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15680	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.681	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15681	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.682	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15682	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.683	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15683	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.684	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15684	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.685	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15685	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.686	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15686	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.687	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15687	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.688	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15688	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.689	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15689	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.690	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15690	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.691	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15691	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.692	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15692	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.693	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15693	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.694	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15694	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.695	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15695	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.696	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.697	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.698	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.699	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.700	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.701	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.702	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.703	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.704	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.705	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.706	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.707	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.708	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.709	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.710	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.711	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.712	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.713	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.714	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.715	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.716	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.717	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.718	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.719	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.720	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.721	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.722	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.723	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.724	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.725	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.726	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.727	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.728	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.729	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.730	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.731	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.732	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.733	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.734	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.735	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.736	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.737	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.738	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.739	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.740	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.741	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.742	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.743	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.744	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.745	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.15.746	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.747	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.748	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.749	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.750	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.751	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.752	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.753	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.754	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.755	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.756	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.757	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.758	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.759	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.760	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.761	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.762	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.763	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.764	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.765	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.766	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.767	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.768	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.769	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.770	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.771	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.772	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.773	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.774	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.775	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.776	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.777	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.778	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.779	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.780	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.781	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.782	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.783	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.784	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.785	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.786	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.787	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.788	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.789	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.790	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.791	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.792	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.793	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.794	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.795	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.15.796	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15796	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.797	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15797	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.798	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15798	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.799	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15799	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.800	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15800	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.801	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15801	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.802	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15802	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.803	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15803	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.804	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15804	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.805	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15805	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.806	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15806	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.807	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15807	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.808	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15808	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.809	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15809	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.810	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15810	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.811	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15811	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.812	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15812	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.813	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15813	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.814	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15814	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.815	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15815	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.816	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15816	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.817	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15817	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.818	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15818	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.819	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15819	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.820	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15820	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.821	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15821	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.822	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15822	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.823	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15823	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.824	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15824	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.825	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15825	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.826	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15826	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.827	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15827	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.828	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15828	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.829	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15829	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.830	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15830	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.831	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15831	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.832	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15832	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.833	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15833	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.834	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15834	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.835	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15835	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.836	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15836	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.837	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15837	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.838	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15838	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.839	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15839	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.840	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15840	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.841	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15841	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.842	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15842	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.843	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15843	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.844	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15844	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.845	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15845	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.846	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.846	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.847	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.847	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.848	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.848	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.849	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.849	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.850	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.850	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.851	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.851	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.852	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.852	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.853	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.853	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.854	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.854	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.855	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.855	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.856	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.856	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.857	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.857	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.858	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.858	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.859	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.859	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.860	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.860	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.861	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.861	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.862	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.862	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.863	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.863	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.864	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.864	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.865	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.865	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.866	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.866	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.867	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.867	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.868	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.868	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.869	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.869	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.870	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.870	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.871	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15871	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.872	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15872	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.873	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15873	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.874	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15874	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.875	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15875	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.876	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15876	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.877	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15877	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.878	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15878	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.879	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15879	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.880	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15880	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.881	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15881	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.882	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15882	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.883	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15883	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.884	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15884	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.885	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15885	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.886	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15886	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.887	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15887	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.888	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15888	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.889	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15889	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.890	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15890	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.891	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15891	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.892	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15892	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.893	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15893	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.894	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15894	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.895	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15895	Boolean	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.15.896	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.896	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.897	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.897	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.898	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.898	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.899	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.899	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.900	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.900	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.901	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.901	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.902	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.902	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.903	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.903	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.904	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.904	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.905	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.905	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.906	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.906	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.907	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.907	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.908	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.908	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.909	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.909	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.910	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.910	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.911	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.911	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.912	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.912	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.913	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.913	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.914	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.914	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.915	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.915	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.916	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.916	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.917	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.917	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.918	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.918	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.919	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.919	Boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.15.920	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.920	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.921	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.921	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.922	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.922	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.923	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.923	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.924	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.924	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.925	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.925	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.926	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.926	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.927	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.927	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.928	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.928	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.929	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.929	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.930	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.930	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.931	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.931	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.932	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.932	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.933	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.933	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.934	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.934	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.935	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.935	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.936	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.936	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.937	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.937	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.938	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.938	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.939	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.939	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.940	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.940	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.941	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.941	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.942	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.942	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.943	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.943	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.944	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.944	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.945	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.945	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.946	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15946	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.947	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15947	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.948	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15948	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.949	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15949	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.950	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15950	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.951	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15951	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.952	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15952	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.953	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15953	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.954	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15954	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.955	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15955	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.956	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15956	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.957	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15957	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.958	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15958	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.959	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15959	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.960	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15960	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.961	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15961	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.962	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15962	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.963	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15963	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.964	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15964	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.965	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15965	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.966	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15966	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.967	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15967	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.968	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15968	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.969	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15969	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.970	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15970	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.15.971	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15971	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.972	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15972	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.973	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15973	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.974	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15974	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.975	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15975	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.976	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15976	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.977	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15977	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.978	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15978	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.979	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15979	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.980	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15980	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.981	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15981	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.982	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15982	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.983	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15983	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.984	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15984	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.985	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15985	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.986	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15986	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.987	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15987	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.988	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15988	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.989	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15989	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.990	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15990	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.991	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15991	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.992	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15992	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.993	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15993	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.994	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15994	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.15.995	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.15995	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.996	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.996	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.997	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.997	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.998	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.998	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.999	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.999	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1000	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.1000	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1001	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.1001	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1002	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.1002	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1003	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.1003	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1004	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.1004	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1005	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.1005	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1006	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.1006	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1007	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.1007	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1008	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.1008	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1009	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.1009	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1010	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.1010	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1011	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.1011	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1012	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.1012	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1013	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.1013	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1014	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.1014	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1015	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.1015	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1016	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.1016	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1017	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.1017	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1018	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.1018	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1019	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.1019	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1020	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.1020	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1021	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151021	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1022	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151022	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1023	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151023	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1024	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151024	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1025	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151025	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1026	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151026	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1027	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151027	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1028	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151028	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1029	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1030	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151030	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1031	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151031	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1032	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1033	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151033	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1034	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151034	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1035	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151035	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1036	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151036	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1037	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151037	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1038	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151038	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1039	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151039	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1040	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151040	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1041	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151041	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1042	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151042	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1043	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151043	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1044	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151044	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1045	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151045	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1046	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151046	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1047	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151047	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1048	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151048	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1049	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151049	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1050	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151050	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1051	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151051	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1052	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1053	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151053	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1054	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151054	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1055	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151055	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1056	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151056	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1057	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151057	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1058	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151058	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1059	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151059	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1060	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151060	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1061	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151061	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1062	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151062	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1063	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151063	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1064	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151064	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1065	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151065	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1066	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151066	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1067	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151067	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1068	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151068	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1069	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151069	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1070	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151070	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1071	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151071	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1072	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151072	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1073	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151073	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1074	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151074	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1075	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151075	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1076	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151076	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1077	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151077	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1078	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151078	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1079	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151079	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1080	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151080	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1081	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151081	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1082	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151082	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1083	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151083	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1084	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151084	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1085	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151085	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1086	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151086	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1087	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151087	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1088	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151088	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1089	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151089	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1090	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151090	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1091	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151091	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1092	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1093	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151093	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1094	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151094	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1095	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151095	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1096	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1097	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1098	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1099	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1100	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1101	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1102	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1103	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1104	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1105	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1106	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1107	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1108	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1109	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1110	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1111	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1112	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1113	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1114	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1115	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1116	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1117	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1118	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1119	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1120	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1121	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1122	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1123	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1124	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1125	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1126	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1127	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1128	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1129	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1130	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1131	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1132	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1133	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1134	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1135	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1136	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1137	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1138	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1139	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1140	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1141	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1142	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1143	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1144	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1145	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1146	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1147	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1148	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1149	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1150	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1151	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1152	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1153	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1154	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1155	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1156	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1157	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1158	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1159	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1160	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1161	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1162	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1163	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1164	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1165	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1166	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1167	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1168	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1169	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1170	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1171	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1172	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1173	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1174	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1175	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1176	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1177	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1178	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1179	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1180	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1181	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1182	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1183	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1184	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1185	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1186	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1187	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1188	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1189	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1190	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1191	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1192	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1193	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1194	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1195	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1196	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151196	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1197	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151197	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1198	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151198	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1199	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151199	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1200	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151200	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1201	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151201	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1202	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151202	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1203	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151203	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1204	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151204	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1205	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151205	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1206	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151206	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1207	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151207	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1208	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151208	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1209	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1210	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151210	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1211	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151211	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1212	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151212	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1213	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151213	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1214	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151214	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1215	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151215	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1216	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151216	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1217	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151217	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1218	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151218	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1219	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151219	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1220	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151220	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1221	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510231	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1222	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510232	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1223	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510233	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1224	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510234	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1225	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510235	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1226	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510236	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1227	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510237	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1228	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510238	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1229	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510239	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1230	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510240	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1231	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510241	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1232	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510242	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1233	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510243	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1234	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510244	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1235	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510245	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1236	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510246	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1237	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510247	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1238	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510248	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1239	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510249	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1240	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510250	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1241	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510251	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1242	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510252	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1243	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510253	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1244	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510254	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1245	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1510255	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1246	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151246	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1247	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151247	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1248	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151248	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1249	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151249	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1250	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151250	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1251	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151251	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1252	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151252	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1253	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151253	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1254	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151254	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1255	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151255	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1256	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151256	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1257	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151257	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1258	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151258	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1259	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151259	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1260	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151260	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1261	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151261	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1262	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151262	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1263	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151263	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1264	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151264	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1265	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151265	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1266	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151266	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1267	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151267	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1268	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151268	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1269	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151269	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1270	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151270	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1271	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151271	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1272	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151272	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1273	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151273	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1274	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151274	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1275	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151275	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1276	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151276	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1277	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151277	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1278	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151278	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1279	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151279	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1280	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151280	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1281	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151281	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1282	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151282	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1283	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151283	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1284	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151284	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1285	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151285	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1286	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151286	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1287	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151287	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1288	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151288	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1289	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151289	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1290	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151290	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1291	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151291	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1292	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151292	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1293	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151293	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1294	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151294	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1295	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151295	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1296	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1297	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1298	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1299	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1300	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1301	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1302	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1303	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1304	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1305	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1306	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1307	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1308	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1309	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1310	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1311	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1312	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1313	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1314	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1315	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1316	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1317	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1318	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1319	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1320	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1321	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1322	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1323	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1324	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1325	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1326	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1327	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1328	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1329	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1330	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1331	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1332	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1333	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1334	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1335	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1336	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1337	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1338	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1339	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1340	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1341	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1342	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1343	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1344	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1345	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151032	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1346	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1347	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1348	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1349	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1350	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1351	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1352	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1353	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1354	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1355	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1356	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1357	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1358	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1359	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1360	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1361	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1362	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1363	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1364	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1365	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1366	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1367	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1368	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1369	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1370	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1371	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1372	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151040	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1373	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151041	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1374	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151042	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1375	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151043	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1376	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151044	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1377	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151045	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1378	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151046	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1379	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151047	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1380	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151048	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1381	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151049	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1382	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151050	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1383	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151051	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1384	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1385	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151053	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1386	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151054	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1387	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151055	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1388	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151056	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1389	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151057	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1390	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151058	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1391	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151059	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1392	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151060	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1393	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151061	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1394	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151062	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1395	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151063	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1396	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1397	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1398	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1399	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1400	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1401	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1402	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1403	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1404	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1405	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1406	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1407	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1408	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1409	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1410	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1411	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1412	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1413	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1414	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1415	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1416	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1417	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1418	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1419	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1420	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1421	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1422	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1423	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1424	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1425	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1426	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1427	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1428	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1429	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1430	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1431	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1432	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1433	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1434	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1435	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1436	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1437	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1438	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1439	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1440	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1441	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1442	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1443	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1444	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1445	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1446	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1447	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1448	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1449	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1450	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1451	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1452	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1453	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1454	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1455	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1456	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1457	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1458	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1459	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1460	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1461	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1462	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1463	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1464	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1465	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1466	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1467	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1468	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1469	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1470	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1471	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1472	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1473	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1474	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1475	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1476	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1477	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1478	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1479	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1480	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1481	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1482	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1483	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1484	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1485	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1486	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1487	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1488	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1489	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1490	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1491	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1492	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1493	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1494	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1495	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1496	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1497	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1498	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1499	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1500	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1501	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1502	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1503	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1504	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1505	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1506	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1507	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1508	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1509	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1510	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1511	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1512	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1513	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1514	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1515	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1516	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1517	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1518	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1519	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1520	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151602	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1521	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1522	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1523	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1524	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1525	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1526	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1527	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1528	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1529	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1530	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1531	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1532	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1533	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1534	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1535	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1536	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1537	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1538	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1539	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1540	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1541	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1542	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1543	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1544	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1545	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15162	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1546	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151546	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1547	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151547	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1548	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151548	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1549	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151549	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1550	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151550	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1551	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151551	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1552	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151552	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1553	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151553	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1554	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151554	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1555	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151555	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1556	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151556	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1557	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151557	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1558	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151558	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1559	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151559	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1560	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151560	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1561	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151561	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1562	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151562	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1563	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151563	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1564	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151564	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1565	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151565	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1566	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151566	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1567	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151567	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1568	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151568	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1569	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151569	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1570	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151570	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1571	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151571	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1572	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151572	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1573	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151573	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1574	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151574	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1575	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151575	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1576	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151576	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1577	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151577	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1578	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151578	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1579	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151579	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1580	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151580	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1581	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151581	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1582	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151582	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1583	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151583	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1584	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151584	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1585	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151585	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1586	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151586	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1587	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151587	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1588	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151588	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1589	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151589	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1590	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151590	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1591	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151591	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1592	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151592	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1593	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151593	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1594	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151594	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1595	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151595	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1596	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151692	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1597	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151693	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1598	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151694	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1599	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151695	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1600	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151696	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1601	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151697	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1602	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151698	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1603	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151699	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1604	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151700	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1605	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151701	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1606	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151702	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1607	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151703	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1608	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151704	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1609	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151705	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1610	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151706	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1611	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151707	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1612	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151708	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1613	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151709	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1614	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151710	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1615	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151711	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1616	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151712	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1617	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151713	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1618	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151714	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1619	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151715	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1620	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151716	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1621	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151621	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1622	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151622	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1623	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151623	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1624	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151624	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1625	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151625	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1626	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151626	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1627	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151627	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1628	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151628	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1629	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151629	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1630	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151630	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1631	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151631	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1632	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1633	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151633	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1634	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151634	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1635	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151635	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1636	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151636	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1637	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151637	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1638	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151638	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1639	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151639	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1640	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151640	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1641	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151641	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1642	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151642	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1643	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151643	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1644	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151644	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1645	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151645	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1646	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1647	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1648	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1649	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1650	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1651	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1652	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1653	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1654	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1655	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1656	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1657	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1658	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1659	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1660	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1661	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1662	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1663	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1664	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1665	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1666	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1667	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1668	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1669	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1670	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1671	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151671	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1672	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151672	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1673	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151673	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1674	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151674	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1675	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151675	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1676	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151676	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1677	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151677	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1678	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151678	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1679	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151679	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1680	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151680	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1681	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151681	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1682	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151682	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1683	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151683	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1684	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151684	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1685	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151685	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1686	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151686	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1687	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151687	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1688	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151688	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1689	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151689	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1690	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151690	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1691	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151691	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1692	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151692	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1693	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151693	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1694	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151694	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1695	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151695	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1696	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151702	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1697	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151703	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1698	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151704	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1699	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151705	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1700	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151706	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1701	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151707	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1702	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151708	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1703	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151709	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1704	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151710	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1705	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151711	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1706	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151712	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1707	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151713	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1708	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151714	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1709	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151715	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1710	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151716	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1711	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151717	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1712	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151718	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1713	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151719	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1714	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151720	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1715	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151721	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1716	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151722	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1717	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151723	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1718	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151724	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1719	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151725	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1720	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151726	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1721	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151721	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1722	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151722	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1723	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151723	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1724	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151724	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1725	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151725	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1726	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151726	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1727	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151727	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1728	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151728	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1729	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151729	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1730	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151730	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1731	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151731	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1732	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151732	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1733	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151733	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1734	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151734	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1735	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151735	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1736	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151736	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1737	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151737	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1738	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151738	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1739	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151739	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1740	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151740	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1741	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151741	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1742	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151742	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1743	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151743	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1744	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151744	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1745	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151745	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1746	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1746	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1747	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1747	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1748	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1748	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1749	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1749	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1750	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1750	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1751	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1751	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1752	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1752	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1753	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1753	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1754	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1754	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1755	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1755	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1756	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1756	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1757	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1757	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1758	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1758	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1759	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1759	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1760	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1760	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1761	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1761	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1762	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1762	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1763	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1763	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1764	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1764	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1765	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1765	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1766	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1766	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1767	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1767	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1768	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1768	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1769	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1769	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1770	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.1770	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1771	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151771	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1772	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151772	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1773	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151773	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1774	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151774	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1775	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151775	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1776	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151776	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1777	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151777	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1778	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151778	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1779	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151779	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1780	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151780	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1781	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151781	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1782	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151782	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1783	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151783	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1784	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151784	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1785	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151785	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1786	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151786	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1787	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151787	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1788	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151788	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1789	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151789	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1790	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151790	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1791	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151791	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1792	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151792	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1793	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151793	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1794	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151794	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1795	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151795	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1796	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151796	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1797	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151797	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1798	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151798	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1799	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151799	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1800	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151800	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1801	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151801	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1802	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151802	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1803	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151803	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1804	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151804	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1805	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151805	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1806	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151806	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1807	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151807	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1808	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151808	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1809	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151809	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1810	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151810	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1811	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151811	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1812	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151812	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1813	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151813	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1814	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151814	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1815	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151815	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1816	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151816	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1817	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151817	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1818	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151818	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1819	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151819	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1820	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151820	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1821	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151821	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1822	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151822	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1823	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151823	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1824	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151824	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1825	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151825	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1826	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151826	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1827	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151827	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1828	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151828	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1829	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151829	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1830	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151830	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1831	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151831	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1832	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151832	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1833	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151833	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1834	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151834	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1835	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151835	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1836	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151836	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1837	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151837	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1838	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151838	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1839	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151839	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1840	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151840	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1841	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151841	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1842	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151842	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1843	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151843	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1844	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151844	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1845	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151845	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1846	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151846	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1847	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151847	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1848	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151848	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1849	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151849	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1850	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151850	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1851	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151851	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1852	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151852	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1853	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151853	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1854	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151854	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1855	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151855	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1856	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151856	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1857	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151857	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1858	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151858	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1859	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151859	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1860	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151860	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1861	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151861	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1862	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151862	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1863	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151863	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1864	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151864	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1865	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151865	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1866	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151866	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1867	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151867	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1868	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151868	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1869	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151869	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1870	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151870	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1871	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151871	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1872	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151872	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1873	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151873	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1874	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151874	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1875	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151875	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1876	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151876	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1877	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151877	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1878	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151878	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1879	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151879	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1880	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151880	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1881	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151881	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1882	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151882	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1883	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151883	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1884	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151884	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1885	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151885	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1886	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151886	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1887	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151887	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1888	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151888	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1889	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151889	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1890	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151890	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1891	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151891	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1892	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151892	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1893	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151893	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1894	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151894	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1895	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151895	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1896	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151896	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1897	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151897	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1898	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151898	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1899	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151899	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1900	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151900	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1901	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151901	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1902	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151902	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1903	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151903	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1904	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151904	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1905	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151905	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1906	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151906	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1907	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151907	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1908	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151908	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1909	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151909	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1910	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151910	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1911	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151911	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1912	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151912	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1913	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151913	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1914	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151914	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1915	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151915	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1916	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151916	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1917	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151917	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1918	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151918	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1919	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151919	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1920	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151920	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1921	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1922	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1923	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1924	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1925	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1926	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1927	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1928	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1929	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1930	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1931	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1932	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1933	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1934	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1935	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1936	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1937	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1938	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1939	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1940	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1941	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1942	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1943	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1944	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1945	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151029	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1946	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1947	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1948	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1949	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1950	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1951	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1952	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1953	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1954	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1955	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1956	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1957	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1958	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1959	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1960	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1961	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1962	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1963	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1964	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1965	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1966	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1967	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1968	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1969	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1970	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151052	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.1971	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151071	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1972	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151072	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1973	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151073	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1974	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151074	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1975	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151075	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1976	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151076	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1977	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151077	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1978	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151078	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1979	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151079	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1980	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151080	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1981	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151081	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1982	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151082	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1983	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151083	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1984	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151084	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1985	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151085	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1986	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151086	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1987	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151087	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1988	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151088	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1989	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151089	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1990	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151090	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1991	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151091	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1992	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1993	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151093	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1994	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151094	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.1995	.2.802.1.1.13.1.5.32962.1.1.2.1.1.151095	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1996	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1997	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1998	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.1999	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2000	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2001	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2002	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2003	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2004	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2005	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2006	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2007	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2008	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2009	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2010	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2011	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2012	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2013	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2014	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2015	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2016	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2017	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2018	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2019	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2020	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2021	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152021	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2022	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152022	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2023	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152023	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2024	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152024	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2025	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152025	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2026	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152026	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2027	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152027	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2028	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152028	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2029	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2030	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152030	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2031	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152031	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2032	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2033	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152033	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2034	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152034	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2035	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152035	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2036	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152036	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2037	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152037	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2038	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152038	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2039	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152039	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2040	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152040	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2041	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152041	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2042	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152042	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2043	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152043	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2044	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152044	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2045	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152045	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2046	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2047	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2048	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2049	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2050	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2051	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2052	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2053	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2054	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2055	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2056	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2057	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2058	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2059	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2060	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2061	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2062	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2063	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2064	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2065	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2066	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2067	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2068	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2069	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2070	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2071	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152071	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2072	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152072	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2073	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152073	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2074	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152074	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2075	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152075	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2076	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152076	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2077	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152077	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2078	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152078	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2079	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152079	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2080	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152080	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2081	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152081	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2082	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152082	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2083	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152083	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2084	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152084	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2085	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152085	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2086	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152086	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2087	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152087	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2088	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152088	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2089	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152089	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2090	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152090	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2091	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152091	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2092	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2093	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152093	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2094	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152094	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2095	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152095	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2096	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152096	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2097	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152097	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2098	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152098	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2099	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152099	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2100	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152100	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2101	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152101	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2102	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152102	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2103	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152103	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2104	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152104	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2105	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152105	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2106	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152106	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2107	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152107	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2108	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152108	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2109	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152109	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2110	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152110	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2111	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152111	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2112	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152112	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2113	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152113	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2114	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152114	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2115	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152115	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2116	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152116	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2117	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152117	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2118	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152118	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2119	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152119	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2120	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152120	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2121	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2122	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2123	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2124	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2125	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2126	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2127	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2128	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2129	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2130	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2131	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2132	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2133	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2134	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2135	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2136	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2137	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2138	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2139	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2140	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2141	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2142	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2143	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2144	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2145	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2171	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2172	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2173	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2174	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2175	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2176	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2177	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2178	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2179	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2180	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2181	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2182	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2183	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2184	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2185	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2186	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2187	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2188	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2189	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2190	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2191	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2192	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2193	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2194	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2195	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2196	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2197	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2198	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2199	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2200	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2201	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2202	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2203	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2204	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2205	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2206	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2207	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2208	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2209	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2210	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2211	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2212	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2213	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2214	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2215	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2216	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2217	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2218	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2219	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2220	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15209	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2221	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2222	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2223	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2224	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2225	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2226	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2227	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2228	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2229	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2230	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2231	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2232	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2233	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2234	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2235	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2236	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2237	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2238	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2239	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2240	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2241	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2242	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2243	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2244	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2245	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52039	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2246	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52246	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2247	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52247	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2248	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52248	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2249	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52249	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2250	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52250	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2251	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52251	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2252	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52252	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2253	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52253	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2254	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52254	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2255	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52255	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2256	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52256	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2257	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52257	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2258	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52258	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2259	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52259	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2260	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52260	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2261	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52261	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2262	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52262	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2263	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52263	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2264	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52264	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2265	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52265	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2266	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52266	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2267	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52267	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2268	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52268	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2269	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52269	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2270	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52270	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2271	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152271	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2272	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152272	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2273	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152273	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2274	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152274	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2275	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152275	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2276	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152276	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2277	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152277	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2278	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152278	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2279	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152279	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2280	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152280	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2281	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152281	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2282	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152282	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2283	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152283	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2284	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152284	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2285	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152285	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2286	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152286	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2287	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152287	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2288	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152288	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2289	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152289	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2290	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152290	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2291	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152291	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2292	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152292	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2293	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152293	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2294	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152294	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2295	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152295	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2296	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152296	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2297	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152297	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2298	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152298	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2299	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152299	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2300	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152300	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2301	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152301	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2302	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152302	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2303	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152303	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2304	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152304	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2305	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152305	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2306	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152306	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2307	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152307	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2308	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152308	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2309	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152309	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2310	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152310	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2311	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152311	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2312	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152312	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2313	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152313	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2314	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152314	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2315	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152315	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2316	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152316	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2317	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152317	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2318	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152318	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2319	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152319	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2320	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152320	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2321	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2322	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2323	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2324	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2325	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2326	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2327	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2328	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2329	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2330	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2331	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2332	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2333	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2334	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2335	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2336	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2337	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2338	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2339	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2340	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2341	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2342	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2343	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2344	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2345	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152632	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2346	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52056	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2347	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52057	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2348	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52058	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2349	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52059	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2350	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52060	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2351	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52061	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2352	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52062	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2353	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52063	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2354	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52064	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2355	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52065	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2356	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52066	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2357	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52067	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2358	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52068	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2359	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52069	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2360	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52070	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2361	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52071	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2362	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52072	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2363	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52073	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2364	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52074	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2365	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52075	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2366	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52076	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2367	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52077	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2368	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52078	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2369	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52079	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2370	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52080	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2371	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52371	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2372	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52372	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2373	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52373	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2374	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52374	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2375	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52375	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2376	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52376	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2377	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52377	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2378	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52378	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2379	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52379	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2380	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52380	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2381	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52381	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2382	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52382	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2383	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52383	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2384	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52384	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2385	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52385	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2386	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52386	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2387	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52387	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2388	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52388	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2389	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52389	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2390	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52390	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2391	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52391	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2392	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52392	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2393	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52393	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2394	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52394	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2395	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52395	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2396	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152396	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2397	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152397	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2398	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152398	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2399	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152399	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2400	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152400	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2401	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152401	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2402	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152402	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2403	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152403	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2404	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152404	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2405	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152405	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2406	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152406	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2407	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152407	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2408	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152408	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2409	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152409	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2410	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152410	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2411	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152411	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2412	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152412	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2413	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152413	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2414	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152414	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2415	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152415	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2416	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152416	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2417	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152417	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2418	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152418	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2419	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152419	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2420	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152420	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2421	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2422	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2423	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2424	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2425	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2426	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2427	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2428	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2429	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2430	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2431	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2432	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2433	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2434	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2435	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2436	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2437	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2438	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2439	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2440	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2441	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2442	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2443	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2444	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2445	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2446	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2447	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2448	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2449	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2450	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2451	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2452	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2453	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2454	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2455	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2456	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2457	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2458	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2459	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2460	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2461	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2462	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2463	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2464	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2465	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2466	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2467	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2468	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2469	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2470	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2471	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152471	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2472	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152472	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2473	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152473	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2474	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152474	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2475	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152475	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2476	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152476	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2477	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152477	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2478	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152478	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2479	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152479	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2480	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152480	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2481	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152481	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2482	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152482	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2483	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152483	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2484	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152484	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2485	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152485	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2486	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152486	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2487	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152487	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2488	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152488	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2489	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152489	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2490	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152490	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2491	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152491	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2492	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152492	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2493	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152493	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2494	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152494	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2495	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152495	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2496	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52696	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2497	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52697	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2498	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52698	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2499	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52699	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2500	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52700	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2501	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52701	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2502	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52702	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2503	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52703	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2504	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52704	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2505	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52705	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2506	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52706	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2507	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52707	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2508	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52708	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2509	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52709	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2510	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52710	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2511	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52711	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2512	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52712	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2513	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52713	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2514	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52714	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2515	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52715	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2516	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52716	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2517	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52717	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2518	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52718	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2519	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52719	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2520	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52720	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2521	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2522	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2523	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2524	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2525	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2526	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2527	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2528	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2529	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2530	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2531	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2532	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2533	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2534	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2535	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2536	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2537	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2538	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2539	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2540	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2541	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2542	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2543	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2544	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2545	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2546	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52656	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2547	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52657	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2548	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52658	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2549	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52659	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2550	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52660	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2551	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52661	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2552	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52662	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2553	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52663	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2554	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52664	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2555	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52665	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2556	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52666	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2557	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52667	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2558	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52668	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2559	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52669	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2560	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52670	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2561	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52671	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2562	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52672	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2563	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52673	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2564	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52674	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2565	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52675	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2566	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52676	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2567	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52677	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2568	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52678	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2569	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52679	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2570	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52680	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2571	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52671	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2572	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52672	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2573	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52673	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2574	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52674	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2575	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52675	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2576	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52676	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2577	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52677	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2578	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52678	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2579	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52679	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2580	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52680	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2581	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52681	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2582	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52682	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2583	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52683	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2584	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52684	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2585	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52685	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2586	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52686	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2587	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52687	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2588	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52688	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2589	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52689	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2590	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52690	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2591	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52691	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2592	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52692	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2593	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52693	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2594	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52694	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2595	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52695	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2596	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52696	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2597	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52697	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2598	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52698	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2599	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52699	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2600	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52700	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2601	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52701	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2602	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52702	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2603	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52703	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2604	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52704	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2605	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52705	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2606	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52706	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2607	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52707	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2608	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52708	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2609	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52709	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2610	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52710	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2611	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52711	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2612	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52712	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2613	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52713	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2614	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52714	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2615	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52715	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2616	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52716	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2617	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52717	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2618	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52718	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2619	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52719	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2620	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52720	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2621	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52621	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2622	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52622	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2623	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52623	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2624	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52624	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2625	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52625	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2626	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52626	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2627	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52627	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2628	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52628	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2629	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52629	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2630	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52630	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2631	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52631	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2632	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2633	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52633	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2634	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52634	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2635	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52635	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2636	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52636	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2637	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52637	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2638	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52638	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2639	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52639	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2640	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52640	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2641	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52641	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2642	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52642	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2643	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52643	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2644	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52644	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2645	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52645	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2646	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2646	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2647	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2647	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2648	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2648	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2649	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2649	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2650	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2650	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2651	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2651	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2652	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2652	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2653	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2653	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2654	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2654	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2655	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2655	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2656	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2656	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2657	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2657	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2658	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2658	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2659	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2659	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2660	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2660	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2661	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2661	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2662	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2662	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2663	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2663	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2664	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2664	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2665	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2665	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2666	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2666	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2667	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2667	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2668	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2668	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2669	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2669	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2670	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2670	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2671	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2671	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2672	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2672	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2673	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2673	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2674	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2674	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2675	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2675	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2676	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2676	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2677	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2677	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2678	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2678	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2679	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2679	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2680	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2680	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2681	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2681	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2682	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2682	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2683	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2683	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2684	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2684	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2685	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2685	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2686	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2686	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2687	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2687	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2688	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2688	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2689	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2689	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2690	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2690	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2691	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2691	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2692	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2692	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2693	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2693	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2694	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2694	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2695	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.2695	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2696	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527696	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2697	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527697	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2698	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527698	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2699	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527699	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2700	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527700	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2701	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527701	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2702	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527702	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2703	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527703	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2704	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527704	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2705	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527705	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2706	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527706	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2707	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527707	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2708	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527708	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2709	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527709	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2710	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527710	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2711	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527711	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2712	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527712	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2713	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527713	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2714	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527714	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2715	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527715	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2716	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527716	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2717	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527717	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2718	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527718	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2719	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527719	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2720	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.527720	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2721	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52721	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2722	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52722	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2723	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52723	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2724	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52724	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2725	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52725	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2726	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52726	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2727	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52727	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2728	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52728	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2729	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52729	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2730	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52730	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2731	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52731	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2732	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52732	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2733	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52733	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2734	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52734	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2735	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52735	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2736	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52736	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2737	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52737	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2738	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52738	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2739	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52739	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2740	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52740	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2741	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52741	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2742	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52742	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2743	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52743	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2744	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52744	Integer	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.2745	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52745	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2746	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52746	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2747	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52747	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2748	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52748	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2749	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52749	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2750	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52750	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2751	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52751	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2752	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52752	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2753	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52753	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2754	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52754	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2755	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52755	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2756	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52756	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2757	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52757	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2758	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52758	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2759	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52759	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2760	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52760	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2761	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52761	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2762	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52762	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2763	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52763	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2764	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52764	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2765	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52765	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2766	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52766	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2767	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52767	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2768	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52768	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2769	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52769	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2770	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52770	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2771	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52771	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2772	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52772	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2773	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52773	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2774	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52774	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2775	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52775	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2776	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52776	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2777	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52777	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2778	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52778	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2779	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52779	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2780	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52780	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2781	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52781	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2782	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52782	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2783	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52783	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2784	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52784	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2785	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52785	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2786	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52786	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2787	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52787	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2788	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52788	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2789	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52789	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2790	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52790	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2791	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52791	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2792	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52792	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2793	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52793	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2794	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52794	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2795	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52795	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2796	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152796	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2797	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152797	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2798	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152798	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2799	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152799	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2800	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152800	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2801	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152801	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2802	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152802	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2803	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152803	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2804	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152804	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2805	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152805	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2806	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152806	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2807	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152807	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2808	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152808	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2809	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152809	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2810	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152810	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2811	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152811	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2812	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152812	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2813	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152813	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2814	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152814	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2815	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152815	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2816	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152816	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2817	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152817	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2818	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152818	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2819	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152819	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2820	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152820	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2821	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52821	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2822	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52822	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2823	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52823	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2824	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52824	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2825	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52825	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2826	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52826	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2827	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52827	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2828	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52828	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2829	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52829	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2830	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52830	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2831	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52831	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2832	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52832	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2833	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52833	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2834	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52834	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2835	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52835	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2836	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52836	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2837	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52837	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2838	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52838	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2839	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52839	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2840	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52840	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2841	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52841	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2842	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52842	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2843	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52843	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2844	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52844	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2845	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52845	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2846	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2846	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2847	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2847	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2848	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2848	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2849	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2849	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2850	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2850	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2851	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2851	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2852	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2852	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2853	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2853	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2854	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2854	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2855	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2855	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2856	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2856	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2857	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2857	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2858	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2858	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2859	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2859	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2860	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2860	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2861	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2861	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2862	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2862	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2863	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2863	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2864	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2864	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2865	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2865	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2866	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2866	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2867	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2867	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2868	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2868	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2869	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2869	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2870	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.15.2870	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2871	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152871	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2872	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152872	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2873	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152873	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2874	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152874	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2875	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152875	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2876	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152876	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2877	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152877	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2878	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152878	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2879	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152879	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2880	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152880	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2881	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152881	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2882	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152882	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2883	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152883	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2884	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152884	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2885	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152885	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2886	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152886	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2887	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152887	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2888	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152888	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2889	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152889	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2890	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152890	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2891	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152891	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2892	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152892	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2893	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152893	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2894	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152894	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2895	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152895	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2896	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152896	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2897	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152897	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2898	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152898	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2899	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152899	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2900	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152900	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2901	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152901	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2902	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152902	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2903	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152903	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2904	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152904	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2905	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152905	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2906	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152906	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2907	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152907	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2908	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152908	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2909	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152909	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2910	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152910	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2911	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152911	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2912	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152912	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2913	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152913	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2914	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152914	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2915	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152915	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2916	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152916	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2917	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152917	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2918	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152918	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2919	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152919	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2920	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152920	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2921	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2922	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2923	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2924	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2925	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2926	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2927	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2928	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2929	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2930	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2931	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2932	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2933	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2934	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2935	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2936	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2937	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2938	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2939	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2940	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2941	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2942	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2943	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2944	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2945	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2946	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52946	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2947	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52947	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2948	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52948	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2949	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52949	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2950	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52950	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2951	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52951	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2952	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52952	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2953	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52953	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2954	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52954	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2955	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52955	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2956	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52956	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2957	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52957	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2958	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52958	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2959	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52959	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2960	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52960	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2961	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52961	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2962	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52962	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2963	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52963	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2964	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52964	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2965	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52965	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2966	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52966	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2967	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52967	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2968	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52968	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2969	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52969	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2970	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.52970	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2971	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2972	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2973	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2974	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2975	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2976	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2977	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2978	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2979	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2980	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2981	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2982	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2983	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2984	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2985	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2986	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2987	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2988	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2989	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2990	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2991	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2992	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2993	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2994	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2995	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.2996	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152996	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2997	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152997	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2998	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152998	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.2999	.2.802.1.1.13.1.5.32962.1.1.2.1.1.152999	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3000	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153000	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3001	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153001	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3002	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153002	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3003	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153003	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3004	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153004	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3005	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153005	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3006	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153006	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3007	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153007	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3008	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153008	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3009	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153009	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3010	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153010	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3011	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153011	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3012	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153012	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3013	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153013	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3014	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153014	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3015	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153015	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3016	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153016	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3017	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153017	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3018	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153018	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3019	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153019	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3020	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153020	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3021	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153021	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3022	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153022	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3023	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153023	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3024	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153024	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3025	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153025	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3026	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153026	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3027	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153027	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3028	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153028	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3029	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153029	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3030	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153030	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3031	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153031	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3032	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153032	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3033	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153033	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3034	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153034	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3035	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153035	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3036	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153036	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3037	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153037	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3038	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153038	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3039	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3040	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153040	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3041	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153041	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3042	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153042	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3043	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153043	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3044	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153044	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3045	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153045	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3046	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153046	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3047	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153047	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3048	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153048	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3049	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153049	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3050	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153050	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3051	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153051	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3052	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153052	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3053	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153053	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3054	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153054	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3055	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153055	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3056	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153056	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3057	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153057	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3058	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153058	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3059	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153059	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3060	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153060	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3061	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153061	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3062	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153062	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3063	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153063	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3064	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153064	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3065	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153065	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3066	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153066	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3067	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153067	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3068	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153068	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3069	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153069	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3070	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153070	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3071	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153071	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3072	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153072	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3073	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153073	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3074	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153074	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3075	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153075	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3076	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153076	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3077	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153077	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3078	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153078	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3079	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153079	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3080	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153080	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3081	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153081	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3082	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153082	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3083	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153083	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3084	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153084	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3085	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153085	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3086	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153086	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3087	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153087	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3088	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153088	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3089	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153089	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3090	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153090	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3091	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153091	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3092	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153092	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3093	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153093	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3094	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153094	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3095	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153095	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3096	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153096	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3097	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153097	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3098	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153098	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3099	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153099	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3100	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153100	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3101	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153101	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3102	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153102	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3103	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153103	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3104	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153104	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3105	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153105	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3106	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153106	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3107	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153107	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3108	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153108	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3109	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153109	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3110	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153110	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3111	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153111	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3112	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153112	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3113	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153113	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3114	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153114	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3115	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153115	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3116	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153116	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3117	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153117	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3118	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153118	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3119	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153119	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3120	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153120	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3121	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3121	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3122	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3122	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3123	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3123	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3124	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3124	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3125	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3125	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3126	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3126	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3127	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3127	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3128	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3128	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3129	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3129	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3130	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3130	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3131	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3131	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3132	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3132	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3133	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3133	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3134	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3134	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3135	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3135	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3136	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3136	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3137	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3137	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3138	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3138	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3139	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3139	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3140	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3140	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3141	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3141	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3142	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3142	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3143	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3143	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3144	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3144	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3145	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3145	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3146	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15015	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3147	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15016	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3148	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15017	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3149	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15018	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3150	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15019	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3151	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15020	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3152	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15021	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3153	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15022	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3154	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15023	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3155	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15024	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3156	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15025	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3157	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15026	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3158	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15027	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3159	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15028	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3160	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15029	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3161	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15030	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3162	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15031	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3163	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15032	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3164	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15033	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3165	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15034	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3166	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15035	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3167	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15036	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3168	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15037	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3169	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15038	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3170	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15039	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3171	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3171	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3172	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3172	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3173	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3173	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3174	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3174	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3175	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3175	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3176	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3176	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3177	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3177	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3178	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3178	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3179	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3179	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3180	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3180	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3181	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3181	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3182	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3182	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3183	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3183	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3184	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3184	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3185	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3185	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3186	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3186	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3187	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3187	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3188	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3188	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3189	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3189	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3190	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3190	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3191	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3191	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3192	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3192	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3193	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3193	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3194	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3194	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3195	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3195	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3196	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153196	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3197	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153197	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3198	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153198	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3199	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153199	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3200	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153200	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3201	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153201	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3202	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153202	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3203	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153203	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3204	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153204	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3205	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153205	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3206	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153206	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3207	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153207	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3208	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153208	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3209	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153209	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3210	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153210	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3211	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153211	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3212	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153212	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3213	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153213	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3214	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153214	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3215	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153215	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3216	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153216	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3217	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153217	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3218	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153218	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3219	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153219	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3220	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153220	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3221	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50231	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3222	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50232	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3223	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50233	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3224	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50234	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3225	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50235	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3226	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50236	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3227	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50237	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3228	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50238	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3229	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50239	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3230	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50240	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3231	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50241	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3232	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50242	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3233	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50243	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3234	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50244	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3235	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50245	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3236	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50246	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3237	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50247	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3238	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50248	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3239	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50249	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3240	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50250	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3241	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50251	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3242	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50252	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3243	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50253	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3244	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50254	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3245	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50255	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3246	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153246	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3247	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153247	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3248	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153248	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3249	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153249	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3250	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153250	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3251	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153251	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3252	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153252	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3253	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153253	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3254	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153254	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3255	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153255	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3256	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153256	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3257	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153257	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3258	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153258	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3259	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153259	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3260	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153260	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3261	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153261	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3262	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153262	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3263	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153263	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3264	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153264	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3265	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153265	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3266	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153266	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3267	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153267	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3268	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153268	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3269	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153269	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3270	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153270	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3271	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53271	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3272	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53272	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3273	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53273	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3274	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53274	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3275	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53275	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3276	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53276	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3277	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53277	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3278	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53278	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3279	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53279	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3280	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53280	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3281	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53281	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3282	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53282	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3283	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53283	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3284	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53284	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3285	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53285	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3286	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53286	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3287	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53287	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3288	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53288	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3289	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53289	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3290	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53290	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3291	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53291	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3292	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53292	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3293	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53293	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3294	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53294	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3295	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53295	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3296	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153296	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3297	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153297	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3298	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153298	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3299	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153299	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3300	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153300	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3301	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153301	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3302	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153302	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3303	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153303	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3304	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153304	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3305	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153305	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3306	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153306	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3307	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153307	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3308	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153308	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3309	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153309	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3310	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153310	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3311	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153311	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3312	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153312	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3313	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153313	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3314	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153314	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3315	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153315	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3316	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153316	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3317	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153317	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3318	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153318	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3319	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153319	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3320	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153320	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3321	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50029	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3322	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50030	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3323	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50031	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3324	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50032	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3325	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50033	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3326	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50034	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3327	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50035	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3328	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50036	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3329	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50037	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3330	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50038	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3331	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3332	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50040	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3333	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50041	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3334	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50042	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3335	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50043	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3336	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50044	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3337	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50045	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3338	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50046	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3339	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50047	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3340	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50048	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3341	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50049	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3342	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50050	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3343	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50051	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3344	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50052	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3345	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50053	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3346	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50046	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3347	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50047	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3348	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50048	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3349	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50049	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3350	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50050	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3351	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50051	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3352	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50052	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3353	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50053	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3354	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50054	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3355	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50055	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3356	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50056	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3357	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50057	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3358	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50058	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3359	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50059	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3360	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50060	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3361	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50061	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3362	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50062	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3363	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50063	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3364	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50064	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3365	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50065	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3366	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50066	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3367	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50067	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3368	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50068	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3369	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50069	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3370	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50070	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3371	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50071	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3372	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50072	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3373	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50073	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3374	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50074	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3375	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50075	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3376	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50076	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3377	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50077	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3378	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50078	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3379	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50079	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3380	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50080	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3381	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50081	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3382	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50082	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3383	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50083	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3384	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50084	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3385	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50085	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3386	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50086	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3387	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50087	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3388	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50088	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3389	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50089	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3390	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50090	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3391	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50091	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3392	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50092	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3393	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50093	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3394	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50094	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3395	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50095	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3396	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153396	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3397	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153397	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3398	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153398	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3399	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153399	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3400	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153400	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3401	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153401	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3402	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153402	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3403	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153403	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3404	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153404	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3405	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153405	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3406	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153406	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3407	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153407	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3408	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153408	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3409	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153409	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3410	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153410	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3411	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153411	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3412	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153412	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3413	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153413	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3414	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153414	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3415	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153415	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3416	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153416	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3417	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153417	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3418	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153418	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3419	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153419	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3420	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153420	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3421	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3421	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3422	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3422	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3423	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3423	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3424	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3424	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3425	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3425	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3426	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3426	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3427	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3427	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3428	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3428	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3429	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3429	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3430	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3430	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3431	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3431	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3432	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3432	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3433	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3433	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3434	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3434	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3435	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3435	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3436	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3436	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3437	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3437	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3438	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3438	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3439	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3439	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3440	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3440	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3441	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3441	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3442	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3442	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3443	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3443	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3444	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3444	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3445	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3445	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3446	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50459	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3447	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50460	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3448	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50461	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3449	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50462	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3450	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50463	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3451	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50464	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3452	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50465	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3453	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50466	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3454	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50467	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3455	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50468	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3456	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50469	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3457	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50470	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3458	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50471	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3459	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50472	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3460	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50473	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3461	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50474	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3462	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50475	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3463	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50476	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3464	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50477	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3465	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50478	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3466	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50479	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3467	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50480	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3468	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50481	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3469	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50482	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3470	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50483	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3471	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3471	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3472	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3472	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3473	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3473	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3474	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3474	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3475	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3475	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3476	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3476	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3477	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3477	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3478	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3478	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3479	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3479	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3480	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3480	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3481	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3481	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3482	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3482	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3483	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3483	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3484	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3484	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3485	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3485	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3486	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3486	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3487	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3487	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3488	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3488	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3489	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3489	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3490	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3490	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3491	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3491	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3492	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3492	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3493	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3493	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3494	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3494	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3495	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3495	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3496	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50692	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3497	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50693	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3498	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50694	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3499	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50695	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3500	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50696	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3501	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50697	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3502	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50698	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3503	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50699	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3504	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50700	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3505	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50701	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3506	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50702	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3507	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50703	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3508	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50704	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3509	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50705	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3510	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50706	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3511	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50707	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3512	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50708	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3513	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50709	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3514	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50710	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3515	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50711	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3516	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50712	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3517	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50713	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3518	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50714	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3519	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50715	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3520	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50716	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3521	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50621	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3522	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50622	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3523	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50623	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3524	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50624	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3525	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50625	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3526	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50626	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3527	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50627	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3528	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50628	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3529	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50629	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3530	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50630	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3531	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50631	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3532	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3533	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50633	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3534	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50634	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3535	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50635	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3536	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50636	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3537	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50637	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3538	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50638	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3539	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50639	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3540	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50640	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3541	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50641	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3542	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50642	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3543	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50643	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3544	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50644	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3545	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50645	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3546	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50654	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3547	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50657	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3548	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50658	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3549	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3550	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3551	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3552	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3553	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3554	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3555	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3556	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3557	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3558	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3559	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3560	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3561	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3562	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3563	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3564	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3565	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3566	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3567	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3568	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3569	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3570	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50659	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3571	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50671	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3572	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50672	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3573	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50673	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3574	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50674	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3575	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50675	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3576	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50676	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3577	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50677	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3578	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50678	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3579	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50679	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3580	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50680	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3581	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50681	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3582	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50682	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3583	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50683	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3584	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50684	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3585	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50685	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3586	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50686	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3587	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50687	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3588	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50688	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3589	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50689	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3590	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50690	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3591	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50691	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3592	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50692	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3593	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50693	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3594	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50694	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3595	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50695	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3596	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53596	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3597	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53597	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3598	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53598	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3599	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53599	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3600	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53600	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3601	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53601	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3602	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53602	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3603	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53603	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3604	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53604	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3605	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53605	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3606	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53606	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3607	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53607	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3608	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53608	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3609	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53609	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3610	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53610	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3611	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53611	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3612	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53612	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3613	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53613	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3614	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53614	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3615	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53615	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3616	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53616	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3617	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53617	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3618	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53618	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3619	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53619	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3620	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53620	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3621	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3621	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3622	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3622	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3623	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3623	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3624	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3624	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3625	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3625	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3626	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3626	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3627	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3627	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3628	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3628	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3629	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3629	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3630	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3630	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3631	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3631	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3632	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3633	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3633	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3634	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3634	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3635	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3635	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3636	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3636	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3637	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3637	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3638	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3638	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3639	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3639	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3640	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3640	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3641	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3641	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3642	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3642	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3643	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3643	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3644	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3644	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.15.3645	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3645	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3646	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3646	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3647	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3647	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3648	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3648	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3649	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3649	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3650	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3650	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3651	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3651	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3652	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3652	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3653	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3653	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3654	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3654	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3655	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3655	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3656	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3656	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3657	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3657	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3658	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3658	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3659	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3660	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3660	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3661	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3661	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3662	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3662	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3663	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3663	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3664	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3664	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3665	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3665	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3666	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3666	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3667	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3667	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3668	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3668	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3669	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3669	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3670	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3670	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3671	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3671	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3672	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3672	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3673	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3673	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3674	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3674	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3675	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3675	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3676	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3676	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3677	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3677	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3678	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3678	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3679	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3679	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3680	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3680	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3681	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3681	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3682	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3682	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3683	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3683	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3684	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3684	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3685	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3685	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3686	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3686	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3687	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3687	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3688	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3688	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3689	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3689	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3690	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3690	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3691	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3691	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3692	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3692	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3693	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3693	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3694	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3694	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3695	.2.802.1.1.13.1.5.32962.1.1.2.1.1.15.3695	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3696	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53696	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3697	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53697	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3698	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53698	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3699	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53699	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3700	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53700	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3701	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53701	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3702	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53702	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3703	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53703	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3704	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53704	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3705	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53705	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3706	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53706	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3707	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53707	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3708	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53708	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3709	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53709	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3710	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53710	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3711	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53711	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3712	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53712	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3713	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53713	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3714	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53714	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3715	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53715	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3716	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53716	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3717	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53717	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3718	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53718	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3719	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53719	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3720	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53720	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3721	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3721	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3722	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3722	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3723	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3723	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3724	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3724	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3725	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3725	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3726	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3726	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3727	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3727	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3728	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3728	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3729	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3729	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3730	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3730	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3731	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3731	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3732	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3732	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3733	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3733	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3734	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3734	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3735	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3735	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3736	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3736	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3737	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3737	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3738	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3738	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3739	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3739	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3740	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3740	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3741	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3741	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3742	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3742	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3743	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3743	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3744	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3744	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3745	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3745	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3746	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50746	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3747	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50747	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3748	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50748	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3749	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50749	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3750	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50750	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3751	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50751	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3752	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50752	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3753	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50753	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3754	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50754	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3755	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50755	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3756	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50756	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3757	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50757	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3758	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50758	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3759	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50759	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3760	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50760	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3761	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50761	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3762	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50762	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3763	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50763	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3764	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50764	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3765	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50765	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3766	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50766	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3767	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50767	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3768	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50768	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3769	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50769	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3770	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50770	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3771	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53771	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3772	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53772	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3773	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53773	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3774	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53774	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3775	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53775	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3776	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53776	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3777	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53777	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3778	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53778	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3779	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53779	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3780	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53780	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3781	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53781	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3782	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53782	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3783	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53783	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3784	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53784	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3785	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53785	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3786	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53786	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3787	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53787	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3788	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53788	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3789	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53789	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3790	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53790	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3791	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53791	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3792	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53792	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3793	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53793	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3794	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53794	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3795	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.53795	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3796	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153796	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3797	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153797	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3798	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153798	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3799	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153799	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3800	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153800	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3801	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153801	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3802	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153802	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3803	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153803	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3804	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153804	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3805	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153805	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3806	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153806	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3807	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153807	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3808	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153808	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3809	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153809	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3810	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153810	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3811	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153811	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3812	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153812	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3813	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153813	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3814	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153814	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3815	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153815	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3816	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153816	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3817	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153817	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3818	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153818	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3819	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153819	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3820	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153820	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3821	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50821	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3822	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50822	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3823	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50823	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3824	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50824	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3825	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50825	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3826	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50826	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3827	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50827	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3828	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50828	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3829	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50829	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3830	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50830	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3831	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50831	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3832	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50832	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3833	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50833	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3834	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50834	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3835	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50835	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3836	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50836	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3837	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50837	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3838	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50838	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3839	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50839	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3840	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50840	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3841	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50841	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3842	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50842	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3843	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50843	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3844	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50844	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3845	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50845	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3846	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50846	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3847	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50847	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3848	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50848	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3849	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50849	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3850	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50850	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3851	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50851	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3852	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50852	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3853	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50853	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3854	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50854	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3855	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50855	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3856	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50856	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3857	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50857	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3858	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50858	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3859	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50859	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3860	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50860	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3861	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50861	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3862	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50862	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3863	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50863	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3864	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50864	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3865	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50865	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3866	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50866	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3867	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50867	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3868	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50868	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3869	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50869	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3870	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50870	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3871	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153871	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3872	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153872	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3873	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153873	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3874	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153874	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3875	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153875	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3876	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153876	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3877	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153877	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3878	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153878	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3879	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153879	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3880	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153880	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3881	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153881	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3882	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153882	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3883	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153883	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3884	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153884	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3885	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153885	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3886	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153886	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3887	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153887	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3888	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153888	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3889	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153889	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3890	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153890	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3891	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153891	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3892	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153892	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3893	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153893	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3894	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153894	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3895	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153895	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3896	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153896	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3897	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153897	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3898	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153898	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3899	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153899	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3900	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153900	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3901	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153901	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3902	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153902	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3903	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153903	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3904	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153904	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3905	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153905	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3906	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153906	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3907	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153907	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3908	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153908	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3909	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153909	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3910	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153910	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3911	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153911	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3912	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153912	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3913	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153913	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3914	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153914	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3915	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153915	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3916	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153916	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3917	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153917	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3918	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153918	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3919	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153919	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3920	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153920	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3921	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50029	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3922	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50030	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3923	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50031	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3924	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50032	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3925	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50033	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3926	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50034	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3927	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50035	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3928	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50036	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3929	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50037	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3930	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50038	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3931	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3932	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50040	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3933	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50041	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3934	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50042	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3935	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50043	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3936	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50044	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3937	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50045	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3938	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50046	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3939	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50047	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3940	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50048	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3941	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50049	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3942	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50050	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3943	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50051	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3944	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50052	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3945	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50053	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3946	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50956	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3947	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50957	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3948	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50958	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3949	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50959	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3950	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50960	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3951	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50961	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3952	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50962	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3953	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50963	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3954	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50964	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3955	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50965	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3956	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50966	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3957	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50967	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3958	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50968	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3959	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50969	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3960	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50970	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3961	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50971	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3962	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50972	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3963	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50973	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3964	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50974	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3965	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50975	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3966	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50976	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3967	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50977	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3968	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50978	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3969	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50979	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3970	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.50980	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3971	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3971	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3972	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3972	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3973	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3973	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3974	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3974	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3975	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3975	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3976	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3976	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3977	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3977	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3978	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3978	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3979	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3979	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3980	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3980	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3981	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3981	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3982	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3982	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3983	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3983	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3984	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3984	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3985	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3985	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3986	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3986	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3987	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3987	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3988	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3988	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3989	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3989	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3990	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3990	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3991	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3991	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3992	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3992	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3993	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3993	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3994	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3994	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3995	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.5.3995	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.3996	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153996	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3997	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153997	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3998	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153998	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.3999	.2.802.1.1.13.1.5.32962.1.1.2.1.1.153999	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4000	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154000	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4001	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154001	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4002	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154002	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4003	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154003	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4004	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154004	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4005	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154005	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4006	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154006	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4007	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154007	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4008	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154008	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4009	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154009	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4010	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154010	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4011	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154011	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4012	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154012	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4013	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154013	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4014	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154014	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4015	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154015	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4016	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154016	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4017	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154017	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4018	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154018	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4019	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154019	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4020	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154020	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.4021	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154021	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4022	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154022	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4023	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154023	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4024	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154024	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4025	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154025	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4026	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154026	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4027	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154027	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4028	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154028	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4029	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154029	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4030	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154030	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4031	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154031	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4032	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4033	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154033	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4034	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154034	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4035	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154035	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4036	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154036	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4037	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154037	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4038	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154038	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4039	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154039	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4040	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154040	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4041	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154041	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4042	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154042	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4043	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154043	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4044	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154044	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4045	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154045	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.4046	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154046	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4047	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154047	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4048	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154048	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4049	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154049	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4050	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154050	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4051	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154051	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4052	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4053	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154053	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4054	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154054	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4055	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154055	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4056	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154056	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4057	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154057	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4058	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154058	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4059	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154059	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4060	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154060	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4061	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154061	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4062	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154062	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4063	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154063	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4064	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154064	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4065	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154065	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4066	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154066	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4067	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154067	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4068	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154068	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4069	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154069	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4070	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154070	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.15.4071	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154071	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4072	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154072	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4073	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154073	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4074	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154074	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4075	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154075	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4076	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154076	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4077	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154077	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4078	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154078	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4079	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154079	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4080	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154080	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4081	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154081	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4082	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154082	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4083	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154083	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4084	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154084	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4085	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154085	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4086	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154086	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4087	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154087	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4088	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154088	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4089	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154089	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4090	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154090	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4091	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154091	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4092	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4093	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154093	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.15.4094	.2.802.1.1.13.1.5.32962.1.1.2.1.1.154094	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.0	.2.802.1.1.13.1.5.32962.1.1.2.1.1.160	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.5	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.5	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.6	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.6	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.7	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.7	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.8	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.8	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.9	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.9	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.10	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.10	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.11	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.11	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.12	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.12	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.13	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.13	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.14	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.14	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.15	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.16	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.17	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.18	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.18	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.19	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.19	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.20	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.20	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.21	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.21	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.22	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.22	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.23	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.23	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.24	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.24	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.25	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.25	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.26	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.26	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.27	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.27	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.28	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.28	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.29	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.29	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.30	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.30	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.31	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.31	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.32	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.32	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.33	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.33	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.34	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.34	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.35	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.35	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.36	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.36	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.37	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.38	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.38	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.39	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.39	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.40	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.40	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.41	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.41	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.42	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.42	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.43	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.43	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.44	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.44	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.45	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.45	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.46	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.46	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.47	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.47	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.48	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.48	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.49	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.49	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.50	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.50	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.16.51	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.51	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.52	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.52	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.53	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.53	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.54	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.54	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.55	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.55	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.56	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.56	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.57	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.57	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.58	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.58	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.59	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.59	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.60	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.60	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.61	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.61	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.62	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.62	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.63	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.63	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.64	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.64	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.65	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.65	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.66	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.66	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.67	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.67	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.68	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.68	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.69	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.69	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.70	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.70	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.71	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.71	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.72	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.72	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.73	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.73	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.74	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.74	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.16.75	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.75	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.76	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.76	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.77	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.77	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.78	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.78	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.79	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.79	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.80	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.80	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.81	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.81	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.82	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.82	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.83	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.83	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.84	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.84	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.85	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.85	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.86	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.86	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.87	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.87	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.88	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.88	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.89	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.89	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.90	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.90	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.91	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.91	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.92	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.92	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.93	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.93	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.94	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.94	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.95	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.95	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.96	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.96	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.97	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.97	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.98	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.98	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.99	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.99	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.100	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.100	Integer	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.16.101	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.102	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.103	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.104	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.105	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.106	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.107	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.108	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.109	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.110	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.111	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.112	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.113	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.114	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.115	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.116	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.117	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.118	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.119	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.120	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.121	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.122	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.123	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.124	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.125	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.126	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.127	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.128	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.129	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.130	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.131	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.132	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.133	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.134	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.135	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.136	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.137	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.138	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.139	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.140	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.141	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.142	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.143	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.144	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.145	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.146	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.147	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.148	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.149	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.150	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.151	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.152	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.153	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.154	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.155	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.156	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.157	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.158	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.159	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.160	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.161	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.162	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.163	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.164	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.165	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.166	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.167	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.168	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.169	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.170	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.171	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.172	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.173	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.174	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.175	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.176	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.177	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.178	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.179	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.180	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.181	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.182	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.183	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.184	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.185	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.186	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.187	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.188	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.189	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.190	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.191	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.192	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.193	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.194	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.195	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.196	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.197	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.198	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.199	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.200	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.16.201	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16201	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.202	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16202	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.203	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16203	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.204	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16204	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.205	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16205	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.206	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16206	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.207	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16207	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.208	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16208	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.209	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16209	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.210	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16210	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.211	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16211	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.212	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16212	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.213	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16213	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.214	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16214	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.215	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16215	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.216	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16216	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.217	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16217	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.218	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16218	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.219	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16219	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.220	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16220	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.221	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16221	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.222	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16222	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.223	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16223	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.224	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16224	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.225	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16225	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.226	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16226	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.227	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16227	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.228	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16228	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.229	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16229	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.230	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16230	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.231	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16231	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.232	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16232	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.233	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16233	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.234	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16234	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.235	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16235	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.236	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16236	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.237	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16237	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.238	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16238	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.239	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16239	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.240	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16240	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.241	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16241	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.242	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16242	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.243	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16243	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.244	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16244	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.245	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16245	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.246	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16246	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.247	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16247	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.248	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16248	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.249	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16249	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.250	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16250	boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.251	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16251	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.252	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16252	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.253	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16253	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.254	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16254	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.255	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16255	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.256	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16256	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.257	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16257	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.258	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16258	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.259	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16259	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.260	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16260	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.261	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16261	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.262	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16262	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.263	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16263	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.264	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16264	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.265	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16265	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.266	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16266	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.267	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16267	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.268	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16268	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.269	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16269	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.270	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16270	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.271	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16271	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.272	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16272	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.273	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16273	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.274	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16274	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.275	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16275	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.276	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16276	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.277	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16277	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.278	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16278	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.279	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16279	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.280	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16280	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.281	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16281	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.282	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16282	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.283	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16283	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.284	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16284	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.285	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16285	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.286	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16286	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.287	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16287	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.288	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16288	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.289	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16289	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.290	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16290	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.291	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16291	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.292	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16292	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.293	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16293	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.294	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16294	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.295	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16295	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.296	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16296	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.297	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16297	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.298	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16298	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.299	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16299	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.300	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16300	Boolean	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.16.301	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16301	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.302	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16302	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.303	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16303	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.304	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16304	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.305	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16305	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.306	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16306	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.307	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16307	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.308	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16308	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.309	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16309	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.310	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16310	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.311	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16311	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.312	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16312	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.313	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16313	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.314	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16314	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.315	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16315	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.316	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16316	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.317	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16317	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.318	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16318	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.319	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16319	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.320	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16320	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.321	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16321	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.322	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16322	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.323	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16323	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.324	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16324	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.325	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16325	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.326	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16326	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.327	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16327	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.328	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16328	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.329	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16329	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.330	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16330	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.331	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16331	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.332	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16332	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.333	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16333	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.334	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16334	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.335	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16335	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.336	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16336	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.337	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16337	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.338	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16338	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.339	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16339	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.340	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16340	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.341	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16341	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.342	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16342	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.343	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16343	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.344	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16344	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.345	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16345	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.346	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16346	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.347	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16347	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.348	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16348	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.349	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16349	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.350	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16350	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.351	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16351	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.352	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16352	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.353	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16353	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.354	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16354	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.355	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16355	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.356	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16356	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.357	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16357	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.358	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16358	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.359	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16359	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.360	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16360	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.361	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16361	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.362	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16362	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.363	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16363	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.364	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16364	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.365	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16365	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.366	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16366	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.367	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16367	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.368	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16368	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.369	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16369	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.370	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16370	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.371	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16371	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.372	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16372	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.373	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16373	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.374	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16374	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.375	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16375	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.376	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16376	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.377	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16377	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.378	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16378	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.379	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16379	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.380	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16380	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.381	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16381	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.382	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16382	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.383	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16383	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.384	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16384	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.385	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16385	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.386	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16386	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.387	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16387	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.388	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16388	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.389	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16389	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.390	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16390	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.391	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16391	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.392	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16392	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.393	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16393	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.394	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16394	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.395	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16395	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.396	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16396	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.397	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16397	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.398	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16398	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.399	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16399	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.400	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16400	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.401	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.402	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.403	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.404	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.405	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.406	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.407	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.408	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.409	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.410	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.411	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.412	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.413	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.414	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.415	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.416	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.417	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.418	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.419	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.420	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.421	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.422	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.423	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.424	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.425	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.426	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.427	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.428	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.429	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.430	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.431	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.432	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.433	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.434	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.435	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.436	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.437	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.438	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.439	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.440	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.441	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.442	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.443	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.444	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.445	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.446	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.447	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.448	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.449	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.450	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.451	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16451	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.452	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16452	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.453	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16453	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.454	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16454	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.455	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16455	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.456	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16456	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.457	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16457	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.458	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16458	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.459	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16459	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.460	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16460	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.461	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16461	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.462	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16462	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.463	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16463	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.464	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16464	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.465	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16465	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.466	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16466	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.467	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16467	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.468	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16468	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.469	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16469	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.470	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16470	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.471	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16471	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.472	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16472	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.473	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16473	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.474	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16474	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.475	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16475	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.476	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16476	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.477	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16477	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.478	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16478	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.479	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16479	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.480	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16480	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.481	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16481	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.482	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16482	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.483	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16483	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.484	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16484	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.485	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16485	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.486	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16486	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.487	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16487	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.488	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16488	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.489	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16489	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.490	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16490	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.491	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16491	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.492	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16492	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.493	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16493	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.494	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16494	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.495	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16495	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.496	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16496	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.497	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16497	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.498	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16498	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.499	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16499	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.500	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16500	Integer	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.16.501	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16501	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.502	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16502	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.503	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16503	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.504	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16504	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.505	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16505	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.506	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16506	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.507	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16507	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.508	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16508	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.509	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16509	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.510	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16510	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.511	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16511	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.512	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16512	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.513	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16513	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.514	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16514	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.515	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16515	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.516	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16516	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.517	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16517	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.518	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16518	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.519	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16519	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.520	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16520	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.521	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16521	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.522	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16522	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.523	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16523	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.524	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16524	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.525	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16525	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.526	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16526	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.527	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16527	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.528	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16528	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.529	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16529	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.530	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16530	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.531	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16531	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.532	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16532	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.533	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16533	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.534	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16534	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.535	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16535	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.536	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16536	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.537	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16537	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.538	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16538	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.539	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16539	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.540	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16540	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.541	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16541	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.542	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16542	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.543	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16543	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.544	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16544	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.545	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16545	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.546	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16546	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.547	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16547	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.548	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16548	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.549	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16549	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.550	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16550	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.551	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16551	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.552	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16552	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.553	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16553	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.554	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16554	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.555	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16555	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.556	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16556	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.557	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16557	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.558	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16558	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.559	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16559	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.560	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16560	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.561	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16561	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.562	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16562	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.563	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16563	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.564	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16564	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.565	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16565	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.566	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16566	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.567	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16567	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.568	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16568	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.569	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16569	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.570	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16570	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.571	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16571	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.572	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16572	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.573	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16573	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.574	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16574	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.575	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16575	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.576	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16576	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.577	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16577	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.578	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16578	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.579	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16579	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.580	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16580	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.581	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16581	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.582	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16582	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.583	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16583	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.584	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16584	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.585	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16585	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.586	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16586	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.587	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16587	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.588	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16588	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.589	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16589	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.590	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16590	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.591	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16591	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.592	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16592	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.593	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16593	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.594	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16594	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.595	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16595	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.596	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16596	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.597	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16597	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.598	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16598	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.599	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16599	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.600	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16600	boolean	false (2)



Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.16.601	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.601	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.602	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.602	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.603	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.603	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.604	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.604	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.605	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.605	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.606	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.606	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.607	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.607	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.608	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.608	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.609	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.609	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.610	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.610	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.611	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.611	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.612	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.612	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.613	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.613	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.614	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.614	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.615	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.615	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.616	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.616	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.617	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.617	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.618	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.618	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.619	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.619	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.620	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.620	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.621	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.621	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.622	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.622	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.623	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.623	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.624	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.624	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.625	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.625	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.626	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16626	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.627	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16627	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.628	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16628	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.629	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16629	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.630	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16630	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.631	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16631	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.632	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16632	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.633	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16633	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.634	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16634	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.635	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16635	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.636	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16636	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.637	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16637	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.638	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16638	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.639	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16639	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.640	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16640	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.641	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16641	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.642	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16642	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.643	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16643	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.644	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16644	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.645	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16645	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.646	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16646	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.647	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16647	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.648	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16648	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.649	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16649	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.650	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16650	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.651	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16651	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.652	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16652	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.653	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16653	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.654	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16654	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.655	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16655	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.656	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16656	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.657	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16657	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.658	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16658	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.659	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16659	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.660	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16660	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.661	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16661	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.662	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16662	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.663	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16663	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.664	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16664	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.665	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16665	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.666	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16666	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.667	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16667	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.668	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16668	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.669	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16669	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.670	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16670	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.671	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16671	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.672	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16672	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.673	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16673	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.674	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16674	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.675	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16675	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.676	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16676	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.677	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16677	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.678	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16678	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.679	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16679	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.680	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16680	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.681	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16681	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.682	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16682	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.683	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16683	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.684	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16684	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.685	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16685	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.686	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16686	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.687	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16687	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.688	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16688	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.689	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16689	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.690	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16690	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.691	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16691	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.692	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16692	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.693	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16693	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.694	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16694	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.695	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16695	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.696	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16696	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.697	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16697	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.698	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16698	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.699	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16699	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.700	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16700	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.701	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.702	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.703	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.704	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.705	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.706	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.707	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.708	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.709	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.710	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.711	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.712	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.713	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.714	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.715	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.716	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.717	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.718	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.719	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.720	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.721	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.722	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.723	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.724	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.725	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.726	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.727	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.728	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.729	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.730	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.731	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.732	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.733	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.734	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.735	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.736	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.737	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.738	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.739	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.740	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.741	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.742	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.743	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.744	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.745	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.746	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.747	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.748	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.749	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.750	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.751	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16751	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.752	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16752	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.753	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16753	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.754	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16754	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.755	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16755	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.756	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16756	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.757	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16757	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.758	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16758	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.759	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16759	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.760	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16760	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.761	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16761	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.762	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16762	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.763	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16763	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.764	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16764	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.765	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16765	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.766	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16766	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.767	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16767	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.768	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16768	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.769	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16769	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.770	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16770	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.771	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16771	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.772	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16772	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.773	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16773	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.774	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16774	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.775	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16775	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.776	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.777	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.778	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.779	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.780	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.781	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.782	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.783	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.784	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.785	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.786	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.787	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.788	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.789	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.790	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.791	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.792	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.793	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.794	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.795	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.796	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.797	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.798	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.799	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.800	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.16.801	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16801	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.802	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16802	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.803	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16803	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.804	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16804	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.805	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16805	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.806	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16806	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.807	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16807	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.808	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16808	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.809	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16809	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.810	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16810	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.811	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16811	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.812	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16812	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.813	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16813	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.814	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16814	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.815	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16815	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.816	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16816	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.817	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16817	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.818	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16818	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.819	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16819	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.820	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16820	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.821	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16821	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.822	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16822	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.823	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16823	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.824	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16824	boolean	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.16.825	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16825	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.826	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.826	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.827	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.827	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.828	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.828	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.829	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.829	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.830	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.830	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.831	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.831	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.832	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.832	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.833	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.833	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.834	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.834	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.835	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.835	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.836	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.836	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.837	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.837	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.838	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.838	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.839	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.839	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.840	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.840	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.841	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.841	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.842	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.842	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.843	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.843	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.844	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.844	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.845	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.845	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.846	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.846	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.847	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.847	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.848	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.848	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.849	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.849	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.850	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.850	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.851	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.851	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.852	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.852	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.853	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.853	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.854	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.854	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.855	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.855	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.856	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.856	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.857	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.857	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.858	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.858	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.859	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.859	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.860	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.860	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.861	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.861	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.862	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.862	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.863	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.863	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.864	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.864	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.865	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.865	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.866	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.866	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.867	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.867	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.868	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.868	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.869	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.869	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.870	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.870	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.871	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.871	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.872	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.872	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.873	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.873	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.874	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.874	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.875	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.875	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.876	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16876	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.877	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16877	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.878	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16878	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.879	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16879	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.880	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16880	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.881	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16881	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.882	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16882	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.883	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16883	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.884	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16884	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.885	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16885	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.886	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16886	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.887	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16887	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.888	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16888	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.889	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16889	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.890	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16890	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.891	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16891	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.892	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16892	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.893	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16893	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.894	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16894	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.895	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16895	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.896	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16896	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.897	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16897	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.898	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16898	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.899	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16899	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.900	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16900	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.901	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.901	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.902	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.902	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.903	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.903	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.904	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.904	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.905	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.905	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.906	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.906	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.907	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.907	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.908	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.908	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.909	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.909	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.910	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.910	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.911	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.911	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.912	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.912	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.913	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.913	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.914	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.914	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.915	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.915	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.916	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.916	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.917	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.917	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.918	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.918	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.919	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.919	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.920	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.920	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.921	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.921	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.922	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.922	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.923	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.923	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.924	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.924	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.925	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.925	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.926	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.926	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.927	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.927	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.928	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.928	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.929	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.929	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.930	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.930	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.931	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.931	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.932	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.932	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.933	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.933	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.934	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.934	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.935	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.935	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.936	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.936	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.937	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.937	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.938	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.938	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.939	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.939	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.940	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.940	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.941	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.941	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.942	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.942	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.943	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.943	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.944	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.944	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.945	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.945	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.946	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.946	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.947	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.947	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.948	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.948	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.949	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.949	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.950	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.950	boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.951	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.951	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.952	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.952	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.953	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.953	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.954	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.954	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.955	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.955	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.956	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.956	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.957	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.957	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.958	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.958	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.959	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.959	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.960	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.960	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.961	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.961	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.962	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.962	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.963	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.963	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.964	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.964	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.965	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.965	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.966	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.966	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.967	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.967	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.968	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.968	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.969	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.969	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.970	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.970	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.971	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.971	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.972	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.972	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.973	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.973	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.974	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.974	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.975	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.975	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.16.976	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16976	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.977	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16977	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.978	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16978	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.979	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16979	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.980	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16980	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.981	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16981	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.982	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16982	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.983	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16983	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.984	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16984	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.985	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16985	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.986	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16986	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.987	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16987	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.988	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16988	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.989	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16989	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.990	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16990	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.991	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16991	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.992	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16992	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.993	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16993	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.994	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16994	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.995	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16995	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.996	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16996	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.997	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16997	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.998	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16998	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.999	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.16999	boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.16.1000	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17000	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1001	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1002	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1003	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1004	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1005	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1006	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1007	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1008	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1009	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1010	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1011	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1012	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1013	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1014	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1015	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1016	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1017	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1018	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1019	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1020	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1021	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1022	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1023	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1024	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1025	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1026	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1027	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1028	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1029	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1030	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1031	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1032	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1033	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1034	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1035	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1036	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1037	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1038	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1039	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1040	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1041	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1042	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1043	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1044	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1045	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1046	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1047	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1048	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1049	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1050	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1051	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1051	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1052	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1052	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1053	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1053	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1054	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1054	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1055	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1055	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1056	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1056	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1057	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1057	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1058	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1058	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1059	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1059	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1060	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1060	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1061	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1061	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1062	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1062	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1063	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1063	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1064	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1064	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1065	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1065	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1066	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1066	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1067	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1067	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1068	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1068	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1069	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1069	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1070	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1070	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1071	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1071	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1072	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1072	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1073	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1073	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1074	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1074	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1075	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1075	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1076	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1076	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1077	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1077	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1078	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1078	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1079	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1079	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1080	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1080	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1081	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1081	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1082	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1082	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1083	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1083	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1084	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1084	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1085	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1085	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1086	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1086	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1087	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1087	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1088	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1088	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1089	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1089	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1090	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1090	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1091	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1091	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1092	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1092	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1093	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1093	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1094	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1094	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1095	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1095	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1096	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1096	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1097	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1097	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1098	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1098	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1099	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1099	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1100	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1100	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1101	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1102	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1103	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1104	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1105	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1106	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1107	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1108	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1109	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1110	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1111	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1112	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1113	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1114	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1115	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1116	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1117	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1118	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1119	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1120	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1121	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1122	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1123	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1124	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1125	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1126	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1127	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1128	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1129	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1130	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1131	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1132	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1133	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1134	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1135	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1136	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1137	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1138	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1139	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1140	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1141	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1142	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1143	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1144	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1145	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1146	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1147	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1148	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1149	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1150	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1151	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1152	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1153	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1154	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1155	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1156	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1157	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1158	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1159	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1160	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1161	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1162	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1163	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1164	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1165	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1166	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1167	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1168	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1169	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1170	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1171	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1172	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1173	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1174	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1175	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1176	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1177	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1178	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1179	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1180	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1181	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1182	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1183	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1184	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1185	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1186	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1187	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1188	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1189	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1190	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1191	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1192	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1193	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1194	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1195	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1196	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1197	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1198	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1199	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1200	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1201	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161201	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1202	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161202	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1203	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161203	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1204	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161204	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1205	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161205	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1206	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161206	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1207	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161207	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1208	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161208	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1209	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161209	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1210	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161210	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1211	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161211	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1212	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161212	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1213	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161213	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1214	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161214	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1215	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161215	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1216	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161216	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1217	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161217	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1218	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161218	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1219	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161219	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1220	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161220	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1221	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161221	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1222	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161222	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1223	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161223	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1224	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161224	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1225	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161225	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1226	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1226	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1227	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1227	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1228	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1228	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1229	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1229	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1230	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1230	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1231	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1231	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1232	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1232	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1233	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1233	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1234	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1234	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1235	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1235	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1236	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1236	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1237	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1237	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1238	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1238	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1239	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1239	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1240	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1240	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1241	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1241	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1242	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1242	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1243	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1243	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1244	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1244	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1245	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1245	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1246	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1246	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1247	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1247	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1248	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1248	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1249	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1249	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1250	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1250	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1251	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161251	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1252	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161252	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1253	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161253	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1254	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161254	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1255	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161255	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1256	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161256	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1257	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161257	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1258	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161258	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1259	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161259	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1260	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161260	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1261	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161261	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1262	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161262	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1263	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161263	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1264	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161264	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1265	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161265	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1266	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161266	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1267	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161267	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1268	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161268	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1269	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161269	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1270	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161270	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1271	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161271	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1272	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161272	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1273	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161273	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1274	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161274	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1275	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161275	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1276	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1276	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1277	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1277	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1278	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1278	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1279	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1279	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1280	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1280	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1281	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1281	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1282	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1282	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1283	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1283	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1284	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1284	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1285	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1285	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1286	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1286	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1287	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1287	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1288	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1288	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1289	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1289	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1290	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1290	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1291	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1291	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1292	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1292	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1293	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1293	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1294	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1294	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1295	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1295	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1296	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1296	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1297	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1297	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1298	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1298	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1299	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1299	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1300	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1300	boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1301	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1302	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1303	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1304	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1305	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1306	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1307	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1308	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1309	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1310	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1311	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1312	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1313	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1314	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1315	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1316	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1317	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1318	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1319	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1320	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1321	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1322	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1323	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1324	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1325	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1326	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1327	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1328	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1329	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1330	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1331	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1332	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1333	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1334	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1335	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1336	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1337	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1338	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1339	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1340	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1341	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1342	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1343	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1344	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1345	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1346	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1347	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1348	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1349	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1350	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1351	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1352	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1353	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1354	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1355	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1356	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1357	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1358	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1359	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1360	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1361	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1362	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1363	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1364	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1365	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1366	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1367	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1368	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1369	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1370	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1371	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1372	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1373	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1374	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1375	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1376	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1377	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1378	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1379	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1380	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1381	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1382	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1383	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1384	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1385	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1386	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1387	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1388	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1389	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1390	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1391	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1392	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1393	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1394	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1395	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1396	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1397	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1398	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1399	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1400	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1401	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1402	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1403	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1404	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1405	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1406	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1407	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1408	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1409	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1410	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1411	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1412	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1413	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1414	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1415	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1416	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1417	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1418	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1419	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1420	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1421	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1422	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1423	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1424	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1425	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1426	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1427	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1428	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1429	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1430	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1431	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1432	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1433	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1434	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1435	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1436	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1437	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1438	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1439	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1440	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1441	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1442	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1443	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1444	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1445	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1446	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1447	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1448	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1449	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1450	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1451	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1452	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1453	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1454	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1455	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1456	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1457	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1458	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1459	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1460	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1461	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1462	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1463	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1464	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1465	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1466	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1467	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1468	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1469	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1470	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1471	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1472	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1473	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1474	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1475	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1476	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1477	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1478	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1479	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1480	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1481	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1482	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1483	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1484	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1485	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1486	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1487	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1488	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1489	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1490	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1491	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1492	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1493	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1494	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1495	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1496	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1497	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1498	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1499	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1500	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1501	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1501	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1502	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1502	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1503	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1503	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1504	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1504	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1505	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1505	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1506	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1506	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1507	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1507	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1508	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1508	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1509	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1509	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1510	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1510	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1511	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1511	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1512	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1512	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1513	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1513	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1514	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1514	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1515	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1515	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1516	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1516	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1517	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1517	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1518	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1518	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1519	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1519	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1520	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1520	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1521	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1521	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1522	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1522	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1523	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1523	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1524	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1524	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1525	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1525	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1526	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1527	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1528	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1529	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1530	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1531	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1532	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1533	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1534	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1535	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1536	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1537	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1538	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1539	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1540	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1541	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1542	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1543	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1544	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1545	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1546	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1547	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1548	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1549	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1550	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1551	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1551	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1552	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1552	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1553	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1553	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1554	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1554	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1555	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1555	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1556	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1556	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1557	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1557	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1558	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1558	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1559	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1559	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1560	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1560	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1561	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1561	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1562	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1562	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1563	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1563	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1564	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1564	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1565	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1565	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1566	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1566	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1567	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1567	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1568	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1568	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1569	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1569	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1570	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1570	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1571	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1571	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1572	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1572	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1573	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1573	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1574	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1574	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1575	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1575	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1576	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1576	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1577	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1577	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1578	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1578	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1579	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1579	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1580	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1580	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1581	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1581	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1582	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1582	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1583	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1583	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1584	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1584	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1585	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1585	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1586	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1586	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1587	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1587	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1588	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1588	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1589	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1589	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1590	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1590	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1591	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1591	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1592	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1592	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1593	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1593	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1594	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1594	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1595	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1595	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1596	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1596	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1597	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1597	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1598	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1598	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1599	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1599	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1600	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1600	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1601	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1602	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1603	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1604	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1605	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1606	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1607	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1608	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1609	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1610	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1611	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1612	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1613	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1614	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1615	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1616	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1617	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1618	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1619	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1620	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1621	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1622	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1623	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1624	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1625	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1626	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1627	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1628	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1629	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1630	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1631	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1632	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1633	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1634	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1635	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1636	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1637	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1638	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1639	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1640	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1641	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1642	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1643	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1644	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1645	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1646	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1647	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1648	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1649	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1650	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1651	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1652	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1653	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1654	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1655	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1656	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1657	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1658	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1659	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1660	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1661	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1662	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1663	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1664	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1665	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1666	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1667	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1668	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1669	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1670	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1671	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1672	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1673	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1674	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1675	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1676	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1676	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1677	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1677	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1678	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1678	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1679	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1679	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1680	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1680	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1681	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1681	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1682	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1682	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1683	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1683	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1684	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1684	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1685	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1685	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1686	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1686	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1687	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1687	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1688	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1688	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1689	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1689	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1690	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1690	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1691	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1691	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1692	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1692	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1693	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1693	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1694	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1694	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1695	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1695	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1696	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1696	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1697	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1697	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1698	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1698	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1699	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1699	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1700	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1700	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1701	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1701	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1702	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1702	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1703	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1703	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1704	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1704	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1705	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1705	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1706	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1706	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1707	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1707	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1708	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1708	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1709	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1709	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1710	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1710	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1711	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1711	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1712	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1712	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1713	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1713	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1714	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1714	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1715	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1715	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1716	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1716	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1717	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1717	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1718	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1718	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1719	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1719	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1720	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1720	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1721	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1721	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1722	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1722	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1723	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1723	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1724	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1724	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1725	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1725	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1726	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1726	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1727	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1727	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1728	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1728	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1729	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1729	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1730	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1730	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1731	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1731	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1732	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1732	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1733	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1733	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1734	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1734	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1735	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1735	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1736	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1736	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1737	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1737	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1738	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1738	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1739	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1739	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1740	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1740	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1741	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1741	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1742	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1742	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1743	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1743	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1744	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1744	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1745	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1745	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1746	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1746	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1747	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1747	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1748	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1748	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1749	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1749	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1750	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1750	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1751	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1751	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1752	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1752	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1753	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1753	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1754	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1754	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1755	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1755	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1756	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1756	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1757	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1757	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1758	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1758	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1759	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1759	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1760	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1760	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1761	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1761	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1762	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1762	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1763	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1763	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1764	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1764	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1765	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1765	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1766	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1766	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1767	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1767	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1768	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1768	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1769	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1769	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1770	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1770	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1771	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1771	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1772	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1772	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1773	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1773	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1774	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1774	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1775	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1775	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1776	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1776	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1777	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1777	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1778	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1778	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1779	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1779	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1780	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1780	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1781	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1781	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1782	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1782	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1783	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1783	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1784	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1784	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1785	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1785	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1786	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1786	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1787	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1787	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1788	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1788	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1789	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1789	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1790	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1790	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1791	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1791	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1792	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1792	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1793	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1793	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1794	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1794	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1795	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1795	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1796	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1796	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1797	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1797	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1798	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1798	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1799	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1799	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1800	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1800	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1801	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161801	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1802	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161802	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1803	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161803	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1804	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161804	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1805	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161805	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1806	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161806	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1807	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161807	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1808	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161808	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1809	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161809	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1810	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161810	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1811	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161811	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1812	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161812	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1813	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161813	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1814	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161814	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1815	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161815	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1816	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161816	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1817	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161817	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1818	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161818	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1819	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161819	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1820	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161820	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1821	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161821	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1822	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161822	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1823	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161823	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1824	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161824	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1825	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161825	boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1826	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1826	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1827	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1827	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1828	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1828	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1829	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1829	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1830	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1830	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1831	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1831	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1832	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1832	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1833	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1833	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1834	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1834	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1835	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1835	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1836	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1836	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1837	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1837	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1838	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1838	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1839	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1839	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1840	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1840	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1841	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1841	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1842	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1842	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1843	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1843	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1844	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1844	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1845	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1845	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1846	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1846	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1847	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1847	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1848	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1848	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1849	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1849	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1850	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1850	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1851	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1851	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1852	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1852	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1853	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1853	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1854	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1854	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1855	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1855	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1856	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1856	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1857	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1857	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1858	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1858	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1859	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1859	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1860	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1860	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1861	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1861	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1862	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1862	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1863	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1863	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1864	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1864	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1865	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1865	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1866	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1866	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1867	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1867	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1868	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1868	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1869	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1869	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1870	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1870	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1871	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1871	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1872	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1872	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1873	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1873	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1874	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1874	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1875	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1875	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1876	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1876	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1877	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1877	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1878	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1878	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1879	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1879	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1880	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1880	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1881	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1881	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1882	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1882	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1883	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1883	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1884	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1884	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1885	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1885	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1886	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1886	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1887	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1887	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1888	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1888	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1889	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1889	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1890	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1890	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1891	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1891	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1892	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1892	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1893	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1893	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1894	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1894	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1895	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1895	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1896	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1896	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1897	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1897	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1898	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1898	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1899	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1899	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1900	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1900	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1901	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1902	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1903	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1904	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1905	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1906	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1907	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1908	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1909	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1910	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1911	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1912	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1913	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1914	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1915	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1916	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1917	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1918	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1919	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1920	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1921	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1922	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1923	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1924	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1925	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1926	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161926	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1927	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161927	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1928	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161928	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1929	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161929	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1930	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161930	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1931	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161931	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1932	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161932	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1933	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161933	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1934	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161934	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1935	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161935	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1936	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161936	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1937	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161937	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1938	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161938	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1939	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161939	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1940	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161940	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1941	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161941	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1942	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161942	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1943	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161943	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1944	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161944	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1945	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161945	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1946	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161946	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1947	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161947	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1948	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161948	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1949	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161949	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1950	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161950	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1951	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1951	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1952	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1952	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1953	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1953	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1954	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1954	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1955	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1955	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1956	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1956	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1957	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1957	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1958	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1958	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1959	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1959	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1960	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1960	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1961	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1961	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1962	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1962	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1963	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1963	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1964	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1964	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1965	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1965	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1966	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1966	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1967	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1967	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1968	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1968	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1969	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1969	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1970	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1970	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1971	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1971	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1972	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1972	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1973	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1973	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1974	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1974	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1975	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.1975	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.1976	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161976	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1977	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161977	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1978	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161978	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1979	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161979	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1980	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161980	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1981	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161981	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1982	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161982	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1983	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161983	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1984	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161984	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1985	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161985	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1986	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161986	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1987	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161987	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1988	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161988	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1989	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161989	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1990	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161990	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1991	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161991	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1992	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161992	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1993	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161993	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1994	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161994	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1995	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161995	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1996	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161996	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1997	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161997	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1998	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161998	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.1999	.2.802.1.1.13.1.5.32962.1.1.2.1.1.161999	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2000	.2.802.1.1.13.1.5.32962.1.1.2.1.1.162000	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2001	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2001	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2002	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2002	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2003	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2003	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2004	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2004	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2005	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2005	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2006	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2006	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2007	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2007	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2008	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2008	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2009	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2009	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2010	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2010	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2011	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2011	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2012	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2012	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2013	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2013	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2014	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2014	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2015	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2015	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2016	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2016	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2017	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2017	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2018	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2018	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2019	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2019	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2020	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2020	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2021	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2021	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2022	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2022	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2023	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2023	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2024	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2024	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2025	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2025	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2026	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2026	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2027	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2027	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2028	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2028	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2029	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2029	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2030	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2030	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2031	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2031	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2032	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2032	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2033	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2033	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2034	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2034	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2035	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2035	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2036	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2036	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2037	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2037	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2038	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2038	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2039	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2040	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2040	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2041	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2041	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2042	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2042	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2043	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2043	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2044	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2044	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2045	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2045	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2046	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2046	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2047	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2047	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2048	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2048	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2049	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2049	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2050	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2050	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2051	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62051	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2052	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62052	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2053	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62053	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2054	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62054	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2055	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62055	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2056	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62056	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2057	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62057	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2058	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62058	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2059	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62059	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2060	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62060	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2061	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62061	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2062	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62062	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2063	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62063	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2064	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62064	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2065	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62065	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2066	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62066	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2067	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62067	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2068	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62068	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2069	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62069	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2070	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62070	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2071	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62071	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2072	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62072	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2073	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62073	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2074	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62074	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2075	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62075	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2076	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62096	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2077	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62097	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2078	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62098	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2079	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62099	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2080	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62100	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2081	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62101	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2082	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62102	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2083	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62103	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2084	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62104	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2085	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62105	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2086	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62106	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2087	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62107	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2088	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62108	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2089	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62109	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2090	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62110	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2091	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62111	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2092	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62112	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2093	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62113	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2094	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62114	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2095	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62115	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2096	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62116	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2097	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62117	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2098	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62118	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2099	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62119	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2100	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62120	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2101	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2102	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2103	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2104	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2105	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2106	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2107	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2108	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2109	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2110	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2111	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2112	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2113	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2114	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2115	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2116	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2117	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2118	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2119	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2120	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2121	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2122	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2123	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2124	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2125	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2126	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2127	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2128	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2129	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2130	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2131	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2132	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2133	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2134	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2135	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2136	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2137	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2138	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2139	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2140	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2141	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2142	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2143	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2144	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2145	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2146	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2147	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2148	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2149	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2150	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2151	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2151	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2152	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2152	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2153	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2153	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2154	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2154	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2155	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2155	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2156	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2156	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2157	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2157	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2158	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2158	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2159	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2159	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2160	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2160	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2161	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2161	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2162	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2162	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2163	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2163	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2164	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2164	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2165	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2165	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2166	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2166	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2167	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2167	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2168	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2168	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2169	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2169	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2170	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2170	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2171	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2171	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2172	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2172	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2173	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2173	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2174	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2174	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2175	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2175	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2176	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2176	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2177	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2177	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2178	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2178	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2179	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2179	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2180	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2180	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2181	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2181	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2182	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2182	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2183	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2183	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2184	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2184	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2185	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2185	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2186	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2186	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2187	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2187	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2188	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2188	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2189	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2189	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2190	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2190	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2191	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2191	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2192	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2192	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2193	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2193	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2194	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2194	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2195	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2195	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2196	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2196	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2197	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2197	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2198	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2198	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2199	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2199	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2200	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2200	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2201	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2201	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2202	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2202	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2203	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2203	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2204	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2204	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2205	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2205	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2206	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2206	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2207	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2207	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2208	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2208	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2209	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2209	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2210	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2210	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2211	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2211	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2212	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2212	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2213	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2213	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2214	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2214	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2215	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2215	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2216	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2216	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2217	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2217	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2218	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2218	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2219	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2219	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2220	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2220	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2221	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2221	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2222	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2222	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2223	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2223	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2224	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2224	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2225	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2225	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2226	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2226	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2227	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2227	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2228	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2228	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2229	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2229	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2230	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2230	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2231	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2231	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2232	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2232	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2233	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2233	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2234	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2234	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2235	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2235	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2236	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2236	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2237	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2237	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2238	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2238	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2239	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2239	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2240	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2240	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2241	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2241	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2242	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2242	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2243	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2243	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2244	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2244	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2245	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2245	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2246	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2246	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2247	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2247	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2248	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2248	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2249	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2249	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2250	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2250	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2251	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2251	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2252	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2252	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2253	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2253	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2254	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2254	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2255	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2255	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2256	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2256	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2257	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2257	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2258	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2258	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2259	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2259	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2260	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2260	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2261	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2261	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2262	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2262	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2263	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2263	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2264	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2264	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2265	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2265	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2266	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2266	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2267	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2267	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2268	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2268	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2269	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2269	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2270	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2270	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2271	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2271	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2272	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2272	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2273	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2273	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2274	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2274	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2275	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2275	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2276	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2276	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2277	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2277	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2278	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2278	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2279	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2279	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2280	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2280	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2281	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2281	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2282	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2282	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2283	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2283	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2284	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2284	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2285	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2285	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2286	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2286	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2287	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2287	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2288	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2288	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2289	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2289	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2290	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2290	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2291	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2291	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2292	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2292	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2293	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2293	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2294	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2294	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2295	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2295	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2296	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2296	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2297	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2297	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2298	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2298	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2299	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2299	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2300	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2300	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2301	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2301	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2302	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2302	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2303	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2303	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2304	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2304	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2305	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2305	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2306	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2306	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2307	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2307	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2308	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2308	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2309	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2309	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2310	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2310	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2311	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2311	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2312	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2312	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2313	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2313	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2314	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2314	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2315	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2315	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2316	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2316	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2317	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2317	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2318	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2318	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2319	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2319	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2320	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2320	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2321	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2321	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2322	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2322	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2323	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2323	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2324	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2324	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2325	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2325	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2326	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2036	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2327	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2037	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2328	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2038	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2329	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2330	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2040	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2331	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2041	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2332	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2042	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2333	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2043	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2334	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2044	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2335	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2045	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2336	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2046	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2337	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2047	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2338	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2048	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2339	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2049	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2340	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2050	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2341	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2051	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2342	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2052	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2343	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2053	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2344	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2054	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2345	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2055	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2346	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2056	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2347	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2057	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2348	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2058	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2349	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2059	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2350	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2060	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2351	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2351	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2352	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2352	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2353	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2353	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2354	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2354	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2355	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2355	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2356	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2356	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2357	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2357	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2358	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2358	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2359	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2359	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2360	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2360	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2361	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2361	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2362	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2362	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2363	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2363	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2364	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2364	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2365	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2365	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2366	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2366	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2367	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2367	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2368	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2368	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2369	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2369	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2370	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2370	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2371	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2371	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2372	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2372	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2373	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2373	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2374	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2374	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2375	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2375	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2376	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2376	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2377	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2377	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2378	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2378	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2379	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2379	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2380	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2380	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2381	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2381	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2382	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2382	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2383	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2383	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2384	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2384	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2385	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2385	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2386	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2386	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2387	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2387	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2388	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2388	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2389	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2389	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2390	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2390	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2391	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2391	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2392	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2392	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2393	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2393	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2394	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2394	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2395	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2395	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2396	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2396	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2397	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2397	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2398	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2398	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2399	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2399	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2400	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2400	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2401	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2401	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2402	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2402	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2403	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2403	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2404	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2404	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2405	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2405	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2406	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2406	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2407	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2407	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2408	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2408	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2409	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2409	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2410	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2410	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2411	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2411	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2412	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2412	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2413	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2413	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2414	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2414	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2415	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2415	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2416	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2416	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2417	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2417	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2418	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2418	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2419	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2419	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2420	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2420	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2421	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2421	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2422	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2422	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2423	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2423	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2424	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2424	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2425	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2425	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2426	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2426	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2427	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2427	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2428	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2428	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2429	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2429	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2430	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2430	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2431	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2431	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2432	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2432	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2433	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2433	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2434	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2434	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2435	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2435	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2436	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2436	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2437	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2437	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2438	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2438	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2439	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2439	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2440	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2440	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2441	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2441	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2442	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2442	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2443	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2443	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2444	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2444	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2445	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2445	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2446	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2446	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2447	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2447	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2448	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2448	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2449	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2449	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2450	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2450	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2451	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2451	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2452	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2452	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2453	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2453	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2454	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2454	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2455	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2455	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2456	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2456	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2457	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2457	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2458	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2458	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2459	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2459	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2460	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2460	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2461	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2461	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2462	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2462	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2463	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2463	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2464	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2464	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2465	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2465	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2466	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2466	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2467	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2467	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2468	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2468	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2469	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2469	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2470	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2470	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2471	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2471	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2472	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2472	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2473	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2473	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2474	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2474	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.2475	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2475	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2476	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2476	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2477	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2477	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2478	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2478	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2479	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2479	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2480	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2480	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2481	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2481	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2482	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2482	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2483	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2483	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2484	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2484	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2485	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2485	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2486	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2486	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2487	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2487	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2488	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2488	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2489	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2489	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2490	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2490	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2491	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2491	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2492	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2492	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2493	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2493	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2494	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2494	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2495	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2495	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2496	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2496	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2497	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2497	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2498	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2498	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2499	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2499	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2500	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2500	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2501	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2501	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2502	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2502	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2503	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2503	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2504	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2504	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2505	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2505	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2506	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2506	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2507	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2507	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2508	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2508	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2509	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2509	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2510	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2510	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2511	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2511	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2512	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2512	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2513	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2513	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2514	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2514	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2515	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2515	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2516	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2516	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2517	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2517	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2518	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2518	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2519	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2519	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2520	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2520	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2521	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2521	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2522	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2522	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2523	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2523	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2524	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2524	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2525	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2525	boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2526	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2526	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2527	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2527	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2528	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2528	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2529	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2529	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2530	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2530	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2531	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2531	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2532	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2532	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2533	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2533	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2534	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2534	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2535	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2535	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2536	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2536	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2537	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2537	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2538	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2538	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2539	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2539	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2540	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2540	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2541	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2541	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2542	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2542	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2543	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2543	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2544	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2544	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2545	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2545	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2546	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2546	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2547	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2547	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2548	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2548	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2549	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2549	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2550	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2550	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2551	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2551	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2552	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2552	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2553	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2553	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2554	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2554	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2555	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2555	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2556	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2556	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2557	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2557	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2558	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2558	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2559	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2559	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2560	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2560	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2561	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2561	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2562	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2562	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2563	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2563	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2564	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2564	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2565	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2565	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2566	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2566	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2567	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2567	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2568	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2568	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2569	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2569	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2570	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2570	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2571	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2571	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2572	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2572	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2573	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2573	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2574	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2574	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2575	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2575	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2576	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2576	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2577	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2577	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2578	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2578	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2579	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2579	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2580	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2580	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2581	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2581	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2582	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2582	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2583	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2583	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2584	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2584	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2585	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2585	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2586	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2586	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2587	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2587	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2588	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2588	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2589	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2589	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2590	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2590	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2591	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2591	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2592	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2592	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2593	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2593	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2594	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2594	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2595	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2595	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2596	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2596	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2597	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2597	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2598	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2598	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2599	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2599	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2600	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2600	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2601	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2601	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2602	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2602	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2603	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2603	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2604	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2604	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2605	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2605	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2606	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2606	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2607	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2607	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2608	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2608	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2609	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2609	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2610	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2610	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2611	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2611	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2612	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2612	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2613	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2613	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2614	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2614	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2615	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2615	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2616	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2616	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2617	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2617	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2618	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2618	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2619	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2619	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2620	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2620	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2621	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2621	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2622	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2622	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2623	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2623	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2624	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2624	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2625	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2625	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2626	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2626	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2627	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2627	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2628	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2628	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2629	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2629	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2630	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2630	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2631	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2631	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2632	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2633	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2633	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2634	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2634	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2635	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2635	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2636	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2636	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2637	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2637	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2638	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2638	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2639	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2639	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2640	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2640	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2641	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2641	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2642	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2642	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2643	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2643	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2644	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2644	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2645	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2645	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2646	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2646	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2647	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2647	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2648	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2648	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2649	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2649	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2650	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2650	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2651	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2651	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2652	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2652	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2653	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2653	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2654	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2654	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2655	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2655	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2656	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2656	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2657	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2657	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2658	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2658	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2659	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2660	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2660	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2661	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2661	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2662	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2662	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2663	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2663	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2664	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2664	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2665	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2665	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2666	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2666	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2667	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2667	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2668	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2668	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2669	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2669	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2670	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2670	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2671	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2671	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2672	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2672	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2673	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2673	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2674	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2674	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2675	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2675	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2676	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2676	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2677	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2677	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2678	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2678	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2679	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2679	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2680	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2680	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2681	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2681	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2682	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2682	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2683	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2683	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2684	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2684	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2685	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2685	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2686	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2686	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2687	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2687	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2688	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2688	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2689	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2689	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2690	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2690	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2691	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2691	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2692	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2692	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2693	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2693	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2694	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2694	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2695	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2695	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2696	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2696	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2697	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2697	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2698	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2698	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2699	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2699	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2700	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2700	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2701	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2701	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2702	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2702	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2703	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2703	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2704	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2704	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2705	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2705	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2706	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2706	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2707	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2707	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2708	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2708	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2709	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2709	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2710	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2710	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2711	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2711	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2712	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2712	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2713	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2713	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2714	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2714	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2715	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2715	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2716	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2716	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2717	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2717	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2718	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2718	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2719	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2719	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2720	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2720	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2721	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2721	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2722	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2722	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2723	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2723	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2724	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2724	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2725	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2725	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2726	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62726	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2727	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62727	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2728	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62728	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2729	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62729	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2730	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62730	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2731	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62731	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2732	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62732	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2733	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62733	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2734	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62734	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2735	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62735	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2736	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62736	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2737	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62737	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2738	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62738	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2739	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62739	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2740	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62740	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2741	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62741	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2742	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62742	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2743	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62743	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2744	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62744	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2745	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62745	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2746	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62746	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2747	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62747	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2748	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62748	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2749	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62749	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2750	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.62750	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2751	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2751	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2752	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2752	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2753	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2753	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2754	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2754	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2755	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2755	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2756	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2756	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2757	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2757	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2758	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2758	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2759	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2759	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2760	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2760	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2761	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2761	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2762	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2762	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2763	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2763	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2764	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2764	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2765	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2765	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2766	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2766	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2767	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2767	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2768	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2768	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2769	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2769	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2770	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2770	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2771	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2771	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2772	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2772	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2773	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2773	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2774	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2774	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2775	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2775	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2776	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2776	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2777	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2777	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2778	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2778	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2779	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2779	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2780	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2780	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2781	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2781	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2782	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2782	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2783	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2783	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2784	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2784	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2785	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2785	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2786	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2786	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2787	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2787	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2788	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2788	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2789	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2789	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2790	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2790	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2791	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2791	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2792	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2792	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2793	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2793	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2794	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2794	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2795	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2795	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2796	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2796	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2797	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2797	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2798	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2798	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2799	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2799	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2800	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2800	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2801	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2801	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2802	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2802	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2803	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2803	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2804	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2804	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2805	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2805	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2806	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2806	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2807	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2807	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2808	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2808	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2809	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2809	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2810	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2810	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2811	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2811	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2812	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2812	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2813	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2813	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2814	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2814	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2815	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2815	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2816	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2816	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2817	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2817	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2818	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2818	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2819	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2819	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2820	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2820	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2821	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2821	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2822	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2822	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2823	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2823	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2824	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2824	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2825	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2825	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2826	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2826	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2827	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2827	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2828	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2828	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2829	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2829	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2830	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2830	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2831	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2831	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2832	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2832	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2833	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2833	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2834	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2834	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2835	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2835	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2836	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2836	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2837	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2837	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2838	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2838	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2839	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2839	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2840	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2840	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2841	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2841	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2842	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2842	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2843	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2843	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2844	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2844	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2845	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2845	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2846	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2846	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2847	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2847	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2848	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2848	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2849	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2849	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2850	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2850	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2851	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2851	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2852	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2852	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2853	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2853	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2854	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2854	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2855	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2855	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2856	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2856	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2857	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2857	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2858	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2858	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2859	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2859	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2860	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2860	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2861	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2861	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2862	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2862	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2863	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2863	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2864	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2864	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2865	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2865	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2866	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2866	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2867	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2867	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2868	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2868	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2869	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2869	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2870	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2870	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2871	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2871	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2872	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2872	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2873	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2873	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2874	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2874	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2875	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2875	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2876	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2876	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2877	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2877	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2878	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2878	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2879	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2879	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2880	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2880	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2881	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2881	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2882	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2882	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2883	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2883	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2884	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2884	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2885	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2885	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2886	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2886	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2887	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2887	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2888	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2888	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2889	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2889	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2890	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2890	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2891	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2891	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2892	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2892	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2893	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2893	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2894	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2894	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2895	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2895	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2896	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2896	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2897	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2897	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2898	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2898	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2899	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2899	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2900	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2900	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2901	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2901	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2902	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2902	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2903	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2903	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2904	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2904	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2905	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2905	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2906	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2906	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2907	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2907	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2908	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2908	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2909	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2909	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2910	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2910	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2911	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2911	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2912	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2912	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2913	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2913	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2914	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2914	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2915	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2915	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2916	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2916	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2917	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2917	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2918	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2918	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2919	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2919	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2920	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2920	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2921	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2921	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2922	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2922	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2923	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2923	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2924	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2924	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2925	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.2925	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2926	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2926	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2927	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2927	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2928	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2928	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2929	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2929	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2930	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2930	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2931	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2931	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2932	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2932	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2933	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2933	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2934	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2934	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2935	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2935	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2936	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2936	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2937	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2937	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2938	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2938	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2939	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2939	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2940	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2940	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2941	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2941	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2942	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2942	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2943	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2943	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2944	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2944	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2945	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2945	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2946	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2946	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2947	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2947	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2948	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2948	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2949	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2949	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2950	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2950	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2951	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2951	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2952	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2952	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2953	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2953	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2954	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2954	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2955	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2955	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2956	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2956	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2957	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2957	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2958	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2958	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2959	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2959	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2960	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2960	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2961	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2961	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2962	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2962	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2963	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2963	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2964	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2964	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2965	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2965	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2966	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2966	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2967	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2967	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2968	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2968	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2969	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2969	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2970	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2970	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2971	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2971	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2972	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2972	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2973	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2973	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2974	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2974	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2975	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2975	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.2976	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2976	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2977	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2977	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2978	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2978	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2979	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2979	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2980	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2980	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2981	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2981	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2982	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2982	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2983	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2983	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2984	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2984	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2985	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2985	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2986	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2986	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2987	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2987	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2988	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2988	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2989	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2989	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2990	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2990	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2991	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2991	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2992	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2992	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2993	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2993	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2994	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2994	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2995	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2995	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2996	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2996	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2997	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2997	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2998	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2998	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.2999	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.2999	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3000	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3000	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3001	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63001	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3002	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63002	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3003	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63003	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3004	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63004	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3005	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63005	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3006	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63006	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3007	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63007	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3008	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63008	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3009	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63009	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3010	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63010	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3011	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63011	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3012	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63012	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3013	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63013	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3014	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63014	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3015	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63015	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3016	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63016	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3017	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63017	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3018	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63018	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3019	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63019	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3020	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63020	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3021	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63021	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3022	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63022	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3023	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63023	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3024	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63024	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3025	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.63025	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3026	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3026	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3027	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3027	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3028	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3028	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3029	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3029	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3030	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3030	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3031	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3031	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3032	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3032	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3033	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3033	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3034	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3034	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3035	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3035	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3036	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3036	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3037	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3037	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3038	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3038	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3039	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3040	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3040	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3041	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3041	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3042	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3042	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3043	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3043	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3044	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3044	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3045	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3045	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3046	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3046	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3047	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3047	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3048	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3048	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3049	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3049	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3050	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3050	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3051	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3051	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3052	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3052	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3053	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3053	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3054	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3054	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3055	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3055	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3056	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3056	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3057	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3057	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3058	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3058	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3059	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3059	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3060	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3060	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3061	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3061	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3062	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3062	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3063	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3063	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3064	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3064	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3065	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3065	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3066	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3066	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3067	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3067	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3068	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3068	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3069	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3069	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3070	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3070	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3071	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3071	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3072	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3072	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3073	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3073	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3074	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3074	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3075	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3075	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3076	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3076	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3077	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3077	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3078	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3078	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3079	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3079	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3080	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3080	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3081	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3081	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3082	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3082	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3083	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3083	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3084	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3084	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3085	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3085	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3086	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3086	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3087	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3087	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3088	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3088	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3089	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3089	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3090	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3090	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3091	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3091	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3092	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3092	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3093	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3093	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3094	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3094	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3095	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3095	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3096	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3096	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3097	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3097	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3098	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3098	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3099	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3099	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3100	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3100	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3101	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3102	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3103	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3104	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3105	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3106	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3107	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3108	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3109	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3110	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3111	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3112	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3113	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3114	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3115	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3116	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3117	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3118	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3119	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3120	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3121	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3122	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3123	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3124	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3125	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3126	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3127	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3128	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3129	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3130	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3131	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3132	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3133	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3134	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3135	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3136	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3137	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3138	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3139	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3140	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3141	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3142	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3143	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3144	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3145	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3146	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3147	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3148	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3149	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3150	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.0.0	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3176	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3176	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3177	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3177	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3178	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3178	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3179	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3179	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3180	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3180	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3181	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3181	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3182	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3182	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3183	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3183	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3184	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3184	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3185	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3185	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3186	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3186	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3187	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3187	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3188	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3188	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3189	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3189	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3190	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3190	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3191	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3191	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3192	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3192	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3193	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3193	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3194	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3194	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3195	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3195	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3196	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3196	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3197	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3197	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3198	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3198	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3199	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3199	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3200	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3200	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3201	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3201	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3202	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3202	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3203	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3203	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3204	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3204	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3205	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3205	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3206	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3206	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3207	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3207	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3208	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3208	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3209	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3209	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3210	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3210	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3211	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3211	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3212	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3212	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3213	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3213	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3214	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3214	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3215	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3215	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3216	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3216	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3217	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3217	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3218	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3218	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3219	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3219	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3220	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3220	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3221	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3221	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3222	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3222	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3223	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3223	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3224	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3224	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3225	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3225	boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3226	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60236	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3227	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60237	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3228	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60238	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3229	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60239	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3230	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60240	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3231	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60241	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3232	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60242	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3233	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60243	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3234	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60244	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3235	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60245	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3236	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60246	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3237	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60247	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3238	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60248	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3239	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60249	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3240	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60250	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3241	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60251	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3242	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60252	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3243	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60253	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3244	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60254	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3245	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60255	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3246	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60256	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3247	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60257	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3248	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60258	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3249	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60259	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3250	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.60260	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3251	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3251	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3252	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3252	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3253	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3253	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3254	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3254	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3255	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3255	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3256	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3256	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3257	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3257	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3258	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3258	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3259	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3259	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3260	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3260	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3261	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3261	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3262	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3262	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3263	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3263	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3264	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3264	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3265	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3265	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3266	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3266	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3267	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3267	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3268	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3268	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3269	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3269	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3270	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3270	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3271	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3271	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3272	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3272	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3273	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3273	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3274	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3274	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3275	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3275	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3276	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3276	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3277	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3277	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3278	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3278	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3279	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3279	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3280	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3280	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3281	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3281	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3282	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3282	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3283	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3283	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3284	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3284	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3285	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3285	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3286	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3286	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3287	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3287	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3288	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3288	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3289	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3289	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3290	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3290	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3291	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3291	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3292	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3292	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3293	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3293	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3294	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3294	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3295	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3295	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3296	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3296	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3297	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3297	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3298	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3298	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3299	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3299	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3300	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3300	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3301	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3301	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3302	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3302	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3303	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3303	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3304	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3304	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3305	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3305	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3306	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3306	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3307	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3307	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3308	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3308	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3309	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3309	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3310	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3310	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3311	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3311	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3312	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3312	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3313	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3313	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3314	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3314	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3315	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3315	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3316	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3316	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3317	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3317	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3318	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3318	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3319	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3319	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3320	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3320	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3321	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3321	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3322	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3322	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3323	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3323	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3324	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3324	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3325	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3325	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3326	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3326	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3327	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3327	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3328	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3328	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3329	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3329	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3330	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3330	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3331	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3331	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3332	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3332	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3333	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3333	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3334	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3334	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3335	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3335	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3336	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3336	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3337	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3337	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3338	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3338	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3339	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3339	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3340	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3340	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3341	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3341	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3342	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3342	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3343	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3343	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3344	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3344	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3345	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3345	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3346	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3346	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3347	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3347	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3348	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3348	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3349	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3349	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3350	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3350	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3351	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3351	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3352	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3352	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3353	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3353	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3354	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3354	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3355	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3355	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3356	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3356	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3357	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3357	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3358	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3358	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3359	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3359	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3360	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3360	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3361	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3361	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3362	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3362	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3363	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3363	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3364	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3364	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3365	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3365	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3366	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3366	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3367	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3367	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3368	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3368	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3369	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3369	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3370	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3370	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3371	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3371	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3372	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3372	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3373	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3373	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3374	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3374	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3375	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3375	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3376	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3376	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3377	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3377	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3378	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3378	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3379	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3379	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3380	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3380	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3381	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3381	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3382	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3382	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3383	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3383	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3384	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3384	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3385	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3385	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3386	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3386	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3387	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3387	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3388	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3388	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3389	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3389	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3390	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3390	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3391	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3391	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3392	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3392	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3393	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3393	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3394	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3394	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3395	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3395	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3396	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3396	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3397	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3397	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3398	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3398	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3399	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3399	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3400	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3400	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3401	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3401	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3402	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3402	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3403	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3403	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3404	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3404	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3405	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3405	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3406	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3406	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3407	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3407	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3408	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3408	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3409	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3409	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3410	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3410	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3411	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3411	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3412	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3412	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3413	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3413	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3414	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3414	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3415	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3415	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3416	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3416	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3417	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3417	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3418	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3418	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3419	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3419	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3420	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3420	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3421	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3421	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3422	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3422	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3423	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3423	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3424	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3424	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3425	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3425	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3426	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3426	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3427	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3427	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3428	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3428	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3429	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3429	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3430	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3430	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3431	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3431	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3432	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3432	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3433	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3433	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3434	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3434	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3435	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3435	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3436	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3436	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3437	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3437	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3438	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3438	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3439	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3439	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3440	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3440	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3441	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3441	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3442	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3442	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3443	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3443	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3444	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3444	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3445	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3445	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3446	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3446	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3447	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3447	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3448	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3448	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3449	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3449	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3450	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3450	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3451	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3452	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.2	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3453	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.3	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3454	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.4	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3455	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.5	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3456	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.6	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3457	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.7	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3458	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.8	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3459	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.9	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3460	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.10	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3461	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.11	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3462	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.12	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3463	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.13	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3464	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.14	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3465	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.15	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3466	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.16	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3467	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.17	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3468	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.18	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3469	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.19	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3470	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.20	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3471	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.21	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3472	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.22	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3473	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.23	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3474	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.24	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3475	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.0.4.5.25	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3476	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3476	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3477	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3477	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3478	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3478	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3479	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3479	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3480	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3480	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3481	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3481	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3482	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3482	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3483	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3483	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3484	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3484	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3485	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3485	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3486	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3486	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3487	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3487	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3488	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3488	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3489	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3489	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3490	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3490	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3491	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3491	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3492	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3492	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3493	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3493	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3494	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3494	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3495	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3495	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3496	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3496	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3497	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3497	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3498	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3498	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3499	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3499	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3500	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3500	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3501	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3501	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3502	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3502	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3503	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3503	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3504	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3504	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3505	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3505	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3506	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3506	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3507	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3507	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3508	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3508	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3509	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3509	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3510	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3510	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3511	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3511	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3512	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3512	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3513	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3513	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3514	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3514	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3515	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3515	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3516	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3516	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3517	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3517	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3518	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3518	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3519	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3519	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3520	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3520	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3521	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3521	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3522	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3522	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3523	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3523	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3524	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3524	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3525	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3525	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3526	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3526	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3527	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3527	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3528	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3528	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3529	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3529	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3530	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3530	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3531	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3531	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3532	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3532	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3533	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3533	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3534	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3534	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3535	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3535	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3536	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3536	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3537	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3537	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3538	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3538	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3539	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3539	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3540	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3540	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3541	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3541	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3542	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3542	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3543	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3543	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3544	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3544	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3545	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3545	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3546	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3546	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3547	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3547	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3548	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3548	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3549	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3549	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3550	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3550	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3551	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3551	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3552	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3552	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3553	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3553	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3554	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3554	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3555	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3555	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3556	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3556	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3557	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3557	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3558	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3558	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3559	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3559	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3560	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3560	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3561	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3561	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3562	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3562	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3563	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3563	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3564	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3564	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3565	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3565	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3566	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3566	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3567	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3567	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3568	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3568	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3569	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3569	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3570	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3570	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3571	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3571	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3572	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3572	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3573	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3573	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3574	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3574	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3575	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3575	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3576	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3576	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3577	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3577	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3578	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3578	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3579	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3579	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3580	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3580	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3581	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3581	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3582	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3582	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3583	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3583	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3584	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3584	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3585	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3585	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3586	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3586	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3587	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3587	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3588	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3588	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3589	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3589	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3590	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3590	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3591	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3591	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3592	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3592	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3593	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3593	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3594	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3594	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3595	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3595	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3596	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3596	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3597	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3597	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3598	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3598	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3599	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3599	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3600	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3600	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3601	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3601	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3602	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3602	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3603	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3603	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3604	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3604	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3605	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3605	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3606	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3606	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3607	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3607	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3608	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3608	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3609	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3609	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3610	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3610	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3611	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3611	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3612	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3612	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3613	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3613	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3614	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3614	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3615	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3615	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3616	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3616	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3617	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3617	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3618	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3618	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3619	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3619	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3620	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3620	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3621	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3621	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3622	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3622	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3623	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3623	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3624	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3624	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3625	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3625	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3626	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3626	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3627	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3627	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3628	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3628	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3629	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3629	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3630	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3630	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3631	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3631	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3632	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3632	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3633	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3633	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3634	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3634	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3635	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3635	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3636	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3636	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3637	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3637	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3638	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3638	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3639	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3639	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3640	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3640	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3641	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3641	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3642	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3642	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3643	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3643	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3644	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3644	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3645	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3645	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3646	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3646	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3647	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3647	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3648	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3648	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3649	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3649	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3650	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3650	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3651	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3651	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3652	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3652	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3653	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3653	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3654	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3654	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3655	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3655	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3656	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3656	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3657	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3657	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3658	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3658	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3659	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3660	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3660	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3661	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3661	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3662	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3662	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3663	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3663	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3664	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3664	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3665	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3665	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3666	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3666	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3667	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3667	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3668	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3668	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3669	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3669	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3670	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3670	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3671	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3671	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3672	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3672	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3673	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3673	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3674	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3674	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3675	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3675	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3676	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3676	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3677	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3677	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3678	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3678	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3679	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3679	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3680	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3680	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3681	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3681	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3682	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3682	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3683	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3683	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3684	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3684	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3685	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3685	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3686	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3686	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3687	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3687	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3688	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3688	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3689	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3689	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3690	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3690	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3691	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3691	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3692	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3692	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3693	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3693	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3694	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3694	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3695	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3695	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3696	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3696	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3697	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3697	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3698	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3698	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3699	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3699	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3700	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3700	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3701	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3701	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3702	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3702	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3703	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3703	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3704	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3704	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3705	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3705	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3706	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3706	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3707	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3707	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3708	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3708	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3709	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3709	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3710	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3710	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3711	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3711	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3712	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3712	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3713	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3713	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3714	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3714	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3715	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3715	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3716	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3716	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3717	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3717	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3718	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3718	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3719	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3719	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3720	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3720	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3721	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3721	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3722	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3722	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3723	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3723	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3724	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3724	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3725	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3725	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3726	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3726	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3727	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3727	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3728	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3728	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3729	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3729	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3730	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3730	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3731	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3731	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3732	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3732	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3733	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3733	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3734	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3734	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3735	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3735	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3736	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3736	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3737	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3737	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3738	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3738	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3739	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3739	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3740	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3740	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3741	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3741	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3742	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3742	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3743	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3743	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3744	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3744	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3745	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3745	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3746	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3746	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3747	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3747	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3748	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3748	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3749	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3749	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3750	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3750	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3751	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3751	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3752	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3752	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3753	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3753	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3754	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3754	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3755	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3755	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3756	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3756	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3757	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3757	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3758	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3758	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3759	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3759	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3760	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3760	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3761	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3761	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3762	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3762	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3763	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3763	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3764	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3764	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3765	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3765	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3766	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3766	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3767	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3767	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3768	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3768	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3769	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3769	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3770	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3770	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3771	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3771	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3772	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3772	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3773	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3773	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3774	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3774	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3775	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3775	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3776	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3776	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3777	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3777	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3778	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3778	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3779	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3779	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3780	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3780	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3781	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3781	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3782	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3782	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3783	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3783	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3784	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3784	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3785	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3785	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3786	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3786	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3787	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3787	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3788	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3788	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3789	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3789	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3790	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3790	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3791	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3791	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3792	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3792	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3793	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3793	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3794	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3794	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3795	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3795	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3796	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3796	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3797	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3797	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3798	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3798	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3799	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3799	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3800	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3800	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3801	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3801	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3802	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3802	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3803	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3803	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3804	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3804	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3805	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3805	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3806	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3806	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3807	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3807	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3808	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3808	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3809	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3809	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3810	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3810	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3811	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3811	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3812	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3812	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3813	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3813	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3814	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3814	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3815	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3815	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3816	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3816	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3817	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3817	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3818	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3818	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3819	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3819	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3820	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3820	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3821	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3821	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3822	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3822	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3823	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3823	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3824	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3824	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3825	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3825	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3826	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3826	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3827	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3827	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3828	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3828	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3829	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3829	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3830	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3830	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3831	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3831	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3832	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3832	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3833	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3833	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3834	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3834	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3835	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3835	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3836	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3836	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3837	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3837	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3838	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3838	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3839	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3839	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3840	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3840	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3841	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3841	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3842	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3842	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3843	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3843	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3844	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3844	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3845	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3845	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3846	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3846	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3847	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3847	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3848	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3848	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3849	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3849	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3850	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3850	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3851	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3851	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3852	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3852	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3853	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3853	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3854	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3854	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3855	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3855	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3856	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3856	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3857	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3857	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3858	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3858	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3859	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3859	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3860	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3860	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3861	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3861	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3862	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3862	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3863	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3863	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3864	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3864	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3865	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3865	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3866	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3866	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3867	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3867	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3868	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3868	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3869	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3869	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3870	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3870	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3871	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3871	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3872	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3872	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3873	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3873	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3874	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3874	boolean	false (2)
IldpV2Xdot1ConfigVlanNameDot11xEnable.16.3875	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3875	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3876	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3876	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3877	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3877	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3878	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3878	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3879	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3879	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3880	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3880	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3881	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3881	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3882	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3882	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3883	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3883	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3884	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3884	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3885	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3885	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3886	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3886	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3887	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3887	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3888	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3888	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3889	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3889	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3890	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3890	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3891	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3891	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3892	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3892	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3893	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3893	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3894	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3894	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3895	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3895	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3896	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3896	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3897	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3897	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3898	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3898	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3899	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3899	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3900	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3900	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3901	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3901	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3902	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3902	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3903	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3903	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3904	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3904	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3905	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3905	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3906	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3906	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3907	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3907	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3908	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3908	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3909	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3909	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3910	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3910	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3911	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3911	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3912	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3912	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3913	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3913	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3914	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3914	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3915	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3915	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3916	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3916	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3917	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3917	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3918	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3918	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3919	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3919	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3920	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3920	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3921	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3921	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3922	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3922	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3923	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3923	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3924	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3924	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3925	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3925	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3926	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3926	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3927	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3927	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3928	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3928	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3929	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3929	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3930	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3930	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3931	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3931	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3932	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3932	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3933	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3933	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3934	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3934	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3935	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3935	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3936	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3936	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3937	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3937	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3938	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3938	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3939	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3939	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3940	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3940	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3941	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3941	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3942	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3942	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3943	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3943	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3944	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3944	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3945	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3945	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3946	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3946	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3947	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3947	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3948	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3948	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3949	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3949	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3950	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3950	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3951	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3951	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3952	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3952	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3953	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3953	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3954	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3954	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3955	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3955	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3956	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3956	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3957	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3957	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3958	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3958	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3959	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3959	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3960	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3960	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3961	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3961	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3962	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3962	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3963	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3963	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3964	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3964	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3965	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3965	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3966	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3966	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3967	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3967	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3968	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3968	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3969	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3969	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3970	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3970	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3971	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3971	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3972	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3972	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3973	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3973	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3974	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3974	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3975	.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.6.3975	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.3976	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3976	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3977	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3977	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3978	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3978	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3979	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3979	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3980	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3980	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3981	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3981	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3982	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3982	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3983	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3983	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3984	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3984	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3985	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3985	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3986	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3986	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3987	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3987	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3988	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3988	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3989	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3989	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3990	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3990	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3991	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3991	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3992	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3992	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3993	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3993	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3994	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3994	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3995	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3995	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3996	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3996	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3997	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3997	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3998	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3998	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.3999	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.3999	boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4000	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4000	boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.4001	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164001	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4002	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164002	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4003	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164003	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4004	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164004	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4005	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164005	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4006	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164006	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4007	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164007	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4008	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164008	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4009	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164009	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4010	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164010	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4011	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164011	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4012	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164012	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4013	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164013	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4014	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164014	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4015	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164015	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4016	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164016	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4017	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164017	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4018	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164018	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4019	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164019	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4020	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164020	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4021	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164021	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4022	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164022	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4023	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164023	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4024	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164024	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4025	.2.802.1.1.13.1.5.32962.1.1.2.1.1.164025	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.4026	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4026	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4027	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4027	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4028	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4028	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4029	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4029	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4030	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4030	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4031	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4031	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4032	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4032	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4033	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4033	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4034	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4034	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4035	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4035	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4036	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4036	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4037	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4037	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4038	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4038	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4039	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4039	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4040	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4040	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4041	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4041	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4042	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4042	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4043	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4043	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4044	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4044	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4045	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4045	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4046	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4046	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4047	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4047	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4048	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4048	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4049	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4049	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4050	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4050	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.4051	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4051	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4052	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4052	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4053	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4053	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4054	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4054	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4055	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4055	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4056	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4056	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4057	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4057	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4058	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4058	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4059	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4059	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4060	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4060	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4061	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4061	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4062	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4062	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4063	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4063	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4064	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4064	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4065	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4065	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4066	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4066	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4067	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4067	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4068	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4068	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4069	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4069	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4070	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4070	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4071	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4071	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4072	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4072	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4073	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4073	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4074	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4074	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4075	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4075	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.16.4076	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4076	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4077	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4077	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4078	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4078	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4079	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4079	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4080	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4080	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4081	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4081	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4082	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4082	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4083	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4083	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4084	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4084	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4085	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4085	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4086	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4086	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4087	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4087	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4088	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4088	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4089	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4089	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4090	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4090	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4091	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4091	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4092	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4093	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4093	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.16.4094	.2.802.1.1.13.1.5.32962.1.1.2.1.1.16.4094	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.0	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.0	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.2	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.2	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.3	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.3	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.4	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.4	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.5	11.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.5	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.17.6	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.6	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.7	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.7	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.8	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.8	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.9	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.9	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.10	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.10	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.11	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.11	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.12	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.12	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.13	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.13	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.14	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.14	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.15	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.15	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.16	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.16	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.17	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.18	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.18	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.19	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.19	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.20	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.20	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.21	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.21	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.22	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.22	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.23	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.23	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.24	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.24	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.25	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.25	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.26	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.26	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.27	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.27	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.28	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.28	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.29	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.29	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.30	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.30	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.17.31	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.31	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.32	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.32	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.33	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.33	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.34	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.34	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.35	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.35	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.36	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.36	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.37	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.37	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.38	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.38	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.39	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.39	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.40	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.40	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.41	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.41	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.42	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.42	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.43	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.43	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.44	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.44	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.45	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.45	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.46	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.46	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.47	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.47	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.48	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.48	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.49	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.49	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.50	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.50	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.51	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.51	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.52	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.52	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.53	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.53	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.54	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.54	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.55	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.55	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.17.56	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.56	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.57	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.57	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.58	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.58	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.59	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.59	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.60	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.60	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.61	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.61	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.62	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.62	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.63	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.63	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.64	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.64	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.65	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.65	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.66	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.66	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.67	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.67	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.68	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.68	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.69	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.69	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.70	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.70	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.71	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.71	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.72	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.72	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.73	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.73	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.74	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.74	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.75	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.75	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.76	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.76	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.77	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.77	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.78	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.78	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.79	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.79	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.80	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.80	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameBxEnable.17.81	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1781	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.82	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1782	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.83	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1783	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.84	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1784	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.85	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1785	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.86	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1786	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.87	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1787	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.88	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1788	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.89	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1789	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.90	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1790	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.91	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1791	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.92	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1792	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.93	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1793	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.94	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1794	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.95	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1795	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.96	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1796	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.97	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1797	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.98	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1798	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.99	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1799	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.100	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1800	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.101	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1801	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.102	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1802	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.103	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1803	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.104	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1804	Integer	false (2)
IldpV2Xdot1ConfigVlanNameBxEnable.17.105	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1805	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.106	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.107	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.108	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.109	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.110	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.111	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.112	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.113	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.114	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.115	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.116	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.117	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.118	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.119	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.120	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.121	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.122	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.123	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.124	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.125	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.126	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.127	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.128	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.129	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.130	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.131	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.132	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.133	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.134	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.135	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.136	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.137	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.138	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.139	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.140	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.141	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.142	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.143	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.144	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.145	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.146	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.147	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.148	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.149	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.150	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.151	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.152	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.153	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.154	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.155	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.17.156	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.157	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.158	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.159	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.160	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.161	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.162	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.163	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.164	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.165	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.166	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.167	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.168	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.169	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.170	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.171	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.172	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.173	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.174	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.175	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.176	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.177	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.178	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.179	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.180	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)



Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.17.181	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.182	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.183	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.184	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.185	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.186	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.187	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.188	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.189	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.190	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.191	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.192	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.193	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.194	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.195	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.196	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.197	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.198	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.199	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.200	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.201	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.202	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.203	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.204	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.205	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.206	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.207	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.208	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.209	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.210	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.211	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.212	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.213	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.214	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.215	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.216	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.217	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.218	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.219	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.220	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.221	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.222	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.223	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.224	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.225	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.226	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.227	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.228	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.229	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.230	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.231	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.232	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.233	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.234	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.235	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.236	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.237	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.238	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.239	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.240	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.241	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.242	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.243	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.244	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.245	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.246	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.247	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.248	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.249	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.250	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.251	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.252	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.253	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.254	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.255	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.256	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.256	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.257	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.257	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.258	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.258	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.259	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.259	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.260	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.260	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.261	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.261	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.262	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.262	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.263	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.263	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.264	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.264	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.265	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.265	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.266	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.266	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.267	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.267	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.268	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.268	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.269	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.269	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.270	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.270	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.271	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.271	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.272	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.272	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.273	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.273	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.274	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.274	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.275	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.275	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.276	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.276	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.277	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.277	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.278	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.278	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.279	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.279	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.280	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.1.280	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.281	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.282	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.283	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.284	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.285	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.286	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.287	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.288	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.289	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.290	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.291	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.292	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.293	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.294	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.295	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.296	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.297	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.298	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.299	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.300	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.301	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.302	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.303	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.304	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.305	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.306	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.307	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.308	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.309	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.310	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.311	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.312	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.313	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.314	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.315	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.316	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.317	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.318	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.319	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.320	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.321	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.322	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.323	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.324	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.325	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.326	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.327	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.328	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.329	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.330	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.331	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.332	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.333	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.334	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.335	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.336	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.337	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.338	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.339	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.340	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.341	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.342	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.343	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.344	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.345	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.346	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.347	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.348	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.349	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.350	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.351	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.352	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.353	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.354	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.355	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.356	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.357	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.358	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.359	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.360	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.361	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.362	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.363	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.364	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.365	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.366	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.367	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.368	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.369	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.370	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.371	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.372	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.373	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.374	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.375	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.376	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.377	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.378	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.379	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.380	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.381	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.382	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.383	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.384	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.385	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.386	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.387	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.388	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.389	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.390	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.391	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.392	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.393	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.394	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.395	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.396	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.397	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.398	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.399	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.400	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.401	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.402	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.403	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.404	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.405	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.406	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.407	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.408	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.409	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.410	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.411	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.412	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.413	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.414	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.415	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.416	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.417	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.418	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.419	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.420	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.421	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.422	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.423	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.424	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.425	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.426	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.427	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.428	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.429	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.430	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.431	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.432	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.433	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.434	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.435	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.436	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.437	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.438	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.439	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.440	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.441	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.442	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.443	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.444	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.445	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.446	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.447	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.448	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.449	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.450	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.451	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.452	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.453	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.454	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.455	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.456	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.457	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.458	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.459	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.460	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.461	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.462	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.463	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.464	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.465	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.466	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.467	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.468	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.469	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.470	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.471	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.472	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.473	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.474	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.475	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.476	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.477	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.478	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.479	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.480	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.481	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.482	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.483	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.484	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.485	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.486	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.487	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.488	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.489	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.490	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.491	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.492	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.493	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.494	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.495	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.496	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.497	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.498	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.499	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.500	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.501	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.502	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.503	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.504	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.505	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.506	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.507	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.508	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.509	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.510	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.511	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.512	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.513	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.514	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.515	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.516	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.517	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.518	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.519	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.520	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.521	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.522	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.523	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.524	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.525	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.526	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.527	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.528	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.529	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.530	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.531	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.532	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.533	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.534	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.535	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.536	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.537	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.538	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.539	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.540	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.541	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.542	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.543	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.544	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.545	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.546	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.547	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.548	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.549	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.550	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.551	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.552	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.553	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.554	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.555	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.556	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.556	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.557	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.557	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.558	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.558	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.559	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.559	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.560	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.560	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.561	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.561	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.562	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.562	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.563	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.563	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.564	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.564	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.565	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.565	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.566	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.566	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.567	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.567	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.568	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.568	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.569	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.569	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.570	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.570	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.571	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.571	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.572	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.572	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.573	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.573	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.574	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.574	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.575	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.575	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.576	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.576	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.577	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.577	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.578	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.578	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.579	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.579	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.580	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.580	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.581	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.582	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.583	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.584	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.585	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.586	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.587	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.588	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.589	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.590	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.591	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.592	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.593	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.594	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.595	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.596	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.597	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.598	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.599	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.600	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.601	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.602	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.603	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.604	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.605	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.631	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.632	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.633	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.634	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.635	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.636	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.637	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.638	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.639	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.640	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.641	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.642	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.643	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.644	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.645	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.646	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.647	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.648	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.649	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.650	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.651	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.652	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.653	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.654	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.655	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.656	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.656	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.657	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.657	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.658	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.658	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.659	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.659	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.660	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.660	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.661	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.661	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.662	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.662	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.663	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.663	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.664	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.664	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.665	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.665	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.666	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.666	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.667	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.667	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.668	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.668	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.669	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.669	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.670	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.670	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.671	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.671	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.672	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.672	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.673	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.673	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.674	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.674	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.675	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.675	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.676	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.676	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.677	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.677	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.678	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.678	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.679	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.679	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.680	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.680	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.681	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.682	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.683	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.684	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.685	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.686	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.687	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.688	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.689	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.690	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.691	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.692	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.693	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.694	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.695	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.696	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.697	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.698	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.699	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.700	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.701	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.702	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.703	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.704	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.705	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)



Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.17.706	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.707	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.708	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.709	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.710	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.711	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.712	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.713	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.714	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.715	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.716	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.717	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.718	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.719	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.720	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.721	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.722	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.723	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.724	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.725	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.726	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.727	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.728	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.729	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.730	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.731	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.732	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.733	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.734	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.735	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.736	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.737	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.738	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.739	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.740	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.741	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.742	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.743	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.744	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.745	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.746	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.747	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.748	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.749	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.750	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.751	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.752	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.753	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.754	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.755	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.756	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.757	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.758	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.759	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.760	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.761	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.762	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.763	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.764	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.765	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.766	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.767	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.768	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.769	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.770	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.771	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.772	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.773	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.774	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.775	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.776	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.777	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.778	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.779	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.780	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigVlanNameExEnable.17.781	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.782	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.783	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.784	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.785	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.786	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.787	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.788	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.789	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.790	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.791	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.792	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.793	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.794	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.795	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.796	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.797	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.798	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.799	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.800	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.801	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.802	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.803	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.804	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)
lldpV2Xdot1ConfigVlanNameExEnable.17.805	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.806	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.806	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.807	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.807	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.808	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.808	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.809	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.809	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.810	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.810	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.811	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.811	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.812	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.812	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.813	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.813	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.814	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.814	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.815	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.815	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.816	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.816	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.817	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.817	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.818	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.818	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.819	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.819	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.820	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.820	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.821	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.821	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.822	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.822	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.823	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.823	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.824	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.824	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.825	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.825	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.826	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.826	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.827	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.827	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.828	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.828	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.829	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.829	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.830	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.830	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.831	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17831	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.832	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17832	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.833	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17833	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.834	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17834	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.835	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17835	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.836	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17836	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.837	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17837	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.838	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17838	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.839	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17839	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.840	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17840	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.841	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17841	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.842	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17842	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.843	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17843	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.844	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17844	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.845	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17845	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.846	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17846	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.847	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17847	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.848	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17848	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.849	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17849	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.850	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17850	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.851	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17851	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.852	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17852	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.853	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17853	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.854	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17854	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.855	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17855	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.856	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.856	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.857	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.857	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.858	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.858	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.859	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.859	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.860	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.860	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.861	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.861	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.862	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.862	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.863	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.863	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.864	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.864	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.865	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.865	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.866	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.866	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.867	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.867	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.868	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.868	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.869	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.869	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.870	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.870	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.871	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.871	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.872	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.872	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.873	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.873	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.874	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.874	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.875	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.875	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.876	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.876	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.877	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.877	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.878	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.878	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.879	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.879	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.880	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17.880	Boolean	false (2)







Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.931	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17931	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.932	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17932	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.933	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17933	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.934	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17934	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.935	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17935	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.936	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17936	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.937	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17937	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.938	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17938	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.939	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17939	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.940	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17940	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.941	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17941	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.942	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17942	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.943	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17943	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.944	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17944	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.945	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17945	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.946	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17946	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.947	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17947	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.948	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17948	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.949	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17949	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.950	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17950	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.951	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17951	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.952	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17952	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.953	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17953	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.954	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17954	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.955	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1.17955	Boolean	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameExEnable.17.981	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.982	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.983	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.984	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.985	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.986	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.987	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.988	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.989	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.990	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.991	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.992	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.993	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.994	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.995	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.996	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.997	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.998	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.999	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.1000	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.1001	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.1002	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.1003	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.1004	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigVlanNameExEnable.17.1005	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.1	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.17.1006	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1007	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1008	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1009	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1010	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1011	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1012	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1013	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1014	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1015	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1016	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1017	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1018	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1019	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1020	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1021	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1022	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1023	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1024	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1025	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1026	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1027	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1028	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1029	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1030	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.17.1031	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171031	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1032	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1033	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171033	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1034	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171034	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1035	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171035	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1036	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171036	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1037	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171037	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1038	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171038	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1039	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171039	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1040	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171040	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1041	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171041	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1042	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171042	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1043	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171043	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1044	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171044	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1045	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171045	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1046	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171046	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1047	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171047	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1048	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171048	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1049	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171049	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1050	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171050	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1051	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171051	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1052	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171052	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1053	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171053	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1054	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171054	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1055	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171055	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.17.1056	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1056	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1057	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1057	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1058	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1058	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1059	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1059	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1060	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1060	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1061	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1061	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1062	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1062	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1063	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1063	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1064	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1064	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1065	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1065	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1066	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1066	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1067	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1067	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1068	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1068	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1069	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1069	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1070	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1070	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1071	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1071	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1072	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1072	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1073	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1073	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1074	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1074	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1075	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1075	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1076	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1076	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1077	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1077	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1078	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1078	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1079	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1079	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1080	.2.802.1.1.13.1.5.32962.1.1.2.1.1.17.1080	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.17.1081	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171081	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1082	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171082	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1083	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171083	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1084	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171084	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1085	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171085	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1086	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171086	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1087	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171087	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1088	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171088	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1089	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171089	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.17.1090	.2.802.1.1.13.1.5.32962.1.1.2.1.1.171090	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1091	.2.802.1.1.13.1.5.32962.1.1.2.1.1.371091	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1092	.2.802.1.1.13.1.5.32962.1.1.2.1.1.371092	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1093	.2.802.1.1.13.1.5.32962.1.1.2.1.1.371093	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1094	.2.802.1.1.13.1.5.32962.1.1.2.1.1.371094	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1095	.2.802.1.1.13.1.5.32962.1.1.2.1.1.371095	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1096	.2.802.1.1.13.1.5.32962.1.1.2.1.1.371096	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1097	.2.802.1.1.13.1.5.32962.1.1.2.1.1.371097	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1098	.2.802.1.1.13.1.5.32962.1.1.2.1.1.371098	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1099	.2.802.1.1.13.1.5.32962.1.1.2.1.1.371099	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1100	.2.802.1.1.13.1.5.32962.1.1.2.1.1.371100	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1101	.2.802.1.1.13.1.5.32962.1.1.2.1.1.371101	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1102	.2.802.1.1.13.1.5.32962.1.1.2.1.1.371102	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1103	.2.802.1.1.13.1.5.32962.1.1.2.1.1.371103	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1104	.2.802.1.1.13.1.5.32962.1.1.2.1.1.371104	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1105	.2.802.1.1.13.1.5.32962.1.1.2.1.1.371105	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1106	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1107	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1108	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1109	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1110	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1111	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1112	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1113	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1114	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1115	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1116	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1117	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1118	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1119	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1120	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1121	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1122	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1123	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1124	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1125	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1126	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1127	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1128	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1129	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1130	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1131	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1132	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1133	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1134	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1135	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1136	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1137	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1138	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1139	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1140	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1141	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1142	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1143	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1144	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1145	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1146	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1147	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1148	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1149	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1150	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1151	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1152	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1153	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1154	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1155	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1156	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1157	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1158	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1159	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1160	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1161	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1162	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1163	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1164	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1165	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1166	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1167	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1168	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1169	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1170	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1171	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1172	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1173	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1174	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1175	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1176	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1177	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1178	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1179	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1180	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1181	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1181	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1182	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1182	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1183	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1183	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1184	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1184	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1185	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1185	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1186	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1186	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1187	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1187	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1188	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1188	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1189	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1189	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1190	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1190	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1191	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1191	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1192	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1192	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1193	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1193	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1194	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1194	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1195	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1195	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1196	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1196	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1197	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1197	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1198	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1198	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1199	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1199	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1200	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1200	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1201	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1201	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1202	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1202	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1203	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1203	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1204	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1204	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1205	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1205	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1206	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1206	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1207	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1207	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1208	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1208	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1209	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1209	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1210	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1210	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1211	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1211	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1212	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1212	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1213	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1213	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1214	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1214	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1215	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1215	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1216	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1216	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1217	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1217	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1218	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1218	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1219	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1219	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1220	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1220	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1221	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1221	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1222	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1222	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1223	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1223	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1224	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1224	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1225	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1225	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1226	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1226	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1227	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1227	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1228	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1228	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1229	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1229	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1230	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1230	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1231	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1231	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1232	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1232	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1233	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1233	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1234	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1234	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1235	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1235	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1236	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1236	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1237	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1237	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1238	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1238	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1239	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1239	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1240	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1240	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1241	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1241	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1242	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1242	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1243	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1243	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1244	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1244	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1245	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1245	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1246	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1246	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1247	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1247	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1248	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1248	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1249	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1249	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1250	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1250	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1251	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1251	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1252	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1252	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1253	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1253	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1254	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1254	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1255	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1255	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1256	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1256	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1257	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1257	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1258	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1258	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1259	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1259	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1260	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1260	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1261	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1261	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1262	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1262	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1263	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1263	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1264	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1264	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1265	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1265	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1266	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1266	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1267	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1267	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1268	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1268	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1269	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1269	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1270	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1270	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1271	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1271	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1272	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1272	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1273	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1273	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1274	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1274	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1275	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1275	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1276	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1276	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1277	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1277	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1278	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1278	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1279	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1279	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1280	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1280	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1281	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1281	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1282	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1282	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1283	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1283	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1284	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1284	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1285	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1285	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1286	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1286	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1287	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1287	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1288	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1288	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1289	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1289	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1290	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1290	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1291	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1291	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1292	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1292	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1293	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1293	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1294	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1294	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1295	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1295	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1296	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1296	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1297	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1297	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1298	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1298	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1299	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1299	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1300	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1300	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1301	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1301	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1302	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1302	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1303	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1303	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1304	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1304	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1305	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1305	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1306	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1306	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1307	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1307	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1308	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1308	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1309	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1309	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1310	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1310	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1311	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1311	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1312	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1312	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1313	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1313	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1314	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1314	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1315	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1315	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1316	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1316	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1317	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1317	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1318	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1318	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1319	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1319	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1320	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1320	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1321	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1321	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1322	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1322	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1323	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1323	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1324	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1324	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1325	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1325	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1326	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1326	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1327	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1327	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1328	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1328	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1329	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1329	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1330	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1330	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1331	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1332	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1333	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1334	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1335	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1336	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1337	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1338	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1339	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1340	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1341	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1342	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1343	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1344	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1345	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1346	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1347	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1348	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1349	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1350	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1351	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1352	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1353	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1354	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1355	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1032	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1356	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1056	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1357	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1057	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1358	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1058	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1359	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1059	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1360	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1060	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1361	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1061	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1362	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1062	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1363	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1063	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1364	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1064	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1365	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1065	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1366	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1066	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1367	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1067	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1368	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1068	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1369	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1069	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1370	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1070	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1371	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1071	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1372	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1072	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1373	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1073	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1374	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1074	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1375	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1075	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1376	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1076	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1377	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1077	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1378	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1078	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1379	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1079	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1380	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1080	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1381	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1381	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1382	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1382	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1383	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1383	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1384	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1384	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1385	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1385	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1386	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1386	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1387	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1387	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1388	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1388	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1389	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1389	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1390	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1390	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1391	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1391	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1392	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1392	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1393	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1393	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1394	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1394	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1395	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1395	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1396	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1396	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1397	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1397	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1398	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1398	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1399	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1399	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1400	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1400	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1401	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1401	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1402	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1402	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1403	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1403	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1404	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1404	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1405	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1405	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1406	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1407	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1408	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1409	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1410	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1411	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1412	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1413	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1414	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1415	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1416	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1417	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1418	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1419	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1420	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1421	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1422	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1423	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1424	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1425	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1426	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1427	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1428	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1429	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1430	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1431	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1432	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1433	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1434	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1435	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1436	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1437	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1438	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1439	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1440	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1441	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1442	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1443	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1444	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1445	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1446	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1447	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1448	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1449	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1450	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1451	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1452	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1453	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1454	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1455	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1456	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1457	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1458	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1459	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1460	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1461	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1462	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1463	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1464	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1465	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1466	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1467	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1468	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1469	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1470	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1471	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1472	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1473	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1474	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1475	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1476	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1477	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1478	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1479	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1480	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1481	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1481	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1482	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1482	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1483	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1483	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1484	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1484	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1485	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1485	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1486	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1486	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1487	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1487	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1488	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1488	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1489	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1489	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1490	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1490	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1491	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1491	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1492	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1492	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1493	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1493	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1494	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1494	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1495	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1495	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1496	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1496	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1497	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1497	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1498	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1498	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1499	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1499	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1500	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1500	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1501	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1501	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1502	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1502	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1503	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1503	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1504	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1504	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1505	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1505	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1506	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1506	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1507	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1507	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1508	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1508	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1509	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1509	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1510	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1510	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1511	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1511	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1512	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1512	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1513	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1513	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1514	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1514	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1515	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1515	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1516	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1516	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1517	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1517	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1518	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1518	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1519	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1519	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1520	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1520	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1521	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1521	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1522	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1522	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1523	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1523	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1524	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1524	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1525	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1525	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1526	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1526	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1527	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1527	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1528	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1528	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1529	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1529	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1530	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1530	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1531	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1531	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1532	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1532	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1533	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1533	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1534	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1534	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1535	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1535	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1536	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1536	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1537	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1537	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1538	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1538	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1539	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1539	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1540	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1540	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1541	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1541	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1542	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1542	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1543	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1543	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1544	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1544	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1545	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1545	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1546	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1546	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1547	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1547	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1548	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1548	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1549	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1549	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1550	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1550	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1551	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1551	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1552	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1552	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1553	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1553	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1554	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1554	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1555	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1555	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1556	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1556	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1557	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1557	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1558	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1558	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1559	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1559	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1560	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1560	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1561	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1561	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1562	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1562	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1563	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1563	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1564	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1564	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1565	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1565	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1566	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1566	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1567	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1567	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1568	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1568	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1569	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1569	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1570	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1570	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1571	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1571	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1572	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1572	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1573	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1573	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1574	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1574	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1575	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1575	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1576	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1576	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1577	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1577	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1578	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1578	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1579	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1579	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1580	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1580	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1581	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1581	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1582	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1582	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1583	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1583	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1584	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1584	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1585	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1585	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1586	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1586	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1587	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1587	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1588	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1588	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1589	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1589	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1590	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1590	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1591	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1591	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1592	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1592	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1593	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1593	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1594	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1594	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1595	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1595	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1596	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1596	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1597	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1597	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1598	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1598	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1599	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1599	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1600	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1600	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1601	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1601	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1602	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1602	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1603	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1603	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1604	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1604	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1605	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1605	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1606	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1606	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1607	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1607	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1608	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1608	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1609	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1609	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1610	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1610	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1611	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1611	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1612	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1612	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1613	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1613	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1614	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1614	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1615	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1615	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1616	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1616	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1617	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1617	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1618	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1618	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1619	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1619	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1620	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1620	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1621	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1621	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1622	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1622	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1623	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1623	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1624	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1624	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1625	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1625	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1626	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1626	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1627	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1627	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1628	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1628	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1629	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1629	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1630	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1630	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1631	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1631	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1632	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1632	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1633	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1633	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1634	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1634	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1635	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1635	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1636	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1636	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1637	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1637	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1638	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1638	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1639	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1639	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1640	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1640	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1641	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1641	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1642	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1642	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1643	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1643	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1644	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1644	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1645	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1645	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1646	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1646	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1647	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1647	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1648	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1648	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1649	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1649	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1650	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1650	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1651	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1651	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1652	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1652	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1653	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1653	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1654	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1654	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1655	.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1655	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVlanNameTxEnable.37.1656	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1656	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1657	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1657	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1658	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1658	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1659	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1659	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1660	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1660	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1661	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1661	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1662	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1662	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1663	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1663	Integer	false (2)
IldpV2Xdot1ConfigVlanNameTxEnable.37.1664	1.2.802.1.1.13.1.5.32962.1.1.2.1.1.37.1664	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.0	1.1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.0	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.1	1.1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.2	1.1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.2	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.3	1.1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.3	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.4	1.1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.4	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.5	1.1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.5	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.6	1.1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.6	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.7	1.1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.7	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.8	1.1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.8	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.9	1.1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.9	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.10	1.1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.10	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.11	1.1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.11	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.12	1.1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.12	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.13	1.1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.13	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.14	1.1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.14	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.15	1.1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.15	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlanTxEnable.1.16	1.2.802.1.1.13.1.5.32962.1.1.3.1.16	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.17	1.2.802.1.1.13.1.5.32962.1.1.3.1.17	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.18	1.2.802.1.1.13.1.5.32962.1.1.3.1.18	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.19	1.2.802.1.1.13.1.5.32962.1.1.3.1.19	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.20	1.2.802.1.1.13.1.5.32962.1.1.3.1.20	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.21	1.2.802.1.1.13.1.5.32962.1.1.3.1.21	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.22	1.2.802.1.1.13.1.5.32962.1.1.3.1.22	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.23	1.2.802.1.1.13.1.5.32962.1.1.3.1.23	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.24	1.2.802.1.1.13.1.5.32962.1.1.3.1.24	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.25	1.2.802.1.1.13.1.5.32962.1.1.3.1.25	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.26	1.2.802.1.1.13.1.5.32962.1.1.3.1.26	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.27	1.2.802.1.1.13.1.5.32962.1.1.3.1.27	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.28	1.2.802.1.1.13.1.5.32962.1.1.3.1.28	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.29	1.2.802.1.1.13.1.5.32962.1.1.3.1.29	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.30	1.2.802.1.1.13.1.5.32962.1.1.3.1.30	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.31	1.2.802.1.1.13.1.5.32962.1.1.3.1.31	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.32	1.2.802.1.1.13.1.5.32962.1.1.3.1.32	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.33	1.2.802.1.1.13.1.5.32962.1.1.3.1.33	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.34	1.2.802.1.1.13.1.5.32962.1.1.3.1.34	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.35	1.2.802.1.1.13.1.5.32962.1.1.3.1.35	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.36	1.2.802.1.1.13.1.5.32962.1.1.3.1.36	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.37	1.2.802.1.1.13.1.5.32962.1.1.3.1.37	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.38	1.2.802.1.1.13.1.5.32962.1.1.3.1.38	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.39	1.2.802.1.1.13.1.5.32962.1.1.3.1.39	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.40	1.2.802.1.1.13.1.5.32962.1.1.3.1.40	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlanTxEnable.1.66	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.66	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.67	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.67	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.68	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.68	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.69	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.69	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.70	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.70	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.71	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.71	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.72	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.72	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.73	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.73	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.74	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.74	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.75	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.75	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.76	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.76	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.77	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.77	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.78	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.78	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.79	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.79	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.80	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.80	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.81	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.81	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.82	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.82	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.83	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.83	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.84	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.84	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.85	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.85	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.86	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.86	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.87	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.87	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.88	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.88	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.89	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.89	Integer	false (2)
IldpV2Xdot1ConfigProtoVlanTxEnable.1.90	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.90	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.91	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.104	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.92	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.105	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.93	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.106	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.94	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.107	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.95	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.108	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.96	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.109	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.97	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.110	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.98	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.111	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.99	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.112	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.100	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.113	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.101	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.114	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.102	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.115	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.103	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.116	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.104	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.117	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.105	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.118	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.106	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.119	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.107	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.120	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.108	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.121	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.109	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.122	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.110	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.123	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.111	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.124	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.112	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.125	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.113	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.126	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.114	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.127	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.115	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.128	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan113xEnable.1.116	1.2.802.1.1.13.1.5.32962.1.1.3.1.116	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.117	1.2.802.1.1.13.1.5.32962.1.1.3.1.117	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.118	1.2.802.1.1.13.1.5.32962.1.1.3.1.118	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.119	1.2.802.1.1.13.1.5.32962.1.1.3.1.119	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.120	1.2.802.1.1.13.1.5.32962.1.1.3.1.120	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.121	1.2.802.1.1.13.1.5.32962.1.1.3.1.121	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.122	1.2.802.1.1.13.1.5.32962.1.1.3.1.122	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.123	1.2.802.1.1.13.1.5.32962.1.1.3.1.123	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.124	1.2.802.1.1.13.1.5.32962.1.1.3.1.124	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.125	1.2.802.1.1.13.1.5.32962.1.1.3.1.125	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.126	1.2.802.1.1.13.1.5.32962.1.1.3.1.126	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.127	1.2.802.1.1.13.1.5.32962.1.1.3.1.127	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.128	1.2.802.1.1.13.1.5.32962.1.1.3.1.128	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.129	1.2.802.1.1.13.1.5.32962.1.1.3.1.129	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.130	1.2.802.1.1.13.1.5.32962.1.1.3.1.130	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.131	1.2.802.1.1.13.1.5.32962.1.1.3.1.131	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.132	1.2.802.1.1.13.1.5.32962.1.1.3.1.132	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.133	1.2.802.1.1.13.1.5.32962.1.1.3.1.133	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.134	1.2.802.1.1.13.1.5.32962.1.1.3.1.134	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.135	1.2.802.1.1.13.1.5.32962.1.1.3.1.135	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.136	1.2.802.1.1.13.1.5.32962.1.1.3.1.136	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.137	1.2.802.1.1.13.1.5.32962.1.1.3.1.137	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.138	1.2.802.1.1.13.1.5.32962.1.1.3.1.138	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.139	1.2.802.1.1.13.1.5.32962.1.1.3.1.139	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113xEnable.1.140	1.2.802.1.1.13.1.5.32962.1.1.3.1.140	Integer	false (2)





Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.191	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1191	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.192	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1192	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.193	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1193	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.194	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1194	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.195	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1195	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.196	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1196	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.197	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1197	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.198	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1198	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.199	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1199	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.200	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1200	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.201	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1201	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.202	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1202	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.203	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1203	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.204	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1204	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.205	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1205	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.206	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1206	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.207	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1207	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.208	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1208	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.209	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1209	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.210	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1210	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.211	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1211	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.212	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1212	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.213	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1213	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.214	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1214	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan113.113.xEnable.1.215	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1215	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.241	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1241	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.242	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1242	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.243	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1243	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.244	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1244	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.245	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1245	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.246	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1246	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.247	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1247	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.248	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1248	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.249	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1249	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.250	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1250	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.251	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1251	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.252	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1252	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.253	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1253	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.254	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1254	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.255	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1255	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.256	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1256	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.257	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1257	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.258	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1258	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.259	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1259	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.260	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1260	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.261	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1261	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.262	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1262	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.263	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1263	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.264	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1264	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan13.11xEnable.1.265	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1265	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.266	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.266	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.267	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.267	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.268	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.268	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.269	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.269	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.270	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.270	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.271	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.271	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.272	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.272	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.273	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.273	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.274	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.274	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.275	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.275	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.276	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.276	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.277	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.277	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.278	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.278	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.279	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.279	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.280	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.280	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.281	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.281	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.282	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.282	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.283	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.283	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.284	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.284	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.285	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.285	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.286	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.286	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.287	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.287	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.288	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.288	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.289	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.289	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.290	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.290	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.291	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1291	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.292	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1292	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.293	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1293	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.294	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1294	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.295	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1295	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.296	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1296	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.297	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1297	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.298	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1298	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.299	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1299	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.300	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1300	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.301	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1301	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.302	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1302	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.303	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1303	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.304	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1304	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.305	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1305	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.306	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1306	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.307	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1307	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.308	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1308	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.309	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1309	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.310	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1310	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.311	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1311	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.312	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1312	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.313	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1313	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.314	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1314	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1311xEnable.1.315	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1315	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1316xEnable.1.316	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1316	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1317xEnable.1.317	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1317	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1318xEnable.1.318	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1318	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1319xEnable.1.319	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1319	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1320xEnable.1.320	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1320	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1321xEnable.1.321	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1321	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1322xEnable.1.322	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1322	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1323xEnable.1.323	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1323	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1324xEnable.1.324	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1324	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1325xEnable.1.325	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1325	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1326xEnable.1.326	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1326	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1327xEnable.1.327	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1327	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1328xEnable.1.328	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1328	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1329xEnable.1.329	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1329	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1330xEnable.1.330	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1330	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1331xEnable.1.331	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1331	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1332xEnable.1.332	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1332	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1333xEnable.1.333	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1333	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1334xEnable.1.334	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1334	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1335xEnable.1.335	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1335	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1336xEnable.1.336	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1336	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1337xEnable.1.337	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1337	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1338xEnable.1.338	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1338	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1339xEnable.1.339	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1339	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1340xEnable.1.340	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1340	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1331xEnable.1.341	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1341	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1332xEnable.1.342	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1342	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1333xEnable.1.343	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1343	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1334xEnable.1.344	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1344	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1335xEnable.1.345	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1345	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1336xEnable.1.346	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1346	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1337xEnable.1.347	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1347	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1338xEnable.1.348	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1348	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1339xEnable.1.349	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1349	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1340xEnable.1.350	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1350	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1341xEnable.1.351	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1351	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1342xEnable.1.352	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1352	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1343xEnable.1.353	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1353	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1344xEnable.1.354	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1354	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1345xEnable.1.355	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1355	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1346xEnable.1.356	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1356	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1347xEnable.1.357	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1357	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1348xEnable.1.358	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1358	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1349xEnable.1.359	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1359	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1350xEnable.1.360	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1360	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1351xEnable.1.361	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1361	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1352xEnable.1.362	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1362	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1353xEnable.1.363	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1363	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1354xEnable.1.364	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1364	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1355xEnable.1.365	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1365	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1366xEnable.1.366	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1366	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1367xEnable.1.367	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1367	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1368xEnable.1.368	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1368	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1369xEnable.1.369	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1369	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1370xEnable.1.370	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1370	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1371xEnable.1.371	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1371	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1372xEnable.1.372	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1372	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1373xEnable.1.373	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1373	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1374xEnable.1.374	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1374	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1375xEnable.1.375	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1375	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1376xEnable.1.376	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1376	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1377xEnable.1.377	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1377	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1378xEnable.1.378	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1378	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1379xEnable.1.379	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1379	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1380xEnable.1.380	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1380	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1381xEnable.1.381	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1381	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1382xEnable.1.382	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1382	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1383xEnable.1.383	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1383	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1384xEnable.1.384	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1384	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1385xEnable.1.385	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1385	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1386xEnable.1.386	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1386	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1387xEnable.1.387	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1387	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1388xEnable.1.388	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1388	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1389xEnable.1.389	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1389	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1390xEnable.1.390	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1390	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.391	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.391	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.392	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.392	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.393	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.393	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.394	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.394	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.395	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.395	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.396	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.396	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.397	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.397	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.398	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.398	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.399	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.399	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.400	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.400	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.401	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.401	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.402	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.402	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.403	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.403	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.404	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.404	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.405	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.405	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.406	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.406	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.407	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.407	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.408	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.408	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.409	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.409	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.410	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.410	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.411	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.411	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.412	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.412	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.413	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.413	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.414	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.414	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.415	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.415	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.416	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1416	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.417	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1417	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.418	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1418	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.419	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1419	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.420	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1420	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.421	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1421	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.422	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1422	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.423	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1423	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.424	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1424	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.425	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1425	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.426	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1426	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.427	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1427	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.428	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1428	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.429	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1429	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.430	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1430	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.431	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1431	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.432	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1432	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.433	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1433	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.434	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1434	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.435	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1435	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.436	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1436	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.437	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1437	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.438	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1438	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.439	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1439	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.440	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1440	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.441	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1441	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.442	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1442	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.443	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1443	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.444	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1444	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.445	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1445	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.446	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1446	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.447	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1447	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.448	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1448	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.449	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1449	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.450	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1450	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.451	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1451	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.452	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1452	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.453	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1453	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.454	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1454	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.455	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1455	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.456	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1456	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.457	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1457	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.458	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1458	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.459	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1459	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.460	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1460	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.461	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1461	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.462	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1462	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.463	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1463	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.464	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1464	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.465	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1465	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.466	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.466	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.467	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.467	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.468	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.468	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.469	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.469	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.470	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.470	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.471	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.471	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.472	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.472	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.473	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.473	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.474	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.474	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.475	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.475	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.476	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.476	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.477	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.477	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.478	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.478	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.479	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.479	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.480	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.480	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.481	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.481	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.482	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.482	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.483	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.483	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.484	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.484	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.485	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.485	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.486	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.486	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.487	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.487	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.488	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.488	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.489	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.489	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.490	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.490	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.491	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.491	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.492	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.492	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.493	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.493	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.494	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.494	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.495	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.495	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.496	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.496	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.497	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.497	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.498	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.498	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.499	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.499	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.500	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.500	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.501	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.501	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.502	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.502	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.503	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.503	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.504	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.504	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.505	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.505	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.506	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.506	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.507	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.507	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.508	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.508	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.509	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.509	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.510	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.510	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.511	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.511	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.512	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.512	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.513	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.513	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.514	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.514	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.515	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.515	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.516	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.516	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.517	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.517	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.518	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.518	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.519	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.519	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.520	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.520	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.521	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.521	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.522	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.522	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.523	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.523	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.524	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.524	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.525	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.525	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.526	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.526	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.527	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.527	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.528	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.528	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.529	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.529	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.530	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.530	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.531	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.531	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.532	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.532	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.533	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.533	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.534	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.534	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.535	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.535	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.536	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.536	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.537	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.537	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.538	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.538	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.539	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.539	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.540	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.540	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.541	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.541	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.542	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.542	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.543	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.543	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.544	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.544	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.545	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.545	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.546	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.546	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.547	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.547	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.548	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.548	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.549	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.549	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.550	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.550	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.551	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.551	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.552	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.552	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.553	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.553	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.554	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.554	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.555	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.555	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.556	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.556	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.557	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.557	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.558	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.558	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.559	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.559	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.560	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.560	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.561	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.561	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.562	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.562	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.563	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.563	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.564	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.564	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.565	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.565	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.566	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.566	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.567	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.567	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.568	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.568	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.569	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.569	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.570	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.570	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.571	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.571	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.572	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.572	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.573	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.573	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.574	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.574	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.575	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.575	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.576	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.576	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.577	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.577	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.578	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.578	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.579	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.579	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.580	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.580	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.581	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.581	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.582	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.582	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.583	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.583	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.584	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.584	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.585	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.585	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.586	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.586	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.587	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.587	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.588	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.588	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.589	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.589	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.590	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.590	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.591	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.591	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.592	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.592	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.593	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.593	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.594	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.594	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.595	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.595	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.596	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.596	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.597	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.597	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.598	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.598	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.599	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.599	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.600	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.600	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.601	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.601	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.602	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.602	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.603	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.603	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.604	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.604	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.605	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.605	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.606	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.606	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.607	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.607	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.608	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.608	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.609	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.609	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.610	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.610	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.611	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.611	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.612	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.612	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.613	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.613	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.614	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.614	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.615	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.615	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.616	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16016	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.617	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16017	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.618	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16018	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.619	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16019	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.620	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16020	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.621	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16021	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.622	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16022	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.623	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16023	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.624	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16024	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.625	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16025	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.626	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16026	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.627	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16027	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.628	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16028	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.629	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16029	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.630	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16030	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.631	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16031	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.632	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16032	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.633	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16033	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.634	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16034	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.635	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16035	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.636	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16036	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.637	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16037	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.638	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16038	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.639	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16039	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.640	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.16040	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.641	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.641	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.642	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.642	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.643	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.643	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.644	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.644	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.645	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.645	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.646	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.646	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.647	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.647	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.648	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.648	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.649	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.649	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.650	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.650	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.651	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.651	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.652	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.652	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.653	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.653	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.654	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.654	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.655	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.655	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.656	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.656	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.657	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.657	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.658	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.658	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.659	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.659	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.660	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.660	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.661	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.661	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.662	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.662	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.663	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.663	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.664	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.664	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.665	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.665	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.666	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.666	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.667	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.667	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.668	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.668	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.669	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.669	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.670	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.670	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.671	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.671	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.672	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.672	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.673	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.673	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.674	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.674	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.675	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.675	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.676	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.676	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.677	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.677	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.678	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.678	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.679	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.679	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.680	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.680	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.681	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.681	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.682	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.682	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.683	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.683	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.684	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.684	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.685	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.685	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.686	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.686	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.687	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.687	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.688	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.688	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.689	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.689	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.690	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.690	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.691	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.691	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.692	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.692	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.693	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.693	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.694	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.694	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.695	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.695	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.696	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.696	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.697	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.697	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.698	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.698	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.699	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.699	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.700	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.700	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.701	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.701	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.702	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.702	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.703	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.703	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.704	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.704	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.705	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.705	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.706	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.706	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.707	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.707	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.708	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.708	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.709	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.709	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.710	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.710	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.711	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.711	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.712	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.712	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.713	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.713	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.714	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.714	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.715	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.715	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.716	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.716	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.717	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.717	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.718	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.718	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.719	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.719	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.720	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.720	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.721	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.721	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.722	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.722	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.723	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.723	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.724	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.724	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.725	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.725	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.726	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.726	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.727	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.727	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.728	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.728	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.729	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.729	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.730	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.730	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.731	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.731	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.732	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.732	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.733	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.733	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.734	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.734	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.735	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.735	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.736	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.736	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.737	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.737	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.738	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.738	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.739	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.739	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan11311xEnable.1.740	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.740	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.741	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1741	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.742	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1742	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.743	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1743	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.744	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1744	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.745	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1745	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.746	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1746	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.747	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1747	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.748	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1748	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.749	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1749	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.750	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1750	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.751	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1751	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.752	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1752	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.753	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1753	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.754	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1754	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.755	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1755	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.756	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1756	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.757	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1757	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.758	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1758	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.759	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1759	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.760	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1760	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.761	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1761	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.762	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1762	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.763	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1763	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.764	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1764	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.765	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1765	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.766	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.766	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.767	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.767	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.768	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.768	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.769	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.769	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.770	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.770	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.771	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.771	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.772	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.772	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.773	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.773	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.774	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.774	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.775	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.775	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.776	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.776	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.777	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.777	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.778	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.778	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.779	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.779	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.780	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.780	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.781	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.781	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.782	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.782	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.783	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.783	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.784	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.784	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.785	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.785	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.786	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.786	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.787	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.787	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.788	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.788	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.789	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.789	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.790	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.790	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.791	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1791	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.792	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1792	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.793	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1793	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.794	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1794	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.795	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1795	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.796	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1796	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.797	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1797	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.798	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1798	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.799	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1799	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.800	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1800	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.801	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1801	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.802	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1802	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.803	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1803	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.804	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1804	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.805	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1805	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.806	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1806	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.807	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1807	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.808	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1808	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.809	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1809	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.810	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1810	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.811	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1811	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.812	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1812	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.813	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1813	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.814	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1814	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.815	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1815	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.816	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1806	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.817	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1807	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.818	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1808	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.819	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1809	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.820	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1810	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.821	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1811	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.822	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1812	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.823	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1813	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.824	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1814	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.825	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1815	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.826	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1816	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.827	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1817	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.828	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1818	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.829	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1819	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.830	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1820	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.831	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1821	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.832	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1822	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.833	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1823	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.834	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1824	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.835	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1825	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.836	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1826	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.837	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1827	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.838	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1828	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.839	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1829	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.840	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1830	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.841	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1841	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.842	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1842	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.843	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1843	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.844	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1844	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.845	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1845	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.846	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1846	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.847	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1847	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.848	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1848	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.849	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1849	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.850	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1850	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.851	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1851	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.852	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1852	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.853	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1853	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.854	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1854	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.855	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1855	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.856	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1856	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.857	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1857	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.858	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1858	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.859	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1859	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.860	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1860	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.861	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1861	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.862	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1862	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.863	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1863	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.864	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1864	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan113.11xEnable.1.865	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1865	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.866	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1866	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.867	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1867	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.868	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1868	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.869	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1869	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.870	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1870	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.871	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1871	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.872	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1872	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.873	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1873	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.874	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1874	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.875	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1875	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.876	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1876	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.877	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1877	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.878	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1878	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.879	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1879	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.880	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1880	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.881	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1881	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.882	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1882	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.883	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1883	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.884	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1884	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.885	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1885	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.886	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1886	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.887	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1887	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.888	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1888	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.889	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1889	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.890	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1890	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.891	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.891	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.892	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.892	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.893	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.893	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.894	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.894	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.895	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.895	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.896	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.896	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.897	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.897	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.898	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.898	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.899	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.899	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.900	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.900	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.901	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.901	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.902	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.902	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.903	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.903	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.904	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.904	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.905	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.905	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.906	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.906	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.907	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.907	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.908	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.908	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.909	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.909	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.910	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.910	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.911	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.911	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.912	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.912	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.913	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.913	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.914	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.914	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.915	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.915	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.916	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1916	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.917	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1917	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.918	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1918	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.919	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1919	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.920	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1920	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.921	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1921	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.922	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1922	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.923	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1923	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.924	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1924	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.925	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1925	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.926	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1926	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.927	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1927	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.928	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1928	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.929	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1929	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.930	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1930	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.931	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1931	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.932	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1932	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.933	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1933	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.934	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1934	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.935	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1935	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.936	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1936	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.937	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1937	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.938	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1938	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.939	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1939	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.940	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1940	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.941	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.941	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.942	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.942	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.943	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.943	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.944	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.944	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.945	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.945	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.946	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.946	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.947	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.947	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.948	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.948	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.949	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.949	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.950	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.950	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.951	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.951	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.952	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.952	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.953	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.953	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.954	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.954	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.955	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.955	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.956	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.956	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.957	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.957	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.958	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.958	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.959	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.959	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.960	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.960	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.961	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.961	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.962	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.962	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.963	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.963	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.964	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.964	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1131xEnable.1.965	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.965	Integer	false (2)



Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.966	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.966	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.967	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.967	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.968	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.968	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.969	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.969	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.970	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.970	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.971	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.971	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.972	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.972	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.973	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.973	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.974	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.974	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.975	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.975	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.976	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.976	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.977	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.977	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.978	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.978	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.979	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.979	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.980	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.980	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.981	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.981	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.982	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.982	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.983	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.983	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.984	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.984	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.985	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.985	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.986	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.986	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.987	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.987	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.988	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.988	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.989	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.989	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.990	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.990	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.991	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.991	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.992	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.992	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.993	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.993	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.994	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.994	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.995	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.995	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.996	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.996	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.997	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.997	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.998	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.998	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.999	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.999	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.1000	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1000	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.1001	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1001	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.1002	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1002	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.1003	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1003	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.1004	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1004	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.1005	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1005	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.1006	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1006	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.1007	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1007	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.1008	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1008	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.1009	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1009	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.1010	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1010	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.1011	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1011	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.1012	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1012	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.1013	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1013	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.1014	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1014	Integer	false (2)
IldpV2Xdot1ConfigProtoVlan1313xEnable.1.1015	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1015	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1016	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1016	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1017	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1017	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1018	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1018	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1019	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1019	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1020	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1020	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1021	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1021	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1022	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1022	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1023	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1023	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1024	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1024	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1025	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1025	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1026	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1026	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1027	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1027	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1028	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1028	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1029	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1029	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1030	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1030	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1031	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1031	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1032	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1032	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1033	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1033	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1034	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1034	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1035	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1035	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1036	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1036	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1037	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1037	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1038	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1038	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1039	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1039	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1040	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1040	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1041	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1041	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1042	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1042	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1043	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1043	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1044	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1044	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1045	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1045	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1046	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1046	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1047	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1047	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1048	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1048	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1049	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1049	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1050	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1050	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1051	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1051	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1052	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1052	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1053	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1053	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1054	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1054	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1055	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1055	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1056	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1056	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1057	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1057	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1058	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1058	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1059	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1059	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1060	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1060	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1061	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1061	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1062	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1062	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1063	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1063	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1064	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1064	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1065	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1065	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1066	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1066	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1067	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1067	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1068	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1068	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1069	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1069	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1070	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1070	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1071	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1071	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1072	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1072	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1073	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1073	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1074	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1074	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1075	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1075	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1076	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1076	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1077	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1077	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1078	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1078	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1079	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1079	Boolean	false (2)
IldpV2Xdot1ConfigProtoVlan3xEnable.1.1080	1.2.802.1.1.13.1.5.32962.1.1.3.1.1.1.1080	Boolean	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.1.1	1.2.802.1.1.13.1.5.32962.1.1.4.1.1.1.1	Boolean	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.2.1	1.2.802.1.1.13.1.5.32962.1.1.4.1.1.1.2	Boolean	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.3.1	1.2.802.1.1.13.1.5.32962.1.1.4.1.1.1.3	Boolean	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.4.1	1.2.802.1.1.13.1.5.32962.1.1.4.1.1.1.4	Boolean	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.5.1	1.2.802.1.1.13.1.5.32962.1.1.4.1.1.1.5	Boolean	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.6.1	1.2.802.1.1.13.1.5.32962.1.1.4.1.1.1.6	Boolean	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.7.1	1.2.802.1.1.13.1.5.32962.1.1.4.1.1.1.7	Boolean	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.8.1	1.2.802.1.1.13.1.5.32962.1.1.4.1.1.1.8	Boolean	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.9.1	1.2.802.1.1.13.1.5.32962.1.1.4.1.1.1.9	Boolean	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.10.1	1.2.802.1.1.13.1.5.32962.1.1.4.1.1.1.10	Boolean	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtocolTxB.11.nable.11.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.11	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.12.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.12	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.13.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.13	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.14.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.14	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.15.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.15	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.16.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.16	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.17.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.17	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.18.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.18	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.19.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.19	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.20.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.20	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.21.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.21	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.22.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.22	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.23.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.23	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.24.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.24	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.25.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.25	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.26.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.26	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.27.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.27	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.28.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.28	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.29.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.29	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.30.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.30	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.31.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.31	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.32.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.32	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.33.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.33	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.34.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.34	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxB.11.nable.35.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.35	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigProtocolTxEnable.36.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.1.36	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.37.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.1.37	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.38.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.1.38	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.39.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.1.39	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.40.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.1.40	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.41.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.1.41	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.42.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.1.42	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.43.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.1.43	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.44.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.1.44	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.45.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.1.45	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.46.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.1.46	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.47.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.1.47	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.48.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.1.48	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.49.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.1.49	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.50.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.1.50	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.51.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.1.51	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.52.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.1.52	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.53.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.1.53	Integer	false (2)
IldpV2Xdot1ConfigProtocolTxEnable.54.1	11.2.802.1.1.13.1.5.32962.1.1.4.1.1.54	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDigestTxEnable.1	11.2.802.1.1.13.1.5.32962.1.1.5.1.1	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDigestTxEnable.2	11.2.802.1.1.13.1.5.32962.1.1.5.1.2	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDigestTxEnable.3	11.2.802.1.1.13.1.5.32962.1.1.5.1.3	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDigestTxEnable.4	11.2.802.1.1.13.1.5.32962.1.1.5.1.4	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDigestTxEnable.5	11.2.802.1.1.13.1.5.32962.1.1.5.1.5	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDigestTxEnable.6	11.2.802.1.1.13.1.5.32962.1.1.5.1.6	Integer	false (2)





Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1132	11.2.802.1.1.13.1.5.32962.1.1.5.1.1132	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1133	11.2.802.1.1.13.1.5.32962.1.1.5.1.1133	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1134	11.2.802.1.1.13.1.5.32962.1.1.5.1.1134	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1135	11.2.802.1.1.13.1.5.32962.1.1.5.1.1135	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1136	11.2.802.1.1.13.1.5.32962.1.1.5.1.1136	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1137	11.2.802.1.1.13.1.5.32962.1.1.5.1.1137	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1138	11.2.802.1.1.13.1.5.32962.1.1.5.1.1138	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1139	11.2.802.1.1.13.1.5.32962.1.1.5.1.1139	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1140	11.2.802.1.1.13.1.5.32962.1.1.5.1.1140	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1141	11.2.802.1.1.13.1.5.32962.1.1.5.1.1141	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1142	11.2.802.1.1.13.1.5.32962.1.1.5.1.1142	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1143	11.2.802.1.1.13.1.5.32962.1.1.5.1.1143	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1144	11.2.802.1.1.13.1.5.32962.1.1.5.1.1144	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1145	11.2.802.1.1.13.1.5.32962.1.1.5.1.1145	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1146	11.2.802.1.1.13.1.5.32962.1.1.5.1.1146	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1147	11.2.802.1.1.13.1.5.32962.1.1.5.1.1147	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1148	11.2.802.1.1.13.1.5.32962.1.1.5.1.1148	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1149	11.2.802.1.1.13.1.5.32962.1.1.5.1.1149	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1150	11.2.802.1.1.13.1.5.32962.1.1.5.1.1150	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1151	11.2.802.1.1.13.1.5.32962.1.1.5.1.1151	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1152	11.2.802.1.1.13.1.5.32962.1.1.5.1.1152	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1153	11.2.802.1.1.13.1.5.32962.1.1.5.1.1153	Integer	false (2)
IldpV2Xdot1ConfigVidUsageDi-3.1.1.1.2.802.1.1.13.1.5.32962.1.1.5.1.1154	11.2.802.1.1.13.1.5.32962.1.1.5.1.1154	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.1	11.2.802.1.1.13.1.5.32962.1.1.6.1.11	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.2	11.2.802.1.1.13.1.5.32962.1.1.6.1.12	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigManVidTxEnable.3	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.4	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.5	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.6	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.7	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.8	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.9	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.10	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.11	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.12	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.13	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.14	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.15	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.16	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.17	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.18	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.19	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.20	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.21	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.22	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.23	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.24	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.25	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.26	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.27	111.2.802.1.1.13.1.5.32962.1.1.6.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
IldpV2Xdot1ConfigManVidTxEnable.28	11.2.802.1.1.13.1.5.32962.1.1.6.1.1128	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.29	11.2.802.1.1.13.1.5.32962.1.1.6.1.1129	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.30	11.2.802.1.1.13.1.5.32962.1.1.6.1.1130	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.31	11.2.802.1.1.13.1.5.32962.1.1.6.1.1131	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.32	11.2.802.1.1.13.1.5.32962.1.1.6.1.1132	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.33	11.2.802.1.1.13.1.5.32962.1.1.6.1.1133	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.34	11.2.802.1.1.13.1.5.32962.1.1.6.1.1134	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.35	11.2.802.1.1.13.1.5.32962.1.1.6.1.1135	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.36	11.2.802.1.1.13.1.5.32962.1.1.6.1.1136	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.37	11.2.802.1.1.13.1.5.32962.1.1.6.1.1137	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.38	11.2.802.1.1.13.1.5.32962.1.1.6.1.1138	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.39	11.2.802.1.1.13.1.5.32962.1.1.6.1.1139	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.40	11.2.802.1.1.13.1.5.32962.1.1.6.1.1140	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.41	11.2.802.1.1.13.1.5.32962.1.1.6.1.1141	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.42	11.2.802.1.1.13.1.5.32962.1.1.6.1.1142	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.43	11.2.802.1.1.13.1.5.32962.1.1.6.1.1143	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.44	11.2.802.1.1.13.1.5.32962.1.1.6.1.1144	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.45	11.2.802.1.1.13.1.5.32962.1.1.6.1.1145	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.46	11.2.802.1.1.13.1.5.32962.1.1.6.1.1146	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.47	11.2.802.1.1.13.1.5.32962.1.1.6.1.1147	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.48	11.2.802.1.1.13.1.5.32962.1.1.6.1.1148	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.49	11.2.802.1.1.13.1.5.32962.1.1.6.1.1149	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.50	11.2.802.1.1.13.1.5.32962.1.1.6.1.1150	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.51	11.2.802.1.1.13.1.5.32962.1.1.6.1.1151	Integer	false (2)
IldpV2Xdot1ConfigManVidTxEnable.52	11.2.802.1.1.13.1.5.32962.1.1.6.1.1152	Integer	false (2)

Name	OID	Value Type	Value Example
lldpV2Xdot1ConfigManVidTxEnable.53	11.2.802.1.1.13.1.5.32962.1.1.6.1.15	Integer	false (2)
lldpV2Xdot1ConfigManVidTxEnable.54	11.2.802.1.1.13.1.5.32962.1.1.6.1.16	Integer	false (2)
lldpV2Xdot1LocPortVlanId.1	11.2.802.1.1.13.1.5.32962.1.2.1.1	Gauge	1
lldpV2Xdot1LocProtoVlanSupported.1.0	11.2.802.1.1.13.1.5.32962.1.2.2.1.2	Integer	true (1)
lldpV2Xdot1LocProtoVlanEnabled.1.0	11.2.802.1.1.13.1.5.32962.1.2.2.1.3	Integer	false (2)
lldpV2Xdot1LocVlanName.1.1.3.1	11.2.802.1.1.13.1.5.32962.1.2.3.1.2	OctetString	VLAN 0001
lldpV2Xdot1LocManVid.1	11.2.802.1.1.13.1.5.32962.1.2.6.1	Gauge	0
lldpV2Xdot1LocLinkAggStatus.1	11.2.802.1.1.13.1.5.32962.1.2.7.1	OctetString	{aggCapable}
lldpV2Xdot1LocLinkAggPortId.1	11.2.802.1.1.13.1.5.32962.1.2.7.1.2	Gauge	0
lldpV2Xdot1RemPortVlanId.139537.1.1.1	11.2.802.1.1.13.1.5.32962.1.3.1.1.1.139537	Gauge.1	1
lldpV2Xdot1RemLinkAggStatus.139537.1.1.1	11.2.802.1.1.13.1.5.32962.1.3.7.1.1.139537	OctetString	{aggCapable}
lldpV2Xdot1RemLinkAggPortId.139537.1.1.1	11.2.802.1.1.13.1.5.32962.1.3.7.1.2.139537	Gauge.1	0
lldpXdot1dcbxConfigETSCongestionTxEnable.1.1	11.2.802.1.1.13.1.5.32962.5.1.1.1.1	Integer	false (2)
lldpXdot1dcbxConfigETSCongestionTxEnable.2.1	11.2.802.1.1.13.1.5.32962.5.1.1.1.1	Integer	false (2)
lldpXdot1dcbxConfigETSCongestionTxEnable.3.1	11.2.802.1.1.13.1.5.32962.5.1.1.1.1	Integer	false (2)
lldpXdot1dcbxConfigETSCongestionTxEnable.4.1	11.2.802.1.1.13.1.5.32962.5.1.1.1.1	Integer	false (2)
lldpXdot1dcbxConfigETSCongestionTxEnable.5.1	11.2.802.1.1.13.1.5.32962.5.1.1.1.1	Integer	false (2)
lldpXdot1dcbxConfigETSCongestionTxEnable.6.1	11.2.802.1.1.13.1.5.32962.5.1.1.1.1	Integer	false (2)
lldpXdot1dcbxConfigETSCongestionTxEnable.7.1	11.2.802.1.1.13.1.5.32962.5.1.1.1.1	Integer	false (2)
lldpXdot1dcbxConfigETSCongestionTxEnable.8.1	11.2.802.1.1.13.1.5.32962.5.1.1.1.1	Integer	false (2)
lldpXdot1dcbxConfigETSCongestionTxEnable.9.1	11.2.802.1.1.13.1.5.32962.5.1.1.1.1	Integer	false (2)
lldpXdot1dcbxConfigETSCongestionTxEnable.10.1	11.2.802.1.1.13.1.5.32962.5.1.1.1.1	Integer	false (2)
lldpXdot1dcbxConfigETSCongestionTxEnable.11.1	11.2.802.1.1.13.1.5.32962.5.1.1.1.1	Integer	false (2)
lldpXdot1dcbxConfigETSCongestionTxEnable.12.1	11.2.802.1.1.13.1.5.32962.5.1.1.1.1	Integer	false (2)
lldpXdot1dcbxConfigETSCongestionTxEnable.13.1	11.2.802.1.1.13.1.5.32962.5.1.1.1.1	Integer	false (2)
lldpXdot1dcbxConfigETSCongestionTxEnable.14.1	11.2.802.1.1.13.1.5.32962.5.1.1.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
lldpXdot1dcbxConfigETSConfigurationTxEnable.15.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.15	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.16.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.16	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.17.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.17	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.18.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.18	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.19.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.19	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.20.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.20	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.21.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.21	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.22.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.22	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.23.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.23	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.24.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.24	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.25.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.25	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.26.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.26	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.27.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.27	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.28.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.28	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.29.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.29	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.30.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.30	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.31.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.31	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.32.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.32	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.33.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.33	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.34.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.34	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.35.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.35	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.36.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.36	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.37.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.37	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.38.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.38	Integer	false (2)
lldpXdot1dcbxConfigETSConfigurationTxEnable.39.1	1.2.802.1.1.13.1.5.32962.5.1.1.1.1.39	Integer	false (2)







Name	OID	Value Type	Value Example
lldpXdot1dcbxConfigETSRe1.3.111commendationTxEnable.36.1	1.2.802.1.1.13.1.5.32962.5.1.1.2.1.1186	Integer	false (2)
lldpXdot1dcbxConfigETSRe1.3.111commendationTxEnable.37.1	1.2.802.1.1.13.1.5.32962.5.1.1.2.1.1187	Integer	false (2)
lldpXdot1dcbxConfigETSRe1.3.111commendationTxEnable.38.1	1.2.802.1.1.13.1.5.32962.5.1.1.2.1.1188	Integer	false (2)
lldpXdot1dcbxConfigETSRe1.3.111commendationTxEnable.39.1	1.2.802.1.1.13.1.5.32962.5.1.1.2.1.1189	Integer	false (2)
lldpXdot1dcbxConfigETSRe1.3.111commendationTxEnable.40.1	1.2.802.1.1.13.1.5.32962.5.1.1.2.1.1190	Integer	false (2)
lldpXdot1dcbxConfigETSRe1.3.111commendationTxEnable.41.1	1.2.802.1.1.13.1.5.32962.5.1.1.2.1.1191	Integer	false (2)
lldpXdot1dcbxConfigETSRe1.3.111commendationTxEnable.42.1	1.2.802.1.1.13.1.5.32962.5.1.1.2.1.1192	Integer	false (2)
lldpXdot1dcbxConfigETSRe1.3.111commendationTxEnable.43.1	1.2.802.1.1.13.1.5.32962.5.1.1.2.1.1193	Integer	false (2)
lldpXdot1dcbxConfigETSRe1.3.111commendationTxEnable.44.1	1.2.802.1.1.13.1.5.32962.5.1.1.2.1.1194	Integer	false (2)
lldpXdot1dcbxConfigETSRe1.3.111commendationTxEnable.45.1	1.2.802.1.1.13.1.5.32962.5.1.1.2.1.1195	Integer	false (2)
lldpXdot1dcbxConfigETSRe1.3.111commendationTxEnable.46.1	1.2.802.1.1.13.1.5.32962.5.1.1.2.1.1196	Integer	false (2)
lldpXdot1dcbxConfigETSRe1.3.111commendationTxEnable.47.1	1.2.802.1.1.13.1.5.32962.5.1.1.2.1.1197	Integer	false (2)
lldpXdot1dcbxConfigETSRe1.3.111commendationTxEnable.48.1	1.2.802.1.1.13.1.5.32962.5.1.1.2.1.1198	Integer	false (2)
lldpXdot1dcbxConfigETSRe1.3.111commendationTxEnable.49.1	1.2.802.1.1.13.1.5.32962.5.1.1.2.1.1199	Integer	false (2)
lldpXdot1dcbxConfigETSRe1.3.111commendationTxEnable.50.1	1.2.802.1.1.13.1.5.32962.5.1.1.2.1.1200	Integer	false (2)
lldpXdot1dcbxConfigETSRe1.3.111commendationTxEnable.51.1	1.2.802.1.1.13.1.5.32962.5.1.1.2.1.1201	Integer	false (2)
lldpXdot1dcbxConfigETSRe1.3.111commendationTxEnable.52.1	1.2.802.1.1.13.1.5.32962.5.1.1.2.1.1202	Integer	false (2)
lldpXdot1dcbxConfigETSRe1.3.111commendationTxEnable.53.1	1.2.802.1.1.13.1.5.32962.5.1.1.2.1.1203	Integer	false (2)
lldpXdot1dcbxConfigETSRe1.3.111commendationTxEnable.54.1	1.2.802.1.1.13.1.5.32962.5.1.1.2.1.1204	Integer	false (2)
lldpXdot1dcbxConfigPFCTxEEnable.1.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1101	Integer	false (2)
lldpXdot1dcbxConfigPFCTxEEnable.2.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1102	Integer	false (2)
lldpXdot1dcbxConfigPFCTxEEnable.3.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1103	Integer	false (2)
lldpXdot1dcbxConfigPFCTxEEnable.4.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1104	Integer	false (2)
lldpXdot1dcbxConfigPFCTxEEnable.5.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1105	Integer	false (2)
lldpXdot1dcbxConfigPFCTxEEnable.6.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1106	Integer	false (2)

Name	OID	Value Type	Value Example
lldpXdot1dcbxConfigPFCTxFenable.7.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.7	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.8.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.8	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.9.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.9	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.10.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.10	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.11.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.11	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.12.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.12	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.13.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.13	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.14.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.14	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.15.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.15	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.16.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.16	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.17.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.17	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.18.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.18	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.19.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.19	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.20.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.20	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.21.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.21	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.22.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.22	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.23.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.23	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.24.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.24	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.25.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.25	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.26.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.26	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.27.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.27	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.28.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.28	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.29.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.29	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.30.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.30	Integer	false (2)
lldpXdot1dcbxConfigPFCTxFenable.31.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.1.31	Integer	false (2)

Name	OID	Value Type	Value Example
IldpXdot1dcbxConfigPFCTxnable.32.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.118	Integer	false (2)
IldpXdot1dcbxConfigPFCTxnable.33.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.119	Integer	false (2)
IldpXdot1dcbxConfigPFCTxnable.34.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.120	Integer	false (2)
IldpXdot1dcbxConfigPFCTxnable.35.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.121	Integer	false (2)
IldpXdot1dcbxConfigPFCTxnable.36.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.122	Integer	false (2)
IldpXdot1dcbxConfigPFCTxnable.37.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.123	Integer	false (2)
IldpXdot1dcbxConfigPFCTxnable.38.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.124	Integer	false (2)
IldpXdot1dcbxConfigPFCTxnable.39.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.125	Integer	false (2)
IldpXdot1dcbxConfigPFCTxnable.40.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.126	Integer	false (2)
IldpXdot1dcbxConfigPFCTxnable.41.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.127	Integer	false (2)
IldpXdot1dcbxConfigPFCTxnable.42.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.128	Integer	false (2)
IldpXdot1dcbxConfigPFCTxnable.43.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.129	Integer	false (2)
IldpXdot1dcbxConfigPFCTxnable.44.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.130	Integer	false (2)
IldpXdot1dcbxConfigPFCTxnable.45.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.131	Integer	false (2)
IldpXdot1dcbxConfigPFCTxnable.46.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.132	Integer	false (2)
IldpXdot1dcbxConfigPFCTxnable.47.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.133	Integer	false (2)
IldpXdot1dcbxConfigPFCTxnable.48.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.134	Integer	false (2)
IldpXdot1dcbxConfigPFCTxnable.49.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.135	Integer	false (2)
IldpXdot1dcbxConfigPFCTxnable.50.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.136	Integer	false (2)
IldpXdot1dcbxConfigPFCTxnable.51.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.137	Integer	false (2)
IldpXdot1dcbxConfigPFCTxnable.52.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.138	Integer	false (2)
IldpXdot1dcbxConfigPFCTxnable.53.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.139	Integer	false (2)
IldpXdot1dcbxConfigPFCTxnable.54.1	1.2.802.1.1.13.1.5.32962.5.1.1.3.1.140	Integer	false (2)
IldpXdot1dcbxConfigApplicationPriorityTxEnable.1.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.121	Integer	false (2)
IldpXdot1dcbxConfigApplicationPriorityTxEnable.2.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.122	Integer	false (2)

Name	OID	Value Type	Value Example
lldpXdot1dcbxConfigApplicationPriorityTxEnable.3.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.4.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.5.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.6.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.7.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.8.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.9.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.10.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.11.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.12.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.13.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.14.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.15.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.16.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.17.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.18.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.19.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.20.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.21.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.22.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.23.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.24.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.25.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.26.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.27.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1	Integer	false (2)

Name	OID	Value Type	Value Example
lldpXdot1dcbxConfigApplicationPriorityTxEnable.28.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1128	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.29.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1129	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.30.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1130	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.31.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1131	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.32.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1132	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.33.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1133	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.34.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1134	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.35.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1135	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.36.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1136	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.37.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1137	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.38.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1138	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.39.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1139	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.40.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1140	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.41.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1141	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.42.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1142	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.43.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1143	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.44.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1144	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.45.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1145	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.46.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1146	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.47.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1147	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.48.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1148	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.49.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1149	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.50.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1150	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.51.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1151	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.52.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.1152	Integer	false (2)

Name	OID	Value Type	Value Example
lldpXdot1dcbxConfigApplicationPriorityTxEnable.53.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.15	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.54.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.15	Integer	false (2)
lldpXdot1dcbxConfigApplicationPriorityTxEnable.54.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.15	String	
lldpXdot1dcbxConfigApplicationPriorityTxEnable.54.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.15	String	
lldpXdot1dcbxConfigApplicationPriorityTxEnable.54.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.15	String	
lldpXdot1dcbxConfigApplicationPriorityTxEnable.54.1	1.2.802.1.1.13.1.5.32962.5.1.1.4.1.15	String	