

Lista de Compatibilidade - ZPF 11 U

Fabricante	Modelo
HP	Business InkJet 1000
HP	Color Laserjet 1600
HP	Color Laserjet 2500
HP	Color LaserJet 2550
HP	Color LaserJet 2550L/LN
HP	Color LaserJet 2600
HP	Color LaserJet 2605
HP	Color LaserJet 2700n
HP	Color LaserJet 2840
HP	Color LaserJet 3700
HP	Color Laserjet 4650
HP	Color Laserjet CM1312 MFP
HP	Designjet 100
HP	Deskjet 1125C
HP	Deskjet 1180C
HP	DeskJet 1280
HP	Deskjet 3325
HP	DeskJet 3420
HP	Deskjet 3535
HP	Deskjet 3650
HP	Deskjet 3743
HP	Deskjet 3748
HP	Deskjet 3820
HP	DeskJet 3920
HP	DeskJet 3940
HP	Deskjet 450C
HP	DeskJet 5440
HP	Deskjet 5550
HP	Deskjet 5652
HP	Deskjet 810C
HP	Deskjet 830C
HP	Deskjet 845C
HP	DeskJet 9300
HP	Deskjet 948c
HP	Deskjet 9600
HP	Deskjet 9650
HP	Deskjet 970c XI
HP	Deskjet 9800
HP	Deskjet D1560
HP	Deskjet D2560

HP	Deskjet D5560
HP	DeskJet F370
HP	DeskJet F380
HP	DeskJet F4185
HP	DeskJet F4280
HP	Deskjet F4480
HP	Laserjet M1005 MFP
HP	LaserJet 1022
HP	LaserJet 1022N
HP	LaserJet 1160
HP	LaserJet 1200
HP	LaserJet 1220
HP	Laserjet 1300
HP	Laserjet 1320
HP	Laserjet 2200d
HP	Laserjet 2300
HP	LaserJet 2410
HP	LaserJet 2420
HP	LaserJet 2550
HP	LaserJet 3015
HP	LaserJet 3050
HP	LaserJet 3055
HP	Laserjet 3200
HP	Laserjet 3330
HP	LaserJet 3330mfp
HP	LaserJet 3380
HP	LaserJet 4250
HP	Laserjet 4650
HP	Laserjet M1005
HP	Laserjet M1005 MFP
HP	Laserjet M1120 MFP
HP	LaserJet M1319F MFP
HP	LaserJet P2015
HP	Officejet J3608
HP	OfficeJet 4255
HP	OfficeJet 4255
HP	OfficeJet 5610
HP	Officejet J5780
HP	OfficeJet 6210
HP	OfficeJet 6310
HP	Officejet 6000
HP	OfficeJet 7210
HP	OfficeJet J4580
HP	Officejet J6480

HP	Officejet K7100
HP	OfficeJet K850
HP	OfficeJet Pro K5300
HP	OfficeJet Pro K550
HP	Officejet Pro L7380
HP	Officejet Pro L7590
HP	Officejet Pro 8000
HP	Photosmart 2610
HP	Photosmart 3110
HP	Photosmart 7150
HP	Photosmart 7200
HP	Photosmart 7550
HP	Photosmart 7660
HP	Photosmart 7830
HP	Photosmart 7900
HP	Photosmart 8200
HP	Photosmart Plus B209a
HP	Photosmart A520
HP	Photosmart C309a
HP	Photosmart C3180
HP	Photosmart C4180
HP	Photosmart C4280
HP	Photosmart C4385
HP	Photosmart C4480
HP	Photosmart C4580
HP	Photosmart C5180
HP	Photosmart C5280
HP	Photosmart C5380
HP	Photosmart C6180
HP	Photosmart C6280
HP	Photosmart C6380
HP	Photosmart C7180
HP	Photosmart C7280
HP	Photosmart D5160
HP	Photosmart D5360
HP	Photosmart D5460
HP	Photosmart D7160
HP	Photosmart D7260
HP	Photosmart D7360
HP	PSC 1315
HP	PSC 1350
HP	PSC 1410

HP	PSC 1610
HP	PSC 2210
HP	PSC 2310
Epson	Aculaser C1100SE
Epson	AcuLaser C1900
Epson	AcuLaser C3800
Epson	AcuLaser C9100
Epson	Aculaser M2010DN
Epson	Aculaser M2010D
Epson	B-508DN
Epson	C750
Epson	CC-500L
Epson	CL-760
Epson	E-300L
Epson	E-520
Epson	E-720
Epson	EC-01
Epson	EPL 5800
Epson	EPL 5800
Epson	EPL 5900
Epson	EPL 5900
Epson	EPL 6100
Epson	EPL 6200
Epson	EPL 6200
Epson	LP2500
Epson	LP-7700
Epson	LP-8700
Epson	LP-8800C
Epson	LP8900
Epson	LP-9500C
Epson	LQ 2090C
Epson	LQ 300+II
Epson	MC-2000
Epson	PictureMate PM250
Epson	PM-860PT
Epson	PM-890C
Epson	PM-920C
Epson	PM-930C
Epson	PM-950C
Epson	PM-970C
Epson	PM-980C
Epson	PM-A550
Epson	PM-A620
Epson	PM-A650
Epson	PM-A720
Epson	PM-A820
Epson	PM-A840
Epson	PM-A850

Epson	PM-A890
Epson	PM-A900
Epson	PM-A920
Epson	PM-A940
Epson	PM-A950
Epson	PM-A970
Epson	PM-2200C
Epson	PM-3500C
Epson	PM-3700C
Epson	PM-4000PX
Epson	PM-D800
Epson	PM-D870
Epson	PM-D1000
Epson	PM-FA700
Epson	PM-G800
Epson	PM-G820
Epson	PM-G850
Epson	PM-G860
Epson	PM-G4500
Epson	PM-T960
Epson	PM-T990
Epson	PX-5000
Epson	PX-A640
Epson	PX-A740
Epson	PX-G5300
Epson	PX-G5100
Epson	PX-G930
Epson	PX-G5000
Epson	PX-V780
Epson	RX 510
Epson	RX 530
Epson	RX 590
Epson	RX 630
Epson	RX 690
Epson	Stylus C20
Epson	Stylus C40
Epson	Stylus C41UX/SX
Epson	Stylus C43UX
Epson	Stylus C45
Epson	Stylus C59
Epson	Stylus C60
Epson	Stylus C63
Epson	Stylus C67
Epson	Stylus C79
Epson	Stylus C90
Epson	Stylus Color 1160
Epson	Stylus Color 1500
Epson	Stylus Color 1520

Epson	Stylus Color 670
Epson	Stylus Color 810
Epson	Stylus Color 900
Epson	Stylus CX-1500
Epson	Stylus CX-2900
Epson	Stylus CX-3500
Epson	Stylus CX-3700
Epson	Stylus CX-3900
Epson	Stylus CX-4100
Epson	Stylus CX-4700
Epson	Stylus CX-4900
Epson	Stylus CX-5300
Epson	Stylus CX-5500
Epson	Stylus CX-5505
Epson	Stylus CX-5900
Epson	Stylus CX-6900F
Epson	Stylus CX-7300
Epson	Stylus CX-7800
Epson	Stylus CX-8300
Epson	Stylus CX-9300F
Epson	Stylus Office T30
Epson	Stylus Office T40W
Epson	Stylus Office TX300F
Epson	Stylus Office TX510FN
Epson	Stylus Office TX600FW
Epson	Stylus Office TX610FW
Epson	Stylus Office T1100
Epson	Stylus Photo 915
Epson	Stylus Photo 1270
Epson	Stylus Photo 1290
Epson	Stylus Photo 1390
Epson	Stylus Photo 2100
Epson	Stylus Photo 710
Epson	Stylus Photo 720
Epson	Stylus Photo 790
Epson	Stylus Photo 810
Epson	Stylus Photo 830U
Epson	Stylus Photo 900
Epson	Stylus Photo 915
Epson	Stylus Photo EX3
Epson	Stylus Photo R1800
Epson	Stylus Photo R210
Epson	Stylus Photo R230
Epson	Stylus Photo R250
Epson	Stylus Photo R270
Epson	Stylus Photo R310
Epson	Stylus Photo R350
Epson	Stylus Photo R2400

Epson	Stylus Photo R800
Epson	Stylus Photo RX430
Epson	Stylus Photo RX 510
Epson	Stylus Photo RX 530
Epson	Stylus Photo RX 590
Epson	Stylus Photo RX 630
Epson	Stylus Photo RX 650
Epson	Stylus Photo RX 690
Epson	Stylus Photo R2880
Epson	Stylus Photo TX700W
Epson	Stylus Photo TX800FW
Epson	Stylus Pro 7600
Epson	Stylus TX550W
Epson	Stylus TX410
Epson	Stylus TX200
Epson	Stylus TX210
Epson	Stylus TX100
Epson	Stylus TX110
Epson	Stylus T20
Epson	Stylus T21
Epson	Stylus Photo T50
Canon	BJF9000
Canon	D380
Canon	I-255
Canon	I-355
Canon	I-450
Canon	I-455
Canon	I-470D
Canon	I-475D
Canon	I-550
Canon	I-560
Canon	I-850
Canon	I-865
Canon	I-950
Canon	I-6100
Canon	I-6500
Canon	I-9100
Canon	I-9950
Canon	IX4000
Canon	IX5000
Canon	Imageclass D380
Canon	MP-160
Canon	MP-638
Canon	MP 770
Canon	MX318
Canon	MX320
Canon	MX700
Canon	PIXUS IP2500

Canon	PIXUS 990i
Canon	PIXMA iP1000
Canon	PIXMA iP1700
Canon	PIXMA iP1800
Canon	PIXMA Ip1880
Canon	PIXMA Ip2000
Canon	PIXMA iP3000
Canon	PIXMA Ip3300
Canon	PIXMA Ip3500
Canon	PIXMA iP4000
Canon	PIXMA Ip4200
Canon	PIXMA Ip4300
Canon	PIXMA Ip4500
Canon	PIXMA Ip5000
Canon	PIXMA Ip6000
Canon	PIXMA Ip8500
Canon	PIXMA MP110
Canon	PIXMA MP130
Canon	PIXMA MP145
Canon	PIXMA MP150
Canon	PIXMA MP180
Canon	PIXMA MP450
Canon	PIXMA MP730
Canon	PIXMA MP780
Canon	PIXMA MP830
Canon	S-200SPX
Lexmark	E230
Lexmark	E322
Lexmark	P4350
Lexmark	P6250
Lexmark	T420
Lexmark	T620
Lexmark	W812
Lexmark	Z42
Lexmark	Z43
Lexmark	Z45
Lexmark	Z55
Lexmark	Z515
Lexmark	Z615
Lexmark	Z705
FUJI Xerox	DocuPrint 2050
FUJI Xerox	DocuPrint 240A
FUJI Xerox	Docuprint C1110B
FUJI Xerox	Phaser 3310
Konica Minolta	Magicolor 2450
Konica Minolta	Magicolor 5450
Konica Minolta	Magicolor 7300
Konica Minolta	PagePro 9100

Samsung	CLP-500
Samsung	CLP-510
Samsung	CLX2160
Samsung	ML-1510/1710
Samsung	ML-1520
Samsung	ML-1710
Samsung	ML-1750
Samsung	ML-1915
Samsung	ML-2010
Samsung	ML-2250
Samsung	ML-2550
Samsung	SCX-4016
Samsung	SCX-4100/4106/4116/4216F
IBM	Infoprint 1116
IBM	Infoprint 1312
IBM	Infoprint 1316
IBM	Infoprint 1332
IBM	Infoprint 1412
Brother	MFC 4800
Brother	MFC 4800J
Brother	MFC 6800
Brother	MFC 7220
Brother	MFC 7420
Brother	MFC 7820N
Brother	MFC 8840D
Brother	MFC 210C
Brother	MFC 240C
Brother	HL-2170W
Brother	IntelliFax 2820
Others	OKI B4350
Others	BENQ CM3000
Avision	MF 3200
Avision	MF 3230
DOCUJET	1610F
DOCUJET	UA1610
Kyocera	FS-1010
Kyocera	FS-1010KX
Kyocera	FS-1020
Kyocera	FS-1920
Kyocera	FS-2000D
Kyocera	FS-820
Kyocera	FS-920
Kyocera	FS-6020
Kyocera	FS-6026