

## **DEAR USER**

The key system TI 730i was developed for our complete line of PABX such as Modulare i, Conecta, Corp 6000, 8000 and 16000. Although these PABX's offer various features, the TI 730i will automatically configure itself when connected.

Please make sure to explore this manual in full to avoid problems in installing and operating this key system.

Your opinion is valuable to us and therefore we appreciate your comments and observations to assist us in improving the quality of the information contained herein .


Product Manual Development Dept  
document@intelbras.com.br  
Fax: ++ 55 48 32819719

**Version: 0.1/07**

# SAFETY RECOMMENDATIONS

- Avoid placing the key system next to equipment that generate heat, or /and interference ;
- Avoid exposing the key system to direct sunlight or humidity;
- Use only dry clothes to clean your key system.

## Tips on how to install the key system



- Upon connecting the TI 730i to any PABX extension, the key system will automatically configure itself ;
- If you disconnect the TI 730i from an extension, you should cancel the position of the key system as mentioned in this manual.

## Max distance between PABX and TI 730i

Modulare i / Conecta		Corp6000/8000/16000	
No of KS	Mtrs	No of KS	Mtrs
1	140	1	200
2	70	2	100
3	35	3	66

# TECHNICAL CHARACTERISTICS

### Signalling

**Audio:**Call (ring);  
Audio Prompt (beep);

**Visual:**LED's ;  
**Line:**MF.

**Power supply**  
12 Vdc (+10%, -30%).

**Weight**  
Gross : 1,05 Kgs  
Net : 0,855 kgs

**Power Consumption**  
0,73 Watts

**Environmental conditions**  
Temp: 00 degC to 37 degC;  
Humidity : 10% to 90%.

**Dimensions ( mm)**  
Height : 10  
Width : 181  
Depth : 220

# GETTING TO KNOW YOUR TI 730i

## LCD

The message Fig.1 will always appear when the key system is in standby mode:

<i>MM/DD/RR</i>	<i>DAY</i>
<i>HH:MM:SS</i>	<i>ALM</i>

The upper line indicates : day, month, year and week day :

**Sun** - Sunday   **Wed** - Wednesday   **Sat** - Saturday  
**Mon** - Monday   **Thu** - Thursday   **Tues** - Tuesday  
**Fri** - Friday

The lower line indicates : Time, mode of operation, and type of alarm :

**log** – call logging : indicates problems with printer or call logging.

**Cal** – calender alarm : indicates calender reset.

**Mem** – indicates call buffer.

**Blk** – alarm access denied : buffer full and external access through operator.

**Ng**t – nightmode alarm : PABX in nightmode.

### Important !

In case of various alarms being programmed, they will appear in a one second sequence.

# Programmable Keys

The upper pannel of the TI 730i comes with a laber that will allow you to configure the keys and annotate the function of each feature.



Upper Pannel Label

## Navigation keys

The below keys will allow you to navigate through the LCD menu to program the various functions of the TI 730i. During standby these keys can be used to adjust the volume of the Mic or the brightness of the LCD:



move cursor right .



move cursor left.



move cursor up or to previous screen.



move cursor down or to next screen .



Enter in programming mode. ( ENTER )




(EXIT)

Return to previous screen, exit funtion or menu programming.

## Predetermined functions keys

The below keys have predetermined functions :



**SPEAKER** access speaker function, use headset..

**FLASH**

**MUTE** stop voice transmission.

**MAIL** access voice mail.

**DIVERT** access call divert menu .

**DIRECTORY** access phone directory .

**INC. CALLS** indicates unanswered, answered and outgoing calls.

**DELETE** delete cursor field.

**HOLD** hold external call .

**BRK CALL/DND** function broker call and DND configuration.

- Keys for entering and editing text;
- Speed dial;
- dial (telephone).



configuration of some services offered by telecom carriers.



configuration of some services offered by telecom carriers as well as memory of LND and **RECALL** .

## STARTING THE TI 730i

When the key system is connected, the following is displayed : **TI 730i Intelbras Version X.Y.**

The upper pannel LED's will flash sequentially to indicate proper communication between the TI 730i and the PABX.

Finally the LCD displays : **KTS \_ \_ PABX Intelbras.**

## Error Message

Error KTS : **KTS problem.**

Communication error : **Problem with communication.**

KTS capacity exceeded : **Maximum TI 730i capacity reached**

Possible reasons :

- PABX and TI 730i powered on at the same time. Check connection.
- Versions PABX and TI 730i incompatible.
- Interference from equipment or connection problem between TI 730i and PABX.

# TI 730i in standby












05/19/04  
09:37:05


WED

## CONFIGURATING THE TI 730i

### Ringer

Four types of ringer sounds for incoming calls .

Press , use  /  to display **Configurations** , press . navigate with  /  to **Ringer**, press . Select **Ringer type** and press , using  /  make a selection and press .

To skip confirmation press .

### Speed Dial












First, you must associate the keys **0** and **9** with phone directory numbers. Check the item “**Configuring Speed Dial for a phone directory number**”.



With the handset off-hook, Speaker ON, or TI 730i in standby, hold down the desired key (0 to 9) for 2 seconds to display the name or number on the LCD.

### Ringer level

2 levels : **High** or **Low**.

Factory settings : High.

Press , navigate with  /  to **Configurations**, press , use  /  to display **Ringer** , press . Select **Ringer volume** , press , use  /  to select the volume, press .





Use  /  to test the various ringer levels.

**Observation** : The Speaker LED will always flash regardless of the ringer type.

## Handset Volume

Levels : 6.

With the handset off-hook :





Press  /  to access the volume selection option and select the desired level using  / . The TI 730i will automatically return to the previous screen.

Factory settings : **Level 4.**

## Volume of SPEAKER

Levels : 6

With SPEAKER key activated :





Press  /  to access volume selection option, select the desired level using  / . The TI 730i will automatically return to the previous screen.

Factory settings : **Level 4.**

## LCD brightness

Levels : 4.



While in standby :

Press  /  to access brightness selection options, select the appropriate level using  / . The TI 730i will automatically return to the previous screen.

Factory settings : **Level 2.**

## Lock keypad

**Activation :** Press  and .

**Desactivate:** Press  and .

During an incoming call, the keypad is unlocked. Once the call is disconnected the keypad lock is reactivated.

Note : TI 730i must be in standby.

## Audio prompts

*One Beep : PABX sends a message.*

*One beep each second : Handset left off-hook for more than 2 minutes.*

On the display appears : **“Put handset on-hook”**.

Factory settings : – **High**

Two beeps + 1 second pause : Reminder ON





Factory settings : **High**.










*Three beeps : Alarm ON.*

Factory settings : **High**.





**Important :** When the TI 730i is in configuration mode, phone directory or call inquiry and Reminder is OFF, the beeps will be emitted when the TI 730i returns to standby. No beeps will be emitted if the TI 730i is in babyphone mode. Only the key system programmed as **attendant** will receive Alarm beeps.






## Off-hook beeps

Press , use  /  to display **Configurations**, press .

use  or  to access **Beep** , use  /  to access **Handset off-hook**, press . Using  /  select the desired level and press  to confirm.

## Reminder beep volume













Press , use  /  to access **Configurations**, press .

use  /  to access **Beep**, press , use  /  to




select **Reminder** and press . Use / to select the level and press  to confirm.

## Beep volume for alarm ON







Press , use / to display **Configurations**, press . Using / select **Beep**, press , use / to select **Alarm set**, press . With / select the level and confirm.

## Configuring the pannel keys








You can associate a predetermined function with all 25 keys available at the upper panel.

To exit the **MENU**, press  various times or hold it down for 2sec.

## Specific extension

Press , use / to select **Set Panel keys** and press. Using / select the option **As Extension**. to display **select key**. Press the programmable key to display **enter extension** ► \_ \_ \_ \_ enter the extension number, press  to confirm.

## Specific line








Press , use / to display **Set panel keys**, press . Using / select **As line** to display **select key**. Press the key to display **enter line** ► \_ \_ enter line number, press  to confirm.

## Specific group

Press , use / to display **Set panel keys**, press . Using / select **Access Group** to display **select key**. Press the desired to display **enter group** ► \_ \_ enter the group

number and press  to confirm.

## Doorphone 1 or 2


Press , use  /  to display **Set panel keys**, press . Using  /  select **As doorphone 1 (2)** to display **select key**. Press the desired key to display **enter doorphone 1 (2)** and press  to confirm.

## Command 1 or 2








Press , use  /  to display **Set panel keys**, press . Using  /  select **As Command 1 (2)**. and then **select key**. Press the desired key to display **enter Command 1 (2)** and press  to confirm.

**Important** : The feature is not available with Modulare i / Conecta.

## Activating/desactivating Extension Lock








Press , use  /  to display **Set panel keys**, press . Using  /  select **Activate lock** to display **select key**. Press the desired key to display **activate** and press  to confirm.

## Activating/desactivating Pager








Press , use  /  to display **Set panel keys**, press . Using  /  select **Activate pager** to display **select key**. Press the desired key to display **activate** and press  to confirm.

**Important** : The feature is not available with Modulare i / Conecta.








## Boss/Secretary 1 or 2

Press , use  /  to display **Set panel keys**, press . Using  /  select **Activate Boss/Secret 1 (2)** to display **select key**. Press the desired key to display **activate B/S 1 (2)** and press  to confirm.








## Activating/desactivating Babyphone

Press , use  /  to display **Set panel keys**, press . Using  /  select **Activate Babyphone**. to display **select key**. Press the desired key to display **activate Babyphone** and press  to confirm.







## Boss/Secretary 1 or 2 speaker

Press , use  /  to display **Set panel keys**, Press . Using  /  select **Activate speaker B/S 1** to display **select key**. Press the desired key to display **activate speaker** and press  to confirm.







## General Ring

Press , use  /  to display **Set panel keys**, press . Using  /  select **Activate General Ring**. to display **select key**. Press the desired key to display **activate General Ring** and press  to confirm.


## Checking key configuration

Press , use  /  to display **Set panel keys**, press . Using  /  select **show key config**. to display **select key**. Press the desired key to display **press enter to see config**. The display will automatically return to standby.



## Cancel key configuration

Press , use  /  to display **Set panel keys**, press . Using  /  select **Cancel key Configuration** to display **select key**. Press the desired key to display **Cancel Configuration ?** press  to confirm

# USING YOUR TI 730i

The use of the key  could be affected if there is interference next to the equipment.

## Answering calls

Press  to hang up, press  again.

If the PABX is without a caller ID board, the following message appears:

**Answer call via** : \_ \_.

## Unanswered calls

The  LED will flash.

## Making an Intercom

Press the **Extension number** or the key programmed as **Extension**.  
An intercom ring is identified by two medium rings.


Situation with Extensions programmed as direct access key:

**Led ON:** extension busy,

**Led FLASHING:** extension receiving a call ;

**Led OFF:** extension free.

If the extension you are calling is a key system, you can use a message to request a call back by pressing 7;

Program recall, press .

## Calling a group

Press the key programmed as **Group**.

## Calling group Boss-Secretary

See "**Configuring pannel keys**" :

- pressing programmed keys you can automatically dial the extensions;
- pressing programmed keys as Interphone boss-secretary, you can access the extension. The handsfree function of the called party will automatically be activated.

Types of Group :

- one boss and one secretary;
- one boss and two secretaries;
- two bosses and one secretary;
- two bosses and two secretaries.

Check your PABX manual for more details.

## Making external calls

Press  or  (please check the PABX manual) or the key programmed as **Line** or **Route** , wait for dial tone and dial the number.

- Led ON**: line busy;
- Led flashing fast** : line receiving or with parked call;
- Led flashing slowly** : call on hold;
- Led OFF**: line is free.

If you have a blocked line or extension without access category, you receive the following message : **Access denied to this service.** followed by a beep.





If accessing a busy tone, press  RECALL. Your extension rings once the line is free. Check your PABX manual for more details.





## Making external calls through special routes

Press the key programmed as **Route**, wait for dial tone and dial the number. Check "**Configuring the pannel keys**". And your PABX manual on how to program special routes".

## Making external calls using the telephone directory

Press  DIRECTORY to access the phone directory. You can also use the **Menu** :



Press , use  /  to display **tel.directory** , press .


using  /  select **Inquire** and press . select name and number and press  to make a call.

For fast selection, enter the first letter of the name .


To exit menu, keep pressing  until you return to the Calendar display or hold down the key for 2s.

## Calling an external number from the list of calls (outgoing, incoming or unanswered ).

Press  look for **Outgoing calls**, **Received calls** or **Missed calls**. Press  to make a call.



To exit before making the call, press .

## Redial

Press . (max = 20 digits).

## Held calls

Check your PABX manual on how to program the time for held calls .

During a call press  ( the led starts flashiong ). Audio beeps are heard if the held time is over. Put the monophone on-hook ou desactivate Hands-free to terminate the call and attend the held call. If the ongoing call is over and the held call time has not expired, you can capture the call : press 569,  or wait until the call rings again on your key system.


## Transferring calls

Ring type: Short + long.

If you make an inquiry and want to transfer the call, disconnect or desactivate the **SPEAKER** key.

After performing the function, you must put the phone ON-HOOK.

## To an extension

Press  + **Extension number** or the key programmed as **Extension**. If the extension is busy, the calls returns to your extension after 60 Sec. Check your PABX manual for more details".

## To a group

Press the key programmed as **Group**.

## To group Boss-Secretary



Press the key programmed as **Boss-Secretary**.

## To Voice Mail


Requires VOICE MAIL accessory.

Press   
MAIL

## Inquiries

During a call inquiry the second call will be put on-hold. To return to the previous call, press  +  .

## Extension

Press  + **Extension number** or press key programmed as **Extension**.

## Group

Press key programmed as **Group**.

## Group Boss-Secretary

Press key programmed as **Boss-Secretary**.

## Activating external activation during a call

Modulare i

Press key programmed as **Command 1**.

### **CORP line**

External activation 1: press key programmed as **Command 1**.

External activation 2: press key programmed as **Command 2**.

## Pager announcement during a call

(Require pager board Corp 16000).



Press key programmed as **Pager**.

## Recall


This function is useful when trying to access a busy line or an extension that is busy or unavailable. Once the line or extension is available you receive a call ( long + short ring ).

Check the PABX manual on how to program the recall time.

## To External number

Press  +  and wait for confirmation.

## To a busy/unavailable extension

Over the busy tone, press .

## Capture

Note : you cannot capture Alarm calls or recalls.

## Capturing a specific extension


Press key programmed as **Extension**. to capture a call or captuting a held call of a specific extension.



## Capturing from a group

Press key programmed as **Group**.

## Capturing a held call

Press  with the Led ON or press the key corresponding to the line with the held call.

## Capturing a parked call

Press the **LINE** key corresponding to the parked call.

## Conference

Type of conferences :

Between 2 extensions

One extension and one external number

Two external numbers.

( beeps will be heard every 30 seconds )

Note : Operator cannot enter in conference with call in the queue.

## Announcing a message on the paging system

(Require pager board for Corp 16000)

Press **Pager**; now your Ti 730 is connected to the pager system.  
*Check your PABX manual for more details*

## Communicating with the doorphone

### Calling the doorphone

Modulare i/Conecta

Press key programmed as **Doorphone 1**.

CORP line

**Doorphone 1**: press key programmed as **Doorphone 1**.

**Doorphone 2**: press key programmed as **Doorphone 2**.

## Opening the doorlock during a call with the doorphone

Only in following conditions :

- Access category;
- Doorphone Attendant;
- Attend doorphone as broker call;
- Capture doorphone call;
- Receive a call transfer from doorphone.

## Answering the doorphone during an external call

The call is identified by the Led of the key programmed as Doorphone and 4 audible beeps.

Press key programmed as **Doorphone**.

## External activation

This feature allows you to activate external devices such as light, bell, etc.. The extension will receive a busy tone when this feature is activated. Check your PABX manual for more details

### Modulare i/Conecta

Press key programmed as **Command 1**.


### CORP family

**Externa activation 1:** press key programmed as **Command 1**.

**Externa activation 2:** press key programmed as **Command 2**.

Check the item “**External activation time**”. In you PABX manual.

## Accessing your voice messages







Press  and wait for messages.




## Registering calls


- 10 received calls
- 45 missed calls
- 45 outgoing calls

Once the above memory capacity is reached, the last registered call will be deleted and replaced by a new call.






## Checking for registered calls

Press the key , use   to select (**Unanswered, Answered or Outgoing**), press . Use  , to display the numbers.










Using . To display the talk time of the call, press . Press .

To return to previous display. Keep Pressing or hold down  for 2 seconds to return to standby.

## Deleting registered calls






Press , use   to select the type of call and press . Select the call and press .

## Storing calls in the phone directory








Press , use   to select the registered call and press . After selecting the number, press . To alter the number, press   and enter the number (max = 16 digits. ) Check the item **“Storing new name/number in the phone directory”**. Press  to confirm. To cancel, press .

Important : To store the number, you should include the name.








## Clearing registered calls

Press , use   and select **delete calls** and press . When prompted **Delete? ENTER = Yes**. Press  to display **Calls deteled**.








## Dialing registered numbers

Press , use   and select the type of call, press . Using  , you can display the numbers and pressing  to automatically dial the number.

## Defining the types of calls to be registered

Press , use /  to display **Calls** and press . Select the calls to be registered and press . Select the type of calls (internal, external, or both ) and press . To exit press .







## Missed incoming calls

Press , use /  to display **Calls** and press . Using /  select **Register missed calls** and press .

Only one key system can register this type of calls. If trying to program this facility with an existing key system programmed, the following is displayed : **EXTENSION \_\_ PROGRAMMED**.

The registered key system should cancel this feature.

## Altering the key prompt “CALLS”

Press , use /  to display **calls** and press . Using /  select **led missed calls** and press . Select the type: **None, Flashing or ON**.




Factory setting :  flashing.


## Telephone directory

Capacity : 100 names and numbers.

Note : You can still answer an incoming call while using the phone.



## Accessing the tel. directory

Press , use / .











Press to .

You can also use the configuration menu :

Press , use /  to select **tel. directory** and press . Select **inquire** and press .

For fast access just enter the first letter of the storedname and use  .

## Storing a new name/number


Press , use   to display **tel. directory** and press . Use   to select **Insert new number** and press . Enter the new name (max = 16 characters) and press  to enter phone number (max = 20 digits). To alter the name, press . To confirm, press .

Long distance calls :

Complete :

local calls : register prefix 0 + carrier + area code + phone number

International : register prefix 00 + carrier + country code + number) or partial (country code + area code + number).

In the first case, the number is dialed automatically. In the second case, you will be required to enter the carrier code. To exit press . If the number is already stored or the memory is full, you can alter or substitute the register.

## Editing/Entering names


**Example:** 5 jkl:


Press the key J once

Press twice the key J to enter the letter K








Press three times the key to enter the letter L




Press four times the key to enter the digit 5

Use  to move to the next digit.

To switch between Capital and small letters, press  before entering the letter.











## Altering the Name/Number

Press , use   to display **tel. directory** and press . Using   select **inquire** and press  to look for the stored data.








Press . Use the keypad to enter new name. Press  to alter the name. Enter the new number and press .

Note : You can enter the same name but with different phone number.








## Deleting a name/number

Press , use / to display **tel. directory** and press . Using / select **Inquire** and press . Press  and then  to confirm. To exit before confirmation, press .

## Checking telephone directory memory

Press , use / to display **Tel. directory** and press . Using / select **memory status** and press .

## Programming speed dial

Press , use / to display **Tel. directory** and press . Using / select **Speed dial** and press . Using the navigation keys or in alphabetical order, ( A to Z), select the desired stored number and press for 2 sec the keys 0 to 9 to substitute the selected number. This digit will appear to the left of the stored name.

To deactivate speed dial follow the same above steps, press the speed dial digit for 2 seconds to delete it.

## Room Monitoring ( Baby Phone )

Check your PABX manual on how to program this feature.

Press the Extension N° that was programmed as baby phone or press the key programmed as **Room monitoring**.





Note : This feature is not available for the operator and nightmode attendant;

## Call back






You can send a message to an extension requesting a call.

Press + , to display : **call Urgently Extension** : \_ \_ \_ \_ .

## Using a headset

Press , use / to select **Operation with headset** and press . to display **Replace handset with headset.** disconnect the handset and connect the headset.

### To connect the handset again :

Press , use / to select **Operation with headset**, press . To display **already set. cancel?.** Press.  To confirm and to display : **replace headset with handset.**












With the headset, the SPEAKER key will assume the function of the hook.



**Led ON : OFF-HOOK;**

**Led OFF: ON-HOOK.**









## Reminder

You annotate up to 3 reminders with prompts ( text, date, time ).





Press , use  to select **Reminder** and press . Use  or  and select the reminder position and press . Using the keypad, enter the text ( max 16 characters) and press . Enter day, month, time . To delete a reminder, press . Press  to confirm. At the programmed date and time, the TI 730i will emit beeps for 20 seconds and display the text. To interrupt, press . To exit the menu, press .




To deactivate the reminder before being displayed follow the above steps again. Once the reminder is selected, press  and then  to cancel.

### Altering the reminder





Press , use / to select **Reminder** and press . Using / select the reminder and press . Position the cursor on the character and enter the new letter or press .




## Accessing the programmed reminders



Press , use /  to select **Reminder** and press .

Use  or  to display the reminder. To exit menu, press .

## Deleting programmed reminders

Press , use /  to select **Reminder** and press .








Use  or  to display the reminder to delete and press .

To display : **Delete ? enter = yes**. Press  to confirm or  to keep the reminder.




# PROGRAMMING SOME OF THE PABX FACILITIES


## Extension password

Press , use   to select **Extension configuration** and press . Use   select **Password** and press .

### To register a new password

Enter password ( 2 to 4 digits ) in first line and repeating it in second line. press .









### To alter a password

Enter new password in first line and actual password in second line, press .










Note : If you forget your password, please check your PABX manual on how to cancel the extension password.

## Follow me

This feature is programmed from the extension receiving the original call.

Press , use   to display **program extension** and press . Use   select **Follow me** and press . Enter your password and your extension number, and then press .

### To cancel

Press , use   to select **extension configuration** and press . Use   select **Follow me**, press . To display: **already set. cancel ?**. Press  to confirm or  to keep configuration.



## Call Divert


You can program an extension, group, or voice mail to attend your calls.

Press **DIVERT** and use   to display the various options :



**If busy to extension :** Press  and enter the extension number.



Press .



**If busy to group.** Press  and enter group number. Press .

**If busy to VMS.** Press , to display: **"Configuration OK"**.





**If no answer to extension :** Press  to display : **After ( ) rings to extension?** ▶ \_ \_ \_ \_ enter number of rings (3 to 7) and press .

**If no answer to Group.** Press  to display : **After ( ) rings to Group** ▶ \_ \_ \_ \_ enter number of rings (3 to 7) and press .

**If no answer to VMS.** Press  to display : **After ( ) rings to VMS?** ▶ \_ \_ \_ \_ enter number of rings (3 to 7) and press .










**Always divert.** Press  to display **Always divert to extension?** ▶ \_ \_ \_ \_ enter the extension number and press .


## Cancel any type of call divert


Press **DIVERT**, use   to display **Cancel Divert** and press  to display : **already set. cancel ?**. Press  to confirm.


## Extension Barring

### Any call barring

Press , use   to display **extension configuration**, press . Using   select **call barring**, press . Use   again to display the various call barring options:

**IDD.** Press , to block international calls.


**DDD.** Press , to block international and long distance calls.


**Regional.** Press , to block international, long distance and interurban calls.

**Block Total.** Press , to block all outgoing calls

**Cancel call barring.** Press . Followed by . To display: **your password** ► \_ \_ \_ . enter your password and press.

## DND ( do not disturb )

Press  to display : **Extension password**

► \_ \_ \_ . Enter password and press .

### Cancel DND







Press  to display : **Cancel ?**. Press  to confirm.


This function is not available for the extension programmer. During DND mode, the TI 730i maintains the alarm and recall functions. The extension with DND programmed, receives a differentiated dial tone (continuous + beeps at each second ).


## Hotline

**Hotline without delay** : Direct access to line after lifting the handset.








**Hotline with delay** : The TI 730i waits 7 seconds, giving you the option of dialing another number.

Press , use /  to select **Extension configuration** and press. Use / to select **Hotline** and press . Use /  to display options :

**Extension with delay** : Enter destination extension number, press .

**External line with delay** : Enter line number and press .

### To cancel :

Press , use /  to display **Program extension e** press . Using /  select **Hotline** and press  to










display: **Cancel ?**. Press  to confirm.


## Cancel hotline without delay


Only main extension can cancel hotline without delay.


You can program external hotline (with or without delay) through route 0 or special routes. Check the item **External call category through special route** in your PABX manual.


## Alarm

Press , use /  to display **extension configuration**, press . Use /  select **Alarm** and press . Use /  to display the various options :

**One day only** : Enter time and press .

**Everyday** : Enter time and press .









**Periodically** : Enter period and press . The Alarm gets OFF is during preprogrammed periods.

**Weekdays** : Enter period and press .

Weekdays and holidays should be programmed. Check your PABX manual for more information.

**Important:** The PABX calendar should set.




## To cancel the Alarm

Press , use /  to display **Program extension** and press . Using /  select **Alarm** and press . To display: **Cancel ?** . Press .

Note : You can only program one alarm at once.









## Blocking direct incoming calls ( DIC )

Incoming external call to your extension can be routed through DISA or operator.

Press  use  or  to display **Extension configuration**,









press . Use  /  select **Block DIC**, press .



### To cancel:

Press , use  or  to display **Pogram Extension**, press . Use  /  select **Block external call**, press . To display : **already set. cancel ?.**, press .

## Extension Telemarketing

Note : Your extension should process a password.

Press , use  /  to display **Extension configuration**, press . Use  /  to select **Extension Telemarketing**, press  to display **Extension password** ► \_ \_ \_ . Enter password and press .





To cancel repeat the above until the following is displayed : **already set. cancel ?** and press . Enter your extension password and press .




To use the telemarketing function, your extension requires access category programmed ( see call intrusion in PABX manual ). The extension telemarketing does not receive beeps during call intrusion.

## POWER FAILURE





The TI 730i does not function during power loss.




## CHECKING THE SOFTWARE VERSION

Press , use   to select **Check Version**, press .





Use   to select **KS version** and press  to display: **TI 730 i Num: \_ \_ Version: \_ \_**.




## Checking version and revision of PABX software

Press , use   to select **Check Version**, press .

Use   to select **PABX version** and press  to display: **PABX Intelbras Version: \_ \_**.

## LEAVING MESSAGES ON YOUR TI 730i

Press , use   to display **Messages** and press .

Use   to select or cancel the message and press  :

- On holiday
- In a meeting
- Unavailable
- On Leave
- Call to my mobile
- Cancel message.

The extension programmer and attendant cannot be programmed with messages.

## USING DND/BROKER CALL


This key has double functions :


Standby : Uses the DND menu options.

OFF-HOOK : As broker call.

**DND** : block direct incoming calls.

**BRK. Call** : Attend two incoming calls at the same time.

Press  to attend a second call and maintain the first call on hold. Press the key again to switch between calls; to disconnect a call put the phone ON-HOOK and wait for the second call to ring.

**Extension inquiry with broker call.** During an external call you can make an intercom inquiry by pressing  to switch between calls.

# WARRANTY TERMS

To benefit from our warranty terms you should fill out the below form and present it along with the purchase invoice.

Name : \_\_\_\_\_

Purchase date: \_\_\_\_\_

Invoice Nº : \_\_\_\_\_

Model: \_\_\_\_\_

Serial Nº : \_\_\_\_\_

Reseller/Salesman: \_\_\_\_\_

## Dear Customer,

Please read carefully the below terms and conditions of our warranty. Any claim that does not meet with the below conditions will not be covered by our warranty.

1.1. Equipment sold by Intelbras are covered by a one year warranty against any Material flaws or manufacturing defects.

1.2. The warranty shall not cover:

- a) damage of any kind whatsoever the cause of which does not predate the sale;
- b) damage, faults and defects attributable to the customer, accidental damage, improper usage or poor maintenance, failure to comply with the instructions given in the user manual, lightning, humidity, power surges or any *force majeure* whatsoever;
- c) the repair or replacement of loose parts (cords, wires, outlets, antennas, etc.), the replacement of accessory elements that require regular replacement (batteries, paper, ink, etc.) and the supply of cleaning products.
- d) call-out charges and hourly rates.

1.3. The warranty shall not apply if:

- a) the Customer cannot prove the purchase via a bill, receipt or ad hoc certificate provided by the reseller;
- b) The Customer, or a person not designated by Intelbras, changes or repairs the PABX ; it has been paid for in full. Until this is the case, the Customer shall not transfer, alter, give as security or a guarantee, or lend the product in any way whatsoever to a third party, nor shall the latter have any right of ownership thereto. In the event of seizure of or any other claim by a third party with respect to the product, the Customer shall inform Intelbras immediately to enable the latter to safeguard its rights.

1.4. The risks shall transfer to the Customer when the product is delivered. Thereafter, Customer shall be liable for all risk of loss, theft and destruction, in full or in part, of the product.

Intelbras S/A se reserves the right to alter any product characteristics without any prior notice.

**Customer Service Support**  
suporte@intelbras.com.br